



Shenzhen Xtooltech Co., Ltd.

Bugatti Function List V10.30

√ This function is supported. ※ This function may be supported which depends on the actual condition of the vehicle.

× This function is not supported.

As for special function please refer to the special function table.

Control unit	Ecu Info.	Read Codes	Erase Codes	Live data	Freeze Frame	Active Test	Special Function
03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
01-Engine Control Module 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
02-Transmission Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
04-Steering Angle Sender	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
05-Kessy	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
06-Seat Adjustment Passenger	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
07-Display Control Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
09-Central Electrics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
0A-Alternative Fuel Engine	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
0B-Auxiliary Air Heater	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
0C-Rear Axle Steering 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
0D-Sliding Door Left	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
0E-Media Player Position 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
0F-Radio Tuner - Digital	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
10-Parking Assistance 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
11-Engine Control Module 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
12-Clutch Control Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
13-Adaptive Cruise Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
14-Wheel Dampening	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
16-Steering Column	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
18-Auxiliary Parking Heater	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1A-Fuel Cell Engine	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1B-Active Steering	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1C-Vehicle Position Detection	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1D-Driver Identification	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1E-Media Player Position 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1F-Radio Tuner - Satellite	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
20-High Beam Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
21-Battery Energy Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
22-All Wheel Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
23-Brake Boost	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
24-Anti Slip Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
26-Electronic Roof Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
27-Display Control Unit Rear	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
28-Climate Control Unit Rear	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
29-Light Control Left	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2A-Control Unit Wireless	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2B-Steering Column Locking	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2C-Seat Allocation Detection	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2D-Voice Amplifier	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2E-Media Player Position 3	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2F-TV Tuner - Digital	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
30-Special Function 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
31-Engine Electronics Group	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

32-Lock Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
33-All OBD Systems	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
34-Ride Control System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
35-Central Locking Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
36-Seat Adjustment Driver	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
37-Navigation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
38-Roof Electronic Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
39-Light Control Right	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
3A-Special Vehicle Assistant	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
3B-Sensor Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
3C-Lane Change Assistant	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
3D-Special Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
3E-Media Player Position 4	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
3F-Dynamic Assembly Mounting	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
40-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
41-Diesel Pump Control Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
42-Door Electronics Driver	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
43-Brake Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
44-Steering Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
45-Interior Monitoring	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
46-Central Module Comfort	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
47-Sound System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
48-Seat Adjustment Rear	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
49-Automatic Light Switch	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
4A-Rear Light	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
4B-Multifunction Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
4C-Tire Pressure Monitoring 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
4D-Data Transmission	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
4E-Control Head Rear Right	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

4F-Central Electrics 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
50-Seat Adjustment 3rd Row	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
51-Drive Motor Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
52-Door Electronics Passenger	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
53-Parking Brake	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
54-Rear Spoiler	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
55-Headlight Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
56-Radio	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
57-TV Tuner	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
58-Fuel Supply	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
59-Towing Protection	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
5A-Longitudinal Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
5B-Seat Adjustment Rear	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
5C-Lane Departure Warning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
5D-Operation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
5E-Control Head Rear Left	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
5F-Information Control Unit 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
60-Tachograph	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
61-Battery Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
62-Door Electronics Rear Left	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
63-Entry Assistance Driver	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
64-Stabilizers	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
65-Tire Pressure Monitoring 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
66-Seat Adjustment Rear	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
67-Voice Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
68-Wiper Control Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
69-Trailer Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
6B-Aerodynamics Control Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
6C-Camera System Rear View	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

6D-Deck Lid Control Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
6E-Display Control Roof	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
6F-Central Module Comfort	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
71-Battery Charger	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
72-Door Electronics Rear	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
73-Entry Assistance Passenger	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
74-Chassis Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
75-Telematics Communication	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
76-Parking Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
77-Telephone	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
78-Sliding Door Right	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
7B-Subbus Systems Interface	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
7D-Auxiliary Heater	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
7E-Dash Board Display Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
7F-Information Control Unit 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
81-Gear Shift Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
82-Head Up Display	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
83-Front Observation Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
84-Night Vision	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
85-On-Board Camera	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
88-Multi Contour Seat Driver	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
89-Multi Contour Seat	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
8A-Multi Contour Seat Rear	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
8B-Adaptive Cruise Control 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
8C-Battery Energy Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
8D-Multi Contour Seat Rear	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
8E-Image Processing	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
8F-Pretensioner Front Left	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
90-Pretensioner Front Right	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

A4-Armrest	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
A5-Front Sensors Driver	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
A6-Microphone Control Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
A7-Infotainment Interface	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
A8-External Communication	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
A9-Actuator For Structure-	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
AA-Wheel Brake Rear Right	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
AB-Wheel Brake Rear Left	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
AC-Reductant Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
AD-Sensors Brake Systems	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
B7-Access Startsystem	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
B8-Electronic Roof Control 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
B9-Auxiliary Display Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
BA-Assembly Mounting	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
BB-Door Electronics Rear	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
BC-Door Electronics Rear	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
BD-High Voltage Battery	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
BE-Sliding Door Rear Left	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
BF-Sliding Door Rear Right	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
C0-Actuator For Exterior	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
C2-Transmission Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
C3-Drive Motor Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
C4-DC/DC Converter Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
C5-Thermal Management	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
C6-Battery Charger Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
C7-Pedestrian Protection	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
C8-Auxiliary Display Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
C9-Rear Mirror	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
CA-Control Module For Sunroof	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

CB-Rear Axle Steering	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
CC-Starter / Generator	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
CD-Laser Scanner	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
CE-Drive Motor Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
CF-Control Unit Lane Change	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
D0-Front Axle Lift System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
D1-Center Display	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
D4-Roll Control System 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
D5-Roll Control System 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
D6-Light Control Left 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
D7-Light Control Right 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
D8-Matrix Headlamp	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
D9-Matrix Headlamp	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
DB-Front Corner Radar 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
DC-Front Corner Radar 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
DD-Control Module 2 For	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
DE-Charger 1 Mobile Devices	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
DF-Charger 2 Mobile Devices	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

Index	Specil Function Name	Index	Specil Function Name
0001	Coding	0002	Basic Settings
0003	Adaptation	0004	Security Access
0005	AdvancedDataStream	0006	Login CodingII
0007	Advanced ID		