Shenzhen Xtooltech Co., Ltd.

Transporter Function List V18.29

NOTES:

√ This function is supported.

* This function is new added.

Model	Model Series	Control Unit Groups	System Name	Read ECU Informati	Read Trouble Code	Read Event fault	Clear Trouble Code	Live Data	Actuation Test	Special Functions
Sprinter	690.6	Body	AB-Airbag	√	√		√			
Sprinter	690.6	Body	ABW-Airbag with window airbag	√	√		√			
Sprinter	690.6	Body	ARS-All-wheel system	√	√		√	√		
Sprinter	690.6	Body	EDW2-Anti-theft alarm	√	√		√	√		
Sprinter	690.6	Body	HZR-Heating control	√	√		√	√		
Sprinter	690.6	Body	RFH backup assist	√	√		√	√		
Sprinter	690.6	Body	WSP immobilizer	√	√		√	√		
Sprinter	690.6	Body	ZV-Central locking system	√	√		√	√		
Sprinter	690.6	Chassis	ABS-Anti lock braking system	√	√		√	√		
Sprinter	690.6	Chassis	ESP-Electronic stability program	√	√		√	√		
Sprinter	690.6	Drive	CR-Common rail	√	√		√	√		
Sprinter	690.6	Drive	CR-Common rail	√	√		√	√		
Sprinter	690.6	Drive	EGS electronic transmission control	√	√	√	√	√		
Sprinter	690.6	Drive	EWM-Electronic selector lever module	√	√	√	√	√		
Sprinter	690.6	Drive	ME-Motor electronics	√	√		√	√		
Sprinter	690.6	Information and communication	APS-Auto pilot system	√	√		√	√		
Sprinter	690.6	Information and communication	AUDIO/APS-Auto pilot system	√	√		√	√		
Sprinter	690.6	Information and communication	KI-Instrument cluster	√	√	√	√	√		
Sprinter	690.6	Information and communication	Radio (SOUND series)	√	√		√	√		

Sprinter	901.6,902.6,903.6,904.6,905.6	Body	AB-Airbag	√	√		√			
Sprinter	901.6,902.6,903.6,904.6,905.6	Body	ABW-Airbag with window airbag	√	√		√			
Sprinter	901.6,902.6,903.6,904.6,905.6	Body	ARS-All-wheel system	√	√		√	√		
Sprinter	901.6,902.6,903.6,904.6,905.6	Body	EDW2-Anti-theft alarm	√	√		√	√		
Sprinter	901.6,902.6,903.6,904.6,905.6	Body	HZR-Heating control	√	√		√	√		
Sprinter	901.6,902.6,903.6,904.6,905.6	Body	RFH backup assist	√	√		√	√		
Sprinter	901.6,902.6,903.6,904.6,905.6	Body	WSP immobilizer	√	√		√	√		
Sprinter	901.6,902.6,903.6,904.6,905.6	Body	ZV-Central locking system	√	√		√	√		
Sprinter	901.6,902.6,903.6,904.6,905.6	Chassis	ABS-Anti lock braking system	√	√		√	√		
Sprinter	901.6,902.6,903.6,904.6,905.6	Chassis	ESP-Electronic stability program	√	√		√	√		
Sprinter	901.6,902.6,903.6,904.6,905.6	Drive	CR-Common rail	√	√		√	√		
Sprinter	901.6,902.6,903.6,904.6,905.6	Drive	CR-Common rail	√	√		√	√		
Sprinter	901.6,902.6,903.6,904.6,905.6	Drive	EGS electronic transmission control	√	√	√	√	√		

Sprinter	901.6,902.6,903.6,904.6,905.6	Drive	EWM-Electronic selector lever module	√	√	√	√	√		
Sprinter	901.6,902.6,903.6,904.6,905.6	Drive	ME-Motor electronics	√	√		√	√		
Sprinter	901.6,902.6,903.6,904.6,905.6	Information and communication	APS-Auto pilot system	√	√		√	√		
Sprinter	901.6,902.6,903.6,904.6,905.6	Information and communication	AUDIO/APS-Auto pilot system	√	√		√	√		
Sprinter	901.6,902.6,903.6,904.6,905.6	Information and communication	KI-Instrument cluster	√	√	√	√	√		SP0023,SP0024
Sprinter	901.6,902.6,903.6,904.6,905.6	Information and communication	Radio (SOUND series)	√	√		√	√		
Sprinter	906	Air conditioning	KLA-Automatic air conditioning	√	√		√	√		SP0016,SP0017,
Sprinter	906	Air conditioning	PTC-Heater booster	√	√	√	√	√		
Sprinter	906	Air conditioning	ZHE-Auxiliary heater	√	√	√	√	√		
Sprinter	906	Air conditioning	ZHZ-Heater booster	√	√	√	√	√		
Sprinter	906	Body	AAG-Trailer connection unit	√	√	√	√	√		
Sprinter	906	Body	ALWR-Headlamp range adjustment	√	√	√	√	√	√	SP0001,
Sprinter	906	Body	DBE-Overhead control panel	√	√	√	√	√	√	
Sprinter	906	Body	EZS-Electronic ignition switch	√	√	√	√	√		
Sprinter	906	Body	EZS-Electronic ignition switch	√	√	√	√	√		
Sprinter	906	Body	EZS-Electronic ignition switch	√	√	√	√	√		
Sprinter	906	Body	KE-Keyless Entry	√	√	√	√	√		
Sprinter	906	Body	MRM-Steering column module	√	√	√	√	√	√	
Sprinter	906	Body	OBF-Upper control panel	√	√	√	√	√		
Sprinter	906	Body	OBF2-Upper control panel	√	√	√	√	√		
Sprinter	906	Body	SAM-Signal acquisition and actuation	√	√	√	√	√		
Sprinter	906	Body	SRS-Supplemental restraint system(LowLine)As of production month 12/2011	√	√		√	√		
Sprinter	906	Body	SRS-supplemental restraint system	√	√	√	√	√		
Sprinter	906	Chassis	ENR-Electronic rear axle level control	√	√	√	√	√		SP0012,SP0013,

Sprinter	906	Chassis	ESP-Electronic stability program	√	√	√	√	√		SP0014,
Sprinter	906	Chassis	ESP9-Electronic stability program	√	√	√	√	√		
Sprinter	906	Chassis	RDK Tire pressure monitor(As of model year 2011)	√	√	√	√			
Sprinter	906	Chassis	RDK Tire pressure monitor(Up to model year 2010)	√	√	√	√			
Sprinter	906	Drive	CDI3-Common Rail Diesel Injection	√	√	√	√	√		
Sprinter	906	Drive	CDI4-Common Rail Diesel Injection	√	√	√	√	√		
Sprinter	906	Drive	CDI4-Common Rail Diesel Injection	√	√	√	√	√		
Sprinter	906	Drive	CDI6-Common Rail Diesel Injection	√	√	√	√	√		
Sprinter	906	Drive	CDI60-Common Rail Diesel Injection(OM642 EPA13)	√	√	√	√			
Sprinter	906	Drive	CDID2-Common Rail Diesel Injection	√	√	√	√	√		
Sprinter	906	Drive	EGS Electronic transmission control	√	√	√	√	√		SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0008, SP0009, SP0010, SP001
Sprinter	906	Drive	EGS Electronic transmission control	√	√		√	√		SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0008, SP0009, SP0010, SP001
Sprinter	906	Drive	EWM-Electronic selector lever module	√	√	√	√	√		
Sprinter	906	Drive	FSCU-Fuel pump	√	√	√	√	√		
Sprinter	906	Drive	ME 97-Motor electronics 9.7	√	√	√	√	√		
Sprinter	906	Drive	ME-SFI-Motor electronics	√	√	√	√	√		SP0018, SP0019, SP0020, SP0021, SP0022
Sprinter	906	Drive	NGT-Natural Gas Technology	√				√		
Sprinter	906	Drive	SCR-Selective Catalytic Reduction	√	√		√	√		
Sprinter	906	Drive	VG-Transfer case	√	√	√	√			
Sprinter	906	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio	√	√	√	√	√		
Sprinter	906	Information and communication	CDW-CD changer	√	√	√	√	√		
Sprinter	906	Information and communication	COMAND or AUDIO	√	√		√			
Sprinter	906	Information and communication	FSE Hands-free system (Bluetooth)	√	√		√	√		
Sprinter	906	Information and communication	KI-Instrument cluster	√	√		√	√		

Sprinter	906	Information and communication	MTCO-Modular tachograph	√	√	√	√			
Sprinter	906	Information and communication	NAVI-Navigation system (COMAND,SOUND 50)	√	√	√	√	√		
Sprinter	906	Information and communication	PTS-Parktronic system	√	√	√	√	√	√	
Sprinter	906	Information and communication	RADIO Sound 20	√	√	√	√			
Sprinter	906	Information and communication	RADIO Sound 5	√	√	√	√			
Sprinter	906	Information and communication	SOUND 5NG	√	√	√	√	√		
Sprinter	906	Information and communication	TEL-Telephone control unit	√	√	√	√	√		
Sprinter	906	LIN Bus	PSM-Parameterizable Special Module	√	√	√	√	√		
Sprinter	906	Seats and DoorS	STL-Left electric sliding door	√	√	√	√	√		
Sprinter	906	Seats and DoorS	STR-Right electric sliding door	√	√	√	√	√		
Sprinter	906	Seats and DoorS	TSG-Door control module front driver side	√	√	√	√	√		
Sprinter	YD...,WD...,XD...	Body	AB-Airbag	√	√		√			
Sprinter	YD...,WD...,XD...	Body	ABW-Airbag with window airbag	√	√		√			
Sprinter	YD...,WD...,XD...	Body	ARS-All-wheel system	√	√		√	√		
Sprinter	YD...,WD...,XD...	Body	EDW2-Anti-theft alarm	√	√		√	√		
Sprinter	YD...,WD...,XD...	Body	HZR-Heating control	√	√		√	√		
Sprinter	YD...,WD...,XD...	Body	RFH backup assist	√	√		√	√		
Sprinter	YD...,WD...,XD...	Body	WSP immobilizer	√	√		√	√		
Sprinter	YD...,WD...,XD...	Body	ZV-Central locking system	√	√		√	√		
Sprinter	YD...,WD...,XD...	Chassis	ABS-Anti lock braking system	√	√		√	√		
Sprinter	YD...,WD...,XD...	Chassis	ESP-Electronic stability program	√	√		√	√		
Sprinter	YD...,WD...,XD...	Drive	CR-Common rail	√	√		√	√		

XTOOL

Sprinter	YD...,WD...,XD...	Drive	CR-Common rail	√	√		√	√		
Sprinter	YD...,WD...,XD...	Drive	EGS electronic transmission control	√	√	√	√	√		
Sprinter	YD...,WD...,XD...	Drive	EWM-Electronic selector lever module	√	√	√	√	√		
Sprinter	YD...,WD...,XD...	Drive	ME-Motor electronics	√	√		√	√		
Sprinter	YD...,WD...,XD...	Information and communication	APS-Auto pilot system	√	√		√	√		
Sprinter	YD...,WD...,XD...	Information and communication	AUDIO/APS-Auto pilot system	√	√		√	√		
Sprinter	YD...,WD...,XD...	Information and communication	KI-Instrument cluster	√	√	√	√	√		
Sprinter	YD...,WD...,XD...	Information and communication	Radio (SOUND series)	√	√		√	√		
VANEO	414	Air conditioning	HEAT/TAC-Automatic temperature control	√	√		√	√		
VANEO	414	Body	ABW-Airbag with window airbag	√	√		√			
VANEO	414	Body	ATA-Anti-theft alarm system	√	√		√	√		
VANEO	414	Body	DAS-Drive authorization system	√	√		√			
VANEO	414	Chassis	ESP-Electronic stability program	√	√		√	√		
VANEO	414	Drive	ACS-Automatic clutch system	√	√		√			
VANEO	414	Drive	CDI-Common Rail Diesel Injection	√	√		√	√		
VANEO	414	Drive	ECM-Engine control monolith	√	√		√	√		
VANEO	414	Drive	ESM-Electronic selector module	√	√		√	√		
VANEO	414	Drive	FTC-Front transmission control	√	√		√			
VANEO	414	Drive	FTC-Front transmission control	√	√		√	√		
VANEO	414	Information and communication	AUDIO/APS-Auto pilot system	√	√		√	√		
VANEO	414	Information and communication	CDC-CD changer	√	√		√			
VANEO	414	Information and communication	COMAND	√	√		√	√		
VANEO	414	Information and communication	CTEL-Cellular telephone 1 (fixed installation or portable)(D2B)	√	√		√	√		
VANEO	414	Information and communication	IC-Instrument cluster	√	√		√	√		
VANEO	414	Information and communication	PTS-Parktronic system	√	√		√	√		

VANEO	414	Information and communication	Radio (SOUND series)	√	√		√	√		
VANEO	414	Information and communication	UHI-Cellular telephone (fixed installation or portable)(D2B)	√	√		√	√		
VANEO	414	Seats and DoorS	CL-Central locking control unit	√	√		√	√		
VITO/VIANO	636	Air conditioning	AAC-Automatic air conditioning	√	√		√	√		
VITO/VIANO	636	Air conditioning	PTC-Heater booster	√	√	√	√	√		
VITO/VIANO	636	Air conditioning	PTC-Heater booster	√	√	√	√	√		
VITO/VIANO	636	Air conditioning	REAR AC-Rear air conditioning	√	√	√	√	√		
VITO/VIANO	636	Air conditioning	STH-Stationary heater	√	√	√	√	√		
VITO/VIANO	636	Body	AAG-Trailer connection unit	√	√	√	√	√		
VITO/VIANO	636	Body	ALWR-Headlamp range adjustment	√	√	√	√	√	√	SP0001,
VITO/VIANO	636	Body	EZS-Electronic ignition switch	√	√	√	√	√		
VITO/VIANO	636	Body	OBF2-Upper control panel	√	√	√	√	√		
VITO/VIANO	636	Body	OCP-Overhead control panel	√	√		√	√		
VITO/VIANO	636	Body	SAM-Signal acquisition and actuation	√	√		√	√		
VITO/VIANO	636	Body	SAM-Signal acquisition and actuation	√	√		√	√		
VITO/VIANO	636	Body	SDE-H-Rear sliding roof unit	√	√		√	√		
VITO/VIANO	636	Body	SRS-supplemental restraint system	√	√		√	√		
VITO/VIANO	636	Body	SRS-supplemental restraint system	√	√		√	√		
VITO/VIANO	636	Body	UCP-Upper control panel	√	√		√	√		
VITO/VIANO	636	Chassis	ENR-Electronic rear axle level control	√	√		√	√		
VITO/VIANO	636	Chassis	ESP-Electronic stability program	√	√	√	√	√		
VITO/VIANO	636	Chassis	TPC-Tire pressure monitor	√	√	√	√	√		
VITO/VIANO	636	Drive	CDI-Common Rail Diesel Injection	√	√	√	√			
VITO/VIANO	636	Drive	CDI4-Common Rail Diesel Injection	√	√	√	√	√		
VITO/VIANO	636	Drive	CDI6-Common Rail Diesel Injection	√	√	√	√	√		
VITO/VIANO	636	Drive	CDID2-Common Rail Diesel Injection	√	√	√	√	√		
VITO/VIANO	636	Drive	EGS Electronic transmission control	√	√	√	√	√		SP0002, SP0003, SP0004, SP0005, SP0006, SP0007, SP0008, SP0009, SP0010, SP001
VITO/VIANO	636	Drive	EGS electronic transmission control	√	√	√	√	√		
VITO/VIANO	636	Drive	ESM-Electronic selector module	√	√		√	√		
VITO/VIANO	636	Drive	FSCU-Fuel pump	√	√	√	√	√		
VITO/VIANO	636	Drive	ME 97-Motor electronics 9.7	√	√	√	√	√		
VITO/VIANO	636	Drive	ME-SFI 2.8-Motor electronics 2.8	√	√		√	√		

VITO/VIANO	636	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio	√	√	√	√	√		
VITO/VIANO	636	Information and communication	AVN-Headlamp range adjustmen	√	√		√	√		
VITO/VIANO	636	Information and communication	CDW-CD changer	√	√	√	√	√		
VITO/VIANO	636	Information and communication	COMAND or AUDIO	√	√		√			
VITO/VIANO	636	Information and communication	DTCO-Digital tachograph	√	√		√			
VITO/VIANO	636	Information and communication	FSE Hands-free system (Bluetooth)	√	√		√	√		
VITO/VIANO	636	Information and communication	IC-Instrument cluster	√	√		√	√		
VITO/VIANO	636	Information and communication	NAVI-Navigation system (COMAND,SOUND 50)	√	√	√	√	√		
VITO/VIANO	636	Information and communication	PTS-Parktronic system	√	√	√	√	√		
VITO/VIANO	636	Information and communication	RADIO Sound 20	√	√	√	√			
VITO/VIANO	636	Information and communication	RADIO Sound 5	√	√	√	√			
VITO/VIANO	636	Information and communication	SOUND 5NG	√	√	√	√	√		
VITO/VIANO	636	Information and communication	TEL-Telephone control unit	√	√	√	√	√		
VITO/VIANO	636	LIN Bus	PSM-Parameterizable Special Module	√	√	√	√	√		
VITO/VIANO	636	Seats and DoorS	DCM-FL-Door control module front left	√	√		√	√		
VITO/VIANO	636	Seats and DoorS	DCM-FR-Door control module front right	√	√		√	√		
VITO/VIANO	636	Seats and DoorS	ESA driver-Electric seat adjustment driver (with memory)	√	√		√	√		
VITO/VIANO	636	Seats and DoorS	ESA passenger-Electric seat adjustment front passenger (with memory)	√	√		√	√		
VITO/VIANO	636	Seats and DoorS	STE-L-ESD [STE] Left electric sliding	√	√		√	√		
VITO/VIANO	636	Seats and DoorS	STE-R-ESD [STE] Right electric sliding	√	√		√	√		
VITO/VIANO	639(2004-2007)		ETC-Electronic transmission control	√	√		√	√		
VITO/VIANO	639(2004-2007)	Air conditioning	AAC-Automatic air conditioning	√	√		√	√		

VITO/VIANO	639(2004-2007)	Air conditioning	PTC-Heater booster	√	√	√	√	√		
VITO/VIANO	639(2004-2007)	Air conditioning	PTC-Heater booster	√	√	√	√	√		
VITO/VIANO	639(2004-2007)	Air conditioning	REAR AC-Rear air conditioning	√	√	√	√	√		
VITO/VIANO	639(2004-2007)	Air conditioning	STH-Stationary heater	√	√	√	√	√		
VITO/VIANO	639(2004-2007)	Body	AAG-Trailer connection unit	√	√	√	√	√		
VITO/VIANO	639(2004-2007)	Body	AHE-Trailer recognition	√	√		√	√		
VITO/VIANO	639(2004-2007)	Body	CGW-Central gateway	√	√	√	√			
VITO/VIANO	639(2004-2007)	Body	EZS-Electronic ignition switch	√	√	√	√	√		
VITO/VIANO	639(2004-2007)	Body	OCP-Overhead control panel	√	√		√	√		
VITO/VIANO	639(2004-2007)	Body	SAM-Signal acquisition and actuation module	√	√		√	√		
VITO/VIANO	639(2004-2007)	Body	SDE-H-Rear sliding roof unit	√	√		√	√		
VITO/VIANO	639(2004-2007)	Body	SRS-supplemental restraint system	√	√		√	√		
VITO/VIANO	639(2004-2007)	Body	SRS-supplemental restraint system	√	√		√	√		
VITO/VIANO	639(2004-2007)	Body	UCP-Upper control panel	√	√		√	√		
VITO/VIANO	639(2004-2007)	Chassis	ENR-Electronic rear axle level control	√	√		√	√		
VITO/VIANO	639(2004-2007)	Chassis	ESP-Electronic stability program	√	√		√	√		
VITO/VIANO	639(2004-2007)	Chassis	ESP-Electronic stability program	√	√	√	√	√		
VITO/VIANO	639(2004-2007)	Chassis	TPC-Tire pressure monitor	√	√	√	√	√		

VITO/VIANO	639(2004-2007)	Drive	CDI-Common Rail Diesel Injection	√	√	√	√			
VITO/VIANO	639(2004-2007)	Drive	CDI-Common Rail Diesel Injection	√	√	√	√			
VITO/VIANO	639(2004-2007)	Drive	CDI4-Common Rail Diesel Injection	√	√	√	√	√		
VITO/VIANO	639(2004-2007)	Drive	CDI4-Common Rail Diesel Injection	√	√	√	√			
VITO/VIANO	639(2004-2007)	Drive	EGS Electronic transmission control	√	√	√	√	√		SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0008,SP0009,SP0010,SP001
VITO/VIANO	639(2004-2007)	Drive	EGS electronic transmission control	√	√	√	√	√		
VITO/VIANO	639(2004-2007)	Drive	ESM-Electronic selector module	√	√		√	√		
VITO/VIANO	639(2004-2007)	Drive	ME-SFI 2.8-Motor electronics 2.8	√	√		√	√		
VITO/VIANO	639(2004-2007)	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio	√	√	√	√	√		
VITO/VIANO	639(2004-2007)	Information and communication	AUDIO/APS-Auto pilot system	√	√		√	√		
VITO/VIANO	639(2004-2007)	Information and communication	AVN-Headlamp range adjustmen	√	√		√	√		
VITO/VIANO	639(2004-2007)	Information and communication	CDC-CD changer	√	√		√			
VITO/VIANO	639(2004-2007)	Information and communication	CDW-CD changer	√	√	√	√	√		
VITO/VIANO	639(2004-2007)	Information and communication	COMAND	√	√		√	√		
VITO/VIANO	639(2004-2007)	Information and communication	CTEL-Cellular telephone 1 (fixed installation or portable)(D2B)	√	√		√	√		
VITO/VIANO	639(2004-2007)	Information and communication	HRA-Headlamp range adjustment	√	√	√	√			
VITO/VIANO	639(2004-2007)	Information and communication	IC-Instrument cluster	√	√		√	√		SP0015,

VITO/VIANO	639(2004-2007)	Information and communication	IC-Instrument cluster	√	√		√	√		SP0015,
VITO/VIANO	639(2004-2007)	Information and communication	NAVI-Navigation system (COMAND,SOUND 50)	√	√	√	√	√		
VITO/VIANO	639(2004-2007)	Information and communication	PTS-Parktronic system	√	√	√	√	√		
VITO/VIANO	639(2004-2007)	Information and communication	RADIO Sound 20	√	√	√	√			
VITO/VIANO	639(2004-2007)	Information and communication	RADIO Sound 5	√	√	√	√			
VITO/VIANO	639(2004-2007)	Information and communication	Radio (SOUND series)	√	√		√	√		
VITO/VIANO	639(2004-2007)	Information and communication	SOUND 5NG	√	√	√	√	√		
VITO/VIANO	639(2004-2007)	Information and communication	TEL-Telephone control unit	√	√	√	√	√		
VITO/VIANO	639(2004-2007)	Information and communication	TV-TV tuner	√	√		√	√		
VITO/VIANO	639(2004-2007)	Information and communication	UHI-Cellular telephone (fixed installation or portable)(D2B)	√	√		√	√		
VITO/VIANO	639(2004-2007)	Information and communication	VCS-Voice control system	√	√		√	√		
VITO/VIANO	639(2004-2007)	LIN Bus	PSM-Parameterizable Special Module	√	√	√	√			
VITO/VIANO	639(2004-2007)	LIN Bus	PSM-Parameterizable Special Module	√	√	√	√	√		
VITO/VIANO	639(2004-2007)	Seats and DoorS	DCM-FL-Door control module front left	√	√		√	√		
VITO/VIANO	639(2004-2007)	Seats and DoorS	DCM-FR-Door control module front right	√	√		√	√		
VITO/VIANO	639(2004-2007)	Seats and DoorS	ESA driver-Electric seat adjustment driver (with memory)	√	√		√	√		
VITO/VIANO	639(2004-2007)	Seats and DoorS	ESA passenger-Electric seat adjustment front passenger (with memory)	√	√		√	√		
VITO/VIANO	639(2004-2007)	Seats and DoorS	STE-L-ESD [STE] Left electric sliding door	√	√		√	√		

VITO/VIANO	639(2004-2007)	Seats and DoorS	STE-R-ESD [STE] Right electric sliding door	√	√		√	√		
VITO/VIANO	639(2008-)	Air conditioning	AAC-Automatic air conditioning	√	√		√	√		
VITO/VIANO	639(2008-)	Air conditioning	PTC-Heater booster	√	√	√	√	√		
VITO/VIANO	639(2008-)	Air conditioning	PTC-Heater booster	√	√	√	√	√		
VITO/VIANO	639(2008-)	Air conditioning	REAR AC-Rear air conditioning	√	√	√	√	√		
VITO/VIANO	639(2008-)	Air conditioning	STH-Stationary heater	√	√	√	√	√		
VITO/VIANO	639(2008-)	Body	AAG-Trailer connection unit	√	√	√	√	√		
VITO/VIANO	639(2008-)	Body	ALWR-Headlamp range adjustment	√	√	√	√	√	√	SP0001,
VITO/VIANO	639(2008-)	Body	EZS-Electronic ignition switch	√	√	√	√	√		
VITO/VIANO	639(2008-)	Body	OBF2-Upper control panel	√	√	√	√	√		
VITO/VIANO	639(2008-)	Body	OCP-Overhead control panel	√	√		√	√		
VITO/VIANO	639(2008-)	Body	SAM-Signal acquisition and actuation	√	√		√	√		
VITO/VIANO	639(2008-)	Body	SAM-Signal acquisition and actuation	√	√		√	√		
VITO/VIANO	639(2008-)	Body	SDE-H-Rear sliding roof unit	√	√		√	√		
VITO/VIANO	639(2008-)	Body	SRS-supplemental restraint system	√	√		√	√		
VITO/VIANO	639(2008-)	Body	SRS-supplemental restraint system	√	√		√	√		
VITO/VIANO	639(2008-)	Body	UCP-Upper control panel	√	√		√	√		
VITO/VIANO	639(2008-)	Chassis	ENR-Electronic rear axle level control	√	√		√	√		
VITO/VIANO	639(2008-)	Chassis	ESP-Electronic stability program	√	√	√	√	√		
VITO/VIANO	639(2008-)	Chassis	TPC-Tire pressure monitor	√	√	√	√	√		
VITO/VIANO	639(2008-)	Drive	CDI-Common Rail Diesel Injection	√	√	√	√			
VITO/VIANO	639(2008-)	Drive	CDI4-Common Rail Diesel Injection	√	√	√	√	√		
VITO/VIANO	639(2008-)	Drive	CDI6-Common Rail Diesel Injection	√	√	√	√	√		
VITO/VIANO	639(2008-)	Drive	CDID2-Common Rail Diesel Injection	√	√	√	√	√		
VITO/VIANO	639(2008-)	Drive	EGS Electronic transmission control	√	√	√	√	√		SP0002,SP0003,SP0004,SP0005,SP0006,SP0007,SP0008,SP0009,SP0010,SP001

VITO/VIANO	639(2008-)	Drive	EGS electronic transmission control	√	√	√	√	√		
VITO/VIANO	639(2008-)	Drive	ESM-Electronic selector module	√	√		√	√		
VITO/VIANO	639(2008-)	Drive	FSCU-Fuel pump	√	√	√	√	√		
VITO/VIANO	639(2008-)	Drive	ME 97-Motor electronics 9.7	√	√	√	√	√		
VITO/VIANO	639(2008-)	Drive	ME-SFI 2.8-Motor electronics 2.8	√	√		√	√		
VITO/VIANO	639(2008-)	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio	√	√	√	√	√		
VITO/VIANO	639(2008-)	Information and communication	AVN-Headlamp range adjustmen	√	√		√	√		
VITO/VIANO	639(2008-)	Information and communication	CDW-CD changer	√	√	√	√	√		
VITO/VIANO	639(2008-)	Information and communication	COMAND or AUDIO	√	√		√			
VITO/VIANO	639(2008-)	Information and communication	DTCO-Digital tachograph	√	√		√			
VITO/VIANO	639(2008-)	Information and communication	FSE Hands-free system (Bluetooth)	√	√		√	√		
VITO/VIANO	639(2008-)	Information and communication	IC-Instrument cluster	√	√		√	√		
VITO/VIANO	639(2008-)	Information and communication	NAVI-Navigation system (COMAND,SOUND 50)	√	√	√	√	√		
VITO/VIANO	639(2008-)	Information and communication	PTS-Parktronic system	√	√	√	√	√		
VITO/VIANO	639(2008-)	Information and communication	RADIO Sound 20	√	√	√	√			
VITO/VIANO	639(2008-)	Information and communication	RADIO Sound 5	√	√	√	√			
VITO/VIANO	639(2008-)	Information and communication	SOUND 5NG	√	√	√	√	√		
VITO/VIANO	639(2008-)	Information and communication	TEL-Telephone control unit	√	√	√	√	√		
VITO/VIANO	639(2008-)	LIN Bus	PSM-Parameterizable Special Module	√	√	√	√	√		
VITO/VIANO	639(2008-)	Seats and DoorS	DCM-FL-Door control module front left	√	√		√	√		
VITO/VIANO	639(2008-)	Seats and DoorS	DCM-FR-Door control module front right	√	√		√	√		
VITO/VIANO	639(2008-)	Seats and DoorS	ESA driver-Electric seat adjustment driver (with memory)	√	√		√	√		

VITO/VIANO	639(2008-)	Seats and DoorS	ESA passenger-Electric seat adjustment front passenger (with memory)	√	√		√	√		
VITO/VIANO	639(2008-)	Seats and DoorS	STE-L-ESD [STE] Left electric sliding	√	√		√	√		
VITO/VIANO	639(2008-)	Seats and DoorS	STE-R-ESD [STE] Right electric sliding door	√	√		√	√		

XTOOL

Special Functions

No.	Model Series	System Name
SP0001	Calibrate control unit LWR	ALWR-Headlamp range adjustment
SP0002	Adaptation values of shift 1-2	EGS Electronic transmission control
SP0003	Adaptation values of shift 2-1	EGS Electronic transmission control
SP0004	Adaptation values of shift 2-3	EGS Electronic transmission control
SP0005	Adaptation values of shift 3-2	EGS Electronic transmission control
SP0006	Adaptation values of shift 3-4	EGS Electronic transmission control
SP0007	Adaptation values of shift 4-3	EGS Electronic transmission control
SP0008	Adaptation values of shift 4-5	EGS Electronic transmission control
SP0009	Adaptation values of shift 5-4	EGS Electronic transmission control
SP0010	Display all adaptation data	EGS Electronic transmission control
SP0011	Resetting of adaptation data	EGS Electronic transmission control
SP0012	A9/1m1 (Air compressor motor)	ENR-Electronic rear axle level control
SP0013	Y36 (Level control valve unit)	ENR-Electronic rear axle level control
SP0014	B24/15 (Yaw rate, lateral and longitudinal acceleration	ESP-Electronic stability program
SP0015	Maintenance light reset	IC-Instrument cluster
SP0016	Initial startup	KLA-Automatic air conditioning
SP0017	Teach-in of actuator motors	KLA-Automatic air conditioning
SP0018	Correction programming of fuel quantity	ME-SFI-Motor electronics
SP0019	Correction programming of ignition	ME-SFI-Motor electronics
SP0020	Recirculated air flap	ME-SFI-Motor electronics
SP0021	Resetting of sensor adaptation	ME-SFI-Motor electronics
SP0022	Teach in of throttle valve stop	ME-SFI-Motor electronics
SP0023	Confirmation of general maintenance	IC-Instrument cluster
SP0024	Reset general maintenance	IC-Instrument cluster