

## Shenzhen Xtooltech Co., Ltd

## **HYUNDAI Function List V5.22**

## Tips and Instructions:

The programming function only supports H6PRO, H6PRO Master Edition products.

- \* This feature is new.
- ✓ This feature is supported.This feature is not supported.
- \* This feature is partially supported.

Model	Model Series	System Name	Read ECU Information	Read Trouble Code	Read Freeze Frame	Clear Trouble Code	Live Data	Actuation Test	Special Functions
Light-Van	Engine management system	W-Engine (DENSO)	√	1		√	<b>√</b>		
Light-Van	Engine management system	VGT EURO 3	<b>√</b>	<b>√</b>		1	<b>√</b>	<b>√</b>	
Light-Van	Break control system	WABCO HPB	<b>√</b>	$\checkmark$		1	<b>√</b>		
Light-Van	Break control system	MOBIS ABS	<b>√</b>	1		√	<b>√</b>		
Light-Van	ETACS		1				<b>√</b>		
Light-Van	DTG/DIS	DTG	√	<b>√</b>		<b>√</b>	<b>√</b>		
Medium truck	ETACS		√				<b>√</b>		
Medium truck	DTG/DIS	DTG/DIS	√	√		√	<b>√</b>		
Medium truck	DTG/DIS	DTG	√	<b>√</b>		<b>√</b>	√		
Heavy-duty goods vehicles	Engine management system	Power Tec (Before 04EM)	√	√		√	√		
Heavy-duty goods vehicles	Engine management system	Power Tec (after 04EM)	√	√		<b>√</b>	√		
	Engine management system	Power Tec (GV/PY/07MY)	√	√		<b>√</b>	<b>√</b>		
Heavy-duty goods vehicles	Engine management system	H-Engine		<b>√</b>		<b>√</b>	<b>√</b>		
	Engine management system	L-Engine		<b>√</b>		<b>√</b>	<b>√</b>		
Heavy-duty goods vehicles	Engine management system	Q-2000 Engine	√	√		<b>√</b>	√		
Heavy-duty goods vehicles		ETACS (04EM)	√				√		
Heavy-duty goods vehicles	Body control system	ETACS (GV/PY/07MY)	√				√		
Heavy-duty goods vehicles	Body control system	BCM (BCM)	√				1		

Heavy-duty goods vehicles	Lane departure alarm system		<b>√</b>	<b></b>	<b>√</b>	<b>√</b>	
Heavy-duty goods vehicles		DTG/DIS	<b>√</b>	<b>√</b>	<b>√</b>	<b>√</b>	
Heavy-duty goods vehicles		DTG	<b>√</b>	<b>√</b>	<b>√</b>	<b>√</b>	
Heavy-duty goods vehicles	А/Т	ASTRONIX ATM2	<b>√</b>	<b>√</b>	<b>√</b>	<b>√</b>	
Heavy-duty goods vehicles	Suspension control system	WABCO ECAS	√	<b>√</b>	<b>√</b>	<b>√</b>	
Heavy-duty goods vehicles	Brake control system	ZF retarder	√	√	√	√	
Light bus	Engine management system	W-Engine (DENSO)	√	<b>√</b>	√	<b>√</b>	
Light bus	Brake control system	WABCO HPB	√	<b>√</b>	<b>√</b>	<b>√</b>	
Light bus	Brake control system	MOBIS ABS	√	√	<b>√</b>	√	
Light bus	ETACS		√			<b>√</b>	
Light bus	DTG/DIS	DTG	√	√	<b>√</b>	<b>√</b>	
Medium bus	Engine management system	Global 900(PLD)	√	<b>√</b>	<b>√</b>	<b>√</b>	
Medium bus	Brake control system	Knorr ABS6	√	√	√	√	
Medium bus	ETACS		√			<b>√</b>	
Medium bus	DTG/DIS	DTG/DIS	√	√	√	<b>√</b>	
Medium bus	DTG/DIS	DTG	√	√	√	√	
Large bus	Engine management system	Power Tec (Before 04EM)	1	<b>√</b>	<b>√</b>	√	
Large bus	Engine management system	Power Tec (after 04EM)	<b>√</b>	<b>√</b>	<b>√</b>	√	
Large bus	Engine management system	Power Tec (GV/PY/07MY)	<b>√</b>	<b>√</b>	<b>√</b>	√	
Large bus	Engine management system	H-Engine		1	<b>√</b>	√	
Large bus	Engine management system	L-Engine		√	1	√	
Large bus	Engine management system	L-Engine (exported to Jaj	1	1	<b>√</b>	√	
Large bus	Engine management system	Q-2000 Engine	√	√	√	√	
Large bus	Brake control system	Knorr ABS6	√	√	$\checkmark$	√	
Large bus	Brake control system	ZF retarder	√	√	√	√	
Large bus	Brake control system	Voice retarder	√	√	√	√	
Large bus	Body control system	ETACS (O4EM)	√			√	
Large bus	Body control system	ETACS (GV/PY/07MY)	√			√	
Large bus	Body control system	BCM	√			√	
Large bus	Lane departure alarm system		√	√	$\checkmark$	√	
Large bus	DTG/DIS	DTG/DIS	√	√	√	√	
Large bus	DTG/DIS	DTG	√	√	√	√	
Large bus	A/T	ZF ECOMAT 2	√	√	√	√	
Large bus	A/T	ZF ECOMAT 4	√	√	√	√	
Large bus	Suspension control system	WABCO ECAS	√	$\checkmark$	√	√	

Large bus	Event recorder	$\checkmark$	<b>√</b>	<b>√</b>	<b>√</b>	

