

## Immobiliser Function List

**Software Version: 26.35**

Automaker	Model	System	Function
BAOJUN	BaoJun 310	Immobiliser	1.Read number of keys 2.Add keys 3.Erase keys 4.Reset ECM 5.Program mode
BAOJUN	BaoJun 330	Immobiliser	1.Read key number 2.Add key 3.Erase keys
BAOJUN	BaoJun 510	Immobiliser	1.Read number of keys 2.Add keys 3.Erase keys 4.Reset ECM 5.Program mode
BAOJUN	BaoJun 560	Immobiliser	1.Read number of keys 2.Add keys 3.Erase keys 4.Reset ECM 5.Program mode
BAOJUN	BaoJun 610	Immobiliser	1.Read key number 2.Program remotes 3.Add key 4.Erase keys
BAOJUN	BaoJun 630	Immobiliser	1.Read key number 2.Program remotes 3.Add key 4.Erase keys
BAOJUN	BaoJun 730	Immobiliser	1.Read number of keys 2.Add keys 3.Erase keys 4.Reset ECM 5.Program mode

BAOJUN	BaoJun 510	smart key system	1.ECU identification 2.Add key 3.All keys lost
BAOJUN	BaoJun 560	smart key system	1.ECU identification 2.Add key 3.All keys lost

*XTOOL*