



Shenzhen Xtooltech Co., Ltd

BAOJUN Function list V26.56

Car series	System type	Model	Function menu	Password required	Password can be read/calculated	Password digits
BAOJUN	Immobiliser	330	1. Read the number of keys 2. Add key 3. Clear key 4. New system matching	NO		
		310	1. Read the number of keys	NO		
		360	2. Read BCM status			
		510	3. Add key			
		530	4. Clear key			
		560	5. ECM reset			
		310 wagon	6. BCM Program			
		730	7. ECM Program			
		610	1. Read the number of keys 2. Remote matching	NO		
		630	3. Key match 4. Key removal			
	Smart key system	310 Wagon	1. Read ECU Information	NO		
		510	2. Add key			
		530	3. Lost all keys			
		560	4. Reset PEPS			
		730	5. Reset ESCL			
		E100	6. Match PEPS			
		E200	7. Match ESCL			
	Remote system	360	1. Remote matching	NO		
		E100				

		E200				
New BAOJUN	Immobiliser	RC-5	1. Read the number of keys 2. Read BCM status 3. Add key 4. Clear key 5. ECM reset 6. BCM Program 7. ECM Program	NO		
		RC-5W				
		RC-6				
		RM-5				
		RS-3				
		RS-5				
		RS-7				
		E300 LV2/LV3				
		E300Plus LV2/LV3				
	Smart key system	RC-5	1. Add key 2. Lost all keys 3. Reset PEPS 4. Reset ESCL 5. Match PEPS 6. Match ESCL	NO		
		RC-5W				
		RC-6				
		RM-5				
		RS-3				
		RS-5				
	Remote system	E300 LV1	1. Remote matching	NO		
		E300Plus LV1				