

Immobiliser Function List			
Software Version: 26.01			
Automaker	Model	System	Function
BORGWARD		Immobiliser	1.Add keys 2.Erase keys 3.Program EMS 4.Program PEPS 5.Program TBOX 6.Program new system 7.Write password to ESCL

XTOOL