



Shenzhen Xtooltech Co., Ltd

FOTON Function List V26.22

Vehicles	Type	Module	Function	Need Pin code	Read Pin code	Digits of Pin code
M4(Light truck)		Door Control Module	1.Number of remotes	NO		
M4(Medium truck)		Door Control Module	2.Program remote 3.Clear remote			
U201		Immobiliser(Continental -Cummins)	1.Program key 2.Clear key	YES	NO	4
		Immobiliser(Continental -G01)	3.Program ECM 4.Program IMMO 5.Reset ECM 6.Reset IMMO			
		Smart Key System	1.After sale program Program blade key Program Smart Key	NO		
			2.Factory program Program key Clear key Read vehicle status Reset key Clear SK Program EVM Program config			
			1.Program remote 2.Clear remote 3.Number of remotes	YES	NO	4
		Body Control Module	1.Program remote 2.Clear remote 3.Number of remotes	NO		
OLLIN(Light truck)	CXT	Door Control Module	1.Number of remotes 2.Program remote 3.Clear remote	NO		
	CXS					
Omarco Light Truck		Door Control Module	1.Number of remotes 2.Program remote 3.Clear remote	NO		
Revo Light Truck						
Other light trucks						
TUNLAND		Smart Key System	1.Program key 2.Program ESCL 3.Program PEPS 4.Write VIN code 5.Write part number 6.Write ECU number	YES	NO	8
TUNLAND IM		Smart Key System	1.Program key 2.Program ESCL 3.Program PEPS	YES	NO	4
		Body Control Module(CETC)	1.Program remote 2.Write VIN code 3.Program BCM	NO		
		Body Control Module(CJAE)	1.Read remote number 2.Program key 3.Program remote 4.Clear key 5.Clear remote	YES	NO	4
TUNLAND IX		Smart Key System	1.Program key 2.Program ESCL 3.Program PEPS 4.Write VIN code 5.Write part number 6.Write ECU number	YES	NO	8
		Body Control Module	1.Program remote	NO		
AUMAN(Heavy truck)		Smart Key System	1.Number of keys 2.Program key	NO		
		Door control module	1.Number of remotes 2.Program remote	NO		
SAVANNA		Body Control Module(Type 1)	1.Program remote 2.Clear remote	NO		
		Body Control Module(Type 2)	3.Number of remotes			
TOANO		Immobiliser(Continental -Cummins)	1.Program key 2.Clear key 3.Program ECM 4.Program IMMO 5.Reset ECM 6.Reset IMMO	YES	NO	4
		Body Control Module	1.Program remote 2.Clear remote 3.Number of remotes	NO		
GRATOUR		Immobiliser(Continental -Cummins)	1.Program key 2.Clear key 3.Program ECM 4.Program IMMO	YES	NO	4
		Immobiliser(Continental -G01)	5.Reset ECM 6.Reset IMMO			
		Body Control Module	1.Program remote 2.Clear remote 3.Number of remotes	NO		
GRATOUR(P202)		Body Control Module	1.Program remote 2.Clear remote 3.Number of remotes	NO		

GRATOUR(2015)		Immobiliser(Continental -Cummins)	1.Program key 2.Clear key 3.Program ECM 4.Program IMMO	YES	NO	4
		Immobiliser(Continental -G01)	5.Reset ECM 6.Reset IMMO			
		Smart Key System	1.After sale program Program blade key Program Smart Key	NO		
			2.Factory program Program key Clear key Read vehicle status Reset key Clear SK Program EVM Program config	YES	NO	4
		Body Control Module	1.Program remote 2.Clear remote 3.Number of remotes	NO		