

Immobiliser Function List

Software Version: 26.10

Automaker	Model	System	Function
HAWTAI	1.B11 2.Boliger 3.Santa Fe(Type 1)	Immobiliser	1.ECU identification 2.Fault codes 3.Erase DTC 4.Live data 5.Program function (1)Read security code (2)Add a key (3)Erase keys (4)Read VIN (5)Check key
HAWTAI	Santa Fe(Type 2)	Immobiliser	1.Program keys 2.ECM neutral 3.Live data
HAWTAI	Santa Fe(Type 3)	Immobiliser	1.Program keys 2.ECM neutral 3.Live data
HAWTAI	Santa Fe(Type 4)	Immobiliser	1.Program keys 2.ECM neutral 3.Live data
HAWTAI		Remote	1.Program remote
HAWTAI		Remote	1Program remote