

Immobiliser Function List

Software Version: 26.28

Automaker	Model	System	Function
Honda/Acura	Immobiliser	Type 1(3 PIN)	1.Add a key 2.All keys lost
Honda/Acura	Immobiliser	Type 2(16 PIN)	1.Add a key 2.All keys lost
Honda/Acura	Smart key system	Type 1(knob)	1. Add a smart key 2. All smart keys lost
Honda/Acura	Smart key system	Type 2(button)	1. Add a smart key 2. All smart keys lost
Honda/Acura	Smart key system	Type 3(button)	1. Add a smart key 2. All smart keys lost
Honda/Acura	Remote	Type 1(9G)	1. Add remotes 2. Erase remotes
Honda/Acura	Remote	Type 2	1. Program remote 2. Remote identification