



深圳市朗仁科技有限公司 Shenzhen Xtooltech Co., Ltd

HONDA V26.44

Description: ▲: Partially support by OBD(Need accessories) △: Partially support by OBD ×: Not support
●: All support by OBD(Need accessories) ○: All support by OBD ◎: Conditional support
■: Partially support (Disassembly) □: All support (Disassembly) /:Unnecessary

Make	Model	Year	Key Type	Read PIN	Add Keys	All Keys Lost	Remote	Other Functions
HONDA	Accord	/	Without smart key	/	○	○	○	Replace immobiliser ECU,Replace the ECM / PCM,Replace MPCS / MICU / IMOES
HONDA	Accord	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	Accord	/	smart key Button type	/	○	○	/	Replace ECM, Replace BCM
HONDA	Insight	/	Without smart key	/	○	○	○	Replace immobiliser ECU,Replace the ECM / PCM,Replace MPCS / MICU / IMOES
HONDA	Insight	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	Insight	/	smart key Button type	/	○	○	/	Replace ECM, Replace BCM
HONDA	Odyssey	/	Without smart key	/	○	○	○	Replace immobiliser ECU,Replace the ECM / PCM,Replace MPCS / MICU / IMOES
HONDA	Odyssey	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	Odyssey	/	smart key Button type	/	○	○	/	Replace ECM, Replace BCM
HONDA	Jade	/	Without smart key	/	○	○	○	Replace immobiliser ECU,Replace the ECM / PCM,Replace MPCS / MICU / IMOES
HONDA	Jade	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	Jade	/	smart key Button type	/	○	○	/	Replace ECM, Replace BCM

HONDA	XR-V	/	Without smart key	/	○	○	○	Replace immobiliser ECU,Replace the ECM / PCM,Replace MPCS / MICU / IMOES
HONDA	XR-V	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	XR-V	/	smart key Button type	/	○	△■	/	Replace ECM, Replace BCM
HONDA	Elysion	/	Without smart key	/	○	○	○	Replace immobiliser ECU,Replace the ECM / PCM,Replace MPCS / MICU / IMOES
HONDA	Elysion	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	Elysion	/	smart key Button type	/	○	○	/	Replace ECM, Replace BCM
HONDA	Crosstour	/	Without smart key	/	○	○	○	Replace immobiliser ECU,Replace the ECM / PCM,Replace MPCS / MICU / IMOES
HONDA	Crosstour	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	Crosstour	/	smart key Button type	/	○	○	/	Replace ECM, Replace BCM
HONDA	CR-V	/	Without smart key	/	○	○	○	Replace immobiliser ECU,Replace the ECM / PCM,Replace MPCS / MICU / IMOES
HONDA	CR-V	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	CR-V	/	smart key Button type	/	○	△■	/	Replace ECM, Replace BCM
HONDA	Element	/	Without smart key	/	○	○	○	Replace immobiliser ECU,Replace the ECM / PCM,Replace MPCS / MICU / IMOES
HONDA	Element	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	Element	/	smart key Button type	/	○	○	/	Replace ECM, Replace BCM
HONDA	Fit	/	Without smart key	/	○	○	○	Replace immobiliser ECU,Replace the ECM / PCM,Replace MPCS / MICU / IMOES
HONDA	Fit	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	Fit	/	smart key Button type	/	○	○	/	Replace ECM, Replace BCM

HONDA	Aviator	/	Without smart key	/	○	○	○	Replace immobiliser ECU,Replace the ECM / PCM,Replace MPCS / MICU / IMOES
HONDA	Aviator	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	Aviator	/	smart key Button type	/	○	○	/	Replace ECM, Replace BCM
HONDA	City	/	Without smart key	/	○	○	○	Replace immobiliser ECU,Replace the ECM / PCM,Replace MPCS / MICU / IMOES
HONDA	City	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	City	/	smart key Button type	/	○	○	/	Replace ECM, Replace BCM
HONDA	Civic	/	Without smart key	/	○	○	○	Replace immobiliser ECU,Replace the ECM / PCM,Replace MPCS / MICU / IMOES
HONDA	Civic	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	Civic	/	smart key Button type	/	○	△■	/	Replace ECM, Replace BCM
HONDA	Civic	/	遥控系统[9代]	/	/	/	○	
HONDA	SPIRIOR	/	Without smart key	/	○	○	○	Replace immobiliser ECU,Replace the ECM / PCM,Replace MPCS / MICU / IMOES
HONDA	SPIRIOR	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	SPIRIOR	/	smart key Button type	/	○	○	/	Replace ECM, Replace BCM
HONDA	EVERUS	/	Without smart key	/	○	○	○	Replace immobiliser ECU,Replace the ECM / PCM,Replace MPCS / MICU / IMOES
HONDA	EVERUS	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	EVERUS	/	smart key Button type	/	○	○	/	Replace ECM, Replace BCM
HONDA	VEZEL	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	VEZEL	/	smart key Button type	/	○	△■	/	Replace ECM, Replace BCM

HONDA	Brio	/	Without smart key	/	○	○	○	Replace immobiliser ECU,Replace the ECM / PCM,Replace MPCS / MICU / IMOES
HONDA	Brio	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	Brio	/	smart key Button type	/	○	○	/	Replace ECM, Replace BCM
HONDA	Amaze	/	Without smart key	/	○	○	○	Replace immobiliser ECU,Replace the ECM / PCM,Replace MPCS / MICU / IMOES
HONDA	Amaze	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	Amaze	/	smart key Button type	/	○	○	/	Replace ECM, Replace BCM
HONDA	Hrv	/	Without smart key	/	○	○	○	Replace immobiliser ECU,Replace the ECM / PCM,Replace MPCS / MICU / IMOES
HONDA	Hrv	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	Hrv	/	smart key Button type	/	○	○	/	Replace ECM, Replace BCM
HONDA	Stream	/	Without smart key	/	○	○	○	Replace immobiliser ECU,Replace the ECM / PCM,Replace MPCS / MICU / IMOES
HONDA	Stream	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	Stream	/	smart key Button type	/	○	○	/	Replace ECM, Replace BCM
HONDA	Legend	/	Without smart key	/	○	○	○	Replace immobiliser ECU,Replace the ECM / PCM,Replace MPCS / MICU / IMOES
HONDA	Legend	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	Legend	/	smart key Button type	/	○	○	/	Replace ECM, Replace BCM
HONDA	CR-Z	/	Without smart key	/	○	○	○	Replace immobiliser ECU,Replace the ECM / PCM,Replace MPCS / MICU / IMOES
HONDA	CR-Z	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	CR-Z	/	smart key Button type	/	○	○	/	Replace ECM, Replace BCM

HONDA	S2000	/	Without smart key	/	○	○	○	Replace immobiliser ECU,Replace the ECM / PCM,Replace MPCS / MICU / IMOES
HONDA	S2000	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	S2000	/	smart key Button type	/	○	○	/	Replace ECM, Replace BCM
HONDA	Mobilo	/	Without smart key	/	○	○	○	Replace immobiliser ECU,Replace the ECM / PCM,Replace MPCS / MICU / IMOES
HONDA	Mobilo	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	Mobilo	/	smart key Button type	/	○	○	/	Replace ECM, Replace BCM
HONDA	Pilot	/	Without smart key	/	○	○	○	Replace immobiliser ECU,Replace the ECM / PCM,Replace MPCS / MICU / IMOES
HONDA	Pilot	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	Pilot	/	smart key Button type	/	○	○	/	Replace ECM, Replace BCM
HONDA	Ridgeline	/	Without smart key	/	○	○	○	Replace immobiliser ECU,Replace the ECM / PCM,Replace MPCS / MICU / IMOES
HONDA	Ridgeline	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	Ridgeline	/	smart key Button type	/	○	○	/	Replace ECM, Replace BCM
HONDA	Acty	/	Without smart key	/	○	○	○	Replace immobiliser ECU,Replace the ECM / PCM,Replace MPCS / MICU / IMOES
HONDA	Acty	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	Acty	/	smart key Button type	/	○	○	/	Replace ECM, Replace BCM
HONDA	Airwave	/	Without smart key	/	○	○	○	Replace immobiliser ECU,Replace the ECM / PCM,Replace MPCS / MICU / IMOES
HONDA	Airwave	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	Airwave	/	smart key Button type	/	○	○	/	Replace ECM, Replace BCM

HONDA	Ascot	/	Without smart key	/	○	○	○	Replace immobiliser ECU,Replace the ECM / PCM,Replace MPCS / MICU / IMOES
HONDA	Ascot	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	Ascot	/	smart key Button type	/	○	○	/	Replace ECM, Replace BCM
HONDA	Avancier	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	Avancier	/	smart key Button type	/	○	△■	/	Replace ECM, Replace BCM
HONDA	Ballade	/	Without smart key	/	○	○	○	Replace immobiliser ECU,Replace the ECM / PCM,Replace MPCS / MICU / IMOES
HONDA	Ballade	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	Ballade	/	smart key Button type	/	○	○	/	Replace ECM, Replace BCM
HONDA	BR-V	/	Without smart key	/	○	○	○	Replace immobiliser ECU,Replace the ECM / PCM,Replace MPCS / MICU / IMOES
HONDA	BR-V	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	BR-V	/	smart key Button type	/	○	○	/	Replace ECM, Replace BCM
HONDA	Capa	/	Without smart key	/	○	○	○	Replace immobiliser ECU,Replace the ECM / PCM,Replace MPCS / MICU / IMOES
HONDA	Capa	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	Capa	/	smart key Button type	/	○	○	/	Replace ECM, Replace BCM
HONDA	Ciimo	/	Without smart key	/	○	○	○	Replace immobiliser ECU,Replace the ECM / PCM,Replace MPCS / MICU / IMOES
HONDA	Ciimo	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	Ciimo	/	smart key Button type	/	○	○	/	Replace ECM, Replace BCM
HONDA	Clarity	/	Without smart key	/	○	○	○	Replace immobiliser ECU,Replace the ECM / PCM,Replace MPCS / MICU / IMOES

HONDA	Clarity	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	Clarity	/	smart key Button type	/	○	○	/	Replace ECM, Replace BCM
HONDA	CR-X	/	Without smart key	/	○	○	○	Replace immobiliser ECU, Replace the ECM / PCM, Replace MPCS / MICU / IMOES
HONDA	CR-X	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	CR-X	/	smart key Button type	/	○	○	/	Replace ECM, Replace BCM
HONDA	Crider	/	Without smart key	/	○	○	○	Replace immobiliser ECU, Replace the ECM / PCM, Replace MPCS / MICU / IMOES
HONDA	Crider	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	Crider	/	smart key Button type	/	○	○	/	Replace ECM, Replace BCM
HONDA	Crossroad	/	Without smart key	/	○	○	○	Replace immobiliser ECU, Replace the ECM / PCM, Replace MPCS / MICU / IMOES
HONDA	Crossroad	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	Crossroad	/	smart key Button type	/	○	○	/	Replace ECM, Replace BCM
HONDA	Domani	/	Without smart key	/	○	○	○	Replace immobiliser ECU, Replace the ECM / PCM, Replace MPCS / MICU / IMOES
HONDA	Domani	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	Domani	/	smart key Button type	/	○	○	/	Replace ECM, Replace BCM
HONDA	Edix	/	Without smart key	/	○	○	○	Replace immobiliser ECU, Replace the ECM / PCM, Replace MPCS / MICU / IMOES
HONDA	Edix	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	Edix	/	smart key Button type	/	○	○	/	Replace ECM, Replace BCM
HONDA	FCX	/	Without smart key	/	○	○	○	Replace immobiliser ECU, Replace the ECM / PCM, Replace MPCS / MICU / IMOES

HONDA	FCX	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	FCX	/	smart key Button type	/	○	○	/	Replace ECM, Replace BCM
HONDA	FR-V	/	Without smart key	/	○	○	○	Replace immobiliser ECU, Replace the ECM / PCM, Replace MPCS / MICU / IMOES
HONDA	FR-V	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	FR-V	/	smart key Button type	/	○	○	/	Replace ECM, Replace BCM
HONDA	Freed	/	Without smart key	/	○	○	○	Replace immobiliser ECU, Replace the ECM / PCM, Replace MPCS / MICU / IMOES
HONDA	Freed	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	Freed	/	smart key Button type	/	○	○	/	Replace ECM, Replace BCM
HONDA	Gienia	/	Without smart key	/	○	○	○	Replace immobiliser ECU, Replace the ECM / PCM, Replace MPCS / MICU / IMOES
HONDA	Gienia	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	Gienia	/	smart key Button type	/	○	○	/	Replace ECM, Replace BCM
HONDA	Grace	/	Without smart key	/	○	○	○	Replace immobiliser ECU, Replace the ECM / PCM, Replace MPCS / MICU / IMOES
HONDA	Grace	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	Grace	/	smart key Button type	/	○	○	/	Replace ECM, Replace BCM
HONDA	Greiz	/	Without smart key	/	○	○	○	Replace immobiliser ECU, Replace the ECM / PCM, Replace MPCS / MICU / IMOES
HONDA	Greiz	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	Greiz	/	smart key Button type	/	○	○	/	Replace ECM, Replace BCM
HONDA	Inspire	/	Without smart key	/	○	○	○	Replace immobiliser ECU, Replace the ECM / PCM, Replace MPCS / MICU / IMOES

HONDA	Inspire	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	Inspire	/	smart key Button type	/	○	○	/	Replace ECM, Replace BCM
HONDA	Integra	/	Without smart key	/	○	○	○	Replace immobiliser ECU, Replace the ECM / PCM, Replace MPCS / MICU / IMOES
HONDA	Integra	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	Integra	/	smart key Button type	/	○	○	/	Replace ECM, Replace BCM
HONDA	Jazz	/	Without smart key	/	○	○	○	Replace immobiliser ECU, Replace the ECM / PCM, Replace MPCS / MICU / IMOES
HONDA	Jazz	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	Jazz	/	smart key Button type	/	○	○	/	Replace ECM, Replace BCM
HONDA	Lagreat	/	Without smart key	/	○	○	○	Replace immobiliser ECU, Replace the ECM / PCM, Replace MPCS / MICU / IMOES
HONDA	Lagreat	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	Lagreat	/	smart key Button type	/	○	○	/	Replace ECM, Replace BCM
HONDA	Life	/	Without smart key	/	○	○	○	Replace immobiliser ECU, Replace the ECM / PCM, Replace MPCS / MICU / IMOES
HONDA	Life	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	Life	/	smart key Button type	/	○	○	/	Replace ECM, Replace BCM
HONDA	Logo	/	Without smart key	/	○	○	○	Replace immobiliser ECU, Replace the ECM / PCM, Replace MPCS / MICU / IMOES
HONDA	Logo	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	Logo	/	smart key Button type	/	○	○	/	Replace ECM, Replace BCM
HONDA	MDX	/	Without smart key	/	○	○	○	Replace immobiliser ECU, Replace the ECM / PCM, Replace MPCS / MICU / IMOES

HONDA	MDX	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	MDX	/	smart key Button type	/	○	○	/	Replace ECM, Replace BCM
HONDA	MR-V	/	Without smart key	/	○	○	○	Replace immobiliser ECU, Replace the ECM / PCM, Replace MPCS / MICU / IMOES
HONDA	MR-V	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	MR-V	/	smart key Button type	/	○	○	/	Replace ECM, Replace BCM
HONDA	N-Box	/	Without smart key	/	○	○	○	Replace immobiliser ECU, Replace the ECM / PCM, Replace MPCS / MICU / IMOES
HONDA	N-Box	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	N-Box	/	smart key Button type	/	○	○	/	Replace ECM, Replace BCM
HONDA	N-One	/	Without smart key	/	○	○	○	Replace immobiliser ECU, Replace the ECM / PCM, Replace MPCS / MICU / IMOES
HONDA	N-One	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	N-One	/	smart key Button type	/	○	○	/	Replace ECM, Replace BCM
HONDA	NSX	/	Without smart key	/	○	○	○	Replace immobiliser ECU, Replace the ECM / PCM, Replace MPCS / MICU / IMOES
HONDA	NSX	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	NSX	/	smart key Button type	/	○	○	/	Replace ECM, Replace BCM
HONDA	Orthia	/	Without smart key	/	○	○	○	Replace immobiliser ECU, Replace the ECM / PCM, Replace MPCS / MICU / IMOES
HONDA	Orthia	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	Orthia	/	smart key Button type	/	○	○	/	Replace ECM, Replace BCM
HONDA	Partner	/	Without smart key	/	○	○	○	Replace immobiliser ECU, Replace the ECM / PCM, Replace MPCS / MICU / IMOES

HONDA	Partner	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	Partner	/	smart key Button type	/	○	○	/	Replace ECM, Replace BCM
HONDA	Prelude	/	Without smart key	/	○	○	○	Replace immobiliser ECU, Replace the ECM / PCM, Replace MPCS / MICU / IMOES
HONDA	Prelude	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	Prelude	/	smart key Button type	/	○	○	/	Replace ECM, Replace BCM
HONDA	Rafaga	/	Without smart key	/	○	○	○	Replace immobiliser ECU, Replace the ECM / PCM, Replace MPCS / MICU / IMOES
HONDA	Rafaga	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	Rafaga	/	smart key Button type	/	○	○	/	Replace ECM, Replace BCM
HONDA	S-MX	/	Without smart key	/	○	○	○	Replace immobiliser ECU, Replace the ECM / PCM, Replace MPCS / MICU / IMOES
HONDA	S-MX	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	S-MX	/	smart key Button type	/	○	○	/	Replace ECM, Replace BCM
HONDA	S660	/	Without smart key	/	○	○	○	Replace immobiliser ECU, Replace the ECM / PCM, Replace MPCS / MICU / IMOES
HONDA	S660	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	S660	/	smart key Button type	/	○	○	/	Replace ECM, Replace BCM
HONDA	Saber	/	Without smart key	/	○	○	○	Replace immobiliser ECU, Replace the ECM / PCM, Replace MPCS / MICU / IMOES
HONDA	Saber	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	Saber	/	smart key Button type	/	○	○	/	Replace ECM, Replace BCM
HONDA	Shuttle	/	Without smart key	/	○	○	○	Replace immobiliser ECU, Replace the ECM / PCM, Replace MPCS / MICU / IMOES

HONDA	Shuttle	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	Shuttle	/	smart key Button type	/	○	○	/	Replace ECM, Replace BCM
HONDA	Spike	/	Without smart key	/	○	○	○	Replace immobiliser ECU, Replace the ECM / PCM, Replace MPCS / MICU / IMOES
HONDA	Spike	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	Spike	/	smart key Button type	/	○	○	/	Replace ECM, Replace BCM
HONDA	Step Wgn	/	Without smart key	/	○	○	○	Replace immobiliser ECU, Replace the ECM / PCM, Replace MPCS / MICU / IMOES
HONDA	Step Wgn	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	Step Wgn	/	smart key Button type	/	○	○	/	Replace ECM, Replace BCM
HONDA	Thats	/	Without smart key	/	○	○	○	Replace immobiliser ECU, Replace the ECM / PCM, Replace MPCS / MICU / IMOES
HONDA	Thats	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	Thats	/	smart key Button type	/	○	○	/	Replace ECM, Replace BCM
HONDA	Today	/	Without smart key	/	○	○	○	Replace immobiliser ECU, Replace the ECM / PCM, Replace MPCS / MICU / IMOES
HONDA	Today	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	Today	/	smart key Button type	/	○	○	/	Replace ECM, Replace BCM
HONDA	Torneo	/	Without smart key	/	○	○	○	Replace immobiliser ECU, Replace the ECM / PCM, Replace MPCS / MICU / IMOES
HONDA	Torneo	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	Torneo	/	smart key Button type	/	○	○	/	Replace ECM, Replace BCM
HONDA	UR-V	/	Without smart key	/	○	○	○	Replace immobiliser ECU, Replace the ECM / PCM, Replace MPCS / MICU / IMOES

HONDA	UR-V	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	UR-V	/	smart key Button type	/	○	○	/	Replace ECM, Replace BCM
HONDA	Vamos	/	Without smart key	/	○	○	○	Replace immobiliser ECU, Replace the ECM / PCM, Replace MPCS / MICU / IMOES
HONDA	Vamos	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	Vamos	/	smart key Button type	/	○	○	/	Replace ECM, Replace BCM
HONDA	Vigor	/	Without smart key	/	○	○	○	Replace immobiliser ECU, Replace the ECM / PCM, Replace MPCS / MICU / IMOES
HONDA	Vigor	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	Vigor	/	smart key Button type	/	○	○	/	Replace ECM, Replace BCM
HONDA	WR-V	/	Without smart key	/	○	○	○	Replace immobiliser ECU, Replace the ECM / PCM, Replace MPCS / MICU / IMOES
HONDA	WR-V	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	WR-V	/	smart key Button type	/	○	○	/	Replace ECM, Replace BCM
HONDA	Z	/	Without smart key	/	○	○	○	Replace immobiliser ECU, Replace the ECM / PCM, Replace MPCS / MICU / IMOES
HONDA	Z	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	Z	/	smart key Button type	/	○	○	/	Replace ECM, Replace BCM
HONDA	Zest	/	Without smart key	/	○	○	○	Replace immobiliser ECU, Replace the ECM / PCM, Replace MPCS / MICU / IMOES
HONDA	Zest	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	Zest	/	smart key Button type	/	○	○	/	Replace ECM, Replace BCM
HONDA	FCV	/	Without smart key	/	○	○	○	Replace immobiliser ECU, Replace the ECM / PCM, Replace MPCS / MICU / IMOES

HONDA	FCV	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	FCV	/	smart key Button type	/	○	○	/	Replace ECM, Replace BCM
HONDA	Passport	/	Without smart key	/	○	○	○	Replace immobiliser ECU, Replace the ECM / PCM, Replace MPCS / MICU / IMOES
HONDA	Passport	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	Passport	/	smart key Button type	/	○	○	/	Replace ECM, Replace BCM
HONDA	Nwgn	/	Without smart key	/	○	○	○	Replace immobiliser ECU, Replace the ECM / PCM, Replace MPCS / MICU / IMOES
HONDA	Nwgn	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	Nwgn	/	smart key Button type	/	○	○	/	Replace ECM, Replace BCM
HONDA	C 001	/	Without smart key	/	○	○	○	Replace immobiliser ECU, Replace the ECM / PCM, Replace MPCS / MICU / IMOES
HONDA	C 001	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	C 001	/	smart key Button type	/	○	○	/	Replace ECM, Replace BCM
HONDA	e Prototype	/	Without smart key	/	○	○	○	Replace immobiliser ECU, Replace the ECM / PCM, Replace MPCS / MICU / IMOES
HONDA	e Prototype	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	e Prototype	/	smart key Button type	/	○	○	/	Replace ECM, Replace BCM
HONDA	Urban	/	Without smart key	/	○	○	○	Replace immobiliser ECU, Replace the ECM / PCM, Replace MPCS / MICU / IMOES
HONDA	Urban	/	smart key Knob type	/	○	○	/	Replace smart key ECU, Replace knob ignition
HONDA	Urban	/	smart key Button type	/	○	○	/	Replace ECM, Replace BCM
HONDA	VE-1	/	smart key Button type	/	○	/	/	Replace ECM, Replace BCM

HONDA	X-NV	/	smart key Button type	/	○	/	/	Replace ECM, Replace BCM
HONDA	M-NV	/	smart key Button type	/	○	/	/	Replace ECM, Replace BCM

XTOOL