

Immobiliser Function List

Software Version: 26.62

Automaker	Area	Model	System	Function
MAZDA	China	B-series	Smart key system	1.Number of keys 2.Add a key 3.All Keys lost
MAZDA	China	Mazda 2	Smart key system	1.Number of keys 2.Add a key 3.All Keys lost
MAZDA	China	Mazda 2	Smart key system (With)	1.Number of keys 2.Add a key 3.All Keys lost
MAZDA	China	Mazda 2	Smart key system (Without)	1.Number of keys 2.Add a key 3.All Keys lost
MAZDA	China	Mazda 3(Type 1)	Immobiliser	1.Number of keys 2.Add a key 3.All keys lost 4.Program immo.and PCM
MAZDA	China	Mazda 3(Type 2)	Immobiliser	1.Number of keys 2.Add a key 3.All Keys lost 4.Program immo.and PCM
MAZDA	China	Mazda3 Axela	Smart key system	1.All smart keys lost 2.Add a smart key 3.Switch ignition on
MAZDA	China	Mazda 5(Type 1)	Immobiliser	1.Number of keys 2.Add a key 3.All keys lost 4.Program immo.and PCM
MAZDA	China	Mazda 5(Type 2)	Immobiliser	1.Number of keys 2.Add a key 3.All Keys lost 4.Program immo.and PCM

MAZDA	China	Mazda 6	Smart key	1.Number of keys 2.Add a key 3.All keys lost 4.Number of smart keys 5.Add a smart key 6.Erase smart keys
MAZDA	China	Mazda 6	Non smart key	1.Number of keys 2.Add a key 3.All keys lost
MAZDA	China	Mazda 6(2008-)	Smart key	1.All keys lost 2.Add keys<ACT4> 3.All smart keys lost 4.Add smart keys 5.Live data 6.Switch ignition on 7.Erase DTC
MAZDA	China	Mazda 6(2008-)	Non smart key	1.Number of keys 2.Add a key 3.All keys lost
MAZDA	China	Mazda6 Atenza	Smart key system	1.All smart keys lost 2.Add a smart key 3.Switch ignition on
MAZDA	China	Mazda 8	Smart key system	1.Add key 2.All keys lost 3.Add smart key 4.Erase smart keys 5.Read number of keys
MAZDA	China	Mazda 8	Non smart	1.Number of keys 2.Add a key 3.All keys lost
MAZDA	China	Mazda CX-3	Smart key system	1.All smart keys lost 2.Add a smart key 3.Switch ignition on
MAZDA	China	Mazda CX-4	Smart key system	1.All smart keys lost 2.Add a smart key 3.Switch ignition on
MAZDA	China	Mazda CX-5	Smart key system	1.All smart keys lost 2.Add a smart key 3.Switch ignition on

MAZDA	China	Mazda CX-7(-2016)	Smart key system	1.Add key 2.All keys lost 3.Add smart key 4.Erase smart keys 5.Read number of keys
MAZDA	China	Mazda CX-7(2016-)	Smart key system	1.All smart keys lost 2.Add a smart key 3.Switch ignition on
MAZDA	China	Mazda CX-7(2004-2009)	Non smart key	1.Number of keys 2.Add a key 3.All keys lost 4.Program immo.and PCM
MAZDA	China	Mazda CX-7(2009-)	Non smart key	1.Number of keys 2.Add a key 3.All Keys lost 4.Program immo.and PCM
MAZDA	China	Mazda CX-9	Smart key system	1.All smart keys lost 2.Add a smart key 3.Switch ignition on
MAZDA	China	Mazda CX-9(2004-2009)	Non smart key	1.Number of keys 2.Add a key 3.All keys lost 4.Program immo.and PCM
MAZDA	China	Mazda CX-9(2009-)	Non smart key	1.Number of keys 2.Add a key 3.All Keys lost 4.Program immo.and PCM
MAZDA	Africa	BT-50(2011-)	Non smart key	1.Current number of keys 2.All Keys Lost 3.Add Key
MAZDA	Africa	Mazda 2(2002-2008)	Non smart key	1.Number of keys 2.Add a key 3.All keys lost
MAZDA	Africa	Mazda 2(2008-2014)	Smart key system	1.All keys lost 2.Add keys<ACT4> 3.All smart keys lost 4.Add smart keys 5.Live data 6.Switch ignition on 7.Erase DTC

MAZDA	Africa	Mazda 2(2008-2014)	Non smart key	1.Number of keys 2.Add a key 3.All Keys lost
MAZDA	Africa	Mazda 2(2014-)	Smart key system	1.All smart keys lost 2.Add a smart key 3.Switch ignition on
MAZDA	Africa	Mazda 3(2004-2008)	Smart key system	1.Number of keys 2.Add a key 3.All keys lost 4.Number of smart keys 5.Add a smart key 6.Erase smart keys
MAZDA	Africa	Mazda 3(2004-2008)	Non smart key	1.Number of keys 2.Add a key 3.All Keys lost
MAZDA	Africa	Mazda 3(2009-2013)	Smart key system	1.All keys lost 2.Add keys<ACT4> 3.All smart keys lost 4.Add smart keys 5.Live data 6.Switch ignition on 7.Erase DTC
MAZDA	Africa	Mazda 3(2009-2013)	Non smart key	1.Number of keys 2.Add a key 3.All Keys lost
MAZDA	Africa	Mazda 3(2014-)	Smart key system	1.All smart keys lost 2.Add a smart key 3.Switch ignition on
MAZDA	Africa	Mazda 5(-2011)	Non smart key	1.Number of keys 2.Add a key 3.All Keys lost
MAZDA	Africa	Mazda 5(2012-)	Non smart key	1.Number of keys 2.Add a key 3.All Keys lost
MAZDA	Africa	Mazda 6(2002-2008)	Non smart key	1.Number of keys 2.Add a key 3.All keys lost

MAZDA	Africa	Mazda 6(2008-2012)	Smart key system	1.All keys lost 2.Add keys<ACT4> 3.All smart keys lost 4.Add smart keys 5.Live data 6.Switch ignition on 7.Erase DTC
MAZDA	Africa	Mazda 6(2012-)	Smart key system	1.All smart keys lost 2.Add a smart key 3.Switch ignition on
MAZDA	Africa	Mazda CX-3(2016-)	Smart key system	1.All smart keys lost 2.Add a smart key 3.Switch ignition on
MAZDA	Africa	Mazda CX-5(2013-)	Smart key system	1.All smart keys lost 2.Add a smart key 3.Switch ignition on
MAZDA	Africa	Mazda CX-7(-2016)	Smart key system	1.Add key 2.All keys lost 3.Add smart key 4.Erase smart keys 5.Read number of keys
MAZDA	Africa	Mazda CX-7(2004-2009)	Non smart key	1.Number of keys 2.Add a key 3.All Keys lost
MAZDA	Africa	Mazda CX-7(2009-)	Non smart key	1.Number of keys 2.Add a key 3.All Keys lost
MAZDA	Africa	Mazda CX-9(2004-2009)	Non smart key	1.Number of keys 2.Add a key 3.All Keys lost
MAZDA	Africa	Mazda CX-9(2009-)	Non smart key	1.Number of keys 2.Add a key 3.All Keys lost
MAZDA	Africa	Mazda CX-9(2009-)	Smart key system	1.All smart keys lost 2.Add a smart key 3.Switch ignition on
MAZDA	Africa	Demio(-2001)	Non smart key	1.Current number of keys 2.All Keys Lost 3.Add Key

MAZDA	Africa	Demio(2002-2007)	Non smart key	1.All smart keys lost 2.Add a smart key 3.Switch ignition on
MAZDA	Africa	Demio(2008-)	Smart key system	1.All keys lost 2.Add keys<ACT4> 3.All smart keys lost 4.Add smart keys 5.Live data 6.Switch ignition on 7.Erase DTC
MAZDA	Africa	Demio(2008-)	Non smart key	1.All smart keys lost 2.Add a smart key 3.Switch ignition on
MAZDA	Africa	MX5(2005-2009)	Non smart key	1.All smart keys lost 2.Add a smart key 3.Switch ignition on
MAZDA	Africa	MX5(2009-2015)	Non smart key	1.All smart keys lost 2.Add a smart key 3.Switch ignition on
MAZDA	Africa	MX5(2016-)	Smart key system	1.All smart keys lost 2.Add a smart key 3.Switch ignition on
MAZDA	Africa	Premacy(2005-)	Non smart key	1.All smart keys lost 2.Add a smart key 3.Switch ignition on
MAZDA	Africa	Premacy(2005-)	Smart key system	1.All keys lost 2.Add keys 3.All smart keys lost 4.Add smart keys 5.Live data 6.Switch ignition on 7.Erase DTC
MAZDA	Africa	RX-8(2004-2009)	Non smart key	1.Number of keys 2.Add a key 3.All keys lost
MAZDA	Africa	RX-8(2009-)	Non smart key	1.Number of keys 2.Add a key 3.All Keys lost
MAZDA	Africa	RX-8(2009-)	Smart key system	1.Number of keys 2.Add a key 3.All keys lost

MAZDA	Asia	BT-50(2011)	Non smart key	1.Add key 2.Erase keys 3.All lost 4.Number of key
MAZDA	Asia	Mazda 121	Non smart key	1.Current number of keys 2.All Keys Lost 3.Add Key
MAZDA	Asia	Mazda 2(2002-2008)	Non smart key	1.Number of keys 2.Add a key 3.All keys lost
MAZDA	Asia	Mazda 2(2008-2014)	Smart key system	1.All keys lost 2.Add keys 3.All smart keys lost 4.Add smart keys 5.Live data 6.Switch ignition on 7.Erase DTC
MAZDA	Asia	Mazda 2(2008-2014)	Non smart key	1.Number of keys 2.Add a key 3.All Keys lost
MAZDA	Asia	Mazda 2(2014-)	Smart key system	1.All smart keys lost 2.Add a smart key 3.Switch ignition on
MAZDA	Asia	Mazda 3(2004-2008)	Smart key system	1.Number of keys 2.Add a key 3.All keys lost 4.Number of smart keys 5.Add a smart key 6.Erase smart keys
MAZDA	Asia	Mazda 3(2004-2008)	Non smart key	1.Number of keys 2.Add a key 3.All Keys lost
MAZDA	Asia	Mazda 3(2009-2013)	Smart key system	1.All keys lost 2.Add keys 3.All smart keys lost 4.Add smart keys 5.Live data 6.Switch ignition on 7.Erase DTC

MAZDA	Asia	Mazda 3(2009-2013)	Non smart key	1.Number of keys 2.Add a key 3.All Keys lost
MAZDA	Asia	Mazda 3(2014-)	Smart key system	1.All smart keys lost 2.Add a smart key 3.Switch ignition on
MAZDA	Asia	Mazda 5(-2011)	Non smart key	1.Number of keys 2.Add a key 3.All Keys lost
MAZDA	Asia	Mazda 5(2012-)	Non smart key	1.Number of keys 2.Add a key 3.All Keys lost
MAZDA	Asia	Mazda 6(2002-2008)	Non smart key	1.Number of keys 2.Add a key 3.All keys lost
MAZDA	Asia	Mazda 6(2008-2012)	Smart key system	1.All keys lost 2.Add keys 3.All smart keys lost 4.Add smart keys 5.Live data 6.Switch ignition on 7.Erase DTC
MAZDA	Asia	Mazda 6(2012-)	Smart key system	1.All smart keys lost 2.Add a smart key 3.Switch ignition on
MAZDA	Asia	Mazda CX-3(2016-)	Smart key system	1.All smart keys lost 2.Add a smart key 3.Switch ignition on
MAZDA	Asia	Mazda CX-5(2013-)	Smart key system	1.All smart keys lost 2.Add a smart key 3.Switch ignition on
MAZDA	Asia	Mazda CX-7(-2016)	Smart key system	1.Add key 2.All keys lost 3.Add smart key 4.Erase smart keys 5.Read number of keys
MAZDA	Asia	Mazda CX-7(2004-2009)	Non smart key	1.Number of keys 2.Add a key 3.All Keys lost

MAZDA	Asia	Mazda CX-7(2009-)	Non smart key	1.Number of keys 2.Add a key 3.All Keys lost
MAZDA	Asia	Mazda CX-9(2004-2009)	Non smart key	1.Number of keys 2.Add a key 3.All Keys lost
MAZDA	Asia	Mazda CX-9(2009-)	Non smart key	1.Number of keys 2.Add a key 3.All Keys lost
MAZDA	Asia	Mazda CX-9(2009-)	Smart key system	1.All smart keys lost 2.Add a smart key 3.Switch ignition on
MAZDA	Asia	Demio(-2001)	Non smart key	1.Current number of keys 2.All Keys Lost 3.Add Key
MAZDA	Asia	Demio(2002-2007)	Non smart key	1.Number of keys 2.Add a key 3.All Keys lost
MAZDA	Asia	Demio(2008-2013)	Smart key system	1.All keys lost 2.Add keys 3.All smart keys lost 4.Add smart keys 5.Live data 6.Switch ignition on 7.Erase DTC
MAZDA	Asia	Demio(2008-2013)	Non smart key	1.Number of keys 2.Add a key 3.All Keys lost
MAZDA	Asia	Demio(2014-)	Smart key system	1.All smart keys lost 2.Add a smart key 3.Switch ignition on
MAZDA	Asia	Mx5(2005-2009)	Non smart key	1.Number of keys 2.Add a key 3.All Keys lost
MAZDA	Asia	Mx5(2009-2015)	Non smart key	1.Number of keys 2.Add a key 3.All Keys lost
MAZDA	Asia	Mx5(2016-)	Smart key system	1.All smart keys lost 2.Add a smart key 3.Switch ignition on

MAZDA	Asia	Premacy(2005-)	Non smart key	1.Number of keys 2.Add a key 3.All Keys lost
	Asia	Premacy(2005-)	Smart key system	1.All keys lost 2.Add keys 3.All smart keys lost 4.Add smart keys 5.Live data 6.Switch ignition on 7.Erase DTC
MAZDA	Asia	RX-8(2004-2009)	Non smart key	1.Number of keys 2.Add a key 3.All keys lost
MAZDA	Asia	RX-8(2009-)	Non smart key	1.Number of keys 2.Add a key 3.All Keys lost
MAZDA	Asia	RX-8(2009-)	Smart key system	1.Number of keys 2.Add a key 3.All keys lost
MAZDA	Australia	BT-50(2011-)	Non smart key	1.Add key 2.Erase keys 3.All lost 4.Number of key
MAZDA	Australia	Mazda 121	Non smart key	1.Current number of keys 2.All Keys Lost 3.Add Key
MAZDA	Australia	Mazda 2(2002-2008)	Non smart key	1.Number of keys 2.Add a key 3.All keys lost
MAZDA	Australia	Mazda 2(2008-2014)	Smart key system	1.All keys lost 2.Add keys 3.All smart keys lost 4.Add smart keys 5.Live data 6.Switch ignition on 7.Erase DTC
MAZDA	Australia	Mazda 2(2008-2014)	Non smart key	1.Number of keys 2.Add a key 3.All Keys lost

MAZDA	Australia	Mazda 2(2014-)	Smart key system	1.All smart keys lost 2.Add a smart key 3.Switch ignition on
MAZDA	Australia	Mazda 3(2004-2008)	Smart key system	1.Number of keys 2.Add a key 3.All keys lost 4.Number of smart keys 5.Add a smart key 6.Erase smart keys
MAZDA	Australia	Mazda 3(2004-2008)	Non smart key	1.Number of keys 2.Add a key 3.All Keys lost
MAZDA	Australia	Mazda 3(2009-2013)	Smart key system	1.All keys lost 2.Add keys 3.All smart keys lost 4.Add smart keys 5.Live data 6.Switch ignition on 7.Erase DTC
MAZDA	Australia	Mazda 3(2009-2013)	Non smart key	1.Number of keys 2.Add a key 3.All Keys lost
MAZDA	Australia	Mazda 3(2014-)	Smart key system	1.All smart keys lost 2.Add a smart key 3.Switch ignition on
MAZDA	Australia	Mazda 5(-2011)	Non smart key	1.Number of keys 2.Add a key 3.All Keys lost
MAZDA	Australia	Mazda 5(2012-)	Non smart key	1.Number of keys 2.Add a key 3.All Keys lost
MAZDA	Australia	Mazda 6(2002-2008)	Non smart key	1.Number of keys 2.Add a key 3.All keys lost
MAZDA	Australia	Mazda 6(2008-2012)	Smart key system	1.All keys lost 2.Add keys 3.All smart keys lost 4.Add smart keys 5.Live data 6.Switch ignition on 7.Erase DTC

MAZDA	Australia	Mazda 6(2012-)	Smart key system	1.All smart keys lost 2.Add a smart key 3.Switch ignition on
MAZDA	Australia	Mazda CX-3(2016-)	Smart key system	1.All smart keys lost 2.Add a smart key 3.Switch ignition on
MAZDA	Australia	Mazda CX-5(2013-)	Smart key system	1.All smart keys lost 2.Add a smart key 3.Switch ignition on
MAZDA	Australia	Mazda CX-7(-2016)	Smart key system	1.Add key 2.All keys lost 3.Add smart key 4.Erase smart keys 5.Read number of keys
MAZDA	Australia	Mazda CX-7(2004-2009)	Non smart key	1.Number of keys 2.Add a key 3.All keys lost
MAZDA	Australia	Mazda CX-7(2009-)	Non smart key	1.Number of keys 2.Add a key 3.All keys lost
MAZDA	Australia	Mazda CX-9(2004-2009)	Non smart key	1.Number of keys 2.Add a key 3.All keys lost
MAZDA	Australia	Mazda CX-9(2009-)	Non smart key	1.Number of keys 2.Add a key 3.All keys lost
MAZDA	Australia	Mazda CX-9(2009-)	Smart key system	1.All smart keys lost 2.Add a smart key 3.Switch ignition on
MAZDA	Australia	Demio(-2001)	Non smart key	1.Current number of keys 2.All Keys Lost 3.Add Key
MAZDA	Australia	Demio(2002-2007)	Non smart key	1.Number of keys 2.Add a key 3.All keys lost

MAZDA	Australia	Demio(2008-2013)	Smart key system	1.All keys lost 2.Add keys 3.All smart keys lost 4.Add smart keys 5.Live data 6.Switch ignition on 7.Erase DTC
MAZDA	Australia	Demio(2008-2013)	Non smart key	1.Number of keys 2.Add a key 3.All keys lost
MAZDA	Australia	Demio(2014-)	Smart key system	1.All smart keys lost 2.Add a smart key 3.Switch ignition on
MAZDA	Australia	Mx5(2005-2009)	Non smart key	1.Number of keys 2.Add a key 3.All keys lost
MAZDA	Australia	Mx5(2009-2015)	Non smart key	1.Number of keys 2.Add a key 3.All keys lost
MAZDA	Australia	Mx5(2016-)	Smart key system	1.All smart keys lost 2.Add a smart key 3.Switch ignition on
MAZDA	Australia	Premacy(2005-)	Non smart key	1.Number of keys 2.Add a key 3.All keys lost
MAZDA	Australia	Premacy(2005-)	Smart key system	1.All keys lost 2.Add keys 3.All smart keys lost 4.Add smart keys 5.Live data 6.Switch ignition on 7.Erase DTC
MAZDA	Australia	RX-8(2004-2009)	Non smart key	1.Number of keys 2.Add a key 3.All keys lost
MAZDA	Australia	RX-8(2009-)	Non smart key	1.Number of keys 2.Add a key 3.All Keys lost

MAZDA	Australia	RX-8(2009-)	Smart key system	1.All keys lost 2.Add keys 3.All smart keys lost 4.Add smart keys 5.Live data 6.Switch ignition on 7.Erase DTC
MAZDA	Europe	BT-50(2011-)	Non smart key	1.Add key 2.Erase keys 3.All lost 4.Number of key
MAZDA	Europe	Mazda 121	Non smart key	1.Current number of keys 2.All Keys Lost 3.Add Key
MAZDA	Europe	Mazda 2(2002-2008)	Non smart key	1.Number of keys 2.Add a key 3.All keys lost
MAZDA	Europe	Mazda 2(2008-2014)	Smart key system	1.All keys lost 2.Add keys 3.All smart keys lost 4.Add smart keys 5.Live data 6.Switch ignition on 7.Erase DTC
MAZDA	Europe	Mazda 2(2008-2014)	Non smart key	1.Number of keys 2.Add a key 3.All Keys lost
MAZDA	Europe	Mazda 2(2014-)	Smart key system	1.All smart keys lost 2.Add a smart key 3.Switch ignition on
MAZDA	Europe	Mazda 3(2004-2008)	Smart key system	1.Number of keys 2.Add a key 3.All keys lost 4.Number of smart keys 5.Add a smart key 6.Erase smart keys
MAZDA	Europe	Mazda 3(2004-2008)	Non smart key	1.Number of keys 2.Add a key 3.All Keys lost

MAZDA	Europe	Mazda 3(2009-2013)	Smart key system	1.All keys lost 2.Add keys 3.All smart keys lost 4.Add smart keys 5.Live data 6.Switch ignition on 7.Erase DTC
MAZDA	Europe	Mazda 3(2009-2013)	Non smart key	1.Number of keys 2.Add a key 3.All Keys lost
MAZDA	Europe	Mazda 3(2014-)	Smart key system	1.All smart keys lost 2.Add a smart key 3.Switch ignition on
MAZDA	Europe	Mazda 5(-2011)	Non smart key	1.Number of keys 2.Add a key 3.All Keys lost
MAZDA	Europe	Mazda 5(2012-)	Non smart key	1.Number of keys 2.Add a key 3.All Keys lost
MAZDA	Europe	Mazda 6(2002-2008)	Non smart key	1.Number of keys 2.Add a key 3.All keys lost
MAZDA	Europe	Mazda 6(2008-2012)	Smart key system	1.All keys lost 2.Add keys 3.All smart keys lost 4.Add smart keys 5.Live data 6.Switch ignition on 7.Erase DTC
MAZDA	Europe	Mazda 6(2012-)	Smart key system	1.All smart keys lost 2.Add a smart key 3.Switch ignition on
MAZDA	Europe	Mazda CX-3(2016-)	Smart key system	1.All smart keys lost 2.Add a smart key 3.Switch ignition on
MAZDA	Europe	Mazda CX-5(2013-)	Smart key system	1.All smart keys lost 2.Add a smart key 3.Switch ignition on

MAZDA	Europe	Mazda CX-7(-2016)	Smart key system	1.Add key 2.All keys lost 3.Add smart key 4.Erase smart keys 5.Read number of keys
MAZDA	Europe	Mazda CX-7(2004-2009)	Non smart key	1.Number of keys 2.Add a key 3.All Keys lost
MAZDA	Europe	Mazda CX-7(2009-)	Non smart key	1.Number of keys 2.Add a key 3.All Keys lost
MAZDA	Europe	Mazda CX-9(2004-2009)	Non smart key	1.Number of keys 2.Add a key 3.All Keys lost
MAZDA	Europe	Mazda CX-9(2009-)	Non smart key	1.Number of keys 2.Add a key 3.All Keys lost
MAZDA	Europe	Mazda CX-9(2009-)	Smart key system	1.All smart keys lost 2.Add a smart key 3.Switch ignition on
MAZDA	Europe	Demio(-2001)	Non smart key	1.Current number of keys 2.All Keys Lost 3.Add Key
MAZDA	Europe	Demio(2002-2007)	Non smart key	1.Number of keys 2.Add a key 3.All Keys lost
MAZDA	Europe	Demio(2008-2013)	Smart key system	1.All keys lost 2.Add keys 3.All smart keys lost 4.Add smart keys 5.Live data 6.Switch ignition on 7.Erase DTC
MAZDA	Europe	Demio(2008-2013)	Non smart key	1.Number of keys 2.Add a key 3.All Keys lost
MAZDA	Europe	Demio(2014-)	Smart key system	1.All smart keys lost 2.Add a smart key 3.Switch ignition on

MAZDA	Europe	Mx5(2005-2009)	Non smart key	1.Number of keys 2.Add a key 3.All Keys lost
MAZDA	Europe	Mx5(2009-2015)	Non smart key	1.Number of keys 2.Add a key 3.All Keys lost
MAZDA	Europe	Mx5(2016-)	Smart key system	1.All smart keys lost 2.Add a smart key 3.Switch ignition on
MAZDA	Europe	Premacy(2005-)	Non smart key	1.Number of keys 2.Add a key 3.All Keys lost
MAZDA	Europe	Premacy(2005-)	Smart key system	1.All keys lost 2.Add keys 3.All smart keys lost 4.Add smart keys 5.Live data 6.Switch ignition on 7.Erase DTC
MAZDA	Europe	RX-8(2004-2009)	Non smart key	1.Number of keys 2.Add a key 3.All keys lost
MAZDA	Europe	RX-8(2009-)	Non smart key	1.Number of keys 2.Add a key 3.All Keys lost
MAZDA	Europe	RX-8(2009-)	Smart key system	1.Number of keys 2.Add a key 3.All keys lo
MAZDA	North America	B-Series(-2007)	Non smart key	1.Current number of keys 2.All Keys Lost 3.Add Key
MAZDA	North America	B-Series(2007-2011)	Non smart key	1.Number of keys 2.Add a key 3.All Keys lost
MAZDA	North America	Mazda 3(2004-2005)	Non smart key	1.Number of keys 2.Add a key 3.All keys lost
MAZDA	North America	Mazda 3(2006-2009)	Non smart key	1.Number of keys 2.Add a key 3.All Keys lost

MAZDA	North America	Mazda 5(2006-2011)	Non smart key	1.Number of keys 2.Add a key 3.All Keys lost
MAZDA	North America	Mazda 6(2003-2008)	Non smart key	1.Number of keys 2.Add a key 3.All Keys lost
MAZDA	North America	Mazda CX-7(2004-2006)	Non smart key	1.Number of keys 2.Add a key 3.All Keys lost
MAZDA	North America	Mazda CX-7(2007-2014)	Non smart key	1.Number of keys 2.Add a key 3.All Keys lost
MAZDA	North America	Mazda CX-9(2004-2006)	Non smart key	1.Number of keys 2.Add a key 3.All Keys lost
MAZDA	North America	Mazda CX-9(2007-2014)	Non smart key	1.Number of keys 2.Add a key 3.All Keys lost
MAZDA	North America	Mx5(2004-2005)	Non smart key	1.Number of keys 2.Add a key 3.All Keys lost
MAZDA	North America	Mx5(2005-2013)	Non smart key	1.Number of keys 2.Add a key 3.All Keys lost
MAZDA	North America	RX-8(2004-2005)	Non smart key	1.Number of keys 2.Add a key 3.All keys lost
MAZDA	North America	Tribute(2005-2008)	Non smart key	1.Number of keys 2.Add a key 3.All keys lost
MAZDA	North America	Tribute(2009-2011)	Smart key system	1.Number of keys 2.All keys lost 3.Add a key
MAZDA	South America	BT-50(2011-)	Non smart key	1.Add key 2.Erase keys 3.All lost 4.Number of key
MAZDA	South America	Mazda 121	Non smart key	1.Current number of keys 2.All Keys Lost 3.Add Key

MAZDA	South America	Mazda 2(2002-2008)	Non smart key	1.Number of keys 2.Add a key 3.All keys lost
MAZDA	South America	Mazda 2(2008-2014)	Smart key system	1.All keys lost 2.Add keys 3.All smart keys lost 4.Add smart keys 5.Live data 6.Switch ignition on 7.Erase DTC
MAZDA	South America	Mazda 2(2008-2014)	Non smart key	1.Number of keys 2.Add a key 3.All keys lost
MAZDA	South America	Mazda 2(2014-)	Smart key system	1.All smart keys lost 2.Add a smart key 3.Switch ignition on
MAZDA	South America	Mazda 3(2004-2008)	Smart key system	1.Number of keys 2.Add a key 3.All keys lost 4.Number of smart keys 5.Add a smart key 6.Erase smart keys
MAZDA	South America	Mazda 3(2004-2008)	Non smart key	1.Number of keys 2.Add a key 3.All keys lost
MAZDA	South America	Mazda 3(2009-2013)	Smart key system	1.All keys lost 2.Add keys 3.All smart keys lost 4.Add smart keys 5.Live data 6.Switch ignition on 7.Erase DTC
MAZDA	South America	Mazda 3(2009-2013)	Non smart key	1.Number of keys 2.Add a key 3.All keys lost
MAZDA	South America	Mazda 3(2014-)	Smart key system	1.All smart keys lost 2.Add a smart key 3.Switch ignition on
MAZDA	South America	Mazda 5(-2011)	Non smart key	1.Number of keys 2.Add a key 3.All keys lost

MAZDA	South America	Mazda 5(2012-)	Non smart key	1.Number of keys 2.Add a key 3.All keys lost
MAZDA	South America	Mazda 6(2002-2008)	Non smart key	1.Number of keys 2.Add a key 3.All keys lost
MAZDA	South America	Mazda 6(2008-2012)	Smart key system	1.All keys lost 2.Add keys 3.All smart keys lost 4.Add smart keys 5.Live data 6.Switch ignition on 7.Erase DTC
MAZDA	South America	Mazda 6(2012-)	Smart key system	1.All smart keys lost 2.Add a smart key 3.Switch ignition on
MAZDA	South America	Mazda CX-3(2016-)	Smart key system	1.All smart keys lost 2.Add a smart key 3.Switch ignition on
MAZDA	South America	Mazda CX-5(2013-)	Smart key system	1.All smart keys lost 2.Add a smart key 3.Switch ignition on
MAZDA	South America	Mazda CX-7(-2016)	Smart key system	1.Add key 2.All keys lost 3.Add smart key 4.Erase smart keys 5.Read number of keys
MAZDA	South America	Mazda CX-7(2004-2009)	Non smart key	1.Number of keys 2.Add a key 3.All keys lost
MAZDA	South America	Mazda CX-7(2009-)	Non smart key	1.Number of keys 2.Add a key 3.All keys lost
MAZDA	South America	Mazda CX-9(2004-2009)	Non smart key	1.Number of keys 2.Add a key 3.All keys lost
MAZDA	South America	Mazda CX-9(2009-)	Non smart key	1.Number of keys 2.Add a key 3.All keys lost

MAZDA	South America	Mazda CX-9(2009-)	Smart key system	1.All smart keys lost 2.Add a smart key 3.Switch ignition on
MAZDA	South America	Demio(-2001)	Non smart key	1.Current number of keys 2.All Keys Lost 3.Add Key
MAZDA	South America	Demio(2002-2007)	Non smart key	1.Number of keys 2.Add a key 3.All keys lost
MAZDA	South America	Demio(2008-2013)	Smart key system	1.All keys lost 2.Add keys 3.All smart keys lost 4.Add smart keys 5.Live data 6.Switch ignition on 7.Erase DTC
MAZDA	South America	Demio(2008-2013)	Non smart key	1.Number of keys 2.Add a key 3.All keys lost
MAZDA	North America	Demio(2014-)	Non smart key	1.Number of keys 2.Add a key 3.All keys lost
MAZDA	North America	Mx5(2005-2009)	Non smart key	1.Number of keys 2.Add a key 3.All keys lost
MAZDA	North America	Mx5(2009-2015)	Smart key system	1.Number of keys 2.Add a key 3.All keys lost