



深圳市朗仁科技有限公司
Shenzhen Xtooltech Co., Ltd

MAZDA V26.83

Description: ○: All support by OBD

△: Partially support by OBD

□: All support (Disassembly)

●: All support by OBD(Need accessories)

▲: Partially support by OBD(Need accessories)

■: Partially support (Disassembly)

✗: Not support

/:Unnecessary

◎: Conditional support

Make	Area	Model	Year	Key Type	Read PIN	Add Keys	All Keys Lost	Programme Remote	Other Functions
MAZDA	China	马自达 2	2008-2014	Smart key	/	○	○	/	1. All keys lost 2. Add keys 3. All smart keys lost 4. Add smart keys 5. Live data 6. Switch ignition on 7. Program immo. and PCM 8. Erase DTC
MAZDA	China	马自达 2	2014-2016	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	China	马自达 2	2017-	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	China	马自达 2	2002-2008	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All Keys lost
MAZDA	China	马自达 2	2008-2014	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Program immo. and PCM

MAZDA	China	Mazda 3 老款		Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. Erase keys 4. Program immo. and PCM
MAZDA	China	Mazda 3 新款		Smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Program immo. and PCM
MAZDA	China	Mazda 3(星骋)	2011-	Smart key	/	○	○	/	1. All keys lost 2. Add keys 3. All smart keys lost 4. Add smart keys 5. Live data 6. Switch ignition on 7. Program immo. and PCM 8. Erase DTC
MAZDA	China	Mazda 3(星骋)	2011-	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Program immo. and PCM
MAZDA	China	Mazda3 Axela(昂克塞拉)	-2016	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	China	Mazda3 Axela(昂克塞拉)	2017-	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	China	Mazda 5 老款		Smart key	/	○	○	/	1. Number of keys 2. Add a key 3. Erase keys 4. Program immo. and PCM
MAZDA	China	Mazda 5 新款		Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Program immo. and PCM

MAZDA	China	Mazda 6		Smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Number of smart keys 5. Add a smart key 6. Erase smart keys 7. Program immo. and PCM
MAZDA	China	Mazda 6		Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All Keys lost
MAZDA	China	Mazda6(睿翼)	2008-	Smart key	/	○	○	/	1. All keys lost 2. Add keys 3. All smart keys lost 4. Add smart keys 5. Live data 6. Switch ignition on 7. Program immo. and PCM 8. Erase DTC

MAZDA	China	Mazda6(睿翼)	2008-	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Program immo. and PCM
MAZDA	China	Mazda6 Atenza(阿特兹)	-2016	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	China	Mazda6 Atenza(阿特兹)	2017-	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	China	Mazda8		Smart key	/	○	○	/	1. Add key 2. All keys lost 3. Add smart key 4. Erase smart keys 5. Read number of keys 6. Program immo. and PCM
MAZDA	China	Mazda8		Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Program immo. and PCM
MAZDA	China	Mazda CX-3	-2016	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	China	Mazda CX-3	2017-	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	China	Mazda CX-4	-2016	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	China	Mazda CX-4	2017-	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM

MAZDA	China	Mazda CX-5	-2016	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	China	Mazda CX-5	2017-	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	China	Mazda CX-7	2004-2009	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. Erase keys 4. Program immo. and PCM
MAZDA	China	Mazda CX-7	2009-	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Program immo. and PCM
MAZDA	China	Mazda CX-7	-2016	Smart key	/	○	○	/	1. Add key 2. All keys lost 3. Add smart key 4. Erase smart keys 5. Read number of keys 6. Program immo. and PCM
MAZDA	China	Mazda CX-7	2016	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	China	Mazda CX-7	2017-	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	China	Mazda CX-9	2004-2009	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. Erase keys 4. Program immo. and PCM
MAZDA	China	Mazda CX-9	2009-	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Program immo. and PCM

MAZDA	China	Mazda CX-9	-2016	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	China	Mazda CX-9	2017-	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	Africa	BT-50	2011-		/	○	○	/	1. Add key 2. Erase keys 3. All keys lost 4. Number of key
MAZDA	Africa	Mazda 2	2002-2008	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All Keys lost
MAZDA	Africa	Mazda 2	2008-2014	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Program immo. and PCM
MAZDA	Africa	Mazda 2	2008-2014	Smart key	/	○	○	/	1. All keys lost 2. Add keys 3. All smart keys lost 4. Add smart keys 5. Live data 6. Switch ignition on 7. Program immo. and PCM 8. Erase DTC
MAZDA	Africa	Mazda 2	2014-2016	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	Africa	Mazda 2	2017-	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM

MAZDA	Africa	Mazda 3	2004–2008	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. Erase keys 4. Program immo. and PCM
MAZDA	Africa	Mazda 3	2009–2013	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Program immo. and PCM
MAZDA	Africa	Mazda 3	2004–2008	Smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Number of smart keys 5. Add a smart key 6. Erase smart keys 7. Program immo. and PCM
MAZDA	Africa	Mazda 3	2009–2013	Smart key	/	○	○	/	1. All keys lost 2. Add keys 3. All smart keys lost 4. Add smart keys 5. Live data 6. Switch ignition on 7. Program immo. and PCM 8. Erase DTC
MAZDA	Africa	Mazda 3	2014–2016	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	Africa	Mazda 3	2017–	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	Africa	Mazda 5	-2011	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. Erase keys 4. Program immo. and PCM
MAZDA	Africa	Mazda 5	2012–	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Program immo. and PCM

MAZDA	Africa	Mazda 6	2002-2008	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All Keys lost
MAZDA	Africa	Mazda 6	2008-2012	Smart key	/	○	○	/	1. All keys lost 2. Add keys 3. All smart keys lost 4. Add smart keys 5. Live data 6. Switch ignition on 7. Program immo. and PCM 8. Erase DTC
MAZDA	Africa	Mazda 6	2012-2016	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	Africa	Mazda 6	2017-	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	Africa	Mazda CX-3	-2017	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	Africa	Mazda CX-3	2017-	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	Africa	Mazda CX-5	2013-2016	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	Africa	Mazda CX-5	2017-	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM

MAZDA	Africa	Mazda CX-7	2004-2009	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. Erase keys 4. Program immo. and PCM
MAZDA	Africa	Mazda CX-7	2009-	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Program immo. and PCM
MAZDA	Africa	Mazda CX-7	-2016	Smart key	/	○	○	/	1. Add key 2. All keys lost 3. Add smart key 4. Erase smart keys 5. Read number of keys 6. Program immo. and PCM
MAZDA	Africa	Mazda CX-9	2004-2009	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. Erase keys 4. Program immo. and PCM
MAZDA	Africa	Mazda CX-9	2009-	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Program immo. and PCM
MAZDA	Africa	Mazda CX-9	2009-2016	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	Africa	Mazda CX-9	2017-	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	Africa	Demio	-2001	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Program immo. and PCM
MAZDA	Africa	Demio	2002-2007	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. Erase keys 4. Program immo. and PCM

MAZDA	Africa	Demio	2008-	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Program immo. and PCM
MAZDA	Africa	Demio	2008-	Smart key	/	○	○	/	1. All keys lost 2. Add keys 3. All smart keys lost 4. Add smart keys 5. Live data 6. Switch ignition on 7. Program immo. and PCM 8. Erase DTC
MAZDA	Africa	Mx5	2005–2009	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. Erase keys 4. Program immo. and PCM
MAZDA	Africa	Mx5	2009–2015	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Program immo. and PCM
MAZDA	Africa	Mx5	2016	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	Africa	Mx5	2017–	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	Africa	Premacy	2005–	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. Erase keys 4. Program immo. and PCM

MAZDA	Africa	Premacy	2005-	Smart key	/	○	○	/	1. All keys lost 2. Add keys 3. All smart keys lost 4. Add smart keys 5. Live data 6. Switch ignition on 7. Program immo. and PCM 8. Erase DTC
MAZDA	Africa	RX-8	2004-2009	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Program immo. and PCM
MAZDA	Africa	RX-8	2009-	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. Erase keys 4. Program immo. and PCM
MAZDA	Africa	RX-8	2009-	Smart key	/	○	○	/	1. Add key 2. All keys lost 3. Add smart key 4. Erase smart keys 5. Read number of keys 6. Program immo. and PCM
MAZDA	Asia	BT-50	2011-		/	○	○	/	1. Add key 2. Erase keys 3. All keys lost 4. Number of key
MAZDA	Asia	Mazda 121			/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Program immo. and PCM
MAZDA	Asia	Mazda 2	2002-2008	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All Keys lost
MAZDA	Asia	Mazda 2	2008-2014	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Program immo. and PCM

MAZDA	Asia	Mazda 2	2008-2014	Smart key	/	○	○	/	1. All keys lost 2. Add keys 3. All smart keys lost 4. Add smart keys 5. Live data 6. Switch ignition on 7. Program immo. and PCM 8. Erase DTC
MAZDA	Asia	Mazda 2	2014-2016	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	Asia	Mazda 2	2017-	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	Asia	Mazda 3	2004-2008	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. Erase keys 4. Program immo. and PCM
MAZDA	Asia	Mazda 3	2009-2013	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Program immo. and PCM
MAZDA	Asia	Mazda 3	2004-2008	Smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Number of smart keys 5. Add a smart key 6. Erase smart keys 7. Program immo. and PCM
MAZDA	Asia	Mazda 3	2009-2013	Smart key	/	○	○	/	1. All keys lost 2. Add keys 3. All smart keys lost 4. Add smart keys 5. Live data 6. Switch ignition on 7. Program immo. and PCM 8. Erase DTC

MAZDA	Asia	Mazda 3	2014-2016	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	Asia	Mazda 3	2017-	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	Asia	Mazda 5	-2011	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. Erase keys 4. Program immo. and PCM
MAZDA	Asia	Mazda 5	2012-	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Program immo. and PCM
MAZDA	Asia	Mazda 6	2002-2008	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All Keys lost
MAZDA	Asia	Mazda 6	2008-2012	Smart key	/	○	○	/	1. All keys lost 2. Add keys 3. All smart keys lost 4. Add smart keys 5. Live data 6. Switch ignition on 7. Program immo. and PCM 8. Erase DTC
MAZDA	Asia	Mazda 6	2012-2016	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	Asia	Mazda 6	2017-	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM

MAZDA	Asia	Mazda CX-3	2016	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	Asia	Mazda CX-3	2017-	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	Asia	Mazda CX-5	2013-2016	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	Asia	Mazda CX-5	2017-	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	Asia	Mazda CX-7	2004-2009	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. Erase keys 4. Program immo. and PCM
MAZDA	Asia	Mazda CX-7	2009-	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Program immo. and PCM
MAZDA	Asia	Mazda CX-7	-2016	智能钥匙	/	○	○	/	1. Add key 2. All keys lost 3. Add smart key 4. Erase smart keys 5. Read number of keys 6. Program immo. and PCM
MAZDA	Asia	Mazda CX-9	2004-2009	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. Erase keys 4. Program immo. and PCM
MAZDA	Asia	Mazda CX-9	2009-	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Program immo. and PCM

MAZDA	Asia	Mazda CX-9	2009–2016	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	Asia	Mazda CX-9	2017–	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	Asia	Demio	-2001	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Program immo. and PCM
MAZDA	Asia	Demio	2002–2007	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. Erase keys 4. Program immo. and PCM
MAZDA	Asia	Demio	2008–2013	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Program immo. and PCM
MAZDA	Asia	Demio	2008–2013	Smart key	/	○	○	/	1. All keys lost 2. Add keys 3. All smart keys lost 4. Add smart keys 5. Live data 6. Switch ignition on 7. Program immo. and PCM 8. Erase DTC
MAZDA	Asia	Demio	2014–2016	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	Asia	Demio	2017–	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM

MAZDA	Asia	Mx5	2005–2009	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. Erase keys 4. Program immo. and PCM
MAZDA	Asia	Mx5	2009–2015	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Program immo. and PCM
MAZDA	Asia	Mx5	2016	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	Asia	Mx5	2017–	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	Asia	Premacy	2005–	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. Erase keys 4. Program immo. and PCM
MAZDA	Asia	Premacy	2005–	Smart key	/	○	○	/	1. All keys lost 2. Add keys 3. All smart keys lost 4. Add smart keys 5. Live data 6. Switch ignition on 7. Program immo. and PCM 8. Erase DTC
MAZDA	Asia	RX-8	2004–2009	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Program immo. and PCM
MAZDA	Asia	RX-8	2009–	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. Erase keys 4. Program immo. and PCM

MAZDA	Asia	RX-8	2009-	Smart key	/	○	○	/	1. Add key 2. All keys lost 3. Add smart key 4. Erase smart keys 5. Read number of keys 6. Program immo. and PCM
MAZDA	Asia	MPV	2006-2016		/	○	○	/	1. Add key 2. All keys lost 3. Add smart key 4. Erase smart keys 5. Read number of keys 6. Program immo. and PCM
MAZDA	Asia	VERISA	2005-2015		/	○	○	/	1. Add key 2. All keys lost 3. Add smart key 4. Erase smart keys 5. Read number of keys 6. Program immo. and PCM
MAZDA	Australia	BT-50	2011-		/	○	○	/	1. Add key 2. Erase keys 3. All keys lost 4. Number of key
MAZDA	Australia	Mazda 121			/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Program immo. and PCM
MAZDA	Australia	Mazda 2	2002-2008	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost
MAZDA	Australia	Mazda 2	2008-2014	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Program immo. and PCM

MAZDA	Australia	Mazda 2	2008-2014	Smart key	/	○	○	/	1. All keys lost 2. Add keys 3. All smart keys lost 4. Add smart keys 5. Live data 6. Switch ignition on 7. Program immo. and PCM 8. Erase DTC
MAZDA	Australia	Mazda 2	2014-2016	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	Australia	Mazda 2	2017-	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	Australia	Mazda 3	2004-2008	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. Erase keys 4. Program immo. and PCM
MAZDA	Australia	Mazda 3	2009-2013	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Program immo. and PCM
MAZDA	Australia	Mazda 3	2004-2008	Smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Number of smart keys 5. Add a smart key 6. Erase smart keys 7. Program immo. and PCM
MAZDA	Australia	Mazda 3	2009-2013	Smart key	/	○	○	/	1. All keys lost 2. Add keys 3. All smart keys lost 4. Add smart keys 5. Live data 6. Switch ignition on 7. Program immo. and PCM 8. Erase DTC

MAZDA	Australia	Mazda 3	2014-2016	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	Australia	Mazda 3	2017-	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	Australia	Mazda 5	-2011	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. Erase keys 4. Program immo. and PCM
MAZDA	Australia	Mazda 5	2012-	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Program immo. and PCM
MAZDA	Australia	Mazda 6	2002-2008	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All Keys lost
MAZDA	Australia	Mazda 6	2008-2012	Smart key	/	○	○	/	1. All keys lost 2. Add keys 3. All smart keys lost 4. Add smart keys 5. Live data 6. Switch ignition on 7. Program immo. and PCM 8. Erase DTC
MAZDA	Australia	Mazda 6	2012-2016	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	Australia	Mazda 6	2017	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM

MAZDA	Australia	Mazda CX-3	2016	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	Australia	Mazda CX-3	2017	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	Australia	Mazda CX-5	2013-2016	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	Australia	Mazda CX-5	2017-	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	Australia	Mazda CX-7	2004-2009	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. Erase keys 4. Program immo. and PCM
MAZDA	Australia	Mazda CX-7	2009-	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Program immo. and PCM
MAZDA	Australia	Mazda CX-7	-2016	Smart key	/	○	○	/	1. Add key 2. All keys lost 3. Add smart key 4. Erase smart keys 5. Read number of keys 6. Program immo. and PCM
MAZDA	Australia	Mazda CX-9	2004-2009	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. Erase keys 4. Program immo. and PCM

MAZDA	Australia	Mazda CX-9	2009-	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Program immo. and PCM
MAZDA	Australia	Mazda CX-9	2009–2016	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	Australia	Mazda CX-9	2017	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	Australia	Demio	-2001	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Program immo. and PCM
MAZDA	Australia	Demio	2002–2007	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. Erase keys 4. Program immo. and PCM
MAZDA	Australia	Demio	2008–2013	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Program immo. and PCM
MAZDA	Australia	Demio	2008–2013	Smart key	/	○	○	/	1. All keys lost 2. Add keys 3. All smart keys lost 4. Add smart keys 5. Live data 6. Switch ignition on 7. Program immo. and PCM 8. Erase DTC

MAZDA	Australia	Demio	2014–2016	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	Australia	Demio	2017–	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	Australia	Mx5	2005–2009	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. Erase keys 4. Program immo. and PCM
MAZDA	Australia	Mx5	2009–2015	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Program immo. and PCM
MAZDA	Australia	Mx5	2016	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	Australia	Mx5	2017	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	Australia	Premacy	2005–	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. Erase keys 4. Program immo. and PCM
MAZDA	Australia	Premacy	2005–	Smart key	/	○	○	/	1. All keys lost 2. Add keys 3. All smart keys lost 4. Add smart keys 5. Live data 6. Switch ignition on 7. Program immo. and PCM 8. Erase DTC

MAZDA	Australia	RX-8	2004-2009	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Program immo. and PCM
MAZDA	Australia	RX-8	2009-	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. Erase keys 4. Program immo. and PCM
MAZDA	Australia	RX-8	2009-	Smart key	/	○	○	/	1. Add key 2. All keys lost 3. Add smart key 4. Erase smart keys 5. Read number of keys 6. Program immo. and PCM
MAZDA	Europe	BT-50	2011-		/	○	○	/	1. Add key 2. Erase keys 3. All keys lost 4. Number of key
MAZDA	Europe	Mazda 121			/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Program immo. and PCM
MAZDA	Europe	Mazda 2	2002-2008	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All Keys lost
MAZDA	Europe	Mazda 2	2008-2014	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Program immo. and PCM

MAZDA	Europe	Mazda 2	2008–2014	Smart key	/	○	○	/	1. All keys lost 2. Add keys 3. All smart keys lost 4. Add smart keys 5. Live data 6. Switch ignition on 7. Program immo. and PCM 8. Erase DTC
MAZDA	Europe	Mazda 2	2014–2016	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	Europe	Mazda 2	2017–	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	Europe	Mazda 3	2004–2008	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. Erase keys 4. Program immo. and PCM
MAZDA	Europe	Mazda 3	2009–2013	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Program immo. and PCM
MAZDA	Europe	Mazda 3	2004–2008	Smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Number of smart keys 5. Add a smart key 6. Erase smart keys 7. Program immo. and PCM

MAZDA	Europe	Mazda 3	2009–2013	Smart key	/	○	○	/	1. All keys lost 2. Add keys 3. All smart keys lost 4. Add smart keys 5. Live data 6. Switch ignition on 7. Program immo. and PCM 8. Erase DTC
MAZDA	Europe	Mazda 3	2014–2016	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	Europe	Mazda 3	2017–	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	Europe	Mazda 5	-2011	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. Erase keys 4. Program immo. and PCM
MAZDA	Europe	Mazda 5	2012–	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Program immo. and PCM
MAZDA	Europe	Mazda 6	2002–2008	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All Keys lost
MAZDA	Europe	Mazda 6	2009–2013	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Program immo. and PCM
MAZDA	Europe	Mazda 6	2009–2013	Smart key	/	○	○	/	1. All keys lost 2. Add keys 3. All smart keys lost 4. Add smart keys 5. Live data 6. Switch ignition on 7. Program immo. and PCM 8. Erase DTC

MAZDA	Europe	Mazda 6	2014-2016	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	Europe	Mazda 6	2017-	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	Europe	Mazda CX-3	-2016	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	Europe	Mazda CX-3	2017-	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	Europe	Mazda CX-5	2013-2016	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	Europe	Mazda CX-5	2017-	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	Europe	Mazda CX-7	2004-2009	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. Erase keys 4. Program immo. and PCM
MAZDA	Europe	Mazda CX-7	2009-	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Program immo. and PCM

MAZDA	Europe	Mazda CX-7	-2016	Smart key	/	○	○	/	1. Add key 2. All keys lost 3. Add smart key 4. Erase smart keys 5. Read number of keys 6. Program immo. and PCM
MAZDA	Europe	Mazda CX-9	2004-2009	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. Erase keys 4. Program immo. and PCM
MAZDA	Europe	Mazda CX-9	2009-	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Program immo. and PCM
MAZDA	Europe	Mazda CX-9	-2016	Smart key	/	○	○	/	1. Add key 2. All keys lost 3. Add smart key 4. Erase smart keys 5. Read number of keys 6. Program immo. and PCM
MAZDA	Europe	Mazda CX-9	2017	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	Europe	Demio	-2001	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Program immo. and PCM
MAZDA	Europe	Demio	2002-2007	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. Erase keys 4. Program immo. and PCM
MAZDA	Europe	Demio	2008-2013	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Program immo. and PCM

MAZDA	Europe	Demio	2008-2013	Smart key	/	○	○	/	1. All keys lost 2. Add keys 3. All smart keys lost 4. Add smart keys 5. Live data 6. Switch ignition on 7. Program immo. and PCM 8. Erase DTC
MAZDA	Europe	Demio	2014-2016	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	Europe	Demio	2017	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	Europe	Mx5	2005-2009	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. Erase keys 4. Program immo. and PCM
MAZDA	Europe	Mx5	2009-2015	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Program immo. and PCM
MAZDA	Europe	Mx5	2017-	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	Europe	Premacy	2005-	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. Erase keys 4. Program immo. and PCM

MAZDA	Europe	Premacy	2005-	Smart key	/	○	○	/	1. All keys lost 2. Add keys 3. All smart keys lost 4. Add smart keys 5. Live data 6. Switch ignition on 7. Program immo. and PCM 8. Erase DTC
MAZDA	Europe	RX-8	2004-2009	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. Erase keys 4. Program immo. and PCM
MAZDA	Europe	RX-8	2009-	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. Erase keys 4. Program immo. and PCM
MAZDA	Europe	RX-8	2009-	Smart key	/	○	○	/	1. Add key 2. All keys lost 3. Add smart key 4. Erase smart keys 5. Read number of keys 6. Program immo. and PCM
MAZDA	North America	Atenza	-2016	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	North America	Atenza	2017-	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	North America	Axela	-2016	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM

MAZDA	North America	Axela	2017-	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	North America	B系列	1999-2000		/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Program immo. and PCM
MAZDA	North America	B系列	-2007		/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Program immo. and PCM
MAZDA	North America	B系列	2007-2011		/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Program immo. and PCM
MAZDA	North America	Mazda 2	2011-2014		/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Program immo. and PCM
MAZDA	North America	Mazda 2	2014-2016		/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	North America	Mazda 2	2017-		/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	North America	Mazda 3	2004-2010	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. Erase keys 4. Program immo. and PCM
MAZDA	North America	Mazda 3	2010-2013	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Program immo. and PCM

MAZDA	North America	Mazda 3	2010–2013	Smart key	/	○	○	/	1. All keys lost 2. Add keys 3. All smart keys lost 4. Add smart keys 5. Live data 6. Switch ignition on 7. Program immo. and PCM 8. Erase DTC
MAZDA	North America	Mazda 3	2014–2016	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	North America	Mazda 3	2017–	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	North America	Mazda 5	2006–2011		/	○	○	/	1. Number of keys 2. Add a key 3. Erase keys 4. Program immo. and PCM
MAZDA	North America	Mazda 5	2012–		/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Program immo. and PCM
MAZDA	North America	Mazda 6	2003–2008	Smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Number of smart keys 5. Add a smart key 6. Erase smart keys 7. Program immo. and PCM
MAZDA	North America	Mazda 6	2003–2008	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All Keys lost

MAZDA	North America	Mazda 6	2008-2013	Smart key	/	○	○	/	1. All keys lost 2. Add keys 3. All smart keys lost 4. Add smart keys 5. Live data 6. Switch ignition on 7. Program immo. and PCM 8. Erase DTC
MAZDA	North America	Mazda 6	2008-2013	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Program immo. and PCM
MAZDA	North America	Mazda 6	2014-2016	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	North America	Mazda 6	2017-2018	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	North America	Mazda 8		Smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Number of smart keys 5. Add a smart key 6. Erase smart keys 7. Program immo. and PCM
MAZDA	North America	Mazda CX-3	2013-2016	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	North America	Mazda CX-3	2017-	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM

MAZDA	North America	Mazda CX-4	2013–2016	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	North America	Mazda CX-4	2017–	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	North America	Mazda CX-5	-2016	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	North America	Mazda CX-5	2017–	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	North America	Mazda CX-7	2004–2008		/	○	○	/	1. Number of keys 2. Add a key 3. Erase keys 4. Program immo. and PCM
MAZDA	North America	Mazda CX-7	2009–2014		/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Program immo. and PCM
MAZDA	North America	Mazda CX-9	2004–2006	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. Erase keys 4. Program immo. and PCM
MAZDA	North America	Mazda CX-9	2007–2014	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Program immo. and PCM

MAZDA	North America	Mazda CX-9	-2016	Smart key	/	○	○	/	1. Add key 2. All keys lost 3. Add smart key 4. Erase smart keys 5. Read number of keys 6. Program immo. and PCM
MAZDA	North America	Mazda CX-9	2017-	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	North America	Mx5	2004-2010	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. Erase keys 4. Program immo. and PCM
MAZDA	North America	Mx5	2010-2013	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Program immo. and PCM
MAZDA	North America	Mx5	-2013	Smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Number of smart keys 5. Add a smart key 6. Erase smart keys 7. Program immo. and PCM
MAZDA	North America	Mx5	2014-2016	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	North America	Mx5	2017-	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	North America	Mx5 miata		Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. Erase keys 4. Program immo. and PCM

MAZDA	North America	Mx5 miata		Smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Number of smart keys 5. Add a smart key 6. Erase smart keys 7. Program immo. and PCM
MAZDA	North America	RX-8		Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Program immo. and PCM
MAZDA	North America	RX-8		Smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Number of smart keys 5. Add a smart key 6. Erase smart keys 7. Program immo. and PCM
MAZDA	North America	Speed 3	2012	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Program immo. and PCM
MAZDA	North America	Tribute	2001-2004		/	○	○	/	1. Number of keys 2. Add a key 3. Erase keys 4. Program immo. and PCM
MAZDA	North America	Tribute	2005-2008		/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Program immo. and PCM
MAZDA	North America	Tribute	2009-2011		/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Program immo. and PCM
MAZDA	South America	BT-50	2011-		/	○	○	/	1. Add key 2. Erase keys 3. All keys lost 4. Number of key

MAZDA	South America	Mazda 121			/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Program immo. and PCM
MAZDA	South America	Mazda 2	2002–2008	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All Keys lost
MAZDA	South America	Mazda 2	2008–2014	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Program immo. and PCM
MAZDA	South America	Mazda 2	2008–2014	Smart key	/	○	○	/	1. All keys lost 2. Add keys 3. All smart keys lost 4. Add smart keys 5. Live data 6. Switch ignition on 7. Program immo. and PCM 8. Erase DTC
MAZDA	South America	Mazda 2	2014–2016	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	South America	Mazda 2	2017	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	South America	Mazda 3	2004–2008	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. Erase keys 4. Program immo. and PCM
MAZDA	South America	Mazda 3	2009–2013	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Program immo. and PCM

MAZDA	South America	Mazda 3	2004–2008	Smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Number of smart keys 5. Add a smart key 6. Erase smart keys 7. Program immo. and PCM
MAZDA	South America	Mazda 3	2009–2013	Smart key	/	○	○	/	1. All keys lost 2. Add keys 3. All smart keys lost 4. Add smart keys 5. Live data 6. Switch ignition on 7. Program immo. and PCM 8. Erase DTC
MAZDA	South America	Mazda 3	2014–2016	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	South America	Mazda 3	2017–	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	South America	Mazda 5	-2011	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. Erase keys 4. Program immo. and PCM
MAZDA	South America	Mazda 5	2012–	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Program immo. and PCM
MAZDA	South America	Mazda 6	2002–2008	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All Keys lost

MAZDA	South America	Mazda 6	2008–2012	Smart key	/	○	○	/	1. All keys lost 2. Add keys 3. All smart keys lost 4. Add smart keys 5. Live data 6. Switch ignition on 7. Program immo. and PCM 8. Erase DTC
MAZDA	South America	Mazda 6	2012–2016	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	South America	Mazda 6	2017	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	South America	Mazda CX-3	2016–	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	South America	Mazda CX-3	2017–	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	South America	Mazda CX-5	2013–2016	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	South America	Mazda CX-5	2017–	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	South America	Mazda CX-7	2004–2009	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. Erase keys 4. Program immo. and PCM

MAZDA	South America	Mazda CX-7	2009-	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Program immo. and PCM
MAZDA	South America	Mazda CX-7	-2016	Smart key	/	○	○	/	1. Add key 2. All keys lost 3. Add smart key 4. Erase smart keys 5. Read number of keys 6. Program immo. and PCM
MAZDA	South America	Mazda CX-9	2004-2009	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. Erase keys 4. Program immo. and PCM
MAZDA	South America	Mazda CX-9	2009-	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Program immo. and PCM
MAZDA	South America	Mazda CX-9	2009-2016	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	South America	Mazda CX-9	2017	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	South America	Demio	-2001	Smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Program immo. and PCM
MAZDA	South America	Demio	2002-2007	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All Keys lost
MAZDA	South America	Demio	2008-2013	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Program immo. and PCM

MAZDA	South America	Demio	2008–2013	Smart key	/	○	○	/	1. All keys lost 2. Add keys 3. All smart keys lost 4. Add smart keys 5. Live data 6. Switch ignition on 7. Program immo. and PCM 8. Erase DTC
MAZDA	South America	Demio	2014–2016	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	South America	Demio	2017	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	South America	Mx5	2005–2009	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. Erase keys 4. Program immo. and PCM
MAZDA	South America	Mx5	2009–2015	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Program immo. and PCM
MAZDA	South America	Mx5	2016	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM
MAZDA	South America	Mx5	2017	Smart key	/	○	○	/	1. All smart keys lost 2. Add a smart key 3. Switch ignition on 4. Program immo. and PCM

MAZDA	South America	Premacy	2005-	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. Erase keys 4. Program immo. and PCM
MAZDA	South America	Premacy	2005-	Smart key	/	○	○	/	1. All keys lost 2. Add keys 3. All smart keys lost 4. Add smart keys 5. Live data 6. Switch ignition on 7. Program immo. and PCM 8. Erase DTC
MAZDA	South America	RX-8	2004-2009	Non smart key	/	○	○	/	1. Number of keys 2. Add a key 3. All keys lost 4. Program immo. and PCM
MAZDA	South America	RX-8	2009-		/	○	○	/	1. Number of keys 2. Add a key 3. Erase keys 4. Program immo. and PCM
MAZDA	South America	RX-8	2009-	Smart key	/	○	○	/	1. Add key 2. All keys lost 3. Add smart key 4. Erase smart keys 5. Read number of keys 6. Program immo. and PCM