

OPEL Function list V9.50

Notes:

- ✓ Functions is fully supported and already existed in former software version.
- * Functions is fully supported and newly added in current software version.
- # Functions is partially supported , which means the functions is verified on some vehicle models or systems and it might supports other vehicle models or systems.
- Functions left with blank is not supported.

Year	Model	Module	System	ECU Infor	Read Codes	Erase Codes	Live Data	Actuators	SpecPtn
2014	Adam		Engine Control Module	✓	✓	✓	✓	✓	0049 0085 0092 0018 0019 0093 0020 0017 0132 0094 0207
2014	Adam		Body Control Module	✓	✓	✓	✓	✓	0048 0046 0208 0047
2014	Adam		Electronic Brake Control Module	✓	✓	✓	✓	✓	0083 0209 0210
2014	Adam		HVAC Control Module	✓	✓	✓	✓	✓	0211 0041
2014	Adam		Inflatable Restraint Sensing and Diagnostic Module	✓	✓	✓	✓	✓	0087
2014	Adam		Instrument Cluster	✓	✓	✓	✓	✓	0041
2014	Adam		Trailer Interface Control Module	✓	✓	✓	✓	✓	0041
2014	Adam		Fuel Injector Control Module	✓	✓	✓	✓	✓	
2014	Adam		Power Steering Control Module	✓	✓	✓	✓	✓	
2014	Adam		Radio	✓	✓	✓	✓	✓	
2014	Adam		Parking Assist Control Module	✓	✓	✓	✓	✓	0041
2014	Ampera		Engine Control Module	✓	✓	✓	✓	✓	0092 0018 0019 0020 0017 0212
2014	Ampera		Transmission Control Module	✓	✓	✓	✓	✓	
2014	Ampera		Body Control Module	✓	✓	✓	✓	✓	0213 0214 0215 0216 0217 0218 0219 0220 0221 0222 0048 0049 0046 0208 0223 0224 0047 0225
2014	Ampera		Electronic Brake Control Module	✓	✓	✓	✓	✓	0049 0226
2014	Ampera		HVAC Control Module	✓	✓	✓	✓	✓	0211 0227
2014	Ampera		Inflatable Restraint Sensing and Diagnostic Module	✓	✓	✓	✓	✓	0087
2014	Ampera		Instrument Cluster	✓	✓	✓	✓	✓	0041
2014	Ampera		Chassis Control Module	✓	✓	✓	✓	✓	0017 0228 0229
2014	Ampera		Auxiliary Transmission Fluid Pump	✓	✓	✓	✓	✓	
2014	Ampera		Drive Motor Control Module 1	✓	✓	✓	✓	✓	
2014	Ampera		Drive Motor Control Module 2	✓	✓	✓	✓	✓	
2014	Ampera		Hybrid Powertrain Control Module	✓	✓	✓	✓	✓	
2014	Ampera		Electric A/C Compressor Control Module	✓	✓	✓	✓	✓	
2014	Ampera		Battery Charger Control Module	✓	✓	✓	✓	✓	
2014	Ampera		Battery Energy Control Module	✓	✓	✓	✓	✓	
2014	Ampera		Coolant Heater Control Module	✓	✓	✓	✓	✓	
2014	Ampera		Hybrid Powertrain Control Module 2	✓	✓	✓	✓	✓	0230 0231 0232 0233 0234 0235
2014	Ampera		Telematics Communication Interface Control Module	✓	✓	✓	✓	✓	
2014	Ampera		Steering Column Lock Control Module	✓	✓	✓	✓	✓	
2014	Ampera		Steering Wheel Angle Sensor Module	✓	✓	✓	✓	✓	0083 0084
2014	Ampera		Keyless Entry Control Module	✓	✓	✓	✓	✓	
2014	Ampera		Power Steering Control Module	✓	✓	✓	✓	✓	0089 0090
2014	Ampera		Frontview Camera Module	✓	✓	✓	✓	✓	0109 0236
2014	Ampera		Digital Radio Receiver Control Module	✓	✓	✓	✓	✓	0041
2014	Ampera		Radio	✓	✓	✓	✓	✓	
2014	Ampera		Front Seat Heating Control Module	✓	✓	✓	✓	✓	
2014	Ampera		Parking Assist Control Module	✓	✓	✓	✓	✓	0041
2014	Ampera		Parking Brake Control Module	✓	✓	✓	✓	✓	0110
2014	Antara		Engine Control Module	✓	✓	✓	✓	✓	0085 0092 0100 0237 0131 0238 0086 0239 0240 0103 0241 0242 0104 0122 0105 0020 0107 0243 0244 0245 0246 0049 0018 0019 0017 0247 0096 0207
2014	Antara		Transmission Control Module	✓	✓	✓	✓	✓	0248
2014	Antara		Body Control Module	✓	✓	✓	✓	✓	0048 0049 0249
2014	Antara		Electronic Brake Control Module	✓	✓	✓	✓	✓	0084
2014	Antara		HVAC Control Module	✓	✓	✓	✓	✓	
2014	Antara		Inflatable Restraint Sensing and Diagnostic Module	✓	✓	✓	✓	✓	0250 0249
2014	Antara		Instrument Cluster	✓	✓	✓	✓	✓	
2014	Antara		Rear Differential Clutch Control Module	✓	✓	✓	✓	✓	0251
2014	Antara		Headlamp Control Module	✓	✓	✓	✓	✓	0252 0253
2014	Antara		Radio	✓	✓	✓	✓	✓	0254
2014	Antara		Mobile Telephone Control Module	✓	✓	✓	✓	✓	
2014	Antara		Auxiliary Body Control Module	✓	✓	✓	✓	✓	
2014	Antara		Remote Control Door Lock Receiver	✓	✓	✓	✓	✓	0255 0214 0215 0216 0217 0218 0256 0225
2014	Antara		Theft Deterrent Module	✓	✓	✓	✓	✓	
2014	Antara		Parking Brake Control Module	✓	✓	✓	✓	✓	0110
2014	Antara		Parking Assist Control Module	✓	✓	✓	✓	✓	
2014	Antara		Variable Power Steering Control Module	✓	✓	✓	✓	✓	
2014	Antara		Info Display Module	✓	✓	✓	✓	✓	0254 0257 0258
2014	Antara		Chassis Control Module	✓	✓	✓	✓	✓	0017 0228 0229
2014	Astra-J		Engine Control Module	✓	✓	✓	✓	✓	0049 0085 0092 0018 0019 0093 0020 0017 0132 0094 0207 0097 0098 0099 0100 0101 0102 0237 0086 0239 0103 0104 0105 0106 0107 0050 0096 0259 0131 0130 0122 0133 0134 0123 0136 0137 0138
2014	Astra-J		Transmission Control Module	✓	✓	✓	✓	✓	0260 0123 0248
2014	Astra-J		Body Control Module	✓	✓	✓	✓	✓	0048 0049 0046 0223 0208 0224 0047 0225
2014	Astra-J		Electronic Brake Control Module	✓	✓	✓	✓	✓	0261 0084 0087
2014	Astra-J		HVAC Control Module	✓	✓	✓	✓	✓	0211 0041
2014	Astra-J		Inflatable Restraint Sensing and Diagnostic Module	✓	✓	✓	✓	✓	0250
2014	Astra-J		Instrument Cluster	✓	✓	✓	✓	✓	0041
2014	Astra-J		Chassis Control Module	✓	✓	✓	✓	✓	0017 0228 0229
2014	Astra-J		Suspension Control Module	✓	✓	✓	✓	✓	
2014	Astra-J		Trailer Interface Control Module	✓	✓	✓	✓	✓	0041

2014	Astra-J		Headlamp Control Module	✓	✓	✓	✓	✓	0252
2014	Astra-J		Fuel Injector Control Module	✓			✓	✓	
2014	Astra-J		Power Steering Control Module	✓	✓	✓	✓	✓	0089 0090
2014	Astra-J		Parking Brake Control Module	✓	✓	✓	✓	✓	0110
2014	Astra-J		Steering Wheel Angle Sensor Module	✓	✓	✓			0083 0084
2014	Astra-J		Multi-Axis Acceleration Sensor Module	✓	✓	✓			0262 0087
2014	Astra-J		Multimedia Player Interface Module	✓	✓	✓	✓		
2014	Astra-J		Frontview Camera Module	✓	✓	✓	✓	✓	0109 0236 0041
2014	Astra-J		Front Seat Heating Control Module	✓	✓	✓	✓	✓	
2014	Astra-J		Digital Radio Receiver Control Module	✓	✓	✓	✓	✓	0041
2014	Astra-J		Mobile Telephone Control Module	✓	✓	✓	✓	✓	0041
2014	Astra-J		Radio	✓	✓	✓	≠	✓	
2014	Astra-J		Parking Assist Control Module	✓	✓	✓	✓	✓	0041
2014	Astra-J		Distance Sensing Cruise Control Module	✓	✓	✓	✓	✓	0263
2014	Cascada		Engine Control Module	✓	✓	✓	✓	✓	0097 0085 0098 0099 0100 0101 0102 0237 0086 0239 0103 0132 0104 0105 0020 0106 0107 0207 0050 0049 0092 0018 0019 0093 0017 0094 0096
2014	Cascada		Transmission Control Module	✓	✓	✓	✓	✓	0260 0123 0248
2014	Cascada		Body Control Module	✓	✓	✓	✓	✓	0048 0049 0046 0223 0208 0224 0047 0225
2014	Cascada		Electronic Brake Control Module	✓	✓	✓	✓	✓	0261 0084 0087
2014	Cascada		HVAC Control Module	✓	✓	✓	✓	✓	0211 0041
2014	Cascada		Inflatable Restraint Sensing and Diagnostic Module	✓	✓	✓	✓	✓	0087
2014	Cascada		Instrument Cluster	✓	✓	✓	✓	✓	0041
2014	Cascada		Suspension Control Module	✓	✓	✓	✓	✓	
2014	Cascada		Folding Top Control Module	✓	✓	✓	✓	✓	0041
2014	Cascada		Headlamp Control Module	✓	✓	✓	✓	✓	0252
2014	Cascada		Power Steering Control Module	✓	✓	✓	✓	✓	0089 0090
2014	Cascada		Parking Brake Control Module	✓	✓	✓	✓	✓	0110
2014	Cascada		Multi-Axis Acceleration Sensor Module	✓	✓	✓			0262 0087
2014	Cascada		Steering Wheel Angle Sensor Module	✓	✓	✓			0083 0084
2014	Cascada		Multimedia Player Interface Module	✓	✓	✓	✓		
2014	Cascada		Frontview Camera Module	✓	✓	✓	✓	✓	0109 0236 0041
2014	Cascada		Front Seat Heating Control Module	✓	✓	✓	✓	✓	
2014	Cascada		Digital Radio Receiver Control Module	✓	✓	✓	✓	✓	0041
2014	Cascada		Mobile Telephone Control Module	✓	✓	✓	✓	✓	0041
2014	Cascada		Radio	✓	✓	✓	≠	✓	
2014	Cascada		Parking Assist Control Module	✓	✓	✓	✓	✓	0041
2014	Cascada		Chassis Control Module	✓	✓	✓	✓	✓	0017 0228 0229
2014	Combo-D		Engine Control Module	✓	✓	✓	✓	✓	0085 0264 0100 0237 0086 0103 0265 0132 0105 0020 0122 0266 0267 0107 0050 0268 0123 0102 0269 0270 0271
2014	Combo-D		Transmission Control Module	✓	✓	✓	✓	✓	0272 0273
2014	Combo-D		Body Control Module	✓	✓	✓	✓	✓	0274
2014	Combo-D		Electronic Brake Control Module	✓	✓	✓	✓	✓	0275 0261 0084
2014	Combo-D		HVAC Control Module	✓	✓	✓	✓	✓	
2014	Combo-D		Inflatable Restraint Sensing and Diagnostic Module	✓	✓	✓	✓	✓	
2014	Combo-D		Instrument Cluster	✓	✓	✓	✓	✓	0276
2014	Combo-D		Auxiliary Heater Control Module	✓	✓	✓	✓	✓	
2014	Combo-D		Multimedia Player Interface Module	✓	✓	✓	✓	✓	
2014	Combo-D		Parking Assist Control Module	✓	✓	✓	✓	✓	
2014	Insignia		Engine Control Module	✓	✓	✓	✓	✓	0049 0085 0092 0018 0019 0093 0020 0017 0132 0094 0207 0097 0098 0099 0100 0101 0102 0237 0086 0239 0103 0104 0105 0106 0107 0050 0096
2014	Insignia		Transmission Control Module	✓	✓	✓	✓	✓	0260 0123 0248 0052
2014	Insignia		Body Control Module	✓	✓	✓	✓	✓	0048 0049 0046 0223 0208 0224 0047 0225
2014	Insignia		Electronic Brake Control Module	✓	✓	✓	✓	✓	0261 0084 0087 0277
2014	Insignia		HVAC Control Module	✓	✓	✓	✓	✓	0211 0041
2014	Insignia		Inflatable Restraint Sensing and Diagnostic Module	✓	✓	✓	✓	✓	0087
2014	Insignia		Instrument Cluster	✓	✓	✓	✓	✓	0041
2014	Insignia		Amplifier	✓	✓	✓	✓		
2014	Insignia		Human Machine Interface Control Module	✓	✓	✓	✓	✓	0278
2014	Insignia		Radio	✓	✓	✓	✓	✓	0279
2014	Insignia		Suspension Control Module	✓	✓	✓	✓	✓	
2014	Insignia		HVAC Controls	✓	✓	✓	✓	✓	0278
2014	Insignia		Infotainment Control Touchpad	✓	✓	✓	✓	✓	
2014	Insignia		Radio Controls	✓	✓	✓	✓	✓	0278
2014	Insignia		Trailer Interface Control Module	✓	✓	✓	✓	✓	0041
2014	Insignia		Liftgate Control Module	✓	✓	✓	✓	✓	0280
2014	Insignia		Steering Column Lock Control Module	✓	✓	✓	✓		
2014	Insignia		Keyless Entry Control Module	✓	✓	✓	✓	✓	
2014	Insignia		Rear Differential Clutch Control Module	✓	✓	✓	✓	✓	
2014	Insignia		Steering Wheel Angle Sensor Module	✓	✓	✓	✓	✓	0083 0084
2014	Insignia		Distance Sensing Cruise Control Module	✓	✓	✓	✓	✓	0263
2014	Insignia		Frontview Camera Module	✓	✓	✓	✓	✓	0109 0236 0041
2014	Insignia		Multi-Axis Acceleration Sensor Module	✓	✓	✓	✓	✓	0262 0087
2014	Insignia		Fuel Injector Control Module	✓			✓	✓	
2014	Insignia		Headlamp Control Module	✓	✓	✓	✓	✓	0252
2014	Insignia		Power Steering Control Module	✓	✓	✓	✓	✓	
2014	Insignia		Parking Brake Control Module	✓	✓	✓	✓	✓	0110
2014	Insignia		Parking Assist Control Module	✓	✓	✓	✓	✓	0041
2014	Insignia		Left Side Object Detection Control Module	✓	✓	✓		✓	
2014	Insignia		Chassis Control Module	✓	✓	✓	✓	✓	0017 0228 0229
2014	Meriva-B		Engine Control Module	✓	✓	✓	✓	✓	0049 0085 0092 0018 0019 0093 0020 0017 0132 0094 0207 0097 0098 0099 0100 0101 0102 0237 0086 0239 0103 0104 0105 0106 0107 0050 0259 0131 0130 0122 0133 0134 0123 0136 0137 0138 0240

2014	Meriva-B		Transmission Control Module	✓	✓	✓	✓	✓	0260 0123
2014	Meriva-B		Body Control Module	✓	✓	✓	✓	✓	0048 0046 0208 0223 0224 0047
2014	Meriva-B		Electronic Brake Control Module	✓	✓	✓	✓	✓	0083 0209 0210
2014	Meriva-B		HVAC Control Module	✓	✓	✓	✓	✓	0211 0041
2014	Meriva-B		Inflatable Restraint Sensing and Diagnostic Module	✓	✓	✓	✓	✓	0087
2014	Meriva-B		Instrument Cluster	✓	✓	✓	✓	✓	0041
2014	Meriva-B		Fuel Injector Control Module	✓			✓	✓	
2014	Meriva-B		Parking Brake Control Module	✓	✓	✓	✓	✓	0110
2014	Meriva-B		Power Steering Control Module	✓	✓	✓	✓	✓	
2014	Meriva-B		Steering Wheel Angle Sensor Module	✓	✓	✓			0083 0084
2014	Meriva-B		Headlamp Control Module	✓	✓	✓	✓	✓	0252
2014	Meriva-B		Radio	✓	✓	✓	#	✓	
2014	Meriva-B		Digital Radio Receiver Control Module	✓	✓	✓	✓	✓	0041
2014	Meriva-B		Multimedia Player Interface Module	✓	✓	✓	✓	✓	
2014	Meriva-B		Mobile Telephone Control Module	✓	✓	✓	✓	✓	0041
2014	Meriva-B		Front Seat Heating Control Module	✓	✓	✓	✓	✓	
2014	Meriva-B		Parking Assist Control Module	✓	✓	✓	✓	✓	0041
2014	Meriva-B		Trailer Interface Control Module	✓	✓	✓	✓	✓	0041
2014	Mokka		Engine Control Module	✓	✓	✓	✓	✓	0049 0085 0092 0018 0019 0132 0093 0020 0017 0094 0207 0098 0259 0131 0086 0130 0122 0105 0133 0134 0107 0050
2014	Mokka		Transmission Control Module	✓	✓	✓	✓	✓	0248
2014	Mokka		Body Control Module	✓	✓	✓	✓	✓	0048 0049 0046 0223 0208 0224 0047 0225
2014	Mokka		Electronic Brake Control Module	✓	✓	✓	✓	✓	0084
2014	Mokka		HVAC Control Module	✓	✓	✓	✓	✓	0211 0041
2014	Mokka		Inflatable Restraint Sensing and Diagnostic Module	✓	✓	✓	✓	✓	0250 0087
2014	Mokka		Instrument Cluster	✓	✓	✓	✓	✓	0041
2014	Mokka		Trailer Interface Control Module	✓	✓	✓	✓	✓	0041
2014	Mokka		Headlamp Control Module	✓	✓	✓	✓	✓	0252
2014	Mokka		Rear Differential Clutch Control Module	✓	✓	✓	✓	✓	0281 0282
2014	Mokka		Power Steering Control Module	✓	✓	✓	✓	✓	
2014	Mokka		Steering Wheel Angle Sensor Module	✓	✓	✓			0083 0084
2014	Mokka		Frontview Camera Module	✓	✓	✓	✓	✓	0109 0236 0041
2014	Mokka		Front Seat Heating Control Module	✓	✓	✓	✓	✓	
2014	Mokka		Fuel Injector Control Module	✓			✓	✓	
2014	Mokka		Digital Radio Receiver Control Module	✓	✓	✓	✓	✓	0041
2014	Mokka		Radio	✓	✓	✓	#	✓	
2014	Mokka		Parking Assist Control Module	✓	✓	✓	✓	✓	0041
2014	Zafira-C		Engine Control Module	✓	✓	✓	✓	✓	0049 0085 0092 0018 0019 0132 0093 0020 0017 0094 0207 0097 0129 0086 0103 0098 0104 0102 0130 0099 0100 0101 0237 0239 0105 0106 0107 0050 0096 0259 0131 0122 0133 0134 0123 0136 0137 0138
2014	Zafira-C		Transmission Control Module	✓	✓	✓	✓	✓	0260 0123 0248
2014	Zafira-C		Body Control Module	✓	✓	✓	✓	✓	0048 0049 0046 0223 0208 0224 0047 0225
2014	Zafira-C		Electronic Brake Control Module	✓	✓	✓	✓	✓	0261 0084 0087
2014	Zafira-C		HVAC Control Module	✓	✓	✓	✓	✓	0211 0041
2014	Zafira-C		Inflatable Restraint Sensing and Diagnostic Module	✓	✓	✓	✓	✓	0250
2014	Zafira-C		Instrument Cluster	✓	✓	✓	✓	✓	0041
2014	Zafira-C		Suspension Control Module	✓	✓	✓	✓	✓	
2014	Zafira-C		Trailer Interface Control Module	✓	✓	✓	✓	✓	0041
2014	Zafira-C		Headlamp Control Module	✓	✓	✓	✓	✓	0252
2014	Zafira-C		Fuel Injector Control Module	✓			✓	✓	
2014	Zafira-C		Power Steering Control Module	✓	✓	✓	✓	✓	0089 0090
2014	Zafira-C		Parking Brake Control Module	✓	✓	✓	✓	✓	0110
2014	Zafira-C		Distance Sensing Cruise Control Module	✓	✓	✓	✓	✓	0263
2014	Zafira-C		Multi-Axis Acceleration Sensor Module	✓	✓	✓	✓	✓	0262 0087
2014	Zafira-C		Steering Wheel Angle Sensor Module	✓	✓	✓	✓	✓	0083 0084
2014	Zafira-C		Multimedia Player Interface Module	✓	✓	✓	✓	✓	
2014	Zafira-C		Frontview Camera Module	✓	✓	✓	✓	✓	0109 0236 0041
2014	Zafira-C		Front Seat Heating Control Module	✓	✓	✓	✓	✓	
2014	Zafira-C		Digital Radio Receiver Control Module	✓	✓	✓	✓	✓	0041
2014	Zafira-C		Radio	✓	✓	✓	#	✓	
2014	Zafira-C		Mobile Telephone Control Module	✓	✓	✓	✓	✓	0041
2014	Zafira-C		Parking Assist Control Module	✓	✓	✓	✓	✓	0041
2014	Zafira-C		Chassis Control Module	✓	✓	✓	✓	✓	0017 0228 0229
2014	Corsa-D	Body	Exterior Lighting	✓	✓	✓	✓	✓	
2014	Corsa-D	Body	Interior Lighting	✓	✓	✓	✓	✓	
2014	Corsa-D	Body	Wipers/Washer	✓	✓	✓	✓	✓	
2014	Corsa-D	Body	Heating,Ventilation and Air Cond.	✓	✓	✓	✓	✓	
2014	Corsa-D	Body	Anti Theft Warning System	✓	✓	✓	✓	✓	
2014	Corsa-D	Body	Central Door Lock	✓	✓	✓	✓	✓	
2014	Corsa-D	Body	Immobiliser	✓	✓	✓	✓	✓	
2014	Corsa-D	Body	AFL (Adaptive Forward Lighting)	✓	✓	✓	✓	✓	
2014	Corsa-D	Body	EHS (Electrical Heater System)	✓	✓	✓	✓	✓	
2014	Corsa-D	Body	IPC ECU (Instrument Control Unit)	✓	✓	✓	✓	✓	
2014	Corsa-D	Body	PAS (Park Pilot)	✓	✓	✓	✓	✓	
2014	Corsa-D	Body	SDM (Airbag)	✓	✓	✓	✓	✓	0001 0002 0003 0004
2014	Corsa-D	Body	TIM(Trailer Interface Module)	✓	✓	✓	✓	✓	
2014	Corsa-D	Body	BCM (Body Control Module)	✓	✓	✓	✓	✓	
2014	Corsa-D	Chassis	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)	✓	✓	✓	✓	✓	
2014	Corsa-D	Chassis	Electronic Power Steering	✓	✓	✓	✓	✓	0005 0006 0007
2014	Corsa-D	Chassis	Fuel injector control module	✓			✓	✓	
2014	Corsa-D	Engine	Z10XEP	✓	✓	✓	✓	✓	0008 0009 0010 0011 0012 0013 0014 0015 0016
2014	Corsa-D	Engine	A10XEP	✓	✓	✓	✓	✓	0007 0017 0018 0019 0020
2014	Corsa-D	Engine	Z12XEP	✓	✓	✓	✓	✓	0007 0008 0009 0010 0011 0012 0013 0014 0015
2014	Corsa-D	Engine	A12XER	✓	✓	✓	✓	✓	0007 0019
2014	Corsa-D	Engine	A12XEL	✓	✓	✓	✓	✓	0007 0019
2014	Corsa-D	Engine	Z13DTH	✓	✓	✓	✓	✓	0021 0011 0012 0015 0022

2014	Corsa-D	Engine	Z13DTE	✓	✓	✓	✓	✓	0007
2014	Corsa-D	Engine	Z13DTJ	✓	✓	✓	✓	✓	0020 0011 0012 0015 0021
2014	Corsa-D	Engine	A13DTC	✓	✓	✓	✓	✓	0020
2014	Corsa-D	Engine	Z14XEP	✓	✓	✓	✓	✓	0007 0008 0009 0010 0011 0012 0013 0014 0015
2014	Corsa-D	Engine	A14XEL	✓	✓	✓	✓	✓	0007 0016 0017 0018 0019
2014	Corsa-D	Engine	A14XER	✓	✓	✓	✓	✓	0007 0016 0017 0018 0019
2014	Corsa-D	Engine	Z16LEL	✓	✓	✓	✓	✓	
2014	Corsa-D	Engine	Z16LER	✓	✓	✓	✓	✓	
2014	Corsa-D	Engine	A16LEL	✓	✓	✓	✓	✓	
2014	Corsa-D	Engine	A16LER	✓	✓	✓	✓	✓	
2014	Corsa-D	Engine	Z17DTR	✓	✓	✓	✓	✓	0020 0023 0012 0015 0024 0025 0026 0013 0027 0028 0029 0030 0021 0031
2014	Corsa-D	Engine	Engine(default)	✓	✓	✓	✓	✓	
2014	Corsa-D	Transmission	MTA(Easytronic Magneti Marelli)	✓	✓	✓	✓	✓	
2014	Corsa-D	Transmission	AF 13-4	✓	✓	✓	✓	✓	0032 0033 0034 0035
2014	Corsa-D	Transmission	MTA(Easytronic)	✓	✓	✓	✓	✓	0036 0037
2013	Adam		Engine Control Module	✓	✓	✓	✓	✓	0049 0085 0092 0018 0019 0093 0020 0017 0132 0094 0207
2013	Adam		Body Control Module	✓	✓	✓	✓	✓	0048 0046 0208 0047
2013	Adam		Electronic Brake Control Module	✓	✓	✓	✓	✓	0083 0209 0210
2013	Adam		HVAC Control Module	✓	✓	✓	✓	✓	0211 0041
2013	Adam		Inflatable Restraint Sensing and Diagnostic Module	✓	✓	✓	✓	✓	0087
2013	Adam		Instrument Cluster	✓	✓	✓	✓	✓	0041
2013	Adam		Power Steering Control Module	✓	✓	✓	✓	✓	
2013	Adam		Trailer Interface Control Module	✓	✓	✓	✓	✓	0041
2013	Adam		Radio	✓	✓	✓	✓	✓	
2013	Adam		Parking Assist Control Module	✓	✓	✓	✓	✓	0041
2013	Agila B	Body	BCM (Body Control Module)	✓	✓	✓	✓	✓	
2013	Agila B	Body	Immobiliser	✓	✓	✓	✓	✓	
2013	Agila B	Body	SDM (Airbag)	✓	✓	✓	✓	✓	0000 0001 0002 0003
2013	Agila B	Chassis	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)	✓	✓	✓	✓	✓	0006
2013	Agila B	Chassis	Electronic Power Steering	✓	✓	✓	✓	✓	
2013	Agila B	Engine	K10B	✓	✓	✓	✓	✓	0016
2013	Agila B	Engine	K12B	✓	✓	✓	✓	✓	0016
2013	Agila B	Engine	D13A / Z 13 DTJ	✓	✓	✓	✓	✓	0042 0020 0012 0022 0021 0019 0029 0026 0043 0044
2013	Agila B	Transmission	TCM (Transmission Control Module)	✓	✓	✓	✓	✓	0034
2013	Ampera		Engine Control Module	✓	✓	✓	✓	✓	0092 0018 0019 0020 0017 0212
2013	Ampera		Transmission Control Module	✓	✓	✓	✓	✓	
2013	Ampera		Body Control Module	✓	✓	✓	✓	✓	0048 0049 0046 0208 0223 0224 0047 0225
2013	Ampera		Electronic Brake Control Module	✓	✓	✓	✓	✓	0049 0226
2013	Ampera		HVAC Control Module	✓	✓	✓	✓	✓	0211 0227
2013	Ampera		Inflatable Restraint Sensing and Diagnostic Module	✓	✓	✓	✓	✓	0250
2013	Ampera		Instrument Cluster	✓	✓	✓	✓	✓	0041
2013	Ampera		Fuel Pump Control Module	✓	✓	✓	✓	✓	0017
2013	Ampera		Hybrid Powertrain Control Module	✓	✓	✓	✓	✓	
2013	Ampera		Drive Motor Control Module 1	✓	✓	✓	✓	✓	
2013	Ampera		Drive Motor Control Module 2	✓	✓	✓	✓	✓	
2013	Ampera		Auxiliary Transmission Fluid Pump	✓	✓	✓	✓	✓	
2013	Ampera		Parking Brake Control Module	✓	✓	✓	✓	✓	0110
2013	Ampera		Multi-Axis Acceleration Sensor Module	✓	✓	✓	✓	✓	0262 0087
2013	Ampera		Power Steering Control Module	✓	✓	✓	✓	✓	0089 0090
2013	Ampera		Steering Wheel Angle Sensor Module	✓	✓	✓	✓	✓	0083 0084
2013	Ampera		Radio	✓	✓	✓	✓	✓	
2013	Ampera		Digital Radio Receiver Control Module	✓	✓	✓	✓	✓	0041
2013	Ampera		Mobile Telephone Control Module	✓	✓	✓	✓	✓	0041
2013	Ampera		Telematics Communication Interface Control Module	✓	✓	✓	✓	✓	
2013	Ampera		Electric A/C Compressor Control Module	✓	✓	✓	✓	✓	
2013	Ampera		Coolant Heater Control Module	✓	✓	✓	✓	✓	
2013	Ampera		Front Seat Heating Control Module	✓	✓	✓	✓	✓	
2013	Ampera		Keyless Entry Control Module	✓	✓	✓	✓	✓	
2013	Ampera		Parking Assist Control Module	✓	✓	✓	✓	✓	0041
2013	Ampera		Steering Column Lock Control Module	✓	✓	✓	✓	✓	
2013	Ampera		Battery Charger Control Module	✓	✓	✓	✓	✓	
2013	Ampera		Hybrid Powertrain Control Module 2	✓	✓	✓	✓	✓	0230 0231 0232 0233 0234 0235
2013	Ampera		Battery Energy Control Module	✓	✓	✓	✓	✓	
2013	Ampera		Multimedia Player Interface Module	✓	✓	✓	✓	✓	0041
2013	Ampera		Frontview Camera Module	✓	✓	✓	✓	✓	0109 0236
2013	Antara		Engine Control Module	✓	✓	✓	✓	✓	0085 0092 0100 0237 0131 0238 0086 0239 0240 0103 0241 0242 0104 0122 0105 0020 0107 0243 0244 0245 0246 0049 0018 0019 0017 0247 0096 0207
2013	Antara		Transmission Control Module	✓	✓	✓	✓	✓	0248
2013	Antara		Body Control Module	✓	✓	✓	✓	✓	0048 0049 0249
2013	Antara		Electronic Brake Control Module	✓	✓	✓	✓	✓	0084
2013	Antara		HVAC Control Module	✓	✓	✓	✓	✓	
2013	Antara		Inflatable Restraint Sensing and Diagnostic Module	✓	✓	✓	✓	✓	0250 0249
2013	Antara		Instrument Cluster	✓	✓	✓	✓	✓	
2013	Antara		Rear Differential Clutch Control Module	✓	✓	✓	✓	✓	0251
2013	Antara		Fuel Pump Control Module	✓	✓	✓	✓	✓	0017
2013	Antara		Parking Assist Control Module	✓	✓	✓	✓	✓	
2013	Antara		Parking Brake Control Module	✓	✓	✓	✓	✓	0110
2013	Antara		Info Display Module	✓	✓	✓	✓	✓	0254 0257 0258
2013	Antara		Variable Power Steering Control Module	✓	✓	✓	✓	✓	
2013	Antara		Radio	✓	✓	✓	✓	✓	0254
2013	Antara		Auxiliary Body Control Module	✓	✓	✓	✓	✓	
2013	Antara		Headlamp Control Module	✓	✓	✓	✓	✓	0252 0253
2013	Antara		Remote Control Door Lock Receiver	✓	✓	✓	✓	✓	0255 0214 0215 0216 0217 0218 0256 0225
2013	Antara		Theft Deterrent Module	✓	✓	✓	✓	✓	
2013	Antara		Mobile Telephone Control Module	✓	✓	✓	✓	✓	

2013	Astra-H	Body	AHL/AFL (Headlamp Levelling)	✓	✓	✓	✓		
2013	Astra-H	Body	Exterior Lighting/Turn Indicator System	✓	✓	✓	✓		
2013	Astra-H	Body	Interior Lighting	✓	✓	✓	✓		
2013	Astra-H	Body	Wipers/Washer	✓	✓	✓	✓		
2013	Astra-H	Body	Central Door Lock	✓	✓	✓	✓		
2013	Astra-H	Body	Instrument	✓	✓	✓	✓		
2013	Astra-H	Body	Immobiliser	✓	✓	✓	✓		
2013	Astra-H	Body	CIM (Steering Column Module)	✓	✓	✓	✓	✓	0053 0004 0054 0002 0005 0055 0056 0006
2013	Astra-H	Body	Anti Theft Warning System	✓	✓	✓	✓		
2013	Astra-H	Body	Electrohydraulic HardTop	✓	✓	✓	✓		
2013	Astra-H	Body	ECC/SAC (Electronic Climate Control)	✓	✓	✓	✓		
2013	Astra-H	Body	IPC ECU (Instrument Control Unit)	✓	✓	✓	✓	✓	0007 0057 0058 0059 0060 0061 0062 0002 0005
2013	Astra-H	Body	EHS (Electrical Heater System)	✓	✓	✓	✓		
2013	Astra-H	Body	PAS (Park Pilot)	✓	✓	✓	✓		
2013	Astra-H	Body	SDM (Airbag)	✓	✓	✓	✓		0000 0001 0002 0003
2013	Astra-H	Body	SLM (Shift Lever Module)	✓	✓	✓	✓		
2013	Astra-H	Body	UEC (Underhood Electrical Centre)	✓	✓	✓	✓		
2013	Astra-H	Body	REC (Rear Electrical Centre)	✓	✓	✓	✓		
2013	Astra-H	Body	PEPS (Open&Start)	✓	✓	✓	✓		
2013	Astra-H	Body	CIM(Steering Column Module)	✓	✓	✓	✓	✓	0052 0004 0053 0002 0005 0054 0055 0006
2013	Astra-H	Chassis	TPMS ECU (Tyre Pressure Monitoring)	✓	✓	✓	✓		0036
2013	Astra-H	Chassis	TPMS (Tyre Pressure Monitoring System)	✓	✓	✓	✓		0063
2013	Astra-H	Chassis	EHPS (Electrohydraulic Power Steering)	✓	✓	✓	✓		0004
2013	Astra-H	Chassis	ABS/TC/ESP ECU(Electronic Control Unit)	✓	✓	✓	✓	✓	0004 0005 0064
2013	Astra-H	Chassis	CDC (Continuous Damping Control)	✓	✓	✓	✓		
2013	Astra-H	Chassis	ABS/TC/ESP (Vehicle Dynamic System)	✓	✓	✓	✓	✓	
2013	Astra-H	Engine	Z12XEP	✓	✓	✓	✓	✓	0010 0065 0012 0066 0013 0067 0007 0008 0009 0019
2013	Astra-H	Engine	Z13DTH	✓	✓	✓	✓	✓	0010 0064 0012 0065 0013 0066 0007 0008 0009 0019
2013	Astra-H	Engine	Z13DTH	✓	✓	✓	✓	✓	0007 0008 0009 0020 0011 0012 0068 0021 0030 0029 0026 0027 0019
2013	Astra-H	Engine	Z14XEL	✓	✓	✓	✓	✓	0007 0008 0009 0010 0011 0012 0067 0013 0014 0019
2013	Astra-H	Engine	Z14XEP	✓	✓	✓	✓	✓	0007 0008 0009 0010 0011 0012 0067 0013 0014 0019
2013	Astra-H	Engine	Z16LET	✓	✓	✓	✓	✓	0010 0064 0012 0065 0013 0066 0007 0008 0009 0019
2013	Astra-H	Engine	Z16XE1	✓	✓	✓	✓	✓	0020 0010 0064 0069 0065 0013 0066 0070 0007 0008 0009 0019
2013	Astra-H	Engine	Z16XEP	✓	✓	✓	✓		0007 0008 0009 0010 0020 0011 0012 0067 0013 0014 0034 0019
2013	Astra-H	Engine	Z16XER	✓	✓	✓	✓		0020 0007 0008 0009 0010 0011 0012 0067 0034 0013 0019
2013	Astra-H	Engine	A16LET	✓	✓	✓	✓	✓	0010 0064 0012 0065 0013 0066 0007 0008 0009 0019
2013	Astra-H	Engine	A16XER	✓	✓	✓	✓	✓	0020 0010 0064 0068 0065 0034 0013 0007 0008 0009 0019
2013	Astra-H	Engine	Z17DTH	✓	✓	✓	✓	✓	0007 0008 0009 0011 0012 0067 0021 0025 0013 0030 0033 0019
2013	Astra-H	Engine	Z17DTJ	✓	✓	✓	✓	✓	0007 0008 0009 0020 0011 0012 0067 0015 0023 0024 0025 0013 0026 0027 0028 0029 0030 0021 0019
2013	Astra-H	Engine	Z17DTL	✓	✓	✓	✓	✓	0064 0012 0065 0021 0025 0013 0030 0033 0019
2013	Astra-H	Engine	Z17DTR	✓	✓	✓	✓	✓	0007 0008 0009 0020 0011 0012 0067 0015 0023 0024 0025 0013 0026 0027 0028 0029 0030 0021 0019
2013	Astra-H	Engine	A17DTJ	✓	✓	✓	✓	✓	0020 0064 0012 0065 0015 0023 0024 0025 0013 0029 0026 0071 0027 0072 0007 0008 0009 0028 0019
2013	Astra-H	Engine	A17DTR	✓	✓	✓	✓	✓	0020 0064 0012 0065 0015 0023 0024 0025 0013 0029 0026 0070 0027 0071 0007 0008 0009 0028 0019
2013	Astra-H	Engine	Z18XE	✓	✓	✓	✓		0020 0007 0008 0009 0010 0011 0012 0067 0013 0019
2013	Astra-H	Engine	Z18XER	✓	✓	✓	✓	✓	0007 0008 0009 0010 0020 0011 0012 0067 0034 0013 0019
2013	Astra-H	Engine	A18XER	✓	✓	✓	✓	✓	0007 0008 0009 0010 0020 0034 0019
2013	Astra-H	Engine	Z19DT	✓	✓	✓	✓	✓	0007 0008 0009 0011 0012 0067 0024 0025 0070 0013 0033 0021 0030 0027 0028 0026 0029 0019
2013	Astra-H	Engine	Z19DTH	✓	✓	✓	✓	✓	0007 0008 0009 0011 0012 0067 0024 0025 0070 0013 0033 0021 0030 0027 0028 0026 0029 0019
2013	Astra-H	Engine	Z20LEH	✓	✓	✓	✓	✓	0010 0064 0012 0065 0013 0066 0007 0008 0009 0019
2013	Astra-H	Engine	Z20LEL	✓	✓	✓	✓	✓	0010 0064 0012 0065 0013 0066 0007 0008 0009 0019
2013	Astra-H	Engine	Z20LER	✓	✓	✓	✓	✓	0010 0064 0012 0065 0013 0066 0007 0008 0009 0019
2013	Astra-H	Engine	Z22YH	✓	✓	✓	✓	✓	0007 0008 0009 0073 0020 0011 0012 0067 0013 0019
2013	Astra-H	Engine	Engine(default)	✓	✓	✓	✓		
2013	Astra-H	Transmission	AF 40-6	✓	✓	✓	✓	✓	0074 0075 0076 0077 0078 0079 0033 0004 0034 0080
2013	Astra-H	Transmission	AF17-4	✓	✓	✓	✓	✓	0031 0032 0033 0004 0034
2013	Astra-H	Transmission	AF 22-4	✓	✓	✓	✓	✓	0033 0081 0034 0031
2013	Astra-H	Transmission	MTA(Easytronic)	✓	✓	✓	✓	✓	0080 0035 0036 0062
2013	Astra-H	Transmission	MTA(Easytronic Magneti Marelli)	✓	✓	✓	✓	✓	0080 0005 0062

2013	Astra-J		Engine Control Module	✓	✓	✓	✓	✓	0049 0085 0092 0018 0019 0093 0020 0017 0132 0094 0207 0098 0259 0131 0086 0130 0122 0105 0133 0134 0107 0050 0097 0099 0100 0101 0102 0237 0239 0103 0104 0106 0096
2013	Astra-J		Transmission Control Module	✓	✓	✓	✓	✓	0260 0123 0248
2013	Astra-J		Body Control Module	✓	✓	✓	✓	✓	0048 0049 0046 0223 0208 0224 0047 0225
2013	Astra-J		Electronic Brake Control Module	✓	✓	✓	✓	✓	0261 0084 0087
2013	Astra-J		HVAC Control Module	✓	✓	✓	✓	✓	0211 0041
2013	Astra-J		Inflatable Restraint Sensing and Diagnostic Module	✓	✓	✓	✓	✓	0250
2013	Astra-J		Instrument Cluster	✓	✓	✓	✓	✓	0041
2013	Astra-J		Fuel Pump Control Module	✓	✓	✓	✓	✓	0017
2013	Astra-J		Parking Brake Control Module	✓	✓	✓	✓	✓	0110
2013	Astra-J		Multi-Axis Acceleration Sensor Module	✓	✓	✓	✓	✓	0262 0087
2013	Astra-J		Power Steering Control Module	✓	✓	✓	✓	✓	0089 0090
2013	Astra-J		Steering Wheel Angle Sensor Module	✓	✓	✓	✓	✓	0083 0084
2013	Astra-J		Suspension Control Module	✓	✓	✓	✓	✓	
2013	Astra-J		Headlamp Control Module	✓	✓	✓	✓	✓	0252
2013	Astra-J		Trailer Interface Control Module	✓	✓	✓	✓	✓	0041
2013	Astra-J		Radio	✓	✓	✓	#	✓	
2013	Astra-J		Digital Radio Receiver Control Module	✓	✓	✓	✓	✓	0041
2013	Astra-J		Multimedia Player Interface Module	✓	✓	✓	✓	✓	
2013	Astra-J		Mobile Telephone Control Module	✓	✓	✓	✓	✓	0041
2013	Astra-J		Front Seat Heating Control Module	✓	✓	✓	✓	✓	
2013	Astra-J		Parking Assist Control Module	✓	✓	✓	✓	✓	0041
2013	Astra-J		Fuel Injector Control Module	✓	✓	✓	✓	✓	
2013	Astra-J		Frontview Camera Module	✓	✓	✓	✓	✓	0109 0236 0041
2013	Astra-J		Distance Sensing Cruise Control Module	✓	✓	✓	✓	✓	0263
2013	Cascada		Engine Control Module	✓	✓	✓	✓	✓	0097 0085 0098 0099 0100 0101 0102 0237 0086 0239 0103 0132 0104 0105 0020 0106 0107 0207 0050 0049 0092 0018 0019 0093 0017 0094 0096
2013	Cascada		Transmission Control Module	✓	✓	✓	✓	✓	0260 0123 0248
2013	Cascada		Body Control Module	✓	✓	✓	✓	✓	0048 0049 0046 0223 0208 0224 0047 0225
2013	Cascada		Electronic Brake Control Module	✓	✓	✓	✓	✓	0261 0084 0087
2013	Cascada		HVAC Control Module	✓	✓	✓	✓	✓	0211 0041
2013	Cascada		Inflatable Restraint Sensing and Diagnostic Module	✓	✓	✓	✓	✓	0087
2013	Cascada		Instrument Cluster	✓	✓	✓	✓	✓	0041
2013	Cascada		Power Steering Control Module	✓	✓	✓	✓	✓	0089 0090
2013	Cascada		Front Seat Heating Control Module	✓	✓	✓	✓	✓	
2013	Cascada		Parking Assist Control Module	✓	✓	✓	✓	✓	0041
2013	Cascada		Mobile Telephone Control Module	✓	✓	✓	✓	✓	0041
2013	Cascada		Digital Radio Receiver Control Module	✓	✓	✓	✓	✓	0041
2013	Cascada		Headlamp Control Module	✓	✓	✓	✓	✓	0252
2013	Cascada		Multi-Axis Acceleration Sensor Module	✓	✓	✓	✓	✓	0262 0087
2013	Cascada		Multimedia Player Interface Module	✓	✓	✓	✓	✓	
2013	Cascada		Suspension Control Module	✓	✓	✓	✓	✓	
2013	Cascada		Folding Top Control Module	✓	✓	✓	✓	✓	0041
2013	Cascada		Steering Wheel Angle Sensor Module	✓	✓	✓	✓	✓	0083 0084
2013	Cascada		Frontview Camera Module	✓	✓	✓	✓	✓	0109 0236 0041
2013	Cascada		Radio	✓	✓	✓	#	✓	
2013	Cascada		Parking Brake Control Module	✓	✓	✓	✓	✓	0110
2013	Cascada		Fuel Pump Control Module	✓	✓	✓	✓	✓	0017
2013	Combo-D		Engine Control Module	✓	✓	✓	✓	✓	0100 0237 0086 0103 0265 0132 0105 0020 0122 0267 0107 0050 0226 0283 0123 0284 0285 0102 0269 0085 0270 0271 0264 0266 0268
2013	Combo-D		Transmission Control Module	✓	✓	✓	✓	✓	0272 0273
2013	Combo-D		Body Control Module	✓	✓	✓	✓	✓	0274
2013	Combo-D		Electronic Brake Control Module	✓	✓	✓	✓	✓	0275 0261 0084
2013	Combo-D		HVAC Control Module	✓	✓	✓	✓	✓	
2013	Combo-D		Inflatable Restraint Sensing and Diagnostic Module	✓	✓	✓	✓	✓	
2013	Combo-D		Instrument Cluster	✓	✓	✓	✓	✓	0276
2013	Combo-D		Multimedia Player Interface Module	✓	✓	✓	✓	✓	
2013	Combo-D		Auxiliary Heater Control Module	✓	✓	✓	✓	✓	
2013	Combo-D		Parking Assist Control Module	✓	✓	✓	✓	✓	
2013	Corsa-D	Body	Exterior Lighting	✓	✓	✓	✓	✓	
2013	Corsa-D	Body	Interior Lighting	✓	✓	✓	✓	✓	
2013	Corsa-D	Body	Wipers/Washer	✓	✓	✓	✓	✓	
2013	Corsa-D	Body	Heating,Ventilation and Air Cond.	✓	✓	✓	✓	✓	
2013	Corsa-D	Body	Anti Theft Warning System	✓	✓	✓	✓	✓	
2013	Corsa-D	Body	Central Door Lock	✓	✓	✓	✓	✓	
2013	Corsa-D	Body	Immobiliser	✓	✓	✓	✓	✓	
2013	Corsa-D	Body	AFL (Adaptive Forward Lighting)	✓	✓	✓	✓	✓	
2013	Corsa-D	Body	EHS (Electrical Heater System)	✓	✓	✓	✓	✓	
2013	Corsa-D	Body	IPC ECU (Instrument Control Unit)	✓	✓	✓	✓	✓	
2013	Corsa-D	Body	PAS (Park Pilot)	✓	✓	✓	✓	✓	
2013	Corsa-D	Body	SDM (Airbag)	✓	✓	✓	✓	✓	0000 0001 0002 0003
2013	Corsa-D	Body	TIM(Trailer Interface Module)	✓	✓	✓	✓	✓	
2013	Corsa-D	Body	BCM (Body Control Module)	✓	✓	✓	✓	✓	
2013	Corsa-D	Chassis	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)	✓	✓	✓	✓	✓	
2013	Corsa-D	Chassis	Electronic Power Steering	✓	✓	✓	✓	✓	0004 0005 0006
2013	Corsa-D	Chassis	Fuel injector control module	✓	✓	✓	✓	✓	
2013	Corsa-D	Engine	Z10XEP	✓	✓	✓	✓	✓	0007 0008 0009 0010 0011 0012 0013 0014 0015
2013	Corsa-D	Engine	A10XEP	✓	✓	✓	✓	✓	0007 0016 0017 0018 0019
2013	Corsa-D	Engine	Z12XEP	✓	✓	✓	✓	✓	0007 0008 0009 0010 0011 0012 0013 0014 0015
2013	Corsa-D	Engine	A12XER	✓	✓	✓	✓	✓	0007 0019
2013	Corsa-D	Engine	A12XEL	✓	✓	✓	✓	✓	0007 0019
2013	Corsa-D	Engine	Z13DTH	✓	✓	✓	✓	✓	0020 0011 0012 0015 0021
2013	Corsa-D	Engine	Z13DTE	✓	✓	✓	✓	✓	0007
2013	Corsa-D	Engine	Z13DTJ	✓	✓	✓	✓	✓	0020 0011 0012 0015 0021

2013	Corsa-D	Engine	A13DTC	✓	✓	✓	✓	✓	0020
2013	Corsa-D	Engine	Z14XEP	✓	✓	✓	✓	✓	0007 0008 0009 0010 0011 0012 0013 0014 0015
2013	Corsa-D	Engine	A14XEL	✓	✓	✓	✓	✓	0007 0016 0017 0018 0019
2013	Corsa-D	Engine	A14XER	✓	✓	✓	✓	✓	0007 0016 0017 0018 0019
2013	Corsa-D	Engine	Z16LEL	✓	✓	✓	✓	✓	
2013	Corsa-D	Engine	Z16LER	✓	✓	✓	✓	✓	
2013	Corsa-D	Engine	A16LEL	✓	✓	✓	✓	✓	
2013	Corsa-D	Engine	A16LER	✓	✓	✓	✓	✓	
2013	Corsa-D	Engine	Z17DTR	✓	✓	✓	✓	✓	0020 0022 0012 0015 0023 0024 0025 0013 0026 0027 0028 0029 0021 0030
2013	Corsa-D	Engine	Engine(default)	✓	✓	✓			
2013	Corsa-D	Transmission	MTA(Easytronic Magneti Marelli)	✓	✓	✓	✓	✓	
2013	Corsa-D	Transmission	AF 13-4	✓	✓	✓	✓	✓	0031 0032 0033 0034
2013	Corsa-D	Transmission	MTA(Easytronic)	✓	✓	✓	✓	✓	0035 0036
2013	Insignia		Engine Control Module	✓	✓	✓	✓	✓	0049 0085 0092 0018 0019 0093 0020 0017 0132 0094 0207 0097 0129 0086 0103 0098 0104 0102 0130 0099 0100 0101 0237 0239 0105 0106 0107 0050 0096
2013	Insignia		Transmission Control Module	✓	✓	✓	✓	✓	0260 0123
2013	Insignia		Body Control Module	✓	✓	✓	✓	✓	0048 0049 0046 0223 0208 0224 0047 0225
2013	Insignia		Electronic Brake Control Module	✓	✓	✓	✓	✓	0261 0084 0087
2013	Insignia		HVAC Control Module	✓	✓	✓	✓	✓	0211 0041
2013	Insignia		Inflatable Restraint Sensing and Diagnostic Module	✓	✓	✓	✓	✓	0250
2013	Insignia		Instrument Cluster	✓	✓	✓	✓	✓	0041
2013	Insignia		Fuel Pump Control Module	✓	✓	✓	✓	✓	0017
2013	Insignia		Parking Brake Control Module	✓	✓	✓	✓	✓	0110
2013	Insignia		Rear Differential Clutch Control Module	✓	✓	✓	✓	✓	
2013	Insignia		Multi-Axis Acceleration Sensor Module	✓	✓	✓	✓	✓	0262 0087
2013	Insignia		Power Steering Control Module	✓	✓	✓	✓	✓	0089 0090
2013	Insignia		Steering Wheel Angle Sensor Module	✓	✓	✓	✓	✓	0083 0084
2013	Insignia		Suspension Control Module	✓	✓	✓	✓	✓	
2013	Insignia		Headlamp Control Module	✓	✓	✓	✓	✓	0252
2013	Insignia		Trailer Interface Control Module	✓	✓	✓	✓	✓	0041
2013	Insignia		Radio	✓	✓	✓	#	✓	
2013	Insignia		Digital Radio Receiver Control Module	✓	✓	✓	✓	✓	0041
2013	Insignia		Multimedia Player Interface Module	✓	✓	✓	✓	✓	
2013	Insignia		Mobile Telephone Control Module	✓	✓	✓	✓	✓	0041
2013	Insignia		Liftgate Control Module	✓	✓	✓	✓	✓	0280
2013	Insignia		Parking Assist Control Module	✓	✓	✓	✓	✓	0041
2013	Insignia		Fuel Injector Control Module	✓	✓	✓	✓	✓	
2013	Insignia		Frontview Camera Module	✓	✓	✓	✓	✓	0109 0236 0041
2013	Insignia		Distance Sensing Cruise Control Module	✓	✓	✓	✓	✓	0263
2013	Meriva-B	Body	Front Seat Heating Control Module	✓	✓	✓	✓	✓	
2013	Meriva-B	Body	BCM (Body Control Module)	✓	✓	✓	✓	✓	
2013	Meriva-B	Body	Headlamp Control Module	✓	✓	✓	✓	✓	
2013	Meriva-B	Body	Inflatable Restraint Sensing&Diag.Module	✓	✓	✓	✓	✓	
2013	Meriva-B	Body	Parking Assist Control Module	✓	✓	✓	✓	✓	0109 0040
2013	Meriva-B	Body	Remote Heater & A/C Control Module	✓	✓	✓	✓	✓	
2013	Meriva-B	Body	Instrument	✓	✓	✓	✓	✓	0040
2013	Meriva-B	Body	Trailer Interface Control Module	✓	✓	✓	✓	✓	
2013	Meriva-B	Chassis	Electronic Brake Control Module	✓	✓	✓	✓	✓	
2013	Meriva-B	Chassis	Electric Power Steering Control Module	✓	✓	✓	✓	✓	
2013	Meriva-B	Chassis	Parking Brake Control Module	✓	✓	✓	✓	✓	0110 0111
2013	Meriva-B	Chassis	Steering Wheel Angle Sensor Module	✓	✓	✓	✓	✓	0082
2013	Meriva-B	Chassis	Fuel injector control module	✓			✓		
2013	Meriva-B	Engine	A 13 DTC 1.3(LDV)	✓	✓	✓	✓	✓	0084 0112 0113 0024 0025 0029 0026 0070 0114 0115 0116 0117 0118 0119
2013	Meriva-B	Engine	A 13 DTE 1.3(LSP)	✓	✓	✓	✓	✓	0084 0120 0112 0024 0025 0029 0026 0070 0113 0114 0115 0116 0117 0121 0019
2013	Meriva-B	Engine	A 14 NEL (LUH)	✓	✓	✓	✓	✓	0019
2013	Meriva-B	Engine	A 14 NET (LUJ)	✓	✓	✓	✓	✓	0019
2013	Meriva-B	Engine	A 14 XER (LDD)	✓	✓	✓	✓	✓	0019
2013	Meriva-B	Engine	A 17 DTC 1.7(LJE)	✓	✓	✓	✓	✓	0122 0104 0019
2013	Meriva-B	Engine	A 17 DTS 1.7(LUD)	✓	✓	✓	✓	✓	0121 0104 0019
2013	Meriva-B	Engine	Engine Control Module	✓	✓	✓	✓	✓	0026 0019
2013	Meriva-B	Transmission	Transmission Control Module	✓	✓	✓	✓	✓	0079 0123
2013	Mokka		Engine Control Module	✓	✓	✓	✓	✓	0049 0085 0092 0018 0019 0132 0093 0020 0017 0094 0207 0098 0259 0131 0086 0130 0122 0105 0133 0134 0107 0050
2013	Mokka		Transmission Control Module	✓	✓	✓	✓	✓	0248
2013	Mokka		Body Control Module	✓	✓	✓	✓	✓	0048 0049 0046 0223 0208 0224 0047 0225
2013	Mokka		Electronic Brake Control Module	✓	✓	✓	✓	✓	0084
2013	Mokka		HVAC Control Module	✓	✓	✓	✓	✓	0211 0041
2013	Mokka		Inflatable Restraint Sensing and Diagnostic Module	✓	✓	✓	✓	✓	0250
2013	Mokka		Instrument Cluster	✓	✓	✓	✓	✓	0041
2013	Mokka		Rear Differential Clutch Control Module	✓	✓	✓	✓	✓	0281 0282
2013	Mokka		Multi-Axis Acceleration Sensor Module	✓	✓	✓	✓	✓	0262 0087
2013	Mokka		Power Steering Control Module	✓	✓	✓	✓	✓	
2013	Mokka		Steering Wheel Angle Sensor Module	✓	✓	✓	✓	✓	0083 0084
2013	Mokka		Headlamp Control Module	✓	✓	✓	✓	✓	0252
2013	Mokka		Trailer Interface Control Module	✓	✓	✓	✓	✓	0041
2013	Mokka		Radio	✓	✓	✓	#	✓	
2013	Mokka		Digital Radio Receiver Control Module	✓	✓	✓	✓	✓	0041
2013	Mokka		Mobile Telephone Control Module	✓	✓	✓	✓	✓	0041
2013	Mokka		Front Seat Heating Control Module	✓	✓	✓	✓	✓	
2013	Mokka		Parking Assist Control Module	✓	✓	✓	✓	✓	0041
2013	Mokka		Frontview Camera Module	✓	✓	✓	✓	✓	0109 0236 0041
2013	Vivaro	Body	Park Pilot	✓	✓	✓	✓	✓	
2013	Vivaro	Body	Add On Heater	✓	✓	✓	✓	✓	0124 0125
2013	Vivaro	Body	Airbag	✓	✓	✓	✓	✓	0005
2013	Vivaro	Engine	P9Q 760/762 (1.9L)	✓	✓	✓	✓	✓	

2013	Vivaro	Transmission	MTA(Tecshift)		✓	✓	✓	✓		
2013	Zafira-B	Body	AHL/AFL (Headlamp Levelling)	✓	✓	✓	✓			
2013	Zafira-B	Body	Exterior Lighting/Turn Indicator System	✓	✓	✓	✓			
2013	Zafira-B	Body	Interior Lighting	✓	✓	✓	✓			
2013	Zafira-B	Body	Wipers/Washer	✓	✓	✓	✓			
2013	Zafira-B	Body	Central Door Lock	✓	✓	✓	✓			
2013	Zafira-B	Body	Instrument	✓	✓	✓	✓			
2013	Zafira-B	Body	Immobiliser	✓	✓	✓	✓			
2013	Zafira-B	Body	CIM (Steering Column Module)	✓	✓	✓	✓	✓		
2013	Zafira-B	Body	ECC/SAC (Electronic Climate Control)	✓	✓	✓	✓			
2013	Zafira-B	Body	EHS (Electrical Heater System)	✓	✓	✓	✓			
2013	Zafira-B	Body	PAS (Park Pilot)	✓	✓	✓	✓			
2013	Zafira-B	Body	SDM (Airbag)	✓	✓	✓	✓			0000 0001 0002 0003
2013	Zafira-B	Body	SLM (Shift Lever Module)	✓	✓	✓	✓			
2013	Zafira-B	Body	UEC (Underhood Electrical Centre)	✓	✓	✓	✓			
2013	Zafira-B	Body	REC (Rear Electrical Centre)	✓	✓	✓	✓			
2013	Zafira-B	Body	PEPS (Open&Start)	✓	✓	✓	✓			
2013	Zafira-B	Body	IPC ECU (Instrument Control Unit)	✓	✓	✓	✓	✓		0007 0056 0057 0058 0059 0060 0061 0002 0005
2013	Zafira-B	Body	Anti Theft Warning System	✓	✓	✓	✓			
2013	Zafira-B	Body	CIM(Steering Column Module)	✓	✓	✓	✓	✓		0052 0004 0053 0002 0005 0054 0055 0006
2013	Zafira-B	Chassis	ABS/TC/ESP (Vehicle Dynamic System)	✓	✓	✓	✓	✓		0006
2013	Zafira-B	Chassis	TPMS ECU (Tyre Pressure Monitoring)	✓	✓	✓	✓			
2013	Zafira-B	Chassis	TPMS (Tyre Pressure Monitoring System)	✓	✓	✓	✓			
2013	Zafira-B	Chassis	EHPS (Electrohydraulic Power Steering)	✓	✓	✓	✓			0004
2013	Zafira-B	Chassis	ABS/TC/ESP ECU(Electronic Control Unit)	✓	✓	✓	✓	✓		0004 0005 0063
2013	Zafira-B	Chassis	CDC (Continuous Damping Control)	✓	✓	✓	✓			
2013	Zafira-B	Engine	Z16XE1	✓	✓	✓	✓	✓		0034 0019
2013	Zafira-B	Engine	Z16XEP	✓	✓	✓	✓			0007 0008 0009 0010 0020 0011 0012 0067 0013 0014 0034 0019
2013	Zafira-B	Engine	Z16XER	✓	✓	✓	✓			0020 0007 0008 0009 0010 0011 0012 0067 0034 0013 0019
2013	Zafira-B	Engine	Z16VNG	✓	✓	✓	✓	✓		0034 0019
2013	Zafira-B	Engine	A16XER	✓	✓	✓	✓	✓		0010 0020 0034 0019
2013	Zafira-B	Engine	Z17DTJ	✓	✓	✓	✓	✓		0020 0026 0028 0021 0019
2013	Zafira-B	Engine	A17DTJ	✓	✓	✓	✓	✓		0007 0008 0009 0020 0026 0028 0019
2013	Zafira-B	Engine	A17DTR	✓	✓	✓	✓	✓		0007 0008 0009 0020 0026 0028 0019
2013	Zafira-B	Engine	Z18XER	✓	✓	✓	✓			0020 0007 0008 0009 0010 0011 0012 0067 0034 0013 0019
2013	Zafira-B	Engine	A18XER	✓	✓	✓	✓	✓		0007 0008 0009 0010 0020 0034 0019
2013	Zafira-B	Engine	Z19DT	✓	✓	✓	✓	✓		0007 0008 0009 0011 0012 0067 0024 0025 0070 0013 0033 0021 0030 0027 0028 0026 0029 0019
2013	Zafira-B	Engine	Z19DTH	✓	✓	✓	✓	✓		0007 0008 0009 0033 0011 0012 0067 0024 0025 0029 0026 0027 0028
2013	Zafira-B	Engine	Z20LEH	✓	✓	✓	✓	✓		0019
2013	Zafira-B	Engine	Z20LER	✓	✓	✓	✓	✓		0019
2013	Zafira-B	Engine	Z22YH	✓	✓	✓	✓	✓		0019
2013	Zafira-B	Engine	Engine(default)	✓	✓	✓	✓			
2013	Zafira-B	Transmission	AF 40-6	✓	✓	✓	✓	✓		0073 0074 0127 0076 0077 0078 0033 0034 0079
2013	Zafira-B	Transmission	MTA(Easytronic)	✓	✓	✓	✓	✓		0035 0036
2013	Zafira-B	Transmission	AF 22-4	✓	✓	✓	✓	✓		0033 0034
2013	Zafira-C		Engine Control Module	✓	✓	✓	✓	✓		0049 0085 0092 0018 0019 0132 0093 0020 0017 0094 0207 0097 0129 0086 0103 0098 0104 0102 0130 0096 0099 0100 0101 0237 0239 0105 0106 0107 0050 0259 0131 0122 0133 0134 0123 0136 0137 0138
2013	Zafira-C		Transmission Control Module	✓	✓	✓	✓	✓		0260 0123 0248
2013	Zafira-C		Body Control Module	✓	✓	✓	✓	✓		0048 0049 0046 0223 0208 0224 0047 0225
2013	Zafira-C		Electronic Brake Control Module	✓	✓	✓	✓	✓		0261 0084 0087
2013	Zafira-C		HVAC Control Module	✓	✓	✓	✓	✓		0211 0041
2013	Zafira-C		Inflatable Restraint Sensing and Diagnostic Module	✓	✓	✓	✓	✓		0250
2013	Zafira-C		Instrument Cluster	✓	✓	✓	✓	✓		0041
2013	Zafira-C		Fuel Injector Control Module	✓	✓	✓	✓	✓		
2013	Zafira-C		Fuel Pump Control Module	✓	✓	✓	✓	✓		0017
2013	Zafira-C		Distance Sensing Cruise Control Module	✓	✓	✓	✓	✓		0263
2013	Zafira-C		Parking Brake Control Module	✓	✓	✓	✓	✓		0110
2013	Zafira-C		Multi-Axis Acceleration Sensor Module	✓	✓	✓	✓	✓		0262 0087
2013	Zafira-C		Power Steering Control Module	✓	✓	✓	✓	✓		0089 0090
2013	Zafira-C		Steering Wheel Angle Sensor Module	✓	✓	✓	✓	✓		0083 0084
2013	Zafira-C		Suspension Control Module	✓	✓	✓	✓	✓		
2013	Zafira-C		Headlamp Control Module	✓	✓	✓	✓	✓		0252
2013	Zafira-C		Trailer Interface Control Module	✓	✓	✓	✓	✓		0041
2013	Zafira-C		Radio	✓	✓	✓	✓	✓		
2013	Zafira-C		Digital Radio Receiver Control Module	✓	✓	✓	✓	✓		0041
2013	Zafira-C		Multimedia Player Interface Module	✓	✓	✓	✓	✓		
2013	Zafira-C		Mobile Telephone Control Module	✓	✓	✓	✓	✓		0041
2013	Zafira-C		Front Seat Heating Control Module	✓	✓	✓	✓	✓		
2013	Zafira-C		Parking Assist Control Module	✓	✓	✓	✓	✓		0041
2013	Zafira-C		Frontview Camera Module	✓	✓	✓	✓	✓		0109 0236 0041
2012	Agila-B	Body	BCM (Body Control Module)	✓	✓	✓	✓			
2012	Agila-B	Body	Immobiliser	✓	✓	✓	✓			
2012	Agila-B	Body	SDM (Airbag)	✓	✓	✓	✓			0000 0001 0002 0003
2012	Agila-B	Chassis	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)	✓	✓	✓	✓			0006
2012	Agila-B	Chassis	Electronic Power Steering	✓	✓	✓	✓			
2012	Agila-B	Engine	K10B	✓	✓	✓	✓	✓		0016
2012	Agila-B	Engine	K12B	✓	✓	✓	✓	✓		0016
2012	Agila-B	Engine	D13A / Z 13 DTJ	✓	✓	✓	✓	✓		0041 0020 0021 0019 0026 0043

2012	Agila-B	Transmission	TCM (Transmission Control Module)	✓	✓	✓	✓	✓	0034
2012	Ampera		Engine Control Module	✓	✓	✓	✓	✓	0092 0018 0019 0020 0017 0212
2012	Ampera		Transmission Control Module	✓	✓	✓	✓	✓	
2012	Ampera		Body Control Module	✓	✓	✓	✓	✓	0048 0049 0046 0208 0223 0224 0047 0225
2012	Ampera		Electronic Brake Control Module	✓	✓	✓	✓	✓	0049 0226
2012	Ampera		Inflatable Restraint Sensing and Diagnostic Module	✓	✓	✓	✓	✓	0250
2012	Ampera		Instrument Cluster	✓	✓	✓	✓	✓	0041
2012	Ampera		Fuel Pump Control Module	✓	✓	✓	✓	✓	0017
2012	Ampera		Hybrid Powertrain Control Module	✓	✓	✓	✓	✓	
2012	Ampera		Drive Motor Control Module 1	✓	✓	✓	✓	✓	
2012	Ampera		Drive Motor Control Module 2	✓	✓	✓	✓	✓	
2012	Ampera		Auxiliary Transmission Fluid Pump	✓	✓	✓	✓	✓	
2012	Ampera		Parking Brake Control Module	✓	✓	✓	✓	✓	0110
2012	Ampera		Multi-Axis Acceleration Sensor Module	✓	✓	✓	✓	✓	0262 0087
2012	Ampera		Power Steering Control Module	✓	✓	✓	✓	#	0089 0090 0091
2012	Ampera		Steering Wheel Angle Sensor Module	✓	✓	✓	✓	✓	0083 0084
2012	Ampera		Passenger Presence Module	✓	✓	✓	✓	✓	
2012	Ampera		Radio	✓	✓	✓	✓	✓	
2012	Ampera		Digital Radio Receiver Control Module	✓	✓	✓	✓	✓	0041
2012	Ampera		Mobile Telephone Control Module	✓	✓	✓	✓	✓	0041
2012	Ampera		Telematics Communication Interface Control Module	✓	✓	✓	✓	✓	0286 0287
2012	Ampera		Remote Heater and Air Conditioning Control Module	✓	✓	✓	✓	✓	0211 0227
2012	Ampera		Electric A/C Compressor Control Module	✓	✓	✓	✓	✓	
2012	Ampera		Coolant Heater Control Module	✓	✓	✓	✓	✓	
2012	Ampera		Front Seat Heating Control Module	✓	✓	✓	✓	✓	
2012	Ampera		Keyless Entry Control Module	✓	✓	✓	✓	✓	
2012	Ampera		Parking Assist Control Module	✓	✓	✓	✓	✓	0041
2012	Ampera		Steering Column Lock Control Module	✓	✓	✓	✓	✓	
2012	Ampera		Battery Charger Control Module	✓	✓	✓	✓	✓	
2012	Ampera		Hybrid Powertrain Control Module 2	✓	✓	✓	✓	✓	0230 0231 0232 0233 0234 0235
2012	Ampera		Battery Energy Control Module	✓	✓	✓	✓	✓	
2012	Antara		Engine Control Module	✓	✓	✓	✓	✓	0049 0085 0092 0018 0019 0020 0017 0096 0247 0100 0237 0131 0238 0086 0239 0240 0103 0241 0242 0104 0122 0105 0107 0243 0244 0245 0246
2012	Antara		Transmission Control Module	✓	✓	✓	✓	✓	0248
2012	Antara		Body Control Module	✓	✓	✓	✓	✓	0048 0049 0249
2012	Antara		Electronic Brake Control Module	✓	✓	✓	✓	✓	0084
2012	Antara		HVAC Control Module	✓	✓	✓	✓	✓	
2012	Antara		Inflatable Restraint Sensing and Diagnostic Module	✓	✓	✓	✓	✓	0250 0249
2012	Antara		Instrument Cluster	✓	✓	✓	✓	✓	
2012	Antara		Fuel Pump Control Module	✓	✓	✓	✓	✓	0017
2012	Antara		Rear Differential Clutch Control Module	✓	✓	✓	✓	✓	0251
2012	Antara		Parking Brake Control Module	✓	✓	✓	✓	✓	0110
2012	Antara		Variable Power Steering Control Module	✓	✓	✓	✓	✓	
2012	Antara		Auxiliary Body Control Module	✓	✓	✓	✓	✓	
2012	Antara		Headlamp Control Module	✓	✓	✓	✓	✓	0252 0253
2012	Antara		Radio	✓	✓	✓	✓	✓	0254
2012	Antara		Mobile Telephone Control Module	✓	✓	✓	✓	✓	
2012	Antara		Info Display Module	✓	✓	✓	✓	✓	0254 0257 0258
2012	Antara		Remote Control Door Lock Receiver	✓	✓	✓	✓	✓	0255 0214 0215 0216 0217 0218 0256 0225
2012	Antara		Parking Assist Control Module	✓	✓	✓	✓	✓	
2012	Antara		Theft Deterrent Module	✓	✓	✓	✓	✓	
2012	Astra-H	Body	AHL/APL (Headlamp Levelling)	✓	✓	✓	✓	✓	
2012	Astra-H	Body	Exterior Lighting/Turn Indicator System	✓	✓	✓	✓	✓	
2012	Astra-H	Body	Interior Lighting	✓	✓	✓	✓	✓	
2012	Astra-H	Body	Wipers/Washer	✓	✓	✓	✓	✓	
2012	Astra-H	Body	Central Door Lock	✓	✓	✓	✓	✓	
2012	Astra-H	Body	Instrument	✓	✓	✓	✓	✓	
2012	Astra-H	Body	Immobiliser	✓	✓	✓	✓	✓	
2012	Astra-H	Body	CIM (Steering Column Module)	✓	✓	✓	✓	✓	
2012	Astra-H	Body	Anti Theft Warning System	✓	✓	✓	✓	✓	
2012	Astra-H	Body	Electrohydraulic HardTop	✓	✓	✓	✓	✓	
2012	Astra-H	Body	ECC/SAC (Electronic Climate Control)	✓	✓	✓	✓	✓	
2012	Astra-H	Body	IPC ECU (Instrument Control Unit)	✓	✓	✓	✓	✓	0007 0056 0057 0058 0059 0060 0061 0002 0005
2012	Astra-H	Body	EHS (Electrical Heater System)	✓	✓	✓	✓	✓	
2012	Astra-H	Body	PAS (Park Pilot)	✓	✓	✓	✓	✓	
2012	Astra-H	Body	SDM (Airbag)	✓	✓	✓	✓	✓	0000 0001 0002 0003
2012	Astra-H	Body	SLM (Shift Lever Module)	✓	✓	✓	✓	✓	
2012	Astra-H	Body	UEC (Underhood Electrical Centre)	✓	✓	✓	✓	✓	
2012	Astra-H	Body	REC (Rear Electrical Centre)	✓	✓	✓	✓	✓	
2012	Astra-H	Body	PEPS (Open&Start)	✓	✓	✓	✓	✓	
2012	Astra-H	Body	CIM(Steering Column Module)	✓	✓	✓	✓	✓	0052 0004 0053 0002 0005 0054 0055 0006
2012	Astra-H	Chassis	TPMS ECU (Tyre Pressure Monitoring)	✓	✓	✓	✓	✓	
2012	Astra-H	Chassis	TPMS (Tyre Pressure Monitoring System)	✓	✓	✓	✓	✓	
2012	Astra-H	Chassis	EHPS (Electrohydraulic Power Steering)	✓	✓	✓	✓	✓	0004
2012	Astra-H	Chassis	ABS/TC/ESP ECU(Electronic Control Unit)	✓	✓	✓	✓	✓	0004 0005 0063
2012	Astra-H	Chassis	CDC (Continuous Damping Control)	✓	✓	✓	✓	✓	
2012	Astra-H	Chassis	ABS/TC/ESP (Vehicle Dynamic System)	✓	✓	✓	✓	✓	
2012	Astra-H	Engine	Z12XEP	✓	✓	✓	✓	✓	0010 0064 0012 0065 0013 0066 0007 0008 0009 0019
2012	Astra-H	Engine	Y13DTH	✓	✓	✓	✓	✓	0010 0064 0012 0065 0013 0066 0007 0008 0009 0019
2012	Astra-H	Engine	Z13DTH	✓	✓	✓	✓	✓	0007 0008 0009 0020 0011 0012 0067 0021 0030 0029 0026 0027 0019
2012	Astra-H	Engine	Z14XEL	✓	✓	✓	✓	✓	0007 0008 0009 0010 0011 0012 0067 0013 0014 0019
2012	Astra-H	Engine	Z14XEP	✓	✓	✓	✓	✓	0007 0008 0009 0010 0011 0012 0067 0013 0014 0019
2012	Astra-H	Engine	Z16LET	✓	✓	✓	✓	✓	0010 0064 0012 0065 0013 0066 0007 0008 0009 0019

2012	Astra-H	Engine	Z16XE1	✓	✓	✓	✓	✓	0020 0010 0064 0068 0065 0013 0066 0069 0007 0008 0009 0019
2012	Astra-H	Engine	Z16XEP	✓	✓	✓	✓		0007 0008 0009 0010 0020 0011 0012 0067 0013 0014 0034 0019
2012	Astra-H	Engine	Z16XER	✓	✓	✓	✓		0020 0007 0008 0009 0010 0011 0012 0067 0034 0013 0019
2012	Astra-H	Engine	A16LET	✓	✓	✓	✓	✓	0010 0064 0012 0065 0013 0066 0007 0008 0009 0019
2012	Astra-H	Engine	A16XER	✓	✓	✓	✓	✓	0020 0010 0064 0068 0065 0034 0013 0007 0008 0009 0019
2012	Astra-H	Engine	Z17DTH	✓	✓	✓	✓	✓	0007 0008 0009 0011 0012 0067 0021 0025 0013 0030 0033 0019
2012	Astra-H	Engine	Z17DTJ	✓	✓	✓	✓	✓	0007 0008 0009 0020 0011 0012 0067 0015 0023 0024 0025 0013 0026 0027 0028 0029 0030 0021 0019
2012	Astra-H	Engine	Z17DTL	✓	✓	✓	✓	✓	0064 0012 0065 0021 0025 0013 0030 0033 0019
2012	Astra-H	Engine	Z17DTR	✓	✓	✓	✓	✓	0007 0008 0009 0020 0011 0012 0067 0015 0023 0024 0025 0013 0026 0027 0028 0029 0030 0021 0019
2012	Astra-H	Engine	A17DTJ	✓	✓	✓	✓	✓	0020 0064 0012 0065 0015 0023 0024 0025 0013 0029 0026 0070 0027 0071 0007 0008 0009 0028 0019
2012	Astra-H	Engine	A17DTR	✓	✓	✓	✓	✓	0020 0064 0012 0065 0015 0023 0024 0025 0013 0029 0026 0070 0027 0071 0007 0008 0009 0028 0019
2012	Astra-H	Engine	Z18XE	✓	✓	✓	✓		0020 0007 0008 0009 0010 0011 0012 0067 0013 0019
2012	Astra-H	Engine	Z18XER	✓	✓	✓	✓	✓	0007 0008 0009 0010 0020 0011 0012 0067 0034 0013 0019
2012	Astra-H	Engine	A18XER	✓	✓	✓	✓	✓	0007 0008 0009 0010 0020 0034 0019
2012	Astra-H	Engine	Z19DT	✓	✓	✓	✓	✓	0007 0008 0009 0011 0012 0067 0024 0025 0070 0013 0033 0021 0030 0027 0028 0026 0029 0019
2012	Astra-H	Engine	Z19DTH	✓	✓	✓	✓	✓	0007 0008 0009 0011 0012 0067 0024 0025 0070 0013 0033 0021 0030 0027 0028 0026 0029 0019
2012	Astra-H	Engine	Z20LEH	✓	✓	✓	✓	✓	0010 0064 0012 0065 0013 0066 0007 0008 0009 0019
2012	Astra-H	Engine	Z20LEL	✓	✓	✓	✓	✓	0010 0064 0012 0065 0013 0066 0007 0008 0009 0019
2012	Astra-H	Engine	Z20LER	✓	✓	✓	✓	✓	0010 0064 0012 0065 0013 0066 0007 0008 0009 0019
2012	Astra-H	Engine	Z22VH	✓	✓	✓	✓	✓	0007 0008 0009 0072 0020 0011 0012 0067 0013 0019
2012	Astra-H	Engine	Engine (default)	✓	✓	✓			
2012	Astra-H	Transmission	AF 40-6	✓	✓	✓	✓	✓	0073 0074 0075 0076 0077 0078 0033 0004 0034 0079
2012	Astra-H	Transmission	AF17-4	✓	✓	✓	✓	✓	0031 0032 0033 0004 0034
2012	Astra-H	Transmission	AF 22-4	✓	✓	✓	✓	✓	0033 0080 0034 0031
2012	Astra-H	Transmission	MTA(Easytronic)	✓	✓	✓	✓	✓	0080 0035 0036 0062
2012	Astra-H	Transmission	MTA(Easytronic Magneti Marelli)	✓	✓	✓	✓	✓	0080 0005 0062
2012	Astra-J		Engine Control Module	✓	✓	✓	✓	✓	0097 0085 0240 0099 0259 0131 0086 0103 0100 0105 0130 0020 0107 0207 0050 0101 0239 0132 0237 0098 0104 0102 0106 0049 0093 0122 0133 0134 0092 0018 0019 0017 0096 0094
2012	Astra-J		Transmission Control Module	✓	✓	✓	✓	✓	0260 0123 0248
2012	Astra-J		Body Control Module	✓	✓	✓	✓	✓	0048 0049 0046 0223 0208 0224 0047
2012	Astra-J		Electronic Brake Control Module	✓	✓	✓	✓	✓	0261 0084 0087
2012	Astra-J		Inflatable Restraint Sensing and Diagnostic Module	✓	✓	✓	✓	✓	0250
2012	Astra-J		Instrument Cluster	✓	✓	✓	✓	✓	0041
2012	Astra-J		Fuel Injector Control Module	✓	✓	✓	✓	✓	
2012	Astra-J		Fuel Pump Control Module	✓	✓	✓	✓	✓	0017
2012	Astra-J		Parking Brake Control Module	✓	✓	✓	✓	✓	0110
2012	Astra-J		Multi-Axis Acceleration Sensor Module	✓	✓	✓	✓	✓	0262 0087
2012	Astra-J		Power Steering Control Module	✓	✓	✓	✓	✓	0089 0090 0091
2012	Astra-J		Steering Wheel Angle Sensor Module	✓	✓	✓	✓	✓	0083 0084
2012	Astra-J		Suspension Control Module	✓	✓	✓	✓	✓	
2012	Astra-J		Chime Alarm Control Module	✓	✓	✓	✓	✓	
2012	Astra-J		Headlamp Control Module	✓	✓	✓	✓	✓	0252
2012	Astra-J		Trailer Interface Control Module	✓	✓	✓	✓	✓	0041
2012	Astra-J		Radio	✓	✓	✓	✓	✓	
2012	Astra-J		Digital Radio Receiver Control Module	✓	✓	✓	✓	✓	0041
2012	Astra-J		Multimedia Player Interface Module	✓	✓	✓	✓	✓	
2012	Astra-J		Mobile Telephone Control Module	✓	✓	✓	✓	✓	0041
2012	Astra-J		Remote Heater and Air Conditioning Control Module	✓	✓	✓	✓	✓	0211 0041
2012	Astra-J		Front Seat Heating Control Module	✓	✓	✓	✓	✓	
2012	Astra-J		Parking Assist Control Module	✓	✓	✓	✓	✓	
2012	Astra-J		Vehicle Direction Camera Control Module	✓	✓	✓	✓	✓	0109 0288 0041
2012	Combo-D		Engine Control Module	✓	✓	✓	✓	✓	0100 0237 0086 0103 0265 0132 0105 0020 0122 0267 0107 0050 0226 0283 0123 0284 0285 0102 0269 0085 0270 0271 0264 0266 0268
2012	Combo-D		Transmission Control Module	✓	✓	✓	✓	✓	0272 0273
2012	Combo-D		Body Control Module	✓	✓	✓	✓	✓	0274
2012	Combo-D		Electronic Brake Control Module	✓	✓	✓	✓	✓	0275 0261 0084
2012	Combo-D		HVAC Control Module	✓	✓	✓	✓	✓	
2012	Combo-D		Inflatable Restraint Sensing and Diagnostic Module	✓	✓	✓	✓	✓	

2012	Combo-D		Instrument Cluster	✓	✓	✓	✓	✓	0276
2012	Combo-D		Multimedia Player Interface Module	✓	✓	✓	✓	✓	
2012	Combo-D		Auxiliary Heater Control Module	✓	✓	✓	✓	✓	
2012	Combo-D		Parking Assist Control Module	✓	✓	✓	✓	✓	
2012	Corsa-C	Body	Airbag	✓	✓	✓	✓	✓	
2012	Corsa-C	Body	Body Control Module	✓	✓	✓	✓	✓	0052 0059 0140
2012	Corsa-C	Body	Instrument	✓	✓	✓	✓	✓	
2012	Corsa-C	Body	Immobiliser	✓	✓	✓	✓	✓	0141 0142
2012	Corsa-C	Body	Add On Heater	✓	✓	✓	✓	✓	0123 0124
2012	Corsa-C	Chassis	Electronic Power Steering	✓	✓	✓	✓	✓	0143
2012	Corsa-C	Chassis	ABS/ESP8 (Anti-lock Braking System/Electronic Stability Program)	✓	✓	✓	✓	✓	0006 0144 0145 0146 0005
2012	Corsa-C	Chassis	ABS-5.3/5.4 (+TC) (Anti-lock Braking System)	✓	✓	✓	✓	✓	
2012	Corsa-C	Chassis	Electronic Power Steering	✓	✓	✓	✓	✓	0142
2012	Corsa-C	Engine	Z10XEP	✓	✓	✓	✓	✓	0012 0022 0066 0034
2012	Corsa-C	Engine	Z12XE	✓	✓	✓	✓	✓	0007 0147 0010 0041 0020 0022 0012 0066 0034
2012	Corsa-C	Engine	Z12XEP	✓	✓	✓	✓	✓	0012 0022 0066 0034
2012	Corsa-C	Engine	Y13DT	✓	✓	✓	✓	✓	0041 0020 0022 0012 0021
2012	Corsa-C	Engine	Z13DT	✓	✓	✓	✓	✓	0020 0041 0022 0012 0021
2012	Corsa-C	Engine	Z13DTJ	✓	✓	✓	✓	✓	0041
2012	Corsa-C	Engine	Z14XE	✓	✓	✓	✓	✓	0022
2012	Corsa-C	Engine	Z14XEP	✓	✓	✓	✓	✓	0012
2012	Corsa-C	Engine	Z16SE	✓	✓	✓	✓	✓	0007 0022 0012
2012	Corsa-C	Engine	Z16YNG	✓	✓	✓	✓	✓	0007 0148 0146 0010 0020 0012 0022
2012	Corsa-C	Engine	Y17DT	✓	✓	✓	✓	✓	
2012	Corsa-C	Engine	Y17DTL	✓	✓	✓	✓	✓	0007 0022 0012
2012	Corsa-C	Engine	Z17DTH	✓	✓	✓	✓	✓	0007 0147 0020 0021 0149 0023 0012 0022
2012	Corsa-C	Engine	Z18XE	✓	✓	✓	✓	✓	0146 0010 0041 0020 0012 0022
2012	Corsa-C	Transmission	AF 13-II/17/20/22 CAN	✓	✓	✓	✓	✓	
2012	Corsa-C	Transmission	Easytronic(MTA)	✓	✓	✓	✓	✓	0012 0150
2012	Corsa-D	Body	Exterior Lighting	✓	✓	✓	✓	✓	
2012	Corsa-D	Body	Interior Lighting	✓	✓	✓	✓	✓	
2012	Corsa-D	Body	Wipers/Washer	✓	✓	✓	✓	✓	
2012	Corsa-D	Body	Heating,Ventilation and Air Cond.	✓	✓	✓	✓	✓	
2012	Corsa-D	Body	Anti Theft Warning System	✓	✓	✓	✓	✓	
2012	Corsa-D	Body	Central Door Lock	✓	✓	✓	✓	✓	
2012	Corsa-D	Body	Immobiliser	✓	✓	✓	✓	✓	
2012	Corsa-D	Body	AFL (Adaptive Forward Lighting)	✓	✓	✓	✓	✓	
2012	Corsa-D	Body	EHS (Electrical Heater System)	✓	✓	✓	✓	✓	
2012	Corsa-D	Body	IPC ECU (Instrument Control Unit)	✓	✓	✓	✓	✓	
2012	Corsa-D	Body	PAS (Park Pilot)	✓	✓	✓	✓	✓	
2012	Corsa-D	Body	SDM (Airbag)	✓	✓	✓	✓	✓	0000 0001 0002 0003
2012	Corsa-D	Body	TIM(Traffier Interface Module)	✓	✓	✓	✓	✓	
2012	Corsa-D	Body	BCM (Body Control Module)	✓	✓	✓	✓	✓	
2012	Corsa-D	Chassis	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)	✓	✓	✓	✓	✓	
2012	Corsa-D	Chassis	Electronic Power Steering	✓	✓	✓	✓	✓	0004 0005 0006
2012	Corsa-D	Chassis	Fuel injector control module	✓	✓	✓	✓	✓	
2012	Corsa-D	Engine	Z10XEP	✓	✓	✓	✓	✓	0007 0008 0009 0010 0011 0012 0013 0014 0015
2012	Corsa-D	Engine	A10XEP	✓	✓	✓	✓	✓	0007 0016 0017 0018 0019
2012	Corsa-D	Engine	Z12XEP	✓	✓	✓	✓	✓	0007 0008 0009 0010 0011 0012 0013 0014 0015
2012	Corsa-D	Engine	A12XER	✓	✓	✓	✓	✓	0007 0019
2012	Corsa-D	Engine	A12XEL	✓	✓	✓	✓	✓	0007 0019
2012	Corsa-D	Engine	Z13DTH	✓	✓	✓	✓	✓	0020 0011 0012 0015 0021
2012	Corsa-D	Engine	Z13DTE	✓	✓	✓	✓	✓	0007
2012	Corsa-D	Engine	Z13DTJ	✓	✓	✓	✓	✓	0020 0011 0012 0015 0021
2012	Corsa-D	Engine	A13DTC	✓	✓	✓	✓	✓	0020
2012	Corsa-D	Engine	Z14XEP	✓	✓	✓	✓	✓	0007 0008 0009 0010 0011 0012 0013 0014 0015
2012	Corsa-D	Engine	A14XEL	✓	✓	✓	✓	✓	0007 0016 0017 0018 0019
2012	Corsa-D	Engine	A14XER	✓	✓	✓	✓	✓	0007 0016 0017 0018 0019
2012	Corsa-D	Engine	Z16LEL	✓	✓	✓	✓	✓	
2012	Corsa-D	Engine	Z16LER	✓	✓	✓	✓	✓	
2012	Corsa-D	Engine	A16LEL	✓	✓	✓	✓	✓	
2012	Corsa-D	Engine	A16LER	✓	✓	✓	✓	✓	
2012	Corsa-D	Engine	Z17DTR	✓	✓	✓	✓	✓	0020 0022 0012 0015 0023 0024 0025 0013 0026 0027 0028 0029 0021 0030
2012	Corsa-D	Engine	Engine(default)	✓	✓	✓	✓	✓	
2012	Corsa-D	Transmission	MTA(Easytronic Magneti Marelli)	✓	✓	✓	✓	✓	
2012	Corsa-D	Transmission	AF 13-4	✓	✓	✓	✓	✓	0031 0032 0033 0034
2012	Corsa-D	Transmission	MTA(Easytronic)	✓	✓	✓	✓	✓	0035 0036
2012	Insignia		Engine Control Module	✓	✓	✓	✓	✓	0097 0085 0129 0086 0103 0098 0104 0102 0130 0020 0017 0094 0099 0101 0239 0132 0100 0237 0105 0106 0107 0207 0050 0019 0049 0092 0018 0096 0093
2012	Insignia		Transmission Control Module	✓	✓	✓	✓	✓	0260 0123
2012	Insignia		Body Control Module	✓	✓	✓	✓	✓	0048 0049 0046 0223 0208 0224 0047
2012	Insignia		Electronic Brake Control Module	✓	✓	✓	✓	✓	0261 0084 0087
2012	Insignia		Inflatable Restraint Sensing and Diagnostic Module	✓	✓	✓	✓	✓	0250
2012	Insignia		Instrument Cluster	✓	✓	✓	✓	✓	0041
2012	Insignia		Fuel Injector Control Module	✓	✓	✓	✓	✓	
2012	Insignia		Fuel Pump Control Module	✓	✓	✓	✓	✓	0017
2012	Insignia		Rear Differential Clutch Control Module	✓	✓	✓	✓	✓	
2012	Insignia		Parking Brake Control Module	✓	✓	✓	✓	✓	0110
2012	Insignia		Multi-Axis Acceleration Sensor Module	✓	✓	✓	✓	✓	0262 0087
2012	Insignia		Power Steering Control Module	✓	✓	✓	✓	✓	0089 0090 0091
2012	Insignia		Steering Wheel Angle Sensor Module	✓	✓	✓	✓	✓	0083 0084
2012	Insignia		Suspension Control Module	✓	✓	✓	✓	✓	
2012	Insignia		Chime Alarm Control Module	✓	✓	✓	✓	✓	
2012	Insignia		Headlamp Control Module	✓	✓	✓	✓	✓	0252
2012	Insignia		Trailer Interface Control Module	✓	✓	✓	✓	✓	0041
2012	Insignia		Radio	✓	✓	✓	✓	✓	

2012	Insignia		Digital Radio Receiver Control Module	✓	✓	✓	✓	✓	0041
2012	Insignia		Multimedia Player Interface Module	✓	✓	✓	✓	✓	0041
2012	Insignia		Mobile Telephone Control Module	✓	✓	✓	✓	✓	0041
2012	Insignia		Remote Heater and Air Conditioning Control Module	✓	✓	✓	✓	✓	0211 0041
2012	Insignia		Liftgate Control Module	✓	✓	✓	✓	✓	0280
2012	Insignia		Seat Memory Control Module	✓	✓	✓	✓	✓	0289
2012	Insignia		Front Seat Heating Control Module	✓	✓	✓	✓	✓	
2012	Insignia		Parking Assist Control Module	✓	✓	✓	✓	✓	
2012	Insignia		Vehicle Direction Camera Control Module	✓	✓	✓	✓	✓	0109 0288 0041
2012	Insignia		Distance Sensing Cruise Control Module	✓	✓	✓	✓	✓	0263
2012	Meriva-B	Body	Front Seat Heating Control Module	✓	✓	✓	✓	✓	
2012	Meriva-B	Body	BCM (Body Control Module)	✓	✓	✓	✓	✓	
2012	Meriva-B	Body	Headlamp Control Module	✓	✓	✓	✓	✓	
2012	Meriva-B	Body	Inflatable Restraint Sensing&Diag.Module	✓	✓	✓	✓	✓	
2012	Meriva-B	Body	Parking Assist Control Module	✓	✓	✓	✓	✓	0108 0040
2012	Meriva-B	Body	Remote Heater & A/C Control Module	✓	✓	✓	✓	✓	
2012	Meriva-B	Body	Instrument	✓	✓	✓	✓	✓	0040
2012	Meriva-B	Body	Trailer Interface Control Module	✓	✓	✓	✓	✓	
2012	Meriva-B	Chassis	Electronic Brake Control Module	✓	✓	✓	✓	✓	
2012	Meriva-B	Chassis	Electric Power Steering Control Module	✓	✓	✓	✓	✓	
2012	Meriva-B	Chassis	Parking Brake Control Module	✓	✓	✓	✓	✓	0109 0110
2012	Meriva-B	Chassis	Steering Wheel Angle Sensor Module	✓	✓	✓	✓	✓	0082
2012	Meriva-B	Chassis	Fuel injector control module	✓	✓	✓	✓	✓	
2012	Meriva-B	Engine	A 13 DTC 1.3(LDV)	✓	✓	✓	✓	✓	0084 0111 0112 0024 0025 0029 0026 0070 0113 0114 0115 0116 0117 0118
2012	Meriva-B	Engine	A 13 DTE 1.3(LSF)	✓	✓	✓	✓	✓	0084 0119 0112 0024 0025 0029 0026 0070 0113 0114 0115 0116 0117 0120 0019
2012	Meriva-B	Engine	A 14 NEL (LUH)	✓	✓	✓	✓	✓	0019
2012	Meriva-B	Engine	A 14 NET (LUJ)	✓	✓	✓	✓	✓	0019
2012	Meriva-B	Engine	A 14 XER (LDD)	✓	✓	✓	✓	✓	0019
2012	Meriva-B	Engine	A 17 DTC 1.7(LUE)	✓	✓	✓	✓	✓	0121 0104 0019
2012	Meriva-B	Engine	A 17 DTS 1.7(LUD)	✓	✓	✓	✓	✓	0121 0104 0019
2012	Meriva-B	Engine	Engine Control Module	✓	✓	✓	✓	✓	0026 0019
2012	Meriva-B	Transmission	Transmission Control Module	✓	✓	✓	✓	✓	0079 0122
2012	Vauxhall VXRS	Body	AHL(Automatic Headlamp Levelling)	✓	✓	✓	✓	✓	
2012	Vauxhall VXRS	Body	BCM (Body Control Module)	✓	✓	✓	✓	✓	
2012	Vauxhall VXRS	Body	HVAC(Heating Ventilation and Cooling)	✓	✓	✓	✓	✓	
2012	Vauxhall VXRS	Body	Immobiliser	✓	✓	✓	✓	✓	
2012	Vauxhall VXRS	Body	MSM(Memory Seat and Mirrors)	✓	✓	✓	✓	✓	
2012	Vauxhall VXRS	Body	Park Assist	✓	✓	✓	✓	✓	
2012	Vauxhall VXRS	Body	SDM(Sensing and Diagnostic Module)	✓	✓	✓	✓	✓	
2012	Vauxhall VXRS	Body	IPC (Instrument Panel Cluster)	✓	✓	✓	✓	✓	
2012	Vauxhall VXRS	Body	RFA (Multipurpose Receiver Module)	✓	✓	✓	✓	✓	
2012	Vauxhall VXRS	Chassis	Fuel Pump Control Module	✓	✓	✓	✓	✓	
2012	Vauxhall VXRS	Chassis	EBCM(Electronic Brake Control Module)	✓	✓	✓	✓	✓	
2012	Vauxhall VXRS	Chassis	ESC(Electronic Suspension Control)	✓	✓	✓	✓	✓	
2012	Vauxhall VXRS	Engine	V8 GEN IV	✓	✓	✓	✓	✓	0151
2012	Vauxhall VXRS	Transmission	Automatic Transmission	✓	✓	✓	✓	✓	
2012	Vivaro	Body	Airbag	✓	✓	✓	✓	✓	0005
2012	Vivaro	Body	Park Pilot	✓	✓	✓	✓	✓	
2012	Vivaro	Body	Add On Heater	✓	✓	✓	✓	✓	0123 0124
2012	Vivaro	Body	Body Control Module	✓	✓	✓	✓	✓	
2012	Vivaro	Body	Airbag	✓	✓	✓	✓	✓	0005
2012	Vivaro	Transmission	MTA(Tecshift)	✓	✓	✓	✓	✓	
2012	Zafira-B	Body	AHL/AFL (Headlamp Levelling)	✓	✓	✓	✓	✓	
2012	Zafira-B	Body	Exterior Lighting/Turn Indicator System	✓	✓	✓	✓	✓	
2012	Zafira-B	Body	Interior Lighting	✓	✓	✓	✓	✓	
2012	Zafira-B	Body	Wipers/Washer	✓	✓	✓	✓	✓	
2012	Zafira-B	Body	Central Door Lock	✓	✓	✓	✓	✓	
2012	Zafira-B	Body	Instrument	✓	✓	✓	✓	✓	
2012	Zafira-B	Body	Immobiliser	✓	✓	✓	✓	✓	
2012	Zafira-B	Body	CIM (Steering Column Module)	✓	✓	✓	✓	✓	
2012	Zafira-B	Body	ECC/SAC (Electronic Climate Control)	✓	✓	✓	✓	✓	
2012	Zafira-B	Body	EHS (Electrical Heater System)	✓	✓	✓	✓	✓	
2012	Zafira-B	Body	PAS (Park Pilot)	✓	✓	✓	✓	✓	
2012	Zafira-B	Body	SDM (Airbag)	✓	✓	✓	✓	✓	0000 0001 0002 0003
2012	Zafira-B	Body	SLM (Shift Lever Module)	✓	✓	✓	✓	✓	
2012	Zafira-B	Body	UEC (Underhood Electrical Centre)	✓	✓	✓	✓	✓	
2012	Zafira-B	Body	REC (Rear Electrical Centre)	✓	✓	✓	✓	✓	
2012	Zafira-B	Body	PEPS (Open&Start)	✓	✓	✓	✓	✓	
2012	Zafira-B	Body	IPC ECU (Instrument Control Unit)	✓	✓	✓	✓	✓	0007 0056 0057 0058 0059 0060 0061 0002 0005
2012	Zafira-B	Body	Anti Theft Warning System	✓	✓	✓	✓	✓	
2012	Zafira-B	Body	CIM(Steering Column Module)	✓	✓	✓	✓	✓	0052 0004 0053 0002 0005 0054 0055 0006
2012	Zafira-B	Chassis	ABS/TC/ESP (Vehicle Dynamic System)	✓	✓	✓	✓	✓	0006
2012	Zafira-B	Chassis	TPMS ECU (Tyre Pressure Monitoring)	✓	✓	✓	✓	✓	
2012	Zafira-B	Chassis	TPMS (Tyre Pressure Monitoring System)	✓	✓	✓	✓	✓	
2012	Zafira-B	Chassis	EHPS (Electrohydraulic Power Steering)	✓	✓	✓	✓	✓	0004
2012	Zafira-B	Chassis	ABS/TC/ESP ECU(Electronic Control Unit)	✓	✓	✓	✓	✓	0004 0005 0063
2012	Zafira-B	Chassis	CDC (Continuous Damping Control)	✓	✓	✓	✓	✓	
2012	Zafira-B	Engine	Z16XE1	✓	✓	✓	✓	✓	0034 0019
2012	Zafira-B	Engine	Z16XEP	✓	✓	✓	✓	✓	0007 0008 0009 0010 0020 0011 0012 0067 0013 0014 0034 0019
2012	Zafira-B	Engine	Z16XER	✓	✓	✓	✓	✓	0020 0007 0008 0009 0010 0011 0012 0067 0034 0013 0019
2012	Zafira-B	Engine	Z16YNG	✓	✓	✓	✓	✓	0034 0019
2012	Zafira-B	Engine	A16XER	✓	✓	✓	✓	✓	0010 0020 0034 0019
2012	Zafira-B	Engine	Z17DTJ	✓	✓	✓	✓	✓	0020 0026 0028 0021 0019
2012	Zafira-B	Engine	A17DTJ	✓	✓	✓	✓	✓	0125 0007 0008 0009 0020 0026 0028 0019
2012	Zafira-B	Engine	A17DTR	✓	✓	✓	✓	✓	0007 0008 0009 0020 0026 0028 0019
2012	Zafira-B	Engine	Z18XER	✓	✓	✓	✓	✓	0020 0007 0008 0009 0010 0011 0012 0067 0034 0013 0019
2012	Zafira-B	Engine	A18XER	✓	✓	✓	✓	✓	0007 0008 0009 0010 0020 0034 0019

2012	Zafira-B	Engine	Z19DT	✓	✓	✓	✓	✓	0007 0008 0009 0011 0012 0067 0024 0025 0070 0013 0033 0021 0030 0027 0028 0026 0029 0019
2012	Zafira-B	Engine	Z19DTH	✓	✓	✓	✓	✓	0007 0008 0009 0033 0011 0012 0067 0024 0025 0029 0026 0027 0028
2012	Zafira-B	Engine	Z20LEH	✓	✓	✓	✓	✓	0019
2012	Zafira-B	Engine	Z20LER	✓	✓	✓	✓	✓	0019
2012	Zafira-B	Engine	Z22YH	✓	✓	✓	✓	✓	0019
2012	Zafira-B	Engine	Engine(default)	✓	✓	✓	✓	✓	
2012	Zafira-B	Transmission	AF 40-6	✓	✓	✓	✓	✓	0073 0074 0076 0077 0078 0033 0034 0079
2012	Zafira-B	Transmission	MTA(Easytronic)	✓	✓	✓	✓	✓	0035 0036
2012	Zafira-B	Transmission	AF 22-4	✓	✓	✓	✓	✓	0033 0034
2012	Zafira-C		Engine Control Module	✓	✓	✓	✓	✓	0097 0085 0099 0101 0086 0239 0103 0132 0100 0237 0098 0104 0102 0105 0020 0106 0107 0207 0050 0129 0130 0017 0094 0049 0092 0018 0019 0093
2012	Zafira-C		Transmission Control Module	✓	✓	✓	✓	✓	0260 0123 0248
2012	Zafira-C		Body Control Module	✓	✓	✓	✓	✓	0048 0049 0046 0223 0208 0224 0047
2012	Zafira-C		Electronic Brake Control Module	✓	✓	✓	✓	✓	0261 0084 0087
2012	Zafira-C		Inflatable Restraint Sensing and Diagnostic Module	✓	✓	✓	✓	✓	0250
2012	Zafira-C		Instrument Cluster	✓	✓	✓	✓	✓	0041
2012	Zafira-C		Fuel Injector Control Module	✓	✓	✓	✓	✓	
2012	Zafira-C		Distance Sensing Cruise Control Module	✓	✓	✓	✓	✓	0263
2012	Zafira-C		Parking Brake Control Module	✓	✓	✓	✓	✓	0110
2012	Zafira-C		Multi-Axis Acceleration Sensor Module	✓	✓	✓	✓	✓	0262 0087
2012	Zafira-C		Power Steering Control Module	✓	✓	✓	✓	#	0089 0090 0091
2012	Zafira-C		Steering Wheel Angle Sensor Module	✓	✓	✓	✓	✓	0083 0084
2012	Zafira-C		Suspension Control Module	✓	✓	✓	✓	✓	
2012	Zafira-C		Chime Alarm Control Module	✓	✓	✓	✓	✓	
2012	Zafira-C		Headlamp Control Module	✓	✓	✓	✓	✓	0252
2012	Zafira-C		Trailer Interface Control Module	✓	✓	✓	✓	✓	0041
2012	Zafira-C		Radio	✓	✓	✓	✓	✓	
2012	Zafira-C		Digital Radio Receiver Control Module	✓	✓	✓	✓	✓	0041
2012	Zafira-C		Multimedia Player Interface Module	✓	✓	✓	✓	✓	
2012	Zafira-C		Mobile Telephone Control Module	✓	✓	✓	✓	✓	0041
2012	Zafira-C		Remote Heater and Air Conditioning Control Module	✓	✓	✓	✓	✓	0211 0041
2012	Zafira-C		Front Seat Heating Control Module	✓	✓	✓	✓	✓	
2012	Zafira-C		Parking Assist Control Module	✓	✓	✓	✓	✓	0041
2012	Zafira-C		Vehicle Direction Camera Control Module	✓	✓	✓	✓	✓	0109 0288 0041
2011	Agila-B	Body	BCM (Body Control Module)	✓	✓	✓	✓	✓	
2011	Agila-B	Body	Immobiliser	✓	✓	✓	✓	✓	
2011	Agila-B	Body	SDM (Airbag)	✓	✓	✓	✓	✓	
2011	Agila-B	Chassis	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)	✓	✓	✓	✓	✓	0006
2011	Agila-B	Chassis	Electronic Power Steering	✓	✓	✓	✓	✓	
2011	Agila-B	Engine	K10B	✓	✓	✓	✓	✓	0016
2011	Agila-B	Engine	K12B	✓	✓	✓	✓	✓	0016
2011	Agila-B	Engine	D13A / Z 13 DTJ	✓	✓	✓	✓	✓	0041 0020 0012 0022 0021 0019 0029 0026 0042 0043
2011	Agila-B	Transmission	TCM (Transmission Control Module)	✓	✓	✓	✓	✓	0034
2011	Antara,Captive (Short Body)	Body	AHL(Automatic Headlamp Levelling)	✓	✓	✓	✓	✓	0142
2011	Antara,Captive (Short Body)	Body	BCM (Body Control Module)	✓	✓	✓	✓	✓	
2011	Antara,Captive (Short Body)	Body	ECC (Electronic Climate Control)	✓	✓	✓	✓	✓	0152 0005
2011	Antara,Captive (Short Body)	Body	Immobiliser	✓	✓	✓	✓	✓	
2011	Antara,Captive (Short Body)	Body	IPC ECU (Instrument Control Unit)	✓	✓	✓	✓	✓	
2011	Antara,Captive (Short Body)	Body	PAS (Park Pilot)	✓	✓	✓	✓	✓	0058
2011	Antara,Captive (Short Body)	Body	XBCM(Auxiliary Body Control Module)	✓	✓	✓	✓	✓	
2011	Antara,Captive (Short Body)	Body	RFA (Multipurpose Receiver Module)	✓	✓	✓	✓	✓	
2011	Antara,Captive (Short Body)	Chassis	ABS/TC/ESP (Vehicle Dynamic System)	✓	✓	✓	✓	✓	0005 0006 0004
2011	Antara,Captive (Short Body)	Chassis	Fuel Pump Control Module	✓	✓	✓	✓	✓	
2011	Antara,Captive (Short Body)	Engine	2.0 L(Diesel)	✓	✓	✓	✓	✓	0011 0012 0067 0021 0025 0013 0029 0026 0028 0030 0153
2011	Antara,Captive (Short Body)	Transmission	TCCM(Transfer Case Control Module)	✓	✓	✓	✓	✓	0154
2011	Antara,Captive (Short Body)	Transmission	Automatic Transmission	✓	✓	✓	✓	✓	0155 0156 0157 0158 0159
2011	Astra-G	Body	Instrument	✓	✓	✓	✓	✓	
2011	Astra-G	Chassis	Electronic Power Steering	✓	✓	✓	✓	✓	
2011	Astra-G	Engine	Z 12 XE	✓	✓	✓	✓	✓	0007 0146 0010 0041 0020 0022 0012 0066 0034
2011	Astra-G	Transmission	AF 13-II/17/20/22	✓	✓	✓	✓	✓	
2011	Astra-H	Body	AHL/AFL (Headlamp Levelling)	✓	✓	✓	✓	✓	
2011	Astra-H	Body	Exterior Lighting/Turn Indicator System	✓	✓	✓	✓	✓	
2011	Astra-H	Body	Interior Lighting	✓	✓	✓	✓	✓	
2011	Astra-H	Body	Wipers/Washer	✓	✓	✓	✓	✓	
2011	Astra-H	Body	Central Door Lock	✓	✓	✓	✓	✓	
2011	Astra-H	Body	Instrument	✓	✓	✓	✓	✓	0056 0057 0058
2011	Astra-H	Body	Immobiliser	✓	✓	✓	✓	✓	
2011	Astra-H	Body	CIM (Steering Column Module)	✓	✓	✓	✓	✓	0052 0004 0053 0002 0005 0054 0055 0006
2011	Astra-H	Body	Anti Theft Warning System	✓	✓	✓	✓	✓	
2011	Astra-H	Body	Electrohydraulic HardTop	✓	✓	✓	✓	✓	0002 0005
2011	Astra-H	Body	ECC/SAC (Electronic Climate Control)	✓	✓	✓	✓	✓	0151 0160 0161 0033 0002 0005 0162
2011	Astra-H	Body	IPC ECU (Instrument Control Unit)	✓	✓	✓	✓	✓	0007 0056 0057 0058 0059 0060 0061 0002 0005
2011	Astra-H	Body	EHS (Electrical Heater System)	✓	✓	✓	✓	✓	0033 0002 0005
2011	Astra-H	Body	PAS (Park Pilot)	✓	✓	✓	✓	✓	0002

2011	Astra-H	Body	SDM (Airbag)	✓	✓	✓	✓	0000 0001 0002 0003
2011	Astra-H	Body	SLM (Shift Lever Module)	✓	✓	✓	✓	
2011	Astra-H	Body	UEC (Underhood Electrical Centre)	✓	✓	✓	✓	
2011	Astra-H	Body	REC (Rear Electrical Centre)	✓	✓	✓	✓	
2011	Astra-H	Body	PEPS (Open&Start)	✓	✓	✓	✓	
2011	Astra-H	Chassis	TPMS ECT(Tyre Pressure Monitoring)	✓	✓	✓	✓	
2011	Astra-H	Chassis	TPMS (Tyre Pressure Monitoring System)	✓	✓	✓	✓	
2011	Astra-H	Chassis	EHPS (Electrohydraulic Power Steering)	✓	✓	✓	✓	0004
2011	Astra-H	Chassis	ABS/TC/ESP ECU(Electronic Control Unit)	✓	✓	✓	✓	0004 0005 0063
2011	Astra-H	Chassis	CDC (Continuous Damping Control)	✓	✓	✓	✓	
2011	Astra-H	Chassis	ABS/TC/ESP (Vehicle Dynamic System)	✓	✓	✓	✓	
2011	Astra-H	Chassis	TPMS ECU(Tyre Pressure Monitoring)	✓	✓	✓	✓	0002
2011	Astra-H	Engine	A16XER	✓	✓	✓	✓	0020 0010 0064 0068 0065 0034 0013 0007 0008 0009 0019
2011	Astra-H	Engine	A16LET	✓	✓	✓	✓	0010 0064 0012 0065 0013 0066 0007 0008 0009 0019
2011	Astra-H	Engine	A17DTJ	✓	✓	✓	✓	0020 0064 0012 0065 0015 0023 0024 0025 0013 0029 0026 0070 0027 0071 0007 0008 0009 0028 0019
2011	Astra-H	Engine	A17DTR	✓	✓	✓	✓	0020 0064 0012 0065 0015 0023 0024 0025 0013 0029 0026 0070 0027 0071 0007 0008 0009 0028 0019
2011	Astra-H	Engine	Y13DTH	✓	✓	✓	✓	0010 0064 0012 0065 0013 0066 0007 0008 0009 0019
2011	Astra-H	Engine	Z12XEP	✓	✓	✓	✓	0010 0064 0012 0065 0013 0066 0007 0008 0009 0019
2011	Astra-H	Engine	Z13DTH	✓	✓	✓	✓	0007 0008 0009 0020 0011 0012 0067 0021 0030 0029 0026 0027 0019
2011	Astra-H	Engine	Z14XEP	✓	✓	✓	✓	0007 0008 0009 0010 0011 0012 0067 0013 0014 0019
2011	Astra-H	Engine	Z14XEL	✓	✓	✓	✓	0007 0008 0009 0010 0011 0012 0067 0013 0014 0019
2011	Astra-H	Engine	Z16LET	✓	✓	✓	✓	0010 0064 0012 0065 0013 0066 0007 0008 0009 0019
2011	Astra-H	Engine	Z16XE1	✓	✓	✓	✓	0020 0010 0064 0068 0065 0013 0066 0069 0007 0008 0009 0019
2011	Astra-H	Engine	Z16XEP	✓	✓	✓	✓	0007 0008 0009 0010 0020 0011 0012 0067 0013 0014 0034 0019
2011	Astra-H	Engine	Z17DTH	✓	✓	✓	✓	0007 0008 0009 0011 0012 0067 0021 0025 0013 0030 0033 0019
2011	Astra-H	Engine	Z17DTL	✓	✓	✓	✓	0064 0012 0065 0021 0025 0013 0030 0033 0019
2011	Astra-H	Engine	Z18XE	✓	✓	✓	✓	0020 0007 0008 0009 0010 0011 0012 0067 0013 0019
2011	Astra-H	Engine	Z18XER	✓	✓	✓	✓	0007 0008 0009 0010 0020 0011 0012 0067 0034 0013 0019
2011	Astra-H	Engine	Z19DT	✓	✓	✓	✓	0007 0008 0009 0011 0012 0067 0024 0025 0070 0013 0033 0021 0030 0027 0028 0026 0029 0019
2011	Astra-H	Engine	Z19DTH	✓	✓	✓	✓	0007 0008 0009 0011 0012 0067 0024 0025 0070 0013 0033 0021 0030 0027 0028 0026 0029 0019
2011	Astra-H	Engine	Z20LEH	✓	✓	✓	✓	0010 0064 0012 0065 0013 0066 0007 0008 0009 0019
2011	Astra-H	Engine	Z20LEL	✓	✓	✓	✓	0010 0064 0012 0065 0013 0066 0007 0008 0009 0019
2011	Astra-H	Engine	Z20LER	✓	✓	✓	✓	0010 0064 0012 0065 0013 0066 0007 0008 0009 0019
2011	Astra-H	Engine	Z22YH	✓	✓	✓	✓	0007 0008 0009 0072 0020 0011 0012 0067 0013 0019
2011	Astra-H	Engine	Engine(default)	✓	✓	✓		0007 0008 0009 0010 0020 0011 0012 0067 0034 0013 0019
2011	Astra-H	Engine	Z 16 XER	✓	✓	✓	✓	0007 0008 0009 0020 0011 0012 0067 0015 0023 0024 0025 0013 0026 0027 0028 0029 0030 0021 0019
2011	Astra-H	Engine	Z 17 DTJ	✓	✓	✓	✓	0007 0008 0009 0020 0011 0012 0067 0015 0023 0024 0025 0013 0026 0027 0028 0029 0030 0021 0019
2011	Astra-H	Engine	Z 17 DTR	✓	✓	✓	✓	0007 0008 0009 0020 0011 0012 0067 0015 0023 0024 0025 0013 0026 0027 0028 0029 0030 0021 0019
2011	Astra-H	Engine	A 18 XER	✓	✓	✓	✓	0007 0008 0009 0010 0020 0011 0012 0067 0034 0019
2011	Astra-H	Transmission	AF 40-6	✓	✓	✓	✓	0073 0074 0075 0076 0077 0078 0033 0004 0034 0079
2011	Astra-H	Transmission	AF 17-4	✓	✓	✓	✓	0033 0080 0034 0031 0032
2011	Astra-H	Transmission	AF 22-4	✓	✓	✓	✓	0033 0080 0034 0031
2011	Astra-H	Transmission	MTA(Easytronic)	✓	✓	✓	✓	0080 0035 0036 0062
2011	Astra-H	Transmission	MTA(Easytronic Magneti Marelli)	✓	✓	✓	✓	0080 0005 0062
2011	Astra-J		Engine Control Module	✓	✓	✓	✓	0097 0085 0240 0099 0259 0131 0086 0103 0100 0105 0130 0020 0107 0207 0050 0101 0239 0132 0237 0098 0104 0102 0106 0049 0093 0122 0133 0134 0092 0018 0019 0017 0096 0094
2011	Astra-J		Transmission Control Module	✓	✓	✓	✓	0260 0123 0248
2011	Astra-J		Body Control Module	✓	✓	✓	✓	0048 0049 0046 0223 0208 0224 0047
2011	Astra-J		Electronic Brake Control Module	✓	✓	✓	✓	0261 0084 0087
2011	Astra-J		Inflatable Restraint Sensing and Diagnostic Module	✓	✓	✓	✓	0250
2011	Astra-J		Instrument Cluster	✓	✓	✓	✓	0041
2011	Astra-J		Fuel Injector Control Module	✓	✓	✓	✓	
2011	Astra-J		Fuel Pump Control Module	✓	✓	✓	✓	0017
2011	Astra-J		Parking Brake Control Module	✓	✓	✓	✓	0110
2011	Astra-J		Multi-Axis Acceleration Sensor Module	✓	✓	✓	✓	0262 0087
2011	Astra-J		Power Steering Control Module	✓	✓	✓	✓	0089 0090 0091
2011	Astra-J		Steering Wheel Angle Sensor Module	✓	✓	✓	✓	0083 0084

2011	Astra-J		Suspension Control Module	✓	✓	✓	✓	✓	
2011	Astra-J		Chime Alarm Control Module	✓	✓	✓	✓	✓	
2011	Astra-J		Headlamp Control Module	✓	✓	✓	✓	✓	0252
2011	Astra-J		Trailer Interface Control Module	✓	✓	✓	✓	✓	0041
2011	Astra-J		Radio	✓	✓	✓	✓	✓	
2011	Astra-J		Digital Radio Receiver Control Module	✓	✓	✓	✓	✓	0041
2011	Astra-J		Multimedia Player Interface Module	✓	✓	✓	✓	✓	
2011	Astra-J		Mobile Telephone Control Module	✓	✓	✓	✓	✓	0041
2011	Astra-J		Remote Heater and Air Conditioning Control Module	✓	✓	✓	✓	✓	0211 0041
2011	Astra-J		Front Seat Heating Control Module	✓	✓	✓	✓	✓	
2011	Astra-J		Parking Assist Control Module	✓	✓	✓	✓	✓	
2011	Astra-J		Vehicle Direction Camera Control Module	✓	✓	✓	✓	✓	0109 0288 0041
2011	Insignia		Engine Control Module	✓	✓	✓	✓	✓	0097 0085 0129 0086 0103 0098 0104 0102 0130 0020 0017 0094 0099 0101 0239 0132 0100 0237 0105 0106 0107 0207 0050 0019 0049 0092 0018 0096 0093
2011	Insignia		Transmission Control Module	✓	✓	✓	✓	✓	0260 0123
2011	Insignia		Body Control Module	✓	✓	✓	✓	✓	0048 0049 0046 0223 0208 0224 0047
2011	Insignia		Electronic Brake Control Module	✓	✓	✓	✓	✓	0261 0084 0087
2011	Insignia		Inflatable Restraint Sensing and Diagnostic Module	✓	✓	✓	✓	✓	0250
2011	Insignia		Instrument Cluster	✓	✓	✓	✓	✓	0041
2011	Insignia		Fuel Injector Control Module	✓	✓	✓	✓	✓	
2011	Insignia		Fuel Pump Control Module	✓	✓	✓	✓	✓	0017
2011	Insignia		Rear Differential Clutch Control Module	✓	✓	✓	✓	✓	
2011	Insignia		Parking Brake Control Module	✓	✓	✓	✓	✓	0110
2011	Insignia		Multi-Axis Acceleration Sensor Module	✓	✓	✓	✓	✓	0262 0087
2011	Insignia		Power Steering Control Module	✓	✓	✓	✓	#	0089 0090 0091
2011	Insignia		Steering Wheel Angle Sensor Module	✓	✓	✓	✓	✓	0083 0084
2011	Insignia		Suspension Control Module	✓	✓	✓	✓	✓	
2011	Insignia		Chime Alarm Control Module	✓	✓	✓	✓	✓	
2011	Insignia		Headlamp Control Module	✓	✓	✓	✓	✓	0252
2011	Insignia		Trailer Interface Control Module	✓	✓	✓	✓	✓	0041
2011	Insignia		Radio	✓	✓	✓	✓	✓	
2011	Insignia		Digital Radio Receiver Control Module	✓	✓	✓	✓	✓	0041
2011	Insignia		Multimedia Player Interface Module	✓	✓	✓	✓	✓	0041
2011	Insignia		Mobile Telephone Control Module	✓	✓	✓	✓	✓	0041
2011	Insignia		Remote Heater and Air Conditioning Control Module	✓	✓	✓	✓	✓	0211 0041
2011	Insignia		Liftgate Control Module	✓	✓	✓	✓	✓	0280
2011	Insignia		Seat Memory Control Module	✓	✓	✓	✓	✓	0289
2011	Insignia		Front Seat Heating Control Module	✓	✓	✓	✓	✓	
2011	Insignia		Parking Assist Control Module	✓	✓	✓	✓	✓	
2011	Insignia		Vehicle Direction Camera Control Module	✓	✓	✓	✓	✓	0109 0288 0041
2011	Insignia		Distance Sensing Cruise Control Module	✓	✓	✓	✓	✓	0263
2011	Meriva-B	Body	Front Seat Heating Control Module	✓	✓	✓	✓	✓	
2011	Meriva-B	Body	BCM (Body Control Module)	✓	✓	✓	✓	✓	
2011	Meriva-B	Body	Headlamp Control Module	✓	✓	✓	✓	✓	
2011	Meriva-B	Body	Inflatable Restraint Sensing&Diag.Module	✓	✓	✓	✓	✓	
2011	Meriva-B	Body	Parking Assist Control Module	✓	✓	✓	✓	✓	0108 0040
2011	Meriva-B	Body	Remote Heater & A/C Control Module	✓	✓	✓	✓	✓	
2011	Meriva-B	Body	Instrument	✓	✓	✓	✓	✓	0040
2011	Meriva-B	Body	Trailer Interface Control Module	✓	✓	✓	✓	✓	
2011	Meriva-B	Chassis	Electronic Brake Control Module	✓	✓	✓	✓	✓	
2011	Meriva-B	Chassis	Electric Power Steering Control Module	✓	✓	✓	✓	✓	
2011	Meriva-B	Chassis	Parking Brake Control Module	✓	✓	✓	✓	✓	0109 0110
2011	Meriva-B	Chassis	Steering Wheel Angle Sensor Module	✓	✓	✓	✓	✓	0082
2011	Meriva-B	Chassis	Fuel injector control module	✓	✓	✓	✓	✓	
2011	Meriva-B	Engine	A 13 DTC 1.3(LDV)	✓	✓	✓	✓	✓	0084 0111 0112 0024 0025 0029 0026 0070 0113 0114 0115 0116 0117 0118
2011	Meriva-B	Engine	A 13 DTE 1.3(LSF)	✓	✓	✓	✓	✓	0084 0119 0112 0024 0025 0029 0026 0070 0113 0114 0115 0116 0117 0120 0019
2011	Meriva-B	Engine	A 14 NET(LUH)	✓	✓	✓	✓	✓	0084 0163 0164 0016 0019 0084
2011	Meriva-B	Engine	A 14 NET (LUJ)	✓	✓	✓	✓	✓	0092 0084 0017 0018 0016 0019
2011	Meriva-B	Engine	A 14 XER (LDD)	✓	✓	✓	✓	✓	0092 0084 0017 0018 0016 0019
2011	Meriva-B	Engine	A 17 DTC 1.7(LUE)	✓	✓	✓	✓	✓	0121 0104 0084 0119 0085 0019 0165 0129
2011	Meriva-B	Engine	A 17 DTS 1.7(LUD)	✓	✓	✓	✓	✓	0121 0104 0084 0119 0085 0019 0164 0129
2011	Meriva-B	Engine	Engine Control Module	✓	✓	✓	✓	✓	0084 0119 0112 0024 0025 0029 0026 0070 0113 0114 0115 0116 0117 0120 0019
2011	Meriva-B	Transmission	Transmission Control Module	✓	✓	✓	✓	✓	0079 0122
2011	Astra-G	Body	Add On Heater	✓	✓	✓	✓	✓	0123 0124
2011	Astra-G	Body	Airbag	✓	✓	✓	✓	✓	
2011	Astra-G	Body	Anti Theft Warning	✓	✓	✓	✓	✓	
2011	Astra-G	Body	Central Door Lock	✓	✓	✓	✓	✓	
2011	Astra-G	Body	Engine Cooling Module	✓	✓	✓	✓	✓	
2011	Astra-G	Body	Electronic Climate Control	✓	✓	✓	✓	✓	
2011	Astra-G	Body	HeadLamp Levelling Device	✓	✓	✓	✓	✓	0142
2011	Astra-G	Body	Immobiliser	✓	✓	✓	✓	✓	0166 0167
2011	Astra-G	Body	Instrument	✓	✓	✓	✓	✓	
2011	Astra-G	Body	Softtop Controller	✓	✓	✓	✓	✓	
2011	Astra-G	Chassis	ABS-5.3/5.4 (+TC) (Anti-lock Braking System)	✓	✓	✓	✓	✓	
2011	Astra-G	Chassis	Electronic Power Steering	✓	✓	✓	✓	✓	
2011	Astra-G	Chassis	ESP (Electronic Stability Program)	✓	✓	✓	✓	✓	0006
2011	Astra-G	Engine	Z 14 XE	✓	✓	✓	✓	✓	0147 0146 0010 0020 0022 0012
2011	Astra-G	Engine	Z 14 XEP	✓	✓	✓	✓	✓	0007 0168 0010 0147 0020 0012 0022 0066 0034
2011	Astra-G	Engine	C 16 SEL	✓	✓	✓	✓	✓	
2011	Astra-G	Engine	Z 16 XE	✓	✓	✓	✓	✓	0007 0022 0012
2011	Astra-G	Engine	Z 16 SE	✓	✓	✓	✓	✓	0007 0022 0012
2011	Astra-G	Engine	Z 16 XEP	✓	✓	✓	✓	✓	0007 0147 0010 0020 0012 0022 0066

2011	Astra-G	Engine	Z 16 YNG	✓	✓	✓	✓	✓	0007 0147 0146 0010 0020 0012 0022
2011	Astra-G	Engine	Y 17 DT	✓	✓	✓	✓	✓	
2011	Astra-G	Engine	Z 17 DTL	✓	✓	✓	✓	✓	
2011	Astra-G	Engine	Z 18 XE	✓	✓	✓	✓	✓	0146 0010 0041 0020 0012 0022
2011	Astra-G	Engine	Z 18 XEL	✓	✓	✓	✓	✓	0012 0022
2011	Astra-G	Engine	Y 20 DTH	✓	✓	✓	✓	✓	0167 0169 0170 0171
2011	Astra-G	Engine	Z 20 LET	✓	✓	✓	✓	✓	0010 0020 0041 0146 0012 0022 0066 0034
2011	Astra-G	Engine	Y 22 DTR	✓	✓	✓	✓	✓	0012 0022
2011	Astra-G	Engine	Z 22 SE	✓	✓	✓	✓	✓	0147 0010 0146 0012 0022 0066 0034
2011	Astra-G	Transmission	AF 13-II/17/20/22 CAN	✓	✓	✓	✓	✓	
2011	Captiva(Long Body)	Body	BCM (Body Control Module)	✓	✓	✓	✓	✓	
2011	Captiva(Long Body)	Body	ECC (Electronic Climate Control)	✓	✓	✓	✓	✓	0151 0005
2011	Captiva(Long Body)	Body	Immobiliser	✓	✓	✓	✓	✓	
2011	Captiva(Long Body)	Body	IPC ECU (Instrument Control Unit)	✓	✓	✓	✓	✓	
2011	Captiva(Long Body)	Body	XBCM(Auxiliary Body Control Module)	✓	✓	✓	✓	✓	
2011	Captiva(Long Body)	Body	RFA (Multipurpose Receiver Module)	✓	✓	✓	✓	✓	
2011	Captiva(Long Body)	Chassis	ABS/TC/ESP (Vehicle Dynamic System)	✓	✓	✓	✓	✓	0005 0006 0004
2011	Captiva(Long Body)	Engine	2.0 L (Diesel)	✓	✓	✓	✓	✓	0011 0012 0067 0021 0025 0013 0029 0026 0028 0030 0152
2011	Captiva(Long Body)	Engine	Z32SE	✓	✓	✓	✓	✓	
2011	Captiva(Long Body)	Transmission	TCCM(Transfer Case Control Module)	✓	✓	✓	✓	✓	
2011	Captiva(Long Body)	Transmission	Automatic Transmission	✓	✓	✓	✓	✓	0172 0155 0156 0157 0034
2011	Corsa-C	Body	Add On Heater	✓	✓	✓	✓	✓	0123 0124
2011	Corsa-C	Body	Airbag	✓	✓	✓	✓	✓	
2011	Corsa-C	Body	Body Control Module	✓	✓	✓	✓	✓	0052 0059 0139
2011	Corsa-C	Body	Instrument	✓	✓	✓	✓	✓	
2011	Corsa-C	Body	Immobiliser	✓	✓	✓	✓	✓	0165 0166
2011	Corsa-C	Chassis	ABS/ESP8 (Anti-lock Braking System/Electronic Stability Program)	✓	✓	✓	✓	✓	0006 0143 0144 0145 0005
2011	Corsa-C	Chassis	ABS-5.3/5.4 (+TC) (Anti-lock Braking System)	✓	✓	✓	✓	✓	
2011	Corsa-C	Chassis	Electronic Power Steering	✓	✓	✓	✓	✓	0142
2011	Corsa-C	Engine	Z 10 XEP	✓	✓	✓	✓	✓	0012 0022 0066 0034
2011	Corsa-C	Engine	Z 12 XE	✓	✓	✓	✓	✓	0007 0146 0010 0041 0020 0022 0012 0066 0034
2011	Corsa-C	Engine	Z 12 XEP	✓	✓	✓	✓	✓	0012 0022 0066 0034
2011	Corsa-C	Engine	Y 13 DT	✓	✓	✓	✓	✓	0041 0020 0022 0012 0021
2011	Corsa-C	Engine	Z 13 DT	✓	✓	✓	✓	✓	0041 0020 0022 0012 0021
2011	Corsa-C	Engine	Z 13 DTJ	✓	✓	✓	✓	✓	0041 0020 0029 0026 0042 0022 0012 0021 0043
2011	Corsa-C	Engine	Z 14 XE	✓	✓	✓	✓	✓	0147 0146 0010 0020 0022 0012
2011	Corsa-C	Engine	Z 14 XEP	✓	✓	✓	✓	✓	0007 0167 0010 0147 0020 0012 0022 0066 0034
2011	Corsa-C	Engine	Z 16 SE	✓	✓	✓	✓	✓	0007 0022 0012
2011	Corsa-C	Engine	Z 16 YNG	✓	✓	✓	✓	✓	0007 0147 0146 0010 0020 0012 0022
2011	Corsa-C	Engine	Y 17 DT	✓	✓	✓	✓	✓	
2011	Corsa-C	Engine	Y 17 DTL	✓	✓	✓	✓	✓	0007 0022 0012
2011	Corsa-C	Engine	Z 17 DTH	✓	✓	✓	✓	✓	
2011	Corsa-C	Engine	Z 18 XE	✓	✓	✓	✓	✓	0146 0010 0041 0020 0012 0022
2011	Corsa-C	Transmission	AF 13-II/17/20/22 CAN	✓	✓	✓	✓	✓	
2011	Corsa-C	Transmission	Easytronic(MTA)	✓	✓	✓	✓	✓	0012 0149
2011	Corsa-D	Body	Exterior Lighting	✓	✓	✓	✓	✓	
2011	Corsa-D	Body	Interior Lighting	✓	✓	✓	✓	✓	
2011	Corsa-D	Body	Wipers/Washer	✓	✓	✓	✓	✓	
2011	Corsa-D	Body	Heating,Ventilation and Air Cond.	✓	✓	✓	✓	✓	
2011	Corsa-D	Body	Anti Theft Warning System	✓	✓	✓	✓	✓	
2011	Corsa-D	Body	Central Door Lock	✓	✓	✓	✓	✓	
2011	Corsa-D	Body	Immobiliser	✓	✓	✓	✓	✓	
2011	Corsa-D	Body	AFL (Adaptive Forward Lighting)	✓	✓	✓	✓	✓	
2011	Corsa-D	Body	EHS (Electrical Heater System)	✓	✓	✓	✓	✓	
2011	Corsa-D	Body	IPC ECU (Instrument Control Unit)	✓	✓	✓	✓	✓	
2011	Corsa-D	Body	PAS (Park Pilot)	✓	✓	✓	✓	✓	
2011	Corsa-D	Body	SDM (Airbag)	✓	✓	✓	✓	✓	0000 0001 0002 0003
2011	Corsa-D	Body	TIM(Trailer Interface Module)	✓	✓	✓	✓	✓	
2011	Corsa-D	Body	BCM (Body Control Module)	✓	✓	✓	✓	✓	
2011	Corsa-D	Chassis	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)	✓	✓	✓	✓	✓	
2011	Corsa-D	Chassis	Electronic Power Steering	✓	✓	✓	✓	✓	0004 0005 0006
2011	Corsa-D	Chassis	Fuel injector control module	✓	✓	✓	✓	✓	
2011	Corsa-D	Engine	Z10XEP	✓	✓	✓	✓	✓	0007 0008 0009 0010 0011 0012 0013 0014 0015
2011	Corsa-D	Engine	A10XEP	✓	✓	✓	✓	✓	0007 0016 0017 0018 0019
2011	Corsa-D	Engine	Z12XEP	✓	✓	✓	✓	✓	0007 0008 0009 0010 0011 0012 0013 0014 0015
2011	Corsa-D	Engine	A12XEP	✓	✓	✓	✓	✓	0007 0019
2011	Corsa-D	Engine	A12XEL	✓	✓	✓	✓	✓	0007 0019
2011	Corsa-D	Engine	Z13DTH	✓	✓	✓	✓	✓	0020 0011 0012 0015 0021
2011	Corsa-D	Engine	Z13DTE	✓	✓	✓	✓	✓	0007
2011	Corsa-D	Engine	Z13DTJ	✓	✓	✓	✓	✓	0020 0011 0012 0015 0021
2011	Corsa-D	Engine	A13DTC	✓	✓	✓	✓	✓	0020
2011	Corsa-D	Engine	Z14XEP	✓	✓	✓	✓	✓	0007 0008 0009 0010 0011 0012 0013 0014 0015
2011	Corsa-D	Engine	A14XEL	✓	✓	✓	✓	✓	0007 0016 0017 0018 0019
2011	Corsa-D	Engine	A14XER	✓	✓	✓	✓	✓	0007 0016 0017 0018 0019
2011	Corsa-D	Engine	Z16LEL	✓	✓	✓	✓	✓	
2011	Corsa-D	Engine	Z16LER	✓	✓	✓	✓	✓	
2011	Corsa-D	Engine	A16LEL	✓	✓	✓	✓	✓	
2011	Corsa-D	Engine	A16LER	✓	✓	✓	✓	✓	

2011	Corsa-D	Engine	Z17DTR	✓	✓	✓	✓	✓	0020 0022 0012 0015 0023 0024 0025 0013 0026 0027 0028 0029 0021 0030
2011	Corsa-D	Transmission	MTA(Easytronic Magneti Marelli)	✓	✓	✓	✓	✓	
2011	Corsa-D	Transmission	AF 13-4	✓	✓	✓	✓	✓	0031 0032 0033 0034
2011	Corsa-D	Transmission	MTA(Easytronic)	✓	✓	✓	✓	✓	0035 0036
2011	Vauxhall VXRS	Body	AHL(Automatic Headlamp Levelling)	✓	✓	✓	✓	✓	
2011	Vauxhall VXRS	Body	BCM (Body Control Module)	✓	✓	✓	✓	✓	
2011	Vauxhall VXRS	Body	HVAC(Heating Ventilation and Cooling)	✓	✓	✓	✓	✓	
2011	Vauxhall VXRS	Body	Immobiliser	✓	✓	✓	✓	✓	
2011	Vauxhall VXRS	Body	MSM(Memory Seat and Mirrors)	✓	✓	✓	✓	✓	
2011	Vauxhall VXRS	Body	Park Assist	✓	✓	✓	✓	✓	
2011	Vauxhall VXRS	Body	SDM(Sensing and Diagnostic Module)	✓	✓	✓	✓	✓	
2011	Vauxhall VXRS	Body	IPC (Instrument Panel Cluster)	✓	✓	✓	✓	✓	
2011	Vauxhall VXRS	Body	RFA (Multipurpose Receiver Module)	✓	✓	✓	✓	✓	
2011	Vauxhall VXRS	Chassis	Fuel Pump Control Module	✓	✓	✓	✓	✓	
2011	Vauxhall VXRS	Chassis	EBCM(Electronic Brake Control Module)	✓	✓	✓	✓	✓	
2011	Vauxhall VXRS	Chassis	ESC(Electronic Suspension Control)	✓	✓	✓	✓	✓	
2011	Vauxhall VXRS	Engine	V8 GEN IV	✓	✓	✓	✓	✓	0016 0150 0173 0174
2011	Vauxhall VXRS	Transmission	Automatic Transmission	✓	✓	✓	✓	✓	
2011	Vivaro	Body	Park Pilot	✓	✓	✓	✓	✓	
2011	Vivaro	Body	Add On Heater	✓	✓	✓	✓	✓	0123 0124
2011	Vivaro	Body	Airbag	✓	✓	✓	✓	✓	0005
2011	Vivaro	Body	Body Control Module	✓	✓	✓	✓	✓	
2011	Vivaro	Engine	F9Q 760/762 (1.9L)	✓	✓	✓	✓	✓	
2011	Vivaro	Transmission	MTA(Tecshift)	✓	✓	✓	✓	✓	
2011	Zafira-B	Body	AHL/AFL (Headlamp Levelling)	✓	✓	✓	✓	✓	
2011	Zafira-B	Body	Exterior Lighting/Turn Indicator System	✓	✓	✓	✓	✓	
2011	Zafira-B	Body	Interior Lighting	✓	✓	✓	✓	✓	
2011	Zafira-B	Body	Wipers/Washer	✓	✓	✓	✓	✓	
2011	Zafira-B	Body	Central Door Lock	✓	✓	✓	✓	✓	
2011	Zafira-B	Body	Instrument	✓	✓	✓	✓	✓	0056 0057 0058
2011	Zafira-B	Body	Immobiliser	✓	✓	✓	✓	✓	
2011	Zafira-B	Body	CIM (Steering Column Module)	✓	✓	✓	✓	✓	0052 0004 0053 0002 0005 0054 0055 0006
2011	Zafira-B	Body	ECC/SAC (Electronic Climate Control)	✓	✓	✓	✓	✓	0151 0159 0160 0002 0005 0161
2011	Zafira-B	Body	EHS (Electrical Heater System)	✓	✓	✓	✓	✓	0033 0002 0005
2011	Zafira-B	Body	PAS (Park Pilot)	✓	✓	✓	✓	✓	0002
2011	Zafira-B	Body	SDM (Airbag)	✓	✓	✓	✓	✓	0000 0001 0002 0003
2011	Zafira-B	Body	SLM (Shift Lever Module)	✓	✓	✓	✓	✓	
2011	Zafira-B	Body	UEC (Underhood Electrical Centre)	✓	✓	✓	✓	✓	
2011	Zafira-B	Body	REC (Rear Electrical Centre)	✓	✓	✓	✓	✓	
2011	Zafira-B	Body	PEPS (Open&Start)	✓	✓	✓	✓	✓	
2011	Zafira-B	Body	IPC ECU (Instrument Control Unit)	✓	✓	✓	✓	✓	0007 0056 0057 0058 0059 0060 0061 0002 0005
2011	Zafira-B	Body	Anti Theft Warning System	✓	✓	✓	✓	✓	
2011	Zafira-B	Chassis	ABS/TC/ESP (Vehicle Dynamic System)	✓	✓	✓	✓	✓	0006
2011	Zafira-B	Chassis	TPMS ECU (Tyre Pressure Monitoring)	✓	✓	✓	✓	✓	0002
2011	Zafira-B	Chassis	TPMS (Tyre Pressure Monitoring System)	✓	✓	✓	✓	✓	
2011	Zafira-B	Chassis	EHPS (Electrohydraulic Power Steering)	✓	✓	✓	✓	✓	0004
2011	Zafira-B	Chassis	ABS/TC/ESP ECU(Electronic Control Unit)	✓	✓	✓	✓	✓	0004 0005 0063
2011	Zafira-B	Chassis	CDC (Continuous Damping Control)	✓	✓	✓	✓	✓	
2011	Zafira-B	Engine	Z 16 XE1	✓	✓	✓	✓	✓	0007 0008 0009 0010 0175 0011 0012 0067 0013 0014 0034 0019
2011	Zafira-B	Engine	Z 16 XEP	✓	✓	✓	✓	✓	0007 0008 0009 0010 0020 0011 0012 0067 0013 0014 0034 0019
2011	Zafira-B	Engine	Z 16 XER	✓	✓	✓	✓	✓	0007 0008 0009 0010 0020 0011 0012 0067 0034 0013 0019
2011	Zafira-B	Engine	Z 16 YNG	✓	✓	✓	✓	✓	0007 0008 0009 0010 0020 0011 0012 0067 0013 0014 0034 0019
2011	Zafira-B	Engine	A 16 XER	✓	✓	✓	✓	✓	0010 0020 0011 0012 0067 0034 0013 0019
2011	Zafira-B	Engine	Z 17 DTJ	✓	✓	✓	✓	✓	0020 0011 0012 0067 0015 0023 0024 0025 0013 0026 0027 0028 0029 0030 0021 0019
2011	Zafira-B	Engine	A 17 DTJ	✓	✓	✓	✓	✓	0007 0008 0009 0020 0011 0012 0067 0015 0023 0024 0025 0013 0029 0026 0070 0027 0071 0028 0019
2011	Zafira-B	Engine	A 17 DTR	✓	✓	✓	✓	✓	0007 0008 0009 0020 0011 0012 0067 0015 0023 0024 0025 0013 0029 0026 0070 0027 0071 0028 0019
2011	Zafira-B	Engine	Z 18 XER	✓	✓	✓	✓	✓	0007 0008 0009 0010 0020 0011 0012 0067 0034 0013 0019
2011	Zafira-B	Engine	A 18 XER	✓	✓	✓	✓	✓	0007 0008 0009 0010 0020 0011 0012 0067 0034 0019
2011	Zafira-B	Engine	Z 19 DT	✓	✓	✓	✓	✓	0007 0008 0009 0011 0012 0067 0024 0025 0070 0013 0033 0021 0030 0027 0028 0026 0029 0019
2011	Zafira-B	Engine	Z 19 DTH	✓	✓	✓	✓	✓	0007 0008 0009 0033 0011 0012 0067 0024 0025 0029 0026 0027 0028
2011	Zafira-B	Engine	Z 20 LEH	✓	✓	✓	✓	✓	0007 0008 0009 0010 0011 0012 0067 0013 0014 0019
2011	Zafira-B	Engine	Z 20 LER	✓	✓	✓	✓	✓	0007 0008 0009 0010 0011 0012 0067 0013 0014 0019
2011	Zafira-B	Engine	Z 22 YH	✓	✓	✓	✓	✓	0007 0008 0009 0072 0020 0011 0012 0067 0013 0014 0019
2011	Zafira-B	Engine	Engine(default)	✓	✓	✓	✓	✓	
2011	Zafira-B	Transmission	AF 40-6	✓	✓	✓	✓	✓	0073 0074 0075 0076 0077 0078 0033 0004 0034 0079
2011	Zafira-B	Transmission	MTA(Easytronic)	✓	✓	✓	✓	✓	0004 0062 0035 0036
2011	Zafira-B	Transmission	AF 22-4	✓	✓	✓	✓	✓	0031 0033 0004 0034
2010	Agila-B	Engine	K10B	✓	✓	✓	✓	✓	0016
2010	Agila-B	Engine	K12B	✓	✓	✓	✓	✓	0016
2010	Agila-B	Engine	D13A / Z 13 DTJ	✓	✓	✓	✓	✓	0041 0020 0012 0022 0021 0019 0029 0026 0042 0043

2010	Agila-B	Transmission	TCM (Transmission Control Module)	✓	✓	✓	✓	✓	0034
2010	Antara, Captive (Short Body)	Body	AHL (Automatic Headlamp Levelling)	✓	✓	✓	✓	✓	0142
2010	Antara, Captive (Short Body)	Body	Anti Theft Warning System	✓	✓	✓	✓	✓	
2010	Antara, Captive (Short Body)	Body	BCM (Body Control Module)	✓	✓	✓	✓	✓	
2010	Antara, Captive (Short Body)	Body	ECC (Electronic Climate Control)	✓	✓	✓	✓	✓	0151 0005
2010	Antara, Captive (Short Body)	Body	Immobiliser	✓	✓	✓	✓	✓	
2010	Antara, Captive (Short Body)	Body	IPC ECU (Instrument Control Unit)	✓	✓	✓	✓	✓	
2010	Antara, Captive (Short Body)	Body	Wipers/Washer	✓	✓	✓	✓	✓	
2010	Antara, Captive (Short Body)	Body	PAS (Park Pilot)	✓	✓	✓	✓	✓	0058
2010	Antara, Captive (Short Body)	Body	XBCM (Auxiliary Body Control Module)	✓	✓	✓	✓	✓	
2010	Antara, Captive (Short Body)	Body	Central Door Lock	✓	✓	✓	✓	✓	
2010	Antara, Captive (Short Body)	Body	RFA (Multipurpose Receiver Module)	✓	✓	✓	✓	✓	
2010	Antara, Captive (Short Body)	Body	SLM (Shift Lever Module)	✓	✓	✓	✓	✓	
2010	Antara, Captive (Short Body)	Body	HVAC (Heating Ventilation and Cooling)	✓	✓	✓	✓	✓	
2010	Antara, Captive (Short Body)	Body	Interior Lighting	✓	✓	✓	✓	✓	
2010	Antara, Captive (Short Body)	Body	Exterior Lighting/Turn Indicator System	✓	✓	✓	✓	✓	
2010	Antara, Captive (Short Body)	Body	SDM (Airbag)	✓	✓	✓	✓	✓	
2010	Antara, Captive (Short Body)	Chassis	ABS/TC/ESP (Vehicle Dynamic System)	✓	✓	✓	✓	✓	0005 0006 0004
2010	Antara, Captive (Short Body)	Engine	2.0 L (Diesel)	✓	✓	✓	✓	✓	0011 0012 0067 0021 0025 0013 0029 0026 0028 0030 0152
2010	Antara, Captive (Short Body)	Engine	Z 24 XE	✓	✓	✓	✓	✓	0011 0034 0016
2010	Antara, Captive (Short Body)	Engine	Z 32 SE	✓	✓	✓	✓	✓	0016 0019 0173
2010	Antara, Captive (Short Body)	Transmission	TCCM (Transfer Case Control Module)	✓	✓	✓	✓	✓	0153
2010	Antara, Captive (Short Body)	Transmission	Automatic Transmission	✓	✓	✓	✓	✓	0154 0155 0156 0157 0158
2010	Astra-H	Body	SDM (Airbag)	✓	✓	✓	✓	✓	
2010	Astra-H	Body	CIM (Steering Column Module)	✓	✓	✓	✓	✓	0052 0004 0053 0002 0005 0054 0055 0006
2010	Astra-H	Body	IPC ECU (Instrument Control Unit)	✓	✓	✓	✓	✓	
2010	Astra-H	Body	REC (Rear Electrical Centre)	✓	✓	✓	✓	✓	
2010	Astra-H	Body	HEC (Underhood Electrical Centre)	✓	✓	✓	✓	✓	
2010	Astra-H	Body	AHL/AFL (Headlamp Levelling)	✓	✓	✓	✓	✓	
2010	Astra-H	Body	Exterior Lighting/Turn Indicator System	✓	✓	✓	✓	✓	
2010	Astra-H	Body	Interior Lighting	✓	✓	✓	✓	✓	
2010	Astra-H	Body	Wipers/Washer	✓	✓	✓	✓	✓	
2010	Astra-H	Body	Central Door Lock	✓	✓	✓	✓	✓	
2010	Astra-H	Body	Instrument	✓	✓	✓	✓	✓	0056 0057 0058
2010	Astra-H	Body	Immobiliser	✓	✓	✓	✓	✓	
2010	Astra-H	Body	Anti Theft Warning System	✓	✓	✓	✓	✓	
2010	Astra-H	Body	Electrohydraulic HardTop	✓	✓	✓	✓	✓	0002 0005
2010	Astra-H	Body	ECC/SAC (Electronic Climate Control)	✓	✓	✓	✓	✓	0151 0159 0160 0033 0002 0005 0161
2010	Astra-H	Body	EHS (Electrical Heater System)	✓	✓	✓	✓	✓	0033 0002 0005
2010	Astra-H	Body	PAS (Park Pilot)	✓	✓	✓	✓	✓	0002
2010	Astra-H	Body	SLM (Shift Lever Module)	✓	✓	✓	✓	✓	
2010	Astra-H	Body	PEPS (Open&Start)	✓	✓	✓	✓	✓	
2010	Astra-H	Body	IPC ECU (Instrument Control Unit)	✓	✓	✓	✓	✓	0007 0056 0057 0058 0059 0060 0061 0002 0005
2010	Astra-H	Chassis	ABS/TC/ESP ECU (Electronic Control Unit)	✓	✓	✓	✓	✓	0004 0005 0063
2010	Astra-H	Chassis	EHPS (Electrohydraulic Power Steering)	✓	✓	✓	✓	✓	
2010	Astra-H	Chassis	TPMS ECU (Tyre Pressure Monitoring)	✓	✓	✓	✓	✓	0002
2010	Astra-H	Chassis	TPMS (Tyre Pressure Monitoring System)	✓	✓	✓	✓	✓	
2010	Astra-H	Chassis	CDC (Continuous Damping Control)	✓	✓	✓	✓	✓	
2010	Astra-H	Chassis	ABS/TC/ESP (Vehicle Dynamic System)	✓	✓	✓	✓	✓	
2010	Astra-H	Engine	A16LET	✓	✓	✓	✓	✓	0010 0064 0012 0065 0013 0066 0007 0008 0009 0019
2010	Astra-H	Engine	A17DTJ	✓	✓	✓	✓	✓	0020 0064 0012 0065 0015 0023 0024 0025 0013 0029 0026 0070 0027 0071 0007 0008 0009 0028 0019
2010	Astra-H	Engine	A17DTR	✓	✓	✓	✓	✓	0020 0064 0012 0065 0015 0023 0024 0025 0013 0029 0026 0070 0027 0071 0007 0008 0009 0028 0019
2010	Astra-H	Engine	Y13DTH	✓	✓	✓	✓	✓	0010 0064 0012 0065 0013 0066 0007 0008 0009 0019
2010	Astra-H	Engine	Z12XEP	✓	✓	✓	✓	✓	0010 0064 0012 0065 0013 0066 0007 0008 0009 0019
2010	Astra-H	Engine	Z13DTH	✓	✓	✓	✓	✓	0007 0008 0009 0020 0011 0012 0067 0021 0030 0029 0026 0027 0019
2010	Astra-H	Engine	Z14XEL	✓	✓	✓	✓	✓	0007 0008 0009 0010 0011 0012 0067 0013 0014 0019
2010	Astra-H	Engine	Z14XEP	✓	✓	✓	✓	✓	0007 0008 0009 0010 0011 0012 0067 0013 0014 0019
2010	Astra-H	Engine	Z16XE1	✓	✓	✓	✓	✓	0020 0010 0064 0068 0065 0013 0066 0069 0007 0008 0009 0019
2010	Astra-H	Engine	Z16XEP	✓	✓	✓	✓	✓	0007 0008 0009 0010 0020 0011 0012 0067 0013 0014 0034 0019
2010	Astra-H	Engine	Z16XER	✓	✓	✓	✓	✓	0020 0007 0008 0009 0010 0011 0012 0067 0034 0013 0019
2010	Astra-H	Engine	Z16LET	✓	✓	✓	✓	✓	0010 0064 0012 0065 0013 0066 0007 0008 0009 0019
2010	Astra-H	Engine	Z17DTH	✓	✓	✓	✓	✓	0007 0008 0009 0011 0012 0067 0021 0025 0013 0030 0033 0019

2010	Astra-H	Engine	Z17DTR	✓	✓	✓	✓	✓	0012
2010	Astra-H	Engine	Z17DTJ	✓	✓	✓	✓	✓	0065
2010	Astra-H	Engine	Z17DTL	✓	✓	✓	✓	✓	0064 0012 0065 0021 0025 0013 0030 0033 0019
2010	Astra-H	Engine	Z18XE	✓	✓	✓	✓	✓	0020 0007 0008 0009 0010 0011 0012 0067 0013 0019
2010	Astra-H	Engine	Z18XER	✓	✓	✓	✓	✓	0007
2010	Astra-H	Engine	Z19DT	✓	✓	✓	✓	✓	0007 0008 0009 0011 0012 0067 0024 0025 0070 0013 0033 0021 0030 0027 0028 0026 0029 0019
2010	Astra-H	Engine	Z19DTH	✓	✓	✓	✓	✓	0007 0008 0009 0011 0012 0067 0024 0025 0070 0013 0033 0021 0030 0027 0028 0026 0029 0019
2010	Astra-H	Engine	Z20LEH	✓	✓	✓	✓	✓	0010 0064 0012 0065 0013 0066 0007 0008 0009 0019
2010	Astra-H	Engine	Z20LEL	✓	✓	✓	✓	✓	0010 0064 0012 0065 0013 0066 0007 0008 0009 0019
2010	Astra-H	Engine	Z20LER	✓	✓	✓	✓	✓	0010 0064 0012 0065 0013 0066 0007 0008 0009 0019
2010	Astra-H	Engine	Z22YH	✓	✓	✓	✓	✓	0007 0008 0009 0072 0020 0011 0012 0067 0013 0019
2010	Astra-H	Engine	Engine(default)	✓	✓	✓			
2010	Astra-H	Transmission	AF 40-6	✓	✓	✓	✓	✓	0073 0074 0075 0076 0077 0078 0033 0004 0034 0079
2010	Astra-H	Transmission	AF 17-4	✓	✓	✓	✓	✓	0031 0032 0033 0004 0034
2010	Astra-H	Transmission	AF 22-4	✓	✓	✓	✓	✓	0033 0080 0034 0031
2010	Astra-H	Transmission	MTA(Easytronic)	✓	✓	✓	✓	✓	0080 0035 0036 0062
2010	Astra-H	Transmission	MTA(Easytronic Magneti Marelli)	✓	✓	✓	✓	✓	0080 0005 0062
2010	Astra-J		Engine Control Module	✓	✓	✓	✓	✓	0097 0085 0240 0099 0259 0131 0086 0103 0100 0105 0130 0020 0107 0207 0050 0101 0239 0132 0237 0098 0104 0102 0106 0049 0093 0122 0133 0134 0092 0018 0019 0017 0096 0094
2010	Astra-J		Transmission Control Module	✓	✓	✓	✓	✓	0260 0123 0248
2010	Astra-J		Body Control Module	✓	✓	✓	✓	✓	0048 0049 0046 0223 0208 0224 0047
2010	Astra-J		Electronic Brake Control Module	✓	✓	✓	✓	✓	0261 0084 0087
2010	Astra-J		Inflatable Restraint Sensing and Diagnostic Module	✓	✓	✓	✓	✓	0250
2010	Astra-J		Instrument Cluster	✓	✓	✓	✓	✓	0041
2010	Astra-J		Fuel Injector Control Module	✓		✓	✓	✓	
2010	Astra-J		Fuel Pump Control Module	✓	✓	✓	✓	✓	0017
2010	Astra-J		Parking Brake Control Module	✓	✓	✓	✓	✓	0110
2010	Astra-J		Multi-Axis Acceleration Sensor Module	✓	✓	✓			0262 0087
2010	Astra-J		Power Steering Control Module	✓	✓	✓	✓	✓	0089 0090 0091
2010	Astra-J		Steering Wheel Angle Sensor Module	✓	✓	✓			0083 0084
2010	Astra-J		Suspension Control Module	✓	✓	✓	✓	✓	
2010	Astra-J		Chime Alarm Control Module	✓	✓	✓	✓	✓	
2010	Astra-J		Headlamp Control Module	✓	✓	✓	✓	✓	0252
2010	Astra-J		Trailer Interface Control Module	✓	✓	✓	✓	✓	0041
2010	Astra-J		Radio	✓	✓	✓	✓	✓	
2010	Astra-J		Digital Radio Receiver Control Module	✓	✓	✓	✓	✓	0041
2010	Astra-J		Multimedia Player Interface Module	✓	✓	✓	✓	✓	
2010	Astra-J		Mobile Telephone Control Module	✓	✓	✓	✓	✓	0041
2010	Astra-J		Remote Heater and Air Conditioning Control Module	✓	✓	✓	✓	✓	0211 0041
2010	Astra-J		Front Seat Heating Control Module	✓	✓	✓	✓	✓	
2010	Astra-J		Parking Assist Control Module	✓	✓	✓	✓	✓	
2010	Astra-J		Vehicle Direction Camera Control Module	✓	✓	✓	✓	✓	0109 0288 0041
2010	Insignia		Engine Control Module	✓	✓	✓	✓	✓	0097 0085 0129 0086 0103 0098 0104 0102 0130 0020 0017 0094 0099 0101 0239 0132 0100 0237 0105 0106 0107 0207 0050 0019 0049 0092 0018 0096 0093
2010	Insignia		Transmission Control Module	✓	✓	✓	✓	✓	0260 0123
2010	Insignia		Body Control Module	✓	✓	✓	✓	✓	0048 0049 0046 0223 0208 0224 0047
2010	Insignia		Electronic Brake Control Module	✓	✓	✓	✓	✓	0261 0084 0087
2010	Insignia		Inflatable Restraint Sensing and Diagnostic Module	✓	✓	✓	✓	✓	0250
2010	Insignia		Instrument Cluster	✓	✓	✓	✓	✓	0041
2010	Insignia		Fuel Injector Control Module	✓		✓	✓	✓	
2010	Insignia		Fuel Pump Control Module	✓	✓	✓	✓	✓	0017
2010	Insignia		Rear Differential Clutch Control Module	✓	✓	✓	✓	✓	
2010	Insignia		Parking Brake Control Module	✓	✓	✓	✓	✓	0110
2010	Insignia		Multi-Axis Acceleration Sensor Module	✓	✓	✓			0262 0087
2010	Insignia		Power Steering Control Module	✓	✓	✓	✓	✓	0089 0090 0091
2010	Insignia		Steering Wheel Angle Sensor Module	✓	✓	✓			0083 0084
2010	Insignia		Suspension Control Module	✓	✓	✓	✓	✓	
2010	Insignia		Chime Alarm Control Module	✓	✓	✓	✓	✓	
2010	Insignia		Headlamp Control Module	✓	✓	✓	✓	✓	0252
2010	Insignia		Trailer Interface Control Module	✓	✓	✓	✓	✓	0041
2010	Insignia		Radio	✓	✓	✓	✓	✓	
2010	Insignia		Digital Radio Receiver Control Module	✓	✓	✓	✓	✓	0041
2010	Insignia		Multimedia Player Interface Module	✓	✓	✓	✓	✓	
2010	Insignia		Mobile Telephone Control Module	✓	✓	✓	✓	✓	0041
2010	Insignia		Remote Heater and Air Conditioning Control Module	✓	✓	✓	✓	✓	0211 0041
2010	Insignia		Liftgate Control Module	✓	✓	✓	✓	✓	0280
2010	Insignia		Seat Memory Control Module	✓	✓	✓	✓	✓	0289
2010	Insignia		Front Seat Heating Control Module	✓	✓	✓	✓	✓	
2010	Insignia		Parking Assist Control Module	✓	✓	✓	✓	✓	
2010	Insignia		Vehicle Direction Camera Control Module	✓	✓	✓	✓	✓	0109 0288 0041
2010	Insignia		Distance Sensing Cruise Control Module	✓	✓	✓	✓	✓	0263
2010	Meriva-B	Body	Front Seat Heating Control Module	✓	✓	✓	✓	✓	
2010	Meriva-B	Body	BCM (Body Control Module)	✓	✓	✓	✓	✓	
2010	Meriva-B	Body	Headlamp Control Module	✓	✓	✓	✓	✓	
2010	Meriva-B	Body	Inflatable Restraint Sensing&Diag.Module	✓	✓	✓	✓	✓	
2010	Meriva-B	Body	Parking Assist Control Module	✓	✓	✓	✓	✓	0108 0040
2010	Meriva-B	Body	Remote Heater & A/C Control Module	✓	✓	✓	✓	✓	

2010	Meriva-B	Body	Instrument	✓	✓	✓	✓	✓	0040
2010	Meriva-B	Body	Trailer Interface Control Module	✓	✓	✓	✓	✓	
2010	Meriva-B	Chassis	Electronic Brake Control Module	✓	✓	✓	✓	✓	
2010	Meriva-B	Chassis	Electric Power Steering Control Module	✓	✓	✓	✓	✓	
2010	Meriva-B	Chassis	Parking Brake Control Module	✓	✓	✓	✓	✓	0109 0110
2010	Meriva-B	Chassis	Steering Wheel Angle Sensor Module	✓	✓	✓	✓	✓	0082
2010	Meriva-B	Engine	A 13 DTC 1.3(LDV)	✓	✓	✓	✓	✓	0084 0111 0112 0024 0025 0029 0026 0070 0113 0114 0115 0116 0117 0118
2010	Meriva-B	Engine	A 13 DTE 1.3(LSF)	✓	✓	✓	✓	✓	0084 0119 0112 0024 0025 0029 0026 0070 0113 0114 0115 0116 0117 0120 0019
2010	Meriva-B	Engine	A 14 NET(LUH)	✓	✓	✓	✓	✓	0084 0162 0163 0016 0019 0084
2010	Meriva-B	Engine	A 14 NET (LUJ)	✓	✓	✓	✓	✓	0092 0084 0017 0018 0016 0019
2010	Meriva-B	Engine	A 14 XER (LDD)	✓	✓	✓	✓	✓	0092 0084 0017 0018 0016 0019
2010	Meriva-B	Engine	A 17 DTC 1.7(LUE)	✓	✓	✓	✓	✓	0121 0104 0084 0119 0085 0019 0164 0129
2010	Meriva-B	Engine	A 17 DTS 1.7(LUD)	✓	✓	✓	✓	✓	0121 0104 0084 0119 0085 0019 0164 0129
2010	Meriva-B	Engine	Engine Control Module	✓	✓	✓	✓	✓	0084 0119 0112 0024 0025 0029 0026 0070 0113 0114 0115 0116 0117 0120 0019
2010	Meriva-B	Transmission	Transmission Control Module	✓	✓	✓	✓	✓	0079 0122
2010	Astra-G	Body	Add On Heater	✓	✓	✓	✓	✓	0123 0124
2010	Astra-G	Body	Airbag	✓	✓	✓	✓	✓	
2010	Astra-G	Body	Anti Theft Warning	✓	✓	✓	✓	✓	
2010	Astra-G	Body	Central Door Lock	✓	✓	✓	✓	✓	
2010	Astra-G	Body	Engine Cooling Module	✓	✓	✓	✓	✓	
2010	Astra-G	Body	Electronic Climate Control	✓	✓	✓	✓	✓	
2010	Astra-G	Body	HeadLamp Levelling Device	✓	✓	✓	✓	✓	0142
2010	Astra-G	Body	Immobiliser	✓	✓	✓	✓	✓	0165 0166
2010	Astra-G	Body	Instrument	✓	✓	✓	✓	✓	
2010	Astra-G	Body	Softtop Controller	✓	✓	✓	✓	✓	
2010	Astra-G	Chassis	ABS-5.3/5.4 (+TC) (Anti-lock Braking System)	✓	✓	✓	✓	✓	
2010	Astra-G	Chassis	Electronic Power Steering	✓	✓	✓	✓	✓	
2010	Astra-G	Chassis	ESP (Electronic Stability Program)	✓	✓	✓	✓	✓	0006
2010	Astra-G	Engine	Z 12 XE	✓	✓	✓	✓	✓	0007 0146 0010 0041 0020 0022 0012 0066 0034
2010	Astra-G	Engine	Z 14 XE	✓	✓	✓	✓	✓	0147 0146 0010 0020 0022 0012
2010	Astra-G	Engine	Z 14 XEP	✓	✓	✓	✓	✓	0007 0167 0010 0147 0020 0012 0022 0066 0034
2010	Astra-G	Engine	C 16 SEL	✓	✓	✓	✓	✓	
2010	Astra-G	Engine	Z 16 XE	✓	✓	✓	✓	✓	0007 0022 0012
2010	Astra-G	Engine	Z 16 SE	✓	✓	✓	✓	✓	0007 0022 0012
2010	Astra-G	Engine	Z 16 XEP	✓	✓	✓	✓	✓	0007 0147 0010 0020 0012 0022 0066
2010	Astra-G	Engine	Z 16 YNG	✓	✓	✓	✓	✓	0007 0147 0146 0010 0020 0012 0022
2010	Astra-G	Engine	Y 17 DT	✓	✓	✓	✓	✓	
2010	Astra-G	Engine	Z 17 DTL	✓	✓	✓	✓	✓	
2010	Astra-G	Engine	Z 18 XE	✓	✓	✓	✓	✓	0146 0010 0041 0020 0012 0022
2010	Astra-G	Engine	Z 18 XEL	✓	✓	✓	✓	✓	0012 0022
2010	Astra-G	Engine	Y 20 DTH	✓	✓	✓	✓	✓	0167 0168 0169 0170
2010	Astra-G	Engine	Z 20 LET	✓	✓	✓	✓	✓	0010 0020 0041 0146 0012 0022 0066 0034
2010	Astra-G	Engine	Y 22 DTR	✓	✓	✓	✓	✓	0012 0022
2010	Astra-G	Engine	Z 22 SE	✓	✓	✓	✓	✓	0147 0010 0146 0012 0022 0066 0034
2010	Astra-G	Transmission	AF 13-II/17/20/22	✓	✓	✓	✓	✓	
2010	Astra-G	Transmission	AF 13-II/17/20/22 CAN	✓	✓	✓	✓	✓	
2010	Captiva(Long Body)	Body	BCM (Body Control Module)	✓	✓	✓	✓	✓	
2010	Captiva(Long Body)	Body	ECC (Electronic Climate Control)	✓	✓	✓	✓	✓	0151 0005
2010	Captiva(Long Body)	Body	Immobiliser	✓	✓	✓	✓	✓	
2010	Captiva(Long Body)	Body	IPC ECU (Instrument Control Unit)	✓	✓	✓	✓	✓	
2010	Captiva(Long Body)	Body	XBCM(Auxiliary Body Control Module)	✓	✓	✓	✓	✓	
2010	Captiva(Long Body)	Body	RFA (Multipurpose Receiver Module)	✓	✓	✓	✓	✓	
2010	Captiva(Long Body)	Chassis	ABS/TC/ESP (Vehicle Dynamic System)	✓	✓	✓	✓	✓	0005 0006 0004
2010	Captiva(Long Body)	Engine	2.0 L (Diesel)	✓	✓	✓	✓	✓	0011 0012 0067 0021 0025 0013 0029 0026 0028 0030 0152
2010	Captiva(Long Body)	Engine	Z32SE	✓	✓	✓	✓	✓	
2010	Captiva(Long Body)	Transmission	TCCM(Transfer Case Control Module)	✓	✓	✓	✓	✓	0153
2010	Captiva(Long Body)	Transmission	Automatic Transmission	✓	✓	✓	✓	✓	0171 0155 0156 0157 0034
2010	Corsa-C	Body	Add On Heater	✓	✓	✓	✓	✓	0123 0124
2010	Corsa-C	Body	Airbag	✓	✓	✓	✓	✓	
2010	Corsa-C	Body	Body Control Module	✓	✓	✓	✓	✓	0052 0059 0139
2010	Corsa-C	Body	HeadLamp Levelling Device	✓	✓	✓	✓	✓	0142
2010	Corsa-C	Body	Instrument	✓	✓	✓	✓	✓	
2010	Corsa-C	Body	Immobiliser	✓	✓	✓	✓	✓	0165 0166
2010	Corsa-C	Chassis	ABS/ESP8 (Anti-lock Braking System/Electronic Stability Program)	✓	✓	✓	✓	✓	0006 0143 0144 0145 0005
2010	Corsa-C	Chassis	ABS-5.3/5.4 (+TC) (Anti-lock Braking System)	✓	✓	✓	✓	✓	
2010	Corsa-C	Chassis	Electronic Power Steering	✓	✓	✓	✓	✓	0142
2010	Corsa-C	Engine	Z 10 XEP	✓	✓	✓	✓	✓	0012 0022 0066 0034
2010	Corsa-C	Engine	Z 12 XE	✓	✓	✓	✓	✓	0007 0146 0010 0041 0020 0022 0012 0066 0034
2010	Corsa-C	Engine	Z 12 XEP	✓	✓	✓	✓	✓	0012 0022 0066 0034
2010	Corsa-C	Engine	Y 13 DT	✓	✓	✓	✓	✓	0041 0020 0022 0012 0021
2010	Corsa-C	Engine	Z 13 DT	✓	✓	✓	✓	✓	0041 0020 0022 0012 0021
2010	Corsa-C	Engine	Z 13 DTJ	✓	✓	✓	✓	✓	0041 0020 0029 0026 0042 0022 0012 0021 0043

2010	Corsa-C	Engine	Z 14 XE	✓				✓	✓	0147 0146 0010 0020 0022 0012
2010	Corsa-C	Engine	Z 14 XEP	✓	✓	✓	✓	✓	✓	0007 0167 0010 0147 0020 0012 0022 0066 0034
2010	Corsa-C	Engine	Z 16 SE	✓	✓	✓	✓	✓	✓	0007 0022 0012
2010	Corsa-C	Engine	Z 16 YNG	✓	✓	✓	✓	✓	✓	0007 0147 0146 0010 0020 0012 0022
2010	Corsa-C	Engine	Y 17 DT	✓	✓	✓	✓	✓	✓	
2010	Corsa-C	Engine	Y 17 DTL	✓	✓	✓	✓	✓	✓	0007 0022 0012
2010	Corsa-C	Engine	Z 17 DTH	✓	✓	✓	✓	✓	✓	
2010	Corsa-C	Engine	Z 18 XE	✓	✓	✓	✓	✓	✓	0146 0010 0041 0020 0012 0022
2010	Corsa-C	Transmission	AF 13-II/17/20/22 CAN	✓	✓	✓	✓	✓	✓	
2010	Corsa-C	Transmission	Easytronic(MTA)	✓	✓	✓	✓	✓	✓	0012 0149
2010	Corsa-D	Body	Exterior Lighting	✓	✓	✓	✓	✓	✓	
2010	Corsa-D	Body	Interior Lighting	✓	✓	✓	✓	✓	✓	
2010	Corsa-D	Body	Wipers/Washer	✓	✓	✓	✓	✓	✓	
2010	Corsa-D	Body	Heating,Ventilation and Air Cond.	✓	✓	✓	✓	✓	✓	
2010	Corsa-D	Body	Anti Theft Warning System	✓	✓	✓	✓	✓	✓	
2010	Corsa-D	Body	Central Door Lock	✓	✓	✓	✓	✓	✓	
2010	Corsa-D	Body	Immobiliser	✓	✓	✓	✓	✓	✓	
2010	Corsa-D	Body	APL (Adaptive Forward Lighting)	✓	✓	✓	✓	✓	✓	
2010	Corsa-D	Body	EHS (Electrical Heater System)	✓	✓	✓	✓	✓	✓	
2010	Corsa-D	Body	IPC ECU (Instrument Control Unit)	✓	✓	✓	✓	✓	✓	
2010	Corsa-D	Body	PAS (Park Pilot)	✓	✓	✓	✓	✓	✓	
2010	Corsa-D	Body	SDM (Airbag)	✓	✓	✓	✓	✓	✓	0000 0001 0002 0003
2010	Corsa-D	Body	TIM(Trailer Interface Module)	✓	✓	✓	✓	✓	✓	
2010	Corsa-D	Body	BCM (Body Control Module)	✓	✓	✓	✓	✓	✓	
2010	Corsa-D	Chassis	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)	✓	✓	✓	✓	✓	✓	
2010	Corsa-D	Chassis	Electronic Power Steering	✓	✓	✓	✓	✓	✓	0004 0005 0006
2010	Corsa-D	Chassis	Fuel injector control module	✓	✓	✓	✓	✓	✓	
2010	Corsa-D	Engine	Z10XEP	✓	✓	✓	✓	✓	✓	0007 0008 0009 0010 0011 0012 0013 0014 0015
2010	Corsa-D	Engine	A10XEP	✓	✓	✓	✓	✓	✓	0007 0016 0017 0018 0019
2010	Corsa-D	Engine	Z12XEP	✓	✓	✓	✓	✓	✓	0007 0008 0009 0010 0011 0012 0013 0014 0015
2010	Corsa-D	Engine	A12XER	✓	✓	✓	✓	✓	✓	0007 0019
2010	Corsa-D	Engine	A12XEL	✓	✓	✓	✓	✓	✓	0007 0019
2010	Corsa-D	Engine	Z13DTH	✓	✓	✓	✓	✓	✓	0020 0011 0012 0015 0021
2010	Corsa-D	Engine	Z13DTE	✓	✓	✓	✓	✓	✓	0007
2010	Corsa-D	Engine	Z13DJ	✓	✓	✓	✓	✓	✓	0020 0011 0012 0015 0021
2010	Corsa-D	Engine	Z14XEP	✓	✓	✓	✓	✓	✓	0007 0008 0009 0010 0011 0012 0013 0014 0015
2010	Corsa-D	Engine	A14XEL	✓	✓	✓	✓	✓	✓	0007 0016 0017 0018 0019
2010	Corsa-D	Engine	A14XER	✓	✓	✓	✓	✓	✓	0007 0016 0017 0018 0019
2010	Corsa-D	Engine	Z16LEL	✓	✓	✓	✓	✓	✓	
2010	Corsa-D	Engine	Z16LER	✓	✓	✓	✓	✓	✓	
2010	Corsa-D	Engine	A16LEL	✓	✓	✓	✓	✓	✓	
2010	Corsa-D	Engine	A16LER	✓	✓	✓	✓	✓	✓	
2010	Corsa-D	Engine	Z17DTR	✓	✓	✓	✓	✓	✓	0020 0022 0012 0015 0023 0024 0025 0013 0026 0027 0028 0029 0021 0030
2010	Corsa-D	Transmission	MTA(Easytronic Magneti Marelli)	✓	✓	✓	✓	✓	✓	
2010	Corsa-D	Transmission	AF 13-4	✓	✓	✓	✓	✓	✓	0031 0032 0033 0034
2010	Corsa-D	Transmission	MTA(Easytronic)	✓	✓	✓	✓	✓	✓	0035 0036
2010	Corsa-D	Engine	Engine(default)	✓	✓	✓	✓	✓	✓	
2010	Meriva	Body	EHS (Electrical Heater System)	✓	✓	✓	✓	✓	✓	
2010	Meriva	Body	Add On Heater	✓	✓	✓	✓	✓	✓	0123 0124
2010	Meriva	Body	Airbag	✓	✓	✓	✓	✓	✓	
2010	Meriva	Body	Body Control Module	✓	✓	✓	✓	✓	✓	0052 0059 0139
2010	Meriva	Body	Electronic Climate Control	✓	✓	✓	✓	✓	✓	
2010	Meriva	Body	HeadLamp Levelling Device	✓	✓	✓	✓	✓	✓	0142
2010	Meriva	Body	Immobiliser	✓	✓	✓	✓	✓	✓	0165 0166
2010	Meriva	Body	Instrument	✓	✓	✓	✓	✓	✓	
2010	Meriva	Chassis	ABS/ESP8 (Anti-lock Braking System/Electronic Stability Program)	✓	✓	✓	✓	✓	✓	0006 0143 0144 0145 0005
2010	Meriva	Chassis	Electronic Power Steering	✓	✓	✓	✓	✓	✓	0142
2010	Meriva	Engine	Y 13 DT	✓	✓	✓	✓	✓	✓	0041 0020 0022 0012 0021
2010	Meriva	Engine	Z 13 DT	✓	✓	✓	✓	✓	✓	0041 0020 0022 0012 0021
2010	Meriva	Engine	Z 13 DTJ	✓	✓	✓	✓	✓	✓	0041 0020 0029 0026 0042 0022 0012 0021 0043
2010	Meriva	Engine	Z 14 XEP	✓	✓	✓	✓	✓	✓	0007 0167 0010 0147 0020 0012 0022 0066 0034
2010	Meriva	Engine	Z 16 LET	✓	✓	✓	✓	✓	✓	0007 0147 0010 0020 0012 0022 0066
2010	Meriva	Engine	Z 16 SE	✓	✓	✓	✓	✓	✓	0007 0022 0012
2010	Meriva	Engine	Z 16 XE	✓	✓	✓	✓	✓	✓	0007 0022 0012
2010	Meriva	Engine	Z 16 XEP	✓	✓	✓	✓	✓	✓	0007 0147 0010 0020 0012 0022 0066
2010	Meriva	Engine	Z 16 YNG	✓	✓	✓	✓	✓	✓	0007 0147 0146 0010 0020 0012 0022
2010	Meriva	Engine	C 16 SEL	✓	✓	✓	✓	✓	✓	
2010	Meriva	Engine	Y 17 DT	✓	✓	✓	✓	✓	✓	
2010	Meriva	Engine	Z 17 DT	✓	✓	✓	✓	✓	✓	0007 0147 0020 0023 0012 0022 0021 0148
2010	Meriva	Engine	Z 17 DTR	✓	✓	✓	✓	✓	✓	
2010	Meriva	Engine	Z 17 DTH	✓	✓	✓	✓	✓	✓	
2010	Meriva	Engine	Z 18 XE	✓	✓	✓	✓	✓	✓	0146 0010 0041 0020 0012 0022
2010	Meriva	Transmission	Easytronic(MTA)	✓	✓	✓	✓	✓	✓	0012 0149
2010	Movano	Body	Airbag	✓	✓	✓	✓	✓	✓	
2010	Movano	Body	Body Control Module	✓	✓	✓	✓	✓	✓	0052 0059 0139
2010	Movano	Body	Park Pilot	✓	✓	✓	✓	✓	✓	
2010	Movano	Chassis	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)	✓	✓	✓	✓	✓	✓	0165 0166
2010	Movano	Chassis	Pneumatic Suspension	✓	✓	✓	✓	✓	✓	
2010	Movano	Transmission	MTA(Tecshift)	✓	✓	✓	✓	✓	✓	
2010	Vivaro	Body	Park Pilot	✓	✓	✓	✓	✓	✓	
2010	Vivaro	Body	Add On Heater	✓	✓	✓	✓	✓	✓	0123 0124
2010	Vivaro	Body	Airbag	✓	✓	✓	✓	✓	✓	0005
2010	Vivaro	Body	Body Control Module	✓	✓	✓	✓	✓	✓	
2010	Vivaro	Chassis	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)	✓	✓	✓	✓	✓	✓	0176 0177

2010	Vivaro	Engine	F9Q 760/762 (1.9L)	✓	✓	✓	✓		
2010	Vivaro	Transmission	MTA(Tecshift)		✓	✓	✓	✓	
2010	Zafira-B	Body	AHL/APL(Headlamp Levelling)	✓	✓	✓	✓		
2010	Zafira-B	Body	Exterior Lighting/Turn Indicator System	✓	✓	✓	✓		
2010	Zafira-B	Body	Interior Lighting	✓	✓	✓	✓		
2010	Zafira-B	Body	Wipers/Washer	✓	✓	✓	✓		
2010	Zafira-B	Body	Central Door Lock	✓	✓	✓	✓		
2010	Zafira-B	Body	Instrument	✓	✓	✓	✓	✓	0056 0057 0058
2010	Zafira-B	Body	Immobiliser	✓	✓	✓	✓		
2010	Zafira-B	Body	CIM(Steering Column Module)	✓	✓	✓	✓	✓	0052 0004 0053 0002 0005 0054 0055 0006
2010	Zafira-B	Body	ECC/SAC(Electronic Climate Control)	✓	✓	✓	✓	✓	0151 0159 0160 0002 0005 0161
2010	Zafira-B	Body	EHS(Electrical Heater System)	✓	✓	✓	✓		0033 0002 0005
2010	Zafira-B	Body	PAS(Park Pilot)	✓	✓	✓	✓	✓	0002
2010	Zafira-B	Body	SDM(Airbag)	✓	✓	✓	✓		0000 0001 0002 0003
2010	Zafira-B	Body	SLM(Shift Lever Module)	✓	✓	✓	✓		
2010	Zafira-B	Body	UEC(Underhood Electrical Centre)	✓	✓	✓	✓		
2010	Zafira-B	Body	REC(Rear Electrical Centre)	✓	✓	✓	✓		
2010	Zafira-B	Body	PEPS (Open&Start)	✓	✓	✓	✓		
2010	Zafira-B	Body	IPC ECU(Instrument Control Unit)	✓	✓	✓	✓	✓	0007 0056 0057 0058 0059 0060 0061 0002 0005
2010	Zafira-B	Body	Anti Theft Warning System	✓	✓	✓	✓	✓	
2010	Zafira-B	Chassis	ABS/TC/ESP (Vehicle Dynamic System)	✓	✓	✓	✓	✓	0006
2010	Zafira-B	Chassis	TPMS ECU (Tyre Pressure Monitoring)	✓	✓	✓	✓	✓	0002
2010	Zafira-B	Chassis	TPMS (Tyre Pressure Monitoring System)	✓	✓	✓	✓		
2010	Zafira-B	Chassis	EHPS (Electrohydraulic Power Steering)	✓	✓	✓	✓		0004
2010	Zafira-B	Chassis	ABS/TC/ESP ECU(Electronic Control Unit)	✓	✓	✓	✓	✓	0004 0005 0063
2010	Zafira-B	Chassis	CDC (Continuous Damping Control)	✓	✓	✓	✓		
2010	Zafira-B	Engine	Z 19 DTH	✓	✓	✓	✓	✓	0007 0008 0009 0033 0011 0012 0067 0024 0025 0029 0026 0027 0028
2010	Zafira-B	Engine	Z 16 XER	✓	✓	✓	✓	✓	0007 0008 0009 0010 0020 0011 0012 0067 0034 0013 0019
2010	Zafira-B	Engine	Z 16 YNG	✓	✓	✓	✓	✓	0007 0008 0009 0010 0020 0011 0012 0067 0013 0014 0034 0019
2010	Zafira-B	Engine	Z 18 XER	✓	✓	✓	✓	✓	0007 0008 0009 0010 0020 0011 0012 0067 0034 0013 0019
2010	Zafira-B	Engine	Z 22 YH	✓	✓	✓	✓	✓	0007 0008 0009 0072 0020 0011 0012 0067 0013 0014 0019
2010	Zafira-B	Engine	Z 20 LER	✓	✓	✓	✓	✓	0007 0008 0009 0010 0011 0012 0067 0013 0014 0019
2010	Zafira-B	Engine	Z 20 LEH	✓	✓	✓	✓	✓	0007 0008 0009 0010 0011 0012 0067 0013 0014 0019
2010	Zafira-B	Engine	Z 19 DT	✓	✓	✓	✓	✓	0007 0008 0009 0011 0012 0067 0024 0025 0070 0013 0033 0021 0030 0027 0028 0026 0029 0019
2010	Zafira-B	Engine	Z 16 XE1	✓	✓	✓	✓	✓	0007 0008 0009 0010 0174 0011 0012 0067 0013 0014 0034 0019
2010	Zafira-B	Engine	Z 16 XEP	✓	✓	✓	✓	✓	0007 0008 0009 0010 0020 0011 0012 0067 0013 0014 0034 0019
2010	Zafira-B	Engine	A 17 DTJ	✓	✓	✓	✓	✓	0007 0008 0009 0020 0011 0012 0067 0015 0023 0024 0025 0013 0029 0026 0070 0027 0071 0028 0019
2010	Zafira-B	Engine	A 17 DTR	✓	✓	✓	✓	✓	0007 0008 0009 0020 0011 0012 0067 0015 0023 0024 0025 0013 0029 0026 0070 0027 0071 0028 0019
2010	Zafira-B	Engine	Z 17 DTJ	✓	✓	✓	✓	✓	0020 0011 0012 0067 0015 0023 0024 0025 0013 0026 0027 0028 0029 0030 0021 0019
2010	Zafira-B	Engine	Engine(default)	✓	✓	✓	✓		
2010	Zafira-B	Transmission	AF 40-6	✓	✓	✓	✓	✓	0073 0074 0075 0076 0077 0078 0033 0004 0034 0079
2010	Zafira-B	Transmission	MTA(Easytronic)	✓	✓	✓	✓	✓	0004 0062 0035 0036
2010	Zafira-B	Transmission	AF 22-4	✓	✓	✓	✓	✓	0031 0033 0004 0034
2009	Agila-B	Body	BCM (Body Control Module)	✓	✓	✓	✓	✓	
2009	Agila-B	Body	Immobiliser		✓	✓	✓		
2009	Agila-B	Body	SDM (Airbag)		✓	✓	✓		
2009	Agila-B	Chassis	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)	✓	✓	✓	✓		0006
2009	Agila-B	Chassis	Electronic Power Steering		✓	✓	✓		
2009	Agila-B	Engine	K10B	✓	✓	✓	✓	✓	0016
2009	Agila-B	Engine	K12B	✓	✓	✓	✓	✓	0016
2009	Agila-B	Engine	D13A / Z 13 DTJ	✓	✓	✓	✓	✓	0041 0020 0012 0022 0021 0019 0029 0026 0042 0043
2009	Agila-B	Transmission	TCM (Transmission Control Module)	✓	✓	✓	✓		0034
2009	Antara,Captiva(Short Body)	Body	AHL(Automatic Headlamp Levelling)	✓	✓	✓	✓	✓	0142
2009	Antara,Captiva(Short Body)	Body	Anti Theft Warning System	✓	✓	✓	✓	✓	
2009	Antara,Captiva(Short Body)	Body	BCM (Body Control Module)	✓	✓	✓	✓	✓	
2009	Antara,Captiva(Short Body)	Body	ECC (Electronic Climate Control)	✓	✓	✓		✓	0151 0005
2009	Antara,Captiva(Short Body)	Body	Immobiliser	✓	✓	✓	✓		
2009	Antara,Captiva(Short Body)	Body	IPC ECU (Instrument Control Unit)	✓	✓	✓	✓	✓	
2009	Antara,Captiva(Short Body)	Body	Wipers/Washer	✓	✓	✓	✓		
2009	Antara,Captiva(Short Body)	Body	PAS (Park Pilot)	✓	✓	✓	✓	✓	0058
2009	Antara,Captiva(Short Body)	Body	XBCM(Auxiliary Body Control Module)	✓	✓	✓	✓	✓	
2009	Antara,Captiva(Short Body)	Body	Central Door Lock	✓	✓	✓	✓	✓	
2009	Antara,Captiva(Short Body)	Body	RFA (Multipurpose Receiver Module)	✓	✓	✓	✓		

2009	Antara, Captiva (Short Body)	Body	SLM (Shift Lever Module)	✓	✓	✓	✓		
2009	Antara, Captiva (Short Body)	Body	HVAC (Heating Ventilation and Cooling)	✓	✓	✓	✓		
2009	Antara, Captiva (Short Body)	Body	Interior Lighting	✓	✓	✓	✓		
2009	Antara, Captiva (Short Body)	Body	Exterior Lighting/Turn Indicator System	✓	✓	✓	✓		
2009	Antara, Captiva (Short Body)	Body	SDM (Airbag)	✓	✓	✓	✓		
2009	Antara, Captiva (Short Body)	Chassis	ABS/TC/ESP (Vehicle Dynamic System)	✓	✓	✓	✓	✓	0005 0006 0004
2009	Antara, Captiva (Short Body)	Engine	2.0 L (Diesel)	✓	✓	✓	✓	✓	0011 0012 0067 0021 0025 0013 0029 0026 0028 0030 0152
2009	Antara, Captiva (Short Body)	Engine	Z 24 XE	✓	✓	✓	✓	✓	0011 0034 0016
2009	Antara, Captiva (Short Body)	Engine	Z 32 SE	✓	✓	✓	✓	✓	0016 0019 0173
2009	Antara, Captiva (Short Body)	Transmission	TCCM (Transfer Case Control Module)	✓	✓	✓	✓		0153
2009	Antara, Captiva (Short Body)	Transmission	Automatic Transmission	✓	✓	✓	✓	✓	0171 0155 0156 0157 0034
2009	Astra-G	Body	Immobiliser	✓	✓	✓	✓		0140 0141
2009	Astra-G	Body	Instrument	✓	✓	✓	✓		
2009	Astra-G	Body	Airbag	✓	✓	✓	✓		
2009	Astra-G	Body	Anti Theft Warning	✓	✓	✓	✓		
2009	Astra-G	Body	Central Door Lock	✓	✓	✓	✓		
2009	Astra-G	Body	Headlamp Levelling Device	✓	✓	✓	✓	✓	0142
2009	Astra-G	Body	Electronic Climate Control	✓	✓	✓	✓		
2009	Astra-G	Body	Engine Cooling Module	✓	✓	✓	✓		
2009	Astra-G	Body	Add On Heater	✓	✓	✓	✓	✓	0123 0124
2009	Astra-G	Body	Softtop Controller	✓	✓	✓	✓	✓	
2009	Astra-G	Chassis	ABS-5.3/5.4(+TC)	✓	✓	✓	✓	✓	
2009	Astra-G	Chassis	ESP	✓	✓	✓	✓	✓	0006
2009	Astra-G	Chassis	Cruise Control	✓	✓	✓	✓		
2009	Astra-G	Chassis	Electronic Power Steering	✓	✓	✓	✓		
2009	Astra-G	Engine	Z12XE	✓	✓	✓	✓	✓	0007 0146 0010 0041 0020 0022 0012 0066 0034
2009	Astra-G	Engine	Z14XE	✓	✓	✓	✓	✓	0147 0146 0010 0020 0022 0012
2009	Astra-G	Engine	Z14XEP	✓	✓	✓	✓	✓	0034 0066 0007 0167 0010 0147 0020 0012 0022
2009	Astra-G	Engine	C16SEL	✓	✓	✓	✓	✓	
2009	Astra-G	Engine	Z16SE	✓	✓	✓	✓	✓	0007 0022 0012
2009	Astra-G	Engine	Z16XE	✓	✓	✓	✓	✓	0007 0022 0012
2009	Astra-G	Engine	Z16XEP	✓	✓	✓	✓	✓	0007 0147 0010 0020 0012 0022 0066
2009	Astra-G	Engine	Z16YNG	✓	✓	✓	✓	✓	0007 0147 0146 0010 0020 0012 0022
2009	Astra-G	Engine	Y17DT	✓	✓	✓	✓	✓	
2009	Astra-G	Engine	Z17DTL	✓	✓	✓	✓	✓	
2009	Astra-G	Engine	Z18XE	✓	✓	✓	✓	✓	0146 0010 0041 0020 0012 0022
2009	Astra-G	Engine	Z18XEL	✓	✓	✓	✓	✓	0012 0022
2009	Astra-G	Engine	Y20DTH	✓	✓	✓	✓	✓	0167 0168 0169 0170
2009	Astra-G	Engine	Z20LET	✓	✓	✓	✓	✓	0010 0020 0041 0146 0012 0022 0066 0034
2009	Astra-G	Engine	Y22DTR	✓	✓	✓	✓	✓	0012 0022
2009	Astra-G	Engine	Z22SE	✓	✓	✓	✓	✓	0066 0147 0146 0010 0012 0022 0034
2009	Astra-G	Transmission	AF 13-II/17/20/22	✓	✓	✓	✓	✓	
2009	Astra-G	Transmission	AF 13-II/17/20/22 CAN	✓	✓	✓	✓	✓	
2009	Astra-H	Body	SDM (Airbag)	✓	✓	✓	✓		
2009	Astra-H	Body	CIM (Steering Column Module)	✓	✓	✓	✓	✓	0052 0004 0053 0002 0005 0054 0055 0006
2009	Astra-H	Body	IPC ECU (Instrument Control Unit)	✓	✓	✓	✓		
2009	Astra-H	Body	REC (Rear Electrical Centre)	✓	✓	✓	✓		
2009	Astra-H	Body	UEC (Underhood Electrical Centre)	✓	✓	✓	✓		
2009	Astra-H	Body	AHL/AFI (Headlamp Levelling)	✓	✓	✓	✓		
2009	Astra-H	Body	Exterior Lighting/Turn Indicator System	✓	✓	✓	✓		
2009	Astra-H	Body	Interior Lighting	✓	✓	✓	✓		
2009	Astra-H	Body	Wipers/Washer	✓	✓	✓	✓		
2009	Astra-H	Body	Central Door Lock	✓	✓	✓	✓		
2009	Astra-H	Body	Instrument	✓	✓	✓	✓	✓	0056 0057 0058
2009	Astra-H	Body	Immobiliser	✓	✓	✓	✓		
2009	Astra-H	Body	Anti Theft Warning System	✓	✓	✓	✓		
2009	Astra-H	Body	Electrohydraulic HardTop	✓	✓	✓	✓	✓	0002 0005
2009	Astra-H	Body	ECC/SAC (Electronic Climate Control)	✓	✓	✓	✓	✓	0151 0159 0160 0033 0002 0005 0161
2009	Astra-H	Body	EHS (Electrical Heater System)	✓	✓	✓	✓		0033 0002 0005
2009	Astra-H	Body	PAS (Park Pilot)	✓	✓	✓	✓	✓	0002
2009	Astra-H	Body	SLM (Shift Lever Module)	✓	✓	✓	✓		
2009	Astra-H	Body	PEPS (Open&Start)	✓	✓	✓	✓		
2009	Astra-H	Body	IPC ECU (Instrument Control Unit)	✓	✓	✓	✓	✓	0007 0056 0057 0058 0059 0060 0061 0002 0005
2009	Astra-H	Chassis	ABS/TC/ESP ECU (Electronic Control Unit)	✓	✓	✓	✓	✓	0004 0005 0063
2009	Astra-H	Chassis	EHPS (Electrohydraulic Power Steering)	✓	✓	✓	✓		
2009	Astra-H	Chassis	TPMS ECU (Tyre Pressure Monitoring)	✓	✓	✓	✓		0002
2009	Astra-H	Chassis	TPMS (Tyre Pressure Monitoring System)	✓	✓	✓	✓		
2009	Astra-H	Chassis	CDC (Continuous Damping Control)	✓	✓	✓	✓		
2009	Astra-H	Chassis	ABS/TC/ESP (Vehicle Dynamic System)	✓	✓	✓	✓	✓	
2009	Astra-H	Chassis	EHPS (Electrohydraulic Power Steering)	✓	✓	✓	✓		0004
2009	Astra-H	Engine	Z13DTH	✓	✓	✓	✓	✓	0007 0008 0009 0020 0011 0012 0067 0021 0030 0029 0026 0027 0019
2009	Astra-H	Engine	Z14XEL	✓	✓	✓	✓	✓	0007 0008 0009 0010 0011 0012 0067 0013 0014 0019
2009	Astra-H	Engine	Z14XEP	✓	✓	✓	✓	✓	0007 0008 0009 0010 0011 0012 0067 0013 0014 0019
2009	Astra-H	Engine	Z16XEP	✓	✓	✓	✓		0007 0008 0009 0010 0020 0011 0012 0067 0013 0014 0034 0019
2009	Astra-H	Engine	Z16XER	✓	✓	✓	✓		0020 0007 0008 0009 0010 0011 0012 0067 0034 0013 0019

2009	Astra-H	Engine	Z17DTH	✓	✓	✓	✓	✓	0007 0008 0009 0011 0012 0067 0021 0025 0013 0030 0033 0019
2009	Astra-H	Engine	Z17DTR	✓	✓	✓	✓	✓	0007 0008 0009 0020 0011 0012 0067 0015 0023 0024 0025 0013 0026 0027 0028 0029 0030 0021 0019
2009	Astra-H	Engine	Z17DTJ	✓	✓	✓	✓	✓	0007 0008 0009 0020 0011 0012 0067 0015 0023 0024 0025 0013 0026 0027 0028 0029 0030 0021 0019
2009	Astra-H	Engine	Z18XE	✓	✓	✓	✓	✓	0020 0007 0008 0009 0010 0011 0012 0067 0013 0019
2009	Astra-H	Engine	Z19DT	✓	✓	✓	✓	✓	0007 0008 0009 0011 0012 0067 0024 0025 0070 0013 0033 0021 0030 0027 0028 0026 0029 0019
2009	Astra-H	Engine	Z19DTH	✓	✓	✓	✓	✓	0007 0008 0009 0011 0012 0067 0024 0025 0070 0013 0033 0021 0030 0027 0028 0026 0029 0019
2009	Astra-H	Engine	Z 12 XEP	✓	✓	✓	✓	✓	0007 0008 0009 0010 0011 0012 0067 0013 0014 0019
2009	Astra-H	Engine	Y 13 DTH	✓	✓	✓	✓	✓	0020 0011 0012 0067 0021 0030 0029 0026 0027 0019
2009	Astra-H	Engine	A 16 LET	✓	✓	✓	✓	✓	0007 0008 0009 0010 0011 0012 0067 0013 0014 0019
2009	Astra-H	Engine	Z 16 XE1	✓	✓	✓	✓	✓	0007 0008 0009 0010 0020 0011 0012 0067 0013 0014 0034 0019
2009	Astra-H	Engine	Z 16 LET	✓	✓	✓	✓	✓	0007 0008 0009 0010 0011 0012 0067 0013 0014 0019
2009	Astra-H	Engine	A 17 DTJ	✓	✓	✓	✓	✓	0007 0008 0009 0020 0011 0012 0067 0015 0023 0024 0025 0013 0029 0026 0070 0027 0071 0028 0019
2009	Astra-H	Engine	A 17 DTR	✓	✓	✓	✓	✓	0007 0008 0009 0020 0011 0012 0067 0015 0023 0024 0025 0013 0029 0026 0070 0027 0071 0028 0019
2009	Astra-H	Engine	Z 17 DTL	✓	✓	✓	✓	✓	0011 0012 0067 0021 0025 0013 0030 0033 0019
2009	Astra-H	Engine	Z 18 XER	✓	✓	✓	✓	✓	0007 0008 0009 0010 0020 0011 0012 0067 0034 0013 0019
2009	Astra-H	Engine	Z 20 LEH	✓	✓	✓	✓	✓	0007 0008 0009 0010 0011 0012 0067 0013 0014 0019
2009	Astra-H	Engine	Z 20 LEL	✓	✓	✓	✓	✓	0007 0008 0009 0010 0011 0012 0067 0013 0014 0019
2009	Astra-H	Engine	Z 20 LER	✓	✓	✓	✓	✓	0007 0008 0009 0010 0011 0012 0067 0013 0014 0019
2009	Astra-H	Engine	Z 22 YH	✓	✓	✓	✓	✓	0007 0008 0009 0072 0020 0011 0012 0067 0013 0019
2009	Astra-H	Engine	Engine(default)	✓	✓	✓	✓	✓	
2009	Astra-H	Transmission	AF 17-4	✓	✓	✓	✓	✓	0031 0032 0033 0004 0034
2009	Astra-H	Transmission	AF 40-6	✓	✓	✓	✓	✓	0073 0074 0075 0076 0077 0078 0033 0004 0034 0079
2009	Astra-H	Transmission	AF 22-4	✓	✓	✓	✓	✓	0031 0033 0004 0034
2009	Astra-H	Transmission	MTA(Easytronic)	✓	✓	✓	✓	✓	0004 0062 0035 0036
2009	Astra-H	Transmission	MTA(Easytronic Magneti Marelli)	✓	✓	✓	✓	✓	0004 0005 0062
2009	Astra-J	Electronic Brake Control Module		✓	✓	✓	✓	✓	0001 0086 0087
2009	Astra-J	Electronic Power Steering Control Module		✓	✓	✓	✓	✓	0088 0089 0090
2009	Astra-J	Engine Control Module	A13DTE	✓	✓	✓	✓	✓	0038 0039 0081 0021
2009	Astra-J	Engine Control Module	A17DTJ	✓	✓	✓	✓	✓	0038 0039 0081 0021
2009	Astra-J	Front Seat Heating Control Module		✓	✓	✓	✓	✓	
2009	Astra-J	Fuel Pump Control Module		✓	✓	✓	✓	✓	
2009	Astra-J	Keyless Entry Control Module		✓	✓	✓	✓	✓	
2009	Astra-J	Steering Column Lock Control Module		✓	✓	✓	✓	✓	
2009	Astra-J	Steering Wheel Angle Sensor Module		✓	✓	✓	✓	✓	0082 0083
2009	Astra-J	Trailer Interface Control Module		✓	✓	✓	✓	✓	
2009	Astra-J	Transmission Control Module		✓	✓	✓	✓	✓	
2009	Captiva(Long Body)	Body	BCM (Body Control Module)	✓	✓	✓	✓	✓	
2009	Captiva(Long Body)	Body	ECC (Electronic Climate Control)	✓	✓	✓	✓	✓	0151 0005
2009	Captiva(Long Body)	Body	Immobiliser	✓	✓	✓	✓	✓	
2009	Captiva(Long Body)	Body	IPC ECU (Instrument Control Unit)	✓	✓	✓	✓	✓	
2009	Captiva(Long Body)	Body	XBCM(Auxiliary Body Control Module)	✓	✓	✓	✓	✓	
2009	Captiva(Long Body)	Body	RFA (Multipurpose Receiver Module)	✓	✓	✓	✓	✓	
2009	Captiva(Long Body)	Chassis	ABS/TC/ESP (Vehicle Dynamic System)	✓	✓	✓	✓	✓	0005 0006 0004
2009	Captiva(Long Body)	Engine	2.0 L (Diesel)	✓	✓	✓	✓	✓	0011 0012 0067 0021 0025 0013 0029 0026 0028 0030 0152
2009	Captiva(Long Body)	Engine	Z32SE	✓	✓	✓	✓	✓	
2009	Captiva(Long Body)	Transmission	TCCM(Transfer Case Control Module)	✓	✓	✓	✓	✓	0153
2009	Captiva(Long Body)	Transmission	Automatic Transmission	✓	✓	✓	✓	✓	0171 0155 0156 0157 0034
2009	Corsa-C	Body	Body Control Module	✓	✓	✓	✓	✓	0052 0059 0139
2009	Corsa-C	Body	Immobiliser	✓	✓	✓	✓	✓	0140 0141
2009	Corsa-C	Body	Airbag	✓	✓	✓	✓	✓	
2009	Corsa-C	Body	Instrument	✓	✓	✓	✓	✓	0178 0179
2009	Corsa-C	Body	Add On Heater	✓	✓	✓	✓	✓	0123 0124
2009	Corsa-C	Body	HeadLamp Levelling Device	✓	✓	✓	✓	✓	0142
2009	Corsa-C	Chassis	ABS-5.3/5.4(+TC)	✓	✓	✓	✓	✓	
2009	Corsa-C	Chassis	ABS8/ESP8	✓	✓	✓	✓	✓	0006 0143 0144 0145 0005
2009	Corsa-C	Chassis	Electronic Power Steering	✓	✓	✓	✓	✓	0142
2009	Corsa-C	Engine	Z10XEP	✓	✓	✓	✓	✓	0012 0022 0066 0034
2009	Corsa-C	Engine	Z12XE	✓	✓	✓	✓	✓	0007 0146 0010 0041 0020 0022 0012 0066 0034
2009	Corsa-C	Engine	Z12XEP	✓	✓	✓	✓	✓	0012 0022 0066 0034
2009	Corsa-C	Engine	Y13DT	✓	✓	✓	✓	✓	0041 0020 0022 0012 0021
2009	Corsa-C	Engine	Z13DT	✓	✓	✓	✓	✓	0020 0041 0022 0012 0021

2009	Corsa-C	Engine	Z14XE	✓			✓	✓	0147 0146 0010 0020 0022 0012
2009	Corsa-C	Engine	Z14XEP	✓	✓	✓	✓	✓	0034 0066 0007 0167 0010 0147 0020 0012 0022
2009	Corsa-C	Engine	Z16SE	✓	✓	✓	✓	✓	0007 0022 0012
2009	Corsa-C	Engine	Z16YNG	✓	✓	✓	✓	✓	0007 0147 0146 0010 0020 0012 0022
2009	Corsa-C	Engine	Y17DT	✓	✓	✓	✓	✓	
2009	Corsa-C	Engine	Y17DTL	✓	✓	✓	✓	✓	0007 0022 0012
2009	Corsa-C	Engine	Z17DTH	✓	✓	✓	✓	✓	0007 0147 0020 0021 0148 0023 0012 0022
2009	Corsa-C	Engine	Z18XE	✓	✓	✓	✓	✓	0146 0010 0041 0020 0012 0022
2009	Corsa-C	Engine	Z13DTJ	✓	✓	✓	✓	✓	0041 0020 0029 0026 0042 0022 0012 0021 0043
2009	Corsa-C	Transmission	AF 13-II/17/20/22 CAN	✓	✓	✓	✓	✓	
2009	Corsa-C	Transmission	MTA(Easytronic)	✓	✓	✓	✓	✓	0012 0149
2009	Corsa-D	Body	SDM(Airbag)	✓	✓	✓	✓		0000 0001 0002 0003
2009	Corsa-D	Body	IPC(Instrument)	✓	✓	✓	✓	✓	0007 0056 0057 0058 0002 0005
2009	Corsa-D	Body	Central Door Lock	✓	✓	✓	✓	✓	
2009	Corsa-D	Body	Exterior Lighting	✓	✓	✓	✓	✓	
2009	Corsa-D	Body	Interior Lighting	✓	✓	✓	✓	✓	
2009	Corsa-D	Body	Wipers/Washer	✓	✓	✓	✓	✓	
2009	Corsa-D	Body	Anti Theft Warning System	✓	✓	✓	✓	✓	
2009	Corsa-D	Body	Immobiliser	✓	✓	✓	✓	✓	
2009	Corsa-D	Body	AFL (Adaptive Forward Lighting)	✓	✓	✓	✓	✓	
2009	Corsa-D	Body	EHS (Electrical Heater System)	✓	✓	✓	✓	✓	
2009	Corsa-D	Body	IPC ECU (Instrument Control Unit)	✓	✓	✓	✓	✓	0007 0056 0057 0058 0002 0005
2009	Corsa-D	Body	PAS (Park Pilot)	✓	✓	✓	✓	✓	
2009	Corsa-D	Body	TIM(Trailer Interface Module)	✓	✓	✓	✓	✓	
2009	Corsa-D	Body	BCM (Body Control Module)	✓	✓	✓	✓	✓	
2009	Corsa-D	Body	SDM(Airbag)	✓	✓	✓	✓	✓	0000 0001 0002 0003
2009	Corsa-D	Chassis	ABS/ESP	✓	✓	✓	✓	✓	0004 0005 0180 0063
2009	Corsa-D	Chassis	Electronic Power Steering	✓	✓	✓	✓	✓	0004 0005 0006
2009	Corsa-D	Engine	Z10XEP	✓	✓	✓	✓	✓	0007 0008 0009 0010 0011 0012 0013 0014 0015
2009	Corsa-D	Engine	Z12XEP	✓	✓	✓	✓	✓	0007 0008 0009 0010 0011 0012 0013 0014 0015
2009	Corsa-D	Engine	Z13DTJ	✓	✓	✓	✓	✓	0020 0011 0012 0015 0021
2009	Corsa-D	Engine	Z13DTH	✓	✓	✓	✓	✓	0020 0011 0012 0015 0021
2009	Corsa-D	Engine	Z14XEP	✓	✓	✓	✓	✓	0007 0008 0009 0010 0011 0012 0013 0014 0015
2009	Corsa-D	Engine	Z17DTR	✓	✓	✓	✓	✓	0020 0022 0012 0015 0023 0024 0025 0013 0026 0027 0028 0029 0021 0030
2009	Corsa-D	Engine	Z16LEL	✓	✓	✓	✓	✓	0010 0011 0012 0067 0013 0014 0015
2009	Corsa-D	Engine	Z16LER	✓	✓	✓	✓	✓	0010 0011 0012 0067 0013 0014 0015
2009	Corsa-D	Engine	Engine(default)	✓	✓	✓	✓	✓	
2009	Corsa-D	Transmission	MTA(Easytronic Magneti Marelli)	✓	✓	✓	✓	✓	0004 0005 0062
2009	Corsa-D	Transmission	AF 13-4	✓	✓	✓	✓	✓	0031 0032 0033 0034
2009	Corsa-D	Transmission	MTA(Easytronic)	✓	✓	✓	✓	✓	0035 0036
2009	Insignia		Engine Control Module	✓	✓	✓	✓	✓	0097 0085 0129 0086 0103 0098 0104 0102 0130 0020 0017 0094 0099 0101 0239 0132 0100 0237 0105 0106 0107 0207 0050 0019 0049 0092 0018 0096 0093
2009	Insignia		Transmission Control Module	✓	✓	✓	✓	✓	0260 0123
2009	Insignia		Body Control Module	✓	✓	✓	✓	✓	0048 0049 0046 0223 0208 0224 0047
2009	Insignia		Electronic Brake Control Module	✓	✓	✓	✓	✓	0261 0084 0087
2009	Insignia		Inflatable Restraint Sensing and Diagnostic Module	✓	✓	✓	✓	✓	0250
2009	Insignia		Instrument Cluster	✓	✓	✓	✓	✓	0041
2009	Insignia		Fuel Injector Control Module	✓	✓	✓	✓	✓	
2009	Insignia		Fuel Pump Control Module	✓	✓	✓	✓	✓	0017
2009	Insignia		Rear Differential Clutch Control Module	✓	✓	✓	✓	✓	
2009	Insignia		Parking Brake Control Module	✓	✓	✓	✓	✓	0110
2009	Insignia		Multi-Axis Acceleration Sensor Module	✓	✓	✓	✓	✓	0262 0087
2009	Insignia		Power Steering Control Module	✓	✓	✓	✓	#	0089 0090 0091
2009	Insignia		Steering Wheel Angle Sensor Module	✓	✓	✓	✓	✓	0083 0084
2009	Insignia		Suspension Control Module	✓	✓	✓	✓	✓	
2009	Insignia		Chime Alarm Control Module	✓	✓	✓	✓	✓	
2009	Insignia		Headlamp Control Module	✓	✓	✓	✓	✓	0252
2009	Insignia		Trailer Interface Control Module	✓	✓	✓	✓	✓	0041
2009	Insignia		Radio	✓	✓	✓	✓	✓	
2009	Insignia		Digital Radio Receiver Control Module	✓	✓	✓	✓	✓	0041
2009	Insignia		Multimedia Player Interface Module	✓	✓	✓	✓	✓	0041
2009	Insignia		Mobile Telephone Control Module	✓	✓	✓	✓	✓	0041
2009	Insignia		Remote Heater and Air Conditioning Control Module	✓	✓	✓	✓	✓	0211 0041
2009	Insignia		Liftgate Control Module	✓	✓	✓	✓	✓	0280
2009	Insignia		Seat Memory Control Module	✓	✓	✓	✓	✓	0289
2009	Insignia		Front Seat Heating Control Module	✓	✓	✓	✓	✓	
2009	Insignia		Parking Assist Control Module	✓	✓	✓	✓	✓	
2009	Insignia		Vehicle Direction Camera Control Module	✓	✓	✓	✓	✓	0109 0288 0041
2009	Insignia		Distance Sensing Cruise Control Module	✓	✓	✓	✓	✓	0263
2009	Meriva	Body	Body Control Module	✓	✓	✓	✓	✓	0052 0059 0139
2009	Meriva	Body	Immobiliser	✓	✓	✓	✓	✓	0140 0141
2009	Meriva	Body	Airbag	✓	✓	✓	✓	✓	
2009	Meriva	Body	Instrument	✓	✓	✓	✓	✓	0177 0178
2009	Meriva	Body	Headlamp Levelling Device	✓	✓	✓	✓	✓	0142
2009	Meriva	Body	Electronic Climate Control	✓	✓	✓	✓	✓	
2009	Meriva	Body	EHS (Electrical Heater System)	✓	✓	✓	✓	✓	
2009	Meriva	Body	Add On Heater	✓	✓	✓	✓	✓	0123 0124
2009	Meriva	Chassis	ABS8/ESP8	✓	✓	✓	✓	✓	0006 0143 0144 0145 0005
2009	Meriva	Chassis	Electronic Power Steering	✓	✓	✓	✓	✓	0142
2009	Meriva	Engine	Y13DT	✓	✓	✓	✓	✓	0041 0020 0022 0012 0021
2009	Meriva	Engine	Z14XEP	✓	✓	✓	✓	✓	0034 0066 0007 0167 0010 0147 0020 0012 0022
2009	Meriva	Engine	Z16SE	✓	✓	✓	✓	✓	0007 0022 0012

2009	Meriva	Engine	Z16XE	✓			✓	✓	0007 0022 0012
2009	Meriva	Engine	Z16XEP	✓	✓	✓	✓	✓	0007 0147 0010 0020 0012 0022 0066
2009	Meriva	Engine	Z17DT	✓	✓	✓	✓	✓	
2009	Meriva	Engine	Z17DTH	✓	✓	✓	✓	✓	0007 0147 0020 0021 0148 0023 0012 0022
2009	Meriva	Engine	Z18XE	✓	✓	✓	✓	✓	0146 0010 0041 0020 0012 0022
2009	Meriva	Engine	Z13DT	✓	✓	✓	✓	✓	0041 0020 0022 0012 0021
2009	Meriva	Engine	Z13DTJ	✓	✓	✓	✓	✓	0041 0020 0029 0026 0042 0022 0012 0021 0043
2009	Meriva	Engine	Z16LET	✓	✓	✓	✓	✓	0007 0147 0010 0020 0012 0022 0066
2009	Meriva	Engine	Z16YNG	✓	✓	✓	✓	✓	0007 0147 0146 0010 0020 0012 0022
2009	Meriva	Engine	C16SEL	✓	✓	✓	✓	✓	
2009	Meriva	Engine	Z17DT	✓	✓	✓	✓	✓	0007 0147 0020 0023 0012 0022 0021 0148
2009	Meriva	Engine	Z17DTR	✓	✓	✓	✓		
2009	Meriva	Transmission	MTA(Easytronic)	✓	✓	✓	✓	✓	0012 0149
2009	Movano	Body	Airbag	✓	✓	✓	✓	✓	
2009	Movano	Body	Body Control Module	✓	✓	✓	✓	✓	0052 0059 0139
2009	Movano	Body	Park Pilot	✓	✓	✓	✓		
2009	Movano	Chassis	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)	✓	✓	✓	✓	✓	0165 0166
2009	Movano	Chassis	Pneumatic Suspension	✓	✓	✓	✓	✓	
2009	Movano	Transmission	MTA(Tecshift)	✓	✓	✓	✓	✓	
2009	Tigra-B	Body	Body Control Module	✓	✓	✓	✓	✓	0052 0059 0139
2009	Tigra-B	Body	Immobiliser	✓	✓	✓	✓	✓	0140 0141
2009	Tigra-B	Body	Airbag	✓	✓	✓	✓	✓	
2009	Tigra-B	Body	Instrument	✓	✓	✓	✓	✓	0177 0178
2009	Tigra-B	Body	Electrohydraulic HardTop	✓	✓	✓	✓	✓	
2009	Tigra-B	Chassis	ABS/ESPS	✓	✓	✓	✓	✓	0006 0143 0144 0145 0005 0142
2009	Tigra-B	Chassis	Electronic Power Steering	✓	✓	✓	✓	✓	
2009	Tigra-B	Engine	Z13DT	✓	✓	✓	✓	✓	0020 0041 0022 0012 0021
2009	Tigra-B	Engine	Z14XEP	✓	✓	✓	✓	✓	0034 0066 0007 0167 0010 0147 0020 0012 0022
2009	Tigra-B	Engine	Z18XE	✓	✓	✓	✓	✓	0146 0010 0041 0020 0012 0022
2009	Tigra-B	Transmission	MTA(Easytronic)	✓	✓	✓	✓	✓	0012 0149
2009	Vauxhall VXRS	Body	AHL(Automatic Headlamp Levelling)	✓	✓	✓	✓	✓	
2009	Vauxhall VXRS	Body	BCM (Body Control Module)	✓	✓	✓	✓	✓	
2009	Vauxhall VXRS	Body	HVAC(Heating Ventilation and Cooling)	✓	✓	✓	✓	✓	
2009	Vauxhall VXRS	Body	Immobiliser	✓	✓	✓	✓	✓	
2009	Vauxhall VXRS	Body	MSM(Memory Seat and Mirrors)	✓	✓	✓	✓	✓	
2009	Vauxhall VXRS	Body	Park Assist	✓	✓	✓	✓	✓	
2009	Vauxhall VXRS	Body	SDM(Sensing and Diagnostic Module)	✓	✓	✓	✓	✓	
2009	Vauxhall VXRS	Body	IPC (Instrument Panel Cluster)	✓	✓	✓	✓	✓	
2009	Vauxhall VXRS	Body	RFA (Multipurpose Receiver Module)	✓	✓	✓	✓	✓	
2009	Vauxhall VXRS	Chassis	ECM(Electronic Brake Control Module)	✓	✓	✓	✓	✓	
2009	Vauxhall VXRS	Chassis	ESC(Electronic Suspension Control)	✓	✓	✓	✓	✓	
2009	Vauxhall VXRS	Engine	V8 GEN IV	✓	✓	✓	✓	✓	0016 0150 0172 0173
2009	Vauxhall VXRS	Transmission	Automatic Transmission	✓	✓	✓	✓	✓	
2009	Vivaro	Body	Airbag	✓	✓	✓	✓	✓	0005
2009	Vivaro	Body	Park Pilot	✓	✓	✓	✓	✓	
2009	Vivaro	Body	Add On Heater	✓	✓	✓	✓	✓	0123 0124
2009	Vivaro	Body	Body Control Module	✓	✓	✓	✓	✓	
2009	Vivaro	Chassis	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)	✓	✓	✓	✓	✓	0175 0176
2009	Vivaro	Engine	F9Q 760/762 (1.9L)	✓	✓	✓	✓	✓	
2009	Vivaro	Transmission	MTA(Tecshift)	✓	✓	✓	✓	✓	
2009	Zafira-B	Body	SDM(Airbag)	✓	✓	✓	✓	✓	0000 0001 0002 0003
2009	Zafira-B	Body	CIM(Steering Column Module)	✓	✓	✓	✓	✓	0052 0004 0053 0002 0005 0054 0055 0006
2009	Zafira-B	Body	IPC ECU(Instrument Control Unit)	✓	✓	✓	✓	✓	
2009	Zafira-B	Body	REC(Rear Electrical Centre)	✓	✓	✓	✓	✓	
2009	Zafira-B	Body	UEC(Underhood Electrical Centre)	✓	✓	✓	✓	✓	
2009	Zafira-B	Body	AHL/AFL(Headlamp Levelling)	✓	✓	✓	✓	✓	
2009	Zafira-B	Body	Exterior Lighting/Turn Indicator System	✓	✓	✓	✓	✓	
2009	Zafira-B	Body	Interior Lighting	✓	✓	✓	✓	✓	
2009	Zafira-B	Body	Wipers/Washer	✓	✓	✓	✓	✓	
2009	Zafira-B	Body	Central Door Lock	✓	✓	✓	✓	✓	
2009	Zafira-B	Body	Instrument	✓	✓	✓	✓	✓	0056 0057 0058
2009	Zafira-B	Body	Immobiliser	✓	✓	✓	✓	✓	
2009	Zafira-B	Body	ECC/SAC(Electronic Climate Control)	✓	✓	✓	✓	✓	0151 0159 0160 0002 0005 0161
2009	Zafira-B	Body	EHS(Electrical Heater System)	✓	✓	✓	✓	✓	0033 0002 0005
2009	Zafira-B	Body	PAS(Park Pilot)	✓	✓	✓	✓	✓	0002
2009	Zafira-B	Body	SLM(Shift Lever Module)	✓	✓	✓	✓	✓	
2009	Zafira-B	Body	PEPS(Open&Start)	✓	✓	✓	✓	✓	
2009	Zafira-B	Body	Anti Theft Warning System	✓	✓	✓	✓	✓	
2009	Zafira-B	Body	IPC ECU(Instrument Control Unit)	✓	✓	✓	✓	✓	0007 0056 0057 0058 0059 0060 0061 0002 0005
2009	Zafira-B	Chassis	ABS/TC/ESP ECU(Electronic Control Unit)	✓	✓	✓	✓	✓	0004 0005 0063
2009	Zafira-B	Chassis	EHPS(Electrohydraulic Power Steering)	✓	✓	✓	✓	✓	
2009	Zafira-B	Chassis	ABS/TC/ESP(Vehicle Dynamic System)	✓	✓	✓	✓	✓	0006
2009	Zafira-B	Chassis	TPMS ECU(Tyre Pressure Monitoring)	✓	✓	✓	✓	✓	0002
2009	Zafira-B	Chassis	TPMS(Tyre Pressure Monitoring System)	✓	✓	✓	✓	✓	
2009	Zafira-B	Chassis	ABS/TC/ESP ECU(Electronic Control Unit)	✓	✓	✓	✓	✓	0004 0005 0063
2009	Zafira-B	Chassis	CDC(Continuous Damping Control)	✓	✓	✓	✓	✓	
2009	Zafira-B	Chassis	EHPS(Electrohydraulic Power Steering)	✓	✓	✓	✓	✓	0004
2009	Zafira-B	Engine	Z16XEP	✓	✓	✓	✓	✓	0007 0008 0009 0010 0020 0011 0012 0067 0013 0014 0034 0019
2009	Zafira-B	Engine	Z16XER	✓	✓	✓	✓	✓	0020 0007 0008 0009 0010 0011 0012 0067 0034 0013 0019
2009	Zafira-B	Engine	Z18XER	✓	✓	✓	✓	✓	0020 0007 0008 0009 0010 0011 0012 0067 0034 0013 0019
2009	Zafira-B	Engine	Z19DT	✓	✓	✓	✓	✓	0007 0008 0009 0011 0012 0067 0024 0025 0070 0013 0033 0021 0030 0027 0028 0026 0029 0019

2009	Zafira-B	Engine	Z19DTH	✓	✓	✓	✓	✓	0007 0008 0009 0033 0011 0012 0067 0024 0025 0029 0026 0027 0028
2009	Zafira-B	Engine	Z16YNG	✓	✓	✓	✓	✓	0007 0008 0009 0010 0020 0011 0012 0067 0013 0014 0034 0019
2009	Zafira-B	Engine	Z16XE1	✓	✓	✓	✓	✓	0007 0008 0009 0010 0174 0011 0012 0067 0013 0014 0034 0019
2009	Zafira-B	Engine	A17DTJ	✓	✓	✓	✓	✓	0007 0008 0009 0020 0011 0012 0067 0015 0023 0024 0025 0013 0029 0026 0070 0027 0071 0028 0019
2009	Zafira-B	Engine	A17DTR	✓	✓	✓	✓	✓	0007 0008 0009 0020 0011 0012 0067 0015 0023 0024 0025 0013 0029 0026 0070 0027 0071 0028 0019
2009	Zafira-B	Engine	Z22YH	✓	✓	✓	✓	✓	0007 0008 0009 0072 0020 0011 0012 0067 0013 0014 0019
2009	Zafira-B	Engine	Z20LER	✓	✓	✓	✓	✓	0007 0008 0009 0010 0011 0012 0067 0013 0014 0019
2009	Zafira-B	Engine	Z20LEH	✓	✓	✓	✓	✓	0007 0008 0009 0010 0011 0012 0067 0013 0014 0019
2009	Zafira-B	Engine	Engine(default)	✓	✓	✓			
2009	Zafira-B	Transmission	MTA(Easutronic)	✓	✓	✓	✓	✓	0004 0062 0035 0036
2009	Zafira-B	Transmission	AF 40-6	✓	✓	✓	✓	✓	0073 0074 0075 0076 0077 0078 0033 0004 0034 0079
2009	Zafira-B	Transmission	AF 22-4	✓	✓	✓	✓	✓	0031 0033 0004 0034
2008	Agila-B	Body	BCM(Body Control Module)	✓	✓	✓	✓	✓	
2008	Agila-B	Body	Immobiliser	✓	✓	✓	✓	✓	
2008	Agila-B	Body	SDM(Airbag)	✓	✓	✓	✓	✓	
2008	Agila-B	Chassis	ABS/ESP(Anti-lock Braking System/Electronic Stability Program)	✓	✓	✓	✓	✓	0006
2008	Agila-B	Chassis	Electronic Power Steering	✓	✓	✓	✓	✓	
2008	Agila-B	Engine	K10B	✓	✓	✓	✓	✓	0016
2008	Agila-B	Engine	K12B	✓	✓	✓	✓	✓	0016
2008	Agila-B	Engine	D13A / Z 13 DTJ	✓	✓	✓	✓	✓	0041 0020 0012 0022 0021 0019 0029 0026 0042 0043
2008	Agila-B	Transmission	TCM(Transmission Control Module)	✓	✓	✓	✓	✓	0034
2008	Antara,Captiva(Short Body)	Body	AHL(Automatic Headlamp Levelling)	✓	✓	✓	✓	✓	0142
2008	Antara,Captiva(Short Body)	Body	Anti Theft Warning System	✓	✓	✓	✓	✓	
2008	Antara,Captiva(Short Body)	Body	BCM(Body Control Module)	✓	✓	✓	✓	✓	
2008	Antara,Captiva(Short Body)	Body	ECC(Electronic Climate Control)	✓	✓	✓	✓	✓	0151 0005
2008	Antara,Captiva(Short Body)	Body	Immobiliser	✓	✓	✓	✓	✓	
2008	Antara,Captiva(Short Body)	Body	IPC ECU(Instrument Control Unit)	✓	✓	✓	✓	✓	
2008	Antara,Captiva(Short Body)	Body	Wipers/Washer	✓	✓	✓	✓	✓	
2008	Antara,Captiva(Short Body)	Body	PAS(Park Pilot)	✓	✓	✓	✓	✓	0058
2008	Antara,Captiva(Short Body)	Body	XBCM(Auxiliary Body Control Module)	✓	✓	✓	✓	✓	
2008	Antara,Captiva(Short Body)	Body	Central Door Lock	✓	✓	✓	✓	✓	
2008	Antara,Captiva(Short Body)	Body	RFA(Multipurpose Receiver Module)	✓	✓	✓	✓	✓	
2008	Antara,Captiva(Short Body)	Body	SLM(Shift Lever Module)	✓	✓	✓	✓	✓	
2008	Antara,Captiva(Short Body)	Body	HVAC(Heating Ventilation and Cooling)	✓	✓	✓	✓	✓	
2008	Antara,Captiva(Short Body)	Body	Interior Lighting	✓	✓	✓	✓	✓	
2008	Antara,Captiva(Short Body)	Body	Exterior Lighting/Turn Indicator System	✓	✓	✓	✓	✓	
2008	Antara,Captiva(Short Body)	Body	SDM(Airbag)	✓	✓	✓	✓	✓	
2008	Antara,Captiva(Short Body)	Chassis	ABS/TC/ESP (Vehicle Dynamic System)	✓	✓	✓	✓	✓	0005 0006 0004
2008	Antara,Captiva(Short Body)	Engine	2.0 L (Diesel)	✓	✓	✓	✓	✓	0011 0012 0067 0021 0025 0013 0029 0026 0028 0030 0152
2008	Antara,Captiva(Short Body)	Engine	Z 24 XE	✓	✓	✓	✓	✓	0011 0034 0016
2008	Antara,Captiva(Short Body)	Engine	Z 32 SE	✓	✓	✓	✓	✓	0016 0019 0173
2008	Antara,Captiva(Short Body)	Transmission	TCCM(Transfer Case Control Module)	✓	✓	✓	✓	✓	0153
2008	Antara,Captiva(Short Body)	Transmission	Automatic Transmission	✓	✓	✓	✓	✓	0171 0155 0156 0157 0034
2008	Astra-G	Body	Immobiliser	✓	✓	✓	✓	✓	0140 0141
2008	Astra-G	Body	Instrument	✓	✓	✓	✓	✓	
2008	Astra-G	Body	Airbag	✓	✓	✓	✓	✓	
2008	Astra-G	Body	Anti Theft Warning	✓	✓	✓	✓	✓	
2008	Astra-G	Body	Central Door Lock	✓	✓	✓	✓	✓	
2008	Astra-G	Body	Headlamp Levelling Device	✓	✓	✓	✓	✓	0142
2008	Astra-G	Body	Electronic Climate Control	✓	✓	✓	✓	✓	
2008	Astra-G	Body	Engine Cooling Module	✓	✓	✓	✓	✓	
2008	Astra-G	Body	Add On Heater	✓	✓	✓	✓	✓	0123 0124
2008	Astra-G	Body	Softtop Controller	✓	✓	✓	✓	✓	
2008	Astra-G	Chassis	ABS-5.3/5.4(HTC)	✓	✓	✓	✓	✓	
2008	Astra-G	Chassis	ESP	✓	✓	✓	✓	✓	0006
2008	Astra-G	Chassis	Cruise Control	✓	✓	✓	✓	✓	
2008	Astra-G	Chassis	Electronic Power Steering	✓	✓	✓	✓	✓	
2008	Astra-G	Engine	Z12XE	✓	✓	✓	✓	✓	0007 0146 0010 0041 0020 0022 0012 0066 0034
2008	Astra-G	Engine	Z14XE	✓	✓	✓	✓	✓	0147 0146 0010 0020 0022 0012
2008	Astra-G	Engine	Z14XEP	✓	✓	✓	✓	✓	0034 0066 0007 0167 0010 0147 0020 0012 0022
2008	Astra-G	Engine	C16SEL	✓	✓	✓	✓	✓	
2008	Astra-G	Engine	Z16SE	✓	✓	✓	✓	✓	0007 0022 0012
2008	Astra-G	Engine	Z16XE	✓	✓	✓	✓	✓	0007 0022 0012
2008	Astra-G	Engine	Z16XEP	✓	✓	✓	✓	✓	0007 0147 0010 0020 0012 0022 0066

2008	Astra-G	Engine	Z16YNG	✓	✓	✓	✓	✓	0007 0147 0146 0010 0020 0012 0022
2008	Astra-G	Engine	Y17DT	✓	✓	✓	✓	✓	
2008	Astra-G	Engine	Z17DTL	✓	✓	✓	✓	✓	
2008	Astra-G	Engine	Z18XE	✓	✓	✓	✓	✓	0146 0010 0041 0020 0012 0022
2008	Astra-G	Engine	Z18XEL	✓	✓	✓	✓	✓	0012 0022
2008	Astra-G	Engine	Y20DTH	✓	✓	✓	✓	✓	0167 0168 0169 0170
2008	Astra-G	Engine	Z20LET	✓	✓	✓	✓	✓	0010 0020 0041 0146 0012 0022 0066 0034
2008	Astra-G	Engine	Y22DTR	✓	✓	✓	✓	✓	0012 0022
2008	Astra-G	Engine	Z22SE	✓	✓	✓	✓	✓	0066 0147 0146 0010 0012 0022 0034
2008	Astra-G	Transmission	AF 13-II/17/20/22	✓	✓	✓	✓	✓	
2008	Astra-G	Transmission	AF 13-II/17/20/22 CAN	✓	✓	✓	✓	✓	
2008	Astra-H	Body	SDM(Airbag)	✓	✓	✓	✓	✓	
2008	Astra-H	Body	CIM(Steering Column Module)	✓	✓	✓	✓	✓	0052 0004 0053 0002 0005 0054 0055 0006
2008	Astra-H	Body	IPC ECU(Instrument Control Unit)	✓	✓	✓	✓	✓	
2008	Astra-H	Body	REC(Rear Electrical Centre)	✓	✓	✓	✓	✓	
2008	Astra-H	Body	UEC(Underhood Electrical Centre)	✓	✓	✓	✓	✓	
2008	Astra-H	Body	AHL/AFL (Headlamp Levelling)	✓	✓	✓	✓	✓	
2008	Astra-H	Body	Exterior Lighting/Turn Indicator System	✓	✓	✓	✓	✓	
2008	Astra-H	Body	Interior Lighting	✓	✓	✓	✓	✓	
2008	Astra-H	Body	Wipers/Washer	✓	✓	✓	✓	✓	
2008	Astra-H	Body	Central Door Lock	✓	✓	✓	✓	✓	
2008	Astra-H	Body	Instrument	✓	✓	✓	✓	✓	0056 0057 0058
2008	Astra-H	Body	Immobiliser	✓	✓	✓	✓	✓	
2008	Astra-H	Body	Anti Theft Warning System	✓	✓	✓	✓	✓	
2008	Astra-H	Body	Electrohydraulic HardTop	✓	✓	✓	✓	✓	0002 0005
2008	Astra-H	Body	ECC/SAC (Electronic Climate Control)	✓	✓	✓	✓	✓	0151 0159 0160 0033 0002 0005 0161
2008	Astra-H	Body	EHS (Electrical Heater System)	✓	✓	✓	✓	✓	0033 0002 0005
2008	Astra-H	Body	PAS (Park Pilot)	✓	✓	✓	✓	✓	0002
2008	Astra-H	Body	SLM (Shift Lever Module)	✓	✓	✓	✓	✓	
2008	Astra-H	Body	PEPS (Open&Start)	✓	✓	✓	✓	✓	
2008	Astra-H	Body	IPC ECU(Instrument Control Unit)	✓	✓	✓	✓	✓	0007 0056 0057 0058 0059 0060 0061 0002 0005
2008	Astra-H	Chassis	ABS/TC/ESP ECU(Electronic Control Unit)	✓	✓	✓	✓	✓	0004 0005 0063
2008	Astra-H	Chassis	EHPS(Electrohydraulic Power Steering)	✓	✓	✓	✓	✓	
2008	Astra-H	Chassis	TPMS ECU(Tyre Pressure Monitoring)	✓	✓	✓	✓	✓	0002
2008	Astra-H	Chassis	TPMS(Tyre Pressure Monitoring System)	✓	✓	✓	✓	✓	
2008	Astra-H	Chassis	CDC(Continuous Damping Control)	✓	✓	✓	✓	✓	
2008	Astra-H	Chassis	ABS/TC/ESP(Vehicle Dynamic System)	✓	✓	✓	✓	✓	
2008	Astra-H	Chassis	EHPS(Electrohydraulic Power Steering)	✓	✓	✓	✓	✓	0004
2008	Astra-H	Engine	Z13DTH	✓	✓	✓	✓	✓	0007 0008 0009 0020 0011 0012 0067 0021 0030 0029 0026 0027 0019
2008	Astra-H	Engine	Z14XEL	✓	✓	✓	✓	✓	0007 0008 0009 0010 0011 0012 0067 0013 0014 0019
2008	Astra-H	Engine	Z14XEP	✓	✓	✓	✓	✓	0007 0008 0009 0010 0011 0012 0067 0013 0014 0019
2008	Astra-H	Engine	Z16XEP	✓	✓	✓	✓	✓	0007 0008 0009 0010 0020 0011 0012 0067 0013 0014 0034 0019
2008	Astra-H	Engine	Z16XER	✓	✓	✓	✓	✓	0020 0007 0008 0009 0010 0011 0012 0067 0034 0013 0019
2008	Astra-H	Engine	Z17DTH	✓	✓	✓	✓	✓	0007 0008 0009 0011 0012 0067 0021 0025 0013 0030 0033 0019
2008	Astra-H	Engine	Z17DTR	✓	✓	✓	✓	✓	0007 0008 0009 0020 0011 0012 0067 0015 0023 0024 0025 0013 0026 0027 0028 0029 0030 0021 0019
2008	Astra-H	Engine	Z17DTJ	✓	✓	✓	✓	✓	0007 0008 0009 0020 0011 0012 0067 0015 0023 0024 0025 0013 0026 0027 0028 0029 0030 0021 0019
2008	Astra-H	Engine	Z18XE	✓	✓	✓	✓	✓	0020 0007 0008 0009 0010 0011 0012 0067 0013 0019
2008	Astra-H	Engine	Z18XER	✓	✓	✓	✓	✓	0007 0008 0009 0010 0020 0011 0012 0067 0034 0013 0019
2008	Astra-H	Engine	Z19DT	✓	✓	✓	✓	✓	0007 0008 0009 0011 0012 0067 0024 0025 0070 0013 0033 0021 0030 0027 0028 0026 0029 0019
2008	Astra-H	Engine	Z19DTH	✓	✓	✓	✓	✓	0007 0008 0009 0011 0012 0067 0024 0025 0070 0013 0033 0021 0030 0027 0028 0026 0029 0019
2008	Astra-H	Engine	Z16LET	✓	✓	✓	✓	✓	0007 0008 0009 0010 0011 0012 0067 0013 0014 0019
2008	Astra-H	Engine	Z20LEH	✓	✓	✓	✓	✓	0007 0008 0009 0010 0011 0012 0067 0013 0014 0019
2008	Astra-H	Engine	Z22YH	✓	✓	✓	✓	✓	0007 0008 0009 0072 0020 0011 0012 0067 0013 0019
2008	Astra-H	Engine	Z17DTL	✓	✓	✓	✓	✓	0011 0012 0067 0021 0025 0013 0030 0033 0019
2008	Astra-H	Engine	Z16XE1	✓	✓	✓	✓	✓	0007 0008 0009 0010 0020 0011 0012 0067 0013 0014 0034 0019
2008	Astra-H	Engine	Z12XEP	✓	✓	✓	✓	✓	0007 0008 0009 0010 0011 0012 0067 0013 0014 0019
2008	Astra-H	Engine	Y13DTH	✓	✓	✓	✓	✓	0020 0011 0012 0067 0021 0030 0029 0026 0027 0019
2008	Astra-H	Engine	Z19DTJ	✓	✓	✓	✓	✓	0011 0012 0067 0024 0025 0070 0013 0033 0021 0030 0027 0028 0026 0029 0019
2008	Astra-H	Engine	Z20LEL	✓	✓	✓	✓	✓	0007 0008 0009 0010 0011 0012 0067 0013 0014 0019
2008	Astra-H	Engine	Z20LER	✓	✓	✓	✓	✓	0007 0008 0009 0010 0011 0012 0067 0013 0014 0019
2008	Astra-H	Engine	Engine(default)	✓	✓	✓	✓	✓	
2008	Astra-H	Transmission	AF 17-4	✓	✓	✓	✓	✓	0031 0032 0033 0004 0034
2008	Astra-H	Transmission	AF 40-6	✓	✓	✓	✓	✓	0073 0074 0075 0076 0077 0078 0033 0004 0034 0079
2008	Astra-H	Transmission	AF 22-4	✓	✓	✓	✓	✓	0031 0033 0004 0034

2008	Astra-H	Transmission	MTA(Easytronic)	✓	✓	✓	✓	✓	0004 0062 0035 0036
2008	Astra-H	Transmission	MTA(Easytronic Magneti Marelli)	✓	✓	✓	✓	✓	0004 0005 0062
2008	Captiva(Long Body)	Body	BCM (Body Control Module)	✓	✓	✓	✓	✓	
2008	Captiva(Long Body)	Body	ECC (Electronic Climate Control)	✓	✓	✓		✓	0151 0005
2008	Captiva(Long Body)	Body	Immobiliser	✓	✓	✓	✓		
2008	Captiva(Long Body)	Body	IPC ECU (Instrument Control Unit)	✓	✓	✓	✓	✓	
2008	Captiva(Long Body)	Body	XBCM(Auxiliary Body Control Module)	✓	✓	✓	✓	✓	
2008	Captiva(Long Body)	Body	RFA (Multipurpose Receiver Module)	✓	✓	✓	✓		
2008	Captiva(Long Body)	Chassis	ABS/TC/ESP (Vehicle Dynamic System)	✓	✓	✓	✓	✓	0005 0006 0004
2008	Captiva(Long Body)	Engine	2.0L(Diesel)	✓	✓	✓	✓	✓	0011 0012 0067 0021 0025 0013 0029 0026 0028 0030 0152
2008	Captiva(Long Body)	Engine	Z32SE	✓	✓	✓	✓	✓	
2008	Captiva(Long Body)	Transmission	TCCM(Transfer Case Control Module)	✓	✓	✓	✓		0153
2008	Captiva(Long Body)	Transmission	Automatic Transmission	✓	✓	✓	✓	✓	0171 0155 0156 0157 0034
2008	Corsa-C	Body	Body Control Module	✓	✓	✓	✓	✓	0052 0059 0139
2008	Corsa-C	Body	Immobiliser	✓	✓	✓	✓	✓	0140 0141
2008	Corsa-C	Body	Airbag	✓	✓	✓	✓	✓	
2008	Corsa-C	Body	Instrument	✓	✓	✓	✓	✓	0177 0178
2008	Corsa-C	Body	Add On Heater	✓	✓	✓	✓	✓	0123 0124
2008	Corsa-C	Body	HeadLamp Levelling Device	✓	✓	✓	✓	✓	0142
2008	Corsa-C	Chassis	ABS-5.3/5.4(+HC)	✓	✓	✓	✓	✓	
2008	Corsa-C	Chassis	ABS8/ESP8	✓	✓	✓	✓	✓	0006 0143 0144 0145 0005
2008	Corsa-C	Chassis	Electronic Power Steering	✓	✓	✓	✓	✓	0142
2008	Corsa-C	Engine	Z10XEP	✓	✓	✓	✓	✓	0012 0022 0066 0034
2008	Corsa-C	Engine	Z12XE	✓	✓	✓	✓	✓	0007 0146 0010 0041 0020 0022 0012 0066 0034
2008	Corsa-C	Engine	Z12XEP	✓	✓	✓	✓	✓	0012 0022 0066 0034
2008	Corsa-C	Engine	Y13DT	✓	✓	✓	✓	✓	0041 0020 0022 0012 0021
2008	Corsa-C	Engine	Z13DT	✓	✓	✓	✓	✓	0020 0041 0022 0012 0021
2008	Corsa-C	Engine	Z14XE	✓			✓	✓	0147 0146 0010 0020 0022 0012
2008	Corsa-C	Engine	Z14XEP	✓	✓	✓	✓	✓	0034 0066 0007 0167 0010 0147 0020 0012 0022
2008	Corsa-C	Engine	Z16SE	✓	✓	✓	✓	✓	0007 0022 0012
2008	Corsa-C	Engine	Z16YNG	✓	✓	✓	✓	✓	0007 0147 0146 0010 0020 0012 0022
2008	Corsa-C	Engine	Y17DT	✓	✓	✓	✓	✓	
2008	Corsa-C	Engine	Y17DTL	✓	✓	✓	✓	✓	0007 0022 0012
2008	Corsa-C	Engine	Z17DTH	✓	✓	✓	✓	✓	0007 0147 0020 0021 0148 0023 0012 0022
2008	Corsa-C	Engine	Z18XE	✓	✓	✓	✓	✓	0146 0010 0041 0020 0012 0022
2008	Corsa-C	Engine	Z13DTJ	✓	✓	✓	✓	✓	0041 0020 0029 0026 0042 0022 0012 0021 0043
2008	Corsa-C	Transmission	AF 13-II/17/20/22 CAN	✓	✓	✓	✓	✓	0012 0149
2008	Corsa-C	Transmission	MTA(Easytronic)	✓	✓	✓	✓	✓	
2008	Corsa-D	Body	SDM(Airbag)	✓	✓	✓	✓	✓	0000 0001 0002 0003
2008	Corsa-D	Body	IPC(Instrument)	✓	✓	✓	✓	✓	0007 0056 0057 0058 0002 0005
2008	Corsa-D	Body	Central Door Lock	✓	✓	✓	✓	✓	
2008	Corsa-D	Body	Exterior Lighting	✓	✓	✓	✓	✓	
2008	Corsa-D	Body	Interior Lighting	✓	✓	✓	✓	✓	
2008	Corsa-D	Body	Wipers/Washer	✓	✓	✓	✓	✓	
2008	Corsa-D	Body	Anti Theft Warning System	✓	✓	✓	✓	✓	
2008	Corsa-D	Body	Immobiliser	✓	✓	✓	✓	✓	
2008	Corsa-D	Body	APL (Adaptive Forward Lighting)	✓	✓	✓	✓	✓	
2008	Corsa-D	Body	EHS (Electrical Heater System)	✓	✓	✓	✓	✓	
2008	Corsa-D	Body	IPC ECU (Instrument Control Unit)	✓	✓	✓	✓	✓	0007 0056 0057 0058 0002 0005
2008	Corsa-D	Body	PAS (Park Pilot)	✓	✓	✓	✓	✓	
2008	Corsa-D	Body	TIM(Trailer Interface Module)	✓	✓	✓	✓	✓	
2008	Corsa-D	Body	SDM(Airbag)	✓	✓	✓	✓	✓	0000 0001 0002 0003
2008	Corsa-D	Chassis	ABS/ESP	✓	✓	✓	✓	✓	0004 0005 0179 0063
2008	Corsa-D	Chassis	Electronic Power Steering	✓	✓	✓	✓	✓	0004 0005 0006
2008	Corsa-D	Engine	Z10XEP	✓	✓	✓	✓	✓	0007 0008 0009 0010 0011 0012 0013 0014 0015
2008	Corsa-D	Engine	Z12XEP	✓	✓	✓	✓	✓	0007 0008 0009 0010 0011 0012 0013 0014 0015
2008	Corsa-D	Engine	Z13DTJ	✓	✓	✓	✓	✓	0020 0011 0012 0015 0021
2008	Corsa-D	Engine	Z13DTH	✓	✓	✓	✓	✓	0020 0011 0012 0015 0021
2008	Corsa-D	Engine	Z14XEP	✓	✓	✓	✓	✓	0007 0008 0009 0010 0011 0012 0013 0014 0015
2008	Corsa-D	Engine	Z17DTR	✓	✓	✓	✓	✓	0020 0022 0012 0015 0023 0024 0025 0013 0026 0027 0028 0029 0021 0030
2008	Corsa-D	Engine	Z16LEL	✓	✓	✓	✓	✓	0010 0011 0012 0067 0013 0014 0015
2008	Corsa-D	Engine	Z16LER	✓	✓	✓	✓	✓	0010 0011 0012 0067 0013 0014 0015
2008	Corsa-D	Engine	Engine(default)	✓	✓	✓	✓	✓	
2008	Corsa-D	Transmission	MTA(Easytronic Magneti Marelli)	✓	✓	✓	✓	✓	0004 0005 0062
2008	Corsa-D	Transmission	AF 13-4	✓	✓	✓	✓	✓	0031 0032 0033 0034
2008	Corsa-D	Transmission	MTA(Easytronic)	✓	✓	✓	✓	✓	0035 0036
2008	Meriva	Body	Body Control Module	✓	✓	✓	✓	✓	0052 0059 0139
2008	Meriva	Body	Immobiliser	✓	✓	✓	✓	✓	0140 0141
2008	Meriva	Body	Airbag	✓	✓	✓	✓	✓	
2008	Meriva	Body	Instrument	✓	✓	✓	✓	✓	0177 0178
2008	Meriva	Body	Headlamp Levelling Device	✓	✓	✓	✓	✓	0142
2008	Meriva	Body	Electronic Climate Control	✓	✓	✓	✓	✓	
2008	Meriva	Body	EHS (Electrical Heater System)	✓	✓	✓	✓	✓	
2008	Meriva	Body	Add On Heater	✓	✓	✓	✓	✓	0123 0124
2008	Meriva	Chassis	ABS8/ESP8	✓	✓	✓	✓	✓	0006 0143 0144 0145 0005
2008	Meriva	Chassis	Electronic Power Steering	✓	✓	✓	✓	✓	0142
2008	Meriva	Engine	Y13DT	✓	✓	✓	✓	✓	0041 0020 0022 0012 0021
2008	Meriva	Engine	Z14XEP	✓	✓	✓	✓	✓	0034 0066 0007 0167 0010 0147 0020 0012 0022

2008	Meriva	Engine	Z16SE	✓	✓	✓	✓	✓	0007 0022 0012
2008	Meriva	Engine	Z16XE	✓			✓	✓	0007 0022 0012
2008	Meriva	Engine	Z16XEP	✓	✓	✓	✓	✓	0007 0147 0010 0020 0012 0022 0066
2008	Meriva	Engine	Y17DT	✓	✓	✓	✓	✓	
2008	Meriva	Engine	Z17DTH	✓		✓	✓	✓	0007 0147 0020 0021 0148 0023 0012 0022
2008	Meriva	Engine	Z18XE	✓	✓	✓	✓	✓	0146 0010 0041 0020 0012 0022
2008	Meriva	Engine	Z13DT	✓	✓	✓	✓	✓	0041 0020 0022 0012 0021
2008	Meriva	Engine	Z13DTJ	✓	✓	✓	✓	✓	0041 0020 0029 0026 0042 0022 0012 0021 0043
2008	Meriva	Engine	Z16LET	✓	✓	✓	✓	✓	0007 0147 0010 0020 0012 0022 0066
2008	Meriva	Engine	Z16YNG	✓	✓	✓	✓	✓	0007 0147 0146 0010 0020 0012 0022
2008	Meriva	Engine	C16SEL	✓	✓	✓	✓	✓	
2008	Meriva	Engine	Z17DT	✓	✓	✓	✓	✓	0007 0147 0020 0023 0012 0022 0021 0148
2008	Meriva	Engine	Z17DTR	✓	✓	✓	✓	✓	
2008	Meriva	Transmission	MTA(Easytronic)	✓	✓	✓	✓	✓	0012 0149
2008	Movano	Body	Airbag	✓	✓	✓	✓	✓	
2008	Movano	Body	Body Control Module	✓	✓	✓	✓	✓	0052 0059 0139
2008	Movano	Body	Park Pilot	✓	✓	✓	✓	✓	
2008	Movano	Chassis	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)		✓	✓	✓	✓	0165 0166
2008	Movano	Chassis	Pneumatic Suspension		✓	✓	✓	✓	
2008	Movano	Transmission	MTA(Tecshift)		✓	✓	✓	✓	
2008	Tigra-B	Body	Body Control Module	✓	✓	✓	✓	✓	0052 0059 0139
2008	Tigra-B	Body	Immobiliser	✓	✓	✓	✓	✓	0140 0141
2008	Tigra-B	Body	Airbag	✓	✓	✓	✓	✓	
2008	Tigra-B	Body	Instrument	✓	✓	✓	✓	✓	0177 0178
2008	Tigra-B	Body	Electrohydraulic HardTop	✓	✓	✓	✓	✓	
2008	Tigra-B	Chassis	ABS/ESP8	✓	✓	✓	✓	✓	0006 0143 0144 0145 0005
2008	Tigra-B	Chassis	Electronic Power Steering	✓	✓	✓	✓	✓	0142
2008	Tigra-B	Engine	Z13DT	✓	✓	✓	✓	✓	0020 0041 0022 0012 0021
2008	Tigra-B	Engine	Z14XEP	✓	✓	✓	✓	✓	0034 0066 0007 0167 0010 0147 0020 0012 0022
2008	Tigra-B	Engine	Z18XE	✓	✓	✓	✓	✓	0146 0010 0041 0020 0012 0022
2008	Tigra-B	Transmission	MTA(Easytronic)	✓	✓	✓	✓	✓	0012 0149
2008	Vauxhall VX88	Body	AHL(Automatic Headlamp Levelling)	✓	✓	✓	✓	✓	
2008	Vauxhall VX88	Body	BCM(Body Control Module)	✓	✓	✓	✓	✓	
2008	Vauxhall VX88	Body	HVAC(Heating Ventilation and Cooling)	✓	✓	✓	✓	✓	
2008	Vauxhall VX88	Body	Immobiliser	✓	✓	✓	✓	✓	
2008	Vauxhall VX88	Body	MSM(Memory Seat and Mirrors)	✓	✓	✓	✓	✓	
2008	Vauxhall VX88	Body	Park Assist	✓	✓	✓	✓	✓	
2008	Vauxhall VX88	Body	SDM(Sensing and Diagnostic Module)	✓	✓	✓	✓	✓	
2008	Vauxhall VX88	Body	IPC(Instrument Panel Cluster)	✓	✓	✓	✓	✓	
2008	Vauxhall VX88	Body	RFA(Multipurpose Receiver Module)	✓	✓	✓	✓	✓	
2008	Vauxhall VX88	Chassis	EBCM(Electronic Brake Control Module)	✓	✓	✓	✓	✓	
2008	Vauxhall VX88	Chassis	ESC(Electronic Suspension Control)	✓	✓	✓	✓	✓	
2008	Vauxhall VX88	Engine	V8 GEN IV	✓	✓	✓	✓	✓	0016 0150 0172 0173
2008	Vauxhall VX88	Transmission	Automatic Transmission	✓	✓	✓	✓	✓	
2008	Vectra-C/Signum	Body	SDM(Airbag,Sensing&Diagnostic Module)	✓	✓	✓	✓	✓	0000 0001 0002 0003
2008	Vectra-C/Signum	Body	Instrument	✓	✓	✓	✓	✓	0170 0057 0058 0181 0002
2008	Vectra-C/Signum	Body	CIM(Steering Column Module)	✓	✓	✓	✓	✓	0052 0004 0053 0002 0005 0054 0055 0006
2008	Vectra-C/Signum	Body	BCM(Body Control Module)	✓	✓	✓	✓	✓	0182 0183
2008	Vectra-C/Signum	Body	DDM(Driver Door Module)	✓	✓	✓	✓	✓	
2008	Vectra-C/Signum	Body	PDM(Passenger Door Module)	✓	✓	✓	✓	✓	
2008	Vectra-C/Signum	Body	REC(Rear Electrical Centre)	✓	✓	✓	✓	✓	
2008	Vectra-C/Signum	Body	UEC(Underhood Electrical Centre)	✓	✓	✓	✓	✓	
2008	Vectra-C/Signum	Body	SLM(Shift Lever Module)	✓	✓	✓	✓	✓	
2008	Vectra-C/Signum	Body	SRM(Sun Roof Module)	✓	✓	✓	✓	✓	
2008	Vectra-C/Signum	Body	AHL/AFL(Headlamp Levelling)	✓	✓	✓	✓	✓	
2008	Vectra-C/Signum	Body	Electrical Horn	✓	✓	✓	✓	✓	
2008	Vectra-C/Signum	Body	SAC (Automatic Climate Control)	✓	✓	✓	✓	✓	0151 0159 0160 0002 0005 0161
2008	Vectra-C/Signum	Body	Interior Lighting	✓	✓	✓	✓	✓	0184 0060
2008	Vectra-C/Signum	Body	Electronic Seat Memory/Seat Heating	✓	✓	✓	✓	✓	
2008	Vectra-C/Signum	Body	Anti Theft Warning System	✓	✓	✓	✓	✓	
2008	Vectra-C/Signum	Body	Central Door Lock	✓	✓	✓	✓	✓	
2008	Vectra-C/Signum	Body	EHS (Electrical Heater System)	✓	✓	✓	✓	✓	0033 0002 0005
2008	Vectra-C/Signum	Body	PAS (Park Pilot)	✓	✓	✓	✓	✓	0002
2008	Vectra-C/Signum	Chassis	ABS/TC/ESP	✓	✓	✓	✓	✓	0026
2008	Vectra-C/Signum	Chassis	EHPS(Electronic Power Steering)	✓	✓	✓	✓	✓	0027
2008	Vectra-C/Signum	Chassis	TPMS (Tyre Pressure Monitoring System)	✓	✓	✓	✓	✓	0021
2008	Vectra-C/Signum	Chassis	CDC(Continuous Damping Control)	✓	✓	✓	✓	✓	0013
2008	Vectra-C/Signum	Chassis	Electronic Cruise Control	✓	✓	✓	✓	✓	
2008	Vectra-C/Signum	Engine	Engine Cooling	✓	✓	✓	✓	✓	
2008	Vectra-C/Signum	Engine	Z16XEP	✓	✓	✓	✓	✓	0011 0012 0067 0014 0150
2008	Vectra-C/Signum	Engine	Z18XE	✓	✓	✓	✓	✓	0020 0011 0012 0067 0150 0013
2008	Vectra-C/Signum	Engine	Z18XER	✓	✓	✓	✓	✓	0020 0010 0011 0012 0067 0150 0034 0013
2008	Vectra-C/Signum	Engine	Z19DT	✓	✓	✓	✓	✓	0150 0011 0012 0067 0024 0025 0070 0021 0013 0027 0030
2008	Vectra-C/Signum	Engine	Z19DTH	✓	✓	✓	✓	✓	0150 0011 0012 0067 0024 0025 0029 0026 0027 0021 0013 0028 0030
2008	Vectra-C/Signum	Engine	Y20DTH	✓	✓	✓	✓	✓	0011 0012 0067 0150
2008	Vectra-C/Signum	Engine	Y22DTR	✓	✓	✓	✓	✓	0011 0012 0067 0150
2008	Vectra-C/Signum	Engine	Z22SE	✓	✓	✓	✓	✓	0011 0012 0067 0150
2008	Vectra-C/Signum	Engine	Z22YH	✓	✓	✓	✓	✓	0024
2008	Vectra-C/Signum	Engine	Z32SE	✓	✓	✓	✓	✓	0020 0011 0012 0067 0150
2008	Vectra-C/Signum	Engine	Z30DT	✓	✓	✓	✓	✓	0020 0011 0067 0030
2008	Vectra-C/Signum	Engine	Z28NEH	✓	✓	✓	✓	✓	0010 0020 0041 0185 0186 0187 0012 0067 0150
2008	Vectra-C/Signum	Engine	Z28NEL	✓	✓	✓	✓	✓	0010 0020 0041 0184 0185 0186 0012 0067 0150
2008	Vectra-C/Signum	Engine	Z28NET	✓	✓	✓	✓	✓	0010 0020 0041 0184 0185 0186 0012 0067 0150
2008	Vectra-C/Signum	Engine	Z16XE	✓	✓	✓	✓	✓	0011 0012 0067 0150 0013

2008	Vectra-C/Signum	Engine	Z20NET	✓	✓	✓	✓	✓	0011 0012 0067 0150
2008	Vectra-C/Signum	Engine	Engine(default)	✓	✓	✓			
2008	Vectra-C/Signum	Transmission	AF 23-5/33-5/40-6	✓	✓	✓	✓	✓	0033 0034
2008	Vectra-C/Signum	Transmission	CVTronic	✓	✓	✓	✓	✓	0188 0189 0190 0033 0004 0034
2008	Vectra-C/Signum	Transmission	MTA(Easytronic)	✓	✓	✓	✓	✓	
2008	Vivaro	Body	Airbag		✓	✓	✓		0005
2008	Vivaro	Body	Park Pilot		✓	✓	✓		
2008	Vivaro	Body	Add On Heater	✓	✓	✓	✓	✓	0123 0124
2008	Vivaro	Body	Body Control Module		✓	✓	✓	✓	
2008	Vivaro	Chassis	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)	✓	✓	✓	✓	✓	0175 0176
2008	Vivaro	Engine	F9Q 760/762 (1.9L)	✓	✓	✓	✓	✓	
2008	Vivaro	Transmission	MTA(Tecshift)	✓	✓	✓	✓	✓	
2008	Zafira-B	Body	SDM(Airbag)	✓	✓	✓	✓	✓	0000 0001 0002 0003
2008	Zafira-B	Body	CIM(Steering Column Module)	✓	✓	✓	✓	✓	0052 0004 0053 0002 0005 0054 0055 0006
2008	Zafira-B	Body	IPC ECU(Instrument Control Unit)	✓	✓	✓	✓		
2008	Zafira-B	Body	REC(Rear Electrical Centre)	✓	✓	✓	✓		
2008	Zafira-B	Body	UEC(Underhood Electrical Centre)	✓	✓	✓	✓		
2008	Zafira-B	Body	AHL/APL(Headlamp Levelling)	✓	✓	✓	✓		
2008	Zafira-B	Body	Exterior Lighting/Turn Indicator System	✓	✓	✓	✓		
2008	Zafira-B	Body	Interior Lighting	✓	✓	✓	✓		
2008	Zafira-B	Body	Wipers/Washer	✓	✓	✓	✓		
2008	Zafira-B	Body	Central Door Lock	✓	✓	✓	✓		
2008	Zafira-B	Body	Instrument	✓	✓	✓	✓	✓	0056 0057 0058
2008	Zafira-B	Body	Immobiliser	✓	✓	✓	✓		
2008	Zafira-B	Body	ECC/SAC(Electronic Climate Control)	✓	✓	✓	✓	✓	0151 0159 0160 0002 0005 0161
2008	Zafira-B	Body	EHS(Electrical Heater System)	✓	✓	✓	✓		0033 0002 0005
2008	Zafira-B	Body	PAS(Park Pilot)	✓	✓	✓	✓	✓	0002
2008	Zafira-B	Body	SLM(Shift Lever Module)	✓	✓	✓	✓		
2008	Zafira-B	Body	PEPS(Open&Start)	✓	✓	✓	✓		
2008	Zafira-B	Body	Anti Theft Warning System	✓	✓	✓	✓	✓	
2008	Zafira-B	Body	IPC ECU(Instrument Control Unit)	✓	✓	✓	✓	✓	0007 0056 0057 0058 0059 0060 0061 0002 0005
2008	Zafira-B	Chassis	ABS/TC/ESP ECU(Electronic Control Unit)	✓	✓	✓	✓	✓	0004 0005 0063
2008	Zafira-B	Chassis	EHPS(Electrohydraulic Power Steering)	✓	✓	✓	✓		
2008	Zafira-B	Chassis	TPMS ECU(Tyre Pressure Monitoring)	✓	✓	✓	✓		0002
2008	Zafira-B	Chassis	TPMS(Tyre Pressure Monitoring System)	✓	✓	✓	✓		
2008	Zafira-B	Chassis	ABS/TC/ESP(Vehicle Dynamic System)	✓	✓	✓	✓	✓	0004 0005 0063
2008	Zafira-B	Chassis	CDC(Continuous Damping Control)	✓	✓	✓	✓		
2008	Zafira-B	Chassis	EHPS(Electrohydraulic Power Steering)	✓	✓	✓	✓		0004
2008	Zafira-B	Engine	Z16XEP	✓	✓	✓	✓		0007 0008 0009 0010 0020 0011 0012 0067 0013 0014 0034 0019
2008	Zafira-B	Engine	Z16XER	✓	✓	✓	✓		0020 0007 0008 0009 0010 0011 0012 0067 0034 0013 0019
2008	Zafira-B	Engine	Z18XER	✓	✓	✓	✓		0020 0007 0008 0009 0010 0011 0012 0067 0034 0013 0019
2008	Zafira-B	Engine	Z19DT	✓	✓	✓	✓	✓	0007 0008 0009 0011 0012 0067 0024 0025 0070 0013 0033 0021 0030 0027 0028 0026 0029 0019
2008	Zafira-B	Engine	Z19DTH	✓	✓	✓	✓	✓	0007 0008 0009 0033 0011 0012 0067 0024 0025 0029 0026 0027 0028
2008	Zafira-B	Engine	Z16YNG	✓	✓	✓	✓	✓	0007 0008 0009 0010 0020 0011 0012 0067 0013 0014 0034 0019
2008	Zafira-B	Engine	Z22YH	✓	✓	✓	✓	✓	0007 0008 0009 0072 0020 0011 0012 0067 0013 0014 0019
2008	Zafira-B	Engine	Z20LER	✓	✓	✓	✓	✓	0007 0008 0009 0010 0011 0012 0067 0013 0014 0019
2008	Zafira-B	Engine	Z20LEH	✓	✓	✓	✓	✓	0007 0008 0009 0010 0011 0012 0067 0013 0014 0019
2008	Zafira-B	Engine	Z16XE1	✓	✓	✓	✓	✓	0007 0008 0009 0010 0174 0011 0012 0067 0013 0014 0034 0019
2008	Zafira-B	Engine	Engine(default)	✓	✓	✓			
2008	Zafira-B	Transmission	MTA(Easutronic)	✓	✓	✓	✓	✓	0004 0062 0035 0036
2008	Zafira-B	Transmission	AF 40-6	✓	✓	✓	✓	✓	0073 0074 0075 0076 0077 0078 0033 0004 0034 0079
2008	Zafira-B	Transmission	AF 22-4	✓	✓	✓	✓	✓	0031 0033 0004 0034
2007	Agila	Body	Immobiliser	✓	✓	✓	✓		0140 0141
2007	Agila	Body	Airbag	✓	✓	✓	✓		
2007	Agila	Body	Instrument	✓	✓	✓	✓		
2007	Agila	Chassis	ABS	✓	✓	✓	✓		
2007	Agila	Chassis	Electronic Power Steering	✓	✓	✓	✓		
2007	Agila	Engine	Z10XEP	✓	✓	✓	✓	✓	0012 0022 0066 0034
2007	Agila	Engine	Z12XE	✓	✓	✓	✓	✓	0007 0146 0010 0041 0020 0022 0012 0066 0034
2007	Agila	Engine	Z12XEP	✓	✓	✓	✓	✓	0012 0022 0066 0034
2007	Agila	Engine	Z13DT	✓	✓	✓	✓	✓	0020 0041 0022 0012 0021
2007	Antara,Captiva(Short Body)	Body	AHL(Automatic Headlamp Levelling)	✓	✓	✓	✓	✓	0142
2007	Antara,Captiva(Short Body)	Body	Anti Theft Warning System	✓	✓	✓	✓	✓	
2007	Antara,Captiva(Short Body)	Body	BCM(Body Control Module)	✓	✓	✓	✓	✓	
2007	Antara,Captiva(Short Body)	Body	ECC(Electronic Climate Control)	✓	✓	✓	✓	✓	0151 0005
2007	Antara,Captiva(Short Body)	Body	Immobiliser	✓	✓	✓	✓		
2007	Antara,Captiva(Short Body)	Body	IPC ECU(Instrument Control Unit)	✓	✓	✓	✓	✓	
2007	Antara,Captiva(Short Body)	Body	Wipers/Washer	✓	✓	✓	✓		
2007	Antara,Captiva(Short Body)	Body	PAS(Park Pilot)	✓	✓	✓	✓	✓	0058
2007	Antara,Captiva(Short Body)	Body	XBCM(Auxiliary Body Control Module)	✓	✓	✓	✓	✓	
2007	Antara,Captiva(Short Body)	Body	Central Door Lock	✓	✓	✓	✓	✓	

2007	Antara, Captiva (Short Body)	Body	RFA (Multipurpose Receiver Module)	✓	✓	✓	✓		
2007	Antara, Captiva (Short Body)	Body	SLM (Shift Lever Module)	✓	✓	✓	✓		
2007	Antara, Captiva (Short Body)	Body	HVAC (Heating Ventilation and Cooling)	✓	✓	✓	✓		
2007	Antara, Captiva (Short Body)	Body	Interior Lighting	✓	✓	✓	✓		
2007	Antara, Captiva (Short Body)	Body	Exterior Lighting/Turn Indicator System	✓	✓	✓	✓		
2007	Antara, Captiva (Short Body)	Body	SDM (Airbag)	✓	✓	✓	✓		
2007	Antara, Captiva (Short Body)	Chassis	ABS/TC/ESP (Vehicle Dynamic System)	✓	✓	✓	✓	✓	0005 0006 0004
2007	Antara, Captiva (Short Body)	Engine	2.0L (Diesel)	✓	✓	✓	✓	✓	0011 0012 0067 0021 0025 0013 0029 0026 0028 0030 0152
2007	Antara, Captiva (Short Body)	Engine	Z24XE	✓	✓	✓	✓	✓	0011 0034 0016
2007	Antara, Captiva (Short Body)	Engine	Z32SE	✓	✓	✓	✓	✓	0016 0019 0173
2007	Antara, Captiva (Short Body)	Transmission	TCCM (Transfer Case Control Module)	✓	✓	✓	✓		0153
2007	Antara, Captiva (Short Body)	Transmission	Automatic Transmission	✓	✓	✓	✓	✓	0171 0155 0156 0157 0034
2007	Astra-G	Body	Immobiliser	✓	✓	✓	✓		0140 0141
2007	Astra-G	Body	Instrument	✓	✓	✓	✓		
2007	Astra-G	Body	Airbag	✓	✓	✓	✓		
2007	Astra-G	Body	Anti Theft Warning	✓	✓	✓	✓		
2007	Astra-G	Body	Central Door Lock	✓	✓	✓	✓		
2007	Astra-G	Body	Headlamp Levelling Device	✓	✓	✓	✓	✓	0142
2007	Astra-G	Body	Electronic Climate Control	✓	✓	✓	✓		
2007	Astra-G	Body	Engine Cooling Module	✓	✓	✓	✓		
2007	Astra-G	Body	Add On Heater	✓	✓	✓	✓	✓	0123 0124
2007	Astra-G	Body	Softtop Controller	✓	✓	✓	✓	✓	
2007	Astra-G	Chassis	ABS-5.3/5.4(+TC)	✓	✓	✓	✓	✓	
2007	Astra-G	Chassis	ESP	✓	✓	✓	✓	✓	0006
2007	Astra-G	Chassis	Cruise Control	✓	✓	✓	✓		
2007	Astra-G	Chassis	Electronic Power Steering	✓	✓	✓	✓	✓	
2007	Astra-G	Engine	Z12XE	✓	✓	✓	✓	✓	0007 0146 0010 0041 0020 0022 0012 0066 0034
2007	Astra-G	Engine	Z14XE	✓	✓	✓	✓	✓	0147 0146 0010 0020 0022 0012
2007	Astra-G	Engine	Z14XEP	✓	✓	✓	✓	✓	0034 0066 0007 0167 0010 0147 0020 0012 0022
2007	Astra-G	Engine	C16SEL	✓	✓	✓	✓	✓	
2007	Astra-G	Engine	Z16SE	✓	✓	✓	✓	✓	0007 0022 0012
2007	Astra-G	Engine	Z16XE	✓	✓	✓	✓	✓	0007 0022 0012
2007	Astra-G	Engine	Z16XEP	✓	✓	✓	✓	✓	0007 0147 0010 0020 0012 0022 0066
2007	Astra-G	Engine	Z16YNG	✓	✓	✓	✓	✓	0007 0147 0146 0010 0020 0012 0022
2007	Astra-G	Engine	Y17DT	✓	✓	✓	✓	✓	
2007	Astra-G	Engine	Z17DTL	✓	✓	✓	✓	✓	
2007	Astra-G	Engine	Z18XE	✓	✓	✓	✓	✓	0146 0010 0041 0020 0012 0022
2007	Astra-G	Engine	Z18XEL	✓	✓	✓	✓		0012 0022
2007	Astra-G	Engine	Y20DTH	✓	✓	✓	✓	✓	0167 0168 0169 0170
2007	Astra-G	Engine	Z20LET	✓	✓	✓	✓	✓	0010 0020 0041 0146 0012 0022 0066 0034
2007	Astra-G	Engine	Y22DTR	✓	✓	✓	✓	✓	0012 0022
2007	Astra-G	Engine	Z22SE	✓	✓	✓	✓	✓	0066 0147 0146 0010 0012 0022 0034
2007	Astra-G	Transmission	AF 13-II/17/20/22	✓	✓	✓	✓	✓	
2007	Astra-G	Transmission	AF 13-II/17/20/22 CAN	✓	✓	✓	✓	✓	
2007	Astra-H	Body	SDM (Airbag)	✓	✓	✓	✓		
2007	Astra-H	Body	CIW (Steering Column Module)	✓	✓	✓	✓	✓	0052 0004 0053 0002 0005 0054 0055 0006
2007	Astra-H	Body	IPC ECU (Instrument Control Unit)	✓	✓	✓	✓	✓	
2007	Astra-H	Body	REC (Rear Electrical Centre)	✓	✓	✓	✓		
2007	Astra-H	Body	UEC (Underhood Electrical Centre)	✓	✓	✓	✓		
2007	Astra-H	Body	AHL/AFL (Headlamp Levelling)	✓	✓	✓	✓		
2007	Astra-H	Body	Exterior Lighting/Turn Indicator System	✓	✓	✓	✓		
2007	Astra-H	Body	Interior Lighting	✓	✓	✓	✓		
2007	Astra-H	Body	Wipers/Washer	✓	✓	✓	✓		
2007	Astra-H	Body	Central Door Lock	✓	✓	✓	✓		
2007	Astra-H	Body	Instrument	✓	✓	✓	✓	✓	0056 0057 0058
2007	Astra-H	Body	Immobiliser	✓	✓	✓	✓		
2007	Astra-H	Body	Anti Theft Warning System	✓	✓	✓	✓	✓	
2007	Astra-H	Body	Electrohydraulic HardTop	✓	✓	✓	✓		0002 0005
2007	Astra-H	Body	ECC/SAC (Electronic Climate Control)	✓	✓	✓	✓	✓	0151 0159 0160 0033 0002 0005 0161
2007	Astra-H	Body	EHS (Electrical Heater System)	✓	✓	✓	✓		0033 0002 0005
2007	Astra-H	Body	PAS (Park Pilot)	✓	✓	✓	✓	✓	0002
2007	Astra-H	Body	SLM (Shift Lever Module)	✓	✓	✓	✓		
2007	Astra-H	Body	PEPS (Open&Start)	✓	✓	✓	✓		
2007	Astra-H	Body	IPC ECU (Instrument Control Unit)	✓	✓	✓	✓	✓	0007 0056 0057 0058 0059 0060 0061 0002 0005
2007	Astra-H	Chassis	ABS/TC/ESP ECU (Electronic Control Unit)	✓	✓	✓	✓	✓	0004 0005 0063
2007	Astra-H	Chassis	EHPS (Electrohydraulic Power Steering)	✓	✓	✓	✓		
2007	Astra-H	Chassis	TPMS ECU (Tyre Pressure Monitoring)	✓	✓	✓	✓		0002
2007	Astra-H	Chassis	TPMS (Tyre Pressure Monitoring System)	✓	✓	✓	✓		
2007	Astra-H	Chassis	CDC (Continuous Damping Control)	✓	✓	✓	✓		
2007	Astra-H	Chassis	ABS/TC/ESP (Vehicle Dynamic System)	✓	✓	✓	✓	✓	
2007	Astra-H	Chassis	EHPS (Electrohydraulic Power Steering)	✓	✓	✓	✓		0004
2007	Astra-H	Engine	Z13DTH	✓	✓	✓	✓	✓	0007 0008 0009 0020 0011 0012 0067 0021 0030 0029 0026 0027 0019
2007	Astra-H	Engine	Z14XEL	✓	✓	✓	✓	✓	0007 0008 0009 0010 0011 0012 0067 0013 0014 0019
2007	Astra-H	Engine	Z14XEP	✓	✓	✓	✓	✓	0007 0008 0009 0010 0011 0012 0067 0013 0014 0019
2007	Astra-H	Engine	Z16XEP	✓	✓	✓	✓		0007 0008 0009 0010 0020 0011 0012 0067 0013 0014 0034 0019

2007	Astra-H	Engine	Z16XER	✓	✓	✓	✓		0020 0007 0008 0009 0010 0011 0012 0067 0034 0013 0019
2007	Astra-H	Engine	Z17DTH	✓	✓	✓	✓	✓	0007 0008 0009 0011 0012 0067 0021 0025 0013 0030 0033 0019
2007	Astra-H	Engine	Z17DTR	✓	✓	✓	✓	✓	0007 0008 0009 0020 0011 0012 0067 0015 0023 0024 0025 0013 0026 0027 0028 0029 0030 0021 0019
2007	Astra-H	Engine	Z17DTJ	✓	✓	✓	✓	✓	0007 0008 0009 0020 0011 0012 0067 0015 0023 0024 0025 0013 0026 0027 0028 0029 0030 0021 0019
2007	Astra-H	Engine	Z18XE	✓	✓	✓	✓		0020 0007 0008 0009 0010 0011 0012 0067 0013 0019
2007	Astra-H	Engine	Z18XER	✓	✓	✓	✓	✓	0007 0008 0009 0010 0020 0011 0012 0067 0034 0013 0019
2007	Astra-H	Engine	Z19DT	✓	✓	✓	✓	✓	0007 0008 0009 0011 0012 0067 0024 0025 0070 0013 0033 0021 0030 0027 0028 0026 0029 0019
2007	Astra-H	Engine	Z19DTH	✓	✓	✓	✓	✓	0007 0008 0009 0011 0012 0067 0024 0025 0070 0013 0033 0021 0030 0027 0028 0026 0029 0019
2007	Astra-H	Engine	Z12XEP	✓	✓	✓	✓	✓	0007 0008 0009 0010 0011 0012 0067 0013 0014 0019
2007	Astra-H	Engine	Y13DTH	✓	✓	✓	✓	✓	0020 0011 0012 0067 0021 0030 0029 0026 0027 0019
2007	Astra-H	Engine	Z16XE1	✓	✓	✓	✓	✓	0007 0008 0009 0010 0020 0011 0012 0067 0013 0014 0034 0019
2007	Astra-H	Engine	Z16LET	✓	✓	✓	✓	✓	0007 0008 0009 0010 0011 0012 0067 0013 0014 0019
2007	Astra-H	Engine	Z17DTL	✓	✓	✓	✓	✓	0011 0012 0067 0021 0025 0013 0030 0033 0019
2007	Astra-H	Engine	Z19DTJ	✓	✓	✓	✓	✓	0011 0012 0067 0024 0025 0070 0013 0033 0021 0030 0027 0028 0026 0029 0019
2007	Astra-H	Engine	Z20LEL	✓	✓	✓	✓	✓	0007 0008 0009 0010 0011 0012 0067 0013 0014 0019
2007	Astra-H	Engine	Z20LEH	✓	✓	✓	✓	✓	0007 0008 0009 0010 0011 0012 0067 0013 0014 0019
2007	Astra-H	Engine	Z20LER	✓	✓	✓	✓	✓	0007 0008 0009 0010 0011 0012 0067 0013 0014 0019
2007	Astra-H	Engine	Z22YH	✓	✓	✓	✓	✓	0007 0008 0009 0072 0020 0011 0012 0067 0013 0019
2007	Astra-H	Engine	Engine(default)	✓	✓	✓	✓		
2007	Astra-H	Infotainment System	EHU(Entertainment Head Unit)	✓	✓	✓	✓		
2007	Astra-H	Infotainment System	DIS(Info Display TID,BID,GID,CID)	✓	✓	✓	✓		
2007	Astra-H	Transmission	AF 17-4	✓	✓	✓	✓	✓	0031 0032 0033 0004 0034
2007	Astra-H	Transmission	AF 40-6	✓	✓	✓	✓	✓	0073 0074 0075 0076 0077 0078 0033 0004 0034 0079
2007	Astra-H	Transmission	AF 22-4	✓	✓	✓	✓	✓	0031 0033 0004 0034
2007	Astra-H	Transmission	MTA(Easytronic)	✓	✓	✓	✓	✓	0004 0062 0035 0036
2007	Astra-H	Transmission	MTA(Easytronic Magneti Marelli)	✓	✓	✓	✓	✓	0004 0005 0062
2007	Captiva(Long Body)	Body	BCM(Body Control Module)	✓	✓	✓	✓	✓	
2007	Captiva(Long Body)	Body	ECC(Electronic Climate Control)	✓	✓	✓	✓	✓	0151 0005
2007	Captiva(Long Body)	Body	Immobiliser	✓	✓	✓	✓		
2007	Captiva(Long Body)	Body	IPC ECU(Instrument Control Unit)	✓	✓	✓	✓	✓	
2007	Captiva(Long Body)	Body	XBCM(Auxiliary Body Control Module)	✓	✓	✓	✓	✓	
2007	Captiva(Long Body)	Body	RFA(Multipurpose Receiver Module)	✓	✓	✓	✓	✓	
2007	Captiva(Long Body)	Chassis	ABS/TC/ESP(Vehicle Dynamic System)	✓	✓	✓	✓	✓	0005 0006 0004
2007	Captiva(Long Body)	Engine	2.0L(Diesel)	✓	✓	✓	✓	✓	0011 0012 0067 0021 0025 0013 0029 0026 0028 0030 0152
2007	Captiva(Long Body)	Engine	Z32SE	✓	✓	✓	✓	✓	
2007	Captiva(Long Body)	Transmission	TCCM(Transfer Case Control Module)	✓	✓	✓	✓		0153
2007	Captiva(Long Body)	Transmission	Automatic Transmission	✓	✓	✓	✓	✓	0171 0155 0156 0157 0034
2007	Combo	Body	Add On Heater	✓	✓	✓	✓	✓	0123 0124
2007	Combo	Body	Airbag	✓	✓	✓	✓	✓	
2007	Combo	Body	Body Control Module	✓	✓	✓	✓	✓	0052 0059 0139
2007	Combo	Body	HeadLamp Levelling Device	✓	✓	✓	✓	✓	0142
2007	Combo	Body	Instrument	✓	✓	✓	✓	✓	
2007	Combo	Body	Immobiliser	✓	✓	✓	✓	✓	0165 0166
2007	Combo	Chassis	ABS8/ESP8(Anti-lock Braking System/Electronic Stability Program)	✓	✓	✓	✓	✓	0006 0143 0144 0145 0005
2007	Combo	Chassis	ABS-5.3/5.4 (+TC) (Anti-lock Braking System)	✓	✓	✓	✓	✓	
2007	Combo	Chassis	Electronic Power Steering	✓	✓	✓	✓	✓	0142
2007	Combo	Engine	Z10XEP	✓	✓	✓	✓	✓	0012 0022 0066 0034
2007	Combo	Engine	Z12XE	✓	✓	✓	✓	✓	0007 0146 0010 0041 0020 0022 0012 0066 0034
2007	Combo	Engine	Z12XEP	✓	✓	✓	✓	✓	0012 0022 0066 0034
2007	Combo	Engine	Y13DT	✓	✓	✓	✓	✓	0041 0020 0022 0012 0021
2007	Combo	Engine	Z13DT	✓	✓	✓	✓	✓	0041 0020 0022 0012 0021
2007	Combo	Engine	Z13DTJ	✓	✓	✓	✓	✓	0041 0020 0029 0026 0042 0022 0012 0021 0043
2007	Combo	Engine	Z14XE						
2007	Combo	Engine	Z14XEP	✓	✓	✓	✓	✓	0007 0167 0010 0147 0020 0012 0022 0066 0034
2007	Combo	Engine	Z16SE	✓	✓	✓	✓	✓	0007 0022 0012
2007	Combo	Engine	Z16YNG	✓	✓	✓	✓	✓	0007 0147 0146 0010 0020 0012 0022
2007	Combo	Engine	Y17DT	✓	✓	✓	✓	✓	
2007	Combo	Engine	Y17DTL	✓	✓	✓	✓	✓	0007 0022 0012
2007	Combo	Engine	Z17DTH	✓	✓	✓	✓	✓	

2007	Combo	Engine	Z18XE	✓	✓	✓	✓	✓	0146 0010 0041 0020 0012 0022
2007	Combo	Infotainment System	Trip Info Display TID	✓	✓	✓	✓	✓	
2007	Combo	Transmission	AF 13-II/17/20/22 CAN	✓	✓	✓	✓	✓	
2007	Combo	Transmission	Easytronic(MTA)	✓	✓	✓	✓	✓	0012 0149
2007	Corsa-C	Body	Body Control Module	✓	✓	✓	✓	✓	0052 0059 0139
2007	Corsa-C	Body	Immobiliser	✓	✓	✓	✓	✓	0140 0141
2007	Corsa-C	Body	Airbag	✓	✓	✓	✓	✓	
2007	Corsa-C	Body	Instrument	✓	✓	✓	✓	✓	0177 0178
2007	Corsa-C	Body	Add On Heater	✓	✓	✓	✓	✓	0123 0124
2007	Corsa-C	Body	HeadLamp Levelling Device	✓	✓	✓	✓	✓	0142
2007	Corsa-C	Chassis	ABS-5.3/5.4(+TC)	✓	✓	✓	✓	✓	
2007	Corsa-C	Chassis	ABS8/ESPS	✓	✓	✓	✓	✓	0006 0143 0144 0145 0005
2007	Corsa-C	Chassis	Electronic Power Steering	✓	✓	✓	✓	✓	0142
2007	Corsa-C	Engine	Z10XEP	✓	✓	✓	✓	✓	0012 0022 0066 0034
2007	Corsa-C	Engine	Z12XE	✓	✓	✓	✓	✓	0007 0146 0010 0041 0020 0022 0012 0066 0034
2007	Corsa-C	Engine	Z12XEP	✓	✓	✓	✓	✓	0012 0022 0066 0034
2007	Corsa-C	Engine	Y13DT	✓	✓	✓	✓	✓	0041 0020 0022 0012 0021
2007	Corsa-C	Engine	Z13DT	✓	✓	✓	✓	✓	0020 0041 0022 0012 0021
2007	Corsa-C	Engine	Z14XE	✓	✓	✓	✓	✓	0147 0146 0010 0020 0022 0012
2007	Corsa-C	Engine	Z14XEP	✓	✓	✓	✓	✓	0034 0066 0007 0167 0010 0147 0020 0012 0022
2007	Corsa-C	Engine	Z16SE	✓	✓	✓	✓	✓	0007 0022 0012
2007	Corsa-C	Engine	Z16YNG	✓	✓	✓	✓	✓	0007 0147 0146 0010 0020 0012 0022
2007	Corsa-C	Engine	Y17DT	✓	✓	✓	✓	✓	
2007	Corsa-C	Engine	Y17DTL	✓	✓	✓	✓	✓	0007 0022 0012
2007	Corsa-C	Engine	Z17DTH	✓	✓	✓	✓	✓	0007 0147 0020 0021 0148 0023 0012 0022
2007	Corsa-C	Engine	Z18XE	✓	✓	✓	✓	✓	0146 0010 0041 0020 0012 0022
2007	Corsa-C	Engine	Z13DTJ	✓	✓	✓	✓	✓	0041 0020 0029 0026 0042 0022 0012 0021 0043
2007	Corsa-C	Transmission	AF 13-II/17/20/22 CAN	✓	✓	✓	✓	✓	
2007	Corsa-C	Transmission	MTA(Easytronic)	✓	✓	✓	✓	✓	0012 0149
2007	Corsa-D	Body	SDM(Airbag)	✓	✓	✓	✓	✓	0000 0001 0002 0003
2007	Corsa-D	Body	IPC(Instrument)	✓	✓	✓	✓	✓	0007 0056 0057 0058 0002 0005
2007	Corsa-D	Body	Central Door Lock	✓	✓	✓	✓	✓	
2007	Corsa-D	Body	Exterior Lighting	✓	✓	✓	✓	✓	
2007	Corsa-D	Body	Interior Lighting	✓	✓	✓	✓	✓	
2007	Corsa-D	Body	Wipers/Washer	✓	✓	✓	✓	✓	
2007	Corsa-D	Body	Anti Theft Warning System	✓	✓	✓	✓	✓	
2007	Corsa-D	Body	Immobiliser	✓	✓	✓	✓	✓	
2007	Corsa-D	Body	AFL(Adaptive Forward Lighting)	✓	✓	✓	✓	✓	
2007	Corsa-D	Body	EHS(Electrical Heater System)	✓	✓	✓	✓	✓	
2007	Corsa-D	Body	IPC ECU(Instrument Control Unit)	✓	✓	✓	✓	✓	0007 0056 0057 0058 0002 0005
2007	Corsa-D	Body	PAS(Park Pilot)	✓	✓	✓	✓	✓	
2007	Corsa-D	Body	TIM(Trailer Interface Module)	✓	✓	✓	✓	✓	
2007	Corsa-D	Body	SDM(Airbag)	✓	✓	✓	✓	✓	0000 0001 0002 0003
2007	Corsa-D	Chassis	ABS/ESP	✓	✓	✓	✓	✓	0004 0005 0179 0063
2007	Corsa-D	Chassis	Electronic Power Steering	✓	✓	✓	✓	✓	0004 0005 0006
2007	Corsa-D	Engine	Z10XEP	✓	✓	✓	✓	✓	0007 0008 0009 0010 0011 0012 0013 0014 0015
2007	Corsa-D	Engine	Z12XEP	✓	✓	✓	✓	✓	0007 0008 0009 0010 0011 0012 0013 0014 0015
2007	Corsa-D	Engine	Z13DTJ	✓	✓	✓	✓	✓	0020 0011 0012 0015 0021
2007	Corsa-D	Engine	Z13DTH	✓	✓	✓	✓	✓	0020 0011 0012 0015 0021
2007	Corsa-D	Engine	Z14XEP	✓	✓	✓	✓	✓	0007 0008 0009 0010 0011 0012 0013 0014 0015
2007	Corsa-D	Engine	Z17DTR	✓	✓	✓	✓	✓	0020 0022 0012 0015 0023 0024 0025 0013 0026 0027 0028 0029 0021 0030
2007	Corsa-D	Engine	Z16LEL	✓	✓	✓	✓	✓	0010 0011 0012 0067 0013 0014 0015
2007	Corsa-D	Engine	Z16LER	✓	✓	✓	✓	✓	0010 0011 0012 0067 0013 0014 0015
2007	Corsa-D	Engine	Engine(default)	✓	✓	✓	✓	✓	
2007	Corsa-D	Transmission	AF 13-4	✓	✓	✓	✓	✓	0031 0032 0033 0034
2007	Corsa-D	Transmission	MTA(Easytronic)	✓	✓	✓	✓	✓	0035 0036
2007	Meriva	Body	Body Control Module	✓	✓	✓	✓	✓	0052 0059 0139
2007	Meriva	Body	Immobiliser	✓	✓	✓	✓	✓	0140 0141
2007	Meriva	Body	Airbag	✓	✓	✓	✓	✓	
2007	Meriva	Body	Instrument	✓	✓	✓	✓	✓	0177 0178
2007	Meriva	Body	Headlamp Levelling Device	✓	✓	✓	✓	✓	0142
2007	Meriva	Body	Electronic Climate Control	✓	✓	✓	✓	✓	
2007	Meriva	Body	EHS(Electrical Heater System)	✓	✓	✓	✓	✓	
2007	Meriva	Body	Add On Heater	✓	✓	✓	✓	✓	0123 0124
2007	Meriva	Chassis	ABS8/ESPS	✓	✓	✓	✓	✓	0006 0143 0144 0145 0005
2007	Meriva	Chassis	Electronic Power Steering	✓	✓	✓	✓	✓	0142
2007	Meriva	Engine	Y13DT	✓	✓	✓	✓	✓	0041 0020 0022 0012 0021
2007	Meriva	Engine	Z13DT	✓	✓	✓	✓	✓	0020 0041 0022 0012 0021
2007	Meriva	Engine	Z14XEP	✓	✓	✓	✓	✓	0034 0066 0007 0167 0010 0147 0020 0012 0022
2007	Meriva	Engine	Z16SE	✓	✓	✓	✓	✓	0007 0022 0012
2007	Meriva	Engine	Z16XE	✓	✓	✓	✓	✓	0007 0022 0012
2007	Meriva	Engine	Z16XEP	✓	✓	✓	✓	✓	0007 0147 0010 0020 0012 0022 0066
2007	Meriva	Engine	Y17DT	✓	✓	✓	✓	✓	
2007	Meriva	Engine	Z17DTH	✓	✓	✓	✓	✓	0007 0147 0020 0021 0148 0023 0012 0022
2007	Meriva	Engine	Z18XE	✓	✓	✓	✓	✓	0146 0010 0041 0020 0012 0022
2007	Meriva	Engine	Z13DTJ	✓	✓	✓	✓	✓	0041 0020 0029 0026 0042 0022 0012 0021 0043
2007	Meriva	Engine	Z16LET	✓	✓	✓	✓	✓	0007 0147 0010 0020 0012 0022 0066
2007	Meriva	Engine	Z16YNG	✓	✓	✓	✓	✓	0007 0147 0146 0010 0020 0012 0022
2007	Meriva	Engine	C16SEL	✓	✓	✓	✓	✓	
2007	Meriva	Engine	Z17DT	✓	✓	✓	✓	✓	0007 0147 0020 0023 0012 0022 0021 0148
2007	Meriva	Engine	Z17DTR	✓	✓	✓	✓	✓	

2007	Meriva	Transmission	MTA(Easytronic)	✓	✓	✓	✓	✓	0012 0149
2007	Movano	Body	Airbag	✓	✓	✓	✓		
2007	Movano	Body	Body Control Module	✓	✓	✓	✓	✓	0052 0059 0139
2007	Movano	Body	Park Pilot		✓	✓	✓		
2007	Movano	Chassis	ABS/ESP(Anti-lock Braking System/Electronic Stability Program)		✓	✓	✓	✓	0165 0166
2007	Movano	Chassis	Pneumatic Suspension		✓	✓	✓	✓	
2007	Movano	Transmission	MTA(Tecshift)		✓	✓	✓	✓	
2007	Speedster/VX220	Body	Immobiliser	✓	✓	✓	✓		0140 0141
2007	Speedster/VX220	Body	Airbag	✓	✓	✓	✓		
2007	Speedster/VX220	Chassis	ABS 430	✓	✓	✓	✓		
2007	Speedster/VX220	Engine	Z20LET	✓	✓	✓	✓		
2007	Speedster/VX220	Engine	Z22SE	✓	✓	✓	✓	✓	0066 0147 0146 0010 0012 0022 0034
2007	Tigra-B	Body	Body Control Module	✓	✓	✓	✓	✓	0052 0059 0139
2007	Tigra-B	Body	Immobiliser	✓	✓	✓	✓		0140 0141
2007	Tigra-B	Body	Airbag	✓	✓	✓	✓	✓	
2007	Tigra-B	Body	Instrument	✓	✓	✓	✓		0177 0178
2007	Tigra-B	Body	Electrohydraulic HardTop	✓	✓	✓	✓	✓	
2007	Tigra-B	Chassis	ABS8/ESP8	✓	✓	✓	✓	✓	0006 0143 0144 0145 0005 0142
2007	Tigra-B	Chassis	Electronic Power Steering	✓	✓	✓	✓		
2007	Tigra-B	Engine	Z13DT	✓	✓	✓	✓	✓	0020 0041 0022 0012 0021
2007	Tigra-B	Engine	Z14XEP	✓	✓	✓	✓	✓	0034 0066 0007 0167 0010 0147 0020 0012 0022
2007	Tigra-B	Engine	Z18XE	✓	✓	✓	✓	✓	0146 0010 0041 0020 0012 0022
2007	Tigra-B	Transmission	MTA(Easytronic)	✓	✓	✓	✓	✓	0012 0149
2007	Vauxhall VX88	Body	AHL(Automatic Headlamp Levelling)	✓	✓	✓	✓		
2007	Vauxhall VX88	Body	BCM(Body Control Module)	✓	✓	✓	✓		
2007	Vauxhall VX88	Body	HVAC(Heating Ventilation and Cooling)	✓	✓	✓	✓		
2007	Vauxhall VX88	Body	Immobiliser	✓	✓	✓	✓		
2007	Vauxhall VX88	Body	MSM(Memory Seat and Mirrors)	✓	✓	✓	✓		
2007	Vauxhall VX88	Body	Park Assist	✓	✓	✓	✓		
2007	Vauxhall VX88	Body	SDM(Sensing and Diagnostic Module)	✓	✓	✓	✓		
2007	Vauxhall VX88	Body	IPC(Instrument Panel Cluster)	✓	✓	✓	✓		
2007	Vauxhall VX88	Body	RPA(Multipurpose Receiver Module)	✓	✓	✓	✓		
2007	Vauxhall VX88	Chassis	EBM(Electronic Brake Control Module)	✓	✓	✓	✓	✓	
2007	Vauxhall VX88	Chassis	ESC(Electronic Suspension Control)	✓	✓	✓	✓		
2007	Vauxhall VX88	Engine	V8 GEN IV	✓	✓	✓	✓	✓	0016 0150 0172 0173
2007	Vauxhall VX88	Transmission	Automatic Transmission	✓	✓	✓	✓	✓	
2007	Vectra-C/Signum	Body	SDM(Airbag,Sensing&Diagnostic Module)	✓	✓	✓	✓		0000 0001 0002 0003
2007	Vectra-C/Signum	Body	Instrument	✓	✓	✓	✓	✓	0170 0057 0058 0180 0002
2007	Vectra-C/Signum	Body	CIM(Steering Column Module)	✓	✓	✓	✓	✓	0052 0004 0053 0002 0005 0054 0055 0006
2007	Vectra-C/Signum	Body	BCM(Body Control Module)	✓	✓	✓	✓		0181 0182
2007	Vectra-C/Signum	Body	DDM(Driver Door Module)	✓	✓	✓	✓		
2007	Vectra-C/Signum	Body	PDM(Passenger Door Module)	✓	✓	✓	✓		
2007	Vectra-C/Signum	Body	REC(Rear Electrical Centre)	✓	✓	✓	✓		
2007	Vectra-C/Signum	Body	UEC(Underhood Electrical Centre)	✓	✓	✓	✓		
2007	Vectra-C/Signum	Body	SLM(Shift Lever Module)	✓	✓	✓	✓		
2007	Vectra-C/Signum	Body	SRM(Sun Roof Module)	✓	✓	✓	✓		
2007	Vectra-C/Signum	Body	AHL/AFL(Headlamp Levelling)	✓	✓	✓	✓		
2007	Vectra-C/Signum	Body	Electrical Horn	✓	✓	✓	✓	✓	
2007	Vectra-C/Signum	Body	SAC(Automatic Climate Control)	✓	✓	✓	✓	✓	0151 0159 0160 0002 0005 0161
2007	Vectra-C/Signum	Body	Interior Lighting	✓	✓	✓	✓	✓	0183 0060
2007	Vectra-C/Signum	Body	Electronic Seat Memory/Seat Heating	✓	✓	✓	✓		
2007	Vectra-C/Signum	Body	Anti Theft Warning System	✓	✓	✓	✓	✓	
2007	Vectra-C/Signum	Body	Central Door Lock	✓	✓	✓	✓		
2007	Vectra-C/Signum	Body	EHS(Electrical Heater System)	✓	✓	✓	✓	✓	0033 0002 0005
2007	Vectra-C/Signum	Body	PAS(Park Pilot)	✓	✓	✓	✓	✓	0002
2007	Vectra-C/Signum	Chassis	ABS/TC/ESP	✓	✓	✓	✓	✓	0004 0005 0063
2007	Vectra-C/Signum	Chassis	EHPS(Electronic Power Steering)	✓	✓	✓	✓		
2007	Vectra-C/Signum	Chassis	TPMS (Tyre Pressure Monitoring System)	✓	✓	✓	✓		0033
2007	Vectra-C/Signum	Chassis	CDC(Continuous Damping Control)	✓	✓	✓	✓		
2007	Vectra-C/Signum	Chassis	Electronic Cruise Control	✓	✓	✓	✓		
2007	Vectra-C/Signum	Engine	Engine Cooling	✓	✓	✓	✓		
2007	Vectra-C/Signum	Engine	Z16XEP	✓	✓	✓	✓	✓	0011 0012 0067 0014 0150
2007	Vectra-C/Signum	Engine	Z18XE	✓	✓	✓	✓	✓	0020 0011 0012 0067 0150 0013
2007	Vectra-C/Signum	Engine	Z18XER	✓	✓	✓	✓	✓	0020 0010 0011 0012 0067 0150 0034 0013
2007	Vectra-C/Signum	Engine	Z19DT	✓	✓	✓	✓	✓	0150 0011 0012 0067 0024 0025 0070 0021 0013 0027 0030
2007	Vectra-C/Signum	Engine	Z19DTH	✓	✓	✓	✓	✓	0150 0011 0012 0067 0024 0025 0029 0026 0027 0021 0013 0028 0030
2007	Vectra-C/Signum	Engine	Y20DTH	✓	✓	✓	✓	✓	0011 0012 0067 0150
2007	Vectra-C/Signum	Engine	Y22DTR	✓	✓	✓	✓	✓	0011 0012 0067 0150
2007	Vectra-C/Signum	Engine	Z22SE	✓	✓	✓	✓	✓	0011 0012 0067 0150
2007	Vectra-C/Signum	Engine	Z22YH	✓	✓	✓	✓	✓	0020 0150
2007	Vectra-C/Signum	Engine	Z32SE	✓	✓	✓	✓	✓	0020 0150
2007	Vectra-C/Signum	Engine	Engine(default)>	✓	✓	✓	✓		
2007	Vectra-C/Signum	Engine	Z16XE	✓	✓	✓	✓	✓	0011 0012 0067 0150 0013
2007	Vectra-C/Signum	Engine	Z20NET	✓	✓	✓	✓	✓	0011 0012 0067 0150
2007	Vectra-C/Signum	Engine	Z28NEH	✓	✓	✓	✓	✓	0010 0020 0041 0184 0185 0186 0012 0067 0150
2007	Vectra-C/Signum	Engine	Z28NEL	✓	✓	✓	✓	✓	0010 0020 0041 0184 0185 0186 0012 0067 0150
2007	Vectra-C/Signum	Engine	Z28NET	✓	✓	✓	✓	✓	0010 0020 0041 0184 0185 0186 0012 0067 0150
2007	Vectra-C/Signum	Engine	Z30DT	✓	✓	✓	✓	✓	0020 0011 0067 0030
2007	Vectra-C/Signum	Transmission	AF 23-5/33-5/40-6	✓	✓	✓	✓	✓	0033 0034
2007	Vectra-C/Signum	Transmission	CVTronic	✓	✓	✓	✓	✓	0187 0188 0189 0033 0004 0034
2007	Vectra-C/Signum	Transmission	MTA(Easytronic)	✓	✓	✓	✓	✓	
2007	Vivaro	Body	Airbag	✓	✓	✓	✓		0005
2007	Vivaro	Body	Park Pilot	✓	✓	✓	✓		
2007	Vivaro	Body	Add On Heater	✓	✓	✓	✓	✓	0123 0124
2007	Vivaro	Body	Body Control Module	✓	✓	✓	✓	✓	
2007	Vivaro	Chassis	ABS/ESP(Anti-lock Braking System/Electronic Stability Program)	✓	✓	✓	✓	✓	0175 0176
2007	Vivaro	Engine	F9Q 760/762 (1.9L)	✓	✓	✓	✓		

2007	Vivaro	Transmission	MTA(Tecshift)		✓	✓	✓	✓		
2007	Zafira-B	Body	SDM(Airbag)	✓	✓	✓	✓	✓		0000 0001 0002 0003
2007	Zafira-B	Body	CIM(Steering Column Module)	✓	✓	✓	✓	✓		0052 0004 0053 0002 0005 0054 0055 0006
2007	Zafira-B	Body	IPC ECU(Instrument Control Unit)	✓	✓	✓	✓	✓		
2007	Zafira-B	Body	REC(Rear Electrical Centre)	✓	✓	✓	✓	✓		
2007	Zafira-B	Body	UEC(Underhood Electrical Centre)	✓	✓	✓	✓	✓		
2007	Zafira-B	Body	AHL/AFL(Headlamp Levelling)	✓	✓	✓	✓	✓		
2007	Zafira-B	Body	Exterior Lighting/Turn Indicator System	✓	✓	✓	✓	✓		
2007	Zafira-B	Body	Interior Lighting	✓	✓	✓	✓	✓		
2007	Zafira-B	Body	Wipers/Washer	✓	✓	✓	✓	✓		
2007	Zafira-B	Body	Central Door Lock	✓	✓	✓	✓	✓		
2007	Zafira-B	Body	Instrument	✓	✓	✓	✓	✓		0056 0057 0058
2007	Zafira-B	Body	Immobiliser	✓	✓	✓	✓	✓		
2007	Zafira-B	Body	ECC/SAC(Electronic Climate Control)	✓	✓	✓	✓	✓		0151 0159 0160 0002 0005 0161
2007	Zafira-B	Body	EHS(Electrical Heater System)	✓	✓	✓	✓	✓		0033 0002 0005
2007	Zafira-B	Body	PAS(Park Pilot)	✓	✓	✓	✓	✓		0002
2007	Zafira-B	Body	SLM(Shift Lever Module)	✓	✓	✓	✓	✓		
2007	Zafira-B	Body	PEPS(Open&Start)	✓	✓	✓	✓	✓		
2007	Zafira-B	Body	Anti Theft Warning System	✓	✓	✓	✓	✓		
2007	Zafira-B	Body	IPC ECU(Instrument Control Unit)	✓	✓	✓	✓	✓		0007 0056 0057 0058 0059 0060 0061 0002 0005
2007	Zafira-B	Chassis	ABS/TC/ESP ECU(Electronic Control Unit)	✓	✓	✓	✓	✓		0004 0005 0063
2007	Zafira-B	Chassis	EHPS(Electrohydraulic Power Steering)	✓	✓	✓	✓	✓		
2007	Zafira-B	Chassis	ABS/TC/ESP(Vehicle Dynamic System)	✓	✓	✓	✓	✓		0006
2007	Zafira-B	Chassis	TPMS ECU(Tyre Pressure Monitoring)	✓	✓	✓	✓	✓		0002
2007	Zafira-B	Chassis	TPMS(Tyre Pressure Monitoring System)	✓	✓	✓	✓	✓		
2007	Zafira-B	Chassis	CDC(Continuous Damping Control)	✓	✓	✓	✓	✓		
2007	Zafira-B	Chassis	EHPS(Electrohydraulic Power Steering)	✓	✓	✓	✓	✓		0004
2007	Zafira-B	Engine	Z16XEP	✓	✓	✓	✓	✓		0007 0008 0009 0010 0020 0011 0012 0067 0013 0014 0034 0019
2007	Zafira-B	Engine	Z18XER	✓	✓	✓	✓	✓		0020 0007 0008 0009 0010 0011 0012 0067 0034 0013 0019
2007	Zafira-B	Engine	Z19DT	✓	✓	✓	✓	✓		0007 0008 0009 0011 0012 0067 0024 0025 0070 0013 0033 0021 0030 0027 0028 0026 0029 0019
2007	Zafira-B	Engine	Z19DTH	✓	✓	✓	✓	✓		0007 0008 0009 0033 0011 0012 0067 0024 0025 0029 0026 0027 0028
2007	Zafira-B	Engine	Z16XE1	✓	✓	✓	✓	✓		0007 0008 0009 0010 0174 0011 0012 0067 0013 0014 0034 0019
2007	Zafira-B	Engine	Z16XER	✓	✓	✓	✓	✓		0007 0008 0009 0010 0020 0011 0012 0067 0034 0013 0019
2007	Zafira-B	Engine	Z16YNG	✓	✓	✓	✓	✓		0007 0008 0009 0010 0020 0011 0012 0067 0013 0014 0034 0019
2007	Zafira-B	Engine	Z20LER	✓	✓	✓	✓	✓		0007 0008 0009 0010 0011 0012 0067 0013 0014 0019
2007	Zafira-B	Engine	Z20LEH	✓	✓	✓	✓	✓		0007 0008 0009 0010 0011 0012 0067 0013 0014 0019
2007	Zafira-B	Engine	Z22YH	✓	✓	✓	✓	✓		0007 0008 0009 0072 0020 0011 0012 0067 0013 0014 0019
2007	Zafira-B	Engine	Engine(default)	✓	✓	✓	✓	✓		
2007	Zafira-B	Transmission	MTA(Easutronic)	✓	✓	✓	✓	✓		0004 0062 0035 0036
2007	Zafira-B	Transmission	AF 40-6	✓	✓	✓	✓	✓		0073 0074 0075 0076 0077 0078 0033 0004 0034 0079
2007	Zafira-B	Transmission	AF 22-4	✓	✓	✓	✓	✓		0031 0033 0004 0034
2006	Agila	Body	Immobiliser	✓	✓	✓	✓	✓		0140 0141
2006	Agila	Body	Airbag	✓	✓	✓	✓	✓		
2006	Agila	Body	Instrument	✓	✓	✓	✓	✓		
2006	Agila	Chassis	ABS	✓	✓	✓	✓	✓		0191
2006	Agila	Chassis	Electronic Power Steering	✓	✓	✓	✓	✓		
2006	Agila	Engine	Z10XEP	✓	✓	✓	✓	✓		0012 0022 0066 0034
2006	Agila	Engine	Z12XE	✓	✓	✓	✓	✓		0007 0146 0010 0041 0020 0022 0012 0066 0034
2006	Agila	Engine	Z12XEP	✓	✓	✓	✓	✓		0012 0022 0066 0034
2006	Agila	Engine	Z13DT	✓	✓	✓	✓	✓		0020 0041 0022 0012 0021
2006	Astra-G	Body	Immobiliser	✓	✓	✓	✓	✓		0140 0141
2006	Astra-G	Body	Instrument	✓	✓	✓	✓	✓		
2006	Astra-G	Body	Airbag	✓	✓	✓	✓	✓		
2006	Astra-G	Body	Anti Theft Warning	✓	✓	✓	✓	✓		
2006	Astra-G	Body	Central Door Lock	✓	✓	✓	✓	✓		
2006	Astra-G	Body	Headlamp Levelling Device	✓	✓	✓	✓	✓		0142
2006	Astra-G	Body	Electronic Climate Control	✓	✓	✓	✓	✓		
2006	Astra-G	Body	Engine Cooling Module	✓	✓	✓	✓	✓		
2006	Astra-G	Body	Add On Heater	✓	✓	✓	✓	✓		0123 0124
2006	Astra-G	Body	Softtop Controller	✓	✓	✓	✓	✓		
2006	Astra-G	Chassis	ABS-5.3/5.4(+TC)	✓	✓	✓	✓	✓		
2006	Astra-G	Chassis	ESP	✓	✓	✓	✓	✓		0006
2006	Astra-G	Chassis	Cruise Control	✓	✓	✓	✓	✓		
2006	Astra-G	Chassis	Electronic Power Steering	✓	✓	✓	✓	✓		
2006	Astra-G	Engine	Z12XE	✓	✓	✓	✓	✓		0007 0146 0010 0041 0020 0022 0012 0066 0034
2006	Astra-G	Engine	Z14XE	✓	✓	✓	✓	✓		0147 0146 0010 0020 0022 0012
2006	Astra-G	Engine	Z14XEP	✓	✓	✓	✓	✓		0034 0066 0007 0167 0010 0147 0020 0012 0022
2006	Astra-G	Engine	C16SEL	✓	✓	✓	✓	✓		
2006	Astra-G	Engine	Z16SE	✓	✓	✓	✓	✓		0007 0022 0012
2006	Astra-G	Engine	Z16XE	✓	✓	✓	✓	✓		0007 0022 0012
2006	Astra-G	Engine	Z16XEP	✓	✓	✓	✓	✓		0007 0147 0010 0020 0012 0022 0066
2006	Astra-G	Engine	Z16YNG	✓	✓	✓	✓	✓		0007 0147 0146 0010 0020 0012 0022
2006	Astra-G	Engine	Y17DT	✓	✓	✓	✓	✓		
2006	Astra-G	Engine	Z17DTL	✓	✓	✓	✓	✓		
2006	Astra-G	Engine	Z18XE	✓	✓	✓	✓	✓		0146 0010 0041 0020 0012 0022
2006	Astra-G	Engine	Z18XEL	✓	✓	✓	✓	✓		0012 0022

2006	Astra-G	Engine	Y20DTH	✓	✓	✓	✓	✓	0167 0168 0169 0170
2006	Astra-G	Engine	Z20LET	✓	✓	✓	✓	✓	0010 0020 0041 0146 0012 0022 0066 0034
2006	Astra-G	Engine	Y22DTR	✓	✓	✓	✓	✓	0012 0022
2006	Astra-G	Engine	Z22SE	✓	✓	✓	✓	✓	0066 0147 0146 0010 0012 0022 0034
2006	Astra-G	Infotainment System	Trip Info Display TID	✓	✓	✓			
2006	Astra-G	Infotainment System	Multi Info Display MID	✓	✓	✓			
2006	Astra-G	Infotainment System	Radio CAR 300	✓	✓	✓			
2006	Astra-G	Infotainment System	Radio CAR 400	✓	✓	✓	✓		
2006	Astra-G	Infotainment System	Radio CDR 500	✓	✓	✓	✓		
2006	Astra-G	Infotainment System	Radio CCR 600	✓	✓	✓	✓		
2006	Astra-G	Infotainment System	Radio CCRT 700	✓	✓	✓	✓		
2006	Astra-G	Infotainment System	Radio NCDR 1100/1500	✓	✓	✓	✓		
2006	Astra-G	Transmission	AF 13-II/17/20/22	✓	✓	✓	✓	✓	
2006	Astra-G	Transmission	AF 13-II/17/20/22 CAN	✓	✓	✓	✓	✓	
2006	Astra-H	Body	SDM(Airbag)	✓	✓	✓	✓		
2006	Astra-H	Body	CIM(Steering Column Module)	✓	✓	✓	✓	✓	0052 0004 0053 0002 0005 0054 0055 0006
2006	Astra-H	Body	IPC ECU(Instrument Control Unit)	✓	✓	✓	✓	✓	
2006	Astra-H	Body	REC(Rear Electrical Centre)	✓	✓	✓	✓	✓	
2006	Astra-H	Body	UEC(Underhood Electrical Centre)	✓	✓	✓	✓	✓	
2006	Astra-H	Body	AHL/AFI(Headlamp Levelling)	✓	✓	✓	✓	✓	
2006	Astra-H	Body	Exterior Lighting/Turn Indicator System	✓	✓	✓	✓	✓	
2006	Astra-H	Body	Interior Lighting	✓	✓	✓	✓	✓	
2006	Astra-H	Body	Wipers/Washer	✓	✓	✓	✓	✓	
2006	Astra-H	Body	Central Door Lock	✓	✓	✓	✓	✓	
2006	Astra-H	Body	Instrument	✓	✓	✓	✓	✓	0056 0057 0058
2006	Astra-H	Body	Immobiliser	✓	✓	✓	✓	✓	
2006	Astra-H	Body	Anti Theft Warning System	✓	✓	✓	✓	✓	
2006	Astra-H	Body	Electrohydraulic HardTop	✓	✓	✓	✓	✓	0002 0005
2006	Astra-H	Body	ECC/SAC(Electronic Climate Control)	✓	✓	✓	✓	✓	0151 0159 0160 0033 0002 0005 0161
2006	Astra-H	Body	EHS(Electrical Heater System)	✓	✓	✓	✓	✓	0033 0002 0005
2006	Astra-H	Body	PAS(Park Pilot)	✓	✓	✓	✓	✓	0002
2006	Astra-H	Body	SLM(Shift Lever Module)	✓	✓	✓	✓	✓	
2006	Astra-H	Body	PEPS(Open&Start)	✓	✓	✓	✓	✓	
2006	Astra-H	Body	IPC ECU(Instrument Control Unit)	✓	✓	✓	✓	✓	0007 0056 0057 0058 0059 0060 0061 0002 0005
2006	Astra-H	Chassis	ABS/TC/ESP ECU(Electronic Control Unit)	✓	✓	✓	✓	✓	0004 0005 0063
2006	Astra-H	Chassis	EHP(S Electrohydraulic Power Steering)	✓	✓	✓	✓	✓	
2006	Astra-H	Chassis	TPMS ECU(Tyre Pressure Monitoring)	✓	✓	✓	✓	✓	0002
2006	Astra-H	Chassis	TPMS (Tyre Pressure Monitoring System)	✓	✓	✓	✓	✓	
2006	Astra-H	Chassis	CDC (Continuous Damping Control)	✓	✓	✓	✓	✓	
2006	Astra-H	Chassis	ABS/TC/ESP(Vehicle Dynamic System)	✓	✓	✓	✓	✓	
2006	Astra-H	Chassis	EHP(S Electrohydraulic Power Steering)	✓	✓	✓	✓	✓	0004
2006	Astra-H	Engine	Z13DTH	✓	✓	✓	✓	✓	0007 0008 0009 0020 0011 0012 0067 0021 0030 0029 0026 0027 0019
2006	Astra-H	Engine	Z14XEL	✓	✓	✓	✓	✓	0007 0008 0009 0010 0011 0012 0067 0013 0014 0019
2006	Astra-H	Engine	Z14XEP	✓	✓	✓	✓	✓	0007 0008 0009 0010 0011 0012 0067 0013 0014 0019
2006	Astra-H	Engine	Z16XEP	✓	✓	✓	✓	✓	0007 0008 0009 0010 0020 0011 0012 0067 0013 0014 0034 0019
2006	Astra-H	Engine	Z17DTH	✓	✓	✓	✓	✓	0007 0008 0009 0011 0012 0067 0021 0025 0013 0030 0033 0019
2006	Astra-H	Engine	Z18XE	✓	✓	✓	✓	✓	0020 0007 0008 0009 0010 0011 0012 0067 0013 0019
2006	Astra-H	Engine	Z18XER	✓	✓	✓	✓	✓	0007 0008 0009 0010 0020 0011 0012 0067 0034 0013 0019
2006	Astra-H	Engine	Z19DT	✓	✓	✓	✓	✓	0007 0008 0009 0011 0012 0067 0024 0025 0070 0013 0033 0021 0030 0027 0028 0026 0029 0019
2006	Astra-H	Engine	Z19DTH	✓	✓	✓	✓	✓	0007 0008 0009 0011 0012 0067 0024 0025 0070 0013 0033 0021 0030 0027 0028 0026 0029 0019
2006	Astra-H	Engine	Z12XEP	✓	✓	✓	✓	✓	0007 0008 0009 0010 0011 0012 0067 0013 0014 0019
2006	Astra-H	Engine	Y13DTH	✓	✓	✓	✓	✓	0020 0011 0012 0067 0021 0030 0029 0026 0027 0019
2006	Astra-H	Engine	Z16XER	✓	✓	✓	✓	✓	0007 0008 0009 0010 0020 0011 0012 0067 0034 0013 0019
2006	Astra-H	Engine	Z17DTL	✓	✓	✓	✓	✓	0011 0012 0067 0021 0025 0013 0030 0033 0019
2006	Astra-H	Engine	Z19DTJ	✓	✓	✓	✓	✓	0011 0012 0067 0024 0025 0070 0013 0033 0021 0030 0027 0028 0026 0029 0019
2006	Astra-H	Engine	Z20LEH	✓	✓	✓	✓	✓	0007 0008 0009 0010 0011 0012 0067 0013 0014 0019
2006	Astra-H	Engine	Z20LEL	✓	✓	✓	✓	✓	0007 0008 0009 0010 0011 0012 0067 0013 0014 0019
2006	Astra-H	Engine	Z20LER	✓	✓	✓	✓	✓	0007 0008 0009 0010 0011 0012 0067 0013 0014 0019
2006	Astra-H	Engine	Engine(default)	✓	✓	✓			
2006	Astra-H	Transmission	AF 17-4	✓	✓	✓	✓	✓	0031 0032 0033 0004 0034
2006	Astra-H	Transmission	AF 40-6	✓	✓	✓	✓	✓	0073 0074 0075 0076 0077 0078 0033 0004 0034 0079
2006	Astra-H	Transmission	MTA(Easytronic)	✓	✓	✓	✓	✓	0004 0062 0035 0036
2006	Astra-H	Transmission	MTA(Easytronic Magneti Marelli)	✓	✓	✓	✓	✓	0004 0005 0062
2006	Combo	Body	Add On Heater	✓	✓	✓	✓	✓	0123 0124
2006	Combo	Body	Airbag	✓	✓	✓	✓	✓	
2006	Combo	Body	Electronic Climate Control	✓	✓	✓	✓	✓	
2006	Combo	Body	Body Control Module	✓	✓	✓	✓	✓	0052 0059 0139
2006	Combo	Body	HeadLamp Levelling Device	✓	✓	✓	✓	✓	0142
2006	Combo	Body	Immobiliser	✓	✓	✓	✓	✓	0165 0166
2006	Combo	Body	Instrument	✓	✓	✓	✓	✓	
2006	Combo	Chassis	ABS/ESP8 (Anti-lock Braking System/Electronic Stability Program)	✓	✓	✓	✓	✓	0006 0143 0144 0145 0005
2006	Combo	Chassis	ABS-5.3/5.4 (+TC) (Anti-lock Braking System)	✓	✓	✓	✓	✓	

2006	Combo	Chassis	Electronic Power Steering	✓	✓	✓	✓	✓	0142
2006	Combo	Engine	Z 10 XEP	✓	✓	✓	✓	✓	0012 0022 0066 0034
2006	Combo	Engine	Z 12 XE	✓	✓	✓	✓	✓	0007 0146 0010 0041 0020 0022 0012 0066 0034
2006	Combo	Engine	Z 12 XEP	✓	✓	✓	✓	✓	0012 0022 0066 0034
2006	Combo	Engine	Y 13 DT	✓	✓	✓	✓	✓	0041 0020 0022 0012 0021
2006	Combo	Engine	Z 13 DT	✓	✓	✓	✓	✓	0041 0020 0022 0012 0021
2006	Combo	Engine	Z 14 XE	✓			✓	✓	0147 0146 0010 0020 0022 0012
2006	Combo	Engine	Z 14 XEP	✓	✓	✓	✓	✓	0007 0167 0010 0147 0020 0012 0022 0066 0034
2006	Combo	Engine	Z 16 SE	✓	✓	✓	✓	✓	0007 0022 0012
2006	Combo	Engine	Z 16 YNG	✓	✓	✓	✓	✓	0007 0147 0146 0010 0020 0012 0022
2006	Combo	Engine	Y 17 DT	✓	✓	✓	✓	✓	
2006	Combo	Engine	Y 17 DTL	✓	✓	✓	✓	✓	0007 0022 0012
2006	Combo	Engine	Z 17 DTH	✓	✓	✓	✓	✓	
2006	Combo	Engine	Z 18 XE	✓	✓	✓	✓	✓	0146 0010 0041 0020 0012 0022
2006	Combo	Infotainment System	Trip Info Display TID	✓	✓	✓			
2006	Combo	Transmission	AF 13-II/17/20/22	✓	✓	✓	✓	✓	
2006	Combo	Transmission	AF 13-II/17/20/22 CAN	✓	✓	✓	✓	✓	
2006	Combo	Transmission	Easvtronic(MTA)	✓	✓	✓	✓	✓	0012 0149
2006	Corsa-C	Body	Body Control Module	✓	✓	✓	✓	✓	0052 0059 0139
2006	Corsa-C	Body	Immobiliser	✓	✓	✓	✓	✓	0140 0141
2006	Corsa-C	Body	Airbag	✓	✓	✓	✓	✓	
2006	Corsa-C	Body	Instrument	✓	✓	✓	✓	✓	0177 0178
2006	Corsa-C	Body	Add On Heater	✓	✓	✓	✓	✓	0123 0124
2006	Corsa-C	Body	Electronic Climate Control	✓	✓	✓	✓	✓	
2006	Corsa-C	Body	HeadLamp Levelling Device	✓	✓	✓	✓	✓	0142
2006	Corsa-C	Chassis	ABS-5_3/5_4(+TC)	✓	✓	✓	✓	✓	
2006	Corsa-C	Chassis	ABS8/ESP8	✓	✓	✓	✓	✓	0006 0143 0144 0145 0005
2006	Corsa-C	Chassis	Electronic Power Steering	✓	✓	✓	✓	✓	0142
2006	Corsa-C	Engine	Z10XEP	✓	✓	✓	✓	✓	0012 0022 0066 0034
2006	Corsa-C	Engine	Z12XE	✓	✓	✓	✓	✓	0007 0146 0010 0041 0020 0022 0012 0066 0034
2006	Corsa-C	Engine	Z12XEP	✓	✓	✓	✓	✓	0012 0022 0066 0034
2006	Corsa-C	Engine	Y13DT	✓	✓	✓	✓	✓	0041 0020 0022 0012 0021
2006	Corsa-C	Engine	Z13DT	✓	✓	✓	✓	✓	0020 0041 0022 0012 0021
2006	Corsa-C	Engine	Z14XE	✓	✓		✓	✓	0147 0146 0010 0020 0022 0012
2006	Corsa-C	Engine	Z14XEP	✓	✓	✓	✓	✓	0034 0066 0007 0167 0010 0147 0020 0012 0022
2006	Corsa-C	Engine	Z16SE	✓	✓	✓	✓	✓	0007 0022 0012
2006	Corsa-C	Engine	Z16YNG	✓	✓	✓	✓	✓	0007 0147 0146 0010 0020 0012 0022
2006	Corsa-C	Engine	Y17DT	✓	✓	✓	✓	✓	
2006	Corsa-C	Engine	Y17DTL	✓	✓	✓	✓	✓	0007 0022 0012
2006	Corsa-C	Engine	Z17DTH	✓	✓	✓	✓	✓	0007 0147 0020 0021 0148 0023 0012 0022
2006	Corsa-C	Engine	Z18XE	✓	✓	✓	✓	✓	0146 0010 0041 0020 0012 0022
2006	Corsa-C	Infotainment System	Trip Info Display TID	✓	✓	✓			
2006	Corsa-C	Transmission	AF 13-II/17/20/22 CAN	✓	✓	✓	✓	✓	
2006	Corsa-C	Transmission	MTA(Easvtronic)	✓	✓	✓	✓	✓	0012 0149
2006	Corsa-C	Transmission	AF 13-II/17/20/22	✓	✓	✓	✓	✓	
2006	Meriva	Body	Body Control Module	✓	✓	✓	✓	✓	0052 0059 0139
2006	Meriva	Body	Immobiliser	✓	✓	✓	✓	✓	0140 0141
2006	Meriva	Body	Airbag	✓	✓	✓	✓	✓	
2006	Meriva	Body	Instrument	✓	✓	✓	✓	✓	0177 0178
2006	Meriva	Body	Headlamp Levelling Device	✓	✓	✓	✓	✓	0142
2006	Meriva	Body	Electronic Climate Control	✓	✓	✓	✓	✓	
2006	Meriva	Body	Add On Heater	✓	✓	✓	✓	✓	0123 0124
2006	Meriva	Chassis	ABS8/ESP8	✓	✓	✓	✓	✓	0006 0143 0144 0145 0005
2006	Meriva	Chassis	Electronic Power Steering	✓	✓	✓	✓	✓	0142
2006	Meriva	Engine	Y13DT	✓	✓	✓	✓	✓	0041 0020 0022 0012 0021
2006	Meriva	Engine	Z13DT	✓	✓	✓	✓	✓	0020 0041 0022 0012 0021
2006	Meriva	Engine	Z14XEP	✓	✓	✓	✓	✓	0034 0066 0007 0167 0010 0147 0020 0012 0022
2006	Meriva	Engine	Z16SE	✓	✓	✓	✓	✓	0007 0022 0012
2006	Meriva	Engine	Z16XE	✓	✓	✓	✓	✓	0007 0022 0012
2006	Meriva	Engine	Z16XEP	✓	✓	✓	✓	✓	0007 0147 0010 0020 0012 0022 0066
2006	Meriva	Engine	Y17DT	✓	✓	✓	✓	✓	
2006	Meriva	Engine	Z17DTH	✓	✓	✓	✓	✓	0007 0147 0020 0021 0148 0023 0012 0022
2006	Meriva	Engine	Z18XE	✓	✓	✓	✓	✓	0146 0010 0041 0020 0012 0022
2006	Meriva	Engine	C16SEL	✓	✓	✓	✓	✓	
2006	Meriva	Engine	Z16LET	✓	✓	✓	✓	✓	0007 0147 0010 0020 0012 0022 0066
2006	Meriva	Infotainment System	Trip Info Display TID	✓	✓	✓			
2006	Meriva	Transmission	MTA(Easvtronic)	✓	✓	✓	✓	✓	0012 0149
2006	Movano	Body	Airbag	✓	✓	✓	✓	✓	
2006	Movano	Body	Body Control Module	✓	✓	✓	✓	✓	0052 0059 0139
2006	Movano	Chassis	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)		✓	✓	✓	✓	0165 0166
2006	Speedster/VX220	Body	Immobiliser	✓	✓	✓	✓	✓	0140 0141
2006	Speedster/VX220	Body	Airbag	✓	✓	✓	✓	✓	
2006	Speedster/VX220	Chassis	ABS 430	✓	✓	✓	✓	✓	
2006	Speedster/VX220	Engine	Z20LET	✓	✓	✓	✓	✓	
2006	Speedster/VX220	Engine	Z22SE	✓	✓	✓	✓	✓	0066 0147 0146 0010 0012 0022 0034
2006	Tigra-B	Body	Body Control Module	✓	✓	✓	✓	✓	0052 0059 0139
2006	Tigra-B	Body	Immobiliser	✓	✓	✓	✓	✓	0140 0141
2006	Tigra-B	Body	Airbag	✓	✓	✓	✓	✓	
2006	Tigra-B	Body	Instrument	✓	✓	✓	✓	✓	0177 0178
2006	Tigra-B	Chassis	ABS8/ESP8	✓	✓	✓	✓	✓	0006 0143 0144 0145 0005
2006	Tigra-B	Chassis	Electronic Power Steering	✓	✓	✓	✓	✓	0142
2006	Tigra-B	Engine	Z13DT	✓	✓	✓	✓	✓	0020 0041 0022 0012 0021
2006	Tigra-B	Engine	Z14XEP	✓	✓	✓	✓	✓	0034 0066 0007 0167 0010 0147 0020 0012 0022
2006	Tigra-B	Engine	Z18XE	✓	✓	✓	✓	✓	0146 0010 0041 0020 0012 0022
2006	Tigra-B	Transmission	MTA(Easvtronic)	✓	✓	✓	✓	✓	0012 0149

2006	Vauxhall Monaro	Engine	V8 GEN IV	✓	✓	✓	✓	✓	0016 0150 0172 0173
2006	Vectra-C/Signum	Body	SDM(Airbag,Sensing&Diagnostic Module)	✓	✓	✓	✓	✓	0000 0001 0002 0003
2006	Vectra-C/Signum	Body	Instrument	✓	✓	✓	✓	✓	0170 0057 0058 0180 0002
2006	Vectra-C/Signum	Body	CIM(Steering Column Module)	✓	✓	✓	✓	✓	0052 0004 0053 0002 0005 0054 0055 0006
2006	Vectra-C/Signum	Body	BCM(Body Control Module)	✓	✓	✓	✓	✓	0181 0182
2006	Vectra-C/Signum	Body	DDM(Driver Door Module)	✓	✓	✓	✓	✓	
2006	Vectra-C/Signum	Body	PDM(Passenger Door Module)	✓	✓	✓	✓	✓	
2006	Vectra-C/Signum	Body	REC(Rear Electrical Centre)	✓	✓	✓	✓	✓	
2006	Vectra-C/Signum	Body	UEC(Underhood Electrical Centre)	✓	✓	✓	✓	✓	
2006	Vectra-C/Signum	Body	SLM(Shift Lever Module)	✓	✓	✓	✓	✓	
2006	Vectra-C/Signum	Body	SRM(Sun Roof Module)	✓	✓	✓	✓	✓	
2006	Vectra-C/Signum	Body	AHL/AFL(Headlamp Levelling)	✓	✓	✓	✓	✓	
2006	Vectra-C/Signum	Body	Electrical Horn	✓	✓	✓	✓	✓	
2006	Vectra-C/Signum	Body	SAC (Automatic Climate Control)	✓	✓	✓	✓	✓	0151 0159 0160 0002 0005 0161
2006	Vectra-C/Signum	Body	Interior Lighting	✓	✓	✓	✓	✓	0183 0060
2006	Vectra-C/Signum	Body	Electronic Seat Memory/Seat Heating	✓	✓	✓	✓	✓	
2006	Vectra-C/Signum	Body	Anti Theft Warning System	✓	✓	✓	✓	✓	
2006	Vectra-C/Signum	Body	Central Door Lock	✓	✓	✓	✓	✓	
2006	Vectra-C/Signum	Body	EHS (Electrical Heater System)	✓	✓	✓	✓	✓	0033 0002 0005
2006	Vectra-C/Signum	Body	PAS (Park Pilot)	✓	✓	✓	✓	✓	0002
2006	Vectra-C/Signum	Chassis	ABS/TC/ESP	✓	✓	✓	✓	✓	0004 0005 0063
2006	Vectra-C/Signum	Chassis	EHPS(Electronic Power Steering)	✓	✓	✓	✓	✓	
2006	Vectra-C/Signum	Chassis	TPMS (Tyre Pressure Monitoring System)	✓	✓	✓	✓	✓	0033
2006	Vectra-C/Signum	Chassis	CDC(Continuous Damping Control)	✓	✓	✓	✓	✓	
2006	Vectra-C/Signum	Chassis	Electronic Cruise Control	✓	✓	✓	✓	✓	
2006	Vectra-C/Signum	Engine	Engine Cooling	✓	✓	✓	✓	✓	
2006	Vectra-C/Signum	Engine	Z16XEP	✓	✓	✓	✓	✓	0011 0012 0067 0014 0150
2006	Vectra-C/Signum	Engine	Z18XE	✓	✓	✓	✓	✓	0020 0011 0012 0067 0150 0013
2006	Vectra-C/Signum	Engine	Z18XER	✓	✓	✓	✓	✓	0020 0010 0011 0012 0067 0150 0034 0013
2006	Vectra-C/Signum	Engine	Z19DT	✓	✓	✓	✓	✓	0150 0011 0012 0067 0024 0025 0070 0021 0013 0027 0030
2006	Vectra-C/Signum	Engine	Z19DTH	✓	✓	✓	✓	✓	0150 0011 0012 0067 0024 0025 0029 0026 0027 0021 0013 0028 0030
2006	Vectra-C/Signum	Engine	Z20DTH	✓	✓	✓	✓	✓	0011 0012 0067 0150
2006	Vectra-C/Signum	Engine	Z22DTR	✓	✓	✓	✓	✓	0011 0012 0067 0150
2006	Vectra-C/Signum	Engine	Z22SE	✓	✓	✓	✓	✓	0011 0012 0067 0150
2006	Vectra-C/Signum	Engine	Z22YH	✓	✓	✓	✓	✓	0020 0150
2006	Vectra-C/Signum	Engine	Z32SE	✓	✓	✓	✓	✓	0020 0150
2006	Vectra-C/Signum	Engine	Z16XE	✓	✓	✓	✓	✓	0011 0012 0067 0150 0013
2006	Vectra-C/Signum	Engine	Z20NET	✓	✓	✓	✓	✓	0011 0012 0067 0150
2006	Vectra-C/Signum	Engine	Z28NEH	✓	✓	✓	✓	✓	0010 0020 0041 0184 0185 0186 0012 0067 0150
2006	Vectra-C/Signum	Engine	Z28NEL	✓	✓	✓	✓	✓	0010 0020 0041 0184 0185 0186 0012 0067 0150
2006	Vectra-C/Signum	Engine	Z28NET	✓	✓	✓	✓	✓	0010 0020 0041 0184 0185 0186 0012 0067 0150
2006	Vectra-C/Signum	Engine	Z30DT	✓	✓	✓	✓	✓	0020 0011 0067 0030
2006	Vectra-C/Signum	Engine	Engine(default)	✓	✓	✓	✓	✓	
2006	Vectra-C/Signum	Transmission	AF 23-5/33-5/40-6	✓	✓	✓	✓	✓	0033 0034
2006	Vectra-C/Signum	Transmission	CVTronic	✓	✓	✓	✓	✓	0187 0188 0189 0033 0004 0034
2006	Vectra-C/Signum	Transmission	MTA(Easytronic)	✓	✓	✓	✓	✓	
2006	Vivaro	Body	Airbag	✓	✓	✓	✓	✓	0005
2006	Vivaro	Body	Add On Heater	✓	✓	✓	✓	✓	0123 0124
2006	Vivaro	Body	Body Control Module	✓	✓	✓	✓	✓	
2006	Vivaro	Chassis	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)	✓	✓	✓	✓	✓	0175 0176
2006	Vivaro	Engine	F9Q 760/762 (1.9L)	✓	✓	✓	✓	✓	
2006	Vivaro	Infotainment System	Trip Info Display TID	✓	✓	✓	✓	✓	
2006	Vivaro	Infotainment System	Radio CAR 2003	✓	✓	✓	✓	✓	
2006	Vivaro	Infotainment System	Radio CDR 2005	✓	✓	✓	✓	✓	
2006	Vivaro	Infotainment System	Radio CCR 2006	✓	✓	✓	✓	✓	
2006	Zafira-B	Body	SDM(Airbag)	✓	✓	✓	✓	✓	0000 0001 0002 0003
2006	Zafira-B	Body	CIM(Steering Column Module)	✓	✓	✓	✓	✓	0052 0004 0053 0002 0005 0054 0055 0006
2006	Zafira-B	Body	IPC ECU(Instrument Control Unit)	✓	✓	✓	✓	✓	
2006	Zafira-B	Body	REC(Rear Electrical Centre)	✓	✓	✓	✓	✓	
2006	Zafira-B	Body	UEC(Underhood Electrical Centre)	✓	✓	✓	✓	✓	
2006	Zafira-B	Body	AHL/AFL(Headlamp Levelling)	✓	✓	✓	✓	✓	
2006	Zafira-B	Body	Exterior Lighting/Turn Indicator System	✓	✓	✓	✓	✓	
2006	Zafira-B	Body	Interior Lighting	✓	✓	✓	✓	✓	
2006	Zafira-B	Body	Wipers/Washer	✓	✓	✓	✓	✓	
2006	Zafira-B	Body	Central Door Lock	✓	✓	✓	✓	✓	
2006	Zafira-B	Body	Instrument	✓	✓	✓	✓	✓	0056 0057 0058
2006	Zafira-B	Body	Immobiliser	✓	✓	✓	✓	✓	
2006	Zafira-B	Body	ECC/SAC(Electronic Climate Control)	✓	✓	✓	✓	✓	0151 0159 0160 0002 0005 0161
2006	Zafira-B	Body	EHS(Electrical Heater System)	✓	✓	✓	✓	✓	0033 0002 0005
2006	Zafira-B	Body	PAS(Park Pilot)	✓	✓	✓	✓	✓	0002
2006	Zafira-B	Body	SLM(Shift Lever Module)	✓	✓	✓	✓	✓	
2006	Zafira-B	Body	PEPS(Open&Start)	✓	✓	✓	✓	✓	
2006	Zafira-B	Body	Anti Theft Warning System	✓	✓	✓	✓	✓	
2006	Zafira-B	Body	IPC ECU(Instrument Control Unit)	✓	✓	✓	✓	✓	0007 0056 0057 0058 0059 0060 0061 0002 0005
2006	Zafira-B	Chassis	ABS/TC/ESP ECU(Electronic Control Unit)	✓	✓	✓	✓	✓	0004 0005 0063
2006	Zafira-B	Chassis	EHPS(Electrohydraulic Power Steering)	✓	✓	✓	✓	✓	
2006	Zafira-B	Chassis	ABS/TC/ESP(Vehicle Dynamic System)	✓	✓	✓	✓	✓	0006
2006	Zafira-B	Chassis	TPMS ECU(Tyre Pressure Monitoring)	✓	✓	✓	✓	✓	0002
2006	Zafira-B	Chassis	TPMS(Tyre Pressure Monitoring System)	✓	✓	✓	✓	✓	
2006	Zafira-B	Chassis	CDC(Continuous Damping Control)	✓	✓	✓	✓	✓	
2006	Zafira-B	Chassis	EHPS(Electrohydraulic Power Steering)	✓	✓	✓	✓	✓	0004
2006	Zafira-B	Engine	Z16XEP	✓	✓	✓	✓	✓	0007 0008 0009 0010 0020 0011 0012 0067 0013 0014 0034 0019
2006	Zafira-B	Engine	Z18XER	✓	✓	✓	✓	✓	0020 0007 0008 0009 0010 0011 0012 0067 0034 0013 0019

2006	Zafira-B	Engine	Z19DT	✓	✓	✓	✓	✓	0007 0008 0009 0011 0012 0067 0024 0025 0070 0013 0033 0021 0030 0027 0028 0026 0029 0019
2006	Zafira-B	Engine	Z19DTH	✓	✓	✓	✓	✓	0007 0008 0009 0033 0011 0012 0067 0024 0025 0029 0026 0027 0028
2006	Zafira-B	Engine	Z16YNG	✓	✓	✓	✓	✓	0007 0008 0009 0010 0020 0011 0012 0067 0013 0014 0034 0019
2006	Zafira-B	Engine	Z16XER	✓	✓	✓	✓	✓	0007 0008 0009 0010 0020 0011 0012 0067 0034 0013 0019
2006	Zafira-B	Engine	Z16XE1	✓	✓	✓	✓	✓	0007 0008 0009 0010 0174 0011 0012 0067 0013 0014 0034 0019
2006	Zafira-B	Engine	Z18XE	✓	✓	✓	✓	✓	0007 0008 0009 0010 0020 0011 0012 0067 0013 0019
2006	Zafira-B	Engine	Z19DTL	✓	✓	✓	✓	✓	0007 0008 0009 0011 0012 0067 0024 0025 0070 0013 0033 0021 0030 0027 0028 0026 0029 0019
2006	Zafira-B	Engine	Z20LER	✓	✓	✓	✓	✓	0007 0008 0009 0010 0011 0012 0067 0013 0014 0019
2006	Zafira-B	Engine	Z20LEH	✓	✓	✓	✓	✓	0007 0008 0009 0010 0011 0012 0067 0013 0014 0019
2006	Zafira-B	Engine	Z22YH	✓	✓	✓	✓	✓	0007 0008 0009 0072 0020 0011 0012 0067 0013 0014 0019
2006	Zafira-B	Engine	Engine(default)	✓	✓	✓	✓	✓	
2006	Zafira-B	Transmission	MTA(Easutronic)	✓	✓	✓	✓	✓	0004 0062 0035 0036
2006	Zafira-B	Transmission	AF 40-6	✓	✓	✓	✓	✓	0073 0074 0075 0076 0077 0078 0033 0004 0034 0079
2006	Zafira-B	Transmission	AF 22-4	✓	✓	✓	✓	✓	0031 0033 0004 0034
2005	Agila	Body	Immobiliser	✓	✓	✓	✓	✓	0140 0141
2005	Agila	Body	Airbag	✓	✓	✓	✓	✓	
2005	Agila	Body	Instrument	✓	✓	✓	✓	✓	
2005	Agila	Chassis	ABS	✓	✓	✓	✓	✓	0190
2005	Agila	Chassis	Electronic Power Steering	✓	✓	✓	✓	✓	
2005	Agila	Engine	Z10XEP	✓	✓	✓	✓	✓	0012 0022 0066 0034
2005	Agila	Engine	Z12XE	✓	✓	✓	✓	✓	0007 0146 0010 0041 0020 0022 0012 0066 0034
2005	Agila	Engine	Z12XEP	✓	✓	✓	✓	✓	0012 0022 0066 0034
2005	Agila	Engine	Z13DT	✓	✓	✓	✓	✓	0020 0041 0022 0012 0021
2005	Agila	Infotainment System	Trip Info Display TID	✓	✓	✓	✓	✓	
2005	Astra-G	Body	Immobiliser	✓	✓	✓	✓	✓	0140 0141
2005	Astra-G	Body	Instrument	✓	✓	✓	✓	✓	
2005	Astra-G	Body	Airbag	✓	✓	✓	✓	✓	
2005	Astra-G	Body	Anti Theft Warning	✓	✓	✓	✓	✓	
2005	Astra-G	Body	Central Door Lock	✓	✓	✓	✓	✓	
2005	Astra-G	Body	Headlamp Levelling Device	✓	✓	✓	✓	✓	0142
2005	Astra-G	Body	Electronic Climate Control	✓	✓	✓	✓	✓	
2005	Astra-G	Body	Engine Cooling Module	✓	✓	✓	✓	✓	
2005	Astra-G	Body	Add On Heater	✓	✓	✓	✓	✓	0123 0124
2005	Astra-G	Chassis	ABS-5.3/5.4(+TC)	✓	✓	✓	✓	✓	
2005	Astra-G	Chassis	ESP	✓	✓	✓	✓	✓	0006
2005	Astra-G	Chassis	Cruise Control	✓	✓	✓	✓	✓	
2005	Astra-G	Chassis	Electronic Power Steering	✓	✓	✓	✓	✓	
2005	Astra-G	Engine	Z12XE	✓	✓	✓	✓	✓	0007 0146 0010 0041 0020 0022 0012 0066 0034
2005	Astra-G	Engine	Z14XE	✓	✓	✓	✓	✓	0147 0146 0010 0020 0022 0012
2005	Astra-G	Engine	Z14XEP	✓	✓	✓	✓	✓	0034 0066 0007 0167 0010 0147 0020 0012 0022
2005	Astra-G	Engine	C16SEL	✓	✓	✓	✓	✓	
2005	Astra-G	Engine	Z16SE	✓	✓	✓	✓	✓	0007 0022 0012
2005	Astra-G	Engine	Z16XE	✓	✓	✓	✓	✓	0007 0022 0012
2005	Astra-G	Engine	Z16XEP	✓	✓	✓	✓	✓	0007 0147 0010 0020 0012 0022 0066
2005	Astra-G	Engine	Z16YNG	✓	✓	✓	✓	✓	0007 0147 0146 0010 0020 0012 0022
2005	Astra-G	Engine	Y17DT	✓	✓	✓	✓	✓	
2005	Astra-G	Engine	Z17DTL	✓	✓	✓	✓	✓	
2005	Astra-G	Engine	Z18XE	✓	✓	✓	✓	✓	0146 0010 0041 0020 0012 0022
2005	Astra-G	Engine	Z18XEL	✓	✓	✓	✓	✓	0012 0022
2005	Astra-G	Engine	Y20DTH	✓	✓	✓	✓	✓	0167 0168 0169 0170
2005	Astra-G	Engine	Z20LET	✓	✓	✓	✓	✓	0010 0020 0041 0146 0012 0022 0066 0034
2005	Astra-G	Engine	Y22DTR	✓	✓	✓	✓	✓	0012 0022
2005	Astra-G	Engine	Z22SE	✓	✓	✓	✓	✓	0066 0147 0146 0010 0012 0022 0034
2005	Astra-G	Infotainment System	Trip Info Display TID	✓	✓	✓	✓	✓	
2005	Astra-G	Infotainment System	Multi Info Display MID	✓	✓	✓	✓	✓	
2005	Astra-G	Infotainment System	Radio CAR 300	✓	✓	✓	✓	✓	
2005	Astra-G	Infotainment System	Radio CAR 400	✓	✓	✓	✓	✓	
2005	Astra-G	Infotainment System	Radio CDR 500	✓	✓	✓	✓	✓	
2005	Astra-G	Infotainment System	Radio CCR 600	✓	✓	✓	✓	✓	
2005	Astra-G	Infotainment System	Radio CCRT 700	✓	✓	✓	✓	✓	
2005	Astra-G	Infotainment System	Radio NCDR 1100/1500	✓	✓	✓	✓	✓	
2005	Astra-G	Transmission	AF 13-II/17/20/22	✓	✓	✓	✓	✓	
2005	Astra-G	Transmission	AF 13-II/17/20/22 CAN	✓	✓	✓	✓	✓	
2005	Astra-G(GMSA)	Body	Airbag	✓	✓	✓	✓	✓	
2005	Astra-G(GMSA)	Body	Anti Theft Warning	✓	✓	✓	✓	✓	
2005	Astra-G(GMSA)	Body	Central Door Lock	✓	✓	✓	✓	✓	
2005	Astra-G(GMSA)	Body	Engine Cooling Module	✓	✓	✓	✓	✓	
2005	Astra-G(GMSA)	Body	Immobiliser	✓	✓	✓	✓	✓	0165 0166
2005	Astra-G(GMSA)	Body	Instrument	✓	✓	✓	✓	✓	
2005	Astra-G(GMSA)	Chassis	ABS-5.3/5.4 (+TC) (Anti-lock Braking System)	✓	✓	✓	✓	✓	
2005	Astra-G(GMSA)	Chassis	Electronic Power Steering	✓	✓	✓	✓	✓	0142
2005	Astra-G(GMSA)	Engine	C 16 SEL	✓	✓	✓	✓	✓	
2005	Astra-G(GMSA)	Engine	Z 18 XE	✓	✓	✓	✓	✓	0146 0010 0041 0020 0012 0022
2005	Astra-G(GMSA)	Engine	Z 22 SE	✓	✓	✓	✓	✓	0147 0010 0146 0012 0022 0066 0034

2005	Astra-G(GMSA)	Infotainment System	Trip Info Display TID	✓	✓	✓					
2005	Astra-H	Body	SDM(Airbag)	✓	✓	✓	✓				
2005	Astra-H	Body	CIM(Steering Column Module)	✓	✓	✓	✓	✓		0052 0004 0053 0002 0005 0054 0055 0006	
2005	Astra-H	Body	IPC ECU(Instrument Control Unit)	✓	✓	✓	✓	✓			
2005	Astra-H	Body	REC(Rear Electrical Centre)	✓	✓	✓	✓	✓			
2005	Astra-H	Body	UEC(Underhood Electrical Centre)	✓	✓	✓	✓	✓			
2005	Astra-H	Body	AHL/AFL(Headlamp Levelling)	✓	✓	✓	✓	✓			
2005	Astra-H	Body	Anti Theft Warning System	✓	✓	✓	✓	✓	✓		
2005	Astra-H	Body	Electrohydraulic HardTop	✓	✓	✓	✓	✓	✓	0002 0005	
2005	Astra-H	Body	ECC/SAC(Electronic Climate Control)	✓	✓	✓	✓	✓	✓	0151 0159 0160 0033 0002 0005 0161	
2005	Astra-H	Body	EHS(Electrical Heater System)	✓	✓	✓	✓	✓	✓	0033 0002 0005	
2005	Astra-H	Body	PAS(Park Pilot)	✓	✓	✓	✓	✓	✓	0002	
2005	Astra-H	Body	SLM(Shift Lever Module)	✓	✓	✓	✓	✓	✓		
2005	Astra-H	Body	PEPS(Open&Start)	✓	✓	✓	✓	✓	✓		
2005	Astra-H	Body	IPC ECU(Instrument Control Unit)	✓	✓	✓	✓	✓	✓	0007 0056 0057 0058 0059 0060 0061 0002 0005	
2005	Astra-H	Chassis	ABS/TC/ESP ECU(Electronic Control Unit)	✓	✓	✓	✓	✓	✓	0004 0005 0063	
2005	Astra-H	Chassis	EHPS(Electrohydraulic Power Steering)	✓	✓	✓	✓	✓	✓		
2005	Astra-H	Chassis	TPMS ECU(Tyre Pressure Monitoring)	✓	✓	✓	✓	✓	✓	0002	
2005	Astra-H	Chassis	TPMS(Tyre Pressure Monitoring System)	✓	✓	✓	✓	✓	✓		
2005	Astra-H	Chassis	CDC(Continuous Damping Control)	✓	✓	✓	✓	✓	✓		
2005	Astra-H	Chassis	ABS/TC/ESP(Vehicle Dynamic System)	✓	✓	✓	✓	✓	✓		
2005	Astra-H	Chassis	EHPS(Electrohydraulic Power Steering)	✓	✓	✓	✓	✓	✓	0004	
2005	Astra-H	Engine	Z13DTH	✓	✓	✓	✓	✓	✓	0007 0008 0009 0020 0011 0012 0067 0021 0030 0029 0026 0027 0019	
2005	Astra-H	Engine	Z14XEP	✓	✓	✓	✓	✓	✓	0007 0008 0009 0010 0011 0012 0067 0013 0014 0019	
2005	Astra-H	Engine	Z16XEP	✓	✓	✓	✓	✓	✓	0007 0008 0009 0010 0020 0011 0012 0067 0013 0014 0034 0019	
2005	Astra-H	Engine	Z17DTH	✓	✓	✓	✓	✓	✓	0007 0008 0009 0011 0012 0067 0021 0025 0013 0030 0033 0019	
2005	Astra-H	Engine	Z18XE	✓	✓	✓	✓	✓	✓	0020 0007 0008 0009 0010 0011 0012 0067 0013 0019	
2005	Astra-H	Engine	Z19DTH	✓	✓	✓	✓	✓	✓	0007 0008 0009 0011 0012 0067 0024 0025 0070 0013 0033 0021 0030 0027 0028 0026 0029 0019	
2005	Astra-H	Engine	Z16XER	✓	✓	✓	✓	✓	✓	0007 0008 0009 0010 0020 0011 0012 0067 0034 0013 0019	
2005	Astra-H	Engine	Z17DTL	✓	✓	✓	✓	✓	✓	0011 0012 0067 0021 0025 0013 0030 0033 0019	
2005	Astra-H	Engine	Z19DT	✓	✓	✓	✓	✓	✓	0007 0008 0009 0011 0012 0067 0024 0025 0070 0013 0033 0021 0030 0027 0028 0026 0029 0019	
2005	Astra-H	Engine	Z19DTJ	✓	✓	✓	✓	✓	✓	0011 0012 0067 0024 0025 0070 0013 0033 0021 0030 0027 0028 0026 0029 0019	
2005	Astra-H	Engine	Z20LEL	✓	✓	✓	✓	✓	✓	0007 0008 0009 0010 0011 0012 0067 0013 0014 0019	
2005	Astra-H	Engine	Z20LEH	✓	✓	✓	✓	✓	✓	0007 0008 0009 0010 0011 0012 0067 0013 0014 0019	
2005	Astra-H	Engine	Z20LER	✓	✓	✓	✓	✓	✓	0007 0008 0009 0010 0011 0012 0067 0013 0014 0019	
2005	Astra-H	Engine	Engine(default)	✓	✓	✓	✓	✓	✓		
2005	Astra-H	Transmission	AF 17-4	✓	✓	✓	✓	✓	✓	0031 0032 0033 0004 0034	
2005	Astra-H	Transmission	MTA(Easytronic)	✓	✓	✓	✓	✓	✓	0004 0062 0035 0036	
2005	Combo	Body	Add On Heater	✓	✓	✓	✓	✓	✓	0123 0124	
2005	Combo	Body	Airbag	✓	✓	✓	✓	✓	✓		
2005	Combo	Body	Body Control Module	✓	✓	✓	✓	✓	✓	0052 0059 0139	
2005	Combo	Body	Immobiliser	✓	✓	✓	✓	✓	✓	0165 0166	
2005	Combo	Body	Instrument	✓	✓	✓	✓	✓	✓		
2005	Combo	Body	Electronic Climate Control	✓	✓	✓	✓	✓	✓		
2005	Combo	Body	HeadLamp Levelling Device	✓	✓	✓	✓	✓	✓	0142	
2005	Combo	Chassis	ABS-5.3/5.4 (+TC) (Anti-lock Braking System)	✓	✓	✓	✓	✓	✓		
2005	Combo	Chassis	Electronic Power Steering	✓	✓	✓	✓	✓	✓	0142	
2005	Combo	Chassis	ABS8/ESP8 (Anti-lock Braking System/Electronic Stability Program)	✓	✓	✓	✓	✓	✓	0006 0143 0144 0145 0005	
2005	Combo	Engine	Z 10 XEP	✓	✓	✓	✓	✓	✓	0012 0022 0066 0034	
2005	Combo	Engine	Z 12 XE	✓	✓	✓	✓	✓	✓	0007 0146 0010 0041 0020 0022 0012 0066 0034	
2005	Combo	Engine	Z 12 XEP	✓	✓	✓	✓	✓	✓	0012 0022 0066 0034	
2005	Combo	Engine	Y 13 DT	✓	✓	✓	✓	✓	✓	0041 0020 0022 0012 0021	
2005	Combo	Engine	Z 13 DT	✓	✓	✓	✓	✓	✓	0041 0020 0022 0012 0021	
2005	Combo	Engine	Z 14 XE	✓	✓	✓	✓	✓	✓	0147 0146 0010 0020 0022 0012	
2005	Combo	Engine	Z 14 XEP	✓	✓	✓	✓	✓	✓	0007 0167 0010 0147 0020 0012 0022 0066 0034	
2005	Combo	Engine	Z 16 SE	✓	✓	✓	✓	✓	✓	0007 0022 0012	
2005	Combo	Engine	Y 17 DT	✓	✓	✓	✓	✓	✓		
2005	Combo	Engine	Y 17 DTL	✓	✓	✓	✓	✓	✓	0007 0022 0012	
2005	Combo	Engine	Z 17 DTH	✓	✓	✓	✓	✓	✓	0007 0147 0020 0023 0012 0022 0021 0148	
2005	Combo	Engine	Z 18 XE	✓	✓	✓	✓	✓	✓	0146 0010 0041 0020 0012 0022	
2005	Combo	Infotainment System	Trip Info Display TID	✓	✓	✓	✓	✓	✓		
2005	Combo	Transmission	AF 13-II/17/20/22	✓	✓	✓	✓	✓	✓		
2005	Combo	Transmission	AF 13-II/17/20/22 CAN	✓	✓	✓	✓	✓	✓		
2005	Combo	Transmission	Easytronic(MTA)	✓	✓	✓	✓	✓	✓	0012 0149	
2005	Corsa-B(GMSA)	Body	Immobiliser	✓	✓	✓	✓	✓	✓	0165 0166	
2005	Corsa-B(GMSA)	Engine	14 NE	✓	✓	✓	✓	✓	✓	0167 0192 0193 0057 0194	
2005	Corsa-B(GMSA)	Engine	16 SE	✓	✓	✓	✓	✓	✓		
2005	Corsa-C	Body	Body Control Module	✓	✓	✓	✓	✓	✓	0052 0059 0139	
2005	Corsa-C	Body	Immobiliser	✓	✓	✓	✓	✓	✓	0140 0141	
2005	Corsa-C	Body	Airbag	✓	✓	✓	✓	✓	✓		
2005	Corsa-C	Body	Instrument	✓	✓	✓	✓	✓	✓	0177 0178	
2005	Corsa-C	Body	Add On Heater	✓	✓	✓	✓	✓	✓	0123 0124	
2005	Corsa-C	Body	Electronic Climate Control	✓	✓	✓	✓	✓	✓		
2005	Corsa-C	Body	HeadLamp Levelling Device	✓	✓	✓	✓	✓	✓	0142	

2005	Corsa-C	Chassis	ABS-5.3/5.4(+TC)	✓	✓	✓	✓	✓	
2005	Corsa-C	Chassis	ABS8/ESP8	✓	✓	✓	✓	✓	0006 0143 0144 0145 0005
2005	Corsa-C	Chassis	Electronic Power Steering	✓	✓	✓	✓	✓	0142
2005	Corsa-C	Engine	Z10XEP	✓	✓	✓	✓	✓	0012 0022 0066 0034
2005	Corsa-C	Engine	Z12XE	✓	✓	✓	✓	✓	0007 0146 0010 0041 0020 0022 0012 0066 0034
2005	Corsa-C	Engine	Z12XEP	✓	✓	✓	✓	✓	0012 0022 0066 0034
2005	Corsa-C	Engine	Y13DT	✓	✓	✓	✓	✓	0041 0020 0022 0012 0021
2005	Corsa-C	Engine	Z13DT	✓	✓	✓	✓	✓	0020 0041 0022 0012 0021
2005	Corsa-C	Engine	Z14XE	✓	✓	✓	✓	✓	0147 0146 0010 0020 0022 0012
2005	Corsa-C	Engine	Z14XEP	✓	✓	✓	✓	✓	0034 0066 0007 0167 0010 0147 0020 0012 0022
2005	Corsa-C	Engine	Z16SE	✓	✓	✓	✓	✓	0007 0022 0012
2005	Corsa-C	Engine	Z16YNG	✓	✓	✓	✓	✓	0007 0147 0146 0010 0020 0012 0022
2005	Corsa-C	Engine	Y17DT	✓	✓	✓	✓	✓	
2005	Corsa-C	Engine	Y17DTL	✓	✓	✓	✓	✓	0007 0022 0012
2005	Corsa-C	Engine	Z17DTH	✓	✓	✓	✓	✓	0007 0147 0020 0021 0148 0023 0012 0022
2005	Corsa-C	Engine	Z18XE	✓	✓	✓	✓	✓	0146 0010 0041 0020 0012 0022
2005	Corsa-C	Infotainment System	Trip Info Display TID	✓	✓	✓	✓	✓	
2005	Corsa-C	Transmission	AF 13-II/17/20/22 CAN	✓	✓	✓	✓	✓	
2005	Corsa-C	Transmission	MTA(Easytronic)	✓	✓	✓	✓	✓	0012 0149
2005	Corsa-C	Transmission	AF 13-II/17/20/22	✓	✓	✓	✓	✓	
2005	Corsa-C(GMSA)	Body	Airbag	✓	✓	✓	✓	✓	
2005	Corsa-C(GMSA)	Body	Body Control Module	✓	✓	✓	✓	✓	0052 0059 0139
2005	Corsa-C(GMSA)	Body	Immobiliser	✓	✓	✓	✓	✓	0165 0166
2005	Corsa-C(GMSA)	Body	Instrument	✓	✓	✓	✓	✓	
2005	Corsa-C(GMSA)	Body	Power Window Lifter Front	✓	✓	✓	✓	✓	
2005	Corsa-C(GMSA)	Body	Power Window Lifter Rear	✓	✓	✓	✓	✓	
2005	Corsa-C(GMSA)	Chassis	ABS-5.3/5.4 (+TC) (Anti-lock Braking System)	✓	✓	✓	✓	✓	
2005	Corsa-C(GMSA)	Chassis	Electronic Power Steering	✓	✓	✓	✓	✓	0142
2005	Corsa-C(GMSA)	Engine	Z 14 XE	✓	✓	✓	✓	✓	0147 0146 0010 0020 0022 0012
2005	Corsa-C(GMSA)	Engine	C 14 SE	✓	✓	✓	✓	✓	0146 0020
2005	Corsa-C(GMSA)	Engine	C 16 SE	✓	✓	✓	✓	✓	0146 0020
2005	Corsa-C(GMSA)	Engine	Y 17 DT	✓	✓	✓	✓	✓	
2005	Corsa-C(GMSA)	Engine	T 17 DTL	✓	✓	✓	✓	✓	0007 0022 0012
2005	Corsa-C(GMSA)	Engine	C 18 XE	✓	✓	✓	✓	✓	0146 0020
2005	Corsa-C(GMSA)	Infotainment System	Trip Info Display TID	✓	✓	✓	✓	✓	
2005	Corsa-C(GMSA)	Infotainment System	Radio CDR 2005	✓	✓	✓	✓	✓	
2005	Corsa-C(GMSA)	Infotainment System	Radio CCRT 2008	✓	✓	✓	✓	✓	
2005	Meriva	Body	Body Control Module	✓	✓	✓	✓	✓	0052 0059 0139
2005	Meriva	Body	Immobiliser	✓	✓	✓	✓	✓	0140 0141
2005	Meriva	Body	Airbag	✓	✓	✓	✓	✓	
2005	Meriva	Body	Instrument	✓	✓	✓	✓	✓	0177 0178
2005	Meriva	Body	Headlamp Levelling Device	✓	✓	✓	✓	✓	0142
2005	Meriva	Body	Electronic Climate Control	✓	✓	✓	✓	✓	
2005	Meriva	Body	Add On Heater	✓	✓	✓	✓	✓	0123 0124
2005	Meriva	Chassis	ABS8/ESP8	✓	✓	✓	✓	✓	0006 0143 0144 0145 0005
2005	Meriva	Chassis	Electronic Power Steering	✓	✓	✓	✓	✓	0142
2005	Meriva	Engine	Y13DT	✓	✓	✓	✓	✓	0041 0020 0022 0012 0021
2005	Meriva	Engine	Z14XEP	✓	✓	✓	✓	✓	0034 0066 0007 0167 0010 0147 0020 0012 0022
2005	Meriva	Engine	Z16SE	✓	✓	✓	✓	✓	0007 0022 0012
2005	Meriva	Engine	Z16XE	✓	✓	✓	✓	✓	0007 0022 0012
2005	Meriva	Engine	Y17DT	✓	✓	✓	✓	✓	
2005	Meriva	Engine	Z17DTH	✓	✓	✓	✓	✓	0007 0147 0020 0021 0148 0023 0012 0022
2005	Meriva	Engine	Z18XE	✓	✓	✓	✓	✓	0146 0010 0041 0020 0012 0022
2005	Meriva	Infotainment System	Trip Info Display TID	✓	✓	✓	✓	✓	
2005	Meriva	Transmission	MTA(Easytronic)	✓	✓	✓	✓	✓	0012 0149
2005	Movano	Body	Airbag	✓	✓	✓	✓	✓	
2005	Movano	Body	Body Control Module	✓	✓	✓	✓	✓	0052 0059 0139
2005	Movano	Chassis	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)	✓	✓	✓	✓	✓	0165 0166
2005	Speedster/VX220	Body	Immobiliser	✓	✓	✓	✓	✓	0140 0141
2005	Speedster/VX220	Body	Airbag	✓	✓	✓	✓	✓	
2005	Speedster/VX220	Chassis	ABS 430	✓	✓	✓	✓	✓	
2005	Speedster/VX220	Engine	Z20LET	✓	✓	✓	✓	✓	
2005	Speedster/VX220	Engine	Z22SE	✓	✓	✓	✓	✓	0066 0147 0146 0010 0012 0022 0034
2005	Tigra-B	Body	Body Control Module	✓	✓	✓	✓	✓	0052 0059 0139
2005	Tigra-B	Body	Immobiliser	✓	✓	✓	✓	✓	0140 0141
2005	Tigra-B	Body	Airbag	✓	✓	✓	✓	✓	
2005	Tigra-B	Body	Instrument	✓	✓	✓	✓	✓	0177 0178
2005	Tigra-B	Chassis	ABS8/ESP8	✓	✓	✓	✓	✓	0006 0143 0144 0145 0005
2005	Tigra-B	Chassis	Electronic Power Steering	✓	✓	✓	✓	✓	0142
2005	Tigra-B	Engine	Z13DT	✓	✓	✓	✓	✓	0020 0041 0022 0012 0021
2005	Tigra-B	Engine	Z14XEP	✓	✓	✓	✓	✓	0034 0066 0007 0167 0010 0147 0020 0012 0022
2005	Tigra-B	Engine	Z18XE	✓	✓	✓	✓	✓	0146 0010 0041 0020 0012 0022
2005	Tigra-B	Transmission	MTA(Easytronic)	✓	✓	✓	✓	✓	0012 0149
2005	Vauxhall Monaro	Engine	V8 GEN IV	✓	✓	✓	✓	✓	0016 0150 0172 0173
2005	Vectra-C/Signum	Body	SDM(Airbag,Sensing&Diagnostic Module)	✓	✓	✓	✓	✓	0000 0001 0002 0003
2005	Vectra-C/Signum	Body	Instrument	✓	✓	✓	✓	✓	0170 0057 0058 0180 0002
2005	Vectra-C/Signum	Body	CIM(Steering Column Module)	✓	✓	✓	✓	✓	0052 0004 0053 0002 0005 0054 0055 0006
2005	Vectra-C/Signum	Body	BCM(Body Control Module)	✓	✓	✓	✓	✓	0181 0182
2005	Vectra-C/Signum	Body	DDM(Driver Door Module)	✓	✓	✓	✓	✓	
2005	Vectra-C/Signum	Body	PDM(Passenger Door Module)	✓	✓	✓	✓	✓	
2005	Vectra-C/Signum	Body	REC(Rear Electrical Centre)	✓	✓	✓	✓	✓	
2005	Vectra-C/Signum	Body	UEC(Underhood Electrical Centre)	✓	✓	✓	✓	✓	
2005	Vectra-C/Signum	Body	SLM(Shift Lever Module)	✓	✓	✓	✓	✓	
2005	Vectra-C/Signum	Body	SRM(Sun Roof Module)	✓	✓	✓	✓	✓	
2005	Vectra-C/Signum	Body	AHL/AFL(Headlamp Levelling)	✓	✓	✓	✓	✓	
2005	Vectra-C/Signum	Body	Electrical Horn	✓	✓	✓	✓	✓	
2005	Vectra-C/Signum	Body	Electronic Seat Memory/Seat Heating	✓	✓	✓	✓	✓	
2005	Vectra-C/Signum	Body	Anti Theft Warning System	✓	✓	✓	✓	✓	

2005	Vectra-C/Signum	Body	Central Door Lock	✓	✓	✓	✓		
2005	Vectra-C/Signum	Body	PAS (Park Pilot)	✓	✓	✓	✓	✓	0002
2005	Vectra-C/Signum	Chassis	ABS/TC/ESP	✓	✓	✓	✓	✓	0004 0005 0063
2005	Vectra-C/Signum	Chassis	EHPS(Electronic Power Steering)	✓	✓	✓	✓		
2005	Vectra-C/Signum	Chassis	TPMS (Tyre Pressure Monitoring System)	✓	✓	✓	✓		0033
2005	Vectra-C/Signum	Chassis	CDC(Continuous Damping Control)	✓	✓	✓			
2005	Vectra-C/Signum	Chassis	Electronic Cruise Control	✓	✓	✓			
2005	Vectra-C/Signum	Engine	Engine Cooling	✓	✓	✓	✓		
2005	Vectra-C/Signum	Engine	Z18XE	✓	✓	✓	✓	✓	0020 0011 0012 0067 0150 0013
2005	Vectra-C/Signum	Engine	Z19DT	✓	✓	✓	✓	✓	0150 0011 0012 0067 0024 0025 0070 0021 0013 0027 0030
2005	Vectra-C/Signum	Engine	Z19DTH	✓	✓	✓	✓	✓	0150 0011 0012 0067 0024 0025 0029 0026 0027 0021 0013 0028 0030
2005	Vectra-C/Signum	Engine	Y20DTH	✓	✓	✓	✓	✓	0011 0012 0067 0150
2005	Vectra-C/Signum	Engine	Y22DTR	✓	✓	✓	✓	✓	0011 0012 0067 0150
2005	Vectra-C/Signum	Engine	Y30DT	✓	✓	✓	✓	✓	
2005	Vectra-C/Signum	Engine	Z22SE	✓	✓	✓	✓	✓	0011 0012 0067 0150
2005	Vectra-C/Signum	Engine	Z22YH	✓	✓	✓	✓	✓	0020 0150
2005	Vectra-C/Signum	Engine	Z32SE	✓	✓	✓	✓	✓	0020 0150
2005	Vectra-C/Signum	Engine	Z16XE	✓	✓	✓	✓	✓	0011 0012 0067 0150 0013
2005	Vectra-C/Signum	Engine	Z20NET	✓	✓	✓	✓	✓	0011 0012 0067 0150
2005	Vectra-C/Signum	Engine	Engine(default)	✓	✓	✓			
2005	Vectra-C/Signum	Transmission	AF 23-5/33-5/40-6	✓	✓	✓	✓	✓	0033 0034
2005	Vectra-C/Signum	Transmission	CVTronic	✓	✓	✓	✓	✓	0187 0188 0189 0033 0004 0034
2005	Vivaro	Body	Airbag	✓	✓	✓	✓		0005
2005	Vivaro	Body	Add On Heater	✓	✓	✓	✓	✓	0123 0124
2005	Vivaro	Body	Body Control Module		✓	✓	✓	✓	
2005	Vivaro	Chassis	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)	✓	✓	✓	✓	✓	0175 0176
2005	Vivaro	Engine	F9Q 760/762 (1.9L)	✓	✓	✓	✓	✓	
2005	Vivaro	Infotainment System	Trip Info Display TID	✓	✓	✓			
2005	Vivaro	Infotainment System	Radio CAR 2003	✓	✓	✓			
2005	Vivaro	Infotainment System	Radio CDR 2005	✓	✓	✓	✓		
2005	Vivaro	Infotainment System	Radio CCR 2006	✓	✓	✓	✓		
2005	Zafira	Body	Immobiliser	✓	✓	✓	✓		0140 0141
2005	Zafira	Body	Instrument	✓	✓	✓	✓		
2005	Zafira	Body	Airbag	✓	✓	✓	✓	✓	
2005	Zafira	Body	Anti Theft Warning	✓	✓	✓	✓		
2005	Zafira	Body	Central Door Lock	✓	✓	✓	✓		
2005	Zafira	Body	Electronic Climate Control	✓	✓	✓	✓		
2005	Zafira	Body	Engine Cooling Module	✓	✓	✓	✓		
2005	Zafira	Body	Headlamp Adjustment(Left)	✓	✓	✓	✓		
2005	Zafira	Body	Headlamp Adjustment(Right)	✓	✓	✓	✓		
2005	Zafira	Chassis	ABS-5.3/5.4(+TC)	✓	✓	✓	✓	✓	
2005	Zafira	Chassis	ESP	✓	✓	✓	✓	✓	0006
2005	Zafira	Chassis	Electronic Power Steering	✓	✓	✓	✓	✓	0142
2005	Zafira	Engine	Z16XE	✓	✓	✓	✓	✓	0007 0022 0012
2005	Zafira	Engine	Z16YNG	✓	✓	✓	✓	✓	
2005	Zafira	Engine	Z18XE	✓	✓	✓	✓	✓	0146 0010 0041 0020 0012 0022
2005	Zafira	Engine	Y20DTH	✓	✓	✓	✓	✓	0167 0168 0169 0170
2005	Zafira	Engine	Z20LET	✓	✓	✓	✓	✓	0010 0020 0041 0146 0012 0022 0066 0034
2005	Zafira	Engine	Y22DTR	✓	✓	✓	✓	✓	0012 0022
2005	Zafira	Engine	Z22SE	✓	✓	✓	✓	✓	0066 0147 0146 0010 0012 0022 0034
2005	Zafira	Engine	Z18XEL	✓	✓	✓	✓	✓	0146 0010 0041 0020
2005	Zafira	Infotainment System	Radio CAR 300	✓	✓	✓	✓		
2005	Zafira	Infotainment System	Trip Info Display TID	✓	✓	✓			
2005	Zafira	Infotainment System	Multi Info Display MID	✓	✓	✓	✓		
2005	Zafira	Infotainment System	Radio CAR 400	✓	✓	✓	✓		
2005	Zafira	Infotainment System	Radio CDR 500	✓	✓	✓	✓		
2005	Zafira	Infotainment System	Radio CCR 600	✓	✓	✓	✓		
2005	Zafira	Infotainment System	Radio CCRT 700	✓	✓	✓	✓		
2005	Zafira	Infotainment System	Radio NCDR 1100/1500	✓	✓	✓	✓		
2005	Zafira	Transmission	AF 13-11/17/20/22 CAN	✓	✓	✓	✓	✓	
2005	Zafira-B	Body	SDM(Airbag)	✓	✓	✓	✓	✓	0000 0001 0002 0003
2005	Zafira-B	Body	CIW(Steering Column Module)	✓	✓	✓	✓	✓	0067
2005	Zafira-B	Body	IPC ECU(Instrument Control Unit)	✓	✓	✓	✓	✓	0034
2005	Zafira-B	Body	REC(Rear Electrical Centre)	✓	✓	✓	✓	✓	0013
2005	Zafira-B	Body	UEC(Underhood Electrical Centre)	✓	✓	✓	✓	✓	0019
2005	Zafira-B	Body	AHL/AFL(Headlamp Levelling)	✓	✓	✓	✓	✓	
2005	Zafira-B	Body	ECC/SAC(Electronic Climate Control)	✓	✓	✓	✓	✓	0151 0159 0160 0002 0005 0161
2005	Zafira-B	Body	EHS(Electrical Heater System)	✓	✓	✓	✓	✓	0033 0002 0005
2005	Zafira-B	Body	PAS(Park Pilot)	✓	✓	✓	✓	✓	0002
2005	Zafira-B	Body	SLM(Shift Lever Module)	✓	✓	✓	✓		
2005	Zafira-B	Body	PEPS(Open&Start)	✓	✓	✓	✓		
2005	Zafira-B	Body	Anti Theft Warning System	✓	✓	✓	✓	✓	
2005	Zafira-B	Body	IPC ECU(Instrument Control Unit)	✓	✓	✓	✓	✓	0007 0056 0057 0058 0059 0060 0061 0002 0005
2005	Zafira-B	Chassis	ABS/TC/ESP ECU(Electronic Control Unit)	✓	✓	✓	✓	✓	0004 0005 0063
2005	Zafira-B	Chassis	EHPS(Electrohydraulic Power Steering)	✓	✓	✓	✓	✓	0011
2005	Zafira-B	Chassis	ABS/TC/ESP(Vehicle Dynamic System)	✓	✓	✓	✓	✓	0006
2005	Zafira-B	Chassis	TPMS ECU(Tyre Pressure Monitoring)	✓	✓	✓	✓	✓	0002
2005	Zafira-B	Chassis	TPMS(Tyre Pressure Monitoring System)	✓	✓	✓	✓		
2005	Zafira-B	Chassis	CDC(Continuous Damping Control)	✓	✓	✓	✓	✓	
2005	Zafira-B	Chassis	EHPS(Electrohydraulic Power Steering)	✓	✓	✓	✓	✓	0004
2005	Zafira-B	Engine	Z16XEP	✓	✓	✓	✓		0007 0008 0009 0010 0020 0011 0012 0067 0013 0014 0034 0019
2005	Zafira-B	Engine	Z18XER	✓	✓	✓	✓		0020 0007 0008 0009 0010 0011 0012 0067 0034 0013 0019
2005	Zafira-B	Engine	Z19DT	✓	✓	✓	✓	✓	0007 0008 0009 0011 0012 0067 0024 0025 0070 0013 0033 0021 0030 0027 0028 0026 0029 0019

2005	Zafira-B	Engine	Z19DTH	✓	✓	✓	✓	✓	0007 0008 0009 0033 0011 0012 0067 0024 0025 0029 0026 0027 0028
2005	Zafira-B	Engine	Z16XE1	✓	✓	✓	✓	✓	0007 0008 0009 0010 0174 0011 0012 0067 0013 0014 0034 0019
2005	Zafira-B	Engine	Z16XEP	✓	✓	✓	✓	✓	0007 0008 0009 0010 0020 0011 0012 0067 0013 0014 0034 0019
2005	Zafira-B	Engine	Z18XE	✓	✓	✓	✓	✓	0007 0008 0009 0010 0020 0011 0012 0067 0013 0019
2005	Zafira-B	Engine	Z20LER	✓	✓	✓	✓	✓	0007 0008 0009 0010 0011 0012 0067 0013 0014 0019
2005	Zafira-B	Engine	Z22YH	✓	✓	✓	✓	✓	0007 0008 0009 0072 0020 0011 0012 0067 0013 0014 0019
2005	Zafira-B	Engine	Engine(default)	✓	✓	✓	✓	✓	
2005	Zafira-B	Transmission	MTA(Easutronic)	✓	✓	✓	✓	✓	0004 0062 0035 0036
2005	Zafira-B	Transmission	AF 40-6	✓	✓	✓	✓	✓	0073 0074 0075 0076 0077 0078 0033 0004 0034 0079
2005	Zafira-B	Transmission	AF 22-4	✓	✓	✓	✓	✓	0031 0033 0004 0034
2004	Agila	Body	Immobiliser	✓	✓	✓	✓	✓	0140 0141
2004	Agila	Body	Airbag	✓	✓	✓	✓	✓	
2004	Agila	Body	Instrument	✓	✓	✓	✓	✓	
2004	Agila	Chassis	ABS	✓	✓	✓	✓	✓	0190
2004	Agila	Chassis	Electronic Power Steering	✓	✓	✓	✓	✓	
2004	Agila	Engine	Z10XEP	✓	✓	✓	✓	✓	0012 0022 0066 0034
2004	Agila	Engine	Z12XE	✓	✓	✓	✓	✓	0007 0146 0010 0041 0020 0022 0012 0066 0034
2004	Agila	Engine	Z13DT	✓	✓	✓	✓	✓	0020 0041 0022 0012 0021
2004	Agila	Infotainment System	Trip Info Display TID	✓	✓	✓	✓	✓	
2004	Agila	Infotainment System	Radio CAR 2003	✓	✓	✓	✓	✓	
2004	Agila	Infotainment System	Radio CDR 2005	✓	✓	✓	✓	✓	
2004	Astra-G	Body	Immobiliser	✓	✓	✓	✓	✓	0140 0141
2004	Astra-G	Body	Instrument	✓	✓	✓	✓	✓	
2004	Astra-G	Body	Airbag	✓	✓	✓	✓	✓	
2004	Astra-G	Body	Anti Theft Warning	✓	✓	✓	✓	✓	
2004	Astra-G	Body	Central Door Lock	✓	✓	✓	✓	✓	
2004	Astra-G	Body	Headlamp Levelling Device	✓	✓	✓	✓	✓	0142
2004	Astra-G	Body	Electronic Climate Control	✓	✓	✓	✓	✓	
2004	Astra-G	Body	Engine Cooling Module	✓	✓	✓	✓	✓	
2004	Astra-G	Body	Add On Heater	✓	✓	✓	✓	✓	0123 0124
2004	Astra-G	Body	Softtop Controller	✓	✓	✓	✓	✓	
2004	Astra-G	Chassis	ABS-5.3/5.4(+TC)	✓	✓	✓	✓	✓	
2004	Astra-G	Chassis	ESP	✓	✓	✓	✓	✓	0006
2004	Astra-G	Chassis	Cruise Control	✓	✓	✓	✓	✓	
2004	Astra-G	Chassis	Electronic Power Steering	✓	✓	✓	✓	✓	
2004	Astra-G	Engine	Z12XE	✓	✓	✓	✓	✓	0007 0146 0010 0041 0020 0022 0012 0066 0034
2004	Astra-G	Engine	Z14XE	✓	✓	✓	✓	✓	0147 0146 0010 0020 0022 0012
2004	Astra-G	Engine	C16SEL	✓	✓	✓	✓	✓	
2004	Astra-G	Engine	Z16SE	✓	✓	✓	✓	✓	0007 0022 0012
2004	Astra-G	Engine	Z16XE	✓	✓	✓	✓	✓	0007 0022 0012
2004	Astra-G	Engine	Z16XEP	✓	✓	✓	✓	✓	0007 0147 0010 0020 0012 0022 0066
2004	Astra-G	Engine	Z16VNG	✓	✓	✓	✓	✓	0007 0147 0146 0010 0020 0012 0022
2004	Astra-G	Engine	Y17DT	✓	✓	✓	✓	✓	
2004	Astra-G	Engine	Z17DTL	✓	✓	✓	✓	✓	
2004	Astra-G	Engine	Z18XE	✓	✓	✓	✓	✓	0146 0010 0041 0020 0012 0022
2004	Astra-G	Engine	Z18XEL	✓	✓	✓	✓	✓	0012 0022
2004	Astra-G	Engine	Y20DTH	✓	✓	✓	✓	✓	0167 0168 0169 0170
2004	Astra-G	Engine	Z20LET	✓	✓	✓	✓	✓	0010 0020 0041 0146 0012 0022 0066 0034
2004	Astra-G	Engine	Y22DTR	✓	✓	✓	✓	✓	0012 0022
2004	Astra-G	Engine	Z22SE	✓	✓	✓	✓	✓	0066 0147 0146 0010 0012 0022 0034
2004	Astra-G	Infotainment System	Trip Info Display TID	✓	✓	✓	✓	✓	
2004	Astra-G	Infotainment System	Multi Info Display MID	✓	✓	✓	✓	✓	
2004	Astra-G	Infotainment System	Radio CAR 300	✓	✓	✓	✓	✓	
2004	Astra-G	Infotainment System	Radio CAR 400	✓	✓	✓	✓	✓	
2004	Astra-G	Infotainment System	Radio CDR 500	✓	✓	✓	✓	✓	
2004	Astra-G	Infotainment System	Radio CCR 600	✓	✓	✓	✓	✓	
2004	Astra-G	Infotainment System	Radio CCRT 700	✓	✓	✓	✓	✓	
2004	Astra-G	Infotainment System	Radio NCDR 1100/1500	✓	✓	✓	✓	✓	
2004	Astra-G	Transmission	AF 13-II/17/20/22	✓	✓	✓	✓	✓	
2004	Astra-G	Transmission	AF 13-II/17/20/22 CAN	✓	✓	✓	✓	✓	
2004	Astra-G(GMSA)	Body	Airbag	✓	✓	✓	✓	✓	
2004	Astra-G(GMSA)	Body	Anti Theft Warning	✓	✓	✓	✓	✓	
2004	Astra-G(GMSA)	Body	Engine Cooling Module	✓	✓	✓	✓	✓	
2004	Astra-G(GMSA)	Body	Central Door Lock	✓	✓	✓	✓	✓	
2004	Astra-G(GMSA)	Body	Immobiliser	✓	✓	✓	✓	✓	0165 0166
2004	Astra-G(GMSA)	Body	Instrument	✓	✓	✓	✓	✓	
2004	Astra-G(GMSA)	Chassis	ABS-5.3/5.4 (+TC) (Anti-lock Braking System)	✓	✓	✓	✓	✓	
2004	Astra-G(GMSA)	Chassis	Electronic Power Steering	✓	✓	✓	✓	✓	
2004	Astra-G(GMSA)	Engine	C 16 SEL	✓	✓	✓	✓	✓	
2004	Astra-G(GMSA)	Engine	Z 18 XE	✓	✓	✓	✓	✓	0146 0010 0041 0020 0012 0022
2004	Astra-G(GMSA)	Engine	Z 22 SE	✓	✓	✓	✓	✓	0147 0010 0146 0012 0022 0066 0034
2004	Astra-G(GMSA)	Infotainment System	Trip Info Display TID	✓	✓	✓	✓	✓	
2004	Astra-H	Body	SDM(Airbag)	✓	✓	✓	✓	✓	
2004	Astra-H	Body	CIM(Steering Column Module)	✓	✓	✓	✓	✓	0052 0004 0053 0002 0005 0054 0055 0006
2004	Astra-H	Body	IPC ECU(Instrument Control Unit)	✓	✓	✓	✓	✓	
2004	Astra-H	Body	REC(Rear Electrical Centre)	✓	✓	✓	✓	✓	
2004	Astra-H	Body	UEC(Underhood Electrical Centre)	✓	✓	✓	✓	✓	
2004	Astra-H	Body	AHL/AFL (Headlamp Levelling)	✓	✓	✓	✓	✓	
2004	Astra-H	Body	Anti Theft Warning System	✓	✓	✓	✓	✓	
2004	Astra-H	Body	Electrohydraulic HardTop	✓	✓	✓	✓	✓	0002 0005
2004	Astra-H	Body	ECC/SAC (Electronic Climate Control)	✓	✓	✓	✓	✓	0151 0159 0160 0033 0002 0005 0161

2004	Astra-H	Body	EHS (Electrical Heater System)	✓	✓	✓	✓	0033 0002 0005
2004	Astra-H	Body	PAS (Park Pilot)	✓	✓	✓	✓	0002
2004	Astra-H	Body	SLM (Shift Lever Module)	✓	✓	✓	✓	
2004	Astra-H	Body	PEPS (Open&Start)	✓	✓	✓	✓	
2004	Astra-H	Body	IPC ECU(Instrument Control Unit)	✓	✓	✓	✓	0007 0056 0057 0058 0059 0060 0061 0002 0005
2004	Astra-H	Chassis	ABS/TC/ESP ECU(Electronic Control Unit)	✓	✓	✓	✓	0004 0005 0063
2004	Astra-H	Chassis	EHPS(Electrohydraulic Power Steering)	✓	✓	✓	✓	
2004	Astra-H	Chassis	CDC (Continuous Damping Control)	✓	✓	✓	✓	
2004	Astra-H	Chassis	ABS/TC/ESP (Vehicle Dynamic System)	✓	✓	✓	✓	
2004	Astra-H	Chassis	EHPS(Electrohydraulic Power Steering)	✓	✓	✓	✓	0004
2004	Astra-H	Engine	Z14XEP	✓	✓	✓	✓	0007 0008 0009 0010 0011 0012 0067 0013 0014 0019
2004	Astra-H	Engine	Z16XEP	✓	✓	✓	✓	0007 0008 0009 0010 0020 0011 0012 0067 0013 0014 0034 0019
2004	Astra-H	Engine	Z17DTH	✓	✓	✓	✓	0007 0008 0009 0011 0012 0067 0021 0025 0013 0030 0033 0019
2004	Astra-H	Engine	Z18XE	✓	✓	✓	✓	0020 0007 0008 0009 0010 0011 0012 0067 0013 0019
2004	Astra-H	Engine	Z16XER	✓	✓	✓	✓	0007 0008 0009 0010 0020 0011 0012 0067 0034 0013 0019
2004	Astra-H	Engine	Z17DTL	✓	✓	✓	✓	0011 0012 0067 0021 0025 0013 0030 0033 0019
2004	Astra-H	Engine	Z19DT	✓	✓	✓	✓	0007 0008 0009 0011 0012 0067 0024 0025 0070 0013 0033 0021 0030 0027 0028 0026 0029 0019
2004	Astra-H	Engine	Z20LEL	✓	✓	✓	✓	0007 0008 0009 0010 0011 0012 0067 0013 0014 0019
2004	Astra-H	Engine	Z20LER	✓	✓	✓	✓	0007 0008 0009 0010 0011 0012 0067 0013 0014 0019
2004	Astra-H	Engine	Engine(default)	✓	✓	✓	✓	
2004	Astra-H	Transmission	AF 17-4	✓	✓	✓	✓	0031 0032 0033 0004 0034
2004	Astra-H	Transmission	MTA(Easytronic)	✓	✓	✓	✓	0004 0062 0035 0036
2004	Combo	Body	Add On Heater	✓	✓	✓	✓	0123 0124
2004	Combo	Body	Airbag	✓	✓	✓	✓	
2004	Combo	Body	Body Control Module	✓	✓	✓	✓	0052 0059 0139
2004	Combo	Body	Immobiliser	✓	✓	✓	✓	0165 0166
2004	Combo	Body	Instrument	✓	✓	✓	✓	
2004	Combo	Body	Electronic Climate Control	✓	✓	✓	✓	
2004	Combo	Body	HeadLamp Levelling Device	✓	✓	✓	✓	0142
2004	Combo	Chassis	ABS-5.3/5.4 (+TC) (Anti-lock Braking System)	✓	✓	✓	✓	
2004	Combo	Chassis	Electronic Power Steering	✓	✓	✓	✓	0142
2004	Combo	Chassis	ABS/ESP8 (Anti-lock Braking System/Electronic Stability Program)	✓	✓	✓	✓	0006 0143 0144 0145 0005
2004	Combo	Engine	Z 10 XEP	✓	✓	✓	✓	0012 0022 0066 0034
2004	Combo	Engine	Z 12 XE	✓	✓	✓	✓	0007 0146 0010 0041 0020 0022 0012 0066 0034
2004	Combo	Engine	Z 13 DT	✓	✓	✓	✓	0041 0020 0022 0012 0021
2004	Combo	Engine	Z 14 XE	✓	✓	✓	✓	0147 0146 0010 0020 0022 0012
2004	Combo	Engine	Z 14 XEP	✓	✓	✓	✓	0007 0167 0010 0147 0020 0012 0022 0066 0034
2004	Combo	Engine	Z 16 SE	✓	✓	✓	✓	0007 0022 0012
2004	Combo	Engine	Y 17 DT	✓	✓	✓	✓	
2004	Combo	Engine	Y 17 DTL	✓	✓	✓	✓	0007 0022 0012
2004	Combo	Engine	Z 17 DTH	✓	✓	✓	✓	0007 0147 0020 0023 0012 0022 0021 0148
2004	Combo	Engine	Z 18 XE	✓	✓	✓	✓	0146 0010 0041 0020 0012 0022
2004	Combo	Infotainment System	Trip Info Display TID	✓	✓	✓	✓	
2004	Combo	Infotainment System	Radio CAR 2003	✓	✓	✓	✓	
2004	Combo	Infotainment System	Radio CDR 2005	✓	✓	✓	✓	
2004	Combo	Infotainment System	Radio CCR 2006	✓	✓	✓	✓	
2004	Combo	Transmission	AF 13-II/17/20/22	✓	✓	✓	✓	
2004	Combo	Transmission	AF 13-II/17/20/22 CAN	✓	✓	✓	✓	
2004	Combo	Transmission	Easytronic(MTA)	✓	✓	✓	✓	0012 0149
2004	Corsa-B(GMSA)	Body	Immobiliser	✓	✓	✓	✓	0165 0166
2004	Corsa-B(GMSA)	Engine	14 NE	✓	✓	✓	✓	0167 0191 0192 0057 0193
2004	Corsa-B(GMSA)	Engine	16 SE	✓	✓	✓	✓	
2004	Corsa-C	Body	Body Control Module	✓	✓	✓	✓	0052 0059 0139
2004	Corsa-C	Body	Immobiliser	✓	✓	✓	✓	0140 0141
2004	Corsa-C	Body	Airbag	✓	✓	✓	✓	
2004	Corsa-C	Body	Instrument	✓	✓	✓	✓	0177 0178
2004	Corsa-C	Body	Add On Heater	✓	✓	✓	✓	0123 0124
2004	Corsa-C	Body	Electronic Climate Control	✓	✓	✓	✓	
2004	Corsa-C	Body	HeadLamp Levelling Device	✓	✓	✓	✓	0142
2004	Corsa-C	Chassis	ABS-5.3/5.4(+TC)	✓	✓	✓	✓	
2004	Corsa-C	Chassis	ABS/ESP8	✓	✓	✓	✓	0006 0143 0144 0145 0005
2004	Corsa-C	Chassis	Electronic Power Steering	✓	✓	✓	✓	0142
2004	Corsa-C	Engine	Z10XEP	✓	✓	✓	✓	0012 0022 0066 0034
2004	Corsa-C	Engine	Z12XE	✓	✓	✓	✓	0007 0146 0010 0041 0020 0022 0012 0066 0034
2004	Corsa-C	Engine	Z13DT	✓	✓	✓	✓	0020 0041 0022 0012 0021
2004	Corsa-C	Engine	Z14XE	✓	✓	✓	✓	0147 0146 0010 0020 0022 0012
2004	Corsa-C	Engine	Z14XEP	✓	✓	✓	✓	0034 0066 0007 0167 0010 0147 0020 0012 0022
2004	Corsa-C	Engine	Z16SE	✓	✓	✓	✓	0007 0022 0012
2004	Corsa-C	Engine	Y17DT	✓	✓	✓	✓	
2004	Corsa-C	Engine	Y17DTL	✓	✓	✓	✓	0007 0022 0012
2004	Corsa-C	Engine	Z17DTH	✓	✓	✓	✓	0007 0147 0020 0021 0148 0023 0012 0022
2004	Corsa-C	Engine	Z18XE	✓	✓	✓	✓	0146 0010 0041 0020 0012 0022
2004	Corsa-C	Infotainment System	Trip Info Display TID	✓	✓	✓	✓	
2004	Corsa-C	Infotainment System	Radio CAR 2003	✓	✓	✓	✓	
2004	Corsa-C	Infotainment System	Radio CDR 2005	✓	✓	✓	✓	
2004	Corsa-C	Infotainment System	Radio CCR 2006	✓	✓	✓	✓	
2004	Corsa-C	Transmission	AF 13-II/17/20/22 CAN	✓	✓	✓	✓	
2004	Corsa-C	Transmission	MTA(Easytronic)	✓	✓	✓	✓	0012 0149
2004	Corsa-C	Transmission	AF 13-II/17/20/22	✓	✓	✓	✓	

2004	Corsa-C(GMSA)	Body	Airbag	✓	✓	✓	✓	✓	
2004	Corsa-C(GMSA)	Body	Body Control Module	✓	✓	✓	✓	✓	0052 0059 0139
2004	Corsa-C(GMSA)	Body	Immobiliser	✓	✓	✓	✓	✓	0165 0166
2004	Corsa-C(GMSA)	Body	Instrument	✓	✓	✓	✓	✓	
2004	Corsa-C(GMSA)	Body	Power Window Lifter Front	✓	✓	✓	✓	✓	
2004	Corsa-C(GMSA)	Body	Power Window Lifter Rear	✓	✓	✓	✓	✓	
2004	Corsa-C(GMSA)	Chassis	ABS-5.3/5.4 (+TC) (Anti-lock Braking System)	✓	✓	✓	✓	✓	
2004	Corsa-C(GMSA)	Chassis	Electronic Power Steering	✓	✓	✓	✓	✓	0142
2004	Corsa-C(GMSA)	Engine	C 14 SE	✓	✓	✓	✓	✓	0146 0020
2004	Corsa-C(GMSA)	Engine	C 16 SE	✓	✓	✓	✓	✓	0146 0020
2004	Corsa-C(GMSA)	Engine	Y 17 DT	✓	✓	✓	✓	✓	
2004	Corsa-C(GMSA)	Engine	T 17 DTL	✓	✓	✓	✓	✓	0007 0022 0012
2004	Corsa-C(GMSA)	Engine	C 18 XE	✓	✓	✓	✓	✓	0146 0020
2004	Corsa-C(GMSA)	Infotainment System	Trip Info Display TID	✓	✓	✓	✓	✓	
2004	Corsa-C(GMSA)	Infotainment System	Radio CDR 2005	✓	✓	✓	✓	✓	
2004	Corsa-C(GMSA)	Infotainment System	Radio CCRT 2008	✓	✓	✓	✓	✓	
2004	Meriva	Body	Body Control Module	✓	✓	✓	✓	✓	0052 0059 0139
2004	Meriva	Body	Immobiliser	✓	✓	✓	✓	✓	0140 0141
2004	Meriva	Body	Airbag	✓	✓	✓	✓	✓	
2004	Meriva	Body	Instrument	✓	✓	✓	✓	✓	0177 0178
2004	Meriva	Body	Headlamp Levelling Device	✓	✓	✓	✓	✓	0142
2004	Meriva	Body	Electronic Climate Control	✓	✓	✓	✓	✓	
2004	Meriva	Body	Add On Heater	✓	✓	✓	✓	✓	0123 0124
2004	Meriva	Chassis	ABS-5.3/5.4(+TC)	✓	✓	✓	✓	✓	
2004	Meriva	Chassis	ESP	✓	✓	✓	✓	✓	0006
2004	Meriva	Chassis	Electronic Power Steering	✓	✓	✓	✓	✓	0142
2004	Meriva	Engine	Z16SE	✓	✓	✓	✓	✓	0007 0022 0012
2004	Meriva	Engine	Z16XE	✓	✓	✓	✓	✓	0007 0022 0012
2004	Meriva	Engine	Y17DT	✓	✓	✓	✓	✓	
2004	Meriva	Engine	Z17DTH	✓	✓	✓	✓	✓	0007 0147 0020 0021 0148 0023 0012 0022
2004	Meriva	Engine	Z18XE	✓	✓	✓	✓	✓	0146 0010 0041 0020 0012 0022
2004	Meriva	Infotainment System	Trip Info Display TID	✓	✓	✓	✓	✓	
2004	Meriva	Infotainment System	Radio CAR 2003	✓	✓	✓	✓	✓	
2004	Meriva	Infotainment System	Radio CDR 2005	✓	✓	✓	✓	✓	
2004	Meriva	Infotainment System	Radio CCR 2006	✓	✓	✓	✓	✓	
2004	Meriva	Transmission	MTA(Easytronic)	✓	✓	✓	✓	✓	0012 0149
2004	Movano	Body	Airbag	✓	✓	✓	✓	✓	
2004	Movano	Body	Immobiliser	✓	✓	✓	✓	✓	0165 0166
2004	Movano	Chassis	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)	✓	✓	✓	✓	✓	0165 0166
2004	Speedster/VX220	Body	Immobiliser	✓	✓	✓	✓	✓	0140 0141
2004	Speedster/VX220	Body	Airbag	✓	✓	✓	✓	✓	
2004	Speedster/VX220	Chassis	ABS 430	✓	✓	✓	✓	✓	
2004	Speedster/VX220	Engine	Z20LET	✓	✓	✓	✓	✓	
2004	Speedster/VX220	Engine	Z22SE	✓	✓	✓	✓	✓	0066 0147 0146 0010 0012 0022 0034
2004	Vectra-C/Signum	Body	SDM(Airbag,Sensing&Diagnostic Module)	✓	✓	✓	✓	✓	0000 0001 0002 0003
2004	Vectra-C/Signum	Body	Instrument	✓	✓	✓	✓	✓	0170 0057 0058 0180 0002
2004	Vectra-C/Signum	Body	CIM(Steering Column Module)	✓	✓	✓	✓	✓	0052 0004 0053 0002 0005 0054 0055 0006
2004	Vectra-C/Signum	Body	BCM(Body Control Module)	✓	✓	✓	✓	✓	0181 0182
2004	Vectra-C/Signum	Body	DDM(Driver Door Module)	✓	✓	✓	✓	✓	
2004	Vectra-C/Signum	Body	PDM(Passenger Door Module)	✓	✓	✓	✓	✓	
2004	Vectra-C/Signum	Body	REC(Rear Electrical Centre)	✓	✓	✓	✓	✓	
2004	Vectra-C/Signum	Body	UEC(Underhood Electrical Centre)	✓	✓	✓	✓	✓	
2004	Vectra-C/Signum	Body	SLM(Shift Lever Module)	✓	✓	✓	✓	✓	
2004	Vectra-C/Signum	Body	SRM(Sun Roof Module)	✓	✓	✓	✓	✓	
2004	Vectra-C/Signum	Body	AHL/AFL(Headlamp Levelling)	✓	✓	✓	✓	✓	
2004	Vectra-C/Signum	Chassis	ABS/TC/ESP	✓	✓	✓	✓	✓	0004 0005 0063
2004	Vectra-C/Signum	Chassis	TPMS (Tyre Pressure Monitoring System)	✓	✓	✓	✓	✓	0033
2004	Vectra-C/Signum	Chassis	EHPS(Electronic Power Steering)	✓	✓	✓	✓	✓	
2004	Vectra-C/Signum	Chassis	Electronic Cruise Control	✓	✓	✓	✓	✓	
2004	Vectra-C/Signum	Engine	Engine Cooling	✓	✓	✓	✓	✓	
2004	Vectra-C/Signum	Engine	Z18XE	✓	✓	✓	✓	✓	0020 0011 0012 0067 0150 0013
2004	Vectra-C/Signum	Engine	Z19DT	✓	✓	✓	✓	✓	0150 0011 0012 0067 0024 0025 0070 0021 0013 0027 0030
2004	Vectra-C/Signum	Engine	Z19DTH	✓	✓	✓	✓	✓	0150 0011 0012 0067 0024 0025 0029 0026 0027 0021 0013 0028 0030
2004	Vectra-C/Signum	Engine	Y20DTH	✓	✓	✓	✓	✓	0011 0012 0067 0150
2004	Vectra-C/Signum	Engine	Y22DTR	✓	✓	✓	✓	✓	0011 0012 0067 0150
2004	Vectra-C/Signum	Engine	Y30DT	✓	✓	✓	✓	✓	
2004	Vectra-C/Signum	Engine	Z22SE	✓	✓	✓	✓	✓	0011 0012 0067 0150
2004	Vectra-C/Signum	Engine	Z22YH	✓	✓	✓	✓	✓	0020 0150
2004	Vectra-C/Signum	Engine	Z32SE	✓	✓	✓	✓	✓	0020 0150
2004	Vectra-C/Signum	Engine	Z16XE	✓	✓	✓	✓	✓	0011 0012 0067 0150 0013
2004	Vectra-C/Signum	Engine	Z20NET	✓	✓	✓	✓	✓	0011 0012 0067 0150
2004	Vectra-C/Signum	Engine	Engine(default)	✓	✓	✓	✓	✓	
2004	Vectra-C/Signum	Transmission	AF 23-5/33-5/40-6	✓	✓	✓	✓	✓	0033 0034
2004	Vectra-C/Signum	Transmission	CVTronic	✓	✓	✓	✓	✓	0187 0188 0189 0033 0004 0034
2004	Vectra-C/Signum	Transmission	AF 23-5/33-5	✓	✓	✓	✓	✓	0033 0034
2004	Vivaro	Body	Airbag	✓	✓	✓	✓	✓	0005
2004	Vivaro	Body	Add On Heater	✓	✓	✓	✓	✓	0123 0124
2004	Vivaro	Body	Body Control Module	✓	✓	✓	✓	✓	
2004	Vivaro	Chassis	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)	✓	✓	✓	✓	✓	0175 0176
2004	Vivaro	Engine	F9Q 760/762 (1.9L)	✓	✓	✓	✓	✓	
2004	Vivaro	Infotainment System	Trip Info Display TID	✓	✓	✓	✓	✓	
2004	Vivaro	Infotainment System	Radio CAR 2003	✓	✓	✓	✓	✓	
2004	Vivaro	Infotainment System	Radio CDR 2005	✓	✓	✓	✓	✓	
2004	Vivaro	Infotainment System	Radio CCR 2006	✓	✓	✓	✓	✓	
2004	Zafira	Body	Immobiliser	✓	✓	✓	✓	✓	0140 0141
2004	Zafira	Body	Instrument	✓	✓	✓	✓	✓	
2004	Zafira	Body	Airbag	✓	✓	✓	✓	✓	
2004	Zafira	Body	Anti Theft Warning	✓	✓	✓	✓	✓	
2004	Zafira	Body	Central Door Lock	✓	✓	✓	✓	✓	
2004	Zafira	Body	Electronic Climate Control	✓	✓	✓	✓	✓	

2004	Zafira	Body	Engine Cooling Module	✓	✓	✓	✓		
2004	Zafira	Body	Headlamp Adjustment(Left)	✓	✓	✓	✓		
2004	Zafira	Body	Headlamp Adjustment(Right)	✓	✓	✓	✓		
2004	Zafira	Chassis	ABS-5.3/5.4(+TC)	✓	✓	✓	✓	✓	
2004	Zafira	Chassis	ESP	✓	✓	✓	✓	✓	0006
2004	Zafira	Chassis	Electronic Power Steering	✓	✓	✓	✓	✓	0142
2004	Zafira	Engine	Z16XE	✓	✓	✓	✓	✓	0007 0022 0012
2004	Zafira	Engine	Z16YNG	✓	✓	✓	✓	✓	
2004	Zafira	Engine	Z18XE	✓	✓	✓	✓	✓	0146 0010 0041 0020 0012 0022
2004	Zafira	Engine	Y20DTH	✓	✓	✓	✓	✓	0167 0168 0169 0170
2004	Zafira	Engine	Z20LET	✓	✓	✓	✓	✓	0010 0020 0041 0146 0012 0022 0066 0034
2004	Zafira	Engine	Y22DTR	✓	✓	✓	✓	✓	0012 0022
2004	Zafira	Engine	Z22SE	✓	✓	✓	✓	✓	0066 0147 0146 0010 0012 0022 0034
2004	Zafira	Engine	Z18XEL	✓	✓	✓	✓	✓	0146 0010 0041 0020
2004	Zafira	Infotainment System	Radio CAR 300	✓	✓	✓	✓	✓	
2004	Zafira	Infotainment System	Trip Info Display TID	✓	✓	✓	✓	✓	
2004	Zafira	Infotainment System	Multi Info Display MID	✓	✓	✓	✓	✓	
2004	Zafira	Infotainment System	Radio CAR 400	✓	✓	✓	✓	✓	
2004	Zafira	Infotainment System	Radio CDR 500	✓	✓	✓	✓	✓	
2004	Zafira	Infotainment System	Radio CCR 600	✓	✓	✓	✓	✓	
2004	Zafira	Infotainment System	Radio CCRT 700	✓	✓	✓	✓	✓	
2004	Zafira	Infotainment System	Radio NCDR 1100/1500	✓	✓	✓	✓	✓	
2004	Zafira	Transmission	AF 13-II/17/20/22 CAN	✓	✓	✓	✓	✓	
2003	Agila	Body	Immobiliser	✓	✓	✓	✓	✓	0140 0141
2003	Agila	Body	Airbag	✓	✓	✓	✓	✓	
2003	Agila	Body	Instrument	✓	✓	✓	✓	✓	
2003	Agila	Chassis	ABS	✓	✓	✓	✓	✓	0190
2003	Agila	Chassis	Electronic Power Steering	✓	✓	✓	✓	✓	
2003	Agila	Engine	Z10XEP	✓	✓	✓	✓	✓	0012 0022 0066 0034
2003	Agila	Engine	Z12XE	✓	✓	✓	✓	✓	0007 0146 0010 0041 0020 0022 0012 0066 0034
2003	Agila	Infotainment System	Trip Info Display TID	✓	✓	✓	✓	✓	
2003	Agila	Infotainment System	Radio CAR 2003	✓	✓	✓	✓	✓	
2003	Agila	Infotainment System	Radio CDR 2005	✓	✓	✓	✓	✓	
2003	Astra-G	Body	Immobiliser	✓	✓	✓	✓	✓	0140 0141
2003	Astra-G	Body	Instrument	✓	✓	✓	✓	✓	
2003	Astra-G	Body	Airbag	✓	✓	✓	✓	✓	
2003	Astra-G	Body	Anti Theft Warning	✓	✓	✓	✓	✓	
2003	Astra-G	Body	Central Door Lock	✓	✓	✓	✓	✓	
2003	Astra-G	Body	Headlamp Levelling Device	✓	✓	✓	✓	✓	0142
2003	Astra-G	Body	Electronic Climate Control	✓	✓	✓	✓	✓	
2003	Astra-G	Body	Engine Cooling Module	✓	✓	✓	✓	✓	
2003	Astra-G	Body	Add On Heater	✓	✓	✓	✓	✓	0123 0124
2003	Astra-G	Body	Softtop Controller	✓	✓	✓	✓	✓	
2003	Astra-G	Chassis	ABS-5.3/5.4(+TC)	✓	✓	✓	✓	✓	
2003	Astra-G	Chassis	ESP	✓	✓	✓	✓	✓	0006
2003	Astra-G	Chassis	Cruise Control	✓	✓	✓	✓	✓	
2003	Astra-G	Chassis	Electronic Power Steering	✓	✓	✓	✓	✓	
2003	Astra-G	Engine	Z12XE	✓	✓	✓	✓	✓	0007 0146 0010 0041 0020 0022 0012 0066 0034
2003	Astra-G	Engine	Z14XE	✓	✓	✓	✓	✓	0147 0146 0010 0020 0022 0012
2003	Astra-G	Engine	C16SEL	✓	✓	✓	✓	✓	
2003	Astra-G	Engine	Z16SE	✓	✓	✓	✓	✓	0007 0022 0012
2003	Astra-G	Engine	Z16XE	✓	✓	✓	✓	✓	0007 0022 0012
2003	Astra-G	Engine	Z16XEP	✓	✓	✓	✓	✓	
2003	Astra-G	Engine	Z16YNG	✓	✓	✓	✓	✓	0007 0147 0146 0010 0020 0012 0022
2003	Astra-G	Engine	Y17DT	✓	✓	✓	✓	✓	
2003	Astra-G	Engine	Z17DTL	✓	✓	✓	✓	✓	
2003	Astra-G	Engine	Z18XE	✓	✓	✓	✓	✓	0146 0010 0041 0020 0012 0022
2003	Astra-G	Engine	Z18XEL	✓	✓	✓	✓	✓	0012 0022
2003	Astra-G	Engine	Y20DTH	✓	✓	✓	✓	✓	0167 0168 0169 0170
2003	Astra-G	Engine	Z20LET	✓	✓	✓	✓	✓	0010 0020 0041 0146 0012 0022 0066 0034
2003	Astra-G	Engine	Y22DTR	✓	✓	✓	✓	✓	0012 0022
2003	Astra-G	Engine	Z22SE	✓	✓	✓	✓	✓	0066 0147 0146 0010 0012 0022 0034
2003	Astra-G	Infotainment System	Trip Info Display TID	✓	✓	✓	✓	✓	
2003	Astra-G	Infotainment System	Multi Info Display MID	✓	✓	✓	✓	✓	
2003	Astra-G	Infotainment System	Radio CAR 300	✓	✓	✓	✓	✓	
2003	Astra-G	Infotainment System	Radio CAR 400	✓	✓	✓	✓	✓	
2003	Astra-G	Infotainment System	Radio CDR 500	✓	✓	✓	✓	✓	
2003	Astra-G	Infotainment System	Radio CCR 600	✓	✓	✓	✓	✓	
2003	Astra-G	Infotainment System	Radio CCRT 700	✓	✓	✓	✓	✓	
2003	Astra-G	Infotainment System	Radio NCDR 1100/1500	✓	✓	✓	✓	✓	
2003	Astra-G	Transmission	AF 13-II/17/20/22	✓	✓	✓	✓	✓	
2003	Astra-G	Transmission	AF 13-II/17/20/22 CAN	✓	✓	✓	✓	✓	
2003	Astra-G(GMSA)	Body	Airbag	✓	✓	✓	✓	✓	
2003	Astra-G(GMSA)	Body	Anti Theft Warning	✓	✓	✓	✓	✓	
2003	Astra-G(GMSA)	Body	Central Door Lock	✓	✓	✓	✓	✓	
2003	Astra-G(GMSA)	Body	Engine Cooling Module	✓	✓	✓	✓	✓	
2003	Astra-G(GMSA)	Body	Immobiliser	✓	✓	✓	✓	✓	0165 0166
2003	Astra-G(GMSA)	Body	Instrument	✓	✓	✓	✓	✓	
2003	Astra-G(GMSA)	Chassis	ABS-5.3/5.4 (+TC) (Anti-lock Braking System)	✓	✓	✓	✓	✓	
2003	Astra-G(GMSA)	Chassis	Electronic Power Steering	✓	✓	✓	✓	✓	
2003	Astra-G(GMSA)	Engine	C 16 SEL	✓	✓	✓	✓	✓	
2003	Astra-G(GMSA)	Engine	Z 18 XE	✓	✓	✓	✓	✓	0146 0010 0041 0020 0012 0022
2003	Astra-G(GMSA)	Engine	Z 20 SEL	✓	✓	✓	✓	✓	0020
2003	Astra-G(GMSA)	Engine	Z 20 LET	✓	✓	✓	✓	✓	0146 0010 0041 0020
2003	Astra-G(GMSA)	Engine	Z 22 SE	✓	✓	✓	✓	✓	0147 0010 0146 0012 0022 0066 0034
2003	Astra-G(GMSA)	Infotainment System	Trip Info Display TID	✓	✓	✓	✓	✓	
2003	Combo	Body	Add On Heater	✓	✓	✓	✓	✓	0123 0124
2003	Combo	Body	Airbag	✓	✓	✓	✓	✓	
2003	Combo	Body	Body Control Module	✓	✓	✓	✓	✓	0052 0059 0139
2003	Combo	Body	Electronic Climate Control	✓	✓	✓	✓	✓	

2003	Combo	Body	Immobiliser	✓	✓	✓	✓		0165 0166
2003	Combo	Body	Instrument	✓	✓	✓	✓		
2003	Combo	Chassis	ABS-5.3/5.4 (+TC) (Anti-lock Braking System)	✓	✓	✓	✓	✓	
2003	Combo	Chassis	Electronic Power Steering	✓	✓	✓	✓	✓	0142
2003	Combo	Engine	Z 10 XE	✓	✓	✓	✓	✓	0147 0195 0010 0020
2003	Combo	Engine	Z 12 XE	✓	✓	✓	✓	✓	0007 0146 0010 0041 0020 0022 0012 0066 0034
2003	Combo	Engine	Z 14 XE	✓	✓	✓	✓	✓	0147 0146 0010 0020 0022 0012
2003	Combo	Engine	Z 16 SE	✓	✓	✓	✓	✓	0007 0022 0012
2003	Combo	Engine	Y 17 DT	✓	✓	✓	✓	✓	
2003	Combo	Engine	Y 17 DTL	✓	✓	✓	✓	✓	0007 0022 0012
2003	Combo	Engine	Z 18 XE	✓	✓	✓	✓	✓	0146 0010 0041 0020 0012 0022
2003	Combo	Infotainment System	Radio CCR 2006	✓	✓	✓	✓	✓	
2003	Combo	Transmission	AF 13-II/17/20/22	✓	✓	✓	✓	✓	
2003	Combo	Transmission	AF 13-II/17/20/22 CAN	✓	✓	✓	✓	✓	
2003	Combo	Transmission	Easytronic(MTA)	✓	✓	✓	✓	✓	0012 0149
2003	Combo	Transmission	Trip Info Display TID	✓	✓	✓	✓	✓	
2003	Combo	Transmission	Radio CAR 2003	✓	✓	✓	✓	✓	
2003	Combo	Transmission	Radio CDR 2005	✓	✓	✓	✓	✓	
2003	Corsa-B	Body	Immobiliser	✓	✓	✓	✓	✓	
2003	Corsa-B	Body	Airbag S	✓	✓	✓	✓	✓	
2003	Corsa-B	Body	Airbag SAB6	✓	✓	✓	✓	✓	
2003	Corsa-B	Body	Anti Theft Warning	✓	✓	✓	✓	✓	
2003	Corsa-B	Body	Instrument	✓	✓	✓	✓	✓	0177 0178
2003	Corsa-B	Chassis	ABS-5.3	✓	✓	✓	✓	✓	
2003	Corsa-B	Chassis	Electronic Power Steering	✓	✓	✓	✓	✓	
2003	Corsa-B	Engine	Z14SZ	✓	✓	✓	✓	✓	
2003	Corsa-B	Engine	C14SE	✓	✓	✓	✓	✓	
2003	Corsa-B	Engine	X14NE	✓	✓	✓	✓	✓	
2003	Corsa-B	Engine	X16NE	✓	✓	✓	✓	✓	
2003	Corsa-B	Infotainment System	Multi Info Dispaly MID	✓	✓	✓	✓	✓	
2003	Corsa-B	Infotainment System	Radio CAR 300	✓	✓	✓	✓	✓	
2003	Corsa-B	Infotainment System	Radio CAR 400	✓	✓	✓	✓	✓	
2003	Corsa-B	Infotainment System	Radio CDR 500	✓	✓	✓	✓	✓	
2003	Corsa-B	Infotainment System	Radio CCR 600	✓	✓	✓	✓	✓	
2003	Corsa-B	Infotainment System	Radio CCRT 700	✓	✓	✓	✓	✓	
2003	Corsa-B	Infotainment System	Radio NCDR 1100/1500	✓	✓	✓	✓	✓	
2003	Corsa-B(GMSA)	Body	Immobiliser	✓	✓	✓	✓	✓	0165 0166
2003	Corsa-B(GMSA)	Engine	14 NE	✓	✓	✓	✓	✓	0167 0191 0192 0057 0193
2003	Corsa-B(GMSA)	Engine	16 SE	✓	✓	✓	✓	✓	
2003	Corsa-C	Body	Body Control Module	✓	✓	✓	✓	✓	0052 0059 0139
2003	Corsa-C	Body	Immobiliser	✓	✓	✓	✓	✓	0140 0141
2003	Corsa-C	Body	Airbag	✓	✓	✓	✓	✓	
2003	Corsa-C	Body	Instrument	✓	✓	✓	✓	✓	0177 0178
2003	Corsa-C	Body	Add On Heater	✓	✓	✓	✓	✓	0123 0124
2003	Corsa-C	Body	Electronic Climate Control	✓	✓	✓	✓	✓	
2003	Corsa-C	Chassis	ABS-5.3/5.4(+TC)	✓	✓	✓	✓	✓	
2003	Corsa-C	Chassis	Electronic Power Steering	✓	✓	✓	✓	✓	0142
2003	Corsa-C	Engine	Z10XE	✓	✓	✓	✓	✓	0147 0194 0010 0020
2003	Corsa-C	Engine	Z12XE	✓	✓	✓	✓	✓	0007 0146 0010 0041 0020 0022 0012 0066 0034
2003	Corsa-C	Engine	Z14XE	✓	✓	✓	✓	✓	0147 0146 0010 0020 0022 0012
2003	Corsa-C	Engine	Z16SE	✓	✓	✓	✓	✓	0007 0022 0012
2003	Corsa-C	Engine	Y17DT	✓	✓	✓	✓	✓	
2003	Corsa-C	Engine	Y17DTL	✓	✓	✓	✓	✓	0007 0022 0012
2003	Corsa-C	Engine	Z18XE	✓	✓	✓	✓	✓	0146 0010 0041 0020 0012 0022
2003	Corsa-C	Infotainment System	Trip Info Display TID	✓	✓	✓	✓	✓	
2003	Corsa-C	Infotainment System	Radio CAR 2003	✓	✓	✓	✓	✓	
2003	Corsa-C	Infotainment System	Radio CDR 2005	✓	✓	✓	✓	✓	
2003	Corsa-C	Infotainment System	Radio CCR 2006	✓	✓	✓	✓	✓	
2003	Corsa-C	Transmission	AF 13-II/17/20/22 CAN	✓	✓	✓	✓	✓	
2003	Corsa-C	Transmission	MTA(Easytronic)	✓	✓	✓	✓	✓	0012 0149
2003	Corsa-C	Transmission	AF 13-II/17/20/22	✓	✓	✓	✓	✓	
2003	Corsa-C(GMSA)	Body	Airbag	✓	✓	✓	✓	✓	
2003	Corsa-C(GMSA)	Body	Body Control Module	✓	✓	✓	✓	✓	0052 0059 0139
2003	Corsa-C(GMSA)	Body	Immobiliser	✓	✓	✓	✓	✓	0165 0166
2003	Corsa-C(GMSA)	Body	Instrument	✓	✓	✓	✓	✓	
2003	Corsa-C(GMSA)	Body	Power Window Lifter Front	✓	✓	✓	✓	✓	
2003	Corsa-C(GMSA)	Body	Power Window Lifter Rear	✓	✓	✓	✓	✓	
2003	Corsa-C(GMSA)	Chassis	ABS-5.3/5.4 (+TC) (Anti-lock Braking System)	✓	✓	✓	✓	✓	
2003	Corsa-C(GMSA)	Chassis	Electronic Power Steering	✓	✓	✓	✓	✓	0142
2003	Corsa-C(GMSA)	Engine	C 14 SE	✓	✓	✓	✓	✓	0146 0020
2003	Corsa-C(GMSA)	Engine	C 16 SE	✓	✓	✓	✓	✓	0146 0020
2003	Corsa-C(GMSA)	Engine	Y 17 DT	✓	✓	✓	✓	✓	
2003	Corsa-C(GMSA)	Engine	Y 17 DTL	✓	✓	✓	✓	✓	0007 0022 0012
2003	Corsa-C(GMSA)	Engine	C 18 XE	✓	✓	✓	✓	✓	0146 0020
2003	Corsa-C(GMSA)	Infotainment System	Trip Info Display TID	✓	✓	✓	✓	✓	
2003	Corsa-C(GMSA)	Infotainment System	Radio CDR 2005	✓	✓	✓	✓	✓	
2003	Corsa-C(GMSA)	Infotainment System	Radio CCRT 2008	✓	✓	✓	✓	✓	
2003	Frontera-B	Body	Anti Theft Warning	✓	✓	✓	✓	✓	
2003	Frontera-B	Engine	Y22DTH	✓	✓	✓	✓	✓	0007
2003	Frontera-B	Infotainment System	Trip Info Display TID	✓	✓	✓	✓	✓	
2003	Frontera-B	Infotainment System	Multi Info Dispaly MID	✓	✓	✓	✓	✓	
2003	Frontera-B	Infotainment System	Radio CAR 300	✓	✓	✓	✓	✓	
2003	Frontera-B	Infotainment System	Radio CAR 400	✓	✓	✓	✓	✓	
2003	Frontera-B	Infotainment System	Radio CDR 500	✓	✓	✓	✓	✓	
2003	Frontera-B	Infotainment System	Radio CCR 600	✓	✓	✓	✓	✓	
2003	Frontera-B	Infotainment System	Radio CCRT 700	✓	✓	✓	✓	✓	
2003	Frontera-B	Infotainment System	Radio NCDR 1100/1500	✓	✓	✓	✓	✓	
2003	Frontera-B	Transmission	AR 25/35	✓	✓	✓	✓	✓	
2003	Frontera-B	Transmission	Airbag	✓	✓	✓	✓	✓	
2003	Frontera-B	Transmission	Central Door Lock	✓	✓	✓	✓	✓	0165 0166
2003	Frontera-B	Transmission	Immobiliser	✓	✓	✓	✓	✓	0165 0166
2003	Meriva	Body	Body Control Module	✓	✓	✓	✓	✓	0052 0059 0139
2003	Meriva	Body	Immobiliser	✓	✓	✓	✓	✓	0140 0141
2003	Meriva	Body	Airbag	✓	✓	✓	✓	✓	

2003	Meriva	Body	Instrument	✓	✓	✓	✓	✓	0177 0178
2003	Meriva	Body	Headlamp Levelling Device	✓	✓	✓	✓	✓	0142
2003	Meriva	Body	Electronic Climate Control	✓	✓	✓	✓	✓	
2003	Meriva	Chassis	ABS-5.3/5.4(+TC)	✓	✓	✓	✓	✓	
2003	Meriva	Chassis	ESP	✓	✓	✓	✓	✓	0006
2003	Meriva	Chassis	Electronic Power Steering	✓	✓	✓	✓	✓	0142
2003	Meriva	Engine	Z16SE	✓	✓	✓	✓	✓	0007 0022 0012
2003	Meriva	Engine	Z16XE	✓	✓	✓	✓	✓	0007 0022 0012
2003	Meriva	Engine	Z18XE	✓	✓	✓	✓	✓	0146 0010 0041 0020 0012 0022
2003	Meriva	Infotainment System	Trip Info Display TID	✓	✓	✓	✓	✓	
2003	Meriva	Infotainment System	Radio CAR 2003	✓	✓	✓	✓	✓	
2003	Meriva	Infotainment System	Radio CDR 2005	✓	✓	✓	✓	✓	
2003	Meriva	Infotainment System	Radio CCR 2006	✓	✓	✓	✓	✓	
2003	Meriva	Transmission	MTA(Easytronic)	✓	✓	✓	✓	✓	0012 0149
2003	Movano	Body	Airbag	✓	✓	✓	✓	✓	
2003	Movano	Body	Immobiliser	✓	✓	✓	✓	✓	0165 0166
2003	Omega-B	Body	Immobiliser	✓	✓	✓	✓	✓	0140 0141
2003	Omega-B	Body	Airbag	✓	✓	✓	✓	✓	
2003	Omega-B	Body	Headlamp Levelling Device	✓	✓	✓	✓	✓	0142
2003	Omega-B	Body	Add On Heater	✓	✓	✓	✓	✓	0123 0124
2003	Omega-B	Body	Anti Theft Warning	✓	✓	✓	✓	✓	
2003	Omega-B	Body	Central Door Lock	✓	✓	✓	✓	✓	0165 0166
2003	Omega-B	Body	Electronic Climate Control	✓	✓	✓	✓	✓	
2003	Omega-B	Body	Instrument	✓	✓	✓	✓	✓	
2003	Omega-B	Chassis	ABS-5.3/5.4(+TC)	✓	✓	✓	✓	✓	
2003	Omega-B	Chassis	ESP	✓	✓	✓	✓	✓	
2003	Omega-B	Engine	Y22DTH	✓	✓	✓	✓	✓	0007
2003	Omega-B	Engine	Z22XE	✓	✓	✓	✓	✓	0147 0146 0010 0041 0020
2003	Omega-B	Engine	Y25DT	✓	✓	✓	✓	✓	
2003	Omega-B	Engine	Y26SE	✓	✓	✓	✓	✓	0146 0010
2003	Omega-B	Engine	X30XE	✓	✓	✓	✓	✓	
2003	Omega-B	Engine	Y32SE	✓	✓	✓	✓	✓	0146 0010
2003	Omega-B	Infotainment System	Trip Info Display TID	✓	✓	✓	✓	✓	
2003	Omega-B	Infotainment System	Multi Info Display MID	✓	✓	✓	✓	✓	
2003	Omega-B	Infotainment System	Radio CAR 2003	✓	✓	✓	✓	✓	
2003	Omega-B	Infotainment System	Radio CDR 2005	✓	✓	✓	✓	✓	
2003	Omega-B	Infotainment System	Radio CCR 2006	✓	✓	✓	✓	✓	
2003	Omega-B	Transmission	AR 25/35	✓	✓	✓	✓	✓	
2003	Omega-B	Transmission	5L40-E	✓	✓	✓	✓	✓	
2003	Speedster/VX220	Body	Immobiliser	✓	✓	✓	✓	✓	0140 0141
2003	Speedster/VX220	Body	Airbag	✓	✓	✓	✓	✓	
2003	Speedster/VX220	Body	Anti Theft Warning	✓	✓	✓	✓	✓	
2003	Speedster/VX220	Chassis	ABS 430	✓	✓	✓	✓	✓	
2003	Speedster/VX220	Engine	Z20LET	✓	✓	✓	✓	✓	
2003	Speedster/VX220	Engine	Z22SE	✓	✓	✓	✓	✓	0066 0147 0146 0010 0012 0022 0034
2003	Vectra-C/Signum	Body	SDM(Airbag,Sensing&Diagnostic Module)	✓	✓	✓	✓	✓	0000 0001 0002 0003
2003	Vectra-C/Signum	Body	Instrument	✓	✓	✓	✓	✓	0170 0057 0058 0180 0002
2003	Vectra-C/Signum	Body	CIM(Steering Column Module)	✓	✓	✓	✓	✓	0052 0004 0053 0002 0005 0054 0055 0006
2003	Vectra-C/Signum	Body	BCM(Body Control Module)	✓	✓	✓	✓	✓	0181 0182
2003	Vectra-C/Signum	Body	DDM(Driver Door Module)	✓	✓	✓	✓	✓	
2003	Vectra-C/Signum	Body	PDM(Passenger Door Module)	✓	✓	✓	✓	✓	
2003	Vectra-C/Signum	Body	REC(Rear Electrical Centre)	✓	✓	✓	✓	✓	
2003	Vectra-C/Signum	Body	UEC(Underhood Electrical Centre)	✓	✓	✓	✓	✓	
2003	Vectra-C/Signum	Body	SLM(Shift Lever Module)	✓	✓	✓	✓	✓	
2003	Vectra-C/Signum	Body	SRM(Sun Roof Module)	✓	✓	✓	✓	✓	
2003	Vectra-C/Signum	Body	AHL/APL(Headlamp Levelling)	✓	✓	✓	✓	✓	
2003	Vectra-C/Signum	Body	Electrical Horn	✓	✓	✓	✓	✓	
2003	Vectra-C/Signum	Body	Electronic Seat Memory/Seat Heating	✓	✓	✓	✓	✓	
2003	Vectra-C/Signum	Body	Anti Theft Warning System	✓	✓	✓	✓	✓	
2003	Vectra-C/Signum	Body	Central Door Lock	✓	✓	✓	✓	✓	
2003	Vectra-C/Signum	Body	PAS (Park Pilot)	✓	✓	✓	✓	✓	0002
2003	Vectra-C/Signum	Chassis	ABS/TC/ESP	✓	✓	✓	✓	✓	0004 0005 0063
2003	Vectra-C/Signum	Chassis	TPMS (Tyre Pressure Monitoring System)	✓	✓	✓	✓	✓	0033
2003	Vectra-C/Signum	Chassis	EHPS(Electronic Power Steering)	✓	✓	✓	✓	✓	
2003	Vectra-C/Signum	Chassis	Electronic Cruise Control	✓	✓	✓	✓	✓	
2003	Vectra-C/Signum	Engine	Engine Cooling	✓	✓	✓	✓	✓	
2003	Vectra-C/Signum	Engine	Z18XE	✓	✓	✓	✓	✓	0020 0011 0012 0067 0150 0013
2003	Vectra-C/Signum	Engine	Y20DTH	✓	✓	✓	✓	✓	0011 0012 0067 0150
2003	Vectra-C/Signum	Engine	Y22DTR	✓	✓	✓	✓	✓	0011 0012 0067 0150
2003	Vectra-C/Signum	Engine	Y30DT	✓	✓	✓	✓	✓	
2003	Vectra-C/Signum	Engine	Z22SE	✓	✓	✓	✓	✓	0011 0012 0067 0150
2003	Vectra-C/Signum	Engine	Z22VH	✓	✓	✓	✓	✓	0020 0150
2003	Vectra-C/Signum	Engine	Z32SE	✓	✓	✓	✓	✓	0020 0150
2003	Vectra-C/Signum	Engine	Z16XE	✓	✓	✓	✓	✓	0011 0012 0067 0150 0013
2003	Vectra-C/Signum	Engine	Z20NET	✓	✓	✓	✓	✓	0011 0012 0067 0150
2003	Vectra-C/Signum	Engine	Engine(default)	✓	✓	✓	✓	✓	
2003	Vectra-C/Signum	Transmission	AF 23-5/33-5/40-6	✓	✓	✓	✓	✓	0033 0034
2003	Vectra-C/Signum	Transmission	AF 23-5/33-5	✓	✓	✓	✓	✓	0033 0034
2003	Vivaro	Body	Airbag	✓	✓	✓	✓	✓	0005
2003	Vivaro	Body	Add On Heater	✓	✓	✓	✓	✓	0123 0124
2003	Vivaro	Body	Body Control Module	✓	✓	✓	✓	✓	
2003	Vivaro	Chassis	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)	✓	✓	✓	✓	✓	0175 0176
2003	Vivaro	Engine	F9Q 760/762 (1.9L)	✓	✓	✓	✓	✓	
2003	Vivaro	Infotainment System	Trip Info Display TID	✓	✓	✓	✓	✓	
2003	Vivaro	Infotainment System	Radio CDR 2005	✓	✓	✓	✓	✓	
2003	Vivaro	Infotainment System	Radio CCR 2006	✓	✓	✓	✓	✓	
2003	Zafira	Body	Immobiliser	✓	✓	✓	✓	✓	0140 0141
2003	Zafira	Body	Instrument	✓	✓	✓	✓	✓	
2003	Zafira	Body	Airbag	✓	✓	✓	✓	✓	
2003	Zafira	Body	Anti Theft Warning	✓	✓	✓	✓	✓	
2003	Zafira	Body	Central Door Lock	✓	✓	✓	✓	✓	
2003	Zafira	Body	Electronic Climate Control	✓	✓	✓	✓	✓	
2003	Zafira	Body	Engine Cooling Module	✓	✓	✓	✓	✓	
2003	Zafira	Body	Headlamp Adjustment(Left)	✓	✓	✓	✓	✓	
2003	Zafira	Body	Headlamp Adjustment(Right)	✓	✓	✓	✓	✓	
2003	Zafira	Chassis	ABS-5.3/5.4(+TC)	✓	✓	✓	✓	✓	

2003	Zafira	Chassis	ESP	✓	✓	✓	✓	✓	0006
2003	Zafira	Chassis	Electronic Power Steering	✓	✓	✓	✓	✓	0142
2003	Zafira	Engine	Z16XE	✓	✓	✓	✓	✓	0007 0022 0012
2003	Zafira	Engine	Z16YNG	✓	✓	✓	✓	✓	
2003	Zafira	Engine	Z18XE	✓	✓	✓	✓	✓	0146 0010 0041 0020 0012 0022
2003	Zafira	Engine	Y20DTH	✓	✓	✓	✓	✓	0167 0168 0169 0170
2003	Zafira	Engine	Z20LET	✓	✓	✓	✓	✓	0010 0020 0041 0146 0012 0022 0066 0034
2003	Zafira	Engine	Y22DTR	✓	✓	✓	✓	✓	0012 0022
2003	Zafira	Engine	Z22SE	✓	✓	✓	✓	✓	0066 0147 0146 0010 0012 0022 0034
2003	Zafira	Infotainment System	Radio CAR 300	✓	✓	✓	✓	✓	
2003	Zafira	Infotainment System	Trip Info Display TID	✓	✓	✓	✓	✓	
2003	Zafira	Infotainment System	Multi Info Display MID	✓	✓	✓	✓	✓	
2003	Zafira	Infotainment System	Radio CAR 400	✓	✓	✓	✓	✓	
2003	Zafira	Infotainment System	Radio CDR 500	✓	✓	✓	✓	✓	
2003	Zafira	Infotainment System	Radio CCR 600	✓	✓	✓	✓	✓	
2003	Zafira	Infotainment System	Radio CCRT 700	✓	✓	✓	✓	✓	
2003	Zafira	Infotainment System	Radio NCDR 1100/1500	✓	✓	✓	✓	✓	
2003	Zafira	Transmission	AF 13-II/17/20/22 CAN	✓	✓	✓	✓	✓	
2002	Agila	Body	Immobiliser	✓	✓	✓	✓	✓	0140 0141
2002	Agila	Body	Airbag	✓	✓	✓	✓	✓	
2002	Agila	Body	Instrument	✓	✓	✓	✓	✓	
2002	Agila	Chassis	ABS	✓	✓	✓	✓	✓	0190
2002	Agila	Chassis	Electronic Power Steering	✓	✓	✓	✓	✓	
2002	Agila	Engine	Z10XEP	✓	✓	✓	✓	✓	0012 0022 0066 0034
2002	Agila	Engine	Z12XE	✓	✓	✓	✓	✓	0007 0146 0010 0041 0020 0022 0012 0066 0034
2002	Agila	Infotainment System	Trip Info Display TID	✓	✓	✓	✓	✓	
2002	Agila	Infotainment System	Radio CAR 2003	✓	✓	✓	✓	✓	
2002	Agila	Infotainment System	Radio CDR 2005	✓	✓	✓	✓	✓	
2002	Astra-F	Body	Immobiliser	✓	✓	✓	✓	✓	0140 0141
2002	Astra-F	Body	Airbag S	✓	✓	✓	✓	✓	
2002	Astra-F	Body	Instrument	✓	✓	✓	✓	✓	
2002	Astra-F	Body	Anti Theft Warning	✓	✓	✓	✓	✓	
2002	Astra-F	Engine	X16SZR	✓	✓	✓	✓	✓	
2002	Astra-F	Engine	X16XEL	✓	✓	✓	✓	✓	0167 0196 0197 0198 0199 0020
2002	Astra-F	Infotainment System	Trip Info Display TID	✓	✓	✓	✓	✓	
2002	Astra-F	Infotainment System	Radio CAR 300	✓	✓	✓	✓	✓	
2002	Astra-F	Infotainment System	Radio CAR 400	✓	✓	✓	✓	✓	
2002	Astra-F	Infotainment System	Radio CDR 500	✓	✓	✓	✓	✓	
2002	Astra-G	Body	Immobiliser	✓	✓	✓	✓	✓	0140 0141
2002	Astra-G	Body	Instrument	✓	✓	✓	✓	✓	
2002	Astra-G	Body	Airbag	✓	✓	✓	✓	✓	
2002	Astra-G	Body	Anti Theft Warning	✓	✓	✓	✓	✓	
2002	Astra-G	Body	Central Door Lock	✓	✓	✓	✓	✓	
2002	Astra-G	Body	Headlamp Levelling Device	✓	✓	✓	✓	✓	0142
2002	Astra-G	Body	Electronic Climate Control	✓	✓	✓	✓	✓	
2002	Astra-G	Body	Engine Cooling Module	✓	✓	✓	✓	✓	
2002	Astra-G	Body	Add On Heater	✓	✓	✓	✓	✓	0123 0124
2002	Astra-G	Body	Softtop Controller	✓	✓	✓	✓	✓	
2002	Astra-G	Chassis	ABS-5.3/5.4(+TC)	✓	✓	✓	✓	✓	
2002	Astra-G	Chassis	ESP	✓	✓	✓	✓	✓	0006
2002	Astra-G	Chassis	Cruise Control	✓	✓	✓	✓	✓	
2002	Astra-G	Chassis	Electronic Power Steering	✓	✓	✓	✓	✓	
2002	Astra-G	Engine	Z12XE	✓	✓	✓	✓	✓	0007 0146 0010 0041 0020 0022 0012 0066 0034
2002	Astra-G	Engine	Z14XE	✓	✓	✓	✓	✓	0147 0146 0010 0020 0022 0012
2002	Astra-G	Engine	C16SEL	✓	✓	✓	✓	✓	
2002	Astra-G	Engine	Z16SE	✓	✓	✓	✓	✓	0007 0022 0012
2002	Astra-G	Engine	Z16XE	✓	✓	✓	✓	✓	0007 0022 0012
2002	Astra-G	Engine	Y17DT	✓	✓	✓	✓	✓	
2002	Astra-G	Engine	Z18XE	✓	✓	✓	✓	✓	0146 0010 0041 0020 0012 0022
2002	Astra-G	Engine	Z18XEL	✓	✓	✓	✓	✓	0012 0022
2002	Astra-G	Engine	Y20DTH	✓	✓	✓	✓	✓	0167 0168 0169 0170
2002	Astra-G	Engine	Y20DTL	✓	✓	✓	✓	✓	0167
2002	Astra-G	Engine	Z20LET	✓	✓	✓	✓	✓	0010 0020 0041 0146 0012 0022 0066 0034
2002	Astra-G	Engine	Z22SE	✓	✓	✓	✓	✓	0066 0147 0146 0010 0012 0022 0034
2002	Astra-G	Engine	Y22DTR	✓	✓	✓	✓	✓	0012 0022
2002	Astra-G	Infotainment System	Trip Info Display TID	✓	✓	✓	✓	✓	
2002	Astra-G	Infotainment System	Multi Info Display MID	✓	✓	✓	✓	✓	
2002	Astra-G	Infotainment System	Radio CAR 300	✓	✓	✓	✓	✓	
2002	Astra-G	Infotainment System	Radio CAR 400	✓	✓	✓	✓	✓	
2002	Astra-G	Infotainment System	Radio CDR 500	✓	✓	✓	✓	✓	
2002	Astra-G	Infotainment System	Radio CCR 600	✓	✓	✓	✓	✓	
2002	Astra-G	Infotainment System	Radio CCRT 700	✓	✓	✓	✓	✓	
2002	Astra-G	Infotainment System	Radio NCDR 1100/1500	✓	✓	✓	✓	✓	
2002	Astra-G	Transmission	AF 13-II/17/20/22	✓	✓	✓	✓	✓	
2002	Astra-G	Transmission	AF 13-II/17/20/22 CAN	✓	✓	✓	✓	✓	
2002	Astra-G (GMSA)	Body	Instrument	✓	✓	✓	✓	✓	
2002	Astra-G (GMSA)	Chassis	ABS-5.3/5.4 (+TC) (Anti-lock Braking System)	✓	✓	✓	✓	✓	
2002	Astra-G (GMSA)	Chassis	Electronic Power Steering	✓	✓	✓	✓	✓	
2002	Astra-G (GMSA)	Chassis	Airbag	✓	✓	✓	✓	✓	
2002	Astra-G (GMSA)	Chassis	Anti Theft Warning	✓	✓	✓	✓	✓	
2002	Astra-G (GMSA)	Chassis	Engine Cooling Module	✓	✓	✓	✓	✓	
2002	Astra-G (GMSA)	Chassis	Central Door Lock	✓	✓	✓	✓	✓	
2002	Astra-G (GMSA)	Chassis	Immobiliser	✓	✓	✓	✓	✓	0165 0166
2002	Astra-G (GMSA)	Chassis	Trip Info Display TID	✓	✓	✓	✓	✓	
2002	Astra-G (GMSA)	Engine	C 16 SEL	✓	✓	✓	✓	✓	
2002	Astra-G (GMSA)	Engine	Z 16 XE	✓	✓	✓	✓	✓	0007 0022 0012
2002	Astra-G (GMSA)	Engine	Z 18 XE	✓	✓	✓	✓	✓	0146 0010 0041 0020 0012 0022
2002	Astra-G (GMSA)	Engine	X 18 XE1	✓	✓	✓	✓	✓	0200
2002	Astra-G (GMSA)	Engine	Z 20 SEL	✓	✓	✓	✓	✓	0020
2002	Astra-G (GMSA)	Engine	Z 20 LET	✓	✓	✓	✓	✓	0146 0010 0041 0020
2002	Campo	Body	Airbag	✓	✓	✓	✓	✓	

2002	Campo	Body	Immobiliser	✓	✓	✓	✓		0165 0166
2002	Combo	Body	Airbag	✓	✓	✓	✓		
2002	Combo	Body	Body Control Module	✓	✓	✓	✓	✓	0052 0059 0139
2002	Combo	Body	Immobiliser	✓	✓	✓	✓		0165 0166
2002	Combo	Chassis	ABS-5.3/5.4 (+TC) (Anti-lock Braking System)	✓	✓	✓	✓	✓	
2002	Combo	Engine	Z 10 XE	✓	✓	✓	✓	✓	0147 0194 0010 0020
2002	Combo	Engine	Z 12 XE	✓	✓	✓	✓	✓	0007 0146 0010 0041 0020 0022 0012 0066 0034
2002	Combo	Engine	Z 13 DT	✓	✓	✓	✓	✓	0041 0020 0022 0012 0021
2002	Combo	Engine	Z 14 XE	✓	✓	✓	✓	✓	0147 0146 0010 0020 0022 0012
2002	Combo	Engine	Z 16 SE	✓	✓	✓	✓	✓	0007 0022 0012
2002	Combo	Engine	Y 17 DT	✓	✓	✓	✓	✓	
2002	Combo	Engine	Y 17 DTL	✓	✓	✓	✓	✓	0007 0022 0012
2002	Combo	Engine	Z 18 XE	✓	✓	✓	✓	✓	0146 0010 0041 0020 0012 0022
2002	Combo	Infotainment System	Trip Info Display TID	✓	✓	✓			
2002	Combo	Infotainment System	Radio CDR 2005	✓	✓	✓	✓		
2002	Combo	Infotainment System	Radio CCR 2006	✓	✓	✓	✓		
2002	Corsa-B	Body	Immobiliser	✓	✓	✓	✓		
2002	Corsa-B	Body	Airbag S	✓	✓	✓	✓		
2002	Corsa-B	Body	Airbag SAB6	✓	✓	✓	✓		
2002	Corsa-B	Body	Anti Theft Warning	✓	✓	✓	✓	✓	
2002	Corsa-B	Body	Instrument	✓	✓	✓	✓		
2002	Corsa-B	Chassis	ABS-5.3	✓	✓	✓	✓		
2002	Corsa-B	Chassis	Electronic Power Steering	✓	✓	✓	✓		
2002	Corsa-B	Engine	Z14SZ	✓	✓	✓	✓	✓	
2002	Corsa-B	Engine	X14SZ	✓	✓	✓	✓	✓	0201 0202 0195 0196 0197 0198 0203 0057
2002	Corsa-B	Engine	X14NE	✓	✓	✓	✓		
2002	Corsa-B	Engine	X16NE	✓	✓	✓	✓		
2002	Corsa-B	Engine	C14SE	✓	✓	✓	✓		
2002	Corsa-B	Infotainment System	Radio CAR 300	✓	✓	✓	✓		
2002	Corsa-B	Infotainment System	Radio CAR 400	✓	✓	✓	✓		
2002	Corsa-B	Infotainment System	Radio CDR 500	✓	✓	✓	✓		
2002	Corsa-B	Infotainment System	Radio CCR 600	✓	✓	✓	✓		
2002	Corsa-B	Infotainment System	Radio CCRT 700	✓	✓	✓	✓		
2002	Corsa-B	Infotainment System	Radio NCDR 1100/1500	✓	✓	✓	✓		
2002	Corsa-B(GMSA)	Body	Immobiliser	✓	✓	✓	✓		0165 0166
2002	Corsa-B(GMSA)	Engine	I4 NE	✓	✓	✓	✓	✓	0167 0191 0192 0057 0193
2002	Corsa-B(GMSA)	Engine	I6 SE	✓	✓	✓	✓		
2002	Corsa-C	Body	Body Control Module	✓	✓	✓	✓	✓	0052 0059 0139
2002	Corsa-C	Body	Immobiliser	✓	✓	✓	✓		0140 0141
2002	Corsa-C	Body	Airbag	✓	✓	✓	✓	✓	
2002	Corsa-C	Body	Instrument	✓	✓	✓	✓	✓	0177 0178
2002	Corsa-C	Body	Add On Heater	✓	✓	✓	✓	✓	0123 0124
2002	Corsa-C	Body	Electronic Climate Control	✓	✓	✓	✓		
2002	Corsa-C	Chassis	ABS-5.3/5.4(+TC)	✓	✓	✓	✓	✓	
2002	Corsa-C	Chassis	Electronic Power Steering	✓	✓	✓	✓		0142
2002	Corsa-C	Engine	Z10XE	✓	✓	✓	✓	✓	0147 0194 0010 0020
2002	Corsa-C	Engine	Z12XE	✓	✓	✓	✓	✓	0007 0146 0010 0041 0020 0022 0012 0066 0034
2002	Corsa-C	Engine	Z14XE	✓	✓	✓	✓	✓	0147 0146 0010 0020 0022 0012
2002	Corsa-C	Engine	Z16SE	✓	✓	✓	✓	✓	0007 0022 0012
2002	Corsa-C	Engine	Y17DT	✓	✓	✓	✓	✓	
2002	Corsa-C	Engine	Y17DTL	✓	✓	✓	✓	✓	0007 0022 0012
2002	Corsa-C	Engine	Z18XE	✓	✓	✓	✓	✓	0146 0010 0041 0020 0012 0022
2002	Corsa-C	Engine	Z16XE	✓	✓	✓	✓	✓	0007 0022 0012
2002	Corsa-C	Infotainment System	Trip Info Display TID	✓	✓	✓			
2002	Corsa-C	Infotainment System	Radio CAR 2003	✓	✓	✓			
2002	Corsa-C	Infotainment System	Radio CDR 2005	✓	✓	✓	✓		
2002	Corsa-C	Infotainment System	Radio CCR 2006	✓	✓	✓	✓		
2002	Corsa-C	Transmission	AF 13-II/17/20/22 CAN	✓	✓	✓	✓	✓	
2002	Corsa-C	Transmission	MTA(Easytronic)	✓	✓	✓	✓	✓	0012 0149
2002	Corsa-C(GMSA)	Body	Airbag	✓	✓	✓	✓	✓	
2002	Corsa-C(GMSA)	Body	Body Control Module	✓	✓	✓	✓	✓	0052 0059 0139
2002	Corsa-C(GMSA)	Body	Immobiliser	✓	✓	✓	✓		0165 0166
2002	Corsa-C(GMSA)	Body	Instrument	✓	✓	✓	✓		
2002	Corsa-C(GMSA)	Body	Power Window Lifter Front	✓	✓	✓	✓		
2002	Corsa-C(GMSA)	Body	Power Window Lifter Rear	✓	✓	✓	✓		
2002	Corsa-C(GMSA)	Chassis	ABS-5.3/5.4 (+TC) (Anti-lock Braking System)	✓	✓	✓	✓	✓	
2002	Corsa-C(GMSA)	Chassis	Electronic Power Steering	✓	✓	✓	✓		0142
2002	Corsa-C(GMSA)	Engine	C 14 SE	✓	✓	✓	✓	✓	0146 0020
2002	Corsa-C(GMSA)	Engine	C 16 SE	✓	✓	✓	✓	✓	0146 0020
2002	Corsa-C(GMSA)	Engine	Y 17 DT	✓	✓	✓	✓	✓	
2002	Corsa-C(GMSA)	Engine	C 18 XE	✓	✓	✓	✓	✓	0146 0020
2002	Corsa-C(GMSA)	Infotainment System	Trip Info Display TID	✓	✓	✓			
2002	Corsa-C(GMSA)	Infotainment System	Radio CDR 2005	✓	✓	✓	✓		
2002	Corsa-C(GMSA)	Infotainment System	Radio CCRT 2008	✓	✓	✓			
2002	Frontera-B	Body	Airbag	✓	✓	✓	✓		
2002	Frontera-B	Body	Anti Theft Warning	✓	✓	✓	✓		
2002	Frontera-B	Body	Central Door Lock	✓	✓	✓	✓	✓	0165 0166
2002	Frontera-B	Body	Immobiliser	✓	✓	✓	✓		0165 0166
2002	Frontera-B	Engine	Y22DTH	✓	✓	✓	✓	✓	0007
2002	Frontera-B	Infotainment System	Trip Info Display TID	✓	✓	✓			
2002	Frontera-B	Infotainment System	Multi Info Display MID	✓	✓	✓			
2002	Frontera-B	Infotainment System	Radio CAR 300	✓	✓	✓			
2002	Frontera-B	Infotainment System	Radio CAR 400	✓	✓	✓			
2002	Frontera-B	Infotainment System	Radio CDR 500	✓	✓	✓	✓		
2002	Frontera-B	Infotainment System	Radio CCR 600	✓	✓	✓	✓		
2002	Frontera-B	Infotainment System	Radio CCRT 700	✓	✓	✓	✓		
2002	Frontera-B	Infotainment System	Radio NCDR 1100/1500	✓	✓	✓	✓		
2002	Frontera-B	Transmission	AR 25/35	✓	✓	✓	✓	✓	
2002	Movano	Body	Immobiliser	✓	✓	✓	✓		0165 0166
2002	Movano	Body	Airbag	✓	✓	✓	✓		
2002	Omega-B	Body	Immobiliser	✓	✓	✓	✓		0140 0141
2002	Omega-B	Body	Airbag	✓	✓	✓	✓	✓	
2002	Omega-B	Body	Headlamp Levelling Device	✓	✓	✓	✓	✓	0142

2002	Omega-B	Body	Add On Heater	✓	✓	✓	✓	✓	0123 0124
2002	Omega-B	Body	Anti Theft Warning	✓	✓	✓	✓	✓	
2002	Omega-B	Body	Central Door Lock	✓	✓	✓	✓	✓	0165 0166
2002	Omega-B	Body	Electronic Climate Control	✓	✓	✓	✓	✓	
2002	Omega-B	Body	Instrument	✓	✓	✓	✓	✓	
2002	Omega-B	Chassis	ABS-5.3/5.4(+TC)	✓	✓	✓	✓	✓	
2002	Omega-B	Chassis	ESP	✓	✓	✓	✓	✓	
2002	Omega-B	Chassis	Servotronic	✓	✓	✓	✓	✓	
2002	Omega-B	Engine	Y220TH	✓	✓	✓	✓	✓	0007
2002	Omega-B	Engine	Z22XE	✓	✓	✓	✓	✓	0147 0146 0010 0041 0020
2002	Omega-B	Engine	Y25DT	✓	✓	✓	✓	✓	
2002	Omega-B	Engine	Y26SE	✓	✓	✓	✓	✓	0146 0010
2002	Omega-B	Engine	X30XE	✓	✓	✓	✓	✓	
2002	Omega-B	Engine	Y32SE	✓	✓	✓	✓	✓	0146 0010
2002	Omega-B	Infotainment System	Trip Info Display TID	✓	✓	✓	✓	✓	
2002	Omega-B	Infotainment System	Multi Info Display MID	✓	✓	✓	✓	✓	
2002	Omega-B	Infotainment System	Radio CAR 2003	✓	✓	✓	✓	✓	
2002	Omega-B	Infotainment System	Radio CDR 2005	✓	✓	✓	✓	✓	
2002	Omega-B	Infotainment System	Radio CCR 2006	✓	✓	✓	✓	✓	
2002	Omega-B	Transmission	AR 25/35	✓	✓	✓	✓	✓	
2002	Omega-B	Transmission	5L40-E	✓	✓	✓	✓	✓	
2002	Speedster/VX220	Body	Immobiliser	✓	✓	✓	✓	✓	0140 0141
2002	Speedster/VX220	Body	Airbag	✓	✓	✓	✓	✓	
2002	Speedster/VX220	Body	Anti Theft Warning	✓	✓	✓	✓	✓	
2002	Speedster/VX220	Chassis	ABS 430	✓	✓	✓	✓	✓	
2002	Speedster/VX220	Engine	Z20LET	✓	✓	✓	✓	✓	
2002	Speedster/VX220	Engine	Z22SE	✓	✓	✓	✓	✓	0066 0147 0146 0010 0012 0022 0034
2002	Vectra-C/Signum	Body	SDM(Airbag,Sensing&Diagnostic Module)	✓	✓	✓	✓	✓	0000 0001 0002 0003
2002	Vectra-C/Signum	Body	Instrument	✓	✓	✓	✓	✓	0170 0057 0058 0180 0002
2002	Vectra-C/Signum	Body	CIM(Steering Column Module)	✓	✓	✓	✓	✓	0052 0004 0053 0002 0005 0054 0055 0006
2002	Vectra-C/Signum	Body	BCM(Body Control Module)	✓	✓	✓	✓	✓	0181 0182
2002	Vectra-C/Signum	Body	DDM(Driver Door Module)	✓	✓	✓	✓	✓	
2002	Vectra-C/Signum	Body	PDM(Passenger Door Module)	✓	✓	✓	✓	✓	
2002	Vectra-C/Signum	Body	REC(Rear Electrical Centre)	✓	✓	✓	✓	✓	
2002	Vectra-C/Signum	Body	UEC(Underhood Electrical Centre)	✓	✓	✓	✓	✓	
2002	Vectra-C/Signum	Body	SLM(Shift Lever Module)	✓	✓	✓	✓	✓	
2002	Vectra-C/Signum	Body	SRM(Sun Roof Module)	✓	✓	✓	✓	✓	
2002	Vectra-C/Signum	Body	AHL/AFL(Headlamp Levelling)	✓	✓	✓	✓	✓	
2002	Vectra-C/Signum	Body	Electrical Horn	✓	✓	✓	✓	✓	
2002	Vectra-C/Signum	Body	Electronic Seat Memory/Seat Heating	✓	✓	✓	✓	✓	
2002	Vectra-C/Signum	Body	Anti Theft Warning System	✓	✓	✓	✓	✓	
2002	Vectra-C/Signum	Body	Central Door Lock	✓	✓	✓	✓	✓	
2002	Vectra-C/Signum	Body	PAS (Park Pilot)	✓	✓	✓	✓	✓	0002
2002	Vectra-C/Signum	Chassis	ABS/TC/ESP	✓	✓	✓	✓	✓	0004 0005 0063
2002	Vectra-C/Signum	Chassis	TPMS (Tyre Pressure Monitoring System)	✓	✓	✓	✓	✓	0033
2002	Vectra-C/Signum	Chassis	EHPS(Electronic Power Steering)	✓	✓	✓	✓	✓	
2002	Vectra-C/Signum	Chassis	Electronic Cruise Control	✓	✓	✓	✓	✓	
2002	Vectra-C/Signum	Engine	Engine Cooling	✓	✓	✓	✓	✓	
2002	Vectra-C/Signum	Engine	Z18XE	✓	✓	✓	✓	✓	0020 0011 0012 0067 0150 0013
2002	Vectra-C/Signum	Engine	Y200TH	✓	✓	✓	✓	✓	0011 0012 0067 0150
2002	Vectra-C/Signum	Engine	Y22DTR	✓	✓	✓	✓	✓	0011 0012 0067 0150
2002	Vectra-C/Signum	Engine	Z22SE	✓	✓	✓	✓	✓	0011 0012 0067 0150
2002	Vectra-C/Signum	Engine	Z32SE	✓	✓	✓	✓	✓	0020 0150
2002	Vectra-C/Signum	Engine	Z16XE	✓	✓	✓	✓	✓	0011 0012 0067 0150 0013
2002	Vectra-C/Signum	Engine	Engine(default)	✓	✓	✓	✓	✓	
2002	Vectra-C/Signum	Transmission	AF 23-5/33-5/40-6	✓	✓	✓	✓	✓	0033 0034
2002	Vectra-C/Signum	Transmission	AF 23-5/33-5	✓	✓	✓	✓	✓	0033 0034
2002	Vivaro	Body	Airbag	✓	✓	✓	✓	✓	0005
2002	Vivaro	Body	Add On Heater	✓	✓	✓	✓	✓	0123 0124
2002	Vivaro	Body	Body Control Module	✓	✓	✓	✓	✓	
2002	Vivaro	Chassis	ABS (Anti-lock Braking System)	✓	✓	✓	✓	✓	0175
2002	Vivaro	Engine	F9Q 760/762 (L9L)	✓	✓	✓	✓	✓	
2002	Vivaro	Infotainment System	Trip Info Display TID	✓	✓	✓	✓	✓	
2002	Vivaro	Infotainment System	Radio CDR 2005	✓	✓	✓	✓	✓	
2002	Vivaro	Infotainment System	Radio CCR 2006	✓	✓	✓	✓	✓	
2002	Zafira	Body	Immobiliser	✓	✓	✓	✓	✓	0140 0141
2002	Zafira	Body	Instrument	✓	✓	✓	✓	✓	
2002	Zafira	Body	Airbag	✓	✓	✓	✓	✓	
2002	Zafira	Body	Anti Theft Warning	✓	✓	✓	✓	✓	
2002	Zafira	Body	Central Door Lock	✓	✓	✓	✓	✓	
2002	Zafira	Body	Electronic Climate Control	✓	✓	✓	✓	✓	
2002	Zafira	Body	Engine Cooling Module	✓	✓	✓	✓	✓	
2002	Zafira	Chassis	ABS-5.3/5.4(+TC)	✓	✓	✓	✓	✓	
2002	Zafira	Chassis	ESP	✓	✓	✓	✓	✓	0006
2002	Zafira	Chassis	Electronic Power Steering	✓	✓	✓	✓	✓	0142
2002	Zafira	Engine	Z16XE	✓	✓	✓	✓	✓	0007 0022 0012
2002	Zafira	Engine	Z16YNG	✓	✓	✓	✓	✓	
2002	Zafira	Engine	Z18XE	✓	✓	✓	✓	✓	0146 0010 0041 0020 0012 0022
2002	Zafira	Engine	Y200TH	✓	✓	✓	✓	✓	0167 0168 0169 0170
2002	Zafira	Engine	Z20LET	✓	✓	✓	✓	✓	0010 0020 0041 0146 0012 0022 0066 0034
2002	Zafira	Engine	Y22DTR	✓	✓	✓	✓	✓	0012 0022
2002	Zafira	Engine	Z22SE	✓	✓	✓	✓	✓	0066 0147 0146 0010 0012 0022 0034
2002	Zafira	Engine	Z18XEL	✓	✓	✓	✓	✓	0146 0010 0041 0020
2002	Zafira	Infotainment System	Radio CAR 300	✓	✓	✓	✓	✓	
2002	Zafira	Infotainment System	Trip Info Display TID	✓	✓	✓	✓	✓	
2002	Zafira	Infotainment System	Multi Info Display MID	✓	✓	✓	✓	✓	
2002	Zafira	Infotainment System	Radio CAR 400	✓	✓	✓	✓	✓	
2002	Zafira	Infotainment System	Radio CDR 500	✓	✓	✓	✓	✓	
2002	Zafira	Infotainment System	Radio CCR 600	✓	✓	✓	✓	✓	
2002	Zafira	Infotainment System	Radio CCRT 700	✓	✓	✓	✓	✓	
2002	Zafira	Infotainment System	Radio NCDR 1100/1500	✓	✓	✓	✓	✓	
2002	Zafira	Transmission	AF 13-II/17/20/22 CAN	✓	✓	✓	✓	✓	
2002	Zafira	Transmission	MTA(Easytronic)	✓	✓	✓	✓	✓	0012 0149
2001	Agila	Body	Immobiliser	✓	✓	✓	✓	✓	0140 0141
2001	Agila	Body	Airbag	✓	✓	✓	✓	✓	

2001	Agila	Body	Instrument	✓	✓	✓	✓		
2001	Agila	Chassis	ABS	✓	✓	✓	✓	✓	0190
2001	Agila	Chassis	Electronic Power Steering	✓	✓	✓	✓		
2001	Agila	Engine	Z10XEP	✓	✓	✓	✓	✓	0012 0022 0066 0034
2001	Agila	Engine	Z12XE	✓	✓	✓	✓	✓	0007 0146 0010 0041 0020 0022 0012 0066 0034
2001	Agila	Infotainment System	Trip Info Display TID	✓	✓	✓			
2001	Agila	Infotainment System	Radio CAR 2003	✓	✓	✓			
2001	Agila	Infotainment System	Radio CDR 2005	✓	✓	✓	✓		
2001	Astra-F	Body	Immobiliser	✓	✓	✓	✓		0140 0141
2001	Astra-F	Body	Airbag S	✓	✓	✓	✓		
2001	Astra-F	Body	Instrument	✓	✓	✓	✓	✓	
2001	Astra-F	Body	Anti Theft Warning	✓	✓	✓	✓	✓	
2001	Astra-F	Engine	X16SZR	✓	✓	✓	✓	✓	
2001	Astra-F	Engine	X16XEL	✓	✓	✓	✓	✓	0167 0195 0196 0197 0198 0020
2001	Astra-F	Infotainment System	Trip Info Display TID	✓	✓	✓			
2001	Astra-F	Infotainment System	Radio CAR 300	✓	✓	✓			
2001	Astra-F	Infotainment System	Radio CAR 400	✓	✓	✓	✓		
2001	Astra-F	Infotainment System	Radio CDR 500	✓	✓	✓	✓		
2001	Astra-G	Body	Immobiliser	✓	✓	✓	✓		0140 0141
2001	Astra-G	Body	Instrument	✓	✓	✓	✓		
2001	Astra-G	Body	Airbag	✓	✓	✓	✓		
2001	Astra-G	Body	Anti Theft Warning	✓	✓	✓	✓		
2001	Astra-G	Body	Central Door Lock	✓	✓	✓	✓		
2001	Astra-G	Body	Engine Cooling Module	✓	✓	✓	✓		
2001	Astra-G	Body	Add On Heater	✓	✓	✓	✓	✓	0123 0124
2001	Astra-G	Chassis	ABS-5.3/5.4(+TC)	✓	✓	✓	✓	✓	
2001	Astra-G	Chassis	ESP	✓	✓	✓	✓	✓	0006
2001	Astra-G	Chassis	Cruise Control	✓	✓	✓	✓		
2001	Astra-G	Chassis	Electronic Power Steering	✓	✓	✓	✓	✓	
2001	Astra-G	Engine	Z12XE	✓	✓	✓	✓	✓	0007 0146 0010 0041 0020 0022 0012 0066 0034
2001	Astra-G	Engine	Z14XE	✓			✓	✓	0147 0146 0010 0020 0022 0012
2001	Astra-G	Engine	C16SEL	✓	✓	✓	✓	✓	
2001	Astra-G	Engine	Z16SE	✓	✓	✓	✓	✓	0007 0022 0012
2001	Astra-G	Engine	Z16XE	✓	✓	✓	✓	✓	0007 0022 0012
2001	Astra-G	Engine	Y17DT	✓	✓	✓	✓	✓	
2001	Astra-G	Engine	Z18XE	✓	✓	✓	✓	✓	0146 0010 0041 0020 0012 0022
2001	Astra-G	Engine	Z18XEL	✓	✓	✓	✓	✓	0012 0022
2001	Astra-G	Engine	Y20DTH	✓	✓	✓	✓	✓	0167 0168 0169 0170
2001	Astra-G	Engine	Y20DTL	✓	✓	✓	✓		0167
2001	Astra-G	Engine	Z20LET	✓	✓	✓	✓	✓	0010 0020 0041 0146 0012 0022 0066 0034
2001	Astra-G	Engine	Z22SE	✓	✓	✓	✓	✓	0066 0147 0146 0010 0012 0022 0034
2001	Astra-G	Engine	X16SZR	✓	✓	✓	✓	✓	
2001	Astra-G	Engine	X18XE1	✓	✓	✓	✓	✓	0199
2001	Astra-G	Infotainment System	Trip Info Display TID	✓	✓	✓			
2001	Astra-G	Infotainment System	Multi Info Display MID	✓	✓	✓			
2001	Astra-G	Infotainment System	Radio CAR 300	✓	✓	✓			
2001	Astra-G	Infotainment System	Radio CAR 400	✓	✓	✓	✓		
2001	Astra-G	Infotainment System	Radio CDR 500	✓	✓	✓	✓		
2001	Astra-G	Infotainment System	Radio CCR 600	✓	✓	✓	✓		
2001	Astra-G	Infotainment System	Radio CCRT 700	✓	✓	✓	✓		
2001	Astra-G	Infotainment System	Radio NCDR 1100/1500	✓	✓	✓	✓		
2001	Astra-G	Transmission	AF 13-II/17/20/22	✓	✓	✓	✓	✓	
2001	Astra-G	Transmission	AF 13-II/17/20/22 CAN	✓	✓	✓	✓	✓	
2001	Astra-G(GMSA)	Body	Airbag	✓	✓	✓	✓		
2001	Astra-G(GMSA)	Body	Anti Theft Warning	✓	✓	✓	✓		
2001	Astra-G(GMSA)	Body	Engine Cooling Module	✓	✓	✓	✓		
2001	Astra-G(GMSA)	Body	Central Door Lock	✓	✓	✓	✓		
2001	Astra-G(GMSA)	Body	Instrument	✓	✓	✓	✓		
2001	Astra-G(GMSA)	Body	Immobiliser	✓	✓	✓	✓		0165 0166
2001	Astra-G(GMSA)	Chassis	ABS-5.3/5.4 (+TC) (Anti-lock Braking System)	✓	✓	✓	✓	✓	
2001	Astra-G(GMSA)	Chassis	Electronic Power Steering	✓	✓	✓	✓	✓	
2001	Astra-G(GMSA)	Engine	C 16 SEL	✓	✓	✓	✓	✓	
2001	Astra-G(GMSA)	Engine	Z 16 XE	✓			✓	✓	0007 0022 0012
2001	Astra-G(GMSA)	Engine	Z 18 XE	✓	✓	✓	✓	✓	0146 0010 0041 0020 0012 0022
2001	Astra-G(GMSA)	Engine	X 18 XE1	✓	✓	✓	✓	✓	0199
2001	Astra-G(GMSA)	Engine	20 SEL	✓	✓	✓	✓	✓	0020
2001	Astra-G(GMSA)	Engine	Z 20 LET	✓	✓	✓	✓	✓	0146 0010 0041 0020
2001	Astra-G(GMSA)	Infotainment System	Trip Info Display TID	✓	✓	✓			
2001	Campo	Body	Airbag	✓	✓	✓	✓		
2001	Campo	Body	Immobiliser	✓	✓	✓	✓		0165 0166
2001	Corsa-B	Body	Immobiliser	✓	✓	✓	✓		
2001	Corsa-B	Body	Airbag S	✓	✓	✓	✓		
2001	Corsa-B	Body	Airbag SAB6	✓	✓	✓	✓		
2001	Corsa-B	Body	Anti Theft Warning	✓	✓	✓	✓	✓	
2001	Corsa-B	Body	Instrument	✓	✓	✓	✓		
2001	Corsa-B	Chassis	ABS-5.3	✓	✓	✓	✓		
2001	Corsa-B	Chassis	Electronic Power Steering	✓	✓	✓	✓		
2001	Corsa-B	Engine	Z14SZ	✓	✓	✓	✓	✓	
2001	Corsa-B	Engine	X14NE	✓	✓	✓	✓		
2001	Corsa-B	Engine	X16NE	✓	✓	✓	✓		
2001	Corsa-B	Engine	C14SE	✓	✓	✓	✓		
2001	Corsa-B	infotainment System	Radio CAR 300	✓	✓	✓			
2001	Corsa-B	infotainment System	Radio CAR 400	✓	✓	✓	✓		
2001	Corsa-B	infotainment System	Radio CDR 500	✓	✓	✓	✓		
2001	Corsa-B	infotainment System	Radio CCR 600	✓	✓	✓	✓		
2001	Corsa-B	infotainment System	Radio CCRT 700	✓	✓	✓	✓		
2001	Corsa-B	infotainment System	Radio NCDR 1100/1500	✓	✓	✓	✓		
2001	Corsa-B(GMSA)	Body	Immobiliser	✓	✓	✓	✓		0165 0166
2001	Corsa-B(GMSA)	Engine	14 NE	✓	✓	✓	✓	✓	0167 0191 0192 0057 0193
2001	Corsa-B(GMSA)	Engine	16 SE	✓	✓	✓			
2001	Corsa-C	Body	Body Control Module	✓	✓	✓	✓	✓	0052 0059 0139
2001	Corsa-C	Body	Immobiliser	✓	✓	✓	✓		0140 0141
2001	Corsa-C	Body	Airbag	✓	✓	✓	✓	✓	

2001	Corsa-C	Body	Instrument	✓	✓	✓	✓	✓	0177 0178
2001	Corsa-C	Body	Add On Heater	✓	✓	✓	✓	✓	0123 0124
2001	Corsa-C	Chassis	ABS-5.3/5.4(+TC)	✓	✓	✓	✓	✓	
2001	Corsa-C	Chassis	Electronic Power Steering	✓	✓	✓	✓	✓	0142
2001	Corsa-C	Engine	Z10XE	✓	✓	✓	✓	✓	0147 0194 0010 0020
2001	Corsa-C	Engine	Z12XE	✓	✓	✓	✓	✓	0007 0146 0010 0041 0020 0022 0012 0066 0034
2001	Corsa-C	Engine	Z14XE	✓			✓	✓	0147 0146 0010 0020 0022 0012
2001	Corsa-C	Engine	Y17DT	✓	✓	✓	✓	✓	
2001	Corsa-C	Engine	Y17DTL	✓	✓	✓	✓	✓	0007 0022 0012
2001	Corsa-C	Engine	Z18XE	✓	✓	✓	✓	✓	0146 0010 0041 0020 0012 0022
2001	Corsa-C	Infotainment System	Trip Info Display TID	✓	✓	✓			
2001	Corsa-C	Infotainment System	Radio CAR 2003	✓	✓	✓			
2001	Corsa-C	Infotainment System	Radio CDR 2005	✓	✓	✓	✓		
2001	Corsa-C	Infotainment System	Radio CCR 2006	✓	✓	✓	✓		
2001	Corsa-C	Transmission	AF 13-11/17/20/22 CAN	✓	✓	✓	✓	✓	
2001	Corsa-C	Transmission	MTA(Easytronic)	✓	✓	✓	✓	✓	0012 0149
2001	Frontera-B	Body	Airbag	✓	✓	✓	✓	✓	
2001	Frontera-B	Body	Anti Theft Warning	✓	✓	✓	✓	✓	
2001	Frontera-B	Body	Central Door Lock	✓	✓	✓	✓	✓	0165 0166
2001	Frontera-B	Body	Immobiliser	✓	✓	✓	✓	✓	0165 0166
2001	Frontera-B	Engine	Y22DTH	✓	✓	✓	✓	✓	0007
2001	Frontera-B	Infotainment System	Trip Info Display TID	✓	✓	✓			
2001	Frontera-B	Infotainment System	Multi Info Display MID	✓	✓	✓			
2001	Frontera-B	Infotainment System	Radio CAR 300	✓	✓	✓			
2001	Frontera-B	Infotainment System	Radio CAR 400	✓	✓	✓	✓		
2001	Frontera-B	Infotainment System	Radio CDR 500	✓	✓	✓	✓		
2001	Frontera-B	Infotainment System	Radio CCR 600	✓	✓	✓	✓		
2001	Frontera-B	Infotainment System	Radio CCRT 700	✓	✓	✓	✓		
2001	Frontera-B	Infotainment System	Radio NCDR 1100/1500	✓	✓	✓	✓		
2001	Frontera-B	Transmission	AR 25/35	✓	✓	✓	✓	✓	
2001	Movano	Body	Immobiliser	✓	✓	✓	✓	✓	0165 0166
2001	Omega-B	Body	Airbag	✓	✓	✓	✓	✓	
2001	Omega-B	Body	Headlamp Levelling Device	✓	✓	✓	✓	✓	0142
2001	Omega-B	Body	Add On Heater	✓	✓	✓	✓	✓	0123 0124
2001	Omega-B	Body	Anti Theft Warning	✓	✓	✓	✓	✓	
2001	Omega-B	Body	Central Door Lock	✓	✓	✓	✓	✓	0165 0166
2001	Omega-B	Body	Electronic Climate Control	✓	✓	✓	✓	✓	
2001	Omega-B	Body	Immobiliser	✓	✓	✓	✓	✓	0165 0166
2001	Omega-B	Body	Instrument	✓	✓	✓	✓	✓	
2001	Omega-B	Chassis	ABS-5.3/5.4(+TC)	✓	✓	✓	✓	✓	
2001	Omega-B	Chassis	Servotronic	✓	✓	✓	✓	✓	
2001	Omega-B	Engine	X20XEV	✓	✓	✓	✓	✓	
2001	Omega-B	Engine	Y22DTH	✓	✓	✓	✓	✓	0007
2001	Omega-B	Engine	Z22XE	✓	✓	✓	✓	✓	0147 0146 0010 0041 0020
2001	Omega-B	Engine	Y26SE	✓	✓	✓	✓	✓	0146 0010
2001	Omega-B	Engine	X30XE	✓	✓	✓	✓	✓	
2001	Omega-B	Engine	Y32SE	✓	✓	✓	✓	✓	0146 0010
2001	Omega-B	Infotainment System	Trip Info Display TID	✓	✓	✓			
2001	Omega-B	Infotainment System	Multi Info Display MID	✓	✓	✓			
2001	Omega-B	Infotainment System	Radio CAR 2003	✓	✓	✓			
2001	Omega-B	Infotainment System	Radio CDR 2005	✓	✓	✓	✓		
2001	Omega-B	Infotainment System	Radio CCR 2006	✓	✓	✓	✓		
2001	Omega-B	Transmission	AR 25/35	✓	✓	✓	✓	✓	
2001	Speedster/VX220	Body	Immobiliser	✓	✓	✓	✓	✓	0140 0141
2001	Speedster/VX220	Body	Airbag	✓	✓	✓	✓	✓	
2001	Speedster/VX220	Body	Anti Theft Warning	✓	✓	✓	✓	✓	
2001	Speedster/VX220	Chassis	ABS 430	✓	✓	✓	✓	✓	
2001	Speedster/VX220	Engine	Z22SE	✓	✓	✓	✓	✓	0066 0147 0146 0010 0012 0022 0034
2001	Vectra-B	Body	Immobiliser	✓	✓	✓	✓	✓	
2001	Vectra-B	Body	Instrument	✓	✓	✓	✓	✓	
2001	Vectra-B	Body	Airbag	✓	✓	✓	✓	✓	
2001	Vectra-B	Body	Airbag SAB6	✓	✓	✓	✓	✓	
2001	Vectra-B	Body	Add On Heater	✓	✓	✓	✓	✓	0123 0124
2001	Vectra-B	Body	Anti Theft Warning	✓	✓	✓	✓	✓	
2001	Vectra-B	Body	Electronic Climate Control	✓	✓	✓	✓	✓	
2001	Vectra-B	Body	Headlamp Adjustment(Left)	✓	✓	✓	✓	✓	
2001	Vectra-B	Body	Headlamp Adjustment(Right)	✓	✓	✓	✓	✓	
2001	Vectra-B	Chassis	ABS 430	✓	✓	✓	✓	✓	
2001	Vectra-B	Chassis	ABS-5.3/5.4(+TC)	✓	✓	✓	✓	✓	
2001	Vectra-B	Engine	X16XEL	✓	✓	✓	✓	✓	0167 0195 0196 0197 0198 0020
2001	Vectra-B	Engine	Y16XE	✓	✓	✓	✓	✓	
2001	Vectra-B	Engine	Z16XE	✓	✓	✓	✓	✓	0007 0022 0012
2001	Vectra-B	Engine	X18XE	✓	✓	✓	✓	✓	0167 0204 0205 0206 0041
2001	Vectra-B	Engine	Z18XE	✓	✓	✓	✓	✓	0146 0010 0041 0020 0012 0022
2001	Vectra-B	Engine	Z18XEL	✓	✓	✓	✓	✓	0012 0022
2001	Vectra-B	Engine	C20SEL	✓	✓	✓	✓	✓	0167
2001	Vectra-B	Engine	Y20DTH	✓	✓	✓	✓	✓	0167 0168 0169 0170
2001	Vectra-B	Engine	X20XEV	✓	✓	✓	✓	✓	
2001	Vectra-B	Engine	C22SEL	✓	✓	✓	✓	✓	0205 0041 0203
2001	Vectra-B	Engine	Y22DTR	✓	✓	✓	✓	✓	0012 0022
2001	Vectra-B	Engine	Z22SE	✓	✓	✓	✓	✓	0066 0147 0146 0010 0012 0022 0034
2001	Vectra-B	Engine	Y26SE	✓	✓	✓	✓	✓	0146 0010
2001	Vectra-B	Engine	Z18XE1	✓	✓	✓	✓	✓	0146 0010 0041 0020
2001	Vectra-B	Infotainment System	Trip Info Display TID	✓	✓	✓			
2001	Vectra-B	Infotainment System	Multi Info Display MID	✓	✓	✓			
2001	Vectra-B	Infotainment System	Radio CAR 300	✓	✓	✓			
2001	Vectra-B	Infotainment System	Radio CAR 400	✓	✓	✓	✓		
2001	Vectra-B	Infotainment System	Radio CDR 500	✓	✓	✓	✓		
2001	Vectra-B	Infotainment System	Radio CCR 600	✓	✓	✓	✓		
2001	Vectra-B	Infotainment System	Radio CCRT 700	✓	✓	✓	✓		
2001	Vectra-B	Infotainment System	Radio NCDR 1100/1500	✓	✓	✓	✓		
2001	Vectra-B	Transmission	AF 13-11/17/20/22	✓	✓	✓	✓	✓	
2001	Vectra-B	Transmission	AF 13-11/17/20/22 CAN	✓	✓	✓	✓	✓	
2001	Vivaro	Body	Airbag	✓	✓	✓	✓	✓	0005

2001	Vivaro	Body	Add On Heater	✓	✓	✓	✓	✓	0123 0124
2001	Vivaro	Body	Body Control Module	✓	✓	✓	✓	✓	
2001	Vivaro	Chassis	ABS (Anti-lock Braking System)	✓	✓	✓	✓	✓	0175
2001	Vivaro	Engine	F9Q 760/762 (1.9L)	✓	✓	✓	✓	✓	
2001	Vivaro	Infotainment System	Trip Info Display TID	✓	✓	✓	✓	✓	
2001	Vivaro	Infotainment System	Multi Info Display MID	✓	✓	✓	✓	✓	
2001	Vivaro	Infotainment System	Radio CDR 2005	✓	✓	✓	✓	✓	
2001	Vivaro	Infotainment System	Radio CCR 2006	✓	✓	✓	✓	✓	
2001	Zafira	Body	Immobiliser	✓	✓	✓	✓	✓	0140 0141
2001	Zafira	Body	Instrument	✓	✓	✓	✓	✓	
2001	Zafira	Body	Airbag	✓	✓	✓	✓	✓	
2001	Zafira	Body	Anti Theft Warning	✓	✓	✓	✓	✓	
2001	Zafira	Body	Central Door Lock	✓	✓	✓	✓	✓	
2001	Zafira	Body	Electronic Climate Control	✓	✓	✓	✓	✓	
2001	Zafira	Body	Engine Cooling Module	✓	✓	✓	✓	✓	
2001	Zafira	Chassis	ABS-5.3/5.4(+TC)	✓	✓	✓	✓	✓	
2001	Zafira	Chassis	ESP	✓	✓	✓	✓	✓	0006
2001	Zafira	Chassis	Electronic Power Steering	✓	✓	✓	✓	✓	0142
2001	Zafira	Engine	Z16XE	✓	✓	✓	✓	✓	0007 0022 0012
2001	Zafira	Engine	Z16VNG	✓	✓	✓	✓	✓	
2001	Zafira	Engine	Z18XE	✓	✓	✓	✓	✓	0146 0010 0041 0020 0012 0022
2001	Zafira	Engine	Z20DTH	✓	✓	✓	✓	✓	0167 0168 0169 0170
2001	Zafira	Engine	Z22SE	✓	✓	✓	✓	✓	0066 0147 0146 0010 0012 0022 0034
2001	Zafira	Engine	Z18XEL	✓	✓	✓	✓	✓	0146 0010 0041 0020
2001	Zafira	Infotainment System	Radio CAR 300	✓	✓	✓	✓	✓	
2001	Zafira	Infotainment System	Trip Info Display TID	✓	✓	✓	✓	✓	
2001	Zafira	Infotainment System	Multi Info Display MID	✓	✓	✓	✓	✓	
2001	Zafira	Infotainment System	Radio CAR 400	✓	✓	✓	✓	✓	
2001	Zafira	Infotainment System	Radio CDR 500	✓	✓	✓	✓	✓	
2001	Zafira	Infotainment System	Radio CCR 600	✓	✓	✓	✓	✓	
2001	Zafira	Infotainment System	Radio CCRT 700	✓	✓	✓	✓	✓	
2001	Zafira	Infotainment System	Radio NCDR 1100/1500	✓	✓	✓	✓	✓	
2001	Zafira	Transmission	AF 13-II/17/20/22 CAN	✓	✓	✓	✓	✓	
2000	Agila	Body	Immobiliser	✓	✓	✓	✓	✓	0140 0141
2000	Agila	Body	Airbag	✓	✓	✓	✓	✓	
2000	Agila	Body	Instrument	✓	✓	✓	✓	✓	
2000	Agila	Chassis	ABS	✓	✓	✓	✓	✓	0190
2000	Agila	Chassis	Electronic Power Steering	✓	✓	✓	✓	✓	
2000	Agila	Engine	Z10XEP	✓	✓	✓	✓	✓	0012 0022 0066 0034
2000	Agila	Engine	Z12XE	✓	✓	✓	✓	✓	0007 0146 0010 0041 0020 0022 0012 0066 0034
2000	Agila	Engine	Z10XE	✓	✓	✓	✓	✓	0147 0194 0010 0020
2000	Agila	Infotainment System	Trip Info Display TID	✓	✓	✓	✓	✓	
2000	Agila	Infotainment System	Radio CAR 2003	✓	✓	✓	✓	✓	
2000	Agila	Infotainment System	Radio CDR 2005	✓	✓	✓	✓	✓	
2000	Arena	Body	Immobiliser	✓	✓	✓	✓	✓	0165 0166
2000	Astra-F	Body	Immobiliser	✓	✓	✓	✓	✓	
2000	Astra-F	Body	Airbag S	✓	✓	✓	✓	✓	
2000	Astra-F	Body	Instrument	✓	✓	✓	✓	✓	
2000	Astra-F	Body	Anti Theft Warning	✓	✓	✓	✓	✓	
2000	Astra-F	Engine	16NZR	✓	✓	✓	✓	✓	
2000	Astra-F	Engine	X16SZR	✓	✓	✓	✓	✓	
2000	Astra-F	Engine	X16XEL	✓	✓	✓	✓	✓	0167 0195 0196 0197 0198 0020
2000	Astra-F	Infotainment System	Trip Info Display TID	✓	✓	✓	✓	✓	
2000	Astra-F	Infotainment System	Radio CAR 300	✓	✓	✓	✓	✓	
2000	Astra-F	Infotainment System	Radio CAR 400	✓	✓	✓	✓	✓	
2000	Astra-F	Infotainment System	Radio CDR 500	✓	✓	✓	✓	✓	
2000	Astra-F	Transmission	AF 13II/20/22/30	✓	✓	✓	✓	✓	
2000	Astra-G	Body	Immobiliser	✓	✓	✓	✓	✓	0140 0141
2000	Astra-G	Body	Instrument	✓	✓	✓	✓	✓	
2000	Astra-G	Body	Airbag	✓	✓	✓	✓	✓	
2000	Astra-G	Body	Airbag SAB6	✓	✓	✓	✓	✓	
2000	Astra-G	Body	Anti Theft Warning	✓	✓	✓	✓	✓	
2000	Astra-G	Body	Central Door Lock	✓	✓	✓	✓	✓	
2000	Astra-G	Body	Engine Cooling Module	✓	✓	✓	✓	✓	
2000	Astra-G	Body	Add On Heater	✓	✓	✓	✓	✓	0123 0124
2000	Astra-G	Chassis	ABS-5.3/5.4(+TC)	✓	✓	✓	✓	✓	
2000	Astra-G	Chassis	ESP	✓	✓	✓	✓	✓	0006
2000	Astra-G	Chassis	Cruise Control	✓	✓	✓	✓	✓	
2000	Astra-G	Chassis	Electronic Power Steering	✓	✓	✓	✓	✓	
2000	Astra-G	Engine	X12XE	✓	✓	✓	✓	✓	0167 0197 0203 0202
2000	Astra-G	Engine	X14XE	✓	✓	✓	✓	✓	
2000	Astra-G	Engine	C16SEL	✓	✓	✓	✓	✓	
2000	Astra-G	Engine	X16SZR	✓	✓	✓	✓	✓	
2000	Astra-G	Engine	X16XEL	✓	✓	✓	✓	✓	0167 0195 0196 0197 0198 0020
2000	Astra-G	Engine	X17DTL	✓	✓	✓	✓	✓	
2000	Astra-G	Engine	Y17DT	✓	✓	✓	✓	✓	
2000	Astra-G	Engine	X18XE1	✓	✓	✓	✓	✓	
2000	Astra-G	Engine	X20DTH	✓	✓	✓	✓	✓	
2000	Astra-G	Engine	X20XER	✓	✓	✓	✓	✓	
2000	Astra-G	Engine	X20XEV	✓	✓	✓	✓	✓	
2000	Astra-G	Engine	Z20LET	✓	✓	✓	✓	✓	0167
2000	Astra-G	Engine	Z22SE	✓	✓	✓	✓	✓	0066 0147 0146 0010 0012 0022 0034
2000	Astra-G	Infotainment System	Trip Info Display TID	✓	✓	✓	✓	✓	
2000	Astra-G	Infotainment System	Multi Info Display MID	✓	✓	✓	✓	✓	
2000	Astra-G	Infotainment System	Radio CAR 300	✓	✓	✓	✓	✓	
2000	Astra-G	Infotainment System	Radio CAR 400	✓	✓	✓	✓	✓	
2000	Astra-G	Infotainment System	Radio CDR 500	✓	✓	✓	✓	✓	
2000	Astra-G	Infotainment System	Radio CCR 600	✓	✓	✓	✓	✓	
2000	Astra-G	Infotainment System	Radio CCRT 700	✓	✓	✓	✓	✓	
2000	Astra-G	Infotainment System	Radio NCDR 1100/1500	✓	✓	✓	✓	✓	
2000	Astra-G	Transmission	AF 13-II/17/20/22	✓	✓	✓	✓	✓	
2000	Astra-G(GMSA)	Body	Airbag	✓	✓	✓	✓	✓	
2000	Astra-G(GMSA)	Body	Anti Theft Warning	✓	✓	✓	✓	✓	
2000	Astra-G(GMSA)	Body	Central Door Lock	✓	✓	✓	✓	✓	
2000	Astra-G(GMSA)	Body	Engine Cooling Module	✓	✓	✓	✓	✓	

2000	Astra-G(GMSA)	Body	Immobiliser	✓	✓	✓	✓		0165 0166
2000	Astra-G(GMSA)	Body	Instrument	✓	✓	✓	✓		
2000	Astra-G(GMSA)	Chassis	ABS-5.3/5.4 (+TC) (Anti-lock Braking System)	✓	✓	✓	✓	✓	
2000	Astra-G(GMSA)	Chassis	Electronic Power Steering	✓	✓	✓	✓	✓	
2000	Astra-G(GMSA)	Engine	C 16 SEL	✓	✓	✓	✓	✓	
2000	Astra-G(GMSA)	Engine	X 18 YE1	✓	✓	✓	✓	✓	0199
2000	Astra-G(GMSA)	Engine	20 SEL	✓	✓	✓	✓	✓	0020
2000	Astra-G(GMSA)	Engine	Z 20 LET	✓	✓	✓	✓	✓	0146 0010 0041 0020
2000	Astra-G(GMSA)	Infotainment System	Trip Info Display TID	✓	✓	✓	✓	✓	
2000	Campo	Body	Airbag	✓	✓	✓	✓	✓	
2000	Corsa-B	Body	Immobiliser	✓	✓	✓	✓	✓	
2000	Corsa-B	Body	Airbag S	✓	✓	✓	✓	✓	
2000	Corsa-B	Body	Airbag SAB6	✓	✓	✓	✓	✓	
2000	Corsa-B	Body	Anti Theft Warning	✓	✓	✓	✓	✓	
2000	Corsa-B	Body	Airbag	✓	✓	✓	✓	✓	
2000	Corsa-B	Chassis	ABS-5.3	✓	✓	✓	✓	✓	
2000	Corsa-B	Chassis	Electronic Power Steering	✓	✓	✓	✓	✓	
2000	Corsa-B	Engine	X10XE	✓	✓	✓	✓	✓	0167 0197 0203 0202
2000	Corsa-B	Engine	X12XE	✓	✓	✓	✓	✓	0167 0197 0203 0202
2000	Corsa-B	Engine	C14SEL	✓	✓	✓	✓	✓	
2000	Corsa-B	Engine	X14SZ	✓	✓	✓	✓	✓	
2000	Corsa-B	Engine	X14XE	✓	✓	✓	✓	✓	
2000	Corsa-B	Engine	C16SEL	✓	✓	✓	✓	✓	
2000	Corsa-B	Engine	X16XE	✓	✓	✓	✓	✓	0167 0196 0197 0198 0020 0202 0057
2000	Corsa-B	Engine	X14NE	✓	✓	✓	✓	✓	
2000	Corsa-B	Engine	X16NE	✓	✓	✓	✓	✓	
2000	Corsa-B	Engine	C14SE	✓	✓	✓	✓	✓	
2000	Corsa-B	Infotainment System	Radio CAR 300	✓	✓	✓	✓	✓	
2000	Corsa-B	Infotainment System	Radio CAR 400	✓	✓	✓	✓	✓	
2000	Corsa-B	Infotainment System	Radio CDR 500	✓	✓	✓	✓	✓	
2000	Corsa-B	Infotainment System	Radio CCR 600	✓	✓	✓	✓	✓	
2000	Corsa-B	Infotainment System	Radio NCDR 1100/1500	✓	✓	✓	✓	✓	
2000	Corsa-B	Infotainment System	Radio CCRT 700	✓	✓	✓	✓	✓	
2000	Corsa-B	Transmission	AF 13/11/20/22/30	✓	✓	✓	✓	✓	
2000	Corsa-B	Transmission	AF 13/14/20	✓	✓	✓	✓	✓	
2000	Corsa-B(GMSA)	Body	Immobiliser	✓	✓	✓	✓	✓	0165 0166
2000	Corsa-B(GMSA)	Engine	13 NE	✓	✓	✓	✓	✓	0167 0191 0192 0057 0193
2000	Corsa-B(GMSA)	Engine	14 NE	✓	✓	✓	✓	✓	0167 0191 0192 0057 0193
2000	Corsa-B(GMSA)	Engine	16 SE	✓	✓	✓	✓	✓	
2000	Frontera-B	Body	Airbag	✓	✓	✓	✓	✓	
2000	Frontera-B	Body	Anti Theft Warning	✓	✓	✓	✓	✓	
2000	Frontera-B	Body	Central Door Lock	✓	✓	✓	✓	✓	0165 0166
2000	Frontera-B	Body	Immobiliser	✓	✓	✓	✓	✓	0165 0166
2000	Frontera-B	Engine	X22DTH	✓	✓	✓	✓	✓	
2000	Frontera-B	Engine	Y22DTH	✓	✓	✓	✓	✓	0007
2000	Frontera-B	Infotainment System	Trip Info Display TID	✓	✓	✓	✓	✓	
2000	Frontera-B	Infotainment System	Multi Info Display MID	✓	✓	✓	✓	✓	
2000	Frontera-B	Infotainment System	Radio CAR 300	✓	✓	✓	✓	✓	
2000	Frontera-B	Infotainment System	Radio CAR 400	✓	✓	✓	✓	✓	
2000	Frontera-B	Infotainment System	Radio CDR 500	✓	✓	✓	✓	✓	
2000	Frontera-B	Infotainment System	Radio CCR 600	✓	✓	✓	✓	✓	
2000	Frontera-B	Infotainment System	Radio CCRT 700	✓	✓	✓	✓	✓	
2000	Frontera-B	Infotainment System	Radio NCDR 1100/1500	✓	✓	✓	✓	✓	
2000	Frontera-B	Transmission	AR 25/35	✓	✓	✓	✓	✓	
2000	Movano	Body	Immobiliser	✓	✓	✓	✓	✓	0165 0166
2000	Omega-B	Body	Airbag	✓	✓	✓	✓	✓	
2000	Omega-B	Body	Headlamp Levelling Device	✓	✓	✓	✓	✓	0142
2000	Omega-B	Body	Add On Heater	✓	✓	✓	✓	✓	0123 0124
2000	Omega-B	Body	Anti Theft Warning	✓	✓	✓	✓	✓	
2000	Omega-B	Body	Central Door Lock	✓	✓	✓	✓	✓	0165 0166
2000	Omega-B	Body	Electronic Climate Control	✓	✓	✓	✓	✓	
2000	Omega-B	Body	Immobiliser	✓	✓	✓	✓	✓	0165 0166
2000	Omega-B	Body	Instrument	✓	✓	✓	✓	✓	
2000	Omega-B	Chassis	ABS-5.3/5.4(+TC)	✓	✓	✓	✓	✓	
2000	Omega-B	Chassis	Servotronic	✓	✓	✓	✓	✓	
2000	Omega-B	Engine	X20DTH	✓	✓	✓	✓	✓	
2000	Omega-B	Engine	X20XEV	✓	✓	✓	✓	✓	
2000	Omega-B	Engine	Y22XE	✓	✓	✓	✓	✓	
2000	Omega-B	Engine	Y25XE	✓	✓	✓	✓	✓	
2000	Omega-B	Engine	Y30XE	✓	✓	✓	✓	✓	
2000	Omega-B	Infotainment System	Trip Info Display TID	✓	✓	✓	✓	✓	
2000	Omega-B	Infotainment System	Multi Info Display MID	✓	✓	✓	✓	✓	
2000	Omega-B	Infotainment System	Radio CAR 2003	✓	✓	✓	✓	✓	
2000	Omega-B	Infotainment System	Radio CDR 2005	✓	✓	✓	✓	✓	
2000	Omega-B	Infotainment System	Radio CCR 2006	✓	✓	✓	✓	✓	
2000	Omega-B	Transmission	AR 25/35	✓	✓	✓	✓	✓	
2000	Vauxhall VX88	Body	Airbag	✓	✓	✓	✓	✓	
2000	Vauxhall VX88	Body	Airbag-S	✓	✓	✓	✓	✓	
2000	Vauxhall VX88	Body	Airbag SAB6	✓	✓	✓	✓	✓	
2000	Vauxhall VX88	Body	Immobiliser	✓	✓	✓	✓	✓	0165 0166
2000	Vauxhall VX88	Chassis	ABS-5.3 (Anti-lock Braking System)	✓	✓	✓	✓	✓	
2000	Vauxhall VX88	Engine	X 14 XE	✓	✓	✓	✓	✓	
2000	Vauxhall VX88	Engine	X 16 XE	✓	✓	✓	✓	✓	0167 0196 0197 0198 0020 0202 0057
2000	Vauxhall VX88	Engine	C 16 SEL	✓	✓	✓	✓	✓	
2000	Vauxhall VX88	Infotainment System	Radio CAR 300	✓	✓	✓	✓	✓	
2000	Vauxhall VX88	Infotainment System	Radio CAR 400	✓	✓	✓	✓	✓	
2000	Vauxhall VX88	Infotainment System	Radio CDR 500	✓	✓	✓	✓	✓	
2000	Vauxhall VX88	Infotainment System	Radio CCR 600	✓	✓	✓	✓	✓	
2000	Vauxhall VX88	Infotainment System	Radio CCRT 700	✓	✓	✓	✓	✓	
2000	Vauxhall VX88	Transmission	AF 13/14/20	✓	✓	✓	✓	✓	
2000	Vectra-B	Body	Immobiliser	✓	✓	✓	✓	✓	
2000	Vectra-B	Body	Instrument	✓	✓	✓	✓	✓	
2000	Vectra-B	Body	Airbag SAB6	✓	✓	✓	✓	✓	
2000	Vectra-B	Body	Add On Heater	✓	✓	✓	✓	✓	0123 0124
2000	Vectra-B	Body	Anti Theft Warning	✓	✓	✓	✓	✓	
2000	Vectra-B	Body	Electronic Climate Control	✓	✓	✓	✓	✓	
2000	Vectra-B	Body	Headlamp Adjustment(Left)	✓	✓	✓	✓	✓	

2000	Vectra-B	Body	Headlamp Adjustment (Right)	✓	✓	✓	✓		
2000	Vectra-B	Chassis	ABS 430	✓	✓	✓	✓		
2000	Vectra-B	Chassis	ABS-5.3/5.4(+TC)	✓	✓	✓	✓	✓	
2000	Vectra-B	Engine	X16SZR	✓	✓	✓	✓	✓	
2000	Vectra-B	Engine	X16XEL	✓	✓	✓	✓	✓	0167 0195 0196 0197 0198 0020
2000	Vectra-B	Engine	Y16XE	✓	✓	✓	✓	✓	
2000	Vectra-B	Engine	X18XE1	✓	✓	✓	✓	✓	
2000	Vectra-B	Engine	Z0NEJ	✓	✓	✓	✓	✓	
2000	Vectra-B	Engine	C20SEL	✓	✓	✓	✓	✓	0167
2000	Vectra-B	Engine	X20DTH	✓	✓	✓	✓	✓	
2000	Vectra-B	Engine	X20DTL	✓	✓	✓	✓	✓	
2000	Vectra-B	Engine	X20XEV	✓	✓	✓	✓	✓	
2000	Vectra-B	Engine	C22SEL	✓	✓	✓	✓	✓	0205 0041 0203
2000	Vectra-B	Engine	16LZ2	✓	✓	✓	✓	✓	
2000	Vectra-B	Engine	X18XE	✓	✓	✓	✓	✓	0167 0203 0204 0205 0041
2000	Vectra-B	Engine	X25XE	✓	✓	✓	✓	✓	
2000	Vectra-B	Infotainment System	Trip Info Display TID	✓	✓	✓	✓	✓	
2000	Vectra-B	Infotainment System	Multi Info Display MID	✓	✓	✓	✓	✓	
2000	Vectra-B	Infotainment System	Radio CAR 300	✓	✓	✓	✓	✓	
2000	Vectra-B	Infotainment System	Radio CAR 400	✓	✓	✓	✓	✓	
2000	Vectra-B	Infotainment System	Radio CDR 500	✓	✓	✓	✓	✓	
2000	Vectra-B	Infotainment System	Radio CCRT 700	✓	✓	✓	✓	✓	
2000	Vectra-B	Transmission	AF 13-II/17/20/22	✓	✓	✓	✓	✓	
2000	Vectra-B	Transmission	AF 13-II/17/20/22 CAN	✓	✓	✓	✓	✓	
2000	Zafira	Body	Immobiliser	✓	✓	✓	✓	✓	0140 0141
2000	Zafira	Body	Instrument	✓	✓	✓	✓	✓	
2000	Zafira	Body	Airbag	✓	✓	✓	✓	✓	
2000	Zafira	Body	Anti Theft Warning	✓	✓	✓	✓	✓	
2000	Zafira	Body	Central Door Lock	✓	✓	✓	✓	✓	
2000	Zafira	Body	Electronic Climate Control	✓	✓	✓	✓	✓	
2000	Zafira	Body	Engine Cooling Module	✓	✓	✓	✓	✓	
2000	Zafira	Body	Airbag SAB6	✓	✓	✓	✓	✓	
2000	Zafira	Chassis	ABS-5.3/5.4(+TC)	✓	✓	✓	✓	✓	
2000	Zafira	Chassis	ESP	✓	✓	✓	✓	✓	0006
2000	Zafira	Chassis	Cruise Control	✓	✓	✓	✓	✓	
2000	Zafira	Chassis	Electronic Power Steering	✓	✓	✓	✓	✓	0142
2000	Zafira	Engine	X16XEL	✓	✓	✓	✓	✓	0167 0195 0196 0197 0198 0020
2000	Zafira	Engine	X18XE1	✓	✓	✓	✓	✓	
2000	Zafira	Engine	X20DTL	✓	✓	✓	✓	✓	
2000	Zafira	Infotainment System	Radio CAR 300	✓	✓	✓	✓	✓	
2000	Zafira	Infotainment System	Trip Info Display TID	✓	✓	✓	✓	✓	
2000	Zafira	Infotainment System	Multi Info Display MID	✓	✓	✓	✓	✓	
2000	Zafira	Infotainment System	Radio CAR 300	✓	✓	✓	✓	✓	
2000	Zafira	Infotainment System	Radio CAR 400	✓	✓	✓	✓	✓	
2000	Zafira	Infotainment System	Radio CDR 500	✓	✓	✓	✓	✓	
2000	Zafira	Infotainment System	Radio CCR 600	✓	✓	✓	✓	✓	
2000	Zafira	Infotainment System	Radio CCRT 700	✓	✓	✓	✓	✓	
2000	Zafira	Infotainment System	Radio NCDR 1100/1500	✓	✓	✓	✓	✓	
2000	Zafira	Transmission	AF 13-II/17/20/22 CAN	✓	✓	✓	✓	✓	
1999	Arena	Body	Immobiliser	✓	✓	✓	✓	✓	0165 0166
1999	Astra-F	Body	Immobiliser	✓	✓	✓	✓	✓	
1999	Astra-F	Body	Airbag S	✓	✓	✓	✓	✓	
1999	Astra-F	Body	Instrument	✓	✓	✓	✓	✓	
1999	Astra-F	Body	Anti Theft Warning	✓	✓	✓	✓	✓	
1999	Astra-F	Engine	16NZR	✓	✓	✓	✓	✓	
1999	Astra-F	Engine	X16SZR	✓	✓	✓	✓	✓	
1999	Astra-F	Engine	X16XEL	✓	✓	✓	✓	✓	0167 0195 0196 0197 0198 0020
1999	Astra-F	Engine	18SE	✓	✓	✓	✓	✓	
1999	Astra-F	Engine	C18SEL	✓	✓	✓	✓	✓	0167
1999	Astra-F	Engine	C16SE	✓	✓	✓	✓	✓	
1999	Astra-F	Engine	X18XE	✓	✓	✓	✓	✓	0167 0203 0204 0205 0041
1999	Astra-F	Infotainment System	Trip Info Display TID	✓	✓	✓	✓	✓	
1999	Astra-F	Infotainment System	Multi Info Display MID	✓	✓	✓	✓	✓	
1999	Astra-F	Infotainment System	Radio CAR 300	✓	✓	✓	✓	✓	
1999	Astra-F	Infotainment System	Radio CAR 400	✓	✓	✓	✓	✓	
1999	Astra-F	Infotainment System	Radio CDR 500	✓	✓	✓	✓	✓	
1999	Astra-F	Transmission	AF 13II/20/22/30	✓	✓	✓	✓	✓	
1999	Astra-G	Body	Immobiliser	✓	✓	✓	✓	✓	0140 0141
1999	Astra-G	Body	Instrument	✓	✓	✓	✓	✓	
1999	Astra-G	Body	Airbag SAB6	✓	✓	✓	✓	✓	
1999	Astra-G	Body	Anti Theft Warning	✓	✓	✓	✓	✓	
1999	Astra-G	Body	Central Door Lock	✓	✓	✓	✓	✓	
1999	Astra-G	Body	Engine Cooling Module	✓	✓	✓	✓	✓	
1999	Astra-G	Chassis	ABS-5.3/5.4(+TC)	✓	✓	✓	✓	✓	
1999	Astra-G	Chassis	Cruise Control	✓	✓	✓	✓	✓	
1999	Astra-G	Engine	X12XE	✓	✓	✓	✓	✓	0167 0197 0203 0202
1999	Astra-G	Engine	X14XE	✓	✓	✓	✓	✓	
1999	Astra-G	Engine	C16SEL	✓	✓	✓	✓	✓	
1999	Astra-G	Engine	X16SZR	✓	✓	✓	✓	✓	
1999	Astra-G	Engine	X16XEL	✓	✓	✓	✓	✓	0167 0195 0196 0197 0198 0020
1999	Astra-G	Engine	X17DTL	✓	✓	✓	✓	✓	
1999	Astra-G	Engine	X18XE1	✓	✓	✓	✓	✓	
1999	Astra-G	Engine	X20DTL	✓	✓	✓	✓	✓	
1999	Astra-G	Engine	X20XEV	✓	✓	✓	✓	✓	
1999	Astra-G	Infotainment System	Trip Info Display TID	✓	✓	✓	✓	✓	
1999	Astra-G	Infotainment System	Multi Info Display MID	✓	✓	✓	✓	✓	
1999	Astra-G	Infotainment System	Radio CAR 300	✓	✓	✓	✓	✓	
1999	Astra-G	Infotainment System	Radio CAR 400	✓	✓	✓	✓	✓	
1999	Astra-G	Infotainment System	Radio CDR 500	✓	✓	✓	✓	✓	
1999	Astra-G	Infotainment System	Radio CCRT 700	✓	✓	✓	✓	✓	
1999	Astra-G	Transmission	AF 13-II/17/20/22	✓	✓	✓	✓	✓	
1999	Astra-G (GMSA)	Body	Immobiliser	✓	✓	✓	✓	✓	0165 0166
1999	Astra-G (GMSA)	Engine	13 NE	✓	✓	✓	✓	✓	0167 0191 0192 0057 0193
1999	Astra-G (GMSA)	Engine	14 NE	✓	✓	✓	✓	✓	0167 0191 0192 0057 0193
1999	Astra-G (GMSA)	Engine	16 SE	✓	✓	✓	✓	✓	
1999	Corsa-B	Body	Immobiliser	✓	✓	✓	✓	✓	
1999	Corsa-B	Body	Airbag S	✓	✓	✓	✓	✓	

1999	Corsa-B	Body	Airbag SAB6	✓	✓	✓	✓		
1999	Corsa-B	Body	Anti Theft Warning	✓	✓	✓	✓	✓	
1999	Corsa-B	Body	Instrument	✓	✓	✓	✓		
1999	Corsa-B	Chassis	ABS-5.3	✓	✓	✓	✓		
1999	Corsa-B	Chassis	Electronic Power Steering	✓	✓	✓	✓		
1999	Corsa-B	Engine	X10XE	✓	✓	✓	✓	✓	0167 0197 0203 0202
1999	Corsa-B	Engine	X12XE	✓	✓	✓	✓	✓	0167 0197 0203 0202
1999	Corsa-B	Engine	C14SEL	✓	✓	✓	✓		
1999	Corsa-B	Engine	X14SZ	✓	✓	✓	✓	✓	
1999	Corsa-B	Engine	X14XE	✓	✓	✓	✓	✓	
1999	Corsa-B	Engine	C16SEL	✓	✓	✓	✓	✓	
1999	Corsa-B	Engine	X16XE	✓	✓	✓	✓	✓	0167 0196 0197 0198 0020 0202 0057
1999	Corsa-B	Engine	C14SE	✓	✓	✓	✓		
1999	Corsa-B	Infotainment System	Radio CAR 300	✓	✓	✓	✓		
1999	Corsa-B	Infotainment System	Radio CAR 400	✓	✓	✓	✓		
1999	Corsa-B	Infotainment System	Radio CDR 500	✓	✓	✓	✓		
1999	Corsa-B	Infotainment System	Radio CCRT 700	✓	✓	✓	✓		
1999	Corsa-B	Transmission	AF 1311/20/22/30	✓	✓	✓	✓		
1999	Corsa-B	Transmission	AF 13/14/20	✓	✓	✓	✓		
1999	Corsa-B (GMSA)	Body	Immobiliser	✓	✓	✓	✓		0165 0166
1999	Corsa-B (GMSA)	Engine	13 NE	✓	✓	✓	✓	✓	0167 0191 0192 0057 0193
1999	Corsa-B (GMSA)	Engine	14 NE	✓	✓	✓	✓	✓	0167 0191 0192 0057 0193
1999	Corsa-B (GMSA)	Engine	16 NE	✓	✓	✓	✓		
1999	Corsa-B (GMSA)	Engine	16 SE	✓	✓	✓	✓		
1999	Frontera-B	Body	Airbag	✓	✓	✓	✓		
1999	Frontera-B	Body	Anti Theft Warning	✓	✓	✓	✓		
1999	Frontera-B	Body	Central Door Lock	✓	✓	✓	✓	✓	0165 0166
1999	Frontera-B	Body	Immobiliser	✓	✓	✓	✓		0165 0166
1999	Frontera-B	Engine	X22DTH	✓	✓	✓	✓		
1999	Frontera-B	Infotainment System	Trip Info Display TID	✓	✓	✓	✓		
1999	Frontera-B	Infotainment System	Multi Info Display MID	✓	✓	✓	✓		
1999	Frontera-B	Infotainment System	Radio CAR 300	✓	✓	✓	✓		
1999	Frontera-B	Infotainment System	Radio CAR 400	✓	✓	✓	✓		
1999	Frontera-B	Infotainment System	Radio CDR 500	✓	✓	✓	✓		
1999	Frontera-B	Infotainment System	Radio CCRT 700	✓	✓	✓	✓		
1999	Frontera-B	Transmission	AR 25/35	✓	✓	✓	✓	✓	
1999	Monterey	Body	Airbag	✓	✓	✓	✓		
1999	Monterey	Body	Immobiliser	✓	✓	✓	✓		0165 0166
1999	Monterey	Body	Anti Theft Warning	✓	✓	✓	✓	✓	
1999	Monterey	Chassis	ABS 5	✓	✓	✓	✓		
1999	Monterey	Engine	4JX1(3.0L)	✓	✓	✓	✓		
1999	Monterey	Engine	6VE1(3.5L,V6)	✓	✓	✓	✓		
1999	Movano	Body	Immobiliser	✓	✓	✓	✓		0165 0166
1999	Omega-B	Body	Airbag SAB6	✓	✓	✓	✓		
1999	Omega-B	Body	Headlamp Levelling Device	✓	✓	✓	✓	✓	0142
1999	Omega-B	Body	Add On Heater	✓	✓	✓	✓	✓	0123 0124
1999	Omega-B	Body	Anti Theft Warning	✓	✓	✓	✓	✓	
1999	Omega-B	Body	Central Door Lock	✓	✓	✓	✓	✓	0165 0166
1999	Omega-B	Body	Electronic Climate Control	✓	✓	✓	✓		
1999	Omega-B	Body	Immobiliser	✓	✓	✓	✓		0165 0166
1999	Omega-B	Body	Instrument	✓	✓	✓	✓		
1999	Omega-B	Chassis	ABS-5.3/5.4(HTC)	✓	✓	✓	✓	✓	
1999	Omega-B	Chassis	Servotronic	✓	✓	✓	✓		
1999	Omega-B	Engine	X20DTH	✓	✓	✓	✓		
1999	Omega-B	Engine	X20XEV	✓	✓	✓	✓	✓	
1999	Omega-B	Engine	X25XE	✓	✓	✓	✓		
1999	Omega-B	Engine	Y30XE	✓	✓	✓	✓		
1999	Omega-B	Engine	20SE	✓	✓	✓	✓		
1999	Omega-B	Infotainment System	Trip Info Display TID	✓	✓	✓	✓		
1999	Omega-B	Infotainment System	Multi Info Display MID	✓	✓	✓	✓		
1999	Omega-B	Infotainment System	Radio CAR 300	✓	✓	✓	✓		
1999	Omega-B	Infotainment System	Radio CAR 400	✓	✓	✓	✓		
1999	Omega-B	Infotainment System	Radio CDR 500	✓	✓	✓	✓		
1999	Omega-B	Infotainment System	Radio CCRT 700	✓	✓	✓	✓		
1999	Omega-B	Transmission	AR 25/35	✓	✓	✓	✓	✓	
1999	Sintra	Body	Airbag	✓	✓	✓	✓		
1999	Sintra	Body	Body Control Module	✓	✓	✓	✓	✓	0052 0059 0139
1999	Sintra	Body	Immobiliser	✓	✓	✓	✓		0165 0166
1999	Sintra	Engine	X22DTH	✓	✓	✓	✓		
1999	Sintra	Infotainment System	Trip Info Display TID	✓	✓	✓	✓		
1999	Sintra	Infotainment System	Multi Info Display MID	✓	✓	✓	✓		
1999	Sintra	Infotainment System	Radio CAR 300	✓	✓	✓	✓		
1999	Sintra	Infotainment System	Radio CAR 400	✓	✓	✓	✓		
1999	Sintra	Infotainment System	Radio CDR 500	✓	✓	✓	✓		
1999	Sintra	Transmission	AF 1311/20/22/30	✓	✓	✓	✓		
1999	Tigra	Body	Immobiliser	✓	✓	✓	✓		
1999	Tigra	Body	Airbag S	✓	✓	✓	✓		
1999	Tigra	Body	Airbag SAB6	✓	✓	✓	✓		
1999	Tigra	Body	Anti Theft Warning	✓	✓	✓	✓	✓	
1999	Tigra	Chassis	ABS-5.3	✓	✓	✓	✓		
1999	Tigra	Engine	C14SEL	✓	✓	✓	✓		
1999	Tigra	Engine	X14XE	✓	✓	✓	✓	✓	
1999	Tigra	Engine	C16SEL	✓	✓	✓	✓		
1999	Tigra	Engine	X16XE	✓	✓	✓	✓	✓	0167 0196 0197 0198 0020 0202 0057
1999	Vauxhall VXRS	Body	Anti Theft Warning	✓	✓	✓	✓	✓	
1999	Vauxhall VXRS	Body	Airbag-S	✓	✓	✓	✓		
1999	Vauxhall VXRS	Body	Airbag SAB6	✓	✓	✓	✓		
1999	Vauxhall VXRS	Body	Immobiliser	✓	✓	✓	✓		0165 0166
1999	Vauxhall VXRS	Engine	X 14 XE	✓	✓	✓	✓	✓	
1999	Vauxhall VXRS	Engine	X 16 XE	✓	✓	✓	✓	✓	0167 0196 0197 0198 0020 0202 0057
1999	Vauxhall VXRS	Engine	C 16 SEL	✓	✓	✓	✓	✓	
1999	Vauxhall VXRS	Infotainment System	Radio CAR 300	✓	✓	✓	✓		
1999	Vauxhall VXRS	Infotainment System	Radio CAR 400	✓	✓	✓	✓		
1999	Vauxhall VXRS	Infotainment System	Radio CDR 500	✓	✓	✓	✓		
1999	Vauxhall VXRS	Infotainment System	Radio CCRT 700	✓	✓	✓	✓		
1999	Vauxhall VXRS	Transmission	AF 13/14/20	✓	✓	✓	✓		
1999	Vectra-B	Body	Immobiliser	✓	✓	✓	✓		

1999	Vectra-B	Body	Instrument	✓	✓	✓	✓		
1999	Vectra-B	Body	Airbag SAB6	✓	✓	✓	✓		
1999	Vectra-B	Body	Add On Heater	✓	✓	✓	✓		0123 0124
1999	Vectra-B	Body	Anti Theft Warning	✓	✓	✓	✓	✓	
1999	Vectra-B	Body	Electronic Climate Control	✓	✓	✓	✓		
1999	Vectra-B	Chassis	ABS 415	✓	✓	✓	✓		
1999	Vectra-B	Chassis	ABS 430	✓	✓	✓	✓		
1999	Vectra-B	Chassis	ABS-5.3/5.4(+TC)	✓	✓	✓	✓	✓	
1999	Vectra-B	Chassis	ABS-5-TC (Anti-lock Braking System)	✓	✓	✓	✓		
1999	Vectra-B	Engine	X16SZR	✓	✓	✓	✓	✓	
1999	Vectra-B	Engine	X16XEL	✓	✓	✓	✓	✓	0167 0195 0196 0197 0198 0020
1999	Vectra-B	Engine	X16XE	✓	✓	✓	✓	✓	
1999	Vectra-B	Engine	X18XE1	✓	✓	✓	✓	✓	
1999	Vectra-B	Engine	20NEJ	✓	✓	✓	✓		
1999	Vectra-B	Engine	C20SEL	✓	✓	✓	✓	✓	0167
1999	Vectra-B	Engine	X20DTH	✓	✓	✓	✓		
1999	Vectra-B	Engine	X20DTL	✓	✓	✓	✓		
1999	Vectra-B	Engine	X20XEV	✓	✓	✓	✓	✓	
1999	Vectra-B	Engine	C22SEL	✓	✓	✓	✓		0205 0041 0203
1999	Vectra-B	Engine	16LZ2	✓	✓	✓	✓		
1999	Vectra-B	Engine	X18XE	✓	✓	✓	✓		0167 0203 0204 0205 0041
1999	Vectra-B	Engine	X25XE	✓	✓	✓	✓		
1999	Vectra-B	Infotainment System	Trip Info Display TID	✓	✓	✓			
1999	Vectra-B	Infotainment System	Multi Info Dispaly MID	✓	✓	✓			
1999	Vectra-B	Infotainment System	Radio CAR 300	✓	✓	✓			
1999	Vectra-B	Infotainment System	Radio CAR 400	✓	✓	✓	✓		
1999	Vectra-B	Infotainment System	Radio CDR 500	✓	✓	✓	✓		
1999	Vectra-B	Infotainment System	Radio CCRT 700	✓	✓	✓	✓		
1999	Vectra-B	Transmission	AF 13-II/17/20/22	✓	✓	✓	✓	✓	
1999	Vectra-B	Transmission	AF 13II/20/22/30	✓	✓	✓	✓		
1999	Zafira	Body	Immobiliser	✓	✓	✓	✓		0140 0141
1999	Zafira	Body	Instrument	✓	✓	✓	✓		
1999	Zafira	Body	Airbag	✓	✓	✓	✓	✓	
1999	Zafira	Body	Anti Theft Warning	✓	✓	✓	✓		
1999	Zafira	Body	Central Door Lock	✓	✓	✓	✓		
1999	Zafira	Body	Electronic Climate Control	✓	✓	✓	✓		
1999	Zafira	Body	Engine Cooling Module	✓	✓	✓	✓		
1999	Zafira	Body	Airbag SAB6	✓	✓	✓	✓		
1999	Zafira	Chassis	ABS-5.3/5.4(+TC)	✓	✓	✓	✓	✓	
1999	Zafira	Chassis	Cruise Control	✓	✓	✓	✓		
1999	Zafira	Chassis	Electronic Power Steering	✓	✓	✓	✓		0142
1999	Zafira	Engine	X16XEL	✓	✓	✓	✓	✓	0167 0195 0196 0197 0198 0020
1999	Zafira	Engine	X18XE1	✓	✓	✓	✓	✓	
1999	Zafira	Infotainment System	Radio CAR 300	✓	✓	✓	✓		
1999	Zafira	Infotainment System	Trip Info Display TID	✓	✓	✓			
1999	Zafira	Infotainment System	Multi Info Dispaly MID	✓	✓	✓			
1999	Zafira	Infotainment System	Radio CAR 300	✓	✓	✓	✓		
1999	Zafira	Infotainment System	Radio CAR 400	✓	✓	✓	✓		
1999	Zafira	Infotainment System	Radio CDR 500	✓	✓	✓	✓		
1999	Zafira	Infotainment System	Radio CCRT 700	✓	✓	✓	✓		
1999	Zafira	Transmission	AF 13-II/17/20/22 CAN	✓	✓	✓	✓	✓	
1998	Arena	Body	Immobiliser	✓	✓	✓	✓		0165 0166
1998	Astra-F	Body	Immobiliser	✓	✓	✓	✓		
1998	Astra-F	Body	Airbag S	✓	✓	✓	✓		
1998	Astra-F	Body	Instrument	✓	✓	✓	✓	✓	
1998	Astra-F	Body	Anti Theft Warning	✓	✓	✓	✓	✓	
1998	Astra-F	Engine	X14XE	✓	✓	✓	✓		
1998	Astra-F	Engine	16NZR	✓	✓	✓	✓		
1998	Astra-F	Engine	X16SZR	✓	✓	✓	✓	✓	
1998	Astra-F	Engine	X16XEL	✓	✓	✓	✓	✓	0167 0195 0196 0197 0198 0020
1998	Astra-F	Engine	18SE	✓	✓	✓	✓		
1998	Astra-F	Engine	C18SEL	✓	✓	✓	✓		0167
1998	Astra-F	Engine	X18XE	✓	✓	✓	✓	✓	0167 0203 0204 0205 0041
1998	Astra-F	Engine	X20XEV	✓	✓	✓	✓	✓	
1998	Astra-F	Engine	C14SE	✓	✓	✓	✓		
1998	Astra-F	Engine	C16SE	✓	✓	✓	✓		
1998	Astra-F	Engine	16LZ2	✓	✓	✓	✓		
1998	Astra-F	Infotainment System	Multi Info Dispaly MID	✓	✓	✓			
1998	Astra-F	Infotainment System	Radio CAR 300	✓	✓	✓			
1998	Astra-F	Infotainment System	Radio CAR 400	✓	✓	✓	✓		
1998	Astra-F	Infotainment System	Radio CDR 500	✓	✓	✓	✓		
1998	Astra-F	Transmission	AF 13II/20/22/30	✓	✓	✓	✓		
1998	Astra-F	Transmission	AF 13/14/20	✓	✓	✓	✓		
1998	Astra-G	Body	Immobiliser	✓	✓	✓	✓		0140 0141
1998	Astra-G	Body	Instrument	✓	✓	✓	✓		
1998	Astra-G	Body	Airbag SAB6	✓	✓	✓	✓		
1998	Astra-G	Body	Anti Theft Warning	✓	✓	✓	✓		
1998	Astra-G	Body	Central Door Lock	✓	✓	✓	✓		
1998	Astra-G	Body	Engine Cooling Module	✓	✓	✓	✓		
1998	Astra-G	Chassis	ABS-5.3/5.4(+TC)	✓	✓	✓	✓	✓	
1998	Astra-G	Chassis	Cruise Control	✓	✓	✓	✓		
1998	Astra-G	Engine	X12XE	✓	✓	✓	✓	✓	0167 0197 0203 0202
1998	Astra-G	Engine	X14XE	✓	✓	✓	✓	✓	
1998	Astra-G	Engine	X16SZR	✓	✓	✓	✓		
1998	Astra-G	Engine	X16XEL	✓	✓	✓	✓	✓	0167 0195 0196 0197 0198 0020
1998	Astra-G	Engine	X17DTL	✓	✓	✓	✓	✓	
1998	Astra-G	Engine	X18XE1	✓	✓	✓	✓	✓	
1998	Astra-G	Engine	X20DTL	✓	✓	✓	✓		
1998	Astra-G	Engine	X20XEV	✓	✓	✓	✓		
1998	Astra-G	Infotainment System	Multi Info Dispaly MID	✓	✓	✓			
1998	Astra-G	Infotainment System	Radio CAR 300	✓	✓	✓			
1998	Astra-G	Infotainment System	Radio CAR 400	✓	✓	✓	✓		
1998	Astra-G	Infotainment System	Radio CDR 500	✓	✓	✓	✓		
1998	Astra-G	Transmission	AF 13-II/17/20/22	✓	✓	✓	✓	✓	
1998	Astra-G(GMSA)	Body	Immobiliser	✓	✓	✓	✓		0165 0166
1998	Astra-G(GMSA)	Engine	13 NE	✓	✓	✓	✓	✓	0167 0191 0192 0057 0193
1998	Astra-G(GMSA)	Engine	14 NE	✓	✓	✓	✓	✓	0167 0191 0192 0057 0193

1998	Astra-G(GMSA)	Engine	16 SE	✓	✓	✓			
1998	Corsa-B	Body	Immobiliser	✓	✓	✓	✓		
1998	Corsa-B	Body	Airbag S	✓	✓	✓	✓		
1998	Corsa-B	Body	Anti Theft Warning	✓	✓	✓	✓	✓	
1998	Corsa-B	Body	Instrument	✓	✓	✓	✓		
1998	Corsa-B	Chassis	ABS-5.3	✓	✓	✓	✓		
1998	Corsa-B	Chassis	Electronic Power Steering	✓	✓	✓	✓		
1998	Corsa-B	Engine	X10XE	✓	✓	✓	✓	✓	0167 0197 0203 0202
1998	Corsa-B	Engine	X12XE	✓	✓	✓	✓	✓	0167 0197 0203 0202
1998	Corsa-B	Engine	C14SEL	✓	✓	✓	✓		
1998	Corsa-B	Engine	C14NZ	✓	✓	✓	✓		
1998	Corsa-B	Engine	X14SZ	✓	✓	✓	✓	✓	
1998	Corsa-B	Engine	X14XE	✓	✓	✓	✓	✓	
1998	Corsa-B	Engine	C16SEL	✓	✓	✓	✓		
1998	Corsa-B	Engine	X16XE	✓	✓	✓	✓	✓	0167 0196 0197 0198 0020 0202 0057
1998	Corsa-B	Infotainment System	Radio CAR 300	✓	✓	✓			
1998	Corsa-B	Infotainment System	Radio CAR 400	✓	✓	✓	✓		
1998	Corsa-B	Infotainment System	Radio CDR 500	✓	✓	✓	✓		
1998	Corsa-B	Transmission	AF 131L/20/22/30	✓	✓	✓	✓		
1998	Corsa-B	Transmission	AF 13/14/20	✓	✓	✓	✓		
1998	Corsa-B(GMSA)	Body	Immobiliser	✓	✓	✓	✓		0165 0166
1998	Corsa-B(GMSA)	Engine	13 NE	✓	✓	✓	✓	✓	0167 0191 0192 0057 0193
1998	Corsa-B(GMSA)	Engine	14 NE	✓	✓	✓	✓	✓	0167 0191 0192 0057 0193
1998	Corsa-B(GMSA)	Engine	16 NE	✓	✓	✓	✓		
1998	Corsa-B(GMSA)	Engine	16 SE	✓	✓	✓	✓		
1998	Frontera	Body	Immobiliser	✓	✓	✓	✓		
1998	Frontera	Body	Anti Theft Warning	✓	✓	✓	✓		
1998	Frontera	Body	Central Door Lock	✓	✓	✓	✓	✓	0165 0166
1998	Frontera	Chassis	ABS 415	✓	✓	✓	✓		
1998	Frontera	Engine	25 TDS	✓	✓	✓	✓		
1998	Frontera	Infotainment System	Multi Info Dispaly MID	✓	✓	✓	✓		
1998	Frontera	Infotainment System	Radio CDR 500	✓	✓	✓	✓		
1998	Monterey	Chassis	ABS 5	✓	✓	✓	✓		
1998	Monterey	Chassis	Anti Theft Warning	✓	✓	✓	✓	✓	
1998	Monterey	Chassis	Body Control Module	✓	✓	✓	✓	✓	0052 0059 0139
1998	Monterey	Chassis	Immobiliser	✓	✓	✓	✓		0165 0166
1998	Omega-B	Body	Immobiliser	✓	✓	✓	✓		
1998	Omega-B	Body	Airbag SAB6	✓	✓	✓	✓		
1998	Omega-B	Body	Headlamp Levelling Device	✓	✓	✓	✓	✓	0142
1998	Omega-B	Body	Add On Heater	✓	✓	✓	✓	✓	0123 0124
1998	Omega-B	Body	Anti Theft Warning	✓	✓	✓	✓	✓	
1998	Omega-B	Body	Central Door Lock	✓	✓	✓	✓	✓	0165 0166
1998	Omega-B	Body	Electronic Climate Control	✓	✓	✓	✓		
1998	Omega-B	Body	Instrument	✓	✓	✓	✓		
1998	Omega-B	Chassis	ABS-5.3/5.4(+TC)	✓	✓	✓	✓	✓	
1998	Omega-B	Chassis	Servotronic	✓	✓	✓	✓		
1998	Omega-B	Engine	X20DTH	✓	✓	✓	✓		
1998	Omega-B	Engine	X20XEV	✓	✓	✓	✓	✓	
1998	Omega-B	Engine	X25XE	✓	✓	✓	✓		
1998	Omega-B	Engine	Y30XE	✓	✓	✓	✓		
1998	Omega-B	Engine	20SE	✓	✓	✓	✓		
1998	Omega-B	Infotainment System	Trip Info Display TID	✓	✓	✓	✓		
1998	Omega-B	Infotainment System	Multi Info Dispaly MID	✓	✓	✓	✓		
1998	Omega-B	Infotainment System	Radio CAR 300	✓	✓	✓	✓		
1998	Omega-B	Infotainment System	Radio CAR 400	✓	✓	✓	✓		
1998	Omega-B	Infotainment System	Radio CDR 500	✓	✓	✓	✓		
1998	Omega-B	Transmission	AR 25/35	✓	✓	✓	✓	✓	
1998	Sintra	Body	Body Control Module	✓	✓	✓	✓	✓	0052 0059 0139
1998	Sintra	Body	Immobiliser	✓	✓	✓	✓		0165 0166
1998	Sintra	Engine	X22DTH	✓	✓	✓	✓		
1998	Sintra	Infotainment System	Multi Info Dispaly MID	✓	✓	✓	✓		
1998	Sintra	Infotainment System	Radio CAR 300	✓	✓	✓	✓		
1998	Sintra	Infotainment System	Radio CAR 400	✓	✓	✓	✓		
1998	Sintra	Infotainment System	Radio CDR 500	✓	✓	✓	✓		
1998	Sintra	Transmission	AF 131L/20/22/30	✓	✓	✓	✓		
1998	Tigra	Body	Immobiliser	✓	✓	✓	✓		
1998	Tigra	Body	Airbag S	✓	✓	✓	✓		
1998	Tigra	Body	Anti Theft Warning	✓	✓	✓	✓	✓	
1998	Tigra	Chassis	ABS-5.3	✓	✓	✓	✓		
1998	Tigra	Engine	C14SEL	✓	✓	✓	✓		
1998	Tigra	Engine	X14XE	✓	✓	✓	✓	✓	
1998	Tigra	Engine	C16SEL	✓	✓	✓	✓		
1998	Tigra	Engine	X16XE	✓	✓	✓	✓	✓	0167 0196 0197 0198 0020 0202 0057
1998	Vauxhall VXRS	Body	Airbag-S	✓	✓	✓	✓		
1998	Vauxhall VXRS	Body	Immobiliser	✓	✓	✓	✓		0165 0166
1998	Vauxhall VXRS	Engine	X 14 XE	✓	✓	✓	✓	✓	
1998	Vauxhall VXRS	Engine	X 16 XE	✓	✓	✓	✓	✓	0167 0196 0197 0198 0020 0202 0057
1998	Vauxhall VXRS	Infotainment System	Radio CAR 300	✓	✓	✓	✓		
1998	Vauxhall VXRS	Infotainment System	Radio CAR 400	✓	✓	✓	✓		
1998	Vauxhall VXRS	Infotainment System	Radio CDR 500	✓	✓	✓	✓		
1998	Vauxhall VXRS	Transmission	AF 13/14/20	✓	✓	✓	✓		
1998	Vectra-B	Body	Immobiliser	✓	✓	✓	✓		
1998	Vectra-B	Body	Instrument	✓	✓	✓	✓		
1998	Vectra-B	Body	Airbag SAB6	✓	✓	✓	✓		
1998	Vectra-B	Body	Add On Heater	✓	✓	✓	✓	✓	0123 0124
1998	Vectra-B	Body	Anti Theft Warning	✓	✓	✓	✓	✓	
1998	Vectra-B	Body	Electronic Climate Control	✓	✓	✓	✓		
1998	Vectra-B	Chassis	ABS 415	✓	✓	✓	✓		
1998	Vectra-B	Chassis	ABS 430	✓	✓	✓	✓		
1998	Vectra-B	Chassis	ABS-5-TC	✓	✓	✓	✓		
1998	Vectra-B	Chassis	ABS-5.3/5.4(+TC)	✓	✓	✓	✓	✓	
1998	Vectra-B	Engine	X16SZR	✓	✓	✓	✓	✓	
1998	Vectra-B	Engine	X16XEL	✓	✓	✓	✓	✓	0167 0195 0196 0197 0198 0020
1998	Vectra-B	Engine	Y16XE	✓	✓	✓	✓	✓	
1998	Vectra-B	Engine	X18XE1	✓	✓	✓	✓	✓	
1998	Vectra-B	Engine	Z0NEJ	✓	✓	✓	✓		
1998	Vectra-B	Engine	C20SEL	✓	✓	✓	✓	✓	0167

1998	Vectra-B	Engine	X20DTH	✓	✓	✓	✓		
1998	Vectra-B	Engine	X20DTL	✓	✓	✓	✓		
1998	Vectra-B	Engine	X20XEV	✓	✓	✓	✓	✓	
1998	Vectra-B	Engine	C22SEL	✓	✓	✓	✓		0205 0041 0203
1998	Vectra-B	Engine	16LZ2	✓	✓	✓	✓		
1998	Vectra-B	Engine	X18XE	✓	✓	✓	✓		0167 0203 0204 0205 0041
1998	Vectra-B	Engine	X25XE	✓	✓	✓	✓		
1998	Vectra-B	Infotainment System	Trip Info Display TID	✓	✓	✓	✓		
1998	Vectra-B	Infotainment System	Multi Info Display MID	✓	✓	✓	✓		
1998	Vectra-B	Infotainment System	Radio CAR 300	✓	✓	✓	✓		
1998	Vectra-B	Infotainment System	Radio CAR 400	✓	✓	✓	✓		
1998	Vectra-B	Infotainment System	Radio CDR 500	✓	✓	✓	✓		
1998	Vectra-B	Infotainment System	Radio CCRT 700	✓	✓	✓	✓		
1998	Vectra-B	Transmission	AF 13-II/17/20/22	✓	✓	✓	✓	✓	
1998	Vectra-B	Transmission	AF 13II/20/22/30	✓	✓	✓	✓		
1997	Astra-F	Body	Immobiliser	✓	✓	✓	✓		
1997	Astra-F	Body	Airbag S	✓	✓	✓	✓		
1997	Astra-F	Body	Instrument	✓	✓	✓	✓	✓	
1997	Astra-F	Body	Anti Theft Warning	✓	✓	✓	✓	✓	
1997	Astra-F	Chassis	Traction Control (TC)	✓	✓	✓	✓		
1997	Astra-F	Engine	C14NZ	✓	✓	✓	✓		
1997	Astra-F	Engine	X14XE	✓	✓	✓	✓		
1997	Astra-F	Engine	16NZR	✓	✓	✓	✓		
1997	Astra-F	Engine	X16SZR	✓	✓	✓	✓	✓	
1997	Astra-F	Engine	X16XEL	✓	✓	✓	✓	✓	0167 0195 0196 0197 0198 0020
1997	Astra-F	Engine	18SE	✓	✓	✓	✓		
1997	Astra-F	Engine	C18SEL	✓	✓	✓	✓		0167
1997	Astra-F	Engine	X18XE	✓	✓	✓	✓		0167 0203 0204 0205 0041
1997	Astra-F	Engine	X20XEV	✓	✓	✓	✓	✓	
1997	Astra-F	Engine	C14SE	✓	✓	✓	✓		
1997	Astra-F	Engine	C16SE	✓	✓	✓	✓		
1997	Astra-F	Engine	16LZ2	✓	✓	✓	✓		
1997	Astra-F	Infotainment System	Multi Info Display MID	✓	✓	✓	✓		
1997	Astra-F	Infotainment System	Radio CAR 300	✓	✓	✓	✓		
1997	Astra-F	Infotainment System	Radio CAR 400	✓	✓	✓	✓		
1997	Astra-F	Infotainment System	Radio CDR 500	✓	✓	✓	✓		
1997	Astra-F	Transmission	AF 13II/20/22/30	✓	✓	✓	✓		
1997	Astra-F	Transmission	AF 13/14/20	✓	✓	✓	✓		
1997	Astra-G(GMSA)	Body	Immobiliser	✓	✓	✓	✓		0165 0166
1997	Astra-G(GMSA)	Engine	13 NE	✓	✓	✓	✓	✓	0167 0191 0192 0057 0193
1997	Astra-G(GMSA)	Engine	14 NE	✓	✓	✓	✓	✓	0167 0191 0192 0057 0193
1997	Astra-G(GMSA)	Engine	16 SE	✓	✓	✓	✓		
1997	Calibra	Body	Immobiliser	✓	✓	✓	✓		
1997	Calibra	Body	Airbag-S	✓	✓	✓	✓		
1997	Calibra	Body	Anti Theft Warning	✓	✓	✓	✓	✓	
1997	Calibra	Chassis	Traction Control (TC)	✓	✓	✓	✓		
1997	Calibra	Engine	X20XEV	✓	✓	✓	✓	✓	
1997	Calibra	Engine	X25XE	✓	✓	✓	✓		
1997	Calibra	Transmission	AF 13II/20/22/30	✓	✓	✓	✓		
1997	Calibra	Transmission	AF 13/14/20	✓	✓	✓	✓		
1997	Corsa-B	Body	Immobiliser	✓	✓	✓	✓		
1997	Corsa-B	Body	Airbag S	✓	✓	✓	✓		
1997	Corsa-B	Body	Anti Theft Warning	✓	✓	✓	✓	✓	
1997	Corsa-B	Body	Instrument	✓	✓	✓	✓		
1997	Corsa-B	Chassis	ABS-5.3	✓	✓	✓	✓		
1997	Corsa-B	Chassis	Electronic Power Steering	✓	✓	✓	✓		
1997	Corsa-B	Engine	X10XE	✓	✓	✓	✓	✓	0167 0197 0203 0202
1997	Corsa-B	Engine	C14NZ	✓	✓	✓	✓		
1997	Corsa-B	Engine	X14SZ	✓	✓	✓	✓	✓	
1997	Corsa-B	Engine	X14XE	✓	✓	✓	✓	✓	
1997	Corsa-B	Engine	X16XE	✓	✓	✓	✓	✓	0167 0196 0197 0198 0020 0202 0057
1997	Corsa-B	Infotainment System	Radio CAR 300	✓	✓	✓	✓		
1997	Corsa-B	Infotainment System	Radio CAR 400	✓	✓	✓	✓		
1997	Corsa-B	Infotainment System	Radio CDR 500	✓	✓	✓	✓		
1997	Corsa-B	Transmission	AF 13/14/20	✓	✓	✓	✓		
1997	Corsa-B(GMSA)	Body	Immobiliser	✓	✓	✓	✓		0165 0166
1997	Corsa-B(GMSA)	Engine	13 NE	✓	✓	✓	✓	✓	0167 0191 0192 0057 0193
1997	Corsa-B(GMSA)	Engine	14 NE	✓	✓	✓	✓	✓	0167 0191 0192 0057 0193
1997	Corsa-B(GMSA)	Engine	16 NE	✓	✓	✓	✓		
1997	Corsa-B(GMSA)	Engine	16 SE	✓	✓	✓	✓		
1997	Frontera	Body	Immobiliser	✓	✓	✓	✓		
1997	Frontera	Body	Anti Theft Warning	✓	✓	✓	✓		
1997	Frontera	Chassis	ABS 415	✓	✓	✓	✓		
1997	Frontera	Engine	25 TDS	✓	✓	✓	✓		
1997	Monterey	Body	Immobiliser	✓	✓	✓	✓		0165 0166
1997	Monterey	Chassis	ABS 5	✓	✓	✓	✓		
1997	Omega-B	Body	Immobiliser	✓	✓	✓	✓		
1997	Omega-B	Body	Airbag S	✓	✓	✓	✓		
1997	Omega-B	Body	Airbag SAB6	✓	✓	✓	✓		
1997	Omega-B	Body	Anti Theft Warning	✓	✓	✓	✓	✓	
1997	Omega-B	Body	Electronic Climate Control	✓	✓	✓	✓		
1997	Omega-B	Chassis	ABS-5.3/5.4(+TC)	✓	✓	✓	✓	✓	
1997	Omega-B	Chassis	Cruise Control	✓	✓	✓	✓		
1997	Omega-B	Chassis	ABS 2SE(+TC) (Anti-lock Braking System)	✓	✓	✓	✓		
1997	Omega-B	Chassis	ABS 2SE(+TC) (Anti-lock Braking System)	✓	✓	✓	✓		
1997	Omega-B	Engine	X20XEV	✓	✓	✓	✓	✓	
1997	Omega-B	Engine	X25XE	✓	✓	✓	✓		
1997	Omega-B	Engine	Y30XE	✓	✓	✓	✓		
1997	Omega-B	Engine	20SE	✓	✓	✓	✓		
1997	Omega-B	Infotainment System	Trip Info Display TID	✓	✓	✓	✓		
1997	Omega-B	Infotainment System	Multi Info Display MID	✓	✓	✓	✓		
1997	Omega-B	Infotainment System	Radio CAR 300	✓	✓	✓	✓		
1997	Omega-B	Infotainment System	Radio CAR 400	✓	✓	✓	✓		
1997	Omega-B	Infotainment System	Radio CDR 500	✓	✓	✓	✓		
1997	Omega-B	Transmission	AR 25/35	✓	✓	✓	✓		
1997	Sintra	Body	Immobiliser	✓	✓	✓	✓		0165 0166
1997	Sintra	Body	Body Control Module	✓	✓	✓	✓	✓	0052 0059 0139
1997	Sintra	Infotainment System	Multi Info Display MID	✓	✓	✓	✓		

1997	Sintra	Infotainment System	Radio CAR 300	✓	✓	✓			
1997	Sintra	Infotainment System	Radio CAR 400	✓	✓	✓	✓		
1997	Sintra	Infotainment System	Radio CDR 500	✓	✓	✓	✓		
1997	Sintra	Transmission	AF 1311/20/22/30	✓	✓	✓	✓		
1997	Tigra	Body	Immobiliser	✓	✓	✓	✓		
1997	Tigra	Body	Airbag S	✓	✓	✓	✓		
1997	Tigra	Body	Anti Theft Warning	✓	✓	✓	✓	✓	
1997	Tigra	Chassis	ABS-5.3	✓	✓	✓	✓		
1997	Tigra	Engine	X14XE	✓	✓	✓	✓	✓	
1997	Tigra	Engine	X16XE	✓	✓	✓	✓	✓	0167 0196 0197 0198 0020 0202 0057
1997	Vauxhall VXRS	Body	Airbag-S	✓	✓	✓	✓		
1997	Vauxhall VXRS	Body	Anti Theft Warning	✓	✓	✓	✓	✓	
1997	Vauxhall VXRS	Body	Immobiliser	✓	✓	✓	✓		0165 0166
1997	Vauxhall VXRS	Engine	X 14 XE	✓	✓	✓	✓	✓	
1997	Vauxhall VXRS	Engine	X 16 XE	✓	✓	✓	✓	✓	0167 0196 0197 0198 0020 0202 0057
1997	Vauxhall VXRS	Engine	ABS-5.3 (Anti-lock Braking System)	✓	✓	✓	✓		
1997	Vauxhall VXRS	Infotainment System	Radio CAR 300	✓	✓	✓			
1997	Vauxhall VXRS	Infotainment System	Radio CAR 400	✓	✓	✓	✓		
1997	Vauxhall VXRS	Infotainment System	Radio CDR 500	✓	✓	✓	✓		
1997	Vauxhall VXRS	Transmission	AF 13/14/20	✓	✓	✓	✓		
1997	Vectra-B	Body	Immobiliser	✓	✓	✓	✓		
1997	Vectra-B	Body	Instrument	✓	✓	✓	✓		
1997	Vectra-B	Body	Airbag	✓	✓	✓	✓		
1997	Vectra-B	Body	Airbag SAB6	✓	✓	✓	✓		
1997	Vectra-B	Body	Add On Heater	✓	✓	✓	✓	✓	0123 0124
1997	Vectra-B	Body	Anti Theft Warning	✓	✓	✓	✓	✓	
1997	Vectra-B	Body	Electronic Climate Control	✓	✓	✓	✓		
1997	Vectra-B	Chassis	ABS 415	✓	✓	✓	✓		
1997	Vectra-B	Chassis	ABS-5-TC	✓	✓	✓	✓		
1997	Vectra-B	Chassis	Cruise Control	✓	✓	✓	✓		
1997	Vectra-B	Engine	X16SZR	✓	✓	✓	✓	✓	
1997	Vectra-B	Engine	X16XEL	✓	✓	✓	✓	✓	0167 0195 0196 0197 0198 0020
1997	Vectra-B	Engine	X18XE1	✓	✓	✓	✓	✓	
1997	Vectra-B	Engine	20NEJ	✓	✓	✓	✓		
1997	Vectra-B	Engine	C20SEL	✓	✓	✓	✓	✓	0167
1997	Vectra-B	Engine	X20DTL	✓	✓	✓	✓		
1997	Vectra-B	Engine	X20XE	✓	✓	✓	✓	✓	
1997	Vectra-B	Engine	16LZ2	✓	✓	✓	✓		
1997	Vectra-B	Engine	X18XE	✓	✓	✓	✓		0167 0203 0204 0205 0041
1997	Vectra-B	Engine	X25XE	✓	✓	✓	✓		
1997	Vectra-B	Infotainment System	Trip Info Display TID	✓	✓	✓			
1997	Vectra-B	Infotainment System	Multi Info Display MID	✓	✓	✓			
1997	Vectra-B	Infotainment System	Radio CAR 300	✓	✓	✓			
1997	Vectra-B	Infotainment System	Radio CAR 400	✓	✓	✓	✓		
1997	Vectra-B	Infotainment System	Radio CDR 500	✓	✓	✓	✓		
1997	Vectra-B	Transmission	AF 1311/20/22/30	✓	✓	✓	✓		

Special Function List

Index	SpecName
0001	Seat Belt Reminder Data
0002	Clear Deployment Record
0003	Program Low Speed CAN-Bus Configuration
0004	Program Seat Belt Reminder
0005	Program High Speed CAN-Bus Configuration
0006	Program Vehicle Identification No.
0007	Steering Angle Sensor Calibration
0008	Display Immobiliser Status
0009	Engine Oil Status
0010	Read Odometer Value
0011	Electronic Throttle Control
0012	Program High Speed CAN-Bus Config
0013	Program Variant Configuration
0014	Program Idle Speed
0015	Reset 02-Loop Block Learn Map
0016	Program VIN
0017	Fuel Trim Reset
0018	H02S Heater Learn
0019	Idle Learn
0020	Engine Oil Life Reset
0021	Injector Cutoff Test
0022	Replace Injector
0023	Program CAN Configuration
0024	Replace Fuel Pump
0025	Replace Mass Air Flow Sensor
0026	Replace Rail Pressure Sensor
0027	Replace Diesel Particulate Filter
0028	Replace Pre-catalyst
0029	Regeneration D.Particulate Filter
0030	Replace Differential-Press. Sensor
0031	Fuel Consumption Correction
0032	Pressure Regulator Sol. Valve Test
0033	TCC Solenoid Valve Test
0034	Reset ECU
0035	Reset Learned Values
0036	Learn Gearbox Parameters
0037	Touch Point Adaption
0038	Fuel Injector Balance
0039	Learn Functions
0040	Reset Functions
0041	CAN Bus Configuration Learn
0042	RPM Control
0043	Replace Precatalyst
0044	Regeneration Diesel Particulate Filter
0045	Brake Padel Position Sensor Learn

0046	Clear Driver Window Learned Values
0047	Read LIN Bus Device ID Information
0048	Battery Sensor Module Learn
0049	Brake Pedal Position Sensor Learn
0050	Injector Flow Rate Programming
0051	Throttle Sweep
0052	Transmission Adaptive Pressure Reset
0053	Key Program
0054	Program Mid Speed CAN-Bus Configuration
0055	Reset CIM Module
0056	Program Immobiliser Function
0057	Instantaneous Tank Content Control
0058	Engine Speed Control
0059	Vehicle Speed Control
0060	Instrument Dimming Test
0061	LED Dimmed Illumination Test
0062	LCD Display Dimmed Illumination Test
0063	Bleed Clutch Hydraulic
0064	Sensor Cluster Calibration
0065	Program High Speed CAN-Bus Config
0066	Program Tyre Circumference
0067	Reset O2-Loop Block Learn Map
0068	Program Tyre Circumference
0069	Program Variant Configuration
0070	Program Learned Values
0071	Replace O2 Sensor
0072	O2 Sensor Connection Check
0073	Swirl Level Control Actuator
0074	SLT Test (Solenoid Valve-Load)
0075	SLU Test (Solenoid Valve-TCC)
0076	SLC1 (Solenoid Valve) Control Test
0077	SLC2 (Solenoid Valve) Control Test
0078	SLC3 (Solenoid Valve) Control Test
0079	SLB1 (Solenoid Valve) Control Test
0080	Learn Selector Lever N Position
0081	Program High Speed CAN-Bus Configuration
0082	DPF Regeneration
0083	Steering Wheel Angle Sensor Reset
0084	Steering Wheel Angle Sensor Learn
0085	Clutch Pedal Position Learn
0086	H02S Learn
0087	Yaw Rate Sensor Learn
0088	Steering Wheel Angle Sensor
0089	Power Steering Softstops Reset
0090	Power Steering Softstops Learn
0091	Steering Wheel Angle Sensor Centering
0092	Crankshaft Position Variation Learn
0093	Idle Speed Adjustment

0094	Throttle Actuator Reset
0095	Fuel Rail Pressure Sensor Or Fuel Rail Learn
0096	Remote Vehicle Start Disable History Reset
0097	APP Learn
0098	Crankshaft Position Reluctor Wheel Learn
0099	DPF Pressure Sensor Learn
0100	EGR Valve Learn
0101	Exhaust Gas Temperature Sensor Learn
0102	Flywheel Learn
0103	MAF Sensor Learn
0104	Turbocharger Learn
0105	DPF Reset
0106	Glow Plug Control Module Reset
0107	DPF Service Regeneration
0108	DPF Pressure Learn
0109	Clear Disable History Data
0110	Park Brake Calibration
0111	Park Brake Cable Replacement Procedure
0112	Cranksh. Pos. Rel. Wheel Learn
0113	Replace EGR
0114	Replace Turbo charger
0115	Replace Glow Time Relay
0116	Replace Flywheel
0117	Replace Throttle Actuator
0118	Replace Exhaust Gas Temp. Sensor
0119	Replace Accel. Pedal Pos. Sensor
0120	Cranksh. Pos. Rel. Wheel Learn
0121	Replace Accel. Pedal Pos. Sensor
0122	DPF Pressure Sensor Reset
0123	Learned Values Reset
0124	Reset Overheat
0125	Reset Start Counter
0126	
0127	SLC1 (Solenoid Valve) Control Test
0128	Clutch Padel Position Learn
0129	Fuel Injector Learn
0130	Catalyst Reset
0131	Fuel Pressure Regulator Learn
0132	Neutral Position Sensor Learn
0133	Exhaust Gas Temperature Sensor Reset
0134	Idle Air Control Reset
0135	Learn Values Reset
0136	NOx Catalyst Reset
0137	Reductant Fluid Tank Level Reset
0138	Reductant System Data Reset
0139	Compression Test
0140	Interior Lamp Test
0141	Erase Key Set

0142	Program Transponder-Keys
0143	Calibration
0144	Longitudinal Sensor Calibration
0145	Learn Partnumber of Sensor
0146	Program Variant Coding
0147	Fuel Tank Ventilation Control
0148	EGR Control
0149	Small Injection Quantity Learning
0150	Clutch Test
0151	Reset Engine Oil Life
0152	Blower Fan Test
0153	Reset EGR Cooler Running Counter
0154	Clutch Calibration Value
0155	Line Pressure Solenoid
0156	TCC Solenoid Test
0157	Shift Pressure Solenoid Test
0158	Gear Control
0159	Reset Learned Valves
0160	Blending Flap Motor Test
0161	Distribution Flap Motor Test
0162	Calibrate Step Motors
0163	H02S Data
0164	Idel Learn
0165	Exh. Gas Temp. Sensor Reset
0166	Erase Key
0167	Programming
0168	Adjust Idle Speed
0169	Start Fuel Quantity Offset
0170	Engine Speed (RPM) Control
0171	Coolant Temperature Control
0172	Line Pressure Solenoid Test
0173	Read crankshaft angle sensor error
0174	Read throttle again
0175	Injector 1 Cutoff
0176	Tyre Size Calibration
0177	Programming Variant Configuration
0178	Service Light Reset
0179	Service Due In
0180	Learn DDS(Deflation Detect. System)
0181	Instantaneous Tank Content
0182	Erase Transponder-Keys And Remote
0183	Program Transponder-Keys And Remote
0184	Light Cigarette Lighter
0185	Canister Purge
0186	Intake Camshaft Phasing B1 Test
0187	Intake Camshaft Phasing B2 Test
0188	Pressure Reg. Sol. Control Test
0189	TCC Solenoid Valve Control Test

0190	Neutral Control Sol. Valve Test
0191	ABS Initialization
0192	CO Adjustment
0193	RON Adjustment
0194	Idle Air Control Test
0195	Fuel Tank Ventilation Valve Test
0196	Reset Idle Adjust
0197	Reset Knockmap
0198	Reset O2 BLM
0199	Reset IAC BLM
0200	IdleSpeed Adjust
0201	Adjust Idle Drive
0202	Adjust Idle P-N
0203	EGR Pulse Ratio Test
0204	Injector Cutoff
0205	Exhaust Gas Recirculation Control
0206	IAC Control (Idle Air Control)
0207	Calculated Fuel Economy Setup
0208	Clear Passenger Window Learned Values
0209	Longitudinal Acceleration Sensor Reset
0210	Deflation Detection System Reset
0211	HVAC Actuators Learn
0212	Average Fuel Age Reset
0213	Erase/Program All Key Fobs
0214	Next Available Slot
0215	Key Fob 1
0216	Key Fob 2
0217	Key Fob 3
0218	Key Fob 4
0219	Key Fob 5
0220	Key Fob 6
0221	Key Fob 7
0222	Key Fob 8
0223	Clear Left Rear Window Learned Values
0224	Clear Right Rear Window Learned Values
0225	Tire Pressure Sensors Learn
0226	Electronic Brake Control Module Learn
0227	HVAC Afterblow Configuration
0228	Exhaust Flow Control Valve Learn
0229	Cylinder Deactivation Exhaust Flow Valve Learn
0230	Hybrid/EV Battery Pack Coolant Control Solenoid Valve
0231	Hybrid/EV Battery Pack Capacity Learn
0232	Passenger Compartment Heater Coolant Control Solenoid Valve Learn
0233	Fuel Economy Reset
0234	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
0235	Hybrid/EV Battery Pack Data Reset
0236	Frontview Camera Learn

0237	Fuel Rail Pressure Sensor or Fuel Rail Learn
0238	Fuel Pressure Regulator Fast Learn
0239	Intake Air Flow Valve Learn
0240	Intake Manifold Runner Control Valve Learn
0241	High Pressure Fuel Pump Learn
0242	Boost Pressure Sensor Learn
0243	Cylinder 1 Injector
0244	Cylinder 2 Injector
0245	Cylinder 3 Injector
0246	Cylinder 4 Injector
0247	Fuel Composition Reset
0248	Transmission Adaptive Values Learn
0249	Setup SDM Part Number in BCM
0250	Configure New Module
	Clutch Control Module/Rear Drive System Matching
0251	Identification Setup
0252	Headlamp Leveling Sensor Learn
0253	Code Index
0254	Module Setup
0255	Erase All Key Fobs
0256	Tire Type/Pressure Selection
0257	Not Linked
0258	Linked
0259	Fuel Injection Small Quantity Learn
0260	Gear Selector -N- Position Learn
0261	Brake Pressure Sensor Calibration
0262	Yaw Rate Sensor Reset
0263	Distance Sensing Cruise Control Module
0264	Clutch Position Learn
0265	Maximum Vehicle Speed Setup
0266	Water In Fuel Sensor Reset
0267	Vehicle Configuration Reset
0268	Throttle Position Learn
0269	Turbocharger Vane Position Learn
0270	Fuel Rail Pressure Relief Valve
0271	Mass Air Flow
0272	Depressurize System
0273	Hydraulic Clutch Bleed
0274	Battery Saver Mode
0275	Longitudinal and Lateral Acceleration Sensor Learn
0276	Service Interval Reset
0277	Adaptive Pressure Control Learn
0278	Control Module Reset
0279	Erase Valet Mode Code
0280	Liftgate Maximum Open Position Learn
0281	AWD Disabled-by-Malfunction Counter Reset
0282	Rear Drive Clutch Service Calibration Setup
0283	Engine Run-in Performance Limitation

0284	Overboost Counter Reset
0285	Knock Counter Reset
0286	Preferred Roaming List Update
0287	Remote Vehicle Speed Limiting Reset
0288	Vehicle Direction Camera Learn
0289	Adjustable Pedals Softstops Learn

XTOOL