

Asia Service Function List

Software Version: 27.70

Automaker	Model	Year	System
ACURA	Auto Reset	BCM	
ACURA	Auto Reset	ICM	
ACURA	Manual Reset	2. 2CL	1997
ACURA	Manual Reset	2. 3CL	1998
ACURA	Manual Reset	2. 5TL	1996
ACURA	Manual Reset	2. 5TL	1997
ACURA	Manual Reset	3. 0CL	1997-1998
ACURA	Manual Reset	3. 2CL	2001-2003
ACURA	Manual Reset	3. 2TL	1996
ACURA	Manual Reset	3. 2TL	1997
ACURA	Manual Reset	3. 2TL	2001-2003
ACURA	Manual Reset	3. 2TL	2004-2005
ACURA	Manual Reset	3. 5RL	2001-2004
ACURA	Manual Reset	3. 5RL	2005
ACURA	Manual Reset	CL	1997-1998
ACURA	Manual Reset	CL	1999-2003
ACURA	Manual Reset	CSX	2006-2010
ACURA	Manual Reset	EL	1997-1999
ACURA	Manual Reset	EL	2000
ACURA	Manual Reset	EL	2001-2005
ACURA	Manual Reset	ILX	2014
ACURA	Manual Reset	INTEGRA	1986-1990
ACURA	Manual Reset	INTEGRA	1991-1993

ACURA	Manual Reset	INTEGRA	1994-1995
ACURA	Manual Reset	INTEGRA	1996-2001
ACURA	Manual Reset	LEGEND	1986-1990
ACURA	Manual Reset	LEGEND	1991-1995
ACURA	Manual Reset	MDX	2001-2005
ACURA	Manual Reset	MDX	2006-2010
ACURA	Manual Reset	MDX	2011-2012
ACURA	Manual Reset	RDX	2007-2010
ACURA	Manual Reset	RDX	2011-2012
ACURA	Manual Reset	RL	1996-1998
ACURA	Manual Reset	RL	2000
ACURA	Manual Reset	RL	2001-2004
ACURA	Manual Reset	RL	2005
ACURA	Manual Reset	RL	2006-2010
ACURA	Manual Reset	RSX	2002-2006
ACURA	Manual Reset	TL	1995-1998
ACURA	Manual Reset	TL	1999-2000
ACURA	Manual Reset	TL	2001-2003
ACURA	Manual Reset	TL	2004-2005
ACURA	Manual Reset	TL	2006-2010
ACURA	Manual Reset	TL	2011-2012
ACURA	Manual Reset	TSX	2004-2005
ACURA	Manual Reset	TSX	2006-2010
ACURA	Manual Reset	TSX	2011
ACURA	Manual Reset	TSX	2012
ACURA	Manual Reset	VIGOR	1992-1994
ACURA	Manual Reset	ZDX	2010
ACURA	Manual Reset	ZDX	2011
ACURA	Manual Reset	ZDX	2012

HONDA	Auto Reset	BCM	
HONDA	Auto Reset	ICM	
HONDA	Manual Reset	integra	1994-1995
HONDA	Manual Reset	integra	1996-2001
HONDA	Manual Reset	Accord Crosstour	2010
HONDA	Manual Reset	Accord Crosstour	2011-2012
HONDA	Manual Reset	JAZZ	2007-2012
HONDA	Manual Reset	ODYSSEY TOURING	2005-2012
HONDA	Manual Reset	JADE	2017
HONDA	Manual Reset	CR-Z	2012
HONDA	Manual Reset	CROSSTOUR	1997-2011
HONDA	Manual Reset	FIT	2007-2012
HONDA	Manual Reset	ACCORD	1982-1985
HONDA	Manual Reset	ACCORD	1986-1990
HONDA	Manual Reset	ACCORD	1991
HONDA	Manual Reset	ACCORD	1992-1996
HONDA	Manual Reset	ACCORD	1997-1999
HONDA	Manual Reset	ACCORD	2000
HONDA	Manual Reset	ACCORD	2001-2002
HONDA	Manual Reset	ACCORD	2003-2005
HONDA	Manual Reset	ACCORD	2006-2010
HONDA	Manual Reset	ACCORD	2013-2014
HONDA	Manual Reset	AVANCIER	
HONDA	Manual Reset	CIVIC	1982-1990
HONDA	Manual Reset	CIVIC	1997-1999
HONDA	Manual Reset	CIVIC	2000
HONDA	Manual Reset	CIVIC	2001-2005
HONDA	Manual Reset	CIVIC	2006-2011
HONDA	Manual Reset	CIVIC	2017 (1.5T)

HONDA	Manual Reset	CR-V	1997-1999
HONDA	Manual Reset	CR-V	2000-2001
HONDA	Manual Reset	CR-V	2002-2006
HONDA	Manual Reset	CR-V	2018
HONDA	Manual Reset	CR-V	2018
HONDA	Manual Reset	CRX)	1984-1990
HONDA	Manual Reset	ELEMENT	2003-2005
HONDA	Manual Reset	INSIGHT	2000-2005
HONDA	Manual Reset	ODYSSAY	1997-1999
HONDA	Manual Reset	ODYSSAY	2000-2004
HONDA	Manual Reset	ODYSSAY	2005
HONDA	Manual Reset	PILOT	2003-2005
HONDA	Manual Reset	PILOT	2006-2012
HONDA	Manual Reset	PRELUDE	1982-1989
HONDA	Manual Reset	PRELUDE	1997-1999
HONDA	Manual Reset	PRELUDE	2000-2002
HONDA	Manual Reset	S2000	2000-2005
HONDA	Manual Reset	S2000	2006
HONDA	Manual Reset	S2000	2007-2009
HONDA	Manual Reset	RIDGELINE	2006-2008
HONDA	Manual Reset	RIDGELINE	2009-2010
HONDA	Manual Reset	RIDGELINE	2011
HONDA	Manual Reset	RIDGELINE	2012
HYUNDAI	Auto Reset		
HYUNDAI	Manual Reset	MISTRA	
ISUZU	Manual Reset	ASOENDER	2003-2005
ISUZU	Manual Reset	ASOENDER	2006
ISUZU	Manual Reset	ASOENDER	2007
ISUZU	Manual Reset	OASIS	1998-1999

ISUZU	Manual Reset	I-280	2006
ISUZU	Manual Reset	I-290	2007
ISUZU	Manual Reset	I-350	2006
ISUZU	Manual Reset	I-370	2007
KIA	Auto Reset		
KIA	Manual Reset	K5	2011-
KIA	Manual Reset	CADENZA	2014
KIA	Manual Reset	FORTE	2010
KIA	Manual Reset	K900	2014
KIA	Manual Reset	OPTIMA	2013-2014
MITSUBISHI	Auto Reset	TYPE1	
MITSUBISHI	Auto Reset	TYPE2	
MITSUBISHI	Manual Reset	LANCER SPORTBACK (CX A)	2008-2010
MITSUBISHI	Manual Reset	LANCER EVOLUTION X	2008-2011
MITSUBISHI	Manual Reset	LANCER EVOLUTION 10	2008-2010
MITSUBISHI	Manual Reset	LANCER (CY\Z A)	2008-2010
MITSUBISHI	Manual Reset	LANCER EVOLUTION	2008-2010
MITSUBISHI	Manual Reset	LANCER SPORTBACK	2009-2010
MITSUBISHI	Manual Reset	OUTLANDER	2007-2010
MITSUBISHI	Manual Reset	COLT	2004-2011
NISSAN	TEANA	NEW TEANA	Oil reset
NISSAN	TEANA	NEW TEANA	Oil filters reset
NISSAN	TEANA	TEANA 2.5	Oil reset
NISSAN	TEANA	TEANA 2.5	Oil filters reset
NISSAN	350Z	2005	
NISSAN	370Z	2009-2010	
NISSAN	ALMERA TINO	2000-2006	
NISSAN	ALTIMA	2007-2010	
NISSAN	ARMADA	2004-2007	

NISSAN	ARMADA	2008-2012	
NISSAN	CUBE	2009-2012	
NISSAN	FRONTIER	2005-2010	
NISSAN	FRONTIER	2011-2012	
NISSAN	GT-R	2009-2012	
NISSAN	MAXIMA	1990-1996	
NISSAN	MAXIMA	2003-2008	
NISSAN	MAXIMA	2009-2012	
NISSAN	MICRA		
NISSAN	MURANO	2003-2008	
NISSAN	MURANO	2009-2012	
NISSAN	N16 ALMERA	2002	
NISSAN	P12 PRIMERA	2002-2008	
NISSAN	PATHFINDER	2005-2007	
NISSAN	PATHFINDER	2008-2012	
NISSAN	PRIMERA	2002-2008	
NISSAN	Qashqai	2006-2011	
NISSAN	QUEST	2005-2010	
NISSAN	TITAN	2004-2012	
NISSAN	X-Trail	2007-2011	
NISSAN	Z	2003-2005	
NISSAN	Z	2006-2008	
NISSAN	Z	2009-2010	
INFINITI	Manual Reset	EX SERIES	2008-2010
INFINITI	Manual Reset	G SERIES	2005-2006
INFINITI	Manual Reset	G SERIES	2007-2012
INFINITI	Manual Reset	FX SERIES	2004-2005
INFINITI	Manual Reset	FX SERIES	2006-2008
INFINITI	Manual Reset	FX SERIES	2009-2012

INFINITI	Manual Reset	M SERIES	2003-2004
INFINITI	Manual Reset	M SERIES	2006-2007
INFINITI	Manual Reset	M SERIES	2008-2012
INFINITI	Manual Reset	QX56	2004-2007
INFINITI	Manual Reset	QX56	2008-2010
INFINITI	Manual Reset	Q50	2014
SUZUKI	Manual Reset	ALTO	2013-
SUZUKI	Manual Reset	SX4	2013-
SUZUKI	Manual Reset	SPLash	2008-2011
SUZUKI	Manual Reset	XL-7	2007-2009
SUZUKI	Manual Reset	Grand Vitara	2013
SUZUKI	Manual Reset	DF40	
TOYOTA	4 RUNNER	2003	
TOYOTA	4 RUNNER	2004	
TOYOTA	4 RUNNER	2005-2009	
TOYOTA	4 RUNNER	2010	
TOYOTA	AVALON	2004-2005	
TOYOTA	AVALON	2006-2007	
TOYOTA	AVALON	2008-2010	
TOYOTA	CAMRY	2004	
TOYOTA	CAMRY	2005-2008	
TOYOTA	CAMRY	2009	
TOYOTA	CAMRY	2010	
TOYOTA	CAMRY HYBRID	2006-2009	
TOYOTA	COASTER	N04C-TY Diesel	
TOYOTA	COROLLA	2005-2008	
TOYOTA	COROLLA	2009-2010	
TOYOTA	COROLLA	2011-	
TOYOTA	ES330	2004	

TOYOTA	ES330	2005	
TOYOTA	FJ CRUISER	2006-2010	
TOYOTA	GX470	2004	
TOYOTA	GX470	2005	
TOYOTA	HIGHLANDER	2004	
TOYOTA	HIGHLANDER	2005-2008	
TOYOTA	HIGHLANDER	2009-2010	
TOYOTA	HIGHLANDER	2012-2014	
TOYOTA	IS330	2004	
TOYOTA	LAND CRUISER	2003-2005	
TOYOTA	LAND CRUISER	2006-2009	
TOYOTA	LAND CRUISER	2010	
TOYOTA	LAND CRUISER 200	2008-2014	
TOYOTA	LAND CRUISER LC200	2007-2011 (1VD-FTV)	
TOYOTA	LEVIN		
TOYOTA	LX470	2004	
TOYOTA	MATRIX	2004	
TOYOTA	MATRIX	2005-2008	
TOYOTA	MATRIX	2009-2010	
TOYOTA	PREVIA	1991-1997	
TOYOTA	PRIUS	2001-2003	
TOYOTA	PRIUS	2004-2005	
TOYOTA	PRIUS	2006-2009	
TOYOTA	PRIUS	2010	
TOYOTA	PRIUS(second generation XW20)	2003-2008	
TOYOTA	PRIUS(third generation XW20)	2009-2013	
TOYOTA	RAV4	2004	
TOYOTA	RAV4	2005-2008	
TOYOTA	RAV4	2009-2010	

TOYOTA	RAV4(third generation XA30)	2009-2013	
TOYOTA	RX330	2004	
TOYOTA	RX330	2005	
TOYOTA	SEQUOIA	2001-2003	
TOYOTA	SEQUOIA	2004	
TOYOTA	SEQUOIA	2005-2008	
TOYOTA	SEQUOIA	2009-2010	
TOYOTA	SIENNA	1998-2003	
TOYOTA	SIENNA	2004	
TOYOTA	SIENNA	2005-2010	
TOYOTA	SOLARA	2004	
TOYOTA	SOLARA	2005	
TOYOTA	SOLARA	2006-2008	
TOYOTA	SOLARA second generation	2004-2008	
TOYOTA	TACOMA	2005-2008	
TOYOTA	TACOMA	2009-2010	
TOYOTA	TACOMA2	2004-2014	
TOYOTA	TUNDRA	2003	
TOYOTA	TUNDRA	2005-2008	
TOYOTA	TUNDRA	2009-2010	
TOYOTA	TUNDRA2	2005-2014	
TOYOTA	VENZA	2008-2013	
TOYOTA	YARIS	2006-2008	
TOYOTA	YARIS	2009-2010	
TOYOTA	YARIS	2011-2013	
TOYOTA	Other	North American	
TOYOTA	Other	Other	
LEXUS	America Area	ES (XV40)	2007-2012
LEXUS	America Area	EX (XV30)	2004-2012

LEXUS	America Area	ES 350	2007-2012
LEXUS	America Area	ES 330	2004-2006
LEXUS	America Area	GS (S190)	2006
LEXUS	America Area	GS (S190)	2007
LEXUS	America Area	GS (S190)	2008-2012
LEXUS	America Area	GS 450h	2007-2012
LEXUS	America Area	GS 460	2008-2012
LEXUS	America Area	GS 350	2007
LEXUS	America Area	GS 350	2008-2012
LEXUS	America Area	GS 430	2006
LEXUS	America Area	GS 430	2007
LEXUS	America Area	GS 300	2006-2007
LEXUS	America Area	GX (J150)	2010-2012
LEXUS	America Area	GX (J120)	2003-2006
LEXUS	America Area	GX (J120)	2007-2009
LEXUS	America Area	GX 460	2010-2012
LEXUS	America Area	GX 470	2003-2006
LEXUS	America Area	GX 470	2007-2009
LEXUS	America Area	IS350	
LEXUS	America Area	IS (XE20)	2006-2007
LEXUS	America Area	IS (XE20)	2008-2012
LEXUS	America Area	IS (XE10)	2004-2005
LEXUS	Chinese Area	ES330	2004
LEXUS	Chinese Area	ES330	2005
LEXUS	Chinese Area	ES350	2007-2011
LEXUS	Chinese Area	GX460	2008-2010
LEXUS	Chinese Area	GS350	2008-2010
LEXUS	Chinese Area	GS450H	2008-2011
LEXUS	Chinese Area	GX470	2004

LEXUS	Chinese Area	GX470	2005
LEXUS	Chinese Area	GX470	2006-2009
LEXUS	Chinese Area	HS250	2010
LEXUS	Chinese Area	IS250/C	2006-2010
LEXUS	Chinese Area	IS350/C	2006-2010
LEXUS	Chinese Area	IS330	2004
LEXUS	Chinese Area	ISF	2008-2010
LEXUS	Chinese Area	LS460	2007-2010
LEXUS	Chinese Area	LS430	2001-2006
LEXUS	Chinese Area	LS600H	2008-2010
LEXUS	Chinese Area	LX470	2004
LEXUS	Chinese Area	LX470	2005-2007
LEXUS	Chinese Area	LX570	2008-2010
LEXUS	Chinese Area	RX330	2004
LEXUS	Chinese Area	RX330	2005
LEXUS	Chinese Area	SC430	2006-2010
SUBARU	Auto Reset		
SUBARU	Manual Reset	Impreza	2012
SUBARU	Manual Reset	Impreza	2013
SUBARU	Manual Reset	Impreza	2014
SUBARU	Manual Reset	Forester	2014
PROTON	Iriz		
MAZDA	MAZDA 2/DEMIO		
MAZDA	MAZDA 3/AXELA		
MAZDA	MAZDA 6/ATENZA		
MAZDA	CX-3		
MAZDA	MX-5		