



Shenzhen Xtooltech Co., Ltd

Asia Service reset Function List

Software Version: 27.83

Automaker	Model	System	Year	Type
Akula	Bodysystem	Auto reset		
Akula	Instrumentationsystem	Auto reset		
Akula	2. 2CL	Manual reset	1997	
Akula	2. 3CL	Manual reset	1998	
Akula	2. 5TL	Manual reset	1996	
Akula	2. 5TL	Manual reset	1997	
Akula	3. 0CL	Manual reset	1997-1998	
Akula	3. 2CL	Manual reset	2001-2003	
Akula	3. 2TL	Manual reset	1996	
Akula	3. 2TL	Manual reset	1997	
Akula	3. 2TL	Manual reset	2001-2003	
Akula	3. 2TL	Manual reset	2004-2005	
Akula	3. 5RL	Manual reset	2001-2004	
Akula	3. 5RL	Manual reset	2005	
Akula	CL	Manual reset	1997-1998	
Akula	CL	Manual reset	1999-2003	
Akula	CSX	Manual reset	2006-2010	
Akula	EL	Manual reset	1997-1999	
Akula	EL	Manual reset	2000	
Akula	EL	Manual reset	2001-2005	
Akula	ILX	Manual reset		Type1
Akula	ILX	Manual reset		Type2

Akula	INTEGRA	Manual reset	1986-1990	
Akula	INTEGRA	Manual reset	1991-1993	
Akula	INTEGRA	Manual reset	1994-1995	
Akula	INTEGRA	Manual reset	1996-2001	
Akula	LEGEND	Manual reset	1986-1990	
Akula	LEGEND	Manual reset	1991-1995	
Akula	MDX	Manual reset	2001-2005	
Akula	MDX	Manual reset	2006-2010	
Akula	MDX	Manual reset	2011-2012	
Akula	MDX	Manual reset	2014-2015	
Akula	RDX	Manual reset	2007-2010	
Akula	RDX	Manual reset	2011-2012	
Akula	RDX	Manual reset	2013-2015	
Akula	RL	Manual reset	1996-1998	
Akula	RL	Manual reset	2000	
Akula	RL	Manual reset	2001-2004	
Akula	RL	Manual reset	2005	
Akula	RL	Manual reset	2006-2010	
Akula	RLX	Manual reset	2014-2015	
Akula	RSX	Manual reset	2002-2006	
Akula	TL	Manual reset	1995-1998	
Akula	TL	Manual reset	1999-2000	
Akula	TL	Manual reset	2001-2003	
Akula	TL	Manual reset	2004-2005	
Akula	TL	Manual reset	2006-2010	
Akula	TL	Manual reset	2011-2012	
Akula	TSX	Manual reset	2004-2005	
Akula	TSX	Manual reset	2006-2010	
Akula	TSX	Manual reset	2011	
Akula	TSX	Manual reset	2012	
Akula	VIGOR	Manual reset	1992-1994	

Akula	ZDX	Manual reset	2010	
Akula	ZDX	Manual reset	2011	
Akula	ZDX	Manual reset	2012	
Honda	Bodysystem	Auto reset		
Honda	Instrumentationsystem	Auto reset		
Honda	Integra (Pattern)	Manual reset	1994-1995	
Honda	Integra (Pattern)	Manual reset	1996-2001	
Honda	Accord (Accord) Crosstour	Manual reset	2010	
Honda	Accord (Accord) Crosstour	Manual reset	2011-2012	
Honda	JAZZ (ImportFit)	Manual reset	2007-2012	
Honda	ODYSSEYTOURING (Odyssey)	Manual reset	2005-2012	
Honda	JADE (Jade)	Manual reset	2017	
Honda	CR-Z	Manual reset	2012	
Honda	CLARITY	Manual reset	2017-2019	
Honda	CROSSTOUR (Songmap)	Manual reset	1997-2015	
Honda	FIT (Fit)	Manual reset	2007-2012	
Honda	FIT (Fit)	Manual reset	2013-2014	
Honda	FIT (Fit)	Manual reset	2015-2019	
Honda	ACCORD (Accord)	Manual reset	1982-1985	
Honda	ACCORD (Accord)	Manual reset	1986-1990	
Honda	ACCORD (Accord)	Manual reset	1991	
Honda	ACCORD (Accord)	Manual reset	1992-1996	
Honda	ACCORD (Accord)	Manual reset	1997-1999	
Honda	ACCORD (Accord)	Manual reset	2000	
Honda	ACCORD (Accord)	Manual reset	2001-2002	
Honda	ACCORD (Accord)	Manual reset	2003-2005	
Honda	ACCORD (Accord)	Manual reset	2006-2011	Type1
Honda	ACCORD (Accord)	Manual reset	2006-2011	Type2
Honda	ACCORD (Accord)	Manual reset	2013-2014	Type1
Honda	ACCORD (Accord)	Manual reset	2013-2014	Type2
Honda	ACCORD (Accord)	Manual reset	2015-2017	

Honda	ACCORD (Accord)	Manual reset	2018-2020	
Honda	ACCORD (Accord)	Manual reset		other
Honda	ACCORD (Accord)	Manual reset		TenGenerationAccord
Honda	AVANCIER (CrownRoad)	Manual reset	-2018	Type1
Honda	AVANCIER (CrownRoad)	Manual reset	2018-	Type2
Honda	AVANCIER (CrownRoad)	Manual reset		Type3
Honda	AVANCIER (CrownRoad)	Manual reset		Type4
Honda	CIVIC (HondaCivic)	Manual reset	1982-1990	
Honda	CIVIC (HondaCivic)	Manual reset	1997-1999	
Honda	CIVIC (HondaCivic)	Manual reset	2000	
Honda	CIVIC (HondaCivic)	Manual reset	2001-2005	
Honda	CIVIC (HondaCivic)	Manual reset	2006-2011	
Honda	CIVIC (HondaCivic)	Manual reset	2012-2015	Nomulti- functiondisplay
Honda	CIVIC (HondaCivic)	Manual reset	2012-2015	Configuremulti- functiondisplay
Honda	CIVIC (HondaCivic)	Manual reset	2016-2020	Nomulti- functiondisplay
Honda	CIVIC (HondaCivic)	Manual reset	2016-2020	Configuremulti- functiondisplay
Honda	CIVIC (HondaCivic)	Manual reset	2017	1.5T
Honda	CR-V	Manual reset	1997-1999	
Honda	CR-V	Manual reset	2000-2001	
Honda	CR-V	Manual reset	2002-2006	
Honda	CR-V	Manual reset	2007-2010	
Honda	CR-V	Manual reset	2012-2016	Nomulti- functiondisplay
Honda	CR-V	Manual reset	2012-2016	Configuremulti- functiondisplay
Honda	CR-V	Manual reset	2017	Nomulti- functiondisplay

Honda	CR-V	Manual reset	2017	Configure multi-function display
Honda	CR-V	Manual reset	2018	Low profile
Honda	CR-V	Manual reset	2018	High profile
Honda	CR-V	Manual reset	2019	No multi-function display
Honda	CR-V	Manual reset	2019	Configure multi-function display
Honda	CR-V	Manual reset		other
Honda	HR-V	Manual reset	2016-2018	
Honda	HR-V	Manual reset	2019	No multi-function display
Honda	HR-V	Manual reset	2019	Configure multi-function display
Honda	UR-V	Manual reset	2017	
Honda	CRX (Civic)	Manual reset	1984-1990	
Honda	CRX (Civic)	Manual reset	2011-2016	
Honda	CRIDER (LingPai)	Manual reset	2019	
Honda	CRIDER (LingPai)	Manual reset		other
Honda	ELEMENT (element)	Manual reset	2003-2006	
Honda	ELEMENT (element)	Manual reset	2007-2011	
Honda	INSIGHT (Insett)	Manual reset	2000-2005	
Honda	INSIGHT (Insett)	Manual reset	2006	
Honda	INSIGHT (Insett)	Manual reset	2010-2012	
Honda	INSIGHT (Insett)	Manual reset	2018-2020	
Honda	INSPIRE (English Poetry)	Manual reset		
Honda	INSPIRE (Accord)	Manual reset	2009-2012	
Honda	ODYSSAY (Odyssey)	Manual reset	1997-1999	
Honda	ODYSSAY (Odyssey)	Manual reset	2000-2004	
Honda	ODYSSAY (Odyssey)	Manual reset	2005	

Honda	ODYSSAY (Odyssey)	Manual reset	2011-2017	No multi-function display
Honda	ODYSSAY (Odyssey)	Manual reset	2011-2017	Configure multi-function display
Honda	ODYSSAY (Odyssey)	Manual reset	2018-2020	
Honda	PASSPORT	Manual reset	2019	
Honda	PILOT (pilot)	Manual reset	2003-2005	
Honda	PILOT (pilot)	Manual reset	2006-2012	
Honda	PILOT (pilot)	Manual reset	2016-2018	
Honda	PILOT (pilot)	Manual reset	2019-2020	
Honda	PRELUDE (Disclosure)	Manual reset	1982-1989	
Honda	PRELUDE (Disclosure)	Manual reset	1997-1999	
Honda	PRELUDE (Disclosure)	Manual reset	2000-2002	
Honda	S2000	Manual reset	2000-2005	
Honda	S2000	Manual reset	2006	
Honda	S2000	Manual reset	2007-2009	
Honda	RIDGELINE	Manual reset	2006-2008	
Honda	RIDGELINE	Manual reset	2009-2010	
Honda	RIDGELINE	Manual reset	2011	
Honda	RIDGELINE	Manual reset	2012	
Honda	RIDGELINE	Manual reset	2017-2019	
Honda	ENVIX	Manual reset	2019	
Honda	Accord Crosstour	Manual reset	2010	
Honda	Accord Crosstour	Manual reset	2011-2012	
Toyota	COROLLA (Carola)	Auto reset	2017-	
Toyota	4RUNNER (Speedmaster)	Manual reset	2003	
Toyota	4RUNNER (Speedmaster)	Manual reset	2004	
Toyota	4RUNNER (Speedmaster)	Manual reset	2005-2009	
Toyota	4RUNNER (Speedmaster)	Manual reset	2010	
Toyota	AVALON (Asian Dragon)	Manual reset	2004-2005	
Toyota	AVALON (Asian Dragon)	Manual reset	2006-2007	

Toyota	AVALON (AsianDragon)	Manual reset	2008-2010	
Toyota	CAMRY (Camry)	Manual reset	2004	
Toyota	CAMRY (Camry)	Manual reset	2005-2008	
Toyota	CAMRY (Camry)	Manual reset	2009	
Toyota	CAMRY (Camry)	Manual reset	2010	
Toyota	CAMRYHYBRID (CamryHybrid)	Manual reset	2006-2009	
Toyota	COASTER (Coster)	Manual reset		N04C-TYDiesel
Toyota	COROLLA (Carola)	Manual reset	2005-2008	
Toyota	COROLLA (Carola)	Manual reset	2009-2010	
Toyota	COROLLA (Carola)	Manual reset	2011-	Withfunctiondisplay
Toyota	COROLLA (Carola)	Manual reset	2011-	Withoutmulti-functiondisplay
Toyota	COROLLA (Carola)	Manual reset	2019-	
Toyota	ES330	Manual reset	2004	
Toyota	ES330	Manual reset	2005	
Toyota	FJCRUISER (FJKuluze)	Manual reset	2006-2010	
Toyota	GX470	Manual reset	2004	
Toyota	GX470	Manual reset	2005	
Toyota	HIGHLANDER (Highlander)	Manual reset	2004	
Toyota	HIGHLANDER (Highlander)	Manual reset	2005-2008	
Toyota	HIGHLANDER (Highlander)	Manual reset	2009-2010	
Toyota	HIGHLANDER (Highlander)	Manual reset	2012-2014	
Toyota	IS330	Manual reset	2004	
Toyota	LANDCRUISER (LandCruiser)	Manual reset	2003-2005	
Toyota	LANDCRUISER (LandCruiser)	Manual reset	2006-2009	
Toyota	LANDCRUISER (LandCruiser)	Manual reset	2010	
Toyota	LANDCRUISER200 (LandCruiser200)	Manual reset	2008-2014	
Toyota	LANDCRUISERLC200 (LandCruiserLC200)	Manual reset	2007-2011	1VD-FTV
Toyota	LEVIN (Leiling)	Manual reset		
Toyota	LX470	Manual reset	2004	
Toyota	MATRIX	Manual reset	2004	

Toyota	MATRIX	Manual reset	2005-2008	
Toyota	MATRIX	Manual reset	2009-2010	
Toyota	PREVIA (Previa)	Manual reset	1991-1997	
Toyota	PRIUS (Prius)	Manual reset	2001-2003	
Toyota	PRIUS (Prius)	Manual reset	2004-2005	
Toyota	PRIUS (Prius)	Manual reset	2006-2009	
Toyota	PRIUS (Prius)	Manual reset	2010	
Toyota	PRIUS (SecondgenerationXW20)	Manual reset	2003-2008	
Toyota	PRIUS (ThreegenerationsXW20)	Manual reset	2009-2013	
Toyota	RAV4 (RongFang)	Manual reset	2004	
Toyota	RAV4 (RongFang)	Manual reset	2005-2008	
Toyota	RAV4 (RongFang)	Manual reset	2009-2010	
Toyota	RAV4 (ThreegenerationsXA30)	Manual reset	2009-2013	
Toyota	RX330	Manual reset	2004	
Toyota	RX330	Manual reset	2005	
Toyota	SEQUOIA (Sequoia)	Manual reset	2001-2003	
Toyota	SEQUOIA (Sequoia)	Manual reset	2004	
Toyota	SEQUOIA (Sequoia)	Manual reset	2005-2008	
Toyota	SEQUOIA (Sequoia)	Manual reset	2009-2010	
Toyota	SIENNA (Sena)	Manual reset	1998-2003	
Toyota	SIENNA (Sena)	Manual reset	2004	
Toyota	SIENNA (Sena)	Manual reset	2005-2010	
Toyota	SOLARA (CamryOverseas)	Manual reset	2004	
Toyota	SOLARA (CamryOverseas)	Manual reset	2005	
Toyota	SOLARA (CamryOverseas)	Manual reset	2006-2008	
Toyota	SOLARA (CamryOverseasSecondGeneration)	Manual reset	2004-2008	
Toyota	TACOMA (Tacoma)	Manual reset	2005-2008	
Toyota	TACOMA (Tacoma)	Manual reset	2009-2010	
Toyota	TACOMA2 (Tacoma2)	Manual reset	2004-2014	
Toyota	TUNDRA (Smoothway)	Manual reset	2003	
Toyota	TUNDRA (Smoothway)	Manual reset	2005-2008	

Toyota	TUNDRA (Smoothway)	Manual reset	2009-2010	
Toyota	TUNDRA2 (Smoothway2)	Manual reset	2005-2014	
Toyota	VENZA (WeiSa)	Manual reset	2008-2013	
Toyota	YARIS (Yaris)	Manual reset	2006-2008	
Toyota	YARIS (Yaris)	Manual reset	2009-2010	
Toyota	YARIS (Yaris)	Manual reset	2011-2013	
Toyota	other	Manual reset		NorthAmerica
Toyota	other	Manual reset		other
Lexus	ES (XV40)	Manual reset	2007-2012	
Lexus	EX (XV30)	Manual reset	2004-2012	
Lexus	ES350	Manual reset	2007-2012	
Lexus	ES330	Manual reset	2004-2006	
Lexus	GS (S190)	Manual reset	2006	
Lexus	GS (S190)	Manual reset	2007	
Lexus	GS (S190)	Manual reset	2008-2012	
Lexus	GS450h	Manual reset	2007-2012	
Lexus	GS460	Manual reset	2008-2012	
Lexus	GS350	Manual reset	2007	
Lexus	GS350	Manual reset	2008-2012	
Lexus	GS430	Manual reset	2006	
Lexus	GS430	Manual reset	2007	
Lexus	GS300	Manual reset	2006-2007	
Lexus	GX (J150)	Manual reset	2010-2012	
Lexus	GX (J120)	Manual reset	2003-2006	
Lexus	GX (J120)	Manual reset	2007-2009	
Lexus	GX460	Manual reset	2010-2012	
Lexus	GX470	Manual reset	2003-2006	
Lexus	GX470	Manual reset	2007-2009	
Lexus	IS350	Manual reset		
Lexus	IS (XE20)	Manual reset	2006-2007	
Lexus	IS (XE20)	Manual reset	2008-2012	

Lexus	IS (XE10)	Manual reset	2004-2005	
Lexus	ES330	Manual reset	2004	
Lexus	ES330	Manual reset	2005	
Lexus	ES350	Manual reset	2007-2011	
Lexus	GX460	Manual reset	2008-2010	
Lexus	GS350	Manual reset	2008-2010	
Lexus	GS450H	Manual reset	2008-2011	
Lexus	GX470	Manual reset	2004	
Lexus	GX470	Manual reset	2005	
Lexus	GX470	Manual reset	2006-2009	
Lexus	HS250	Manual reset	2010	
Lexus	IS250/C	Manual reset	2006-2010	
Lexus	IS350/C	Manual reset	2006-2010	
Lexus	IS330	Manual reset	2004	
Lexus	ISF	Manual reset	2008-2010	
Lexus	LS460	Manual reset	2007-2010	
Lexus	LS430	Manual reset	2001-2006	
Lexus	LS600H	Manual reset	2008-2010	
Lexus	LX470	Manual reset	2004	
Lexus	LX470	Manual reset	2005-2007	
Lexus	LX570	Manual reset	2008-2010	
Lexus	RX300	Manual reset	2018	
Lexus	RX330	Manual reset	2004	
Lexus	RX330	Manual reset	2005	
Lexus	SC430	Manual reset	2006-2010	
Nissan	Teana	Manual reset		Type1 (NewTeana)
Nissan	Teana	Manual reset		Type1 (Teana2. 5)
Nissan	Teana	Manual reset	2008-2012	Type2
Nissan	Bluebird	Manual reset		
Nissan	NewBluebird	Manual reset		
Nissan	Junyi (Geniss)	Manual reset		

Nissan	LiWei (Livina)	Manual reset		
Nissan	sunlight	Manual reset		
Nissan	Geek	Manual reset		Type 1
Nissan	Geek	Manual reset		Type 2
Nissan	SYLPHY (XuanYi)	Manual reset		
Nissan	TIIDA (Yida)	Manual reset		
Nissan	350Z	Manual reset	2005	
Nissan	350Z	Manual reset		other
Nissan	370Z	Manual reset	2009-2010	
Nissan	370Z	Manual reset		other
Nissan	ARMADA	Manual reset	2008-2012	
Nissan	CUBE	Manual reset	2009-2012	
Nissan	CEFIRO (demeanor)	Manual reset		
Nissan	FRONTIER	Manual reset	2005-2010	
Nissan	FRONTIER	Manual reset	2011-2012	
Nissan	GT-R (Noble)	Manual reset	2009-2012	
Nissan	MAXIMA	Manual reset	1990-1996	
Nissan	MAXIMA	Manual reset	2003-2008	
Nissan	MAXIMA	Manual reset	2009-2012	
Nissan	MARCH (MaChi)	Manual reset		
Nissan	MICRA	Manual reset		
Nissan	MURANO (Loulan)	Manual reset	2003-2008	
Nissan	MURANO (Loulan)	Manual reset	2009-2012	
Nissan	MURANO (Loulan)	Manual reset	2017-	
Nissan	MURANO (Loulan)	Manual reset	other	
Nissan	N16ALMERA	Manual reset	2002	
Nissan	NV (1500/2500/3500CargoVan)	Manual reset	2012-2014	
Nissan	NV200 (PassengerVan)	Manual reset	2013-2014	
Nissan	P12PRIMERA	Manual reset	2002-2008	
Nissan	PATROL (Tule)	Manual reset		
Nissan	PATHFINDER	Manual reset	2005-2007	

Nissan	PATHFINDER	Manual reset	2008-2012	
Nissan	PATHFINDER	Manual reset	2004-2011	Withnavigationsystem
Nissan	PATHFINDER	Manual reset	2004-2011	Withoutnavigationsys tem
Nissan	PALADIN (Paladin)	Manual reset		
Nissan	PRIMERA	Manual reset	2002-2008	Type 1
Nissan	Qashqai (Qashqai)	Manual reset	2006-2011	Settingmethod
Nissan	Qashqai (Qashqai)	Manual reset	2006-2011	Maintenanceinterval, Settingscanbechanged , Proceedasfollows
Nissan	Qashqai (Qashqai)	Manual reset	2016	
Nissan	QUEST	Manual reset	2005-2010	
Nissan	TITAN	Manual reset	2004-2012	
Nissan	X-Trail (QiJun)	Manual reset	2007-2011	Settingmethod
Nissan	X-Trail (QiJun)	Manual reset	2007-2011	Maintenanceinterval, Settingscanbechanged , Proceedasfollows
Nissan	X-Trail (QiJun)	Manual reset	2018-	
Nissan	X-Trail (QiJun)	Manual reset		Other
Nissan	Z	Manual reset	2003-2005	
Nissan	Z	Manual reset	2006-2008	
Nissan	Z	Manual reset	2009-2010	
Nissan	NOTE	Manual reset	2006-2011	
Nissan	PRIMASTAR	Manual reset	2006-2008	
Nissan	PRIMASTAR	Manual reset	2009-2011	Type 1
Nissan	PRIMASTAR	Manual reset	2009-2011	Type 2
Nissan	PRIMASTAR	Manual reset	2012	
Infiniti	EXSERIES	Manual reset	2008-2010	
Infiniti	GSERIES	Manual reset	2005-2006	
Infiniti	GSERIES	Manual reset	2007-2012	

Infiniti	FXSERIES	Manual reset	2004-2005	
Infiniti	FXSERIES	Manual reset	2006-2008	
Infiniti	FXSERIES	Manual reset	2009-2012	
Infiniti	MSERIES	Manual reset	2003-2004	
Infiniti	MSERIES	Manual reset	2006-2007	
Infiniti	MSERIES	Manual reset	2008-2012	
Infiniti	QX56	Manual reset	2004-2007	
Infiniti	QX56	Manual reset	2008-2010	
Infiniti	Q50	Manual reset	2014	
HYUNDAI	ALL	Auto reset		
HYUNDAI	Namemap	Manual reset		
HYUNDAI	Festa	Manual reset	2018-	
Kia	ALL	Auto reset		
Kia	K5	Manual reset	2011-	
Kia	CADENZA	Manual reset	2014	
Kia	FORTE	Manual reset	2010	
Kia	K900	Manual reset	2014	
Kia	OPTIMA	Manual reset	2013-2014	
Kia	Sportage	Manual reset	2019	
Mitsubishi	Type 1	Auto reset		
Mitsubishi	Type 2	Auto reset		
Mitsubishi	Type 3 (Entersetvalue)	Auto reset		
Mitsubishi	LANCERSPORTBACK (CX A)	Manual reset	2008-2010	
Mitsubishi	LANCEREVOLUTIONX	Manual reset	2008-2011	
Mitsubishi	LANCEREVOLUTION10	Manual reset	2008-2010	
Mitsubishi	LANCER (CY\Z A)	Manual reset	2008-2010	
Mitsubishi	LANCEREVOLUTION	Manual reset	2008-2010	
Mitsubishi	LANCERSPORTBACK	Manual reset	2009-2010	
Mitsubishi	OUTLANDER	Manual reset	2007-2010	

Mitsubishi	OUTLANDER	Manual reset	2018	
Mitsubishi	OUTLANDER	Manual reset	2019	
Mitsubishi	COLT	Manual reset	2004-2011	
Mazda	BONGO/BONGOBRWNY/SPECTRON (Bengue)	Auto reset		
Mazda	CX-3	Auto reset		
Mazda	CX-5	Auto reset		
Mazda	CX-7 (Europe/Commonarea)	Auto reset		
Mazda	CX-8	Auto reset		
Mazda	CX-9 (NorthAmerica/Commonarea)	Auto reset		
Mazda	DEMIO/121DEMIO/121	Auto reset		
Mazda	DEMIO/FESTIVAMINIWAGON	Auto reset		
Mazda	FAMILIA/LASER (Familia)	Auto reset		
Mazda	Mazda2/DEMIO	Auto reset		
Mazda	Mazda3	Auto reset		
Mazda	Mazda3/Atz	Auto reset		
Mazda	Mazda3/Uncella	Auto reset		
Mazda	Mazda5/i-MAX	Auto reset		
Mazda	Mazda6/Atz	Auto reset		
Mazda	MPV (NorthAmerica/Commonarea)	Auto reset		
Mazda	MX-5 (NorthAmerica/Commonarea)	Auto reset		
Mazda	MX-5	Auto reset		
Mazda	MX-5/ROADSTER	Auto reset		
Mazda	MX-5MIATA	Auto reset		
Mazda	Millenia (millennium)	Auto reset		
Mazda	PREMACY (Prima)	Auto reset		
Mazda	PROTEGE (Everything)	Auto reset		
Mazda	Titan (Hercules)	Auto reset		
Mazda	XEDOS9	Auto reset		
Mazda	CX-4	Manual reset		

Mazda	CX-5	Manual reset		Type1
Mazda	CX-5	Manual reset		Type2
Mazda	CX-5	Manual reset		Type3
Mazda	CX-5	Manual reset		Type4
Mazda	CX-5	Manual reset		Type5
Mazda	MAZDA3/AXELA	Manual reset		Type1
Mazda	MAZDA3/AXELA	Manual reset		Type2
Mazda	MAZDA3/AXELA	Manual reset		Type3
Mazda	MAZDA3/AXELA	Manual reset		Type4
Mazda	MAZDA3/AXELA	Manual reset	2020	Type5
Mazda	MAZDA2/DAMIO	Manual reset		Type1
Mazda	MAZDA2/DAMIO	Manual reset		Type2
Subaru		Auto reset		
Subaru	Forester (Forester)	Manual reset	2014	
Subaru	Impreza (Impreza)	Manual reset	2012	
Subaru	Impreza (Impreza)	Manual reset	2013	
Subaru	Impreza (Impreza)	Manual reset	2014	
Subaru	Legacy (Lishi)	Manual reset		
Subaru	Levorg	Manual reset		
Subaru	Outback (Outback)	Manual reset		
Subaru	Tribeca (Chippen)	Manual reset		
Subaru	Wrx	Manual reset		
Subaru	XV	Manual reset	2019	
Isuzu	ASOENDER	Manual reset	2003-2005	
Isuzu	ASOENDER	Manual reset	2006	
Isuzu	ASOENDER	Manual reset	2007	
Isuzu	OASIS	Manual reset	1998-1999	
Isuzu	I-280	Manual reset	2006	
Isuzu	I-290	Manual reset	2007	

Isuzu	I-350	Manual reset	2006	
Isuzu	I-370	Manual reset	2007	
SUZUKI	(T) XL-7/GRANDVITARA/VITARA	Auto reset		
SUZUKI	NewAlto	Manual reset	2013-	
SUZUKI	SX4Amagatarai	Manual reset	2013-	
SUZUKI	SPlash (Pai)	Manual reset	2008-2011	
SUZUKI	XL-7	Manual reset	2007-2009	
SUZUKI	GrandVitara (SuperVitra)	Manual reset	2013	
SUZUKI	DF40	Manual reset		
Proton	Iriz	Auto reset		

*XT***ool**