



Shenzhen Xtooltech Co., Ltd

China service reset function list

Software version: 29.18

Automaker	Model	method	Year	Type
BAIC	BJ20	Auto reset	-2018	
BAIC	BJ20	Auto reset	2018	
BAIC	BJ40	Auto reset		
BAIC	BJ40 PLUS	Auto reset		
BAIC	BJ40L	Auto reset	2018	Petrol
BAIC	BJ40L	Auto reset	2018	Diesel
BAIC	BJ40L	Auto reset	2018	City Hunter Edition
BAIC	BJ80C	Auto reset		
BAIC	BJ80J	Auto reset		
BAIC	E Series	Auto reset		
BAIC	CC (C60F)	Auto reset		
BAIC	D20 (C30D/C31D)	Auto reset		
BAIC	D50 (C50E)	Auto reset		Type 1
BAIC	D50 (C50E)	Auto reset		Type 2
BAIC	D50 (C50E)	Manual reset	-2018	
BAIC	D50 (C50E)	Manual reset	2018-	
BAIC	New D50	Auto reset		
BAIC	D60 (C60F)	Auto reset		
BAIC	D70 (C70G)	Auto reset		Type 1
BAIC	D70 (C70G)	Auto reset		Type 2
BAIC	New D70	Auto reset		

BAIC	D80 (C80G)	Auto reset		
BAIC	U7	Auto reset		
BAIC	X25 (C33D)	Auto reset	-2016	
BAIC	X25 (C33D)	Auto reset	2016-2017	
BAIC	X3	Auto reset		
BAIC	X35 (C32B)	Auto reset	-2016	
BAIC	X35 (C32B)	Auto reset	2016	
BAIC	X55 (C51E)	Auto reset		Type 1
BAIC	X55 (C51E)	Auto reset		Type 2
BAIC	New X55	Auto reset		
BAIC	X65 (C61X)	Auto reset		
BAIC	ZhiDao	Auto reset		
BAIC	WeiWang 307	Auto reset	-2015	
BAIC	WeiWang 308 EV	Auto reset		
BAIC	EV150	Auto reset		
BAIC	EV160	Auto reset		
BAIC	EV200	Auto reset		
BAIC	EV300	Auto reset		
BAIC	EX200	Auto reset		
BAIC	EX260	Auto reset		
BAIC	EX360	Auto reset		
BAIC	EX5	Auto reset		
BAIC	EU220	Auto reset		
BAIC	EU260	Auto reset		
BAIC	EU300	Auto reset		
BAIC	EU400	Auto reset		
BAIC	EU5	Auto reset		
BAIC	EH300	Auto reset		
BAIC	ARCFOX	Auto reset		
BAIC	ARCFOX (ADAS)	Auto reset		
BAIC	LITE	Auto reset		Basic

BAIC	LITE	Auto reset		ADASA
BAIC	LITE	Auto reset		300
BAIC	M50F	Auto reset		
BAIC	M60	Auto reset		
BAIC	S50	Auto reset		
BaoJun	RS-5	Auto reset		
BaoJun	RS-5	Manual reset		
BARGWARD	BX3	Auto reset		
BARGWARD	BX5	Auto reset		
BARGWARD	BX7	Auto reset		
BYD	E5 300	Manual reset		
BYD	G5	Manual reset		
BYD	G6	Manual reset		
BYD	M6	Manual reset		
BYD	S6	Manual reset		
BYD	S7	Manual reset		
BYD	Qin	Manual reset		
BYD	Qin-100	Manual reset		
BYD	Qin-EV300	Manual reset		
BYD	Sirui	Manual reset		
BYD	Song	Manual reset		
BYD	Song-DM	Manual reset		
BYD	Song- (Fuel version)	Manual reset		
BYD	Song- (Fuel version)	Manual reset	2017	
BYD	Surui	Manual reset		
BYD	Tang	Manual reset		
BYD	Tang-100	Manual reset		
BYD	Yuan	Manual reset		
ChangAn	CS15	Auto reset		

ChangAn	CS15 EV	Auto reset		
ChangAn	CS35	Auto reset	2017	
ChangAn	CS55	Auto reset		
ChangAn	CS75	Auto reset	-2019	
ChangAn	CS85	Auto reset		Type 1
ChangAn	CS85	Auto reset		Type 2
ChangAn	New BenBen	Auto reset		
ChangAn	RAETON(SDE Instrument)	Auto reset		
ChangAn	KeSai 5	Auto reset		
ChangAn	CS15	Manual reset		
ChangAn	CS35	Manual reset		
ChangAn	CS75	Manual reset		
ChangAn	CS95	Manual reset		
GREAT WALL	Auto recognition	Auto reset		
GREAT WALL	C30	Auto reset		
GREAT WALL	C30(CH041E)	Auto reset		
GREAT WALL	C50	Auto reset		CHB012
GREAT WALL	C50	Auto reset		JZ40
GREAT WALL	C50	Manual reset		
GREAT WALL	FengJun 5	Manual reset		
GREAT WALL	Great	Auto reset		Type 1
GREAT WALL	Great	Auto reset		Type 2
GREAT WALL	F5	Auto reset		
GREAT WALL	F7	Auto reset		Type 1
GREAT WALL	F7	Auto reset		Type 2
GREAT WALL	F7X	Auto reset		
GREAT WALL	H1	Auto reset		
GREAT WALL	H2	Auto reset		
GREAT WALL	H2s	Auto reset		

GREAT WALL	H4	Auto reset		
GREAT WALL	H6	Manual reset	-2014	
GREAT WALL	H6	Auto reset	2015-2020	
GREAT WALL	H6	Auto reset	2021	
GREAT WALL	H6 COUPE	Auto reset		Type 1
GREAT WALL	H6 COUPE	Auto reset		Type 2
GREAT WALL	H7	Auto reset		Type 1
GREAT WALL	H7	Auto reset		Type 2
GREAT WALL	H8	Auto reset		6AT
GREAT WALL	H8	Auto reset		8AT
GREAT WALL	H9	Auto reset		6AT
GREAT WALL	H9	Auto reset		8AT
GREAT WALL	H9	Auto reset	2020	
GREAT WALL	M6	Auto reset		
GREAT WALL	ChuLian	Auto reset		
GREAT WALL	DOG	Auto reset		
GREAT WALL	Rabbit	Auto reset		
GREAT WALL	P8	Auto reset		
GREAT WALL	VV5	Auto reset		Type 1
GREAT WALL	VV5	Auto reset		Type 2
GREAT WALL	VV6	Auto reset		
GREAT WALL	VV7	Auto reset	-2020	
GREAT WALL	VV7	Auto reset	2020	GT/PHEV
GREAT WALL	TANK 300	Auto reset		
GREAT WALL	Mocha	Auto reset		
GREAT WALL	IQ	Auto reset		
GREAT WALL	R1	Auto reset		
GREAT WALL	R2	Auto reset		
GREAT WALL	IQ-420	Auto reset		

GREAT WALL	HaoMao	Auto reset		
GREAT WALL	C30EV	Auto reset		Type 1
GREAT WALL	C30EV	Auto reset		Type 2
GREAT WALL	C30EV	Auto reset		Type 3
GREAT WALL	FengJun 7	Auto reset		
ChangHe	Q25	Auto reset		
ChangHe	Q35	Auto reset		
ChangHe	A6	Auto reset	-2019	
ChangHe	A6	Auto reset	2019-	
ChangHe	Q7	Auto reset		Type 1
ChangHe	Q7	Auto reset		Type 2
ChangFeng	CS9	Manual reset		
ChangFeng	CS10	Manual reset		
DFFG	IX5	Manual reset		
DFFG	E3	Auto reset		
DFFG	IX5 upgrade	Auto reset		
DFFG	IX7	Auto reset		
DFFS	A30	Manual reset	2014-2016	
DFFS	AX3	Manual reset		Type 1
DFFS	AX3	Manual reset		Type 2
DFFS	AX4	Manual reset	2017-2018	
DFFS	AX4	Manual reset	2019	
DFFS	AX5	Manual reset		
DFFS	AX7	Manual reset	2015-2016	
DFFS	AX7	Manual reset	2017	
DFFS	AX7	Manual reset		A14T
DFFS	AX7	Manual reset		Other
DFFS	New AX7	Manual reset		Type 1
DFFS	New AX7	Manual reset		Type 2

DFFS	A60	Manual reset		
DFFS	A9	Manual reset	2016	
DFFS	E70	Manual reset		
DFFS	L60	Manual reset	2015	
DFFS	D53	Manual reset		
DFFS	AX5	Auto reset		
Soueast	A5	Manual reset		
Soueast	DX3	Manual reset		
Soueast	DX7	Manual reset		
Soueast	V5	Manual reset		
FOTON	Takuru	Auto reset		
FOTON	Savanna (U201)	Auto reset		
Maple	30x	Auto reset		
Qoros	Qoros 3	Auto reset		
Qoros	Qoros 3s	Auto reset		
Qoros	Qoros 3 5-door version	Auto reset		
Qoros	Qoros 3 SUV	Auto reset		
Qoros	Qoros 3 Car	Auto reset		
Qoros	Qoros 3 GT	Auto reset		
Qoros	Qoros 5	Auto reset		
Qoros	Qoros 5s	Auto reset		
Qoros	Qoros 5 SUV	Auto reset		
Brilliance	Zhonghua V3(Third generation)	Auto reset		
Brilliance	Zhonghua V6	Auto reset		
Brilliance	Zhonghua V7	Auto reset		
Brilliance	Renault Gold Cup view	Auto reset		High configuration
Brilliance	Renault Gold Cup view	Auto reset		Low configuration
HanTeng	A45	Auto reset		
HanTeng	X5	Auto reset		

HanTeng	X5 (M11G)	Auto reset		
HanTeng	X7	Auto reset		
HanTeng	X7 (B15G)	Auto reset		
HanTeng	X7S	Auto reset		
HanTeng	X5 EV	Auto reset		
HanTeng	X7 PHEV	Auto reset		
HaiMa	M5	Auto reset		VIKEER ICM
HaiMa	M8	Auto reset		VIKEER ICM
HaiMa	S7	Auto reset		VIKEER ICM
HaiMa	V70	Auto reset		VIKEER ICM
HaiMa	F7	Auto reset		VIKEER ICM
HaiMa	Family	Auto reset		
HaiMa	8S (SG00)	Auto reset		ICM-SG00
HaiMa	S5	Manual reset		
Geely	BO YUE	Auto reset	-2019	
Geely	BO YUE	Auto reset	2019-	
Geely	BO YUE (PRO)	Auto reset		
Geely	BO RUI	Auto reset		
Geely	BO RUI (GE)	Auto reset	-2019	
Geely	BO RUI (GE)	Auto reset	2019-	
Geely	Bin Yue (Traditional power+MHEV)	Auto reset	-2019	
Geely	Bin Yue (Traditional power+MHEV)	Auto reset	2019-	
Geely	Bin Rui	Auto reset	-2019	GL14T/15T
Geely	Bin Rui	Auto reset	2019-	GL14T/15T
Geely	Emgrand (HEV)	Auto reset		
Geely	Emgrand (GL)	Auto reset		GL
Geely	Emgrand (GL)	Auto reset	-2019	GL 14T/15T
Geely	Emgrand (GL)	Auto reset	2019-	GL 14T/15T
Geely	Emgrand (GS)	Auto reset		GS

Geely	Emgrand (GS)	Auto reset		GS 14T
Geely	Emgrand (GS)	Auto reset	-2019	GS 15T
Geely	Emgrand (GS)	Auto reset	2019-	GS 15T
Geely	New Emgrand/VISION (S1)	Auto reset	-2019	
Geely	New Emgrand/VISION (S1)	Auto reset	2019-	Type 1
Geely	New Emgrand/VISION (S1)	Auto reset	2019-	Type 2
Geely	VISION (X1)	Auto reset		
Geely	VISION (X3)	Auto reset	-2018	
Geely	VISION (X3)	Auto reset	2019-	
Geely	VISION (X6)	Auto reset	-2019	Wly
Geely	VISION (X6)	Auto reset	2019-	Wly
Geely	VISION (X6)	Auto reset	2016	
Geely	VISION (X6)	Auto reset	2018	
Geely	VISION (X6)	Auto reset	2020	Wly
Geely	New VISION	Auto reset	-2018	Wly
Geely	New VISION	Auto reset	2019	
Geely	Jia Ji (Traditional power-MHEV)	Auto reset	-2019	
Geely	Jia Ji (Traditional power-MHEV)	Auto reset	2019-	
Geely	Xing yue (Traditional power-MHEV)	Auto reset		
Geely	PREFACE	Auto reset		
Geely	GX7	Auto reset		
Geely	GX9	Auto reset		
Geely	SX7	Auto reset		
Geely	Bin Yue (PHEV)	Auto reset		
Geely	Emgrand (EV)	Auto reset		
Geely	Emgrand (EV300)	Auto reset		
Geely	Emgrand (EV450)	Auto reset		
Geely	Emgrand (GL PHEV)	Auto reset	-2019	
Geely	Emgrand (GL PHEV)	Auto reset	2019-	

Geely	Emgrand (GSe)	Auto reset		
Geely	Emgrand (GSE-battery version)	Auto reset		
Geely	New Emgrand (EV450)	Auto reset		
Geely	New Emgrand (PHEV)	Auto reset		
Geely	Emgrand (GL PHEV)	Auto reset	-2019	
Geely	Emgrand (GL PHEV)	Auto reset	2019-	
Geely	Ji He A	Auto reset		
Geely	Ji He C	Auto reset		
Geely	Xing yue (PHEV)	Auto reset		
Geely	ICON	Auto reset		
Geely	Emgrand (GL)	Manual reset		
Geely	New VISION X6	Manual reset		
Geely	EmgrandEC7	Manual reset		
Geely	VISION X6	Manual reset	2016/2018	
Geely	GX7/GX9	Manual reset		
Geely	Emgrand (Million)	Manual reset		
Geely	Jia Ji	Manual reset		
Geely	Bin Yue	Manual reset		
JETOUR	X70	Auto reset		
JETOUR	X70 Coupe	Auto reset		
JETOUR	X70 Plus	Auto reset		
JETOUR	X70S	Auto reset		
JETOUR	X90S	Auto reset		
JETOUR	X95	Auto reset		
JETOUR	X70	Manual reset	2018	
JMC	S350	Auto reset		
JMC	WeiLong	Auto reset		
JMC	Transit	Manual reset		
JMC	X5	Manual reset		

JMC	X5 PLUS	Manual reset		
JMC	X7	Manual reset		Type 1
JMC	X7	Manual reset		Type 2
JAC	A60	Manual reset		
JAC	M3	Manual reset		
JAC	M4	Manual reset		Type 1
JAC	M4	Manual reset		Type 2
JAC	M5	Manual reset		
JAC	S2	Manual reset		
JAC	S3	Manual reset		
JAC	S5	Manual reset		
JAC	Heyue	Manual reset		
JAC	Yue Yue	Manual reset		
JAC	Jiayue A5	Manual reset		
JAC	Jiayue X4	Manual reset		
JAC	Jiayue X7	Manual reset		
JAC	Si Hao A5	Manual reset		
JAC	Si Hao X4	Manual reset		
JAC	Si Hao X7	Manual reset		
JAC	Si Hao X8	Manual reset		
JAC	Other	Manual reset		
JunMa	A40 (S70)	Auto reset		
JunMa	S301 (MEET3)	Auto reset		
JunMa	A40 (S70)	Manual reset		
JunMa	D50 (SEEK5)	Manual reset		
COWIN	showjet	Auto reset		
COWIN	C3/C3R	Auto reset		
COWIN	V3 (MC22)	Auto reset		
COWIN	X3 (XC51)	Manual reset		

COWIN	S32 EV	Auto reset		
COWIN	E3	Auto reset		
COWIN	X5	Auto reset		
LiFan	X80	Auto reset		
Suzuki	Vitara	Auto reset		
Suzuki	S-cross	Auto reset	2016-	
Suzuki	S-cross	Manual reset		
Suzuki	Xiao tu	Manual reset		
Suzuki	New Alto	Manual reset	2013-	
Suzuki	SX4	Manual reset	2013-	
Suzuki	Vitra	Manual reset		
Suzuki	Vitra XL-7	Manual reset	2007-2009	
Suzuki	Grand Vitara	Manual reset	2013	
Suzuki	SPlash	Manual reset	2008-2011	
Suzuki	DF40	Manual reset		
LYNK&CO	01/02/03/05	Auto reset		
LYNK&CO	06	Auto reset		
LYNK&CO		Manual reset		
MG	Auto recognition	Auto reset		
MG	CN6	Auto reset		
MG	GS	Auto reset		
MG	GS (EU)	Auto reset		
MG	New GS	Auto reset		
MG	GT (1. 5L/1. 4T)	Auto reset		
MG	HS	Auto reset	2019-	
MG	MG3	Auto reset		
MG	MG3 EU	Auto reset		
MG	MG3 Zero	Auto reset		
MG	MG3 Zero	Auto reset	2013	

MG	MG5	Auto reset		AP12
MG	MG5	Auto reset		AP13
MG	MG6	Auto reset		
MG	MG6	Auto reset	2013	
MG	MG6	Auto reset	2014	
MG	MG6-EU	Auto reset		
MG	MG6 TT	Auto reset		
MG	New MG6	Auto reset		
MG	MG7	Auto reset		Type 1
MG	MG7	Auto reset		Type 2
MG	MG7-L	Auto reset		
MG	MG7 750	Auto reset		
MG	MGTF	Auto reset		
MG	eZS	Auto reset		
MG	ZS (ZS11)	Auto reset		
MG	ZS (ZS12)	Auto reset		
MG		Manual reset		
NAVECO	NAVECO	Auto reset		
NAVECO	Yue Jin	Auto reset		
NAVECO	Chao Yue	Auto reset		
Luxgen		Manual reset		Type 1
Luxgen		Manual reset		Type 2
CHERY	Auto recognition	Auto reset		
CHERY	A1	Auto reset		ATECH
CHERY	A1	Auto reset		AMT Series
CHERY	A2	Auto reset		
CHERY	A3	Auto reset		
CHERY	A5/Cowin 3	Auto reset		ATECH
CHERY	A16	Auto reset		

CHERY	A19	Auto reset		
CHERY	E3	Auto reset		
CHERY	E5	Auto reset		
CHERY	QQ6/Cowin 1	Auto reset		ATECH
CHERY	QQ6/Cowin 1	Auto reset		AMT Series
CHERY	QQME	Auto reset		
CHERY	New QQ	Auto reset		
CHERY	Eastar/Cowin 5	Auto reset		
CHERY	Eastar cross	Auto reset		
CHERY	New Eastar	Auto reset		
CHERY	Fulwin 2	Auto reset		Type 1
CHERY	Fulwin 2	Auto reset		Type 2
CHERY	Tiggo 3/Tiggo Facelift	Auto reset		1.8 AMT
CHERY	Tiggo 3/Tiggo Facelift	Auto reset		1.6 VVT
CHERY	Tiggo 3X	Auto reset		
CHERY	Tiggo 5	Auto reset		
CHERY	Tiggo 5X	Auto reset		
CHERY	Tiggo 7	Auto reset		
CHERY	New Tiggo 7	Auto reset		
CHERY	Tiggo 8	Auto reset		
CHERY	Arrizo 3	Auto reset		
CHERY	Arrizo 5	Auto reset		
CHERY	Arrizo 7	Auto reset		
CHERY	Arrizo 7E	Auto reset		
CHERY	Arrizo 8	Auto reset		
CHERY	Arrizo M7	Auto reset		
CHERY	Arrizo EX/GX	Auto reset		
CHERY	M1	Auto reset		
CHERY	M2	Auto reset		

CHERY	M3	Auto reset		
CHERY	M5	Auto reset		
CHERY	X1	Auto reset		
CHERY	G2	Auto reset		
CHERY	G3	Auto reset		
CHERY	G6	Auto reset		
CHERY	H3	Auto reset		
CHERY	H5	Auto reset		
CHERY	V5	Auto reset		KWP
CHERY	V5	Auto reset		CAN
CHERY	V8	Auto reset		
CHERY	X5	Auto reset		
CHERY	Dolphin EV	Auto reset		
CHERY	V2	Auto reset		
CHERY	S22	Auto reset		
CHERY	K60 (KM23)	Auto reset		
CHERY	K60 1.5T	Auto reset		
CHERY	K60 2018	Auto reset		
CHERY	K50S (Q26FL)	Auto reset		
CHERY	QQ3	Auto reset		
CHERY	S18	Auto reset		
CHERY	eQ	Auto reset		
CHERY	eQ1 (S51EV)	Auto reset		
CHERY	eQ5	Auto reset		
CHERY	S32EV	Auto reset		
CHERY	Arrizo E	Auto reset		
CHERY	Arrizo 5E	Auto reset		
CHERY	Tiggo 3xe	Auto reset		
CHERY	Tiggo E	Auto reset		

CHERY	A1	Manual reset		
CHERY	B11	Manual reset		
CHERY	S21-QQ6	Manual reset		
CHERY	S11-QQ3	Manual reset		
CHERY	S16-QQme	Manual reset		
CHERY	S12-A1	Manual reset		
CHERY	T11-Tiggo	Manual reset		Type 1
CHERY	T11-Tiggo	Manual reset		Type 2
CHERY	A15-Cowin 2	Manual reset		
CHERY	A21-A5/Cowin 3	Manual reset		
CHERY	M11-A3	Manual reset		
CHERY	M12-A3	Manual reset		
CHERY	A13	Manual reset		
CHERY	J15	Manual reset		
CHERY	S22L	Manual reset		
CHERY	A18	Manual reset		
CHERY	Q26 (K50)	Manual reset		
ROEWE	Auto recognition	Auto reset		
ROEWE	350	Auto reset		
ROEWE	360 (1.4T)	Auto reset		
ROEWE	360 (1.5VCT/1.5T)	Auto reset		
ROEWE	550	Auto reset		
ROEWE	New 550	Auto reset		
ROEWE	750	Auto reset	-2010	
ROEWE	750	Auto reset	2010-	
ROEWE	New 750	Auto reset		
ROEWE	950	Auto reset		
ROEWE	i5	Auto reset		
ROEWE	i6 (IP31)	Auto reset		

ROEWE	RX3	Auto reset		
ROEWE	RX5	Auto reset		
ROEWE	E50	Auto reset		
ROEWE	Ei6(IP34)	Auto reset		Type 1
ROEWE	Ei6(IP34)	Auto reset		Type 2
ROEWE	New 550 HYBRID	Auto reset		
ROEWE	New 750 HYBRID	Auto reset		
ROEWE	E950	Manual reset		
ROEWE	Other	Manual reset		
Rover	75	Manual reset	1999-2005	
Rover	75	Manual reset	2002	
MAXUS	D60	Auto reset		
MAXUS	D90	Auto reset		
MAXUS	G50	Auto reset		
MAXUS	G10	Auto reset		Type 1
MAXUS	G10	Auto reset		Type 2
MAXUS	G10	Manual reset		
MAXUS	G20	Auto reset		
MAXUS	T60	Auto reset		
MAXUS	T70	Auto reset		
MAXUS	V80(2018-)	Auto reset		
MAXUS	V90	Auto reset		
MAXUS	EXTENDER	Auto reset		
MAXUS	EG10	Auto reset		
MAXUS	EG50	Auto reset		
MAXUS	EV30	Auto reset		
MAXUS	EV90	Auto reset		
MAXUS	EV30 OVERSEAS	Auto reset		
MAXUS	EUNIQ5 (EV)	Auto reset		

MAXUS	EUNIQ5 PLUS-IN (PHEV)	Auto reset		
MAXUS	EUNIQ6 (EV)	Auto reset		
MAXUS	EUNIQ6 PLUS-IN (PHEV)	Auto reset		
MAXUS		Manual reset		
SWM	X7	Manual reset		
TJFAW	A70	Auto reset		
TJFAW	D80	Auto reset		
EXEED	LX	Auto reset		
Yema	T70	Auto reset		
Yema	T70S	Auto reset		
Yema	T80	Auto reset		
Yema	SPICA	Auto reset		
Yema	Bo Jun	Auto reset		
Yema	E70/T70EV	Auto reset		
Yema	EC30	Auto reset		
FAW	B30	Auto reset		
FAW	B90	Auto reset		
FAW	X40	Auto reset	-2019	Type 1
FAW	X40	Auto reset	-2019	Type 2
FAW	X40	Auto reset	2019-	Type 1
FAW	X40	Auto reset	2019-	Type 2
FAW	X80	Auto reset		
FAW	T33	Auto reset		
FAW	T77	Auto reset		
FAW	T99	Auto reset		
FAW	B50	Manual reset		Type 1
FAW	B50	Manual reset		Type 2
FAW	New B50	Manual reset		Type 1
FAW	B90	Manual reset		Type 1

FAW	B90	Manual reset		Type 2
FAW	X80	Manual reset		Type 1
FAW	X80	Manual reset		Type 2
FAW	X80	Manual reset		Type 3
FAW	T77	Manual reset		Type 1
FAW	T99	Manual reset	2019	
FAW	X40	Manual reset		Type 1
Faw HongQI	H5	Auto reset		
Faw HongQI	H7	Auto reset		
Faw HongQI	HS3	Auto reset		
Faw HongQI	HS5	Auto reset		
Faw HongQI	HS7	Auto reset		
Faw HongQI	H9	Auto reset		
Faw Daihatsu	R7	Auto reset		
Faw Daihatsu	R9	Auto reset		
ZOTYE	E20	Auto reset		
ZOTYE	G60	Auto reset		
ZOTYE	G60E	Auto reset		
ZOTYE	G60S	Auto reset		
ZOTYE	G70S	Auto reset		
ZOTYE	X5	Auto reset		
ZOTYE	X7	Auto reset		
ZOTYE	E30	Auto reset		
ZOTYE	SR7	Auto reset	-2017	
ZOTYE	SR7	Auto reset	2017-	
ZOTYE	SR9	Auto reset		
ZOTYE	L10	Auto reset		
ZOTYE	T300	Auto reset		
ZOTYE	T500	Auto reset		

ZOTYE	T600	Auto reset		
ZOTYE	T600 COUPE	Auto reset		
ZOTYE	T600	Auto reset		
ZOTYE	New T600	Auto reset	2019	
ZOTYE	T700	Auto reset		
ZOTYE	T800	Auto reset		
ZOTYE	Z100	Auto reset		
ZOTYE	Z200	Auto reset		
ZOTYE	Z300	Auto reset		
ZOTYE	Z360	Auto reset		
ZOTYE	Z500	Auto reset		
ZOTYE	Z560	Auto reset		
ZOTYE	Z700	Auto reset		
ZOTYE	A16	Auto reset		
ZOTYE	B21	Auto reset		
ZOTYE	M300	Auto reset		
ZOTYE	Han long	Auto reset		
ZOTYE	SR7 EV	Auto reset		
ZOTYE	T300EV	Auto reset		
ZOTYE	Z500 EV	Auto reset		
ZOTYE	T200	Manual reset		
ZOTYE	T300	Manual reset		
ZOTYE	T600	Manual reset		
ZOTYE	SR7	Manual reset		
ZOTYE	SR9	Manual reset		
ZOTYE	Z100	Manual reset		
ZOTYE	Z300	Manual reset		Type 1
ZOTYE	Z300	Manual reset		Type 2
ZOTYE	Z500	Manual reset		

ZOTYE	X5	Manual reset		
ZOTYE	X7	Manual reset		
ZOTYE	LangLang	Manual reset		
ZhengZhou Nissan	A17C	Auto reset		
ZhengZhou Nissan	Rui qi6	Auto reset		
ZhengZhou Nissan	Rui qi6 EV	Auto reset		
ZhengZhou Nissan	MX5	Manual reset		
ZhengZhou Nissan	MX6	Manual reset		
ZhengZhou Nissan	NV200	Manual reset	2017	
ZXAUTO	Lord	Manual reset		

XTOOL