

Captur/kaptur br/in/ru	Multimedia interface	✓	✓		✓	✓	✓	001, 00D, 00B, 196, 214
Captur/kaptur br/in/ru	HANDS-FREE MODULE	✓	✓	✓	✓	✓	✓	00C, 00D, 00F, 128, 12F, 130, 131, 132, 133, 134, 135, 136, 137, 138, 139, 13A, 13B
Clio II ph6	Engine System	✓	✓	✓	✓	✓	✓	001, 00C, 00D, 06D, 0C4, 0C5, 0D9, 0DA, 0DB, 0DC, 10C
Clio II ph6	ABS	✓	✓	✓	✓	✓	✓	00C, 00D, 019, 08B
Clio II ph6	UCH	✓	✓	✓	✓	✓	✓	00C, 00D, 005, 183
Clio II ph6	Airbag/pretenioners	✓	✓	✓	✓	✓	✓	00C, 00D, 022, 023, 02E, 037, 141, 142, 143, 144, 145, 146
Clio II ph6	TRACKER	✓	✓	✓	✓	✓	✓	001, 1EE
Clio II	Engine System	✓	✓		✓	✓	✓	001, 002, 004, 009, 00A, 00B, 052, 06B, 06C, 0C4, 0CE, 0CF, 18D, 257, 258, 276, 277, 291, 292, 293, 294, 295, 296, 297, 2A1, 2DF, 2E0, 2E1, 2E2
Clio II	ABS	✓	✓		✓	✓	✓	019, 08B
Clio II	UCH	✓	✓		✓	✓	✓	00E, 127, 183, 261, 27E, 27F, 280, 281, 282, 284, 285, 286, 287, 288, 28E, 2BF, 2C0, 2C1, 2C2, 2C3, 2C4, 2C5, 2C6, 2C7, 2C8, 2C9, 2CA, 2CB
Clio II	Airbag/pretenioners	✓	✓		✓	✓	✓	019, 01F, 263, 264
Clio II	Air conditioning	✓	✓		✓	✓	✓	019, 2E6, 2E7, 2E8, 2E9, 2EA, 2EB, 2EC, 2ED, 2EE, 2EF, 2F0, 2F1, 2F2, 2F3, 2F4, 2F5, 2F6, 2F7
Clio II	Automatic gearbox	✓	✓		✓	✓	✓	018, 01A, 01B, 01F, 04E, 082, 099, 09A, 09B, 09C, 275, 276, 277, 278, 279, 27A, 27B, 27C
Clio II	GAS Injection	✓	✓		✓	✓	✓	
Clio III	Engine System	✓	✓	✓	✓	✓	✓	001, 002, 003, 004, 005, 006, 007, 008, 009, 00A, 00B, 00C, 00D, 06D, 0C4, 0C5, 0C7, 0D0, 0D9, 0DA, 0DB, 0DC, 0DD, 0F3, 0F7, 0F9, 0FA, 10B, 186, 187, 189, 18A, 20D, 237, 256
Clio III	ABS	✓	✓	✓	✓	✓	✓	00C, 00D, 014, 015, 016, 017, 019, 088, 08B, 1C0
Clio III	Instrument panel	✓	✓		✓	✓	✓	00C, 00D, 048, 049, 04A, 04B, 04C, 04D, 04E, 04F, 050, 052, 053, 064, 070, 071, 072, 073, 074, 075, 077, 079, 07C, 07D, 0AB, 0AC, 0AD, 0AE, 0AF, 0E1, 149, 15E, 15F, 160, 162, 163, 164, 165, 166, 1F1, 1F2, 1F3, 1F4
Clio III	UCH	✓	✓		✓	✓	✓	00C, 00D, 00F, 010, 052, 059, 05A, 05B, 05C, 05D, 05E, 05F, 061, 0B1, 0B7, 0C3, 0C6, 22E
Clio III	Airbag/pretenioners	✓	✓	✓	✓	✓	✓	00C, 00D, 019, 022, 023, 024, 025, 026, 027, 02A, 02B, 02C, 02D, 02E, 02F, 032, 033, 034, 036, 037, 062, 063, 092, 093, 094, 095
Clio III	Air conditioning	✓	✓		✓	✓	✓	00C, 00D, 012, 013, 069
Clio III	Automatic gearbox	✓	✓	✓	✓	✓	✓	004, 00C, 00D, 019, 01A, 01B, 081, 082, 153, 156, 157, 1C8, 1C9, 1CA
Clio III	Communications unit	✓	✓		✓	✓	✓	00C, 00D, 019, 04C, 06A, 181, 182, 1CF, 1DF
Clio III	Variable PAS	✓	✓	✓	✓	✓	✓	00C, 00D, 01E, 01F
Clio III	LPC	✓	✓	✓	✓	✓	✓	001, 00D
Clio III	Tyres	✓	✓		✓	✓	✓	00C, 00D, 012
Clio III	Lighting	✓	✓	✓	✓	✓	✓	00C, 00D, 012, 08C, 08D, 08E, 08F, 090, 091
Clio III	Parking assistance	✓	✓	✓	✓	✓	✓	00C, 00D, 065, 066, 067
Clio III	Radio	✓	✓		✓	✓	✓	001, 00D, 01F
Clio III	Multimedia interface	✓	✓	✓	✓	✓	✓	001, 00D, 012, 055, 19C, 19D, 1C1
Clio III	Multimed. connection	✓	✓	✓	✓	✓	✓	00C, 00D, 019, 181
Clio IV	Engine System	✓	✓	✓	✓	✓	✓	001, 002, 003, 004, 005, 006, 007, 008, 009, 00C, 06D, 0C5, 0D0, 0D9, 0DA, 0DB, 0DC, 0DD, 0DF, 0E0, 0F3, 0F7, 0F8, 0F9, 0FA, 0FB, 0FC, 0FD, 0FF, 100, 101, 103, 104, 105, 106, 107, 108, 109, 10A, 10B, 10C, 114, 115, 116, 117, 13C, 13D, 14C, 17D, 186, 1EF, 1F0, 1FF, 200, 201, 202, 203, 20D, 20E, 20F, 210, 211, 212, 213

Clio IV	ABS	✓	✓	✓	✓	✓	✓	00C, 00D, 019, 08B, 0E9, 0EA, 0EB, 0EC, 0ED, 0EE, 0F0
Clio IV	Instrument panel	✓	✓	✓	✓	✓	✓	00C, 00D, 04C, 04F, 074, 079, 0E2
Clio IV	UCH	✓	✓	✓	✓	✓	✓	00C, 010, 0F6, 105, 108, 129, 12B, 139
Clio IV	Airbag/pretenioners	✓	✓	✓	✓	✓	✓	00C, 00D, 022, 023
Clio IV	Air conditioning	✓	✓	✓	✓	✓	✓	00C, 00D, 0D1, 0F4
Clio IV	Automatic gearbox	✓	✓	✓	✓	✓	✓	00C, 00D, 0EC, 111, 153, 154, 155, 156, 158, 159, 15A, 15B, 15C, 1C4, 21A
Clio IV	Communications unit	✓	✓	✓	✓	✓	✓	00C, 00D, 04C, 06F, 07A, 0D7
Clio IV	Variable PAS	✓	✓	✓	✓	✓	✓	00C, 00D
Clio IV	UPC	✓	✓	✓	✓	✓	✓	00D, 0E2, 105, 118, 11B, 123
Clio IV	Lighting	✓	✓	✓	✓	✓	✓	
Clio IV	Parking prox can	✓	✓	✓	✓	✓	✓	00C, 00D, 065, 067, 124, 125, 126
Clio IV	Radio	✓	✓	✓	✓	✓	✓	001, 00C, 00D, 01F, 06F, 0D7, 1F7, 1FC
Clio IV	Telematic ctrl unit	✓	✓	✓	✓	✓	✓	00C, 00D, 0D2
Clio IV	Multimedia interface	✓	✓	✓	✓	✓	✓	001, 00D, 0D8, 196, 214
Clio IV	Amplifier	✓	✓	✓	✓	✓	✓	00C, 00D, 181
Clio IV	HANDS-FREE MODULE	✓	✓	✓	✓	✓	✓	00C, 00D, 0F5, 128, 12F, 130, 131, 132, 133, 134, 135, 136, 137, 138, 139, 13A, 13B
Clio v6 ph2	Engine System	✓	✓	✓	✓	✓	✓	0C4
Clio v6 ph2	UCH	✓	✓	✓	✓	✓	✓	00E
Clio v6 ph2	Airbag/pretenioners	✓	✓	✓	✓	✓	✓	024, 025, 026, 027, 02A, 02B, 02C, 02D, 02E, 062, 063, 145, 146, 26D, 26E, 26F
Clio v6 ph2	Air conditioning	✓	✓	✓	✓	✓	✓	
Clio v6	Engine System	✓	✓	✓	✓	✓	✓	0C4
Clio v6	UCH	✓	✓	✓	✓	✓	✓	284, 285, 286, 287, 2BE, 2BF, 2C0, 2C1, 2C2, 2C3, 2C4, 2C5, 2C6, 2C7, 2C8, 2C9, 2CA, 2CB
Clio v6	Airbag/pretenioners	✓	✓	✓	✓	✓	✓	019
Clio v6	Air conditioning	✓	✓	✓	✓	✓	✓	2E8, 2E9, 2EA, 2EB, 2EC, 2ED, 2EE, 2EF, 2F0, 2F1, 2F2, 2F3, 2F6, 2F7
ClioIp2/3/4	Engine System	✓	✓	✓	✓	✓	✓	001, 002, 004, 009, 00A, 00B, 052, 0C4, 0CE, 0CF, 18D, 257, 258, 2A1
ClioIp2/3/4	ABS	✓	✓	✓	✓	✓	✓	019, 08B
ClioIp2/3/4	UCH	✓	✓	✓	✓	✓	✓	00E
ClioIp2/3/4	Airbag/pretenioners	✓	✓	✓	✓	✓	✓	024, 025, 026, 027, 02A, 02B, 02C, 02D, 02E, 062, 063, 145, 146, 26D, 26E, 26F
ClioIp2/3/4	Air conditioning	✓	✓	✓	✓	✓	✓	
ClioIp2/3/4	Automatic gearbox	✓	✓	✓	✓	✓	✓	004, 018, 01A, 01B, 01F, 04E, 081, 082, 099, 09A, 09B, 09C, 153, 1C8, 27A, 27B, 27C
ClioIp2/3/4	GAS Injection	✓	✓	✓	✓	✓	✓	
ClioIp2/3/4	Variable PAS	✓	✓	✓	✓	✓	✓	019, 01C
ClioIp2/3/4	Lighting	✓	✓	✓	✓	✓	✓	
ClioIp2/3/4	Discharge Lamp	✓	✓	✓	✓	✓	✓	
Dokker/kangoo	Engine System	✓	✓	✓	✓	✓	✓	001, 002, 004, 009, 06D, 0C5, 0D0, 0D9, 0DA, 0DB, 0DC, 0DD, 0E0, 0F3, 0F7, 0F8, 0F9, 0FA, 0FB, 0FC, 0FD, 0FF, 101, 103, 105, 108, 109, 10A, 10B, 10C, 114, 115, 116, 117, 13C, 13D, 14C, 186, 1EF, 1F0, 1FF, 200, 201, 202, 203
Dokker/kangoo	ABS	✓	✓	✓	✓	✓	✓	00C, 00D, 019, 08B, 0E9, 0EA, 0EB, 0ED, 0F0
Dokker/kangoo	Instrument panel	✓	✓	✓	✓	✓	✓	00C, 00D, 04C, 04F, 052, 072, 074, 0E1, 0E2, 14B, 164
Dokker/kangoo	UCH	✓	✓	✓	✓	✓	✓	00C, 010, 0F6, 105, 108, 129, 12B, 139
Dokker/kangoo	Airbag/pretenioners	✓	✓	✓	✓	✓	✓	00C, 00D, 022, 023
Dokker/kangoo	Variable PAS	✓	✓	✓	✓	✓	✓	00C, 00D, 01F
Dokker/kangoo	Radio	✓	✓	✓	✓	✓	✓	001, 00C, 00D, 01F, 06F, 0D7, 1FC
Dokker/kangoo	Telematic ctrl unit	✓	✓	✓	✓	✓	✓	00C, 00D, 0D2
Dokker/kangoo	Multimedia interface	✓	✓	✓	✓	✓	✓	001, 00D, 0D8, 196, 214
Dokker/kangoo	HANDS-FREE MODULE	✓	✓	✓	✓	✓	✓	00C, 00D, 0F5, 128, 12F, 130, 131, 132, 133, 134, 135, 136, 137, 138, 139, 13A, 13B
Duster ph2	Engine System	✓	✓	✓	✓	✓	✓	001, 002, 003, 004, 005, 006, 007, 008, 009, 00C, 06D, 0C5, 0D0, 0D9, 0DA, 0DB, 0DC, 0DD, 0F3, 0F5, 0F7, 0F8, 0F9, 0FA, 0FB, 0FC, 0FD, 0FF, 100, 101, 103, 104, 105, 106, 107, 108, 109, 10A, 10B, 10C, 114, 115, 116, 117, 13C, 13D, 14C, 17D, 186, 1EF, 1F0, 1F5, 1F6, 20D, 20E, 20F, 210, 211

Duster ph2	ABS	✓	✓	✓	✓	✓	✓	00C, 00D, 019, 08B, 0E9, 0EA, 0EB, 0EC, 0ED, 0EE, 0F0
Duster ph2	Instrument panel							
Duster ph2	UCH	✓	✓	✓	✓	✓	✓	00C, 010, 0F6, 105, 108, 129, 12B, 139
Duster ph2	Airbag/pretensioners	✓	✓	✓	✓	✓	✓	00C, 00D, 022, 023
Duster ph2	Air conditioning	✓	✓	✓	✓	✓	✓	00C, 00D, 069, 0D1
Duster ph2	Automatic gearbox	✓	✓	✓	✓	✓	✓	
Duster ph2	Variable PAS	✓	✓	✓	✓	✓	✓	00C, 00D, 01F
Duster ph2	4 wheels drive	✓	✓	✓	✓	✓	✓	00C, 00D, 012, 08B, 0E2, 1C5
Duster ph2	Radio	✓	✓	✓	✓	✓	✓	001, 00C, 00D, 01F, 06F, 0D7, 1FC
Duster ph2	Telematic ctrl unit	✓	✓	✓	✓	✓	✓	00C, 00D, 002
Duster ph2	Multimedia interface	✓	✓	✓	✓	✓	✓	001, 00D, 0D8, 196, 214
Duster ph2	HANDS-FREE MODULE	✓	✓	✓	✓	✓	✓	00C, 00D, 0F5, 128, 12F, 130, 131, 132, 133, 134, 135, 136, 137, 138, 139, 13A, 13B
Duster	Engine System	✓	✓	✓	✓	✓	✓	001, 002, 003, 005, 006, 007, 008, 009, 00B, 00C, 00D, 06D, 0C4, 0C5, 0C7, 0D0, 0D9, 0DA, 0DB, 0DC, 0DD, 0F3, 0F7, 0F9, 0FA, 10B, 10C, 186, 187, 20D, 256
Duster	ABS	✓	✓	✓	✓	✓	✓	00C, 00D, 019, 08B, 1B0
Duster	UCH	✓	✓	✓	✓	✓	✓	00C, 00D, 0D5, 183
Duster	Airbag/pretensioners	✓	✓	✓	✓	✓	✓	00C, 00D, 022, 023, 026, 027, 02E, 02F, 030, 031, 037, 07D, 141, 142, 143, 144, 199, 19A, 19B, 1AE, 1AF
Duster	Automatic gearbox	✓	✓	✓	✓	✓	✓	00C, 00D, 019, 01A, 01B, 082
Duster	Variable PAS	✓	✓	✓	✓	✓	✓	00C, 00D, 01F
Duster	TRACKER	✓	✓	✓	✓	✓	✓	001, 1EE
Duster	4 wheels drive	✓	✓	✓	✓	✓	✓	00C, 00D, 012, 08B, 0E2, 1C5
Duster	Radio	✓	✓	✓	✓	✓	✓	001, 00C, 00D, 01F, 05B, 06F, 0D7, 1F7
Espace IV	Engine System	✓	✓	✓	✓	✓	✓	002, 004, 009, 00A, 00B, 00C, 00D, 06B, 06C, 06D, 0C4, 0C7, 0CE, 0CF, 0D0, 0D9
Espace IV	ABS	✓	✓	✓	✓	✓	✓	00C, 00D, 014, 015, 017, 019, 052, 08B, 098, 0E9, 0EA, 0EB
Espace IV	Instrument panel	✓	✓	✓	✓	✓	✓	00C, 00D, 012, 04B, 04C, 04D, 04E, 04F, 050, 051, 052, 053, 074, 077, 079, 07A, 07B, 07C, 07E, 0A0, 0A1, 0A2, 0A3, 0A4, 0A7, 0A8, 0A9, 0AA, 147, 148, 149
Espace IV	UCH	✓	✓	✓	✓	✓	✓	00C, 00D, 010, 011, 012, 04D, 052, 05A, 05B, 05D, 061, 07C, 086, 083, 0B4, 0B5, 0B6, 0B7, 0B8, 0B9, 0BA, 0BB, 0BC, 0BD, 0BE, 0BF, 0C0, 0C1, 0C2, 227, 231, 232
Espace IV	Airbag/pretensioners	✓	✓	✓	✓	✓	✓	00C, 00D, 019, 022, 023, 037
Espace IV	Air conditioning	✓	✓	✓	✓	✓	✓	00C, 00D, 013, 05B, 069, 084, 085, 1A5, 222, 223, 224, 24B
Espace IV	Automatic gearbox	✓	✓	✓	✓	✓	✓	00D, 019, 081, 082, 233
Espace IV	Parking brake	✓	✓	✓	✓	✓	✓	00C, 00D, 055, 056, 057, 058
Espace IV	Hands-free kit	✓	✓	✓	✓	✓	✓	001, 00D, 019, 06E, 06F
Espace IV	Discharge Lamp	✓	✓	✓	✓	✓	✓	00C, 00D, 012, 01C
Espace IV	Parking assistance	✓	✓	✓	✓	✓	✓	00C, 00D, 065, 066, 067
Espace IV	HEATER	✓	✓	✓	✓	✓	✓	00C, 0CC, 0CD
Espace V	Engine System	✓	✓	✓	✓	✓	✓	001, 004, 005, 006, 007, 008, 009, 00C, 06D, 0C5, 0D9, 0DA, 0DB, 0DC, 0DD, 0F7, 0F8, 0F9, 0FA, 0FB, 0FC, 0FD, 0FE, 0FF, 100, 101, 102, 103, 104, 105, 106, 107, 108, 109, 10A, 10B, 150, 151
Espace V	ABS	✓	✓	✓	✓	✓	✓	00C, 00D, 01E, 08B, 0E9, 0EA, 0EB, 0EC, 0ED, 0EF, 0F0, 0F1, 0F2
Espace V	Instrument panel	✓	✓	✓	✓	✓	✓	00C, 00D, 04A, 04C, 04F, 074, 07A, 0E1, 0E2
Espace V	UCH	✓	✓	✓	✓	✓	✓	00B, 00C, 010, 05C, 0B5, 0F6, 127, 128, 129, 12A, 12B, 12C, 12D, 12E
Espace V	Airbag/pretensioners	✓	✓	✓	✓	✓	✓	00C, 00D, 022, 023, 037
Espace V	Front radar	✓	✓	✓	✓	✓	✓	00C, 00D
Espace V	Air conditioning	✓	✓	✓	✓	✓	✓	00C, 00D, 069, 0D1
Espace V	Automatic gearbox	✓	✓	✓	✓	✓	✓	00C, 00D, 13E, 13F, 140, 156, 158
Espace V	Parking brake	✓	✓	✓	✓	✓	✓	00C, 00D, 10D, 10E
Espace V	Variable PAS	✓	✓	✓	✓	✓	✓	00C, 00D
Espace V	UPC	✓	✓	✓	✓	✓	✓	00D, 0E2, 105, 108, 118, 11B, 14D, 14E
Espace V	Power back door	✓	✓	✓	✓	✓	✓	00C, 14F
Espace V	Head up display	✓	✓	✓	✓	✓	✓	009, 00C

Espace V	4 wheels steering	✓	✓	✓	✓	✓	✓	00D, 0E3, 0E4, 0E5
Espace V	Parking prox can	✓	✓		✓	✓	✓	00C, 00D, 065, 067, 124, 125, 126
Espace V	Gearbox elec control	✓	✓	✓	✓	✓	✓	00C, 00D, 152
Espace V	Piloted suspension	✓	✓	✓	✓	✓	✓	00C, 00D
Espace V	Driver's seat	✓	✓		✓	✓	✓	00C, 00D, 066, 0E7, 0E8
Espace V	Front camera	✓	✓		✓	✓	✓	00C, 00D, 01C
Espace V	Radio	✓	✓		✓	✓	✓	00C, 00D, 04C, 06F, 07A, 0A8, 0D6, 0D7, 0D8
Espace V	Telematic ctrl unit	✓	✓		✓	✓	✓	00C, 00D, 0D2
Espace V	Left-hand door or passenger	✓	✓		✓	✓	✓	00C, 00D, 0E6, 0E7, 0E8
Espace V	Right-hand door or collapse	✓	✓		✓	✓	✓	00C, 00D
Espace V	Multimedia interface	✓	✓		✓	✓	✓	00D, 06A
Espace V	Amplifier	✓	✓		✓	✓	✓	001, 00D, 0D3, 0D4
Espace	Engine System	✓	✓		✓	✓	✓	06B, 06C, 0C4, 0CE, 0CF, 0F7, 212, 257, 276, 277, 291, 292, 293, 294, 297, 298, 299, 29A, 29B, 29C, 29D, 29E, 29F, 2A6, 2A7, 2A8, 2E1, 2E2
Espace	ABS	✓	✓		✓	✓	✓	019, 08B
Espace	Instrument panel	✓	✓		✓	✓	✓	019, 291, 292, 2A9, 2AB, 2AE, 2AF, 2B2, 2B3, 2B8, 2B9, 2BC, 2BD, 2CD, 2CE, 2CF, 2D0, 2D1, 2D2, 2D4, 2D5, 2D6, 2D7, 2D8, 2D9, 2DA, 2DB, 2DC, 2DD
Espace	UCH	✓				✓	✓	27D, 27E, 27F, 282, 283, 284, 285, 286, 287, 2A9, 2AA, 2AB, 2AC, 2AD, 2AE, 2AF, 2B0, 2B1, 2B2, 2B3, 2B4, 2B5, 2B6, 2B7, 2B8, 2B9, 2BA, 2BB, 2BC, 2BD, 2DC, 2DD
Espace	Airbag/pretensioners	✓	✓		✓	✓	✓	019, 095, 26A, 26B, 26C
Espace	Air conditioning	✓	✓		✓	✓	✓	2FA, 2FB, 2FC, 2FD, 2FE, 2FF
Espace	Automatic gearbox	✓	✓		✓	✓	✓	018, 01A, 01B, 01F, 04E, 082, 099, 09A, 09B, 09C, 274, 275, 276, 277, 278, 279
Espace	Lighting	✓	✓		✓	✓	✓	
Espace	Discharge Lamp	✓	✓		✓	✓	✓	
Espace	HEATER	✓	✓		✓	✓	✓	
EspaceIV ph2/3/4	Engine System	✓	✓	✓	✓	✓	✓	001, 002, 004, 009, 00A, 00B, 00C, 00D, 06A, 06B, 06C, 06D, 0C4, 0C5, 0C7, 0CE, 0CF, 0D0, 0D9, 0DC, 0DD, 0F7, 0F8, 0F9, 0FA, 0FB, 0FF, 10A, 10B, 186, 22F, 230
EspaceIV ph2/3/4	ABS	✓	✓	✓	✓	✓	✓	00C, 00D, 014, 015, 017, 019, 052, 08B, 0E9, 0EA, 0EB
EspaceIV ph2/3/4	Instrument panel	✓	✓		✓	✓	✓	00C, 00D, 04B, 04C, 04D, 04E, 050, 052, 053, 074, 077, 079, 07A, 07C, 07E, 147, 148, 149, 14A, 14B
EspaceIV ph2/3/4	UCH	✓	✓	✓	✓	✓	✓	00C, 00D, 010, 012, 052, 05A, 05B, 05D, 061, 07C, 086, 0B3, 0B4, 0B5, 0B6, 0B7, 0B8, 0B9, 0BA, 0BB, 0BC, 0BD, 0BE, 0BF, 0C0, 0C1, 0C2, 231, 232
EspaceIV ph2/3/4	Airbag/pretensioners	✓	✓	✓	✓	✓	✓	00C, 00D, 019, 022, 023, 037
EspaceIV ph2/3/4	Air conditioning	✓	✓		✓	✓	✓	00C, 00D, 013, 05B, 069, 084, 085, 1A5, 222, 223, 224, 24B
EspaceIV ph2/3/4	Automatic gearbox	✓	✓	✓	✓	✓	✓	00D, 019, 081, 082, 154, 233
EspaceIV ph2/3/4	Communications unit	✓	✓		✓	✓	✓	001, 00C, 00D, 012, 019, 04C, 06A, 07F, 080, 181, 182, 1CF, 1DF
EspaceIV ph2/3/4	Parking brake	✓	✓	✓	✓	✓	✓	00C, 00D, 055, 056, 057, 058
EspaceIV ph2/3/4	Variable PAS	✓	✓	✓	✓	✓	✓	00C, 00D, 01C
EspaceIV ph2/3/4	Lighting	✓	✓	✓	✓	✓	✓	00C, 00D, 012, 05B, 08C, 08D, 08E, 090, 148, 234
EspaceIV ph2/3/4	Parking prox can	✓	✓	✓	✓	✓	✓	00C, 00D, 019, 065, 066, 067, 220, 221
EspaceIV ph2/3/4	Parking assistance	✓	✓	✓	✓	✓	✓	00C, 00D, 065, 066, 067
EspaceIV ph2/3/4	HEATER	✓	✓	✓	✓	✓	✓	00C, 0CC, 0CD
EspaceIV ph2/3/4	Radio	✓			✓	✓	✓	001, 00D, 01F, 04C, 236, 238
EspaceIV ph2/3/4	Multimedia interface	✓	✓	✓	✓	✓	✓	001, 00D, 012, 055, 06A
EspaceIV ph2/3/4	Multimed. connection	✓	✓	✓	✓	✓	✓	00C, 00D, 019, 181
Kadjar cn	Engine System	✓	✓	✓	✓	✓	✓	001, 009, 06D, 0C5, 0D9, 0DA, 0DB, 0DC, 0DD, 0F3, 0FB, 103, 105, 108, 109, 10A, 13C, 13D, 14C, 150, 151
Kadjar cn	ABS	✓	✓	✓	✓	✓	✓	00C, 00D, 019, 08B, 0E9, 0EA, 0EB, 0EC, 0ED, 0EE, 0F0
Kadjar cn	Instrument panel	✓	✓		✓	✓	✓	00C, 00D, 04A, 04C, 04F, 074, 07A, 0E1, 0E2

Kangoo MUX	Engine System	✓	✓		✓	✓	✓	001, 002, 004, 009, 00A, 00B, 052, 06B, 06C, 0C4, 0CE, 0CF, 0F7, 18D, 257, 258, 298, 299, 29A, 29B, 29C, 29D, 29E, 29F, 2A1
Kangoo MUX	ABS	✓	✓		✓	✓	✓	019, 01F, 08B
Kangoo MUX	UCH	✓	✓		✓	✓	✓	00E, 05D, 0B5, 127, 229
Kangoo MUX	Airbag/prentensioners	✓	✓		✓	✓	✓	01F
Kangoo MUX	Automatic gearbox	✓	✓		✓	✓	✓	018, 01A, 01B, 01F, 04E, 081, 082, 099, 09A, 09B, 09C, 27A, 27B, 27C
Kangoo MUX	GAS Injection	✓	✓		✓	✓	✓	
Kangoo VLL	Engine System	✓	✓	✓	✓	✓	✓	001, 002, 003, 005, 006, 007, 008, 009, 00B, 00C, 00D, 06D, 0C4, 0C5, 0D9, 0DA, 0DB, 0DC, 10C
Kangoo VLL	ABS	✓	✓	✓	✓	✓	✓	00C, 00D, 019, 08B
Kangoo VLL	UCH	✓	✓	✓	✓	✓	✓	00C, 00D, 0D5
Kangoo VLL	Airbag/prentensioners	✓	✓	✓	✓	✓	✓	00C, 00D, 019, 022, 023
Kangoo VLL	Variable PAS	✓	✓	✓	✓	✓	✓	00C, 00D, 01F
Kangoo VLL	TRACKER	✓	✓	✓	✓	✓	✓	001, 1EE
Kangoo ZE/StopStart/ph2	Engine System	✓	✓	✓	✓	✓	✓	001, 002, 004, 009, 00C, 06D, 0C5, 0D0, 0D9, 0DA, 0DB, 0DC, 0DD, 0E0, 0F3, 0F7, 0F8, 0F9, 0FA, 0FB, 0FC, 0FD, 0FF, 100, 101, 103, 105, 107, 108, 109, 10A, 10B, 114, 115, 116, 117, 13C, 13D, 14C, 186, 1EF, 1F0, 1FF, 200, 201, 202, 203
Kangoo ZE/StopStart/ph2	ABS	✓	✓	✓	✓	✓	✓	00C, 00D, 014, 015, 016, 017, 019, 08B, 0E9, 0EA, 0EB, 0EC, 0EE
Kangoo ZE/StopStart/ph2	Instrument panel	✓	✓	✓	✓	✓	✓	00C, 00D, 048, 049, 04B, 04C, 070, 071, 072, 074, 079, 0B6, 0E1, 149, 15E, 15F, 160, 166, 1E8, 1E9, 1EA, 1EB
Kangoo ZE/StopStart/ph2	UCH	✓	✓	✓	✓	✓	✓	00C, 1BE, 1BF
Kangoo ZE/StopStart/ph2	Airbag/prentensioners	✓	✓	✓	✓	✓	✓	00C, 00D, 022, 023, 02E, 037, 142, 143, 1D5, 1D6, 1D7, 1D8, 1D9, 1DA, 1DB, 1DC, 1DD, 1DE
Kangoo ZE/StopStart/ph2	Air conditioning	✓	✓	✓	✓	✓	✓	00C, 00D, 069, 0D1
Kangoo ZE/StopStart/ph2	Automatic gearbox	✓	✓	✓	✓	✓	✓	00C, 00D, 0EC, 111, 153, 154, 155, 156, 158, 159, 15A, 15B, 15C, 1C4, 21A
Kangoo ZE/StopStart/ph2	Communications unit	✓	✓	✓	✓	✓	✓	00C, 00D, 019, 04C, 06F, 07A, 0DT
Kangoo ZE/StopStart/ph2	Variable PAS	✓	✓	✓	✓	✓	✓	00C, 00D, 01E, 01F, 1A4
Kangoo ZE/StopStart/ph2	UPC	✓	✓		✓	✓	✓	001, 00D, 019, 0F4, 105, 114, 115, 116, 117, 118, 119, 11A, 11B, 11C, 11D, 11E, 11F, 120, 121, 122, 123, 1C4, 1EC, 1ED
Kangoo ZE/StopStart/ph2	Tyres	✓	✓	✓	✓	✓	✓	00C, 00D
Kangoo ZE/StopStart/ph2	ADAPTATION UNIT	✓	✓	✓	✓	✓	✓	00C
Kangoo ZE/StopStart/ph2	CHARGE CONTROLLER	✓	✓	✓	✓	✓	✓	00C, 00D
Kangoo ZE/StopStart/ph2	Parking prox can	✓	✓	✓	✓	✓	✓	00C, 00D, 065
Kangoo ZE/StopStart/ph2	Parking assistance	✓	✓	✓	✓	✓	✓	00C, 00D, 065, 067
Kangoo ZE/StopStart/ph2	HEATER	✓	✓	✓	✓	✓	✓	00C, 0CC, 0CD
Kangoo ZE/StopStart/ph2	Radio	✓	✓	✓	✓	✓	✓	001, 00C, 00D, 01F, 055, 06F, 0D7, 181, 194, 195, 1F7, 1FC
Kangoo ZE/StopStart/ph2	Telematic ctrl unit	✓	✓	✓	✓	✓	✓	00C, 00D, 0D2
Kangoo ZE/StopStart/ph2	Multimedia interface	✓	✓	✓	✓	✓	✓	001, 00D, 0D8, 196, 214
Kangoo ZE/StopStart/ph2	Multimed. connection	✓	✓	✓	✓	✓	✓	00C, 00D, 019, 06A
Kangoo ZE/StopStart/ph2	BCB	✓	✓	✓	✓	✓	✓	00C
Kangoo ZE/StopStart/ph2	BMS	✓	✓	✓	✓	✓	✓	00C, 180, 1D0, 1D1
Kangoo ZE/StopStart/ph2	EVC	✓	✓	✓	✓	✓	✓	00C, 0DD, 179, 17A, 1D0, 1E0, 1E1, 1E2
Kangoo ZE/StopStart/ph2	PEB	✓	✓	✓	✓	✓	✓	00C, 17B
Kangoo ZE/StopStart/ph2	BMS safety	✓	✓	✓	✓	✓	✓	00C, 17F
Kangoo	Engine System	✓	✓		✓	✓	✓	001, 002, 004, 009, 00A, 00B, 052, 06B, 06C, 0C4, 0CE, 0CF, 0F7, 18D, 257, 258, 276, 277, 291, 292, 293, 294, 295, 296, 297, 298, 299, 29A, 29B, 29C, 29D, 29E, 29F, 2A1, 2D0, 2E0, 2E1, 2E2, 2E5
Kangoo	ABS	✓	✓		✓	✓	✓	019, 01F, 08B
Kangoo	UCH	✓	✓		✓	✓	✓	27E, 27F, 282, 284, 285, 286, 287, 288, 28E, 28F, 2C0, 2C1
Kangoo	Airbag/prentensioners	✓	✓		✓	✓	✓	019, 01F, 022, 023, 265, 266, 267, 268, 269
Kangoo	Air conditioning	✓	✓		✓	✓	✓	019, 2F6, 2F7, 2E8, 2E9, 2EA, 2EB, 2EC, 2ED, 2EE, 2EF, 2F0, 2F1, 2F2, 2F3, 2F4, 2F5, 2F6, 2F7
Kangoo	Automatic gearbox	✓	✓		✓	✓	✓	018, 01A, 01B, 01F, 04E, 082, 099, 09A, 09B, 09C, 275, 276, 277, 278, 279, 27A, 27B, 27C
Kangoo	GAS Injection	✓	✓		✓	✓	✓	

Kangoo	Supervisor or DCDC	✓	✓		✓	✓	✓	01F, 23C, 270, 271, 272, 273
Kangoo	INVERTER	✓	✓		✓	✓	✓	
Kangoo	HEATER	✓	✓		✓	✓	✓	
Koleos II/QM6	Engine System	✓	✓	✓	✓	✓	✓	001, 004, 005, 006, 007, 008, 009, 00C, 06D, 0C5, 0D9, 0DA, 0DB, 0DC, 0DD, 0F7, 0F8, 0F9, 0FA, 0FB, 0FC, 0FD, 0FE, 0FF, 100, 101, 102, 103, 104, 105, 106, 107, 108, 109, 10A, 10B, 150, 151
Koleos II/QM6	ABS	✓	✓	✓	✓	✓	✓	00C, 00D, 019, 08B, 0E9, 0EA, 0EB, 0EC, 0ED, 0EE, 0FO
Koleos II/QM6	Instrument panel	✓	✓		✓	✓	✓	00C, 00D, 04A, 04C, 04F, 074, 07A, 0E1, 0E2
Koleos II/QM6	UCH	✓	✓	✓	✓	✓	✓	009, 00C, 010, 05C, 0B5, 0F6, 127, 128, 129, 12A, 12B, 12C, 12D, 12E
Koleos II/QM6	Airbag/pretenioners	✓	✓	✓	✓	✓	✓	00C, 00D, 022, 023, 037
Koleos II/QM6	Front radar	✓	✓		✓	✓	✓	00C, 00D
Koleos II/QM6	Air conditioning	✓	✓		✓	✓	✓	00C, 00D, 069, 0D1
Koleos II/QM6	Automatic gearbox	✓	✓	✓	✓	✓	✓	00C, 00D, 019, 154, 17C
Koleos II/QM6	Parking brake	✓	✓	✓	✓	✓	✓	00C, 00D, 10D, 10E
Koleos II/QM6	Variable PAS	✓	✓	✓	✓	✓	✓	00C, 00D
Koleos II/QM6	UPC	✓	✓	✓	✓	✓	✓	00D, 0E2, 105, 108, 118, 11B, 14D, 14E
Koleos II/QM6	Power back door	✓	✓		✓	✓	✓	00C, 14F
Koleos II/QM6	4 wheels drive	✓	✓		✓	✓	✓	00C
Koleos II/QM6	Parking prox can	✓	✓		✓	✓	✓	00C, 00D, 065, 067, 124, 125, 126
Koleos II/QM6	Driver's seat	✓	✓		✓	✓	✓	
Koleos II/QM6	Front camera	✓	✓		✓	✓	✓	00C, 01C
Koleos II/QM6	Radio	✓	✓		✓	✓	✓	00C, 00D, 04C, 06F, 07A, 0A8, 0D2, 0D6, 0D7, 0D8
Koleos II/QM6	Telematic ctrl unit	✓	✓		✓	✓	✓	00C, 00D, 0D2
Koleos II/QM6	Left-hand door or passenger	✓	✓		✓	✓	✓	
Koleos II/QM6	Multimedia interface	✓	✓		✓	✓	✓	00C, 00D, 06A, 0D2
Koleos II/QM6	Amplifier	✓	✓		✓	✓	✓	001, 00D, 0D3, 0D4
Koleos/QM5	Engine System	✓	✓	✓	✓	✓	✓	001, 004, 00D, 06A, 06D, 0C5, 0C7, 10B, 18D, 18E, 190, 191, 192, 249, 24A
Koleos/QM5	ABS	✓	✓		✓	✓	✓	00C
Koleos/QM5	Instrument panel	✓	✓		✓	✓	✓	00C, 04A, 04C, 04E, 04F, 074, 079, 07D, 0A4, 0B6, 0E1, 149, 165, 1B1, 1B2, 1B3, 1B4, 1B5, 1B6
Koleos/QM5	UCH	✓	✓	✓	✓	✓	✓	00C, 010, 011, 05A, 061, 07D, 0B4, 0B5, 0B9, 129, 228, 240, 241, 242, 243, 244, 245, 246
Koleos/QM5	Airbag/pretenioners	✓	✓		✓	✓	✓	00C
Koleos/QM5	Automatic gearbox	✓	✓		✓	✓	✓	00C, 24F
Koleos/QM5	Communications unit	✓	✓		✓	✓	✓	001, 00C, 00D, 012, 019, 04C, 06A, 181, 1C2, 1C3
Koleos/QM5	Parking brake	✓	✓	✓	✓	✓	✓	00C, 00D, 055, 057, 250, 251, 252, 253
Koleos/QM5	Blind spot detection	✓	✓	✓	✓	✓	✓	00C, 00D, 0F5
Koleos/QM5	Variable PAS	✓	✓	✓	✓	✓	✓	00C
Koleos/QM5	UPC	✓	✓		✓	✓	✓	001
Koleos/QM5	Tyres	✓	✓		✓	✓	✓	00C, 00D, 0F4, 0F5, 0F6
Koleos/QM5	4 wheels drive	✓	✓		✓	✓	✓	00C
Koleos/QM5	Parking prox can	✓	✓	✓	✓	✓	✓	00C, 00D, 019, 052, 065, 067, 220, 221, 248
Koleos/QM5	Auto front lighting	✓	✓		✓	✓	✓	00C, 23F
Koleos/QM5	Discharge Lamp	✓	✓		✓	✓	✓	00C, 08C, 1D4
Koleos/QM5	Radio	✓	✓	✓	✓	✓	✓	001, 00C, 00D, 01F, 04C, 05B, 0D7, 181, 194, 1F7, 247
Koleos/QM5	Telematic ctrl unit	✓	✓	✓	✓	✓	✓	00C, 00D, 0D2, 161
Koleos/QM5	Multimedia interface	✓	✓	✓	✓	✓	✓	001, 00D, 012, 055, 0D8, 196, 19C, 1C1
Koleos/QM5	Amplifier	✓	✓	✓	✓	✓	✓	001, 00D, 01F, 0D3, 161, 181
Koleos/QM5	Multimed. connection	✓	✓	✓	✓	✓	✓	00C, 00D, 019, 181
Kwid	Engine System	✓	✓	✓	✓	✓	✓	002, 00C, 06D, 0C5, 0D9, 0DA, 0DB, 0DC, 0DF, 178
Kwid	Instrument panel	✓	✓	✓	✓	✓	✓	00C, 00D, 072, 0E2, 15D
Kwid	UCH	✓	✓	✓	✓	✓	✓	00C
Kwid	Airbag/pretenioners	✓	✓	✓	✓	✓	✓	00C, 00D, 022, 023
Kwid	Variable PAS	✓	✓	✓	✓	✓	✓	00C, 00D
Kwid	Radio	✓	✓		✓	✓	✓	00C, 00D, 01F, 06F, 0D7
KoleosII CN/QM6 CN	Engine System	✓	✓		✓	✓	✓	001, 00A, 0D8, 105, 109, 10A, 150, 151
KoleosII CN/QM6 CN	ABS	✓	✓	✓	✓	✓	✓	00C, 00D, 019, 08B, 0E9, 0EA, 0EB, 0EC, 0ED, 0EE, 0FO
KoleosII CN/QM6 CN	Instrument panel	✓	✓		✓	✓	✓	00C, 00D, 04A, 04C, 04F, 074, 07A, 0E1, 0E2
KoleosII CN/QM6 CN	UCH	✓	✓	✓	✓	✓	✓	009, 00C, 010, 05C, 0B5, 0F6, 127, 128, 129, 12A, 12B, 12C, 12D, 12E
KoleosII CN/QM6 CN	Airbag/pretenioners	✓	✓	✓	✓	✓	✓	00C, 00D, 022, 023, 037
KoleosII CN/QM6 CN	Front radar	✓	✓		✓	✓	✓	00C, 00D
KoleosII CN/QM6 CN	Air conditioning	✓	✓		✓	✓	✓	00C, 00D, 069, 0D1
KoleosII CN/QM6 CN	Automatic gearbox	✓	✓	✓	✓	✓	✓	00C, 00D, 019, 154, 17C
KoleosII CN/QM6 CN	Parking brake	✓	✓	✓	✓	✓	✓	00C, 00D, 10D, 10E

KoleosII CN/QM6 CN	Variable PAS	✓	✓	✓	✓	✓	✓	00C, 00D
KoleosII CN/QM6 CN	UPC	✓	✓	✓	✓	✓	✓	00D, 0E2, 105, 108, 118, 11B, 14D, 14E
KoleosII CN/QM6 CN	Power back door	✓	✓	✓	✓	✓	✓	00C, 14F
KoleosII CN/QM6 CN	4 wheels drive	✓	✓	✓	✓	✓	✓	00C
KoleosII CN/QM6 CN	Parking prox can	✓	✓	✓	✓	✓	✓	00C, 00D, 065, 067, 124, 125, 126
KoleosII CN/QM6 CN	Driver's seat	✓	✓	✓	✓	✓	✓	
KoleosII CN/QM6 CN	Front camera	✓	✓	✓	✓	✓	✓	00C, 01C
KoleosII CN/QM6 CN	Radio	✓	✓	✓	✓	✓	✓	00C, 00D, 04C, 06F, 07A, 0A8, 0D2, 0D6, 0D7, 0D8
KoleosII CN/QM6 CN	Telematic ctrl unit	✓	✓	✓	✓	✓	✓	00C, 00D, 0D2
KoleosII CN/QM6 CN	Left-hand door or passenger	✓	✓	✓	✓	✓	✓	
KoleosII CN/QM6 CN	Multimedia interface	✓	✓	✓	✓	✓	✓	00C, 00D, 06A, 0D2
KoleosII CN/QM6 CN	Amplifier	✓	✓	✓	✓	✓	✓	001, 00D, 0D3, 0D4
Laguna II	Engine System	✓	✓	✓	✓	✓	✓	002, 004, 009, 00C, 00D, 06B, 06C, 06D, 0C4, 0C7, 0CE, 0CF, 0D9
Laguna II	ABS	✓	✓	✓	✓	✓	✓	00C, 00D, 017, 019, 03B, 098
Laguna II	Instrument panel	✓	✓	✓	✓	✓	✓	00C, 00D, 012, 048, 049, 04B, 04C, 04D, 04E, 050, 051, 052, 053, 064, 070, 071, 072, 073, 074, 075, 076, 077, 078, 079, 07A, 07B, 07C, 07D, 07E, 09D, 09E, 09F, 0A0, 0A1, 0A2, 0A3, 0A4
Laguna II	UCH	✓	✓	✓	✓	✓	✓	00C, 00D, 010, 011, 04D, 052, 05A, 05B, 07C, 086, 0A5, 0B3, 0B4, 0B5, 0B6, 0B8, 0BA, 0BB, 0BF, 0C0, 1A7, 1D2, 21F, 225, 226, 227, 228, 229, 22A, 22B, 22C
Laguna II	Airbag/pretensioners	✓	✓	✓	✓	✓	✓	00C, 00D, 019, 022, 023, 037
Laguna II	Air conditioning	✓	✓	✓	✓	✓	✓	00C, 00D, 012, 083, 084, 085, 086, 087
Laguna II	Automatic gearbox	✓	✓	✓	✓	✓	✓	00C, 00D, 018, 01A, 04E, 081, 082, 099, 09A, 09B, 09C
Laguna II	GAS Injection	✓	✓	✓	✓	✓	✓	00C
Laguna II	Discharge Lamp	✓	✓	✓	✓	✓	✓	00C, 00D, 012, 01C
Laguna II	Parking assistance	✓	✓	✓	✓	✓	✓	00C, 00D, 065, 066, 067
Laguna II	HEATER	✓	✓	✓	✓	✓	✓	00C, 0CC, 0CD
Laguna III	Engine System	✓	✓	✓	✓	✓	✓	001, 002, 003, 004, 06D, 0C5, 0C7, 0D0, 0D9, 0DA, 0DB, 0DC, 0DD, 0F3, 0F4, 0F7, 0F8, 0F9, 0FA, 0FB, 0FF, 100, 103, 105, 10B, 10C, 114, 115, 116, 117, 186, 187, 189, 18A, 18D, 192, 1E7
Laguna III	ABS	✓	✓	✓	✓	✓	✓	00C, 00D, 019, 08B, 0E9, 0EA, 0EB
Laguna III	Instrument panel	✓	✓	✓	✓	✓	✓	00C, 00D, 04C, 04F, 053, 074, 079, 07A, 0A4, 0E1
Laguna III	UCH	✓	✓	✓	✓	✓	✓	00C, 1D2, 1D3
Laguna III	Airbag/pretensioners	✓	✓	✓	✓	✓	✓	00C, 00D, 022, 023, 037
Laguna III	Air conditioning	✓	✓	✓	✓	✓	✓	00C, 00D, 069, 0D1, 0F4
Laguna III	Automatic gearbox	✓	✓	✓	✓	✓	✓	00C, 00D, 081, 0EC, 153, 154, 155, 156, 158, 159, 15A, 15B, 15C, 1C4
Laguna III	Communications unit	✓	✓	✓	✓	✓	✓	001, 00C, 00D, 019, 04C, 06F, 0D7
Laguna III	Parking brake	✓	✓	✓	✓	✓	✓	00C, 00D, 057, 18F
Laguna III	Variable PAS	✓	✓	✓	✓	✓	✓	00C, 00D, 01C
Laguna III	UPC	✓	✓	✓	✓	✓	✓	001, 00D, 0F4, 105, 114, 115, 116, 117, 118, 119, 11A, 11B, 11C, 11D, 11E, 11F, 120, 121, 122, 1C4, 1EC, 1ED
Laguna III	Lighting	✓	✓	✓	✓	✓	✓	00C, 00D, 08C
Laguna III	4 wheels steering	✓	✓	✓	✓	✓	✓	00D, 0E3, 0E4, 0E5
Laguna III	Parking prox can	✓	✓	✓	✓	✓	✓	00C, 00D, 065, 067, 220, 221
Laguna III	Driver's door	✓	✓	✓	✓	✓	✓	00C, 00D
Laguna III	Passenger's door	✓	✓	✓	✓	✓	✓	00C, 00D
Laguna III	Driver's seat	✓	✓	✓	✓	✓	✓	00C, 00D, 1B7
Laguna III	Radio	✓	✓	✓	✓	✓	✓	001, 00C, 00D, 01F, 06F, 07F, 0D7, 181, 194, 195, 1F7, 236, 238
Laguna III	Telematic ctrl unit	✓	✓	✓	✓	✓	✓	00C, 00D, 0D2
Laguna III	Left-hand door or passenger	✓	✓	✓	✓	✓	✓	0D1
Laguna III	Right-hand door or collapsi	✓	✓	✓	✓	✓	✓	0D1
Laguna III	Multimedia interface	✓	✓	✓	✓	✓	✓	001, 00D, 0D8, 196
Laguna III	Amplifier	✓	✓	✓	✓	✓	✓	001, 00D, 01F, 0D3, 1B7
Laguna III	Multimed. connection	✓	✓	✓	✓	✓	✓	00C, 00D, 019, 06A
Laguna ph2	Engine System	✓	✓	✓	✓	✓	✓	06B, 06C, 0C4, 0CE, 0CF, 276, 277, 291, 292, 297, 29A, 29B, 29E, 29F
Laguna ph2	ABS	✓	✓	✓	✓	✓	✓	019
Laguna ph2	Instrument panel	✓	✓	✓	✓	✓	✓	04A, 1F3, 2CC, 2D3
Laguna ph2	UCH	✓	✓	✓	✓	✓	✓	27E, 27F, 282, 283, 284, 285, 286, 287
Laguna ph2	Airbag/pretensioners	✓	✓	✓	✓	✓	✓	019, 01F, 022, 023, 265, 266, 267, 268, 269
Laguna ph2	Air conditioning	✓	✓	✓	✓	✓	✓	
Laguna ph2	Automatic gearbox	✓	✓	✓	✓	✓	✓	01B, 01F, 274, 275, 276, 277, 278, 279

Laguna ph2	Voice synthesiser	✓	✓	✓	✓	✓	✓	2CC
Laguna ph2	GAS Injection	✓	✓	✓	✓	✓	✓	
Laguna ph2	Variable PAS	✓	✓	✓	✓	✓	✓	019, 300
Laguna ph2	Driver's seat	✓	✓	✓	✓	✓	✓	01F
Laguna	Engine System	✓	✓	✓	✓	✓	✓	06B, 06C, 0CE, 0CF, 276, 277, 291, 292, 297, 2E1, 2E2
Laguna	ABS	✓	✓	✓	✓	✓	✓	019
Laguna	Instrument panel	✓	✓	✓	✓	✓	✓	04A, 1F3, 2CC, 2D3
Laguna	UCH	✓	✓	✓	✓	✓	✓	27E, 27F, 282, 283, 284, 285, 286, 287
Laguna	Airbag/pretensioners	✓	✓	✓	✓	✓	✓	019, 022, 023, 265, 266, 267, 268, 269
Laguna	Air conditioning	✓	✓	✓	✓	✓	✓	
Laguna	Automatic gearbox	✓	✓	✓	✓	✓	✓	274
Laguna	Voice synthesiser	✓	✓	✓	✓	✓	✓	2CC
Laguna	Variable PAS	✓	✓	✓	✓	✓	✓	019, 300
Laguna	Driver's seat	✓	✓	✓	✓	✓	✓	01F
LagunaII ph2	Engine System	✓	✓	✓	✓	✓	✓	001, 002, 004, 009, 00A, 00B, 00C, 00D, 06A, 06B, 06C, 06D, 0C5, 0C7, 0CE, 0CF, 0D9, 230
LagunaII ph2	ABS	✓	✓	✓	✓	✓	✓	00C, 00D, 014, 015, 017, 019, 052, 08B, 0E9, 0EA, 0EB
LagunaII ph2	Instrument panel	✓	✓	✓	✓	✓	✓	00C, 00D, 012, 048, 049, 04B, 04C, 04D, 04E, 050, 051, 052, 053, 064, 070, 071, 072, 073, 074, 075, 076, 077, 078, 079, 07A, 07B, 07C, 07D, 07E
LagunaII ph2	UCH	✓	✓	✓	✓	✓	✓	00C, 00D, 010, 011, 012, 04D, 052, 05A, 05B, 05D, 061, 07C, 086, 0A5, 0B3, 0B4, 0B5, 0B6, 0B7, 0B8, 0B9, 0BA, 0BB, 0BC, 0BD, 0BE, 0BF, 0C0, 0C1, 0C2, 1A7, 1D2, 21F, 225, 226, 227, 228, 229, 22A, 22B, 22C, 231
LagunaII ph2	Airbag/pretensioners	✓	✓	✓	✓	✓	✓	00C, 00D, 019, 022, 023, 037
LagunaII ph2	Air conditioning	✓	✓	✓	✓	✓	✓	00C, 00D, 012, 083, 084, 085, 086, 087
LagunaII ph2	Automatic gearbox	✓	✓	✓	✓	✓	✓	00C, 00D, 01A, 01B, 081, 082
LagunaII ph2	Communications unit	✓	✓	✓	✓	✓	✓	001, 00D, 012, 06A, 07F, 080
LagunaII ph2	Parking brake	✓	✓	✓	✓	✓	✓	00C, 00D, 055, 056, 057, 058
LagunaII ph2	Lighting	✓	✓	✓	✓	✓	✓	00C, 00D, 012, 08C, 08D, 08E, 08F, 090
LagunaII ph2	Hands-free kit	✓	✓	✓	✓	✓	✓	001, 00D, 019, 06E, 06F
LagunaII ph2	Parking assistance	✓	✓	✓	✓	✓	✓	00C, 00D, 065, 066, 067
LagunaII ph2	HEATER	✓	✓	✓	✓	✓	✓	00C, 0CC, 0CD
LagunaII ph2	Radio	✓	✓	✓	✓	✓	✓	
Latitude/sm5	Engine System	✓	✓	✓	✓	✓	✓	001, 002, 003, 004, 009, 06A, 06D, 0C5, 0C7, 0D0, 0D9, 0DA, 0DB, 0DC, 0DD, 0E0, 0F3, 0F7, 0F8, 0F9, 0FA, 0FB, 0FF, 100, 103, 105, 108, 109, 10A, 10B, 10C, 114, 115, 116, 117, 13C, 13D, 14C, 186, 187, 189, 18A, 18D, 18E, 190, 191, 192, 1A1, 1A2, 1A3, 1E7, 1FF, 200, 201, 202, 203
Latitude/sm5	ABS	✓	✓	✓	✓	✓	✓	00C, 00D, 019, 08B, 0E9, 0EA, 0EB, 0ED
Latitude/sm5	Instrument panel	✓	✓	✓	✓	✓	✓	00C, 00D, 04C, 04E, 04F, 052, 053, 074, 079, 07A, 0A4, 0B6, 0E1, 193
Latitude/sm5	UCH	✓	✓	✓	✓	✓	✓	00C, 13A
Latitude/sm5	Airbag/pretensioners	✓	✓	✓	✓	✓	✓	00C, 00D, 022, 023, 037
Latitude/sm5	Air conditioning	✓	✓	✓	✓	✓	✓	00C, 00D, 069, 0D1
Latitude/sm5	Automatic gearbox	✓	✓	✓	✓	✓	✓	00C, 00D, 019, 0EC, 111, 153, 154, 155, 156, 158, 159, 15A, 15B, 15C, 1C4, 21A
Latitude/sm5	Communications unit	✓	✓	✓	✓	✓	✓	001, 00C, 00D, 019, 04C, 06F, 0D7
Latitude/sm5	Parking brake	✓	✓	✓	✓	✓	✓	00C, 00D, 057, 18F
Latitude/sm5	Blind spot detection	✓	✓	✓	✓	✓	✓	00C, 00D
Latitude/sm5	Variable PAS	✓	✓	✓	✓	✓	✓	00C, 00D
Latitude/sm5	UPC	✓	✓	✓	✓	✓	✓	001, 00D, 0E2, 118, 11B, 122, 215
Latitude/sm5	Lighting	✓	✓	✓	✓	✓	✓	00C, 00D, 08C
Latitude/sm5	Parking prox can	✓	✓	✓	✓	✓	✓	00C, 00D, 065, 067, 220, 221
Latitude/sm5	Driver's door	✓	✓	✓	✓	✓	✓	00C, 00D
Latitude/sm5	Passenger's door	✓	✓	✓	✓	✓	✓	00C, 00D
Latitude/sm5	Driver's seat	✓	✓	✓	✓	✓	✓	00C, 00D, 1B7
Latitude/sm5	Radio	✓	✓	✓	✓	✓	✓	001, 00C, 00D, 01F, 06F, 07F, 0D7, 181, 194, 195, 1F7, 1FC
Latitude/sm5	Telematic ctrl unit	✓	✓	✓	✓	✓	✓	00C, 00D, 0D2
Latitude/sm5	Left-hand door or passenger	✓	✓	✓	✓	✓	✓	0D1
Latitude/sm5	Right-hand door or collapsi	✓	✓	✓	✓	✓	✓	0D1
Latitude/sm5	Multimedia interface	✓	✓	✓	✓	✓	✓	001, 00D, 0D8, 196
Latitude/sm5	Amplifier	✓	✓	✓	✓	✓	✓	001, 00D, 01F, 0D3, 197
Latitude/sm5	Multimed. connection	✓	✓	✓	✓	✓	✓	00C, 00D, 019, 06A

Lodgy	Engine System	✓	✓	✓	✓	✓	✓	001, 002, 003, 004, 005, 006, 007, 008, 009, 00C, 06D, 0C5, 0D0, 0D9, 0DA, 0DB, 0DC, 0DD, 0E0, 0F3, 0F7, 0F8, 0F9, 0FA, 0FB, 0FC, 0FD, 0FF, 100, 101, 103, 104, 105, 106, 107, 108, 109, 10A, 10B, 10C, 114, 115, 116, 117, 13C, 13D, 14C, 17D, 186, 1EF, 1F0, 1F5, 1F6, 1FF, 200, 201, 202, 203, 200, 20E, 20F, 210, 211
Lodgy	ABS	✓	✓	✓	✓	✓	✓	00C, 00D, 019, 08B, 0E9, 0EA, 0EB, 0ED, 0F0
Lodgy	Instrument panel	✓	✓	✓	✓	✓	✓	00C, 00D, 04C, 04F, 052, 072, 074, 0E1, 0E2, 14B, 164
Lodgy	UCH	✓	✓	✓	✓	✓	✓	00C, 010, 0F6, 105, 108, 129, 12B, 139
Lodgy	Airbag/pretensioners	✓	✓	✓	✓	✓	✓	00C, 00D, 022, 023
Lodgy	Automatic gearbox	✓	✓	✓	✓	✓	✓	
Lodgy	Variable PAS	✓	✓	✓	✓	✓	✓	00C, 00D, 01F
Lodgy	Radio	✓	✓	✓	✓	✓	✓	001, 00C, 00D, 01F, 06F, 0D7, 1FC
Lodgy	HANDS-FREE MODULE	✓	✓	✓	✓	✓	✓	00C, 00D, 0F5, 128, 12F, 130, 131, 132, 133, 134, 135, 136, 137, 138, 139, 13A, 13B
Logan II/sandero II	Engine System	✓	✓	✓	✓	✓	✓	001, 002, 003, 004, 005, 006, 007, 008, 009, 00C, 06D, 0C5, 0D0, 0D9, 0DA, 0DB, 0DC, 0DD, 0DF, 0F3, 0F5, 0F7, 0F8, 0F9, 0FA, 0FB, 0FC, 0FD, 0FF, 100, 101, 103, 104, 105, 106, 107, 108, 109, 10A, 10B, 10C, 114, 115, 116, 117, 13C, 13D, 17D, 186, 1EF, 1F0, 20D, 20E, 20F, 210, 211, 212, 213
Logan II/sandero II	ABS	✓	✓	✓	✓	✓	✓	00C, 00D, 019, 08B, 0E9, 0EA, 0EB, 0EC, 0ED, 0EE, 0F0
Logan II/sandero II	Instrument panel	✓	✓	✓	✓	✓	✓	00C, 00D, 04C, 04F, 052, 053, 072, 074, 0E1, 0E2, 14B, 164
Logan II/sandero II	UCH	✓	✓	✓	✓	✓	✓	00C, 010, 05D, 0F6, 105, 108, 129, 12B, 139
Logan II/sandero II	Airbag/pretensioners	✓	✓	✓	✓	✓	✓	00C, 00D, 022, 023
Logan II/sandero II	Air conditioning	✓	✓	✓	✓	✓	✓	00C, 00D, 0D1
Logan II/sandero II	Automatic gearbox	✓	✓	✓	✓	✓	✓	00C, 00D, 111, 112, 113
Logan II/sandero II	Variable PAS	✓	✓	✓	✓	✓	✓	00C, 00D, 01F
Logan II/sandero II	TRACKER	✓	✓	✓	✓	✓	✓	001, 1EE
Logan II/sandero II	Radio	✓	✓	✓	✓	✓	✓	001, 00C, 00D, 01F, 06F, 0D7, 1FC
Logan II/sandero II	Telematic ctrl unit	✓	✓	✓	✓	✓	✓	00C, 00D, 0D2
Logan II/sandero II	Multimedia interface	✓	✓	✓	✓	✓	✓	001, 00D, 0D8, 196, 214
Logan II/sandero II	HANDS-FREE MODULE	✓	✓	✓	✓	✓	✓	00C, 00D, 0F5, 128, 12F, 130, 131, 132, 133, 134, 135, 136, 137, 138, 139, 13A, 13B
Logan	Engine System	✓	✓	✓	✓	✓	✓	001, 002, 003, 005, 006, 007, 008, 009, 00B, 00C, 00D, 06D, 0C4, 0C5, 0C7, 0D0, 0D9, 0DA, 0DB, 0DC, 0DD, 0F3, 0F7, 0F9, 0FA, 10B, 10C, 17D, 186, 187, 20D, 254, 255, 256
Logan	ABS	✓	✓	✓	✓	✓	✓	00C, 00D, 019, 08B
Logan	UCH	✓	✓	✓	✓	✓	✓	00C, 00D, 0D5, 183
Logan	Airbag/pretensioners	✓	✓	✓	✓	✓	✓	00C, 00D, 022, 023, 026, 027, 02E, 02F, 037, 07D, 141, 142, 143, 144, 145, 146, 199, 19A, 19B, 1FD, 1FE
Logan	Automatic gearbox	✓	✓	✓	✓	✓	✓	00C, 00D, 019, 01A, 01B, 082
Logan	GAS Injection	✓	✓	✓	✓	✓	✓	00C, 00D
Logan	Variable PAS	✓	✓	✓	✓	✓	✓	00C, 00D, 01F
Logan	TRACKER	✓	✓	✓	✓	✓	✓	001, 1EE
Logan	Radio	✓	✓	✓	✓	✓	✓	001, 00C, 00D, 01F, 05B, 06F, 0D7, 1F7
Mast.PRO.ph2	Engine System	✓	✓	✓	✓	✓	✓	257, 2A0
Mast.PRO.ph2	ABS	✓	✓	✓	✓	✓	✓	08B
Mast.PRO.ph2	UCH	✓	✓	✓	✓	✓	✓	00E, 0A4, 24C
Mast.PRO.ph2	Airbag/pretensioners	✓	✓	✓	✓	✓	✓	
Mast.PRO.ph2	ADAPTATION UNIT	✓	✓	✓	✓	✓	✓	
Mast.PRO.ph3	Engine System	✓	✓	✓	✓	✓	✓	001, 004, 009, 06D, 0C7
Mast.PRO.ph3	ABS	✓	✓	✓	✓	✓	✓	00C, 00D, 019, 08B
Mast.PRO.ph3	UCH	✓	✓	✓	✓	✓	✓	00C, 00D, 0B5
Mast.PRO.ph3	Airbag/pretensioners	✓	✓	✓	✓	✓	✓	00C, 00D, 019, 022, 023
Mast.PRO.ph3	Communications unit	✓	✓	✓	✓	✓	✓	001, 00D
Mast.PRO.ph3	ADAPTATION UNIT	✓	✓	✓	✓	✓	✓	0E3

Master III	Engine System	✓	✓	✓	✓	✓	✓	001, 002, 003, 005, 006, 007, 008, 009, 00C, 06D, 0C5, 0D0, 0D9, 0DC, 0DD, 0DE, 0F7, 0F8, 0F9, 0FA, 0FB, 0FF, 100, 101, 102, 103, 105, 106, 107, 108, 109, 10B, 114, 115, 116, 117, 185, 186, 187, 188
Master III	ABS	✓	✓	✓	✓	✓	✓	00C, 00D, 019, 08B, 0E9, 0EA, 0EB, 0EC, 0ED, 0EE, 0EF
Master III	Instrument panel	✓	✓	✓	✓	✓	✓	00C, 00D, 048, 049, 04B, 04C, 070, 071, 072, 074, 079, 0E1, 149, 15E, 166
Master III	UCH	✓	✓	✓	✓	✓	✓	00C, 1BE, 1BF
Master III	Airbag/pretenioners	✓	✓	✓	✓	✓	✓	00C, 00D, 022, 023, 02E, 037
Master III	Air conditioning	✓	✓	✓	✓	✓	✓	00C, 00D, 0D1, 0F4
Master III	Automatic gearbox	✓	✓	✓	✓	✓	✓	004, 00C, 00D, 019, 153, 156, 157, 178, 1C8, 1C9, 1CA
Master III	Communications unit	✓	✓	✓	✓	✓	✓	00C, 00D, 019, 04C, 06F, 07A, 0D7
Master III	Variable PAS	✓	✓	✓	✓	✓	✓	00C, 00D, 218
Master III	TRACKER	✓	✓	✓	✓	✓	✓	001, 1EE
Master III	UPC	✓	✓	✓	✓	✓	✓	001, 00D, 00F, 019, 0F4, 105, 114, 115, 116, 117, 118, 119, 11A, 11B, 11C, 11D, 11E, 11F, 120, 121, 122, 123, 1C4, 1EC, 1ED
Master III	Tyres	✓	✓	✓	✓	✓	✓	00C, 00D
Master III	ADAPTATION UNIT	✓	✓	✓	✓	✓	✓	00C, 00D
Master III	Lighting	✓	✓	✓	✓	✓	✓	00C, 00D
Master III	Parking assistance	✓	✓	✓	✓	✓	✓	00C, 00D, 065, 067
Master III	HANDS-FREE ACCESS	✓	✓	✓	✓	✓	✓	00C, 00D, 1B8, 1B9, 1BA, 1BB, 1BC, 1BD
Master III	Front camera	✓	✓	✓	✓	✓	✓	00C, 00D, 06A
Master III	Radio	✓	✓	✓	✓	✓	✓	001, 00C, 00D, 01F, 055, 06F, 07F, 0D7, 181, 194, 195, 1F7, 1FC
Master III	Telematic ctrl unit	✓	✓	✓	✓	✓	✓	00C, 00D, 0D2
Master III	UREA DOSING CONTROL MODULE	✓	✓	✓	✓	✓	✓	00C, 00D, 16B, 16C, 16D, 16E, 16F, 170, 171, 172, 173, 174, 175, 176, 177
Master III	Multimedia interface	✓	✓	✓	✓	✓	✓	001, 00D, 0D8, 196, 214
Master III	Multimed. connection	✓	✓	✓	✓	✓	✓	00C, 00D, 019, 06A
Master PROP.	Engine System	✓	✓	✓	✓	✓	✓	
Master PROP.	UCH	✓	✓	✓	✓	✓	✓	27E, 27F, 282, 284, 285, 286, 287, 288, 2BE, 2BF, 2C0, 2C1
Master PROP.	Airbag/pretenioners	✓	✓	✓	✓	✓	✓	01F
Master ph2	Engine System	✓	✓	✓	✓	✓	✓	06B, 06C, 0CE, 0F7, 243, 257, 2A0
Master ph2	ABS	✓	✓	✓	✓	✓	✓	
Master ph2	UCH	✓	✓	✓	✓	✓	✓	00E, 260
Master ph2	Airbag/pretenioners	✓	✓	✓	✓	✓	✓	
Master ph2	Automatic gearbox	✓	✓	✓	✓	✓	✓	004, 081, 153, 1C8
Master ph2	ADAPTATION UNIT	✓	✓	✓	✓	✓	✓	
Master ph2	Parking prox cam	✓	✓	✓	✓	✓	✓	065, 066, 067
Master ph2	Piloted suspension	✓	✓	✓	✓	✓	✓	01F
Master ph2	Parking assistance	✓	✓	✓	✓	✓	✓	065, 066, 067
Master ph3	Engine System	✓	✓	✓	✓	✓	✓	001, 004, 009, 00C, 06A, 06B, 06C, 06D, 0C5, 0C7, 0CE, 0CF, 0D9, 10B, 1EF, 23A, 23B, 23C
Master ph3	ABS	✓	✓	✓	✓	✓	✓	00C, 017, 019, 08B, 0ED
Master ph3	UCH	✓	✓	✓	✓	✓	✓	00C, 00D, 0B5
Master ph3	Airbag/pretenioners	✓	✓	✓	✓	✓	✓	00C, 00D, 019, 022, 023
Master ph3	Automatic gearbox	✓	✓	✓	✓	✓	✓	004, 00D, 019, 081, 153, 156, 157, 1C8, 1C9, 1CA, 235
Master ph3	Communications unit	✓	✓	✓	✓	✓	✓	001, 00D
Master ph3	TRACKER	✓	✓	✓	✓	✓	✓	001, 1EE
Master ph3	ADAPTATION UNIT	✓	✓	✓	✓	✓	✓	0E3
Master ph3	Piloted suspension	✓	✓	✓	✓	✓	✓	0E3
Master ph3	Parking assistance	✓	✓	✓	✓	✓	✓	00C, 00D, 065, 066, 067
Master	Engine System	✓	✓	✓	✓	✓	✓	06B, 06C, 0CE, 0CF, 0F7, 212, 243, 257, 297, 298, 299, 29A, 29B, 29C, 29D, 29E, 29F, 2A2, 2A3, 2A4, 2A5, 2A6, 2A7, 2A8
Master	ABS	✓	✓	✓	✓	✓	✓	
Master	UCH	✓	✓	✓	✓	✓	✓	27E, 27F, 282, 284, 285, 286, 287, 288, 2BE, 2BF, 2C0, 2C1
Master	Airbag/pretenioners	✓	✓	✓	✓	✓	✓	019, 01F, 022, 023, 267, 269
Master	Piloted suspension	✓	✓	✓	✓	✓	✓	01F
MeganeII	Engine System	✓	✓	✓	✓	✓	✓	001, 002, 003, 004, 005, 006, 007, 008, 009, 00A, 00B, 00C, 06A, 06B, 06C, 06D, 0C4, 0C5, 0C7, 230, 237
MeganeII	ABS	✓	✓	✓	✓	✓	✓	00C, 00D, 014, 015, 016, 017, 019, 088, 08B
MeganeII	Instrument panel	✓	✓	✓	✓	✓	✓	00C, 00D, 012, 048, 049, 04A, 04B, 04C, 04D, 04E, 04F, 050, 052, 053, 064, 070, 071, 072, 075, 077, 07C, 07D, 0AB, 0AC, 0AD, 0AE, 0AF, 149

MeganeII	UCH	✓	✓	✓	✓	✓	00C, 00D, 00E, 00F, 010, 011, 052, 059, 05A, 05B, 05E, 080, 0B1, 0B2, 22E
MeganeII	Airbag/pretenioners	✓	✓	✓	✓	✓	00C, 00D, 012, 019, 022, 023, 024, 025, 026, 027, 028, 029, 02A, 02B, 02C, 02D, 02E, 02F, 030, 031, 032, 033, 034, 035, 036, 037, 038, 039, 03A, 03B, 03C, 03D, 03E, 03F, 040, 041, 042, 043, 044, 045, 046, 047, 062, 063
MeganeII	Air conditioning	✓	✓	✓	✓	✓	00C, 00D, 012, 013
MeganeII	Automatic gearbox	✓	✓	✓	✓	✓	00C, 00D, 018, 019, 01A, 01B, 082
MeganeII	Communications unit	✓	✓	✓	✓	✓	001, 00D
MeganeII	GAS Injection	✓	✓	✓	✓	✓	00C, 00D
MeganeII	Variable PAS	✓	✓	✓	✓	✓	00C, 00D, 01E, 01F, 020, 021
MeganeII	TRACKER	✓	✓	✓	✓	✓	001, 1EE
MeganeII	UPC	✓	✓	✓	✓	✓	001, 00D, 068
MeganeII	SUNROOF CONTROL UNIT	✓	✓	✓	✓	✓	009, 00C, 054
MeganeII	Lighting	✓	✓	✓	✓	✓	00C, 00D, 012, 08C, 08D, 08E, 090
MeganeII	Discharge Lamp	✓	✓	✓	✓	✓	00C, 00D, 01D
MeganeII	Left COSLAD	✓	✓	✓	✓	✓	00C, 00D, 012, 01C, 01D
MeganeII	Right COSLAD	✓	✓	✓	✓	✓	00C, 00D, 012, 01C, 01D
MeganeII	Parking assistance	✓	✓	✓	✓	✓	00C, 00D, 065, 066, 067
MeganeIV	Engine System	✓	✓	✓	✓	✓	001, 002, 004, 005, 006, 007, 008, 009, 00C, 06D, 0C5, 0D9, 0DA, 0DB, 0DC, 0DD, 0DE, 0DF, 0F3, 0F7, 0F8, 0F9, 0FA, 0FB, 0FC, 0FD, 0FE, 0FF, 100, 101, 102, 103, 104, 105, 106, 107, 108, 109, 10A, 10B, 114, 115, 116, 117, 13C, 13D, 14C, 150, 151
MeganeIV	ABS	✓	✓	✓	✓	✓	00C, 00D, 01E, 08B, 0E9, 0EA, 0EB, 0EC, 0ED, 0EF, 0F0, 0F1, 0F2
MeganeIV	Instrument panel	✓	✓	✓	✓	✓	00C, 00D, 04A, 04C, 04F, 074, 07A, 0E1, 0E2
MeganeIV	UCH	✓	✓	✓	✓	✓	009, 00C, 010, 05C, 0B5, 0F6, 127, 128, 129, 12A, 12B, 12C, 12D, 12E
MeganeIV	Airbag/pretenioners	✓	✓	✓	✓	✓	00C, 00D, 022, 023, 037
MeganeIV	Front radar	✓	✓	✓	✓	✓	00C, 00D
MeganeIV	Air conditioning	✓	✓	✓	✓	✓	00C, 00D, 069, 0D1
MeganeIV	Automatic gearbox	✓	✓	✓	✓	✓	00C, 00D, 153, 154, 155, 156, 157, 158, 159, 15A, 15B, 15C
MeganeIV	Parking brake	✓	✓	✓	✓	✓	00C, 00D, 10D, 10E
MeganeIV	Supervisor or DCDC	✓	✓	✓	✓	✓	00C
MeganeIV	Variable PAS	✓	✓	✓	✓	✓	00C, 00D
MeganeIV	UPC	✓	✓	✓	✓	✓	00D, 0E2, 105, 108, 118, 11B, 14D, 14E
MeganeIV	Head up display	✓	✓	✓	✓	✓	009, 00C
MeganeIV	4 wheels steering	✓	✓	✓	✓	✓	00D, 0E3, 0E4, 0E5
MeganeIV	Parking prox can	✓	✓	✓	✓	✓	00C, 00D, 065, 067, 124, 125, 126
MeganeIV	Driver's seat	✓	✓	✓	✓	✓	00C, 00D, 0E6, 0E7, 0E8
MeganeIV	Front camera	✓	✓	✓	✓	✓	00C, 00D, 01C
MeganeIV	Radio	✓	✓	✓	✓	✓	00C, 00D, 04C, 06F, 07A, 0A8, 0D2, 0D6, 0D7, 0D8
MeganeIV	Telematic ctrl unit	✓	✓	✓	✓	✓	00C, 00D, 0D2
MeganeIV	Left-hand door or passenger	✓	✓	✓	✓	✓	00C, 00D, 0E6, 0E7, 0E8
MeganeIV	Multimedia interface	✓	✓	✓	✓	✓	00C, 00D, 06A, 0D2
MeganeIV	Amplifier	✓	✓	✓	✓	✓	001, 00D, 0D3, 0D4
MeganeIV	BMS	✓	✓	✓	✓	✓	00C, 180
MeganeIV	PEB	✓	✓	✓	✓	✓	00C
MeganeIV	BMS safety	✓	✓	✓	✓	✓	00C, 17F
Megane/scen.	Engine System	✓	✓	✓	✓	✓	052, 06B, 06C, 0C4, 0CE, 0CF, 0F7, 18D, 257, 258, 276, 277, 291, 292, 293, 294, 295, 296, 297, 298, 299, 29A, 29B, 29C, 29D, 29E, 29F, 2A6, 2A7, 2DE, 2E3, 2E4
Megane/scen.	ABS	✓	✓	✓	✓	✓	019, 01F, 088
Megane/scen.	Airbag/pretenioners	✓	✓	✓	✓	✓	019, 01F, 022, 023, 265, 266, 267, 268, 269
Megane/scen.	Air conditioning	✓	✓	✓	✓	✓	019, 2E6, 2E7, 2E8, 2E9, 2EA, 2EB, 2EC, 2ED, 2EF, 2F0, 2F1, 2F2, 2F3, 2F4, 2F5, 2F6, 2F7, 2F8, 2F9
Megane/scen.	Automatic gearbox	✓	✓	✓	✓	✓	018, 01A, 01B, 01F, 04E, 082, 099, 09A, 09B, 09C, 274, 275, 276, 277, 278, 279, 27A, 27B, 27C
Megane/scen.	GAS Injection	✓	✓	✓	✓	✓	
Megane/scen.	Tyres	✓	✓	✓	✓	✓	012, 0B3
Megane/scen.	SUNROOF CONTROL UNIT	✓	✓	✓	✓	✓	
Megane/scen.	Driver's seat	✓	✓	✓	✓	✓	01F

MeganeIII/ScenicIII	Engine System	✓	✓	✓	✓	✓	✓	001, 002, 003, 004, 005, 006, 007, 008, 009, 00C, 06D, 0C5, 0C7, 0D0, 0D9, 0DA, 0DB, 0DC, 0DD, 0E0, 0F3, 0F7, 0F8, 0F9, 0FA, 0FB, 0FC, 0FD, 0FE, 0FF, 100, 101, 102, 103, 104, 105, 106, 107, 108, 109, 10A, 10B, 10C, 114, 115, 116, 117, 13C, 13D, 14C, 185, 186, 187, 188, 189, 18A, 18D, 1E7, 1FF, 200, 201, 202, 203, 20D, 20E, 20F, 210, 211
MeganeIII/ScenicIII	ABS	✓	✓	✓	✓	✓	✓	00C, 00D, 019, 08B, 0E9, 0EA, 0EB, 0F0
MeganeIII/ScenicIII	Instrument panel	✓	✓	✓	✓	✓	✓	00C, 00D, 04C, 04F, 052, 053, 074, 079, 07A, 0A4, 0E1, 19E, 1D4
MeganeIII/ScenicIII	UCH	✓	✓	✓	✓	✓	✓	00C, 19F, 1A0, 24E
MeganeIII/ScenicIII	Airbag/pretenioners	✓	✓	✓	✓	✓	✓	00C, 00D, 022, 023, 027
MeganeIII/ScenicIII	Air conditioning	✓	✓	✓	✓	✓	✓	00C, 00D, 0D1
MeganeIII/ScenicIII	Automatic gearbox	✓	✓	✓	✓	✓	✓	00C, 00D, 019, 081, 0EC, 111, 153, 154, 155, 156, 158, 159, 15A, 15B, 15C, 1C4, 21A
MeganeIII/ScenicIII	Communications unit	✓	✓	✓	✓	✓	✓	001, 00C, 00D, 019, 04C, 06F, 0D7
MeganeIII/ScenicIII	Parking brake	✓	✓	✓	✓	✓	✓	00C, 00D, 10D, 10E
MeganeIII/ScenicIII	Variable PAS	✓	✓	✓	✓	✓	✓	00C, 00D, 01E
MeganeIII/ScenicIII	UPC	✓	✓	✓	✓	✓	✓	001, 00D, 0F4, 105, 114, 115, 116, 117, 118, 119, 11A, 11B, 11C, 11D, 11E, 11F, 120, 121, 122, 1C4, 1EC, 1ED
MeganeIII/ScenicIII	SUNROOF CONTROL UNIT	✓	✓	✓	✓	✓	✓	00C, 0D2, 0E2, 184
MeganeIII/ScenicIII	Lighting	✓	✓	✓	✓	✓	✓	00C, 00D, 08C
MeganeIII/ScenicIII	Parking prox can	✓	✓	✓	✓	✓	✓	00C, 00D, 065, 067, 220, 221
MeganeIII/ScenicIII	Driver's door	✓	✓	✓	✓	✓	✓	00C, 00D, 0D1
MeganeIII/ScenicIII	Passenger's door	✓	✓	✓	✓	✓	✓	00C, 00D
MeganeIII/ScenicIII	Driver's seat	✓	✓	✓	✓	✓	✓	00C, 00D, 1B7
MeganeIII/ScenicIII	Front camera	✓	✓	✓	✓	✓	✓	00C, 00D, 06A
MeganeIII/ScenicIII	Radio	✓	✓	✓	✓	✓	✓	001, 00C, 00D, 01F, 055, 06F, 07F, 0D7, 181, 194, 195, 1F7, 1FC, 236, 238
MeganeIII/ScenicIII	Telematic ctrl unit	✓	✓	✓	✓	✓	✓	00C, 00D, 0D2
MeganeIII/ScenicIII	Multimedia interface	✓	✓	✓	✓	✓	✓	001, 00D, 0D8, 196, 214
MeganeIII/ScenicIII	Multimed. connection	✓	✓	✓	✓	✓	✓	00C, 00D, 019, 06A
Modus	Engine System	✓	✓	✓	✓	✓	✓	001, 002, 003, 004, 005, 006, 007, 008, 009, 00A, 00B, 00C, 00D, 06D, 0C4, 0C5, 0C7, 0D0, 0D9, 0DA, 0DB, 0DC, 0DD, 0F3, 0F7, 0F9, 0FA, 10B, 186, 187, 189, 18A, 20D, 237, 256
Modus	ABS	✓	✓	✓	✓	✓	✓	00C, 00D, 014, 015, 016, 017, 019, 088, 08B
Modus	Instrument panel	✓	✓	✓	✓	✓	✓	00C, 00D, 012, 048, 049, 04B, 04C, 04D, 04E, 050, 052, 053, 070, 071, 072, 074, 077, 079, 07C, 089, 08A, 149, 165, 18B, 18C
Modus	UCH	✓	✓	✓	✓	✓	✓	00C, 00D, 010, 059, 05A, 05B, 05C, 05D, 05E, 05F, 060, 061
Modus	Airbag/pretenioners	✓	✓	✓	✓	✓	✓	00C, 00D, 019, 022, 023, 024, 025, 026, 027, 02A, 02B, 02C, 02D, 02E, 02F, 030, 031, 032, 036, 037, 062, 063, 092, 093, 094, 095, 096, 097
Modus	Air conditioning	✓	✓	✓	✓	✓	✓	00C, 00D, 012, 013, 069
Modus	Automatic gearbox	✓	✓	✓	✓	✓	✓	004, 00C, 00D, 019, 01A, 01B, 081, 082, 153, 156, 157, 1C8, 1C9, 1CA
Modus	Variable PAS	✓	✓	✓	✓	✓	✓	00C, 00D, 01E, 01F
Modus	UPC	✓	✓	✓	✓	✓	✓	001, 00D
Modus	Tyres	✓	✓	✓	✓	✓	✓	00C, 00D, 012
Modus	Lighting	✓	✓	✓	✓	✓	✓	00C, 00D, 012, 08C, 08D, 08E, 08F, 090, 091
Modus	Hands-free kit	✓	✓	✓	✓	✓	✓	001, 00D, 019, 06E, 06F
Modus	Parking assistance	✓	✓	✓	✓	✓	✓	00C, 00D, 065, 066, 067
Meganeivsedan	Engine System	✓	✓	✓	✓	✓	✓	001, 002, 004, 005, 006, 007, 008, 009, 00C, 06D, 0C5, 0D9, 0DA, 0DB, 0DC, 0DD, 0DE, 0DF, 0F3, 0F7, 0F8, 0F9, 0FA, 0FB, 0FC, 0FD, 0FE, 0FF, 100, 101, 102, 103, 104, 105, 106, 107, 108, 109, 10A, 10B, 114, 115, 116, 117, 13C, 13D, 14C

Meganeivsedan	ABS	✓	✓	✓	✓	✓	✓	00C, 00D, 01E, 08B, 0E9, 0EA, 0EB, 0EC, 0ED, 0EF, 0FO, 0F1, 0F2
Meganeivsedan	Instrument panel	✓	✓		✓	✓	✓	00C, 00D, 04A, 04C, 04F, 074, 07A, 0E1, 0E2
Meganeivsedan	UCH	✓	✓	✓	✓	✓	✓	009, 00C, 010, 05C, 0B5, 0F6, 127, 128, 129, 12A, 12B, 12C, 12D, 12E
Meganeivsedan	Airbag/pretenioners	✓	✓	✓	✓	✓	✓	00C, 00D, 022, 023, 037
Meganeivsedan	Front radar	✓	✓	✓	✓	✓	✓	00C, 00D
Meganeivsedan	Air conditioning	✓	✓		✓	✓	✓	00C, 00D, 069, 0D1
Meganeivsedan	Automatic gearbox	✓	✓	✓	✓	✓	✓	00C, 00D, 019, 153, 154, 155, 156, 157, 158, 159, 15A, 15B, 15C, 17C
Meganeivsedan	Parking brake	✓	✓	✓	✓	✓	✓	00C, 00D, 10D, 10E
Meganeivsedan	Variable PAS	✓	✓	✓	✓	✓	✓	00C, 00D
Meganeivsedan	UPC	✓	✓	✓	✓	✓	✓	00D, 0E2, 105, 108, 118, 11B, 14D, 14E
Meganeivsedan	Head up displav							
Meganeivsedan	Parking prox can	✓	✓		✓	✓	✓	00C, 00D, 065, 067, 124, 125, 126
Meganeivsedan	Driver's seat	✓	✓		✓	✓	✓	00C, 00D, 0E6, 0E7, 0E8
Meganeivsedan	Front camera	✓	✓		✓	✓	✓	00C, 00D, 01C
Meganeivsedan	Radio	✓	✓		✓	✓	✓	00C, 00D, 04C, 06F, 07A, 0A8, 0D2, 0D6, 0D7, 0D8
Meganeivsedan	Telematic ctrl unit	✓	✓		✓	✓	✓	00C, 00D, 0D2
Meganeivsedan	Left-hand door or passenger	✓	✓		✓	✓	✓	00C, 00D, 0E6, 0E7, 0E8
Meganeivsedan	Multimedia interface	✓	✓		✓	✓	✓	00C, 00D, 06A, 0D2
Meganeivsedan	Amplifier	✓	✓		✓	✓	✓	001, 00D, 0D3, 0D4
New sm3/fluence/megane	Engine System	✓	✓	✓	✓	✓	✓	001, 002, 003, 004, 009, 00C, 06D, 0C5, 0D0, 0D9, 0DA, 0DB, 0DC, 0DD, 0F3, 0F5, 0F7, 0F8, 0F9, 0FA, 0FB, 0FC, 0FD, 0FE, 0FF, 100, 101, 102, 103, 105, 107, 108, 109, 10A, 10B, 10C, 114, 115, 116, 117, 13C, 13D, 186, 187, 189, 18A, 1E7, 20D, 20E, 20F, 210, 211
New sm3/fluence/megane	ABS	✓	✓	✓	✓	✓	✓	00C, 00D, 019, 08B, 0E9, 0EA, 0EB, 0F0
New sm3/fluence/megane	Instrument panel	✓	✓	✓	✓	✓	✓	00C, 00D, 04C, 04E, 04F, 052, 053, 074, 079, 07A, 0A4, 0B6, 0E1, 1D4
New sm3/fluence/megane	UCH	✓	✓	✓	✓	✓	✓	00C, 0BE, 19F, 1A0
New sm3/fluence/megane	Airbag/pretenioners	✓	✓	✓	✓	✓	✓	00C, 00D, 022, 023, 037
New sm3/fluence/megane	Air conditioning	✓	✓	✓	✓	✓	✓	00C, 00D, 0D1, 0F4
New sm3/fluence/megane	Automatic gearbox	✓	✓	✓	✓	✓	✓	00C, 00D, 019, 01A, 01B, 082, 0EC, 153, 154, 155, 156, 158, 159, 15A, 15B, 15C, 17C, 1C4
New sm3/fluence/megane	Communications unit	✓	✓	✓	✓	✓	✓	00C, 00D, 019, 04C, 06F, 0D7
New sm3/fluence/megane	Parking brake	✓	✓	✓	✓	✓	✓	00C, 00D, 10D, 10E
New sm3/fluence/megane	Blind spot detection	✓	✓	✓	✓	✓	✓	00C, 00D
New sm3/fluence/megane	Variable PAS	✓	✓	✓	✓	✓	✓	00C, 00D, 01E
New sm3/fluence/megane	TRACKER	✓	✓		✓	✓	✓	001, 1EE
New sm3/fluence/megane	UPC	✓	✓	✓	✓	✓	✓	001, 00D, 118, 11B, 122, 216, 217
New sm3/fluence/megane	SUNROOF CONTROL UNIT	✓	✓	✓	✓	✓	✓	00C, 0E2, 184
New sm3/fluence/megane	Lighting	✓	✓	✓	✓	✓	✓	00C, 00D, 08C
New sm3/fluence/megane	Parking prox can	✓	✓	✓	✓	✓	✓	00C, 00D, 065, 067, 220, 221
New sm3/fluence/megane	Driver's door	✓	✓	✓	✓	✓	✓	00C, 00D, 0D1
New sm3/fluence/megane	Radio	✓	✓	✓	✓	✓	✓	001, 00C, 00D, 01F, 055, 06F, 07F, 0D7, 181, 194, 195, 1F7, 1FC
New sm3/fluence/megane	Telematic ctrl unit	✓	✓	✓	✓	✓	✓	00C, 00D, 0D2
New sm3/fluence/megane	Multimedia interface	✓	✓		✓	✓	✓	001, 00D, 0D8, 196, 214
New sm3/fluence/megane	Amplifier	✓	✓	✓	✓	✓	✓	001, 00D, 01F, 0D3, 197
New sm3/fluence/megane	Multimed. connection	✓	✓	✓	✓	✓	✓	00C, 00D, 019, 06A
New sm3/fluence/megane	BCB	✓	✓	✓	✓	✓	✓	00C, 1F8, 1F9, 1FA
New sm3/fluence/megane	BMS	✓	✓	✓	✓	✓	✓	00C, 180, 1D0, 1D1, 1FB
New sm3/fluence/megane	EVC	✓	✓	✓	✓	✓	✓	00C, 0DD, 179, 17A, 1D0, 1E0, 1E1, 1E2
New sm3/fluence/megane	PEB	✓	✓	✓	✓	✓	✓	00C
New sm3/fluence/megane	BMS safetv	✓	✓	✓	✓	✓	✓	00C, 17F
Sandero	Engine System	✓	✓	✓	✓	✓	✓	001, 002, 003, 005, 006, 007, 008, 009, 00B, 00C, 00D, 06D, 0C4, 0C5, 0C7, 0D0, 0D9, 0DA, 0DB, 0DC, 0DD, 0F3, 0F7, 0F9, 0FA, 10B, 10C, 17D, 186, 187, 20D, 254, 255, 256
Sandero	ABS	✓	✓	✓	✓	✓	✓	00C, 00D, 019, 08B
Sandero	UCH	✓	✓		✓	✓	✓	00C, 00D, 0D5, 183
Sandero	Airbag/pretenioners	✓	✓	✓	✓	✓	✓	00C, 00D, 022, 023, 026, 027, 02E, 02F, 037, 07D, 141, 142, 143, 144, 145, 146, 199, 19A, 19B, 1FD, 1FE
Sandero	Automatic gearbox	✓	✓	✓	✓	✓	✓	00C, 00D, 019, 01A, 01B, 082
Sandero	GAS Injection	✓	✓	✓	✓	✓	✓	00C, 00D
Sandero	Variable PAS	✓	✓	✓	✓	✓	✓	00C, 00D, 01F
Sandero	TRACKER	✓	✓		✓	✓	✓	001, 1EE

Sandero	Radio	✓	✓	✓	✓	✓	✓	001, 00C, 00D, 01F, 05B, 06F, 0D7, 1F7
Scenic II	Engine System	✓	✓	✓	✓	✓	✓	001, 002, 003, 004, 005, 006, 007, 008, 009, 00A, 00B, 00C, 06A, 06B, 06C, 06D, 0C4, 0C5, 0C7, 230, 237
Scenic II	ABS	✓	✓	✓	✓	✓	✓	00C, 00D, 014, 015, 016, 017, 019, 088, 08B
Scenic II	Instrument panel	✓	✓	✓	✓	✓	✓	00C, 00D, 012, 048, 049, 04A, 04B, 04C, 04D, 04E, 04F, 050, 051, 052, 053, 070, 071, 072, 077, 149
Scenic II	UCH	✓	✓	✓	✓	✓	✓	00C, 00D, 00E, 00F, 010, 011, 052, 059, 05A, 05B, 05E, 0B0, 0B1, 0B2, 22E
Scenic II	Airbag/pretenioners	✓	✓	✓	✓	✓	✓	00C, 00D, 012, 019, 022, 023, 024, 025, 026, 027, 028, 029, 02A, 02B, 02C, 02D, 02E, 02F, 030, 031, 032, 033, 034, 035, 036, 037, 038, 039, 03A, 03B, 03C, 03D, 03E, 03F, 040, 041, 042, 043, 044, 045, 046, 047
Scenic II	Air conditioning	✓	✓	✓	✓	✓	✓	00C, 00D, 012, 013
Scenic II	Automatic gearbox	✓	✓	✓	✓	✓	✓	00C, 00D, 018, 019, 01A, 01B, 081, 082, 154
Scenic II	Communications unit	✓	✓	✓	✓	✓	✓	001, 00D, 012, 06A, 07F, 080
Scenic II	GAS Injection	✓	✓	✓	✓	✓	✓	00C, 00D
Scenic II	Parking brake	✓	✓	✓	✓	✓	✓	00C, 00D, 055, 056, 057, 058
Scenic II	Variable PAS	✓	✓	✓	✓	✓	✓	00C, 00D, 01E, 01F, 020, 021
Scenic II	UPC	✓	✓	✓	✓	✓	✓	001, 00D, 068
Scenic II	Parking prox can	✓	✓	✓	✓	✓	✓	00C, 00D, 019, 065, 066, 067, 220, 221
Scenic II	Discharge Lamp	✓	✓	✓	✓	✓	✓	00C, 00D, 012, 01C
Scenic II	Parking assistance	✓	✓	✓	✓	✓	✓	00C, 00D, 065, 066, 067
Scenic II	Radio	✓	✓	✓	✓	✓	✓	001, 00D, 01F, 04C, 236, 238
Scenic II	Multimedia interface	✓	✓	✓	✓	✓	✓	001, 00D, 012, 055, 06A
Scenic IV	Engine System	✓	✓	✓	✓	✓	✓	001, 002, 004, 005, 006, 007, 008, 009, 00C, 06D, 0C5, 0D9, 0DA, 0DB, 0DC, 0DD, 0F3, 0F7, 0F8, 0F9, 0FA, 0FB, 0FC, 0FD, 0FE, 0FF, 100, 101, 102, 103, 104, 105, 106, 107, 108, 109, 10A, 10B, 114, 115, 116, 117, 13C, 13D, 14C
Scenic IV	ABS	✓	✓	✓	✓	✓	✓	00C, 00D, 01E, 08B, 0E9, 0EA, 0EB, 0EC, 0ED, 0EF, 0F0, 0F1, 0F2
Scenic IV	Instrument panel	✓	✓	✓	✓	✓	✓	00C, 00D, 04A, 04C, 04F, 074, 07A, 0E1, 0E2
Scenic IV	UCH	✓	✓	✓	✓	✓	✓	009, 00C, 010, 05C, 0B5, 0F6, 127, 128, 129, 12A, 12B, 12C, 12D, 12E
Scenic IV	Airbag/pretenioners	✓	✓	✓	✓	✓	✓	00C, 00D, 022, 023, 037
Scenic IV	Air conditioning	✓	✓	✓	✓	✓	✓	00C, 00D, 069, 0D1
Scenic IV	Automatic gearbox	✓	✓	✓	✓	✓	✓	00C, 00D, 10D, 10E
Scenic IV	Parking brake	✓	✓	✓	✓	✓	✓	00C
Scenic IV	Supervisor or DCDC	✓	✓	✓	✓	✓	✓	00C, 00D
Scenic IV	Variable PAS	✓	✓	✓	✓	✓	✓	00D, 0E2, 105, 108, 118, 11B, 14D, 14E
Scenic IV	UPC	✓	✓	✓	✓	✓	✓	009, 00C
Scenic IV	Head up display	✓	✓	✓	✓	✓	✓	00C, 00D, 065, 067, 124, 125, 126
Scenic IV	Parking prox can	✓	✓	✓	✓	✓	✓	00C, 00D, 0E6, 0E7, 0E8
Scenic IV	Driver's seat	✓	✓	✓	✓	✓	✓	00C, 00D, 0E6, 0E7, 0E8
Scenic IV	Front camera	✓	✓	✓	✓	✓	✓	00C, 00D, 04C, 06F, 07A, 0A8, 0D2, 0D6, 0D7, 0D8
Scenic IV	Radio	✓	✓	✓	✓	✓	✓	00C, 00D, 002
Scenic IV	Telematic ctrl unit	✓	✓	✓	✓	✓	✓	00C, 00D, 0E6, 0E7, 0E8
Scenic IV	Left-hand door or passenger	✓	✓	✓	✓	✓	✓	00C, 00D
Scenic IV	Right-hand door or collapsi	✓	✓	✓	✓	✓	✓	00C, 00D, 06A, 0D2
Scenic IV	Multimedia interface	✓	✓	✓	✓	✓	✓	001, 00D, 0D3, 0D4
Scenic IV	Amplifier	✓	✓	✓	✓	✓	✓	00C, 180
Scenic IV	BMS	✓	✓	✓	✓	✓	✓	00C
Scenic IV	PEB	✓	✓	✓	✓	✓	✓	00C, 17F
Scenic IV	BMS safety	✓	✓	✓	✓	✓	✓	001, 06A, 06D, 0C7, 18D, 18E, 190, 191, 192, 1A1, 1A2, 1A3
Sm7-L47	Engine System	✓	✓	✓	✓	✓	✓	00C, 00D, 019, 08B, 0E9, 0EA, 0EB, 0ED
Sm7-L47	ABS	✓	✓	✓	✓	✓	✓	00C, 00D, 04C, 04E, 04F, 052, 053, 074, 079, 07A, 0A4, 0B6, 0E1
Sm7-L47	Instrument panel	✓	✓	✓	✓	✓	✓	00C, 13A
Sm7-L47	UCH	✓	✓	✓	✓	✓	✓	00C, 00D, 022, 023, 037
Sm7-L47	Airbag/pretenioners	✓	✓	✓	✓	✓	✓	00C, 00D, 069, 0D1
Sm7-L47	Air conditioning	✓	✓	✓	✓	✓	✓	

Sm7-L47	Automatic gearbox	✓	✓	✓	✓	✓	✓	00C, 00D, 019, 0EC, 111, 153, 154, 155, 156, 158, 159, 15A, 15B, 15C, 1C4, 21A
Sm7-L47	Communications unit	✓	✓	✓	✓	✓	✓	00C, 00D, 019, 04C
Sm7-L47	Parking brake	✓	✓	✓	✓	✓	✓	00C, 00D, 057, 18F
Sm7-L47	Blind spot detection	✓	✓	✓	✓	✓	✓	00C, 00D
Sm7-L47	Variable PAS	✓	✓	✓	✓	✓	✓	00C, 00D
Sm7-L47	UPC	✓	✓	✓	✓	✓	✓	001, 00D, 0E2, 118, 11B
Sm7-L47	Lighting	✓	✓	✓	✓	✓	✓	00C, 00D, 08C
Sm7-L47	Parking prox can	✓	✓	✓	✓	✓	✓	00C, 00D, 065, 067, 220, 221
Sm7-L47	Driver's door	✓	✓	✓	✓	✓	✓	00C, 00D
Sm7-L47	Passenger's door	✓	✓	✓	✓	✓	✓	00C, 00D
Sm7-L47	Driver's seat	✓	✓	✓	✓	✓	✓	00C, 00D, 187
Sm7-L47	Radio	✓	✓	✓	✓	✓	✓	001, 00C, 00D, 01F, 06F, 07F, 0D7, 181, 194, 195, 1F7, 1FC
Sm7-L47	Left-hand door or passenger	✓	✓	✓	✓	✓	✓	0D1
Sm7-L47	Right-hand door or collapsi	✓	✓	✓	✓	✓	✓	0D1
Sm7-L47	Multimedia interface	✓	✓	✓	✓	✓	✓	001, 00D, 0D8, 196
Sm7-L47	Amplifier	✓	✓	✓	✓	✓	✓	001, 00D, 01F, 0D3, 197
Sm7-L47	Multimed. connection	✓	✓	✓	✓	✓	✓	00C, 00D, 019, 06A
Talisman/sm6	Engine System	✓	✓	✓	✓	✓	✓	001, 002, 004, 005, 006, 007, 008, 009, 00C, 06D, 0C5, 0D9, 0DA, 0DB, 0DC, 0DD, 0DE, 0DF, 0F7, 0F8, 0F9, 0FA, 0FB, 0FC, 0FD, 0FE, 0FF, 100, 101, 102, 103, 104, 105, 106, 107, 108, 109, 10A, 10B, 114, 115, 116, 117, 150, 151
Talisman/sm6	ABS	✓	✓	✓	✓	✓	✓	00C, 00D, 01E, 08B, 0E9, 0EA, 0EB, 0EC, 0ED, 0EF, 0F0, 0F1, 0F2
Talisman/sm6	Instrument panel	✓	✓	✓	✓	✓	✓	00C, 00D, 04A, 04C, 04F, 074, 07A, 0E1, 0E2
Talisman/sm6	UCH	✓	✓	✓	✓	✓	✓	009, 00C, 010, 05C, 0B5, 0F6, 127, 128, 129, 12A, 12B, 12C, 12D, 12E
Talisman/sm6	Airbag/pretenioners	✓	✓	✓	✓	✓	✓	00C, 00D, 022, 023, 037
Talisman/sm6	Front radar	✓	✓	✓	✓	✓	✓	00C, 00D
Talisman/sm6	Air conditioning	✓	✓	✓	✓	✓	✓	00C, 00D, 069, 0D1
Talisman/sm6	Automatic gearbox	✓	✓	✓	✓	✓	✓	00C, 00D, 019, 153, 154, 155, 156, 157, 158, 159, 15A, 15B, 15C, 17C
Talisman/sm6	Parking brake	✓	✓	✓	✓	✓	✓	00C, 00D, 10D, 10E
Talisman/sm6	Variable PAS	✓	✓	✓	✓	✓	✓	00C, 00D
Talisman/sm6	UPC	✓	✓	✓	✓	✓	✓	00D, 0E2, 105, 108, 118, 11B, 14D, 14E
Talisman/sm6	Power back door	✓	✓	✓	✓	✓	✓	00C, 14F
Talisman/sm6	Head up display	✓	✓	✓	✓	✓	✓	009, 00C
Talisman/sm6	4 wheels steering	✓	✓	✓	✓	✓	✓	00D, 0E3, 0E4, 0E5
Talisman/sm6	Parking prox can	✓	✓	✓	✓	✓	✓	00C, 00D, 065, 067, 124, 125, 126
Talisman/sm6	Piloted suspension	✓	✓	✓	✓	✓	✓	00C, 00D
Talisman/sm6	Driver's seat	✓	✓	✓	✓	✓	✓	00C, 00D, 0E6, 0E7, 0E8
Talisman/sm6	Front camera	✓	✓	✓	✓	✓	✓	00C, 00D, 01C
Talisman/sm6	Radio	✓	✓	✓	✓	✓	✓	00C, 00D, 04C, 06F, 07A, 0A8, 0D2, 0D6, 0D7, 0D8
Talisman/sm6	Telematic ctrl unit	✓	✓	✓	✓	✓	✓	00C, 00D, 0D2
Talisman/sm6	Left-hand door or passenger	✓	✓	✓	✓	✓	✓	00C, 00D, 0E6, 0E7, 0E8
Talisman/sm6	Multimedia interface	✓	✓	✓	✓	✓	✓	00C, 00D, 06A, 0D2
Talisman/sm6	Amplifier	✓	✓	✓	✓	✓	✓	001, 00D, 0D3, 0D4
Thalia/symb. 2	Engine System	✓	✓	✓	✓	✓	✓	001, 002, 003, 005, 006, 007, 008, 009, 00B, 00C, 00D, 052, 06D, 0C4, 0C5, 0CE, 0D9, 0DA, 0DB, 0DC, 10C, 17D, 18D, 1F5, 22F, 254, 255, 257, 258, 259
Thalia/symb. 2	ABS	✓	✓	✓	✓	✓	✓	00C, 00D, 019, 08B
Thalia/symb. 2	UCH	✓	✓	✓	✓	✓	✓	00C, 00D, 0D5, 183
Thalia/symb. 2	Airbag/pretenioners	✓	✓	✓	✓	✓	✓	00C, 00D, 022, 023, 026, 027, 02E, 02F, 037, 07D, 141, 142, 143, 144, 145, 146, 198, 199, 19A, 19B
Thalia/symb. 2	Air conditioning	✓	✓	✓	✓	✓	✓	00C
Thalia/symb. 2	Automatic gearbox	✓	✓	✓	✓	✓	✓	00C, 00D, 019, 01A, 01B, 082
Thalia/symb. 2	Variable PAS	✓	✓	✓	✓	✓	✓	00C, 00D, 01F
Thalia/symb. 2	TRACKER	✓	✓	✓	✓	✓	✓	001, 1EE
Thalia/symbol	Engine System	✓	✓	✓	✓	✓	✓	001, 002, 004, 009, 00A, 00B, 052, 0C4, 0CE, 0CF, 18D, 257, 258, 2A1
Thalia/symbol	ABS	✓	✓	✓	✓	✓	✓	019, 08B
Thalia/symbol	UCH	✓	✓	✓	✓	✓	✓	00E, 127, 183, 261, 27E, 27F, 28D, 291, 282, 284, 285, 286, 287, 288, 28E, 2BF, 2C0, 2C1, 2C2, 2C3, 2C4, 2C5, 2C6, 2C7, 2C8, 2C9, 2CA, 2CB
Thalia/symbol	Airbag/pretenioners	✓	✓	✓	✓	✓	✓	019, 01F, 02E, 037, 141, 142, 143, 144, 145, 146, 263, 264
Thalia/symbol	Air conditioning	✓	✓	✓	✓	✓	✓	019, 2E6, 2E7, 2E8, 2E9, 2EA, 2EB, 2EC, 2ED, 2EE, 2EF, 2FO, 2F1, 2F2, 2F3, 2F4, 2F5, 2F6, 2F7

Thalia/symbol	Automatic gearbox	✓	✓	✓	✓	✓	018, 01A, 01B, 01F, 04E, 082, 099, 09A, 09B, 09C, 275, 276, 277, 278, 279, 27A, 27B, 27C
Trafic II	Engine System	✓	✓	✓	✓	✓	06B, 06C, 0C4, 0CE, 0F7, 257, 298, 299, 29A, 29B, 29C, 29D, 29E, 29F, 2A0
Trafic II	ABS	✓	✓	✓	✓	✓	
Trafic II	UCH	✓	✓	✓	✓	✓	00E
Trafic II	Airbag/pretenioners	✓	✓	✓	✓	✓	037
Trafic II	Automatic gearbox	✓	✓	✓	✓	✓	004, 081, 153, 1C8
Trafic II	ADAPTATION UNIT	✓	✓	✓	✓	✓	
Trafic II	Parking prox can						
Trafic II	Parking assistance						
Trafic II	HEATER	✓	✓	✓	✓	✓	
Trafic III	Engine System	✓	✓	✓	✓	✓	005, 006, 007, 008, 00C, 06D, 0C5, 0D9, 0DC, 0DD, 0DE, 0F7, 0F8, 0F9, 0FA, 0FB, 0FC, 0FD, 0FE, 0FF, 100, 101, 102, 103, 106, 10B, 114, 115, 116, 117, 13C
Trafic III	ABS	✓	✓	✓	✓	✓	00C, 00D, 01E, 08B, 0E9, 0EA, 0EB, 0EC, 0ED, 0EF, 0FO, 0F1, 0F2
Trafic III	Instrument panel	✓	✓	✓	✓	✓	00C, 00D, 04C, 04F, 074, 079, 0E2
Trafic III	UCH	✓	✓	✓	✓	✓	00C, 010, 05A, 12B, 219
Trafic III	Airbag/pretenioners	✓	✓	✓	✓	✓	00C, 00D, 022, 023
Trafic III	Air conditioning	✓	✓	✓	✓	✓	00C, 00D, 069, 0D1
Trafic III	Communications unit	✓	✓	✓	✓	✓	00C, 00D, 04C, 06F, 07A, 0D7
Trafic III	Variable PAS	✓	✓	✓	✓	✓	00C, 00D, 218
Trafic III	UPC	✓	✓	✓	✓	✓	00D, 0E2, 105, 118, 11B, 123
Trafic III	ADAPTATION UNIT	✓	✓	✓	✓	✓	00C, 00D
Trafic III	Parking prox can	✓	✓	✓	✓	✓	00C, 00D, 065
Trafic III	HEATER	✓	✓	✓	✓	✓	00C, 0CC, 0CD
Trafic III	Radio	✓	✓	✓	✓	✓	001, 00C, 00D, 01F, 06F, 0D7, 1F7
Trafic III	Telematic ctrl unit	✓	✓	✓	✓	✓	00C, 00D, 0D2
Trafic III	UREA DOSING CONTROL MODULE	✓	✓	✓	✓	✓	00C, 00D, 16B, 16C, 16D, 16E, 16F, 170, 171, 172, 173, 174, 175, 176, 177
Trafic III	Multimedia interface	✓	✓	✓	✓	✓	001, 00D, 0D8, 196, 214
Trafic III	HANDS-FREE MODULE	✓	✓	✓	✓	✓	00C, 00D, 0F5, 128, 12F, 130, 131, 132, 133, 134, 135, 136, 137, 138, 139, 13A, 13B
TraficI1p2/3	Engine System	✓	✓	✓	✓	✓	001, 002, 004, 009, 00A, 00B, 00C, 06A, 06B, 06C, 06D, 0C5, 0C7, 0CE, 0CF, 0D9, 0DC, 0DD, 0FF, 0F9, 0FA, 0FB, 0FC, 10B, 185, 186, 187, 188, 1C7, 212
TraficI1p2/3	ABS	✓	✓	✓	✓	✓	00C, 00D, 016, 017, 019, 088, 08B, 0ED, 0F2, 1C0
TraficI1p2/3	Instrument panel	✓	✓	✓	✓	✓	00C, 00D, 04B, 04C, 04E, 052, 053, 073, 077, 079, 07D, 0AE, 0E1, 0E2, 149, 163, 165, 1CC, 1CD, 1CE
TraficI1p2/3	UCH	✓	✓	✓	✓	✓	00C, 00D, 04D, 05A, 05D, 0B5, 1A7, 239, 24C, 24D
TraficI1p2/3	Airbag/pretenioners	✓	✓	✓	✓	✓	00C, 00D, 019, 022, 023, 037
TraficI1p2/3	Air conditioning	✓	✓	✓	✓	✓	00C, 00D, 012, 1CB
TraficI1p2/3	Automatic gearbox	✓	✓	✓	✓	✓	004, 00C, 00D, 019, 081, 153, 156, 157, 1C8, 1C9, 1CA, 235
TraficI1p2/3	Communications unit	✓	✓	✓	✓	✓	001, 00C, 00D, 019, 04C, 06A, 181, 182, 1CF
TraficI1p2/3	ADAPTATION UNIT	✓	✓	✓	✓	✓	0E3
TraficI1p2/3	Parking assistance	✓	✓	✓	✓	✓	00C, 00D, 065, 066, 067
TraficI1p2/3	HEATER	✓	✓	✓	✓	✓	00C, 0CC, 0CD
TraficI1p2/3	Radio	✓	✓	✓	✓	✓	001, 00D, 01F, 1C6
TraficI1p2/3	Multimedia interface	✓	✓	✓	✓	✓	001, 00D, 055, 19C, 19D, 1C1
TraficI1p2/3	Multimed. connection	✓	✓	✓	✓	✓	00C, 00D, 019, 181
Twingo II	Engine System	✓	✓	✓	✓	✓	001, 002, 003, 004, 005, 006, 007, 008, 009, 00A, 00B, 00C, 06D, 0C5, 0C7, 0D0, 0D9, 0DA, 0DB, 0DC, 0DD, 0F3, 0F7, 0F9, 0FA, 10B, 186, 187, 189, 18A, 20D, 256
Twingo II	ABS	✓	✓	✓	✓	✓	00C, 00D, 014, 015, 017, 019, 052, 08B, 0ED, 1B0
Twingo II	Instrument panel	✓	✓	✓	✓	✓	00C, 00D, 04B, 04C, 04D, 04E, 052, 053, 07D, 0AE, 0AF, 149, 163, 164, 1E5, 1E6
Twingo II	UCH	✓	✓	✓	✓	✓	00C, 00D, 00F, 010, 011, 05A, 0B0, 0B1, 0B5, 0B9, 0C3, 0C6, 129, 1A5, 1A6, 1A7, 1A8, 1A9, 1AA, 1AB, 1AC

Twingo II	Airbag/pretenioners	✓	✓	✓	✓	✓	00C, 00D, 022, 023, 024, 025, 026, 027, 02E, 02F, 030, 031, 037, 142, 143, 145, 146, 19A, 19B
Twingo II	Air conditioning	✓	✓		✓	✓	00C, 00D, 012, 013, 069
Twingo II	Automatic gearbox	✓	✓	✓	✓	✓	004, 00D, 019, 081, 153, 156, 157, 1C8, 1C9
Twingo II	Variable PAS	✓	✓	✓	✓	✓	00C, 1A4
Twingo II	REV COUNTER/SYMBOL	✓	✓	✓	✓	✓	00D, 04E, 165, 1B3, 1E3, 1E4
Twingo II	Parking assistance	✓	✓	✓	✓	✓	00C, 00D, 065, 066, 067
Twingo II	Radio	✓	✓	✓	✓	✓	001, 00C, 00D, 01F, 07F, 181, 1F7
Twingo II	Multimedia interface	✓	✓		✓	✓	001, 00D, 012, 055, 19C, 19D
Twingo II	Multimed. connection	✓	✓	✓	✓	✓	00C, 00D, 019, 181
Twingo III	Engine System	✓	✓	✓	✓	✓	001, 06D, 0C5, 0D9, 0DA, 0DB, 0DC, 0DD, 0DE, 0DF, 0E0
Twingo III	ABS	✓	✓	✓	✓	✓	00C, 00D, 0E9, 0EA, 0EB, 0EC, 0ED, 0EE, 0FO, 10F, 110
Twingo III	Instrument panel	✓	✓		✓	✓	00C, 00D, 04C, 04F, 074, 079, 0E2
Twingo III	UCH	✓	✓	✓	✓	✓	00C, 010, 05A, 05D, 129, 12B
Twingo III	Airbag/pretenioners	✓	✓	✓	✓	✓	00C, 00D, 022, 023
Twingo III	Front radar	✓	✓		✓	✓	00C, 00D
Twingo III	Air conditioning	✓	✓		✓	✓	00C, 00D, 069, 0D1
Twingo III	Automatic gearbox	✓	✓	✓	✓	✓	00C, 00D, 13E, 153, 154, 156, 158, 15A, 15B, 15C, 17E
Twingo III	Communications unit	✓	✓	✓	✓	✓	00C, 00D, 04C, 06F, 07A, 0D7
Twingo III	Variable PAS	✓	✓	✓	✓	✓	00C, 00D
Twingo III	UPC	✓	✓	✓	✓	✓	00D, 0E2, 105, 118, 11B, 123
Twingo III	Gearbox elec control	✓	✓	✓	✓	✓	00C, 00D
Twingo III	Front camera	✓	✓		✓	✓	00C, 00D, 06A
Twingo III	Radio	✓	✓	✓	✓	✓	001, 00C, 00D, 06F, 0D7, 1F7
Twingo III	Telematic ctrl unit	✓	✓		✓	✓	00C, 00D, 0D2
Twingo III	Multimedia interface	✓	✓		✓	✓	001, 00D, 0D8, 196, 214
Twingo ph2	Engine System	✓	✓		✓	✓	001, 004, 009, 00A, 00B, 06B, 06C, 0C4, 291, 292, 293, 294, 2DF, 2E0
Twingo ph2	ABS	✓	✓		✓	✓	019
Twingo ph2	UCH	✓	✓		✓	✓	00E, 183, 262, 27E, 27F, 280, 281, 282, 284, 285, 286, 287, 288, 28E, 2BF, 2C0, 2C1
Twingo ph2	Airbag/pretenioners	✓	✓		✓	✓	019, 01F, 022, 023, 265, 266, 267, 268, 269
Twingo ph2	Automatic gearbox	✓	✓		✓	✓	004, 052, 081, 153, 1C8
Twingo ph2	CAS Injection	✓	✓		✓	✓	
Twingo ph2	Variable PAS	✓	✓		✓	✓	
X09	Instrument panel	✓	✓		✓	✓	00C, 00D, 012, 019, 04C, 072, 20A, 20B, 20C
X09	UCH	✓	✓		✓	✓	00C, 00D, 183
X09	Airbag/pretenioners	✓	✓	✓	✓	✓	00C, 00D, 022, 023, 02E, 037, 141, 142, 143, 144, 1FD, 1FE
X09	ADAPTATION UNIT	✓	✓		✓	✓	00C, 00D, 01F
X09	BCB	✓	✓		✓	✓	
X09	BMS	✓	✓		✓	✓	
Velsatis	Engine System	✓	✓	✓	✓	✓	002, 004, 009, 00A, 00B, 00C, 00D, 06B, 06C, 06D, 0C4, 0C7, 0CE, 0CF, 0D0, 0D9
Velsatis	ABS	✓	✓	✓	✓	✓	00C, 00D, 017, 019, 08B, 098
Velsatis	Instrument panel	✓	✓		✓	✓	00C, 00D, 012, 048, 049, 04B, 04C, 04D, 04E, 050, 051, 052, 053, 064, 070, 071, 072, 073, 074, 075, 076, 077, 079, 07A, 07B, 07C, 07D, 07E, 09D, 09E, 09F, 0A0, 0A1, 0A2, 0A3, 0A4, 0A6, 21B, 21C, 21D, 21E
Velsatis	UCH	✓	✓	✓	✓	✓	00C, 00D, 010, 011, 04D, 052, 05A, 05B, 07C, 086, 0B4, 0B5, 0B6, 0B8, 0BA, 0BB, 0BF, 0C0, 1A7, 1D2, 21F, 225, 226, 227, 228, 229, 22A, 22B, 22C, 22D
Velsatis	Airbag/pretenioners	✓	✓	✓	✓	✓	00C, 00D, 019, 022, 023, 037
Velsatis	Front radar	✓	✓	✓	✓	✓	00C, 00D, 019, 0C8, 0C9, 0CA, 0CB
Velsatis	Air conditioning	✓	✓	✓	✓	✓	00C, 00D, 012, 083, 084, 085, 086, 087
Velsatis	Automatic gearbox	✓	✓	✓	✓	✓	00D, 081, 082
Velsatis	Parking brake	✓	✓		✓	✓	00C, 00D, 055, 056, 057, 058
Velsatis	Tyres	✓	✓		✓	✓	00C, 012, 0A5
Velsatis	Hands-free kit	✓	✓		✓	✓	001, 00D, 019, 06E, 06F
Velsatis	Discharge Lamp	✓	✓	✓	✓	✓	00C, 00D, 012, 01C
Velsatis	Parking assistance	✓	✓	✓	✓	✓	00C, 00D, 065, 066, 067
Velsatis	HEATER	✓	✓	✓	✓	✓	00C, 00C, 0CD

Velsatis ph2	Engine System	✓	✓	✓	✓	✓	✓	001, 002, 004, 009, 00A, 00B, 00C, 00D, 06A, 06B, 06C, 06D, 0C4, 0C5, 0C7, 0CE, 0CF, 0D0, 0D9, 22F, 230
Velsatis ph2	ABS	✓	✓	✓	✓	✓	✓	00C, 00D, 014, 015, 017, 019, 052, 08B, 098, 0E9, 0EA, 0EB
Velsatis ph2	Instrument panel	✓	✓	✓	✓	✓	✓	00C, 00D, 012, 048, 049, 04B, 04C, 04D, 04E, 050, 051, 052, 053, 064, 070, 071, 072, 073, 074, 075, 076, 077, 079, 07A, 07B, 07C, 07D, 07E, 21B, 21C, 21D, 21E
Velsatis ph2	UCH	✓	✓	✓	✓	✓	✓	00C, 00D, 010, 011, 012, 052, 05A, 05B, 05D, 061, 07C, 086, 08D, 08E, 08F, 08G, 08H, 08I, 08J, 08K, 08L, 08M, 08N, 08O, 08P, 08Q, 08R, 08S, 08T, 08U, 08V, 08W, 08X, 08Y, 08Z, 090, 091, 092, 093, 094, 095, 096, 097, 098, 099, 09A, 09B, 09C, 09D, 09E, 09F, 09G, 09H, 09I, 09J, 09K, 09L, 09M, 09N, 09O, 09P, 09Q, 09R, 09S, 09T, 09U, 09V, 09W, 09X, 09Y, 09Z, 221, 232
Velsatis ph2	Airbag/pretenioners	✓	✓	✓	✓	✓	✓	00C, 00D, 019, 022, 023, 037
Velsatis ph2	Air conditioning	✓	✓	✓	✓	✓	✓	00C, 00D, 012, 083, 084, 085, 086, 087
Velsatis ph2	Automatic gearbox	✓	✓	✓	✓	✓	✓	00D, 019, 081, 082, 154, 233
Velsatis ph2	Communications unit	✓	✓	✓	✓	✓	✓	001, 00D, 012, 06A, 07F, 080
Velsatis ph2	Parking brake	✓	✓	✓	✓	✓	✓	00C, 00D, 055, 056, 057, 058
Velsatis ph2	Lighting	✓	✓	✓	✓	✓	✓	00C, 00D, 012, 08C, 08D, 08E, 08F, 090
Velsatis ph2	Parking prox can	✓	✓	✓	✓	✓	✓	00C, 00D, 019, 065, 066, 067, 220, 221
Velsatis ph2	Hands-free kit	✓	✓	✓	✓	✓	✓	001, 00D, 019, 06E, 06F
Velsatis ph2	Parking assistance	✓	✓	✓	✓	✓	✓	00C, 00D, 065, 066, 067
Velsatis ph2	HEATER	✓	✓	✓	✓	✓	✓	00C, 0CC, 0CD
Velsatis ph2	Radio	✓	✓	✓	✓	✓	✓	
Wind	Engine System	✓	✓	✓	✓	✓	✓	001, 004, 00A, 00B, 0C5
Wind	ABS	✓	✓	✓	✓	✓	✓	00C, 00D, 014, 015, 017, 019, 052, 08B, 0ED, 1B0
Wind	Instrument panel	✓	✓	✓	✓	✓	✓	00C, 00D, 04C, 04E, 053, 073, 074, 079, 07C, 0E2, 162, 166
Wind	UCH	✓	✓	✓	✓	✓	✓	00C, 00D, 00F, 010, 011, 05A, 080, 081, 085, 089, 0C6, 129, 1A5, 1A6, 1A7, 1A8, 1A9, 1AA, 1AB, 1AC, 1AD
Wind	Airbag/pretenioners	✓	✓	✓	✓	✓	✓	00C, 00D, 022, 023, 026, 027, 02E, 02F, 037, 142, 143, 19A, 19B, 1AE, 1AF
Wind	Air conditioning	✓	✓	✓	✓	✓	✓	00C, 00D, 012, 013, 069
Wind	Variable PAS	✓	✓	✓	✓	✓	✓	00C, 1A4
Wind	SUNROOF CONTROL UNIT	✓	✓	✓	✓	✓	✓	00C
Wind	Radio	✓	✓	✓	✓	✓	✓	001, 00C, 00D, 01F, 07F, 181, 1F7
Wind	Multimedia interface	✓	✓	✓	✓	✓	✓	001, 00D, 055, 19C, 19D
Wind	Multimed. connection	✓	✓	✓	✓	✓	✓	00C, 00D, 019, 181
XBB	Engine System	✓	✓	✓	✓	✓	✓	
XBB	ABS	✓	✓	✓	✓	✓	✓	
XBB	Instrument panel	✓	✓	✓	✓	✓	✓	
XBB	UCH	✓	✓	✓	✓	✓	✓	
XBB	Airbag/pretenioners	✓	✓	✓	✓	✓	✓	00C, 00D, 022, 023
XBB	Variable PAS	✓	✓	✓	✓	✓	✓	00C, 00D
XBB	Radio	✓	✓	✓	✓	✓	✓	00C, 00D, 01F, 06F, 0D7
XBB	Multimedia interface	✓	✓	✓	✓	✓	✓	
Z0E	ABS	✓	✓	✓	✓	✓	✓	00C, 00D, 019, 08B, 0E9, 0EA, 0EB, 0EC, 0ED, 0EE
Z0E	Instrument panel	✓	✓	✓	✓	✓	✓	00C, 00D, 04A, 04C, 053, 07A, 0E1
Z0E	UCH	✓	✓	✓	✓	✓	✓	00C, 1A0
Z0E	Airbag/pretenioners	✓	✓	✓	✓	✓	✓	00C, 00D, 022, 023
Z0E	Air conditioning	✓	✓	✓	✓	✓	✓	00C, 00D, 0D1
Z0E	Communications unit	✓	✓	✓	✓	✓	✓	00C, 00D, 04C, 06F, 07A, 0D7
Z0E	Variable PAS	✓	✓	✓	✓	✓	✓	00C, 00D, 01F
Z0E	UPC	✓	✓	✓	✓	✓	✓	00D, 118, 11A, 11B, 11C, 11D, 11E, 11F, 120, 121
Z0E	ADAPTATION UNIT	✓	✓	✓	✓	✓	✓	00C, 00D, 01F
Z0E	Parking prox can	✓	✓	✓	✓	✓	✓	00C, 00D, 065
Z0E	Radio	✓	✓	✓	✓	✓	✓	001, 00C, 00D, 01F, 06F, 0D7, 1F7, 1FC
Z0E	Telematic ctrl unit	✓	✓	✓	✓	✓	✓	00C, 00D, 0D2
Z0E	UNCOUPLED PEDAL	✓	✓	✓	✓	✓	✓	00C, 00D, 01F, 0EC, 204, 205, 206, 207, 208, 209
Z0E	BCB	✓	✓	✓	✓	✓	✓	00C, 1F8, 1F9, 1FA
Z0E	BMS	✓	✓	✓	✓	✓	✓	00C, 180, 1D0, 1D1, 1FB
Z0E	EVC	✓	✓	✓	✓	✓	✓	00C, 0DD, 179, 17A
Z0E	PEB	✓	✓	✓	✓	✓	✓	00C, 17B
Z0E	BMS safetv	✓	✓	✓	✓	✓	✓	00C
001	Fault memory				002	EGR adaptives		
003	Pressure regulation adaptives				004	Programmed values		
005	Cylinder 1 Injector Code				006	Cylinder 2 Injector Code		
007	Cylinder 3 Injector Code				008	Cylinder 4 Injector Code		
009	WRITE V.I.N.				00A	Unlock injector control		
00B	Lock injector control				00C	Fault memory		
00D	Write VIN				00E	Automatic relocking		
00F	Front fog lights				010	Hazard warning lights illumination by ABS		

011	See-me-home lighting	012	Vehicle type
013	Heating resistor type	014	Prevention of stop light auto illumination
015	Auto stop lights illumination authorisation	016	Esp automatic reconnection threshold
017	Vehicle parameters	018	Converter lock up adaptive
019	Write date of last after sales operation	01A	Note oil wear counter
01B	Write transmission oil change date	01C	Computer calibration
01D	Computer address	01E	Steering wheel angle sensor programming
01F	Write date of after sales operation	020	Pulling correction program
021	Pulling correction	022	Lock computer
023	Unlock computer	024	Curtain side air bag, Driver's side
025	Curtain side air bag, Passenger's side	026	Front thorax side air bag, Driver's side
027	Front thorax side air bag, Passenger's side	028	Rear thorax side air bag, Driver's side
029	Rear thorax side air bag, Passenger's side	02A	Passenger's front air bag circuit 2
02B	Driver front air bag circuit 1	02C	Driver front air bag circuit 2
02D	Passenger's front air bag circuit 1	02E	Passenger's air bag locking mode
02F	Driver's seat buckle sensor	030	Passenger's seat buckle sensor
031	Passenger's presence detection sensor	032	Rear inertia reels
033	Passenger's LAP strap/seat airbag	034	Driver's LAP STRAP/SEAT airbag
035	Front buckle pretensioners	036	Driver's seat position sensor
037	Side on which steering wheel fitted	038	Passenger's side rear strap sensor
039	Driver's side rear strap sensor	03A	Driver's side rear frontal airbag
03B	Passenger's side rear frontal airbag	03C	B/C without side airbags
03D	B/C with front thorax + head airbags	03E	B/C with fr/rr thorax + head airbags
03F	G/S with head airbags	040	G/S without head airbag
041	I without side airbags	042	I with side AB W/O rear chest AB
043	E with side airbags	044	E without side airbags
045	K/L without side airbags	046	K/L with F chest + curt airbags
047	K/L with F/R chest + curt airbags	048	Oil change interval in KM
049	Oil change interval in months	04A	Language configuration
04B	Fuel type	04C	Distance units
04D	Overspeed function-arabia	04E	Trajectory control
04F	Consumption measurement units	050	Tyre pressure monitoring
051	Automatic handbrake	052	Gearbox type
053	Cruise CTRL/SPD Limiter	054	Roll bars
055	Vehicle configuration	056	SLOPE INITIALISATION
057	SAVE CLUTCH PEDAL PROGRAMMING	058	WRITE CLUTCH PEDAL PROGRAMMING
059	New vehicle storage mode deactivation	05A	Deadlocking
05B	Driving type	05C	Windscreen type
05D	Selective opening of doors	05E	Childproof lock
05F	3-button key	060	Tailgate flap
061	Headlight washers	062	Driver's lateral sensor
063	Passenger's lateral sensor	064	Reserve capacity
065	BUZZER VOLUME	066	Vehicle identification
067	Tone adjustment	068	Alternator type
069	GEOGRAPHICAL ZONE	06A	Ecu Memory
06B	Decrement idle speed	06C	Increment of idle speed
06D	Fuel supply prevention	06E	Audio links test
06F	Language	070	Oil change range:current value in KM
071	Oil change range:current value in months	072	Update odometer
073	FUEL GAUGE CALIBRATION	074	ADAC display type
075	Tank capacity	076	UCH
077	Particle filter	078	Gas reserv. capac.
079	Language version	07A	Tyre pressure units
07B	Voice synthesiser	07C	Lights automatic illumination
07D	Seat belt reminder buzzer	07E	CRUISE Control/SP. LIMIT. Speed difference
07F	Customer settings and details	080	Netherlands legislation
081	Fault/s memorised	082	Auto-adaptives
083	Heated windscreen	084	Compressor type
085	Drive ratio	086	Type of power steering
087	Evaporator temperature sensor	088	ESP sensor programming
089	Fuel sender calibration (DOI) .	08A	Fuel sender calibration (EUROPE)
08B	Snedo index	08C	Sytem initialisation
08D	Dynamic correction	08E	Automatic fold-down headlights
08F	Dipped headlights raise	090	Signature
091	Cornering lights	092	Front seat belt retractors
093	With FR chest airbags+head-level airbags	094	W FR chest airbags without head-lvl airbags
095	Without side airbags	096	Driver lap strap pretensioner
097	Passenger's lap strap pretensioner	098	ABS/ESP calibration
099	ORB memory	09A	Check motor torque by ABS
09B	Selector lever locking	09C	Air conditioning with wire connection
09D	Adaptive cruise control	09E	POX AT
09F	PGX MANUAL	0A0	V4Y AUTOMATIC GEARBOX
0A1	V4Y MANUAL	0A2	Other at
0A3	Other manual	0A4	Distance before next oil change
0A5	Change in triggering limit	0A6	Engine/gearbox type
0A7	Increase fuel warning threshold	0A8	Temperature units
0A9	Hands free	0AA	Navigation system
0AB	Vehicle speed signal transmitter	0AC	Bodywork type
0AD	Card/key	0AE	Clock
0AF	Rheostat presence	0B0	Engine type
0B1	External temperature sensor	0B2	Rear screen wiper
0B3	Following tyre change	0B4	Hands-free function
0B5	Daytime running lights	0B6	Tyre pressure monitor function
0B7	Discharge Lamp	0B8	Electric child safety
0B9	Rain/light sensor	0BA	Auto locking warning sound
0BB	Memorising Driver's seat position	0BC	Sunroof
0BD	Hands-free start up	0BE	Light sensor sensitivity
0BF	Hands free locking	0C0	Automatic closing of windows (by card)
0C1	Vehicle family	0C2	Inhibition of selective door opening
0C3	One-Touch Electric windows/Sunroof	0C4	Programming reinitialisation
0C5	INTERVAL OF OIL CHANGE (OCS) OXIDATION	0C6	Temperature display
0C7	Stop fuel supply prevention	0C8	Erase stored misalignment
0C9	Steering angle offset	0CA	km
0CB	miles	0CC	Erase overheating counter
0CD	Erase incorrect cranking counter	0CE	Air conditioning
0CF	Thermoplungers	0D0	Air path programming
0D1	Computer reinitialisation	0D2	Computer reset
0D3	Amplifier reset	0D4	Noise-reducing microphone
0D5	SDO	0D6	Touch screen
0D7	Country model	0D8	Time format
0D9	Engine adaptives	0DA	Programming throttle limits
0DB	Richness regulation programming	0DC	Flywheel target programming
0DD	Cruise control/speed limiter programming	0DE	Turbocharger programming
0DF	Upstream oxygen sensor	0E0	Vacuum pump operation request
0E1	Overspeed Alarm	0E2	Computer initialisation
0E3	Fault memory	0E4	Inhibition of 4-wheel drive function
0E5	Reinstatement of 4-wheel drive function	0E6	Front slide learning
0E7	Rear slide learning	0E8	Lumbar learning
0E9	Steering wheel angle offset sensor	0EA	Transverse acceleration offset sensor
0EB	Brake pressure offset sensor	0EC	Reset
0ED	Steering wheel angle sensor	0EE	Acceleration sensor
0EF	Trailer stability function	0F0	Longitudinal acceleration sensor offset
0F1	Transverse acceleration sensor	0F2	Longitudinal acceleration sensor
0F3	Camshaft sensor programming	0F4	Parametrege prive 1
0F5	Configuration privee 1	0F6	PROGRAMMING THE CODES OF THE FOUR VALVES
0F7	EGR valve programming	0F8	Adaptives on air intake flap fault
0F9	Air damper valve programming	0FA	Rail pressure sensor adaptives
0FB	Proportional richness sensor programming	0FC	Exhaust flap low setting

0FD	Low pressure EGR valve programming	0FE	Swirl flap programming
0FF	Fuel pump programming	100	Air flowmeter programming
101	Particle filter pressure difference sensor	102	SWIRL flap
103	Injection pump adaptatives	104	Starter adaptatives
105	Number of starting cycles	106	EGR bypass programming
107	Catalytic converter	108	High pressure pump counter
109	Stop and start function	10A	Alternator setpoint voltage
10B	OIL CHANGE INTERVAL (OCS): DILUTION	10C	Alcohol level prog.
10D	Activate maintenance mode	10E	Deactivate maintenance mode
10F	Front wheel circumference	110	Rear wheel circumference
111	Reset clutch data	112	Reset clutch data protection
113	Reset gearbox data	114	Number of starting 1
115	Number of starting 2	116	Number of starting 3
117	Number of starting 4	118	Diagnostic trouble codes reset
119	Number of starting	11A	Calculate battery wear counters
11B	Resetting internal protection	11C	Corrosion battery counter memorised
11D	Corrosion battery counter estimated	11E	Battery corrosion counter
11F	Battery cycle counter memorised	120	Battery cycle counter estimated
121	Battery cycle counter	122	Stop/start function configuration
123	Alternator floating voltage	124	Front detection
125	Rear detection	126	Side detection
127	Illuminate hazard lamps upon impact	128	Remote Locking Buzzer
129	Alarm	12A	Scandinavian runnings lights
12B	Second fitting alarm	12C	Trailer present
12D	Hands-free deadlocking	12E	Deadlocking with remote control on key
12F	Configuration Privee 3	130	Programming routine
131	Confirm programming	132	Abandon programming
133	HEAD CARD SIGNAL	134	Read card 2 signal
135	Configuration privee 2	136	Configuration Privee 4
137	Testing card presented	138	HFM programming routine
139	Remote engine starting	13A	Column steering lock
13B	Configuration Reservee 1	13C	Injector adaptives
13D	Waste gate regulation	13E	Program clutch assembly
13F	Automatic gearbox control	140	Shift fork
141	Pass airbag deactivation warning light	142	Driver's front airbag
143	Passenger's front airbag	144	Impact information connection
145	Driver's front buckle pretensioner	146	Passenger's front buckle pretensioner
147	Parking aid	148	Directional headlights
149	Personalised oil change frequency	14A	Electric pump unit
14B	Battery charge warning information	14C	Camshaft sensor Number 2 programming
14D	Control Headlight Motors	14E	Starter wear counter
14F	Power back door cylinder	150	Driver start counter
151	Idle stop and start counter	152	Configuration of system components
153	Programme slip point	154	Erase auto-adaptive values
155	Clutch wear	156	Programming selection/engaging zones
157	Write clutch initial closed position	158	Shift drum reference position
159	Program clutch adjustment	15A	Programme clutch position
15B	Program clutch 1 adjustment	15C	Program clutch 2 adjustment
15D	Engine immobiliser	15E	Restart the computer
15F	LCD display fuel gauge calibration	160	Analogic display fuel gauge calibration
161	Computer configuration	162	Drive type configuration
163	ADAC configuration	164	External temperature
165	Free shift	166	Seat belt warning module
167	Hill start	168	Improved grip function
169	Stop and start configuration	16A	BUZZER
16B	Adblue tank programming	16C	Adblue pump module programming
16D	Adblue Injector Programming	16E	Adblue dosing module catalyst
16F	Adblue small quantity test metering	170	Adblue large volume test metering
171	Adblue pressure preparation test	172	Adblue spray test
173	Adblue emptying test	174	Adblue leak test
175	Adblue Injector Release Test	176	Adblue Backflow Pump Test
177	Adblue first filling test	178	Memorisation of speeds
179	Fan assembly	17A	Driving water pump
17B	Inverter fan assembly	17C	Gearbox vehicle acceleration sensor init.
17D	Injection time programming	17E	Gear change paddles
17F	Start authorisation from BMS safety	180	Start authorisation from BMS
181	System configuration	182	Constructor/manufacturer
183	Flashing buzzer	184	Computer programming/initialisation
185	Average air temperature	186	Particle filter relative pressure sensor
187	Exhaust injector circuit	188	Preheater unit
189	Pinking sensor programming	18A	Ignition coil adaptive
18B	Modus fuel sender calibration (EUROPE)	18C	Modus long fuel sender calibration (EUROPE)
18D	Vehicle function programming	18E	Erase idle regulation adaptives
18F	Assisted engagement when stationary	190	Adaptive value-TFS
191	Adaptive value-A/F ratio	192	Catalytic converter test
193	Comande Privee 1	194	External components
195	Emergency call number	196	Temperature display
197	Subwoofer	198	Without inhibition switch
199	Seat belt light	19A	Driver's front side impact sensor
19B	Passenger's front side impact sensor	19C	Radio
19D	Lighting	19E	Unit of volume
19F	Configuration Reservee 10	1A0	Steering lock
1A1	Self learning value erase-butane ratio	1A2	Self learning value Erase-fuel Pump PWM
1A3	Fuel pump forced conversion	1A4	Mode number
1A5	Air conditioning type	1A6	Calibration
1A7	Automatic locking when driving	1A8	Wiper intermittent speed ring
1A9	Opening elements central locking	1AA	Automatic lighting function
1AB	Automatic wiping function	1AC	Key type
1AD	Gradual switching on and off of courtesy	1AE	Driver's front inertia reel
1AF	Passenger's front inertia reel	1B0	Sensor offsets
1B1	Slope sensor adjustment	1B2	Type of parking brake
1B3	Free shift display	1B4	Pointer animation
1B5	Daytime backlights	1B6	Blind spot detection
1B7	Programming of seat stops	1B8	Hands-free cards low battery counter
1B9	Interior aerial 1 test	1BA	Interior aerial 2 test
1BB	External boot aerial test	1BC	Front left-hand external aerial test
1BD	Front right-hand external aerial test	1BE	Stored energy management data
1BF	Timed lighting supply	1C0	VEH. speed at initialisation
1C1	Navigation	1C2	Gsm connectivity
1C3	Gsm antenna circuit	1C4	Parametrage privee 2
1C5	Modification of parameters after	1C6	Configuring the multimedia computer
1C7	Idle speed reference	1C8	Clutch initial closed position
1C9	Write date new clutch fitted	1CA	Program clutch open position
1CB	Compressor feedback	1CC	Tachograph
1CD	ABS/ESP	1CE	Tyres
1CF	Gsm antenna	1D0	Traction battery lock
1D1	Traction battery interlock	1D2	Interior lighting
1D3	Interior Ambience lighting	1D4	EEPROM memory write procedure
1D5	Front left-hand chest-level side airbag	1D6	Left-hand curtain airbag
1D7	Front right-hand chest-level side airbag	1D8	Right-hand curtain airbag
1D9	Left-hand side impact sensor	1DA	Right-hand side impact sensor
1DB	Front left-hand seat belt sensor	1DC	Front right-hand seat belt sensor
1DD	Front left-hand buckle pretensioner	1DE	Front right-hand buckle pretensioner
1DF	Angle of assembly	1E0	VACUUM pump ageing counter
1E1	Charge water pump	1E2	Heating
1E3	Overspeed light	1E4	Rheostat lighting
1E5	Fuel level display update	1E6	Electric power assisted steering
1E7	Parametrage privee 98	1E8	Maintenance autonomy interval in km

1E9	Maintenance autonomy interval in months	1EA	Maintenance autonomy:current value in km
1EB	Maintenance autonomy:current value month	1EC	Parametrage prive 3
1ED	Parametrage prive 4	1EE	SVT configuration
1EF	EGR programming	1FO	Manifold pressure sensor programming
1FI	Fuel gauge calibration LCD (Japan)	1F2	Fuel gauge calibration needle (Japan)
1F3	Distance before next oil change configuration	1F4	Rev counter
1F5	Injection prohibition	1F6	Parametrage prive 250
1F7	Reset radio	1F8	BMS
1F9	Instrument panel	1FA	Charge plug
1FB	Module change	1FC	Rear loud speaker
1FD	Front left-hand inertia wheel	1FE	Front right-hand inertia wheel
1FF	Inhibit EVAP strategy	200	Activate EVAP programming
201	Static test	202	Parametrage prive 159
203	Parametrage prive 160	204	Brake pedal position 1 and 2 sensor status offset
205	Piston pressure sensor status offset	206	Master cylinder pressure sensor offset
207	Piston pressure sensor offset	208	UBP solenoid valve
209	Wheel circumference	20A	Traction battery range
20B	GEAR positions memorization	20C	Econometer
20D	Fuel flow regulator	20E	Injector adaptives Number 1
20F	Injector adaptives Number 2	210	Injector adaptives Number 3
211	Injector adaptives Number 4	212	With SWIRL flap
213	Oil vapour heater	214	Hour setting
215	ESM configuration	216	ESM inhibition command
217	ESM Activation command	218	Tuning version number
219	Load Area	21A	start Control Counter
21B	Oil pressure warning threshold	21C	Oil temperature measurement threshold
21D	Oil measurement timer	21E	Parking proximity sensor function
21F	Voice synthesiser	220	Front buzzer volume
221	Front tone setting	222	Alternator type
223	Additional heating	224	Rear shelves
225	Rain sensor	226	Automatic seat recall
227	Card locking	228	Card reminder warning
229	Timer courtesy light	22A	Door unlocking mode
22B	Unlocking mode, doors hands free	22C	Power-assisted steering program
22D	Overspeed alarm for arabia	22E	Rear access aerials
22F	Prevention of electrical consumers	230	Stop electrical consumer prevention
231	RAIN/Luminosity Sensor Type	232	Automatic folding of door mirrors
233	Neutral position programming	234	Light sensor signal
235	Reinit, extreme cold reverse gear engagement	236	Test parameters
237	Particle filter adaptives	238	CD changer and auxiliary input
239	Multiplexed network configuration	23A	Van fast idle speed increase
23B	Van fast idle speed decrease	23C	Boiler
23D	Rear right-hand inertia reel	23E	REAR LEFT-HAND INERTIA WHEEL
23F	Steering angle sensor initialisation	240	Anti theft alarm trigger S/W
241	One-touch electric windows	242	Head lamp battery saver function
243	Passenger's compartment heating resistor	244	Raising of elect. window (with Anti PINCH)
245	BONCLE	246	Indicator light configuration
247	CD changer	248	Sensor type
249	Idle air volume learning-factory mode	24A	Idle air volume learning-service mode
24B	Toxicity sensor	24C	Rear screen demister
24D	Heated rear screen indicator light circuit	24E	Parametrage prive 9
24F	Reset oil change counter	250	Shoe lining energy counter
251	Rear brake unit initialisation	252	Rear brake unit repositioning
253	BRAKE LINING FRICTION LEARNING	254	Idle speed learning
255	Torque learning	256	Parametrage prive 237
257	Engine parameter adaptives	258	Power steering electric pump unit
259	Number of heating elements	25A	Hazard lamps recall on TRF
25B	Adjust oil change counter	25C	ABS type
25D	Radiofrequency type	25E	Sunroof control unit
25F	Uch type	260	Cruise control/speed limiter
261	Raid function authorisation by diag	262	TYPE N4
263	With passenger's airbag	264	Without passenger's airbag
265	Without passenger's frontal airbag	266	Without Passenger's seat
267	Without airbags (pretensioners only)	268	With passenger's airbags
269	Comp configuration	26A	With side airbags
26B	Without fuel pump cut out	26C	With fuel pump cut out
26D	Driver's side rear inertia reel	26E	Passenger's side rear inertia reel
26F	Driver's seat sensor	270	With range extension
271	Without range extension	272	100 Ah traction battery
273	Range extender	274	Air conditioning programming
275	Oil change counter offset	276	With air conditioning
277	Without air conditioning	278	With OBD
279	Without OBD	27A	Air conditioning connection fault finding
27B	Lever locking connection fault finding	27C	Engine torque control function
27D	Enter access code	27E	Programming with 1 key
27F	Programming with 2 keys	280	With SDO
281	Without SDO	282	Diesel/petrol ENG immob without coded solenoid valve
283	Diesel engine immobiliser	284	With INFRA-RED remote control
285	With radio frequency remote control	286	Without timed courtesy light
287	With timed courtesy light	288	Coded diesel solenoid valve engine immobiliser
289	End of key reallocation validation	28A	Abandon key reallocation
28B	Type 1 Unit	28C	Type 2 unit
28D	Engine immobiliser authorisation	28E	Engine immobiliser prohibition
28F	With alarm	290	Without alarm
291	With automatic transmission	292	Without automatic transmission
293	With power assisted steering	294	Without power assisted steering
295	Preheating prevention	296	Stop preheating prevention
297	Power assisted steering	298	Without power steering electric pump unit
299	With power steering electric pump unit	29A	With thermoplungers
29B	Without thermoplungers	29C	With boiler
29D	Without boiler	29E	Without air conditioning
29F	With air conditioning	2A0	ADAPTIVES ON EGR VALVE FAULT
2A1	Cruise ctrl/speed limiter	2A2	Without air CON./without heated windscreen
2A3	With air CON./without heated windscreen	2A4	Without air CON./with heated windscreen
2A5	With air conditioning/with heated windscreen	2A6	With cruise control
2A7	Without cruise control	2A8	Without SWIRL flap
2A9	Control panel type	2AA	BII type
2AB	Vehicle engine type	2AC	With tailgate module
2AD	Without tailgate module	2AE	With radio display
2AF	Without radio display	2B0	Opening rear screen
2B1	Fixed rear screen	2B2	With air bag
2B3	Without air bag	2B4	SDM air bag
2B5	EC6 air bag	2B6	Vehicle type: all types except JEOP/IEOE
2B7	Vehicle type: IEDE or JEOP	2B8	Left hand drive
2B9	Right hand drive	2BA	With ADAC
2BB	Without ADAC	2BC	With hazard lamps recall on TRF
2BD	Without hazard lamps recall on TRF	2BE	One-touch central door locking button
2BF	Rocker central door locking button	2C0	Raid function authorisation
2C1	Auto locking when driving function prevention	2C2	Without variable intermittent wipe
2C3	With variable w' screen wiper intermittent	2C4	Without overspeed warning
2C5	With overspeed warning	2C6	Without running lights
2C7	With running lights	2C8	With automatic re LOCKING
2C9	Without automatic re LOCKING	2CA	Without hazard lights upon impact
2CB	With hazard lights upon impact	2CC	Number of cylinders configuration
2CD	Left Hand Drive/4 cylinder configuration	2CE	Left Hand Drive/6 cylinder configuration
2CF	Right Hand Drive/4 cylinder configuration	2D0	Left Hand Drive/diesel configuration
2D1	Right Hand Drive/6 cylinder configuration	2D2	Right Hand Drive/diesel configuration
2D3	Engine immobiliser 2	2D4	With ABS

2D5	No ABS	2D6	Petrol injection
2D7	Diesel injection	2D8	With self levelling suspension
2D9	Without self levelling suspension	2DA	With catalytic converter
2DB	Without catalytic converter	2DC	Oil level displayed 20sec
2DD	Oil level displayed 20 sec when ADAC pressed	2DE	Erase OBD fault memory
2DF	Memory saved	2E0	With manual gearbox
2E1	Idle speed setting incrementation	2E2	Idle speed setting decrementation
2E3	With AC (fixed capacity compressor)	2E4	With AC (variable capacity compressor)
2E5	Oil change counter reset	2E6	With heated rear screen
2E7	Without heated rear screen	2E8	With coolant sensor
2E9	Without coolant sensor	2EA	With evaporator temperature sensor
2EB	Without evaporator temperature sensor	2EC	With recycling motor timer
2ED	Without recycling motor timer	2EE	With permanent type control
2EF	With one-touch type control	2F0	With harrison type compressor
2F1	With sanden type compressor	2F2	BEHR PROBE configuration
2F3	HOKURIKU probe configuration	2F4	Siemens probe configuration
2F5	Eeprom probe configuration	2F6	Configuration with recycling flap auto-setting
2F7	Configuration without recycling flap auto-	2F8	Right hand drive
2F9	Left-hand drive	2FA	Avantime (P4R) : with heated windscreen
2FB	Avantime (P4R) : without heated windscreen	2FC	Avantime (except P4R) :with heated windscr.
2FD	Avantime (expt P4R) :without heated windscr.	2FE	Espace: with evaporator sensor
2FF	Espace: without evaporator sensor	300	Writing conformity