

CATERPILLAR V20.21 FUNCTION LIST

| System | System | System Information | Read Fault Code | clear Fault Code | Read Datastream | Action Test | Special Test | Notes |
|------------|-----------------------|--------------------|-----------------|------------------|-----------------|-------------|--------------|--|
| 320D/323 D | Hydraulic system | √ | √ | √ | √ | | | |
| | Engine control module | √ | √ | √ | √ | | √ | 1.Read Injector data 2.Write injector data 3.Injector exchange test 4.Cylinder cutoff Test 5.Parameters |
| 312 | Hydraulic system | √ | √ | √ | √ | | | |
| | Engine control module | √ | √ | √ | √ | | √ | 1.Read Injector data 2.Write injector data 3.Injector exchange test 4.Cylinder cutoff Test 5.Parameters |
| 320C/323 C | Engine control module | √ | √ | √ | √ | | √ | 1.Parameters 2.Machine optional components 3.Control input installation 4.Driving speed shift parameters 5.Throttle knob engine speed 6.Throttle knob hydraulic power percentage 7.Recommended maintenance intervals |
| 385C/385 D | Hydraulic system | √ | √ | √ | √ | | | |
| | Engine control module | √ | √ | √ | √ | | √ | 1.Read Injector data 2.Write injector data 3.Injector exchange test 4.Cylinder cutoff Test 5.Parameters |
| 330C/330 D | Hydraulic system | √ | √ | √ | √ | | | |
| | Engine control module | √ | √ | √ | √ | | √ | 1.Injector data#Mode 1 2.Injector exchange test 3.Injector data#Mode 2 4.Cylinder cutoff Test 5.Configuration |
| | Monitor | √ | | | | | | |

CATERPILLAR V20.21 FUNCTION LIST

| System | System | System Information | Read Fault Code | clear Fault Code | Read Datastream | Action Test | Special Test | Notes |
|------------|-----------------------|--------------------|-----------------|------------------|-----------------|-------------|--------------|--|
| 325C/329 D | Hydraulic system | √ | √ | √ | √ | | √ | 1.Parameters 2.Machine optional components 3.Control input installation 4.Driving speed shift parameters 5.Throttle knob engine speed 6.Throttle knob hydraulic power percentage 7.Recommended maintenance intervals |
| | Engine control module | √ | √ | √ | √ | | √ | 1.Injector data#Mode 1 2.Injector exchange test 3.Injector data#Mode 2 4.Cylinder cutoff Test 5.Configuration |
| | Monitor | √ | | | | | | |