

# BOBCAT V20.31 FUNCTION LIST

System	System	System Information	Read Fault Code	clear Fault Code	Read Datastream	Action Test	Special Test	Parameters and Features
BOBCAT	Cummins	√	√	√	√	√	√	√

XTOOL