



Shenzhen Xtooltech Co., Ltd

BJBenz Function List V21.00

Tips and Instructions:

The programming function only supports H6PRO, H6PRO Master ,A80Pro, A80ProMaster, NitroGT, NitroXT Edition products.

* This feature is new.

✓ This feature is supported.

× This feature is not supported.

※ This feature is partially supported.

Model	Model Series	Control Unit Groups	System Name	Read ECU Information	Read Trouble Code	Clear Trouble Code	Live Data	Read Freeze Frame	Actuation Test	Special Functions	Coding	programming
A-Class	177	Air conditioning	AAC-Automatic air conditioning	✓	✓	✓	×	×	×	×	×	×
A-Class	177	Air conditioning	AAC-Automatic air conditioning	✓	✓	✓	✓	×	×	×	×	×
A-Class	177	Air conditioning	AAC-Automatic air conditioning	✓	✓	✓	✓	×	ACT0416,ACT0182,ACT0417,ACT0186,ACT0194,ACT0195,ACT0197,ACT0196,ACT0028,	SP1065,SP1066,SP1067,SP1159,SP1160	×	×
A-Class	177	Air conditioning	STH-Stationary heater	✓	✓	✓	✓	×	ACT0202	×	×	×
A-Class	177	Air conditioning	TSTH-Radio remote control of stationary heater	✓	✓	✓	✓	×	ACT0203,ACT0418	×	×	×
A-Class	177	Body	"Driver" seat heater	✓	✓	✓	✓	×	ACT0411,ACT0412,ACT0413,ACT0414,ACT0415	SP1157,SP1158	×	×
A-Class	177	Body	"Front passenger" seat heater	✓	✓	✓	✓	×	×	×	×	×
A-Class	177	Body	AML-Ambiance light	✓	✓	✓	✓	×	ACT0389,ACT0390,ACT0391,ACT0392,ACT0393,ACT0394,ACT0395,ACT0396,ACT0043	SP1149	×	×
A-Class	177	Body	Anti glare interior rearview mirror(DBE)	✓	✓	✓	✓	×	×	×	×	×
A-Class	177	Body	AS-Alarm siren(H3/1)	✓	✓	✓	✓	×	ACT0309,ACT0465,ACT0466	×	×	×
A-Class	177	Body	ATA-Interior motion sensor	✓	✓	✓	✓	×	×	×	×	×
A-Class	177	Body	BMS-Battery management system	✓	✓	✓	✓	×	ACT0453,ACT0454,ACT0455	SP1197	×	×
A-Class	177	Body	BSN-Battery sensor(B95)	✓	✓	✓	✓	×	×	×	×	×
A-Class	177	Body	DC/DC-DC/DC converter	✓	✓	✓	✓	×	×	×	×	×
A-Class	177	Body	DCCU-Direct current charge connection unit	✓	✓	✓	✓	×	×	×	×	×
A-Class	177	Body	Driver side SAM-Front signal acquisition and actuation module	✓	✓	✓	✓	×	×	×	×	×
A-Class	177	Body	EZS-Electronic ignition switch	✓	✓	✓	✓	×	ACT0372	×	×	×
A-Class	177	Body	FSW-Windshield wiper	✓	✓	✓	✓	×	×	×	×	×
A-Class	177	Body	GES-Hand motion sensor	✓	✓	✓	✓	×	×	×	×	×
A-Class	177	Body	GTO-Garage door	✓	✓	✓	✓	×	×	×	×	×
A-Class	177	Body	HE-Hand detection	✓	✓	✓	✓	×	×	×	×	×
A-Class	177	Body	LIB-Lithium ion battery	✓	✓	✓	✓	×	×	×	×	×
A-Class	177	Body	LIB-Lithium ion battery	✓	✓	✓	✓	×	×	×	×	×
A-Class	177	Body	LRE-Steering wheel electronics	✓	✓	✓	✓	×	×	×	×	×
A-Class	177	Body	Multifunction control unit-Multifunction control unit	✓	✓	✓	✓	×	×	×	×	×

A-Class	177	Body	Multifunction control unit- Multifunction control unit	√	√	√	√	×	ACT0204	×	×	×
A-Class	177	Body	N38 (Rear switching module)	√	√	√	√	×	×	×	×	×
A-Class	177	Body	OCP-Overhead control panel	√	√	√	√	×	×	×	×	×
A-Class	177	Body	PSD-Panoramic sliding roof	√	√	√	√	×	×	×	×	×
A-Class	177	Body	RevETR LF-Left front reversible emergency tensioning retractor	√	√	√	√	×	×	×	×	×
A-Class	177	Body	RevETR LF-Left front reversible emergency tensioning retractor	√	√	√	√	×	ACT0209	×	×	×
A-Class	177	Body	RevETR RF-Right front reversible emergency tensioning	√	√	√	√	×	×	×	×	×
A-Class	177	Body	RevETR RF-Right front reversible emergency tensioning	√	√	√	√	×	ACT0213	×	×	×
A-Class	177	Body	RGLS-Rain/light sensor(B38/2)	√	√	√	√	×	×	×	×	×
A-Class	177	Body	SCM-Steering column module	√	√	√	√	×	×	×	×	×
A-Class	177	Body	SG LG-Charger	√	√	√	√	×	ACT0405,ACT0406,ACT0407, ACT0408,ACT0409,ACT0410	×	×	×
A-Class	177	Body	SG LML VL-LED matrix of left front lamp unit	√	√	√	√	×	×	×	×	×
A-Class	177	Body	SG LML VL-LED matrix of left front lamp unit	√	√	√	√	×	×	×	×	×
A-Class	177	Body	SG SW L-Left headlamp	√	√	√	√	×	×	×	×	×
A-Class	177	Body	SG SW R-Right headlamp	√	√	√	√	×	×	×	×	×
A-Class	177	Body	SG-LML-VR-LED matrix of right front lamp unit	√	√	√	√	×	×	×	×	×
A-Class	177	Body	SOGESTAR2-Sound generator for electric vehicle	√	√	√	√	×	×	×	×	×
A-Class	177	Body	SRS-Supplemental restraint	√	√	√	√	√	×	×	×	×
A-Class	177	Body	STM-Mirror taximeter	√	√	√	√	×	×	×	×	×
A-Class	177	Body	Trailer recognition module- Trailer recognition	√	√	√	√	×	×	×	×	×
A-Class	177	Body	WSS-Weight sensing	√	√	√	√	×	×	×	×	×
A-Class	177	Chassis	ADS-Adaptive damping system(N51/5)	√	√	√	√	×	×	SP1061	×	×
A-Class	177	Chassis	ADS-Adaptive damping system(N51/5)	√	√	√	√	×	×	SP1061	×	×
A-Class	177	Chassis	AMG DRVU-AMG DRIVE UNIT	√	√	√	√	×	ACT0401,ACT0402,ACT0403, ACT0404	SP1153,SP1154,SP1155	×	×
A-Class	177	Chassis	ES - Electric power steering	√	√	√	√	×	×	SP1071,SP1069,SP1167, SP1168,SP1169	×	×
A-Class	177	Chassis	ESP- Electric stability program	√	√	√	√	√	ACT0069,ACT0070,ACT0285, ACT0288	SP1174,SP1175,SP1176, SP1177,SP1178,SP1179, SP1180,SP1181,SP1182,	×	×
A-Class	177	Chassis	ESP- Electric stability program	√	√	√	√	×	ACT0069,ACT0070,ACT0285, ACT0288	SP1174,SP1175,SP1176, SP1177,SP1178,SP1179, SP1180,SP1181,SP1182,	×	×
A-Class	177	Chassis	Lower control panel(DRVU)	√	√	√	×	×	×	×	×	×
A-Class	177	Drive	48V on board electrical system of ISG starter generator	√	√	√	×	×	×	×	×	×

A-Class	177	Drive	CDI-Engine Electronics CRR2 for Internal Combustion Engine OM608	✓	✓	✓	✓	✓	ACT0336,ACT0005,ACT0002,ACT0031,ACT0030,ACT0032,ACT0022,ACT0328,ACT0026,ACT0033,ACT0337	SP1000,SP1118,SP1119,SP1120,SP1121,SP1122,SP1123,SP1124,SP1125,SP1126,SP1127,SP1022,SP1128,SP1021,SP1129,	×	×
A-Class	177	Drive	FSCU-Fuel pump	✓	✓	✓	✓	×	×	×	×	×
A-Class	177	Drive	N127 (Drivetrain control unit)	✓	✓	✓	×	×	×	×	×	×
A-Class	177	Drive	N127 (Drivetrain control unit)	✓	✓	✓	✓	×	ACT0028,ACT0430,ACT0431,ACT0432,ACT0433,ACT0007,ACT0434,ACT0435,ACT0436,ACT0437,ACT0438,ACT0439,ACT0440,ACT0441,ACT0442,ACT0443,ACT0444,ACT0445,ACT0446,ACT0447,ACT0448,	SP1186,SP1042,SP1025,SP1187,SP1188,SP1189,SP1190,SP1191,SP1192	×	×
A-Class	177	Drive	N15/13 (Double clutch transmission control unit)	✓	✓	✓	✓	×	×	×	×	×
A-Class	177	Drive	N3/10-Motor electronics "EM71" for combustion engine "M282"	✓	✓	✓	✓	✓	ACT0330,ACT0002,ACT0005,ACT0456,ACT0323,ACT0324,ACT0325,ACT0025,ACT0328,ACT0329,ACT0022,ACT0457,	SP1001,SP1004,SP1109,SP1115,SP1017,SP1198	×	×
A-Class	177	Drive	N3/10-Motor electronics "MED41" for combustion engine "M260/M264"	✓	✓	✓	✓	✓	ACT0330,ACT0003,ACT0459,ACT0323,ACT0324,ACT0333,ACT0025,ACT0328,ACT0331,ACT0332,ACT0004,ACT0005,ACT0456,ACT0002,ACT0460,ACT0329,ACT0022,ACT0325,	SP1199,SP1117	×	×
A-Class	177	Drive	N3/10-Motor electronics "MRG1AMGR4" for combustion engine "M139"	✓	✓	✓	✓	×	ACT0330,ACT0002,ACT0025,ACT0005,ACT0022,ACT0456,ACT0329,ACT0462,ACT0328,ACT0463,ACT0464,ACT0331	SP1001,SP1004,SP1200,SP1201,SP1202,SP1203,SP1204,SP1110,SP1109,SP1139,SP1017,SP1111,	×	×
A-Class	177	Drive	N3/40-Motor electronics "MRD1" for combustion engine "OM654"	✓	✓	✓	✓	✓	ACT0001,ACT0005,ACT0006,ACT0321,ACT0008,ACT0009,ACT0010,ACT0322,ACT0011,ACT0012,ACT0016,ACT0018,ACT0022,ACT0023,ACT0024,ACT0026,ACT0000,ACT0338,ACT0339,ACT0340,ACT0341	SP1001,SP1000,SP1130,SP1125,SP1131,SP1132,SP1133,SP1134,SP1135,SP1136,SP1017,SP1137,SP1138,SP1024,SP1139,SP1140,SP1015,SP1141,SP1142,SP1143,SP1144,SP1021,SP1022,SP1145,	×	×
A-Class	177	Drive	SCR-Selective catalytic reduction	✓	✓	✓	✓	×	ACT0424,ACT0425,ACT0426,ACT0427,ACT0428,ACT0429	SP1184,SP1185	×	×
A-Class	177	Drive	SG EM-Power electronics	✓	✓	✓	✓	×	ACT0451,ACT0452	SP1193,SP1194,SP1195,SP1196,SP1150	×	×
A-Class	177	Drive	SG LML VR-LED matrix of right front lamp unit	✓	✓	✓	✓	×	×	×	×	×
A-Class	177	Drive	VG-All-wheel drive	✓	✓	✓	✓	×	×	×	×	×
A-Class	177	Drive	VG-All-wheel drive	✓	✓	✓	✓	×	ACT0043	SP1171	×	×
A-Class	177	Drive	VG-All-wheel drive	✓	✓	✓	✓	×	ACT0422,ACT0423	SP1099,SP1170	×	×
A-Class	177	Drive	Y3/14n4 (Dual clutch transmission fully integrated transmission control unit)	✓	✓	✓	×	×	×	×	×	×

A-Class	177	Drive	Y3/14n4 (Dual clutch transmission fully integrated transmission control unit)	√	√	√	×	×	×	×	×	×
A-Class	177	Driver assistance	DTR-DISTRONIC	√	√	√	√	×	×	×	×	×
A-Class	177	Driver assistance	DTR-DISTRONIC	√	√	√	√	×	×	SP1161,SP1162	×	×
A-Class	177	Driver assistance system	IRS HLA-Outer left rear integrated radar sensor (B92/11)	√	√	√	√	×	×	SP1150,SP1151	×	×
A-Class	177	Driver assistance system	IRS HRA-Outer right rear integrated radar sensor (B92/6)	√	√	√	√	×	×	SP1150,SP1151	×	×
A-Class	177	Driver assistance	KAR-Augmented reality camera	√	√	√	√	×	×	×	×	×
A-Class	177	Driver assistance system	MFK-Multifunction camera(mono)(A40/11)	√	√	√	√	×	ACT0181,ACT0065	SP1156	×	×
A-Class	177	Driver assistance system	MFK-Multifunction camera(stereo)(A40/13)	√	√	√	√	×	ACT0181,ACT0065	SP1063	×	×
A-Class	177	Driver assistance	NBR LR-Left rear short-range	√	√	√	√	×	×	SP1173	×	×
A-Class	177	Driver assistance	NBR RR-Right rear short-range	√	√	√	√	×	×	SP1172	×	×
A-Class	177	Driver assistance	PTS-PARKTRONIC	√	√	√	√	×	ACT0421,ACT0306	SP1166	×	×
A-Class	177	Driver assistance	RFK-Backup camera	√	√	√	√	×	×	SP1152	×	×
A-Class	177	Driver assistance system	SG AWF-COLLISION PREVENTION ASSIST	√	√	√	√	×	×	SP1063	×	×
A-Class	177	Driver assistance	SGR-Radar sensors control unit	√	√	√	√	×	ACT0419,ACT0420	SP1163,SP1164,SP1165	×	×
A-Class	177	Driver assistance system	TPM-Tire pressure monitor(N88)	√	√	√	√	×	ACT0078,ACT0079,ACT0081,ACT0080	SP1053	×	×
A-Class	177	Information and communication	Audio-Audio or COMAND	√	√	√	×	×	×	×	×	×
A-Class	177	Information and communication	CSM-Windshield reader system	√	√	√	√	×	×	×	×	×
A-Class	177	Information and communication	CTEL-Cellular telephone	√	√	√	√	×	×	×	×	×
A-Class	177	Information and communication	HERMES-control unit for telematics services	√	√	√	√	×	×	SP1046	×	×
A-Class	177	Information and communication	HUD-Head up display	√	√	√	√	×	ACT0210,ACT0212	×	×	×
A-Class	177	Information and communication	IC-Instrument cluster	√	√	√	√	×	ACT0039,ACT0397,ACT0048,ACT0210,ACT0398,ACT0399,ACT0050,ACT0400	SP1043,SP1044,SP1045	×	×
A-Class	177	Information and communication	MTAS-Mobile phone cradle	√	√	√	√	×	×	×	×	×
A-Class	177	Information and communication	SOUND-Sound system	√	√	√	√	×	×	×	×	×
A-Class	177	Information and communication	TPAD-Touchpad	√	√	√	√	×	×	×	×	×
A-Class	177	Information and communication	ZAN-Audio/COMAND display	√	√	√	√	×	ACT0291,ACT0206,ACT0039	×	×	×
A-Class	177	Seats and Doors	DCU LR-Left rear door	√	√	√	√	×	ACT0360,ACT0361,ACT0362,ACT0363,ACT0347,ACT0364,ACT0365,ACT0366	SP1080,SP1147,SP1148	×	×

A-Class	177	Seats and Doors	DCU RF-Right front door	√	√	√	√	×	ACT0353,ACT0274,ACT0273, ACT0354,ACT0283,ACT0284, ACT0281,ACT0282,ACT0355, ACT0278,ACT0356,ACT0357, ACT0347,ACT0279,ACT0348, ACT0349,ACT0358,ACT0359,	SP1080,SP1147,SP1148	×	×
A-Class	177	Seats and Doors	DCU RR-Right rear door	√	√	√	√	×	ACT0367,ACT0368,ACT0369, ACT0370,ACT0347,ACT0371, ACT0365,ACT0366	SP1080,SP1147,SP1148	×	×
A-Class	177	Seats and Doors	ESA Front passenger-Electric seat adjustment Front passenger	√	√	√	√	×	ACT0230,ACT0378,ACT0234, ACT0379,ACT0233,ACT0380, ACT0381,ACT0382	SP1075	×	×
A-Class	177	Seats and Doors	ESV Driver-Electric seat adjustment Driver	√	√	√	√	×	ACT0214,ACT0373,ACT0218, ACT0374,ACT0217,ACT0375, ACT0376,ACT0377	SP1075	×	×
A-Class	177	Seats and Doors	LFD-Left front door	√	√	√	√	×	ACT0342,ACT0255,ACT0254, ACT0343,ACT0269,ACT0270, ACT0267,ACT0268,ACT0344, ACT0261,ACT0345,ACT0346, ACT0347,ACT0263,ACT0348, ACT0349,ACT0350,ACT0351,	SP1080,SP1147,SP1148	×	×
A-Class	177	Seats and Doors	MKS LF-Left front multicontour seat	√	√	√	√	×	ACT0383,ACT0384,ACT0385, ACT0386,ACT0387,ACT0388	×	×	×
A-Class	177	Seats and Doors	MKS RF-Right front multicontour seat	√	√	√	√	×	ACT0383,ACT0384,ACT0385, ACT0386,ACT0387,ACT0388	×	×	×
A-Class	177	Seats and Doors	MKS-BFS-Front passenger more copy the seat	√	√	√	√	×	ACT0383,ACT0384,ACT0386	×	×	×
A-Class	177	Seats and Doors	MKS-FS-Pilot multi-profile seat	√	√	√	√	×	ACT0383,ACT0384,ACT0386	×	×	×
A-Class	177	Seats and Doors	S22 (Driver"s door seat adjustment switch)	√	√	√	×	×	×	×	×	×
A-Class	177	Seats and Doors	S22 (Driver"s door seat adjustment switch)	√	√	√	√	×	×	×	×	×
A-Class	177	Seats and Doors	S23 (Front passenger door seat adjustment switch)	√	√	√	×	×	×	×	×	×
A-Class	177	Seats and Doors	S23 (Front passenger door seat adjustment switch)	√	√	√	√	×	×	×	×	×
A-Class	177	Seats and Doors	S47/2 (Driver door switch	√	√	√	×	×	×	×	×	×
A-Class	177	Seats and Doors	S47/2 (Driver door switch	√	√	√	√	×	×	×	×	×
A-Class	177	Seats and Doors	S47/3 (Front passenger door switch module)	√	√	√	×	×	×	×	×	×
A-Class	177	Seats and Doors	S47/3 (Front passenger door switch module)	√	√	√	√	×	×	×	×	×
A-Class	177	Seats and Doors	S51/1 (Driver seat climate control switch group)	√	√	√	√	×	×	×	×	×
A-Class	177	Seats and Doors	S51/1 (Driver"s door seat heating switch)	√	√	√	×	×	×	×	×	×
A-Class	177	Seats and Doors	S51/2 (Front passenger door seat heating switch)	√	√	√	×	×	×	×	×	×
A-Class	177	Seats and Doors	S51/2 (Front passenger seat climate control switch group)	√	√	√	√	×	×	×	×	×

B-Class	242/246	Air conditioning	AAC-Automatic air conditioning	√	√	√	√	×	ACT0182,ACT0183,ACT0184,ACT0185,ACT0028,ACT0186,ACT0187,ACT0188,ACT0189,ACT0190,ACT0191,ACT0192,ACT0193,ACT0194,ACT0195,	SP1065,SP1066,SP1067	×	√
B-Class	242/246	Air conditioning	STH-Stationary heater	√	√	√	√	×	ACT0200,ACT0201,ACT0202,ACT0203	SP1068	×	√
B-Class	242/246	Body	AISP-Dimming inside rearview mirror(A67)	√	√	√	√	×	×	×	×	×
B-Class	242/246	Body	AS-Alarm siren(H3/1)	√	√	√	×	×	ACT0309	×	×	×
B-Class	242/246	Body	AS-Alarm siren(H3/1)	√	√	√	√	×	ACT0309	×	×	×
B-Class	242/246	Body	B38/2-Rain/light sensor(RGLS)	√	√	√	√	×	×	×	×	×
B-Class	242/246	Body	B38/2-Rain/light sensor(RGLS)	√	√	√	√	×	×	SP1098	×	×
B-Class	242/246	Body	BSN-Battery sensor(B95)	√	√	√	√	×	×	×	×	×
B-Class	242/246	Body	BSN-Battery sensor(B95)	√	√	√	√	×	×	×	×	×
B-Class	242/246	Body	E1n7 (Actuation module, LED exterior lighting, left front)	√	√	√	√	×	×	×	×	×
B-Class	242/246	Body	E2n7 (Actuation module, LED exterior lighting, right front)	√	√	√	√	×	×	×	×	×
B-Class	242/246	Body	EZS-Electronic ignition lock	√	√	√	√	×	×	×	CD0621	×
B-Class	242/246	Body	EZS-Electronic ignition lock	√	√	√	√	×	×	×	×	×
B-Class	242/246	Body	EZS-Electronic ignition lock	√	√	√	√	×	×	×	×	×
B-Class	242/246	Body	EZS-Electronic ignition switch	√	√	√	√	×	×	SP1048,SP1049,SP1050	CD0621,CD0622,CD0623,CD0624,CD0625	×
B-Class	242/246	Body	GTO-Garage door	√	√	√	√	×	×	×	×	×
B-Class	242/246	Body	IMS-Interior motion sensor	√	√	√	√	×	ACT0075,ACT0076,ACT0077	×	×	√
B-Class	242/246	Body	IRS HLA-Outer left rear intelligent radar sensor system	√	√	√	√	×	×	×	×	√
B-Class	242/246	Body	IRS HRA-Outer right rear intelligent radar sensor	√	√	√	√	×	×	×	×	√
B-Class	242/246	Body	KG-KEYLESS GO(N69/5)	√	√	√	√	×	ACT0131,ACT0132	×	×	√
B-Class	242/246	Body	Multifunction control unit-Multifunction control unit	√	√	√	√	×	ACT0111,ACT0112,ACT0113,ACT0114,ACT0115,ACT0116,ACT0117,ACT0118,ACT0119,ACT0120,ACT0121,ACT0122,ACT0123,ACT0124,ACT0125,ACT0126,ACT0127,ACT0128	×	×	√
B-Class	242/246	Body	N32/1 (Driver seat control unit)	√	×	×	√	×	×	×	×	×
B-Class	242/246	Body	N32/2 (Front passenger seat control unit)	√	×	×	√	×	×	×	×	×
B-Class	242/246	Body	OCP-Control unit 'Overhead control panel'	√	√	√	√	×	ACT0301,ACT0302,ACT0303,ACT0304	×	×	×
B-Class	242/246	Body	PSD-Control module 'Panoramic sliding roof'(A98)	√	√	√	√	×	ACT0208,ACT0207	SP1072	×	√
B-Class	242/246	Body	RBS-Regenerative braking system	√	√	√	√	×	ACT0069,ACT0070	SP1450,SP1330,SP1051,SP1490,SP1491,SP1457	CD0609,CD0689,	√
B-Class	242/246	Body	RevETR LF-Left front reversible emergency tensioning retractor	√	√	√	√	×	ACT0209	×	×	√
B-Class	242/246	Body	RevETR RF-Right front reversible emergency tensioning	√	√	√	√	×	ACT0213	×	×	√
B-Class	242/246	Body	SAM-Signal acquisition and actuation module(N10)	√	√	√	√	×	×	×	×	√

B-Class	242/246	Body	SAM-Signal acquisition and actuation module(N10)	√	√	√	√	×	×	×	×	√
B-Class	242/246	Body	SCM-Steering column module(N80)	√	√	√	√	×	ACT0060,ACT0061,ACT0062,ACT0063,ACT0064,ACT0065	×	×	√
B-Class	242/246	Body	SG SW L-Left headlamp	√	√	√	√	×	ACT0292,ACT0293,ACT0297,ACT0298,ACT0299,ACT0300	SP1084,SP1088,SP1089,SP1090,SP1091,SP1092,	CD0621	√
B-Class	242/246	Body	SG SW L-Left headlamp(E1n9)	√	√	√	√	×	ACT0292,ACT0293,ACT0297,ACT0298,ACT0299,ACT0300	SP1084,SP1088,SP1089,SP1090,SP1094,SP1091,SP1092,SP1093	CD0621	√
B-Class	242/246	Body	SG SW R-Right headlamp	√	√	√	√	×	ACT0292,ACT0293,ACT0297,ACT0298,ACT0299,ACT0300	SP1095,SP1096,SP1097,SP1091,SP1092,SP1093	CD0621	√
B-Class	242/246	Body	SG SW R-Right headlamp(E1n9)	√	√	√	√	×	ACT0292,ACT0293,ACT0297,ACT0298,ACT0299,ACT0300	SP1091,SP1092,SP1093,SP1095,SP1096,SP1097	CD0621	√
B-Class	242/246	Body	SG SW-Control unit 'Headlamp'(N71/1)	√	√	√	√	×	ACT0292,ACT0293,ACT0294,ACT0295,ACT0296	SP1084,SP1085,SP1086,SP1087	CD0621	√
B-Class	242/246	Body	SOGESTAR2-Sound generator for electric vehicle	√	√	√	√	×	ACT0666	×	CD0621	√
B-Class	242/246	Body	SRS-Supplemental restraint system (N2/10)	√	√	√	√	√	×	×	×	√
B-Class	242/246	Body	Trailer recognition module-Trailer recognition	√	√	√	√	×	ACT0237,ACT0236,ACT0238,ACT0239,ACT0240,ACT0241,ACT0242,ACT0243,ACT0248,ACT0249,ACT0245,ACT0250,	×	CD0664	√
B-Class	242/246	Body	TRM-Trailer recognition module (N28/1)	√	√	√	√	×	ACT0236,ACT0237,ACT0238,ACT0239,ACT0240,ACT0241,ACT0242,ACT0243,ACT0244,ACT0245,ACT0246,ACT0247	SP1077,SP1078	×	√
B-Class	242/246	Body	UCP-Upper control panel	√	√	√	√	×	×	×	×	×
B-Class	242/246	Body	WSS-Weight sensing	√	√	√	√	×	×	×	×	×
B-Class	242/246	Chassis	ADS-Adaptive damping system(N51/5)	√	√	√	√	×	ACT0167,ACT0168,ACT0169,ACT0170	SP1061	CD0621	√
B-Class	242/246	Chassis	AMG DRVU-AMG DRIVE UNIT(N145)	√	√	√	√	×	ACT0066,ACT0067,ACT0068	×	×	√
B-Class	242/246	Chassis	DTR-DISTRONIC (A89)	√	√	√	√	×	×	SP1079	CD0621	√
B-Class	242/246	Chassis	EFB-Electronic parking brake(N128)	√	√	√	√	×	ACT0285,ACT0286,ACT0287,ACT0288	SP1081	×	√
B-Class	242/246	Chassis	ES-Electrical power	√	√	√	√	×	×	SP1069,SP1070,SP1071	×	√
B-Class	242/246	Chassis	ESP-Electronic stability program(N30/4)	√	√	√	√	√	ACT0069,ACT0070	SP1051,SP1052	×	√
B-Class	242/246	Chassis	Powertrain control unit gateway	√	√	√	√	×	×	×	×	√
B-Class	242/246	Drive	CNG-Compressed natural gas	√	×	×	√	×	×	×	×	√
B-Class	242/246	Drive	DKG-Electronic transmission control for double-plate clutch transmission	√	√	√	√	√	ACT0312,ACT0313,ACT0314,ACT0315,ACT0316,ACT0317,ACT0318,ACT0319	SP1074,SP1002,SP1103,SP1104	CD0621,CD0608,CD0609,CD0610	√
B-Class	242/246	Drive	FSCU-Fuel pump	√	√	√	√	×	ACT0252,ACT0320	×	CD0621,CD0608	√
B-Class	242/246	Drive	FSCU05-Control unit Fuel pump	√	√	√	√	×	ACT0252	×	×	√
B-Class	242/246	Drive	N127 (Drivetrain control unit)	√	√	√	√	×	ACT0029,ACT0321	SP1105,SP1106,SP1107	CD0621,CD0608,CD0609	√

B-Class	242/246	Drive	N3/10-Motor electronics "MED40" for combustion engine "M274"	√	√	√	√	√	ACT0002,ACT0003,ACT0005,ACT0322,ACT0323,ACT0324,ACT0325,ACT0326,ACT0025,ACT0327,ACT0017,ACT0328,ACT0329,ACT0022,ACT0024,ACT0330,ACT0331,ACT0332,SP1108,SP1017,SP1109,SP1110,SP1111,SP1112,SP1007,SP1113,SP1114,SP1001,SP1004,SP1115,SP1002,SP1029,SP1042,SP1116	CD0621,CD0608,CD0609,CD0610,CD0677,CD0678,CD0679,CD0680,CD0681	√	
B-Class	242/246	Drive	N3/10-Motor electronics "MED40CNG" for combustion engine "M270"	√	√	√	√	√	ACT0002,ACT0003,ACT0005,ACT0322,ACT0323,ACT0324,ACT0325,ACT0025,ACT0016,ACT0017,ACT0328,ACT0329,ACT0022,ACT0024,ACT0330,ACT0331,ACT0332,ACT0333,ACT1146,ACT1051,ACT1143,SP1001,SP1002,SP1004,SP1114,SP1116,SP1042,SP1113,SP1108,SP1117,SP1029,SP1462,SP1463,SP1115,SP1464	CD0621,CD0608,CD0609,CD0610,CD0677,CD0678,CD0681,CD0756,CD0757,CD0679,CD0680	√	
B-Class	242/246	Drive	N3/3-Motor electronics "OM607" for combustion engine "CRR1"	√	√	√	√	√	ACT0005,ACT0029,ACT0030,ACT0031,ACT0032,ACT0025,ACT0033,ACT0034,ACT0035,ACT0036,ACT0037,ACT0028,ACT0004,ACT0038,ACT0017,SP1029,SP1002,SP1030,SP1000,SP1031,SP1032,SP1033,SP1034,SP1035,SP1036,SP1037,SP1038,SP1039,SP1040,SP1041,	CD0608,CD0609,CD0610	√	
B-Class	242/246	Drive	N3/9-Motor electronics "CDID3" for combustion engine "OM651"	√	√	√	√	√	ACT0000,ACT0001,ACT0002,ACT0003,ACT0004,ACT0005,ACT0006,ACT0007,ACT0008,ACT0009,ACT0010,ACT0011,ACT0012,ACT0013,ACT0014,ACT0015,ACT0016,ACT0017,ACT0018,ACT0019,ACT0020,ACT0021,ACT0022,ACT0023,SP1000,SP1001,SP1002,SP1003,SP1004,SP1005,SP1006,SP1007,SP1008,SP1009,SP1010,SP1011,SP1012,SP1013,SP1014,SP1015,SP1016,SP1017,SP1018,SP1019,SP1020,SP1021,SP1022,SP1023,	CD0608,CD0609,CD0610,CD0611	√	
B-Class	242/246	Drive	N3/9-Motor electronics "CDID3" for combustion engine "OM651"	√	√	√	√	×	ACT0001,ACT0004,ACT0005,ACT0002,ACT0028,ACT0008,ACT0009,ACT0010,ACT0011,ACT0022,ACT0023,ACT0024,ACT0012,ACT0015,ACT0026,SP1001,SP1000,SP1004,SP1003,SP1005,SP1025,SP1007,SP1012,SP1013,SP1006,SP1026,SP1009,SP1017,SP1027,SP1028	CD0608,CD0609,CD0610	√	
B-Class	242/246	Drive	PTCU-Common powertrain controller(N127)	√	√	√	√	×	ACT0036,ACT0037,ACT0028,ACT0004,ACT0038,ACT0017	SP1042	CD0621,CD0608,CD0609	√
B-Class	242/246	Drive	PTCU-Common powertrain controller(N127)	√	√	√	√	×	ACT0612,ACT0028,ACT1238,ACT1239,ACT1240,ACT1241,ACT1242,ACT1243	SP1492,SP1493	×	√
B-Class	242/246	Drive	VG-All wheel drive	√	√	√	√	×	ACT0308	SP1099,SP1100,SP1101,SP1102	×	√
B-Class	242/246	Driver assistance system	CPA-Control unit 'COLLISION PREVENTION ASSIST'(A90)	√	√	√	√	×	ACT0110	SP1059	×	√
B-Class	242/246	Driver assistance	DTR-DISTRONIC (A89)	√	√	√	√	×	×	SP1079	CD0621	√
B-Class	242/246	Driver assistance system	IRS HLA-Outer left rear intelligent radar sensor system	√	√	√	√	×	×	×	×	×
B-Class	242/246	Driver assistance system	IRS HRA-Outer right rear intelligent radar sensor	√	√	√	√	×	×	×	×	×
B-Class	242/246	Driver assistance	MFK-Multifunction camera	√	√	√	√	×	ACT0181,ACT0065	SP1063	×	√
B-Class	242/246	Driver assistance	MFK-Multifunction	√	√	√	√	×	ACT0181,ACT0065	SP1063,SP1064	×	√
B-Class	242/246	Driver assistance	PARK-Parking system (N62)	√	√	√	√	×	ACT0305,ACT0306	×	CD0621,CD0672	√
B-Class	242/246	Driver assistance system	PTS-Parktronic system	√	√	√	√	×	ACT0935	×	CD0621,CD0672,CD0708,CD0709	√
B-Class	242/246	Driver assistance	RFK-Backup camera	√	√	√	√	×	ACT0098	SP1082,SP1083	×	√
B-Class	242/246	Driver assistance	RFK-Backup camera	√	√	√	√	×	ACT0098,ACT0100	SP1082,SP1083	×	√

B-Class	242/246	Driver assistance system	TPM-Tire pressure monitor(N88)	√	√	√	√	×	ACT0078,ACT0079,ACT0080,ACT0081	SP1053	×	√
B-Class	242/246	Information and communication	Audio-Audio or COMAND	√	√	√	√	×	×	×	×	×
B-Class	242/246	Information and communication	Audio-Audio or COMAND	√	√	√	√	×	×	×	×	×
B-Class	242/246	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√	×	×	×	×	×
B-Class	242/246	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√	×	ACT0082,ACT0083,ACT0084,ACT0085,ACT0086,ACT0074,ACT0087,ACT0044,ACT0088,ACT0089,ACT0090,ACT0091,ACT0092,ACT0093,ACT0094,ACT0095,ACT0096,ACT0097,ACT0098,ACT0099,ACT0100,ACT0097,ACT0098,ACT0099,ACT0098,ACT0100,ACT0101,ACT0043,ACT0102,ACT0103,ACT0104,ACT0090,ACT0091,ACT0092,ACT0097,ACT0095,ACT0096,ACT0083,ACT0084,ACT0105,ACT0106,ACT0082,	SP1054,SP1055,SP1056,SP1057,SP1058	×	×
B-Class	242/246	Information and communication	COU-Audio/COMAND operating unit (A40/9)	√	√	√	√	×	ACT0289	×	×	√
B-Class	242/246	Information and communication	COU-Audio/COMAND operating unit (A40/9)	√	√	√	√	×	ACT0289	×	×	√
B-Class	242/246	Information and communication	DAB-Digital Audio Broadcasting	√	√	√	√	×	×	×	×	×
B-Class	242/246	Information and communication	DAB-Digital Audio Broadcasting	√	√	√	√	×	ACT0198,ACT0087,ACT0199,ACT0039	×	×	×
B-Class	242/246	Information and communication	DAB-Digital Audio Broadcasting	√	√	√	√	×	ACT0198,ACT0087,ACT0199,ACT0039	×	CD0621	×
B-Class	242/246	Information and communication	DAB-Digital Audio Broadcasting(N87/3)	√	√	√	√	×	×	×	×	×
B-Class	242/246	Information and communication	Drive Kit Plus-Drive kit for iPhone	√	√	√	√	×	ACT0204,ACT0205,ACT0058,ACT0043	×	×	×
B-Class	242/246	Information and communication	E call [Europe]-Emergency call system	√	√	√	√	×	ACT0039,ACT0040,ACT0041,ACT0042,ACT0043,ACT0044	×	×	×
B-Class	242/246	Information and communication	HUD-Head up display	√	√	√	√	×	ACT0210,ACT0211,ACT0212	SP1073	×	×
B-Class	242/246	Information and communication	IC-Instrument cluster	√	√	√	√	×	ACT0045,ACT0046,ACT0047,ACT0048,ACT0049,ACT0039,	SP1043,SP1044,SP1045	×	√
B-Class	242/246	Information and communication	KOMO-Communication module Telematics services	√	√	√	√	×	ACT0051,ACT0039,ACT0043,ACT0040,ACT0052,ACT0053,ACT0054,ACT0055,ACT0056,	×	×	√
B-Class	242/246	Information and communication	MIF-Media interface	√	√	√	√	×	×	×	×	×
B-Class	242/246	Information and communication	MIF-Media interface	√	√	√	√	×	ACT0043	×	×	×
B-Class	242/246	Information and communication	NAV-Navigation module(A2/30)	√	√	√	√	×	ACT0071,ACT0072,ACT0073,ACT0074	×	×	√
B-Class	242/246	Information and communication	NAVI20-Navigation(N125/2)	√	√	√	√	×	ACT0206,ACT0044	×	×	×

B-Class	242/246	Information and communication	SDAR-Satellite radio	√	√	√	√	×	ACT0221,ACT0222,ACT0133,ACT0223	×	CD0645CD0646,CD0647,C D0647	×
B-Class	242/246	Information and communication	SOUND-Bose sound system	√	√	√	√	×	ACT0160,ACT0135,ACT0139,ACT0144,ACT0146,ACT0150,ACT0058,ACT0142,ACT0145,ACT0161,ACT0162,ACT0138,ACT0163,ACT0164,ACT0165,ACT0159,ACT0166,ACT0133	SP1060	×	×
B-Class	242/246	Information and communication	SOUND-Sound system	√	√	√	√	×	ACT0043,ACT0133,ACT0134,ACT0135,ACT0136,ACT0137,ACT0138,ACT0139,ACT0140,ACT0058,ACT0141,ACT0142,ACT0143,ACT0144,ACT0145,ACT0146,ACT0147,ACT0148,ACT0149,ACT0150,ACT0151,ACT0152,ACT0153,ACT0154,	×	CD0621	×
B-Class	242/246	Information and communication	TB5-TV tuner Tuner unit	√	√	√	√	×	ACT0198,ACT0224,ACT0225,ACT0226,ACT0109,ACT0227,ACT0087,ACT0133	×	×	×
B-Class	242/246	Information and communication	TS-Telematic system(N123/4)	√	√	√	√	×	ACT0043,ACT0058,ACT0059,ACT0039	×	×	√
B-Class	242/246	Information and communication	TV tuner (TV)	√	√	√	√	×	ACT0043,ACT0228,ACT0199,ACT0087,ACT0229,ACT0224,	×	×	×
B-Class	242/246	Information and communication	TV-TV tuner	√	√	√	√	×	ACT0043,ACT0228,ACT0199,ACT0087,ACT0229,ACT0224,	×	×	×
B-Class	242/246	Information and communication	TV-TV tuner	√	√	√	√	×	ACT0174,ACT0175,ACT0176,ACT0177,ACT0178,ACT0087,ACT0179,ACT0133,ACT0109,ACT0180	×	CD0645CD0646,CD0647,C D0648,CD0649,CD0650,C D0651,CD0652,CD0653,C D0654,CD0655,CD0656	×
B-Class	242/246	Information and communication	TV-TV tuner	√	√	√	√	×	ACT0174,ACT0175,ACT0176,ACT0177,ACT0178,ACT0087,ACT0641,ACT0180	×	×	×
B-Class	242/246	Information and communication	TV-TV tuner	√	√	√	√	×	ACT0174,ACT0175,ACT0176,ACT0177,ACT0178,ACT0087,ACT0179,ACT0133,ACT0109,ACT0180	×	CD0645CD0646,CD0647,C D0648,CD0649,CD0650,C D0651,CD0652,CD0653,C D0654,CD0655,CD0656	×
B-Class	242/246	Information and communication	TV-TV tuner	√	√	√	√	×	ACT0198,ACT0224,ACT0225,ACT0226,ACT0109,ACT0227,ACT0087,ACT0133	×	×	×
B-Class	242/246	Information and communication	ZAN-Audio/COMAND display	√	√	√	√	×	ACT0290,ACT0096,ACT0090,ACT0091,ACT0095	×	×	√
B-Class	242/246	Information and communication	ZAN-Audio/COMAND display	√	√	√	√	×	ACT0291,ACT0039,ACT0043,ACT0206	×	×	√
B-Class	242/246	Seats and Doors	DCU RF-Right front door	√	√	√	√	×	ACT0272,ACT0273,ACT0274,ACT0256,ACT0275,ACT0258,ACT0276,ACT0277,ACT0278,ACT0262,ACT0279,ACT0280,ACT0265,ACT0266,ACT0281,ACT0282,ACT0283,ACT0284,	SP1080	×	√
B-Class	242/246	Seats and Doors	ESV Driver-Electric seat adjustmnet Driver with memory	√	√	√	√	×	ACT0214,ACT0215,ACT0216,ACT0217,ACT0218,ACT0219,	SP1074,SP1075,SP1076	×	√

B-Class	242/246	Seats and Doors	ESV Front passenger-Electric seat adjustment Front passenger with memory function	√	√	√	√	×	ACT0230,ACT0231,ACT0232,ACT0233,ACT0234,ACT0235,ACT0220	SP1074,SP1075	×	√
B-Class	242/246	Seats and Doors	KOMO/mbrace-Communication module 'Telematics services'/Notrufsystem	√	√	√	√	×	×	SP1046,SP1047	×	×
B-Class	242/246	Seats and Doors	LFD-Left front door	√	√	√	√	×	ACT0253,ACT0254,ACT0255,ACT0256,ACT0257,ACT0258,ACT0259,ACT0260,ACT0261,ACT0262,ACT0263,ACT0264,ACT0265,ACT0266,ACT0267,ACT0268,ACT0269,ACT0270,	SP1080	×	√
C-Class	205	Air conditioning	AAC-Automatic air conditioning	√	√	√	×	×	×	×	×	×
C-Class	205	Air conditioning	AAC-Automatic air conditioning	√	√	√	×	×	×	×	×	×
C-Class	205	Air conditioning	AAC-Automatic air conditioning	√	√	√	×	×	×	×	×	×
C-Class	205	Air conditioning	AAC-Automatic air conditioning	√	√	√	√	×	ACT0182,ACT0417,ACT0183,ACT0771,ACT0772,ACT0204,ACT0773,ACT0003,ACT0186,ACT0190,ACT0665,ACT0774,ACT0189,ACT0775,ACT0776,ACT0188,ACT0777,ACT0778,ACT0779,ACT0663,ACT0780,ACT0662,ACT0781,ACT0782,ACT0783,ACT0784,ACT0785,ACT0786,ACT0787,ACT0788,ACT0655,ACT0656,ACT0781,ACT0782,ACT0783,ACT0784,ACT0785,ACT0786,ACT0788,ACT0652,ACT0655,ACT0656,ACT0781,ACT0782,ACT0786,ACT0787,ACT0789,ACT0790,ACT0194,ACT0647,ACT0648,ACT0649,ACT0650,ACT0653,ACT0654,ACT0791,ACT0792,ACT0793,ACT0794,	SP1066,SP1065,SP1067,SP1360,SP1159	×	×
C-Class	205	Air conditioning	STH-Stationary heater	√	√	√	√	×	ACT1030,ACT0202,ACT1118	×	×	×
C-Class	205	Air conditioning	TSTH-Radio remote control of stationary heater	√	√	√	√	×	ACT0203,ACT0418	×	×	×
C-Class	205	Body	"Driver" seat heater	√	√	√	√	×	ACT0411,ACT0412,ACT0413,ACT0414,ACT0415	SP1157,SP1158	×	×
C-Class	205	Body	"Front passenger" seat heater	√	√	√	√	×	×	×	×	×
C-Class	205	Body	AIRSCARF-Neck heating system(N25/7)	√	√	√	√	×	ACT1113	×	×	×
C-Class	205	Body	AML-Ambiance light	√	√	√	√	×	ACT0389,ACT0390,ACT0391,ACT0392,ACT0393,ACT0394,ACT0395,ACT0396,ACT0043	SP1149	×	×
C-Class	205	Body	AML-Active engine mount	√	√	√	√	×	×	×	×	×
C-Class	205	Body	AMLAB-L (Actuation module, LED exterior lighting, left front)	√	√	√	√	×	×	×	×	×

C-Class	205	Body	AMLAB-L (Actuation module, LED exterior lighting, left front)	√	√	√	√	×	ACT0299,ACT0300	SP1448	×	×
C-Class	205	Body	AMLAB-R (Actuation module, LED exterior lighting, right front)	√	√	√	√	×	×	×	×	×
C-Class	205	Body	AMLAB-R (Actuation module, LED exterior lighting, right front)	√	√	√	√	×	ACT0299,ACT0300	SP1447	×	×
C-Class	205	Body	Anti glare interior rearview mirror(DBE)	√	√	√	√	×	×	×	×	×
C-Class	205	Body	Anti glare interior rearview mirror(SAM)	√	√	√	√	×	×	×	×	×
C-Class	205	Body	AS-Alarm siren(H3/1)	√	√	√	√	×	ACT0309,ACT0465,ACT0466	×	×	×
C-Class	205	Body	ATA-ATA[EDW]/tow-away protection/interior protection	√	√	√	√	×	ACT0075,ACT0465	×	×	×
C-Class	205	Body	AU-Analog clock	√	√	√	×	×	×	×	×	×
C-Class	205	Body	BMS-Battery management system	√	√	√	√	×	ACT0453,ACT0454,ACT0455	SP1197	×	×
C-Class	205	Body	BMS-Battery management system	√	√	√	√	×	ACT0778,ACT1120	SP1386,SP1193	×	×
C-Class	205	Body	BMS-Battery management system	√	√	√	√	×	ACT1121,ACT0453,ACT0410,ACT0604	SP1197	×	×
C-Class	205	Body	BSN-Battery sensor(B95)	√	√	√	√	×	×	×	×	×
C-Class	205	Body	BSN-Battery sensor(B95)	√	√	√	√	×	×	×	×	×
C-Class	205	Body	Button group, instrument panel, driver side	√	√	√	√	×	×	×	×	×
C-Class	205	Body	DC/DC-DC/DC converter	√	√	√	√	×	×	×	×	×
C-Class	205	Body	ESA Front passenger-Electric seat adjustment Front passenger	√	√	√	√	×	×	×	×	×
C-Class	205	Body	ESV Driver-Electric seat adjustmnet Driver	√	√	√	√	×	×	×	×	×
C-Class	205	Body	EZS-Electronic ignition lock	√	√	√	√	×	×	×	×	×
C-Class	205	Body	EZS-Electronic ignition lock	√	√	√	√	×	ACT1054	×	×	×
C-Class	205	Body	FSW-Windshield wiper	√	√	√	√	×	×	×	×	×
C-Class	205	Body	GTO-Garage door	√	√	√	√	×	×	×	×	×
C-Class	205	Body	GTO-Garage door	√	√	√	√	×	×	×	×	×
C-Class	205	Body	IRSS-FOL-Left rear interior protection sensor	√	√	√	×	×	ACT1117	×	×	×
C-Class	205	Body	IRSS-FOR-Right rear interior protection sensor	√	√	√	×	×	ACT1116	×	×	×
C-Class	205	Body	IRSS-VL-Left front interior protection sensor	√	√	√	×	×	ACT1114	×	×	×
C-Class	205	Body	IRSS-VR-Right front interior protection sensor	√	√	√	×	×	ACT1115	×	×	×
C-Class	205	Body	KG-Keyless Go	√	√	√	√	×	ACT0131,ACT0132	×	×	×
C-Class	205	Body	KG-Keyless Go	√	√	√	√	×	ACT0131,ACT0132	×	×	×
C-Class	205	Body	LIB-Lithium ion battery	√	√	√	√	×	×	×	×	×
C-Class	205	Body	LIB-Lithium ion battery	√	√	√	√	×	×	×	×	×
C-Class	205	Body	LIB-Lithium ion battery	√	√	√	√	×	×	×	×	×
C-Class	205	Body	LRE-Steering wheel electronics	√	√	√	√	×	×	×	×	×
C-Class	205	Body	Multifunction control unit-Multifunction control unit	√	√	√	√	×	×	×	×	×
C-Class	205	Body	Multifunction control unit-Multifunction control unit	√	√	√	√	×	ACT0204	×	×	×
C-Class	205	Body	N25/6 (Rear passenger compartment seat heater control	√	√	√	√	×	×	×	×	×

C-Class	205	Body	N38 (Rear switching module)	√	√	√	√	×	×	×	×	×
C-Class	205	Body	OCP-Overhead control panel	√	√	√	√	×	×	×	×	×
C-Class	205	Body	OCP-Overhead control panel	√	√	√	√	×	×	×	×	×
C-Class	205	Body	OCP-Overhead control panel	√	√	√	√	×	ACT1093,ACT0302,ACT1094,ACT0303,ACT0304,ACT1112	×	×	×
C-Class	205	Body	OCP-Overhead control panel	√	√	√	√	×	ACT1093,ACT1094,ACT0303,ACT0302,ACT1095,ACT1096,ACT1097,ACT1098,ACT1099,ACT0465,ACT1100	SP1441	×	×
C-Class	205	Body	PSD-Control module Panoramic sliding roof	√	√	√	√	×	ACT0207,ACT1091,ACT1092	SP1072	×	×
C-Class	205	Body	PSD-Panoramic sliding roof	√	√	√	√	×	×	×	×	×
C-Class	205	Body	PSD-Panoramic sliding roof	√	√	√	√	×	×	SP1072	×	×
C-Class	205	Body	RevETR LF-Left front reversible emergency tensioning retractor	√	√	√	√	×	ACT0209	×	×	×
C-Class	205	Body	RevETR RF-Right front reversible emergency tensioning	√	√	√	√	×	ACT0213	×	×	×
C-Class	205	Body	RGLS-Rain/light sensor(B38/2)	√	√	√	√	×	×	×	×	×
C-Class	205	Body	RGLS-Rain/light sensor(B38/2)	√	√	√	√	×	×	×	×	×
C-Class	205	Body	SAMF-Front signal acquisition and actuation module(N10/6)	√	√	√	√	×	ACT0729,ACT0730,ACT0731,ACT0732,ACT0344,ACT0507,ACT0733,ACT0675,ACT0734,ACT0676,ACT0735,ACT0736,ACT0737,ACT0738,ACT0465,ACT0739,ACT0740,ACT0741,ACT0742,ACT0743,ACT0744,	×	×	×
C-Class	205	Body	SAMF-Front signal acquisition and actuation module(N10/6)	√	√	√	√	×	ACT1066,ACT1067,ACT1068,ACT0729,ACT0730,ACT0344,ACT0507,ACT0734,ACT0733,ACT0675,ACT0676,ACT0735,ACT1069,ACT1070,ACT1071,ACT1072,ACT0909,ACT0465,	×	×	×
C-Class	205	Body	SAMR-Rear signal acquisition and actuation module(N10/8)	√	√	√	√	×	ACT0747,ACT0240,ACT0748,ACT0749,ACT0750,ACT0731,ACT0751,ACT0752,ACT0753,ACT0754,ACT0755,ACT0756,ACT0757,ACT0758,ACT0759,ACT0760,ACT0761,ACT0762,ACT0763,ACT0764,ACT0765,ACT0766,ACT0767,ACT0768,	×	×	×
C-Class	205	Body	SAMR-Rear signal acquisition and actuation module(N10/8)	√	√	√	√	×	ACT0747,ACT1073,ACT0240,ACT1074,ACT1075,ACT0891,ACT0890,ACT0751,ACT0752,ACT0754,ACT1076,ACT1077,ACT1078,ACT1079,ACT1080,ACT1081,ACT0761,ACT1082,ACT0760,ACT1083,ACT0768,ACT0765,ACT1084,ACT1085,ACT0908,ACT0769,ACT0802,	×	×	×
C-Class	205	Body	SCM-Steering column module(N80)	√	√	√	√	×	ACT0060,ACT0061,ACT0062,ACT0063,ACT0064,ACT0065	×	×	×

C-Class	205	Body	SCM-Steering column module(N80)	√	√	√	√	×	ACT0060,ACT0061,ACT0062,ACT0063,ACT0064,ACT0065	×	×	×
C-Class	205	Body	SG FOND-Rear control unit	√	√	√	√	×	×	×	×	×
C-Class	205	Body	SG FOND-Rear control unit	√	√	√	√	×	ACT1101,ACT1102,ACT0362,ACT0363,ACT0369,ACT0370,ACT0926,ACT1103,ACT0948,ACT1104,ACT1105,ACT1106,	SP1442,SP1443,SP1444	×	×
C-Class	205	Body	SG LG-Charger	√	√	√	√	×	ACT0405,ACT0406,ACT0407,ACT0408,ACT0409,ACT0410	×	×	×
C-Class	205	Body	SG LG-Charger	√	√	√	√	×	ACT0405,ACT0406,ACT0407,ACT0408,ACT0611,ACT0410	×	×	×
C-Class	205	Body	SG LML VL-LED matrix of left front lamp unit	√	√	√	√	×	ACT0299,ACT0815,ACT0816,ACT0300	SP1089,SP1361	×	×
C-Class	205	Body	SG SW L-Left headlamp	√	√	√	√	×	×	×	×	×
C-Class	205	Body	SG SW L-Left headlamp	√	√	√	√	×	×	×	×	×
C-Class	205	Body	SG SW L-Left headlamp	√	√	√	√	×	ACT0292,ACT0293,ACT0297,ACT0298,ACT0299,ACT0300	SP1445,SP1088,SP1089,SP1090,SP1094	×	×
C-Class	205	Body	SG SW R-Right headlamp	√	√	√	√	×	×	×	×	×
C-Class	205	Body	SG SW R-Right headlamp	√	√	√	√	×	×	×	×	×
C-Class	205	Body	SG SW R-Right headlamp	√	√	√	√	×	ACT0292,ACT0293,ACT0297,ACT0298,ACT0299,ACT0300	SP1362,SP1096,SP1097	×	×
C-Class	205	Body	SG-LML-VR-LED matrix of right front lamp unit	√	√	√	√	×	ACT0299,ACT0815,ACT0300,ACT0816	SP1362,SP1363	×	×
C-Class	205	Body	SOGESTAR2-Sound generator for electric vehicle	√	√	√	√	×	×	×	×	×
C-Class	205	Body	SRS-Supplemental restraint	√	√	√	√	×	×	×	×	×
C-Class	205	Body	SRS-Supplemental restraint	√	√	√	√	√	×	×	×	×
C-Class	205	Body	STM-Mirror taximeter	√	√	√	√	×	×	×	×	×
C-Class	205	Body	Trailer recognition module-Trailer recognition	√	√	√	√	×	×	×	×	×
C-Class	205	Body	WSS-Weight sensing	√	√	√	√	×	×	×	×	×
C-Class	205	Chassis	ADS-Adaptive damping system(N51/5)	√	√	√	√	×	ACT0628,ACT1119,ACT0631,ACT0630,ACT0632,ACT0633,ACT0634,ACT0635,ACT0167,ACT0168,ACT0169,ACT0170,ACT0636,ACT0637,ACT0639,	SP1061,SP1339	×	×
C-Class	205	Chassis	AMG DRVU-AMG DRIVE UNIT	√	√	√	√	×	ACT0401,ACT0402,ACT0403,ACT0404	SP1153,SP1154,SP1155	×	×
C-Class	205	Chassis	AMG DRVU-AMG DRIVE	√	√	√	×	×	ACT1109	×	×	×
C-Class	205	Chassis	EFB-Electric parking brake	√	√	√	√	×	ACT0285,ACT0286,ACT0287,ACT0288	SP1081	×	×
C-Class	205	Chassis	ES - Electric power steering	√	√	√	√	×	×	SP1071	×	×
C-Class	205	Chassis	ES - Electric power steering	√	√	√	√	×	×	SP1071,SP1167	×	×
C-Class	205	Chassis	ESP-Electric stability	√	√	√	√	√	ACT0069,ACT0070	SP1450,SP1456,SP1457	×	×
C-Class	205	Chassis	ESP-Electric stability program(N30/4)	√	√	√	√	×	ACT0069,ACT0070,ACT0285,ACT0286,ACT0287	SP1174,SP1176,SP1178,SP1367	×	×
C-Class	205	Chassis	ESP-Electric stability program(N30/4)	√	√	√	√	√	ACT0069,ACT0070,ACT0285,ACT0286,ACT0287,ACT0288	SP1174,SP1176,SP1178,SP1183	×	×
C-Class	205	Chassis	ESP-Electric stability program(N30/4)	√	√	√	√	√	ACT0069,ACT0070,ACT0612,ACT0285,ACT0286,ACT0287,ACT0288	SP1174,SP1175,SP1176,SP1177,SP1178,SP1179,SP1180,SP1181,SP1367,	×	×

C-Class	205	Chassis	ESP-Electric stability program(N30/4)	√	√	√	√	√	ACT0069,ACT0070,ACT0612,ACT0285,ACT0288	SP1051,SP1330,SP1450,SP1451,SP1452,SP1453,SP1179,SP1181,SP1454,SP1455,SP1367	×	×
C-Class	205	Chassis	ESP-Electric stability program(N30/4)	√	√	√	√	√	ACT0069,ACT0070,ACT0863,ACT0285,ACT0286,ACT0287,ACT0288	SP1174,SP1175,SP1176,SP1177,SP1178,SP1179,SP1366,SP1181,SP1367,	×	×
C-Class	205	Drive	EAGGS-Electric differential lock	√	√	√	√	×	ACT0814	SP1155	×	×
C-Class	205	Drive	FSCU-Control unit Fuel pump	√	√	√	√	×	ACT0252,ACT0320	×	×	×
C-Class	205	Drive	HFFPM-Haptic accelerator pedal module	√	√	√	√	×	ACT1110,ACT1111	×	×	×
C-Class	205	Drive	ISG-Integrated starter alternator	√	√	√	√	×	×	×	×	×
C-Class	205	Drive	ISG-Integrated starter alternator	√	√	√	√	×	×	SP1368	×	×
C-Class	205	Drive	ISM-Shift module	√	√	√	√	×	ACT0670,ACT0671,ACT0318	SP1345,SP1346,SP1446	×	×
C-Class	205	Drive	N127 (Drivetrain control unit)	√	√	√	√	×	ACT0028,ACT0430,ACT0431,ACT0432,ACT0433,ACT0007,ACT0434,ACT0435,ACT0436,ACT0437,ACT0438,ACT0439,ACT0440,ACT0441,ACT0442,ACT0443,ACT0444,ACT0445,ACT0446,ACT0447,ACT0448,	SP1186,SP1042,SP1025,SP1187,SP1188,SP1189,SP1190,SP1191,SP1192	×	×
C-Class	205	Drive	N127 (Drivetrain control unit)	√	√	√	√	×	ACT0038,ACT0028,ACT0441,ACT0440,ACT0007,ACT0434,ACT0436,ACT0431,ACT0439,ACT0438,ACT0434,ACT0437	SP1382	×	×
C-Class	205	Drive	N3/10-Motor electronics "MED177" for combustion engine "M276"	√	√	√	√	√	ACT0005,ACT0002,ACT0003,ACT0335,ACT0480,ACT0463,ACT0705,ACT0464,ACT0706,ACT0325,ACT0326,ACT0025,ACT0016,ACT0707,ACT0708,ACT0017,ACT0441,ACT0709,	SP1108,SP1109,SP1017,SP1110,SP1115,SP1001,SP1459,SP1202,SP1113,SP1004,SP1352,SP1000	×	×
C-Class	205	Drive	N3/10-Motor electronics "MED1775" for combustion engine "M178"	√	√	√	√	√	ACT0002,ACT0028,ACT0431,ACT0432,ACT0433,ACT0864,ACT0865,ACT0435,ACT0480,ACT0476,ACT0475,ACT0478,ACT0477,ACT0326,ACT0866,ACT0867,ACT0436,ACT0025,ACT0868,ACT0712,ACT0713,	SP1017,SP1109,SP1110,SP1369,SP1370,SP1371,SP1112,SP1202,SP1203,SP1001,SP1187,SP1372,SP1201,SP1000	×	×
C-Class	205	Drive	N3/10-Motor electronics "MED177V6LA" for combustion engine "M276Turbocharger"	√	√	√	√	√	ACT0005,ACT0002,ACT0003,ACT0335,ACT0480,ACT0463,ACT0705,ACT0464,ACT0706,ACT0325,ACT0326,ACT0025,ACT0016,ACT0017,ACT0441,ACT0709,ACT0022,ACT0712,	SP1109,SP1110,SP1108,SP1017,SP1369,SP1371,SP1370,SP1112,SP1203,SP1202,SP1113,SP1352,SP1004,SP1001,SP1201,SP1000	×	×
C-Class	205	Drive	N3/10-Motor electronics "MED40" for combustion engine "M274"	√	√	√	√	√	ACT0002,ACT0005,ACT0460,ACT0322,ACT0323,ACT0324,ACT0325,ACT0326,ACT0025,ACT0327,ACT0328,ACT0329,ACT0022,ACT0024,ACT0330,ACT0331,ACT0332,ACT0333,	SP1017,SP1004,SP1000	×	×

C-Class	205	Drive	N3/10-Motor electronics "MED41" for combustion engine "M260/M264"	✓	✓	✓	✓	✓	ACT0330,ACT0003,ACT0459, ACT0323,ACT0324,ACT0333, ACT0025,ACT0328,ACT0331, ACT0332,ACT0004,ACT0005, ACT0456,ACT0002,ACT0460, ACT0329,ACT0022,ACT0325,	SP1199,SP1117	×	×
C-Class	205	Drive	N3/10-Motor electronics "MRG1" for combustion engine "M256"	✓	✓	✓	✓	✓	ACT0002,ACT0025,ACT0005, ACT0022,ACT0456,ACT0329, ACT0325,ACT0328,ACT0323, ACT0324,ACT0460,ACT0871,	SP1001,SP1004,SP1201, SP1202,SP1203,SP1110, SP1109,SP1139,SP1017, SP1371,SP1112,SP1000	×	×
C-Class	205	Drive	N3/40-Motor electronics "MRD1" for combustion engine "OM654"	✓	✓	✓	✓	✓	ACT0001,ACT0005,ACT0006, ACT0321,ACT0008,ACT0009, ACT0010,ACT0322,ACT0011, ACT0012,ACT0016,ACT0018, ACT0022,ACT0023,ACT0024, ACT0026,ACT0000,ACT0338, ACT0339,ACT0340,ACT0341	SP1001,SP1000,SP1130, SP1125,SP1131,SP1132, SP1133,SP1134,SP1135, SP1136,SP1017,SP1137, SP1138,SP1024,SP1139, SP1140,SP1015,SP1141, SP1142,SP1143,SP1144, SP1021,SP1022,SP1145,	×	×
C-Class	205	Drive	N3/9-Motor electronics "CDI41R" for combustion engine "OM626"	✓	✓	✓	✓	✓	ACT0005,ACT0029,ACT0008, ACT1048,ACT1049,ACT1050, ACT0327,ACT1051,ACT1052, ACT0033,ACT1053	SP1029,SP1000,SP1001, SP1010,SP1032,SP1035, SP1432,SP1034,SP1033, SP1291,SP1433,SP1025, SP1012,SP1013,SP1434, SP1435,SP1294,SP1436,	×	×
C-Class	205	Drive	N3/9-Motor electronics "CDID3S2" for combustion engine "OM651"	✓	✓	✓	✓	✓	×	SP1001,SP1015,SP1016, SP1004,SP1003,SP1012, SP1013,SP1006,SP1014, SP1128,SP1020,SP1005, SP1025,SP1017,SP1018, SP1000,SP1007,SP1022,	×	×
C-Class	205	Drive	N3/9-Motor electronics "CR43" for combustion engine "OM651"	✓	✓	✓	✓	×	ACT0026,ACT0000,ACT0589, ACT0330,ACT0005,ACT0003, ACT0008,ACT0011,ACT0010, ACT0022,ACT0012,ACT0016, ACT0017,ACT0018,ACT0019,	SP1000,SP1001,SP1003, SP1004,SP1410,SP1290, SP1291,SP1123,SP1292, SP1293,SP1294,SP1012, SP1013,SP1144,SP1015,	×	×
C-Class	205	Drive	SCR-Selective catalytic reduction	✓	✓	✓	✓	×	ACT0424,ACT0425,ACT0426, ACT0427,ACT0428,ACT0429	SP1184,SP1185	×	×
C-Class	205	Drive	SCR-Selective catalytic reduction	✓	✓	✓	✓	×	ACT0424,ACT0602,ACT0425, ACT0426,ACT0427,ACT0598	SP1185,SP1322,SP1184, SP1319,SP1318,SP1023	×	×
C-Class	205	Drive	SG EM-Power electronics	✓	✓	✓	✓	×	ACT0451,ACT0452	SP1193,SP1194,SP1195, SP1196,SP1150	×	×
C-Class	205	Drive	SG EM-Power electronics	✓	✓	✓	✓	×	ACT0451,ACT0452	SP1193,SP1323,SP1458	×	×
C-Class	205	Drive	SG SOGE AGA-Sound generator for exhaust system	✓	✓	✓	✓	×	×	×	×	×
C-Class	205	Drive	Y3/8n4-Fully integrated transmission control	✓	✓	✓	✓	✓	ACT0592,ACT0318	SP1299,SP1300,SP1301, SP1302,SP1303,SP1304, SP1233,SP1305,SP1306, SP1306,SP1307,SP1308, SP1309,SP1002,SP1310,	×	×
C-Class	205	Drive	Y3/8n4-Transmission control for 9 speed transmission	✓	✓	✓	✓	✓	ACT0592,ACT0312,ACT0593, ACT0714,ACT0317	SP1311,SP1315,SP1316, SP1305,SP1355,SP1312, SP1356,SP1300,SP1357, SP1358,SP1359,SP1317	×	×

[illegible]

C-Class	205	Information and communication	COU[ZBE]-Audio/COMAND operating unit	√	√	√	√	×	ACT0289,ACT0041	SP1199	×	×
C-Class	205	Information and communication	CTEL-Cellular telephone	√	√	√	√	×	×	×	×	×
C-Class	205	Information and communication	DAB-Digital radio Tuner unit	√	√	√	√	×	ACT0198,ACT0087,ACT0199,ACT0039	×	×	×
C-Class	205	Information and communication	HERMES-control unit for telematics services	√	√	√	√	×	×	SP1046	×	×
C-Class	205	Information and communication	HUD-Head up display	√	√	√	√	×	ACT0210,ACT0212	×	×	×
C-Class	205	Information and communication	IC-Instrument cluster	√	√	√	√	×	ACT0397,ACT0048,ACT0210,ACT0398,ACT0399,ACT0947,ACT0050,ACT0400	SP1043,SP1044,SP1045,SP1381	×	×
C-Class	205	Information and communication	IC-Instrument cluster(A1)	√	√	√	√	×	ACT0397,ACT0048,ACT0210,ACT0398,ACT0399,ACT0050,ACT0400,ACT0039	SP1043,SP1044,SP1045	×	×
C-Class	205	Information and communication	KOMO/mbrace-Communication module 'Telematics services'/Notrufsystem	√	√	√	√	×	ACT0051,ACT0039,ACT0043,ACT0040,ACT0052,ACT0053,ACT0054,ACT0055,ACT0056,	×	×	×
C-Class	205	Information and communication	mbrace-mbrace	√	√	√	√	×	ACT0039,ACT0040,ACT0041,ACT0042,ACT0043,ACT0044	×	×	×
C-Class	205	Information and communication	mbrace-mbrace	√	√	√	√	×	ACT0043,ACT0058,ACT0059,ACT0039	×	×	×
C-Class	205	Information and communication	MTAS-Mobile phone cradle	√	√	√	√	×	×	×	×	×
C-Class	205	Information and communication	MTAS-Mobile phone cradle	√	√	√	√	×	×	×	×	×
C-Class	205	Information and communication	N72/1 (Upper control panel control unit)	√	√	√	×	×	×	×	×	×
C-Class	205	Information and communication	N72/4 (Left lower control panel)	√	√	√	×	×	×	×	×	×
C-Class	205	Information and communication	N72/4 (Left lower control panel)	√	√	√	×	×	×	×	×	×
C-Class	205	Information and communication	SG MSND-Engine sound	√	√	√	√	×	×	×	×	×
C-Class	205	Information and communication	SG MSND-Engine sound	√	√	√	√	×	ACT0043,ACT0044,ACT0082,ACT0130	×	×	×
C-Class	205	Information and communication	SOUND-Sound system	√	√	√	√	×	×	×	×	×
C-Class	205	Information and communication	SOUND-Sound system	√	√	√	√	×	×	×	×	×
C-Class	205	Information and communication	TPAD-Touchpad	√	√	√	√	×	×	×	×	×
C-Class	205	Information and communication	TPAD-Touchpad	√	√	√	√	×	×	×	×	×
C-Class	205	Information and communication	TV tuner (TV)	√	√	√	√	×	×	×	×	×
C-Class	205	Information and communication	TV tuner (TV)	√	√	√	√	×	×	×	×	×
C-Class	205	Information and communication	TV tuner (TV)	√	√	√	√	×	×	×	×	×
C-Class	205	Information and communication	TV tuner (TV)	√	√	√	√	×	×	×	×	×

C-Class	205	Information and communication	ZAN-Audio/COMAND display	√	√	√	√	×	ACT0206,ACT0946,ACT0291,ACT0039	×	×	×
C-Class	205	Information and communication	ZAN-Audio/COMAND display	√	√	√	√	×	ACT0206,ACT0946,ACT0291,ACT0039	×	×	×
C-Class	205	Information and communication	ZAN-Audio/COMAND display	√	√	√	√	×	ACT0291,ACT0206,ACT0039	×	×	×
C-Class	205	Seats and Doors	DCU LR-Left rear door	√	√	√	√	×	ACT0360,ACT0361,ACT0362,ACT0363,ACT0723,ACT0688,ACT0347,ACT0364,ACT0724,ACT0366,ACT0725	SP1080,SP1147,SP1148	×	×
C-Class	205	Seats and Doors	DCU LR-Left rear door	√	√	√	√	×	ACT0687,ACT0686,ACT1060,ACT0688,ACT1061,ACT0362,ACT0363,ACT0723,ACT0360,ACT0361,ACT0271,ACT0725	SP1080	×	×
C-Class	205	Seats and Doors	DCU RF-Right front door	√	√	√	√	×	ACT0272,ACT0273,ACT0274,ACT0256,ACT0275,ACT0277,ACT0276,ACT1058,ACT0278,ACT0279,ACT0357,ACT1056,ACT0349,ACT1059,ACT0348,ACT0281,ACT0282,ACT0258,ACT0283,ACT0284,ACT0271,	SP1080	×	×
C-Class	205	Seats and Doors	DCU RF-Right front door	√	√	√	√	×	ACT0353,ACT0274,ACT0273,ACT0354,ACT0720,ACT0283,ACT0284,ACT0281,ACT0282,ACT0721,ACT0355,ACT0278,ACT0356,ACT0357,ACT0347,ACT0279,ACT0348,ACT0349,ACT0358,ACT0359,ACT0722,	SP1080,SP1147,SP1148	×	×
C-Class	205	Seats and Doors	DCU RR-Right rear door	√	√	√	√	×	ACT0367,ACT0368,ACT0369,ACT0370,ACT0726,ACT0692,ACT0347,ACT0371,ACT0365,ACT0727,ACT0728,ACT0366	SP1080,SP1147,SP1148	×	×
C-Class	205	Seats and Doors	DCU RR-Right rear door	√	√	√	√	×	ACT0691,ACT0690,ACT1062,ACT0692,ACT1056,ACT1063,ACT0369,ACT0370,ACT0726,ACT0367,ACT0368,ACT0728,	SP1080	×	×
C-Class	205	Seats and Doors	ESA Front passenger-Electric seat adjustment Front passenger	√	√	√	√	×	×	×	×	×
C-Class	205	Seats and Doors	ESV Driver-Electric seat adjustmnet Driver	√	√	√	√	×	×	×	×	×
C-Class	205	Seats and Doors	ESV Driver-Electric seat adjustmnet Driver with memory function	√	√	√	√	×	ACT0214,ACT0373,ACT0218,ACT0374,ACT0217,ACT1064,ACT0375,ACT0376,ACT0377	SP1438,SP1075,SP1074	×	×
C-Class	205	Seats and Doors	ESV Front passenger-Electric seat adjustment Front passenger with memory function	√	√	√	√	×	ACT0230,ACT0378,ACT0234,ACT0379,ACT0233,ACT1065,ACT0380,ACT0381,ACT0382	SP1438,SP1075,SP1074	×	×
C-Class	205	Seats and Doors	HKS-Tailgate control	√	√	√	√	×	ACT1089,ACT1023,ACT0171,ACT0173	SP1440	×	×
C-Class	205	Seats and Doors	HKS-Tailgate control	√	√	√	√	×	ACT1089,ACT1090	SP1439	×	×

C-Class	205	Seats and Doors	LFD-Left front door	√	√	√	√	×	ACT0253,ACT0254,ACT0255,ACT0256,ACT0257,ACT0260,ACT0259,ACT1055,ACT0261,ACT0263,ACT0346,ACT1056,ACT0349,ACT1057,ACT0348,ACT0267,ACT0268,ACT0258,ACT0270,ACT0269,ACT0271,	SP1080	×	×
C-Class	205	Seats and Doors	LFD-Left front door	√	√	√	√	×	ACT0342,ACT0255,ACT0254,ACT0343,ACT0715,ACT0269,ACT0361,ACT0267,ACT0268,ACT0716,ACT0344,ACT0261,ACT0345,ACT0346,ACT0347,ACT0263,ACT0348,ACT0349,ACT0350,ACT0351,ACT0717,	SP1080,SP1147,SP1148	×	×
C-Class	205	Seats and Doors	MKS-BFS-Front passenger more copy the seat	√	√	√	√	×	ACT0383,ACT0384,ACT0386	×	×	×
C-Class	205	Seats and Doors	MKS-FS-Pilot multi-profile seat	√	√	√	√	×	ACT0383,ACT0384,ACT0386	×	×	×
C-Class	205	Seats and Doors	S22 (Driver"s door seat adjustment switch)	√	√	√	×	×	×	×	×	×
C-Class	205	Seats and Doors	S23 (Front passenger door seat adjustment switch)	√	√	√	×	×	×	×	×	×
C-Class	205	Seats and Doors	S47/2 (Driver door switch	√	√	√	×	×	×	×	×	×
C-Class	205	Seats and Doors	S47/3 (Front passenger door switch module)	√	√	√	×	×	×	×	×	×
C-Class	205	Seats and Doors	S51/1 (Driver"s door seat heating switch)	√	√	√	×	×	×	×	×	×
C-Class	205	Seats and Doors	S51/2 (Front passenger door seat heating switch)	√	√	√	×	×	×	×	×	×
C-Class	205	Seats and Doors	S51/3 (Left rear seat heater	√	√	√	×	×	×	×	×	×
C-Class	205	Seats and Doors	S51/4 (Right rear seat heater	√	√	√	×	×	×	×	×	×
CLA-Class	118	Air conditioning	AAC-Automatic air conditioning	√	√	√	√	×	×	×	×	×
CLA-Class	118	Air conditioning	AAC-Automatic air conditioning	√	√	√	√	×	ACT0416,ACT0182,ACT0417,ACT0186,ACT0194,ACT0195,ACT0197,ACT0196,ACT0028,	SP1065,SP1066,SP1067,SP1159,SP1160	×	×
CLA-Class	118	Air conditioning	STH-Stationary heater	√	√	√	√	×	ACT0202	×	×	×
CLA-Class	118	Air conditioning	TSTH-Radio remote control of stationary heater	√	√	√	√	×	ACT0203,ACT0418	×	×	×
CLA-Class	118	Body	"Driver" seat heater	√	√	√	√	×	ACT0411,ACT0412,ACT0413,ACT0414,ACT0415	SP1157,SP1158	×	×
CLA-Class	118	Body	"Front passenger" seat heater	√	√	√	√	×	×	×	×	×
CLA-Class	118	Body	AML-Ambiance light	√	√	√	√	×	ACT0389,ACT0390,ACT0391,ACT0392,ACT0393,ACT0394,ACT0395,ACT0396,ACT0043	SP1149	×	×
CLA-Class	118	Body	Anti glare interior rearview mirror(DBE)	√	√	√	√	×	×	×	×	×
CLA-Class	118	Body	AS-Alarm siren(H3/1)	√	√	√	√	×	ACT0309,ACT0465,ACT0466	×	×	×
CLA-Class	118	Body	ATA-Interior motion sensor	√	√	√	√	×	×	×	×	×

CLA-Class	118	Body	BMS-Battery management system	√	√	√	√	×	ACT0453,ACT0454,ACT0455	SP1197	×	×
CLA-Class	118	Body	BSN-Battery sensor(B95)	√	√	√	√	×	×	×	×	×
CLA-Class	118	Body	DC/DC-DC/DC converter	√	√	√	√	×	×	×	×	×
CLA-Class	118	Body	DCCU-Direct current charge connection unit	√	√	√	√	×	×	×	×	×
CLA-Class	118	Body	Driver side SAM-Front signal acquisition and actuation module	√	√	√	√	×	×	×	×	×
CLA-Class	118	Body	EZS-Electronic ignition switch	√	√	√	√	×	ACT0372	×	×	×
CLA-Class	118	Body	FSW-Windshield wiper	√	√	√	√	×	×	×	×	×
CLA-Class	118	Body	GES-Hand motion sensor	√	√	√	√	×	×	×	×	×
CLA-Class	118	Body	GTO-Garage door opener(A67n2)	√	√	√	√	×	×	×	×	×
CLA-Class	118	Body	HE-Hand detection	√	√	√	√	×	×	×	×	×
CLA-Class	118	Body	LIB-Lithium ion battery	√	√	√	√	×	×	×	×	×
CLA-Class	118	Body	LIB-Lithium ion battery	√	√	√	√	×	×	×	×	×
CLA-Class	118	Body	LRE-Steering wheel electronics	√	√	√	√	×	×	×	×	×
CLA-Class	118	Body	Multifunction control unit-Multifunction control unit	√	√	√	√	×	×	×	×	×
CLA-Class	118	Body	Multifunction control unit-Multifunction control unit	√	√	√	√	×	ACT0204	×	×	×
CLA-Class	118	Body	N38 (Rear switching module)	√	√	√	√	×	×	×	×	×
CLA-Class	118	Body	OCP-Overhead control panel	√	√	√	√	×	×	×	×	×
CLA-Class	118	Body	PSD-Panoramic sliding roof	√	√	√	√	×	×	×	×	×
CLA-Class	118	Body	RevETR LF-Left front reversible emergency tensioning retractor	√	√	√	√	×	×	×	×	×
CLA-Class	118	Body	RevETR LF-Left front reversible emergency tensioning retractor	√	√	√	√	×	ACT0209	×	×	×
CLA-Class	118	Body	RevETR RF-Right front reversible emergency tensioning	√	√	√	√	×	×	×	×	×
CLA-Class	118	Body	RevETR RF-Right front reversible emergency tensioning	√	√	√	√	×	ACT0213	×	×	×
CLA-Class	118	Body	RGLS-Rain/light sensor(B38/2)	√	√	√	√	×	×	×	×	×
CLA-Class	118	Body	SCM-Steering column module	√	√	√	√	×	×	×	×	×
CLA-Class	118	Body	SG LG-Charger	√	√	√	√	×	ACT0405,ACT0406,ACT0407,ACT0408,ACT0409,ACT0410	×	×	×
CLA-Class	118	Body	SG LML VL-LED matrix of left front lamp unit	√	√	√	√	×	×	×	×	×

CLA-Class	118	Body	SG SW L-Left headlamp	√	√	√	√	×	×	×	×	×
CLA-Class	118	Body	SG SW R-Right headlamp	√	√	√	√	×	×	×	×	×
CLA-Class	118	Body	SG-LML-VR-LED matrix of right front lamp unit	√	√	√	√	×	×	×	×	×
CLA-Class	118	Body	SOGESTAR2-Sound generator for electric vehicle	√	√	√	√	×	×	×	×	×
CLA-Class	118	Body	SRS-Supplemental restraint system	√	√	√	√	√	×	×	×	×
CLA-Class	118	Body	Trailer recognition module-Trailer recognition	√	√	√	√	×	×	×	×	×
CLA-Class	118	Body	WSS-Weight sensing system(N110)	√	√	√	√	×	×	×	×	×
CLA-Class	118	Chassis	ADS-Adaptive damping system(N51/5)	√	√	√	√	×	×	SP1061	×	×
CLA-Class	118	Chassis	ADS-Adaptive damping system(N51/5)	√	√	√	√	×	×	SP1061	×	×
CLA-Class	118	Chassis	AMG DRVU-AMG DRIVE UNIT	√	√	√	√	×	ACT0401,ACT0402,ACT0403,ACT0404	SP1153,SP1154,SP1155	×	×
CLA-Class	118	Chassis	ES - Electric power steering	√	√	√	√	×	×	SP1071,SP1069,SP1167,SP1168,SP1169	×	×
CLA-Class	118	Chassis	ESP- Electric stability program	√	√	√	√	√	ACT0069,ACT0070,ACT0285,ACT0288	SP1174,SP1175,SP1176,SP1177,SP1178,SP1179,SP1180,SP1181,SP1182,	×	×
CLA-Class	118	Chassis	ESP- Electric stability program	√	√	√	√	×	ACT0069,ACT0070,ACT0285,ACT0288	SP1174,SP1175,SP1176,SP1177,SP1178,SP1179,SP1180,SP1181,SP1182,	×	×
CLA-Class	118	Chassis	Lower control panel(DRVU)	√	√	√	×	×	×	×	×	×
CLA-Class	118	Drive	48V on board electrical system of ISG starter generator	√	√	√	×	×	×	×	×	×
CLA-Class	118	Drive	CDI-Engine Electronics CRR2 for Internal Combustion Engine OM608	√	√	√	√	√	ACT0336,ACT0005,ACT0002,ACT0031,ACT0030,ACT0032,ACT0022,ACT0328,ACT0026,ACT0033,ACT0337	SP1000,SP1118,SP1119,SP1120,SP1121,SP1122,SP1123,SP1124,SP1125,SP1126,SP1127,SP1022,SP1128,SP1021,SP1129,	×	×
CLA-Class	118	Drive	FSCU-Fuel pump	√	√	√	√	×	×	×	×	×
CLA-Class	118	Drive	N127 (Drivetrain control unit)	√	√	√	×	×	×	×	×	×
CLA-Class	118	Drive	N127 (Drivetrain control unit)	√	√	√	√	×	ACT0028,ACT0430,ACT0431,ACT0432,ACT0433,ACT0007,ACT0434,ACT0435,ACT0436,ACT0437,ACT0438,ACT0439,ACT0440,ACT0441,ACT0442,ACT0443,ACT0444,ACT0445,ACT0446,ACT0447,ACT0448,	SP1186,SP1042,SP1025,SP1187,SP1188,SP1189,SP1190,SP1191,SP1192	×	×
CLA-Class	118	Drive	N15/13 (Double clutch transmission control unit)	√	√	√	√	×	×	×	×	×

CLA-Class	118	Drive	N3/10-Motor electronics "EM71" for combustion engine "M282"	√	√	√	√	√	ACT0330,ACT0002,ACT0005,ACT0456,ACT0323,ACT0324,ACT0325,ACT0025,ACT0328,ACT0329,ACT0022,ACT0457,	SP1001,SP1004,SP1109,SP1115,SP1017,SP1198	×	×
CLA-Class	118	Drive	N3/10-Motor electronics "MED41" for combustion engine "M260/M264"	√	√	√	√	√	ACT0330,ACT0003,ACT0459,ACT0323,ACT0324,ACT0333,ACT0025,ACT0328,ACT0331,ACT0332,ACT0004,ACT0005,ACT0456,ACT0002,ACT0460,ACT0329,ACT0022,ACT0325,	SP1199,SP1117	×	×
CLA-Class	118	Drive	N3/10-Motor electronics "MRG1AMGR4" for combustion engine "M139"	√	√	√	√	×	ACT0330,ACT0002,ACT0025,ACT0005,ACT0022,ACT0456,ACT0329,ACT0462,ACT0328,ACT0463,ACT0464,ACT0331	SP1001,SP1004,SP1200,SP1201,SP1202,SP1203,SP1204,SP1110,SP1109,SP1139,SP1017,SP1111,	×	×
CLA-Class	118	Drive	N3/40-Motor electronics "MRD1" for combustion engine "OM654"	√	√	√	√	√	ACT0001,ACT0005,ACT0006,ACT0321,ACT0008,ACT0009,ACT0010,ACT0322,ACT0011,ACT0012,ACT0016,ACT0018,ACT0022,ACT0023,ACT0024,ACT0026,ACT0000,ACT0338,ACT0339,ACT0340,ACT0341	SP1001,SP1000,SP1130,SP1125,SP1131,SP1132,SP1133,SP1134,SP1135,SP1136,SP1017,SP1137,SP1138,SP1024,SP1139,SP1140,SP1015,SP1141,SP1142,SP1143,SP1144,SP1021,SP1022,SP1145,	×	×
CLA-Class	118	Drive	SCR-Selective catalytic reduction	√	√	√	√	×	ACT0424,ACT0425,ACT0426,ACT0427,ACT0428,ACT0429	SP1184,SP1185	×	×
CLA-Class	118	Drive	SG EM-Power electronics	√	√	√	√	×	ACT0451,ACT0452	SP1193,SP1194,SP1195,SP1196,SP1150	×	×
CLA-Class	118	Drive	VG-All-wheel drive	√	√	√	√	×	×	×	×	×
CLA-Class	118	Drive	VG-All-wheel drive	√	√	√	√	×	ACT0043	SP1171	×	×
CLA-Class	118	Drive	VG-All-wheel drive	√	√	√	√	×	ACT0422,ACT0423	SP1099,SP1170	×	×
CLA-Class	118	Drive	Y3/14n4 (Dual clutch transmission fully integrated transmission control unit)	√	√	√	×	×	×	×	×	×
CLA-Class	118	Drive	Y3/14n4 (Dual clutch transmission fully integrated transmission control unit)	√	√	√	×	×	×	×	×	×
CLA-Class	118	Driver assistance system	DTR-DISTRONIC	√	√	√	√	×	×	SP1161,SP1162	×	×
CLA-Class	118	Driver assistance system	IRS HLA-Outer left rear integrated radar sensor (B92/11)	√	√	√	√	×	×	SP1150,SP1151	×	×
CLA-Class	118	Driver assistance system	IRS HRA-Outer right rear integrated radar sensor (B92/6)	√	√	√	√	×	×	SP1150,SP1151	×	×
CLA-Class	118	Driver assistance system	KAR-Augmented reality camera	√	√	√	√	×	×	×	×	×
CLA-Class	118	Driver assistance system	MFK-Multifunction camera(mono)(A40/11)	√	√	√	√	×	ACT0181,ACT0065	SP1156	×	×
CLA-Class	118	Driver assistance system	MFK-Multifunction camera(stereo)(A40/13)	√	√	√	√	×	ACT0181,ACT0065	SP1063	×	×
CLA-Class	118	Driver assistance system	NBR LR-Left rear short-range radar	√	√	√	√	×	×	SP1173	×	×

CLA-Class	118	Driver assistance system	NBR RR-Right rear short-range radar	√	√	√	√	×	×	SP1172	×	×
CLA-Class	118	Driver assistance system	PTS-PARKTRONIC	√	√	√	√	×	ACT0421,ACT0306	SP1166	×	×
CLA-Class	118	Driver assistance system	RFK-Backup camera	√	√	√	√	×	×	SP1152	×	×
CLA-Class	118	Driver assistance system	SG AWF-COLLISION PREVENTION ASSIST	√	√	√	√	×	×	SP1063	×	×
CLA-Class	118	Driver assistance system	SGR-Radar sensors control unit	√	√	√	√	×	ACT0419,ACT0420	SP1163,SP1164,SP1165	×	×
CLA-Class	118	Driver assistance system	TPM-Tire pressure monitor(N88)	√	√	√	√	×	ACT0078,ACT0079,ACT0081,ACT0080	SP1053	×	×
CLA-Class	118	Information and communication	Audio-Audio or COMAND	√	√	√	×	×	×	×	×	×
CLA-Class	118	Information and communication	CSM-Windshield reader system	√	√	√	√	×	×	×	×	×
CLA-Class	118	Information and communication	HERMES-control unit for telematics services	√	√	√	√	×	×	SP1046	×	×
CLA-Class	118	Information and communication	HUD-Head up display	√	√	√	√	×	ACT0210,ACT0212	×	×	×
CLA-Class	118	Information and communication	IC-Instrument cluster	√	√	√	√	×	ACT0039,ACT0397,ACT0048,ACT0210,ACT0398,ACT0399,ACT0050,ACT0400	SP1043,SP1044,SP1045	×	×
CLA-Class	118	Information and communication	MTAS-Mobile phone cradle	√	√	√	√	×	×	×	×	×
CLA-Class	118	Information and communication	SOUND-Sound system	√	√	√	√	×	×	×	×	×
CLA-Class	118	Information and communication	TPAD-Touchpad	√	√	√	√	×	×	×	×	×
CLA-Class	118	Information and communication	ZAN-Audio/COMAND display	√	√	√	√	×	ACT0291,ACT0206,ACT0039	×	×	×
CLA-Class	118	Seats and Doors	DCU LR-Left rear door	√	√	√	√	×	ACT0360,ACT0361,ACT0362,ACT0363,ACT0347,ACT0364,ACT0365,ACT0366	SP1080,SP1147,SP1148	×	×
CLA-Class	118	Seats and Doors	DCU RF-Right front door	√	√	√	√	×	ACT0353,ACT0274,ACT0273,ACT0354,ACT0283,ACT0284,ACT0281,ACT0282,ACT0355,ACT0278,ACT0356,ACT0357,ACT0347,ACT0279,ACT0348,ACT0349,ACT0358,ACT0359,	SP1080,SP1147,SP1148	×	×
CLA-Class	118	Seats and Doors	DCU RR-Right rear door	√	√	√	√	×	ACT0367,ACT0368,ACT0369,ACT0370,ACT0347,ACT0371,ACT0365,ACT0366	SP1080,SP1147,SP1148	×	×
CLA-Class	118	Seats and Doors	ESA Front passenger-Electric seat adjustment Front passenger	√	√	√	√	×	ACT0230,ACT0378,ACT0234,ACT0379,ACT0233,ACT0380,ACT0381,ACT0382	SP1075	×	×
CLA-Class	118	Seats and Doors	ESV Driver-Electric seat adjustmnet Driver	√	√	√	√	×	ACT0214,ACT0373,ACT0218,ACT0374,ACT0217,ACT0375,ACT0376,ACT0377	SP1075	×	×
CLA-Class	118	Seats and Doors	HKS-Tailgate control	√	√	√	√	×	×	×	×	×

CLA-Class	118	Seats and Doors	LFD-Left front door	√	√	√	√	×	ACT0342,ACT0255,ACT0254,ACT0343,ACT0269,ACT0270,ACT0267,ACT0268,ACT0344,ACT0261,ACT0345,ACT0346,ACT0347,ACT0263,ACT0348,ACT0349,ACT0350,ACT0351,	SP1080,SP1147,SP1148	×	×
CLA-Class	118	Seats and Doors	MKS LF-Left front multicontour seat	√	√	√	√	×	ACT0383,ACT0384,ACT0385,ACT0386,ACT0387,ACT0388	×	×	×
CLA-Class	118	Seats and Doors	MKS RF-Right front multicontour seat	√	√	√	√	×	ACT0383,ACT0384,ACT0385,ACT0386,ACT0387,ACT0388	×	×	×
CLA-Class	118	Seats and Doors	MKS-BFS-Front passenger more copy the seat	√	√	√	√	×	ACT0383,ACT0384,ACT0386	×	×	×
CLA-Class	118	Seats and Doors	MKS-FS-Pilot multi-profile seat	√	√	√	√	×	ACT0383,ACT0384,ACT0386	×	×	×
CLA-Class	118	Seats and Doors	S22 (Driver"s door seat adjustment switch)	√	√	√	√	×	×	×	×	×
CLA-Class	118	Seats and Doors	S23 (Front passenger door seat adjustment switch)	√	√	√	√	×	×	×	×	×
CLA-Class	118	Seats and Doors	S47/2 (Driver door switch module)	√	√	√	√	×	×	×	×	×
CLA-Class	118	Seats and Doors	S47/3 (Front passenger door switch module)	√	√	√	√	×	×	×	×	×
CLA-Class	118	Seats and Doors	S51/1 (Driver seat climate control switch group)	√	√	√	√	×	×	×	×	×
CLA-Class	118	Seats and Doors	S51/2 (Front passenger seat climate control switch group)	√	√	√	√	×	×	×	×	×
E-Class	212	Air conditioning	A9/5 (Electric refrigerant compressor)	√	√	√	√	×	ACT1123	×	×	√
E-Class	212	Air conditioning	AAC-Automatic air conditioning	√	√	√	√	×	ACT0182,ACT0185,ACT0003,ACT0558,ACT0773,ACT0188,ACT0183,ACT0184,ACT0194,ACT0196,ACT0197,ACT0647,ACT0648,ACT0649,ACT0650,ACT0653,ACT0654,ACT1027,ACT0655,ACT0656,ACT1026,	SP1065,SP1066,SP1067	×	√
E-Class	212	Air conditioning	LRH-Steering wheel heater	√	√	√	√	×	ACT0064	×	×	√
E-Class	212	Air conditioning	STH-Stationary heater	√	√	√	√	×	ACT0200,ACT0201,ACT1028,ACT1029,ACT0664,ACT1030,ACT1031,ACT0203,ACT1032,	×	×	√
E-Class	212	Body	AISP-Dimming inside rearview mirror(A67)	√	√	√	√	×	×	×	×	×
E-Class	212	Body	AISP-Dimming inside rearview mirror(A67)	√	√	√	√	×	×	×	×	×
E-Class	212	Body	AMLAB L 2-Actuation module 2, LED exterior lighting, left	√	√	√	√	×	ACT0299,ACT0300	SP1091,SP1092,SP1094	CD0621	×
E-Class	212	Body	AMLAB R 2-Actuation module 2, LED exterior lighting, right front(E2n8)	√	√	√	√	×	ACT0299,ACT0300	SP1091,SP1092	CD0621	×
E-Class	212	Body	AS-Alarm siren(H3/1)	√	√	√	√	×	ACT0936	×	×	×
E-Class	212	Body	AS-Alarm siren(H3/1)	√	√	√	×	×	ACT0936	×	×	×
E-Class	212	Body	ATA-ATA[EDW]/tow-away protection/interior protection	√	√	√	√	×	ACT0937,ACT0938	×	×	×

E-Class	212	Body	AU-Analog clock	√	√	√	×	×	×	×	×	×
E-Class	212	Body	B38/2-Rain/light sensor(RGLS)	√	√	√	√	×	×	×	×	×
E-Class	212	Body	BMS-Battery management system(N82/2)	√	√	√	√	×	ACT0778,ACT1120,ACT0960	SP1386,SP1193	×	√
E-Class	212	Body	BMS-Battery management system(N82/2)	√	√	√	√	×	ACT0778,ACT1120,ACT1136,ACT1137,ACT0960	SP1104	CD0646	√
E-Class	212	Body	BSN-Battery sensor(B95)	√	√	√	√	×	×	×	×	×
E-Class	212	Body	BSN-Battery sensor(B95)	√	√	√	√	×	×	×	×	×
E-Class	212	Body	CGW-Central gateway	√	√	√	√	×	×	SP1373	×	√
E-Class	212	Body	CGW[ZGW]-Central gateway	√	√	√	√	×	×	SP1373	CD0621	√
E-Class	212	Body	CGW[ZGW]-Central gateway	√	√	√	√	×	×	SP1373	CD0621	√
E-Class	212	Body	Driver side SAM-Driver signal acquisition and actuation module	√	√	√	√	×	ACT0880,ACT0881,ACT0882,ACT0883,ACT0884,ACT0885,ACT0886,ACT0887	×	×	√
E-Class	212	Body	Driver side SAM-Driver signal acquisition and actuation module	√	√	√	√	×	ACT0880,ACT0881,ACT0882,ACT0883,ACT0884,ACT0885,ACT0886,ACT0887	×	×	√
E-Class	212	Body	Driver side SAM-Front signal acquisition and actuation module	√	√	√	√	×	ACT0880,ACT0881,ACT0882,ACT0883,ACT0884,ACT0885,ACT0886,ACT0887	×	×	√
E-Class	212	Body	E1n7 (Actuation module, LED exterior lighting, left front)	√	√	√	√	×	ACT0299,ACT0300	SP1091,SP1092,SP1094	CD0621	×
E-Class	212	Body	E2n7 (Actuation module, LED exterior lighting, right front)	√	√	√	√	×	ACT0299,ACT0300	SP1091,SP1092	CD0621	×
E-Class	212	Body	Exterior lights switch	√	√	√	√	×	×	×	×	×
E-Class	212	Body	EZS-Electronic ignition lock	√	√	√	√	×	×	×	CD0621	×
E-Class	212	Body	EZS-Electronic ignition lock	√	√	√	√	×	×	×	×	×
E-Class	212	Body	EZS-Electronic ignition lock	√	√	√	√	×	×	×	×	×
E-Class	212	Body	EZS-Electronic ignition switch	√	√	√	√	×	×	×	×	×
E-Class	212	Body	EZS-Electronic ignition switch	√	√	√	√	×	×	SP1048,SP1049,SP1050	CD0621,CD0622,CD0623,CD0624,CD0625	×
E-Class	212	Body	FSW-Windshield wiper	√	√	√	√	×	ACT0934	×	×	×
E-Class	212	Body	FSW-Windshield wiper	√	√	√	√	×	ACT0934	×	×	×
E-Class	212	Body	GTO-Garage door	√	√	√	√	×	×	×	×	×
E-Class	212	Body	GTO-Garage door	√	√	√	√	×	×	×	×	×
E-Class	212	Body	Hazard warning light system	√	√	√	√	×	×	×	×	×
E-Class	212	Body	IRS HLA-Outer left rear intelligent radar sensor system	√	√	√	√	×	×	×	×	√
E-Class	212	Body	IRS HRA-Outer right rear intelligent radar sensor	√	√	√	√	×	×	×	×	√
E-Class	212	Body	KG-KEYLESS GO	√	√	√	√	×	ACT0875,ACT0132,ACT0131,ACT0876	×	×	×
E-Class	212	Body	KG-KEYLESS GO(N69/5)	√	√	√	√	×	ACT0131,ACT0132	×	×	√
E-Class	212	Body	KG-KEYLESS GO(N69/5)	√	√	√	√	×	ACT0877,ACT0875,ACT0131,ACT0132,ACT0876	×	×	√
E-Class	212	Body	LCP-Lower control panel	√	√	√	√	×	×	×	×	×
E-Class	212	Body	LCP-Lower control panel	√	√	√	√	×	×	×	×	×

E-Class	212	Body	Multifunction control unit- Multifunction control unit	√	√	√	√	×	ACT0111,ACT0112,ACT0113, ACT0114,ACT0115,ACT0116, ACT0117,ACT0118,ACT0119, ACT0120,ACT0121,ACT0122, ACT0123,ACT0124,ACT0125, ACT0126,ACT0127,ACT0128	×	×	√
E-Class	212	Body	OCP-Overhead control panel	√	√	√	√	×	ACT0667,ACT0302,ACT0303, ACT0301	SP1072	×	√
E-Class	212	Body	PSD-Control module 'Panoramic sliding roof'(A98)	√	√	√	√	×	ACT0207,ACT0208	SP1072	×	√
E-Class	212	Body	Rear SAM-Rear signal acquisition and actuation module	√	√	√	√	×	ACT0888,ACT0889,ACT0890, ACT0813,ACT0240,ACT0751, ACT0891,ACT0748,ACT0752, ACT0892,ACT0893,ACT0894, ACT0895,ACT0757,ACT0896, ACT0897,ACT0898,ACT0677, ACT0899,ACT0900,ACT0901, ACT0411,ACT0412,ACT0902, ACT0903,ACT0904,ACT0905, ACT0768,ACT0616,ACT0906, ACT0907,ACT0908,ACT0465, ACT0909,ACT0741,ACT0910, ACT0911,ACT0912,ACT0888, ACT0240,ACT0751,ACT0891, ACT0748,ACT0752,ACT0888, ACT0890,ACT0240,ACT0751, ACT0891,ACT0748,ACT0752, ACT0910,ACT0911,ACT0913, ACT0910,ACT0914,ACT0911, ACT0915,ACT0916,ACT0917,	×	×	√
E-Class	212	Body	REAR SAM-Rear signal acquisition and actuation module	√	√	√	√	×	ACT0888,ACT0889,ACT0890, ACT0813,ACT0240,ACT0751, ACT0891,ACT0748,ACT0752, ACT0892,ACT0893,ACT0894, ACT0895,ACT0757,ACT0896, ACT0897,ACT0898,ACT0677, ACT0899,ACT0900,ACT0901, ACT0411,ACT0412,ACT0902, ACT0903,ACT0904,ACT0905, ACT0768,ACT0616,ACT0906, ACT0907,ACT0908,ACT0465, ACT0909,ACT0741,ACT0910, ACT0911,ACT0912,ACT0888, ACT0240,ACT0751,ACT0891, ACT0748,ACT0752,ACT0888, ACT0890,ACT0240,ACT0751, ACT0891,ACT0748,ACT0752, ACT0910,ACT0911,ACT0913, ACT0910,ACT0914,ACT0911, ACT0915,ACT0916,ACT0917,	×	×	√

E-Class	212	Body	REAR SAM-Rear signal acquisition and actuation module	√	√	√	√	×	ACT0888,ACT0889,ACT0890,ACT0813,ACT0240,ACT0751,ACT0891,ACT0748,ACT0752,ACT0892,ACT0893,ACT0894,ACT0895,ACT0757,ACT0896,ACT0897,ACT0898,ACT0677,ACT0899,ACT0900,ACT0901,ACT0411,ACT0412,ACT0902,ACT0903,ACT0904,ACT0905,ACT0768,ACT0616,ACT0906,ACT0907,ACT0908,ACT0465,ACT0909,ACT0741,ACT0910,ACT0911,ACT0912,ACT0888,ACT0240,ACT0751,ACT0891,ACT0748,ACT0752,ACT0888,ACT0890,ACT0240,ACT0751,ACT0891,ACT0748,ACT0752,ACT0888,ACT0910,ACT0911,ACT0913,ACT0910,ACT0914,ACT0911,ACT0915,ACT0916,ACT0917,	×	×	√
E-Class	212	Body	RevETR LF-Left front reversible emergency tensioning retractor	√	√	√	√	×	ACT0209	×	×	√
E-Class	212	Body	RevETR RF-Right front reversible emergency tensioning	√	√	√	√	×	ACT0213	×	×	√
E-Class	212	Body	SCCM-Steering column module(N80)	√	√	√	√	×	ACT0060,ACT0062,ACT0065,ACT0063,ACT0061	×	×	√
E-Class	212	Body	SCM-Steering column module(N80)	√	√	√	√	×	ACT0060,ACT0061,ACT0062,ACT0063,ACT0064,ACT0065	×	×	√
E-Class	212	Body	SG SW L-Left headlamp	√	√	√	√	×	ACT0292,ACT0293,ACT0297,ACT0298,ACT0299,ACT0300	SP1084,SP1088,SP1089,SP1090,SP1091,SP1092,	CD0621	√
E-Class	212	Body	SG SW L-Left headlamp(E1n9)	√	√	√	√	×	ACT0292,ACT0293,ACT0297,ACT0298,ACT0299,ACT0300	SP1084,SP1088,SP1089,SP1090,SP1094,SP1091,SP1092,SP1093	CD0621	√
E-Class	212	Body	SG SW R-Right headlamp	√	√	√	√	×	ACT0292,ACT0293,ACT0297,ACT0298,ACT0299,ACT0300	SP1095,SP1096,SP1097,SP1091,SP1092,SP1093	CD0621	√
E-Class	212	Body	SG SW R-Right headlamp(E1n9)	√	√	√	√	×	ACT0292,ACT0293,ACT0297,ACT0298,ACT0299,ACT0300	SP1091,SP1092,SP1093,SP1095,SP1096,SP1097	CD0621	√
E-Class	212	Body	SRS-Supplemental restraint	√	√	√	√	√	×	×	×	√
E-Class	212	Body	SRS-Supplemental restraint system (N2/10)	√	√	√	√	√	×	×	×	√
E-Class	212	Body	TLC-Trunk lid control	√	√	√	√	×	ACT0171,ACT1023,ACT1024,ACT0173,ACT1025	SP1062,SP1428	×	√
E-Class	212	Body	TRM-Trailer recognition module (N28/1)	√	√	√	√	×	ACT0237,ACT0236,ACT0238,ACT0239,ACT0747,ACT0240,ACT0241,ACT0242,ACT1035	×	×	√
E-Class	212	Body	UCP-Upper control panel	√	√	√	√	×	×	×	×	×
E-Class	212	Body	UCP-Upper control panel	√	√	√	√	×	×	×	×	×
E-Class	212	Body	WSS-Weight sensing	√	√	√	√	×	×	×	×	×
E-Class	212	Body	WSS-Weight sensing	√	√	√	√	×	×	×	×	×
E-Class	212	Body	XALWA L-Left xenon headlamp(E1n1)	√	√	√	√	×	ACT1037,ACT1038,ACT0294,ACT1134,ACT1042,ACT0297	SP1084,SP1087,SP1430	×	√

E-Class	212	Body	XALWA R-Right xenon headlamp(E2n1)	√	√	√	√	×	ACT1043,ACT1044,ACT0294,ACT1135,ACT1045,ACT0297	SP1430	×	√
E-Class	212	Chassis	ADS-Adaptive damping system	√	√	√	√	×	ACT0167,ACT0168,ACT0169,ACT0170	SP1061	×	√
E-Class	212	Chassis	ADS-Adaptive damping system(N51/5)	√	√	√	√	×	ACT0167,ACT0168,ACT0169,ACT0170	SP1061	×	√
E-Class	212	Chassis	AMG DRVU-AMG DRIVE UNIT(N145)	√	√	√	√	×	ACT0066,ACT0067,ACT0068	×	×	√
E-Class	212	Chassis	ELC-Electronic level control	√	√	√	√	×	ACT1140,ACT1141,ACT0629,ACT0628,ACT0639,ACT0638,	SP1339,SP1061	×	√
E-Class	212	Chassis	ES-Electric power steering(N68)	√	√	√	√	×	×	SP1071	×	√
E-Class	212	Chassis	ES-Electric power steering(N68)	√	√	√	√	×	×	SP1071,SP1167	×	√
E-Class	212	Chassis	ESP- Electric stability program	√	√	√	√	√	ACT0873,ACT0874,ACT1018,ACT0069,ACT0070	SP1426,SP1051	×	√
E-Class	212	Chassis	ESP-Electronic stability program(N30/4)	√	√	√	√	√	ACT0069,ACT0070,ACT1122	SP1460,SP1327	×	√
E-Class	212	Chassis	ESP-Regenerative braking system(N30/6)	√	√	√	√	√	ACT0612,ACT0069,ACT0070	SP1168,SP1051,SP1329,SP1330,SP1331,SP1332	CD0608,CD0609,CD0689,CD0690	√
E-Class	212	Chassis	FGW-Chassis gateway	√	√	√	√	×	×	×	CD0621	√
E-Class	212	Drive	CNG-Compressed natural gas	√	×	×	√	×	×	×	×	√
E-Class	212	Drive	FSCU-Fuel pump	√	√	√	√	×	ACT0252,ACT0320	×	CD0621,CD0608	√
E-Class	212	Drive	FSCU-Fuel pump	√	√	√	√	×	ACT0320	×	×	√
E-Class	212	Drive	FSCU05-Control unit Fuel pump	√	√	√	√	×	ACT0252	×	×	√
E-Class	212	Drive	ISM-Shift module	√	√	√	√	×	ACT0669,ACT0670,ACT0671,ACT0318,ACT0672	SP1345,SP1002,SP1346	×	√
E-Class	212	Drive	N15/3-Transmission control for 5 speed transmission	√	√	√	√	√	ACT1017,ACT0592	SP1422,SP1423,SP1302,SP1424,SP1425,SP1117,	CD0621,CD0608,CD0609	√
E-Class	212	Drive	N15/5 (Electronic selector lever module control unit)	√	√	√	√	×	ACT0932,ACT0933,ACT0509	×	×	√
E-Class	212	Drive	N3/10-Motor electronics "CNGCM212" for combustion engine "M271CNG"	√	×	×	√	×	ACT1142,ACT1143,ACT1144,ACT1145,ACT1146,ACT1147,ACT1148	×	×	√
E-Class	212	Drive	N3/10-Motor electronics "ME97 AMG" for combustion engine "M156"	√	√	√	√	√	ACT0002,ACT0003,ACT0952,ACT0953,ACT0939,ACT0954,ACT0941,ACT0955,ACT0956,ACT0463,ACT0705,ACT0464,ACT0706,ACT0325,ACT0957,ACT0326,ACT0958,ACT0000,	SP1001,SP1002,SP1117,SP1383,SP1216,SP1116	CD0621,CD0608,CD0609,CD0610,CD0677,CD0678,CD0682,CD0680	√
E-Class	212	Drive	N3/10-Motor electronics "ME97" for combustion engine "M272"	√	√	√	√	√	ACT0002,ACT0003,ACT0005,ACT0939,ACT0954,ACT0941,ACT0463,ACT0705,ACT0464,ACT0706,ACT0325,ACT0326,ACT0958,ACT0000,ACT0331	SP1004,SP1001,SP1002,SP1113,SP1117,SP1383,SP1108,SP1216,SP1202	CD0621,CD0608,CD0609,CD0610,CD0677,CD0678,CD0682,CD0680	√
E-Class	212	Drive	N3/10-Motor electronics "MED177" for combustion engine "M276"	√	√	√	√	√	ACT0005,ACT0002,ACT0003,ACT0335,ACT0480,ACT0463,ACT0705,ACT0464,ACT0706,ACT0325,ACT0326,ACT0025,ACT0016,ACT0707,ACT0708,ACT0017,ACT0709,ACT0022,	SP1109,SP1110,SP1017,SP1108,SP1349,SP1350,SP1351,SP1002,SP1113,SP1352,SP1001,SP1202,SP1004,SP1201	CD0621,CD0608,CD0609,CD0610,CD0677,CD0678,CD0682,CD0680,CD0681	√

E-Class	212	Drive	N3/10-Motor electronics "MED177V6LA" for combustion engine "M276Turbocharger"	✓	✓	✓	✓	✓	ACT0005,ACT0002,ACT0003, ACT0711,ACT0480,ACT0463, ACT0705,ACT0464,ACT0706, ACT0325,ACT0326,ACT0025, ACT0016,ACT0017,ACT0441, ACT0709,ACT0022,ACT0712, SP1203	SP1109,SP1110,SP1017, SP1108,SP1349,SP1353, SP1354,SP1112,SP1001, SP1002,SP1004,SP1352, SP1113,SP1202,SP1201, SP1203	CD0621,CD0608,CD0609, CD0610,CD0677,CD0678, CD0682,CD0680,CD0681	✓
E-Class	212	Drive	N3/10-Motor electronics "MED40" for combustion engine "M274"	✓	✓	✓	✓	✓	ACT0002,ACT0003,ACT0005, ACT0322,ACT0323,ACT0324, ACT0325,ACT0326,ACT0025, ACT0327,ACT0017,ACT0328, ACT0329,ACT0022,ACT0024, ACT0330,ACT0331,ACT0332, SP1116	SP1108,SP1017,SP1109, SP1110,SP1111,SP1112, SP1007,SP1113,SP1114, SP1001,SP1004,SP1115, SP1002,SP1029,SP1042, SP1116	CD0621,CD0608,CD0609, CD0610,CD0677,CD0678, CD0679,CD0680,CD0681	✓
E-Class	212	Drive	N3/10-Motor electronics "MED40CNG" for combustion engine "M270"	✓	✓	✓	✓	✓	ACT0002,ACT0003,ACT0005, ACT0322,ACT0323,ACT0324, ACT0325,ACT0025,ACT0016, ACT0017,ACT0328,ACT0329, ACT0022,ACT0024,ACT0330, ACT0331,ACT0332,ACT0333, ACT1146,ACT1051,ACT1143,	SP1001,SP1002,SP1004, SP1114,SP1116,SP1042, SP1113,SP1108,SP1117, SP1029,SP1462,SP1463, SP1115,SP1464	CD0621,CD0608,CD0609, CD0610,CD0677,CD0678, CD0681,CD0756,CD0757, CD0679,CD0680	✓
E-Class	212	Drive	N3/10-Motor electronics "MED97" for combustion engine "M272"	✓	✓	✓	✓	✓	ACT0003,ACT0480,ACT0005, ACT0954,ACT0463,ACT0705, ACT0464,ACT0706,ACT0325, ACT0328,ACT0025,ACT0017, ACT1047,ACT0334,ACT0000,	SP1004,SP1001,SP1002, SP1117,SP1216,SP1202	CD0621,CD0608,CD0609, CD0610,CD0677,CD0678, CD0682,,CD0680,CD0681	✓
E-Class	212	Drive	N3/10-Motor electronics "SIM271DE20" for combustion engine "M271EVO"	✓	✓	✓	✓	✓	ACT0458,ACT0002,ACT0003, ACT0005,ACT0939,ACT0940, ACT0480,ACT0014,ACT0941, ACT0323,ACT0324,ACT0325, ACT0326,ACT0025,ACT0017, ACT0329,ACT0331,ACT0942,	SP1001,SP1004,SP1378, SP1109,SP1002,SP1379, SP1380,SP1007	CD0621,CD0608,CD0609, CD0610,CD0677,CD0678, CD0716,CD0679,CD0680, CD0717	✓
E-Class	212	Drive	N3/10-Motor electronics "SIM271KECNG" for combustion engine "M271CNG"	✓	✓	✓	✓	✓	ACT0005,ACT0456,ACT0325, ACT0003,ACT0002,ACT0958, ACT0323,ACT0324,ACT0326, ACT0942,ACT0017,ACT1143, ACT1142,ACT1144,ACT1145, ACT1146,ACT1147,ACT1148	SP1001,SP1004,SP1431, SP1002,SP1379,SP1110, SP1109,SP1380,SP1465, SP1466,SP1467	CD0621,CD0608,CD0609, CD0610,CD0677,CD0678, CD0716,CD0682,CD0680, CD0717,CD0758,CD0759	✓
E-Class	212	Drive	N3/9-Motor electronics "CDI60LS" for combustion engine "OM642"	✓	✓	✓	✓	✓	ACT0002,ACT0003,ACT0005, ACT0008,ACT0010,ACT0011, ACT0590,ACT0016,ACT0018, ACT0012,ACT0591,ACT0026	SP1000,SP1001,SP1002, SP1004,SP1020,SP1137, SP1295,SP1019,SP1135, SP1009,SP1294,SP1012, SP1013,SP1144,SP1015, SP1016,SP1023,SP1021,	CD0608,CD0609,CD0610	✓
E-Class	212	Drive	N3/9-Motor electronics "CDI61" for combustion engine "OM642"	✓	✓	✓	✓	✓	ACT0026,ACT0005,ACT0002, ACT0003,ACT0008,ACT0033, ACT0010,ACT0011,ACT0024, ACT0012,ACT0016,ACT0017, ACT0018	SP1000,SP1001,SP1004, SP1002,SP1009,SP1137, SP1295,SP1135,SP1016, SP1015,SP1296,SP1297, SP1144,SP1298,SP1019, SP1023,SP1020,SP1012, SP1294,SP1013,SP1021,	CD0608,CD0609,CD0610, CD0611	✓

E-Class	212	Drive	N3/9-Motor electronics "CDI6BIN5EU6" for combustion engine "OM642"	√	√	√	√	×	ACT0005,ACT0002,ACT0028,ACT0008,ACT0010,ACT0012,ACT0016,ACT0033,ACT0026,ACT0000	SP1000,SP1015,SP1294,SP1009,SP1004,SP1001,SP1002,SP1012,SP1413,SP1013,SP1414,SP1415,SP1416,SP1014,SP1023,SP1021,SP1022,SP1019,	CD0608,CD0609,CD0610	√
E-Class	212	Drive	N3/9-Motor electronics "CDI6EU5" for combustion engine "OM642"	√	√	√	√	√	ACT0005,ACT0002,ACT0003,ACT0008,ACT0010,ACT1006,ACT0012,ACT0016,ACT0033,ACT0026,ACT0000	SP1000,SP1015,SP1294,SP1009,SP1004,SP1001,SP1002,SP1012,SP1413,SP1416,SP1013,SP1414,	CD0608,CD0609,CD0610	√
E-Class	212	Drive	N3/9-Motor electronics "CDID2" for combustion engine "OM651"	√	√	√	√	√	ACT0000,ACT0330,ACT0002,ACT0003,ACT0005,ACT0006,ACT0008,ACT0009,ACT0010,ACT0012,ACT0014,ACT0016,ACT0017,ACT0018,ACT0019,ACT0020,ACT0023,ACT1015,ACT0024,ACT1016,ACT0026,	×	CD0621,CD0608,CD0609,CD0610	√
E-Class	212	Drive	N3/9-Motor electronics "CDID3" for combustion engine "OM651"	√	√	√	√	√	ACT0000,ACT0001,ACT0002,ACT0003,ACT0004,ACT0005,ACT0006,ACT0007,ACT0008,ACT0009,ACT0010,ACT0011,ACT0012,ACT0013,ACT0014,ACT0015,ACT0016,ACT0017,ACT0018,ACT0019,ACT0020,ACT0021,ACT0022,ACT0023,	SP1000,SP1001,SP1002,SP1003,SP1004,SP1005,SP1006,SP1007,SP1008,SP1009,SP1010,SP1011,SP1012,SP1013,SP1014,SP1015,SP1016,SP1017,SP1018,SP1019,SP1020,SP1021,SP1022,SP1023,	CD0608,CD0609,CD0610,CD0611	√
E-Class	212	Drive	N3/9-Motor electronics "CR42" for combustion engine "OM651"	√	√	√	√	√	ACT0004,ACT0005,ACT0002,ACT0003,ACT0008,ACT0009,ACT0010,ACT0011,ACT0022,ACT0023,ACT0024,ACT0012,ACT0016,ACT0017,ACT0018,ACT0019,ACT0027,ACT0026,ACT0000,ACT0020	SP1000,SP1001,SP1002,SP1003,SP1004,SP1020,SP1410,SP1290,SP1291,SP1019,SP1292,SP1293,SP1009,SP1294,SP1012,SP1013,SP1411,SP1015,SP1412,SP1023,SP1021,	CD0608,CD0609,CD0610	√
E-Class	212	Drive	N3/9-Motor electronics "CR43" for combustion engine "OM651"	√	√	√	√	√	ACT0330,ACT0589,ACT0005,ACT0003,ACT0008,ACT0010,ACT0011,ACT0022,ACT0023,ACT0024,ACT0012,ACT0014,ACT0017,ACT0018,ACT0026,ACT0000	SP1000,SP1001,SP1002,SP1003,SP1004,SP1020,SP1289,SP1290,SP1291,SP1133,SP1019,SP1292,SP1293,SP1009,SP1294,SP1012,SP1013,SP1144,SP1015,SP1016,SP1021,	CD0608,CD0609,CD0610,CD0611	√
E-Class	212	Drive	PE-Power electronics(N129/1)	√	√	√	√	×	ACT0451,ACT0452	SP1193,SP1323,SP1461,SP1002	CD0608,CD0609	√
E-Class	212	Drive	SCR-Selective catalytic reduction	√	√	√	√	×	ACT0424,ACT0602,ACT0425,ACT0426,ACT0427,ACT0598	SP1185,SP1322,SP1184,SP1319,SP1318,SP1023	CD0608,CD0609,CD0610	√
E-Class	212	Drive	SCR-Selective Catalytic Reduction	√	√	√	√	×	ACT0594,ACT0595,ACT0596,ACT0597,ACT0598,ACT0427,ACT0599,ACT0425,ACT0600,	SP1185,SP1318,SP1319,SP1023,SP1320,SP1321	CD0608,CD0609,CD0610,CD0611	√
E-Class	212	Drive	Y3/8n4-Fully integrated transmission control	√	√	√	√	√	ACT0592,ACT0318	SP1299,SP1300,SP1301,SP1302,SP1303,SP1304,SP1233,SP1305,SP1306,SP1306,SP1307,SP1308,SP1309,SP1002,SP1310,	CD0621,CD0608,CD0609,CD0611	√

E-Class	212	Drive	Y3/8n4-Transmission control for 7 speed transmission	√	√	√	√	√	ACT0592	SP1302,SP1312,SP1300,SP1303,SP1304,SP1233,SP1313,SP1313,SP1230,SP1314,SP1309,SP1002,	CD0621,CD0608,CD0609,CD0611,CD0683	√
E-Class	212	Drive	Y3/8n4-Transmission control for 9 speed transmission	√	√	√	√	√	ACT0592,ACT0312,ACT0593,ACT0317	SP1311,SP1315,SP1316,SP1305,SP1312,SP1317	CD0621,CD0608,CD0609,CD0610,CD0611	√
E-Class	212	Driver assistance system	CAMERA-360 camera(N148)	√	√	√	√	×	ACT0421	SP1205,SP1206,SP1207,SP1208,SP1209,SP1082	×	√
E-Class	212	Driver assistance	CAMERA-360 camera(N148)	√	√	√	√	×	ACT0624	SP1336,SP1337,SP1338	×	√
E-Class	212	Driver assistance system	CPA-Control unit 'COLLISION PREVENTION ASSIST'(A90)	√	√	√	√	×	ACT0110	SP1059	×	√
E-Class	212	Driver assistance	DTR-DISTRONIC	√	√	√	√	×	×	×	×	√
E-Class	212	Driver assistance	DTR-DISTRONIC	√	√	√	√	×	×	×	×	√
E-Class	212	Driver assistance system	IRS HLA-Outer left rear intelligent radar sensor system	√	√	√	√	×	×	×	×	×
E-Class	212	Driver assistance system	IRS HRA-Outer right rear intelligent radar sensor	√	√	√	√	×	×	×	×	×
E-Class	212	Driver assistance	MFK-Multifunction camera	√	√	√	√	×	ACT0181,ACT0065	SP1063	×	√
E-Class	212	Driver assistance	MFK-Multifunction	√	√	√	√	×	ACT0181,ACT0065	SP1063,SP1064	×	√
E-Class	212	Driver assistance	NSA-Night View Assist(N101)	√	√	√	√	×	ACT0683,ACT0684,ACT0685	SP1063	×	√
E-Class	212	Driver assistance	NSA-Night View Assist(N101)	√	√	√	√	×	ACT1124,ACT0685	SP1063	×	√
E-Class	212	Driver assistance	PARK-Parking system (N62)	√	√	√	√	×	ACT0305,ACT0306	×	CD0621,CD0672	√
E-Class	212	Driver assistance system	PTS-Parktronic system	√	√	√	√	×	ACT0935	×	CD0621,CD0672,CD0708,CD0709	√
E-Class	212	Driver assistance	RFK-Backup camera	√	√	√	√	×	ACT0098	SP1082,SP1083	×	√
E-Class	212	Driver assistance	RFK-Backup camera	√	√	√	√	×	ACT0098	SP1083	×	√
E-Class	212	Driver assistance	RFK-Backup camera	√	√	√	√	×	ACT0098,ACT0099	SP1083,SP1082,SP1429	CD0621	√
E-Class	212	Driver assistance system	SGR-Radar sensors control unit	√	√	√	√	×	×	SP1333,SP1334,SP1335,SP1167	×	√
E-Class	212	Driver assistance system	SGR-Radar sensors control unit(N62/1)	√	√	√	√	×	×	SP1163,SP1334,SP1335,SP1164,SP1167	×	√
E-Class	212	Driver assistance system	SGR-Radar sensors control unit(N62/1)	√	√	√	√	×	×	SP1333,SP1334,SP1335,SP1167	×	√
E-Class	212	Driver assistance system	TPM-Tire pressure monitor(N88)	√	√	√	√	×	ACT0078,ACT0079,ACT0081,ACT0080	SP1053,SP1392	×	√
E-Class	212	Information and communication	Audio-Audio or COMAND	√	√	√	√	×	×	×	×	×
E-Class	212	Information and communication	Audio-Audio or COMAND	√	√	√	√	×	×	×	×	×
E-Class	212	Information and communication	Audio-Audio or COMAND	√	√	√	×	×	ACT0082,ACT0083,ACT0084,ACT0085,ACT0086,ACT0074,ACT0087,ACT0044,ACT0088,ACT0089,ACT0090,ACT0091,ACT0092,ACT0097,ACT0093,ACT0095,ACT0096,ACT0101,ACT00971,ACT0043,ACT0090,ACT0091,ACT0092,ACT0097,ACT0095,ACT0096,ACT00972,ACT0093,ACT0094,ACT0083,ACT0084,ACT0105,ACT00975,ACT0082,ACT0085,ACT0086,ACT0074,ACT0088,ACT0101,	SP1393,SP1054,SP1394	CD0621,CD0723,CD0633,CD0724,CD0634,CD0635,CD0725,CD0726,CD0718,CD0636,CD0727,CD0728,CD0638	×

E-Class	212	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√	×	×	×	×	×
E-Class	212	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√	×	ACT0082,ACT0083,ACT0084,ACT0085,ACT0086,ACT0074,ACT0087,ACT0044,ACT0088,ACT0089,ACT0090,ACT0091,ACT0092,ACT0093,ACT0094,ACT0095,ACT0096,ACT0097,ACT0098,ACT0099,ACT0100,ACT0097,ACT0098,ACT0099,ACT0098,ACT0100,ACT0101,ACT0043,ACT0102,ACT0103,ACT0104,ACT0090,ACT0091,ACT0092,ACT0097,ACT0095,ACT0096,ACT0083,ACT0084,ACT0105,ACT0106,ACT0082,	SP1054,SP1055,SP1056,SP1057,SP1058	×	×
E-Class	212	Information and communication	AVE H-Rear audio video unit	√	√	√	√	×	ACT0605,ACT0072,ACT0606,ACT0607,ACT0608	×	CD0621,CD0684,CD0685,CD0686,CD0656	√
E-Class	212	Information and communication	AVE H-Rear audio video unit	√	√	√	√	×	ACT0605,ACT0072,ACT0606,ACT0702,ACT0607,ACT0608	×	CD0621,CD0684,CD0685,CD0686,CD0656	√
E-Class	212	Information and communication	COU-Audio/COMAND operating unit (A40/9)	√	√	√	√	×	ACT0289	×	×	√
E-Class	212	Information and communication	COU-Audio/COMAND operating unit (A40/9)	√	√	√	√	×	ACT0289	×	×	√
E-Class	212	Information and communication	CTEL-Mobile phone	√	√	√	√	×	ACT0043,ACT1046	×	×	×
E-Class	212	Information and communication	D FOL-Display in left rear passenger compartment	√	√	√	√	×	ACT0043,ACT0206,ACT0072,ACT0607,ACT0608	SP1340,SP1341,SP1342,SP1343,SP1344	CD0621,CD0684,CD0685,CD0656	√
E-Class	212	Information and communication	D FOL-Display in left rear passenger compartment	√	√	√	√	×	ACT0043,ACT0206,ACT0072,ACT0607,ACT0608	SP1340,SP1341,SP1342,SP1343,SP1344	CD0621,CD0684,CD0685,CD0656	√
E-Class	212	Information and communication	D FOR-Display in right rear passenger compartment	√	√	√	√	×	ACT0043,ACT0206,ACT0072,ACT0607,ACT0608	SP1340,SP1341,SP1342,SP1343,SP1344	CD0621,CD0684,CD0685,CD0656	√
E-Class	212	Information and communication	D FOR-Display in right rear passenger compartment	√	√	√	√	×	ACT0043,ACT0206,ACT0072,ACT0607,ACT0608	SP1340,SP1341,SP1342,SP1343,SP1344	CD0621,CD0684,CD0685,CD0656	√
E-Class	212	Information and communication	DAB-Digital Audio Broadcasting	√	√	√	√	×	×	×	×	×
E-Class	212	Information and communication	DAB-Digital Audio Broadcasting	√	√	√	√	×	ACT0198,ACT0087,ACT0199,ACT0039	×	×	×
E-Class	212	Information and communication	DAB-Digital Audio Broadcasting	√	√	√	√	×	ACT0198,ACT0087,ACT0199,ACT0039	×	CD0621	×
E-Class	212	Information and communication	DAB-Digital Audio Broadcasting(N87/3)	√	√	√	√	×	×	×	×	×
E-Class	212	Information and communication	Drive Kit Plus-Drive kit for iPhone	√	√	√	√	×	ACT0204,ACT0205,ACT0058,ACT0043	×	×	×
E-Class	212	Information and communication	DSI-DIRECT SELECT interface(N150)	√	√	√	√	×	ACT0307	×	×	√
E-Class	212	Information and communication	ECS-N123/4 Emergency call system control unit	√	√	√	√	×	ACT0043,ACT0058,ACT0059	×	×	×
E-Class	212	Information and communication	HUD-Head up display	√	√	√	√	×	ACT0210,ACT0211,ACT0212	SP1073	×	×
E-Class	212	Information and communication	IC-Instrument cluster	√	√	√	√	×	ACT0045,ACT0046,ACT0047,ACT0048,ACT0049,ACT0039,	SP1043,SP1044,SP1045	×	√

E-Class	212	Information and communication	ICI-InCar Internet(N125/3)	√	√	√	√	×	ACT0206,ACT0044,ACT0039	×	×	×
E-Class	212	Information and communication	KOMO-Communication module Telematics services	√	√	√	√	×	ACT0051,ACT0039,ACT0043, ACT0040,ACT0052,ACT0053, ACT0054,ACT0055,ACT0056,	×	×	√
E-Class	212	Information and communication	Left front short range radar	√	√	√	√	×	×	×	×	√
E-Class	212	Information and communication	Left front short range radar	√	×	×	×	×	×	×	×	√
E-Class	212	Information and communication	MIF-Media interface	√	√	√	√	×	×	×	×	×
E-Class	212	Information and communication	MIF-Media interface	√	√	√	√	×	ACT0043	×	×	×
E-Class	212	Information and communication	N123/4 (emergency call system control unit) - an emergency call	√	√	√	√	×	×	×	×	×
E-Class	212	Information and communication	N123/4 (emergency call system control unit) - anti-theft tracking	√	√	√	√	×	×	×	×	×
E-Class	212	Information and communication	N123/4 (emergency call system control unit) - Mercedes - Benz (MB) information/fault rescue	√	√	√	√	×	×	×	×	×
E-Class	212	Information and communication	N123/4 (emergency call system control unit) - the vehicle remote control unlocking/locking the vehicle remote	√	√	√	√	×	×	×	×	×
E-Class	212	Information and communication	NAV-Navigation module(A2/30)	√	√	√	√	×	ACT0071,ACT0072,ACT0073, ACT0074	×	×	√
E-Class	212	Information and communication	NAVI20-Navigation(N125/2)	√	√	√	√	×	ACT0206,ACT0044	×	×	×
E-Class	212	Information and communication	SDAR-Satellite radio	√	√	√	√	×	ACT0221,ACT0222,ACT0133, ACT0223	×	CD0645CD0646,CD0647,C D0647	×
E-Class	212	Information and communication	SOUND-Bose sound system	√	√	√	√	×	ACT0160,ACT0135,ACT0139, ACT0144,ACT0146,ACT0150, ACT0058,ACT0142,ACT0145, ACT0161,ACT0162,ACT0138, ACT0163,ACT0164,ACT0165, ACT0159,ACT0166,ACT0133	SP1060	×	×
E-Class	212	Information and communication	SOUND-Bose sound system	√	√	√	√	×	ACT0160,ACT0626,ACT0158, ACT0135,ACT0154,ACT0155, ACT0142,ACT0145,ACT0141, ACT0058,ACT0138,ACT0143, ACT0140,ACT0146,ACT0150, ACT0149,ACT0137,ACT0166,	×	×	×
E-Class	212	Information and communication	SOUND-Sound system	√	√	√	√	×	ACT0043,ACT0133,ACT0134, ACT0135,ACT0136,ACT0137, ACT0138,ACT0139,ACT0140, ACT0058,ACT0141,ACT0142, ACT0143,ACT0144,ACT0145, ACT0146,ACT0147,ACT0148, ACT0149,ACT0150,ACT0151, ACT0152,ACT0153,ACT0154,	×	CD0621	×
E-Class	212	Information and communication	TB5-TV tuner Tuner unit	√	√	√	√	×	ACT0198,ACT0224,ACT0225, ACT0226,ACT0109,ACT0227, ACT0087,ACT0133	×	×	×

E-Class	212	Information and communication	TS-Telematic system(N123/4)	√	√	√	√	×	ACT0043,ACT0058,ACT0059,ACT0039	×	×	√
E-Class	212	Information and communication	TV tuner (TV)	√	√	√	√	×	ACT0043,ACT0228,ACT0199,ACT0087,ACT0229,ACT0224,	×	×	×
E-Class	212	Information and communication	TV-TV tuner	√	√	√	√	×	ACT0043,ACT0228,ACT0199,ACT0087,ACT0229,ACT0224,	×	×	×
E-Class	212	Information and communication	TV-TV tuner	√	√	√	√	×	ACT0174,ACT0175,ACT0176,ACT0177,ACT0178,ACT0087,ACT0179,ACT0133,ACT0109,ACT0180	×	CD0645CD0646,CD0647,C D0648,CD0649,CD0650,C D0651,CD0652,CD0653,C D0654,CD0655,CD0656	×
E-Class	212	Information and communication	TV-TV tuner	√	√	√	√	×	ACT0174,ACT0175,ACT0176,ACT0177,ACT0178,ACT0087,ACT0641,ACT0180	×	×	×
E-Class	212	Information and communication	TV-TV tuner	√	√	√	√	×	ACT0174,ACT0175,ACT0176,ACT0177,ACT0178,ACT0087,ACT0179,ACT0133,ACT0109,ACT0180	×	CD0645CD0646,CD0647,C D0648,CD0649,CD0650,C D0651,CD0652,CD0653,C D0654,CD0655,CD0656	×
E-Class	212	Information and communication	TV-TV tuner	√	√	√	√	×	ACT0198,ACT0224,ACT0225,ACT0226,ACT0109,ACT0227,ACT0087,ACT0133	×	×	×
E-Class	212	Information and communication	ZAN-Audio/COMAND display	√	√	√	√	×	ACT0290,ACT0096,ACT0090,ACT0091,ACT0095	×	×	√
E-Class	212	Information and communication	ZAN-Audio/COMAND display	√	√	√	√	×	ACT0291,ACT0039,ACT0043,ACT0206	×	×	√
E-Class	212	Seats and Doors	AMKS LF-Active multicontour seat(N32/19)	√	√	√	√	×	ACT1138,ACT1139,ACT0386,ACT0620,ACT0066,ACT0615	×	×	√
E-Class	212	Seats and Doors	AMKS RF-Active multicontour seat(N32/22)	√	√	√	√	×	ACT1138,ACT1139,ACT0386,ACT0620,ACT0066,ACT0615	×	×	√
E-Class	212	Seats and Doors	DCU LR-Left rear door	√	√	√	√	×	ACT0272,ACT0273,ACT0274,ACT0256,ACT0275,ACT0258,ACT0686,ACT0687,ACT0278,ACT0262,ACT0688,ACT0265,ACT1036,ACT0689,ACT0362,ACT0363,ACT0360,ACT0361,	SP1080	×	√
E-Class	212	Seats and Doors	DCU RF-Right front door	√	√	√	√	×	ACT0272,ACT0273,ACT0274,ACT0256,ACT0275,ACT0258,ACT0276,ACT0277,ACT0278,ACT0262,ACT0279,ACT0265,ACT0927,ACT0280,ACT0281,ACT0282,ACT0283,ACT0284,	SP1080	×	√
E-Class	212	Seats and Doors	DCU RR-Right rear door	√	√	√	√	×	ACT0272,ACT0273,ACT0274,ACT0256,ACT0275,ACT0258,ACT0690,ACT0691,ACT0278,ACT0262,ACT0692,ACT0265,ACT0927,ACT0693,ACT0369,ACT0370,ACT0367,ACT0368,	SP1080	×	√
E-Class	212	Seats and Doors	LFD-Left front door	√	√	√	√	×	ACT0253,ACT0254,ACT0255,ACT0256,ACT0257,ACT0258,ACT0259,ACT0260,ACT0261,ACT0262,ACT0263,ACT0265,ACT0927,ACT0264,ACT0267,ACT0268,ACT0269,ACT0270,	SP1080	×	√

E-Class	212	Seats and Doors	N25/6 (Rear passenger compartment seat heater control	√	√	√	√	×	ACT1132,ACT1133	×	×	√
E-Class	212	Seats and Doors	N32/1 (Driver seat control unit)	√	√	√	√	×	ACT0214,ACT0215,ACT0216,ACT0217,ACT0218,ACT0220	SP1074,SP1075,SP1377,SP1076	×	√
E-Class	212	Seats and Doors	N32/1 (Driver seat control unit)	√	√	√	√	×	ACT0214,ACT0215,ACT0216,ACT0217,ACT0218,ACT0220	SP1074,SP1075,SP1377,SP1076	×	√
E-Class	212	Seats and Doors	N32/2 (Front passenger seat control unit)	√	√	√	√	×	ACT0230,ACT0231,ACT0232,ACT0233,ACT0234	SP1074,SP1075	×	√
E-Class	212	Seats and Doors	N32/2 (Front passenger seat control unit)	√	√	√	√	×	ACT0230,ACT0231,ACT0232,ACT0233,ACT0234	SP1074,SP1075	×	√
E-Class	212	Seats and Doors	PPAMKS-Pneumatic pump for active multicontour seat	√	√	√	√	×	ACT0613,ACT0614,ACT0615	×	×	√
E-Class	212	Seats and Doors	PPAMKS-Pneumatic pump for multicontour seat	√	√	√	√	×	ACT0616,ACT0617,ACT0618,ACT0619,ACT0615	×	×	√
E-Class	213	Air conditioning	AAC-Automatic air conditioning	√	√	√	×	×	×	×	×	×
E-Class	213	Air conditioning	AAC-Automatic air conditioning	√	√	√	×	×	×	×	×	×
E-Class	213	Air conditioning	AAC-Automatic air conditioning	√	√	√	×	×	×	×	×	×
E-Class	213	Air conditioning	AAC-Automatic air conditioning	√	√	√	×	×	ACT0182,ACT0417,ACT0183,ACT0771,ACT0772,ACT0204,ACT0773,ACT0003,ACT0186,ACT0190,ACT0665,ACT0774,ACT0189,ACT0775,ACT0776,ACT0188,ACT0777,ACT0778,ACT0779,ACT0663,ACT0780,ACT0662,ACT0781,ACT0782,ACT0783,ACT0784,ACT0785,ACT0786,ACT0787,ACT0788,ACT0655,ACT0656,ACT0781,ACT0782,ACT0783,ACT0784,ACT0785,ACT0786,ACT0788,ACT0789,ACT0790,ACT0781,ACT0782,ACT0783,ACT0784,ACT0785,ACT0786,ACT0788,ACT0652,ACT0655,ACT0656,ACT0781,ACT0782,ACT0786,ACT0787,ACT0789,ACT0790,ACT0194,ACT0647,ACT0648,ACT0649,ACT0650,ACT0653,ACT0654,ACT0791,ACT0792,ACT0793,ACT0794,	SP1066,SP1065,SP1067,SP1360,SP1159	×	×
E-Class	213	Air conditioning	N61 (Windshield heater control	√	√	√	×	×	×	×	×	×
E-Class	213	Air conditioning	SCR-Selective catalytic reduction	√	√	√	×	×	×	×	×	×
E-Class	213	Air conditioning	STH-Stationary heater	√	√	√	√	×	ACT0201,ACT1030,ACT0202,ACT1118	×	×	×
E-Class	213	Air conditioning	TSTH-Radio remote control of stationary heater	√	√	√	√	×	ACT0203,ACT0418	×	×	×
E-Class	213	Body	"Driver" seat heater	√	√	√	√	×	ACT0411,ACT0412,ACT0413,ACT0414,ACT0415	SP1157,SP1158	×	×
E-Class	213	Body	"Front passenger" seat heater	√	√	√	√	×	×	×	×	×
E-Class	213	Body	AML-Ambiance light	√	√	√	√	×	ACT0389,ACT0390,ACT0391,ACT0392,ACT0393,ACT0394,ACT0395,ACT0396,ACT0043	SP1149	×	×

E-Class	213	Body	AMLA-Active engine mount	√	√	√	√	×	×	×	×	×
E-Class	213	Body	Anti glare interior rearview mirror(DBE)	√	√	√	√	×	×	×	×	×
E-Class	213	Body	AS-Alarm siren(H3/1)	√	√	√	√	×	ACT0309,ACT0465,ACT0466	×	×	×
E-Class	213	Body	AU-Analog clock	√	√	√	×	×	×	×	×	×
E-Class	213	Body	BMS-Battery management system	√	√	√	√	×	ACT0453,ACT0454,ACT0455	SP1197	×	×
E-Class	213	Body	BMS-Battery management system	√	√	√	√	×	ACT1121,ACT0453,ACT0410,ACT0604	SP1197	×	×
E-Class	213	Body	BSN-Battery sensor(B95)	√	√	√	√	×	×	×	×	×
E-Class	213	Body	Button group, instrument panel, driver side	√	√	√	√	×	×	×	×	×
E-Class	213	Body	DC/DC-DC/DC converter	√	√	√	√	×	×	×	×	×
E-Class	213	Body	DCCU-Direct current charge connection unit	√	√	√	√	×	×	×	×	×
E-Class	213	Body	EZS-Electronic ignition lock	√	√	√	√	×	ACT1054	×	×	×
E-Class	213	Body	FSW-Windshield wiper	√	√	√	√	×	×	×	×	×
E-Class	213	Body	GES-Hand motion sensor	√	√	√	√	×	×	×	×	×
E-Class	213	Body	GTO-Garage door	√	√	√	√	×	×	×	×	×
E-Class	213	Body	KG-Keyless Go	√	√	√	√	×	ACT0131,ACT0132	×	×	×
E-Class	213	Body	LIB-Lithium ion battery	√	√	√	√	×	×	×	×	×
E-Class	213	Body	LIB-Lithium ion battery	√	√	√	√	×	×	×	×	×
E-Class	213	Body	LIB-Lithium ion battery	√	√	√	√	×	×	×	×	×
E-Class	213	Body	LRE-Steering wheel electronics	√	√	√	√	×	×	×	×	×
E-Class	213	Body	LRE-Steering wheel electronics	√	√	√	√	×	×	×	×	×
E-Class	213	Body	LRE-Steering wheel electronics	√	√	√	×	×	×	×	×	×
E-Class	213	Body	Multifunction control unit-Multifunction control unit	√	√	√	√	×	×	×	×	×
E-Class	213	Body	Multifunction control unit-Multifunction control unit	√	√	√	√	×	ACT0204	×	×	×
E-Class	213	Body	N25/6 (Rear passenger compartment seat heater control	√	√	√	√	×	×	×	×	×
E-Class	213	Body	N38 (Rear switching module)	√	√	√	√	×	×	×	×	×
E-Class	213	Body	N5 (Armrest heater control unit)	√	√	√	√	×	ACT0817,ACT0818,ACT0819,ACT0820,ACT0821,ACT0822,ACT0823,ACT0824,ACT0825,ACT0826,ACT0827,ACT0828,ACT0829,ACT0830,ACT0831,ACT0832,ACT0833,ACT0834,ACT0829,ACT0830,ACT0831,ACT0835,ACT0836,ACT0837,ACT0838,ACT0829,ACT0835,ACT0836,ACT0837,ACT0838,ACT0839,ACT0840,ACT0841,ACT0842,ACT0843,ACT0844,ACT0845,ACT0846,ACT0847,ACT0848,ACT0829,ACT0832,ACT0839,ACT0840,ACT0841,ACT0842,ACT0843,ACT0844,	SP1364,SP1365	×	×
E-Class	213	Body	OCP-Overhead control panel	√	√	√	√	×	ACT1093,ACT1094,ACT0303,ACT0302,ACT1095,ACT1096,ACT1097,ACT1098,ACT1099,ACT0465,ACT1100	SP1441	×	×

E-Class	213	Body	PSD-Panoramic sliding roof	√	√	√	√	×	×	×	×	×	
E-Class	213	Body	RevETR LF-Left front reversible emergency tensioning retractor	√	√	√	√	×	×	×	×	×	
E-Class	213	Body	RevETR RF-Right front reversible emergency tensioning	√	√	√	√	×	×	×	×	×	
E-Class	213	Body	RGLS-Rain/light sensor(B38/2)	√	√	√	√	×	×	×	×	×	
E-Class	213	Body	SAMF-Front signal acquisition and actuation module(N10/6)	√	√	√	√	×	ACT0729,ACT0730,ACT0731, ACT0732,ACT0344,ACT0507, ACT0733,ACT0675,ACT0734, ACT0676,ACT0735,ACT0736, ACT0737,ACT0738,ACT0465, ACT0739,ACT0740,ACT0741, ACT0742,ACT0743,ACT0744,		×	×	×
E-Class	213	Body	SAMR-Rear signal acquisition and actuation module(N10/8)	√	√	√	√	×	ACT0747,ACT0240,ACT0748, ACT0749,ACT0750,ACT0731, ACT0751,ACT0752,ACT0753, ACT0754,ACT0755,ACT0756, ACT0757,ACT0758,ACT0759, ACT0760,ACT0761,ACT0762, ACT0763,ACT0764,ACT0765, ACT0766,ACT0767,ACT0768,		×	×	×
E-Class	213	Body	SCM-Steering column module(N80)	√	√	√	√	×	ACT0060,ACT0061,ACT0062, ACT0063,ACT0064,ACT0065		×	×	×
E-Class	213	Body	SG LG-Charger	√	√	√	√	×	ACT0405,ACT0406,ACT0407, ACT0408,ACT0409,ACT0410		×	×	×
E-Class	213	Body	SG LG-Charger	√	√	√	√	×	ACT0405,ACT0406,ACT0407, ACT0408,ACT0611,ACT0410		×	×	×
E-Class	213	Body	SG LML VL-LED matrix of left front lamp unit	√	√	√	√	×	ACT0299,ACT0815,ACT0816, ACT0300		SP1089,SP1361	×	×
E-Class	213	Body	SG SW L-Left headlamp	√	√	√	√	×	×	×	×	×	×
E-Class	213	Body	SG SW L-Left headlamp	√	√	√	√	×	×	×	×	×	×
E-Class	213	Body	SG SW L-Left headlamp	√	√	√	√	×	ACT0292,ACT0293,ACT0297, ACT0298,ACT0299,ACT0300		SP1445,SP1088,SP1089, SP1090,SP1094	×	×
E-Class	213	Body	SG SW R-Right headlamp	√	√	√	√	×	×	×	×	×	×
E-Class	213	Body	SG SW R-Right headlamp	√	√	√	√	×	×	×	×	×	×
E-Class	213	Body	SG SW R-Right headlamp	√	√	√	√	×	ACT0292,ACT0293,ACT0297, ACT0298,ACT0299,ACT0300		SP1362,SP1096,SP1097	×	×
E-Class	213	Body	SG-LML-VR-LED matrix of right front lamp unit	√	√	√	√	×	ACT0299,ACT0815,ACT0300, ACT0816		SP1362,SP1363	×	×
E-Class	213	Body	SOGESTAR2-Sound generator for electric vehicle	√	√	√	√	×	×	×	×	×	×
E-Class	213	Body	SOGESTAR2-Sound generator for electric vehicle	√	√	√	×	×	×	×	×	×	×
E-Class	213	Body	SRS-Supplemental restraint	√	√	√	√	√	×	×	×	×	×
E-Class	213	Body	STM-Mirror taximeter	√	√	√	√	×	×	×	×	×	×
E-Class	213	Body	Trailer recognition module- Trailer recognition	√	√	√	√	×	×	×	×	×	×
E-Class	213	Body	WSS-Weight sensing	√	√	√	√	×	×	×	×	×	×
E-Class	213	Chassis	ADS-Adaptive damping system	√	√	√	√	×	×	SP1061,SP1339		×	×

E-Class	213	Chassis	ADS-Adaptive damping system(N51/5)	√	√	√	√	×	ACT0628,ACT1119,ACT0631,ACT0630,ACT0632,ACT0633,ACT0634,ACT0635,ACT0167,ACT0168,ACT0169,ACT0170,ACT0636,ACT0637,ACT0639,	SP1061,SP1339	×	×
E-Class	213	Chassis	AIRmatic-AIRmatic PLUS	√	√	√	√	×	×	×	×	×
E-Class	213	Chassis	AMG DRVU-AMG DRIVE UNIT	√	√	√	√	×	ACT0401,ACT0402,ACT0403,ACT0404	SP1153,SP1154,SP1155	×	×
E-Class	213	Chassis	AMG DRVU-AMG DRIVE	√	√	√	×	×	ACT1109	×	×	×
E-Class	213	Chassis	ELC-Electronic level control	√	√	√	√	×	ACT0631,ACT0630,ACT1160,ACT1161,ACT1162,ACT1163,ACT0638,ACT0639	SP1061	×	×
E-Class	213	Chassis	ES - Electric power steering	√	√	√	√	×	×	SP1071	×	×
E-Class	213	Chassis	ES - Electric power steering	√	√	√	√	×	×	SP1071,SP1167	×	×
E-Class	213	Chassis	ESP-Electric stability program(N30/4)	√	√	√	√	×	ACT0069,ACT0070,ACT0285,ACT0286,ACT0287	SP1174,SP1176,SP1178,SP1367	×	×
E-Class	213	Chassis	ESP-Electric stability program(N30/4)	√	√	√	√	√	ACT0069,ACT0070,ACT0612,ACT0285,ACT0286,ACT0287,ACT0288	SP1174,SP1175,SP1176,SP1177,SP1178,SP1179,SP1180,SP1181,SP1367,	×	×
E-Class	213	Chassis	ESP-Electric stability program(N30/4)	√	√	√	√	√	ACT0069,ACT0070,ACT0863,ACT0285,ACT0286,ACT0287,ACT0288	SP1174,SP1175,SP1176,SP1177,SP1178,SP1179,SP1366,SP1181,SP1367,	×	×
E-Class	213	Drive	CDI-Motor electronics CR61 for combustion engine OM642	√	√	√	×	×	ACT0001,ACT0005,ACT0006,ACT0321,ACT0431,ACT0008,ACT1150,ACT0012,ACT0016,ACT1151,ACT0018,ACT0022,ACT0023,ACT0026,ACT0000,ACT0338,ACT0339,ACT0340,ACT1152,ACT0341	SP1210,SP1000,SP1130,SP1125,SP1131,SP1469,SP1132,SP1470,SP1134,SP1133,SP1135,SP1136,SP1017,SP1137,SP1138,SP1024,SP1139,SP1471,SP1141,SP1142,SP1143,SP1472,SP1021,SP1145,	×	×
E-Class	213	Drive	EAGGS-Electric differential lock	√	√	√	√	×	ACT0814	SP1155	×	×
E-Class	213	Drive	FSCU-Control unit Fuel pump	√	√	√	√	×	ACT0252,ACT0320	×	×	×
E-Class	213	Drive	HFFM-Haptic accelerator pedal module	√	√	√	√	×	ACT1110,ACT1111	×	×	×
E-Class	213	Drive	ISG-Integrated starter alternator	√	√	√	√	×	×	×	×	×
E-Class	213	Drive	ISG-Integrated starter alternator	√	√	√	×	×	×	×	×	×
E-Class	213	Drive	ISG-Integrated starter alternator	√	√	√	√	×	×	SP1368	×	×
E-Class	213	Drive	N127 (Drivetrain control unit)	√	√	√	×	×	×	×	×	×
E-Class	213	Drive	N127 (Drivetrain control unit)	√	√	√	√	×	ACT0028,ACT0430,ACT0431,ACT0432,ACT0433,ACT0007,ACT0434,ACT0435,ACT0436,ACT0437,ACT0438,ACT0439,ACT0440,ACT0441,ACT0442,ACT0443,ACT0444,ACT0445,ACT0446,ACT0447,ACT0448,	SP1186,SP1042,SP1025,SP1187,SP1188,SP1189,SP1190,SP1191,SP1192	×	×
E-Class	213	Drive	N15/15n4 (Fully integrated transmission control unit)	√	√	√	√	×	×	×	×	×

E-Class	213	Drive	N3/10-Motor electronics "MED1775" for combustion engine "M178"	√	√	√	√	√	ACT0002,ACT0028,ACT0431, ACT0432,ACT0433,ACT0864, ACT0865,ACT0435,ACT0480, ACT0476,ACT0475,ACT0478, ACT0477,ACT0326,ACT0866, ACT0867,ACT0436,ACT0025, ACT0868,ACT0712,ACT0713,	SP1017,SP1109,SP1110, SP1369,SP1370,SP1371, SP1112,SP1202,SP1203, SP1001,SP1187,SP1372, SP1201,SP1000	×	×
E-Class	213	Drive	N3/10-Motor electronics "MED177V6LA" for combustion engine "M276Turbocharger"	√	√	√	√	√	ACT0005,ACT0002,ACT0003, ACT0335,ACT0480,ACT0463, ACT0705,ACT0464,ACT0706, ACT0325,ACT0326,ACT0025, ACT0016,ACT0017,ACT0441, ACT0709,ACT0022,ACT0712, SP1000	SP1109,SP1110,SP1108, SP1017,SP1369,SP1371, SP1370,SP1112,SP1203, SP1202,SP1113,SP1352, SP1004,SP1001,SP1201, SP1000	×	×
E-Class	213	Drive	N3/10-Motor electronics "MED40" for combustion engine "M274"	√	√	√	√	√	ACT0002,ACT0005,ACT0460, ACT0322,ACT0323,ACT0324, ACT0325,ACT0326,ACT0025, ACT0327,ACT0328,ACT0329, ACT0022,ACT0024,ACT0330, ACT0331,ACT0332,ACT0333,	SP1017,SP1004,SP1000	×	×
E-Class	213	Drive	N3/10-Motor electronics "MED41" for combustion engine "M260/M264"	√	√	√	√	√	ACT0330,ACT0003,ACT0459, ACT0323,ACT0324,ACT0333, ACT0025,ACT0328,ACT0331, ACT0332,ACT0004,ACT0005, ACT0456,ACT0002,ACT0460, ACT0329,ACT0022,ACT0325,	SP1199,SP1117	×	×
E-Class	213	Drive	N3/10-Motor electronics "MRG1" for combustion engine "M256"	√	√	√	√	√	ACT0002,ACT0025,ACT0005, ACT0022,ACT0456,ACT0329, ACT0325,ACT0328,ACT0323, ACT0324,ACT0460,ACT0871,	SP1001,SP1004,SP1201, SP1202,SP1203,SP1110, SP1109,SP1139,SP1017, SP1371,SP1112,SP1000	×	×
E-Class	213	Drive	N3/10-Motor electronics "MRG2" for combustion engine "M254"	√	√	√	×	×	ACT0011,ACT1164,ACT1165, ACT0025,ACT1166,ACT0871, ACT0341,ACT0002,ACT0005, ACT1167,ACT1168,ACT0339,	SP1110,SP1109,SP1353, SP1139,SP1112,SP1017, SP1001,SP1116,SP1004, SP1200	×	×
E-Class	213	Drive	N3/40-Motor electronics "MRD1" for combustion engine "OM654"	√	√	√	√	√	ACT0001,ACT0005,ACT0006, ACT0321,ACT0008,ACT0009, ACT0010,ACT0322,ACT0011, ACT0012,ACT0016,ACT0018, ACT0022,ACT0023,ACT0024, ACT0026,ACT0000,ACT0338, ACT0339,ACT0340,ACT0341	SP1001,SP1000,SP1130, SP1125,SP1131,SP1132, SP1133,SP1134,SP1135, SP1136,SP1017,SP1137, SP1138,SP1024,SP1139, SP1140,SP1015,SP1141, SP1142,SP1143,SP1144, SP1021,SP1022,SP1145,	×	×
E-Class	213	Drive	N3/9-Motor electronics "CDI61" for combustion engine "OM642"	√	√	√	√	√	ACT0033,ACT0026,ACT0005, ACT0002,ACT0028,ACT0008, ACT0010,ACT0011,ACT0024, ACT0012,ACT0016,ACT0018	SP1468,SP1000,SP1001, SP1002,SP1004,SP1295, SP1135,SP1009,SP1294, SP1012,SP1013,SP1298, SP1144,SP1296,SP1297, SP1137,SP1015,SP1016, SP1020,SP1128,SP1021, SP1022,SP1023,SP1017,	×	×
E-Class	213	Drive	SCR-Selective catalytic reduction	√	√	√	√	×	ACT0424,ACT0425,ACT0426, ACT0427,ACT0428,ACT0429	SP1184,SP1185	×	×
E-Class	213	Drive	SCR-Selective catalytic reduction	√	√	√	√	×	ACT0424,ACT0602,ACT0425, ACT0426,ACT0427,ACT0598	SP1185,SP1322,SP1184, SP1319,SP1318,SP1023	×	×

E-Class	213	Drive	SG EM-Power electronics	√	√	√	√	×	ACT0451,ACT0452	SP1193,SP1194,SP1195, SP1196,SP1150	×	×
E-Class	213	Drive	VG-All-wheel drive	√	√	√	√	×	ACT0422,ACT0423	SP1099,SP1170	×	×
E-Class	213	Drive	Y3/8n4-Fully integrated transmission control	√	√	√	√	√	ACT0592,ACT0318	SP1299,SP1300,SP1301, SP1302,SP1303,SP1304, SP1233,SP1305,SP1306, SP1306,SP1307,SP1308, SP1309,SP1002,SP1310,	×	×
E-Class	213	Drive	Y3/8n4-Transmission control for 9 speed transmission	√	√	√	√	√	ACT0592,ACT0312,ACT0593, ACT0714,ACT0317	SP1311,SP1315,SP1316, SP1305,SP1355,SP1312, SP1356,SP1300,SP1357, SP1358,SP1359,SP1317	×	×
E-Class	213	Driver assistance	DTR-DISTRONIC	√	√	√	√	×	×	×	×	×
E-Class	213	Driver assistance	DTR-DISTRONIC	√	√	√	×	×	×	×	×	×
E-Class	213	Driver assistance	DTR-DISTRONIC	√	√	√	√	×	×	SP1161,SP1162	×	×
E-Class	213	Driver assistance system	IRS HLA-Outer left rear integrated radar sensor (B92/11)	√	√	√	√	×	×	SP1473	×	×
E-Class	213	Driver assistance system	IRS HLA-Outer left rear intelligent radar sensor system	√	√	√	×	×	×	×	×	×
E-Class	213	Driver assistance system	IRS HRA-Outer right rear integrated radar sensor (B92/6)	√	√	√	√	×	×	SP1474	×	×
E-Class	213	Driver assistance system	IRS HRA-Outer right rear intelligent radar sensor system	√	√	√	×	×	×	×	×	×
E-Class	213	Driver assistance	KAR-Augmented reality camera	√	√	√	√	×	×	×	×	×
E-Class	213	Driver assistance system	MFK-Multifunction camera(mono)(A40/11)	√	√	√	√	×	ACT0181,ACT0065	SP1156	×	×
E-Class	213	Driver assistance system	MFK-Multifunction camera(stereo)(A40/13)	√	√	√	√	×	ACT0181,ACT0065	SP1063	×	×
E-Class	213	Driver assistance	NBR LF-Left front short range	√	√	√	√	×	×	×	×	×
E-Class	213	Driver assistance	NBR LR-Left rear short-range	√	√	√	√	×	×	SP1173	×	×
E-Class	213	Driver assistance system	NBR RF-Right front short range radar	√	√	√	√	×	×	×	×	×
E-Class	213	Driver assistance	NBR RR-Right rear short-range	√	√	√	√	×	×	SP1172	×	×
E-Class	213	Driver assistance	PTS-PARKTRONIC	√	√	√	√	×	ACT0421,ACT0306	SP1166	×	×
E-Class	213	Driver assistance	RFK-Backup camera	√	√	√	√	×	×	SP1152	×	×
E-Class	213	Driver assistance	RFK-Backup camera	√	√	√	√	×	ACT1159	SP1475	×	×
E-Class	213	Driver assistance system	SG AWF-Control unit COLLISION PREVENTION	√	√	√	√	×	ACT0583	SP1476,SP1477	×	×
E-Class	213	Driver assistance	SGR-Radar sensors control unit	√	√	√	√	×	ACT0419,ACT0420	SP1163,SP1164,SP1165	×	×
E-Class	213	Driver assistance system	TPM-Tire pressure monitor(N88)	√	√	√	√	×	ACT0078,ACT0079,ACT0081, ACT0080	SP1053	×	×
E-Class	213	Information and communication	Audio-Audio or COMAND	√	√	√	×	×	×	×	×	×
E-Class	213	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√	×	×	×	×	×
E-Class	213	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√	×	×	×	×	×
E-Class	213	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√	×	×	×	×	×
E-Class	213	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√	×	×	×	×	×

E-Class	213	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√	×	×	×	×	×
E-Class	213	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√	×	×	×	×	×
E-Class	213	Information and communication	AVE H-Controller unit Rear entertainment system	√	√	√	√	×	ACT0809,ACT0810,ACT0811,ACT0812,ACT0813	×	×	×
E-Class	213	Information and communication	COU[ZBE]-Audio/COMAND operating unit	√	√	√	√	×	ACT0289,ACT0041	SP1199	×	×
E-Class	213	Information and communication	CTEL-Cellular telephone	√	√	√	√	×	×	×	×	×
E-Class	213	Information and communication	DAB-Digital radio Tuner unit	√	√	√	√	×	ACT0198,ACT0087,ACT0199,ACT0039	×	×	×
E-Class	213	Information and communication	HERMES-control unit for telematics services	√	√	√	√	×	×	SP1046	×	×
E-Class	213	Information and communication	HUD-Head up display	√	√	√	×	×	×	×	×	×
E-Class	213	Information and communication	HUD-Head up display	√	√	√	√	×	ACT0210,ACT0212	×	×	×
E-Class	213	Information and communication	IC-Instrument cluster	√	√	√	√	×	ACT0039,ACT0397,ACT0048,ACT0210,ACT0398,ACT0399,ACT0050,ACT0400	SP1043,SP1044,SP1045	×	×
E-Class	213	Information and communication	IC-Instrument cluster(A1)	√	√	√	√	×	ACT0397,ACT0048,ACT0210,ACT0398,ACT0399,ACT0050,ACT0400,ACT0039	SP1043,SP1044,SP1045	×	×
E-Class	213	Information and communication	MTAS FO-Mobile phone cradle in rear passenger compartment	√	√	√	√	×	×	×	×	×
E-Class	213	Information and communication	MTAS FO-Mobile phone cradle in rear passenger compartment	√	√	√	×	×	×	×	×	×
E-Class	213	Information and communication	MTAS-Mobile phone cradle	√	√	√	√	×	×	×	×	×
E-Class	213	Information and communication	MTAS-Mobile phone cradle	√	√	√	√	×	×	×	×	×
E-Class	213	Information and communication	MTAS-Mobile phone cradle	√	√	√	√	×	×	×	×	×
E-Class	213	Information and communication	MTAS-Mobile phone cradle	√	√	√	×	×	×	×	×	×
E-Class	213	Information and communication	N72/1 (Upper control panel control unit)	√	√	√	×	×	×	×	×	×
E-Class	213	Information and communication	N72/4 (Left lower control panel)	√	√	√	×	×	×	×	×	×
E-Class	213	Information and communication	N72/4 (Left lower control panel)	√	√	√	×	×	×	×	×	×
E-Class	213	Information and communication	SG MSND-Engine sound	√	√	√	√	×	×	×	×	×
E-Class	213	Information and communication	SOUND-Sound system	√	√	√	√	×	×	×	×	×
E-Class	213	Information and communication	SOUND-Sound system	√	√	√	√	×	×	×	×	×
E-Class	213	Information and communication	TPAD-Touchpad	√	√	√	√	×	×	×	×	×
E-Class	213	Information and communication	TPAD-Touchpad	√	√	√	√	×	×	×	×	×

E-Class	213	Information and communication	TSC H-Touchscreen in rear passenger compartment	√	√	√	√	×	×	×	×	×
E-Class	213	Information and communication	TV tuner (TV)	√	√	√	√	×	×	×	×	×
E-Class	213	Information and communication	TV tuner (TV)	√	√	√	√	×	×	×	×	×
E-Class	213	Information and communication	TV tuner (TV)	√	√	√	√	×	×	×	×	×
E-Class	213	Information and communication	TV tuner (TV)	√	√	√	√	×	×	×	×	×
E-Class	213	Information and communication	ZAN-Audio/COMAND display	√	√	√	√	×	ACT0206,ACT0946,ACT0291,ACT0039	×	×	×
E-Class	213	Information and communication	ZAN-Audio/COMAND display	√	√	√	√	×	ACT0291,ACT0206,ACT0039	×	×	×
E-Class	213	Seats and Doors	"Driver" seat heater	√	√	√	√	×	×	×	×	×
E-Class	213	Seats and Doors	"Front passenger" seat heater	√	√	√	√	×	×	×	×	×
E-Class	213	Seats and Doors	DCU LR-Left rear door	√	√	√	×	×	×	×	×	×
E-Class	213	Seats and Doors	DCU LR-Left rear door	√	√	√	×	×	×	×	×	×
E-Class	213	Seats and Doors	DCU LR-Left rear door	√	√	√	√	×	ACT0360,ACT0361,ACT0362,ACT0363,ACT0723,ACT0688,ACT0347,ACT0364,ACT0724,ACT0366,ACT0725	SP1080,SP1147,SP1148	×	×
E-Class	213	Seats and Doors	DCU LR-Left rear door	√	√	√	√	×	ACT0360,ACT0361,ACT0362,ACT0363,ACT0723,ACT0688,ACT0347,ACT0364,ACT0724,ACT0727,ACT0366	SP1080,SP1147,SP1148	×	×
E-Class	213	Seats and Doors	DCU RF-Right front door	√	√	√	√	×	ACT0353,ACT0274,ACT0273,ACT0354,ACT0720,ACT0283,ACT0284,ACT0281,ACT0282,ACT0721,ACT0355,ACT0278,ACT0356,ACT0357,ACT0347,ACT0279,ACT0348,ACT0349,ACT0358,ACT0359,ACT0722,	SP1080,SP1147,SP1148	×	×
E-Class	213	Seats and Doors	DCU RF-Right front door	√	√	√	√	×	ACT1157,ACT0274,ACT0273,ACT1158,ACT0720,ACT0283,ACT0284,ACT0281,ACT0282,ACT0721,ACT0366,ACT0278,ACT1155,ACT0357,ACT0347,ACT0279,ACT0348,ACT0349,ACT0358,ACT0359,ACT1156,	SP1080,SP1147,SP1148	×	×
E-Class	213	Seats and Doors	DCU RR-Right rear door	√	√	√	×	×	×	×	×	×
E-Class	213	Seats and Doors	DCU RR-Right rear door	√	√	√	×	×	×	×	×	×
E-Class	213	Seats and Doors	DCU RR-Right rear door	√	√	√	√	×	ACT0367,ACT0368,ACT0369,ACT0370,ACT0726,ACT0692,ACT0347,ACT0371,ACT0365,ACT0727,ACT0366	SP1080,SP1147,SP1148	×	×
E-Class	213	Seats and Doors	DCU RR-Right rear door	√	√	√	√	×	ACT0367,ACT0368,ACT0369,ACT0370,ACT0726,ACT0692,ACT0347,ACT0371,ACT0365,ACT0727,ACT0728,ACT0366	SP1080,SP1147,SP1148	×	×
E-Class	213	Seats and Doors	ESA Front passenger-Electric seat adjustment Front passenger	√	√	√	√	×	×	×	×	×

E-Class	213	Seats and Doors	ESA Front passenger-Electric seat adjustment Front passenger	√	√	√	√	×	ACT0230,ACT0378,ACT0234,ACT0379,ACT0233,ACT0380,ACT0381,ACT0382	SP1075	×	×
E-Class	213	Seats and Doors	ESE RL-Left rear electrical seat adjustment	√	√	√	√	×	×	×	×	×
E-Class	213	Seats and Doors	ESV Driver-Electric seat adjustmnet Driver	√	√	√	√	×	×	×	×	×
E-Class	213	Seats and Doors	ESV Driver-Electric seat adjustmnet Driver	√	√	√	√	×	ACT0214,ACT0373,ACT0218,ACT0374,ACT0217,ACT0375,ACT0376,ACT0377	SP1075	×	×
E-Class	213	Seats and Doors	ESV Driver-Electric seat adjustmnet Driver with memory function	√	√	√	√	×	ACT0214,ACT0373,ACT0218,ACT0374,ACT0217,ACT1064,ACT0375,ACT0376,ACT0377	SP1438,SP1075,SP1074	×	×
E-Class	213	Seats and Doors	ESV Front passenger-Electric seat adjustment Front passenger with memory function	√	√	√	√	×	ACT0230,ACT0378,ACT0234,ACT0379,ACT0233,ACT1065,ACT0380,ACT0381,ACT0382	SP1438,SP1075,SP1074	×	×
E-Class	213	Seats and Doors	HKS-Tailgate control	√	√	√	√	×	ACT1089,ACT1090	SP1439	×	×
E-Class	213	Seats and Doors	LFD-Left front door	√	√	√	√	×	ACT0342,ACT0255,ACT0254,ACT0343,ACT0715,ACT0269,ACT0361,ACT0267,ACT0268,ACT0716,ACT0344,ACT0261,ACT0345,ACT0346,ACT0347,ACT0263,ACT0348,ACT0349,ACT0350,ACT0351,ACT0717,	SP1080,SP1147,SP1148	×	×
E-Class	213	Seats and Doors	LFD-Left front door	√	√	√	√	×	ACT1153,ACT0255,ACT0254,ACT1154,ACT0715,ACT0269,ACT0270,ACT0267,ACT0268,ACT0716,ACT0366,ACT0261,ACT1155,ACT0346,ACT0347,ACT0263,ACT0348,ACT0349,ACT0350,ACT0351,ACT1156,	SP1080,SP1147,SP1148	×	×
E-Class	213	Seats and Doors	Massage function in left front seat	√	√	√	√	×	×	×	×	×
E-Class	213	Seats and Doors	Massage function in left rear seat	√	√	√	√	×	×	×	×	×
E-Class	213	Seats and Doors	Massage function in right front	√	√	√	√	×	×	×	×	×
E-Class	213	Seats and Doors	Massage function in right rear	√	√	√	√	×	×	×	×	×
E-Class	213	Seats and Doors	MFSF-LF	√	√	√	√	×	×	×	×	×
E-Class	213	Seats and Doors	MFSF-RF	√	√	√	√	×	×	×	×	×
E-Class	213	Seats and Doors	MKS LF-Left front multicontour seat	√	√	√	√	×	ACT0383,ACT0384,ACT0387,ACT0388,ACT0386,ACT0802	×	×	×
E-Class	213	Seats and Doors	MKS LF-Left rear multicontour seat	√	√	√	√	×	ACT0383,ACT0803,ACT0384,ACT0386,ACT0613	×	×	×
E-Class	213	Seats and Doors	MKS RF-Right front multicontour seat	√	√	√	√	×	ACT0383,ACT0384,ACT0387,ACT0388,ACT0386,ACT0802	×	×	×
E-Class	213	Seats and Doors	MKS RF-Right rear multicontour seat	√	√	√	√	×	ACT0383,ACT0803,ACT0384,ACT0386,ACT0613	×	×	×
E-Class	213	Seats and Doors	PPAMKS-Pneumatic pump for multicontour seat	√	√	√	√	×	ACT0616,ACT0804	×	×	×
E-Class	213	Seats and Doors	Right rear ESE-Right rear electrical seat adjustment	√	√	√	√	×	×	×	×	×
E-Class	213	Seats and Doors	S22 (Driver's door seat adjustment switch)	√	√	√	×	×	×	×	×	×

E-Class	213	Seats and Doors	S23 (Front passenger door seat adjustment switch)	√	√	√	×	×	×	×	×	×
E-Class	213	Seats and Doors	S47/2 (Driver door switch	√	√	√	×	×	×	×	×	×
E-Class	213	Seats and Doors	S47/3 (Front passenger door switch module)	√	√	√	×	×	×	×	×	×
E-Class	213	Seats and Doors	S51/1 (Driver"s door seat heating switch)	√	√	√	×	×	×	×	×	×
E-Class	213	Seats and Doors	S51/2 (Front passenger door seat heating switch)	√	√	√	×	×	×	×	×	×
E-Class	213	Seats and Doors	S51/3 (Left rear seat heater	√	√	√	×	×	×	×	×	×
E-Class	213	Seats and Doors	S51/4 (Right rear seat heater	√	√	√	×	×	×	×	×	×
E-Class	213	Seats and Doors	Seat heater in left rear passenger compartment	√	√	√	√	×	×	×	×	×
E-Class	213	Seats and Doors	Seat heater in right rear passenger compartment	√	√	√	√	×	×	×	×	×
ED-Class	243	Air conditioning	AAC-Automatic air conditioning	√	√	√	√	×	×	×	×	×
ED-Class	243	Air conditioning	AAC-Automatic air conditioning	√	√	√	√	×	ACT0416,ACT0182,ACT0417,ACT0186,ACT0194,ACT0195,ACT0197,ACT0196,ACT0028,	SP1065,SP1066,SP1067,SP1159,SP1160	×	×
ED-Class	243	Body	"Driver" seat heater	√	√	√	√	×	ACT0411,ACT0412,ACT0413,ACT0414,ACT0415	SP1157,SP1158	×	×
ED-Class	243	Body	"Front passenger" seat heater	√	√	√	√	×	×	×	×	×
ED-Class	243	Body	AML-Ambiance light	√	√	√	√	×	ACT0389,ACT0390,ACT0391,ACT0392,ACT0393,ACT0394,ACT0395,ACT0396,ACT0043	SP1149	×	×
ED-Class	243	Body	Anti glare interior rearview mirror(DBE)	√	√	√	√	×	×	×	×	×
ED-Class	243	Body	AS-Alarm siren(H3/1)	√	√	√	√	×	ACT0309,ACT0465,ACT0466	×	×	×
ED-Class	243	Body	ATA-Interior motion sensor	√	√	√	√	×	×	×	×	×
ED-Class	243	Body	BMS-Battery management system	√	√	√	×	×	×	×	×	×
ED-Class	243	Body	BMS-Battery management system	√	√	√	×	×	×	×	×	×
ED-Class	243	Body	BSN-Battery sensor(B95)	√	√	√	√	×	×	×	×	×
ED-Class	243	Body	DC/DC-DC/DC converter	√	√	√	×	×	×	×	×	×
ED-Class	243	Body	DCCU-Direct current charge connection unit	√	√	√	√	×	×	×	×	×
ED-Class	243	Body	Driver side SAM-Front signal acquisition and actuation module	√	√	√	√	×	×	×	×	×
ED-Class	243	Body	EZS-Electronic ignition switch	√	√	√	√	×	ACT0372	×	×	×
ED-Class	243	Body	FSW-Windshield wiper	√	√	√	√	×	×	×	×	×
ED-Class	243	Body	GTO-Garage door	√	√	√	√	×	×	×	×	×
ED-Class	243	Body	HE-Hand detection	√	√	√	√	×	×	×	×	×
ED-Class	243	Body	LRE-Steering wheel electronics	√	√	√	√	×	×	×	×	×
ED-Class	243	Body	Multifunction control unit-Multifunction control unit	√	√	√	√	×	×	×	×	×
ED-Class	243	Body	N38 (Rear switching module)	√	√	√	√	×	×	×	×	×
ED-Class	243	Body	OCP-Overhead control panel	√	√	√	√	×	×	×	×	×
ED-Class	243	Body	PSD-Control module Panoramic sliding roof	√	√	√	√	×	×	×	×	×
ED-Class	243	Body	PSD-Panoramic sliding roof	√	√	√	√	×	×	×	×	×
ED-Class	243	Body	RevETR LF-Left front reversible emergency tensioning retractor	√	√	√	√	×	×	×	×	×

ED-Class	243	Body	RevETR LF-Left front reversible emergency tensioning retractor	√	√	√	√	×	ACT0209	×	×	×
ED-Class	243	Body	RevETR RF-Right front reversible emergency tensioning	√	√	√	√	×	×	×	×	×
ED-Class	243	Body	RevETR RF-Right front reversible emergency tensioning	√	√	√	√	×	ACT0213	×	×	×
ED-Class	243	Body	RGLS-Rain/light sensor(B38/2)	√	√	√	√	×	×	×	×	×
ED-Class	243	Body	SCM-Steering column module	√	√	√	√	×	×	×	×	×
ED-Class	243	Body	SG LG-Charger	√	√	√	×	×	×	×	×	×
ED-Class	243	Body	SG LG-Charger	√	√	√	×	×	×	×	×	×
ED-Class	243	Body	SG SW L-Left headlamp	√	√	√	√	×	×	×	×	×
ED-Class	243	Body	SG SW R-Right headlamp	√	√	√	√	×	×	×	×	×
ED-Class	243	Body	SOGESTAR2-Sound generator for electric vehicle	√	√	√	√	×	×	×	×	×
ED-Class	243	Body	SRS-Supplemental restraint	√	√	√	√	√	×	×	×	×
ED-Class	243	Body	STM-Mirror taximeter	√	√	√	√	×	×	×	×	×
ED-Class	243	Body	Trailer recognition module-Trailer recognition	√	√	√	√	×	×	×	×	×
ED-Class	243	Body	WSS-Weight sensing	√	√	√	√	×	×	×	×	×
ED-Class	243	Chassis	ADS-Adaptive damping system(N51/5)	√	√	√	√	×	×	SP1061	×	×
ED-Class	243	Chassis	ADS-Adaptive damping system(N51/5)	√	√	√	√	×	×	SP1061	×	×
ED-Class	243	Chassis	ES - Electric power steering	√	√	√	√	×	×	SP1071,SP1069,SP1167,SP1168,SP1169	×	×
ED-Class	243	Chassis	ESP- Electric stability program	√	√	√	√	√	ACT0069,ACT0070,ACT0285,ACT0288	SP1174,SP1175,SP1176,SP1177,SP1178,SP1179,SP1180,SP1181,SP1182,	×	×
ED-Class	243	Drive	N127 (Drivetrain control unit)	√	√	√	×	×	×	×	×	×
ED-Class	243	Drive	SG EM-Power electronics	√	√	√	×	×	×	×	×	×
ED-Class	243	Drive	SG EM-Power electronics	√	√	√	√	×	ACT0451,ACT0452,ACT1237	×	×	×
ED-Class	243	Driver assistance	DTR-DISTRONIC	√	√	√	√	×	×	SP1161,SP1162	×	×
ED-Class	243	Driver assistance system	IRS HLA-Outer left rear integrated radar sensor (B92/11)	√	√	√	√	×	×	SP1150,SP1151	×	×
ED-Class	243	Driver assistance system	IRS HRA-Outer right rear integrated radar sensor (B92/6)	√	√	√	√	×	×	SP1150,SP1151	×	×
ED-Class	243	Driver assistance	KAR-Augmented reality camera	√	√	√	√	×	×	×	×	×
ED-Class	243	Driver assistance system	MFK-Multifunction camera(mono)(A40/11)	√	√	√	√	×	ACT0181,ACT0065	SP1156	×	×
ED-Class	243	Driver assistance system	MFK-Multifunction camera(stereo)(A40/13)	√	√	√	√	×	ACT0181,ACT0065	SP1063	×	×
ED-Class	243	Driver assistance	NBR LR-Left rear short-range	√	√	√	√	×	×	SP1173	×	×
ED-Class	243	Driver assistance	NBR RR-Right rear short-range	√	√	√	√	×	×	SP1172	×	×
ED-Class	243	Driver assistance	PTS-PARKTRONIC	√	√	√	√	×	ACT0421,ACT0306	SP1166	×	×
ED-Class	243	Driver assistance	RFK-Backup camera	√	√	√	√	×	×	SP1152	×	×
ED-Class	243	Driver assistance system	SG AWF-COLLISION PREVENTION ASSIST	√	√	√	√	×	×	SP1063	×	×
ED-Class	243	Driver assistance	SGR-Radar sensors control unit	√	√	√	√	×	ACT0419,ACT0420	SP1163,SP1164,SP1165	×	×
ED-Class	243	Driver assistance system	TPM-Tire pressure monitor(N88)	√	√	√	√	×	ACT0078,ACT0079,ACT0081,ACT0080	SP1053	×	×
ED-Class	243	Information and communication	Audio-Audio or COMAND	√	√	√	×	×	×	×	×	×

ED-Class	243	Information and communication	CSM-Windshield reader system	√	√	√	√	×	×	×	×	×
ED-Class	243	Information and communication	CTEL-Cellular telephone	√	√	√	√	×	×	×	×	×
ED-Class	243	Information and communication	HERMES-control unit for telematics services	√	√	√	√	×	×	SP1046	×	×
ED-Class	243	Information and communication	HUD-Head up display	√	√	√	√	×	ACT0210,ACT0212	×	×	×
ED-Class	243	Information and communication	IC-Instrument cluster	√	√	√	√	×	ACT0039,ACT0397,ACT0048,ACT0210,ACT0398,ACT0399,ACT0050,ACT0400	SP1043,SP1044,SP1045	×	×
ED-Class	243	Information and communication	MTAS-Mobile phone cradle	√	√	√	√	×	×	×	×	×
ED-Class	243	Information and communication	SOUND-Sound system	√	√	√	√	×	×	×	×	×
ED-Class	243	Information and communication	TPAD-Touchpad	√	√	√	√	×	×	×	×	×
ED-Class	243	Information and communication	ZAN-Audio/COMAND display	√	√	√	√	×	ACT0291,ACT0206,ACT0039	×	×	×
ED-Class	243	Seats and Doors	DCU LR-Left rear door	√	√	√	√	×	ACT0360,ACT0361,ACT0362,ACT0363,ACT0347,ACT0364,ACT0365,ACT0366	SP1080,SP1147,SP1148	×	×
ED-Class	243	Seats and Doors	DCU RF-Right front door	√	√	√	√	×	ACT0353,ACT0274,ACT0273,ACT0354,ACT0283,ACT0284,ACT0281,ACT0282,ACT0355,ACT0278,ACT0356,ACT0357,ACT0347,ACT0279,ACT0348,ACT0349,ACT0358,ACT0359,	SP1080,SP1147,SP1148	×	×
ED-Class	243	Seats and Doors	DCU RR-Right rear door	√	√	√	√	×	ACT0367,ACT0368,ACT0369,ACT0370,ACT0347,ACT0371,ACT0365,ACT0366	SP1080,SP1147,SP1148	×	×
ED-Class	243	Seats and Doors	ESA Front passenger-Electric seat adjustment Front passenger	√	√	√	√	×	ACT0230,ACT0378,ACT0234,ACT0379,ACT0233,ACT0380,ACT0381,ACT0382	SP1075	×	×
ED-Class	243	Seats and Doors	ESV Driver-Electric seat adjustmnet Driver	√	√	√	√	×	ACT0214,ACT0373,ACT0218,ACT0374,ACT0217,ACT0375,ACT0376,ACT0377	SP1075	×	×
ED-Class	243	Seats and Doors	HKS-Tailgate control	√	√	√	√	×	×	×	×	×
ED-Class	243	Seats and Doors	LFD-Left front door	√	√	√	√	×	ACT0342,ACT0255,ACT0254,ACT0343,ACT0269,ACT0270,ACT0267,ACT0268,ACT0344,ACT0261,ACT0345,ACT0346,ACT0347,ACT0263,ACT0348,ACT0349,ACT0350,ACT0351,	SP1080,SP1147,SP1148	×	×
ED-Class	243	Seats and Doors	MKS-BFS-Front passenger more copy the seat	√	√	√	√	×	ACT0383,ACT0384,ACT0386	×	×	×
ED-Class	243	Seats and Doors	MKS-FS-Pilot multi-profile seat	√	√	√	√	×	ACT0383,ACT0384,ACT0386	×	×	×
ED-Class	243	Seats and Doors	S22 (Driver"s door seat adjustment switch)	√	√	√	√	×	×	×	×	×
ED-Class	243	Seats and Doors	S23 (Front passenger door seat adjustment switch)	√	√	√	√	×	×	×	×	×
ED-Class	243	Seats and Doors	S47/2 (Driver door switch	√	√	√	√	×	×	×	×	×

[illegible]

EQC-Class	293	Body	BMS-Battery management system 2	√	√	√	√	×	×	×	×	×
EQC-Class	293	Body	BSN-Battery sensor(B95)	√	√	√	√	×	×	×	×	×
EQC-Class	293	Body	Button group, instrument panel, driver side	√	√	√	√	×	×	×	×	×
EQC-Class	293	Body	DC/DC-DC/DC converter	√	√	√	√	×	×	SP1324	×	×
EQC-Class	293	Body	DCCU-Direct current charge connection unit	√	√	√	√	×	×	×	×	×
EQC-Class	293	Body	EZS-Electronic ignition lock	√	√	√	√	×	ACT1054	×	×	×
EQC-Class	293	Body	FSW-Windshield wiper	√	√	√	√	×	×	×	×	×
EQC-Class	293	Body	GES-Hand motion sensor	√	√	√	√	×	×	×	×	×
EQC-Class	293	Body	GTO-Garage door opener(A67n2)	√	√	√	√	×	×	×	×	×
EQC-Class	293	Body	KG-Keyless Go	√	√	√	√	×	ACT0131,ACT0132	×	×	×
EQC-Class	293	Body	LRE-Steering wheel electronics	√	√	√	√	×	×	×	×	×
EQC-Class	293	Body	N25/6 (Rear passenger compartment seat heater control	√	√	√	√	×	×	×	×	×
EQC-Class	293	Body	N38 (Rear switching module)	√	√	√	√	×	×	×	×	×
EQC-Class	293	Body	OCP-Overhead control panel	√	√	√	√	×	ACT1093,ACT1094,ACT0303,ACT0302,ACT1095,ACT1096,ACT1097,ACT1098,ACT1099,ACT0465,ACT1100	SP1441	×	×
EQC-Class	293	Body	PSD-Panoramic sliding roof	√	√	√	√	×	×	×	×	×
EQC-Class	293	Body	RevETR LF-Left front reversible emergency tensioning retractor	√	√	√	√	×	ACT0209	×	×	×
EQC-Class	293	Body	RevETR RF-Right front reversible emergency tensioning	√	√	√	√	×	ACT0213	×	×	×
EQC-Class	293	Body	RGLS-Rain/light sensor(B38/2)	√	√	√	√	×	×	×	×	×
EQC-Class	293	Body	SAMF-Front signal acquisition and actuation module(N10/6)	√	√	√	√	×	ACT0729,ACT0730,ACT0731,ACT0732,ACT0344,ACT0507,ACT0733,ACT0675,ACT0734,ACT0676,ACT0735,ACT0736,ACT0737,ACT0738,ACT0465,ACT0739,ACT0740,ACT0741,ACT0742,ACT0743,ACT0744,	×	×	×
EQC-Class	293	Body	SAMR-Rear signal acquisition and actuation module(N10/8)	√	√	√	√	×	ACT0747,ACT0240,ACT0748,ACT0749,ACT0750,ACT0731,ACT0751,ACT0752,ACT0753,ACT0754,ACT0755,ACT0756,ACT0757,ACT0758,ACT0759,ACT0760,ACT0761,ACT0762,ACT0763,ACT0764,ACT0765,ACT0766,ACT0767,ACT0768,	×	×	×

EQC-Class	293	Body	SCM-Steering column module(N80)	√	√	√	√	×	ACT0060,ACT0061,ACT0062,ACT0063,ACT0064,ACT0065	×	×	×
EQC-Class	293	Body	SG LG-Charger	√	√	√	√	×	ACT0405,ACT0406,ACT0407,ACT0408,ACT0409,ACT0410	×	×	×
EQC-Class	293	Body	SG LML VL-LED matrix of left front lamp unit	√	√	√	√	×	×	×	×	×
EQC-Class	293	Body	SG SW L-Left headlamp	√	√	√	√	×	×	×	×	×
EQC-Class	293	Body	SG SW R-Right headlamp	√	√	√	√	×	×	×	×	×
EQC-Class	293	Body	SG-LML-VR-LED matrix of right front lamp unit	√	√	√	√	×	×	×	×	×
EQC-Class	293	Body	SOGESTAR2-Sound generator for electric vehicle	√	√	√	√	×	×	×	×	×
EQC-Class	293	Body	SRS-Supplemental restraint system	√	√	√	√	√	×	×	×	×
EQC-Class	293	Body	Trailer recognition module-Trailer recognition	√	√	√	√	×	×	×	×	×
EQC-Class	293	Body	WSS-Weight sensing system(N110)	√	√	√	√	×	×	×	×	×
EQC-Class	293	Chassis	AIRmatic-AIRmatic PLUS	√	√	√	√	×	×	×	×	×
EQC-Class	293	Chassis	AMG DRVU-AMG DRIVE UNIT	√	√	√	√	×	ACT0401,ACT0402,ACT0403,ACT0404	SP1153,SP1154,SP1155	×	×
EQC-Class	293	Chassis	AMG DRVU-AMG DRIVE UNIT	√	√	√	×	×	ACT1109	×	×	×
EQC-Class	293	Chassis	EFB-Electric parking brake	√	√	√	√	×	ACT0285,ACT0286,ACT0287,ACT0288	SP1081	×	×
EQC-Class	293	Chassis	ELC-Electronic level control	√	√	√	√	×	ACT0631,ACT0630,ACT1160,ACT1161,ACT1162,ACT1163,ACT0638,ACT0639	SP1061	×	×
EQC-Class	293	Chassis	ES - Electric power steering	√	√	√	√	×	×	SP1071,SP1167	×	×
EQC-Class	293	Chassis	ESP-Electric stability program(N30/4)	√	√	√	√	√	ACT0069,ACT0070,ACT0863,ACT0285,ACT0286,ACT0287,ACT0288	SP1174,SP1175,SP1176,SP1177,SP1178,SP1179,SP1366,SP1181,SP1367,	×	×
EQC-Class	293	Drive	EAGGS-Electric differential lock	√	√	√	√	×	ACT0814	SP1155	×	×
EQC-Class	293	Drive	FSCU-Control unit Fuel pump	√	√	√	√	×	ACT0252,ACT0320	×	×	×
EQC-Class	293	Drive	HFFM-Haptic accelerator pedal module	√	√	√	√	×	ACT1110,ACT1111	×	×	×
EQC-Class	293	Drive	ISG-Integrated starter alternator	√	√	√	√	×	×	×	×	×
EQC-Class	293	Drive	ISG-Integrated starter alternator	√	√	√	√	×	×	SP1368	×	×
EQC-Class	293	Drive	ISM-Shift module	√	√	√	√	×	ACT0670,ACT0671,ACT0318	SP1345,SP1346,SP1446	×	×
EQC-Class	293	Drive	N127 (Drivetrain control unit)	√	√	√	√	×	ACT1244,ACT1245,ACT1246,ACT0028,ACT1247,ACT1248,ACT1249,ACT0995,ACT1250,ACT1251,ACT1252,ACT1253,ACT1254,ACT1239,ACT1255,	SP1495,SP1496,SP1497,SP1498,SP1499,SP1500,SP1501	×	×

EQC-Class	293	Drive	SG EM-Power electronics	√	√	√	√	×	ACT0451,ACT0452,ACT1237	×	×	×
EQC-Class	293	Drive	SG EM-Power electronics 1	√	√	√	√	×	ACT0451,ACT0452	×	×	×
EQC-Class	293	Driver assistance system	DTR-DISTRONIC	√	√	√	√	×	×	SP1161,SP1162	×	×
EQC-Class	293	Driver assistance system	IRS HLA-Outer left rear integrated radar sensor (B92/11)	√	√	√	√	×	×	SP1473	×	×
EQC-Class	293	Driver assistance system	IRS HRA-Outer right rear integrated radar sensor (B92/6)	√	√	√	√	×	×	SP1474	×	×
EQC-Class	293	Driver assistance system	KAR-Augmented reality camera	√	√	√	√	×	×	×	×	×
EQC-Class	293	Driver assistance system	MFK-Multifunction camera(mono)(A40/11)	√	√	√	√	×	ACT0181,ACT0065	SP1156	×	×
EQC-Class	293	Driver assistance system	MFK-Multifunction camera(stereo)(A40/13)	√	√	√	√	×	ACT0181,ACT0065	SP1063	×	×
EQC-Class	293	Driver assistance system	NBR LR-Left rear short-range radar	√	√	√	√	×	×	SP1173	×	×
EQC-Class	293	Driver assistance system	NBR RR-Right rear short-range radar	√	√	√	√	×	×	SP1172	×	×
EQC-Class	293	Driver assistance system	PTS-PARKTRONIC	√	√	√	√	×	ACT0421,ACT0306	SP1166	×	×
EQC-Class	293	Driver assistance system	RFK-Backup camera	√	√	√	√	×	×	SP1152	×	×
EQC-Class	293	Driver assistance system	SG AWF-COLLISION PREVENTION ASSIST	√	√	√	√	×	×	SP1063	×	×
EQC-Class	293	Driver assistance system	SGR-Radar sensors control unit	√	√	√	√	×	ACT0419,ACT0420	SP1163,SP1164,SP1165	×	×
EQC-Class	293	Driver assistance system	TPM-Tire pressure monitor(N88)	√	√	√	√	×	ACT0078,ACT0079,ACT0081,ACT0080	SP1053	×	×
EQC-Class	293	Information and communication	Audio-Audio or COMAND	√	√	√	×	×	×	×	×	×
EQC-Class	293	Information and communication	COU[ZBE]-Audio/COMAND operating unit	√	√	√	√	×	ACT0289,ACT0041	SP1199	×	×
EQC-Class	293	Information and communication	CSM-Windshield reader system	√	√	√	√	×	×	×	×	×
EQC-Class	293	Information and communication	HERMES-control unit for telematics services	√	√	√	√	×	×	SP1046	×	×
EQC-Class	293	Information and communication	HUD-Head up display	√	√	√	√	×	ACT0210,ACT0212	×	×	×
EQC-Class	293	Information and communication	IC-Instrument cluster(A1)	√	√	√	√	×	ACT0397,ACT0048,ACT0210,ACT0398,ACT0399,ACT0050,ACT0400,ACT0039	SP1043,SP1044,SP1045	×	×
EQC-Class	293	Information and communication	LCP-Lower control panel	√	√	√	×	×	×	×	×	×
EQC-Class	293	Information and communication	MTAS-Mobile phone cradle	√	√	√	√	×	×	×	×	×
EQC-Class	293	Information and communication	N72/1 (Upper control panel control unit)	√	√	√	×	×	×	×	×	×
EQC-Class	293	Information and communication	N72/4 (Left lower control panel)	√	√	√	×	×	×	×	×	×
EQC-Class	293	Information and communication	N72/4 (Left lower control panel)	√	√	√	×	×	×	×	×	×

EQC-Class	293	Information and communication	SOUND-Sound system	√	√	√	√	×	×	×	×	×
EQC-Class	293	Information and communication	TPAD-Touchpad	√	√	√	√	×	×	×	×	×
EQC-Class	293	Information and communication	TPAD-Touchpad	√	√	√	√	×	×	×	×	×
EQC-Class	293	Information and communication	ZAN-Audio/COMAND display	√	√	√	√	×	ACT0291,ACT0206,ACT0039	×	×	×
EQC-Class	293	Seats and Doors	DCU LR-Left rear door	√	√	√	√	×	ACT0360,ACT0361,ACT0362,ACT0363,ACT0723,ACT0688,ACT0347,ACT0364,ACT0724,ACT0366,ACT0725	SP1080,SP1147,SP1148	×	×
EQC-Class	293	Seats and Doors	DCU RF-Right front door	√	√	√	√	×	ACT0353,ACT0274,ACT0273,ACT0354,ACT0720,ACT0283,ACT0284,ACT0281,ACT0282,ACT0721,ACT0355,ACT0278,ACT0356,ACT0357,ACT0347,ACT0279,ACT0348,ACT0349,ACT0358,ACT0359,ACT0722,	SP1080,SP1147,SP1148	×	×
EQC-Class	293	Seats and Doors	DCU RR-Right rear door	√	√	√	√	×	ACT0367,ACT0368,ACT0369,ACT0370,ACT0726,ACT0692,ACT0347,ACT0371,ACT0365,ACT0727,ACT0728,ACT0366	SP1080,SP1147,SP1148	×	×
EQC-Class	293	Seats and Doors	ESA Front passenger-Electric seat adjustment Front passenger	√	√	√	√	×	×	×	×	×
EQC-Class	293	Seats and Doors	ESV Driver-Electric seat adjustmnet Driver	√	√	√	√	×	×	×	×	×
EQC-Class	293	Seats and Doors	ESV Driver-Electric seat adjustmnet Driver with memory function	√	√	√	√	×	ACT0214,ACT0373,ACT0218,ACT0374,ACT0217,ACT1064,ACT0375,ACT0376,ACT0377	SP1438,SP1075,SP1074	×	×
EQC-Class	293	Seats and Doors	ESV Front passenger-Electric seat adjustment Front passenger with memory function	√	√	√	√	×	ACT0230,ACT0378,ACT0234,ACT0379,ACT0233,ACT1065,ACT0380,ACT0381,ACT0382	SP1438,SP1075,SP1074	×	×
EQC-Class	293	Seats and Doors	HKS-Tailgate control	√	√	√	√	×	ACT1089,ACT1090	SP1439	×	×
EQC-Class	293	Seats and Doors	LFD-Left front door	√	√	√	√	×	ACT0342,ACT0255,ACT0254,ACT0343,ACT0715,ACT0269,ACT0361,ACT0267,ACT0268,ACT0716,ACT0344,ACT0261,ACT0345,ACT0346,ACT0347,ACT0263,ACT0348,ACT0349,ACT0350,ACT0351,ACT0717,	SP1080,SP1147,SP1148	×	×
EQC-Class	293	Seats and Doors	MKS-BFS-Front passenger more copy the seat	√	√	√	√	×	ACT0383,ACT0384,ACT0386	×	×	×
EQC-Class	293	Seats and Doors	MKS-FS-Pilot multi-profile seat	√	√	√	√	×	ACT0383,ACT0384,ACT0386	×	×	×
EQC-Class	293	Seats and Doors	S22 (Driver"s door seat adjustment switch)	√	√	√	×	×	×	×	×	×
EQC-Class	293	Seats and Doors	S23 (Front passenger door seat adjustment switch)	√	√	√	×	×	×	×	×	×
EQC-Class	293	Seats and Doors	S47/2 (Driver door switch module)	√	√	√	×	×	×	×	×	×

EQC-Class	293	Seats and Doors	S47/3 (Front passenger door switch module)	√	√	√	×	×	×	×	×	×
EQC-Class	293	Seats and Doors	S51/1 (Driver"s door seat heating switch)	√	√	√	×	×	×	×	×	×
EQC-Class	293	Seats and Doors	S51/2 (Front passenger door seat heating switch)	√	√	√	×	×	×	×	×	×
EQC-Class	293	Seats and Doors	S51/3 (Left rear seat heater switch)	√	√	√	×	×	×	×	×	×
EQC-Class	293	Seats and Doors	S51/4 (Right rear seat heater switch)	√	√	√	×	×	×	×	×	×
GL-Class	X 164	Air conditioning	AAC-Automatic air conditioning	√	√	√	√	×	ACT0555,ACT0556,ACT0557,ACT0558,ACT0559,ACT0560,ACT0561,ACT0562,ACT0563	SP1254,SP1255,SP1256,SP1257	×	×
GL-Class	X 164	Air conditioning	LRH-Steering wheel heater	√	√	√	√	×	ACT0564	×	×	×
GL-Class	X 164	Air conditioning	STH-Stationary heater with remote control	√	√	√	√	×	ACT0565,ACT0566,ACT0567	×	×	×
GL-Class	X 164	Body	AB-Airbag	√	√	√	√	√	×	SP1240	×	×
GL-Class	X 164	Body	CGW-Central gateway	√	√	√	×	×	×	×	×	×
GL-Class	X 164	Body	EZS-Electronic ignition switch	√	√	√	√	×	×	×	×	×
GL-Class	X 164	Body	EZS-Electronic ignition switch	√	√	√	√	×	×	×	×	×
GL-Class	X 164	Body	HBF-Rear control field	√	√	√	√	×	ACT0509,ACT0507,ACT0510,ACT0511	×	×	×
GL-Class	X 164	Body	HRA-Automatic headlamp range adjustment and headlamp control	√	√	√	√	×	ACT0292	SP1253	×	×
GL-Class	X 164	Body	KG-Keyless Go	√	√	√	√	×	×	×	×	×
GL-Class	X 164	Body	KG-KEYLESS GO	√	√	√	√	×	×	×	×	×
GL-Class	X 164	Body	OCP-Overhead control panel	√	√	√	√	×	ACT0301,ACT0504,ACT0505,ACT0506,ACT0507,ACT0508	SP1245,SP1246	×	×
GL-Class	X 164	Body	REAR SAM-Rear signal acquisition and actuation module	√	√	√	√	×	×	×	×	×
GL-Class	X 164	Body	RevETR LF-Left front reversible emergency tensioning retractor	√	√	√	√	×	×	×	×	×
GL-Class	X 164	Body	RevETR LF-Left front reversible emergency tensioning retractor	√	√	√	√	×	×	×	×	×
GL-Class	X 164	Body	RevETR RF-Right front reversible emergency tensioning	√	√	√	√	×	×	×	×	×
GL-Class	X 164	Body	RevETR RF-Right front reversible emergency tensioning	√	√	√	√	×	×	×	×	×
GL-Class	X 164	Body	SAM F-Signal acquisition and actuation module front	√	√	√	√	×	ACT0512,ACT0513,ACT0514,ACT0515,ACT0516,ACT0517,ACT0518,ACT0519,ACT0520	×	×	×
GL-Class	X 164	Body	System diagnosis(CAN)	√	√	√	√	×	×	×	×	×
GL-Class	X 164	Body	UCP-Upper control panel	√	√	√	√	×	ACT0509,ACT0507	×	×	×
GL-Class	X 164	Body	WSS-Weight sensing system	√	√	√	√	×	×	×	×	×
GL-Class	X 164	Body	XALWA L-Xenon headlamp, left	√	√	√	√	×	×	SP1084,SP1250,SP1251	×	×
GL-Class	X 164	Body	XALWA L-Xenon headlamp, left	√	√	√	√	×	ACT0549,ACT0550,ACT0551,ACT0552	SP1252	×	×
GL-Class	X 164	Body	XALWA R-Xenon headlamp,	√	√	√	√	×	×	SP1084,SP1250,SP1251	×	×
GL-Class	X 164	Body	XALWA R-Xenon headlamp,	√	√	√	√	×	ACT0553,ACT0554	SP1252	×	×
GL-Class	X 164	Chassis	EHPS-Electrohydraulic Power Steering	√	√	√	√	×	×	×	×	×
GL-Class	X 164	Chassis	ESP-Electronic stability program	√	√	√	√	×	ACT0482,ACT0483,ACT0484	SP1238,SP1239	×	×

GL-Class	X 164	Chassis	Suspension	√	√	√	√	×	ACT0496,ACT0497,ACT0498, ACT0499,ACT0500,ACT0501, ACT0502,ACT0503	SP1242,SP1243,SP1244	×	×
GL-Class	X 164	Chassis	TPM-Tire pressure monitor	√	√	√	√	×	×	×	×	×
GL-Class	X 164	Chassis	TPM-Tire pressure monitor	√	√	√	√	×	×	×	×	×
GL-Class	X 164	Drive	CDI 4-Common Rail Diesel	√	√	√	√	√	×	SP1212	×	×
GL-Class	X 164	Drive	CDI 5-Common Rail Diesel	√	√	√	√	√	×	SP1212	×	×
GL-Class	X 164	Drive	CDI 6-Common Rail Diesel Injection	√	√	√	√	√	ACT0002,ACT0577,ACT0578, ACT0579,ACT0580,ACT0032	SP1212	×	×
GL-Class	X 164	Drive	CDI 60LS-Common Rail Diesel Injection	√	√	√	√	√	ACT0026,ACT0586,ACT0002, ACT0472,ACT0005,ACT0578, ACT0587,ACT0579,ACT0580, ACT0032,ACT0588,ACT0024	SP1258,SP1284,SP1259, SP1262,SP1264,SP1211, SP1263,SP1265,SP1266, SP1267,SP1285,SP1271, SP1281,SP1210,SP1286, SP1275,SP1287,SP1278,	×	×
GL-Class	X 164	Drive	CDI 6BIN5-Common Rail Diesel Injection	√	√	√	√	√	×	SP1258,SP1259,SP1260, SP1004,SP1261,SP1262, SP1263,SP1264,SP1265, SP1266,SP1267,SP1268, SP1269,SP1270,SP1271, SP1272,SP1273,SP1274, SP1275,SP1276,SP1277,	×	×
GL-Class	X 164	Drive	DTR-Distronic	√	√	√	√	×	×	×	×	×
GL-Class	X 164	Drive	DTR-Distronic	√	√	√	√	×	×	SP1077	×	×
GL-Class	X 164	Drive	ETC-Electronic transmission control	√	√	√	√	√	×	SP1217,SP1218,SP1219, SP1220,SP1221,SP1222, SP1223,SP1214,SP1224, SP1225,SP1226,SP1227, SP1228,SP1229,SP1214, SP1230,SP1231,SP1232, SP1233,SP1234,SP1235,	×	√
GL-Class	X 164	Drive	FSCU-Fuel pump	√	√	√	√	×	ACT0320	×	×	×
GL-Class	X 164	Drive	HAQ-Interwheel differential lock at rear axle	√	√	√	√	×	×	×	×	×
GL-Class	X 164	Drive	IRS HLA-Outer left rear intelligent radar sensor system	√	√	√	√	×	×	×	×	×
GL-Class	X 164	Drive	IRS HRA-Outer right rear intelligent radar sensor system	√	√	√	√	×	×	×	×	×
GL-Class	X 164	Drive	ISM-Intelligent servo module	√	√	√	√	×	ACT0490,ACT0491,ACT0492, ACT0493,ACT0494	×	×	×
GL-Class	X 164	Drive	ISM-Shift module	√	√	√	√	×	ACT0490,ACT0495,ACT0492, ACT0493,ACT0494	SP1241	×	×
GL-Class	X 164	Drive	ME 9.7-Motor electronics 9.7	√	√	√	√	√	ACT0467,ACT0468,ACT0005, ACT0002,ACT0469,ACT0470, ACT0471,ACT0472,ACT0473, ACT0474,ACT0475,ACT0476, ACT0477,ACT0478,ACT0479, ACT0480,ACT0000,ACT0481	SP1210,SP1211,SP1212, SP1213,SP1214,SP1215, SP1216	×	√
GL-Class	X 164	Drive	SCR-Selective Catalytic Reduction	√	√	√	√	×	ACT0581,ACT0582,ACT0583, ACT0584,ACT0585	SP1279,SP1280,SP1281, SP1282,SP1283	×	×
GL-Class	X 164	Drive	VG-Transfer case	√	√	√	√	×	ACT0489	×	×	×

GL-Class	X 164	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	√	√	√	√	×	×	×	×	×
GL-Class	X 164	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	√	√	√	√	×	×	×	×	×
GL-Class	X 164	Information and communication	ASSYST PLUS-PLUS Active Service System	√	√	√	√	×	×	SP1248,SP1249	×	×
GL-Class	X 164	Information and communication	ASSYST-Active Service System	√	√	√	√	×	×	SP1247	×	×
GL-Class	X 164	Information and communication	AUDIO	√	√	√	√	×	×	×	×	×
GL-Class	X 164	Information and communication	AVE H-Rear audio video unit	√	√	√	√	×	×	×	×	×
GL-Class	X 164	Information and communication	AVE H-Rear audio video unit	√	√	√	√	×	×	×	×	×
GL-Class	X 164	Information and communication	CDC-CD changer	√	√	√	√	×	×	×	×	×
GL-Class	X 164	Information and communication	CM-Compass module	√	√	√	√	×	×	×	×	×
GL-Class	X 164	Information and communication	COMAND or AUDIO	√	√	√	√	×	×	×	×	×
GL-Class	X 164	Information and communication	COMAND or AUDIO	√	√	√	√	×	×	×	×	×
GL-Class	X 164	Information and communication	CTEL-Cellular telephone	√	√	√	√	×	×	×	×	×
GL-Class	X 164	Information and communication	CTEL-Cellular telephone(JAPAN)	√	√	√	√	×	×	×	×	×
GL-Class	X 164	Information and communication	CTEL-Mobile phone adapter with universal interface	√	√	√	√	×	×	×	×	×
GL-Class	X 164	Information and communication	DAB-Digital radio	√	√	√	√	×	×	×	×	×
GL-Class	X 164	Information and communication	IC-Instrument cluster	√	√	√	√	×	ACT0485,ACT0486,ACT0487,ACT0488	×	×	×
GL-Class	X 164	Information and communication	Left rear screen	√	√	√	√	×	ACT0568,ACT0569,ACT0570,ACT0571,ACT0572	×	×	×
GL-Class	X 164	Information and communication	NAVI-Navigation system	√	√	√	√	×	×	×	×	×
GL-Class	X 164	Information and communication	PTS-Parktronic system	√	√	√	√	×	×	×	×	×
GL-Class	X 164	Information and communication	PTS-Parktronic system	√	√	√	√	×	×	×	×	×
GL-Class	X 164	Information and communication	RFK-Backup camera	√	√	√	√	×	×	×	×	×
GL-Class	X 164	Information and communication	Right rear screen	√	√	√	√	×	ACT0573,ACT0569,ACT0574,ACT0575,ACT0576	×	×	×
GL-Class	X 164	Information and communication	SCM [MRM]-Steering column module	√	√	√	√	×	ACT0540	SP1077	×	×
GL-Class	X 164	Information and communication	SDAR-Satellite radio	√	√	√	√	×	×	×	×	×
GL-Class	X 164	Information and communication	SDAR-Satellite radio(Valid for USA)	√	√	√	√	×	×	×	×	×

GL-Class	X 164	Information and communication	SOUND-Sound system	√	√	√	√	×	×	×	×	×
GL-Class	X 164	Information and communication	TELE AID-Control unit	√	√	√	√	×	×	×	×	×
GL-Class	X 164	Information and communication	TELE AID-Telematic services Emergency call	√	√	√	√	×	×	×	×	×
GL-Class	X 164	Information and communication	TELE AID-Telematic services MB Info,Roadside assistance(USA, Canada),Tele	√	√	√	√	×	×	×	×	×
GL-Class	X 164	Information and communication	TELE AID-Telematic services Remote door unlocking,Remote door locking	√	√	√	√	×	×	×	×	×
GL-Class	X 164	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	√	√	√	√	×	×	×	×	×
GL-Class	X 164	Information and communication	TV-TV tuner	√	√	√	√	×	×	×	×	×
GL-Class	X 164	Information and communication	TV-TV tuner	√	√	√	√	×	×	×	×	×
GL-Class	X 164	Information and communication	TV-TV tuner	√	√	√	√	×	×	×	×	×
GL-Class	X 164	Information and communication	TV-TV tuner	√	√	√	√	×	×	×	×	×
GL-Class	X 164	Information and communication	TV-TV tuner(AGW)	√	√	√	√	×	×	×	×	×
GL-Class	X 164	Information and communication	UCI-Media interface	√	√	√	√	×	×	×	×	×
GL-Class	X 164	Information and communication	VCS-Voice control system	√	√	√	√	×	×	×	×	×
GL-Class	X 164	Seats and Doors	DCM FL-Door control module front left	√	√	√	√	×	ACT0521,ACT0522,ACT0523,ACT0256,ACT0524,ACT0525,ACT0526,ACT0527	×	×	×
GL-Class	X 164	Seats and Doors	DCM FR-Door control module front right	√	√	√	√	×	ACT0528,ACT0522,ACT0523,ACT0524,ACT0529,ACT0530,	×	×	×
GL-Class	X 164	Seats and Doors	DS LF-Left front dynamic seat	√	√	√	√	×	ACT0532,ACT0533,ACT0534,ACT0535,ACT0536	×	×	×
GL-Class	X 164	Seats and Doors	DS RF-Right front dynamic seat	√	√	√	√	×	ACT0532,ACT0533,ACT0534,ACT0537,ACT0538	×	×	×
GL-Class	X 164	Seats and Doors	DSP-Pneumatic pump for dynamic seat	√	√	√	√	×	×	×	×	×
GL-Class	X 164	Seats and Doors	ERA-Electric fold-down backrest system (3rd seat row)	√	√	√	√	×	ACT0539	×	×	×
GL-Class	X 164	Seats and Doors	ESV driver-Electric seat adjustment driver (with memory)	√	√	√	√	×	×	×	×	×
GL-Class	X 164	Seats and Doors	ESV passenger-Electric seat adjustment passenger	√	√	√	√	×	×	×	×	×
GL-Class	X 164	Seats and Doors	HS-Seat heater	√	√	√	√	×	ACT0545,ACT0546,ACT0547,ACT0548,ACT0413,ACT0414	×	×	×
GL-Class	X 164	Seats and Doors	REDC-Rear end door closing control module	√	√	√	√	×	ACT0541	×	×	×
GL-Class	X 164	Seats and Doors	REDC-Rear end door closing control module	√	√	√	√	×	ACT0542,ACT0543,ACT0544	×	×	×
GLB/B/ GLA-	247	Air conditioning	AAC-Automatic air conditioning	√	√	√	√	×	×	×	×	×

GLB/B/ GLA- Class	247	Air conditioning	AAC-Automatic air conditioning	√	√	√	√	×	ACT0416,ACT0182,ACT0417, ACT0186,ACT0194,ACT0195, ACT0197,ACT0196,ACT0028,	SP1065,SP1066,SP1067, SP1159,SP1160	×	×
GLB/B/ GLA-	247	Air conditioning	STH-Stationary heater	√	√	√	√	×	ACT0202	×	×	×
GLB/B/ GLA-	247	Air conditioning	TSTH-Radio remote control of stationary heater	√	√	√	√	×	ACT0203,ACT0418	×	×	×
GLB/B/ GLA-	247	Body	"Driver" seat heater	√	√	√	√	×	ACT0411,ACT0412,ACT0413, ACT0414,ACT0415	SP1157,SP1158	×	×
GLB/B/ GLA-	247	Body	"Front passenger" seat heater	√	√	√	√	×	×	×	×	×
GLB/B/ GLA- Class	247	Body	AML-Ambiance light	√	√	√	√	×	ACT0389,ACT0390,ACT0391, ACT0392,ACT0393,ACT0394, ACT0395,ACT0396,ACT0043	SP1149	×	×
GLB/B/ GLA-	247	Body	Anti glare interior rearview mirror(DBE)	√	√	√	√	×	×	×	×	×
GLB/B/ GLA-	247	Body	AS-Alarm siren(H3/1)	√	√	√	√	×	ACT0309,ACT0465,ACT0466	×	×	×
GLB/B/ GLA-	247	Body	ATA-Interior motion sensor	√	√	√	√	×	×	×	×	×
GLB/B/ GLA-	247	Body	BMS-Battery management system	√	√	√	√	×	ACT0453,ACT0454,ACT0455	SP1197	×	×
GLB/B/ GLA-	247	Body	BSN-Battery sensor(B95)	√	√	√	√	×	×	×	×	×
GLB/B/ GLA-	247	Body	DC/DC-DC/DC converter	√	√	√	√	×	×	×	×	×
GLB/B/ GLA-	247	Body	DCCU-Direct current charge connection unit	√	√	√	√	×	×	×	×	×
GLB/B/ GLA-	247	Body	Driver side SAM-Front signal acquisition and actuation module	√	√	√	√	×	×	×	×	×
GLB/B/ GLA-	247	Body	EZS-Electronic ignition switch	√	√	√	√	×	ACT0372	×	×	×
GLB/B/ GLA-	247	Body	FSW-Windshield wiper	√	√	√	√	×	×	×	×	×
GLB/B/ GLA-	247	Body	GES-Hand motion sensor	√	√	√	√	×	×	×	×	×
GLB/B/ GLA-	247	Body	GTO-Garage door opener(A67n2)	√	√	√	√	×	×	×	×	×
GLB/B/ GLA-	247	Body	HE-Hand detection	√	√	√	√	×	×	×	×	×
GLB/B/ GLA-	247	Body	LIB-Lithium ion battery	√	√	√	√	×	×	×	×	×
GLB/B/ GLA-	247	Body	LIB-Lithium ion battery	√	√	√	√	×	×	×	×	×
GLB/B/ GLA-	247	Body	LRE-Steering wheel electronics	√	√	√	√	×	×	×	×	×
GLB/B/ GLA-	247	Body	Multifunction control unit- Multifunction control unit	√	√	√	√	×	×	×	×	×
GLB/B/ GLA-	247	Body	Multifunction control unit- Multifunction control unit	√	√	√	√	×	ACT0204	×	×	×
GLB/B/ GLA-	247	Body	N38 (Rear switching module)	√	√	√	√	×	×	×	×	×

GLB/B/ GLA-	247	Body	OCP-Overhead control panel	√	√	√	√	×	×	×	×	×
GLB/B/ GLA-	247	Body	PSD-Control module Panoramic sliding roof	√	√	√	√	×	×	×	×	×
GLB/B/ GLA-	247	Body	PSD-Panoramic sliding roof	√	√	√	√	×	×	×	×	×
GLB/B/ GLA-	247	Body	RevETR LF-Left front reversible emergency tensioning retractor	√	√	√	√	×	×	×	×	×
GLB/B/ GLA-	247	Body	RevETR LF-Left front reversible emergency tensioning retractor	√	√	√	√	×	ACT0209	×	×	×
GLB/B/ GLA-	247	Body	RevETR RF-Right front reversible emergency tensioning	√	√	√	√	×	×	×	×	×
GLB/B/ GLA-	247	Body	RevETR RF-Right front reversible emergency tensioning	√	√	√	√	×	ACT0213	×	×	×
GLB/B/ GLA-	247	Body	RGLS-Rain/light sensor(B38/2)	√	√	√	√	×	×	×	×	×
GLB/B/ GLA-	247	Body	SCM-Steering column module	√	√	√	√	×	×	×	×	×
GLB/B/ GLA-	247	Body	SG LG-Charger	√	√	√	√	×	ACT0405,ACT0406,ACT0407,ACT0408,ACT0409,ACT0410	×	×	×
GLB/B/ GLA-	247	Body	SG LML VL-LED matrix of left front lamp unit	√	√	√	√	×	×	×	×	×
GLB/B/ GLA-	247	Body	SG SW L-Left headlamp	√	√	√	√	×	×	×	×	×
GLB/B/ GLA-	247	Body	SG SW R-Right headlamp	√	√	√	√	×	×	×	×	×
GLB/B/ GLA-	247	Body	SG-LML-VR-LED matrix of right front lamp unit	√	√	√	√	×	×	×	×	×
GLB/B/ GLA-	247	Body	SOGESTAR2-Sound generator for electric vehicle	√	√	√	√	×	×	×	×	×
GLB/B/ GLA-	247	Body	SRS-Supplemental restraint system	√	√	√	√	√	×	×	×	×
GLB/B/ GLA-	247	Body	STM-Mirror taximeter	√	√	√	√	×	×	×	×	×
GLB/B/ GLA-	247	Body	Trailer recognition module-Trailer recognition	√	√	√	√	×	×	×	×	×
GLB/B/ GLA-	247	Body	WSS-Weight sensing system(N110)	√	√	√	√	×	×	×	×	×
GLB/B/ GLA-	247	Chassis	ADS-Adaptive damping system(N51/5)	√	√	√	√	×	×	SP1061	×	×
GLB/B/ GLA-	247	Chassis	ADS-Adaptive damping system(N51/5)	√	√	√	√	×	×	SP1061	×	×
GLB/B/ GLA-	247	Chassis	AMG DRVU-AMG DRIVE UNIT	√	√	√	√	×	ACT0401,ACT0402,ACT0403,ACT0404	SP1153,SP1154,SP1155	×	×
GLB/B/ GLA-	247	Chassis	ES - Electric power steering	√	√	√	√	×	×	SP1071,SP1069,SP1167,SP1168,SP1169	×	×
GLB/B/ GLA- Class	247	Chassis	ESP- Electric stability program	√	√	√	√	√	ACT0069,ACT0070,ACT0285,ACT0288	SP1174,SP1175,SP1176,SP1177,SP1178,SP1179,SP1180,SP1181,SP1182,	×	×
GLB/B/ GLA- Class	247	Chassis	ESP- Electric stability program	√	√	√	√	×	ACT0069,ACT0070,ACT0285,ACT0288	SP1174,SP1175,SP1176,SP1177,SP1178,SP1179,SP1180,SP1181,SP1182,	×	×

GLB/B/ GLA-	247	Chassis	Lower control panel(DRVU)	√	√	√	×	×	×	×	×	×
GLB/B/ GLA-	247	Drive	48V on board electrical system of ISG starter generator	√	√	√	×	×	×	×	×	×
GLB/B/ GLA- Class	247	Drive	CDI-Engine Electronics CRR2 for Internal Combustion Engine OM608	√	√	√	√	√	ACT0336,ACT0005,ACT0002, ACT0031,ACT0030,ACT0032, ACT0022,ACT0328,ACT0026, ACT0033,ACT0337	SP1000,SP1118,SP1119, SP1120,SP1121,SP1122, SP1123,SP1124,SP1125, SP1126,SP1127,SP1022, SP1128,SP1021,SP1129,	×	×
GLB/B/ GLA-	247	Drive	FSCU-Fuel pump	√	√	√	√	×	×	×	×	×
GLB/B/ GLA-	247	Drive	N127 (Drivetrain control unit)	√	√	√	×	×	×	×	×	×
GLB/B/ GLA- Class	247	Drive	N127 (Drivetrain control unit)	√	√	√	√	×	ACT0028,ACT0430,ACT0431, ACT0432,ACT0433,ACT0007, ACT0434,ACT0435,ACT0436, ACT0437,ACT0438,ACT0439, ACT0440,ACT0441,ACT0442, ACT0443,ACT0444,ACT0445, ACT0446,ACT0447,ACT0448,	SP1186,SP1042,SP1025, SP1187,SP1188,SP1189, SP1190,SP1191,SP1192	×	×
GLB/B/ GLA-	247	Drive	N15/13 (Double clutch transmission control unit)	√	√	√	√	×	×	×	×	×
GLB/B/ GLA- Class	247	Drive	N3/10-Motor electronics "EM71" for combustion engine "M282"	√	√	√	√	√	ACT0330,ACT0002,ACT0005, ACT0456,ACT0323,ACT0324, ACT0325,ACT0025,ACT0328, ACT0329,ACT0022,ACT0457,	SP1001,SP1004,SP1109, SP1115,SP1017,SP1198	×	×
GLB/B/ GLA- Class	247	Drive	N3/10-Motor electronics "MED41" for combustion engine "M260/M264"	√	√	√	√	√	ACT0330,ACT0003,ACT0459, ACT0323,ACT0324,ACT0333, ACT0025,ACT0328,ACT0331, ACT0332,ACT0004,ACT0005, ACT0456,ACT0002,ACT0460, ACT0329,ACT0022,ACT0325,	SP1199,SP1117	×	×
GLB/B/ GLA- Class	247	Drive	N3/10-Motor electronics "MRG1AMGR4" for combustion engine "M139"	√	√	√	√	×	ACT0330,ACT0002,ACT0025, ACT0005,ACT0022,ACT0456, ACT0329,ACT0462,ACT0328, ACT0463,ACT0464,ACT0331	SP1001,SP1004,SP1200, SP1201,SP1202,SP1203, SP1204,SP1110,SP1109, SP1139,SP1017,SP1111,	×	×
GLB/B/ GLA- Class	247	Drive	N3/40-Motor electronics "MRD1" for combustion engine "OM654"	√	√	√	√	√	ACT0001,ACT0005,ACT0006, ACT0321,ACT0008,ACT0009, ACT0010,ACT0322,ACT0011, ACT0012,ACT0016,ACT0018, ACT0022,ACT0023,ACT0024, ACT0026,ACT0000,ACT0338, ACT0339,ACT0340,ACT0341	SP1001,SP1000,SP1130, SP1125,SP1131,SP1132, SP1133,SP1134,SP1135, SP1136,SP1017,SP1137, SP1138,SP1024,SP1139, SP1140,SP1015,SP1141, SP1142,SP1143,SP1144, SP1021,SP1022,SP1145,	×	×
GLB/B/ GLA-	247	Drive	SCR-Selective catalytic reduction	√	√	√	√	×	ACT0424,ACT0425,ACT0426, ACT0427,ACT0428,ACT0429	SP1184,SP1185	×	×
GLB/B/ GLA-	247	Drive	SG EM-Power electronics	√	√	√	√	×	ACT0451,ACT0452	SP1193,SP1194,SP1195, SP1196,SP1150	×	×
GLB/B/ GLA-	247	Drive	VG-All-wheel drive	√	√	√	√	×	×	×	×	×
GLB/B/ GLA-	247	Drive	VG-All-wheel drive	√	√	√	√	×	ACT0043	SP1171	×	×

GLB/B/ GLA-	247	Drive	VG-All-wheel drive	√	√	√	√	×	ACT0422,ACT0423	SP1099,SP1170	×	×
GLB/B/ GLA- Class	247	Drive	Y3/14n4 (Dual clutch transmission fully integrated transmission control unit)	√	√	√	×	×	×	×	×	×
GLB/B/ GLA- Class	247	Drive	Y3/14n4 (Dual clutch transmission fully integrated transmission control unit)	√	√	√	×	×	×	×	×	×
GLB/B/ GLA-	247	Driver assistance system	DTR-DISTRONIC	√	√	√	√	×	×	SP1161,SP1162	×	×
GLB/B/ GLA-	247	Driver assistance system	IRS HLA-Outer left rear integrated radar sensor (B92/11)	√	√	√	√	×	×	SP1150,SP1151	×	×
GLB/B/ GLA-	247	Driver assistance system	IRS HRA-Outer right rear integrated radar sensor (B92/6)	√	√	√	√	×	×	SP1150,SP1151	×	×
GLB/B/ GLA-	247	Driver assistance system	KAR-Augmented reality camera	√	√	√	√	×	×	×	×	×
GLB/B/ GLA-	247	Driver assistance system	MFK-Multifunction camera(mono)(A40/11)	√	√	√	√	×	ACT0181,ACT0065	SP1156	×	×
GLB/B/ GLA-	247	Driver assistance system	MFK-Multifunction camera(stereo)(A40/13)	√	√	√	√	×	ACT0181,ACT0065	SP1063	×	×
GLB/B/ GLA-	247	Driver assistance system	NBR LR-Left rear short-range radar	√	√	√	√	×	×	SP1173	×	×
GLB/B/ GLA-	247	Driver assistance system	NBR RR-Right rear short-range radar	√	√	√	√	×	×	SP1172	×	×
GLB/B/ GLA-	247	Driver assistance system	PTS-PARKTRONIC	√	√	√	√	×	ACT0421,ACT0306	SP1166	×	×
GLB/B/ GLA-	247	Driver assistance system	RFK-Backup camera	√	√	√	√	×	×	SP1152	×	×
GLB/B/ GLA-	247	Driver assistance system	SG AWF-COLLISION PREVENTION ASSIST	√	√	√	√	×	×	SP1063	×	×
GLB/B/ GLA-	247	Driver assistance system	SGR-Radar sensors control unit	√	√	√	√	×	ACT0419,ACT0420	SP1163,SP1164,SP1165	×	×
GLB/B/ GLA-	247	Driver assistance system	TPM-Tire pressure monitor(N88)	√	√	√	√	×	ACT0078,ACT0079,ACT0081,ACT0080	SP1053	×	×
GLB/B/ GLA-	247	Information and communication	Audio-Audio or COMAND	√	√	√	×	×	×	×	×	×
GLB/B/ GLA-	247	Information and communication	CSM-Windshield reader system	√	√	√	√	×	×	×	×	×
GLB/B/ GLA-	247	Information and communication	HERMES-control unit for telematics services	√	√	√	√	×	×	SP1046	×	×
GLB/B/ GLA-	247	Information and communication	HUD-Head up display	√	√	√	√	×	ACT0210,ACT0212	×	×	×
GLB/B/ GLA- Class	247	Information and communication	IC-Instrument cluster	√	√	√	√	×	ACT0039,ACT0397,ACT0048,ACT0210,ACT0398,ACT0399,ACT0050,ACT0400	SP1043,SP1044,SP1045	×	×
GLB/B/ GLA-	247	Information and communication	MTAS-Mobile phone cradle	√	√	√	√	×	×	×	×	×
GLB/B/ GLA-	247	Information and communication	SOUND-Sound system	√	√	√	√	×	×	×	×	×
GLB/B/ GLA-	247	Information and communication	TPAD-Touchpad	√	√	√	√	×	×	×	×	×
GLB/B/ GLA-	247	Information and communication	ZAN-Audio/COMAND display	√	√	√	√	×	ACT0291,ACT0206,ACT0039	×	×	×

GLB/B/ GLA- Class	247	Seats and Doors	DCU LR-Left rear door	√	√	√	√	×	ACT0360,ACT0361,ACT0362, ACT0363,ACT0347,ACT0364, ACT0365,ACT0366	SP1080,SP1147,SP1148	×	×
GLB/B/ GLA- Class	247	Seats and Doors	DCU RF-Right front door	√	√	√	√	×	ACT0353,ACT0274,ACT0273, ACT0354,ACT0283,ACT0284, ACT0281,ACT0282,ACT0355, ACT0278,ACT0356,ACT0357, ACT0347,ACT0279,ACT0348, ACT0349,ACT0358,ACT0359,	SP1080,SP1147,SP1148	×	×
GLB/B/ GLA- Class	247	Seats and Doors	DCU RR-Right rear door	√	√	√	√	×	ACT0367,ACT0368,ACT0369, ACT0370,ACT0347,ACT0371, ACT0365,ACT0366	SP1080,SP1147,SP1148	×	×
GLB/B/ GLA- Class	247	Seats and Doors	ESA Front passenger-Electric seat adjustment Front passenger	√	√	√	√	×	ACT0230,ACT0378,ACT0234, ACT0379,ACT0233,ACT0380, ACT0381,ACT0382	SP1075	×	×
GLB/B/ GLA- Class	247	Seats and Doors	ESV Driver-Electric seat adjustment Driver	√	√	√	√	×	ACT0214,ACT0373,ACT0218, ACT0374,ACT0217,ACT0375, ACT0376,ACT0377	SP1075	×	×
GLB/B/ GLA- Class	247	Seats and Doors	HKS-Tailgate control	√	√	√	√	×	×	×	×	×
GLB/B/ GLA- Class	247	Seats and Doors	LFD-Left front door	√	√	√	√	×	ACT0342,ACT0255,ACT0254, ACT0343,ACT0269,ACT0270, ACT0267,ACT0268,ACT0344, ACT0261,ACT0345,ACT0346, ACT0347,ACT0263,ACT0348, ACT0349,ACT0350,ACT0351,	SP1080,SP1147,SP1148	×	×
GLB/B/ GLA- Class	247	Seats and Doors	MKS LF-Left front multicontour seat	√	√	√	√	×	ACT0383,ACT0384,ACT0385, ACT0386,ACT0387,ACT0388	×	×	×
GLB/B/ GLA- Class	247	Seats and Doors	MKS RF-Right front multicontour seat	√	√	√	√	×	ACT0383,ACT0384,ACT0385, ACT0386,ACT0387,ACT0388	×	×	×
GLB/B/ GLA- Class	247	Seats and Doors	MKS-BFS-Front passenger more copy the seat	√	√	√	√	×	ACT0383,ACT0384,ACT0386	×	×	×
GLB/B/ GLA- Class	247	Seats and Doors	MKS-FS-Pilot multi-profile seat	√	√	√	√	×	ACT0383,ACT0384,ACT0386	×	×	×
GLB/B/ GLA- Class	247	Seats and Doors	S22 (Driver's door seat adjustment switch)	√	√	√	√	×	×	×	×	×
GLB/B/ GLA- Class	247	Seats and Doors	S23 (Front passenger door seat adjustment switch)	√	√	√	√	×	×	×	×	×
GLB/B/ GLA- Class	247	Seats and Doors	S47/2 (Driver door switch module)	√	√	√	√	×	×	×	×	×
GLB/B/ GLA- Class	247	Seats and Doors	S47/3 (Front passenger door switch module)	√	√	√	√	×	×	×	×	×
GLB/B/ GLA- Class	247	Seats and Doors	S51/1 (Driver seat climate control switch group)	√	√	√	√	×	×	×	×	×
GLB/B/ GLA- Class	247	Seats and Doors	S51/2 (Front passenger seat climate control switch group)	√	√	√	√	×	×	×	×	×
GLC-	253	Air conditioning	AAC-Automatic air conditioning	√	√	√	×	×	×	×	×	×
GLC-	253	Air conditioning	AAC-Automatic air conditioning	√	√	√	×	×	×	×	×	×
GLC-	253	Air conditioning	AAC-Automatic air conditioning	√	√	√	×	×	×	×	×	×

GLC-Class	253	Air conditioning	AAC-Automatic air conditioning	√	√	√	√	×	ACT0182,ACT0417,ACT0183,ACT0771,ACT0772,ACT0204,ACT0773,ACT0003,ACT0186,ACT0190,ACT0665,ACT0774,ACT0189,ACT0775,ACT0776,ACT0188,ACT0777,ACT0778,ACT0779,ACT0663,ACT0780,ACT0662,ACT0781,ACT0782,ACT0783,ACT0784,ACT0785,ACT0786,ACT0787,ACT0788,ACT0655,ACT0656,ACT0781,ACT0782,ACT0783,ACT0784,ACT0785,ACT0786,ACT0788,ACT0652,ACT0655,ACT0656,ACT0781,ACT0782,ACT0786,ACT0787,ACT0789,ACT0790,ACT0781,ACT0782,ACT0783,ACT0784,ACT0785,ACT0786,ACT0788,ACT0652,ACT0655,ACT0656,ACT0781,ACT0782,ACT0786,ACT0787,ACT0789,ACT0790,ACT0194,ACT0647,ACT0648,ACT0649,ACT0650,ACT0653,ACT0654,ACT0791,ACT0792,ACT0793,ACT0794,	SP1066,SP1065,SP1067,SP1360,SP1159	×	×
GLC-Class	253	Air conditioning	STH-Stationary heater	√	√	√	√	×	ACT0201,ACT1030,ACT0202,ACT1118	×	×	×
GLC-Class	253	Air conditioning	STH-Stationary heater	√	√	√	√	×	ACT1030,ACT0202,ACT1118	×	×	×
GLC-Class	253	Air conditioning	TSTH-Radio remote control of stationary heater	√	√	√	√	×	ACT0203,ACT0418	×	×	×
GLC-Class	253	Body	"Driver" seat heater	√	√	√	√	×	ACT0411,ACT0412,ACT0413,ACT0414,ACT0415	SP1157,SP1158	×	×
GLC-Class	253	Body	"Front passenger" seat heater	√	√	√	√	×	×	×	×	×
GLC-Class	253	Body	AML-Ambiance light	√	√	√	√	×	ACT0389,ACT0390,ACT0391,ACT0392,ACT0393,ACT0394,ACT0395,ACT0396,ACT0043	SP1149	×	×
GLC-Class	253	Body	AML-Active engine mount	√	√	√	√	×	×	×	×	×
GLC-Class	253	Body	AMLAB-L (Actuation module, LED exterior lighting, left front)	√	√	√	√	×	×	×	×	×
GLC-Class	253	Body	AMLAB-L (Actuation module, LED exterior lighting, left front)	√	√	√	√	×	ACT0299,ACT0300	SP1448	×	×
GLC-Class	253	Body	AMLAB-R (Actuation module, LED exterior lighting, right front)	√	√	√	√	×	×	×	×	×
GLC-Class	253	Body	AMLAB-R (Actuation module, LED exterior lighting, right front)	√	√	√	√	×	ACT0299,ACT0300	SP1447	×	×
GLC-Class	253	Body	Anti glare interior rearview mirror(DBE)	√	√	√	√	×	×	×	×	×
GLC-Class	253	Body	Anti glare interior rearview mirror(SAM)	√	√	√	√	×	×	×	×	×
GLC-Class	253	Body	AS-Alarm siren(H3/1)	√	√	√	√	×	ACT0309,ACT0465,ACT0466	×	×	×
GLC-Class	253	Body	ATA-ATA[EDW]/tow-away protection/interior protection	√	√	√	√	×	ACT0075,ACT0465	×	×	×
GLC-Class	253	Body	BMS-Battery management system	√	√	√	√	×	ACT0453,ACT0454,ACT0455	SP1197	×	×
GLC-Class	253	Body	BMS-Battery management system	√	√	√	√	×	ACT0778,ACT1120	SP1386,SP1193	×	×

GLC-Class	253	Body	BMS-Battery management system	√	√	√	√	×	ACT1121,ACT0453,ACT0410,ACT0604	SP1197	×	×
GLC-	253	Body	BSN-Battery sensor(B95)	√	√	√	√	×	×	×	×	×
GLC-	253	Body	BSN-Battery sensor(B95)	√	√	√	√	×	×	×	×	×
GLC-Class	253	Body	Button group, instrument panel, driver side	√	√	√	√	×	×	×	×	×
GLC-Class	253	Body	CSHVB-Crash sensor high-voltage battery	√	√	√	√	×	×	SP1494	×	×
GLC-	253	Body	DC/DC-DC/DC converter	√	√	√	√	×	×	×	×	×
GLC-	253	Body	DC/DC-DC/DC converter	√	√	√	√	×	×	SP1324	×	×
GLC-Class	253	Body	ESA Front passenger-Electric seat adjustment Front passenger	√	√	√	√	×	×	×	×	×
GLC-Class	253	Body	ESV Driver-Electric seat adjustmnet Driver	√	√	√	√	×	×	×	×	×
GLC-	253	Body	EZS-Electronic ignition lock	√	√	√	√	×	×	×	×	×
GLC-	253	Body	EZS-Electronic ignition lock	√	√	√	√	×	ACT1054	×	×	×
GLC-	253	Body	FSW-Windshield wiper	√	√	√	√	×	×	×	×	×
GLC-	253	Body	GES-Hand motion sensor	√	√	√	√	×	×	×	×	×
GLC-	253	Body	GTO-Garage door	√	√	√	√	×	×	×	×	×
GLC-	253	Body	GTO-Garage door	√	√	√	√	×	×	×	×	×
GLC-	253	Body	KG-Keyless Go	√	√	√	√	×	ACT0131,ACT0132	×	×	×
GLC-	253	Body	KG-Keyless Go	√	√	√	√	×	ACT0131,ACT0132	×	×	×
GLC-	253	Body	LIB-Lithium ion battery	√	√	√	√	×	×	×	×	×
GLC-	253	Body	LIB-Lithium ion battery	√	√	√	√	×	×	×	×	×
GLC-	253	Body	LIB-Lithium ion battery	√	√	√	√	×	×	×	×	×
GLC-	253	Body	LRE-Steering wheel electronics	√	√	√	√	×	×	×	×	×
GLC-Class	253	Body	Multifunction control unit-Multifunction control unit	√	√	√	√	×	×	×	×	×
GLC-Class	253	Body	Multifunction control unit-Multifunction control unit	√	√	√	√	×	ACT0204	×	×	×
GLC-Class	253	Body	N25/6 (Rear passenger compartment seat heater control	√	√	√	√	×	×	×	×	×
GLC-	253	Body	N38 (Rear switching module)	√	√	√	√	×	×	×	×	×
GLC-Class	253	Body	OCP-Overhead control panel	√	√	√	√	×	ACT1093,ACT0302,ACT1094,ACT0303,ACT0304,ACT1112	×	×	×
GLC-Class	253	Body	OCP-Overhead control panel	√	√	√	√	×	ACT1093,ACT1094,ACT0303,ACT0302,ACT1095,ACT1096,ACT1097,ACT1098,ACT1099,ACT0465,ACT1100	SP1441	×	×
GLC-Class	253	Body	PSD-Control module Panoramic sliding roof	√	√	√	√	×	ACT0207,ACT1091,ACT1092	SP1072	×	×
GLC-	253	Body	PSD-Panoramic sliding roof	√	√	√	√	×	×	×	×	×
GLC-	253	Body	PSD-Panoramic sliding roof	√	√	√	√	×	×	SP1072	×	×
GLC-Class	253	Body	RevETR LF-Left front reversible emergency tensioning retractor	√	√	√	√	×	ACT0209	×	×	×
GLC-Class	253	Body	RevETR RF-Right front reversible emergency tensioning	√	√	√	√	×	ACT0213	×	×	×
GLC-	253	Body	RGLS-Rain/light sensor(B38/2)	√	√	√	√	×	×	×	×	×
GLC-	253	Body	RGLS-Rain/light sensor(B38/2)	√	√	√	√	×	×	×	×	×

GLC-Class	253	Body	SAMF-Front signal acquisition and actuation module(N10/6)	√	√	√	√	×	ACT0729,ACT0730,ACT0731,ACT0732,ACT0344,ACT0507,ACT0733,ACT0675,ACT0734,ACT0676,ACT0735,ACT0736,ACT0737,ACT0738,ACT0465,ACT0739,ACT0740,ACT0741,ACT0742,ACT0743,ACT0744,	×	×	×
GLC-Class	253	Body	SAMF-Front signal acquisition and actuation module(N10/6)	√	√	√	√	×	ACT1066,ACT1067,ACT1068,ACT0729,ACT0730,ACT0344,ACT0507,ACT0734,ACT0733,ACT0675,ACT0676,ACT0735,ACT1069,ACT1070,ACT1071,ACT1072,ACT0909,ACT0465,	×	×	×
GLC-Class	253	Body	SAMR-Rear signal acquisition and actuation module(N10/8)	√	√	√	√	×	ACT0747,ACT0240,ACT0748,ACT0749,ACT0750,ACT0731,ACT0751,ACT0752,ACT0753,ACT0754,ACT0755,ACT0756,ACT0757,ACT0758,ACT0759,ACT0760,ACT0761,ACT0762,ACT0763,ACT0764,ACT0765,ACT0766,ACT0767,ACT0768,	×	×	×
GLC-Class	253	Body	SAMR-Rear signal acquisition and actuation module(N10/8)	√	√	√	√	×	ACT0747,ACT1073,ACT0240,ACT1074,ACT1075,ACT0891,ACT0890,ACT0751,ACT0752,ACT0754,ACT1076,ACT1077,ACT1078,ACT1079,ACT1080,ACT1081,ACT0761,ACT1082,ACT0760,ACT1083,ACT0768,ACT0765,ACT1084,ACT1085,ACT0908,ACT0769,ACT0802,	×	×	×
GLC-Class	253	Body	SCM-Steering column module(N80)	√	√	√	√	×	ACT0060,ACT0061,ACT0062,ACT0063,ACT0064,ACT0065	×	×	×
GLC-Class	253	Body	SCM-Steering column module(N80)	√	√	√	√	×	ACT0060,ACT0061,ACT0062,ACT0063,ACT0064,ACT0065	×	×	×
GLC-	253	Body	SG FOND-Rear control unit	√	√	√	√	×	×	×	×	×
GLC-Class	253	Body	SG LG-Charger	√	√	√	√	×	ACT0405,ACT0406,ACT0407,ACT0408,ACT0409,ACT0410	×	×	×
GLC-Class	253	Body	SG LG-Charger	√	√	√	√	×	ACT0405,ACT0406,ACT0407,ACT0408,ACT0611,ACT0410	×	×	×
GLC-Class	253	Body	SG LML VL-LED matrix of left front lamp unit	√	√	√	√	×	ACT0299,ACT0815,ACT0816,ACT0300	SP1089,SP1361	×	×
GLC-	253	Body	SG SW L-Left headlamp	√	√	√	√	×	×	×	×	×
GLC-	253	Body	SG SW L-Left headlamp	√	√	√	√	×	×	×	×	×
GLC-Class	253	Body	SG SW L-Left headlamp	√	√	√	√	×	ACT0292,ACT0293,ACT0297,ACT0298,ACT0299,ACT0300	SP1445,SP1088,SP1089,SP1090,SP1094	×	×
GLC-	253	Body	SG SW R-Right headlamp	√	√	√	√	×	×	×	×	×
GLC-	253	Body	SG SW R-Right headlamp	√	√	√	√	×	×	×	×	×
GLC-Class	253	Body	SG SW R-Right headlamp	√	√	√	√	×	ACT0292,ACT0293,ACT0297,ACT0298,ACT0299,ACT0300	SP1362,SP1096,SP1097	×	×
GLC-Class	253	Body	SG-LML-VR-LED matrix of right front lamp unit	√	√	√	√	×	ACT0299,ACT0815,ACT0300,ACT0816	SP1362,SP1363	×	×

GLC-Class	253	Body	SOGESTAR2-Sound generator for electric vehicle	√	√	√	√	×	×	×	×	×
GLC-	253	Body	SRS-Supplemental restraint	√	√	√	√	×	×	×	×	×
GLC-	253	Body	SRS-Supplemental restraint	√	√	√	√	√	×	×	×	×
GLC-	253	Body	STM-Mirror taximeter	√	√	√	√	×	×	×	×	×
GLC-Class	253	Body	Trailer recognition module-Trailer recognition	√	√	√	√	×	×	×	×	×
GLC-	253	Body	WSS-Weight sensing	√	√	√	√	×	×	×	×	×
GLC-	253	Chassis	ADS-Adaptive damping system	√	√	√	√	×	×	SP1061,SP1339	×	×
GLC-Class	253	Chassis	ADS-Adaptive damping system(N51/5)	√	√	√	√	×	ACT0628,ACT1119,ACT0631,ACT0630,ACT0632,ACT0633,ACT0634,ACT0635,ACT0167,ACT0168,ACT0169,ACT0170,ACT0636,ACT0637,ACT0639,	SP1061,SP1339	×	×
GLC-	253	Chassis	AIRmatic-AIRmatic PLUS	√	√	√	√	×	×	×	×	×
GLC-Class	253	Chassis	AMG DRVU-AMG DRIVE UNIT	√	√	√	√	×	ACT0401,ACT0402,ACT0403,ACT0404	SP1153,SP1154,SP1155	×	×
GLC-	253	Chassis	AMG DRVU-AMG DRIVE	√	√	√	×	×	ACT1109	×	×	×
GLC-Class	253	Chassis	EFB-Electric parking brake	√	√	√	√	×	ACT0285,ACT0286,ACT0287,ACT0288	SP1081	×	×
GLC-Class	253	Chassis	ELC-Electronic level control	√	√	√	√	×	ACT0631,ACT0630,ACT1160,ACT1161,ACT1162,ACT1163,ACT0638,ACT0639	SP1061	×	×
GLC-	253	Chassis	ES - Electric power steering	√	√	√	√	×	×	SP1071	×	×
GLC-	253	Chassis	ES - Electric power steering	√	√	√	√	×	×	SP1071,SP1167	×	×
GLC-	253	Chassis	ESP-Electric stability	√	√	√	√	√	ACT0069,ACT0070	SP1450,SP1456,SP1457	×	×
GLC-Class	253	Chassis	ESP-Electric stability program(N30/4)	√	√	√	√	√	ACT0069,ACT0070,ACT0285,ACT0286,ACT0287,ACT0288	SP1174,SP1176,SP1178,SP1183	×	×
GLC-Class	253	Chassis	ESP-Electric stability program(N30/4)	√	√	√	√	√	ACT0069,ACT0070,ACT0612,ACT0285,ACT0288	SP1051,SP1330,SP1450,SP1451,SP1452,SP1453,SP1179,SP1181,SP1454,SP1455,SP1367	×	×
GLC-Class	253	Chassis	ESP-Electric stability program(N30/4)	√	√	√	√	√	ACT0069,ACT0070,ACT0863,ACT0285,ACT0286,ACT0287,ACT0288	SP1174,SP1175,SP1176,SP1177,SP1178,SP1179,SP1366,SP1181,SP1367,	×	×
GLC-	253	Drive	EAGGS-Electric differential lock	√	√	√	√	×	ACT0814	SP1155	×	×
GLC-	253	Drive	Exhaust air turbocharger	√	√	√	√	×	×	×	×	×
GLC-	253	Drive	FSCU-Control unit Fuel pump	√	√	√	√	×	ACT0252,ACT0320	×	×	×
GLC-	253	Drive	Fuel cell management system	√	√	√	√	×	×	×	×	×
GLC-	253	Drive	Fuel cell stack	√	√	√	√	×	×	×	×	×
GLC-	253	Drive	Fuel tank	√	√	√	√	×	×	×	×	×
GLC-Class	253	Drive	HFPM-Haptic accelerator pedal module	√	√	√	√	×	ACT1110,ACT1111	×	×	×
GLC-	253	Drive	ISG-Integrated starter alternator	√	√	√	√	×	×	×	×	×
GLC-	253	Drive	ISG-Integrated starter alternator	√	√	√	√	×	×	SP1368	×	×
GLC-	253	Drive	ISM-Shift module	√	√	√	√	×	ACT0670,ACT0671,ACT0318	SP1345,SP1346,SP1446	×	×

GLC-Class	253	Drive	N127 (Drivetrain control unit)	√	√	√	√	×	ACT0028,ACT0430,ACT0431,ACT0432,ACT0433,ACT0007,ACT0434,ACT0435,ACT0436,ACT0437,ACT0438,ACT0439,ACT0440,ACT0441,ACT0442,ACT0443,ACT0444,ACT0445,ACT0446,ACT0447,ACT0448,	SP1186,SP1042,SP1025,SP1187,SP1188,SP1189,SP1190,SP1191,SP1192	×	×
GLC-Class	253	Drive	N127 (Drivetrain control unit)	√	√	√	√	×	ACT0038,ACT0028,ACT0441,ACT0440,ACT0007,ACT0434,ACT0436,ACT0431,ACT0439,ACT0438,ACT0434,ACT0437	SP1382	×	×
GLC-Class	253	Drive	N127 (Drivetrain control unit)	√	√	√	√	×	ACT1244,ACT1245,ACT1246,ACT0028,ACT1247,ACT1248,ACT1249,ACT0995,ACT1250,ACT1251,ACT1252,ACT1253,ACT1254,ACT1239,ACT1255,	SP1495,SP1496,SP1497,SP1498,SP1499,SP1500,SP1501	×	×
GLC-Class	253	Drive	N3/10-Motor electronics "MED177" for combustion engine "M276"	√	√	√	√	√	ACT0005,ACT0002,ACT0003,ACT0335,ACT0480,ACT0463,ACT0705,ACT0464,ACT0706,ACT0325,ACT0326,ACT0025,ACT0016,ACT0707,ACT0708,ACT0017,ACT0441,ACT0709,	SP1108,SP1109,SP1017,SP1110,SP1115,SP1001,SP1459,SP1202,SP1113,SP1004,SP1352,SP1000	×	×
GLC-Class	253	Drive	N3/10-Motor electronics "MED1775" for combustion engine "M178"	√	√	√	√	√	ACT0002,ACT0028,ACT0431,ACT0432,ACT0433,ACT0864,ACT0865,ACT0435,ACT0480,ACT0476,ACT0475,ACT0478,ACT0477,ACT0326,ACT0866,ACT0867,ACT0436,ACT0025,ACT0868,ACT0712,ACT0713,	SP1017,SP1109,SP1110,SP1369,SP1370,SP1371,SP1112,SP1202,SP1203,SP1001,SP1187,SP1372,SP1201,SP1000	×	×
GLC-Class	253	Drive	N3/10-Motor electronics "MED177V6LA" for combustion engine "M276Turbocharger"	√	√	√	√	√	ACT0005,ACT0002,ACT0003,ACT0335,ACT0480,ACT0463,ACT0705,ACT0464,ACT0706,ACT0325,ACT0326,ACT0025,ACT0016,ACT0017,ACT0441,ACT0709,ACT0022,ACT0712,	SP1109,SP1110,SP1108,SP1017,SP1369,SP1371,SP1370,SP1112,SP1203,SP1202,SP1113,SP1352,SP1004,SP1001,SP1201,SP1000	×	×
GLC-Class	253	Drive	N3/10-Motor electronics "MED40" for combustion engine "M274"	√	√	√	√	√	ACT0002,ACT0005,ACT0460,ACT0322,ACT0323,ACT0324,ACT0325,ACT0326,ACT0025,ACT0327,ACT0328,ACT0329,ACT0022,ACT0024,ACT0330,ACT0331,ACT0332,ACT0333,	SP1017,SP1004,SP1000	×	×
GLC-Class	253	Drive	N3/10-Motor electronics "MED41" for combustion engine "M260/M264"	√	√	√	√	√	ACT0330,ACT0003,ACT0459,ACT0323,ACT0324,ACT0333,ACT0025,ACT0328,ACT0331,ACT0332,ACT0004,ACT0005,ACT0456,ACT0002,ACT0460,ACT0329,ACT0022,ACT0325,	SP1199,SP1117	×	×
GLC-Class	253	Drive	N3/9-Motor electronics "CR43" for combustion engine "OM651"	√	√	√	√	×	ACT0026,ACT0000,ACT0589,ACT0330,ACT0005,ACT0003,ACT0008,ACT0011,ACT0010,ACT0022,ACT0012,ACT0016,ACT0017,ACT0018,ACT0019,	SP1000,SP1001,SP1003,SP1004,SP1410,SP1290,SP1291,SP1123,SP1292,SP1293,SP1294,SP1012,SP1013,SP1144,SP1015,	×	×

GLC-Class	253	Drive	SCR-Selective catalytic reduction	√	√	√	√	×	ACT0424,ACT0425,ACT0426,ACT0427,ACT0428,ACT0429	SP1184,SP1185	×	×
GLC-Class	253	Drive	SCR-Selective catalytic reduction	√	√	√	√	×	ACT0424,ACT0602,ACT0425,ACT0426,ACT0427,ACT0598	SP1185,SP1322,SP1184,SP1319,SP1318,SP1023	×	×
GLC-Class	253	Drive	SG EM-Power electronics	√	√	√	√	×	ACT0451,ACT0452	SP1193,SP1194,SP1195,SP1196,SP1150	×	×
GLC-	253	Drive	SG EM-Power electronics	√	√	√	√	×	ACT0451,ACT0452,ACT1237	×	×	×
GLC-	253	Drive	SG EM-Power electronics	√	√	√	√	×	ACT1226	SP1193,SP1323,SP1324	×	×
GLC-	253	Drive	VG-All-wheel drive	√	√	√	√	×	ACT0422,ACT0423	SP1099,SP1170	×	×
GLC-	253	Drive	Voltage converter of fuel cell	√	√	√	√	×	×	×	×	×
GLC-Class	253	Drive	Y3/8n4-Fully integrated transmission control	√	√	√	√	√	ACT0592,ACT0318	SP1299,SP1300,SP1301,SP1302,SP1303,SP1304,SP1233,SP1305,SP1306,SP1306,SP1307,SP1308,SP1309,SP1002,SP1310,	×	×
GLC-Class	253	Drive	Y3/8n4-Transmission control for 9 speed transmission	√	√	√	√	√	ACT0592,ACT0312,ACT0593,ACT0714,ACT0317	SP1311,SP1315,SP1316,SP1305,SP1355,SP1312,SP1356,SP1300,SP1357,SP1358,SP1359,SP1317	×	×
GLC-Class	253	Driver assistance system	CAMERA-360 camera(N148)	√	√	√	√	×	×	SP1205,SP1206,SP1207,SP1208,SP1209	×	×
GLC-	253	Driver assistance	DTR-DISTRONIC	√	√	√	√	×	×	×	×	×
GLC-	253	Driver assistance	DTR-DISTRONIC	√	√	√	√	×	×	SP1161,SP1162	×	×
GLC-	253	Driver assistance	DTR-DISTRONIC(B29)	√	√	√	√	×	×	SP1079	×	×
GLC-Class	253	Driver assistance system	IRS HLA-Outer left rear integrated radar sensor (B92/11)	√	√	√	√	×	×	SP1150,SP1151	×	×
GLC-Class	253	Driver assistance system	IRS HLA-Outer left rear intelligent radar sensor system	√	√	√	√	×	×	×	×	×
GLC-Class	253	Driver assistance system	IRS HRA-Outer right rear integrated radar sensor (B92/6)	√	√	√	√	×	×	SP1150,SP1151	×	×
GLC-Class	253	Driver assistance system	IRS HRA-Outer right rear intelligent radar sensor system	√	√	√	√	×	×	×	×	×
GLC-	253	Driver assistance	KAB-Control unit Camera cover	√	√	√	√	×	ACT0310,ACT0311	×	×	×
GLC-	253	Driver assistance	KAR-Augmented reality camera	√	√	√	√	×	×	×	×	×
GLC-Class	253	Driver assistance system	MFK-Multifunction camera(mono)(A40/11)	√	√	√	√	×	ACT0181,ACT0065	SP1063	×	×
GLC-Class	253	Driver assistance system	MFK-Multifunction camera(mono)(A40/11)	√	√	√	√	×	ACT0181,ACT0065	SP1156	×	×
GLC-Class	253	Driver assistance system	MFK-Multifunction camera(stereo)(A40/13)	√	√	√	√	×	ACT0181,ACT0065	SP1063	×	×
GLC-Class	253	Driver assistance system	MFK-Multifunction camera(stereo)(A40/13)	√	√	√	√	×	ACT0181,ACT0065	SP1063	×	×
GLC-	253	Driver assistance	NBR LR-Left rear short-range	√	√	√	√	×	×	SP1173	×	×
GLC-	253	Driver assistance	NBR RR-Right rear short-range	√	√	√	√	×	×	SP1172	×	×
GLC-	253	Driver assistance	PARK-Parking system (N62)	√	√	√	√	×	ACT0306	×	×	×
GLC-	253	Driver assistance	PTS-PARKTRONIC	√	√	√	√	×	ACT0421,ACT0306	SP1166	×	×
GLC-	253	Driver assistance	RFK-Backup camera	√	√	√	√	×	×	×	×	×
GLC-	253	Driver assistance	RFK-Backup camera	√	√	√	√	×	×	SP1152	×	×
GLC-Class	253	Driver assistance system	SG AWF-COLLISION PREVENTION ASSIST	√	√	√	√	×	×	SP1063	×	×
GLC-Class	253	Driver assistance system	SG AWF-Control unit COLLISION PREVENTION	√	√	√	√	×	×	SP1059	×	×

GLC-Class	253	Driver assistance system	SG AWF-Control unit COLLISION PREVENTION	√	√	√	√	×	×	SP1063	×	×
GLC-Class	253	Driver assistance system	SGR-Radar sensors control unit	√	√	√	√	×	ACT0419,ACT0420	SP1163,SP1164,SP1165	×	×
GLC-Class	253	Driver assistance system	SGR-Radar sensors control unit(N62/1)	√	√	√	√	×	×	SP1163,SP1164,SP1449	×	×
GLC-Class	253	Driver assistance system	TPM-Tire pressure monitor(N88)	√	√	√	√	×	ACT0078,ACT0079,ACT0081,ACT0080	SP1053	×	×
GLC-Class	253	Information and communication	Audio-Audio or COMAND	√	√	√	×	×	×	×	×	×
GLC-Class	253	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√	×	×	×	×	×
GLC-Class	253	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√	×	×	×	×	×
GLC-Class	253	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√	×	×	×	×	×
GLC-Class	253	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√	×	×	×	×	×
GLC-Class	253	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√	×	×	×	×	×
GLC-Class	253	Information and communication	COU[ZBE]-Audio/COMAND operating unit	√	√	√	√	×	ACT0289,ACT0041	SP1199	×	×
GLC-Class	253	Information and communication	CSM-Windshield reader system	√	√	√	√	×	×	×	×	×
GLC-Class	253	Information and communication	CTEL-Cellular telephone	√	√	√	√	×	×	×	×	×
GLC-Class	253	Information and communication	DAB-Digital radio Tuner unit	√	√	√	√	×	ACT0198,ACT0087,ACT0199,ACT0039	×	×	×
GLC-Class	253	Information and communication	HERMES-control unit for telematics services	√	√	√	√	×	×	SP1046	×	×
GLC-Class	253	Information and communication	HUD-Head up display	√	√	√	√	×	ACT0210,ACT0212	×	×	×
GLC-Class	253	Information and communication	IC-Instrument cluster	√	√	√	√	×	ACT0397,ACT0048,ACT0210,ACT0398,ACT0399,ACT0947,ACT0050,ACT0400	SP1043,SP1044,SP1045,SP1381	×	×
GLC-Class	253	Information and communication	IC-Instrument cluster(A1)	√	√	√	√	×	ACT0397,ACT0048,ACT0210,ACT0398,ACT0399,ACT0050,ACT0400,ACT0039	SP1043,SP1044,SP1045	×	×
GLC-Class	253	Information and communication	KOMO/mbrace-Communication module 'Telematics services'/Notrufsystem	√	√	√	√	×	ACT0051,ACT0039,ACT0043,ACT0040,ACT0052,ACT0053,ACT0054,ACT0055,ACT0056,	×	×	×
GLC-Class	253	Information and communication	LCP-Lower control panel	√	√	√	×	×	×	×	×	×
GLC-Class	253	Information and communication	mbrace-mbrace	√	√	√	√	×	ACT0039,ACT0040,ACT0041,ACT0042,ACT0043,ACT0044	×	×	×
GLC-Class	253	Information and communication	mbrace-mbrace	√	√	√	√	×	ACT0043,ACT0058,ACT0059,ACT0039	×	×	×
GLC-Class	253	Information and communication	MTAS-Mobile phone cradle	√	√	√	√	×	×	×	×	×
GLC-Class	253	Information and communication	MTAS-Mobile phone cradle	√	√	√	√	×	×	×	×	×
GLC-Class	253	Information and communication	N72/1 (Upper control panel control unit)	√	√	√	×	×	×	×	×	×

GLC-Class	253	Information and communication	N72/4 (Left lower control panel)	√	√	√	×	×	×	×	×	×
GLC-Class	253	Information and communication	N72/4 (Left lower control panel)	√	√	√	×	×	×	×	×	×
GLC-Class	253	Information and communication	SG MSND-Engine sound	√	√	√	√	×	ACT0043,ACT0044,ACT0082,ACT0130	×	×	×
GLC-Class	253	Information and communication	SOUND-Sound system	√	√	√	√	×	×	×	×	×
GLC-Class	253	Information and communication	SOUND-Sound system	√	√	√	√	×	×	×	×	×
GLC-Class	253	Information and communication	SOUND-Sound system	√	√	√	√	×	×	×	×	×
GLC-Class	253	Information and communication	TPAD-Touchpad	√	√	√	√	×	×	×	×	×
GLC-Class	253	Information and communication	TPAD-Touchpad	√	√	√	√	×	×	×	×	×
GLC-Class	253	Information and communication	TPAD-Touchpad	√	√	√	√	×	×	×	×	×
GLC-Class	253	Information and communication	TV tuner (TV)	√	√	√	√	×	×	×	×	×
GLC-Class	253	Information and communication	TV tuner (TV)	√	√	√	√	×	×	×	×	×
GLC-Class	253	Information and communication	TV tuner (TV)	√	√	√	√	×	×	×	×	×
GLC-Class	253	Information and communication	TV tuner (TV)	√	√	√	√	×	×	×	×	×
GLC-Class	253	Information and communication	ZAN-Audio/COMAND display	√	√	√	√	×	ACT0206,ACT0946,ACT0291,ACT0039	×	×	×
GLC-Class	253	Information and communication	ZAN-Audio/COMAND display	√	√	√	√	×	ACT0291,ACT0206,ACT0039	×	×	×
GLC-Class	253	Seats and Doors	DCU LR-Left rear door	√	√	√	√	×	ACT0360,ACT0361,ACT0362,ACT0363,ACT0723,ACT0688,ACT0347,ACT0364,ACT0724,ACT0366,ACT0725	SP1080,SP1147,SP1148	×	×
GLC-Class	253	Seats and Doors	DCU LR-Left rear door	√	√	√	√	×	ACT0687,ACT0686,ACT1060,ACT0688,ACT1061,ACT0362,ACT0363,ACT0723,ACT0360,ACT0361,ACT0271,ACT0725	SP1080	×	×
GLC-Class	253	Seats and Doors	DCU RF-Right front door	√	√	√	√	×	ACT0272,ACT0273,ACT0274,ACT0256,ACT0275,ACT0277,ACT0276,ACT1058,ACT0278,ACT0279,ACT0357,ACT1056,ACT0349,ACT1059,ACT0348,ACT0281,ACT0282,ACT0258,ACT0283,ACT0284,ACT0271,	SP1080	×	×
GLC-Class	253	Seats and Doors	DCU RF-Right front door	√	√	√	√	×	ACT0353,ACT0274,ACT0273,ACT0354,ACT0720,ACT0283,ACT0284,ACT0281,ACT0282,ACT0721,ACT0355,ACT0278,ACT0356,ACT0357,ACT0347,ACT0279,ACT0348,ACT0349,ACT0358,ACT0359,ACT0722,	SP1080,SP1147,SP1148	×	×

GLC-Class	253	Seats and Doors	DCU RR-Right rear door	√	√	√	√	×	ACT0367,ACT0368,ACT0369,ACT0370,ACT0726,ACT0692,ACT0347,ACT0371,ACT0365,ACT0727,ACT0728,ACT0366	SP1080,SP1147,SP1148	×	×
GLC-Class	253	Seats and Doors	DCU RR-Right rear door	√	√	√	√	×	ACT0691,ACT0690,ACT1062,ACT0692,ACT1056,ACT1063,ACT0369,ACT0370,ACT0726,ACT0367,ACT0368,ACT0728,	SP1080	×	×
GLC-Class	253	Seats and Doors	ESA Front passenger-Electric seat adjustment Front passenger	√	√	√	√	×	×	×	×	×
GLC-Class	253	Seats and Doors	ESV Driver-Electric seat adjustmnet Driver	√	√	√	√	×	×	×	×	×
GLC-Class	253	Seats and Doors	ESV Driver-Electric seat adjustmnet Driver with memory function	√	√	√	√	×	ACT0214,ACT0373,ACT0218,ACT0374,ACT0217,ACT1064,ACT0375,ACT0376,ACT0377	SP1438,SP1075,SP1074	×	×
GLC-Class	253	Seats and Doors	ESV Front passenger-Electric seat adjustment Front passenger with memory function	√	√	√	√	×	ACT0230,ACT0378,ACT0234,ACT0379,ACT0233,ACT1065,ACT0380,ACT0381,ACT0382	SP1438,SP1075,SP1074	×	×
GLC-Class	253	Seats and Doors	HKS-Tailgate control	√	√	√	√	×	ACT1089,ACT1023,ACT0171,ACT0173	SP1440	×	×
GLC-	253	Seats and Doors	HKS-Tailgate control	√	√	√	√	×	ACT1089,ACT1090	SP1439	×	×
GLC-Class	253	Seats and Doors	LFD-Left front door	√	√	√	√	×	ACT0253,ACT0254,ACT0255,ACT0256,ACT0257,ACT0260,ACT0259,ACT1055,ACT0261,ACT0263,ACT0346,ACT1056,ACT0349,ACT1057,ACT0348,ACT0267,ACT0268,ACT0258,ACT0270,ACT0269,ACT0271,	SP1080	×	×
GLC-Class	253	Seats and Doors	LFD-Left front door	√	√	√	√	×	ACT0342,ACT0255,ACT0254,ACT0343,ACT0715,ACT0269,ACT0361,ACT0267,ACT0268,ACT0716,ACT0344,ACT0261,ACT0345,ACT0346,ACT0347,ACT0263,ACT0348,ACT0349,ACT0350,ACT0351,ACT0717,	SP1080,SP1147,SP1148	×	×
GLC-Class	253	Seats and Doors	MKS-BFS-Front passenger more copy the seat	√	√	√	√	×	ACT0383,ACT0384,ACT0386	×	×	×
GLC-	253	Seats and Doors	MKS-FS-Pilot multi-profile seat	√	√	√	√	×	ACT0383,ACT0384,ACT0386	×	×	×
GLC-Class	253	Seats and Doors	S22 (Driver"s door seat adjustment switch)	√	√	√	×	×	×	×	×	×
GLC-Class	253	Seats and Doors	S23 (Front passenger door seat adjustment switch)	√	√	√	×	×	×	×	×	×
GLC-	253	Seats and Doors	S47/2 (Driver door switch	√	√	√	×	×	×	×	×	×
GLC-Class	253	Seats and Doors	S47/3 (Front passenger door switch module)	√	√	√	×	×	×	×	×	×
GLC-Class	253	Seats and Doors	S51/1 (Driver"s door seat heating switch)	√	√	√	×	×	×	×	×	×
GLC-Class	253	Seats and Doors	S51/2 (Front passenger door seat heating switch)	√	√	√	×	×	×	×	×	×
GLC-	253	Seats and Doors	S51/3 (Left rear seat heater	√	√	√	×	×	×	×	×	×
GLC-	253	Seats and Doors	S51/4 (Right rear seat heater	√	√	√	×	×	×	×	×	×

GLS/GL E-Class	167	Air conditioning	AAC-Automatic air conditioning	√	√	√	×	×	×	×	×	×
GLS/GL E-Class	167	Air conditioning	AAC-Automatic air conditioning	√	√	√	×	×	×	×	×	×
GLS/GL E-Class	167	Air conditioning	AAC-Automatic air conditioning	√	√	√	√	×	×	×	×	×
GLS/GL E-Class	167	Air conditioning	AAC-Automatic air conditioning	√	√	√	√	×	ACT0182,ACT0417,ACT0183,ACT0771,ACT0772,ACT0204,ACT0773,ACT0003,ACT0186,ACT0190,ACT0665,ACT0774,ACT0189,ACT0775,ACT0776,ACT0188,ACT0777,ACT0778,ACT0779,ACT0663,ACT0780,ACT0662,ACT0781,ACT0782,ACT0783,ACT0784,ACT0785,ACT0786,ACT0787,ACT0788,ACT0655,ACT0656,ACT0781,ACT0782,ACT0783,ACT0784,ACT0785,ACT0786,ACT0787,ACT0788,ACT0789,ACT0790,ACT0781,ACT0782,ACT0783,ACT0784,ACT0785,ACT0786,ACT0788,ACT0652,ACT0655,ACT0656,ACT0781,ACT0782,ACT0786,ACT0787,ACT0789,ACT0790,ACT0194,ACT0647,ACT0648,ACT0649,ACT0650,ACT0653,ACT0654,ACT0791,ACT0792,ACT0793,ACT0794,	SP1066,SP1065,SP1067,SP1360,SP1159	×	×
GLS/GL E-Class	167	Air conditioning	AAC-Automatic air conditioning	√	√	√	√	×	ACT0416,ACT0182,ACT0417,ACT0186,ACT0194,ACT0195,ACT0197,ACT0196,ACT0028,	SP1065,SP1066,SP1067,SP1159,SP1160	×	×
GLS/GL E-Class	167	Air conditioning	N61 (Windshield heater control unit)	√	√	√	×	×	×	×	×	×
GLS/GL E-Class	167	Air conditioning	STH-Stationary heater	√	√	√	√	×	ACT0202	×	×	×
GLS/GL E-Class	167	Air conditioning	TSTH-Radio remote control of stationary heater	√	√	√	√	×	ACT0203,ACT0418	×	×	×
GLS/GL E-Class	167	Body	AGS-Active bell buckle	√	√	√	√	×	ACT0805,ACT0806,ACT0807,ACT0808	×	×	×
GLS/GL E-Class	167	Body	AML-Ambiance light	√	√	√	√	×	ACT0389,ACT0390,ACT0391,ACT0392,ACT0393,ACT0394,ACT0395,ACT0396,ACT0043	SP1149	×	×
GLS/GL E-Class	167	Body	AML-A-Active engine mount	√	√	√	√	×	×	×	×	×
GLS/GL E-Class	167	Body	Anti glare interior rearview mirror(DBE)	√	√	√	√	×	×	×	×	×
GLS/GL E-Class	167	Body	AS-Alarm siren(H3/1)	√	√	√	√	×	ACT0309,ACT0465,ACT0466	×	×	×
GLS/GL E-Class	167	Body	ATA-Interior motion sensor	√	√	√	√	×	×	×	×	×
GLS/GL E-Class	167	Body	BMS-Battery management system	√	√	√	√	×	ACT0453,ACT0454,ACT0455	SP1197	×	×

GLS/GL E-Class	167	Body	BSN-Battery sensor(B95)	√	√	√	√	×	×	×	×	×
GLS/GL E-Class	167	Body	DC/DC-DC/DC converter	√	√	√	√	×	×	×	×	×
GLS/GL E-Class	167	Body	DCCU-Direct current charge connection unit	√	√	√	√	×	×	×	×	×
GLS/GL E-Class	167	Body	EZS-Electronic ignition switch	√	√	√	√	×	ACT0372	×	×	×
GLS/GL E-Class	167	Body	FSW-Windshield wiper	√	√	√	√	×	×	×	×	×
GLS/GL E-Class	167	Body	GES-Hand motion sensor	√	√	√	√	×	×	×	×	×
GLS/GL E-Class	167	Body	GTO-Garage door opener(A67n2)	√	√	√	√	×	×	×	×	×
GLS/GL E-Class	167	Body	HE-Hand detection	√	√	√	√	×	×	×	×	×
GLS/GL E-Class	167	Body	LIB-Lithium ion battery	√	√	√	√	×	×	×	×	×
GLS/GL E-Class	167	Body	LIB-Lithium ion battery	√	√	√	√	×	×	×	×	×
GLS/GL E-Class	167	Body	LIB-Lithium ion battery	√	√	√	√	×	×	×	×	×
GLS/GL E-Class	167	Body	LRE-Steering wheel electronics	√	√	√	√	×	×	×	×	×
GLS/GL E-Class	167	Body	Multifunction control unit-Multifunction control unit	√	√	√	√	×	ACT0204	×	×	×
GLS/GL E-Class	167	Body	N25/6 (Rear passenger compartment seat heater control	√	√	√	√	×	×	×	×	×
GLS/GL E-Class	167	Body	N38 (Rear switching module)	√	√	√	√	×	×	×	×	×
GLS/GL E-Class	167	Body	N5 (Armrest heater control unit)	√	√	√	√	×	ACT0817,ACT0818,ACT0819,ACT0820,ACT0821,ACT0822,ACT0823,ACT0824,ACT0825,ACT0826,ACT0827,ACT0828,ACT0829,ACT0830,ACT0831,ACT0832,ACT0833,ACT0834,ACT0829,ACT0830,ACT0831,ACT0835,ACT0836,ACT0837,ACT0838,ACT0829,ACT0835,ACT0836,ACT0837,ACT0838,ACT0839,ACT0840,ACT0841,ACT0842,ACT0843,ACT0844,ACT0845,ACT0846,ACT0847,ACT0848,ACT0829,ACT0832,ACT0839,ACT0840,ACT0841,ACT0842,ACT0843,ACT0844,	SP1364,SP1365	×	×
GLS/GL E-Class	167	Body	OCP-Overhead control panel	√	√	√	√	×	×	×	×	×
GLS/GL E-Class	167	Body	PSD-Control module Panoramic sliding roof	√	√	√	√	×	×	×	×	×
GLS/GL E-Class	167	Body	PSD-Control module Panoramic sliding roof	√	√	√	√	×	×	×	×	×

GLS/GL E-Class	167	Body	PSD-Panoramic sliding roof	√	√	√	√	×	×	×	×	×
GLS/GL E-Class	167	Body	RevETR LF-Left front reversible emergency tensioning retractor	√	√	√	√	×	×	×	×	×
GLS/GL E-Class	167	Body	RevETR LF-Left front reversible emergency tensioning retractor	√	√	√	√	×	ACT0209	×	×	×
GLS/GL E-Class	167	Body	RevETR RF-Right front reversible emergency tensioning	√	√	√	√	×	×	×	×	×
GLS/GL E-Class	167	Body	RevETR RF-Right front reversible emergency tensioning	√	√	√	√	×	ACT0213	×	×	×
GLS/GL E-Class	167	Body	RGLS-Rain/light sensor(B38/2)	√	√	√	√	×	×	×	×	×
GLS/GL E-Class	167	Body	SAMF-Front signal acquisition and actuation module(N10/6)	√	√	√	√	×	ACT0729,ACT0730,ACT0731,ACT0732,ACT0344,ACT0507,ACT0733,ACT0675,ACT0734,ACT0676,ACT0735,ACT0736,ACT0737,ACT0738,ACT0465,ACT0739,ACT0740,ACT0741,ACT0742,ACT0743,ACT0744,	×	×	×
GLS/GL E-Class	167	Body	SAMR-Rear signal acquisition and actuation module(N10/8)	√	√	√	√	×	ACT0747,ACT0240,ACT0748,ACT0749,ACT0750,ACT0731,ACT0751,ACT0752,ACT0753,ACT0754,ACT0755,ACT0756,ACT0757,ACT0758,ACT0759,ACT0760,ACT0761,ACT0762,ACT0763,ACT0764,ACT0765,ACT0766,ACT0767,ACT0768,	×	×	×
GLS/GL E-Class	167	Body	SCM-Steering column module	√	√	√	√	×	×	×	×	×
GLS/GL E-Class	167	Body	SG LG-Charger	√	√	√	√	×	ACT0405,ACT0406,ACT0407,ACT0408,ACT0409,ACT0410	×	×	×
GLS/GL E-Class	167	Body	SG LML VL-LED matrix of left front lamp unit	√	√	√	√	×	ACT0299,ACT0815,ACT0816,ACT0300	SP1089,SP1361	×	×
GLS/GL E-Class	167	Body	SG SW L-Left headlamp	√	√	√	√	×	×	×	×	×
GLS/GL E-Class	167	Body	SG SW R-Right headlamp	√	√	√	√	×	×	×	×	×
GLS/GL E-Class	167	Body	SG-LML-VR-LED matrix of right front lamp unit	√	√	√	√	×	ACT0299,ACT0815,ACT0300,ACT0816	SP1362,SP1363	×	×
GLS/GL E-Class	167	Body	SOGESTAR2-Sound generator for electric vehicle	√	√	√	√	×	×	×	×	×
GLS/GL E-Class	167	Body	SRS-Supplemental restraint system	√	√	√	√	√	×	×	×	×
GLS/GL E-Class	167	Body	Trailer recognition module-Trailer recognition	√	√	√	√	×	×	×	×	×
GLS/GL E-Class	167	Body	WSS-Weight sensing system(N110)	√	√	√	√	×	×	×	×	×
GLS/GL E-Class	167	Chassis	ADS-Adaptive damping system(N51/5)	√	√	√	√	×	×	SP1061	×	×
GLS/GL E-Class	167	Chassis	ADS-Adaptive damping system(N51/5)	√	√	√	√	×	×	SP1061	×	×

GLS/GL E-Class	167	Chassis	AIRmatic	√	√	√	√	×	ACT0851,ACT0631,ACT0852,ACT0039,ACT0167,ACT0168,ACT0169,ACT0170,ACT0853,ACT0854,ACT0855,ACT0856,	SP1061	×	×
GLS/GL E-Class	167	Chassis	AIRmatic	√	√	√	√	×	ACT0858,ACT0859,ACT0039,ACT0167,ACT0168,ACT0169,ACT0170,ACT0853,ACT0854,ACT0855,ACT0856	SP1061	×	×
GLS/GL E-Class	167	Chassis	AMG DRVU-AMG DRIVE UNIT	√	√	√	√	×	ACT0401,ACT0402,ACT0403,ACT0404	SP1153,SP1154,SP1155	×	×
GLS/GL E-Class	167	Chassis	ES - Electric power steering	√	√	√	√	×	×	SP1071	×	×
GLS/GL E-Class	167	Chassis	ESP-Electric stability program(N30/4)	√	√	√	√	√	ACT0069,ACT0070,ACT0612,ACT0285,ACT0286,ACT0287,ACT0288	SP1174,SP1175,SP1176,SP1177,SP1178,SP1179,SP1180,SP1181,SP1367,	×	×
GLS/GL E-Class	167	Chassis	ESP-Electric stability program(N30/4)	√	√	√	√	√	ACT0069,ACT0070,ACT0863,ACT0285,ACT0286,ACT0287,ACT0288	SP1174,SP1175,SP1176,SP1177,SP1178,SP1179,SP1366,SP1181,SP1367,	×	×
GLS/GL E-Class	167	Chassis	Left front suspension strut	√	√	√	√	×	ACT0636	×	×	×
GLS/GL E-Class	167	Chassis	Left front suspension strut	√	√	√	√	×	ACT0860,ACT0861,ACT0862	×	×	×
GLS/GL E-Class	167	Chassis	Left rear suspension strut	√	√	√	√	×	ACT0860,ACT0861,ACT0862	×	×	×
GLS/GL E-Class	167	Chassis	Right front suspension strut	√	√	√	√	×	ACT0637	×	×	×
GLS/GL E-Class	167	Chassis	Right front suspension strut	√	√	√	√	×	ACT0860,ACT0861,ACT0862	×	×	×
GLS/GL E-Class	167	Chassis	Right rear suspension strut	√	√	√	√	×	ACT0860,ACT0861,ACT0862	×	×	×
GLS/GL E-Class	167	Drive	EAGGS-Electric differential lock	√	√	√	√	×	ACT0814	SP1155	×	×
GLS/GL E-Class	167	Drive	FSCU-Fuel pump	√	√	√	√	×	×	×	×	×
GLS/GL E-Class	167	Drive	ISG-Integrated starter alternator	√	√	√	×	×	×	×	×	×
GLS/GL E-Class	167	Drive	ISG-Integrated starter alternator	√	√	√	√	×	×	SP1368	×	×
GLS/GL E-Class	167	Drive	N127 (Drivetrain control unit)	√	√	√	×	×	×	×	×	×
GLS/GL E-Class	167	Drive	N127 (Drivetrain control unit)	√	√	√	√	×	ACT0028,ACT0430,ACT0431,ACT0432,ACT0433,ACT0007,ACT0434,ACT0435,ACT0436,ACT0437,ACT0438,ACT0439,ACT0440,ACT0441,ACT0442,ACT0443,ACT0444,ACT0445,ACT0446,ACT0447,ACT0448,	SP1186,SP1042,SP1025,SP1187,SP1188,SP1189,SP1190,SP1191,SP1192	×	×

GLS/GL E-Class	167	Drive	N3/10-Motor electronics "MED1775" for combustion engine "M178"	√	√	√	√	√	ACT0002,ACT0028,ACT0431,ACT0432,ACT0433,ACT0864,ACT0865,ACT0435,ACT0480,ACT0476,ACT0475,ACT0478,ACT0477,ACT0326,ACT0866,ACT0867,ACT0436,ACT0025,ACT0868,ACT0712,ACT0713,	SP1017,SP1109,SP1110,SP1369,SP1370,SP1371,SP1112,SP1202,SP1203,SP1001,SP1187,SP1372,SP1201,SP1000	×	×
GLS/GL E-Class	167	Drive	N3/10-Motor electronics "MED40" for combustion engine "M274"	√	√	√	√	√	ACT0002,ACT0005,ACT0460,ACT0322,ACT0323,ACT0324,ACT0325,ACT0326,ACT0025,ACT0327,ACT0328,ACT0329,ACT0022,ACT0024,ACT0330,ACT0331,ACT0332,ACT0333,	SP1017,SP1004,SP1000	×	×
GLS/GL E-Class	167	Drive	N3/10-Motor electronics "MED41" for combustion engine "M260/M264"	√	√	√	√	√	ACT0330,ACT0003,ACT0459,ACT0323,ACT0324,ACT0333,ACT0025,ACT0328,ACT0331,ACT0332,ACT0004,ACT0005,ACT0456,ACT0002,ACT0460,ACT0329,ACT0022,ACT0325,	SP1199,SP1117	×	×
GLS/GL E-Class	167	Drive	N3/10-Motor electronics "MRG1" for combustion engine "M256"	√	√	√	√	√	ACT0002,ACT0025,ACT0005,ACT0022,ACT0456,ACT0329,ACT0325,ACT0328,ACT0323,ACT0324,ACT0460,ACT0871,	SP1001,SP1004,SP1201,SP1202,SP1203,SP1110,SP1109,SP1139,SP1017,SP1371,SP1112,SP1000	×	×
GLS/GL E-Class	167	Drive	N3/40-Motor electronics "MRD1" for combustion engine "OM654"	√	√	√	√	√	ACT0001,ACT0005,ACT0006,ACT0321,ACT0008,ACT0009,ACT0010,ACT0322,ACT0011,ACT0012,ACT0016,ACT0018,ACT0022,ACT0023,ACT0024,ACT0026,ACT0000,ACT0338,ACT0339,ACT0340,ACT0341	SP1001,SP1000,SP1130,SP1125,SP1131,SP1132,SP1133,SP1134,SP1135,SP1136,SP1017,SP1137,SP1138,SP1024,SP1139,SP1140,SP1015,SP1141,SP1142,SP1143,SP1144,SP1021,SP1022,SP1145,	×	×
GLS/GL E-Class	167	Drive	SCR-Selective catalytic reduction	√	√	√	√	×	ACT0424,ACT0425,ACT0426,ACT0427,ACT0428,ACT0429	SP1184,SP1185	×	×
GLS/GL E-Class	167	Drive	SG EM-Power electronics	√	√	√	√	×	ACT0451,ACT0452	SP1193,SP1194,SP1195,SP1196,SP1150	×	×
GLS/GL E-Class	167	Drive	SG SOGE AGA-Sound generator for exhaust system	√	√	√	√	×	×	×	×	×
GLS/GL E-Class	167	Drive	VG-Transfer case	√	√	√	√	×	×	×	×	×
GLS/GL E-Class	167	Drive	Y3/8n4-Transmission control for 9 speed transmission	√	√	√	√	√	ACT0592,ACT0312,ACT0593,ACT0714,ACT0317	SP1311,SP1315,SP1316,SP1305,SP1355,SP1312,SP1356,SP1300,SP1357,SP1358,SP1359,SP1317	×	×
GLS/GL E-Class	167	Driver assistance system	DTR-DISTRONIC	√	√	√	√	×	×	SP1161,SP1162	×	×
GLS/GL E-Class	167	Driver assistance system	IRS HLA-Outer left rear integrated radar sensor (B92/11)	√	√	√	√	×	×	SP1150,SP1151	×	×
GLS/GL E-Class	167	Driver assistance system	IRS HRA-Outer right rear integrated radar sensor (B92/6)	√	√	√	√	×	×	SP1150,SP1151	×	×
GLS/GL E-Class	167	Driver assistance system	KAR-Augmented reality camera	√	√	√	√	×	×	×	×	×
GLS/GL E-Class	167	Driver assistance system	MFK-Multifunction camera(mono)(A40/11)	√	√	√	√	×	ACT0181,ACT0065	SP1156	×	×

GLS/GL E-Class	167	Driver assistance system	MFK-Multifunction camera(stereo)(A40/13)	√	√	√	√	×	ACT0181,ACT0065	SP1063	×	×
GLS/GL E-Class	167	Driver assistance system	NBR LF-Left front short range radar	√	√	√	√	×	×	×	×	×
GLS/GL E-Class	167	Driver assistance system	NBR LR-Left rear short-range radar	√	√	√	√	×	×	SP1173	×	×
GLS/GL E-Class	167	Driver assistance system	NBR RF-Right front short range radar	√	√	√	√	×	×	×	×	×
GLS/GL E-Class	167	Driver assistance system	NBR RR-Right rear short-range radar	√	√	√	√	×	×	SP1172	×	×
GLS/GL E-Class	167	Driver assistance system	PTS-PARKTRONIC	√	√	√	√	×	ACT0421,ACT0306	SP1166	×	×
GLS/GL E-Class	167	Driver assistance system	RFK-Backup camera	√	√	√	√	×	×	SP1152	×	×
GLS/GL E-Class	167	Driver assistance system	SG AWF-COLLISION PREVENTION ASSIST	√	√	√	√	×	×	SP1063	×	×
GLS/GL E-Class	167	Driver assistance system	SGR-Radar sensors control unit	√	√	√	√	×	ACT0419,ACT0420	SP1163,SP1164,SP1165	×	×
GLS/GL E-Class	167	Driver assistance system	TPM-Tire pressure monitor(N88)	√	√	√	√	×	ACT0078,ACT0079,ACT0081,ACT0080	SP1053	×	×
GLS/GL E-Class	167	Information and communication	Audio-Audio or COMAND	√	√	√	×	×	×	×	×	×
GLS/GL E-Class	167	Information and communication	AVE H-Controller unit Rear entertainment system	√	√	√	√	×	ACT0809,ACT0810,ACT0811,ACT0812,ACT0813	×	×	×
GLS/GL E-Class	167	Information and communication	CTEL-Cellular telephone	√	√	√	√	×	×	×	×	×
GLS/GL E-Class	167	Information and communication	D FOL-Display in left rear passenger compartment	√	√	√	×	×	×	×	×	×
GLS/GL E-Class	167	Information and communication	D FOR-Display in right rear passenger compartment	√	√	√	×	×	×	×	×	×
GLS/GL E-Class	167	Information and communication	HERMES-control unit for telematics services	√	√	√	√	×	×	SP1046	×	×
GLS/GL E-Class	167	Information and communication	HUD-Head up display	√	√	√	√	×	ACT0210,ACT0212	×	×	×
GLS/GL E-Class	167	Information and communication	IC-Instrument cluster	√	√	√	√	×	ACT0039,ACT0397,ACT0048,ACT0210,ACT0398,ACT0399,ACT0050,ACT0400	SP1043,SP1044,SP1045	×	×
GLS/GL E-Class	167	Information and communication	MTAS-Mobile phone cradle	√	√	√	√	×	×	×	×	×
GLS/GL E-Class	167	Information and communication	MTAS-Mobile phone cradle	√	√	√	√	×	×	×	×	×
GLS/GL E-Class	167	Information and communication	ORBF-Off-road operating panel	√	√	√	×	×	×	×	×	×
GLS/GL E-Class	167	Information and communication	SOUND-Sound system	√	√	√	√	×	×	×	×	×
GLS/GL E-Class	167	Information and communication	TPAD-Touchpad	√	√	√	√	×	×	×	×	×
GLS/GL E-Class	167	Information and communication	ZAN-Audio/COMAND display	√	√	√	√	×	ACT0291,ACT0206,ACT0039	×	×	×
GLS/GL E-Class	167	Seats and Doors	"Driver" seat heater	√	√	√	√	×	×	×	×	×
GLS/GL E-Class	167	Seats and Doors	"Front passenger" seat heater	√	√	√	√	×	×	×	×	×

GLS/GL E-Class	167	Seats and Doors	ARB-Electric step	√	√	√	×	×	×	×	×	×
GLS/GL E-Class	167	Seats and Doors	DCU LR-Left rear door	√	√	√	×	×	×	×	×	×
GLS/GL E-Class	167	Seats and Doors	DCU LR-Left rear door	√	√	√	√	×	ACT0360,ACT0361,ACT0362,ACT0363,ACT0723,ACT0688,ACT0347,ACT0364,ACT0724,ACT0366,ACT0725	SP1080,SP1147,SP1148	×	×
GLS/GL E-Class	167	Seats and Doors	DCU RF-Right front door	√	√	√	√	×	ACT0353,ACT0274,ACT0273,ACT0354,ACT0720,ACT0283,ACT0284,ACT0281,ACT0282,ACT0721,ACT0355,ACT0278,ACT0356,ACT0357,ACT0347,ACT0279,ACT0348,ACT0349,ACT0358,ACT0359,ACT0722,	SP1080,SP1147,SP1148	×	×
GLS/GL E-Class	167	Seats and Doors	DCU RR-Right rear door	√	√	√	×	×	×	×	×	×
GLS/GL E-Class	167	Seats and Doors	DCU RR-Right rear door	√	√	√	√	×	ACT0367,ACT0368,ACT0369,ACT0370,ACT0726,ACT0692,ACT0347,ACT0371,ACT0365,ACT0727,ACT0728,ACT0366	SP1080,SP1147,SP1148	×	×
GLS/GL E-Class	167	Seats and Doors	ESA Front passenger-Electric seat adjustment Front passenger	√	√	√	√	×	×	×	×	×
GLS/GL E-Class	167	Seats and Doors	ESA Front passenger-Electric seat adjustment Front passenger	√	√	√	√	×	ACT0230,ACT0378,ACT0234,ACT0379,ACT0233,ACT0380,ACT0381,ACT0382	SP1075	×	×
GLS/GL E-Class	167	Seats and Doors	ESE_RL-Left rear electrical seat adjustment	√	√	√	√	×	×	×	×	×
GLS/GL E-Class	167	Seats and Doors	ESV Driver-Electric seat adjustmnet Driver	√	√	√	√	×	×	×	×	×
GLS/GL E-Class	167	Seats and Doors	ESV Driver-Electric seat adjustmnet Driver	√	√	√	√	×	ACT0214,ACT0373,ACT0218,ACT0374,ACT0217,ACT0375,ACT0376,ACT0377	SP1075	×	×
GLS/GL E-Class	167	Seats and Doors	HKS-Tailgate control	√	√	√	√	×	×	×	×	×
GLS/GL E-Class	167	Seats and Doors	LFD-Left front door	√	√	√	√	×	ACT0342,ACT0255,ACT0254,ACT0343,ACT0715,ACT0269,ACT0361,ACT0267,ACT0268,ACT0716,ACT0344,ACT0261,ACT0345,ACT0346,ACT0347,ACT0263,ACT0348,ACT0349,ACT0350,ACT0351,ACT0717,	SP1080,SP1147,SP1148	×	×
GLS/GL E-Class	167	Seats and Doors	Massage function in left front seat	√	√	√	√	×	×	×	×	×
GLS/GL E-Class	167	Seats and Doors	Massage function in left rear seat	√	√	√	√	×	×	×	×	×
GLS/GL E-Class	167	Seats and Doors	Massage function in left rear seat	√	√	√	√	×	ACT0850	×	×	×
GLS/GL E-Class	167	Seats and Doors	Massage function in right front seat	√	√	√	√	×	×	×	×	×
GLS/GL E-Class	167	Seats and Doors	Massage function in right rear seat	√	√	√	√	×	×	×	×	×

GLS/GL E-Class	167	Seats and Doors	Massage function in right rear seat	√	√	√	√	×	ACT0850	×	×	×
GLS/GL E-Class	167	Seats and Doors	MFSF-LF	√	√	√	√	×	×	×	×	×
GLS/GL E-Class	167	Seats and Doors	MFSF-RF	√	√	√	√	×	×	×	×	×
GLS/GL E-Class	167	Seats and Doors	MKS LF-Left front multicontour seat	√	√	√	√	×	ACT0383,ACT0384,ACT0387,ACT0388,ACT0386,ACT0802	×	×	×
GLS/GL E-Class	167	Seats and Doors	MKS LF-Left rear multicontour seat	√	√	√	√	×	ACT0383,ACT0803,ACT0384,ACT0386	×	×	×
GLS/GL E-Class	167	Seats and Doors	MKS LF-Left rear multicontour seat	√	√	√	√	×	ACT0383,ACT0803,ACT0384,ACT0386,ACT0613	×	×	×
GLS/GL E-Class	167	Seats and Doors	MKS RF-Right front multicontour seat	√	√	√	√	×	ACT0383,ACT0384,ACT0387,ACT0388,ACT0386,ACT0802	×	×	×
GLS/GL E-Class	167	Seats and Doors	MKS RF-Right rear multicontour seat	√	√	√	√	×	ACT0383,ACT0803,ACT0384,ACT0386	×	×	×
GLS/GL E-Class	167	Seats and Doors	MKS RF-Right rear multicontour seat	√	√	√	√	×	ACT0383,ACT0803,ACT0384,ACT0386,ACT0613	×	×	×
GLS/GL E-Class	167	Seats and Doors	PPAMKS-Pneumatic pump for multicontour seat	√	√	√	√	×	ACT0616,ACT0804	×	×	×
GLS/GL E-Class	167	Seats and Doors	Right rear ESE-Right rear electrical seat adjustment	√	√	√	√	×	×	×	×	×
GLS/GL E-Class	167	Seats and Doors	S158/11 (Left 2nd seat row seats switch group)	√	√	√	×	×	×	×	×	×
GLS/GL E-Class	167	Seats and Doors	S158/12 (Right 2nd seat row seats switch group)	√	√	√	×	×	×	×	×	×
GLS/GL E-Class	167	Seats and Doors	S158/13 (Seats switch group (left load compartment))	√	√	√	×	×	×	×	×	×
GLS/GL E-Class	167	Seats and Doors	S158/14 (Seats switch group (right load compartment))	√	√	√	×	×	×	×	×	×
GLS/GL E-Class	167	Seats and Doors	S22 (Driver's door seat adjustment switch)	√	√	√	√	×	×	×	×	×
GLS/GL E-Class	167	Seats and Doors	S23 (Front passenger door seat adjustment switch)	√	√	√	√	×	×	×	×	×
GLS/GL E-Class	167	Seats and Doors	S47/2 (Driver door switch module)	√	√	√	√	×	×	×	×	×
GLS/GL E-Class	167	Seats and Doors	S47/3 (Front passenger door switch module)	√	√	√	√	×	×	×	×	×
GLS/GL E-Class	167	Seats and Doors	S51/1 (Driver seat climate control switch group)	√	√	√	√	×	×	×	×	×
GLS/GL E-Class	167	Seats and Doors	S51/2 (Front passenger seat climate control switch group)	√	√	√	√	×	×	×	×	×
GLS/GL E-Class	167	Seats and Doors	S51/3 (Left rear seat heater switch)	√	√	√	×	×	×	×	×	×
GLS/GL E-Class	167	Seats and Doors	S51/4 (Right rear seat heater switch)	√	√	√	×	×	×	×	×	×
GLS/GL E-Class	167	Seats and Doors	S51/5 (Left 3rd seat row seat heating switch)	√	√	√	√	×	×	×	×	×
GLS/GL E-Class	167	Seats and Doors	S51/6 (Right 3rd seat row seat heating switch)	√	√	√	√	×	×	×	×	×
GLS/GL E-Class	167	Seats and Doors	Seat heater in left rear passenger compartment	√	√	√	√	×	×	×	×	×

GLS/GL E-Class	167	Seats and Doors	Seat heater in right rear passenger compartment	√	√	√	√	×	×	×	×	×
GLS/GL E-Class	167	Seats and Doors	SIH-Seat heating of third seat row	√	√	√	√	×	ACT0545,ACT0546,ACT0415	×	×	×
M-Class	164	Air conditioning	AAC-Automatic air conditioning	√	√	√	√	×	ACT0555,ACT0556,ACT0557,ACT0558,ACT0559,ACT0560,ACT0561,ACT0562,ACT0563	SP1254,SP1255,SP1256,SP1257	×	×
M-Class	164	Air conditioning	EKMK-Electric refrigerant compressor	√	√	√	√	×	×	×	×	×
M-Class	164	Air conditioning	LRH-Steering wheel heater	√	√	√	√	×	ACT0564	×	×	×
M-Class	164	Air conditioning	STH-Stationary heater with remote control	√	√	√	√	×	ACT0565,ACT0566,ACT0567	×	×	×
M-Class	164	Body	AB-Airbag	√	√	√	√	√	×	SP1240	×	×
M-Class	164	Body	CGW-Central gateway	√	√	√	×	×	×	×	×	×
M-Class	164	Body	EZS-Electronic ignition switch	√	√	√	√	×	×	×	×	×
M-Class	164	Body	EZS-Electronic ignition switch	√	√	√	√	×	×	×	×	×
M-Class	164	Body	HBF-Rear control field	√	√	√	√	×	ACT0509,ACT0507,ACT0510,ACT0511	×	×	×
M-Class	164	Body	HRA-Automatic headlamp range adjustment and headlamp control	√	√	√	√	×	ACT0292	SP1253	×	×
M-Class	164	Body	KG-Keyless Go	√	√	√	√	×	×	×	×	×
M-Class	164	Body	KG-KEYLESS GO	√	√	√	√	×	×	×	×	×
M-Class	164	Body	OCP-Overhead control panel	√	√	√	√	×	ACT0301,ACT0504,ACT0505,ACT0506,ACT0507,ACT0508	SP1245,SP1246	×	×
M-Class	164	Body	REAR SAM-Rear signal acquisition and actuation module	√	√	√	√	×	×	×	×	×
M-Class	164	Body	RevETR LF-Left front reversible emergency tensioning retractor	√	√	√	√	×	×	×	×	×
M-Class	164	Body	RevETR LF-Left front reversible emergency tensioning retractor	√	√	√	√	×	×	×	×	×
M-Class	164	Body	RevETR RF-Right front reversible emergency tensioning	√	√	√	√	×	×	×	×	×
M-Class	164	Body	RevETR RF-Right front reversible emergency tensioning	√	√	√	√	×	×	×	×	×
M-Class	164	Body	SAM F-Signal acquisition and actuation module front	√	√	√	√	×	ACT0512,ACT0513,ACT0514,ACT0515,ACT0516,ACT0517,ACT0518,ACT0519,ACT0520	×	×	×
M-Class	164	Body	SG BMS-Battery management system control unit	√	√	√	√	×	×	×	×	×
M-Class	164	Body	SG DDW-DC/DC converter control unit	√	√	√	√	×	×	×	×	×
M-Class	164	Body	System diagnosis(CAN)	√	√	√	√	×	×	×	×	×
M-Class	164	Body	UCP-Upper control panel	√	√	√	√	×	ACT0509,ACT0507	×	×	×
M-Class	164	Body	WSS-Weight sensing system	√	√	√	√	×	×	×	×	×
M-Class	164	Body	XALWA L-Xenon headlamp, left	√	√	√	√	×	×	SP1084,SP1250,SP1251	×	×
M-Class	164	Body	XALWA L-Xenon headlamp, left	√	√	√	√	×	ACT0549,ACT0550,ACT0551,ACT0552	SP1252	×	×
M-Class	164	Body	XALWA R-Xenon headlamp,	√	√	√	√	×	×	SP1084,SP1250,SP1251	×	×
M-Class	164	Body	XALWA R-Xenon headlamp,	√	√	√	√	×	ACT0553,ACT0554	SP1252	×	×
M-Class	164	Chassis	EHPS-Electrohydraulic Power Steering	√	√	√	√	×	×	×	×	×
M-Class	164	Chassis	ESP-Electronic stability program	√	√	√	√	×	ACT0482,ACT0483,ACT0484	SP1238,SP1239	×	×

M-Class	164	Chassis	RBS-Regenerative braking	√	√	√	√	×	×	×	×	×
M-Class	164	Chassis	Suspension	√	√	√	√	×	ACT0496,ACT0497,ACT0498, ACT0499,ACT0500,ACT0501, ACT0502,ACT0503	SP1242,SP1243,SP1244	×	×
M-Class	164	Chassis	TPM-Tire pressure monitor	√	√	√	√	×	×	×	×	×
M-Class	164	Chassis	TPM-Tire pressure monitor	√	√	√	√	×	×	×	×	×
M-Class	164	Drive	CDI 4-Common Rail Diesel	√	√	√	√	√	×	SP1212	×	×
M-Class	164	Drive	CDI 5-Common Rail Diesel	√	√	√	√	√	×	SP1212	×	×
M-Class	164	Drive	CDI 6-Common Rail Diesel Injection	√	√	√	√	√	ACT0002,ACT0577,ACT0578, ACT0579,ACT0580,ACT0032	SP1212	×	×
M-Class	164	Drive	CDI 6-Common Rail Diesel Injection	√	√	√	√	√	ACT0002,ACT0577,ACT0578, ACT0579,ACT0580,ACT0032	SP1212	×	×
M-Class	164	Drive	CDI 6BIN5-Common Rail Diesel Injection	√	√	√	√	√	×	SP1258,SP1259,SP1260, SP1004,SP1261,SP1262, SP1263,SP1264,SP1265, SP1266,SP1267,SP1268, SP1269,SP1270,SP1271, SP1272,SP1273,SP1274, SP1275,SP1276,SP1277,	×	×
M-Class	164	Drive	DTR-Distronic	√	√	√	√	×	×	×	×	×
M-Class	164	Drive	DTR-Distronic	√	√	√	√	×	×	SP1077	×	×
M-Class	164	Drive	ETC-Electronic transmission	√	√	√	√	√	×	×	×	×
M-Class	164	Drive	ETC-Electronic transmission control	√	√	√	√	√	×	SP1217,SP1218,SP1219, SP1220,SP1221,SP1222, SP1223,SP1214,SP1224, SP1225,SP1226,SP1227, SP1228,SP1229,SP1214, SP1230,SP1231,SP1232, SP1233,SP1234,SP1235,	×	√
M-Class	164	Drive	FSCU Left-Control unit 'Left fuel pump'	√	√	√	√	×	×	×	×	×
M-Class	164	Drive	FSCU Right-Control unit 'Right fuel pump'	√	√	√	√	×	×	×	×	×
M-Class	164	Drive	FSCU-Fuel pump	√	√	√	√	×	×	×	×	×
M-Class	164	Drive	FSCU-Fuel pump	√	√	√	√	×	ACT0320	×	×	×
M-Class	164	Drive	HAQ-Interwheel differential lock at rear axle	√	√	√	√	×	×	×	×	×
M-Class	164	Drive	HSG-Hybrid control unit	√	√	√	√	×	ACT1371,ACT1372,ACT1373	×	×	×
M-Class	164	Drive	IRS HLA-Outer left rear intelligent radar sensor system	√	√	√	√	×	×	×	×	×
M-Class	164	Drive	IRS HRA-Outer right rear intelligent radar sensor system	√	√	√	√	×	×	×	×	×
M-Class	164	Drive	ISM-Intelligent servo module	√	√	√	√	×	ACT0490,ACT0491,ACT0492, ACT0493,ACT0494	×	×	×
M-Class	164	Drive	ISM-Shift module	√	√	√	√	×	ACT0490,ACT0495,ACT0492, ACT0493,ACT0494	SP1241	×	×
M-Class	164	Drive	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	√	√	√	√	√	ACT0467,ACT0468,ACT1365, ACT1366,ACT0469,ACT0470, ACT0471,ACT0472,ACT0473, ACT0474,ACT0475,ACT0476, ACT0477,ACT0478,ACT1367, ACT0480,ACT0000,ACT0481,	SP1210,SP1211,SP1212, SP1516,SP1214,SP1215, SP1216	×	×

M-Class	164	Drive	ME 9.7-Motor electronics 9.7	√	√	√	√	√	ACT0467,ACT0468,ACT0005, ACT0002,ACT0469,ACT0470, ACT0471,ACT0472,ACT0473, ACT0474,ACT0475,ACT0476, ACT0477,ACT0478,ACT0479, ACT0480,ACT0000,ACT0481	SP1210,SP1211,SP1212, SP1213,SP1214,SP1215, × SP1216		√
M-Class	164	Drive	ME SF 17.7-Motor electronics 17.7	√	√	√	√	√	ACT1348,ACT0468,ACT0005, ACT0002,ACT0469,ACT0481, ACT0471,ACT0472,ACT1369, ACT0474,ACT0475,ACT0476, ACT0477,ACT0478,ACT0479, ACT0480,ACT0022,ACT1370	SP1210,SP1211,SP1212, SP1213,SP1214,SP1215, × SP1216		×
M-Class	164	Drive	ME SFI 2.8-Motor electronics 2.8	√	√	√	√	√	ACT1348,ACT0468,ACT0005, ACT0002,ACT1349,ACT0469, ACT0470,ACT1350,ACT0471, ACT1351,ACT1352,ACT0474, ACT1353,ACT0335,ACT1354,	SP1212	×	×
M-Class	164	Drive	ME SFI 2.8-Motor electronics 2.8	√	√	√	√	×	ACT1348,ACT0468,ACT0005, ACT0002,ACT1349,ACT0469, ACT0470,ACT1350,ACT0471, ACT1351,ACT1352,ACT0474, ACT1353,ACT0335,ACT1354,	SP1212	×	×
M-Class	164	Drive	SCR-Selective Catalytic Reduction	√	√	√	√	×	ACT0581,ACT0582,ACT0583, ACT0584,ACT0585	SP1279,SP1280,SP1281, SP1282,SP1283	×	×
M-Class	164	Drive	VG-Transfer case	√	√	√	√	×	ACT0489	×	×	×
M-Class	164	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	√	√	√	√	×	×	×	×	×
M-Class	164	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	√	√	√	√	×	×	×	×	×
M-Class	164	Information and communication	ASSYST PLUS-PLUS Active Service System	√	√	√	√	×	×	SP1248,SP1249	×	×
M-Class	164	Information and communication	ASSYST-Active Service System	√	√	√	√	×	×	SP1247	×	×
M-Class	164	Information and communication	AUDIO	√	√	√	√	×	×	×	×	×
M-Class	164	Information and communication	AVE H-Rear audio video unit	√	√	√	√	×	×	×	×	×
M-Class	164	Information and communication	AVE H-Rear audio video unit	√	√	√	√	×	×	×	×	×
M-Class	164	Information and communication	CDC-CD changer	√	√	√	√	×	×	×	×	×
M-Class	164	Information and communication	CM-Compass module	√	√	√	√	×	×	×	×	×
M-Class	164	Information and communication	COMAND or AUDIO	√	√	√	√	×	×	×	×	×
M-Class	164	Information and communication	COMAND or AUDIO	√	√	√	√	×	×	×	×	×
M-Class	164	Information and communication	CTEL-Cellular telephone	√	√	√	√	×	×	×	×	×
M-Class	164	Information and communication	CTEL-Cellular telephone(JAPAN)	√	√	√	√	×	×	×	×	×

M-Class	164	Information and communication	CTEL-Mobile phone adapter with universal interface	√	√	√	√	×	×	×	×	×
M-Class	164	Information and communication	DAB-Digital radio	√	√	√	√	×	×	×	×	×
M-Class	164	Information and communication	IC-Instrument cluster	√	√	√	√	×	ACT0485,ACT0486,ACT0487,ACT0488	×	×	×
M-Class	164	Information and communication	Left rear screen	√	√	√	√	×	ACT0568,ACT0569,ACT0570,ACT0571,ACT0572	×	×	×
M-Class	164	Information and communication	NAVI-Navigation system	√	√	√	√	×	×	×	×	×
M-Class	164	Information and communication	PTS-Parktronic system	√	√	√	√	×	×	×	×	×
M-Class	164	Information and communication	PTS-Parktronic system	√	√	√	√	×	×	×	×	×
M-Class	164	Information and communication	RFK-Backup camera	√	√	√	√	×	×	×	×	×
M-Class	164	Information and communication	Right rear screen	√	√	√	√	×	ACT0573,ACT0569,ACT0574,ACT0575,ACT0576	×	×	×
M-Class	164	Information and communication	SCM [MRM]-Steering column module	√	√	√	√	×	ACT0540	SP1077	×	×
M-Class	164	Information and communication	SDAR-Satellite radio	√	√	√	√	×	×	×	×	×
M-Class	164	Information and communication	SDAR-Satellite radio(Valid for USA)	√	√	√	√	×	×	×	×	×
M-Class	164	Information and communication	SOUND-Sound system	√	√	√	√	×	×	×	×	×
M-Class	164	Information and communication	TELE AID-Control unit	√	√	√	√	×	×	×	×	×
M-Class	164	Information and communication	TELE AID-Telematic services Emergency call	√	√	√	√	×	×	×	×	×
M-Class	164	Information and communication	TELE AID-Telematic services MB Info,Roadside assistance(USA, Canada),Tele	√	√	√	√	×	×	×	×	×
M-Class	164	Information and communication	TELE AID-Telematic services Remote door unlocking,Remote door locking	√	√	√	√	×	×	×	×	×
M-Class	164	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	√	√	√	√	×	×	×	×	×
M-Class	164	Information and communication	TV-TV tuner	√	√	√	√	×	×	×	×	×
M-Class	164	Information and communication	TV-TV tuner	√	√	√	√	×	×	×	×	×
M-Class	164	Information and communication	TV-TV tuner	√	√	√	√	×	×	×	×	×
M-Class	164	Information and communication	TV-TV tuner	√	√	√	√	×	×	×	×	×
M-Class	164	Information and communication	TV-TV tuner(AGW)	√	√	√	√	×	×	×	×	×
M-Class	164	Information and communication	UCI-Media interface	√	√	√	√	×	×	×	×	×
M-Class	164	Information and communication	VCS-Voice control system	√	√	√	√	×	×	×	×	×

M-Class	164	Seats and Doors	DCM FL-Door control module front left	√	√	√	√	×	ACT0521,ACT0522,ACT0523,ACT0256,ACT0524,ACT0525,ACT0526,ACT0527	×	×	×
M-Class	164	Seats and Doors	DCM FR-Door control module front right	√	√	√	√	×	ACT0528,ACT0522,ACT0523,ACT0524,ACT0529,ACT0530,	×	×	×
M-Class	164	Seats and Doors	DS LF-Left front dynamic seat	√	√	√	√	×	ACT0532,ACT0533,ACT0534,ACT0535,ACT0536	×	×	×
M-Class	164	Seats and Doors	DS RF-Right front dynamic seat	√	√	√	√	×	ACT0532,ACT0533,ACT0534,ACT0537,ACT0538	×	×	×
M-Class	164	Seats and Doors	DSP-Pneumatic pump for dynamic seat	√	√	√	√	×	×	×	×	×
M-Class	164	Seats and Doors	ESV driver-Electric seat adjustment driver (with memory)	√	√	√	√	×	×	×	×	×
M-Class	164	Seats and Doors	ESV passenger-Electric seat adjustment passenger	√	√	√	√	×	×	×	×	×
M-Class	164	Seats and Doors	HS-Seat heater	√	√	√	√	×	ACT0545,ACT0546,ACT0547,ACT0548,ACT0413,ACT0414	×	×	×
M-Class	164	Seats and Doors	REDC-Rear end door closing control module	√	√	√	√	×	ACT0541	×	×	×
M-Class	164	Seats and Doors	REDC-Rear end door closing control module	√	√	√	√	×	ACT0542,ACT0543,ACT0544	×	×	×
S-Class	221	Air conditioning	AAC-Automatic air conditioning	√	√	√	√	×	ACT1828,ACT1829,ACT1830,ACT1831,ACT1832,ACT1833,ACT1834,ACT1835,ACT1836,ACT1837,ACT0555,ACT0558,ACT0562,ACT1838,ACT1839,ACT0655,ACT0656,ACT1344,ACT0559,ACT1840,ACT1346,ACT0183,ACT1841,ACT1842,	SP1254,SP1574,SP1256,SP1257,SP1575	×	√
S-Class	221	Air conditioning	KBE H-Rear A/C operating unit	√	√	√	√	×	ACT0509	×	×	×
S-Class	221	Air conditioning	STH-Stationary heater with remote control	√	√	√	√	×	ACT0565,ACT0566,ACT1844,ACT1845,ACT1846,ACT1847,ACT1848,ACT1849,ACT1850,ACT1851,ACT1852,ACT1853,	SP1576	×	×
S-Class	221	Body	AB-Airbag	√	√	√	√	×	×	×	×	×
S-Class	221	Body	AHE-Trailer recognition	√	√	√	√	×	ACT0237,ACT0236,ACT1396,ACT1397,ACT1398,ACT1375,ACT1307,ACT1783,ACT1784	×	×	×
S-Class	221	Body	BNS-Vehicle power supply control module	√	√	√	√	×	ACT1778,ACT1779,ACT1780,ACT1779,ACT1780,ACT1781,	×	×	×
S-Class	221	Body	CGW-Central gateway	√	√	√	×	×	×	×	×	×
S-Class	221	Body	COU [ZBE]-Central operating	√	√	√	√	×	ACT0507	×	×	×
S-Class	221	Body	Dr side SAM-Driver signal acquisition and actuation module	√	√	√	√	×	ACT1749,ACT0516,ACT1750,ACT1751,ACT1752,ACT1301,ACT1302,ACT1753,ACT1754,ACT1755,ACT1756,ACT1295,ACT1757,ACT1638,ACT1485,ACT1631,ACT1758,ACT1759,ACT0220,ACT0739,ACT1760,	SP1565	×	√
S-Class	221	Body	EZS-Electronic ignition switch	√	√	√	√	×	×	×	×	×
S-Class	221	Body	EZS-Electronic ignition switch	√	√	√	√	×	×	SP1556,SP1557,SP1558,SP1559,SP1560	×	×

S-Class	221	Body	HBF-Rear control field	√	√	√	√	×	ACT1419	×	×	×
S-Class	221	Body	KG-Keyless Go	√	√	√	√	×	ACT1699,ACT1700,ACT1701,ACT1702,ACT1703,ACT1704,ACT1662,ACT1705,ACT1664,ACT1706,ACT1707,ACT1708,ACT1665,ACT1709,ACT1710,ACT1711,ACT1712,ACT1713,ACT1662,ACT1705,ACT1664,ACT1706,ACT1714,ACT1715,	×	×	×
S-Class	221	Body	KG-KEYLESS GO	√	√	√	√	×	ACT1718,ACT1719,ACT1720,ACT1721,ACT1722,ACT1723,	×	×	×
S-Class	221	Body	MSS-Special vehicle multifunction control module	√	√	√	√	×	ACT1919,ACT1675,ACT1920,ACT1921,ACT1922,ACT1923,ACT1924,ACT1925,ACT1926,ACT1927,ACT1928,ACT1929,ACT1930,ACT1931,ACT1932,ACT1407,ACT1933,ACT1934,ACT1399,ACT1400,ACT1935,ACT1936,ACT1937,ACT1938,	×	×	×
S-Class	221	Body	OCP-Overhead control panel	√	√	√	√	×	ACT0301,ACT0504,ACT0505,ACT0506,ACT1725,ACT0508,ACT1726,ACT1727,ACT1091,	×	×	×
S-Class	221	Body	PSD-Panoramic sliding roof(Interior CAN bus)	√	√	√	√	×	ACT1727,ACT1940	SP1583	×	√
S-Class	221	Body	REAR SAM-Rear signal acquisition and actuation module	√	√	√	√	×	ACT1762,ACT1763,ACT1764,ACT1765,ACT1576,ACT1766,ACT1305,ACT1307,ACT0754,ACT1767,ACT1768,ACT1769,ACT1770,ACT1771,ACT1772,ACT1773,ACT1774,ACT1775,	×	×	√
S-Class	221	Body	RevETR LF-Left front reversible emergency tensioning retractor	√	√	√	√	×	ACT1955	×	×	×
S-Class	221	Body	RevETR LF-Left front reversible emergency tensioning retractor	√	√	√	√	×	ACT1975	×	×	×
S-Class	221	Body	RevETR RF-Right front reversible emergency tensioning	√	√	√	√	×	ACT1956	×	×	×
S-Class	221	Body	RevETR RF-Right front reversible emergency tensioning	√	√	√	√	×	ACT1975	×	×	×
S-Class	221	Body	SG BMS-Battery management system control unit	√	√	√	√	×	ACT1976,ACT1977,ACT1978,ACT1979,ACT1599	×	×	×
S-Class	221	Body	SG DDW-DC/DC converter control unit	√	√	√	√	×	×	×	×	×
S-Class	221	Body	System diagnosis(CAN)	√	√	√	√	×	×	×	×	×
S-Class	221	Body	TRM-Trailer recognition module (N28/1)	√	√	√	√	×	×	×	×	×
S-Class	221	Body	UCP-Upper control panel	√	√	√	√	×	ACT0509,ACT0507,ACT1728,ACT1729,ACT1730,ACT1731,ACT1732,ACT1733,ACT1734,ACT1735,ACT1736,ACT1737,ACT1738,ACT0509,ACT0507,ACT1739,ACT1740,ACT1741,ACT1742,ACT1743,ACT1744,ACT1745,ACT1746,ACT1747,	×	×	×

S-Class	221	Body	WSS-Weight sensing system	√	√	√	√	×	×	×	×	×
S-Class	221	Body	WSS-Weight sensing	√	√	√	√	×	×	×	×	×
S-Class	221	Body	XALWA L-Xenon headlamp, left	√	√	√	√	×	×	SP1251,SP1577	×	×
S-Class	221	Body	XALWA L-Xenon headlamp, left	√	√	√	√	×	ACT0549,ACT0550,ACT0551,ACT0552,ACT1855,ACT1856,ACT1857,ACT1858,ACT1859	×	×	×
S-Class	221	Body	XALWA L-Xenon headlamp, left	√	√	√	√	×	ACT0549,ACT0550,ACT0551,ACT0552,ACT1855,ACT1860,ACT1861,ACT1862,ACT1863	SP1577,SP1251	×	×
S-Class	221	Body	XALWA R-Xenon headlamp,	√	√	√	√	×	×	SP1251,SP1577	×	×
S-Class	221	Body	XALWA R-Xenon headlamp, right	√	√	√	√	×	ACT0553,ACT0554,ACT1864,ACT1858	×	×	×
S-Class	221	Body	XALWA R-Xenon headlamp, right	√	√	√	√	×	ACT0553,ACT0554,ACT1865,ACT1866	SP1577,SP1251	×	×
S-Class	221	Chassis	ABC-Active body control(N51/2)	√	√	√	√	×	ACT1606,ACT1607,ACT1608,ACT1609,ACT1610,ACT0502,ACT1185,ACT1186,ACT1230,	SP1564	×	×
S-Class	221	Chassis	ABR-Adaptive Brake	√	√	√	√	×	ACT0873	SP1388,SP1510	×	√
S-Class	221	Chassis	ABR-Adaptive Brake	√	√	√	√	×	ACT1690,ACT0483	SP1388,SP1561,SP1562,SP1563	×	√
S-Class	221	Chassis	AIRmatic	√	√	√	√	×	ACT0503,ACT0502,ACT1691,ACT0498,ACT0499,ACT0500,ACT0501,ACT1692,ACT0497,ACT1693,ACT0636,ACT0637,	SP1061	×	×
S-Class	221	Chassis	EHPS-Electrohydraulic Power Steering	√	√	√	√	×	×	×	×	×
S-Class	221	Chassis	EPB-Electric parking brake	√	√	√	√	×	ACT1684,ACT1685	SP1552,SP1553	×	×
S-Class	221	Chassis	RBS-Regenerative braking	√	√	√	√	×	×	SP1388,SP1510	×	√
S-Class	221	Chassis	TPM-Tire pressure monitor	√	√	√	√	×	ACT1601,ACT1602,ACT1603,ACT1604	×	×	×
S-Class	221	Chassis	TPM-Tire pressure monitor	√	√	√	√	×	ACT1686,ACT1687,ACT1688,ACT1689	SP1554,SP1555	×	×
S-Class	221	Drive	CDI 3-Common Rail Diesel Injection3	√	√	√	√	√	ACT1385,ACT1583,ACT0001,ACT0002,ACT0003,ACT0005,ACT0008,ACT0579,ACT0011,ACT0012,ACT0014,ACT1891,ACT0017,ACT0588,ACT0019,ACT1980,ACT1981,ACT0022,ACT1982,ACT0024,ACT1983,	SP1587,SP1588,SP1589,SP1284,SP1210,SP1278,SP1262,SP1259,SP1590,SP1591,SP1592,SP1593	×	×
S-Class	221	Drive	CDI 5-Common Rail Diesel	√	√	√	√	√	×	SP1212	×	×
S-Class	221	Drive	CDI 60LS-Common Rail Diesel Injection	√	√	√	√	√	ACT0026,ACT0586,ACT0002,ACT0472,ACT0005,ACT0578,ACT0587,ACT0579,ACT0580,ACT0032,ACT0588,ACT0024	SP1258,SP1284,SP1259,SP1262,SP1264,SP1211,SP1263,SP1265,SP1266,SP1267,SP1285,SP1271,SP1281,SP1210,SP1286,SP1275,SP1287,SP1278,	×	×
S-Class	221	Drive	DTR-Distronic	√	√	√	√	×	×	×	×	×
S-Class	221	Drive	DTR-Distronic	√	√	√	√	×	×	×	×	×

S-Class	221	Drive	ETC-Electronic transmission control	√	√	√	√	√	×	SP1217,SP1218,SP1219,SP1220,SP1221,SP1222,SP1223,SP1214,SP1224,SP1225,SP1226,SP1227,SP1228,SP1229,SP1214,SP1230,SP1231,SP1232,SP1233,SP1234,SP1235,	×	√
S-Class	221	Drive	ETC-Electronic transmission	√	√	√	√	√	ACT1017	×	×	×
S-Class	221	Drive	ETC-Electronic transmission	√	√	√	√	√	ACT1017	×	×	×
S-Class	221	Drive	FSCU-Fuel pump	√	√	√	√	×	ACT0320	×	×	×
S-Class	221	Drive	FSCU-Fuel pump	√	√	√	√	×	ACT0320	×	×	×
S-Class	221	Drive	FSCU-Fuel pump	√	√	√	√	×	ACT0320	×	×	×
S-Class	221	Drive	FSCU-Fuel pump	√	√	√	√	×	ACT0320	×	×	×
S-Class	221	Drive	FSCU-Fuel pump	√	√	√	√	×	ACT0320	×	×	×
S-Class	221	Drive	ISM-Intelligent servo module	√	√	√	√	×	ACT0490,ACT0491,ACT0492,ACT0493,ACT0494	×	×	×
S-Class	221	Drive	ISM-Shift module	√	√	√	√	×	ACT0490,ACT0495,ACT0492,ACT0493,ACT0494	SP1241	×	×
S-Class	221	Drive	ME 2.7.2-Motor electronics 2.7.2	√	√	√	√	×	ACT1348,ACT0468,ACT0005,ACT0469,ACT0470,ACT1502,ACT0472,ACT0473,ACT1888,ACT0335,ACT0481	SP1210,SP1212,SP1534,SP1578,SP1536	×	×
S-Class	221	Drive	ME 2.7.2-Motor electronics 2.7.2	√	√	√	√	×	ACT1348,ACT0468,ACT0005,ACT0469,ACT0470,ACT1502,ACT0472,ACT0473,ACT1888,ACT0335,ACT0481	SP1210,SP1212,SP1534,SP1578,SP1536	×	×
S-Class	221	Drive	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	√	√	√	√	√	ACT0467,ACT0468,ACT1365,ACT1366,ACT0469,ACT0470,ACT0471,ACT0472,ACT0473,ACT0474,ACT0475,ACT0476,ACT0477,ACT0478,ACT1367,ACT0480,ACT0000,ACT0481,	SP1210,SP1211,SP1212,SP1516,SP1214,SP1215,SP1216	×	×
S-Class	221	Drive	ME 9.7-Motor electronics 9.7	√	√	√	√	√	ACT0467,ACT0468,ACT0005,ACT0002,ACT0469,ACT0470,ACT0471,ACT0472,ACT0473,ACT0474,ACT0475,ACT0476,ACT0477,ACT0478,ACT0479,ACT0480,ACT0000,ACT0481	SP1210,SP1211,SP1212,SP1213,SP1214,SP1215,SP1216	×	√
S-Class	221	Drive	ME SF 17.7-Motor electronics 17.7	√	√	√	√	√	ACT1348,ACT0468,ACT0005,ACT0002,ACT0469,ACT0481,ACT0471,ACT0472,ACT1369,ACT0474,ACT0475,ACT0476,ACT0477,ACT0478,ACT0479,ACT0480,ACT0022,ACT1370	SP1210,SP1211,SP1212,SP1213,SP1214,SP1215,SP1216	×	×
S-Class	221	Drive	MED 17.7-Motor electronics for direct injection 17.7	√	√	√	√	√	ACT0002,ACT0472,ACT0005,ACT1889,ACT1890,ACT0335,ACT0480,ACT0708,ACT0707,ACT0476,ACT0475,ACT0478,ACT0477,ACT0469,ACT0470,ACT0025,ACT1891,ACT0017,ACT0709,ACT0328,ACT1892,	SP1210,SP1211,SP1212,SP1213,SP1579,SP1580,SP1214,SP1215,SP1581,SP1216,SP1582,SP1017,SP1258	×	×

S-Class	221	Drive	SCR-Selective Catalytic Reduction	√	√	√	√	×	ACT0581,ACT0582,ACT0583,ACT0584,ACT0585	SP1279,SP1280,SP1281,SP1282,SP1283	×	×
S-Class	221	Drive	SG EM-Electric motor control	√	√	√	√	×	ACT1599	SP1585,SP1586	×	×
S-Class	221	Drive	SGR-Radar sensors control unit	√	√	√	√	×	ACT1695	×	×	×
S-Class	221	Driver assistance	SGR-Radar sensors control unit	√	√	√	√	×	×	×	×	×
S-Class	221	Driver assistance system	SGR-Radar sensors control unit	√	√	√	√	×	×	SP1333,SP1334,SP1335,SP1167	×	√
S-Class	221	Information and communication	ASSYST PLUS	√	√	√	√	×	×	SP1541,SP1542,SP1045	×	×
S-Class	221	Information and communication	ASSYST-Active Service System	√	√	√	√	×	×	SP1572,SP1573	×	×
S-Class	221	Information and communication	AVE H-Rear audio video unit	√	√	√	√	×	ACT1957,ACT1958,ACT1959,ACT1960	×	×	×
S-Class	221	Information and communication	AVE H-Rear audio video unit	√	√	√	√	×	ACT1961,ACT1962,ACT1963,ACT1964,ACT1965,ACT1966	×	×	×
S-Class	221	Information and communication	COMAND	√	√	√	√	×	ACT1867,ACT1868,ACT1869,ACT0097,ACT1870,ACT1871,	×	×	×
S-Class	221	Information and communication	COMAND	√	√	√	√	×	ACT1870,ACT0083,ACT1867,ACT1868,ACT1869,ACT0097,ACT1873,ACT1874,ACT1875,ACT1876,ACT1877,ACT0101	×	×	×
S-Class	221	Information and communication	CTEL-Mobile phone adapter with universal interface	√	√	√	√	×	ACT1885,ACT1886	×	×	×
S-Class	221	Information and communication	DAB-Digital radio	√	√	√	√	×	×	×	×	×
S-Class	221	Information and communication	IC-Instrument cluster	√	√	√	√	×	ACT1683,ACT1390,ACT1337,ACT0488,ACT1599,ACT1600	×	×	×
S-Class	221	Information and communication	ICI-InCar Internet(N125/3)	√	√	√	√	×	×	×	×	×
S-Class	221	Information and communication	Left rear screen	√	√	√	√	×	ACT0568,ACT0569,ACT0570,ACT0571,ACT0572	×	×	×
S-Class	221	Information and communication	MFK-Multifunction camera	√	√	√	√	×	×	×	×	×
S-Class	221	Information and communication	NSA-Night View Assist	√	√	√	√	×	ACT1696,ACT1697,ACT1698	×	×	×
S-Class	221	Information and communication	PTS-Parktronic system	√	√	√	√	×	ACT1827	×	×	×
S-Class	221	Information and communication	PTS-PARKTRONIC(N62)	√	√	√	√	×	ACT1827	×	×	×
S-Class	221	Information and communication	RFK-Backup camera	√	√	√	√	×	×	×	×	×
S-Class	221	Information and communication	Right rear screen	√	√	√	√	×	ACT0573,ACT0569,ACT0574,ACT0575,ACT0576	×	×	×
S-Class	221	Information and communication	SCM [MRM]-Steering column module	√	√	√	√	×	ACT1825	SP1077	×	×
S-Class	221	Information and communication	SDAR-Satellite radio(Valid for USA)	√	√	√	√	×	×	×	×	×
S-Class	221	Information and communication	TELE AID-Control unit	√	√	√	√	×	×	×	×	×
S-Class	221	Information and communication	TELE AID-Telematic services Emergency call	√	√	√	√	×	×	×	×	×

S-Class	221	Information and communication	TELE AID-Telematic services MB Info,Roadside assistance(USA, Canada),Tele	√	√	√	√	×	×	×	×	×
S-Class	221	Information and communication	TELE AID-Telematic services Remote door unlocking,Remote door locking	√	√	√	√	×	×	×	×	×
S-Class	221	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	√	√	√	√	×	×	×	×	×
S-Class	221	Information and communication	Tuner-Standard tuner	√	√	√	√	×	ACT1878,ACT1879,ACT1880,ACT1881,ACT1882,ACT0135	×	×	×
S-Class	221	Information and communication	Tuner-Tuner sound	√	√	√	√	×	ACT1878,ACT1879,ACT1880,ACT1881,ACT1882,ACT0135	×	×	×
S-Class	221	Information and communication	Tuner-Tuner sound	√	√	√	√	×	ACT1878,ACT1879,ACT1880,ACT1881,ACT1882,ACT0135	×	×	×
S-Class	221	Information and communication	TV-TV tuner(AGW)	√	√	√	√	×	×	×	×	×
S-Class	221	Information and communication	TV-TV tuner(AGW)	√	√	√	√	×	×	×	×	×
S-Class	221	Information and communication	UCI-Media interface	√	√	√	√	×	×	×	×	×
S-Class	221	Information and communication	VC-Voice control	√	√	√	√	×	ACT1883,ACT1884	×	×	×
S-Class	221	Information and communication	ZAN-Central display	√	√	√	√	×	ACT1887,ACT1337	×	×	×
S-Class	221	Seats and Doors	DCM FL-Door control module front left	√	√	√	√	×	ACT1414,ACT1804,ACT0522,ACT1416,ACT0523,ACT1805,ACT0256,ACT1499,ACT1329,ACT1806,ACT1807,ACT0527,ACT0526,ACT1808,ACT1809,ACT1499,ACT1810,ACT1811,	SP1566	×	√
S-Class	221	Seats and Doors	DCM FR-Door control module front right	√	√	√	√	×	ACT1414,ACT1804,ACT0522,ACT1416,ACT0523,ACT1805,ACT0256,ACT1499,ACT1329,ACT1806,ACT1807,ACT0531,ACT1813,ACT1814,ACT1809,ACT1499,ACT1810,ACT1811,	SP1566	×	×
S-Class	221	Seats and Doors	DCM RL-Door control module rear left	√	√	√	√	×	ACT1414,ACT1941,ACT1329,ACT1942,ACT1806,ACT1807,ACT1943,ACT1944,ACT1809,ACT1945,ACT1946,ACT1947	SP1566	×	×
S-Class	221	Seats and Doors	DCM RR-Door control module rear right	√	√	√	√	×	ACT1414,ACT1941,ACT1329,ACT1942,ACT1806,ACT1807,ACT1948,ACT1949,ACT1809,ACT1945,ACT1946,ACT1947	SP1566	×	×
S-Class	221	Seats and Doors	DS LF-Left front dynamic seat	√	√	√	√	×	ACT1785,ACT1786,ACT0532,ACT1787,ACT1788,ACT1789,ACT1790,ACT1791,ACT1792,ACT1793,ACT1794,ACT1795,ACT1796,ACT1797,ACT1798,ACT1799,ACT1800,ACT1801,	×	×	√
S-Class	221	Seats and Doors	DS LF-Left front dynamic seat	√	√	√	√	×	ACT1785,ACT1786,ACT1787,ACT1974,ACT1788,ACT1789,	×	×	√

S-Class	221	Seats and Doors	DS RF-Right front dynamic seat	√	√	√	√	×	ACT1785,ACT1786,ACT0532,ACT1787,ACT1788,ACT1789,ACT1790,ACT1791,ACT1792,ACT1793,ACT1794,ACT1795,ACT1796,ACT1797,ACT1798,ACT1799,ACT1800,ACT1801,	×	×	√
S-Class	221	Seats and Doors	DS RF-Right front dynamic seat	√	√	√	√	×	ACT1785,ACT1786,ACT1787,ACT1974,ACT1788,ACT1789,	×	×	√
S-Class	221	Seats and Doors	DSP-Pneumatic pump for dynamic seat	√	√	√	√	×	ACT1803	×	×	×
S-Class	221	Seats and Doors	ESA FL-Electric seat adjustment front left	√	√	√	√	×	ACT1469,ACT1471,ACT1470,ACT1818,ACT1472,ACT1473,ACT1819,ACT1820,ACT1821,ACT1822,ACT1823,ACT1824	SP1567,SP1568,SP1569,SP1570,SP1571	×	×
S-Class	221	Seats and Doors	ESA FR-Electric seat adjustment front right	√	√	√	√	×	ACT1469,ACT1471,ACT1470,ACT1818,ACT1472,ACT1473,ACT1819,ACT1820,ACT1821,ACT1822,ACT1823,ACT1824	SP1567,SP1568,SP1569,SP1570,SP1571	×	×
S-Class	221	Seats and Doors	ESA R-Electric seat adjustment rear	√	√	√	√	×	ACT1950,ACT1906,ACT1951,ACT0545,ACT1952,ACT1821,ACT1950,ACT1907,ACT1953,ACT0546,ACT1954,ACT1821	SP1584	×	×
S-Class	221	Seats and Doors	MKL HL-Rear left multicontour backrest	√	√	√	√	×	ACT0532,ACT1788,ACT1790,ACT1789,ACT1796,ACT1797,ACT1798,ACT1799,ACT1800,ACT1801,ACT1802	×	×	√
S-Class	221	Seats and Doors	MKL HR-Rear right multicontour backrest	√	√	√	√	×	ACT0532,ACT1788,ACT1790,ACT1789,ACT1796,ACT1797,ACT1798,ACT1799,ACT1800,ACT1801,ACT1802	×	×	√
S-Class	221	Seats and Doors	TLC-Trunk lid control	√	√	√	√	×	ACT1235	×	×	×
S-Class	221	Seats and Doors	TLC-Trunk lid control	√	√	√	√	×	ACT1826	×	×	×
S-Class	221	Seats and Doors	TSG ML-Left center door control unit (interior Can bus)	√	√	√	√	×	ACT1967,ACT1968,ACT0507,ACT1969,ACT1970,ACT1971	×	×	×
S-Class	221	Seats and Doors	TSG MR-Right center door control unit (interior Can bus)	√	√	√	√	×	ACT1967,ACT1968,ACT0507,ACT1972,ACT1973,ACT1971	×	×	×
S-Class	222	Air conditioning	AAC-Automatic air conditioning	√	√	√	×	×	×	×	×	×
S-Class	222	Air conditioning	AAC-Automatic air conditioning	√	√	√	×	×	×	×	×	×
S-Class	222	Air conditioning	AAC-Automatic air conditioning	√	√	√	×	×	×	×	×	×

S-Class	222	Air conditioning	AAC-Automatic air conditioning	√	√	√	√	×	ACT0182,ACT0417,ACT0183,ACT0771,ACT0772,ACT0204,ACT0773,ACT0003,ACT0186,ACT0190,ACT0665,ACT0774,ACT0189,ACT0775,ACT0776,ACT0188,ACT0777,ACT0778,ACT0779,ACT0663,ACT0780,ACT0662,ACT0781,ACT0782,ACT0783,ACT0784,ACT0785,ACT0786,ACT0787,ACT0788,ACT0655,ACT0656,ACT0781,ACT0782,ACT0783,ACT0784,ACT0785,ACT0786,ACT0787,ACT0788,ACT0789,ACT0790,ACT0781,ACT0782,ACT0783,ACT0784,ACT0785,ACT0786,ACT0788,ACT0652,ACT0655,ACT0656,ACT0781,ACT0782,ACT0786,ACT0787,ACT0789,ACT0790,ACT0194,ACT0647,ACT0648,ACT0649,ACT0650,ACT0653,ACT0654,ACT0791,ACT0792,ACT0793,ACT0794,	SP1066,SP1065,SP1067,SP1360,SP1159	×	×
S-Class	222	Air conditioning	N61 (Windshield heater control	√	√	√	×	×	×	×	×	×
S-Class	222	Air conditioning	STH-Stationary heater	√	√	√	√	×	ACT0200,ACT0201,ACT1031,ACT1205,ACT0203	×	×	×
S-Class	222	Air conditioning	STH-Stationary heater	√	√	√	√	×	ACT1030,ACT0202,ACT1118	×	×	×
S-Class	222	Air conditioning	TSTH-Radio remote control of stationary heater	√	√	√	√	×	ACT0203,ACT0418	×	×	×
S-Class	222	Body	AGS-Active bell buckle	√	√	√	√	×	ACT0805,ACT0806,ACT0807,ACT0808	×	×	×
S-Class	222	Body	AIRSCARF-Neck heating system(N25/7)	√	√	√	√	×	ACT1113	×	×	×
S-Class	222	Body	AML-Ambiance light	√	√	√	√	×	ACT0389,ACT0390,ACT0391,ACT0392,ACT0393,ACT0394,ACT0395,ACT0396,ACT0043	SP1149	×	×
S-Class	222	Body	AMLAB-L (Actuation module, LED exterior lighting, left front)	√	√	√	√	×	×	×	×	×
S-Class	222	Body	AMLAB-L (Actuation module, LED exterior lighting, left front)	√	√	√	√	×	ACT0299,ACT0300	SP1448	×	×
S-Class	222	Body	AMLAB-R (Actuation module, LED exterior lighting, right front)	√	√	√	√	×	×	×	×	×
S-Class	222	Body	AMLAB-R (Actuation module, LED exterior lighting, right front)	√	√	√	√	×	ACT0299,ACT0300	SP1447	×	×
S-Class	222	Body	Anti glare interior rearview mirror(DBE)	√	√	√	√	×	×	×	×	×
S-Class	222	Body	Anti glare interior rearview mirror(SAM)	√	√	√	√	×	×	×	×	×
S-Class	222	Body	AS-Alarm siren(H3/1)	√	√	√	√	×	ACT0309,ACT0465,ACT0466	×	×	×
S-Class	222	Body	ATA-ATA[EDW]/tow-away protection/interior protection	√	√	√	√	×	ACT0075,ACT0465	×	×	×
S-Class	222	Body	AU-Analog clock	√	√	√	×	×	×	×	×	×

S-Class	222	Body	BMS-Battery management system	√	√	√	√	×	ACT0453,ACT0454,ACT0455	SP1197	×	×
S-Class	222	Body	BMS-Battery management system	√	√	√	√	×	ACT0778,ACT1120	SP1386,SP1193	×	×
S-Class	222	Body	BMS-Battery management system	√	√	√	√	×	ACT1121,ACT0453,ACT0410,ACT0604	SP1197	×	×
S-Class	222	Body	BSN-Battery sensor(B95)	√	√	√	√	×	×	×	×	×
S-Class	222	Body	BSN-Battery sensor(B95)	√	√	√	√	×	×	×	×	×
S-Class	222	Body	Button group, instrument panel, center	√	√	√	√	×	×	×	×	×
S-Class	222	Body	Button group, instrument panel, driver side	√	√	√	√	×	×	×	×	×
S-Class	222	Body	DC/DC-DC/DC converter	√	√	√	√	×	×	×	×	×
S-Class	222	Body	DC/DC-DC/DC converter	√	√	√	√	×	×	SP1324	×	×
S-Class	222	Body	EZS-Electronic ignition lock	√	√	√	√	×	×	×	×	×
S-Class	222	Body	EZS-Electronic ignition lock	√	√	√	√	×	ACT1054	×	×	×
S-Class	222	Body	FLANFS-Fire extinguishing system and emergency fresh air system	√	√	√	√	×	ACT1218,ACT1219,ACT1220,ACT1221,ACT1222,ACT1223,ACT1224,ACT1225	×	×	×
S-Class	222	Body	FSW-Windshield wiper	√	√	√	√	×	ACT1174	×	×	×
S-Class	222	Body	GTO-Garage door	√	√	√	√	×	×	×	×	×
S-Class	222	Body	GTO-Garage door	√	√	√	√	×	×	×	×	×
S-Class	222	Body	IRSS-FOL-Left rear interior protection sensor	√	√	√	×	×	ACT1117	×	×	×
S-Class	222	Body	IRSS-FOR-Right rear interior protection sensor	√	√	√	×	×	ACT1116	×	×	×
S-Class	222	Body	IRSS-VL-Left front interior protection sensor	√	√	√	×	×	ACT1114	×	×	×
S-Class	222	Body	IRSS-VR-Right front interior protection sensor	√	√	√	×	×	ACT1115	×	×	×
S-Class	222	Body	KG-Keyless Go	√	√	√	√	×	ACT0131,ACT0132	×	×	×
S-Class	222	Body	KG-Keyless Go	√	√	√	√	×	ACT0131,ACT0132	×	×	×
S-Class	222	Body	LIB-Lithium ion battery	√	√	√	√	×	×	×	×	×
S-Class	222	Body	LIB-Lithium ion battery	√	√	√	√	×	×	×	×	×
S-Class	222	Body	LIB-Lithium ion battery	√	√	√	√	×	×	×	×	×
S-Class	222	Body	LRE-Steering wheel electronics	√	√	√	√	×	×	×	×	×
S-Class	222	Body	MSC-MAGIC SKY CONTROL	√	√	√	√	×	ACT0872	×	×	×
S-Class	222	Body	Multifunction control unit-Multifunction control unit	√	√	√	√	×	×	×	×	×
S-Class	222	Body	Multifunction control unit-Multifunction control unit	√	√	√	√	×	ACT0204	×	×	×
S-Class	222	Body	N25/6 (Rear passenger compartment seat heater control	√	√	√	√	×	×	×	×	×
S-Class	222	Body	N38 (Rear switching module)	√	√	√	√	×	×	×	×	×

S-Class	222	Body	N5 (Armrest heater control unit)	√	√	√	√	×	ACT0817,ACT0818,ACT0819,ACT0820,ACT0821,ACT0822,ACT0823,ACT0824,ACT0825,ACT0826,ACT0827,ACT0828,ACT0829,ACT0830,ACT0831,ACT0832,ACT0833,ACT0834,ACT0829,ACT0830,ACT0831,ACT0835,ACT0836,ACT0837,ACT0838,ACT0829,ACT0835,ACT0836,ACT0837,ACT0838,ACT0839,ACT0840,ACT0841,ACT0842,ACT0843,ACT0844,ACT0845,ACT0846,ACT0847,ACT0848,ACT0829,ACT0832,ACT0839,ACT0840,ACT0841,ACT0842,ACT0843,ACT0844,	SP1364,SP1365	×	×
S-Class	222	Body	OCP-Overhead control panel	√	√	√	√	×	ACT1093,ACT0302,ACT1094,ACT0303,ACT0304,ACT1112	×	×	×
S-Class	222	Body	OCP-Overhead control panel	√	√	√	√	×	ACT1093,ACT1094,ACT0303,ACT0302,ACT1095,ACT1096,ACT1097,ACT1098,ACT1099,ACT0465,ACT1100	SP1441	×	×
S-Class	222	Body	PSD-Control module Panoramic sliding roof	√	√	√	√	×	ACT0207,ACT1091,ACT1092	SP1072	×	×
S-Class	222	Body	RevETR LF-Left front reversible emergency tensioning retractor	√	√	√	√	×	ACT0209	×	×	×
S-Class	222	Body	RevETR RF-Right front reversible emergency tensioning	√	√	√	√	×	ACT0213	×	×	×
S-Class	222	Body	RGLS-Rain/light sensor(B38/2)	√	√	√	√	×	×	×	×	×
S-Class	222	Body	RGLS-Rain/light sensor(B38/2)	√	√	√	√	×	×	×	×	×
S-Class	222	Body	SAMF-Front signal acquisition and actuation module(N10/6)	√	√	√	√	×	ACT0729,ACT0730,ACT0731,ACT0732,ACT0344,ACT0507,ACT0733,ACT0675,ACT0734,ACT0676,ACT0735,ACT0736,ACT0737,ACT0738,ACT0465,ACT0739,ACT0740,ACT0741,ACT0742,ACT0743,ACT0744,	×	×	×
S-Class	222	Body	SAMF-Front signal acquisition and actuation module(N10/6)	√	√	√	√	×	ACT1066,ACT1067,ACT1068,ACT0729,ACT0730,ACT0344,ACT0507,ACT0734,ACT0733,ACT0675,ACT0676,ACT0735,ACT1069,ACT1070,ACT1071,ACT1072,ACT0909,ACT0465,	×	×	×
S-Class	222	Body	SAMR-Rear signal acquisition and actuation module(N10/8)	√	√	√	√	×	ACT0747,ACT0240,ACT0748,ACT0749,ACT0750,ACT0731,ACT0751,ACT0752,ACT0753,ACT0754,ACT0755,ACT0756,ACT0757,ACT0758,ACT0759,ACT0760,ACT0761,ACT0762,ACT0763,ACT0764,ACT0765,ACT0766,ACT0767,ACT0768,	×	×	×

S-Class	222	Body	SAMR-Rear signal acquisition and actuation module(N10/8)	√	√	√	√	×	ACT0747,ACT1073,ACT0240,ACT1074,ACT1075,ACT0891,ACT0890,ACT0751,ACT0752,ACT0754,ACT1076,ACT1077,ACT1078,ACT1079,ACT1080,ACT1081,ACT0761,ACT1082,ACT0760,ACT1083,ACT0768,ACT0765,ACT1084,ACT1085,ACT0908,ACT0769,ACT0802,	×	×	×
S-Class	222	Body	SCM-Steering column module(N80)	√	√	√	√	×	ACT0060,ACT0061,ACT0062,ACT0063,ACT0064,ACT0065	×	×	×
S-Class	222	Body	SCM-Steering column module(N80)	√	√	√	√	×	ACT0060,ACT0061,ACT0062,ACT0063,ACT0064,ACT0065	×	×	×
S-Class	222	Body	SG FOND-Rear control unit	√	√	√	√	×	ACT1101,ACT1102,ACT0362,ACT0363,ACT0369,ACT0370,ACT0926,ACT1103,ACT0948,ACT1104,ACT1105,ACT1106,	SP1442,SP1443,SP1444	×	×
S-Class	222	Body	SG LG-Charger	√	√	√	√	×	ACT0405,ACT0406,ACT0407,ACT0408,ACT0409,ACT0410	×	×	×
S-Class	222	Body	SG LG-Charger	√	√	√	√	×	ACT0405,ACT0406,ACT0407,ACT0408,ACT0611,ACT0410	×	×	×
S-Class	222	Body	SG LML VL-LED matrix of left front lamp unit	√	√	√	√	×	ACT0299,ACT0815,ACT0816,ACT0300	SP1089,SP1361	×	×
S-Class	222	Body	SG SW L-Left headlamp	√	√	√	√	×	×	×	×	×
S-Class	222	Body	SG SW L-Left headlamp	√	√	√	√	×	ACT0292,ACT0293,ACT0297,ACT0298,ACT0299,ACT0300	SP1445,SP1088,SP1089,SP1090,SP1094	×	×
S-Class	222	Body	SG SW R-Right headlamp	√	√	√	√	×	×	×	×	×
S-Class	222	Body	SG SW R-Right headlamp	√	√	√	√	×	ACT0292,ACT0293,ACT0297,ACT0298,ACT0299,ACT0300	SP1362,SP1096,SP1097	×	×
S-Class	222	Body	SG-LML-VR-LED matrix of right front lamp unit	√	√	√	√	×	ACT0299,ACT0815,ACT0300,ACT0816	SP1362,SP1363	×	×
S-Class	222	Body	SOGESTAR2-Sound generator for electric vehicle	√	√	√	√	×	×	×	×	×
S-Class	222	Body	SRS-Supplemental restraint	√	√	√	√	×	×	×	×	×
S-Class	222	Body	SRS-Supplemental restraint	√	√	√	√	√	×	×	×	×
S-Class	222	Body	STM-Mirror taximeter	√	√	√	√	×	×	×	×	×
S-Class	222	Body	Trailer recognition module-Trailer recognition	√	√	√	√	×	×	×	×	×
S-Class	222	Body	Trailer recognition module-Trailer recognition	√	√	√	√	×	×	×	×	×
S-Class	222	Body	WSS-Weight sensing	√	√	√	√	×	×	×	×	×
S-Class	222	Chassis	ABC-Active body control(N51/2)	√	√	√	√	×	ACT0631,ACT0630,ACT1177,ACT1178,ACT1179,ACT1180,ACT1181,ACT1182,ACT1183,ACT1184,ACT1185,ACT1186,	SP1478,SP1479,SP1061,SP1480,SP1481,SP1482,SP1483	×	×
S-Class	222	Chassis	ADS-Adaptive damping system(N51/5)	√	√	√	√	×	ACT0628,ACT1119,ACT0631,ACT0630,ACT0632,ACT0633,ACT0634,ACT0635,ACT0167,ACT0168,ACT0169,ACT0170,ACT0636,ACT0637,ACT0639,	SP1061,SP1339	×	×
S-Class	222	Chassis	AMG DRVU-AMG DRIVE UNIT	√	√	√	√	×	ACT0401,ACT0402,ACT0403,ACT0404	SP1153,SP1154,SP1155	×	×

S-Class	222	Chassis	EFB-Electric parking brake	√	√	√	√	×	ACT0285,ACT0286,ACT0287,ACT0288	SP1081	×	×
S-Class	222	Chassis	ES - Electric power steering	√	√	√	√	×	×	SP1071	×	×
S-Class	222	Chassis	ES - Electric power steering	√	√	√	√	×	×	SP1071,SP1167	×	×
S-Class	222	Chassis	ES - Electric power steering	√	√	√	√	×	×	SP1346,SP1167	×	×
S-Class	222	Chassis	ESP-Electric stability program(N30/4)	√	√	√	√	√	ACT0069,ACT0070,ACT0612,ACT0285,ACT0286,ACT0287,ACT0288	SP1174,SP1175,SP1176,SP1177,SP1178,SP1179,SP1180,SP1181,SP1367,	×	×
S-Class	222	Chassis	ESP-Electric stability program(N30/4)	√	√	√	√	×	ACT0612,ACT0698,ACT0069,ACT0070,ACT1188	SP1051,SP1330,SP1331,SP1389	×	×
S-Class	222	Drive	FSCU-Control unit Fuel pump	√	√	√	√	×	ACT0252,ACT0320	×	×	×
S-Class	222	Drive	HPPM-Haptic accelerator pedal module	√	√	√	√	×	ACT1110,ACT1111	×	×	×
S-Class	222	Drive	ISG-Integrated starter alternator	√	√	√	√	×	×	×	×	×
S-Class	222	Drive	ISG-Integrated starter alternator	√	√	√	√	×	×	SP1368	×	×
S-Class	222	Drive	ISM-Shift module	√	√	√	√	×	ACT0670,ACT0671,ACT0318	SP1345,SP1346,SP1446	×	×
S-Class	222	Drive	N127 (Drivetrain control unit)	√	√	√	√	×	ACT0028,ACT0430,ACT0431,ACT0432,ACT0433,ACT0007,ACT0434,ACT0435,ACT0436,ACT0437,ACT0438,ACT0439,ACT0440,ACT0441,ACT0442,ACT0443,ACT0444,ACT0445,ACT0446,ACT0447,ACT0448,	SP1186,SP1042,SP1025,SP1187,SP1188,SP1189,SP1190,SP1191,SP1192	×	×
S-Class	222	Drive	N127 (Drivetrain control unit)	√	√	√	√	×	ACT0038,ACT0028,ACT0441,ACT0440,ACT0007,ACT0434,ACT0436,ACT0431,ACT0439,ACT0438,ACT0434,ACT0437	SP1382	×	×
S-Class	222	Drive	N3/10-Motor electronics "ME1778" for combustion engine "M279"	√	√	√	√	×	ACT0002,ACT0003,ACT0005,ACT0335,ACT0325,ACT0326,ACT0016,ACT0939,ACT0955,ACT0956,ACT0329,ACT0958	SP1001,SP1004,SP1117	×	×
S-Class	222	Drive	N3/10-Motor electronics "MED177" for combustion engine "M276"	√	√	√	√	√	ACT0005,ACT0002,ACT0003,ACT0335,ACT0480,ACT0463,ACT0705,ACT0464,ACT0706,ACT0325,ACT0326,ACT0025,ACT0016,ACT0707,ACT0708,ACT0017,ACT0441,ACT0709,	SP1108,SP1109,SP1017,SP1110,SP1115,SP1001,SP1459,SP1202,SP1113,SP1004,SP1352,SP1000	×	×
S-Class	222	Drive	N3/10-Motor electronics "MED1775" for combustion engine "M178"	√	√	√	√	√	ACT0002,ACT0028,ACT0431,ACT0432,ACT0433,ACT0864,ACT0865,ACT0435,ACT0480,ACT0476,ACT0475,ACT0478,ACT0477,ACT0326,ACT0866,ACT0867,ACT0436,ACT0025,ACT0868,ACT0712,ACT0713,	SP1017,SP1109,SP1110,SP1369,SP1370,SP1371,SP1112,SP1202,SP1203,SP1001,SP1187,SP1372,SP1201,SP1000	×	×
S-Class	222	Drive	N3/10-Motor electronics "MED177V6LA" for combustion engine "M276Turbocharger"	√	√	√	√	√	ACT0005,ACT0002,ACT0003,ACT0335,ACT0480,ACT0463,ACT0705,ACT0464,ACT0706,ACT0325,ACT0326,ACT0025,ACT0016,ACT0017,ACT0441,ACT0709,ACT0022,ACT0712,	SP1109,SP1110,SP1108,SP1017,SP1369,SP1371,SP1370,SP1112,SP1203,SP1202,SP1113,SP1352,SP1004,SP1001,SP1201,SP1000	×	×

S-Class	222	Drive	N3/10-Motor electronics "MED41" for combustion engine "M260/M264"	√	√	√	√	√	ACT0330,ACT0003,ACT0459,ACT0323,ACT0324,ACT0333,ACT0025,ACT0328,ACT0331,ACT0332,ACT0004,ACT0005,ACT0456,ACT0002,ACT0460,ACT0329,ACT0022,ACT0325,	SP1199,SP1117	×	×
S-Class	222	Drive	N3/10-Motor electronics "MRG1" for combustion engine "M256"	√	√	√	√	√	ACT0002,ACT0025,ACT0005,ACT0022,ACT0456,ACT0329,ACT0325,ACT0328,ACT0323,ACT0324,ACT0460,ACT0871,	SP1001,SP1004,SP1201,SP1202,SP1203,SP1110,SP1109,SP1139,SP1017,SP1371,SP1112,SP1000	×	×
S-Class	222	Drive	N3/40-Motor electronics "MRD1" for combustion engine "OM654"	√	√	√	√	√	ACT0001,ACT0005,ACT0006,ACT0321,ACT0008,ACT0009,ACT0010,ACT0322,ACT0011,ACT0012,ACT0016,ACT0018,ACT0022,ACT0023,ACT0024,ACT0026,ACT0000,ACT0338,ACT0339,ACT0340,ACT0341	SP1001,SP1000,SP1130,SP1125,SP1131,SP1132,SP1133,SP1134,SP1135,SP1136,SP1017,SP1137,SP1138,SP1024,SP1139,SP1140,SP1015,SP1141,SP1142,SP1143,SP1144,SP1021,SP1022,SP1145,	×	×
S-Class	222	Drive	N3/9-Motor electronics "CDI61" for combustion engine "OM642"	√	√	√	√	√	ACT0033,ACT0026,ACT0005,ACT0002,ACT0028,ACT0008,ACT0010,ACT0011,ACT0024,ACT0012,ACT0016,ACT0018	SP1468,SP1000,SP1001,SP1002,SP1004,SP1295,SP1135,SP1009,SP1294,SP1012,SP1013,SP1298,SP1144,SP1296,SP1297,SP1137,SP1015,SP1016,SP1020,SP1128,SP1021,SP1022,SP1023,SP1017,	×	×
S-Class	222	Drive	N3/9-Motor electronics "CR43" for combustion engine "OM651"	√	√	√	√	×	ACT0026,ACT0000,ACT0589,ACT0330,ACT0005,ACT0003,ACT0008,ACT0011,ACT0010,ACT0022,ACT0012,ACT0016,ACT0017,ACT0018,ACT0019,	SP1000,SP1001,SP1003,SP1004,SP1410,SP1290,SP1291,SP1123,SP1292,SP1293,SP1294,SP1012,SP1013,SP1144,SP1015,	×	×
S-Class	222	Drive	SCR-Selective catalytic reduction	√	√	√	√	×	ACT0424,ACT0425,ACT0426,ACT0427,ACT0428,ACT0429	SP1184,SP1185	×	×
S-Class	222	Drive	SCR-Selective catalytic reduction	√	√	√	√	×	ACT0424,ACT0602,ACT0425,ACT0426,ACT0427,ACT0598	SP1185,SP1322,SP1184,SP1319,SP1318,SP1023	×	×
S-Class	222	Drive	SG EM-Power electronics	√	√	√	√	×	ACT0451,ACT0452	SP1193,SP1194,SP1195,SP1196,SP1150	×	×
S-Class	222	Drive	SG EM-Power electronics	√	√	√	√	×	ACT0451,ACT0452	SP1193,SP1323,SP1458	×	×
S-Class	222	Drive	SG EM-Power electronics	√	√	√	√	×	ACT1226	SP1193,SP1323,SP1324	×	×
S-Class	222	Drive	VG-All-wheel drive	√	√	√	√	×	ACT0422,ACT0423	SP1099,SP1170	×	×
S-Class	222	Drive	Y3/8n4-Fully integrated transmission control	√	√	√	√	√	ACT0592,ACT0318	SP1299,SP1300,SP1301,SP1302,SP1303,SP1304,SP1233,SP1305,SP1306,SP1306,SP1307,SP1308,SP1309,SP1002,SP1310,	×	×
S-Class	222	Drive	Y3/8n4-Transmission control for 9 speed transmission	√	√	√	√	√	ACT0592,ACT0312,ACT0593,ACT0714,ACT0317	SP1311,SP1315,SP1316,SP1305,SP1355,SP1312,SP1356,SP1300,SP1357,SP1358,SP1359,SP1317	×	×
S-Class	222	Driver assistance system	CAMERA-360 camera(N148)	√	√	√	√	×	×	SP1337,SP1205,SP1206,SP1207,SP1208,SP1209	×	×
S-Class	222	Driver assistance	DTR-DISTRONIC	√	√	√	√	×	×	×	×	×

S-Class	222	Driver assistance	DTR-DISTRONIC	√	√	√	√	×	×	×	×	×
S-Class	222	Driver assistance	DTR-DISTRONIC	√	√	√	√	×	×	SP1161,SP1162	×	×
S-Class	222	Driver assistance system	IRS HLA-Outer left rear integrated radar sensor (B92/11)	√	√	√	√	×	×	SP1473	×	×
S-Class	222	Driver assistance system	IRS HRA-Outer right rear integrated radar sensor (B92/6)	√	√	√	√	×	×	SP1474	×	×
S-Class	222	Driver assistance	KAB-Control unit Camera cover	√	√	√	√	×	ACT0310,ACT0311	×	×	×
S-Class	222	Driver assistance system	MFK-Multifunction camera(mono)(A40/11)	√	√	√	√	×	ACT0181,ACT0065	SP1063	×	×
S-Class	222	Driver assistance system	MFK-Multifunction camera(mono)(A40/11)	√	√	√	√	×	ACT0181,ACT0065	SP1156	×	×
S-Class	222	Driver assistance system	MFK-Multifunction camera(stereo)(A40/13)	√	√	√	√	×	ACT0181,ACT0065	SP1063	×	×
S-Class	222	Driver assistance system	MFK-Multifunction camera(stereo)(A40/13)	√	√	√	√	×	ACT0181,ACT0065	SP1063	×	×
S-Class	222	Driver assistance	NBR LR-Left rear short-range	√	√	√	√	×	×	SP1173	×	×
S-Class	222	Driver assistance	NBR RR-Right rear short-range	√	√	√	√	×	×	SP1172	×	×
S-Class	222	Driver assistance	NSA-Night View Assist(N101)	√	√	√	√	×	ACT1173,ACT0685	SP1063	×	×
S-Class	222	Driver assistance	PARK-Parking system (N62)	√	√	√	√	×	ACT0306	×	×	×
S-Class	222	Driver assistance	PTS-PARKTRONIC	√	√	√	√	×	ACT0421,ACT0306	SP1166	×	×
S-Class	222	Driver assistance	RFK-Backup camera	√	√	√	√	×	×	×	×	×
S-Class	222	Driver assistance	RFK-Backup camera	√	√	√	√	×	×	SP1152	×	×
S-Class	222	Driver assistance system	SG AWF-Control unit COLLISION PREVENTION	√	√	√	√	×	×	SP1059	×	×
S-Class	222	Driver assistance system	SG AWF-Control unit COLLISION PREVENTION	√	√	√	√	×	ACT0583	SP1476,SP1477	×	×
S-Class	222	Driver assistance	SGR-Radar sensors control unit	√	√	√	√	×	ACT0419,ACT0420	SP1163,SP1164,SP1165	×	×
S-Class	222	Driver assistance system	SGR-Radar sensors control unit(N62/1)	√	√	√	√	×	×	SP1163,SP1164,SP1449	×	×
S-Class	222	Driver assistance system	TPM-Tire pressure monitor(N88)	√	√	√	√	×	ACT0078,ACT0079,ACT0081,ACT0080	SP1053	×	×
S-Class	222	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√	×	×	×	×	×
S-Class	222	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√	×	×	×	×	×
S-Class	222	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√	×	×	×	×	×
S-Class	222	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√	×	×	×	×	×
S-Class	222	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√	×	×	×	×	×
S-Class	222	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√	×	×	×	×	×
S-Class	222	Information and communication	AVE H-Controller unit Rear entertainment system	√	√	√	√	×	ACT0043,ACT0206,ACT1210,ACT0039,ACT0083,ACT1211,ACT1212,ACT1213,ACT1214	SP1057,SP1489	×	×
S-Class	222	Information and communication	AVE H-Controller unit Rear entertainment system	√	√	√	√	×	ACT0043,ACT1215,ACT1216,ACT0039,ACT0083,ACT1217,	×	×	×
S-Class	222	Information and communication	COU[ZBE]-Audio/COMAND operating unit	√	√	√	√	×	ACT0041,ACT1171	×	×	×
S-Class	222	Information and communication	COU[ZBE]-Audio/COMAND operating unit	√	√	√	√	×	ACT0041,ACT1171	×	×	×

S-Class	222	Information and communication	CTEL-Cellular telephone	√	√	√	√	×	×	×	×	×
S-Class	222	Information and communication	D FOL-Display in left rear passenger compartment	√	√	√	√	×	ACT1206,ACT1207,ACT1208,ACT0039,ACT1209	SP1488,SP1342	×	×
S-Class	222	Information and communication	D FOR-Display in right rear passenger compartment	√	√	√	√	×	ACT1206,ACT1207,ACT1208,ACT0039,ACT1209	SP1488,SP1342	×	×
S-Class	222	Information and communication	DAB-Digital radio Tuner unit	√	√	√	√	×	ACT0198,ACT0087,ACT0199,ACT0039	×	×	×
S-Class	222	Information and communication	HERMES-control unit for telematics services	√	√	√	√	×	×	SP1046	×	×
S-Class	222	Information and communication	HUD-Head up display	√	√	√	√	×	ACT0210,ACT0212	×	×	×
S-Class	222	Information and communication	IC-Instrument cluster	√	√	√	√	×	ACT0397,ACT0048,ACT0210,ACT0398,ACT0399,ACT0947,ACT0050,ACT0400	SP1043,SP1044,SP1045,SP1381	×	×
S-Class	222	Information and communication	IC-Instrument cluster(A1)	√	√	√	√	×	ACT0397,ACT0048,ACT0210,ACT0398,ACT0399,ACT0050,ACT0400,ACT0039	SP1043,SP1044,SP1045	×	×
S-Class	222	Information and communication	KOMO/mbrace-Communication module 'Telematics services'/Notrufsystem	√	√	√	√	×	ACT0051,ACT0039,ACT0043,ACT0040,ACT0052,ACT0053,ACT0054,ACT0055,ACT0056,	×	×	×
S-Class	222	Information and communication	LCP-Lower control panel	√	√	√	×	×	×	×	×	×
S-Class	222	Information and communication	mbrace-mbrace	√	√	√	√	×	ACT0039,ACT0040,ACT0041,ACT0042,ACT0043,ACT0044	×	×	×
S-Class	222	Information and communication	mbrace-mbrace	√	√	√	√	×	ACT0043,ACT0058,ACT0059,ACT0039	×	×	×
S-Class	222	Information and communication	MTAS FO-Mobile phone cradle in rear passenger compartment	√	√	√	√	×	×	×	×	×
S-Class	222	Information and communication	MTAS-Mobile phone cradle	√	√	√	√	×	×	×	×	×
S-Class	222	Information and communication	SOUND-Sound system	√	√	√	√	×	×	×	×	×
S-Class	222	Information and communication	SOUND-Sound system	√	√	√	√	×	×	×	×	×
S-Class	222	Information and communication	Telephone keypad	√	√	√	×	×	×	×	×	×
S-Class	222	Information and communication	TPAD-Touchpad	√	√	√	√	×	×	×	×	×
S-Class	222	Information and communication	TPAD-Touchpad	√	√	√	√	×	×	×	×	×
S-Class	222	Information and communication	TV tuner (TV)	√	√	√	√	×	×	×	×	×
S-Class	222	Information and communication	TV tuner (TV)	√	√	√	√	×	×	×	×	×
S-Class	222	Information and communication	TV tuner (TV)	√	√	√	√	×	×	×	×	×
S-Class	222	Information and communication	TV tuner (TV)	√	√	√	√	×	×	×	×	×
S-Class	222	Information and communication	ZAN-Audio/COMAND display	√	√	√	√	×	ACT0090,ACT1172,ACT0291,ACT0043,ACT0039	×	×	×
S-Class	222	Information and communication	ZAN-Audio/COMAND display	√	√	√	√	×	ACT0206,ACT0946,ACT0291,ACT0039	×	×	×

S-Class	222	Seats and Doors	"Driver" seat heater	✓	✓	✓	✓	×	×	×	×	×
S-Class	222	Seats and Doors	"Front passenger" seat heater	✓	✓	✓	✓	×	×	×	×	×
S-Class	222	Seats and Doors	BFS LSE-Lumbar support 'Front passenger seat'(N32/24)	✓	✓	✓	✓	×	ACT1175,ACT1176	×	×	×
S-Class	222	Seats and Doors	DCU LR-Left rear door	✓	✓	✓	×	×	×	×	×	×
S-Class	222	Seats and Doors	DCU LR-Left rear door	✓	✓	✓	×	×	×	×	×	×
S-Class	222	Seats and Doors	DCU LR-Left rear door	✓	✓	✓	×	×	×	×	×	×
S-Class	222	Seats and Doors	DCU LR-Left rear door	✓	✓	✓	✓	×	ACT0360,ACT0361,ACT0362,ACT0363,ACT0723,ACT0688,ACT0347,ACT0364,ACT0724,ACT0366,ACT0725	SP1080,SP1147,SP1148	×	×
S-Class	222	Seats and Doors	DCU LR-Left rear door	✓	✓	✓	✓	×	ACT0360,ACT0361,ACT0362,ACT0363,ACT0723,ACT0688,ACT0347,ACT0364,ACT0724,ACT0727,ACT0366	SP1080,SP1147,SP1148	×	×
S-Class	222	Seats and Doors	DCU LR-Left rear door	✓	✓	✓	✓	×	ACT0687,ACT0686,ACT1060,ACT0688,ACT1061,ACT0362,ACT0363,ACT0723,ACT0360,ACT0361,ACT0271,ACT0725	SP1080	×	×
S-Class	222	Seats and Doors	DCU RF-Right front door	✓	✓	✓	×	×	×	×	×	×
S-Class	222	Seats and Doors	DCU RF-Right front door	✓	✓	✓	✓	×	ACT0272,ACT0273,ACT0274,ACT0256,ACT0275,ACT0277,ACT0276,ACT1058,ACT0278,ACT0279,ACT0357,ACT1056,ACT0349,ACT1059,ACT0348,ACT0281,ACT0282,ACT0258,ACT0283,ACT0284,ACT0271,	SP1080	×	×
S-Class	222	Seats and Doors	DCU RF-Right front door	✓	✓	✓	✓	×	ACT0353,ACT0274,ACT0273,ACT0354,ACT0720,ACT0283,ACT0284,ACT0281,ACT0282,ACT0721,ACT0355,ACT0278,ACT0356,ACT0357,ACT0347,ACT0279,ACT0348,ACT0349,ACT0358,ACT0359,ACT0722,	SP1080,SP1147,SP1148	×	×
S-Class	222	Seats and Doors	DCU RF-Right front door	✓	✓	✓	✓	×	ACT1157,ACT0274,ACT0273,ACT1158,ACT0720,ACT0283,ACT0284,ACT0281,ACT0282,ACT0721,ACT0366,ACT0278,ACT1155,ACT0357,ACT0347,ACT0279,ACT0348,ACT0349,ACT0358,ACT0359,ACT1156,	SP1080,SP1147,SP1148	×	×
S-Class	222	Seats and Doors	DCU RR-Right rear door	✓	✓	✓	×	×	×	×	×	×
S-Class	222	Seats and Doors	DCU RR-Right rear door	✓	✓	✓	×	×	×	×	×	×
S-Class	222	Seats and Doors	DCU RR-Right rear door	✓	✓	✓	×	×	×	×	×	×
S-Class	222	Seats and Doors	DCU RR-Right rear door	✓	✓	✓	✓	×	ACT0367,ACT0368,ACT0369,ACT0370,ACT0726,ACT0692,ACT0347,ACT0371,ACT0365,ACT0727,ACT0366	SP1080,SP1147,SP1148	×	×
S-Class	222	Seats and Doors	DCU RR-Right rear door	✓	✓	✓	✓	×	ACT0367,ACT0368,ACT0369,ACT0370,ACT0726,ACT0692,ACT0347,ACT0371,ACT0365,ACT0727,ACT0728,ACT0366	SP1080,SP1147,SP1148	×	×

S-Class	222	Seats and Doors	DCU RR-Right rear door	√	√	√	√	×	ACT0691,ACT0690,ACT1062,ACT0692,ACT1056,ACT1063,ACT0369,ACT0370,ACT0726,ACT0367,ACT0368,ACT0728,	SP1080	×	×
S-Class	222	Seats and Doors	ESE_RL-Left rear electrical seat adjustment	√	√	√	√	×	ACT1191,ACT1192,ACT1193,ACT1194,ACT1195,ACT1196	SP1075,SP1074	×	×
S-Class	222	Seats and Doors	ESV Driver-Electric seat adjustmnet Driver with memory function	√	√	√	√	×	ACT0214,ACT0373,ACT0218,ACT0374,ACT0217,ACT1064,ACT0375,ACT0376,ACT0377	SP1438,SP1075,SP1074	×	×
S-Class	222	Seats and Doors	ESV Front passenger-Electric seat adjustment Front passenger with memory function	√	√	√	√	×	ACT0230,ACT0378,ACT0234,ACT0379,ACT0233,ACT1065,ACT0380,ACT0381,ACT0382	SP1438,SP1075,SP1074	×	×
S-Class	222	Seats and Doors	HKS-Tailgate control	√	√	√	√	×	ACT1089,ACT1023,ACT0171,ACT0173	SP1440	×	×
S-Class	222	Seats and Doors	HKS-Tailgate control	√	√	√	√	×	ACT1089,ACT1090	SP1439	×	×
S-Class	222	Seats and Doors	LFD-Left front door	√	√	√	×	×	×	×	×	×
S-Class	222	Seats and Doors	LFD-Left front door	√	√	√	√	×	ACT0253,ACT0254,ACT0255,ACT0256,ACT0257,ACT0260,ACT0259,ACT1055,ACT0261,ACT0263,ACT0346,ACT1056,ACT0349,ACT1057,ACT0348,ACT0267,ACT0268,ACT0258,ACT0270,ACT0269,ACT0271,	SP1080	×	×
S-Class	222	Seats and Doors	LFD-Left front door	√	√	√	√	×	ACT0342,ACT0255,ACT0254,ACT0343,ACT0715,ACT0269,ACT0361,ACT0267,ACT0268,ACT0716,ACT0344,ACT0261,ACT0345,ACT0346,ACT0347,ACT0263,ACT0348,ACT0349,ACT0350,ACT0351,ACT0717,	SP1080,SP1147,SP1148	×	×
S-Class	222	Seats and Doors	LFD-Left front door	√	√	√	√	×	ACT1153,ACT0255,ACT0254,ACT1154,ACT0715,ACT0269,ACT0270,ACT0267,ACT0268,ACT0716,ACT0366,ACT0261,ACT1155,ACT0346,ACT0347,ACT0263,ACT0348,ACT0349,ACT0350,ACT0351,ACT1156,	SP1080,SP1147,SP1148	×	×
S-Class	222	Seats and Doors	LSE FS-N32/23 (Driver seat lumbar support adjustment	√	√	√	√	×	ACT1175,ACT1176	×	×	×
S-Class	222	Seats and Doors	Massage function in left front seat	√	√	√	√	×	ACT0850	×	×	×
S-Class	222	Seats and Doors	Massage function in left rear seat	√	√	√	√	×	ACT0850	×	×	×
S-Class	222	Seats and Doors	Massage function in right front	√	√	√	√	×	ACT0850	×	×	×
S-Class	222	Seats and Doors	Massage function in right rear	√	√	√	√	×	ACT0850	×	×	×
S-Class	222	Seats and Doors	MKS LF-Left front multicontour seat	√	√	√	√	×	ACT1170,ACT0383,ACT0803,ACT0384,ACT0387,ACT0388	×	×	×
S-Class	222	Seats and Doors	MKS LF-Left rear multicontour seat	√	√	√	√	×	ACT0383,ACT0803,ACT0384,ACT0386	×	×	×
S-Class	222	Seats and Doors	MKS RF-Right front multicontour seat	√	√	√	√	×	ACT1170,ACT0383,ACT0803,ACT0384,ACT0387,ACT0388	×	×	×
S-Class	222	Seats and Doors	MKS RF-Right rear multicontour seat	√	√	√	√	×	ACT0383,ACT0803,ACT0384,ACT0386	×	×	×

S-Class	222	Seats and Doors	PPAMKS-Pneumatic pump for multicontour seat	√	√	√	√	×	ACT0616,ACT0619	×	×	×
S-Class	222	Seats and Doors	PPAMKS-Pneumatic pump for multicontour seat	√	√	√	√	×	ACT0616,ACT0804	×	×	×
S-Class	222	Seats and Doors	Right rear ESE-Right rear electrical seat adjustment	√	√	√	√	×	ACT1197,ACT1198,ACT1199,ACT1200,ACT1201,ACT1202,ACT1203,ACT1204	SP1075,SP1074	×	×
S-Class	222	Seats and Doors	S22 (Driver's door seat adjustment switch)	√	√	√	×	×	×	×	×	×
S-Class	222	Seats and Doors	S23 (Front passenger door seat adjustment switch)	√	√	√	×	×	×	×	×	×
S-Class	222	Seats and Doors	S47/2 (Driver door switch)	√	√	√	×	×	×	×	×	×
S-Class	222	Seats and Doors	S47/3 (Front passenger door switch module)	√	√	√	×	×	×	×	×	×
S-Class	222	Seats and Doors	Seat heater in left rear passenger compartment	√	√	√	√	×	×	×	×	×
S-Class	222	Seats and Doors	Seat heater in right rear passenger compartment	√	√	√	√	×	×	×	×	×
SLS-Class	197	Air conditioning	AAC-Automatic air conditioning	√	√	√	√	×	ACT0182,ACT0003,ACT0558,ACT0196,ACT0197,ACT0797,ACT0194,ACT0657,ACT0659,ACT0658,ACT0979	SP1065,SP1066,SP1067	×	√
SLS-Class	197	Body	AIRSCARF-Neck heating system(N25/7)	√	√	√	√	×	×	×	×	√
SLS-Class	197	Body	AISP-Dimming inside rearview mirror(A67)	√	√	√	√	×	×	×	×	×
SLS-Class	197	Body	AISP-Dimming inside rearview mirror(A67)	√	√	√	√	×	×	×	×	×
SLS-	197	Body	AS-Alarm siren(H3/1)	√	√	√	×	×	ACT0936	×	×	×
SLS-Class	197	Body	ATA-ATA[EDW]/tow-away protection/interior protection	√	√	√	√	×	ACT0937,ACT0938	×	×	×
SLS-	197	Body	B38/2-Rain/light sensor(RGLS)	√	√	√	√	×	×	×	×	×
SLS-Class	197	Body	BMS-H-Battery management system, rear (master)	√	√	√	√	×	ACT0959,ACT0455,ACT0960	SP1384,SP1385,SP1386,SP1387	×	√
SLS-Class	197	Body	BMS-M-Battery management system, center (master)	√	√	√	√	×	ACT0453,ACT1002,ACT1003,ACT1004,ACT1005,ACT0960	SP1405,SP1406,SP1407,SP1408,SP1386,SP1409	×	√
SLS-Class	197	Body	BMS-V-Battery management system, front (slave)	√	√	√	√	×	ACT1001,ACT0455,ACT0960	SP1402,SP1403,SP1386,SP1404	×	√
SLS-	197	Body	BSN-Battery sensor(B95)	√	√	√	√	×	×	×	×	×
SLS-	197	Body	BSN-Battery sensor(B95)	√	√	√	√	×	×	×	×	×
SLS-	197	Body	CGW-Central gateway	√	√	√	√	×	×	SP1373	×	√
SLS-	197	Body	CGW[ZGW]-Central gateway	√	√	√	√	×	×	SP1373	CD0621	√
SLS-	197	Body	CGW[ZGW]-Central gateway	√	√	√	√	×	×	SP1373	CD0621	√
SLS-Class	197	Body	CSHVB-Crash sensor high-voltage battery	√	√	√	√	×	×	×	×	×
SLS-	197	Body	DDW-DC/DC converter(N83/1)	√	√	√	√	×	×	×	×	√
SLS-Class	197	Body	Driver side SAM-Driver signal acquisition and actuation module	√	√	√	√	×	ACT0880,ACT0881,ACT0882,ACT0883,ACT0884,ACT0885,ACT0886,ACT0887	×	×	√
SLS-Class	197	Body	Driver side SAM-Driver signal acquisition and actuation module	√	√	√	√	×	ACT0880,ACT0881,ACT0882,ACT0883,ACT0884,ACT0885,ACT0886,ACT0887	×	×	√

SLS-Class	197	Body	Driver side SAM-Front signal acquisition and actuation module	√	√	√	√	×	ACT0880,ACT0881,ACT0882,ACT0883,ACT0884,ACT0885,ACT0886,ACT0887	×	×	√
SLS-	197	Body	Exterior lights switch	√	√	√	√	×	×	×	×	×
SLS-	197	Body	EZS-Electronic ignition switch	√	√	√	√	×	×	×	×	×
SLS-	197	Body	FSW-Windshield wiper	√	√	√	√	×	×	×	×	×
SLS-	197	Body	FSW-Windshield wiper	√	√	√	√	×	ACT0934	×	×	×
SLS-	197	Body	FSW-Windshield wiper	√	√	√	√	×	ACT0934	×	×	×
SLS-	197	Body	GTO-Garage door	√	√	√	√	×	×	×	×	×
SLS-	197	Body	GTO-Garage door	√	√	√	√	×	×	×	×	×
SLS-Class	197	Body	IRS HLA-Outer left rear intelligent radar sensor system	√	√	√	√	×	×	×	×	√
SLS-Class	197	Body	IRS HRA-Outer right rear intelligent radar sensor	√	√	√	√	×	×	×	×	√
SLS-Class	197	Body	KG-KEYLESS GO	√	√	√	√	×	ACT0875,ACT0132,ACT0131,ACT0876	×	×	×
SLS-Class	197	Body	KG-KEYLESS GO(N69/5)	√	√	√	√	×	ACT0877,ACT0875,ACT0131,ACT0132,ACT0876	×	×	√
SLS-	197	Body	LIB-Lithium ion battery	√	√	√	√	×	×	×	×	×
SLS-Class	197	Body	Rear SAM-Rear signal acquisition and actuation module	√	√	√	√	×	ACT0888,ACT0889,ACT0890,ACT0813,ACT0240,ACT0751,ACT0891,ACT0748,ACT0752,ACT0892,ACT0893,ACT0894,ACT0895,ACT0757,ACT0896,ACT0897,ACT0898,ACT0677,ACT0899,ACT0900,ACT0901,ACT0411,ACT0412,ACT0902,ACT0903,ACT0904,ACT0905,ACT0768,ACT0616,ACT0906,ACT0907,ACT0908,ACT0465,ACT0909,ACT0741,ACT0910,ACT0911,ACT0912,ACT0888,ACT0240,ACT0751,ACT0891,ACT0748,ACT0752,ACT0888,ACT0890,ACT0240,ACT0751,ACT0891,ACT0748,ACT0752,ACT0910,ACT0911,ACT0913,ACT0910,ACT0914,ACT0911,ACT0915,ACT0916,ACT0917,	×	×	√

SLS-Class	197	Body	REAR SAM-Rear signal acquisition and actuation module	√	√	√	√	×	ACT0888,ACT0889,ACT0890,ACT0813,ACT0240,ACT0751,ACT0891,ACT0748,ACT0752,ACT0892,ACT0893,ACT0894,ACT0895,ACT0757,ACT0896,ACT0897,ACT0898,ACT0677,ACT0899,ACT0900,ACT0901,ACT0411,ACT0412,ACT0902,ACT0903,ACT0904,ACT0905,ACT0768,ACT0616,ACT0906,ACT0907,ACT0908,ACT0465,ACT0909,ACT0741,ACT0910,ACT0911,ACT0912,ACT0888,ACT0240,ACT0751,ACT0891,ACT0748,ACT0752,ACT0888,ACT0890,ACT0240,ACT0751,ACT0891,ACT0748,ACT0752,ACT0888,ACT0910,ACT0911,ACT0913,ACT0910,ACT0914,ACT0911,ACT0915,ACT0916,ACT0917,	×	×	√
SLS-Class	197	Body	REAR SAM-Rear signal acquisition and actuation module	√	√	√	√	×	ACT0888,ACT0889,ACT0890,ACT0813,ACT0240,ACT0751,ACT0891,ACT0748,ACT0752,ACT0892,ACT0893,ACT0894,ACT0895,ACT0757,ACT0896,ACT0897,ACT0898,ACT0677,ACT0899,ACT0900,ACT0901,ACT0411,ACT0412,ACT0902,ACT0903,ACT0904,ACT0905,ACT0768,ACT0616,ACT0906,ACT0907,ACT0908,ACT0465,ACT0909,ACT0741,ACT0910,ACT0911,ACT0912,ACT0888,ACT0240,ACT0751,ACT0891,ACT0748,ACT0752,ACT0888,ACT0890,ACT0240,ACT0751,ACT0891,ACT0748,ACT0752,ACT0888,ACT0910,ACT0911,ACT0913,ACT0910,ACT0914,ACT0911,ACT0915,ACT0916,ACT0917,	×	×	√
SLS-Class	197	Body	SCM [MRM]-Steering column module	√	√	√	√	×	ACT0060,ACT0961	×	×	√
SLS-Class	197	Body	SCM-Steering column module(N80)	√	√	√	√	×	ACT0060,ACT0061,ACT0062,ACT0063,ACT0064,ACT0065	×	×	√
SLS-Class	197	Body	SG LG-Charger	√	√	√	√	×	ACT0986,ACT0987	×	CD0646,CD0729,CD0730,CD0731,CD0732	√
SLS-	197	Body	SRS-Supplemental restraint	√	√	√	√	√	×	×	×	√
SLS-Class	197	Body	STC-Soft top control(N52)	√	√	√	√	×	ACT0948,ACT0949,ACT0950,ACT0951	×	×	√
SLS-	197	Body	UCP-Upper control panel	√	√	√	√	×	×	×	×	×
SLS-	197	Body	WSS-Weight sensing	√	√	√	√	×	×	×	×	×

SLS-Class	197	Chassis	ADS-Adaptive damping system	√	√	√	√	×	ACT0167,ACT0168,ACT0169,ACT0170	×	×	√
SLS-Class	197	Chassis	AMG DRVU-AMG DRIVE UNIT(N145)	√	√	√	√	×	ACT0066,ACT0067,ACT0068	×	×	√
SLS-Class	197	Chassis	EFB-Electric parking brake	√	√	√	√	×	ACT1000,ACT0288	SP1401	×	√
SLS-Class	197	Chassis	EFB-Electronic parking brake(N128)	√	√	√	√	×	ACT0285,ACT0286,ACT0287,ACT0288	SP1081	×	√
SLS-Class	197	Chassis	EHPS-Electorhydraulic power Steering	√	√	√	√	×	×	×	×	√
SLS-Class	197	Chassis	ESP-Electric stability	√	√	√	√	×	×	SP1389	×	√
SLS-Class	197	Chassis	ESP-Electronic stability program(N30/4)	√	√	√	√	×	ACT0873,ACT0069,ACT0963	SP1388,SP1168,SP1374,SP1375	×	√
SLS-Class	197	Drive	DKG-Electronic transmission control for double-plate clutch transmission	√	√	√	√	√	ACT0312,ACT0313,ACT0314,ACT0315,ACT0316,ACT0317,ACT0318,ACT0319	SP1074,SP1002,SP1103,SP1104	CD0621,CD0608,CD0609,CD0610	√
SLS-Class	197	Drive	ELM-HL-Rear left electrical machine	√	√	√	√	×	ACT0964,ACT0965,ACT0980,ACT0967,ACT0981,ACT0451,ACT0452,ACT0982,ACT0970,	SP1396	×	√
SLS-Class	197	Drive	ELM-HR-Rear right electrical machine	√	√	√	√	×	ACT0964,ACT0965,ACT0983,ACT0967,ACT0984,ACT0451,ACT0452,ACT0985,ACT0970,	SP1397,SP1391	×	√
SLS-Class	197	Drive	ELM-VL-Front left electrical machine	√	√	√	√	×	ACT0964,ACT0965,ACT0966,ACT0967,ACT0968,ACT0451,ACT0452,ACT0969,ACT0970,	SP1390,SP1391	×	√
SLS-Class	197	Drive	ELM-VR-Front right electrical machine	√	√	√	√	×	ACT0964,ACT0965,ACT0976,ACT0967,ACT0977,ACT0451,ACT0452,ACT0978,ACT0970,	SP1395	×	√
SLS-Class	197	Drive	FSCU-Fuel pump	√	√	√	√	×	ACT0320	×	×	√
SLS-Class	197	Drive	ISM-Shift module	√	√	√	√	×	ACT0669,ACT0670,ACT0671,ACT0318,ACT0672	SP1345,SP1002,SP1346	×	√
SLS-Class	197	Drive	N3/10-Motor electronics "ME97 AMG" for combustion engine "M156"	√	√	√	√	√	ACT0002,ACT0003,ACT0952,ACT0953,ACT0939,ACT0954,ACT0941,ACT0955,ACT0956,ACT0463,ACT0705,ACT0464,ACT0706,ACT0325,ACT0957,ACT0326,ACT0958,ACT0000,	SP1001,SP1002,SP1117,SP1383,SP1216,SP1116	CD0621,CD0608,CD0609,CD0610,CD0677,CD0678,CD0682,CD0680	√
SLS-Class	197	Drive	PTCU-MA-Drivetrain (master)	√	√	√	√	×	ACT0988,ACT0989,ACT0990,ACT0991,ACT0992,ACT0993,ACT0994,ACT0995,ACT0996,ACT0997,ACT0998	SP1150,SP1398,SP1399,SP1400	×	√
SLS-Class	197	Drive	PTCU-SL-Drivetrain (slave)	√	√	√	√	×	ACT0999	×	×	√
SLS-Class	197	Driver assistance system	IRS HLA-Outer left rear intelligent radar sensor system	√	√	√	√	×	×	×	×	×
SLS-Class	197	Driver assistance system	IRS HRA-Outer right rear intelligent radar sensor	√	√	√	√	×	×	×	×	×
SLS-Class	197	Driver assistance system	PTS-Parktronic system	√	√	√	√	×	ACT0935	×	CD0621,CD0672,CD0708,CD0709	√
SLS-Class	197	Driver assistance system	TPM-Tire pressure monitor(N88)	√	√	√	√	×	ACT0078,ACT0079,ACT0081,ACT0080	SP1053,SP1392	×	√
SLS-Class	197	Information and communication	AMG PM-AMG Performance Media(N125/2)	√	√	√	√	×	ACT0962	×	×	√

SLS-Class	197	Information and communication	Audio-Audio or COMAND	√	√	√	×	×	ACT0082,ACT0083,ACT0084,ACT0085,ACT0086,ACT0074,ACT0087,ACT0044,ACT0088,ACT0089,ACT0090,ACT0091,ACT0092,ACT0097,ACT0093,ACT0095,ACT0096,ACT0101,ACT0971,ACT0043,ACT0090,ACT0091,ACT0092,ACT0097,ACT0095,ACT0096,ACT0972,ACT0973,ACT0974,ACT0083,ACT0084,ACT0105,ACT0975,ACT0082,ACT0085,ACT0086,ACT0074,ACT0088,ACT0101,	SP1393,SP1054,SP1394	CD0621,CD0723,CD0633,CD0724,CD0634,CD0635,CD0725,CD0726,CD0718,CD0636,CD0727,CD0728,CD0638	×
SLS-Class	197	Information and communication	COU-Audio/COMAND operating unit (A40/9)	√	√	√	√	×	ACT0289	×	×	√
SLS-Class	197	Information and communication	DAB-Digital Audio Broadcasting	√	√	√	√	×	×	×	×	×
SLS-Class	197	Information and communication	DAB-Digital Audio Broadcasting(N87/3)	√	√	√	√	×	×	×	×	×
SLS-Class	197	Information and communication	DSI-DIRECT SELECT interface(N150)	√	√	√	√	×	ACT0307	×	×	√
SLS-Class	197	Information and communication	ECS-N123/4 Emergency call system control unit	√	√	√	√	×	ACT0043,ACT0058,ACT0059	×	×	×
SLS-Class	197	Information and communication	IC-Instrument cluster(A1)	√	√	√	√	×	ACT0045,ACT0046,ACT0047,ACT0048,ACT0049,ACT0039,	SP1043,SP1044,SP1045	×	√
SLS-Class	197	Information and communication	KOMO-Communication module Telematics services	√	√	√	√	×	ACT0052,ACT0040,ACT0039	×	×	√
SLS-Class	197	Information and communication	MIF-Media interface	√	√	√	√	×	×	×	×	×
SLS-Class	197	Information and communication	MIF-Media interface	√	√	√	√	×	ACT0043	×	×	×
SLS-Class	197	Information and communication	N123/4 (emergency call system control unit) - an emergency call	√	√	√	√	×	×	×	×	×
SLS-Class	197	Information and communication	N123/4 (emergency call system control unit) - anti-theft tracking	√	√	√	√	×	×	×	×	×
SLS-Class	197	Information and communication	N123/4 (emergency call system control unit) - Mercedes - Benz (MB) information/fault rescue	√	√	√	√	×	×	×	×	×
SLS-Class	197	Information and communication	N123/4 (emergency call system control unit) - the vehicle remote control unlocking/locking the vehicle remote	√	√	√	√	×	×	×	×	×
SLS-Class	197	Information and communication	SDAR-Satellite radio	√	√	√	√	×	ACT0221,ACT0222,ACT0133,ACT0223	×	CD0645CD0646,CD0647,CD0647	×
SLS-Class	197	Information and communication	SOUND-Bose sound system	√	√	√	√	×	ACT0160,ACT0135,ACT0139,ACT0144,ACT0146,ACT0150,ACT0058,ACT0142,ACT0145,ACT0161,ACT0162,ACT0138,ACT0163,ACT0164,ACT0165,ACT0159,ACT0166,ACT0133	SP1060	×	×

SLS-Class	197	Information and communication	SOUND-Bose sound system	√	√	√	√	×	ACT0160,ACT0626,ACT0158,ACT0135,ACT0154,ACT0155,ACT0142,ACT0145,ACT0141,ACT0058,ACT0138,ACT0143,ACT0140,ACT0146,ACT0150,ACT0149,ACT0137,ACT0166,	×	×	×
SLS-Class	197	Information and communication	ZAN-Audio/COMAND display	√	√	√	√	×	ACT0290,ACT0096,ACT0090,ACT0091,ACT0095	×	×	√
SLS-Class	197	Seats and Doors	DCU RF-Right front door	√	√	√	√	×	ACT0272,ACT0273,ACT0274,ACT0256,ACT0275,ACT0258,ACT0276,ACT0277,ACT0278,ACT0262,ACT0279,ACT0265,ACT0927,ACT0280,ACT0281,ACT0282,ACT0283,ACT0284,	SP1080	×	√
SLS-Class	197	Seats and Doors	LFD-Left front door	√	√	√	√	×	ACT0253,ACT0254,ACT0255,ACT0256,ACT0257,ACT0258,ACT0259,ACT0260,ACT0261,ACT0262,ACT0263,ACT0265,ACT0927,ACT0264,ACT0267,ACT0268,ACT0269,ACT0270,	SP1080	×	√
SLS-Class	197	Seats and Doors	N32/1 (Driver seat control unit)	√	√	√	√	×	ACT0214,ACT0215,ACT0216,ACT0217,ACT0218,ACT0220	SP1074,SP1075,SP1377,SP1076	×	√
SLS-Class	197	Seats and Doors	N32/1 (Driver seat control unit)	√	√	√	√	×	ACT0214,ACT0215,ACT0216,ACT0217,ACT0218,ACT0220	SP1074,SP1075,SP1377,SP1076	×	√
SLS-Class	197	Seats and Doors	N32/2 (Front passenger seat control unit)	√	√	√	√	×	ACT0230,ACT0231,ACT0232,ACT0233,ACT0234	SP1074,SP1075	×	√
SLS-Class	197	Seats and Doors	N32/2 (Front passenger seat control unit)	√	√	√	√	×	ACT0230,ACT0231,ACT0232,ACT0233,ACT0234	SP1074,SP1075	×	√
X 290 AMG-Class	290	Air conditioning	AAC-Automatic air conditioning	√	√	√	×	×	×	×	×	×
X 290 AMG-Class	290	Air conditioning	AAC-Automatic air conditioning	√	√	√	×	×	×	×	×	×
X 290 AMG-Class	290	Air conditioning	AAC-Automatic air conditioning	√	√	√	×	×	×	×	×	×

X 290 AMG-Class	290	Air conditioning	AAC-Automatic air conditioning	√	√	√	√	×	ACT0182,ACT0417,ACT0183,ACT0771,ACT0772,ACT0204,ACT0773,ACT0003,ACT0186,ACT0190,ACT0665,ACT0774,ACT0189,ACT0775,ACT0776,ACT0188,ACT0777,ACT0778,ACT0779,ACT0663,ACT0780,ACT0662,ACT0781,ACT0782,ACT0783,ACT0784,ACT0785,ACT0786,ACT0787,ACT0788,ACT0655,ACT0656,ACT0781,ACT0782,ACT0783,ACT0784,ACT0785,ACT0786,ACT0787,ACT0788,ACT0789,ACT0790,ACT0781,ACT0782,ACT0783,ACT0784,ACT0785,ACT0786,ACT0788,ACT0652,ACT0655,ACT0656,ACT0781,ACT0782,ACT0786,ACT0787,ACT0789,ACT0790,ACT0194,ACT0647,ACT0648,ACT0649,ACT0650,ACT0653,ACT0654,ACT0791,ACT0792,ACT0793,ACT0794,	SP1066,SP1065,SP1067,SP1360,SP1159	×	×
X 290 AMG-Class	290	Air conditioning	N61 (Windshield heater control unit)	√	√	√	×	×	×	×	×	×
X 290 AMG-Class	290	Air conditioning	SG EM-Power electronics	√	√	√	√	×	×	×	×	×
X 290 AMG-Class	290	Air conditioning	STH-Stationary heater	√	√	√	√	×	ACT0201,ACT1030,ACT0202,ACT1118	×	×	×
X 290 AMG-Class	290	Air conditioning	TSTH-Radio remote control of stationary heater	√	√	√	√	×	ACT0203,ACT0418	×	×	×
X 290 AMG-Class	290	Body	"Driver" seat heater	√	√	√	√	×	ACT0411,ACT0412,ACT0413,ACT0414,ACT0415	SP1157,SP1158	×	×
X 290 AMG-Class	290	Body	"Front passenger" seat heater	√	√	√	√	×	×	×	×	×
X 290 AMG-Class	290	Body	AML-Ambiance light	√	√	√	√	×	ACT0389,ACT0390,ACT0391,ACT0392,ACT0393,ACT0394,ACT0395,ACT0396,ACT0043	SP1149	×	×
X 290 AMG-Class	290	Body	AML-Active engine mount	√	√	√	√	×	×	×	×	×
X 290 AMG-Class	290	Body	Anti glare interior rearview mirror(DBE)	√	√	√	√	×	×	×	×	×
X 290 AMG-Class	290	Body	AS-Alarm siren(H3/1)	√	√	√	√	×	ACT0309,ACT0465,ACT0466	×	×	×

X 290 AMG- Class	290	Body	BMS-Battery management system	√	√	√	√	×	×	×	×	×
X 290 AMG- Class	290	Body	BSN-Battery sensor(B95)	√	√	√	√	×	×	×	×	×
X 290 AMG- Class	290	Body	Button group, instrument panel, driver side	√	√	√	√	×	×	×	×	×
X 290 AMG- Class	290	Body	DC/DC-DC/DC converter	√	√	√	√	×	×	×	×	×
X 290 AMG- Class	290	Body	DC/DC-DC/DC converter	√	√	√	×	×	×	×	×	×
X 290 AMG- Class	290	Body	EZS-Electronic ignition lock	√	√	√	√	×	ACT1054	×	×	×
X 290 AMG- Class	290	Body	FSW-Windshield wiper	√	√	√	√	×	×	×	×	×
X 290 AMG- Class	290	Body	FSW-Windshield wiper	√	√	√	√	×	×	×	×	×
X 290 AMG- Class	290	Body	GES-Hand motion sensor	√	√	√	√	×	×	×	×	×
X 290 AMG- Class	290	Body	GTO-Garage door opener(A67n2)	√	√	√	√	×	×	×	×	×
X 290 AMG- Class	290	Body	KG-Keyless Go	√	√	√	√	×	ACT0131,ACT0132	×	×	×
X 290 AMG- Class	290	Body	LIB-Lithium ion battery	√	√	√	√	×	×	×	×	×
X 290 AMG- Class	290	Body	LIB-Lithium ion battery	√	√	√	√	×	×	×	×	×
X 290 AMG- Class	290	Body	LIB-Lithium ion battery	√	√	√	√	×	×	×	×	×
X 290 AMG- Class	290	Body	LRE-Steering wheel electronics	√	√	√	√	×	×	×	×	×
X 290 AMG- Class	290	Body	Multifunction control unit- Multifunction control unit	√	√	√	√	×	ACT0204	×	×	×
X 290 AMG- Class	290	Body	N25/6 (Rear passenger compartment seat heater control unit)	√	√	√	√	×	×	×	×	×

X 290 AMG-Class	290	Body	N38 (Rear switching module)	√	√	√	√	×	×	×	×	×
X 290 AMG-Class	290	Body	N5 (Armrest heater control unit)	√	√	√	√	×	ACT0817,ACT0818,ACT0819,ACT0820,ACT0821,ACT0822,ACT0823,ACT0824,ACT0825,ACT0826,ACT0827,ACT0828,ACT0829,ACT0830,ACT0831,ACT0832,ACT0833,ACT0834,ACT0829,ACT0830,ACT0831,ACT0835,ACT0836,ACT0837,ACT0838,ACT0829,ACT0835,ACT0836,ACT0837,ACT0838,ACT0839,ACT0840,ACT0841,ACT0842,ACT0843,ACT0844,ACT0845,ACT0846,ACT0847,ACT0848,ACT0829,ACT0832,ACT0839,ACT0840,ACT0841,ACT0842,ACT0843,ACT0844,	SP1364,SP1365	×	×
X 290 AMG-Class	290	Body	OCP-Overhead control panel	√	√	√	√	×	ACT1093,ACT1094,ACT0303,ACT0302,ACT1095,ACT1096,ACT1097,ACT1098,ACT1099,ACT0465,ACT1100	SP1441	×	×
X 290 AMG-Class	290	Body	PSD-Panoramic sliding roof	√	√	√	√	×	×	×	×	×
X 290 AMG-Class	290	Body	RevETR LF-Left front reversible emergency tensioning retractor	√	√	√	√	×	×	×	×	×
X 290 AMG-Class	290	Body	RevETR RF-Right front reversible emergency tensioning retractor	√	√	√	√	×	×	×	×	×
X 290 AMG-Class	290	Body	RGLS-Rain/light sensor(B38/2)	√	√	√	√	×	×	×	×	×
X 290 AMG-Class	290	Body	SAMF-Front signal acquisition and actuation module(N10/6)	√	√	√	√	×	ACT0729,ACT0730,ACT0731,ACT0732,ACT0344,ACT0507,ACT0733,ACT0675,ACT0734,ACT0676,ACT0735,ACT0736,ACT0737,ACT0738,ACT0465,ACT0739,ACT0740,ACT0741,ACT0742,ACT0743,ACT0744,	×	×	×
X 290 AMG-Class	290	Body	SAMR-Rear signal acquisition and actuation module(N10/8)	√	√	√	√	×	ACT0747,ACT0240,ACT0748,ACT0749,ACT0750,ACT0731,ACT0751,ACT0752,ACT0753,ACT0754,ACT0755,ACT0756,ACT0757,ACT0758,ACT0759,ACT0760,ACT0761,ACT0762,ACT0763,ACT0764,ACT0765,ACT0766,ACT0767,ACT0768,	×	×	×
X 290 AMG-Class	290	Body	SCM-Steering column module(N80)	√	√	√	√	×	ACT0060,ACT0061,ACT0062,ACT0063,ACT0064,ACT0065	×	×	×

X 290 AMG-Class	290	Body	SG LG-Charger	√	√	√	√	×	ACT0405,ACT0406,ACT0407,ACT0408,ACT0409,ACT0410	×	×	×
X 290 AMG-Class	290	Body	SG LML VL-LED matrix of left front lamp unit	√	√	√	√	×	ACT0299,ACT0815,ACT0816,ACT0300	SP1089,SP1361	×	×
X 290 AMG-Class	290	Body	SG SW L-Left headlamp	√	√	√	√	×	×	×	×	×
X 290 AMG-Class	290	Body	SG SW R-Right headlamp	√	√	√	√	×	×	×	×	×
X 290 AMG-Class	290	Body	SG-LML-VR-LED matrix of right front lamp unit	√	√	√	√	×	ACT0299,ACT0815,ACT0300,ACT0816	SP1362,SP1363	×	×
X 290 AMG-Class	290	Body	SRS-Supplemental restraint system	√	√	√	√	√	×	×	×	×
X 290 AMG-Class	290	Body	Trailer recognition module-Trailer recognition	√	√	√	√	×	×	×	×	×
X 290 AMG-Class	290	Body	WSS-Weight sensing system(N110)	√	√	√	√	×	×	×	×	×
X 290 AMG-Class	290	Chassis	ADS-Adaptive damping system	√	√	√	√	×	×	SP1061,SP1339	×	×
X 290 AMG-Class	290	Chassis	AIRmatic-AIRmatic PLUS	√	√	√	√	×	×	×	×	×
X 290 AMG-Class	290	Chassis	AMG DRVU-AMG DRIVE UNIT	√	√	√	√	×	ACT0401,ACT0402,ACT0403,ACT0404	SP1153,SP1154,SP1155	×	×
X 290 AMG-Class	290	Chassis	ES - Electric power steering	√	√	√	√	×	×	SP1071,SP1167	×	×
X 290 AMG-Class	290	Chassis	ESP-Electric stability program(N30/4)	√	√	√	√	√	ACT0069,ACT0070,ACT0285,ACT0286,ACT0287,ACT0288	SP1174,SP1176,SP1178,SP1183	×	×
X 290 AMG-Class	290	Chassis	Left rear axle steering	√	√	√	√	×	×	×	×	×
X 290 AMG-Class	290	Chassis	Rear wing	√	√	√	√	×	×	×	×	×
X 290 AMG-Class	290	Chassis	Right rear axle steering	√	√	√	√	×	×	×	×	×
X 290 AMG-Class	290	Drive	Active transmission mount	√	√	√	√	×	×	×	×	×

X 290 AMG-Class	290	Drive	EAGGS-Electric differential lock	√	√	√	√	×	ACT0814	SP1155	×	×
X 290 AMG-Class	290	Drive	FSCU-Control unit Fuel pump	√	√	√	√	×	ACT0252,ACT0320	×	×	×
X 290 AMG-Class	290	Drive	HFPM-Haptic accelerator pedal module	√	√	√	√	×	ACT1110,ACT1111	×	×	×
X 290 AMG-Class	290	Drive	ISG-Integrated starter alternator	√	√	√	√	×	×	×	×	×
X 290 AMG-Class	290	Drive	ISG-Integrated starter alternator	√	√	√	√	×	×	SP1368	×	×
X 290 AMG-Class	290	Drive	ISM-Shift module	√	√	√	√	×	ACT0307	SP1502	×	×
X 290 AMG-Class	290	Drive	N127 (Drivetrain control unit)	√	√	√	×	×	×	×	×	×
X 290 AMG-Class	290	Drive	N127 (Drivetrain control unit)	√	√	√	√	×	ACT0028,ACT0430,ACT0431,ACT0432,ACT0433,ACT0007,ACT0434,ACT0435,ACT0436,ACT0437,ACT0438,ACT0439,ACT0440,ACT0441,ACT0442,ACT0443,ACT0444,ACT0445,ACT0446,ACT0447,ACT0448,	SP1186,SP1042,SP1025,SP1187,SP1188,SP1189,SP1190,SP1191,SP1192	×	×
X 290 AMG-Class	290	Drive	N15/15n4 (Fully integrated transmission control unit)	√	√	√	√	×	×	×	×	×
X 290 AMG-Class	290	Drive	N3/10-Motor electronics "MED1775" for combustion engine "M178"	√	√	√	√	√	ACT0002,ACT0028,ACT0431,ACT0432,ACT0433,ACT0864,ACT0865,ACT0435,ACT0480,ACT0476,ACT0475,ACT0478,ACT0477,ACT0326,ACT0866,ACT0867,ACT0436,ACT0025,ACT0868,ACT0712,ACT0713,	SP1017,SP1109,SP1110,SP1369,SP1370,SP1371,SP1112,SP1202,SP1203,SP1001,SP1187,SP1372,SP1201,SP1000	×	×
X 290 AMG-Class	290	Drive	N3/10-Motor electronics "MRG1" for combustion engine "M256"	√	√	√	√	√	ACT0002,ACT0025,ACT0005,ACT0022,ACT0456,ACT0329,ACT0325,ACT0328,ACT0323,ACT0324,ACT0460,ACT0871,	SP1001,SP1004,SP1201,SP1202,SP1203,SP1110,SP1109,SP1139,SP1017,SP1371,SP1112,SP1000	×	×
X 290 AMG-Class	290	Drive	VG-All-wheel drive	√	√	√	√	×	ACT0422,ACT0423	SP1099,SP1170	×	×
X 290 AMG-Class	290	Drive	Y3/8n4-Transmission control for 9 speed transmission	√	√	√	√	√	ACT0592,ACT0312,ACT0593,ACT0714,ACT0317	SP1311,SP1315,SP1316,SP1305,SP1355,SP1312,SP1356,SP1300,SP1357,SP1358,SP1359,SP1317	×	×
X 290 AMG-Class	290	Driver assistance system	DTR-DISTRONIC	√	√	√	√	×	×	×	×	×

X 290 AMG-Class	290	Driver assistance system	DTR-DISTRONIC	√	√	√	√	×	×	SP1161,SP1162	×	×
X 290 AMG-Class	290	Driver assistance system	IRS HLA-Outer left rear integrated radar sensor (B92/11)	√	√	√	√	×	×	SP1473	×	×
X 290 AMG-Class	290	Driver assistance system	IRS HRA-Outer right rear integrated radar sensor (B92/6)	√	√	√	√	×	×	SP1474	×	×
X 290 AMG-Class	290	Driver assistance system	MFK-Multifunction camera(mono)(A40/11)	√	√	√	√	×	ACT0181,ACT0065	SP1156	×	×
X 290 AMG-Class	290	Driver assistance system	MFK-Multifunction camera(stereo)(A40/13)	√	√	√	√	×	ACT0181,ACT0065	SP1063	×	×
X 290 AMG-Class	290	Driver assistance system	NBR LF-Left front short range radar	√	√	√	√	×	×	×	×	×
X 290 AMG-Class	290	Driver assistance system	NBR LR-Left rear short-range radar	√	√	√	√	×	×	SP1173	×	×
X 290 AMG-Class	290	Driver assistance system	NBR RF-Right front short range radar	√	√	√	√	×	×	×	×	×
X 290 AMG-Class	290	Driver assistance system	NBR RR-Right rear short-range radar	√	√	√	√	×	×	SP1172	×	×
X 290 AMG-Class	290	Driver assistance system	PTS-PARKTRONIC	√	√	√	√	×	ACT0421,ACT0306	SP1166	×	×
X 290 AMG-Class	290	Driver assistance system	RFK-Backup camera	√	√	√	√	×	ACT1159	SP1475	×	×
X 290 AMG-Class	290	Driver assistance system	SG AWF-Control unit COLLISION PREVENTION ASSIST	√	√	√	√	×	ACT0583	SP1476,SP1477	×	×
X 290 AMG-Class	290	Driver assistance system	SGR-Radar sensors control unit	√	√	√	√	×	ACT0419,ACT0420	SP1163,SP1164,SP1165	×	×
X 290 AMG-Class	290	Driver assistance system	TPM-Tire pressure monitor(N88)	√	√	√	√	×	ACT0078,ACT0079,ACT0081,ACT0080	SP1053	×	×
X 290 AMG-Class	290	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√	×	×	×	×	×
X 290 AMG-Class	290	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√	×	×	×	×	×
X 290 AMG-Class	290	Information and communication	COU[ZBE]-Audio/COMAND operating unit	√	√	√	√	×	ACT0289,ACT0041	SP1199	×	×

X 290 AMG-Class	290	Information and communication	CTEL-Cellular telephone	√	√	√	√	×	×	×	×	×
X 290 AMG-Class	290	Information and communication	HERMES-control unit for telematics services	√	√	√	√	×	×	SP1046	×	×
X 290 AMG-Class	290	Information and communication	HUD-Head up display	√	√	√	√	×	ACT0210,ACT0212	×	×	×
X 290 AMG-Class	290	Information and communication	IC-Instrument cluster	√	√	√	√	×	ACT0039,ACT0397,ACT0048,ACT0210,ACT0398,ACT0399,ACT0050,ACT0400	SP1043,SP1044,SP1045	×	×
X 290 AMG-Class	290	Information and communication	IC-Instrument cluster(A1)	√	√	√	√	×	ACT0397,ACT0048,ACT0210,ACT0398,ACT0399,ACT0050,ACT0400,ACT0039	SP1043,SP1044,SP1045	×	×
X 290 AMG-Class	290	Information and communication	LCP-L	√	√	√	√	×	×	×	×	×
X 290 AMG-Class	290	Information and communication	LCP-R	√	√	√	√	×	×	×	×	×
X 290 AMG-Class	290	Information and communication	MTAS FO-Mobile phone cradle in rear passenger comparrtment	√	√	√	√	×	×	×	×	×
X 290 AMG-Class	290	Information and communication	MTAS-Mobile phone cradle	√	√	√	√	×	×	×	×	×
X 290 AMG-Class	290	Information and communication	MTAS-Mobile phone cradle	√	√	√	√	×	×	×	×	×
X 290 AMG-Class	290	Information and communication	OCP-Overhead control panel	√	√	√	×	×	×	×	×	×
X 290 AMG-Class	290	Information and communication	SG MSND-Engine sound	√	√	√	√	×	×	×	×	×
X 290 AMG-Class	290	Information and communication	SOUND-Sound system	√	√	√	√	×	×	×	×	×
X 290 AMG-Class	290	Information and communication	SOUND-Sound system	√	√	√	√	×	×	×	×	×
X 290 AMG-Class	290	Information and communication	TPAD-Touchpad	√	√	√	√	×	×	×	×	×
X 290 AMG-Class	290	Information and communication	TSC H-Touchscreen in rear passenger comparrtment	√	√	√	√	×	×	×	×	×
X 290 AMG-Class	290	Information and communication	TV tuner (TV)	√	√	√	√	×	×	×	×	×

X 290 AMG-Class	290	Information and communication	ZAN-Audio/COMAND display	√	√	√	√	×	ACT0206,ACT0946,ACT0291,ACT0039	×	×	×
X 290 AMG-Class	290	Information and communication	ZAN-Audio/COMAND display	√	√	√	√	×	ACT0291,ACT0206,ACT0039	×	×	×
X 290 AMG-Class	290	Seats and Doors	"Driver" seat heater	√	√	√	√	×	×	×	×	×
X 290 AMG-Class	290	Seats and Doors	"Front passenger" seat heater	√	√	√	√	×	×	×	×	×
X 290 AMG-Class	290	Seats and Doors	DCU LR-Left rear door	√	√	√	×	×	×	×	×	×
X 290 AMG-Class	290	Seats and Doors	DCU LR-Left rear door	√	√	√	√	×	ACT0360,ACT0361,ACT0362,ACT0363,ACT0723,ACT0688,ACT0347,ACT0364,ACT0724,ACT0366,ACT0725	SP1080,SP1147,SP1148	×	×
X 290 AMG-Class	290	Seats and Doors	DCU RF-Right front door	√	√	√	√	×	ACT0353,ACT0274,ACT0273,ACT0354,ACT0720,ACT0283,ACT0284,ACT0281,ACT0282,ACT0721,ACT0355,ACT0278,ACT0356,ACT0357,ACT0347,ACT0279,ACT0348,ACT0349,ACT0358,ACT0359,ACT0722,	SP1080,SP1147,SP1148	×	×
X 290 AMG-Class	290	Seats and Doors	DCU RR-Right rear door	√	√	√	×	×	×	×	×	×
X 290 AMG-Class	290	Seats and Doors	DCU RR-Right rear door	√	√	√	√	×	ACT0367,ACT0368,ACT0369,ACT0370,ACT0726,ACT0692,ACT0347,ACT0371,ACT0365,ACT0727,ACT0728,ACT0366	SP1080,SP1147,SP1148	×	×
X 290 AMG-Class	290	Seats and Doors	ESA Front passenger-Electric seat adjustment Front passenger	√	√	√	√	×	×	×	×	×
X 290 AMG-Class	290	Seats and Doors	ESA Front passenger-Electric seat adjustment Front passenger	√	√	√	√	×	ACT0230,ACT0378,ACT0234,ACT0379,ACT0233,ACT0380,ACT0381,ACT0382	SP1075	×	×
X 290 AMG-Class	290	Seats and Doors	ESV Driver-Electric seat adjustmnet Driver	√	√	√	√	×	×	×	×	×
X 290 AMG-Class	290	Seats and Doors	ESV Driver-Electric seat adjustmnet Driver	√	√	√	√	×	ACT0214,ACT0373,ACT0218,ACT0374,ACT0217,ACT0375,ACT0376,ACT0377	SP1075	×	×
X 290 AMG-Class	290	Seats and Doors	ESV Driver-Electric seat adjustmnet Driver with memory function	√	√	√	√	×	ACT0214,ACT0373,ACT0218,ACT0374,ACT0217,ACT1064,ACT0375,ACT0376,ACT0377	SP1438,SP1075,SP1074	×	×
X 290 AMG-Class	290	Seats and Doors	ESV Front passenger-Electric seat adjustment Front passenger with memory function	√	√	√	√	×	ACT0230,ACT0378,ACT0234,ACT0379,ACT0233,ACT1065,ACT0380,ACT0381,ACT0382	SP1438,SP1075,SP1074	×	×

X 290 AMG-Class	290	Seats and Doors	HKS-Tailgate control	√	√	√	√	×	×	×	×	×
X 290 AMG-Class	290	Seats and Doors	LFD-Left front door	√	√	√	√	×	ACT0342,ACT0255,ACT0254,ACT0343,ACT0715,ACT0269,ACT0361,ACT0267,ACT0268,ACT0716,ACT0344,ACT0261,ACT0345,ACT0346,ACT0347,ACT0263,ACT0348,ACT0349,ACT0350,ACT0351,ACT0717,	SP1080,SP1147,SP1148	×	×
X 290 AMG-Class	290	Seats and Doors	Massage function in left front seat	√	√	√	√	×	×	×	×	×
X 290 AMG-Class	290	Seats and Doors	Massage function in right front seat	√	√	√	√	×	×	×	×	×
X 290 AMG-Class	290	Seats and Doors	MFSF-LF	√	√	√	√	×	×	×	×	×
X 290 AMG-Class	290	Seats and Doors	MFSF-RF	√	√	√	√	×	×	×	×	×
X 290 AMG-Class	290	Seats and Doors	MKS LF-Left front multicontour seat	√	√	√	√	×	ACT0383,ACT0384,ACT0385,ACT0387,ACT0388	×	×	×
X 290 AMG-Class	290	Seats and Doors	MKS LF-Left front multicontour seat	√	√	√	√	×	ACT0383,ACT0384,ACT0387,ACT0388,ACT0386,ACT0802	×	×	×
X 290 AMG-Class	290	Seats and Doors	MKS RF-Right front multicontour seat	√	√	√	√	×	ACT0383,ACT0384,ACT0385,ACT0387,ACT0388	×	×	×
X 290 AMG-Class	290	Seats and Doors	MKS RF-Right front multicontour seat	√	√	√	√	×	ACT0383,ACT0384,ACT0387,ACT0388,ACT0386,ACT0802	×	×	×
X 290 AMG-Class	290	Seats and Doors	PPAMKS-Pneumatic pump for multicontour seat	√	√	√	√	×	ACT0616,ACT0804	×	×	×
X 290 AMG-Class	290	Seats and Doors	S22 (Driver"s door seat adjustment switch)	√	√	√	×	×	×	×	×	×
X 290 AMG-Class	290	Seats and Doors	S23 (Front passenger door seat adjustment switch)	√	√	√	×	×	×	×	×	×
X 290 AMG-Class	290	Seats and Doors	S47/2 (Driver door switch module)	√	√	√	×	×	×	×	×	×
X 290 AMG-Class	290	Seats and Doors	S47/3 (Front passenger door switch module)	√	√	√	×	×	×	×	×	×
X 290 AMG-Class	290	Seats and Doors	S51/1 (Driver"s door seat heating switch)	√	√	√	×	×	×	×	×	×

X 290 AMG- Class	290	Seats and Doors	S51/2 (Front passenger door seat heating switch)	√	√	√	×	×	×	×	×	×
X 290 AMG- Class	290	Seats and Doors	S51/3 (Left rear seat heater switch)	√	√	√	×	×	×	×	×	×
X 290 AMG- Class	290	Seats and Doors	S51/4 (Right rear seat heater switch)	√	√	√	×	×	×	×	×	×

XTOOL

Coding Functions List

No.	Functions Name	System Name
CD0001	All codes	AAC-Automatic air conditioning
CD0002	All coding settings	AAC-Automatic air conditioning
CD0003	Read coding and change if necessary.	AAC-Automatic air conditioning
CD0004	Special settings	AAC-Automatic air conditioning
CD0005	This setting should only be changed if requested by customer.	AAC-Automatic air conditioning
CD0006	Workshop coding	AAC-Automatic air conditioning
CD0007	Workshop coding1	AAC-Automatic air conditioning
CD0008	Workshop coding2	AAC-Automatic air conditioning
CD0009	Automatic child seat recognition(AKSE)/Seat occupied recognition	AB-Airbag
CD0010	Buckle emergency tensioning retractor	AB-Airbag
CD0011	Disposal detonation	AB-Airbag
CD0012	Emergency tensioning retractor	AB-Airbag
CD0013	Emergency tensioning retractor(FRONT)	AB-Airbag
CD0014	Kneebags	AB-Airbag
CD0015	NECK-PRO head restraint	AB-Airbag
CD0016	Passenger airbag	AB-Airbag
CD0017	Pyrofuse	AB-Airbag
CD0018	Read coding and change if necessary.	AB-Airbag
CD0019	Rear seat belts	AB-Airbag
CD0020	Seat belt buckle switch(FRONT)	AB-Airbag
CD0021	Seat belt buckles	AB-Airbag
CD0022	Seat belt reminder warning for front passenger	AB-Airbag
CD0023	Seat fittings	AB-Airbag
CD0024	Seat mat type 'Passenger'	AB-Airbag
CD0025	Settings	AB-Airbag
CD0026	Side airbag deactivation [USA]	AB-Airbag
CD0027	Side airbags	AB-Airbag
CD0028	Side airbags[FRONT PASSENGER]	AB-Airbag
CD0029	Special protection	AB-Airbag
CD0030	Steering variant	AB-Airbag
CD0031	Vehicle equipment	AB-Airbag
CD0032	Vehicle model	AB-Airbag
CD0033	Window airbags	AB-Airbag

CD0034	Additional settings	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)
CD0035	Installation state	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)
CD0036	Radio parameters	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)
CD0037	Specified configuration of MOST components	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)
CD0038	Read coding and change if necessary.	AHE-Trailer recognition
CD0039	Variant coding	AHE-Trailer recognition
CD0040	Brake data	ASSYST PLUS-PLUS Active Service System
CD0041	Current brake lining thickness	ASSYST PLUS-PLUS Active Service System
CD0042	Internal ASSYST PLUS data	ASSYST PLUS-PLUS Active Service System
CD0043	Service work sequence	ASSYST PLUS-PLUS Active Service System
CD0044	ATA alarm signal siren	ATA-Anti theft alarm system
CD0045	ATA basic function	ATA-Anti theft alarm system
CD0046	Installation state	AUDIO
CD0047	Navigation	AUDIO
CD0048	Navigation parameters	AUDIO
CD0049	Radio parameters	AUDIO
CD0050	Rear screen	AUDIO
CD0051	TV parameters(Shut off criteria)	AUDIO
CD0052	All codes	C AAC-Convenience automatic air conditioning/AAC-Automatic air conditioning/HEAT-Automatic
CD0053	Special settings	C AAC-Convenience automatic air conditioning/AAC-Automatic air conditioning/HEAT-Automatic
CD0054	This setting should only be changed if requested by customer.	C AAC-Convenience automatic air conditioning/AAC-Automatic air conditioning/HEAT-Automatic
CD0055	Workshop coding	C AAC-Convenience automatic air conditioning/AAC-Automatic air conditioning/HEAT-Automatic
CD0056	Coding	CDI 3-Common Rail Diesel Injection3
CD0057	Read coding and change if necessary.	CDI 3-Common Rail Diesel Injection3
CD0058	SCN(Software Calibration Number)	CDI 3-Common Rail Diesel Injection3
CD0059	Variant coding according to factory data	CDI 3-Common Rail Diesel Injection3
CD0060	All codes	CGW-Central gateway
CD0061	Factory settings	COMAND
CD0062	Language settings	COMAND
CD0063	Menu settings	COMAND
CD0064	Menu settings()	COMAND
CD0065	AUX input	COMAND or AUDIO
CD0066	Language settings	COMAND or AUDIO
CD0067	Navigation data	COMAND or AUDIO
CD0068	Read coding and change if necessary.	DCM FL-Door control module front left
CD0069	Read coding and change if necessary.	DCM FR-Door control module front right

CD0070	Read coding and change if necessary.	DCM RL-Door control module rear left
CD0071	Read coding and change if necessary.	DCM RR-Door control module rear right
CD0072	Refrigerant' pressure sensor	Dr side SAM-Driver signal acquisition and actuation module
CD0073	Air conditioning	Dr side SAM-Driver signal acquisition and actuation module
CD0074	Auxiliary fan Coolant	Dr side SAM-Driver signal acquisition and actuation module
CD0075	Blower motor in control module box	Dr side SAM-Driver signal acquisition and actuation module
CD0076	Coding of model series	Dr side SAM-Driver signal acquisition and actuation module
CD0077	Curve illumination	Dr side SAM-Driver signal acquisition and actuation module
CD0078	Engine version	Dr side SAM-Driver signal acquisition and actuation module
CD0079	Equipment	Dr side SAM-Driver signal acquisition and actuation module
CD0080	Exterior lighting	Dr side SAM-Driver signal acquisition and actuation module
CD0081	Footwell lighting	Dr side SAM-Driver signal acquisition and actuation module
CD0082	Gear display	Dr side SAM-Driver signal acquisition and actuation module
CD0083	Headlamp cleaning system	Dr side SAM-Driver signal acquisition and actuation module
CD0084	Heated steering wheel	Dr side SAM-Driver signal acquisition and actuation module
CD0085	Model designation(Only with code 336)	Dr side SAM-Driver signal acquisition and actuation module
CD0086	Oil cooler relay	Dr side SAM-Driver signal acquisition and actuation module
CD0087	Signal Terminal 61	Dr side SAM-Driver signal acquisition and actuation module
CD0088	Steering column module	Dr side SAM-Driver signal acquisition and actuation module
CD0089	Turning lamps	Dr side SAM-Driver signal acquisition and actuation module
CD0090	Washer nozzle heater	Dr side SAM-Driver signal acquisition and actuation module
CD0091	Windshield wiper	Dr side SAM-Driver signal acquisition and actuation module
CD0092	Wiper rest heater	Dr side SAM-Driver signal acquisition and actuation module
CD0093	Wiper system	Dr side SAM-Driver signal acquisition and actuation module
CD0094	Read coding and change if necessary.	EPB-Electric parking brake
CD0095	Variant coding	ESA FL-Electric seat adjustment front left
CD0096	Variant coding	ESA FR-Electric seat adjustment front right
CD0097	Read coding and change if necessary.	ESA R-Electric seat adjustment rear
CD0098	Variant coding	ESA R-Electric seat adjustment rear
CD0099	Read coding and change if necessary.	ESA driver-Electric seat adjustment driver (with memory)
CD0100	Read coding and change if necessary.	ESA passenger-Electric seat adjustment passenger
CD0101	Read coding and change if necessary.	ESM-Electronic selector module
CD0102	Distronic	ESP-Electronic stability program
CD0103	ESP-Trailer stabilization	ESP-Electronic stability program
CD0104	Speed-sensitive power steering	ESP-Electronic stability program
CD0105	AIRmatic/ABC active body control	EZS-Electronic ignition switch

CD0106	ATA interior motion / towing sensor	EZS-Electronic ignition switch
CD0107	ATA interior motion sensor	EZS-Electronic ignition switch
CD0108	ATA towing sensor	EZS-Electronic ignition switch
CD0109	All codes	EZS-Electronic ignition switch
CD0110	Automatic closing of front windows	EZS-Electronic ignition switch
CD0111	Automatic closing of rear windows	EZS-Electronic ignition switch
CD0112	Automatic dimming mirror	EZS-Electronic ignition switch
CD0113	Automatic driving lights on	EZS-Electronic ignition switch
CD0114	COMAND or AUDIO	EZS-Electronic ignition switch
CD0115	Cellular telephone	EZS-Electronic ignition switch
CD0116	Central gateway functionality	EZS-Electronic ignition switch
CD0117	Climate control	EZS-Electronic ignition switch
CD0118	Convenience systems	EZS-Electronic ignition switch
CD0119	Distronic	EZS-Electronic ignition switch
CD0120	Driving lights	EZS-Electronic ignition switch
CD0121	Engine cooling	EZS-Electronic ignition switch
CD0122	Fuel cell or electric drive	EZS-Electronic ignition switch
CD0123	Headlamp cleaning system	EZS-Electronic ignition switch
CD0124	Headlamp range adjustment	EZS-Electronic ignition switch
CD0125	Keyless Go	EZS-Electronic ignition switch
CD0126	Lane recognition	EZS-Electronic ignition switch
CD0127	Manual recirculated air control	EZS-Electronic ignition switch
CD0128	Multifunction steering wheel	EZS-Electronic ignition switch
CD0129	National version	EZS-Electronic ignition switch
CD0130	Parktronic	EZS-Electronic ignition switch
CD0131	Power locking	EZS-Electronic ignition switch
CD0132	Rear air conditioning	EZS-Electronic ignition switch
CD0133	Rear window screen	EZS-Electronic ignition switch
CD0134	Relocking/Vehicle speed threshold for automatic locking	EZS-Electronic ignition switch
CD0135	Seat adjustment	EZS-Electronic ignition switch
CD0136	Series and engine version	EZS-Electronic ignition switch
CD0137	Set status CAN bus	EZS-Electronic ignition switch
CD0138	Sound system	EZS-Electronic ignition switch
CD0139	Special vehicle multifunction control module (SVMCM)	EZS-Electronic ignition switch
CD0140	Special vehicles	EZS-Electronic ignition switch
CD0141	Standard setting: Climate control	EZS-Electronic ignition switch

CD0142	Stationary heater or Telestart	EZS-Electronic ignition switch
CD0143	Sun sensor	EZS-Electronic ignition switch
CD0144	Telecommunications	EZS-Electronic ignition switch
CD0145	Telematic service 'Remote door unlocking' (TELE AID)	EZS-Electronic ignition switch
CD0146	Tire pressure monitor	EZS-Electronic ignition switch
CD0147	Trailer	EZS-Electronic ignition switch
CD0148	Trailer lighting	EZS-Electronic ignition switch
CD0149	Trailer recognition	EZS-Electronic ignition switch
CD0150	Trailer recognition/Trailer lighting	EZS-Electronic ignition switch
CD0151	Transmission	EZS-Electronic ignition switch
CD0152	Turn signal confirmation for opening and closing via transmitter key	EZS-Electronic ignition switch
CD0153	Vehicle speed signal threshold for automatic locking	EZS-Electronic ignition switch
CD0154	Voice control system	EZS-Electronic ignition switch
CD0155	Washer system	EZS-Electronic ignition switch
CD0156	Windscreen heater	EZS-Electronic ignition switch
CD0157	Wiper system	EZS-Electronic ignition switch
CD0158	Wipers	EZS-Electronic ignition switch
CD0159	Read coding.	FSCU-Fuel pump
CD0160	Read coding and change if necessary.	FSCU-Fuel pump AMG
CD0161	Read coding and change if necessary.	HRA-Automatic headlamp range adjustment and headlamp control
CD0162	Configuration for key 1	IC-Instrument cluster
CD0163	Configuration for key 2	IC-Instrument cluster
CD0164	Configuration for key 3	IC-Instrument cluster
CD0165	Current menu setting	IC-Instrument cluster
CD0166	Customer-specific settings	IC-Instrument cluster
CD0167	Trip computer settings	IC-Instrument cluster
CD0168	Codings specific for instrument cluster	ICM-Instrument cluster with maintenance interval display
CD0169	Configuration for key 1	ICM-Instrument cluster with maintenance interval display
CD0170	Configuration for key 2	ICM-Instrument cluster with maintenance interval display
CD0171	Configuration for key 3	ICM-Instrument cluster with maintenance interval display
CD0172	Display coding	ICM-Instrument cluster with maintenance interval display
CD0173	Factory settings	ICM-Instrument cluster with maintenance interval display
CD0174	RDK tire pressure control	ICM-Instrument cluster with maintenance interval display
CD0175	Special equipment	ICM-Instrument cluster with maintenance interval display
CD0176	Read coding and change if necessary.	KG-KEYLESS GO
CD0177	Read coding and change if necessary.	KG-Keyless Go

CD0178	Coding	ME 9.7-Motor electronics 9.7
CD0179	Coding	ME SF 17.7-Motor electronics 17.7
CD0180	Read coding and change if necessary.	ME SFI 2.0-Motor electronics 2.0
CD0181	Special vehicle special protection(B4):Read coding and change if necessary	ME SFI 2.0-Motor electronics 2.0
CD0182	Special vehicle special protection(B6/B7):Read coding and change if necessary	ME SFI 2.0-Motor electronics 2.0
CD0183	CVN(Calibration verification number)	ME SFI 2.8-Motor electronics 2.8
CD0184	Coding	ME SFI 2.8-Motor electronics 2.8
CD0185	Read coding and change if necessary.	ME SFI 2.8-Motor electronics 2.8
CD0186	Read coding.	ME SFI 2.8-Motor electronics 2.8
CD0187	SCN(Software Calibration Number)	ME SFI 2.8-Motor electronics 2.8
CD0188	Special vehicle special protection:Read coding and change if necessary.	ME SFI 2.8-Motor electronics 2.8
CD0189	CVN(Calibration verification number)	ME SFI-CNG compressed natural gas
CD0190	Coding	ME SFI-CNG compressed natural gas
CD0191	SCN(Software Calibration Number)	ME SFI-CNG compressed natural gas
CD0192	Variant coding according to factory data	ME SFI-CNG compressed natural gas
CD0193	CVN(Calibration verification number)	ME SFI-Gasoline engine control
CD0194	Coding	ME SFI-Gasoline engine control
CD0195	Coding according to plant data	ME SFI-Gasoline engine control
CD0196	SCN(Software Calibration Number)	ME SFI-Gasoline engine control
CD0197	Coding	ME SFI-Motor electronics
CD0198	Read coding and change if necessary.	ME SFI-Motor electronics
CD0199	Read coding.	ME SFI-Motor electronics
CD0200	CVN(Calibration verification number)	MED 17.7-Motor electronics for direct injection 17.7
CD0201	Coding	MED 17.7-Motor electronics for direct injection 17.7
CD0202	SCN(Software Calibration Number)	MED 17.7-Motor electronics for direct injection 17.7
CD0203	Type approval number	MED 17.7-Motor electronics for direct injection 17.7
CD0204	Coding	MED 9.7-Motor electronics for direct injection 9.7
CD0205	Additional equipment	MSS-Special vehicle multifunction control module
CD0206	Advanced options	MSS-Special vehicle multifunction control module
CD0207	Full alarm	MSS-Special vehicle multifunction control module
CD0208	Higher-priority alarm options	MSS-Special vehicle multifunction control module
CD0209	Odometer	MSS-Special vehicle multifunction control module
CD0210	Options	MSS-Special vehicle multifunction control module
CD0211	Radio help call	MSS-Special vehicle multifunction control module
CD0212	Read the coding of control module ZGW.	MSS-Special vehicle multifunction control module
CD0213	Run-on times	MSS-Special vehicle multifunction control module

CD0214	Silent alarm	MSS-Special vehicle multifunction control module
CD0215	Undervoltage value	MSS-Special vehicle multifunction control module
CD0216	Anti-pinch protection	OCP-Overhead control panel
CD0217	Automatic interior mirror dimming	OCP-Overhead control panel
CD0218	Close-via-tilt function	OCP-Overhead control panel
CD0219	Closing of tilting/sliding roof when it rains	OCP-Overhead control panel
CD0220	Coding of sliding/tilting roof function of 'automatic operation'	OCP-Overhead control panel
CD0221	Interior lamp-Actuation	OCP-Overhead control panel
CD0222	Light sensor	OCP-Overhead control panel
CD0223	Panoramic sliding roof	OCP-Overhead control panel
CD0224	Parameterization and windshield adaptation	OCP-Overhead control panel
CD0225	Presafe	OCP-Overhead control panel
CD0226	Read coding and change if necessary.	OCP-Overhead control panel
CD0227	Read coding and change if necessary.(Panoramic sliding roof)	OCP-Overhead control panel
CD0228	Read coding and change if necessary.(Sliding/tilting roof)	OCP-Overhead control panel
CD0229	Roller sun blind	OCP-Overhead control panel
CD0230	Sliding/tilting roof	OCP-Overhead control panel
CD0231	Tilting/sliding roof memory feature	OCP-Overhead control panel
CD0232	Central locking	PSE-Pneumatic system equipment
CD0233	Childproof locks	PSE-Pneumatic system equipment
CD0234	Emergency opening	PSE-Pneumatic system equipment
CD0235	Factory settings Trunk lid remote closing	PSE-Pneumatic system equipment
CD0236	Head restraint adjustment	PSE-Pneumatic system equipment
CD0237	Multicontour backrests	PSE-Pneumatic system equipment
CD0238	Power locking	PSE-Pneumatic system equipment
CD0239	Trunk interior button(1)	PSE-Pneumatic system equipment
CD0240	Trunk interior button(2)	PSE-Pneumatic system equipment
CD0241	Trunk lid remote closing	PSE-Pneumatic system equipment
CD0242	Trunk lid remote release	PSE-Pneumatic system equipment
CD0243	License plate bracket	PTS-PARKTRONIC
CD0244	Steering version	PTS-PARKTRONIC
CD0245	Trailer coupling	PTS-PARKTRONIC
CD0246	Warning signal-Configuration	PTS-PARKTRONIC
CD0247	License plate bracket	PTS-Parktronic system
CD0248	PTS switch	PTS-Parktronic system
CD0249	ROELight Configuration	PTS-Parktronic system

CD0250	Rear warning elements	PTS-Parktronic system
CD0251	Trailer coupling	PTS-Parktronic system
CD0252	Vehicle version	PTS-Parktronic system
CD0253	Warning signal-Configuration	PTS-Parktronic system
CD0254	Front seat heater	Pass side SAM-Passenger-side signal acquisition and actuation module
CD0255	Radiator blind	Pass side SAM-Passenger-side signal acquisition and actuation module
CD0256	Side lamp Version	Pass side SAM-Passenger-side signal acquisition and actuation module
CD0257	Turning lamps	Pass side SAM-Passenger-side signal acquisition and actuation module
CD0258	ATA National variant coding	REAR SAM-Rear signal acquisition and actuation module
CD0259	ATA Volume control:Warning buzzer(USA)	REAR SAM-Rear signal acquisition and actuation module
CD0260	Ambiance lighting(Code 877)	REAR SAM-Rear signal acquisition and actuation module
CD0261	Battery sensor	REAR SAM-Rear signal acquisition and actuation module
CD0262	Battery sensor LIN bus	REAR SAM-Rear signal acquisition and actuation module
CD0263	Cigarette lighter	REAR SAM-Rear signal acquisition and actuation module
CD0264	Diesel particulate filter	REAR SAM-Rear signal acquisition and actuation module
CD0265	EDW anti-theft alarm	REAR SAM-Rear signal acquisition and actuation module
CD0266	Easy Entry	REAR SAM-Rear signal acquisition and actuation module
CD0267	Easy Entry/Rear seat belt buckle switch(Code U01)	REAR SAM-Rear signal acquisition and actuation module
CD0268	Electric rear window curtain	REAR SAM-Rear signal acquisition and actuation module
CD0269	Equipment version	REAR SAM-Rear signal acquisition and actuation module
CD0270	Flashing stop lamp	REAR SAM-Rear signal acquisition and actuation module
CD0271	LED'Trailer lighting'	REAR SAM-Rear signal acquisition and actuation module
CD0272	Light	REAR SAM-Rear signal acquisition and actuation module
CD0273	Miscellaneous	REAR SAM-Rear signal acquisition and actuation module
CD0274	Model series	REAR SAM-Rear signal acquisition and actuation module
CD0275	Rear foglight	REAR SAM-Rear signal acquisition and actuation module
CD0276	Rear head restraint lowering	REAR SAM-Rear signal acquisition and actuation module
CD0277	Rear screen	REAR SAM-Rear signal acquisition and actuation module
CD0278	Rear-end door lock	REAR SAM-Rear signal acquisition and actuation module
CD0279	Relays Seat adjustment	REAR SAM-Rear signal acquisition and actuation module
CD0280	Assignment of control unit to model series	REDC-Rear end door closing control module
CD0281	Read coding and change if necessary.	REDC-Rear end door closing control module
CD0282	Special equipment 'Spare wheel carrier'	REDC-Rear end door closing control module
CD0283	Read coding and change if necessary.	RWT-Rear end door control module
CD0284	Read coding and change if necessary.	RevETR LF-Left front reversible emergency tensioning retractor
CD0285	Vehicle equipment	RevETR LF-Left front reversible emergency tensioning retractor

CD0286	Read coding and change if necessary.	RevETR RF-Right front reversible emergency tensioning retractor
CD0287	Vehicle equipment	RevETR RF-Right front reversible emergency tensioning retractor
CD0288	Read coding and change if necessary.(Only for special protection vehicles)	SAM F-Signal acquisition and actuation module front
CD0289	Basic setting(N10 (SAM control unit))	SAM-Signal acquisition and actuation module
CD0290	Light sensor	SAM-Signal acquisition and actuation module
CD0291	Rear foglight(National version)	SAM-Signal acquisition and actuation module
CD0292	CVN(Calibration verification number)	SCR-Selective Catalytic Reduction
CD0293	Coding according to plant data	SCR-Selective Catalytic Reduction
CD0294	SCN(Software Calibration Number)	SCR-Selective Catalytic Reduction
CD0295	Type approval number	SCR-Selective Catalytic Reduction
CD0296	Read coding and change if necessary.	TLC-Trunk lid control
CD0297	Read coding and change if necessary.	TPM-Tire pressure monitor
CD0298	National variant coding	TV-TV tuner(AGW)
CD0299	PAL/NTSC	TV-TV tuner(AGW)
CD0300	Read coding and change if necessary.	UCP-Upper control panel
CD0301	Coding according to plant data:Read coding and change if necessary.	XALWA L-Xenon headlamp, left
CD0302	Display of coding data	XALWA L-Xenon headlamp, left
CD0303	Read coding and change if necessary.	XALWA L-Xenon headlamp, left
CD0304	Display of SCN	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
CD0305	Display of CVN	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
CD0306	Display of model check number	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
CD0307	Writing of the VIN	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
CD0308	Initial startup	E call [Europe]-Emergency call system
CD0309	Current menu settings	IC-Instrument cluster
CD0310	Transfer of manufacturer default settings	IC-Instrument cluster
CD0311	Oil grade factor	IC-Instrument cluster
CD0312	Customer-specific settings	IC-Instrument cluster
CD0313	Subsequent adjustment of resistance of GSM antenna	KOMO-Communication module Telematics services
CD0314	Language setting	KOMO/mbrace-Communication module 'Telematics services'/Notrufsystem
CD0315	Check configuration.	KOMO/mbrace-Communication module 'Telematics services'/Notrufsystem
CD0316	Data logger	KOMO/mbrace-Communication module 'Telematics services'/Notrufsystem
CD0317	Display of coding data	EZS-Electronic ignition switch
CD0318	Disabling of key or key track with workshop key	EZS-Electronic ignition switch
CD0319	Disabling of key or key track	EZS-Electronic ignition switch
CD0320	Re-enabling of key or key track	EZS-Electronic ignition switch
CD0321	Writing of vehicle identification number	EZS-Electronic ignition switch

CD0322	Vehicle model	AMG DRVU-AMG DRIVE UNIT(N145)
CD0323	Events	ESP-Electronic stability program(N30/4)
CD0324	Check coding "Hill Start Assist".	ESP-Electronic stability program(N30/4)
CD0325	Special function FIN	ESP-Electronic stability program(N30/4)
CD0326	Check of control unit software	SRS-Supplemental restraint system (N2/10)
CD0327	Locking of control unit	SRS-Supplemental restraint system (N2/10)
CD0328	Unlocking of control unit	SRS-Supplemental restraint system (N2/10)
CD0329	Setting language	AUDIO-Audio or COMAND(A2-A40/3)
CD0330	Video AUX jack	AUDIO-Audio or COMAND(A2-A40/3)
CD0331	Mercedes-Benz Contact	AUDIO-Audio or COMAND(A2-A40/3)
CD0332	Run-on time after switching off ignition	AUDIO-Audio or COMAND(A2-A40/3)
CD0333	SPLITVIEW	AUDIO-Audio or COMAND(A2-A40/3)
CD0334	Restart MOST ring.	AUDIO-Audio or COMAND(A2-A40/3)
CD0335	Taxi	Multifunction control unit-Multifunction control unit
CD0336	Customer request	Multifunction control unit-Multifunction control unit
CD0337	Mercedes-Benz Guard special protection vehicle	Multifunction control unit-Multifunction control unit
CD0338	Reset of coding	Multifunction control unit-Multifunction control unit
CD0339	Restoration of communication with the control unit	Multifunction control unit-Multifunction control unit
CD0340	Control unit reset	Multifunction control unit-Multifunction control unit
CD0341	Control unit replacement with initial startup of new control unit	TV-TV tuner
CD0342	Initial startup of already installed control unit	TV-TV tuner
CD0343	National version	TV-TV tuner
CD0344	Control line of component "Antenna amplifier"	TV-TV tuner
CD0345	Type of antennas	TV-TV tuner
CD0346	Type of video signal	TV-TV tuner
CD0347	PAL / NTSC	TV-TV tuner
CD0348	Configuration of AUX jacks	TV-TV tuner
CD0349	Special function	TV-TV tuner
CD0350	Fan	TV-TV tuner
CD0351	All codings	TV-TV tuner
CD0352	Reset	TV-TV tuner
CD0353	Workshop coding	AAC-Automatic air conditioning
CD0354	Special settings	AAC-Automatic air conditioning
CD0355	No-load current	AAC-Automatic air conditioning
CD0356	Parameters of DAB tuner	DAB-Digital Audio Broadcasting(N87/3)
CD0357	Variant coding	STH-Stationary heater

CD0358	Data record	STH-Stationary heater
CD0359	Model of trailer hitch	TRM-Trailer recognition module (N28/1)
CD0360	Erasing of initialization values	Trailer recognition module-Trailer recognition
CD0361	Teach-in process	WSS-Weight sensing system(N110)
CD0362	Security code	GTO-Garage door opener(A67n2)
CD0363	Country code	GTO-Garage door opener(A67n2)
CD0364	Initialization	GTO-Garage door opener(A67n2)
CD0365	Version of switch group	OCP-Control unit 'Overhead control panel'
CD0366	Location of interior lamp	OCP-Control unit 'Overhead control panel'
CD0367	E15/3 (Rear dome lamp)	OCP-Control unit 'Overhead control panel'
CD0368	Volume and frequency	PARK-Parking system (N62)
CD0369	Function illumination	DSI-DIRECT SELECT interface(N150)
CD0370	Manual initial startup	VG-All wheel drive
CD0371	Volume of acoustic locking feedback	AS-Alarm siren(H3/1)
CD0372	Important note	AS-Alarm siren(H3/1)
CD0373	Correction programming of ignition	N3/10-Motor electronics "MED40" for combustion engine "M274"
CD0374	Correction programming of fuel quantity	N3/10-Motor electronics "MED40" for combustion engine "M274"
CD0375	Correction programming of specified idle speed	N3/10-Motor electronics "MED40" for combustion engine "M274"
CD0376	Correction programming of specified idle speed with gear range engaged	N3/10-Motor electronics "MED40" for combustion engine "M274"
CD0377	Injector injection quantity adjustment	N3/10-Motor electronics "MED40" for combustion engine "M274"
CD0378	Correction programming of specified idle speed in selector lever position "P"	N3/10-Motor electronics "MED40AMG" for combustion engine "M133"
CD0379	Correction programming of electrohydraulic actuator part number	Y3/8n4-Transmission control for 7 speed transmission
CD0380	Automatic function:Transfer of coding into control unit "Display in rear pass	AVE H-Rear audio video unit
CD0381	Connected control units	AVE H-Rear audio video unit
CD0382	Region code	AVE H-Rear audio video unit
CD0383	Special functionFIN	ESP-Electronic stability program(N30/4)
CD0384	Calibration of component "A7/3 (Traction system hydraulic unit)"	ESP-Electronic stability program(N30/4)
CD0385	Special functions	ESP-Regenerative braking system(N30/6)
CD0386	Special functionVIN	ESP-Regenerative braking system(N30/6)
CD0387	M40Pneumatic pump for multicontour seat	PPAMKS-Pneumatic pump for active multicontour seat
CD0388	M40/1Pneumatic pump for active multicontour seat	PPAMKS-Pneumatic pump for active multicontour seat
CD0389	M40 (Multicontour seat pneumatic pump)	PPAMKS-Pneumatic pump for multicontour seat
CD0390	M40/1 (Dynamic multicontour seat pneumatic pump)	PPAMKS-Pneumatic pump for multicontour seat
CD0391	M40/1 (Active multicontour seat pneumatic pump)	PPAMKS-Pneumatic pump for multicontour seat
CD0392	Activation of component "Rear switching module"	KG-KEYLESS GO(N69/5)
CD0393	Parameters of sound system	SOUND-Bose sound system

CD0394	Antenna monitoring	ECS-N123/4 Emergency call system control unit
CD0395	Waking control unit by pressing a button	ECS-N123/4 Emergency call system control unit
CD0396	NavigationParameter	ECS-N123/4 Emergency call system control unit
CD0397	Model series	ECS-N123/4 Emergency call system control unit
CD0398	Vehicle configuration	ECS-N123/4 Emergency call system control unit
CD0399	Messages in multifunction display	ECS-N123/4 Emergency call system control unit
CD0400	Antenna resistance values	ECS-N123/4 Emergency call system control unit
CD0401	Antenna resistance values(alternative)	ECS-N123/4 Emergency call system control unit
CD0402	EXTENDEDSet	ECS-N123/4 Emergency call system control unit
CD0403	AirbagCode	ECS-N123/4 Emergency call system control unit
CD0404	Width of license plate bracket	PTS-Parktronic system
CD0405	Trailer hitch	PTS-Parktronic system
CD0406	Delay period for turn signals after closing of trunk lid	EZS-Electronic ignition switch
CD0407	Special functions VIN	ESP- Electric stability program
CD0408	Seat adjustment	N32/1 (Driver seat control unit)
CD0409	Exit lamp "A-pillar"	OCP-Control unit 'Overhead control panel'
CD0410	Switch group	OCP-Control unit 'Overhead control panel'
CD0411	Interior lamp in rear compartment	OCP-Control unit 'Overhead control panel'
CD0412	Correction programming of electric fan for combustion engine or air conditi	N3/10-Motor electronics "SIM271DE20" for combustion engine "M271EVO"
CD0413	Default initialization	N3/10-Motor electronics "SIM271DE20" for combustion engine "M271EVO"
CD0414	Frequency readout	AUDIO-Audio(A2)
CD0415	Perform control unit reset.	AUDIO-Audio(A2)
CD0416	The production run is active.	STC-Soft top control(N52)
CD0417	Adjusting the parameters	AMG PM-AMG Performance Media(N125/2)
CD0418	Special function VIN	ESP-Electronic stability program(N30/4)
CD0419	Check codings in control unit "Audio or COMAND" and change if necessary	Audio-Audio or COMAND
CD0420	Language for the voice control system	Audio-Audio or COMAND
CD0421	Navigation data	Audio-Audio or COMAND
CD0422	Special equipment	Audio-Audio or COMAND
CD0423	Deactivation of MOST communication	Audio-Audio or COMAND
CD0424	Activation of MOST communication	Audio-Audio or COMAND
CD0425	Check codings in control unit "22 KW".	SG LG-Charger
CD0426	Automatic codings	SG LG-Charger
CD0427	Lock high-voltage component lock.	SG LG-Charger
CD0428	Unlock high-voltage component lock.	SG LG-Charger
CD0429	Set type of antenna.	KOMO-Communication module Telematics services

CD0430	Reading of parameter data from control unit	PTCU-MA-Drivetrain (master)
CD0431	Writing of parameter data to control unit	PTCU-MA-Drivetrain (master)
CD0432	Display currently set codings.	PTCU-MA-Drivetrain (master)
CD0433	Coding of control unit	PTCU-MA-Drivetrain (master)
CD0434	Roof sign lamp	Multifunction control unit-Multifunction control unit
CD0435	Silent alarm	Multifunction control unit-Multifunction control unit
CD0436	Active alarm	Multifunction control unit-Multifunction control unit
CD0437	Radio help call	Multifunction control unit-Multifunction control unit
CD0438	Run-on times	Multifunction control unit-Multifunction control unit
CD0439	Other options	Multifunction control unit-Multifunction control unit
CD0440	Increase in the opening angle of the liftgate	TLC-Trunk lid control
CD0441	Panoramic sliding sunroof	PSD-Control module 'Panoramic sliding roof'(A98)
CD0442	A67 (Inside rearview mirror)	OCP-Overhead control panel
CD0443	Tilting/sliding sunroof	OCP-Overhead control panel
CD0444	OFF time of interior lamp in dimmed state	OCP-Overhead control panel
CD0445	ON time of interior lamp in dimmed state	OCP-Overhead control panel
CD0446	Type of trailer hitch and national version	TRM-Trailer recognition module (N28/1)
CD0447	Read out coding and modify if necessary.	FSCU01-Control unit Fuel pump
CD0448	Manual coding	FSCU Left-Control unit 'Left fuel pump'
CD0449	Folding in/out of outside mirrors	DCU LF-Left front door(N69/1)
CD0450	Special equipment "AIRCAP"	REAR-Rear unit(N22/6)
CD0451	Coding of component "Belt extender"	REAR-Rear control unit(N22/6)
CD0452	Enable natural gas operation	N3/10-Motor electronics "MED40CNG" for combustion engine "M270"
CD0453	Enable natural gas operation after crash event.	N3/10-Motor electronics "MED40CNG" for combustion engine "M270"
CD0454	Natural gas operationCorrection value	N3/10-Motor electronics "SIM271KECNG" for combustion engine "M271CNG"
CD0455	Correction programming of fuel quantity(Natural gas operation)	N3/10-Motor electronics "SIM271KECNG" for combustion engine "M271CNG"
CD0456	ValveMassage function	MKS LF-Left front multicontour seat
CD0457	Reading of parameter data for the component "M56 (Vacuum pump)"	PTCU-Common powertrain controller(N127)
CD0458	Writing of parameter data for the component "M56 (Vacuum pump)"	PTCU-Common powertrain controller(N127)
CD0459	Resetting of parameter data for the component "M56 (Vacuum pump)"	PTCU-Common powertrain controller(N127)
CD0460	Reading of fare settings	PTCU-Common powertrain controller(N127)
CD0461	Writing of fare settings	PTCU-Common powertrain controller(N127)
CD0462	Resetting of fare settings	PTCU-Common powertrain controller(N127)
CD0463	Performance of a control unit power-down	PTCU-Common powertrain controller(N127)

Special Functions

No.	Functions Name	System Name
SP0001	AC compressor	AAC-Automatic air conditioning
SP0002	Breaking-in of refrigerant compressor	AAC-Automatic air conditioning
SP0003	Breaking-in procedure after replacement of refrigerant compressor	AAC-Automatic air conditioning
SP0004	Breaking-in of refrigerant compressor	AAC-Automatic air conditioning
SP0005	Check of the adjustment range of the actuator motors	AAC-Automatic air conditioning
SP0006	Normalization of actuator motors	AAC-Automatic air conditioning
SP0007	Normalizing of positioning motors	AAC-Automatic air conditioning
SP0008	Teach-in of actuator motors	AAC-Automatic air conditioning
SP0009	Teach-in of actuator motors after actuator motor replacement	AAC-Automatic air conditioning
SP0010	Steering variant	AB-Airbag
SP0011	Calibration of plunger travel	ABC-ABC active body control
SP0012	Initial startup with automatic takeover of settings of previous control unit	ABC-ABC active body control
SP0013	Raise and lower the suspension struts at high speed	ABC-ABC active body control
SP0014	Raise and lower the suspension struts at high speed	ABC-ABC active body control
SP0015	Raise and lower the suspension struts at low speed	ABC-ABC active body control
SP0016	Raise and lower the suspension struts at medium speed	ABC-ABC active body control
SP0017	Raise and lower the suspension struts at medium speed	ABC-ABC active body control
SP0018	Reset of calibrations	ABC-ABC active body control
SP0019	Driving test	ABR-Adaptive Brake
SP0020	Erase zero point offset error of component N49 (Steering angle sensor)	ABR-Adaptive Brake
SP0021	PML speed-sensitive power steering	ABR-Adaptive Brake
SP0022	Tyre pressure loss alarm (activated)	ABR-Adaptive Brake
SP0023	Reset of compressor operating time	ADS-Adaptive damping system
SP0024	Initial startup with automatic takeover of settings of previous control unit	AIRmatic
SP0025	Level calibration	AIRmatic
SP0026	Breaking-in procedure after replacement of refrigerant compressor	C AAC-Convenience automatic air conditioning/AAC-Automatic air
SP0027	Normalizing of positioning motors	C AAC-Convenience automatic air conditioning/AAC-Automatic air
SP0028	Teach-in of actuator motors after actuator motor replacement	C AAC-Convenience automatic air conditioning/AAC-Automatic air
SP0029	Activate fuel pump	CDI 3-Common Rail Diesel Injection3
SP0030	Adjustment of injector injection quantities	CDI 3-Common Rail Diesel Injection3
SP0031	B79/2 (Transmission neutral position sensor)	CDI 3-Common Rail Diesel Injection3
SP0032	Injector injection quantity adjustment	CDI 3-Common Rail Diesel Injection3
SP0033	Oxidation catalytic converter	CDI 3-Common Rail Diesel Injection3
SP0034	Regeneration of diesel particulate filter	CDI 3-Common Rail Diesel Injection3

SP0035	Replacement component Diesel particulate filter	CDI 3-Common Rail Diesel Injection3
SP0036	Reset of lambda values	CDI 3-Common Rail Diesel Injection3
SP0037	Reset quantity mean value adaptation data	CDI 3-Common Rail Diesel Injection3
SP0038	Resetting of contamination level of air filter	CDI 3-Common Rail Diesel Injection3
SP0039	Resetting of learned values of component 'B6/1 (Camshaft Hall sensor)'	CDI 3-Common Rail Diesel Injection3
SP0040	Teach in of throttle valve stop	CDI 3-Common Rail Diesel Injection3
SP0041	Teach-in of diesel particulate filter after replacement of control unit 'N3/9 (CDI control unit)'	CDI 3-Common Rail Diesel Injection3
SP0042	Teach-in of intake port shutoff	CDI 3-Common Rail Diesel Injection3
SP0043	Teach-in process after replacement of component 'AdBlue metering valve'	CDI 3-Common Rail Diesel Injection3
SP0044	Teach-in process after replacement of component 'B16/15 (Temperature sensor upstream of SCR	CDI 3-Common Rail Diesel Injection3
SP0045	Teach-in process after replacement of component 'Diesel particulate filter'	CDI 3-Common Rail Diesel Injection3
SP0046	Teach-in process after replacement of component 'SCR catalytic converter'	CDI 3-Common Rail Diesel Injection3
SP0047	Teach-in process after replacing NOx sensor	CDI 3-Common Rail Diesel Injection3
SP0048	Adjustment of injector injection quantities	CDI 4-Common Rail Diesel Injection
SP0049	Diesel particulate filter Configuration	CDI 4-Common Rail Diesel Injection
SP0050	Diesel particulate filter Purge control	CDI 4-Common Rail Diesel Injection
SP0051	Rapid teach-in of zero quantity calibration values	CDI 4-Common Rail Diesel Injection
SP0052	Regeneration of the diesel particulate filter while driving	CDI 4-Common Rail Diesel Injection
SP0053	Replacement component Diesel particulate filter	CDI 4-Common Rail Diesel Injection
SP0054	Reset quantity mean value adaptation data	CDI 4-Common Rail Diesel Injection
SP0055	Reset values for HFM drift compensation	CDI 4-Common Rail Diesel Injection
SP0056	Resetting air filter learned values after air filter replacement	CDI 4-Common Rail Diesel Injection
SP0057	Teach in of throttle valve stop	CDI 4-Common Rail Diesel Injection
SP0058	Activate fuel pump	CDI 6-Common Rail Diesel Injection
SP0059	Adjustment of injector injection quantities	CDI 6-Common Rail Diesel Injection
SP0060	B28/8(Differential pressure sensor (DPF))	CDI 6-Common Rail Diesel Injection
SP0061	G3/2(Oxygen sensor upstream of catalytic converter)	CDI 6-Common Rail Diesel Injection
SP0062	Quick teach-in of values of zero quantity calibration	CDI 6-Common Rail Diesel Injection
SP0063	Regeneration of diesel particulate filter	CDI 6-Common Rail Diesel Injection
SP0064	Replacement of component 'Diesel particulate filter'	CDI 6-Common Rail Diesel Injection
SP0065	Reset values of HFM drift compensation	CDI 6-Common Rail Diesel Injection
SP0066	Reset values of quantity mean value adaptation	CDI 6-Common Rail Diesel Injection
SP0067	Resetting of contamination level of air filter	CDI 6-Common Rail Diesel Injection
SP0068	Teach in of throttle valve stop	CDI 6-Common Rail Diesel Injection
SP0069	Teach in used diesel particulate filter	CDI 6-Common Rail Diesel Injection
SP0070	Y74(Pressure control valve)	CDI 6-Common Rail Diesel Injection
SP0071	Activate fuel pump	CDI 60LS-Common Rail Diesel Injection

SP0072	B16/15 (Temperature sensor upstream of SCR catalytic converter)	CDI 60LS-Common Rail Diesel Injection
SP0073	B28/8 (DPF differential pressure sensor)	CDI 60LS-Common Rail Diesel Injection
SP0074	G3/2 (Oxygen sensor upstream of catalytic converter)	CDI 60LS-Common Rail Diesel Injection
SP0075	Injector injection quantity adjustment	CDI 60LS-Common Rail Diesel Injection
SP0076	Oxidation catalytic converter	CDI 60LS-Common Rail Diesel Injection
SP0077	Quick teach-in of values of zero quantity calibration	CDI 60LS-Common Rail Diesel Injection
SP0078	Regeneration of the diesel particulate filter while driving	CDI 60LS-Common Rail Diesel Injection
SP0079	Replacing component 'Diesel particulate filter'	CDI 60LS-Common Rail Diesel Injection
SP0080	Reset values of HFM drift compensation	CDI 60LS-Common Rail Diesel Injection
SP0081	Reset values of quantity mean value adaptation	CDI 60LS-Common Rail Diesel Injection
SP0082	Resetting of contamination level of air filter	CDI 60LS-Common Rail Diesel Injection
SP0083	SCR catalytic converter	CDI 60LS-Common Rail Diesel Injection
SP0084	Teach in of throttle valve stop	CDI 60LS-Common Rail Diesel Injection
SP0085	Teach in used diesel particulate filter	CDI 60LS-Common Rail Diesel Injection
SP0086	Teach-in process after replacing Nox sensor	CDI 60LS-Common Rail Diesel Injection
SP0087	Y129 (AdBlue metering valve)	CDI 60LS-Common Rail Diesel Injection
SP0088	Y74 (Pressure regulating valve)	CDI 60LS-Common Rail Diesel Injection
SP0089	Activate fuel pump	CDI-Common Rail Diesel Injection
SP0090	Adjustment of injector injection quantities	CDI-Common Rail Diesel Injection
SP0091	Reset quantity mean value adaptation data	CDI-Common Rail Diesel Injection
SP0092	Reset values for HFM drift compensation	CDI-Common Rail Diesel Injection
SP0093	Resetting air filter learned values after air filter replacement	CDI-Common Rail Diesel Injection
SP0094	Teach-in of diesel particulate filter after replacement of engine control unit without transfer of values	CDI-Common Rail Diesel Injection
SP0095	Teach-in process after replacement of component (B28/8(Differential pressure sensor(DPF)	CDI-Common Rail Diesel Injection
SP0096	Teach-in process after replacement of component G3/1(O2 sensor downstream TWC)	CDI-Common Rail Diesel Injection
SP0097	Teach-in process after replacement of component Y100/2(Boost pressure regulator)	CDI-Common Rail Diesel Injection
SP0098	Teach-in process after replacement of component Y74(Pressure control valve)	CDI-Common Rail Diesel Injection
SP0099	Teach-in process after replacement of component diesel particulate filter	CDI-Common Rail Diesel Injection
SP0100	Teaching in the diesel particulate filter after replacing the engine control unit	CDI-Common Rail Diesel Injection
SP0101	Activate fuel pump	CDI-Motor electronics 'CR42' for combustion engine 'OM607'
SP0102	B16/15 (Temperature sensor upstream of SCR catalytic converter)	CDI-Motor electronics 'CR42' for combustion engine 'OM607'
SP0103	B79/2 (Transmission neutral position sensor)	CDI-Motor electronics 'CR42' for combustion engine 'OM607'
SP0104	Diesel particulate filter	CDI-Motor electronics 'CR42' for combustion engine 'OM607'
SP0105	G3/2(Oxygen sensor upstream of catalytic converter)	CDI-Motor electronics 'CR42' for combustion engine 'OM607'
SP0106	Injector injection quantity adjustment	CDI-Motor electronics 'CR42' for combustion engine 'OM607'
SP0107	Oxidation catalytic converter	CDI-Motor electronics 'CR42' for combustion engine 'OM607'
SP0108	Quick teach-in of values of zero quantity calibration	CDI-Motor electronics 'CR42' for combustion engine 'OM607'

SP0109	Reset values of HFM drift compensation	CDI-Motor electronics 'CR42' for combustion engine 'OM607'
SP0110	Reset values of quantity mean value adaptation	CDI-Motor electronics 'CR42' for combustion engine 'OM607'
SP0111	Resetting of contamination level of air filter	CDI-Motor electronics 'CR42' for combustion engine 'OM607'
SP0112	Teach in of throttle valve stop	CDI-Motor electronics 'CR42' for combustion engine 'OM607'
SP0113	Y129 (AdBlue metering valve)	CDI-Motor electronics 'CR42' for combustion engine 'OM607'
SP0114	Y74(Pressure control valve)	CDI-Motor electronics 'CR42' for combustion engine 'OM607'
SP0115	Y94 (Quantity control valve)	CDI-Motor electronics 'CR42' for combustion engine 'OM607'
SP0116	Activate fuel pump	CDI-Motor electronics 'CRR1' for combustion engine 'OM607'
SP0117	Injector injection quantity adjustment	CDI-Motor electronics 'CRR1' for combustion engine 'OM607'
SP0118	Regeneration of the diesel particulate filter while driving	CDI-Motor electronics 'CRR1' for combustion engine 'OM607'
SP0119	Resetting of learned values of component 'B4/6 (Rail pressure sensor)'	CDI-Motor electronics 'CRR1' for combustion engine 'OM607'
SP0120	Resetting of learned values of component 'Diesel particulate filter'	CDI-Motor electronics 'CRR1' for combustion engine 'OM607'
SP0121	Resetting of learned values of component 'Fuel system high pressure pump'	CDI-Motor electronics 'CRR1' for combustion engine 'OM607'
SP0122	Resetting of learned values of component 'G3/2 (Oxygen sensor upstream of catalytic converter)'	CDI-Motor electronics 'CRR1' for combustion engine 'OM607'
SP0123	Resetting of learned values of component 'Turbocharger'	CDI-Motor electronics 'CRR1' for combustion engine 'OM607'
SP0124	Status of teach-in processes	CDI-Motor electronics 'CRR1' for combustion engine 'OM607'
SP0125	Teach in component 'M16/57 (Exhaust flap controller)'	CDI-Motor electronics 'CRR1' for combustion engine 'OM607'
SP0126	Teach in component 'M16/6 (Throttle valve actuator)'	CDI-Motor electronics 'CRR1' for combustion engine 'OM607'
SP0127	Teach in component 'Y27/7 (Exhaust gas recirculation actuator, low pressure)'	CDI-Motor electronics 'CRR1' for combustion engine 'OM607'
SP0128	Teach in component 'Y27/8 (Exhaust gas recirculation actuator, high pressure)'	CDI-Motor electronics 'CRR1' for combustion engine 'OM607'
SP0129	Activate fuel pump	CDID-Common Rail Diesel Injection
SP0130	Injector injection quantity adjustment	CDID-Common Rail Diesel Injection
SP0131	Learning component'Y94 (Quantity control valve)'	CDID-Common Rail Diesel Injection
SP0132	Regeneration of diesel particulate filter	CDID-Common Rail Diesel Injection
SP0133	Replacement component Diesel particulate filter	CDID-Common Rail Diesel Injection
SP0134	Reset of lambda values	CDID-Common Rail Diesel Injection
SP0135	Reset values of quantity mean value adaptation	CDID-Common Rail Diesel Injection
SP0136	Resetting of contamination level of air filter	CDID-Common Rail Diesel Injection
SP0137	Teach in of throttle valve stop	CDID-Common Rail Diesel Injection
SP0138	Teach in used diesel particulate filter	CDID-Common Rail Diesel Injection
SP0139	Teach-in of intake port shutoff	CDID-Common Rail Diesel Injection
SP0140	Initial startup	DTR-Distronic
SP0141	Calibration of control unit 'N128 (Electric parking brake control unit)'	EFB-Electronic parking brake
SP0142	Replacing brake pads	EFB-Electronic parking brake
SP0143	Reset of compressor operating time	ELC-Electronic level control
SP0144	Calibration of the torque sensor	ES-Electrical power steering
SP0145	Erase zero point offset error of component N49 (Steering angle sensor)	ESP-Electronic stability program

SP0146	Erase zero point offset error of component N49 (Steering angle sensor).	ESP-Electronic stability program
SP0147	Reset offset value of signal 'Steering angle'	ESP-Electronic stability program
SP0148	Tyre pressure loss alarm (activated)	ESP-Electronic stability program
SP0149	Adaptation values of shift 1-2	ETC-Electronic transmission control
SP0150	Adaptation values of shift 2-1	ETC-Electronic transmission control
SP0151	Adaptation values of shift 2-3	ETC-Electronic transmission control
SP0152	Adaptation values of shift 3-2	ETC-Electronic transmission control
SP0153	Adaptation values of shift 3-4	ETC-Electronic transmission control
SP0154	Adaptation values of shift 4-3	ETC-Electronic transmission control
SP0155	Adaptation values of shift 4-5	ETC-Electronic transmission control
SP0156	Adaptation values of shift 5-4	ETC-Electronic transmission control
SP0157	Adaptation values of shift 5-6	ETC-Electronic transmission control
SP0158	Adaptation values of shift 6-5	ETC-Electronic transmission control
SP0159	Adaptation values of shift 6-7	ETC-Electronic transmission control
SP0160	Adaptation values of shift 7-6	ETC-Electronic transmission control
SP0161	Display all adaptation data	ETC-Electronic transmission control
SP0162	Resetting of adaptation data	ETC-Electronic transmission control
SP0163	Resetting of adaptation data - Hydraulic brake	ETC-Electronic transmission control
SP0164	Resetting of adaptation data(Torque converter lockup clutch)	ETC-Electronic transmission control
SP0165	Reverse gear	ETC-Electronic transmission control
SP0166	Switch off solenoid valve for torque converter lockup clutch	ETC-Electronic transmission control
SP0167	Switch off the incline recognition for dynamometer mode	ETC-Electronic transmission control
SP0168	Torque converter lockup clutch	ETC-Electronic transmission control
SP0169	Y3/8s1(Selection range sensor(VGS))	ETC-Electronic transmission control
SP0170	Activate control module N26/5 (Electric steering lock control module)	EZS-Electronic ignition switch
SP0171	Switch off solenoid valve for torque converter lockup clutch	FCVT-Continuously variable automatic transmission
SP0172	N121 (Trunk lid control control unit)	HKS-Tailgate control (N121/1)
SP0173	N121/1 (Liftgate control control unit)	HKS-Tailgate control (N121/1)
SP0174	Curve illumination	HRA-Automatic headlamp range adjustment and headlamp control
SP0175	Headlamp range adjustment	HRA-Automatic headlamp range adjustment and headlamp control
SP0176	Maintenance light reset	IC-Instrument cluster
SP0177	Confirmation of general maintenance	ICM-Instrument cluster with maintenance interval display
SP0178	Maintenance light reset	ICM-Instrument cluster with maintenance interval display
SP0179	Reset general maintenance	ICM-Instrument cluster with maintenance interval display
SP0180	Activate fuel pump	ME 9.7-Motor electronics 9.7
SP0181	Correction programming of fuel quantity	ME 9.7-Motor electronics 9.7
SP0182	Correction programming of ignition	ME 9.7-Motor electronics 9.7

SP0183	Correction programming of specified idle speed in selector lever position P or N	ME 9.7-Motor electronics 9.7
SP0184	Correction programming of specified idle speed with gear range engaged	ME 9.7-Motor electronics 9.7
SP0185	Reset of cold start adaptation values	ME 9.7-Motor electronics 9.7
SP0186	Teach in of throttle valve stop	ME 9.7-Motor electronics 9.7
SP0187	Activate fuel pump	ME SFI-Motor electronics
SP0188	Correction programming of fuel quantity	ME SFI-Motor electronics
SP0189	Correction programming of ignition	ME SFI-Motor electronics
SP0190	Correction programming of specified idle speed in selector lever position P or N	ME SFI-Motor electronics
SP0191	Correction programming of specified idle speed with gear range engaged	ME SFI-Motor electronics
SP0192	Correction programming of the electric suction fan for engine or air conditioning	ME SFI-Motor electronics
SP0193	Resetting of mixture adaptation	ME SFI-Motor electronics
SP0194	Teach in component B79/2 (Transmission neutral position sensor)	ME SFI-Motor electronics
SP0195	Teach in of throttle valve stop	ME SFI-Motor electronics
SP0196	Activate fuel pump	ME-Motor electronics 'MED177AMG' for combustion engine 'M152'
SP0197	Correction programming of fuel quantity	ME-Motor electronics 'MED177AMG' for combustion engine 'M152'
SP0198	Correction programming of specified idle speed in selector lever position P or N	ME-Motor electronics 'MED177AMG' for combustion engine 'M152'
SP0199	Correction programming of specified idle speed with gear range engaged	ME-Motor electronics 'MED177AMG' for combustion engine 'M152'
SP0200	Injector injection quantity adjustment	ME-Motor electronics 'MED177AMG' for combustion engine 'M152'
SP0201	Resetting of adaptation values	ME-Motor electronics 'MED177AMG' for combustion engine 'M152'
SP0202	Teach in of throttle valve stop	ME-Motor electronics 'MED177AMG' for combustion engine 'M152'
SP0203	Activate fuel pump	ME-Motor electronics 'MED40' for combustion engine 'M270'
SP0204	Injector injection quantity adjustment	ME-Motor electronics 'MED40' for combustion engine 'M270'
SP0205	Resetting of adaptation values	ME-Motor electronics 'MED40' for combustion engine 'M270'
SP0206	Teach in of throttle valve stop	ME-Motor electronics 'MED40' for combustion engine 'M270'
SP0207	Teach-in of positions for camshafts	ME-Motor electronics 'MED40' for combustion engine 'M270'
SP0208	Activate fuel pump	ME-Motor electronics 'MED40AMG' for combustion engine 'M133'
SP0209	Correction programming of fuel quantity	ME-Motor electronics 'MED40AMG' for combustion engine 'M133'
SP0210	Correction programming of ignition	ME-Motor electronics 'MED40AMG' for combustion engine 'M133'
SP0211	Correction programming of specified idle speed in selector lever position P or N	ME-Motor electronics 'MED40AMG' for combustion engine 'M133'
SP0212	Correction programming of specified idle speed with gear range engaged	ME-Motor electronics 'MED40AMG' for combustion engine 'M133'
SP0213	Injector injection quantity adjustment	ME-Motor electronics 'MED40AMG' for combustion engine 'M133'
SP0214	Resetting of adaptation values	ME-Motor electronics 'MED40AMG' for combustion engine 'M133'
SP0215	Teach in of throttle valve stop	ME-Motor electronics 'MED40AMG' for combustion engine 'M133'
SP0216	Teach-in of positions for camshafts	ME-Motor electronics 'MED40AMG' for combustion engine 'M133'
SP0217	B79/3 (Manual transmission main shifter shaft position sensor)	ME-Motor electronics 'MED40CNG' for combustion engine 'M274'
SP0218	Correction programming of fuel quantity	ME-Motor electronics 'MED40CNG' for combustion engine 'M274'
SP0219	Correction programming of ignition	ME-Motor electronics 'MED40CNG' for combustion engine 'M274'

SP0220	Correction programming of specified idle speed	ME-Motor electronics 'MED40CNG' for combustion engine 'M274'
SP0221	Injector injection quantity adjustment	ME-Motor electronics 'MED40CNG' for combustion engine 'M274'
SP0222	Resetting of adaptation values	ME-Motor electronics 'MED40CNG' for combustion engine 'M274'
SP0223	Resetting reading of frequency counter for ethanol teach-in processes	ME-Motor electronics 'MED40CNG' for combustion engine 'M274'
SP0224	Teach in of throttle valve stop	ME-Motor electronics 'MED40CNG' for combustion engine 'M274'
SP0225	Teach-in of positions for camshafts	ME-Motor electronics 'MED40CNG' for combustion engine 'M274'
SP0226	Teaching in the ethanol proportion in the fuel	ME-Motor electronics 'MED40CNG' for combustion engine 'M274'
SP0227	Activate fuel pump	MED 17.7-Motor electronics for direct injection 17.7
SP0228	Correction programming of fuel quantity	MED 17.7-Motor electronics for direct injection 17.7
SP0229	Correction programming of specified idle speed in selector lever position P or N	MED 17.7-Motor electronics for direct injection 17.7
SP0230	Correction programming of specified idle speed with gear range engaged	MED 17.7-Motor electronics for direct injection 17.7
SP0231	Injector injection quantity adjustment	MED 17.7-Motor electronics for direct injection 17.7
SP0232	Resetting of adaptation values	MED 17.7-Motor electronics for direct injection 17.7
SP0233	Teach in of throttle valve stop	MED 17.7-Motor electronics for direct injection 17.7
SP0234	Teach-in process after replacement of the combustion engine	MED 17.7-Motor electronics for direct injection 17.7
SP0235	Activate fuel pump	MED 9.7-Motor electronics for direct injection 9.7
SP0236	Correction programming of fuel quantity	MED 9.7-Motor electronics for direct injection 9.7
SP0237	Correction programming of ignition	MED 9.7-Motor electronics for direct injection 9.7
SP0238	Correction programming of specified idle speed in selector lever position P or N	MED 9.7-Motor electronics for direct injection 9.7
SP0239	Correction programming of specified idle speed with gear range engaged	MED 9.7-Motor electronics for direct injection 9.7
SP0240	Resetting of adaptation data	MED 9.7-Motor electronics for direct injection 9.7
SP0241	Teach in of throttle valve stop	MED 9.7-Motor electronics for direct injection 9.7
SP0242	Teach-in process after replacement of the combustion engine	MED 9.7-Motor electronics for direct injection 9.7
SP0243	Activate system 'SBC'	SBC-Sensotronic Brake Control
SP0244	Response threshold of speed sensors	SBC-Sensotronic Brake Control
SP0245	System 'SBC' deactivated	SBC-Sensotronic Brake Control
SP0246	Initial startup	SCM [MRM]-Steering column module
SP0247	Resetting of operating hours counters of component 'E1(Left front lamp unit)'	SG SW L-Left headlamp
SP0248	Zero position adjustment	SG SW L-Left headlamp
SP0249	Resetting of operating hours counters of component 'E2(Right front lamp unit)'	SG SW R-Right headlamp
SP0250	Resetting of operating hours counters of component 'Xenon headlamp, left'	SG SW-Control unit 'Headlamp'
SP0251	Resetting of operating hours counters of component 'Xenon headlamp, right'	SG SW-Control unit 'Headlamp'
SP0252	Zero position adjustment	SG SW-Control unit 'Headlamp'
SP0253	Initial startup with automatic takeover of settings of previous control unit	Suspension
SP0254	Initial startup with manual settings input for new control unit/Level calibration	Suspension
SP0255	Reset compressor operating time	Suspension
SP0256	Reset of operating hours counter	XALWA L-Xenon headlamp, left

SP0257	EP:Reset of operating hours counter	XALWA R-Xenon headlamp, right
SP0258	Reset of operating hours counter	XALWA R-Xenon headlamp, right
SP0300	Road test	ABR-Adaptive Brake
SP0301	Tire pressure loss warnerActivating	ABR-Adaptive Brake
SP0302	Erase zero point offset error of component N49 (Steering angle sensor).	ABR-Adaptive Brake
SP0303	Calibration of control unit N47-5 (ESP control unit)	ABR-Adaptive Brake
SP0304	Tourist mode-Adaptation of headlamps from left-hand traffic system to right-hand traffic system or	XALWA L-Xenon headlamp, left
SP0305	Resetting operating hours counter	XALWA L-Xenon headlamp, left
SP0306	Tourist mode-Adaptation of headlamps from left-hand traffic system to right-hand traffic system or	XALWA L-Xenon headlamp, left
SP0307	Resetting operating hours counter	XALWA L-Xenon headlamp, left
SP0308	Tourist mode-Adaptation of headlamps from left-hand traffic system to right-hand traffic system or	XALWA R-Xenon headlamp, right
SP0309	Resetting operating hours counter	XALWA R-Xenon headlamp, right
SP0310	Tourist mode-Adaptation of headlamps from left-hand traffic system to right-hand traffic system or	XALWA R-Xenon headlamp, right
SP0311	Resetting operating hours counter	XALWA R-Xenon headlamp, right
SP0312	Adjustment of injector injection quantities	CDI 60LS-Common Rail Diesel Injection
SP0313	Regeneration of diesel particulate filter when driving	CDI 60LS-Common Rail Diesel Injection
SP0314	Teaching in the diesel particulate filter after replacing the engine control unit	CDI 60LS-Common Rail Diesel Injection
SP0315	Teach-in process after replacement of component Diesel particulate filter	CDI 60LS-Common Rail Diesel Injection
SP0316	Teach-in process after replacement of component SCR-Catalytic converter	CDI 60LS-Common Rail Diesel Injection
SP0317	Learning of the throttle valve stop	CDI 60LS-Common Rail Diesel Injection
SP0318	Teach-in process after replacement of component Diesel oxidation catalytic converter	CDI 60LS-Common Rail Diesel Injection
SP0319	Teach-in process after replacement of component B16/15 (Temperature sensor upstream of SCR	CDI 60LS-Common Rail Diesel Injection
SP0320	Teach-in process after replacement of component B28/8 (Pressure differential sensor (DPF))	CDI 60LS-Common Rail Diesel Injection
SP0321	Teach-in process after replacement of component G3/2 (O2 sensor upstream of KAT)	CDI 60LS-Common Rail Diesel Injection
SP0322	Teach-in process after replacement of component NOx sensor	CDI 60LS-Common Rail Diesel Injection
SP0323	Teach-in process after replacement of component Y74 (Pressure control valve)	CDI 60LS-Common Rail Diesel Injection
SP0324	Teach-in process after replacement of component Y129 (AdBlue? metering valve)	CDI 60LS-Common Rail Diesel Injection
SP0325	Activate fuel pump.	CDI 60LS-Common Rail Diesel Injection
SP0326	Reset quantity mean value adaptation data.	CDI 60LS-Common Rail Diesel Injection
SP0327	Rapid teach-in of zero quantity calibration values	CDI 60LS-Common Rail Diesel Injection
SP0328	Reset values for HFM drift compensation.	CDI 60LS-Common Rail Diesel Injection
SP0329	Resetting air filter learned values after air filter replacement	CDI 60LS-Common Rail Diesel Injection
SP0330	Cancellation of limitation of engine starts(USA)/Cancellation of limitation of remaining distance	CDI 60LS-Common Rail Diesel Injection
SP0331	Reset of fault message 'Fault in AdBlue system' in instrument cluster	CDI 60LS-Common Rail Diesel Injection
SP0332	Injector injection quantity adjustment (manual input)	CDI 3-Common Rail Diesel Injection3
SP0333	Injector injection quantity adjustment (input via data scanner)	CDI 3-Common Rail Diesel Injection3
SP0334	Regeneration of diesel particulate filter	CDI 3-Common Rail Diesel Injection3

SP0335	Regeneration of diesel particulate filter when driving	CDI 3-Common Rail Diesel Injection3
SP0336	Activate fuel pump.	CDI 3-Common Rail Diesel Injection3
SP0337	Resetting air filter learned values after air filter replacement	CDI 3-Common Rail Diesel Injection3
SP0338	Teach-in process after replacement of component Diesel particulate filter	CDI 3-Common Rail Diesel Injection3
SP0339	Teaching in the diesel particulate filter after replacing the engine control unit	CDI 3-Common Rail Diesel Injection3
SP0340	Teach in component M16/6 (Throttle valve actuator).	CDI 3-Common Rail Diesel Injection3
SP0341	Teach in component M55 (Inlet port shutoff motor).	CDI 3-Common Rail Diesel Injection3
SP0342	Teach in component Y77/1 (Charge pressure positioner).	CDI 3-Common Rail Diesel Injection3
SP0343	Resetting the lambda values	CDI 3-Common Rail Diesel Injection3
SP0344	Detach the transport protection of control module ISM, personalize or activate the control module.	ISM-Shift module
SP0345	Disable key or key track.	EZS-Electronic ignition switch
SP0346	Disable key or key track with the workshop key.	EZS-Electronic ignition switch
SP0347	Once again authorize key or key track.	EZS-Electronic ignition switch
SP0348	Program replacement keys.	EZS-Electronic ignition switch
SP0349	Activate control module N73 (EIS [EZS] control unit).	EZS-Electronic ignition switch
SP0350	Test procedure for voltage comparison	SG EM-Electric motor control unit
SP0351	Test procedure for rpm comparison	SG EM-Electric motor control unit
SP0352	Normalizing of positioning motors	AAC-Automatic air conditioning
SP0353	Check of adjustment range of positioning motors	AAC-Automatic air conditioning
SP0354	Teach-in of actuator motors after actuator motor replacement	AAC-Automatic air conditioning
SP0355	Breaking-in procedure after replacement of refrigerant compressor	AAC-Automatic air conditioning
SP0356	Teach-in of rotary potentiometers for the air outlets	AAC-Automatic air conditioning
SP0357	Level calibration	AIRmatic
SP0358	Activate fuel pump.	ME SF 17.7-Motor electronics 17.7
SP0359	Learning of the throttle valve stop	ME SF 17.7-Motor electronics 17.7
SP0360	Teach in of drive authorization system	ME SF 17.7-Motor electronics 17.7
SP0361	Teach-in process after engine replacement	ME SF 17.7-Motor electronics 17.7
SP0362	Resetting of adaptation data	ME SF 17.7-Motor electronics 17.7
SP0363	Resetting the cold-start adaptation values	ME SF 17.7-Motor electronics 17.7
SP0364	Sensor rotor adaptation	ME SF 17.7-Motor electronics 17.7
SP0365	Activate fuel pump.	ME 2.7.2-Motor electronics 2.7.2
SP0366	Teach in of drive authorization system	ME 2.7.2-Motor electronics 2.7.2
SP0367	Resetting of mixture adaptation	ME 2.7.2-Motor electronics 2.7.2
SP0368	Reset lambda adaptation	ME 2.7.2-Motor electronics 2.7.2
SP0369	Default initialization	ME 2.7.2-Motor electronics 2.7.2
SP0370	Activate fuel pump.	ME 2.7.2-Motor electronics 2.7.2
SP0371	Teach in of drive authorization system	ME 2.7.2-Motor electronics 2.7.2

SP0372	Resetting of mixture adaptation	ME 2.7.2-Motor electronics 2.7.2
SP0373	Reset lambda adaptation	ME 2.7.2-Motor electronics 2.7.2
SP0374	Default initialization	ME 2.7.2-Motor electronics 2.7.2
SP0375	Activate fuel pump.	ME 9.7-Motor electronics 9.7
SP0376	Learning of the throttle valve stop	ME 9.7-Motor electronics 9.7
SP0377	Teach in of drive authorization system	ME 9.7-Motor electronics 9.7
SP0378	Teach-in process after engine replacement	ME 9.7-Motor electronics 9.7
SP0379	Resetting of adaptation data	ME 9.7-Motor electronics 9.7
SP0380	Resetting the cold-start adaptation values	ME 9.7-Motor electronics 9.7
SP0381	Sensor rotor adaptation	ME 9.7-Motor electronics 9.7
SP0382	Activate fuel pump.	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)
SP0383	Learning of the throttle valve stop	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)
SP0384	Teach in of drive authorization system	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)
SP0385	Teach-in of camshaft positions	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)
SP0386	Resetting of adaptation data	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)
SP0387	Resetting the cold-start adaptation values	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)
SP0388	Sensor rotor adaptation	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)
SP0389	Activate fuel pump.	MED 17.7-Motor electronics for direct injection 17.7
SP0390	Learning of the throttle valve stop	MED 17.7-Motor electronics for direct injection 17.7
SP0391	Teach in of drive authorization system	MED 17.7-Motor electronics for direct injection 17.7
SP0392	Teach-in process after engine replacement	MED 17.7-Motor electronics for direct injection 17.7
SP0393	Teach in ethanol portion in fuel.	MED 17.7-Motor electronics for direct injection 17.7
SP0394	Teach-in process for component M16/45 (EGR [ARF] actuator motors)	MED 17.7-Motor electronics for direct injection 17.7
SP0395	Resetting of adaptation data	MED 17.7-Motor electronics for direct injection 17.7
SP0396	Resetting the cold-start adaptation values	MED 17.7-Motor electronics for direct injection 17.7
SP0397	Resetting the reading of the counter for ethanol teach-in processes	MED 17.7-Motor electronics for direct injection 17.7
SP0398	Sensor rotor adaptation	MED 17.7-Motor electronics for direct injection 17.7
SP0399	Quick test of mixture adaptation	MED 17.7-Motor electronics for direct injection 17.7
SP0400	Enabling of engine start after crash event	MED 17.7-Motor electronics for direct injection 17.7
SP0401	Steering column module	Dr side SAM-Driver signal acquisition and actuation module
SP0402	Road test	ABR-Adaptive Brake
SP0403	Tire pressure loss warner	ABR-Adaptive Brake
SP0404	Erase zero point offset error of component Steering angle sensor.	ABR-Adaptive Brake
SP0405	Calibration of control unit ABR	ABR-Adaptive Brake
SP0406	Refill AdBlue.	SCR-Selective Catalytic Reduction
SP0407	Erasing adaptation values after replacement of AdBlue fluid	SCR-Selective Catalytic Reduction
SP0408	Teach-in process after replacement of component Y129 (AdBlue? metering valve)	SCR-Selective Catalytic Reduction

SP0409	Cancellation of limitation of engine starts-Cancellation of limitation of remaining distance	SCR-Selective Catalytic Reduction
SP0410	Reset of fault message 'Fault in AdBlue system' in instrument cluster	SCR-Selective Catalytic Reduction
SP0411	Normalizing-Rear left and right	ESA R-Electric seat adjustment rear
SP0412	Normalization of all seat adjustment motors	ESA FL-Electric seat adjustment front left
SP0413	Change standard distance of travel.	ESA FL-Electric seat adjustment front left
SP0414	Adjust end of forward range.	ESA FL-Electric seat adjustment front left

XTOOL

SP0415	Adjust end of forward range.	ESA FL-Electric seat adjustment front left
SP0416	Adjust beginning of rearward range	ESA FL-Electric seat adjustment front left
SP0417	Normalization of all seat adjustment motors	ESA FR-Electric seat adjustment front right
SP0418	Change standard distance of travel.	ESA FR-Electric seat adjustment front right
SP0419	Adjust end of forward range.	ESA FR-Electric seat adjustment front right
SP0420	Adjust end of forward range.	ESA FR-Electric seat adjustment front right
SP0421	Adjust beginning of rearward range	ESA FR-Electric seat adjustment front right
SP0422	Write wheel electronics identification number.	TPM-Tire pressure monitor
SP0423	Write specified tire pressure values.	TPM-Tire pressure monitor
SP0424	Initialization of power closing	DCM RL-Door control module rear left
SP0425	Initialization of power closing	DCM RR-Door control module rear right
SP0426	Initialization of power closing	DCM FL-Door control module front left
SP0427	Initialization of power closing	DCM FR-Door control module front right
SP0428	Teach-in process for anti-pinch protection function of panoramic sliding sunroofRoller sun blind	PSD-Panoramic sliding roof(Interior CAN bus)
SP0429	Performing adaptation(Wet start-off clutch (NAK))	ETC-Electronic transmission control
SP0430	Adaptation values of shift 1-2:	ETC-Electronic transmission control
SP0431	Adaptation values of shift 2-3:	ETC-Electronic transmission control
SP0432	Adaptation values of shift 3-4:	ETC-Electronic transmission control
SP0433	Adaptation values of shift 4-5:	ETC-Electronic transmission control
SP0434	Adaptation values of shift 5-6:	ETC-Electronic transmission control
SP0435	Adaptation values of shift 6-7:	ETC-Electronic transmission control
SP0436	Resetting of adaptation data	ETC-Electronic transmission control
SP0437	Adaptation values of shift 7-6:	ETC-Electronic transmission control
SP0438	Adaptation values of shift 6-5:	ETC-Electronic transmission control
SP0439	Adaptation values of shift 5-4:	ETC-Electronic transmission control
SP0440	Adaptation values of shift 4-3:	ETC-Electronic transmission control
SP0441	Adaptation values of shift 3-2:	ETC-Electronic transmission control
SP0442	Adaptation values of shift 2-1:	ETC-Electronic transmission control
SP0443	Resetting of adaptation data	ETC-Electronic transmission control
SP0444	Reverse gear	ETC-Electronic transmission control
SP0445	UPSHIFT	ETC-Electronic transmission control
SP0446	DOWNSHIFT	ETC-Electronic transmission control
SP0447	Acceleration downshifts	ETC-Electronic transmission control
SP0448	Resetting of adaptation data(Torque converter lockup clutch)	ETC-Electronic transmission control
SP0449	Adaptation via torque ranges	ETC-Electronic transmission control
SP0450	Fill time adaptation of the torque converter lockup clutch	ETC-Electronic transmission control
SP0451	Thrust-Program	ETC-Electronic transmission control

SP0452	ASSYST settings	ASSYST-Active Service System
SP0453	Re-initialization of AdBlue range	ASSYST-Active Service System
SP0454	Learning component A8/3 (STH radio remote control transmitter)	ASSYST-Active Service System
SP0455	Adaptation of the gearshifts	ETC-Electronic transmission control
SP0456	Upshifts	VGS-Fully integrated transmission control
SP0457	Downshifts	VGS-Fully integrated transmission control
SP0458	Acceleration downshifts	VGS-Fully integrated transmission control
SP0459	Standstill adaptation	VGS-Fully integrated transmission control
SP0460	Upshifts	VGS-Transmission control for 7-speed transimssion
SP0461	Downshifts	VGS-Transmission control for 7-speed transimssion
SP0462	Acceleration downshifts	VGS-Transmission control for 7-speed transimssion
SP0463	Standstill adaptation	VGS-Transmission control for 9-speed transimssion
SP0464	Adaptation procedure for torque converter lockup clutch	VGS-Transmission control for 9-speed transimssion
SP1000	Injector injection quantity adjustment	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
SP1001	Activation of fuel pump	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
SP1002	Teach-in of drive authorization system	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
SP1003	Teach-in of intake port shutoff	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
SP1004	Teach in of throttle valve stop	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
SP1005	Teach-in process of component "B28/8 (DPF differential pressure sensor)"	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
SP1006	Resetting of learned values of component "B6/1 (Camshaft Hall sensor)"	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
SP1007	B79/2 (Transmission neutral position sensor)	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
SP1008	Teach in component "Y77/1 (Boost pressure positioner)".	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
SP1009	Quick teach-in of values of zero quantity calibration	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
SP1010	Quick teach-in of the zero quantity calibration values at idle	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
SP1011	Quick teach-in of the zero quantity calibration values while driving	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
SP1012	Reset values of HFM drift compensation.	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
SP1013	Resetting of contamination level of air filter	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
SP1014	Oxidation catalytic converter	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
SP1015	Teach-in of diesel particulate filter after replacement of control unit "N3/9 (CDI control unit)"	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
SP1016	Teach-in process after replacement of component "Diesel particulate filter"	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
SP1017	Enabling of engine start after crash event	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
SP1018	Bleeding of high-pressure fuel circuit	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
SP1019	Perform teach-in process for component "Y129 (AdBlue?metering valve)".	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
SP1020	Perform teach-in process for component "B16/15 (Temperature sensor upstream of SCR catalytic	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
SP1021	Reset learned values of components "NOx sensor upstream of SCR catalytic converter" and "NOx	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
SP1022	Reset learned values for AdBlue?metering.	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
SP1023	Teach-in process after replacement of component "SCR catalytic converter"	N3/9-Motor electronics "CDID3" for combustion engine "OM651"

SP1024	Resetting of learned values of component "M16/46 (Low-pressure exhaust gas recirculation actuator	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
SP1025	Teach-in process of component "B53/1 (Clutch pedal sensor)"	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
SP1026	Resetting learned values "Exhaust gas recirculation (low pressure)"	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
SP1027	Teach-in process after replacement of diesel particulate filter combined with NOx storage catalytic	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
SP1028	Teach-in of diesel particulate filter combined with NOx storage catalytic converter after replacement	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
SP1029	Status of teach-in processes	N3/3-Motor electronics "OM607" for combustion engine "CRR1"
SP1030	Regeneration of the diesel particulate filter while driving	N3/3-Motor electronics "OM607" for combustion engine "CRR1"
SP1031	Resetting of learned values of component "Fuel injectors"	N3/3-Motor electronics "OM607" for combustion engine "CRR1"
SP1032	Teach in component "M16/6 (Throttle valve actuator)".	N3/3-Motor electronics "OM607" for combustion engine "CRR1"
SP1033	Teach in component "Y27/8 (Exhaust gas recirculation actuator, high pressure)".	N3/3-Motor electronics "OM607" for combustion engine "CRR1"
SP1034	Teach in component "Y27/7 (Exhaust gas recirculation actuator, low pressure)".	N3/3-Motor electronics "OM607" for combustion engine "CRR1"
SP1035	Teach in component "M16/57 (Exhaust flap controller)".	N3/3-Motor electronics "OM607" for combustion engine "CRR1"
SP1036	Resetting of learned values of component "B4/6 (Rail pressure sensor)"	N3/3-Motor electronics "OM607" for combustion engine "CRR1"
SP1037	Resetting of learned values of component "Fuel system high pressure pump"	N3/3-Motor electronics "OM607" for combustion engine "CRR1"
SP1038	Resetting of learned values of component "B28/8 (Differential pressure sensor (DPF))"	N3/3-Motor electronics "OM607" for combustion engine "CRR1"
SP1039	Resetting of learned values of component "G3/2 (Oxygen sensor upstream of catalytic converter)"	N3/3-Motor electronics "OM607" for combustion engine "CRR1"
SP1040	Resetting of learned values of component "Turbocharger"	N3/3-Motor electronics "OM607" for combustion engine "CRR1"
SP1041	Resetting of learned values of component "Diesel particulate filter"	N3/3-Motor electronics "OM607" for combustion engine "CRR1"
SP1042	B79/3 (Manual transmission main shifter shaft position sensor)	N3/3-Motor electronics "OM607" for combustion engine "CRR1"
SP1043	Confirmation of general maintenance	IC-Instrument cluster
SP1044	Reset general maintenance.	IC-Instrument cluster
SP1045	Special maintenance	IC-Instrument cluster
SP1046	Activation	KOMO/mbrace-Communication module 'Telematics services'/Notrufsystem
SP1047	Deactivation	KOMO/mbrace-Communication module 'Telematics services'/Notrufsystem
SP1048	Teach-in of a spare key	EZS-Electronic ignition switch
SP1049	Activation of control unit "N73 (Electronic ignition lock control unit)"	EZS-Electronic ignition switch
SP1050	Initial startup:ESL [ELV]	EZS-Electronic ignition switch
SP1051	Activate function "Tire pressure loss warning".	ESP-Electronic stability program(N30/4)
SP1052	Calibration of component "Acceleration sensor"	ESP-Electronic stability program(N30/4)
SP1053	Write identification numbers of tire pressure sensors.	TPM-Tire pressure monitor(N88)
SP1054	Activate comfort telephony.	AUDIO-Audio or COMAND(A2-A40/3)
SP1055	Comfort telephony	AUDIO-Audio or COMAND(A2-A40/3)
SP1056	Pairing:Audio or COMAND-mbrace(Internet connection)	AUDIO-Audio or COMAND(A2-A40/3)
SP1057	Restore initial authorization certificate for VPN connection.	AUDIO-Audio or COMAND(A2-A40/3)
SP1058	Teach-in process"Current date(GPS data)"	AUDIO-Audio or COMAND(A2-A40/3)
SP1059	Resetting of learned values of component "A90 (COLLISION PREVENTION ASSIST controller	CPA-Control unit 'COLLISION PREVENTION ASSIST'(A90)
SP1060	Calibration of microphone for sound system	SOUND-Bose sound system

SP1061	Level calibration	ADS-Adaptive damping system(N51/5)
SP1062	N121/1 (Liftgate control control unit)	HKS-Tailgate control
SP1063	Calibration	MFK-Multifunction camera
SP1064	Retrofitting	MFK-Multifunction camera(A40/11)
SP1065	Normalization of actuator motors	AAC-Automatic air conditioning
SP1066	Teach-in of actuator motors	AAC-Automatic air conditioning
SP1067	Breaking-in of refrigerant compressor	AAC-Automatic air conditioning
SP1068	Teach in component "A8/3 (Stationary heater radio remote control transmitter)".	STH-Stationary heater
SP1069	Calibration of component "A91b1 (Electric power steering torque sensor)"	ES-Electrical power steering(N68)
SP1070	Resetting the center position of the steering	ES-Electrical power steering(N68)
SP1071	Reset of coding	ES-Electrical power steering(N68)
SP1072	Teach-in process of anti-pinch protection	PSD-Control module 'Panoramic sliding roof'(A98)
SP1073	Coding	HUD-Head up display
SP1074	Normalization and adaptation	ESV Driver-Electric seat adjustmnet Driver with memory function
SP1075	Normalization	ESV Driver-Electric seat adjustmnet Driver with memory function
SP1076	Easy entry/exit	ESV Driver-Electric seat adjustmnet Driver with memory function
SP1077	Initial startup	TRM-Trailer recognition module (N28/1)
SP1078	Erasing of initialization values	TRM-Trailer recognition module (N28/1)
SP1079	Calibration of long range radar sensor	DTR-DISTRONIC (A89)
SP1080	Normalization of power window	LFD-Left front door
SP1081	Calibration of control unit "N128 (Electric parking brake control unit)"	EFB-Electronic parking brake(N128)
SP1082	Calibration of steering angle sensor	RFK-Backup camera
SP1083	Calibration of reversing camera	RFK-Backup camera
SP1084	Zero position adjustment	SG SW-Control unit 'Headlamp'(N71/1)
SP1085	Resetting the operating hours counter of component "Left xenon headlamp"	SG SW-Control unit 'Headlamp'(N71/1)
SP1086	Resetting the operating hours counter of component "Right xenon headlamp"	SG SW-Control unit 'Headlamp'(N71/1)
SP1087	Tourist mode	SG SW-Control unit 'Headlamp'(N71/1)
SP1088	Adjustment of headlamps via diagnosis	SG SW L-Left headlamp
SP1089	Resetting of operating hours counters of component "E1 (Left front lamp unit)"	SG SW L-Left headlamp
SP1090	Resetting of operating hours counters of component "E1m4 (Left front lamp unit fan motor 1)"	SG SW L-Left headlamp
SP1091	Adaptation of codings of control units to lamp unit	SG SW L-Left headlamp
SP1092	Adaptation of coding of control unit to lamp unit	SG SW L-Left headlamp
SP1093	Resetting of assignment of control unit "E1n9" to vehicle side	SG SW L-Left headlamp
SP1094	Resetting of operating hours counters of component "E1m5 (Left front lamp unit fan motor 2)"	SG SW L-Left headlamp(E1n9)
SP1095	Resetting of operating hours counters of component "E2 (Right front headlamp unit)"	SG SW R-Right headlamp
SP1096	Resetting of operating hours counters of component "E2m4 (Right front lamp unit fan motor 1)"	SG SW R-Right headlamp
SP1097	Resetting of operating hours counters of component "E2m5 (Right front lamp unit fan motor 2)"	SG SW R-Right headlamp

SP1098	Parameterization and adaptation of windshield	B38/2-Rain/light sensor(RGLS)
SP1099	Resetting the oil service data	VG-All wheel drive
SP1100	Replacement of component "Transfer case"	VG-All wheel drive
SP1101	Function test of component "Y68/3 (All-wheel drive solenoid valve)" while driving	VG-All wheel drive
SP1102	Resetting of learned values of component "Y68/3 (All-wheel drive solenoid valve)"	VG-All wheel drive
SP1103	Display of EEPROM values	DKG-Electronic transmission control for double-plate clutch transmission
SP1104	Deactivate transport protection.	DKG-Electronic transmission control for double-plate clutch transmission
SP1105	B28/18 (Low-pressure exhaust gas recirculation differential pressure sensor)	N127 (Drivetrain control unit)
SP1106	Teach in component "M16/46 (Low-pressure exhaust gas recirculation actuator motor)".	N127 (Drivetrain control unit)
SP1107	Teach in component "M16/57 (Exhaust flap controller actuator motor)".	N127 (Drivetrain control unit)
SP1108	Resetting reading of frequency counter for ethanol teach-in processes	N3/10-Motor electronics "MED40" for combustion engine "M274"
SP1109	Reset of mixture adaptation values	N3/10-Motor electronics "MED40" for combustion engine "M274"
SP1110	Resetting of values for sensor rotor adaptation	N3/10-Motor electronics "MED40" for combustion engine "M274"
SP1111	Resetting of learned values of component "Gasoline particulate filter"	N3/10-Motor electronics "MED40" for combustion engine "M274"
SP1112	Reset learned values for diagnosis of CAN bus through control unit "N3/10 (ME-SFI [ME] control	N3/10-Motor electronics "MED40" for combustion engine "M274"
SP1113	Teaching in the ethanol proportion in the fuel	N3/10-Motor electronics "MED40" for combustion engine "M274"
SP1114	Teach-in of exhaust gas recirculation actuator	N3/10-Motor electronics "MED40" for combustion engine "M274"
SP1115	Perform teach-in process "Sensor rotor adaptation".	N3/10-Motor electronics "MED40" for combustion engine "M274"
SP1116	Teach-in of positions for camshafts	N3/10-Motor electronics "MED40" for combustion engine "M274"
SP1117	Resetting of adaptation values	N3/10-Motor electronics "MED40AMG" for combustion engine "M133"
SP1118	Adjustment of zero quantity calibration	CDI-Engine Electronics CRR2 for Internal Combustion Engine OM608
SP1119	Resetting of learned values of component "B2/5 (Hot film mass air flow sensor)"	CDI-Engine Electronics CRR2 for Internal Combustion Engine OM608
SP1120	Resetting of learned values of component "B175 (Temperature sensors sensor unit)"	CDI-Engine Electronics CRR2 for Internal Combustion Engine OM608
SP1121	Resetting of learned values of component "Exhaust aftertreatment unit"	CDI-Engine Electronics CRR2 for Internal Combustion Engine OM608
SP1122	Resetting learned values of component parts "Fuel system high pressure pump" and "Rail"	CDI-Engine Electronics CRR2 for Internal Combustion Engine OM608
SP1123	Teach-in process of component "Y27/7 (Exhaust gas recirculation actuator, low pressure)"	CDI-Engine Electronics CRR2 for Internal Combustion Engine OM608
SP1124	Teach-in process of component "Y27/8 (Exhaust gas recirculation actuator, high pressure)"	CDI-Engine Electronics CRR2 for Internal Combustion Engine OM608
SP1125	Teach-in process of component "M16/6 (Throttle valve actuator)"	CDI-Engine Electronics CRR2 for Internal Combustion Engine OM608
SP1126	Teach-in process of component "Y77/1 (Boost pressure regulator)"	CDI-Engine Electronics CRR2 for Internal Combustion Engine OM608
SP1127	Activation of component "M3 (Fuel pump)"	CDI-Engine Electronics CRR2 for Internal Combustion Engine OM608
SP1128	Resetting of learned values of component "Y129 (AdBlue?metering valve)"	CDI-Engine Electronics CRR2 for Internal Combustion Engine OM608
SP1129	Resetting of learned values of component "A103 (AdBlue?pump module)"	CDI-Engine Electronics CRR2 for Internal Combustion Engine OM608
SP1130	Teach-in process after replacement of component "B2/5 (Hot film mass air flow sensor)"	N3/40-Motor electronics "MRD1" for combustion engine "OM654"
SP1131	Teach-in process of component "M55 (Intake port shutoff actuator motor)"	N3/40-Motor electronics "MRD1" for combustion engine "OM654"
SP1132	Teach-in process of component "Y77/1 (Boost pressure positioner)"	N3/40-Motor electronics "MRD1" for combustion engine "OM654"
SP1133	Teach-in process of component "M16/46 (Low-pressure exhaust gas recirculation actuator motor)"	N3/40-Motor electronics "MRD1" for combustion engine "OM654"
SP1134	Teach-in process of component "Y27/9 (Exhaust gas recirculation actuator)"	N3/40-Motor electronics "MRD1" for combustion engine "OM654"

SP1135	Teach-in process after replacement of component "Y74 (Pressure regulating valve)"	N3/40-Motor electronics "MRD1" for combustion engine "OM654"
SP1136	Teach-in process after replacement of component "Y94 (Quantity control valve)"	N3/40-Motor electronics "MRD1" for combustion engine "OM654"
SP1137	Teach-in process after replacement of component "B28/8 (DPF differential pressure sensor)"	N3/40-Motor electronics "MRD1" for combustion engine "OM654"
SP1138	Teach-in process after replacement of component "B28/18 (Low-pressure exhaust gas recirculation	N3/40-Motor electronics "MRD1" for combustion engine "OM654"
SP1139	Resetting the event memory for loss of synchronization between crankshaft and camshaft	N3/40-Motor electronics "MRD1" for combustion engine "OM654"
SP1140	Reset learned values for diagnosis of CAN bus through control unit "N3/9 (CDI control unit)".	N3/40-Motor electronics "MRD1" for combustion engine "OM654"
SP1141	Teach-in process after replacement of component "B19/7 (Temperature sensor upstream of catalytic	N3/40-Motor electronics "MRD1" for combustion engine "OM654"
SP1142	Teach-in process after replacement of component "B19/9 (Temperature sensor upstream of diesel	N3/40-Motor electronics "MRD1" for combustion engine "OM654"
SP1143	Teach-in process after replacement of component "B175 (Temperature sensors sensor unit)"	N3/40-Motor electronics "MRD1" for combustion engine "OM654"
SP1144	Teach-in process after replacement of component "Oxidation catalytic converter"	N3/40-Motor electronics "MRD1" for combustion engine "OM654"
SP1145	Reset learned values of components "Diesel particulate filter" and "SCR catalytic converter".	N3/40-Motor electronics "MRD1" for combustion engine "OM654"
SP1146	Teach-in process of component "Y129 (AdBlue?metering valve)"	N3/40-Motor electronics "MRD1" for combustion engine "OM654"
SP1147	Deactivation of production mode	LFD-Left front door
SP1148	Start control unit reset.	LFD-Left front door
SP1149	Addressing of LIN bus participants	AML-Ambiance light
SP1150	Writing of the VIN	IRS HRA-Outer right rear integrated radar sensor (B92/6)
SP1151	Reset VIN.	IRS HRA-Outer right rear integrated radar sensor (B92/6)
SP1152	Calibration with calibration aid	RFK-Backup camera
SP1153	Teach-in processSoftware module "AMG suspension"	AMG DRVU-AMG DRIVE UNIT
SP1154	Teach-in process of component "N170 (Rear wing control unit)"	AMG DRVU-AMG DRIVE UNIT
SP1155	Initialization of component part "ActuatorDifferential lock"	AMG DRVU-AMG DRIVE UNIT
SP1156	Calibration of component "A40/11 (Multifunction camera)"	MFK-Multifunction camera(mono)(A40/11)
SP1157	Control unitUNLOCK	'Driver' seat heater
SP1158	Control unitLOCK	'Driver' seat heater
SP1159	Resetting of counter "Degree of contamination of air filter"	AAC-Automatic air conditioning
SP1160	Teach-in of sensor "B12/2 (Refrigerant pressure sensor)"	AAC-Automatic air conditioning
SP1161	Resetting of learned values of component "B92/12 (Short and long-range radar sensor)"	DTR-DISTRONIC
SP1162	Loading of manufacturer default settings	DTR-DISTRONIC
SP1163	Reset of reading of frequency counter "Crash event"	SGR-Radar sensors control unit
SP1164	Writing of vehicle identification number	SGR-Radar sensors control unit
SP1165	Resetting of learned values of component "Mercedes-Benz Intelligent Drive"	SGR-Radar sensors control unit
SP1166	Calibration of control unit "N62 (Parking system control unit)"	PTS-PARKTRONIC
SP1167	Reset learned values.	ES - Electric power steering
SP1168	Reset offset value of signal "Steering angle".	ES - Electric power steering
SP1169	Reset adaptation values for internal friction of steering.	ES - Electric power steering
SP1170	Calibration of component "Transfer case"	VG-All-wheel drive
SP1171	Adaptation of clutch engagement point	VG-All-wheel drive

SP1172	Reset learned values of component "B92/7 (Right outer rear bumper radar sensor)".	NBR RR-Right rear short-range radar
SP1173	Reset learned values of component "B92/10 (Left outer rear bumper radar sensor)".	NBR LR-Left rear short-range radar
SP1174	Calibration of component "Yaw rate sensor for lateral and longitudinal acceleration"	ESP- Electric stability program
SP1175	Calibration of component "ESP?control valves"	ESP- Electric stability program
SP1176	Calibration of component "Electric parking brake"	ESP- Electric stability program
SP1177	Calibration of component "B37/1 (Pedal angle sensor)"	ESP- Electric stability program
SP1178	Activation of function "Tire pressure loss warning"	ESP- Electric stability program
SP1179	Resetting value "Clutch grip point"	ESP- Electric stability program
SP1180	Reset wear value of component "M56 (Vacuum pump)".	ESP- Electric stability program
SP1181	Test of component "B37/1 (Pedal angle sensor)"	ESP- Electric stability program
SP1182	Function test of component "S9/1 (Brake light switch)"	ESP- Electric stability program
SP1183	Activation of function "Permanent fault memory"	ESP- Electric stability program
SP1184	Calibration of component "A103/1b5 (AdBlue?fill level sensor)"	SCR-Selective catalytic reduction
SP1185	Resetting the calculated fill level of the AdBlue?tank	SCR-Selective catalytic reduction
SP1186	DEF@CPC_NG_ODX_MFA2*44058**default*70630	N127 (Drivetrain control unit)
SP1187	Bleeding the cooling system of the low-temperature circuit	N127 (Drivetrain control unit)
SP1188	Filling the cooling system of the low-temperature circuit	N127 (Drivetrain control unit)
SP1189	TEST MODE1	N127 (Drivetrain control unit)
SP1190	TEST MODE2	N127 (Drivetrain control unit)
SP1191	B79/3 (Manual transmission main shifter shaft position sensor)Position REVERSE	N127 (Drivetrain control unit)
SP1192	B79/3 (Manual transmission main shifter shaft position sensor)Position Gear 5	N127 (Drivetrain control unit)
SP1193	Perform voltage adjustment.	SG EM-Power electronics
SP1194	Teach-in of position sensor	SG EM-Power electronics
SP1195	Contacting of component "Electric machine"(High voltage)	SG EM-Power electronics
SP1196	Test of contact of electrical line of ground strap on component "DC/DC converter"	SG EM-Power electronics
SP1197	High-voltage component lock	BMS-Battery management system
SP1198	Teach-in process Timing chain	N3/10-Motor electronics "EM71" for combustion engine "M282"
SP1199	Teach-in processes	N3/10-Motor electronics "MED41" for combustion engine "M260/M264"
SP1200	Perform teach-in process "Sensor rotor adaptation" at vehicle standstill.	N3/10-Motor electronics "MRG1AMGR4" for combustion engine "M139"
SP1201	Perform teach-in process "Sensor rotor adaptation" during driving operation.	N3/10-Motor electronics "MRG1AMGR4" for combustion engine "M139"
SP1202	Teach-in process after replacement of the combustion engine	N3/10-Motor electronics "MRG1AMGR4" for combustion engine "M139"
SP1203	Teach-in of used fuel injectors	N3/10-Motor electronics "MRG1AMGR4" for combustion engine "M139"
SP1204	Resetting of function "CAN bus"Configuration	N3/10-Motor electronics "MRG1AMGR4" for combustion engine "M139"
SP1205	Calibration of 360?camera at front end	CAMERA-360 camera(N148)
SP1206	Calibration of 360?camera at rear end	CAMERA-360 camera(N148)
SP1207	Calibration of 360?camera in left outside mirror	CAMERA-360 camera(N148)
SP1208	Calibration of 360?camera in right outside mirror	CAMERA-360 camera(N148)

SP1209	Calibration of multiple 360°cameras	CAMERA-360 camera(N148)
SP1210	X21 (Engine cab-chassis electrical connector)	ME 9.7-Motor electronics 9.7
SP1211	ALWAYS ACTIVE	ME 9.7-Motor electronics 9.7
SP1212	[9 (Pressure reservoir)	ME 9.7-Motor electronics 9.7
SP1213	X900.18 (CAN interface electrical connector)	ME 9.7-Motor electronics 9.7
SP1214	The hydraulic cylinders of the soft top compartment lid may be leaky.	ME 9.7-Motor electronics 9.7
SP1215	Discharging	ME 9.7-Motor electronics 9.7
SP1216	Short circuit at component "{0}"	ME 9.7-Motor electronics 9.7
SP1217	The valve of the exhaust gas turbocharger is jammed closed.(The temperature in the component ")"	ETC-Electronic transmission control
SP1218	F108f3A (Electrical fuse 3A)1-2	ETC-Electronic transmission control
SP1219	F108f3A (Electrical fuse 3A)2-3	ETC-Electronic transmission control
SP1220	F108f3A (Electrical fuse 3A)3-4	ETC-Electronic transmission control
SP1221	F108f3A (Electrical fuse 3A)4-5	ETC-Electronic transmission control
SP1222	F108f3A (Electrical fuse 3A)5-6	ETC-Electronic transmission control
SP1223	F108f3A (Electrical fuse 3A)6-7	ETC-Electronic transmission control
SP1224	The soft top compartment lid does not move.	ETC-Electronic transmission control
SP1225	F108f3A (Electrical fuse 3A)7-6	ETC-Electronic transmission control
SP1226	F108f3A (Electrical fuse 3A)6-5	ETC-Electronic transmission control
SP1227	F108f3A (Electrical fuse 3A)5-4	ETC-Electronic transmission control
SP1228	F108f3A (Electrical fuse 3A)4-3	ETC-Electronic transmission control
SP1229	F108f3A (Electrical fuse 3A)3-2	ETC-Electronic transmission control
SP1230	F108f3A (Electrical fuse 3A)2-1	ETC-Electronic transmission control
SP1231	E3e5 (Left rear fog light)	ETC-Electronic transmission control
SP1232	N70/3s1 (Panoramic sliding roof switch)	ETC-Electronic transmission control
SP1233	S40/4r1 (DISTRONIC control)	ETC-Electronic transmission control
SP1234	Remedial actions to be performed step-by-step	ETC-Electronic transmission control
SP1235	The hydraulic cylinders of the soft top compartment lid may be leaky.(Normalization of seat backrest	ETC-Electronic transmission control
SP1236	No open circuits, short circuits to ground or short circuits to positive were detected.	ETC-Electronic transmission control
SP1237	Workshop mode is activated.	ETC-Electronic transmission control
SP1238	The plug - is not used.Deactivation mode of refrigerant compressor via button "{0}"	ETC-Electronic transmission control
SP1239	Both switches of the control element "All-wheel drive" are defective or permanently actuated.If no	ISM-Shift module
SP1240	The key is not initialized or not present in the center console.	Suspension
SP1241	Now insert the unprogrammed key into the center console./Communication with the control processor	Suspension
SP1242	X502 (Left additional lamp electrical connector)	Suspension
SP1243	Number of activations of heating element of compressed-air diffuser	OCP-Overhead control panel
SP1244	E48/2 (Center front emergency hammer illumination)	OCP-Overhead control panel
SP1245	Check the status of the FBS4 components of the displayed control units via the diagnostic unit.	XALWA L-Xenon headlamp, left

SP1246	X272x1 (Radiator trim flap electrical connector)(S82.X1.10 (Electrical connector))	XALWA L-Xenon headlamp, left
SP1247	A deactivated fan can result in increased fuel consumption, increased noise emissions or damage to	XALWA L-Xenon headlamp, left
SP1248	X4/4 (Circuit 30 terminal block)	HRA-Automatic headlamp range adjustment and headlamp control
SP1249	B8/3 (Inner left front parking system distance sensor)	SCR-Selective Catalytic Reduction
SP1250	137411	SCR-Selective Catalytic Reduction
SP1251	Check battery heater.The indicator lamp {0} flashes.	SCR-Selective Catalytic Reduction
SP1252	-	SCR-Selective Catalytic Reduction
SP1253	If the actual value is not inside the specified value range, a calibration of the radar sensor must be	SCR-Selective Catalytic Reduction
SP1254	Deactivate alarm triggered by panic alarm system after {0}.	CDI 60LS-Common Rail Diesel Injection
SP1255	F55/1f45 (Fuse 45, spare)	CDI 60LS-Common Rail Diesel Injection
SP1256	High-voltage intermediate circuit	CDI 60LS-Common Rail Diesel Injection
SP1257	Check battery heater.B33 (Inclination sensor)	CDI 60LS-Common Rail Diesel Injection
SP1258	Check battery heater.X262x2 (Active engine mount electrical connector 2)-The output of radiator	CDI 60LS-Common Rail Diesel Injection
SP1259	Check battery heater.E43/156 (Right front seat right upper trim strip ambient lighting)	CDI 60LS-Common Rail Diesel Injection
SP1260	Check battery heater.A negative value means that the sensor is aligned to the right by the indicated	CDI 60LS-Common Rail Diesel Injection
SP1261	Check battery heater.A telephone connection to the CAC must be established.	CDI 60LS-Common Rail Diesel Injection
SP1262	Check battery heater.Replace battery of component "{0}".	CDI 60LS-Common Rail Diesel Injection
SP1263	Check battery heater.Temperature sensor 3 "Exhaust system" (cylinder bank 1) has an electrical fault.	CDI 60LS-Common Rail Diesel Injection
SP1264	Check battery heater.Is component "{0}" parameterized to "{1}"?	CDI 60LS-Common Rail Diesel Injection
SP1265	Y49 (Hydraulic constant throttle (for R6 engine))	CDI 60LS-Common Rail Diesel Injection
SP1266	The compression test is no longer available for vehicles with combustion engine from AMG.	CDI 60LS-Common Rail Diesel Injection
SP1267	Z274/5 (Engine cooling circuit LIN end sleeve)	CDI 60LS-Common Rail Diesel Injection
SP1268	F153/2f3 (Electrical fuse 3)	CDI 60LS-Common Rail Diesel Injection
SP1269	(USA)/	CDI 60LS-Common Rail Diesel Injection
SP1270	Perform teach-in process for component "B28/8 (DPF differential pressure sensor)".	N3/9-Motor electronics "CR43" for combustion engine "OM651"
SP1271	Teach-in process of component "B79/2 (Transmission neutral position sensor)"	N3/9-Motor electronics "CR43" for combustion engine "OM651"
SP1272	Teach-in process of component "G3/2 (Oxygen sensor upstream of catalytic converter)"	N3/9-Motor electronics "CR43" for combustion engine "OM651"
SP1273	Teach-in process of component "Y74 (Pressure regulating valve)"	N3/9-Motor electronics "CR43" for combustion engine "OM651"
SP1274	Teach-in process of component "Y94 (Quantity control valve)"	N3/9-Motor electronics "CR43" for combustion engine "OM651"
SP1275	Reset values of quantity mean value adaptation.	N3/9-Motor electronics "CR43" for combustion engine "OM651"
SP1276	Teach-in process after replacement of component "G3/2 (Oxygen sensor upstream of catalytic	N3/9-Motor electronics "CDI60LS" for combustion engine "OM642"
SP1277	Teach-in process after replacement of combined diesel particulate filter with oxidation catalytic	N3/9-Motor electronics "CDI61" for combustion engine "OM642"
SP1278	Teach-in of combined diesel particulate filter with oxidation catalytic converter after replacement of	N3/9-Motor electronics "CDI61" for combustion engine "OM642"
SP1279	Teach-in of oxidation catalytic converter after replacement of control unit "N3/9 (CDI control unit)"	N3/9-Motor electronics "CDI61" for combustion engine "OM642"
SP1280	Adaptation of component "Torque converter lockup clutch"	Y3/8n4-Fully integrated transmission control
SP1281	Adaptation of wet start-up clutch (NAK)	Y3/8n4-Fully integrated transmission control
SP1282	Extended adaptation of "Wet clutch" component when driving	Y3/8n4-Fully integrated transmission control

SP1283	Assignment of hydraulic shift elements	Y3/8n4-Fully integrated transmission control
SP1284	Upshifts	Y3/8n4-Fully integrated transmission control
SP1285	Downshifts	Y3/8n4-Fully integrated transmission control
SP1286	Acceleration downshifts	Y3/8n4-Fully integrated transmission control
SP1287	Standstill adaptation	Y3/8n4-Fully integrated transmission control
SP1288	Adaptation values of shift operations	Y3/8n4-Fully integrated transmission control
SP1289	Resetting the service life data of the torque converter	Y3/8n4-Fully integrated transmission control
SP1290	Resetting of service life data of automatic transmission	Y3/8n4-Fully integrated transmission control
SP1291	Resetting learned values "Deceleration mode"	Y3/8n4-Fully integrated transmission control
SP1292	Teach-in of selection range sensor	Y3/8n4-Fully integrated transmission control
SP1293	Teach-in of position sensor of park pawl	Y3/8n4-Fully integrated transmission control
SP1294	Adaptation procedure for torque converter lockup clutch	Y3/8n4-Transmission control for 7 speed transmission
SP1295	Shift	Y3/8n4-Transmission control for 7 speed transmission
SP1296	Reverse gear	Y3/8n4-Transmission control for 7 speed transmission
SP1297	Torque converter	Y3/8n4-Transmission control for 7 speed transmission
SP1298	Shift qualityHistory	Y3/8n4-Transmission control for 9 speed transmission
SP1299	Resetting the service life data of the shift elements	Y3/8n4-Transmission control for 9 speed transmission
SP1300	Resetting of learned values of component "Park pawl"	Y3/8n4-Transmission control for 9 speed transmission
SP1301	Teach-in process after replacement of component "AdBlue?metering valve"	SCR-Selective Catalytic Reduction
SP1302	Resetting of adaptation values-Factor for long-term adaptation of SCR exhaust aftertreatment system	SCR-Selective Catalytic Reduction
SP1303	Resetting the adaptation values of the NOx sensors	SCR-Selective Catalytic Reduction
SP1304	Cancellation of limitation of remaining distance	SCR-Selective Catalytic Reduction
SP1305	Resetting adaptation values of component "A103/2m1 (AdBlue?delivery pump)"	SCR-Selective catalytic reduction
SP1306	Reset of "L20 (Electric machine rotor position sensor)" component	SG EM-Power electronics
SP1307	Calculation of average value for transition resistance of ground strap of component "N83/1 (DC/DC	SG EM-Power electronics
SP1308	Reactivate tire pressure loss warning.	ESP-Electronic stability program(N30/4)
SP1309	Calibration of component "A7/3 (Traction system hydraulic unit)"	ESP-Electronic stability program(N30/4)
SP1310	Calibration of component "B24/15 (Yaw rate sensor for lateral and longitudinal acceleration)"	ESP-Electronic stability program(N30/4)
SP1311	Production	ESP-Electronic stability program(N30/4)
SP1312	Calibrate separation and intake valves in component "A7/3 (Traction system hydraulic unit)".	ESP-Regenerative braking system(N30/6)
SP1313	Teach in component "B37/1 (Pedal angle sensor)".	ESP-Regenerative braking system(N30/6)
SP1314	Resetting the operating hours counter of component "M56 (Vacuum pump)"	ESP-Regenerative braking system(N30/6)
SP1315	Development data	ESP-Regenerative braking system(N30/6)
SP1316	Reset frequency counter "Emergency stop".	SGR-Radar sensors control unit
SP1317	Initial startup of components "B29/2 (Left front bumper DISTRONIC (DTR) sensor)" and "B29/3	SGR-Radar sensors control unit
SP1318	Read out actual values "Offset value of component "Left front short range radar"" and "Offset value of	SGR-Radar sensors control unit
SP1319	Calibration of component "N148 (360?camera control unit)"	CAMERA-360 camera(N148)

SP1320	Transfer of calibration values	CAMERA-360 camera(N148)
SP1321	Special measures	CAMERA-360 camera(N148)
SP1322	Reset of compressor operating time	ADS-Adaptive damping system(N51/5)
SP1323	Pairing of Mercedes-Benz headphones	D FOL-Display in left rear passenger compartment
SP1324	Pairing of other headphones(Only for the development department)	D FOL-Display in left rear passenger compartment
SP1325	Manufacturer default setting	D FOL-Display in left rear passenger compartment
SP1326	Currently paired headphones	D FOL-Display in left rear passenger compartment
SP1327	Pairing of Mercedes-Benz headphones(Only for the development department)	D FOL-Display in left rear passenger compartment
SP1328	Calibrate control unit "A80 (Intelligent servo module for DIRECT SELECT)".	ISM-Shift module
SP1329	Variant coding reset	ISM-Shift module
SP1330	Teach in of sensors	RC-Roll control(B38/2)
SP1331	Calibration of component "N15/7 (Transfer case control module)"	VG-Transfer case
SP1332	Resetting learned values of component parts "Left" and "Right" Gasoline particulate filter	N3/10-Motor electronics "MED177" for combustion engine "M276"
SP1333	Resetting of learned values of component "Gasoline particulate filter" Right	N3/10-Motor electronics "MED177" for combustion engine "M276"
SP1334	Resetting of learned values of component "Gasoline particulate filter" Left	N3/10-Motor electronics "MED177" for combustion engine "M276"
SP1335	Teach-in of exhaust gas recirculation actuators	N3/10-Motor electronics "MED177" for combustion engine "M276"
SP1336	Resetting of learned values of component "Gasoline particulate filter"Right	N3/10-Motor electronics "MED177V6LA" for combustion engine
SP1337	Resetting of learned values of component "Gasoline particulate filter"Left	N3/10-Motor electronics "MED177V6LA" for combustion engine
SP1338	Carrying out adaptation	Y3/8n4-Transmission control for 9 speed transmission
SP1339	Fast adaptation of the component "Wet clutch(NAK)"	Y3/8n4-Transmission control for 9 speed transmission
SP1340	Initializing of control module	Y3/8n4-Transmission control for 9 speed transmission
SP1341	Resetting of adaptation values(Quick adaptation)	Y3/8n4-Transmission control for 9 speed transmission
SP1342	Resetting the adaptation values(Wet clutch(NAK))	Y3/8n4-Transmission control for 9 speed transmission
SP1343	LEFTB-pillar	AAC-Automatic air conditioning
SP1344	Resetting the operating hours counter of component "E1m4 (Left front lamp unit fan motor 1)"	SG LML VL-LED matrix of left front lamp unit
SP1345	Resetting of operating hours counters of component "E2 (Right front lamp unit)"	SG-LML-VR-LED matrix of right front lamp unit
SP1346	Resetting the operating hours counter of component "E2m4 (Right front lamp unit fan motor 1)"	SG-LML-VR-LED matrix of right front lamp unit
SP1347	Control unit UNLOCK	N5 (Armrest heater control unit)
SP1348	Control unit LOCK	N5 (Armrest heater control unit)
SP1349	Reset wear value of component "M56 (Electric vacuum pump)".	ESP-Electric stability program(N30/4)
SP1350	Test of component "S9/1 (Brake light switch)"	ESP-Electric stability program(N30/4)
SP1351	Teach in component "N129 (Starter-alternator control unit)".	ISG-Integrated starter alternator
SP1352	Resetting learned values of component parts "Gasoline particulate filterLeft" and "Gasoline particulate	N3/10-Motor electronics "MED1775" for combustion engine "M178"
SP1353	Resetting of learned values of component "Gasoline particulate filterLeft"	N3/10-Motor electronics "MED1775" for combustion engine "M178"
SP1354	Resetting of learned values of component "Gasoline particulate filterRight"	N3/10-Motor electronics "MED1775" for combustion engine "M178"
SP1355	Teach-in of throttle valve end stops of right and left throttle valve actuators	N3/10-Motor electronics "MED1775" for combustion engine "M178"
SP1356	Vehicle data	CGW[ZGW]-Central gateway

SP1357	Calibration of intake valves	ESP- Electric stability program
SP1358	Calibration of separation valves	ESP- Electric stability program
SP1359	Calibrate control unit "N30/4 (Electronic Stability Program control unit)".	ESP- Electric stability program
SP1360	Separate normalization of steering column	N32/1 (Driver seat control unit)
SP1361	M59 (Intake manifold swirl flap actuator motor)	N3/10-Motor electronics "SIM271DE20" for combustion engine "M271EVO"
SP1362	Acceleration of sensor rotor adaptation	N3/10-Motor electronics "SIM271DE20" for combustion engine "M271EVO"
SP1363	Perform teach-in process for control unit "ME".	N3/10-Motor electronics "SIM271DE20" for combustion engine "M271EVO"
SP1364	Special procedures	IC-Instrument cluster
SP1365	M16/53 (Left exhaust flap actuator motor)	N127 (Drivetrain control unit)
SP1366	Reset of cold start adaptation values	N3/10-Motor electronics "ME97 AMG" for combustion engine "M156"
SP1367	Sensor rotor adaptation	N3/10-Motor electronics "ME97 AMG" for combustion engine "M156"
SP1368	Operating time of component "M75/7 (Rear high-voltage battery coolant pump)"	BMS-H-Battery management system, rear (master)
SP1369	M75/7 (Rear high-voltage battery coolant pump)	BMS-H-Battery management system, rear (master)
SP1370	Unlock high-voltage component lock.	BMS-H-Battery management system, rear (master)
SP1371	Reset of control unit "N82/8 (Rear battery management system control unit (slave))"	BMS-H-Battery management system, rear (master)
SP1372	Road test	ESP-Electronic stability program(N30/4)
SP1373	ESP?calibration at standstill	ESP-Electric stability program(N30/4)
SP1374	Initial startup of component "Front left electrical machine"	ELM-VL-Front left electrical machine
SP1375	FBS3-teach-in processes	ELM-VL-Front left electrical machine
SP1376	Write tire pressure specified values.	TPM-Tire pressure monitor(N88)
SP1377	Customer-specific data	Audio-Audio or COMAND
SP1378	Teach-in processCurrent dateGPS data	Audio-Audio or COMAND
SP1379	Initial startup of component "Front right electrical machine"	ELM-VR-Front right electrical machine
SP1380	Initial startup of component "Rear left electrical machine"	ELM-HL-Rear left electrical machine
SP1381	Initial startup of component "Rear right electrical machine"	ELM-HR-Rear right electrical machine
SP1382	Bleeding of coolant circuit(Electric drive)	PTCU-MA-Drivetrain (master)
SP1383	Bleeding of coolant circuit(High-voltage battery)	PTCU-MA-Drivetrain (master)
SP1384	Check of coolant level of coolant circuit for high-voltage battery	PTCU-MA-Drivetrain (master)
SP1385	Bedding in new brake pads	EFB-Electric parking brake
SP1386	Operating time of component "M75/5 (Front high-voltage battery coolant pump)"	BMS-V-Battery management system, front (slave)
SP1387	M75/5 (Front high-voltage battery coolant pump)	BMS-V-Battery management system, front (slave)
SP1388	Reset of control unit "N82/7 (Front battery management system control unit (slave))"	BMS-V-Battery management system, front (slave)
SP1389	Operating time of component "M75/6 (Center high-voltage battery coolant pump)"	BMS-M-Battery management system, center (master)
SP1390	Measurements before replacement of componentsHigh-voltage battery:Writing the offset	BMS-M-Battery management system, center (master)
SP1391	After replacement of component "High-voltage battery":Writing the offset value:Kilometer reading	BMS-M-Battery management system, center (master)
SP1392	M75/6 (Center high-voltage battery coolant pump)	BMS-M-Battery management system, center (master)
SP1393	Reset of control unit "N82/6 (Battery management system control unit (master))"	BMS-M-Battery management system, center (master)

SP1394	Teach-in process of component "B28/8 (Differential pressure sensor (DPF))"	N3/9-Motor electronics "CR42" for combustion engine "OM651"
SP1395	Teach-in process of component "Oxidation catalytic converter"	N3/9-Motor electronics "CR42" for combustion engine "OM651"
SP1396	Perform teach-in process for component "Diesel particulate filter".	N3/9-Motor electronics "CR42" for combustion engine "OM651"
SP1397	Replace component "Diesel particulate filter".	N3/9-Motor electronics "CDI6" for combustion engine "OM642"
SP1398	Y74 (Pressure regulating valve)	N3/9-Motor electronics "CDI6" for combustion engine "OM642"
SP1399	B28/8 (DPF differential pressure sensor)	N3/9-Motor electronics "CDI6" for combustion engine "OM642"
SP1400	G3/2 (Oxygen sensor upstream of catalytic converter)	N3/9-Motor electronics "CDI6EU5" for combustion engine "OM642"
SP1401	Teach in component "Y94 (Quantity control valve)".	N3/9-Motor electronics "CDI" for combustion engine "OM646"
SP1402	Teach in used diesel particulate filter.	N3/9-Motor electronics "CDI" for combustion engine "OM646"
SP1403	Quick teach-in of the zero quantity calibration values for calibration point 230.0bar	N3/9-Motor electronics "CDI" for combustion engine "OM646"
SP1404	Quick teach-in of the zero quantity calibration values for calibration point 600.0bar	N3/9-Motor electronics "CDI" for combustion engine "OM646"
SP1405	Number of injection period corrections for all fuel injectors	N3/9-Motor electronics "CDI" for combustion engine "OM646"
SP1406	Definition	N15/3-Transmission control for 5 speed transmission
SP1407	Information on the adaptation limit values	N15/3-Transmission control for 5 speed transmission
SP1408	Display of all adaptation data	N15/3-Transmission control for 5 speed transmission
SP1409	Adaptation of the gearshifts	N15/3-Transmission control for 5 speed transmission
SP1410	Teach in component "B24/15 (Yaw rate sensor for lateral and longitudinal acceleration)".	ESP- Electric stability program
SP1411	Activation of control unit "N26/5 (Electric steering lock control unit)"	EZS-Electronic ignition lock
SP1412	N121 (Trunk lid control control unit)	TLC-Trunk lid control
SP1413	Resetting of calibration settings	RFK-Backup camera
SP1414	Reset of operating hours counter	XALWA L-Xenon headlamp, left
SP1415	Teach-in of stop for boost pressure control flap	N3/10-Motor electronics "SIM271KE20" for combustion engine "M271"
SP1416	Teach in component "M55 (Intake port shutoff actuator motor)".	N3/9-Motor electronics "CDI41R" for combustion engine "OM626"
SP1417	Teach-in process of component "B79/3 (Manual transmission main shifter shaft position sensor)"	N3/9-Motor electronics "CDI41R" for combustion engine "OM626"
SP1418	Resetting of learned values of component "B28/8 (DPF differential pressure sensor)"	N3/9-Motor electronics "CDI41R" for combustion engine "OM626"
SP1419	Resetting adaptation values of component "Turbocharger"	N3/9-Motor electronics "CDI41R" for combustion engine "OM626"
SP1420	Resetting of learned values of component "Low-pressure fuel circuit"	N3/9-Motor electronics "CDI41R" for combustion engine "OM626"
SP1421	Teach in diesel particulate filter again.	N3/9-Motor electronics "CDI41R" for combustion engine "OM626"
SP1422	Remove and install head restraint.	ESV Driver-Electric seat adjustmnet Driver with memory function
SP1423	Perform normalization of component "N121/1 (Liftgate control control unit)".	HKS-Tailgate control
SP1424	N121/1 (Trunk lid/liftgate control control unit)	HKS-Tailgate control
SP1425	Automatic illumination test	OCP-Overhead control panel
SP1426	Normalization of right rear power window	SG FOND-Rear control unit
SP1427	Normalization of left rear power window	SG FOND-Rear control unit
SP1428	Normalization of trunk lid control	SG FOND-Rear control unit
SP1429	Intelligent Light SystemActivation	SG SW L-Left headlamp
SP1430	Teach-in process of control unit "A80 (Intelligent servo module for DIRECT SELECT)" after	ISM-Shift module

SP1431	Resetting the operating hours counter of component "E2m5 (Right front lamp unit fan motor 2)"	AMLAB-R (Actuation module, LED exterior lighting, right front)
SP1432	Resetting the operating hours counter of component "E1m5 (Left front lamp unit fan motor 2)"	AMLAB-L (Actuation module, LED exterior lighting, left front)
SP1433	Resetting of learned values of component "SGR"	SGR-Radar sensors control unit(N62/1)
SP1434	Teach in component "B24/15 (Yaw rate, lateral and longitudinal acceleration sensor)".	ESP-Electric stability program(N30/4)
SP1435	Teach in component "ESP?control valves".	ESP-Electric stability program(N30/4)
SP1436	Teach in component "Electric parking brake".	ESP-Electric stability program(N30/4)
SP1437	Resetting value "Offset value for steering wheel angle"	ESP-Electric stability program(N30/4)
SP1438	Resetting value "Wear values"	ESP-Electric stability program(N30/4)
SP1439	Permanent fault memory	ESP-Electric stability program(N30/4)
SP1440	Teach in component "S9/1 (Brake light switch)".	ESP-Electric stability program(N30/4)
SP1441	Check offset value of component "N49 (Steering angle sensor)".	ESP-Electric stability program(N30/4)
SP1442	Test of contact of electrical line of ground strap on component "N129/1 (Power electronics control	SG EM-Power electronics
SP1443	Regeneration of gasoline particulate filter	N3/10-Motor electronics "MED177" for combustion engine "M276"
SP1444	Tire pressure loss warning	ESP-Electronic stability program(N30/4)
SP1445	The contact of the ground strap is faulty.	PE-Power electronics(N129/1)
SP1446	Commissioning of control unit "N118/2 (CNG control unit)"	N3/10-Motor electronics "MED40CNG" for combustion engine "M270"
SP1447	Bleeding after replacement of fuel components	N3/10-Motor electronics "MED40CNG" for combustion engine "M270"
SP1448	Enable natural gas operation after crash event.	N3/10-Motor electronics "MED40CNG" for combustion engine "M270"
SP1449	Y107/1 (Gas cylinder shutoff valves)	N3/10-Motor electronics "SIM271KECNG" for combustion engine
SP1450	Enable natural gas operation	N3/10-Motor electronics "SIM271KECNG" for combustion engine
SP1451	PRESSURE CONTROL	N3/10-Motor electronics "SIM271KECNG" for combustion engine
SP1452	Injector injection quantity adjustment(Manual entry)	N3/9-Motor electronics "CDI61" for combustion engine "OM642"
SP1453	Activate fuel pump.	CDI-Motor electronics CR61 for combustion engine OM642
SP1454	Teach-in process of component "M16/53 (Left exhaust flap actuator motor)"	CDI-Motor electronics CR61 for combustion engine OM642
SP1455	Teach-in process of component "Y77/6 (Boost pressure regulator)"	CDI-Motor electronics CR61 for combustion engine OM642
SP1456	Reset learned values for diagnosis of CAN bus through control unit "N3/49 (CDI control unit)".	CDI-Motor electronics CR61 for combustion engine OM642
SP1457	Teach-in process after replacement of component "NOx storage catalytic converter"	CDI-Motor electronics CR61 for combustion engine OM642
SP1458	Resetting of learned values of component "B92/11 (Left outer rear bumper integrated radar sensor)"	IRS HLA-Outer left rear integrated radar sensor (B92/11)
SP1459	Resetting of learned values of component "B92/6 (Right outer rear bumper integrated radar sensor)"	IRS HRA-Outer right rear integrated radar sensor (B92/6)
SP1460	B84/3 (Reversing camera)	RFK-Backup camera
SP1461	Resetting of learned values of component "A108 (Active Brake Assist controller unit)"	SG AWF-Control unit COLLISION PREVENTION ASSIST
SP1462	Reset of frequency counter "Emergency stop"	SG AWF-Control unit COLLISION PREVENTION ASSIST
SP1463	Resetting of calibration values	ABC-Active body control(N51/2)
SP1464	Calibration of stroke of suspension struts	ABC-Active body control(N51/2)
SP1465	Vehicle load condition comparison	ABC-Active body control(N51/2)
SP1466	Calibration of component "B24/12 (ABC lateral acceleration sensor)"	ABC-Active body control(N51/2)
SP1467	Initial startup after repair	ABC-Active body control(N51/2)

SP1468	Control unit reset	ABC-Active body control(N51/2)
SP1469	Commissioning of control unit "E1n8 (Actuation module 2, LED exterior lighting, left front)"	XALWA L-Left xenon headlamp(E1n1)
SP1470	Commissioning of control unit "E1n7 (Actuation module, LED exterior lighting, left front)"	XALWA L-Left xenon headlamp(E1n1)
SP1471	Commissioning of control unit "E2n8 (Actuation module 2, LED exterior lighting, right front)"	XALWA R-Right xenon headlamp(E2n1)
SP1472	Commissioning of control unit "E2n7 (Actuation module, LED exterior lighting, right front)"	XALWA R-Right xenon headlamp(E2n1)
SP1473	List of paired devices Remote control Headphones	D FOL-Display in left rear passenger compartment
SP1474	Pairing'Handset'	AVE H-Controller unit Rear entertainment system
SP1475	Check component "B37/1 (Pedal angle sensor)".	RBS-Regenerative braking system
SP1476	Check component "S9/1 (Brake light switch)".	RBS-Regenerative braking system
SP1477	Teach-in process of component "N158 (Park pawl control unit)"	PTCU-Common powertrain controller(N127)
SP1478	Teach-in process of component "M56 (Vacuum pump)"	PTCU-Common powertrain controller(N127)
SP1479	Perform control unit reset.	CSHVB-Crash sensor high-voltage battery
SP1480	Check electronic accelerator pedal.	N127 (Drivetrain control unit)
SP1481	Electrical contacting of coolant pumps via LIN bus	N127 (Drivetrain control unit)
SP1482	Electrical contacting of fans	N127 (Drivetrain control unit)
SP1483	Electrical contacting of relays	N127 (Drivetrain control unit)
SP1484	Electrical contacting of coolant pumps	N127 (Drivetrain control unit)
SP1485	Electrical contacting of valves	N127 (Drivetrain control unit)
SP1486	Electrical contacting of PTC heater "High voltage"	N127 (Drivetrain control unit)
SP1487	Function illumination(Author data)	ISM-Shift module
SP1488	Teach-in process after replacement of component "Y27/9 (Exhaust gas recirculation actuator)"	N3/30-Motor electronics "CDI6" for combustion engine "OM642"
SP1489	Activate radio code.	AUDIO-Audio or COMAND(A2-A40/3)
SP1490	Fixed assignment of control unit to vehicle	EZS-Electronic ignition switch
SP1491	Reactivate key.	EZS-Electronic ignition switch
SP1492	Revocably deactivate key.	EZS-Electronic ignition switch
SP1493	Irrevocably deactivate key.	EZS-Electronic ignition switch
SP1494	Calibration of component "B24/8 (Steering angle sensor)"	ESP- Electric stability program
SP1495	Z81/3z4 (Circuit 58 connector sleeve 4)	ESP-Electronic stability program
SP1496	Parameters for internal tachographThe actual value of the boost pressure positioner changes when the	ESP-Electronic stability program
SP1497	The network is broadcast.	AAM-All Activity Module
SP1498	Y19/12 (High-voltage battery cooling evaporator shutoff valve)	AAM-All Activity Module
SP1499	Install missing switch.	AAM-All Activity Module
SP1500	U1086 (Valid without code 613 Headlamps for left-hand traffic system)	AAM-All Activity Module
SP1501	S55/1s6 (Left rear seat memory function switch)	DAS-Drive authorization system
SP1502	Y93/1 (Left exhaust flap switchover valve)	DAS-Drive authorization system
SP1503	Y93/2 (Right exhaust flap switchover valve)	DAS-Drive authorization system
SP1504	The limit switch "Rear shelf UP" has a malfunction.	DAS-Drive authorization system

SP1505	Turn air distribution flap of actuator motor of right B-pillar to the right into position {0}.	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)
SP1506	Code MB6 (Low-emission vehicle, Euro 6 Group 1)	ES-Electrical power steering
SP1507	Now insert the unprogrammed key into the center console.(Put only the initialized key in the	ESV driver-Electric seat adjustment driver (with memory)
SP1508	Overload can result in vehicle damage that puts other road users at risk.	ICM-Instrument cluster with maintenance interval display
SP1509	If the correction value for the injection duration undershoots a value of {0} or exceeds a value of {1},	ICM-Instrument cluster with maintenance interval display
SP1510	The fault code {0}, {1}, {2} or {3} is present and current.	ICM-Instrument cluster with maintenance interval display
SP1511	The actual value indicates whether the solenoid valve is open or closed.	RCM-Rear control module
SP1512	The actual value indicates the status of the heater.	RCM-Rear control module
SP1513	K40/9f14 (Circuit 15 LDS, instrument cluster, diagnostic connector fuse)	ME SFI-Motor electronics
SP1514	X54/21 (Left rear seat longitudinal/inclination adjustment motors electrical connector)Before erasing	ME SFI-Motor electronics
SP1515	Refrigerant pressure sensor	ME SFI-Motor electronics
SP1516	Initial startup of components "{0}" and "{1}"	ME SFI-Motor electronics
SP1517	OLD	ME SFI-Motor electronics
SP1518	OLD(X54/21 (Left rear seat longitudinal/inclination adjustment motors electrical connector))	ME SFI-Motor electronics
SP1519	Is the fault code stored in other control units?	ME SFI-Motor electronics
SP1520	K40/11F17 (Electrical fuse 17)X101/3 (Frame floor assembly/left rear underfloor electrical	SBC-Sensotronic Brake Control
SP1521	Regeneration of the soot particulate sensor has occurred.X101/3 (Frame floor assembly/left rear	SBC-Sensotronic Brake Control
SP1522	Type of governor with power take-off {0}	SBC-Sensotronic Brake Control
SP1523	A32/4m3 (Rear blend air flap actuator motor)	Suspension
SP1524	Activate cooling of component "{0}".	ASSYST PLUS-PLUS Active Service System
SP1525	The ignition key is in position "{0}" (circuit {1}).	ASSYST PLUS-PLUS Active Service System
SP1526	At least one of the switches "Seat adjustment" (channel 4) has a short circuit to ground.	ABR-Adaptive Brake
SP1527	Status "{0}" is displayed even for unsupported devices.	ICM-Instrument cluster with maintenance interval display
SP1528	Communication with the control processor has been ended.	ABC-Active body control(N51/2)
SP1529	The measurement value indicates the specified interior temperature value set in the control unit.	OCP-Overhead control panel
SP1530	The setting of coding "{0}"depends on coding "{1}".	OCP-Overhead control panel
SP1531	U994 (Not valid for comfort central locking system)	OCP-Overhead control panel
SP1532	Standard-Fehlercode	EPB-Electric parking brake
SP1533	Charge battery.	EPB-Electric parking brake
SP1534	Clip unclipped pins back in if necessary.	TPM-Tire pressure monitor
SP1535	The clutch actuator has an electrical fault or open circuit.	TPM-Tire pressure monitor
SP1536	Heavy vehicle acceleration	EZS-Electronic ignition switch
SP1537	A85/1s4 (Right front door additional door lock actuator motor switch)	EZS-Electronic ignition switch
SP1538	LIN communication with the oil sensor has a malfunction.	EZS-Electronic ignition switch
SP1539	The adaptation values have not been reset.	EZS-Electronic ignition switch
SP1540	Manual regeneration of the diesel particulate filter by the workshop has failed.Abort of regeneration	EZS-Electronic ignition switch
SP1541	Lock of forward gear	ABR-Adaptive Brake

SP1542	Parameters for internal tachographInput signal from control unit "{0}"	ABR-Adaptive Brake
SP1543	Standard-FehlercodeStandard-Fehlercode	ABR-Adaptive Brake
SP1544	Now insert the unprogrammed key into the center console.	ABC-Active body control(N51/2)
SP1545	Position in TV channel list	Dr side SAM-Driver signal acquisition and actuation module
SP1546	The selection of the drive program "{0}" remains stored for the duration of the trip.	DCM FL-Door control module front left
SP1547	XD/FRI (Air humidifier electrical connection)	ESA FL-Electric seat adjustment front left
SP1548	Maximum permissible gear with power take-off	ESA FL-Electric seat adjustment front left
SP1549	Speed limit with power take-off	ESA FL-Electric seat adjustment front left
SP1550	Switch for deactivating air conditioning	ESA FL-Electric seat adjustment front left
SP1551	Since the membrane in the pressure sensor is very sensitive to mechanical contact, it must be cleaned	ESA FL-Electric seat adjustment front left
SP1552	The calibration frame is moved upwards.	ASSYST-Active Service System
SP1553	UGZ7 (Transmission ZF 6 HP 592 - ECOMAT II)	ASSYST-Active Service System
SP1554	Temperature sensor 4 of inverter "Electric machine B" has a malfunction.	AAC-Automatic air conditioning
SP1555	Communication with the rear warning indicator has a malfunction.	AAC-Automatic air conditioning
SP1556	W1-ESD (Steering wheel ground point - electrostatic discharge)	AAC-Automatic air conditioning
SP1557	W2-ESD (Steering wheel ground point - electrostatic discharge)	AAC-Automatic air conditioning
SP1558	#210E (Checksum of signal group "EVC_CfgBit_01_32_Pr2")	AAC-Automatic air conditioning
SP1559	The soft top must be closed.Initial startup with automatic transfer of settings from old control unit is	STH-Stationary heater with remote control
SP1560	X272x1 (Radiator trim flap electrical connector)-Z35/44z1 (Interior CAN (CAN B) Low connector	XALWA L-Xenon headlamp, left
SP1561	145800	ME 2.7.2-Motor electronics 2.7.2
SP1562	The test has been aborted.	MED 17.7-Motor electronics for direct injection 17.7
SP1563	Service scope is out of condition.Y68/1 (Rear axle differential lock solenoid valve)	MED 17.7-Motor electronics for direct injection 17.7
SP1564	Communication via diagnosis is not possible.	MED 17.7-Motor electronics for direct injection 17.7
SP1565	Y31/5 (Charge pressure control vacuum transducer)	MED 17.7-Motor electronics for direct injection 17.7
SP1566	158634	MED 17.7-Motor electronics for direct injection 17.7
SP1567	E48/2 (Center front emergency hammer illumination)Check of fill level sensors	PSD-Panoramic sliding roof(Interior CAN bus)
SP1568	TOP RIGHT-Check electrical line from component "{0}" (pin {1}) to component "{2}".	ESA R-Electric seat adjustment rear
SP1569	138572	SG EM-Electric motor control unit
SP1570	138576	SG EM-Electric motor control unit
SP1571	148374	CDI 3-Common Rail Diesel Injection3
SP1572	148373	CDI 3-Common Rail Diesel Injection3
SP1573	Valid for vehicles with national version "{0}":	CDI 3-Common Rail Diesel Injection3
SP1574	Z21/40 (Right end position closing assist end sleeve)The heating element has a malfunction.	CDI 3-Common Rail Diesel Injection3
SP1575	Z21/40 (Right end position closing assist end sleeve)Automatic window raising	CDI 3-Common Rail Diesel Injection3
SP1576	Z21/40 (Right end position closing assist end sleeve)Moisture in reference duct	CDI 3-Common Rail Diesel Injection3
SP1577	Code J10 (Digital tachograph, 2nd generation, ADR)	CDI 3-Common Rail Diesel Injection3
SP1578	Supplier:	SBC-Sensotronic Brake Control

SP1579	K40/11F18 (Electrical fuse 18)	SBC-Sensotronic Brake Control
SP1580	E327e1 (Right low beam)K40/5f404 (Electrical fuse 404)	SBC-Sensotronic Brake Control
SP1581	High-pressure regulation has a malfunction.	SBC-Sensotronic Brake Control

XTOOL

Actions

No.	Functions Name	System Name
ACT0000	Compression test	N3/9-Motor electronics ''CDID3'' for combustion engine ''OM651''
ACT0001	B76/1 (Condensation sensor for fuel filter with heating element)	N3/9-Motor electronics ''CDID3'' for combustion engine ''OM651''
ACT0002	M3 (Fuel pump)	N3/9-Motor electronics ''CDID3'' for combustion engine ''OM651''
ACT0003	M4/7 (Combustion engine and air conditioning with integrated control fan motor)	N3/9-Motor electronics ''CDID3'' for combustion engine ''OM651''
ACT0004	M13/7 (Transmission oil cooling coolant circulation pump)	N3/9-Motor electronics ''CDID3'' for combustion engine ''OM651''
ACT0005	M16/6 (Throttle valve actuator)	N3/9-Motor electronics ''CDID3'' for combustion engine ''OM651''
ACT0006	Actuation of component ''M16/6 (Throttle valve actuator)'' with automatic evaluation of the test results	N3/9-Motor electronics ''CDID3'' for combustion engine ''OM651''
ACT0007	M43/6 (Low temperature circuit circulation pump 1)	N3/9-Motor electronics ''CDID3'' for combustion engine ''OM651''
ACT0008	M55 (Intake port shutoff actuator motor)	N3/9-Motor electronics ''CDID3'' for combustion engine ''OM651''
ACT0009	N14/3 (Glow output stage)	N3/9-Motor electronics ''CDID3'' for combustion engine ''OM651''
ACT0010	R39/1 (Vent line heating element)	N3/9-Motor electronics ''CDID3'' for combustion engine ''OM651''
ACT0011	R48 (Coolant thermostat heating element)	N3/9-Motor electronics ''CDID3'' for combustion engine ''OM651''
ACT0012	Y27/9 (Exhaust gas recirculation actuator)	N3/9-Motor electronics ''CDID3'' for combustion engine ''OM651''
ACT0013	Actuation of component ''Y27/9 (Exhaust gas recirculation actuator)'' with automatic evaluation of the test results	N3/9-Motor electronics ''CDID3'' for combustion engine ''OM651''
ACT0014	Y31/4 (Wastegate control pressure transducer)	N3/9-Motor electronics ''CDID3'' for combustion engine ''OM651''
ACT0015	Y58/13 (Heat exchanger shutoff valve)	N3/9-Motor electronics ''CDID3'' for combustion engine ''OM651''
ACT0016	Y77/1 (Boost pressure positioner)	N3/9-Motor electronics ''CDID3'' for combustion engine ''OM651''
ACT0017	Y84 (Radiator shutters actuator)	N3/9-Motor electronics ''CDID3'' for combustion engine ''OM651''

ACT0018	Y85 (Exhaust gas recirculation cooler bypass switchover valve)	N3/9-Motor electronics ''CDID3'' for combustion engine ''OM651''
ACT0019	Y93 (Boost pressure control flap pressure transducer)	N3/9-Motor electronics ''CDID3'' for combustion engine ''OM651''
ACT0020	Switchable engine mounts	N3/9-Motor electronics ''CDID3'' for combustion engine ''OM651''
ACT0021	Check contacts of components ''Y123 (Left switchable engine mount)'' and ''Y123/1 (Right switchable engine mount)'' via	N3/9-Motor electronics ''CDID3'' for combustion engine ''OM651''
ACT0022	Y130 (Engine oil pump valve)	N3/9-Motor electronics ''CDID3'' for combustion engine ''OM651''
ACT0023	Y131 (Oil spray nozzles shutoff valve)	N3/9-Motor electronics ''CDID3'' for combustion engine ''OM651''
ACT0024	Y133 (Coolant pump switchover valve)	N3/9-Motor electronics ''CDID3'' for combustion engine ''OM651''
ACT0025	Y76 (Fuel injectors)	N3/9-Motor electronics ''CDID3'' for combustion engine ''OM651''
ACT0026	Injector shutoff	N3/9-Motor electronics ''CDID3'' for combustion engine ''OM651''
ACT0027	Actuation of components ''Y93 (Boost pressure control flap pressure transducer)'' and ''Y31/4 (Wastegate control pressure	N3/9-Motor electronics ''CDID3'' for combustion engine ''OM651''
ACT0028	M4/7 (fan motor)	N3/9-Motor electronics ''CDID3'' for combustion engine ''OM651''
ACT0029	M16/57 (Exhaust flap controller)	N3/3-Motor electronics ''OM607'' for combustion engine ''CRR1''
ACT0030	Y27/8 (Exhaust gas recirculation actuator, high pressure)	N3/3-Motor electronics ''OM607'' for combustion engine ''CRR1''
ACT0031	Y27/7 (Exhaust gas recirculation actuator, low pressure)	N3/3-Motor electronics ''OM607'' for combustion engine ''CRR1''
ACT0032	Y77/1 (Boost pressure regulator)	N3/3-Motor electronics ''OM607'' for combustion engine ''CRR1''
ACT0033	Diagnostic glowing	N3/3-Motor electronics ''OM607'' for combustion engine ''CRR1''
ACT0034	N33/2 (DPF regeneration heater booster control unit)	N3/3-Motor electronics ''OM607'' for combustion engine ''CRR1''
ACT0035	Rail pressure	N3/3-Motor electronics ''OM607'' for combustion engine ''CRR1''
ACT0036	A92/3 (Fuel filter module)	N3/3-Motor electronics ''OM607'' for combustion engine ''CRR1''
ACT0037	F32k1 (Decoupling relay)	N3/3-Motor electronics ''OM607'' for combustion engine ''CRR1''

ACT0038	Status of circuit 87	N3/3-Motor electronics ''OM607'' for combustion engine ''CRR1''
ACT0039	Control unit reset	E call [Europe]-Emergency call system
ACT0040	Workshop mode	E call [Europe]-Emergency call system
ACT0041	Status LEDs	E call [Europe]-Emergency call system
ACT0042	Emergency call	E call [Europe]-Emergency call system
ACT0043	Self-test	E call [Europe]-Emergency call system
ACT0044	Speaker	E call [Europe]-Emergency call system
ACT0045	A1h1 (Warning buzzer)	IC-Instrument cluster
ACT0046	Mechanical instrument pointers	IC-Instrument cluster
ACT0047	A1p13 (Multifunction display)	IC-Instrument cluster
ACT0048	Indicator lamps	IC-Instrument cluster
ACT0049	A1e8 (Instrument illumination)	IC-Instrument cluster
ACT0050	Segments on speedometer	IC-Instrument cluster
ACT0051	USB interface	KOMO-Communication module Telematics services
ACT0052	Restoration of initial authorization certificate	KOMO-Communication module Telematics services
ACT0053	Transfer VIN to control unit ''N112/2 (Telematics services communication module)''.	KOMO-Communication module Telematics services
ACT0054	Transfer certain digits of the VIN to the control unit ''N112/2 (Telematics services communication module)''.	KOMO-Communication module Telematics services
ACT0055	Manufacturer default setting	KOMO-Communication module Telematics services
ACT0056	Reset operating condition.	KOMO-Communication module Telematics services
ACT0057	Special function	KOMO-Communication module Telematics services

ACT0058	H4/27 (Center instrument panel speaker)	TS-Telematic system(N123/4)
ACT0059	Muting	TS-Telematic system(N123/4)
ACT0060	Button illumination of multifunction steering wheel	SCM-Steering column module(N80)
ACT0061	Illumination of component ''S16/13 (DIRECT SELECT lever)''	SCM-Steering column module(N80)
ACT0062	S40/4v1 (SPEEDTRONIC light-emitting diode)	SCM-Steering column module(N80)
ACT0063	S59/1e1 (Steering wheel heater indicator lamp)	SCM-Steering column module(N80)
ACT0064	R22/4 (Steering wheel heater)	SCM-Steering column module(N80)
ACT0065	M99 (Steering wheel vibration motor)	SCM-Steering column module(N80)
ACT0066	Actuate LEDs.	AMG DRVU-AMG DRIVE UNIT(N145)
ACT0067	LEDs of component ''S192 (Transmission mode rotary switch)''	AMG DRVU-AMG DRIVE UNIT(N145)
ACT0068	Actuate rear spoiler.	AMG DRVU-AMG DRIVE UNIT(N145)
ACT0069	A7/3m1 (High-pressure and return flow pump)	ESP-Electronic stability program(N30/4)
ACT0070	A7/3y11 (Left rear pressure regulating valve (pressure release))	ESP-Electronic stability program(N30/4)
ACT0071	Unlocking of component ''Navigation module''	NAV-Navigation module(A2/30)
ACT0072	Output of test sound	NAV-Navigation module(A2/30)
ACT0073	Measured volume level of microphone	NAV-Navigation module(A2/30)
ACT0074	Measurement of reception field strength	NAV-Navigation module(A2/30)
ACT0075	Self-test of control unit ''ATA [EDW]/tow-away protection/interior protection''	IMS-Interior motion sensor
ACT0076	Erase alarm sources	IMS-Interior motion sensor
ACT0077	Actuation of components ''S93/3s1 (Tow-away protection button)'' and ''S93/3s3 (Interior protection button)''	IMS-Interior motion sensor

ACT0078	A69/1 (Left front tire pressure sensor)	TPM-Tire pressure monitor(N88)
ACT0079	A69/2 (Right front tire pressure sensor)	TPM-Tire pressure monitor(N88)
ACT0080	A69/3 (Left rear tire pressure sensor)	TPM-Tire pressure monitor(N88)
ACT0081	A69/4 (Right rear tire pressure sensor)	TPM-Tire pressure monitor(N88)
ACT0082	Wake-up line	AUDIO-Audio or COMAND (A2-A40/3)
ACT0083	Internal fan	AUDIO-Audio or COMAND (A2-A40/3)
ACT0084	External fan	AUDIO-Audio or COMAND (A2-A40/3)
ACT0085	Determination of number of receivable radio transmitters	AUDIO-Audio or COMAND (A2-A40/3)
ACT0086	Wiring test of radio antennas	AUDIO-Audio or COMAND (A2-A40/3)
ACT0087	Antenna measuring drive	AUDIO-Audio or COMAND (A2-A40/3)
ACT0088	Electrical self-test of microphones.	AUDIO-Audio or COMAND (A2-A40/3)
ACT0089	Volume level	AUDIO-Audio or COMAND (A2-A40/3)
ACT0090	Color display	AUDIO-Audio or COMAND (A2-A40/3)
ACT0091	Sample display	AUDIO-Audio or COMAND (A2-A40/3)
ACT0092	TV tuner	AUDIO-Audio or COMAND (A2-A40/3)
ACT0093	AUX jack	AUDIO-Audio or COMAND (A2-A40/3)
ACT0094	Navigation	AUDIO-Audio or COMAND (A2-A40/3)
ACT0095	Display illumination	AUDIO-Audio or COMAND (A2-A40/3)
ACT0096	Extending/retracting the display	AUDIO-Audio or COMAND (A2-A40/3)
ACT0097	Backup camera	AUDIO-Audio or COMAND (A2-A40/3)

ACT0098	B84/3 (Reversing camera)	AUDIO-Audio or COMAND (A2-A40/3)
ACT0099	B84/5 (Front passenger outside mirror camera)	AUDIO-Audio or COMAND (A2-A40/3)
ACT0100	B84/6 (Passenger-side outside mirror backup camera)	AUDIO-Audio or COMAND (A2-A40/3)
ACT0101	Check CD/DVD insert and eject.	AUDIO-Audio or COMAND (A2-A40/3)
ACT0102	Slot for memory cardTest	AUDIO-Audio or COMAND (A2-A40/3)
ACT0103	TestUSB interface	AUDIO-Audio or COMAND (A2-A40/3)
ACT0104	Erase customer-specific data	AUDIO-Audio or COMAND (A2-A40/3)
ACT0105	Speaker(Development data)	AUDIO-Audio or COMAND (A2-A40/3)
ACT0106	Init_NTG45	AUDIO-Audio or COMAND (A2-A40/3)
ACT0107	Self-test of mobile phone cradle	AUDIO-Audio or COMAND (A2-A40/3)
ACT0108	Perform control unit reset.	AUDIO-Audio or COMAND (A2-A40/3)
ACT0109	Restart MOST ring.	AUDIO-Audio or COMAND (A2-A40/3)
ACT0110	A1e52 (COLLISION PREVENTION ASSIST warning lamp)	CPA-Control unit 'COLLISION PREVENTION ASSIST' (A90)
ACT0111	Power supply of taximeter	Multifunction control unit-Multifunction control unit
ACT0112	Power supply (10.0A) for peripheral devices	Multifunction control unit-Multifunction control unit
ACT0113	Power supply (5.0A) for peripheral devices	Multifunction control unit-Multifunction control unit
ACT0114	Output ''Windshield heater''	Multifunction control unit-Multifunction control unit
ACT0115	Power supply of roof sign lamp	Multifunction control unit-Multifunction control unit
ACT0116	Power supply for flashing lights in trunk lid or liftgate	Multifunction control unit-Multifunction control unit
ACT0117	Power supply of two-way radio	Multifunction control unit-Multifunction control unit

ACT0118	Output ''Circuit 58''	Multifunction control unit-Multifunction control unit
ACT0119	Output ''Circuit 58d''	Multifunction control unit-Multifunction control unit
ACT0120	Output ''Circuit 15''	Multifunction control unit-Multifunction control unit
ACT0121	Output ''Status of taximeter''	Multifunction control unit-Multifunction control unit
ACT0122	Output for indicator lamp of roof sign main switch	Multifunction control unit-Multifunction control unit
ACT0123	Output for indicator lamp of button ''Two-way radio cut-in''	Multifunction control unit-Multifunction control unit
ACT0124	Output for indicator lamp of button ''Two-way radio main switch''	Multifunction control unit-Multifunction control unit
ACT0125	Output ''Radio help call''	Multifunction control unit-Multifunction control unit
ACT0126	Output ''Seat occupied recognition''	Multifunction control unit-Multifunction control unit
ACT0127	Output ''Status of buttons for horns''	Multifunction control unit-Multifunction control unit
ACT0128	Output ''Travel distance''	Multifunction control unit-Multifunction control unit
ACT0129	Activation Sound system	SG MSND-Engine sound
ACT0130	Deactivation Engine sound	SG MSND-Engine sound
ACT0131	KEYLESS GO system test	KG-KEYLESS GO (N69/5)
ACT0132	KEYLESS-GO key search	KG-KEYLESS GO (N69/5)
ACT0133	Actuation of fan	SOUND-Sound system
ACT0134	Lighting	SOUND-Sound system
ACT0135	Actuation of speakers	SOUND-Sound system
ACT0136	H4/73 (Right door midrange speaker)	SOUND-Sound system
ACT0137	H4/4h2 (Right rear woofer)	SOUND-Sound system

ACT0138	H4/29 (Woofer)	SOUND-Sound system
ACT0139	Left front speaker group	SOUND-Sound system
ACT0140	H4/2h2 (Right front door woofer)	SOUND-Sound system
ACT0141	H4/76 (Center instrument panel tweeter)	SOUND-Sound system
ACT0142	H4/54 (Left rear surround speaker)	SOUND-Sound system
ACT0143	H4/1h2 (Left front door woofer)	SOUND-Sound system
ACT0144	Right front speaker group	SOUND-Sound system
ACT0145	H4/57 (Right rear surround speaker)	SOUND-Sound system
ACT0146	H4/3 (Left rear speaker)	SOUND-Sound system
ACT0147	H4/35 (Center rear tweeter)/H4/77 (Center rear tweeter)	SOUND-Sound system
ACT0148	H4/72 (Left door midrange speaker)	SOUND-Sound system
ACT0149	H4/3h2 (Left rear woofer)	SOUND-Sound system
ACT0150	H4/4 (Right rear speaker)	SOUND-Sound system
ACT0151	1H4/29 (Woofer)-Solenoid 1	SOUND-Sound system
ACT0152	Solenoid 2 of speaker H4/29 (Woofer)-Solenoid 2	SOUND-Sound system
ACT0153	H4/77 (Center rear tweeter)	SOUND-Sound system
ACT0154	H4/1h1 (Left front door tweeter)	SOUND-Sound system
ACT0155	H4/2h1 (Right front door tweeter)	SOUND-Sound system
ACT0156	H4/23 (Left instrument panel speaker)	SOUND-Sound system
ACT0157	H4/24 (Right instrument panel speaker)	SOUND-Sound system

ACT0158	Electrical self-test of speakers	SOUND-Bose sound system
ACT0159	Control device	SOUND-Bose sound system
ACT0160	Test of microphone for sound system	SOUND-Bose sound system
ACT0161	H4/38 (Rear woofer)Solenoid 1	SOUND-Bose sound system
ACT0162	H4/38 (Rear woofer)Solenoid 2	SOUND-Bose sound system
ACT0163	H4/88 (Left door bass speaker)	SOUND-Bose sound system
ACT0164	H4/89 (Right door bass speaker)	SOUND-Bose sound system
ACT0165	H4/49 (Center rear speaker)	SOUND-Bose sound system
ACT0166	Fan self-test	SOUND-Bose sound system
ACT0167	Y51 (Left front axle damping valve unit)	ADS-Adaptive damping system (N51/5)
ACT0168	Y52 (Right front axle damping valve unit)	ADS-Adaptive damping system (N51/5)
ACT0169	Y53 (Left rear axle damping valve unit)	ADS-Adaptive damping system (N51/5)
ACT0170	Y54 (Right rear axle damping valve unit)	ADS-Adaptive damping system (N51/5)
ACT0171	M51/3m1 (Tailgate control electric motor)	HKS-Tailgate control
ACT0172	H4/60 (Liftgate control warning buzzer)	HKS-Tailgate control
ACT0173	Usage is only permissible in consultation with your hotline.	HKS-Tailgate control
ACT0174	Check signal line to component ''COMAND''.	TV-TV tuner
ACT0175	Check signal line to component ''AVE-H''.	TV-TV tuner
ACT0176	Wiring test of TV antennas	TV-TV tuner
ACT0177	Reception measurement for TV antennas by input of channel number	TV-TV tuner

ACT0178	Reception measurement for TV antennas by input of frequency	TV-TV tuner
ACT0179	Frequency of use of TV antennas	TV-TV tuner
ACT0180	Reset	TV-TV tuner
ACT0181	R50 (Auxiliary heater heating element)	MFK-Multifunction camera
ACT0182	A9 (Refrigerant compressor)	AAC-Automatic air conditioning
ACT0183	A9/5 (Electric refrigerant compressor)	AAC-Automatic air conditioning
ACT0184	Y19/3 (Evaporator shutoff valve)	AAC-Automatic air conditioning
ACT0185	A9y1 (Refrigerant compressor magnetic clutch)	AAC-Automatic air conditioning
ACT0186	M13/5 (Coolant circulation pump)	AAC-Automatic air conditioning
ACT0187	A32n1 (Blower regulator)	AAC-Automatic air conditioning
ACT0188	R22/3 (PTC heater booster)	AAC-Automatic air conditioning
ACT0189	N33/5 (High-voltage PTC heater)	AAC-Automatic air conditioning
ACT0190	M91/6 (Heater circuit circulation pump)	AAC-Automatic air conditioning
ACT0191	Rear windshield heater	AAC-Automatic air conditioning
ACT0192	Switch and controls illumination of component ''N22/7 (Automatic air conditioning control and operating unit)''	AAC-Automatic air conditioning
ACT0193	LEDs of component ''N22/7 (Automatic air conditioning control and operating unit)''	AAC-Automatic air conditioning
ACT0194	M2/5 (Fresh air/recirculated air flap actuator motor)	AAC-Automatic air conditioning
ACT0195	M2/4 (Central air distribution actuator motor)	AAC-Automatic air conditioning
ACT0196	M2/6 (Left blend air flap actuator motor)	AAC-Automatic air conditioning
ACT0197	M2/7 (Right blend air flap actuator motor)	AAC-Automatic air conditioning

ACT0198	Reception measurement	DAB-Digital Audio Broadcasting
ACT0199	Bit error rate	DAB-Digital Audio Broadcasting
ACT0200	Function check	STH-Stationary heater
ACT0201	Activation of stationary heater in test mode	STH-Stationary heater
ACT0202	Unlock component ''A6 (Stationary heater heater unit)''.	STH-Stationary heater
ACT0203	Teach in component ''A8/3 (Stationary heater radio remote control transmitter)''.	STH-Stationary heater
ACT0204	Display test	Drive Kit Plus-Drive kit for iPhone
ACT0205	HDMIInterface	Drive Kit Plus-Drive kit for iPhone
ACT0206	Test picture display	NAVI20-Navigation (N125/2)
ACT0207	Panoramic sliding sunroof	PSD-Control module 'Panoramic sliding roof ' (A98)
ACT0208	Roller sun blind	PSD-Control module 'Panoramic sliding roof ' (A98)
ACT0209	A76 (Left front reversible emergency tensioning retractor)	RevETR LF-Left front reversible emergency tensioning retractor
ACT0210	Display	HUD-Head up display
ACT0211	Display brightness	HUD-Head up display
ACT0212	Mirror glass	HUD-Head up display
ACT0213	A76/1 (Right front reversible emergency tensioning retractor)	RevETR RF-Right front reversible emergency tensioning retractor
ACT0214	M27/1 (Driver seat fore/aft adjustment motor)	ESV Driver-Electric seat adjustmnet Driver with memory function
ACT0215	M27/2 (Driver seat height adjustment motor)	ESV Driver-Electric seat adjustmnet Driver with memory function
ACT0216	M27/3 (Driver seat inclination adjustment motor)	ESV Driver-Electric seat adjustmnet Driver with memory function
ACT0217	M27/4 (Head restraint adjustment motor, driver seat)	ESV Driver-Electric seat adjustmnet Driver with memory function

ACT0218	M27/5 (Driver seat backrest inclination adjustment motor)	ESV Driver-Electric seat adjustmnet Driver with memory function
ACT0219	M27/8 (Seat adjustment motor, seat cushion length, driver seat)	ESV Driver-Electric seat adjustmnet Driver with memory function
ACT0220	Steering column adjustment	ESV Driver-Electric seat adjustmnet Driver with memory function
ACT0221	Test signal line of component ''A2/82 (Satellite Digital Audio Radio (SDAR) antenna)''.	SDAR-Satellite radio
ACT0222	Test signal line of component ''A28/11 (Multifunction antenna)''.	SDAR-Satellite radio
ACT0223	Self-test of control unit ''HD radio''	SDAR-Satellite radio
ACT0224	External feed and supply voltage	TB5-TV tuner Tuner unit
ACT0225	Signal quality	TB5-TV tuner Tuner unit
ACT0226	Signal level	TB5-TV tuner Tuner unit
ACT0227	Supply voltageAntenna amplifier	TB5-TV tuner Tuner unit
ACT0228	Signal/noise ratio	TV tuner (TV)
ACT0229	Reception field strength	TV tuner (TV)
ACT0230	M28/1 (Front passenger seat fore/aft adjustment motor)	ESV Front passenger-Electric seat adjustment Front passenger with memory function
ACT0231	M28/2 (Front passenger seat height adjustment motor)	ESV Front passenger-Electric seat adjustment Front passenger with memory function
ACT0232	M28/3 (Front passenger seat inclination adjustment motor)	ESV Front passenger-Electric seat adjustment Front passenger with memory function
ACT0233	M28/4 (Head restraint adjustment motor, front passenger seat)	ESV Front passenger-Electric seat adjustment Front passenger with memory function
ACT0234	M28/5 (Front passenger seat backrest inclination adjustment motor)	ESV Front passenger-Electric seat adjustment Front passenger with memory function
ACT0235	M28/8 (Seat adjustment motor, seat cushion length, front passenger seat)	ESV Front passenger-Electric seat adjustment Front passenger with memory function
ACT0236	Right turn signal	TRM-Trailer recognition module (N28/1)
ACT0237	Left turn signal	TRM-Trailer recognition module (N28/1)

ACT0238	Left taillamp	TRM-Trailer recognition module (N28/1)
ACT0239	Right taillamp	TRM-Trailer recognition module (N28/1)
ACT0240	Brake light	TRM-Trailer recognition module (N28/1)
ACT0241	Rear fog light	TRM-Trailer recognition module (N28/1)
ACT0242	Backup lamp	TRM-Trailer recognition module (N28/1)
ACT0243	Terminal 30G ''Trailer socket''	TRM-Trailer recognition module (N28/1)
ACT0244	Indicator lamp of switch ''S62/24''	TRM-Trailer recognition module (N28/1)
ACT0245	Indicator lamp of component ''A63''	TRM-Trailer recognition module (N28/1)
ACT0246	Switch and controls illumination of switch ''S62/24''	TRM-Trailer recognition module (N28/1)
ACT0247	Unlocking of trailer hitch	TRM-Trailer recognition module (N28/1)
ACT0248	Terminal 15G ''Trailer socket''	Trailer recognition module-Trailer recognition
ACT0249	Indicator lamp of switch ''S142/2''	Trailer recognition module-Trailer recognition
ACT0250	Switch and controls illumination of switch ''S142/2''	Trailer recognition module-Trailer recognition
ACT0251	Extension and retraction of trailer hitch	Trailer recognition module-Trailer recognition
ACT0252	Actuation of fuel pump	FSCU05-Control unit Fuel pump
ACT0253	Left outside mirror adjustment	LFD-Left front door
ACT0254	Left mirror heater	LFD-Left front door
ACT0255	Folding in/out of left outside mirror	LFD-Left front door
ACT0256	Mirror dimming	LFD-Left front door
ACT0257	Left memory function	LFD-Left front door

ACT0258	Blind Spot Assist	LFD-Left front door
ACT0259	Door handle illumination ''Left front door''	LFD-Left front door
ACT0260	Switch illumination ''Left front door''	LFD-Left front door
ACT0261	Turn signal lamp in left outside mirror	LFD-Left front door
ACT0262	LEDs	LFD-Left front door
ACT0263	Exit and warning lamp ''Left front door''	LFD-Left front door
ACT0264	E17/43 (Left front door ambiance illumination)	LFD-Left front door
ACT0265	Ambient illumination	LFD-Left front door
ACT0266	LED of switch ''Rear passenger compartment seat heater''	LFD-Left front door
ACT0267	Left front power window	LFD-Left front door
ACT0268	Denormalization of left front power window	LFD-Left front door
ACT0269	Central locking ''Left front door''	LFD-Left front door
ACT0270	Additional door lock ''Left front door''	LFD-Left front door
ACT0271	Start control unit reset.	LFD-Left front door
ACT0272	Right outside mirror adjustment	DCU RF-Right front door
ACT0273	Right mirror heater	DCU RF-Right front door
ACT0274	Folding in/out of right outside mirror	DCU RF-Right front door
ACT0275	Right memory function	DCU RF-Right front door
ACT0276	Door handle illumination ''Right front door''	DCU RF-Right front door
ACT0277	Switch illumination ''Right front door''	DCU RF-Right front door

ACT0278	Turn signal lamp in right outside mirror	DCU RF-Right front door
ACT0279	Exit and warning lamp ''Right front door''	DCU RF-Right front door
ACT0280	E17/44 (Right front door ambiance illumination)	DCU RF-Right front door
ACT0281	Right front power window	DCU RF-Right front door
ACT0282	Denormalization of right front power window	DCU RF-Right front door
ACT0283	Central locking ''Right front door''	DCU RF-Right front door
ACT0284	Additional door lock ''Right front door''	DCU RF-Right front door
ACT0285	Electric parking brake	EFB-Electronic parking brake(N128)
ACT0286	M76/1 (Left electric parking brake actuator motor)	EFB-Electronic parking brake(N128)
ACT0287	M76/2 (Right electric parking brake actuator motor)	EFB-Electronic parking brake(N128)
ACT0288	Move to the assembly position	EFB-Electronic parking brake(N128)
ACT0289	Symbol illuminationA40/9 (Audio/COMAND control panel)	COU-Audio/COMAND operating unit (A40/9)
ACT0290	Display in ''SERVICE'' position	ZAN-Audio/COMAND display
ACT0291	Brightness	ZAN-Audio/COMAND display
ACT0292	Headlamp range adjustment	SG SW-Control unit 'Headlamp' (N71/1)
ACT0293	Active curve illumination	SG SW-Control unit 'Headlamp' (N71/1)
ACT0294	Intelligent Light System	SG SW-Control unit 'Headlamp' (N71/1)
ACT0295	Cornering illumination	SG SW-Control unit 'Headlamp' (N71/1)
ACT0296	High beams	SG SW-Control unit 'Headlamp' (N71/1)
ACT0297	Active curve illumination with steering angle	SG SW L-Left headlamp

ACT0298	Intelligent light spread	SG SW L-Left headlamp
ACT0299	LED exterior lights	SG SW L-Left headlamp
ACT0300	Fan	SG SW L-Left headlamp
ACT0301	Interior lamp	OCP-Control unit 'Overhead control panel'
ACT0302	Reading lamps	OCP-Control unit 'Overhead control panel'
ACT0303	Rear lamp	OCP-Control unit 'Overhead control panel'
ACT0304	Mirror lamps of sun visors	OCP-Control unit 'Overhead control panel'
ACT0305	Warning indicator ''front parking system''	PARK-Parking system (N62)
ACT0306	Warning indicator ''rear parking system''	PARK-Parking system (N62)
ACT0307	Actuation of function ''Illumination''	DSI-DIRECT SELECT interface (N150)
ACT0308	Y68/3 (All-wheel drive solenoid valve)	VG-All wheel drive
ACT0309	Actuate component ''H3/1 (Alarm siren)''.	AS-Alarm siren (H3/1)
ACT0310	N42 (Camera cover control unit)	KAB-Control unit Camera cover
ACT0311	Self-test of control unit ''N42 (Camera cover control unit)''	KAB-Control unit Camera cover
ACT0312	Valve flushing	DKG-Electronic transmission control for double-plate clutch transmission
ACT0313	Workshop test	DKG-Electronic transmission control for double-plate clutch transmission
ACT0314	Coolant pump actuation	DKG-Electronic transmission control for double-plate clutch transmission
ACT0315	Test of park pawl	DKG-Electronic transmission control for double-plate clutch transmission
ACT0316	Self-test of system ''Differential lock''	DKG-Electronic transmission control for double-plate clutch transmission
ACT0317	Oil level check	DKG-Electronic transmission control for double-plate clutch transmission

ACT0318	Shift transmission to neutral position.	DKG-Electronic transmission control for double-plate clutch transmission
ACT0319	Tests for fault code	DKG-Electronic transmission control for double-plate clutch transmission
ACT0320	Empty fuel tank.	FSCU-Fuel pump
ACT0321	M16/46 (Low-pressure exhaust gas recirculation actuator motor)	N127 (Drivetrain control unit)
ACT0322	R39/2 (Wide open throttle operation vent line heating element)	N3/10-Motor electronics ''MED40'' for combustion engine ''M274''
ACT0323	Y49/1 (Intake camshaft solenoid)	N3/10-Motor electronics ''MED40'' for combustion engine ''M274''
ACT0324	Y49/2 (Exhaust camshaft solenoid)	N3/10-Motor electronics ''MED40'' for combustion engine ''M274''
ACT0325	Y58/1 (Purging switchover valve)	N3/10-Motor electronics ''MED40'' for combustion engine ''M274''
ACT0326	Y58/4 (Activated charcoal canister shutoff valve)	N3/10-Motor electronics ''MED40'' for combustion engine ''M274''
ACT0327	Y31/5 (Boost pressure control pressure transducer)	N3/10-Motor electronics ''MED40'' for combustion engine ''M274''
ACT0328	Y94 (Quantity control valve)	N3/10-Motor electronics ''MED40'' for combustion engine ''M274''
ACT0329	Y101 (Deceleration air switchover valve)	N3/10-Motor electronics ''MED40'' for combustion engine ''M274''
ACT0330	A1e58 (Engine diagnosis indicator lamp)	N3/10-Motor electronics ''MED40'' for combustion engine ''M274''
ACT0331	Mixture formation	N3/10-Motor electronics ''MED40'' for combustion engine ''M274''
ACT0332	Rail pressure reduction	N3/10-Motor electronics ''MED40'' for combustion engine ''M274''
ACT0333	Y49/8 (Intake camshaft valve lift switching actuator)	N3/10-Motor electronics ''MED40'' for combustion engine ''M274''
ACT0334	Exhaust gas recirculation	N3/10-Motor electronics ''MED40'' for combustion engine ''M274''
ACT0335	M44 (charge air cooler circulation pump)	N3/10-Motor electronics ''MED40AMG'' for combustion engine ''M133''
ACT0336	A92/3r1 (Fuel filter heater heating element)	CDI-Engine Electronics CRR2 for Internal Combustion Engine OM608
ACT0337	Notes on actuations of component parts in other control units	CDI-Engine Electronics CRR2 for Internal Combustion Engine OM608

ACT0338	Y100/2 (Boost pressure control pressure transducer)	N3/40-Motor electronics ''MRD1'' for combustion engine ''OM654''
ACT0339	Y77 (Wastegate pressure transducer)	N3/40-Motor electronics ''MRD1'' for combustion engine ''OM654''
ACT0340	Actuation of components ''Y100/2 (Boost pressure control pressure transducer)'', ''Y77 (Wastegate pressure	N3/40-Motor electronics ''MRD1'' for combustion engine ''OM654''
ACT0341	CAMTRONIC	N3/40-Motor electronics ''MRD1'' for combustion engine ''OM654''
ACT0342	Setting Mirror glass Left	LFD-Left front door
ACT0343	Mirror dimming Left	LFD-Left front door
ACT0344	Switch and controls illumination	LFD-Left front door
ACT0345	Warning lamp ''Blind Spot Assist''	LFD-Left front door
ACT0346	Ambient illumination ''Left outside mirror''	LFD-Left front door
ACT0347	External door handle illumination	LFD-Left front door
ACT0348	LED of switch ''Child safety lock''	LFD-Left front door
ACT0349	LED of switch ''Mirror selection''	LFD-Left front door
ACT0350	LED of switch ''Left front seat ventilation''	LFD-Left front door
ACT0351	LED of switch ''Left front seat heater''	LFD-Left front door
ACT0352	LED ''SwitchesRefueling safety detection''	LFD-Left front door
ACT0353	Setting Mirror glass Right	DCU RF-Right front door
ACT0354	Mirror dimming Right	DCU RF-Right front door
ACT0355	Switch and controls illumination Switches	DCU RF-Right front door
ACT0356	Warning lamp Blind Spot Assist	DCU RF-Right front door
ACT0357	Ambient illumination ''Right outside mirror''	DCU RF-Right front door

ACT0358	LED of switch ''Right front seat ventilation''	DCU RF-Right front door
ACT0359	LED of switch ''Right front seat heater''	DCU RF-Right front door
ACT0360	Central locking ''Left rear door''	DCU LR-Left rear door
ACT0361	Additional door lock ''Left rear door''	DCU LR-Left rear door
ACT0362	Left rear power window	DCU LR-Left rear door
ACT0363	Denormalization of left rear power window	DCU LR-Left rear door
ACT0364	LED of switch ''Left rear heated seat''	DCU LR-Left rear door
ACT0365	LED of switch ''Right rear seat ventilation''	DCU LR-Left rear door
ACT0366	Switch and controls illuminationSwitches	DCU LR-Left rear door
ACT0367	Central locking ''Right rear door''	DCU RR-Right rear door
ACT0368	Additional door lock ''Right rear door''	DCU RR-Right rear door
ACT0369	Right rear power window	DCU RR-Right rear door
ACT0370	Denormalization of right rear power window	DCU RR-Right rear door
ACT0371	LED of switch ''Right rear heated seat''	DCU RR-Right rear door
ACT0372	Switch and controls illumination of component ''S2/2 (Start/stop button with ECO start/stop function button)''	EZS-Electronic ignition switch
ACT0373	M27/10 (Seat adjustment motor, seat height adjustment, driver seat)	ESV Driver-Electric seat adjustmnet Driver
ACT0374	M27/9 (Seat inclination adjustment motor, driver seat)	ESV Driver-Electric seat adjustmnet Driver
ACT0375	M27/8 (Seat cushion length adjustment motor, driver seat)	ESV Driver-Electric seat adjustmnet Driver
ACT0376	M20/2 (Steering column up/down adjustment motor)	ESV Driver-Electric seat adjustmnet Driver
ACT0377	M20/1 (Steering column in/out adjustment motor)	ESV Driver-Electric seat adjustmnet Driver

ACT0378	M28/10 (Seat adjustment motor, seat height adjustment, front passenger seat)	ESA Front passenger-Electric seat adjustment Front passenger
ACT0379	M28/9 (Seat inclination adjustment motor, front passenger seat)	ESA Front passenger-Electric seat adjustment Front passenger
ACT0380	M28/8 (Seat cushion length adjustment motor, front passenger seat)	ESA Front passenger-Electric seat adjustment Front passenger
ACT0381	M104 (Footrest adjustment actuator motor)	ESA Front passenger-Electric seat adjustment Front passenger
ACT0382	M86 (Screen adjustment actuator motor)	ESA Front passenger-Electric seat adjustment Front passenger
ACT0383	Actuation of air cushion of upper lumbar support	MKS LF-Left front multicontour seat
ACT0384	Actuation of air cushion of lower lumbar support	MKS LF-Left front multicontour seat
ACT0385	Actuation of air cushion ''Seat side bolsters of sitting surface''	MKS LF-Left front multicontour seat
ACT0386	Actuation of air cushions in seat side bolsters	MKS LF-Left front multicontour seat
ACT0387	Actuation of air cushion of left seat side bolster	MKS LF-Left front multicontour seat
ACT0388	Actuation of air cushion of right seat side bolster	MKS LF-Left front multicontour seat
ACT0389	LIN bus1:Driver door	AML-Ambiance light
ACT0390	LIN bus2:Passenger door	AML-Ambiance light
ACT0391	LIN bus3:Left rear door	AML-Ambiance light
ACT0392	LIN bus4:Right rear door	AML-Ambiance light
ACT0393	LIN bus5:Instrument cluster,Center console	AML-Ambiance light
ACT0394	LIN bus6:Midrange speaker	AML-Ambiance light
ACT0395	LIN bus7:Instrument panel, Footwell, Cup holder in center console	AML-Ambiance light
ACT0396	All	AML-Ambiance light
ACT0397	Pointer	IC-Instrument cluster

ACT0398	H4/61 (Instrument cluster speaker)	IC-Instrument cluster
ACT0399	Instrument illumination	IC-Instrument cluster
ACT0400	Warning message	IC-Instrument cluster
ACT0401	ActuatorDifferential lock	AMG DRVU-AMG DRIVE UNIT
ACT0402	Lower control panelCenter console	AMG DRVU-AMG DRIVE UNIT
ACT0403	N170 (Rear wing control unit)	AMG DRVU-AMG DRIVE UNIT
ACT0404	AMGAmbient illumination	AMG DRVU-AMG DRIVE UNIT
ACT0405	Indicator lamp ''Green'' of component ''X58/23 (Charger feed-in socket)''	SG LG-Charger
ACT0406	Indicator lamp ''Red'' of component ''X58/23 (Charger feed-in socket)''	SG LG-Charger
ACT0407	Indicator lamp ''White'' of component ''X58/23 (Charger feed-in socket)''	SG LG-Charger
ACT0408	Locking or unlocking of charging cable on component ''X58/23 (Charger feed-in socket)''	SG LG-Charger
ACT0409	Locking/unlocking of exterior socket flap of vehicle socket	SG LG-Charger
ACT0410	High-voltage component lock	SG LG-Charger
ACT0411	Left front seat heater	''Driver'' seat heater
ACT0412	Right front seat heater	''Driver'' seat heater
ACT0413	Left front seat ventilation	''Driver'' seat heater
ACT0414	Right front seat ventilation	''Driver'' seat heater
ACT0415	Enabling of function ''Seat heater''	''Driver'' seat heater
ACT0416	Blower	AAC-Automatic air conditioning
ACT0417	A9/7y2 (Refrigerant compressor magnetic clutch)	AAC-Automatic air conditioning

ACT0418	Erasing of all taught-in radio remote control transmitters	TSTH-Radio remote control of stationary heater
ACT0419	S6/1s1 (Steering-Pilot button)	SGR-Radar sensors control unit
ACT0420	S6/1s2 (Lane Keeping Assist button)	SGR-Radar sensors control unit
ACT0421	360?camera	PTS-PARKTRONIC
ACT0422	Self-test of system ''Clutch''	VG-All-wheel drive
ACT0423	Function test of component ''Transfer case''	VG-All-wheel drive
ACT0424	A103/2m1 (AdBlue?delivery pump)	SCR-Selective catalytic reduction
ACT0425	A103/1r1 (AdBlue?tank heating element)	SCR-Selective catalytic reduction
ACT0426	R7/1 (AdBlue?pressure line heating element)	SCR-Selective catalytic reduction
ACT0427	Y129 (AdBlue?metering valve)	SCR-Selective catalytic reduction
ACT0428	Evacuation of pressure line of system ''AdBlue?'	SCR-Selective catalytic reduction
ACT0429	Bleeding of system ''AdBlue?'	SCR-Selective catalytic reduction
ACT0430	M4/16 (Engine oil cooler fan motor)	N127 (Drivetrain control unit)
ACT0431	M16/53 (Left exhaust flap actuator motor)	N127 (Drivetrain control unit)
ACT0432	M16/54 (Right exhaust flap actuator motor)	N127 (Drivetrain control unit)
ACT0433	M16/55 (Center exhaust flap actuator motor)	N127 (Drivetrain control unit)
ACT0434	M43/7 (Low temperature circuit circulation pump 2)	N127 (Drivetrain control unit)
ACT0435	M43/8 (Low-temperature circuit circulation pump 3)	N127 (Drivetrain control unit)
ACT0436	Y73/1 (Low-temperature circuit switchover valve)	N127 (Drivetrain control unit)
ACT0437	Y73/2 (Low-temperature circuit switchover valve 2)	N127 (Drivetrain control unit)

ACT0438	Y110 (High-voltage battery cooling system expansion valve)	N127 (Drivetrain control unit)
ACT0439	Y140 (High-voltage battery cooling system switchover valve)	N127 (Drivetrain control unit)
ACT0440	M2/37 (Radiator trim flap actuator motor)	N127 (Drivetrain control unit)
ACT0441	M87 (Radiator shutters actuator motor)	N127 (Drivetrain control unit)
ACT0442	M2/38 (Upper radiator trim flap actuator motor)	N127 (Drivetrain control unit)
ACT0443	M2/39 (Lower radiator trim flap actuator motor)	N127 (Drivetrain control unit)
ACT0444	Check power consumption of component ''M43/6 (Low temperature circuit circulation pump 1)'' via actual value.	N127 (Drivetrain control unit)
ACT0445	M43/6 (Low temperature circuit circulation pump 1) (MFA2)	N127 (Drivetrain control unit)
ACT0446	Check power consumption of component ''M43/7 (Low temperature circuit circulation pump 2)'' via actual value.	N127 (Drivetrain control unit)
ACT0447	M43/7 (Low temperature circuit circulation pump 2) (MFA2)	N127 (Drivetrain control unit)
ACT0448	Check power consumption of component ''M43/8 (Low-temperature circuit circulation pump 3)'' via actual value.	N127 (Drivetrain control unit)
ACT0449	M108/1 (Engine cooling air flap left actuator motor)	N127 (Drivetrain control unit)
ACT0450	M108/2 (Engine cooling air flap right actuator motor)	N127 (Drivetrain control unit)
ACT0451	Lock high-voltage component lock.	SG EM-Power electronics
ACT0452	Unlock high-voltage component lock.	SG EM-Power electronics
ACT0453	Signal generator for interlock circuit	BMS-Battery management system
ACT0454	Contactors of high-voltage battery	BMS-Battery management system
ACT0455	Isolation measurement	BMS-Battery management system
ACT0456	M16/7 (Boost pressure control flap actuator)	N3/10-Motor electronics ''EM71'' for combustion engine ''M282''
ACT0457	Shift operation(CAMTRONIC)	N3/10-Motor electronics ''EM71'' for combustion engine ''M282''

ACT0458	High fuel pressure	N3/10-Motor electronics ''EM71'' for combustion engine ''M282''
ACT0459	M43/4 (Starter-alternator coolant pump)	N3/10-Motor electronics ''MED41'' for combustion engine ''M260/M264''
ACT0460	M75/11 (Electric coolant pump)	N3/10-Motor electronics ''MED41'' for combustion engine ''M260/M264''
ACT0461	Y58/2 (Partial load operation crankcase ventilation valve)	N3/10-Motor electronics ''MED41'' for combustion engine ''M260/M264''
ACT0462	Y58/9 ((Fuel tank bleed valve))	N3/10-Motor electronics ''MRG1AMGR4'' for combustion engine ''M139''
ACT0463	Y49/4 (Left intake camshaft solenoid)	N3/10-Motor electronics ''MRG1AMGR4'' for combustion engine ''M139''
ACT0464	Y49/6 (Left exhaust camshaft solenoid)	N3/10-Motor electronics ''MRG1AMGR4'' for combustion engine ''M139''
ACT0465	Erase alarm sources.	AS-Alarm siren(H3/1)
ACT0466	Check battery of component ''H3/1 (Alarm siren)''.	AS-Alarm siren(H3/1)
ACT0467	Y32 (Air pump switchover valve)M33 (electric air pump) (EURO 3	ME 9.7-Motor electronics 9.7
ACT0468	Y62 (Fuel injectors)	ME 9.7-Motor electronics 9.7
ACT0469	Y58/1 (Purge control valve)	ME 9.7-Motor electronics 9.7
ACT0470	Y58/4 (Activated charcoal canister shut-off valve)	ME 9.7-Motor electronics 9.7
ACT0471	Mixture adaptation	ME 9.7-Motor electronics 9.7
ACT0472	M4/7 (Engine and AC electric suction fan with integrated control)	ME 9.7-Motor electronics 9.7
ACT0473	Fuel tank leak test	ME 9.7-Motor electronics 9.7
ACT0474	Y22/6 (variable intake manifold switchover valve)	ME 9.7-Motor electronics 9.7
ACT0475	Y49/5 (Right camshaft intake solenoid)	ME 9.7-Motor electronics 9.7
ACT0476	Y49/4 (Left camshaft intake solenoid)	ME 9.7-Motor electronics 9.7
ACT0477	Y49/7 (Right camshaft exhaust solenoid)	ME 9.7-Motor electronics 9.7

ACT0478	Y49/6 (Left camshaft exhaust solenoid)	ME 9.7-Motor electronics 9.7
ACT0479	Y110 (Three-disk thermostat valve)	ME 9.7-Motor electronics 9.7
ACT0480	Y16/2 (Heating system shutoff valve)	ME 9.7-Motor electronics 9.7
ACT0481	Alternator diagnosis	ME 9.7-Motor electronics 9.7
ACT0482	BAS Brake assist in ESP Electronic Stability Program	ESP-Electronic stability program
ACT0483	PML speed-sensitive power steering	ESP-Electronic stability program
ACT0484	Road test	ESP-Electronic stability program
ACT0485	Actuation of the instrument pointer up to the maximum position	IC-Instrument cluster
ACT0486	Actuate light warning buzzer	IC-Instrument cluster
ACT0487	Display test images on the LCD display	IC-Instrument cluster
ACT0488	Bulb test	IC-Instrument cluster
ACT0489	Shift transfer case.	VG-Transfer case
ACT0490	Gear selector switch position	ISM-Intelligent servo module
ACT0491	Actuation of actuator motor in position P R N D	ISM-Intelligent servo module
ACT0492	Charging of spring accumulator	ISM-Intelligent servo module
ACT0493	Control unit back in normal mode	ISM-Intelligent servo module
ACT0494	Move transmission into Neutral position.	ISM-Intelligent servo module
ACT0495	Actuation of actuator motor in position P R N D	ISM-Shift module
ACT0496	Release pressure in central reservoir.	Suspension
ACT0497	Fill central reservoir.	Suspension

ACT0498	Left front damper valves	Suspension
ACT0499	Right front damper valves	Suspension
ACT0500	Left rear damper valves	Suspension
ACT0501	Right rear damper valves	Suspension
ACT0502	Move toward calibrated level (automatic).	Suspension
ACT0503	Move toward calibrated level (manually).	Suspension
ACT0504	Rear lighting	OCP-Overhead control panel
ACT0505	Left reading lamp	OCP-Overhead control panel
ACT0506	Right reading lamp	OCP-Overhead control panel
ACT0507	Switch illumination	OCP-Overhead control panel
ACT0508	Vanity mirror illumination	OCP-Overhead control panel
ACT0509	Function illumination	UCP-Upper control panel
ACT0510	Terminal 58d	HBF-Rear control field
ACT0511	Function illumination Dynamic test	HBF-Rear control field
ACT0512	All front exterior lights	SAM F-Signal acquisition and actuation module front
ACT0513	Windshield washer pump (Front)	SAM F-Signal acquisition and actuation module front
ACT0514	Windshield washer pump (Rear)	SAM F-Signal acquisition and actuation module front
ACT0515	Headlamp cleaning system	SAM F-Signal acquisition and actuation module front
ACT0516	Terminal 15	SAM F-Signal acquisition and actuation module front
ACT0517	Denormalize rear left power window	SAM F-Signal acquisition and actuation module front

ACT0518	Denormalize rear right power window	SAM F-Signal acquisition and actuation module front
ACT0519	Central locking (Left rear door)	SAM F-Signal acquisition and actuation module front
ACT0520	Charge line to additional battery	SAM F-Signal acquisition and actuation module front
ACT0521	Denormalizing of left front power window	DCM FL-Door control module front left
ACT0522	Mirror lens adjustment	DCM FL-Door control module front left
ACT0523	Mirror heater	DCM FL-Door control module front left
ACT0524	Switch illumination (Terminal 58d)	DCM FL-Door control module front left
ACT0525	E6/5 (Left exterior mirror turn signal lamp)	DCM FL-Door control module front left
ACT0526	E17/3 (Left front door entry/exit lamp)	DCM FL-Door control module front left
ACT0527	M21/1e1 (Left outside mirror ambient lamp)	DCM FL-Door control module front left
ACT0528	Denormalizing of right front power window	DCM FR-Door control module front right
ACT0529	E6/6 (Right exterior mirror turn signal lamp)	DCM FR-Door control module front right
ACT0530	E17/4 (Right front door entry/exit lamp)	DCM FR-Door control module front right
ACT0531	M21/2e1 (Right outside mirror ambient lamp)	DCM FR-Door control module front right
ACT0532	Inflatable cushion for lateral support	DS LF-Left front dynamic seat
ACT0533	Top inflatable cushion in lumbar region	DS LF-Left front dynamic seat
ACT0534	Bottom inflatable cushion in lumbar region	DS LF-Left front dynamic seat
ACT0535	Function lighting in switch S109s1 (Left front PULSE switch)	DS LF-Left front dynamic seat
ACT0536	Function lighting in switch S109/1 (Left front DYNAMIC switch)	DS LF-Left front dynamic seat
ACT0537	Function lighting in switch S108s1 (Right front PULSE switch)	DS RF-Right front dynamic seat

ACT0538	Function lighting in switch S108/1 (Right front DYNAMIC switch)	DS RF-Right front dynamic seat
ACT0539	Release actuators	ERA-Electric fold-down backrest system (3rd seat row)
ACT0540	Actuations	SCM [MRM]-Steering column module
ACT0541	Denormalization of the rear-end door closing system	REDC-Rear end door closing control module
ACT0542	Actuation of the rear-end door closing system	REDC-Rear end door closing control module
ACT0543	Actuation of warning buzzer	REDC-Rear end door closing control module
ACT0544	Actuation of switch and controls illumination	REDC-Rear end door closing control module
ACT0545	Left seat heater	HS-Seat heater
ACT0546	Right seat heater	HS-Seat heater
ACT0547	Left rear heated seat	HS-Seat heater
ACT0548	Right rear heated seat	HS-Seat heater
ACT0549	Headlamp range adjustment of left headlamp	XALWA L-Xenon headlamp, left
ACT0550	Headlamp range adjustment of left and right headlamps	XALWA L-Xenon headlamp, left
ACT0551	Curve illumination of left headlamp	XALWA L-Xenon headlamp, left
ACT0552	Curve illumination of left and right headlamps	XALWA L-Xenon headlamp, left
ACT0553	Headlamp range adjustment of right headlamp	XALWA R-Xenon headlamp, right
ACT0554	Curve illumination of right headlamp	XALWA R-Xenon headlamp, right
ACT0555	M2/5 (Fresh and recirculated air flaps actuator)	AAC-Automatic air conditioning
ACT0556	M2/12 (Rear shutoff flap positioning motor)	AAC-Automatic air conditioning
ACT0557	M2/21 (Rear air distribution flap positioning motor)	AAC-Automatic air conditioning

ACT0558	A32ml (Blower motor)	AAC-Automatic air conditioning
ACT0559	Electric suction fan	AAC-Automatic air conditioning
ACT0560	Illumination of pushbutton control module	AAC-Automatic air conditioning
ACT0561	AC compressor	AAC-Automatic air conditioning
ACT0562	M13 (Heating water circulation pump)	AAC-Automatic air conditioning
ACT0563	Closing air recirculation flap (for cleaning)	AAC-Automatic air conditioning
ACT0564	Heated steering wheel	LRH-Steering wheel heater
ACT0565	Switch on stationary heater (normal mode).	STH-Stationary heater with remote control
ACT0566	Switch on stationary heater (test mode).	STH-Stationary heater with remote control
ACT0567	Heating/Switch on ventilation in line with the request from the AC pushbutton control module.	STH-Stationary heater with remote control
ACT0568	Selftest of control module Left rear screen	Left rear screen
ACT0569	Output of test tone(Test of headphones output)	Left rear screen
ACT0570	Display test images on the LCD display. (Left rear screen)	Left rear screen
ACT0571	Output of audio and video signal from CD/DVD drive on control unit 'Left rear screen'.	Left rear screen
ACT0572	Output of audio and video signal from AUX jack on control unit 'Left rear screen'.	Left rear screen
ACT0573	Selftest of control module Right rear screen	Right rear screen
ACT0574	Display test images on the LCD display. (Right rear screen)	Right rear screen
ACT0575	Output of audio and video signal from CD/DVD drive on control unit 'Right rear screen'.	Right rear screen
ACT0576	Output of audio and video signal from AUX jack on control unit 'Right rear screen'.	Right rear screen
ACT0577	M13/7 (Transmission oil cooler circulation pump)	CDI 6-Common Rail Diesel Injection

ACT0578	M55 (Inlet port shutoff motor)	CDI 6-Common Rail Diesel Injection
ACT0579	R39/1 (Vent line heater element)	CDI 6-Common Rail Diesel Injection
ACT0580	Y27/9 (Left EGR positioner)	CDI 6-Common Rail Diesel Injection
ACT0581	AdBlue reversing valve	SCR-Selective Catalytic Reduction
ACT0582	AdBlue delivery pump	SCR-Selective Catalytic Reduction
ACT0583	Heating	SCR-Selective Catalytic Reduction
ACT0584	AdBlue metering valve	SCR-Selective Catalytic Reduction
ACT0585	AdBlue(R) return flow	SCR-Selective Catalytic Reduction
ACT0586	G3/2 (O2 sensor upstream of KAT)	CDI 60LS-Common Rail Diesel Injection
ACT0587	N14/3 (Glow time output stage)	CDI 60LS-Common Rail Diesel Injection
ACT0588	Y85 (EGR [AGR] cooler bypass flap switchover valve)	CDI 60LS-Common Rail Diesel Injection
ACT0589	Check component ''Fuel filter heater''.	N3/9-Motor electronics ''CR43'' for combustion engine ''OM651''
ACT0590	Switchable engine mountsY123 (Left switchable engine mount)Y123/1 (Right switchable engine mount)	N3/9-Motor electronics ''CDI60LS'' for combustion engine ''OM642''
ACT0591	Perform diagnostic glowing.	N3/9-Motor electronics ''CDI60LS'' for combustion engine ''OM642''
ACT0592	Switch off incline recognition for dynamometer mode.	Y3/8n4-Fully integrated transmission control
ACT0593	Closing of torque converter lockup clutch	Y3/8n4-Transmission control for 9 speed transmission
ACT0594	A103/2y1 (AdBlue?switchover valve)	SCR-Selective Catalytic Reduction
ACT0595	AdBlue?delivery pump	SCR-Selective Catalytic Reduction
ACT0596	Dynamic test of component ''A103/2ml (AdBlue?delivery pump)''	SCR-Selective Catalytic Reduction
ACT0597	AdBlue?return	SCR-Selective Catalytic Reduction

ACT0598	Visual leak test	SCR-Selective Catalytic Reduction
ACT0599	Test of AdBlue?metering amount	SCR-Selective Catalytic Reduction
ACT0600	A103/1r2 (AdBlue?pressure line heating element)	SCR-Selective Catalytic Reduction
ACT0601	A103/2r1 (AdBlue?delivery module heating element)	SCR-Selective Catalytic Reduction
ACT0602	A103/2m2 (AdBlue?extraction pump)	SCR-Selective catalytic reduction
ACT0603	Isolation measurement with open contactors-Relay ''OPEN''	BMS-Battery management system(N82/2)
ACT0604	Battery capacity/Determination of status of high-voltage battery	BMS-Battery management system(N82/2)
ACT0605	Self-test of control unit ''DVD player''	AVE H-Rear audio video unit
ACT0606	Output of an audio and video signal from control unit ''COMAND'' on the displays in the rear passenger compartment	AVE H-Rear audio video unit
ACT0607	Output of an audio and video signal from the DVD player on the displays in the rear passenger compartment	AVE H-Rear audio video unit
ACT0608	Output of an audio and video signal from the AUX jack on the displays in the rear passenger compartment	AVE H-Rear audio video unit
ACT0609	Actuator control	TPAD-Touchpad
ACT0610	Calibration of touch-sensitive surface	TPAD-Touchpad
ACT0611	Locking/unlocking of socket flap	SG LG-Charger
ACT0612	M56 (Vacuum pump)	ESP-Regenerative braking system(N30/6)
ACT0613	Actuation of pneumatic pump	PPAMKS-Pneumatic pump for active multicontour seat
ACT0614	Clear fault memory	PPAMKS-Pneumatic pump for active multicontour seat
ACT0615	Check overall system for leaktightness and compressed air supply.	PPAMKS-Pneumatic pump for active multicontour seat
ACT0616	M40 (Multicontour seat pneumatic pump)	PPAMKS-Pneumatic pump for multicontour seat
ACT0617	M40/1 (Dynamic multicontour seat pneumatic pump)	PPAMKS-Pneumatic pump for multicontour seat

ACT0618	M40/1 (Active multicontour seat pneumatic pump)	PPAMKS-Pneumatic pump for multicontour seat
ACT0619	Compressed air valveDRAINING	PPAMKS-Pneumatic pump for multicontour seat
ACT0620	Actuation of air cushion ''Seat cushion length''	MKS LF-Left front multicontour seat
ACT0621	ActuationM25/8 (Left front multicontour seat pneumatic pump)	MKS LF-Left front multicontour seat
ACT0622	Check compressed air line between control unit ''N32/29 (Driver multicontour seat control unit)'' and air cushion for	MKS LF-Left front multicontour seat
ACT0623	Check compressed air line between control unit ''N32/30 (Front passenger multicontour seat control unit)'' and air cushion	MKS LF-Left front multicontour seat
ACT0624	360 deg C camera	CAMERA-360 camera (N148)
ACT0625	ActuationM25/9 (Right front multicontour seat pneumatic pump)	MKS RF-Right front multicontour seat
ACT0626	Calibration of microphone for sound system	SOUND-Bose sound system
ACT0627	Y36/6y5 (AIRMATIC central reservoir filling valve)	ADS-Adaptive damping system (N51/5)
ACT0628	A9/1y1 (AIRMATIC pressure relief valve)	ADS-Adaptive damping system (N51/5)
ACT0629	K67 (AIRMATIC relay)	ADS-Adaptive damping system (N51/5)
ACT0630	Move to calibrated vehicle level (automatically).	ADS-Adaptive damping system (N51/5)
ACT0631	Move to calibrated vehicle level (manually).	ADS-Adaptive damping system (N51/5)
ACT0632	Y36/6y1 (Left front level control valve)	ADS-Adaptive damping system (N51/5)
ACT0633	Y36/6y2 (Right front level control valve)	ADS-Adaptive damping system (N51/5)
ACT0634	Y36/6y3 (Left rear level control valve)	ADS-Adaptive damping system (N51/5)
ACT0635	Y36/6y4 (Right rear level control valve)	ADS-Adaptive damping system (N51/5)
ACT0636	Left front suspension strut	ADS-Adaptive damping system (N51/5)
ACT0637	Right front suspension strut	ADS-Adaptive damping system (N51/5)

ACT0638	Right rear suspension strut	ADS-Adaptive damping system(N51/5)
ACT0639	Left rear suspension strut	ADS-Adaptive damping system(N51/5)
ACT0640	F58kT (AIRmatic relay)	ADS-Adaptive damping system(N51/5)
ACT0641	Erase fault memory.	TV-TV tuner
ACT0642	F4kB (Rear window heater relay)	AAC-Automatic air conditioning
ACT0643	F58kS (Wiper park position heater relay)	AAC-Automatic air conditioning
ACT0644	N29 (Electronic blower regulator)	AAC-Automatic air conditioning
ACT0645	N29/8 (Booster blower electronic blower controller)	AAC-Automatic air conditioning
ACT0646	N29/2 (Rear air conditioning electronic blower regulator)	AAC-Automatic air conditioning
ACT0647	M2/8 (Left defroster flap actuator motor)	AAC-Automatic air conditioning
ACT0648	M2/9 (Right defroster flap actuator motor)	AAC-Automatic air conditioning
ACT0649	M2/10 (Left footwell flap actuator motor)	AAC-Automatic air conditioning
ACT0650	M2/11 (Right footwell flap actuator motor)	AAC-Automatic air conditioning
ACT0651	M2/21 (Rear actuator motor blend air flap with shutoff function)	AAC-Automatic air conditioning
ACT0652	M2/35 (Rear air distribution flap actuator motor)	AAC-Automatic air conditioning
ACT0653	M2/12 (Left center air vent flap actuator motor)	AAC-Automatic air conditioning
ACT0654	M2/13 (Right center air vent flap actuator motor)	AAC-Automatic air conditioning
ACT0655	M16/33 (Left B-pillar air distribution actuator motor)	AAC-Automatic air conditioning
ACT0656	M16/34 (Right B-pillar air distribution actuator motor)	AAC-Automatic air conditioning
ACT0657	M2/16 (Defroster flap actuator motor)	AAC-Automatic air conditioning

ACT0658	M2/22 (Center vent flap positioning motor)	AAC-Automatic air conditioning
ACT0659	M2/15 (Footwell flap positioning motor)	AAC-Automatic air conditioning
ACT0660	M2/21 (Fresh air flap actuator)	AAC-Automatic air conditioning
ACT0661	Windshield heater	AAC-Automatic air conditioning
ACT0662	Y19/9 (Rear air conditioning evaporator shutoff valve)	AAC-Automatic air conditioning
ACT0663	Y19/3 (Front evaporator shutoff valve)	AAC-Automatic air conditioning
ACT0664	Y16 (Stationary heater switchover valve)	AAC-Automatic air conditioning
ACT0665	N18/9 (Driver side air vent ionizer)	AAC-Automatic air conditioning
ACT0666	Test sound	SOGESTAR2-Sound generator for electric vehicle
ACT0667	Tilting/sliding sunroof	SD-Control module 'Sliding roof ' (A98/1)
ACT0668	N83/1 (DC/DC converter control unit)	DDW-DC/DC converter(N83/1)
ACT0669	Actuation of actuator motor in position ''P R N D''	ISM-Shift module
ACT0670	Charging of suspension fluid reservoir	ISM-Shift module
ACT0671	Change to normal mode	ISM-Shift module
ACT0672	Selection of drive position	ISM-Shift module
ACT0673	Heater pads in rear passenger compartment	REAR-Rear control unit(N10/8)
ACT0674	Left and right pop-out window	REAR-Rear control unit(N10/8)
ACT0675	Ambiance illumination ''Cockpit''	REAR-Rear control unit(N10/8)
ACT0676	Illuminated door sill moldings	REAR-Rear control unit(N10/8)
ACT0677	M14/7 (Liftgate central locking motor)	REAR-Rear control unit(N10/8)

ACT0678	E40 (Liftgate ambient lamp)	REAR-Rear control unit(N10/8)
ACT0679	S62/36e1 (Liftgate control button symbol illumination)	REAR-Rear control unit(N10/8)
ACT0680	Code 843 (Electric EASY-ENTRY)	REAR-Rear control unit(N10/8)
ACT0681	Third seat row can be folded forward.	REAR-Rear control unit(N10/8)
ACT0682	M35/2 (Rear camera cover motor)	REAR-Rear control unit(N10/8)
ACT0683	B84 (Infrared camera)	NSA-Night View Assist(N101)
ACT0684	A40/8 (Audio/COMAND display)	NSA-Night View Assist(N101)
ACT0685	Infrared light	NSA-Night View Assist(N101)
ACT0686	Door handle illumination ''Left rear door''	DCU LR-Left rear door(N69/3)
ACT0687	Switch illumination ''Left rear door''	DCU LR-Left rear door(N69/3)
ACT0688	Exit and warning lamp ''Left rear door''	DCU LR-Left rear door(N69/3)
ACT0689	E17/45 (Left rear door ambiance illumination)	DCU LR-Left rear door(N69/3)
ACT0690	Door handle illumination ''Right rear door''	DCU RR-Right rear door(N69/4)
ACT0691	Switch illumination ''Right rear door''	DCU RR-Right rear door(N69/4)
ACT0692	Exit and warning lamp ''Right rear door''	DCU RR-Right rear door(N69/4)
ACT0693	E17/46 (Right rear door ambiance illumination)	DCU RR-Right rear door(N69/4)
ACT0694	Directional control valves	RC-Roll control (B38/2)
ACT0695	Pressure control valves	RC-Roll control (B38/2)
ACT0696	Y86/2 (Active Roll Stabilization throttle valve)	RC-Roll control (B38/2)
ACT0697	Y86/3 (Active roll stabilization safety valve)	RC-Roll control (B38/2)

ACT0698	Bleeding of hydraulic system	RC-Roll control (B38/2)
ACT0699	High-pressure test	RC-Roll control (B38/2)
ACT0700	Vertical calibration	RC-Roll control (B38/2)
ACT0701	Horizontal calibration	RC-Roll control (B38/2)
ACT0702	Output of an audio and video signal from control unit ''TV tuner'' on the displays in the rear passenger compartment	AVE H-Rear audio video unit
ACT0703	Actuate component ''Y108 (Transfer case switchover magnet)''.	VG-Transfer case
ACT0704	Actuate component ''Interaxle differential lock''.	VG-Transfer case
ACT0705	Y49/5 (Right intake camshaft solenoid)	N3/10-Motor electronics ''MED177'' for combustion engine ''M276''
ACT0706	Y49/7 (Right exhaust camshaft solenoid)	N3/10-Motor electronics ''MED177'' for combustion engine ''M276''
ACT0707	Y77/2 (Intake manifold resonance flap switchover valve)	N3/10-Motor electronics ''MED177'' for combustion engine ''M276''
ACT0708	Y77/3 (Intake manifold selector drum switchover valve)	N3/10-Motor electronics ''MED177'' for combustion engine ''M276''
ACT0709	Y93 (Exhaust flap switchover valve)	N3/10-Motor electronics ''MED177'' for combustion engine ''M276''
ACT0710	Y137 (High-temperature/low-temperature circuit switchover valve)	N3/10-Motor electronics ''MED177'' for combustion engine ''M276''
ACT0711	M45 (Coolant circulation pump)	N3/10-Motor electronics ''MED177V6LA'' for combustion engine ''M276Turbocharger''
ACT0712	Y101/1 (Left bypass air switchover valve)	N3/10-Motor electronics ''MED177V6LA'' for combustion engine ''M276Turbocharger''
ACT0713	Y101/2 (Right bypass air switchover valve)	N3/10-Motor electronics ''MED177V6LA'' for combustion engine ''M276Turbocharger''
ACT0714	Flushing the wet clutch	Y3/8n4-Transmission control for 9 speed transmission
ACT0715	Left front memory function	LFD-Left front door
ACT0716	Left front extendable tweeter	LFD-Left front door
ACT0717	LED ''Switches Left or right seat adjustment''	LFD-Left front door

ACT0718	LED ''Switches Refueling safety detection''	LFD-Left front door
ACT0719	LED of switch ''Trailer hitch''	LFD-Left front door
ACT0720	Right front memory function	DCU RF-Right front door
ACT0721	Right front extendable tweeter	DCU RF-Right front door
ACT0722	Switches Left or right seat adjustment	DCU RF-Right front door
ACT0723	Roller sun blind for left rear door	DCU LR-Left rear door
ACT0724	LED of switch ''Left rear seat ventilation''	DCU LR-Left rear door
ACT0725	Left rear extendible tweeter	DCU LR-Left rear door
ACT0726	Roller sun blind for right rear door	DCU RR-Right rear door
ACT0727	SwitchesSeat adjustmentFront passenger seat	DCU RR-Right rear door
ACT0728	Right rear extendible tweeter	DCU RR-Right rear door
ACT0729	E1 (Left front lamp unit)	SAMF-Front signal acquisition and actuation module(N10/6)
ACT0730	E2 (Right front lamp unit)	SAMF-Front signal acquisition and actuation module(N10/6)
ACT0731	Side-marker lamp	SAMF-Front signal acquisition and actuation module(N10/6)
ACT0732	Exterior light functions	SAMF-Front signal acquisition and actuation module(N10/6)
ACT0733	Ambiance illumination in ''footwell''	SAMF-Front signal acquisition and actuation module(N10/6)
ACT0734	Footwell illumination	SAMF-Front signal acquisition and actuation module(N10/6)
ACT0735	M5/1 (Windshield washer system pump)	SAMF-Front signal acquisition and actuation module(N10/6)
ACT0736	NOT PRESENT	SAMF-Front signal acquisition and actuation module(N10/6)
ACT0737	Supply voltage to components ''N59 (Perfume atomizer generator)'' and ''E13/1 (Glove compartment lamp)''	SAMF-Front signal acquisition and actuation module(N10/6)

ACT0738	K40/8kG (Engine compartment circuit 15 relay)	SAMF-Front signal acquisition and actuation module(N10/6)
ACT0739	Fanfare horns	SAMF-Front signal acquisition and actuation module(N10/6)
ACT0740	M35/1 (Front camera cover motor)	SAMF-Front signal acquisition and actuation module(N10/6)
ACT0741	Transport mode	SAMF-Front signal acquisition and actuation module(N10/6)
ACT0742	Confirmation of battery change	SAMF-Front signal acquisition and actuation module(N10/6)
ACT0743	Activate demo mode of exterior lights.	SAMF-Front signal acquisition and actuation module(N10/6)
ACT0744	Windshield wiper	SAMF-Front signal acquisition and actuation module(N10/6)
ACT0745	Footwell lamp	SAMF-Front signal acquisition and actuation module(N10/6)
ACT0746	Deep discharge protection	SAMF-Front signal acquisition and actuation module(N10/6)
ACT0747	Taillamps	SAMR-Rear signal acquisition and actuation module(N10/8)
ACT0748	Rear turn signal lamps	SAMR-Rear signal acquisition and actuation module(N10/8)
ACT0749	Actuation of function ''Turn signal lamp''	SAMR-Rear signal acquisition and actuation module(N10/8)
ACT0750	Backup lamps	SAMR-Rear signal acquisition and actuation module(N10/8)
ACT0751	Rear fog lamp	SAMR-Rear signal acquisition and actuation module(N10/8)
ACT0752	License plate lamps	SAMR-Rear signal acquisition and actuation module(N10/8)
ACT0753	Only for the development department	SAMR-Rear signal acquisition and actuation module(N10/8)
ACT0754	Trunk lamps	SAMR-Rear signal acquisition and actuation module(N10/8)
ACT0755	E40/2 (Left trunk lid/liftgate ambient lamp and warning lamp)	SAMR-Rear signal acquisition and actuation module(N10/8)
ACT0756	Output Illumination of component ''S62/26 (Trunk lid/liftgate control button)''	SAMR-Rear signal acquisition and actuation module(N10/8)
ACT0757	Illumination of component ''S88/10 (Trunk lid emergency opening switch)''	SAMR-Rear signal acquisition and actuation module(N10/8)

ACT0758	E17/17 (Left rear passenger compartment footwell lamp), E17/18 (Right rear passenger compartment footwell lamp)	SAMR-Rear signal acquisition and actuation module (N10/8)
ACT0759	F152/2kU (Rear cup holder relay)	SAMR-Rear signal acquisition and actuation module (N10/8)
ACT0760	K40/5kX (1st seat row/trunk refrigerator box and power outlet relay)	SAMR-Rear signal acquisition and actuation module (N10/8)
ACT0761	K40/5kT (Rear window heater relay)	SAMR-Rear signal acquisition and actuation module (N10/8)
ACT0762	Trunk lid/liftgate	SAMR-Rear signal acquisition and actuation module (N10/8)
ACT0763	Trunk lid control	SAMR-Rear signal acquisition and actuation module (N10/8)
ACT0764	Load compartment cover	SAMR-Rear signal acquisition and actuation module (N10/8)
ACT0765	M14/10 (Tank cap central locking actuator)	SAMR-Rear signal acquisition and actuation module (N10/8)
ACT0766	M6/4 (Liftgate wiper motor)	SAMR-Rear signal acquisition and actuation module (N10/8)
ACT0767	M14/18 (Glove compartment central locking actuator motor)	SAMR-Rear signal acquisition and actuation module (N10/8)
ACT0768	M24 (Rear window roller sun blind motor)	SAMR-Rear signal acquisition and actuation module (N10/8)
ACT0769	Rear seats	SAMR-Rear signal acquisition and actuation module (N10/8)
ACT0770	Actuation of output ''Circuit 15''	SAMR-Rear signal acquisition and actuation module (N10/8)
ACT0771	A31/1 (Rear heating system valve unit)	AAC-Automatic air conditioning
ACT0772	A32n1 (Blower regulator)/A32m1 (Blower motor)	AAC-Automatic air conditioning
ACT0773	M2/1 (Rear passenger compartment blower motor)	AAC-Automatic air conditioning
ACT0774	N29/8 (Booster blower electronic blower regulator)	AAC-Automatic air conditioning
ACT0775	N59 (Perfume atomizer generator)	AAC-Automatic air conditioning
ACT0776	N61 (Windshield heater control unit)	AAC-Automatic air conditioning
ACT0777	Y16/5 (High-voltage PTC heater switchover valve)	AAC-Automatic air conditioning

ACT0778	Y19/1 (High-voltage battery cooling system shutoff valve)	AAC-Automatic air conditioning
ACT0779	Y19/2 (AC water valve)	AAC-Automatic air conditioning
ACT0780	Actuate components ''Y19/3 (Front evaporator shutoff valve)'' and ''Y19/9 (Rear air conditioning evaporator shutoff	AAC-Automatic air conditioning
ACT0781	M2/8 (Left blend air flap actuator)	AAC-Automatic air conditioning
ACT0782	M2/9 (Right blend air flap actuator)	AAC-Automatic air conditioning
ACT0783	M2/10 (Rear blend air flap actuator motor)	AAC-Automatic air conditioning
ACT0784	M2/11 (Left footwell vent/center air vent/side air vent and rear air vent flap actuator motor)	AAC-Automatic air conditioning
ACT0785	M2/12 (Right footwell vent/center air vent and side air vent flap actuator motor)	AAC-Automatic air conditioning
ACT0786	M2/13 (Fresh air/ram air/air recirculation flap actuator motor)	AAC-Automatic air conditioning
ACT0787	M2/14 (Defroster/footwell/center air vent flap actuator motor)	AAC-Automatic air conditioning
ACT0788	M2/15 (Defroster flap actuator motor)	AAC-Automatic air conditioning
ACT0789	M16/11 (Left A-pillar air distribution actuator motor)	AAC-Automatic air conditioning
ACT0790	M16/12 (Right A-pillar air distribution actuator motor)	AAC-Automatic air conditioning
ACT0791	M2/17 (Left side air vent flap actuator motor)	AAC-Automatic air conditioning
ACT0792	M2/18 (Right side air vent flap actuator motor)	AAC-Automatic air conditioning
ACT0793	M2/30 (Upper left blend air flap actuator motor)	AAC-Automatic air conditioning
ACT0794	M2/31 (Lower left blend air flap actuator motor)	AAC-Automatic air conditioning
ACT0795	M2/32 (Upper right blend air flap actuator motor)	AAC-Automatic air conditioning
ACT0796	M2/33 (Lower right blend air flap actuator motor)	AAC-Automatic air conditioning
ACT0797	M2/34 (Ram air flap actuator motor)	AAC-Automatic air conditioning

ACT0798	M16/51 (Left rear center air outlet actuator motor)	AAC-Automatic air conditioning
ACT0799	M16/52 (Right rear center air outlet actuator motor)	AAC-Automatic air conditioning
ACT0800	Y148 (CO2 expansion valve)	AAC-Automatic air conditioning
ACT0801	Y148/2 (Rear passenger compartment CO2 air conditioning expansion valve)	AAC-Automatic air conditioning
ACT0802	Pneumatic pump	MKS LF-Left front multicontour seat
ACT0803	Actuation of air cushion of middle lumbar support	MKS LF-Left rear multicontour seat
ACT0804	Compressed air valveVENTILATION	PPAMKS-Pneumatic pump for multicontour seat
ACT0805	NormalizationM64/1 (Left rear seat active belt buckle motor)	AGS-Active bell buckle
ACT0806	NormalizationM64/2 (Right rear seat active belt buckle motor)	AGS-Active bell buckle
ACT0807	M64/1 (Left rear seat active belt buckle motor)	AGS-Active bell buckle
ACT0808	M64/2 (Right rear seat active belt buckle motor)	AGS-Active bell buckle
ACT0809	Button assignment	AVE H-Controller unit Rear entertainment system
ACT0810	Status of component ''A105/6 (Tablet cradle electric controller unit)''	AVE H-Controller unit Rear entertainment system
ACT0811	Switch component ''A105/7 (Tablet PC)'' on and off.	AVE H-Controller unit Rear entertainment system
ACT0812	WAKE-UP	AVE H-Controller unit Rear entertainment system
ACT0813	Background illumination	AVE H-Controller unit Rear entertainment system
ACT0814	Electric differential lock	EAGGS-Electric differential lock
ACT0815	Light distribution of LED matrix	SG LML VL-LED matrix of left front lamp unit
ACT0816	Self-test of system ''LED matrix''	SG LML VL-LED matrix of left front lamp unit
ACT0817	Heating element for left front armrest	N5 (Armrest heater control unit)

ACT0818	Heating element for right front armrest	N5 (Armrest heater control unit)
ACT0819	Front center console armrest heating element	N5 (Armrest heater control unit)
ACT0820	Heating element for left rear armrest	N5 (Armrest heater control unit)
ACT0821	Heating element for right rear armrest	N5 (Armrest heater control unit)
ACT0822	Rear center console armrest heating element	N5 (Armrest heater control unit)
ACT0823	Heating element for left front armrest PWM signal 100%	N5 (Armrest heater control unit)
ACT0824	Heating element for right front armrest PWM signal 100%	N5 (Armrest heater control unit)
ACT0825	Front center console armrest heating element PWM signal 100%	N5 (Armrest heater control unit)
ACT0826	Heating element for left rear armrest PWM signal 100%	N5 (Armrest heater control unit)
ACT0827	Heating element for right rear armrest PWM signal 100%	N5 (Armrest heater control unit)
ACT0828	Rear center console armrest heating element PWM signal 100%	N5 (Armrest heater control unit)
ACT0829	Armrest heater for front center console	N5 (Armrest heater control unit)
ACT0830	Left front armrest heater	N5 (Armrest heater control unit)
ACT0831	Right front armrest heater	N5 (Armrest heater control unit)
ACT0832	Armrest heater for center console in the rear	N5 (Armrest heater control unit)
ACT0833	Left rear armrest heater	N5 (Armrest heater control unit)
ACT0834	Right rear armrest heater	N5 (Armrest heater control unit)
ACT0835	Armrest of left front door	N5 (Armrest heater control unit)
ACT0836	Armrest of right front door	N5 (Armrest heater control unit)
ACT0837	Armrest of left front center console	N5 (Armrest heater control unit)

ACT0838	Armrest of right front center console	N5 (Armrest heater control unit)
ACT0839	Armrest Left front door	N5 (Armrest heater control unit)
ACT0840	Door trim Left front door	N5 (Armrest heater control unit)
ACT0841	Armrest Right front door	N5 (Armrest heater control unit)
ACT0842	Door trim Right front door	N5 (Armrest heater control unit)
ACT0843	Armrest Front center console	N5 (Armrest heater control unit)
ACT0844	Armrest Left rear door	N5 (Armrest heater control unit)
ACT0845	Door trim Left rear door	N5 (Armrest heater control unit)
ACT0846	Armrest Right rear door	N5 (Armrest heater control unit)
ACT0847	Door trim Right rear door	N5 (Armrest heater control unit)
ACT0848	Armrest Center console in rear passenger compartment	N5 (Armrest heater control unit)
ACT0849	Enabling of function ''Armrest heater''	N5 (Armrest heater control unit)
ACT0850	Actuation of air cushions for massage function	Massage function in left rear seat
ACT0851	Automatic adjustment of vehicle level	AIRmatic
ACT0852	Run system test.	AIRmatic
ACT0853	Recirculate pressure to central reservoir.	AIRmatic
ACT0854	Release pressure.	AIRmatic
ACT0855	Fill suspension struts from central reservoir.	AIRmatic
ACT0856	Fill suspension struts from external gas cylinder.	AIRmatic
ACT0857	Electrohydraulic controller unit	AIRmatic

ACT0858	Automatically move to normal level.	AIRmatic
ACT0859	Actuation of vehicle level	AIRmatic
ACT0860	Function test of component ''EHSE''	Left front suspension strut
ACT0861	Hydraulic unit''EHSE''EVACUATION	Left front suspension strut
ACT0862	Hydraulic unit''EHSE''FILLING	Left front suspension strut
ACT0863	M56 (Electric vacuum pump)	ESP-Electric stability program(N30/4)
ACT0864	M16/60 (Left throttle valve actuator)	N3/10-Motor electronics ''MED1775'' for combustion engine ''M178''
ACT0865	M16/61 (Right throttle valve actuator)	N3/10-Motor electronics ''MED1775'' for combustion engine ''M178''
ACT0866	Y58/11 (Left purging switchover valve)	N3/10-Motor electronics ''MED1775'' for combustion engine ''M178''
ACT0867	Y58/12 (Right purging switchover valve)	N3/10-Motor electronics ''MED1775'' for combustion engine ''M178''
ACT0868	Y77/1 (Boost pressure control pressure transducer)	N3/10-Motor electronics ''MED1775'' for combustion engine ''M178''
ACT0869	Y94/1 (Left quantity control valve)	N3/10-Motor electronics ''MED1775'' for combustion engine ''M178''
ACT0870	Y94/2 (Right quantity control valve)	N3/10-Motor electronics ''MED1775'' for combustion engine ''M178''
ACT0871	M60/1 (Electric additional compressor)	N3/10-Motor electronics ''MRG1'' for combustion engine ''M256''
ACT0872	MAGIC SKY CONTROL	MSC-MAGIC SKY CONTROL (N53)
ACT0873	Y10 (Speed-sensitive power steering solenoid valve)	ESP- Electric stability program
ACT0874	Y10/1 (Power steering pump quantity control valve)	ESP- Electric stability program
ACT0875	KEYLESS GO test of ignition key	KG-KEYLESS GO
ACT0876	Test of the entire KEYLESS GO system	KG-KEYLESS GO
ACT0877	Opening assists ''KEYLESS GO''	KG-KEYLESS GO (N69/5)

ACT0878	M16/22 (Air distribution flap actuator motor)	AAC-Automatic air conditioning
ACT0879	M2/14 (Blend air flap actuator motor)	AAC-Automatic air conditioning
ACT0880	Voltages	Driver side SAM-Driver signal acquisition and actuation module
ACT0881	ECO start/stop function	Driver side SAM-Driver signal acquisition and actuation module
ACT0882	Exterior illumination	Driver side SAM-Driver signal acquisition and actuation module
ACT0883	Interior illumination	Driver side SAM-Driver signal acquisition and actuation module
ACT0884	Air conditioning	Driver side SAM-Driver signal acquisition and actuation module
ACT0885	Wipe and wash	Driver side SAM-Driver signal acquisition and actuation module
ACT0886	Central lockingRear doors	Driver side SAM-Driver signal acquisition and actuation module
ACT0887	N10/1k0 (Fanfare horn relay)	Driver side SAM-Driver signal acquisition and actuation module
ACT0888	Taillight	Rear SAM-Rear signal acquisition and actuation module
ACT0889	Side-marker lamp/Taillight	Rear SAM-Rear signal acquisition and actuation module
ACT0890	Rear side-marker lamps	Rear SAM-Rear signal acquisition and actuation module
ACT0891	Backup light	Rear SAM-Rear signal acquisition and actuation module
ACT0892	Trunk lamp	Rear SAM-Rear signal acquisition and actuation module
ACT0893	E40 (Trunk lid ambient lamp)	Rear SAM-Rear signal acquisition and actuation module
ACT0894	E17/27 (Trunk lid warning/ambient lamp)	Rear SAM-Rear signal acquisition and actuation module
ACT0895	Illumination of component ''S62/36 (Tailgate control button)''	Rear SAM-Rear signal acquisition and actuation module
ACT0896	N10/2kA (Circuit 15 relay)	Rear SAM-Rear signal acquisition and actuation module
ACT0897	Relay ''Circuit 15R''	Rear SAM-Rear signal acquisition and actuation module

ACT0898	F32k2 (No-load current cutout relay)	Rear SAM-Rear signal acquisition and actuation module
ACT0899	M14/10 (Tank cap central locking motor)	Rear SAM-Rear signal acquisition and actuation module
ACT0900	M14/18 (Glove compartment central locking actuator motor)/M14/19 (Stowage compartment central locking actuator)	Rear SAM-Rear signal acquisition and actuation module
ACT0901	M14/31 (Liftgate lock element)	Rear SAM-Rear signal acquisition and actuation module
ACT0902	N29/5 (Left front seat ventilation blower regulator)	Rear SAM-Rear signal acquisition and actuation module
ACT0903	N29/6 (Right front seat ventilation blower regulator)	Rear SAM-Rear signal acquisition and actuation module
ACT0904	R1 (Rear window heater)	Rear SAM-Rear signal acquisition and actuation module
ACT0905	N10/2kE (Liftgate window wiper relay)	Rear SAM-Rear signal acquisition and actuation module
ACT0906	Head restraint release in rear passenger compartment	Rear SAM-Rear signal acquisition and actuation module
ACT0907	M24/11 (Trunk partition motor)	Rear SAM-Rear signal acquisition and actuation module
ACT0908	Actuation of load compartment cover	Rear SAM-Rear signal acquisition and actuation module
ACT0909	Wiper blade heater	Rear SAM-Rear signal acquisition and actuation module
ACT0910	E3 (Left rear lamp unit)	Rear SAM-Rear signal acquisition and actuation module
ACT0911	E4 (Right rear lamp unit)	Rear SAM-Rear signal acquisition and actuation module
ACT0912	E3/7 (Center rear lamp unit)	Rear SAM-Rear signal acquisition and actuation module
ACT0913	E3/6 (Rear fog lamp)	Rear SAM-Rear signal acquisition and actuation module
ACT0914	E3/5 (Left rear additional lamp)	Rear SAM-Rear signal acquisition and actuation module
ACT0915	E4/5 (Right rear additional lamp)	Rear SAM-Rear signal acquisition and actuation module
ACT0916	Exterior illuminationComponents197(Only for the development department)	Rear SAM-Rear signal acquisition and actuation module
ACT0917	Exterior illuminationFunctions view197(Only for the development department)	Rear SAM-Rear signal acquisition and actuation module

ACT0918	Exterior illuminationComponents207 / 212(Only for the development department)	Rear SAM-Rear signal acquisition and actuation module
ACT0919	Exterior illuminationFunctions view207 / 212(Only for the development department)	Rear SAM-Rear signal acquisition and actuation module
ACT0920	Exterior illuminationComponents204 / 204X ohne ERT(Only for the development department)	Rear SAM-Rear signal acquisition and actuation module
ACT0921	Exterior illuminationFunctions view204 / 204X ohne ERT(Only for the development department)	Rear SAM-Rear signal acquisition and actuation module
ACT0922	STATICCurrentSwitches	Rear SAM-Rear signal acquisition and actuation module
ACT0923	VIA_SAT	Rear SAM-Rear signal acquisition and actuation module
ACT0924	Air admissionSOUND	Rear SAM-Rear signal acquisition and actuation module
ACT0925	Characters	Rear SAM-Rear signal acquisition and actuation module
ACT0926	M96/1 (Draft stop actuator motor)	REAR SAM-Rear signal acquisition and actuation module
ACT0927	LED of switch ''S51/4 (Right rear seat heater button)''	LFD-Left front door
ACT0928	Switch ''Roller sun blind for right rear door''	LFD-Left front door
ACT0929	M10/5 (Left rear power window motor)	STC-Soft top control (N52)
ACT0930	M10/6 (Right rear power window motor)	STC-Soft top control (N52)
ACT0931	Switch illumination of Vario roof control	STC-Soft top control (N52)
ACT0932	R lock	N15/5 (Electronic selector lever module control unit)
ACT0933	P lock	N15/5 (Electronic selector lever module control unit)
ACT0934	Windshield wiper FSW	FSW-Windshield wiper
ACT0935	Warning indicators ''Parking system''	PTS-Parktronic system
ACT0936	H3/1 (Alarm siren)	AS-Alarm siren(H3/1)
ACT0937	Actuation of components ''N70s8 (Interior protection button)'' and ''N70s9 (Tow-away protection button)''	ATA-ATA[EDW]/tow-away protection/interior protection

ACT0938	Self-test of control unit ''Interior protection and tow-away protection''	ATA-ATA[EDW]/tow-away protection/interior protection
ACT0939	M33 (Electric air pump)	N3/10-Motor electronics ''SIM271DE20'' for combustion engine ''M271EVO''
ACT0940	M59 (Intake manifold swirl flap actuator motor)	N3/10-Motor electronics ''SIM271DE20'' for combustion engine ''M271EVO''
ACT0941	Y32 (Air pump switchover valve)	N3/10-Motor electronics ''SIM271DE20'' for combustion engine ''M271EVO''
ACT0942	Secondary air injection	N3/10-Motor electronics ''SIM271DE20'' for combustion engine ''M271EVO''
ACT0943	Thermal management	N3/10-Motor electronics ''SIM271DE20'' for combustion engine ''M271EVO''
ACT0944	H4/3 (Left rear door speaker)	AUDIO-Audio(A2)
ACT0945	H4/4 (Right rear door speaker)	AUDIO-Audio(A2)
ACT0946	Test picture display ''COMAND Online''	ZAN-Audio/COMAND display
ACT0947	E43/49 (Upper audio/COMAND display ambiance illumination)E43/50 (Lower audio/COMAND display ambiance	IC-Instrument cluster
ACT0948	Soft top	STC-Soft top control (N52)
ACT0949	Actuation of left side flap	STC-Soft top control (N52)
ACT0950	Actuation of right side flap	STC-Soft top control (N52)
ACT0951	Actuation of soft top lock	STC-Soft top control (N52)
ACT0952	M16/3 (Front throttle valve actuator)	N3/10-Motor electronics ''ME97 AMG'' for combustion engine ''M156''
ACT0953	M16/4 (Rear throttle valve actuator)	N3/10-Motor electronics ''ME97 AMG'' for combustion engine ''M156''
ACT0954	Y22/6 (Intake manifold switchover valve)	N3/10-Motor electronics ''ME97 AMG'' for combustion engine ''M156''
ACT0955	Y32/1 (Air pump 1 switchover valve)	N3/10-Motor electronics ''ME97 AMG'' for combustion engine ''M156''
ACT0956	Y32/2 (Air pump 2 switchover valve)	N3/10-Motor electronics ''ME97 AMG'' for combustion engine ''M156''
ACT0957	M4/1 (Oil cooler fan motor)	N3/10-Motor electronics ''ME97 AMG'' for combustion engine ''M156''

ACT0958	Y62 (Injection valves)	N3/10-Motor electronics ''ME97 AMG'' for combustion engine ''M156''
ACT0959	M75/7 (Rear high-voltage battery coolant pump)	BMS-H-Battery management system, rear (master)
ACT0960	Measurement log for self-discharge of battery cells	BMS-H-Battery management system, rear (master)
ACT0961	Function illumination ''SPEEDTRONIC''	SCM [MRM]-Steering column module
ACT0962	Switchover of video signal source	AMG PM-AMG Performance Media(N125/2)
ACT0963	A7/3y7 (Left front pressure regulating valve (pressure release))	ESP-Electronic stability program(N30/4)
ACT0964	Perform current adjustment.	ELM-VL-Front left electrical machine
ACT0965	Perform voltage adjustment.	ELM-VL-Front left electrical machine
ACT0966	L20/4 (Left front electrical machine rotor position sensor)	ELM-VL-Front left electrical machine
ACT0967	Reset of ''Sensor ''Voltage of high-voltage on-board electrical system'''' component	ELM-VL-Front left electrical machine
ACT0968	Check contact of component ''Front left electrical machine''.	ELM-VL-Front left electrical machine
ACT0969	Reset of frequency counter ''Emergency shutoff of component 'N129/4 (Left front electrical machine control unit)''''	ELM-VL-Front left electrical machine
ACT0970	Resetting of frequency counter ''Emergency shutoff due to implausible torque request''	ELM-VL-Front left electrical machine
ACT0971	Enable CD/DVD drive.	Audio-Audio or COMAND
ACT0972	BRIGHT	Audio-Audio or COMAND
ACT0973	DARK	Audio-Audio or COMAND
ACT0974	Mittel	Audio-Audio or COMAND
ACT0975	NTG4Initial startup	Audio-Audio or COMAND
ACT0976	L20/5 (Right front electrical machine rotor position sensor)	ELM-VR-Front right electrical machine
ACT0977	Check contact of component ''Front right electrical machine''.	ELM-VR-Front right electrical machine

ACT0978	Reset of frequency counter ''Emergency shutoff of component 'N129/5 (Right front electrical machine control unit)''''	ELM-VR-Front right electrical machine
ACT0979	N19/4 (Electric refrigerant compressor control unit)	AAC-Automatic air conditioning
ACT0980	L20/6 (Left rear electrical machine rotor position sensor)	ELM-HL-Rear left electrical machine
ACT0981	Check contact of component ''Rear right electrical machine''.	ELM-HL-Rear left electrical machine
ACT0982	Reset of frequency counter ''Emergency shutoff of component 'N129/6 (Left rear electrical machine control unit)''''	ELM-HL-Rear left electrical machine
ACT0983	L20/7 (Right rear electrical machine rotor position sensor)	ELM-HR-Rear right electrical machine
ACT0984	Check contact of component ''A79/7 (Right rear electrical machine)''.	ELM-HR-Rear right electrical machine
ACT0985	Reset of frequency counter ''Emergency shutoff of component 'N129/7 (Right rear electrical machine control unit)''''	ELM-HR-Rear right electrical machine
ACT0986	LED of component ''X58/23 (Charger feed-in socket)''	SG LG-Charger
ACT0987	Locking of charging cable	SG LG-Charger
ACT0988	Y139/1 (Drive coolant pump regulation valve)	PTCU-MA-Drivetrain (master)
ACT0989	Y139/3 (High-voltage battery coolant pump regulation valve)	PTCU-MA-Drivetrain (master)
ACT0990	Y139/9 (Climate control coolant pump regulation valve)	PTCU-MA-Drivetrain (master)
ACT0991	Y107/9 (Shutoff valve 2)	PTCU-MA-Drivetrain (master)
ACT0992	Shutoff valves of refrigerant circuit	PTCU-MA-Drivetrain (master)
ACT0993	PTC heater booster	PTCU-MA-Drivetrain (master)
ACT0994	M75/8 (Front electric drive coolant pump)	PTCU-MA-Drivetrain (master)
ACT0995	M75/9 (Rear electric drive coolant pump)	PTCU-MA-Drivetrain (master)
ACT0996	M4/2 (Coolant fan motor)	PTCU-MA-Drivetrain (master)
ACT0997	Circuit 87	PTCU-MA-Drivetrain (master)

ACT0998	Circuit 15	PTCU-MA-Drivetrain (master)
ACT0999	M40 (Differential lock vacuum pump)	PTCU-SL-Drivetrain (slave)
ACT1000	A13 (Electric parking brake control unit)	EFB-Electric parking brake
ACT1001	M75/5 (Front high-voltage battery coolant pump)	BMS-V-Battery management system, front (slave)
ACT1002	Component ''Valve1''CENTER	BMS-M-Battery management system, center (master)
ACT1003	Component ''Valve2''CENTER	BMS-M-Battery management system, center (master)
ACT1004	Component ''Valve3''CENTER	BMS-M-Battery management system, center (master)
ACT1005	M75/6 (Center high-voltage battery coolant pump)	BMS-M-Battery management system, center (master)
ACT1006	Actuation of components ''Y123 (Left switchable engine mount)'' and ''Y123/1 (Right switchable engine mount)''	N3/9-Motor electronics ''CDI6EU5'' for combustion engine ''OM642''
ACT1007	M16/5 (Throttle valve actuator)	N3/9-Motor electronics ''CDI'' for combustion engine ''OM646''
ACT1008	Y100/1 (Boost pressure positioner)	N3/9-Motor electronics ''CDI'' for combustion engine ''OM646''
ACT1009	Bleeding of high-pressure fuel circuit	N3/9-Motor electronics ''CDI'' for combustion engine ''OM646''
ACT1010	A1e16 (Preglow indicator lamp)	N3/9-Motor electronics ''CDI'' for combustion engine ''OM646''
ACT1011	Pressure drop test	N3/9-Motor electronics ''CDI'' for combustion engine ''OM646''
ACT1012	B2/5 (Hot film mass air flow sensor)	N3/9-Motor electronics ''CDI'' for combustion engine ''OM646''
ACT1013	Test of fuel system high pressure pump	N3/9-Motor electronics ''CDI'' for combustion engine ''OM646''
ACT1014	Test for rail pressure fluctuations	N3/9-Motor electronics ''CDI'' for combustion engine ''OM646''
ACT1015	Y132 (Charge air bypass flap switchover valve)	N3/9-Motor electronics ''CDID2'' for combustion engine ''OM651''
ACT1016	Actuation of components ''Y93 (Boost pressure control flap pressure transducer)'', ''Y31/4 (Wastegate control pressure	N3/9-Motor electronics ''CDID2'' for combustion engine ''OM651''
ACT1017	Test all solenoid valves.	N15/3-Transmission control for 5 speed transmission

ACT1018	Tire pressure loss warning	ESP- Electric stability program
ACT1019	Actuation of component ''H4/31 (Exhaust system sound generator speaker)''	SG SOGE AGA-Sound generator for exhaust system
ACT1020	Actuation of component ''H4/31 (Exhaust system sound generator speaker)'' Frequency range	SG SOGE AGA-Sound generator for exhaust system
ACT1021	Power supply of peripheral devices	Multifunction control unit-Multifunction control unit
ACT1022	Output ''Two-way radio cut-in''	Multifunction control unit-Multifunction control unit
ACT1023	M51/3 (Trunk lid control drive unit)	TLC-Trunk lid control
ACT1024	M14/31 (Trunk lid lock element)	TLC-Trunk lid control
ACT1025	M51/3y1 (Tailgate control magnetic clutch)	TLC-Trunk lid control
ACT1026	M2/35 (Rear blend air flap actuator motor)	AAC-Automatic air conditioning
ACT1027	M2/21 (Diffuser flap actuator motor)	AAC-Automatic air conditioning
ACT1028	A6m2 (Stationary heater combustion air blower)	STH-Stationary heater
ACT1029	A6r4 (Stationary heater glow plug/flame monitor unit)	STH-Stationary heater
ACT1030	Y23 (Stationary heater fuel pump)	STH-Stationary heater
ACT1031	Measurement of fuel flow rate	STH-Stationary heater
ACT1032	Deactivation of fault interlock or overheating protection	STH-Stationary heater
ACT1033	Deactivation of safety lock	STH-Stationary heater
ACT1034	Automatic illumination test	OCP-Overhead control panel
ACT1035	Indicator lamp ''Trailer hitch LOCKED''	TRM-Trailer recognition module (N28/1)
ACT1036	LED of switch ''S51/3 (Left rear seat heater button)''	DCU LR-Left rear door
ACT1037	E1m1 (Left headlamp range adjustment actuator motor)	XALWA L-Xenon headlamp, left

ACT1038	E1m2 (Left active curve illumination actuator motor)	XALWA L-Xenon headlamp, left
ACT1039	Headlamp range adjustment of both xenon bulbs	XALWA L-Xenon headlamp, left
ACT1040	Active curve illumination of both xenon bulbs	XALWA L-Xenon headlamp, left
ACT1041	Light output of xenon bulb	XALWA L-Xenon headlamp, left
ACT1042	E1e9 (Left cornering illumination)	XALWA L-Xenon headlamp, left
ACT1043	E2m1 (Right headlamp range adjustment actuator motor)	XALWA R-Xenon headlamp, right
ACT1044	E2m2 (Right active curve illumination actuator motor)	XALWA R-Xenon headlamp, right
ACT1045	E2e9 (Right cornering illumination)	XALWA R-Xenon headlamp, right
ACT1046	Test of telephone connection	CTEL-Mobile phone
ACT1047	Y125 (Low temperature circuit shutoff valve)	N3/10-Motor electronics ''MED97'' for combustion engine ''M272''
ACT1048	Combustion engine AT STANDSTILL	N3/9-Motor electronics ''CDI41R'' for combustion engine ''OM626''
ACT1049	Combustion engine IDLING	N3/9-Motor electronics ''CDI41R'' for combustion engine ''OM626''
ACT1050	Y88 (Coolant thermostat shutoff valve)	N3/9-Motor electronics ''CDI41R'' for combustion engine ''OM626''
ACT1051	Shutoff of injection	N3/9-Motor electronics ''CDI41R'' for combustion engine ''OM626''
ACT1052	Rail pressure regulation	N3/9-Motor electronics ''CDI41R'' for combustion engine ''OM626''
ACT1053	B20 (Fuel filter element with integrated heater)	N3/9-Motor electronics ''CDI41R'' for combustion engine ''OM626''
ACT1054	Switch and controls illumination of component ''S2/3 (KEYLESS-GO start/stop button)''	EZS-Electronic ignition lock
ACT1055	Left front door outer door handle illumination	LFD-Left front door
ACT1056	LED of switch ''Front passenger seat adjustment''	LFD-Left front door
ACT1057	Ambiance illumination ''Left front door''	LFD-Left front door

ACT1058	Right front door outer door handle illumination	DCU RF-Right front door
ACT1059	Ambiance illumination ''Right front door''	DCU RF-Right front door
ACT1060	Left rear door outer door handle illumination	DCU LR-Left rear door
ACT1061	Ambiance illumination ''Left rear door''	DCU LR-Left rear door
ACT1062	Right rear door outer door handle illumination	DCU RR-Right rear door
ACT1063	Ambiance illumination ''Right rear door''	DCU RR-Right rear door
ACT1064	M79/1 (Driver seat head restraint inclination motor)	ESV Driver-Electric seat adjustmnet Driver with memory function
ACT1065	M79/2 (Front passenger seat head restraint inclination motor)	ESV Front passenger-Electric seat adjustment Front passenger with memory function
ACT1066	K40/6 (Left fuse and relay module)	SAMF-Front signal acquisition and actuation module(N10/6)
ACT1067	K40/8 (Engine fuse and relay module)	SAMF-Front signal acquisition and actuation module(N10/6)
ACT1068	F32/4k2 (No-load current shutoff relay)	SAMF-Front signal acquisition and actuation module(N10/6)
ACT1069	M5/2 (Headlamp cleaning system pump)	SAMF-Front signal acquisition and actuation module(N10/6)
ACT1070	Spray nozzle heating and spray nozzle hose heater	SAMF-Front signal acquisition and actuation module(N10/6)
ACT1071	K40/8kM (Wiper park position heater relay)	SAMF-Front signal acquisition and actuation module(N10/6)
ACT1072	K40/6kD (Reserve relay)	SAMF-Front signal acquisition and actuation module(N10/6)
ACT1073	Taillight/Brake light	SAMR-Rear signal acquisition and actuation module(N10/8)
ACT1074	Center stop lamp	SAMR-Rear signal acquisition and actuation module(N10/8)
ACT1075	Rear turn signal lights	SAMR-Rear signal acquisition and actuation module(N10/8)
ACT1076	Ambient lamp and warning lamp	SAMR-Rear signal acquisition and actuation module(N10/8)
ACT1077	(Ambiance illumination Rear)	SAMR-Rear signal acquisition and actuation module(N10/8)

ACT1078	Illumination of component ''S62/26 (Trunk lid/liftgate control button)''	SAMR-Rear signal acquisition and actuation module(N10/8)
ACT1079	S88/10 (Trunk lid emergency opening switch)	SAMR-Rear signal acquisition and actuation module(N10/8)
ACT1080	K40/5kS (Vehicle interior circuit 15 relay)	SAMR-Rear signal acquisition and actuation module(N10/8)
ACT1081	K40/5kW (Circuit 15R relay)	SAMR-Rear signal acquisition and actuation module(N10/8)
ACT1082	K40/5kU (2nd seat row cup holder and power outlet relay)	SAMR-Rear signal acquisition and actuation module(N10/8)
ACT1083	Head restraints in rear passenger compartment	SAMR-Rear signal acquisition and actuation module(N10/8)
ACT1084	M14/19 (Stowage compartment central locking actuator motor)	SAMR-Rear signal acquisition and actuation module(N10/8)
ACT1085	A85/5m1 (Trunk lid lock motor)	SAMR-Rear signal acquisition and actuation module(N10/8)
ACT1086	Rear window wiper	SAMR-Rear signal acquisition and actuation module(N10/8)
ACT1087	Outside brake lights and taillights	SAMR-Rear signal acquisition and actuation module(N10/8)
ACT1088	CB-Repeat teach-in process.	SAMR-Rear signal acquisition and actuation module(N10/8)
ACT1089	H4/60 (Trunk lid/liftgate control warning buzzer)	HKS-Tailgate control
ACT1090	M51/3m1 (Trunk lid/liftgate control electric motor)	HKS-Tailgate control
ACT1091	Front roller sun blind	PSD-Control module Panoramic sliding roof
ACT1092	Rear roller sun blind	PSD-Control module Panoramic sliding roof
ACT1093	Front interior lights	OCP-Overhead control panel
ACT1094	Interior lights in rear passenger compartment	OCP-Overhead control panel
ACT1095	Illumination of vanity mirrors	OCP-Overhead control panel
ACT1096	Symbol illumination	OCP-Overhead control panel
ACT1097	Ambiance illumination of roof	OCP-Overhead control panel

ACT1098	Roof ventilator	OCP-Overhead control panel
ACT1099	Self-test of system ''ATA [EDW]/tow-away protection/interior protection''	OCP-Overhead control panel
ACT1100	Delete history of function ''Parking Damage Detection''.	OCP-Overhead control panel
ACT1101	Left belt extender	SG FOND-Rear control unit
ACT1102	Right belt extender	SG FOND-Rear control unit
ACT1103	M96/2 (Wind deflector actuator motor)	SG FOND-Rear control unit
ACT1104	Switch illumination of soft top control	SG FOND-Rear control unit
ACT1105	Head restraint in rear passenger compartment	SG FOND-Rear control unit
ACT1106	Retraction of trunk partition	SG FOND-Rear control unit
ACT1107	M47/1 (Front soft top lock motor)	SG FOND-Rear control unit
ACT1108	Denormalization of trunk lid control	SG FOND-Rear control unit
ACT1109	Actuator Differential lock	AMG DRVU-AMG DRIVE UNIT
ACT1110	Generation of an actuation point at component ''Haptic accelerator pedal module''	HFPM-Haptic accelerator pedal module
ACT1111	Generation of a double pulse at component ''Haptic accelerator pedal module''	HFPM-Haptic accelerator pedal module
ACT1112	Ambiance illumination	OCP-Overhead control panel
ACT1113	N25/7 (AIRSCARF control unit)	AIRSCARF-Neck heating system(N25/7)
ACT1114	B44/1 (Left front door interior protection sensor)	IRSS-VL-Left front interior protection sensor
ACT1115	B44/2 (Right front door interior protection sensor)	IRSS-VR-Right front interior protection sensor
ACT1116	B44/4 (Right rear interior protection sensor)	IRSS-FOR-Right rear interior protection sensor
ACT1117	B44/3 (Left rear interior protection sensor)	IRSS-FOL-Left rear interior protection sensor

ACT1118	Deactivation of production mode	STH-Stationary heater
ACT1119	K40/8kR (AIRmatic relay)	ADS-Adaptive damping system(N51/5)
ACT1120	Isolation measurement with open contactors	BMS-Battery management system
ACT1121	Isolation measurement with open contactors, Relay ''OPEN''	BMS-Battery management system
ACT1122	SBC Hold	ESP-Electronic stability program(N30/4)
ACT1123	Electric refrigerant compressor	A9/5 (Electric refrigerant compressor)
ACT1124	Test image	NSA-Night View Assist(N101)
ACT1125	A10 (Left belt extender)	REAR-Rear control unit(N22/6)
ACT1126	A11 (Right belt extender)	REAR-Rear control unit(N22/6)
ACT1127	Denormalization of power window	REAR-Rear control unit(N22/6)
ACT1128	Overheating protection	REAR-Rear control unit(N22/6)
ACT1129	Illumination of switches ''Power window''	REAR-Rear control unit(N22/6)
ACT1130	LEDs of button ''S84s4 (Draft stop and wind deflector button)''	REAR-Rear control unit(N22/6)
ACT1131	M28/14 (Actuator motor for head restraint drive in rear passenger compartment)	REAR-Rear control unit(N22/6)
ACT1132	Seat heater in left rear passenger compartment	N25/6 (Rear passenger compartment seat heater control unit)
ACT1133	Seat heater in right rear passenger compartment	N25/6 (Rear passenger compartment seat heater control unit)
ACT1134	E1e10 (Left xenon bulb with integrated ignition module)	XALWA L-Left xenon headlamp(E1n1)
ACT1135	E2e10 (Right xenon bulb with integrated ignition module)	XALWA R-Right xenon headlamp(E2n1)
ACT1136	Isolation measurement with closed contactors	BMS-Battery management system(N82/2)
ACT1137	Actuate component ''A100s1 (Contactor)''.	BMS-Battery management system(N82/2)

ACT1138	Actuation of air cushion ''Upper lumbar support''	AMKS LF-Active multicontour seat(N32/19)
ACT1139	Actuation of air cushion ''Lower lumbar support''	AMKS LF-Active multicontour seat(N32/19)
ACT1140	Y36/8y1 (Left rear level control valve)	ELC-Electronic level control
ACT1141	Y36/8y2 (Right rear level control valve)	ELC-Electronic level control
ACT1142	Fill natural gas system.	N3/10-Motor electronics ''CNGCM212'' for combustion engine ''M271CNG''
ACT1143	Drain natural gas system.	N3/10-Motor electronics ''CNGCM212'' for combustion engine ''M271CNG''
ACT1144	Actuation of component ''Y107/2 (Gas safety shutoff valve)''	N3/10-Motor electronics ''CNGCM212'' for combustion engine ''M271CNG''
ACT1145	Y106 (Injection valves)	N3/10-Motor electronics ''CNGCM212'' for combustion engine ''M271CNG''
ACT1146	Operating mode	N3/10-Motor electronics ''CNGCM212'' for combustion engine ''M271CNG''
ACT1147	Y107/1 (Gas cylinder shutoff valves)	N3/10-Motor electronics ''CNGCM212'' for combustion engine ''M271CNG''
ACT1148	Component ''Y107/1 (Gas cylinder shutoff valves)''	N3/10-Motor electronics ''CNGCM212'' for combustion engine ''M271CNG''
ACT1149	Enable natural gas operation.	N3/10-Motor electronics ''MED40CNG'' for combustion engine ''M270''
ACT1150	N14/2 (Glow output stage)	CDI-Motor electronics CR61 for combustion engine OM642
ACT1151	Y77/6 (Boost pressure regulator)	CDI-Motor electronics CR61 for combustion engine OM642
ACT1152	Actuation of components ''Y100/2 (Boost pressure control pressure transducer)'', ''Y77/1 (Boost pressure positioner)''	CDI-Motor electronics CR61 for combustion engine OM642
ACT1153	SettingMirror glassLeft	LFD-Left front door
ACT1154	Mirror dimmingLeft	LFD-Left front door
ACT1155	Warning lampBlind Spot Assist	LFD-Left front door
ACT1156	LED ''SwitchesLeft or right seat adjustment''	LFD-Left front door
ACT1157	SettingMirror glassRight	DCU RF-Right front door

ACT1158	Mirror dimmingRight	DCU RF-Right front door
ACT1159	Calibration of reversing camera	RFK-Backup camera
ACT1160	K40/8kR (AIR BODY CONTROL relay)	ELC-Electronic level control
ACT1161	A9/1y1 (AIR BODY CONTROL pressure relief valve)	ELC-Electronic level control
ACT1162	Y36/8y3 (Left rear level control valve)	ELC-Electronic level control
ACT1163	Y36/8y4 (Right rear level control valve)	ELC-Electronic level control
ACT1164	Y49/3 (Exhaust camshaft adjustment solenoid)	N3/10-Motor electronics ''MRG2'' for combustion engine ''M254''
ACT1165	Y49/8 (Intake camshaft positioner)	N3/10-Motor electronics ''MRG2'' for combustion engine ''M254''
ACT1166	Y147/1 (Quantity control valve)	N3/10-Motor electronics ''MRG2'' for combustion engine ''M254''
ACT1167	M43/10 (Electric coolant pump)	N3/10-Motor electronics ''MRG2'' for combustion engine ''M254''
ACT1168	Y58 (Purge valve)	N3/10-Motor electronics ''MRG2'' for combustion engine ''M254''
ACT1169	Y144 (Oil pressure regulation valve)	N3/10-Motor electronics ''MRG2'' for combustion engine ''M254''
ACT1170	Actuation of air cushion in shoulder area	MKS LF-Left front multicontour seat
ACT1171	Button illumination	COU[ZBE]-Audio/COMAND operating unit
ACT1172	Color displayCOMAND Online	ZAN-Audio/COMAND display
ACT1173	Video on multifunction display	NSA-Night View Assist(N101)
ACT1174	M6/1 (Wiper motor)	FSW-Windshield wiper
ACT1175	Air cushion Lower lumbar support	LSE FS-N32/23 (Driver seat lumbar support adjustment control unit)
ACT1176	Air cushion Upper lumbar support	LSE FS-N32/23 (Driver seat lumbar support adjustment control unit)
ACT1177	Y36/1y1 (Left front suspension strut control valve)	ABC-Active body control(N51/2)

ACT1178	Y36/1y3 (Right front suspension strut control valve)	ABC-Active body control (N51/2)
ACT1179	Y36/2y1 (Left rear suspension strut control valve)	ABC-Active body control (N51/2)
ACT1180	Y36/2y3 (Right rear suspension strut control valve)	ABC-Active body control (N51/2)
ACT1181	Y86/1 (ABC throttle valve)	ABC-Active body control (N51/2)
ACT1182	Shutoff valves	ABC-Active body control (N51/2)
ACT1183	Damper valves	ABC-Active body control (N51/2)
ACT1184	LED of component ''A40/9 (Audio/COMAND control panel)''	ABC-Active body control (N51/2)
ACT1185	Cyclically alternating actuation of all suspension struts in a circular motion (rodeo)	ABC-Active body control (N51/2)
ACT1186	Cyclically alternating actuation of front and rear suspension struts (pitch)	ABC-Active body control (N51/2)
ACT1187	Release of system pressure	ABC-Active body control (N51/2)
ACT1188	PRE-SAFE?system	ESP-Electric stability program (N30/4)
ACT1189	Headlamp range adjustment of both lamps units	XALWA L-Left xenon headlamp (E1n1)
ACT1190	Active curve lights of both lamp units	XALWA L-Left xenon headlamp (E1n1)
ACT1191	M18/13 (Left rear seat head restraint height adjustment motor)	ESE_RL-Left rear electrical seat adjustment
ACT1192	M18/15 (Left rear seat head restraint inclination adjustment motor)	ESE_RL-Left rear electrical seat adjustment
ACT1193	M27/11 (Left rear seat backrest inclination adjustment motor)	ESE_RL-Left rear electrical seat adjustment
ACT1194	M18/19 (Left rear seat cushion inclination adjustment motor)	ESE_RL-Left rear electrical seat adjustment
ACT1195	M18/23 (Left rear seat leg rest inclination adjustment motor)	ESE_RL-Left rear electrical seat adjustment
ACT1196	M18/25 (Left rear seat leg rest fore/aft adjustment motor)	ESE_RL-Left rear electrical seat adjustment
ACT1197	M18/14 (Right rear seat head restraint height adjustment motor)	Right rear ESE-Right rear electrical seat adjustment

ACT1198	M18/16 (Right rear seat head restraint inclination adjustment motor)	Right rear ESE-Right rear electrical seat adjustment
ACT1199	M53/3 (Center rear passenger compartment head restraint adjustment motor)	Right rear ESE-Right rear electrical seat adjustment
ACT1200	M28/11 (Right rear seat backrest inclination adjustment motor)	Right rear ESE-Right rear electrical seat adjustment
ACT1201	M18/20 (Right rear seat cushion inclination adjustment motor)	Right rear ESE-Right rear electrical seat adjustment
ACT1202	M18/24 (Right rear seat leg rest inclination adjustment motor)	Right rear ESE-Right rear electrical seat adjustment
ACT1203	M18/26 (Right rear seat leg rest fore/aft adjustment motor)	Right rear ESE-Right rear electrical seat adjustment
ACT1204	Switch and controls illumination of switch ''S52/6 (Rear seat center head restraint height adjustment switch)''	Right rear ESE-Right rear electrical seat adjustment
ACT1205	Unlock component ''A6n1 (Stationary heater control unit)''.	STH-Stationary heater
ACT1206	Cabled headphones(Only for the development department)	D FOL-Display in left rear passenger compartment
ACT1207	TestBackground illumination	D FOL-Display in left rear passenger compartment
ACT1208	ActuationBackground illumination	D FOL-Display in left rear passenger compartment
ACT1209	The position ''LVDS'' is faulty.	D FOL-Display in left rear passenger compartment
ACT1210	{Actuation} {Button illumination} {Switch and controls illumination}	AVE H-Controller unit Rear entertainment system
ACT1211	Self-test Handset	AVE H-Controller unit Rear entertainment system
ACT1212	Speaker Handset	AVE H-Controller unit Rear entertainment system
ACT1213	Microphone Handset	AVE H-Controller unit Rear entertainment system
ACT1214	Audio and video signal lines	AVE H-Controller unit Rear entertainment system
ACT1215	Display in left rear passenger compartment	AVE H-Controller unit Rear entertainment system
ACT1216	Display in right rear passenger compartment	AVE H-Controller unit Rear entertainment system
ACT1217	DVD/Blu-ray drive	AVE H-Controller unit Rear entertainment system

ACT1218	N72/1s37 (Air recirculation mode button)	FLANFS-Fire extinguishing system and emergency fresh air system
ACT1219	A48/4h1 (Warning buzzer)	FLANFS-Fire extinguishing system and emergency fresh air system
ACT1220	Actuation of components ''M90/1 (Left vent flap actuator motor)'' and ''M90/2 (Right vent flap actuator motor)''	FLANFS-Fire extinguishing system and emergency fresh air system
ACT1221	Check cylinder pressure of emergency fresh air system.	FLANFS-Fire extinguishing system and emergency fresh air system
ACT1222	Check cylinder pressure of fire extinguishing system.	FLANFS-Fire extinguishing system and emergency fresh air system
ACT1223	Function illumination of component ''A48/4s4 (Emergency fresh-air system/fire extinguishing system activation button)''	FLANFS-Fire extinguishing system and emergency fresh air system
ACT1224	Function illumination of component ''A48/4s6 (Emergency fresh-air system button)''	FLANFS-Fire extinguishing system and emergency fresh air system
ACT1225	Function illumination of component ''A48/4s5 (Fire extinguishing system button)''	FLANFS-Fire extinguishing system and emergency fresh air system
ACT1226	Determination of demagnetization of electric motor	SG EM-Power electronics
ACT1227	Actuation of component ''H4/31 (Exhaust system sound generator speaker)''-Frequency range	SG SOGE AGA-Sound generator for exhaust system
ACT1228	Actuation of air cushions in seat side bolsters Seat backrest	MKS LF-Left front multicontour seat
ACT1229	Actuation of air cushions in seat side bolsters Seat cushion	MKS LF-Left front multicontour seat
ACT1230	Dynamic test	ABC-Active body control (N51/2)
ACT1231	LEDs of component ''N72 (Lower control panel control unit)''	ABC-Active body control (N51/2)
ACT1232	Release pressure in suspension struts.	ABC-Active body control (N51/2)
ACT1233	Switch illumination ''Loading aid''	STC-Soft top control (N52)
ACT1234	M49/1 (Side flaps motor)	STC-Soft top control (N52)
ACT1235	Actuation of trunk lid	STC-Soft top control (N52)
ACT1236	H4/60 (Trunk lid control warning buzzer)	STC-Soft top control (N52)
ACT1237	Resetting adaptation values of component ''Park pawl''	SG EM-Power electronics

ACT1238	F58kT (Heated windshield relay)	PTCU-Common powertrain controller(N127)
ACT1239	Y19/1 (High-voltage battery cooling shutoff valve)	PTCU-Common powertrain controller(N127)
ACT1240	F58kM (Circuit 87C relay)	PTCU-Common powertrain controller(N127)
ACT1241	F58kN (Terminal 87T relay)	PTCU-Common powertrain controller(N127)
ACT1242	M2/16 (Park pawl actuator motor)	PTCU-Common powertrain controller(N127)
ACT1243	Pre-air conditioning	PTCU-Common powertrain controller(N127)
ACT1244	Actuation of component ''Radiator shutters''	N127 (Drivetrain control unit)
ACT1245	Bleeding of coolant circuit	N127 (Drivetrain control unit)
ACT1246	PTC heater ''High voltage''	N127 (Drivetrain control unit)
ACT1247	Actuation of component ''Vacuum pump''	N127 (Drivetrain control unit)
ACT1248	Start enable status of component ''Fuel cell system''	N127 (Drivetrain control unit)
ACT1249	Start enable status of component ''N127 (Drivetrain control unit)''	N127 (Drivetrain control unit)
ACT1250	M43/12 (Left fuel cell cooling coolant pump)	N127 (Drivetrain control unit)
ACT1251	M75/10 (High-voltage battery coolant pump)	N127 (Drivetrain control unit)
ACT1252	M43/13 (Center fuel cell cooling coolant pump)	N127 (Drivetrain control unit)
ACT1253	Release of coolant pumps	N127 (Drivetrain control unit)
ACT1254	Locking of coolant pumps	N127 (Drivetrain control unit)
ACT1255	Y138 (High temperature coolant circuit regulation valve 1)	N127 (Drivetrain control unit)
ACT1256	Y85 (Low temperature coolant circuit 1 regulation valve 1)	N127 (Drivetrain control unit)
ACT1257	M51/3m1 (Right liftgate control electric motor)-M51/5m1 (Left liftgate control electric motor)	HKS-Tailgate control

ACT1258	Warning buzzer	IC-Instrument cluster
ACT1259	Function illumination of component ''S62/29 (Fire extinguishing system button)''	FLANFS-Fire extinguishing system and emergency fresh air system
ACT1260	Function illumination of component ''S62/41 (Fire extinguishing system activation button)''	FLANFS-Fire extinguishing system and emergency fresh air system
ACT1261	H13 (Fire extinguishing system warning buzzer)	FLANFS-Fire extinguishing system and emergency fresh air system
ACT1262	Activate air recirculation mode.	FLANFS-Fire extinguishing system and emergency fresh air system
ACT1263	Rear passenger compartment seat heater	N10/8 (Rear passenger compartment control unit)
ACT1264	M14/7 (Rear-end door central locking motor)	N10/8 (Rear passenger compartment control unit)
ACT1265	LEDs of components ''S51/3 (Left rear seat heater button)'' and ''S51/4 (Right rear seat heater button)''	N10/8 (Rear passenger compartment control unit)
ACT1266	LEDs of component ''S51/3 (Left rear seat heater button)''	N10/8 (Rear passenger compartment control unit)
ACT1267	LEDs of component ''S51/4 (Right rear seat heater button)''	N10/8 (Rear passenger compartment control unit)
ACT1268	DC/AC converter	N10/8 (Rear passenger compartment control unit)
ACT1269	Sliding roof	N10/8 (Rear passenger compartment control unit)
ACT1270	Y54 (Right rear axle damper valve unit)	ADS-Adaptive damping system(N51/5)
ACT1271	Actuator motors for headlamp range adjustment	SG SW-Control unit 'Headlamp' (N71/1)
ACT1272	Switch status	EAGGS-Electric differential lock
ACT1273	Light warning buzzer	ICM-Instrument cluster with maintenance interval display
ACT1274	Gauges	ICM-Instrument cluster with maintenance interval display
ACT1275	Automatic dimming mirror	EAM-Extended activity module
ACT1276	Rear window defroster	EAM-Extended activity module
ACT1277	Left front entrance lamp	EAM-Extended activity module

ACT1278	Right front entrance lamp	EAM-Extended activity module
ACT1279	Left rear entrance lamp	EAM-Extended activity module
ACT1280	Right rear entrance lamp	EAM-Extended activity module
ACT1281	Lamella roof/Sliding/tilting roof	EAM-Extended activity module
ACT1282	F2k9 (Relay 9) (Terminal 15)	EAM-Extended activity module
ACT1283	Wake-up cable to control module AAM	EAM-Extended activity module
ACT1284	Open/close everything	AAM-All Activity Module
ACT1285	Open driver door tailgate	AAM-All Activity Module
ACT1286	Auxiliary fan	AAM-All Activity Module
ACT1287	Interior blower	AAM-All Activity Module
ACT1288	Circulation pump	AAM-All Activity Module
ACT1289	Heater booster	AAM-All Activity Module
ACT1290	Front wiper	AAM-All Activity Module
ACT1291	Rear wiper	AAM-All Activity Module
ACT1292	Fog lamps	AAM-All Activity Module
ACT1293	Turn signals	AAM-All Activity Module
ACT1294	Hazard warning display	AAM-All Activity Module
ACT1295	Interior lighting	AAM-All Activity Module
ACT1296	Convenience relay	AAM-All Activity Module
ACT1297	Power windows	AAM-All Activity Module

ACT1298	Horn	AAM-All Activity Module
ACT1299	Alarm signal horn	AAM-All Activity Module
ACT1300	ATA status display	AAM-All Activity Module
ACT1301	Low beam	AAM-All Activity Module
ACT1302	Main beam	AAM-All Activity Module
ACT1303	Left parking lamp	AAM-All Activity Module
ACT1304	Right parking lamp	AAM-All Activity Module
ACT1305	License plate lights	AAM-All Activity Module
ACT1306	Foglights	AAM-All Activity Module
ACT1307	Rear foglight	AAM-All Activity Module
ACT1308	Buzzer signal to control module Instrument cluster	AAM-All Activity Module
ACT1309	Signal to hazard warning light	AAM-All Activity Module
ACT1310	H1 (Two-tone signal system)	AAM-All Activity Module
ACT1311	H3/1 (Alarm signal siren with additional battery)	AAM-All Activity Module
ACT1312	S97/6e3 (ATA status indicator)	AAM-All Activity Module
ACT1313	Signal from interior motion/towing sensor	AAM-All Activity Module
ACT1314	Alarm signal to control module E-call	AAM-All Activity Module
ACT1315	H3 (Alarm signal horn)	AAM-All Activity Module
ACT1316	Front left power window	AAM-All Activity Module
ACT1317	Front right power window	AAM-All Activity Module

ACT1318	Left front interior light	AAM-All Activity Module
ACT1319	Right front interior light	AAM-All Activity Module
ACT1320	Left rear interior light	AAM-All Activity Module
ACT1321	Right rear interior light	AAM-All Activity Module
ACT1322	Engine fan	AAM-All Activity Module
ACT1323	Convenience relay for seats	AAM-All Activity Module
ACT1324	Convenience relay for windows and roof	AAM-All Activity Module
ACT1325	F1k11 (Diesel voltage supply relay)	AAM-All Activity Module
ACT1326	F1k12 (Circuit 15 relay)	AAM-All Activity Module
ACT1327	F1k27 (Rear door washer pump relay)	AAM-All Activity Module
ACT1328	LED in switch S6/1s4 (Tailgate wiper switch)	AAM-All Activity Module
ACT1329	Central locking	AAM-All Activity Module
ACT1330	Denormalizing of Right front power window	LCP-Lower operating panel with power window function
ACT1331	Denormalizing of left rear power window	LCP-Lower operating panel with power window function
ACT1332	Denormalizing of right rear power window	LCP-Lower operating panel with power window function
ACT1333	LEDs for blower speed	LCP-Lower operating panel with power window function
ACT1334	LEDs for blower direction	LCP-Lower operating panel with power window function
ACT1335	Mirror housing adjustment Left	LCP-Lower operating panel with power window function
ACT1336	Mirror housing adjustment Right	LCP-Lower operating panel with power window function
ACT1337	Display test images on the LCD display.	COMAND

ACT1338	Output of test tone	COMAND
ACT1339	Test of fader setting	COMAND
ACT1340	Test of voice output	COMAND
ACT1341	M2/8 (Defroster flap positioning motor)	AAC-Automatic air conditioning
ACT1342	M2/22 (Center vent flap positioning motor)/M2/6 (Blended air flap positioning motor)	AAC-Automatic air conditioning
ACT1343	M2/5 (Fresh and recirculated air flap positioning motor)	AAC-Automatic air conditioning
ACT1344	M2/1 (Rear blower motor)	AAC-Automatic air conditioning
ACT1345	M13 (Heating water circulation pump)/M2/2 (Module box blower motor)	AAC-Automatic air conditioning
ACT1346	A9 (AC compressor)	AAC-Automatic air conditioning
ACT1347	R1 (rear window defroster)	AAC-Automatic air conditioning
ACT1348	Y32 (Air pump switchover valve)M33 (electric air pump)	ME SFI 2.8-Motor electronics 2.8
ACT1349	M3/1 (Intank fuel pump)	ME SFI 2.8-Motor electronics 2.8
ACT1350	Y31/1 (EGR vacuum transducer)	ME SFI 2.8-Motor electronics 2.8
ACT1351	Electric suction fan for engine or air conditioning	ME SFI 2.8-Motor electronics 2.8
ACT1352	Ignition circuit shutoffT1/x (ignition coil(s))	ME SFI 2.8-Motor electronics 2.8
ACT1353	Y2/1 (Supercharger magnetic clutch)	ME SFI 2.8-Motor electronics 2.8
ACT1354	M44/1 (Left charge air cooler circulation pump)M44/2 (Right charge air cooler circulation pump)	ME SFI 2.8-Motor electronics 2.8
ACT1355	M16/7 (Recirculating air flap actuator)	ME SFI 2.8-Motor electronics 2.8
ACT1356	Actuation of exhaust gas recirculation	CDI 2-Common Rail Diesel Injection
ACT1357	Y75 (Electric switchover valve)	CDI 2-Common Rail Diesel Injection

ACT1358	M56 (Brake booster vacuum pump)	VP-Vacuum pump brake booster
ACT1359	Test actuation of component M3 (Fuel pump).	CDI V-Common Rail Diesel Injection
ACT1360	Test actuation of component Y83 (Inlet port shutoff switchover valve).	CDI V-Common Rail Diesel Injection
ACT1361	Check components Y27/9 (Left EGR positioner) and Y27/10 (Right EGR positioner) via actuation.	CDI V-Common Rail Diesel Injection
ACT1362	Check components Y100 (Left charge pressure positioner) and Y100/1 (Right charge pressure positioner) via actuation.	CDI V-Common Rail Diesel Injection
ACT1363	Test actuation of component M16/5 (Throttle valve actuator).	CDI V-Common Rail Diesel Injection
ACT1364	Test actuation of component M44 (charge air cooler circulation pump).	CDI V-Common Rail Diesel Injection
ACT1365	M16/3 (Front throttle valve actuator) M16/4 (Rear throttle valve actuator)	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)
ACT1366	M3 (Right fuel pump) M3/2 (Left fuel pump)	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)
ACT1367	R48 (Two-disk thermostat heating element)	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)
ACT1368	M45 (Engine coolant circulation pump)	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)
ACT1369	M13/9 (Power electronics circulation pump 2)	ME SF 17.7-Motor electronics 17.7
ACT1370	Current battery capacity	ME SF 17.7-Motor electronics 17.7
ACT1371	Automatic engine start/stop	HSG-Hybrid control unit
ACT1372	Erasing of crash-relevant fault codes	HSG-Hybrid control unit
ACT1373	Regenerative braking system	HSG-Hybrid control unit
ACT1374	R/P locking solenoid	GRM-Gear recognition module
ACT1375	Reversing lamp	GRM-Gear recognition module
ACT1376	Illumination of shift indicator	GRM-Gear recognition module
ACT1377	Refrigerant compressor	TAC-Automatic temperature control

ACT1378	Fresh air and recirculated air flap	TAC-Automatic temperature control
ACT1379	Blending air flap	TAC-Automatic temperature control
ACT1380	Suction fan	TAC-Automatic temperature control
ACT1381	PTC heater booster	TAC-Automatic temperature control
ACT1382	PTC enable	TAC-Automatic temperature control
ACT1383	Additional water pump	TAC-Automatic temperature control
ACT1384	Blower stage 1	TAC-Automatic temperature control
ACT1385	Test of compression	CDI-Common Rail Diesel Injection
ACT1386	M3(Fuel pump)	ME SFI-Gasoline engine control
ACT1387	M4/7(Engine and AC electric suction fan with integrated control)	ME SFI-Gasoline engine control
ACT1388	Y58/1(Purge control valve)	ME SFI-Gasoline engine control
ACT1389	Idle speed controller	ME SFI-Gasoline engine control
ACT1390	Actuate light warning buzzer.	IC-Instrument cluster
ACT1391	Move instrument pointer.	IC-Instrument cluster
ACT1392	Bulb Test	IC-Instrument cluster
ACT1393	Shift lock	ESM-Electronic selector module
ACT1394	Lamella roof(Draft stop)	OCP-Overhead control panel
ACT1395	Automatic air conditioning	ATA-Anti theft alarm system
ACT1396	Left tail light	AHE-Trailer recognition
ACT1397	Right tail light	AHE-Trailer recognition

ACT1398	Stop lamp	AHE-Trailer recognition
ACT1399	Output Two-way radio set 1	MSS-Special vehicle multifunction control module
ACT1400	Output Two-way radio set 2	MSS-Special vehicle multifunction control module
ACT1401	Output Rear foglight	MSS-Special vehicle multifunction control module
ACT1402	Output Left turn signal	MSS-Special vehicle multifunction control module
ACT1403	Output Right turn signal	MSS-Special vehicle multifunction control module
ACT1404	Output Horn	MSS-Special vehicle multifunction control module
ACT1405	Output Low beam	MSS-Special vehicle multifunction control module
ACT1406	Output Terminal 15(6A)	MSS-Special vehicle multifunction control module
ACT1407	Output Flashlights in trunk lid	MSS-Special vehicle multifunction control module
ACT1408	Output Main beam	MSS-Special vehicle multifunction control module
ACT1409	Output Reverse gear	MSS-Special vehicle multifunction control module
ACT1410	Output Stop lamp	MSS-Special vehicle multifunction control module
ACT1411	Output Side lamp	MSS-Special vehicle multifunction control module
ACT1412	Output Terminal 30(10A)	MSS-Special vehicle multifunction control module
ACT1413	Output Terminal 15(10A)	MSS-Special vehicle multifunction control module
ACT1414	Denormalize power windows.	DCM FL-Door control module front left
ACT1415	Actuation Front left power window	DCM FL-Door control module front left
ACT1416	Mirror housing adjustment	DCM FL-Door control module front left
ACT1417	E17/3(Left front door entrance/exit and warning lamp)	DCM FL-Door control module front left

ACT1418	E6/5(Left exterior mirror turn signal lamp)	DCM FL-Door control module front left
ACT1419	Function lighting	DCM FL-Door control module front left
ACT1420	Switch illumination(Terminal 58d)	DCM FL-Door control module front left
ACT1421	Actuation Front right power window	DCM FR-Door control module front right
ACT1422	E17/4(Right front door entrance/exit and warning lamp)	DCM FR-Door control module front right
ACT1423	E6/6(Right exterior mirror turn signal lamp)	DCM FR-Door control module front right
ACT1424	Denormalizing of left rear power windows	DCM RL-Door control module rear left
ACT1425	Actuation Rear left power window	DCM RL-Door control module rear left
ACT1426	Denormalizing of right rear power windows.	DCM RR-Door control module rear right
ACT1427	Actuation Rear right power window	DCM RR-Door control module rear right
ACT1428	M3/3 (Fuel pump with fuel tank sensor)	CDI-Common Rail Diesel Injection
ACT1429	Y100/2 (Boost pressure regulator)	CDI-Common Rail Diesel Injection
ACT1430	Gong in instrument cluster	VR-Vario roof
ACT1431	Auxiliary(or Aspirator) fan stages	TAC-Automatic temperature control
ACT1432	A/C compressor electromagnetic coupling	TAC-Automatic temperature control
ACT1433	Fresh air and recirculating air flaps	TAC-Automatic temperature control
ACT1434	Idle speed increase	TAC-Automatic temperature control
ACT1435	Y49(Adjustable camshaft timing solenoid)	ME SFI-Motor electronics
ACT1436	Y58/4(Activated charcoal canister shut-off valve) , (Only valid for USA vehivles)	ME SFI-Motor electronics
ACT1437	Secondary air valve	ME SFI-Motor electronics

ACT1438	Roller dynamometer	ESP-Electronic stability program
ACT1439	Y58/4 (Activated charcoal canister shut-off valve) (Only valid for USA vehicles)	ME SFI-Motor electronics
ACT1440	Y62y1 (Cylinder 1 injector)	ME SFI-Motor electronics
ACT1441	Y62y2 (Cylinder 2 injector)	ME SFI-Motor electronics
ACT1442	Y62y3 (Cylinder 3 injector)	ME SFI-Motor electronics
ACT1443	Y62y4 (Cylinder 4 injector)	ME SFI-Motor electronics
ACT1444	Secondary air valve-Test secondary air injection (function chain).	ME SFI-Motor electronics
ACT1445	Exhaust flap	ME SFI-Motor electronics
ACT1446	Actuate pointer instruments	IC-Instrument cluster
ACT1447	Actuate warning buzzer	IC-Instrument cluster
ACT1448	Footwell lights	SAM F-Signal acquisition and actuation module front
ACT1449	LED fog light	SAM F-Signal acquisition and actuation module front
ACT1450	LED Rear foglight	SAM F-Signal acquisition and actuation module front
ACT1451	M5/1(Windshield washer fluid pump)	SAM F-Signal acquisition and actuation module front
ACT1452	M5/2(HCS pump)	SAM F-Signal acquisition and actuation module front
ACT1453	M6/1(wiper motor)	SAM F-Signal acquisition and actuation module front
ACT1454	R2/1(Heated windshield washer nozzle)	SAM F-Signal acquisition and actuation module front
ACT1455	N10/1kP(Circuit 15 relay)	SAM F-Signal acquisition and actuation module front
ACT1456	N10/1kM(Starter circuit 50 relay)	SAM F-Signal acquisition and actuation module front
ACT1457	N10/1kI (Fanfare horns relay)	SAM F-Signal acquisition and actuation module front

ACT1458	N10/2kF(Circuit 15R relay 1)	REAR SAM-Rear signal acquisition and actuation module
ACT1459	N10/2kB(Circuit 15R relay 2)	REAR SAM-Rear signal acquisition and actuation module
ACT1460	Fuel filler cap lock	REAR SAM-Rear signal acquisition and actuation module
ACT1461	A44/4 (PTS warning display, instrument panel center)	PTS-Parktronic system
ACT1462	A44/3 (Rear PTS warning display)	PTS-Parktronic system
ACT1463	Denormalize power windows	DCM L-Door control module left
ACT1464	Mirror lens adjustment	DCM L-Door control module left
ACT1465	Mirror housing adjustment	DCM L-Door control module left
ACT1466	E17/3(Left door entrance/exit lamp)	DCM L-Door control module left
ACT1467	Mirror park position	DCM R-Door control module right
ACT1468	E17/3(Right door entrance/exit lamp)	DCM R-Door control module right
ACT1469	Forward/back adjustment	ESV driver-Electric seat adjustment driver (with memory)
ACT1470	Height at front	ESV driver-Electric seat adjustment driver (with memory)
ACT1471	Height at rear	ESV driver-Electric seat adjustment driver (with memory)
ACT1472	Backrest	ESV driver-Electric seat adjustment driver (with memory)
ACT1473	Head restraint	ESV driver-Electric seat adjustment driver (with memory)
ACT1474	Function illumination for variable speed limiter	SCM [MRM]-Steering column module
ACT1475	Search illumination of multifunction steering wheel	SCM [MRM]-Steering column module
ACT1476	Function illumination for steering wheel heater	SCM [MRM]-Steering column module
ACT1477	M2/16(Left and right defroster flaps actuator)	AAC-Automatic air conditioning

ACT1478	M2/15(Left and right footwell flaps actuator)	AAC-Automatic air conditioning
ACT1479	M2/5(Fresh and recirculated air flaps actuator)	AAC-Automatic air conditioning
ACT1480	A32ml(Blower motor)	AAC-Automatic air conditioning
ACT1481	Actuation of switch and control illumination	AAC-Automatic air conditioning
ACT1482	Left head area ventilation	HS-Seat heater
ACT1483	Right head area ventilation	HS-Seat heater
ACT1484	M5/1 (Windshield washer fluid pump)	SAM F-Signal acquisition and actuation module front
ACT1485	Washer nozzle and washer nozzle hose heater	SAM F-Signal acquisition and actuation module front
ACT1486	Wipers	SAM F-Signal acquisition and actuation module front
ACT1487	Switch illumination:Exterior lamp switch, E10/2 (Left air vent illumination), E10/1 (Center air vent illumination), E10/3	SAM F-Signal acquisition and actuation module front
ACT1488	N10/1kI (Fanfare horns relay)	SAM F-Signal acquisition and actuation module front
ACT1489	Actuation	AHE-Trailer recognition
ACT1490	Radio muting	E call [Japan]-Telematic system
ACT1491	Y100/1 (Right charge pressure positioner)	CDI 3-Common Rail Diesel Injection3
ACT1492	Actuation: Headlamp range adjustment of Right headlamp	XALWA R-Xenon headlamp, right
ACT1493	Soft top operating switch indicator lamp	RVC-Rollover bar soft top control module
ACT1494	Rollover bar bow operating switch indicator lamp	RVC-Rollover bar soft top control module
ACT1495	Gong	RVC-Rollover bar soft top control module
ACT1496	Memory Mirror position	DCM L-Door control module left
ACT1497	Exit light	DCM L-Door control module left

ACT1498	Door interior lighting	DCM L-Door control module left
ACT1499	Additional turn signal light in exterior mirror	DCM L-Door control module left
ACT1500	LED Trunk lid remote release	DCM L-Door control module left
ACT1501	Injection valves	ME SFI-Motor electronics
ACT1502	Actuation of mixture adaptation	ME SFI-Motor electronics
ACT1503	Alternator serial interface	ME SFI-Motor electronics
ACT1504	Camshaft positioner 'Intake'	ME SFI-Motor electronics
ACT1505	Camshaft positioner 'Exhaust'	ME SFI-Motor electronics
ACT1506	Carry out compression test.	ME SFI-Motor electronics
ACT1507	Mode	ME SFI-Motor electronics
ACT1508	Y107/1y1 (Gas cylinder 1 shutoff valve)-Y107/1y4 (Gas cylinder 4 shutoff valve)/Y107/2 (Gas safety shutoff valve)	ME SFI-Motor electronics
ACT1509	Check component Y107/2 (Gas safety shutoff valve).	ME SFI-Motor electronics
ACT1510	Evacuating the gas system	ME SFI-Motor electronics
ACT1511	Filling the gas system	ME SFI-Motor electronics
ACT1512	Release pressure in left front suspension strut.	AIRmatic
ACT1513	Release pressure in right front suspension strut.	AIRmatic
ACT1514	Release pressure in left rear suspension strut.	AIRmatic
ACT1515	Release pressure in right rear suspension strut.	AIRmatic
ACT1516	Release pressure in the rear suspension strut.This function is needed in cases where both rear suspension struts are replaced	AIRmatic
ACT1517	Fill left front suspension strut.	AIRmatic

ACT1518	Fill right front suspension strut.	AIRmatic
ACT1519	Fill left rear suspension strut.	AIRmatic
ACT1520	Fill right rear suspension strut.	AIRmatic
ACT1521	Y51/1 (AIRmatic valve unit, left front suspension strut)	AIRmatic
ACT1522	Y52/1 (AIRmatic valve unit, right front suspension strut)	AIRmatic
ACT1523	Y53/1 (AIRmatic valve unit, left rear suspension strut)	AIRmatic
ACT1524	Y54/1 (AIRmatic valve unit, right rear suspension strut)	AIRmatic
ACT1525	Front axle/Rear axle RAISE + LOWER	AIRmatic
ACT1526	K75 (Cutoff relay for interruptible loads)	BCM-Battery control module
ACT1527	K57/2 (Auxiliary battery relay)	BCM-Battery control module
ACT1528	Standing and parking lamp 'Driver's side'	Dr side SAM-Driver signal acquisition and actuation module
ACT1529	Low beam 'Driver's side'	Dr side SAM-Driver signal acquisition and actuation module
ACT1530	High beam 'Driver's side'	Dr side SAM-Driver signal acquisition and actuation module
ACT1531	Fog lamp 'Driver's side'	Dr side SAM-Driver signal acquisition and actuation module
ACT1532	Front turn signal lamp 'Driver's side'	Dr side SAM-Driver signal acquisition and actuation module
ACT1533	Front side marker lamp 'Driver's side'	Dr side SAM-Driver signal acquisition and actuation module
ACT1534	Front side marker lamp 'Passenger side'	Dr side SAM-Driver signal acquisition and actuation module
ACT1535	Gear display	Dr side SAM-Driver signal acquisition and actuation module
ACT1536	LED Fog light	Dr side SAM-Driver signal acquisition and actuation module
ACT1537	M5/3 (Tailgate washer fluid pump)	Dr side SAM-Driver signal acquisition and actuation module

ACT1538	M5/2 (HCS pump)	Dr side SAM-Driver signal acquisition and actuation module
ACT1539	M16/32 (Heat exchanger shutoff motor)	Dr side SAM-Driver signal acquisition and actuation module
ACT1540	N10/1kN (Circuit 15 relay)\nN10/1kK (Circuit 87 relay, chassis)	Dr side SAM-Driver signal acquisition and actuation module
ACT1541	N10/1kP (Circuit 15R relay)	Dr side SAM-Driver signal acquisition and actuation module
ACT1542	N10/1kO (FAN relay module)	Dr side SAM-Driver signal acquisition and actuation module
ACT1543	Standing and parking lamp 'Front-passenger side'	Pass side SAM-Passenger-side signal acquisition and actuation module
ACT1544	Low beam 'Passenger side'	Pass side SAM-Passenger-side signal acquisition and actuation module
ACT1545	High beam 'Passenger side'	Pass side SAM-Passenger-side signal acquisition and actuation module
ACT1546	Fog lamp 'Front-passenger side'	Pass side SAM-Passenger-side signal acquisition and actuation module
ACT1547	Turn signal lamp 'Front-passenger side'	Pass side SAM-Passenger-side signal acquisition and actuation module
ACT1548	Surround lamp Trunk lid	REAR SAM-Rear signal acquisition and actuation module
ACT1549	Actuation of rear window defroster relay	REAR SAM-Rear signal acquisition and actuation module
ACT1550	Rear blind	REAR SAM-Rear signal acquisition and actuation module
ACT1551	Open or close the switch panel	UCP-Upper control panel
ACT1552	Dome lamp	OCP-Overhead control panel
ACT1553	Left front reading lamp	OCP-Overhead control panel
ACT1554	Right front reading lamp	OCP-Overhead control panel
ACT1555	Left rear reading lamp	OCP-Overhead control panel
ACT1556	Right rear reading lamp	OCP-Overhead control panel
ACT1557	Automatic interior mirror dimming	OCP-Overhead control panel

ACT1558	Open or close central locking	DCM FL-Door control module front left
ACT1559	Mirror housing adjustment(Special equipment)	DCM FL-Door control module front left
ACT1560	Mirror memory(Special equipment)	DCM FL-Door control module front left
ACT1561	Front passenger exterior mirror in park position(Special equipment)	DCM FL-Door control module front left
ACT1562	Warning lamp	DCM FL-Door control module front left
ACT1563	Surround lamp	DCM FL-Door control module front left
ACT1564	LED E17/11 (Left front door inside handle illumination)	DCM FL-Door control module front left
ACT1565	LED' Trunk lid opened'	DCM FL-Door control module front left
ACT1566	LED' Childproof lock activated'	DCM FL-Door control module front left
ACT1567	LED E17/12 (Right front door inside handle illumination)	DCM FR-Door control module front right
ACT1568	LED Childproof locks	DCM FR-Door control module front right
ACT1569	Switch illumination Terminal 58d	DCM RL-Door control module rear left
ACT1570	E17/13 (Left rear door inside handle illumination)	DCM RL-Door control module rear left
ACT1571	E17/14 (Right rear door inside handle illumination)	DCM RR-Door control module rear right
ACT1572	Check component M16/32 (Heat exchanger shutoff motor).	AAC-Automatic air conditioning
ACT1573	Check of LEDs	AAC-Automatic air conditioning
ACT1574	R22/4(Steering wheel heater)	LRH-Steering wheel heater
ACT1575	Loading floor automatically extendable	LAE [LAA]-Loading floor automatically extendable
ACT1576	Reversing lights	RWT-Rear end door control module
ACT1577	Signal 'Rear-end door open'	RWT-Rear end door control module

ACT1578	Rear-end door lock	RWT-Rear end door control module
ACT1579	Unlock and lock central locking.	RWT-Rear end door control module
ACT1580	Check component Y27 (Exhaust gas recirculation positioner) by means of actuation.	CDI5-Common Rail Diesel Injection(USA)
ACT1581	Check component Y77/1 (Boost pressure regulator) by means of actuation.	CDI5-Common Rail Diesel Injection(USA)
ACT1582	Pressure regulator valve and quantity control valve	CDI5-Common Rail Diesel Injection(USA)
ACT1583	A1e58 (Engine diagnosis malfunction indicator lamp)	CDID-Common Rail Diesel Injection
ACT1584	Y125 (Low temperature cooling system shutoff valve)	MED 9.7-Motor electronics for direct injection 9.7
ACT1585	Y62(Fuel injectors)	ME SFI 2.0-Motor electronics 2.0
ACT1586	M4/3 (engine/AC electric suction fan)	ME SFI 2.0-Motor electronics 2.0
ACT1587	A7/3y6 (front left solenoid valve, hold pressure)	ESP-Electronic stability program
ACT1588	A7/3y7 (front left solenoid valve, reduce pressure)	ESP-Electronic stability program
ACT1589	A7/3y8 (front right solenoid valve, hold pressure)	ESP-Electronic stability program
ACT1590	A7/3y9 (front right solenoid valve, reduce pressure)	ESP-Electronic stability program
ACT1591	A7/3y10 (rear left solenoid valve, hold pressure)	ESP-Electronic stability program
ACT1592	A7/3y11(rear left solenoid valve, reduce pressure)	ESP-Electronic stability program
ACT1593	A7/3y12 (rear right solenoid valve, hold pressure)	ESP-Electronic stability program
ACT1594	A7/3y13 (rear right solenoid valve, reduce pressure)	ESP-Electronic stability program
ACT1595	A7/3y18 (front axle switchover solenoid valve)	ESP-Electronic stability program
ACT1596	A7/3y19 (rear axle switchover solenoid valve)	ESP-Electronic stability program
ACT1597	A7/3y22 (front axle inlet solenoid valve)	ESP-Electronic stability program

ACT1598	A7/3y23 (rear axle inlet solenoid valve)	ESP-Electronic stability program
ACT1599	Control module reset	ICM-Instrument cluster with maintenance interval display
ACT1600	Brightness of instrument lighting	ICM-Instrument cluster with maintenance interval display
ACT1601	Test of signal transmission between A69/1 (left front tire pressure monitor sensor) and N88 (TPM [RDK] control unit)	TPM-Tire pressure monitor
ACT1602	Test of signal transmission between A69/2 (right front tire pressure monitor sensor) and N88 (TPM [RDK] control unit)	TPM-Tire pressure monitor
ACT1603	Test of signal transmission between A69/3 (left rear tire pressure monitor sensor) and N88 (TPM [RDK] control unit)	TPM-Tire pressure monitor
ACT1604	Test of signal transmission between A69/4 (rear right tire pressure control wheel sensor) and N88 (TPM [RDK] control	TPM-Tire pressure monitor
ACT1605	Illumination of shift indicator	ESM-Electronic selector module
ACT1606	Y86/1 (ABC suction restrictor valve)	ABC-Active body control (N51/2)
ACT1607	Control and locking valve of front left suspension strut	ABC-Active body control (N51/2)
ACT1608	Control and locking valve of front right suspension strut	ABC-Active body control (N51/2)
ACT1609	Control and locking valve of rear left suspension strut	ABC-Active body control (N51/2)
ACT1610	Control and locking valve of rear right suspension strut	ABC-Active body control (N51/2)
ACT1611	Cyclic switching of control valves with maximum positive and negative current	ABC-Active body control (N51/2)
ACT1612	Cyclically alternating actuation of left and right suspension struts (roll)	ABC-Active body control (N51/2)
ACT1613	Actuation Power window	DCM FL-Door control module front left
ACT1614	M21/lm3 (Mirror fold-in motor)	DCM FL-Door control module front left
ACT1615	M21/lr1 (Mirror heater)	DCM FL-Door control module front left
ACT1616	E17/11 (Left front door inside handle illumination)	DCM FL-Door control module front left
ACT1617	Switch search illumination	DCM FL-Door control module front left

ACT1618	Power locking	DCM FL-Door control module front left
ACT1619	M21/2m3 (Mirror fold-in motor)	DCM FR-Door control module front right
ACT1620	M21/2r1 (Mirror heater)	DCM FR-Door control module front right
ACT1621	E17/4 (Right front door entry/exit lamp)	DCM FR-Door control module front right
ACT1622	E17/12 (Right front door inside handle illumination)	DCM FR-Door control module front right
ACT1623	Switch search illumination	DCM FR-Door control module front right
ACT1624	Actuate orientation lighting.	RCM-Rear control module
ACT1625	A44/1 (PTS warning display, instrument panel driver side)	PTS-Parktronic system
ACT1626	A44/3 (PTS warning display, rear dome lamp)	PTS-Parktronic system
ACT1627	Right low beam	SAM FL-Front left signal acquisition and actuation module
ACT1628	Left front side lamp and parking lamp	SAM FL-Front left signal acquisition and actuation module
ACT1629	Left foglamp	SAM FL-Front left signal acquisition and actuation module
ACT1630	Left main beam	SAM FL-Front left signal acquisition and actuation module
ACT1631	Wiper rest heater	SAM FL-Front left signal acquisition and actuation module
ACT1632	Left low beam	SAM FR-Front right signal acquisition and actuation module
ACT1633	Right front side light and parking light	SAM FR-Front right signal acquisition and actuation module
ACT1634	Right fog light	SAM FR-Front right signal acquisition and actuation module
ACT1635	Right main beam	SAM FR-Front right signal acquisition and actuation module
ACT1636	Right front turn signal lamp	SAM FR-Front right signal acquisition and actuation module
ACT1637	Illumination for front ashtray, spectacles compartment, storage compartment and footwell	SAM FR-Front right signal acquisition and actuation module

ACT1638	Windshield washer pump	SAM FR-Front right signal acquisition and actuation module
ACT1639	K40/7kP (Fanfare horns relay)	SAM FR-Front right signal acquisition and actuation module
ACT1640	Rear screen	REAR SAM-Rear signal acquisition and actuation module
ACT1641	Trailer lighting	AHE-Trailer recognition
ACT1642	LED of component Trailer recognition	AHE-Trailer recognition
ACT1643	Front makeup light, rear makeup light	OCP-Overhead control panel
ACT1644	Unlock trunk lid	PSE-Pneumatic system equipment
ACT1645	Deactivate the child safety lock of the rear doors.	PSE-Pneumatic system equipment
ACT1646	Emergency opening by simulating the crash signal	PSE-Pneumatic system equipment
ACT1647	Duo valves	AAC-Automatic air conditioning
ACT1648	Defroster outlet flaps	AAC-Automatic air conditioning
ACT1649	Footwell flaps	AAC-Automatic air conditioning
ACT1650	Center outlets	AAC-Automatic air conditioning
ACT1651	Active carbon filter flap	AAC-Automatic air conditioning
ACT1652	Illumination of pushbutton control and of center outlets	AAC-Automatic air conditioning
ACT1653	Blower for in-car temperature at pushbutton control module	AAC-Automatic air conditioning
ACT1654	Normalizing of positioning motors	AAC-Automatic air conditioning
ACT1655	Actuation of stationary heater	AAC-Automatic air conditioning
ACT1656	All lift solenoids	KG-Keyless Go
ACT1657	L12 (Left front door Keyless Go lift solenoid)	KG-Keyless Go

ACT1658	L12/1 (Left rear door Keyless Go lift solenoid)	KG-Keyless Go
ACT1659	L12/2 (Right front door Keyless Go lift solenoid)	KG-Keyless Go
ACT1660	L12/3 (Right rear door Keyless Go lift solenoid)	KG-Keyless Go
ACT1661	A2/38 (Keyless Go antenna, left front door)	KG-Keyless Go
ACT1662	A2/39 (Keyless Go antenna, left rear door)	KG-Keyless Go
ACT1663	A2/40 (Keyless Go antenna, right front door)	KG-Keyless Go
ACT1664	A2/41 (Keyless Go antenna, right rear door)	KG-Keyless Go
ACT1665	A2/35 (Keyless Go antenna, trunk)	KG-Keyless Go
ACT1666	A2/31 (Keyless Go antenna, rear bumper)	KG-Keyless Go
ACT1667	Horn contact	MSS-Special vehicle multifunction control module
ACT1668	Taximeter	MSS-Special vehicle multifunction control module
ACT1669	Undervoltage check	MSS-Special vehicle multifunction control module
ACT1670	2nd battery	MSS-Special vehicle multifunction control module
ACT1671	Jack	MSS-Special vehicle multifunction control module
ACT1672	Roof sign	MSS-Special vehicle multifunction control module
ACT1673	Indicator for roof sign	MSS-Special vehicle multifunction control module
ACT1674	Radiophone	MSS-Special vehicle multifunction control module
ACT1675	Output Terminal 15	MSS-Special vehicle multifunction control module
ACT1676	ACTUATIONS	HRA-Headlamp range adjustment
ACT1677	M16/22 (Up/down air distribution actuator motor)	REAR AC-Rear air conditioning

ACT1678	Y67 (Rear air conditioning refrigerant shutoff valve)	REAR AC-Rear air conditioning
ACT1679	A31/1m1 (circulation pump)	REAR AC-Rear air conditioning
ACT1680	Rear lamp	OCP-Overhead control panel
ACT1681	Left front reading lamp	OCP-Overhead control panel
ACT1682	Automatic interior mirror dimming	OCP-Overhead control panel
ACT1683	Actuation of mechanical instrument pointers to maximum position	IC-Instrument cluster
ACT1684	Installation position of brake cables	EPB-Electric parking brake
ACT1685	Operate parking brake.	EPB-Electric parking brake
ACT1686	Test of signal transmission between A69/1 (Left front tire pressure sensor) and N88 (Tire pressure monitor control unit)	TPM-Tire pressure monitor
ACT1687	Test of signal transmission between A69/2 (Right front tire pressure sensor) and N88 (Tire pressure monitor control unit)	TPM-Tire pressure monitor
ACT1688	Test of signal transmission between A69/3 (Left rear tire pressure sensor) and N88 (Tire pressure monitor control unit)	TPM-Tire pressure monitor
ACT1689	Test of signal transmission between A69/4 (Right rear tire pressure sensor) and N88 (Tire pressure monitor control unit)	TPM-Tire pressure monitor
ACT1690	BAS Brake assist	ABR-Adaptive Brake
ACT1691	Set the driving level.	AIRmatic
ACT1692	Empty central reservoir.	AIRmatic
ACT1693	Actuation of LED in button 'Vehicle level'	AIRmatic
ACT1694	Release of system pressure	ABC-Active body control (N51/2)
ACT1695	SGRRadar sensors control unit	SGR-Radar sensors control unit
ACT1696	Test image on instrument cluster display	NSA-Night View Assist
ACT1697	Actuate component B84/2 (Night View Assist camera)	NSA-Night View Assist

ACT1698	Infrared headlamp	NSA-Night View Assist
ACT1699	Function test(Actuation of components)	KG-Keyless Go
ACT1700	M14/6 (Left front door central locking motor)	KG-Keyless Go
ACT1701	M14/5 (Right front door central locking motor)	KG-Keyless Go
ACT1702	M14/8 (CL left rear door motor)	KG-Keyless Go
ACT1703	M14/9 (CL right rear door motor)	KG-Keyless Go
ACT1704	AllMotors	KG-Keyless Go
ACT1705	A2/39 (Left door Keyless Go antenna)	KG-Keyless Go
ACT1706	A2/41 (Right door Keyless Go antenna)	KG-Keyless Go
ACT1707	A2/60 (Keyless Go antenna center console)	KG-Keyless Go
ACT1708	A2/61 (Keyless Go antenna, interior)	KG-Keyless Go
ACT1709	A17/1 (Left front Keyless Go door handle)	KG-Keyless Go
ACT1710	A17/3 (Left rear Keyless Go door handle)	KG-Keyless Go
ACT1711	A17/2 (Right front Keyless Go door handle)	KG-Keyless Go
ACT1712	A17/4 (Right rear Keyless Go door handle)	KG-Keyless Go
ACT1713	AllCheck door handles using actual value.	KG-Keyless Go
ACT1714	A2/60 (Cockpit Keyless Go antenna)/A2/61 (Keyless Go antenna, interior)	KG-Keyless Go
ACT1715	A2/35 (Keyless Go antenna, trunk) (W221)	KG-Keyless Go
ACT1716	In vehicle	KG-Keyless Go
ACT1717	Trunk	KG-Keyless Go

ACT1718	Left front door	KG-KEYLESS GO
ACT1719	Left rear door	KG-KEYLESS GO
ACT1720	Right front door	KG-KEYLESS GO
ACT1721	Right rear door	KG-KEYLESS GO
ACT1722	Key search within vehicle	KG-KEYLESS GO
ACT1723	Key search outside vehicle	KG-KEYLESS GO
ACT1724	Keyless Go system check	KG-KEYLESS GO
ACT1725	Inside rearview mirror (automatically dimming)	OCP-Overhead control panel
ACT1726	Sliding/tilting roof	OCP-Overhead control panel
ACT1727	Panoramic sliding roof	OCP-Overhead control panel
ACT1728	Ambiance lighting	UCP-Upper control panel
ACT1729	N72/1e2 (ATA [EDW] function indicator)	UCP-Upper control panel
ACT1730	N72/1s30 (STH/HB [ZUH]/residual heat button)	UCP-Upper control panel
ACT1731	N72/1s33 (Left automatic air conditioning button)	UCP-Upper control panel
ACT1732	N72/1s37 (Air recirculation button)	UCP-Upper control panel
ACT1733	N72/1s38 (OFF/residual heat button)	UCP-Upper control panel
ACT1734	N72/1s39 (Heated rear window button)	UCP-Upper control panel
ACT1735	N72/1s42 (Right automatic air conditioning button)	UCP-Upper control panel
ACT1736	E13/1 (Glove compartment lamp)	UCP-Upper control panel
ACT1737	E17/15 (Right front footwell lamp), E17/16 (Left front footwell lamp)	UCP-Upper control panel

ACT1738	A70/1 (Analog clock)	UCP-Upper control panel
ACT1739	S6/2e1 (Automatic child seat recognition airbag OFF indicator lamp)	UCP-Upper control panel
ACT1740	S6/2s10 (Level adjustment switch)	UCP-Upper control panel
ACT1741	S6/2s11 (ESP OFF switch)	UCP-Upper control panel
ACT1742	S6/2s15 (Suspension settings switch)	UCP-Upper control panel
ACT1743	S6/2s12 (PTS OFF switch)	UCP-Upper control panel
ACT1744	S1e4 (Exterior lamp switch illumination)	UCP-Upper control panel
ACT1745	S1e1 (Foglamps indicator lamp)	UCP-Upper control panel
ACT1746	S1e2 (Rear foglamp indicator lamp)	UCP-Upper control panel
ACT1747	S1e3 (Standing lamps indicator lamp)	UCP-Upper control panel
ACT1748	A40/9 (Front central operating unit)	UCP-Upper control panel
ACT1749	Circuit 15R	Dr side SAM-Driver signal acquisition and actuation module
ACT1750	Daytime running lamps	Dr side SAM-Driver signal acquisition and actuation module
ACT1751	Parking light	Dr side SAM-Driver signal acquisition and actuation module
ACT1752	Side lamp	Dr side SAM-Driver signal acquisition and actuation module
ACT1753	Main beam(Bi-xenon)	Dr side SAM-Driver signal acquisition and actuation module
ACT1754	Fog light	Dr side SAM-Driver signal acquisition and actuation module
ACT1755	Turn signal lamp	Dr side SAM-Driver signal acquisition and actuation module
ACT1756	Side marker lamp	Dr side SAM-Driver signal acquisition and actuation module
ACT1757	Windshield wiper motor	Dr side SAM-Driver signal acquisition and actuation module

ACT1758	Heating water circulation pump	Dr side SAM-Driver signal acquisition and actuation module
ACT1759	Shutoff valve	Dr side SAM-Driver signal acquisition and actuation module
ACT1760	Quiescent current shutoff	Dr side SAM-Driver signal acquisition and actuation module
ACT1761	Test of additional battery	Dr side SAM-Driver signal acquisition and actuation module
ACT1762	Taillights	REAR SAM-Rear signal acquisition and actuation module
ACT1763	Side marker lamps	REAR SAM-Rear signal acquisition and actuation module
ACT1764	Stop lights	REAR SAM-Rear signal acquisition and actuation module
ACT1765	Center high-mounted stop lamp	REAR SAM-Rear signal acquisition and actuation module
ACT1766	Turn signal lights	REAR SAM-Rear signal acquisition and actuation module
ACT1767	Surround lamp/Warning lamp	REAR SAM-Rear signal acquisition and actuation module
ACT1768	N10/2kM (Circuit 15 relay)	REAR SAM-Rear signal acquisition and actuation module
ACT1769	N10/2kN (Circuit 15R relay)	REAR SAM-Rear signal acquisition and actuation module
ACT1770	N10/2k0 (Power outlet relay)	REAR SAM-Rear signal acquisition and actuation module
ACT1771	N10/2kP (Heated rear window relay)	REAR SAM-Rear signal acquisition and actuation module
ACT1772	Rear screen Denormalizing	REAR SAM-Rear signal acquisition and actuation module
ACT1773	Rear screen Normalizing	REAR SAM-Rear signal acquisition and actuation module
ACT1774	Actuation Rear screen	REAR SAM-Rear signal acquisition and actuation module
ACT1775	Y24/11 (Rear head restraints valve block)Rear center	REAR SAM-Rear signal acquisition and actuation module
ACT1776	M14/7 (Trunk lid CL motor)	REAR SAM-Rear signal acquisition and actuation module
ACT1777	M14/10 (CL fuel filler flap motor)	REAR SAM-Rear signal acquisition and actuation module

ACT1778	Internal charge transformer	BNS-Vehicle power supply control module
ACT1779	N82/1k1 (Quiescent current cutout relay)	BNS-Vehicle power supply control module
ACT1780	F32k1 (Coupling relay battery)	BNS-Vehicle power supply control module
ACT1781	Consumer shutoff	BNS-Vehicle power supply control module
ACT1782	On-board electrical system warnings	BNS-Vehicle power supply control module
ACT1783	Indicator lamp 'Trailer hitch locked'	AHE-Trailer recognition
ACT1784	Terminal 30G 'Trailer socket'	AHE-Trailer recognition
ACT1785	Inflatable cushion in shoulder area	DS LF-Left front dynamic seat
ACT1786	Left air cushion for lateral support	DS LF-Left front dynamic seat
ACT1787	Right air cushion for lateral support	DS LF-Left front dynamic seat
ACT1788	Lumbar top	DS LF-Left front dynamic seat
ACT1789	Lumbar middle	DS LF-Left front dynamic seat
ACT1790	Lumbar bottom	DS LF-Left front dynamic seat
ACT1791	Air cushion in left upper leg area	DS LF-Left front dynamic seat
ACT1792	Air cushion in right upper leg area	DS LF-Left front dynamic seat
ACT1793	Air cushion for lateral support in left upper leg area	DS LF-Left front dynamic seat
ACT1794	Air cushion for lateral support in right upper leg area	DS LF-Left front dynamic seat
ACT1795	Air cushion for lateral support in upper leg area	DS LF-Left front dynamic seat
ACT1796	Air cushion for massage function, row 1 (lower)	DS LF-Left front dynamic seat
ACT1797	Air cushion for massage function, row 2	DS LF-Left front dynamic seat

ACT1798	Air cushion for massage function, row 3	DS LF-Left front dynamic seat
ACT1799	Air cushion for massage function, row 4	DS LF-Left front dynamic seat
ACT1800	Air cushion for massage function, row 5	DS LF-Left front dynamic seat
ACT1801	Air cushion for massage function, row 6	DS LF-Left front dynamic seat
ACT1802	Air cushion for massage function, row 7 (upper)	DS LF-Left front dynamic seat
ACT1803	Pneumatic pump for dynamic seat	DSP-Pneumatic pump for dynamic seat
ACT1804	Power window	DCM FL-Door control module front left
ACT1805	Mirror memory	DCM FL-Door control module front left
ACT1806	Additional door lock	DCM FL-Door control module front left
ACT1807	Switch illuminationTerminal 58d	DCM FL-Door control module front left
ACT1808	E17/19 (Left front door warning light)	DCM FL-Door control module front left
ACT1809	Door handle recess and trim strip illumination	DCM FL-Door control module front left
ACT1810	LEDsFunction lighting	DCM FL-Door control module front left
ACT1811	LEDsSeat heater and ventilation	DCM FL-Door control module front left
ACT1812	LEDsBlind spot assist	DCM FL-Door control module front left
ACT1813	E17/4 (Right front door entry/exit lamp	DCM FR-Door control module front right
ACT1814	E17/21 (Right front door warning light)	DCM FR-Door control module front right
ACT1815	Power windowWindow in short stroke position	RCM-Rear control module
ACT1816	Head restraint adjustment	RCM-Rear control module
ACT1817	Terminal 58d(Switch illumination)	RCM-Rear control module

ACT1818	Seat cushion depth	ESA FL-Electric seat adjustment front left
ACT1819	Seat heater	ESA FL-Electric seat adjustment front left
ACT1820	Seat ventilation	ESA FL-Electric seat adjustment front left
ACT1821	Seat belt wear convenience	ESA FL-Electric seat adjustment front left
ACT1822	Footwell lightingREAR	ESA FL-Electric seat adjustment front left
ACT1823	Lumbar support adjustment	ESA FL-Electric seat adjustment front left
ACT1824	Test current consumption of component Seat ventilation.	ESA FL-Electric seat adjustment front left
ACT1825	Switch illumination/Function illumination	SCM [MRM]-Steering column module
ACT1826	Denormalization and normalization of remote trunk closing	TLC-Trunk lid control
ACT1827	PTS-Parktronic (Interior CAN bus)	PTS-Parktronic system
ACT1828	M2/8 (Left defroster flap actuator)	AAC-Automatic air conditioning
ACT1829	M2/9 (Right defroster flap actuator)	AAC-Automatic air conditioning
ACT1830	M2/10 (Left footwell flap actuator)	AAC-Automatic air conditioning
ACT1831	M2/11 (Right footwell flap actuator)	AAC-Automatic air conditioning
ACT1832	M2/17 (Left side outlet flap actuator motor)	AAC-Automatic air conditioning
ACT1833	M2/18 (Right side outlet flap actuator motor)	AAC-Automatic air conditioning
ACT1834	M2/12 (Left center vent air flap actuator motor)	AAC-Automatic air conditioning
ACT1835	M2/13 (Right center vent air flap actuator motor)	AAC-Automatic air conditioning
ACT1836	M2/30 (Upper left blending air flap actuator motor)M2/31 (Lower left blending air flap actuator motor)	AAC-Automatic air conditioning
ACT1837	M2/32 (Upper right blending air flap actuator motor)M2/33 (Lower right blending air flap actuator motor)	AAC-Automatic air conditioning

ACT1838	M16/19 (Left rear center nozzle open/close actuator motor)	AAC-Automatic air conditioning
ACT1839	M16/20 (Right rear center nozzle open/close actuator motor)	AAC-Automatic air conditioning
ACT1840	Illumination for rotary potentiometers	AAC-Automatic air conditioning
ACT1841	R22/3 (Heater booster)	AAC-Automatic air conditioning
ACT1842	Heated windshield	AAC-Automatic air conditioning
ACT1843	A31/1 (Rear heating system delivery unit)	AAC-Automatic air conditioning
ACT1844	Operational check	STH-Stationary heater with remote control
ACT1845	HeatingSwitch on ventilation in line with the request from the AC pushbutton control module.	STH-Stationary heater with remote control
ACT1846	Switch on component A6r4 (Flame monitor glowpin unit).	STH-Stationary heater with remote control
ACT1847	Switch on component A6r5 (Fuel preheating system).	STH-Stationary heater with remote control
ACT1848	Switch on component A6m2 (combustion air blower).	STH-Stationary heater with remote control
ACT1849	Switch on component Y16 (STH switchover valve).	STH-Stationary heater with remote control
ACT1850	Switch on component Y23 (Stationary heater or heater booster fuel metering pump).	STH-Stationary heater with remote control
ACT1851	Measurement of fuel delivery quantity	STH-Stationary heater with remote control
ACT1852	Learning component A8/3 (STH radio remote control transmitter)	STH-Stationary heater with remote control
ACT1853	Deletion of fault interlock or temperature cutoutFault interlock	STH-Stationary heater with remote control
ACT1854	Deletion of crash interlock	STH-Stationary heater with remote control
ACT1855	Actuation of curve illumination with vehicle at standstill	XALWA L-Xenon headlamp, left
ACT1856	Cornering illumination, left	XALWA L-Xenon headlamp, left
ACT1857	Cornering illumination, left and right	XALWA L-Xenon headlamp, left

ACT1858	Move xenon bulb to removal position.	XALWA L-Xenon headlamp, left
ACT1859	Left and right motorway spotlight	XALWA L-Xenon headlamp, left
ACT1860	Light distribution of left headlamp	XALWA L-Xenon headlamp, left
ACT1861	Light distribution of left and right headlamps	XALWA L-Xenon headlamp, left
ACT1862	Left cornering light or static curve light	XALWA L-Xenon headlamp, left
ACT1863	Left and right cornering light or static curve illumination	XALWA L-Xenon headlamp, left
ACT1864	Cornering illumination, right	XALWA R-Xenon headlamp, right
ACT1865	Light distribution of right headlamp	XALWA R-Xenon headlamp, right
ACT1866	Right cornering light or static curve light	XALWA R-Xenon headlamp, right
ACT1867	Colors	COMAND
ACT1868	Stripes	COMAND
ACT1869	TV	COMAND
ACT1870	Check of wake-up line to the MOST components	COMAND
ACT1871	Deleting customer-specific dataReset control unit 'COMAND'.	COMAND
ACT1872	Optical ring test	COMAND
ACT1873	SelftestCOMAND	COMAND
ACT1874	SelftestHandsfree system microphone	COMAND
ACT1875	Operational checksHard disk	COMAND
ACT1876	Operational checksMap reader	COMAND
ACT1877	Operational checksUSB connection	COMAND

ACT1878	Selftest of control module Tuner	Tuner-Standard tuner
ACT1879	Microphone test for sound amplifier	Tuner-Standard tuner
ACT1880	Tests of speakers	Tuner-Standard tuner
ACT1881	Check of volume, balance and fader settings	Tuner-Standard tuner
ACT1882	Guided test of speakers	Tuner-Standard tuner
ACT1883	Selftest of control module Voice control	VC-Voice control
ACT1884	Test of microphone group and voice volume	VC-Voice control
ACT1885	SelftestCTEL	CTEL-Mobile phone adapter with universal interface
ACT1886	Test of antenna amplifier	CTEL-Mobile phone adapter with universal interface
ACT1887	Swivel of display	ZAN-Central display
ACT1888	Y101 (Divert air switchover valve)	ME 2.7.2-Motor electronics 2.7.2
ACT1889	M16/45m1 (Right exhaust gas recirculation actuator motor)	MED 17.7-Motor electronics for direct injection 17.7
ACT1890	M16/45m2 (Left exhaust gas recirculation actuator motor)	MED 17.7-Motor electronics for direct injection 17.7
ACT1891	Y77/1 (Charge pressure positioner)	MED 17.7-Motor electronics for direct injection 17.7
ACT1892	Y94/1 (Left quantity control valve)-Y94/2 (Right quantity control valve)	MED 17.7-Motor electronics for direct injection 17.7
ACT1893	Level adjustment	AIRmatic
ACT1894	Move toward calibrated level (manually)	AIRmatic
ACT1895	Move toward calibrated level (automatic)	AIRmatic
ACT1896	Empty central reservoir	AIRmatic
ACT1897	Fill central reservoir	AIRmatic

ACT1898	E17/5 (Right rear door entry/exit lamp)	DCM RL-Door control module rear left
ACT1899	E17/13 (Right rear door inside handle illumination)	DCM RL-Door control module rear left
ACT1900	Cigarette lighter	DCM RL-Door control module rear left
ACT1901	Left forward/back adjustment	ESA R-Electric seat adjustment rear
ACT1902	Left Seat ventilation	ESA R-Electric seat adjustment rear
ACT1903	Right forward/back adjustment	ESA R-Electric seat adjustment rear
ACT1904	Right Seat ventilation	ESA R-Electric seat adjustment rear
ACT1905	Engine test	ESA R-Electric seat adjustment rear
ACT1906	Left seat cushion angle	ESA R-Electric seat adjustment rear
ACT1907	Right seat cushion angle	ESA R-Electric seat adjustment rear
ACT1908	Center inflatable cushion in lumbar region	OSB R-Multicontour backrest rear
ACT1909	Function lighting in switch S104s1 (Dynamic lumbar support adjustment switch)	OSB R-Multicontour backrest rear
ACT1910	Function lighting in switch S103s1 (Dynamic lumbar support adjustment switch)	OSB R-Multicontour backrest rear
ACT1911	Top inflatable cushion in shoulder region	OSB FL-Multicontour backrest front left
ACT1912	Bottom inflatable cushion in shoulder region	OSB FL-Multicontour backrest front left
ACT1913	Function lighting in switch S109s1 (Dynamic lumbar support adjustment switch)	OSB FL-Multicontour backrest front left
ACT1914	Function lighting in switch S108s1 (Dynamic lumbar support adjustment switch)	OSB FR-Multicontour backrest front right
ACT1915	Function lighting in switch S108s1 (right front PULSE switch)	DS RF-Right front dynamic seat
ACT1916	Pressure lighting in switch S108/1 (Right front DYNAMIC switch)	DS RF-Right front dynamic seat
ACT1917	Perform overpressure run.	DSP-Pneumatic pump for dynamic seat

ACT1918	Actuate pneumatic pump.	DSP-Pneumatic pump for dynamic seat
ACT1919	Output Door contact	MSS-Special vehicle multifunction control module
ACT1920	Output Terminal 58d	MSS-Special vehicle multifunction control module
ACT1921	Output Distance	MSS-Special vehicle multifunction control module
ACT1922	OutputTaximeter supply	MSS-Special vehicle multifunction control module
ACT1923	Output Two-way radio connection	MSS-Special vehicle multifunction control module
ACT1924	OutputRoof sign	MSS-Special vehicle multifunction control module
ACT1925	OutputRoof sign inverted	MSS-Special vehicle multifunction control module
ACT1926	Output Voltage supply of peripheral units1	MSS-Special vehicle multifunction control module
ACT1927	Output Voltage supply of peripheral units2	MSS-Special vehicle multifunction control module
ACT1928	Output Radio help call	MSS-Special vehicle multifunction control module
ACT1929	Output KL15C/KL15R/KL15	MSS-Special vehicle multifunction control module
ACT1930	Output Two-way radio set supply	MSS-Special vehicle multifunction control module
ACT1931	Output Horn contact	MSS-Special vehicle multifunction control module
ACT1932	Output Charging of 2nd battery	MSS-Special vehicle multifunction control module
ACT1933	Output 2nd battery	MSS-Special vehicle multifunction control module
ACT1934	Output Two-way radio handsfree facility	MSS-Special vehicle multifunction control module
ACT1935	Output Reset Through	MSS-Special vehicle multifunction control module
ACT1936	Output KL30(10A)	MSS-Special vehicle multifunction control module
ACT1937	Output KL15(10A)	MSS-Special vehicle multifunction control module

ACT1938	Output Communication	MSS-Special vehicle multifunction control module
ACT1939	Output KL15(6A)	MSS-Special vehicle multifunction control module
ACT1940	Front roller sun blindRear roller sun blind	PSD-Panoramic sliding roof(Interior CAN bus)
ACT1941	ActuationPower window	DCM RL-Door control module rear left
ACT1942	Childproof locks	DCM RL-Door control module rear left
ACT1943	E17/5 (Left rear door entry/exit lamp)	DCM RL-Door control module rear left
ACT1944	E17/20 (Left rear door warning light)	DCM RL-Door control module rear left
ACT1945	LEDS55/1s10 (Front or rear seat adjustment selection switch)	DCM RL-Door control module rear left
ACT1946	LEDsSeat heater	DCM RL-Door control module rear left
ACT1947	LEDsSeat ventilation	DCM RL-Door control module rear left
ACT1948	E17/6 (Right rear door entry/exit lamp)	DCM RR-Door control module rear right
ACT1949	E17/22 (Right rear door warning light)	DCM RR-Door control module rear right
ACT1950	Longitudinal adjustment and backrest adjustment	ESA R-Electric seat adjustment rear
ACT1951	Left rear head restraint lowering	ESA R-Electric seat adjustment rear
ACT1952	Left seat ventilation	ESA R-Electric seat adjustment rear
ACT1953	Right rear head restraint lowering	ESA R-Electric seat adjustment rear
ACT1954	Right seat ventilation	ESA R-Electric seat adjustment rear
ACT1955	Left front reversible emergency tensioning retractor	RevETR LF-Left front reversible emergency tensioning retractor
ACT1956	Right front reversible emergency tensioning retractor	RevETR RF-Right front reversible emergency tensioning retractor
ACT1957	Selftest of control module	AVE H-Rear audio video unit

ACT1958	Cabling test of component TV tuner	AVE H-Rear audio video unit
ACT1959	Headphone test(Output of test tone)	AVE H-Rear audio video unit
ACT1960	Check of AUX connections for video signals	AVE H-Rear audio video unit
ACT1961	Selftest of control module ,	AVE H-Rear audio video unit
ACT1962	Output of test tone(Headphone test)	AVE H-Rear audio video unit
ACT1963	Output of audio and video signal from control unit 'COMAND' on rear monitors.	AVE H-Rear audio video unit
ACT1964	Output of audio and video signal from control unit 'TV tuner' on rear monitors.	AVE H-Rear audio video unit
ACT1965	Output of audio and video signal from CD/DVD drive on rear monitors.	AVE H-Rear audio video unit
ACT1966	Output of audio and video signal from AUX jack on rear monitors.	AVE H-Rear audio video unit
ACT1967	Window roller blind	TSG ML-Left center door control unit (interior Can bus)
ACT1968	Seat lengthwise adjustment	TSG ML-Left center door control unit (interior Can bus)
ACT1969	E6/7 (Left center side-marker lamp)	TSG ML-Left center door control unit (interior Can bus)
ACT1970	E3e6 (Left side marker lamp)	TSG ML-Left center door control unit (interior Can bus)
ACT1971	Door trim strip illumination	TSG ML-Left center door control unit (interior Can bus)
ACT1972	E6/8 (Right center side-marker lamp)	TSG MR-Right center door control unit (interior Can bus)
ACT1973	E4e6 (Right side marker lamp)	TSG MR-Right center door control unit (interior Can bus)
ACT1974	Air cushion in seat cushion	DS LF-Left front dynamic seat
ACT1975	Test of emergency tensioning retractor function	RevETR LF-Left front reversible emergency tensioning retractor
ACT1976	Actuation of contactors	SG BMS-Battery management system control unit
ACT1977	Actuation of component Y19/1 (High-voltage battery cooling system shutoff valve)	SG BMS-Battery management system control unit

ACT1978	Measurement of insulation resistance with open contactors	SG BMS-Battery management system control unit
ACT1979	Measurement of insulation resistance with closed contactors	SG BMS-Battery management system control unit
ACT1980	Y123 (Left switchable engine mount)Y123/1 (Right switchable engine mount)Automatic evaluation of measurement results	CDI 3-Common Rail Diesel Injection3
ACT1981	Check actuations of components Y123 (Left switchable engine mount) and Y123/1 (Right switchable engine mount).	CDI 3-Common Rail Diesel Injection3
ACT1982	Y131 (Oil spray nozzle shutoff valve)	CDI 3-Common Rail Diesel Injection3
ACT1983	Perform an actuation of components Y93 (Boost pressure control flap pressure transducer) and Y31/4 (Wastegate control	CDI 3-Common Rail Diesel Injection3
ACT1984	Right front turn signal light	Pass side SAM-Passenger-side signal acquisition and actuation module
ACT1985	K40/4kP (Fanfare horns relay)	Pass side SAM-Passenger-side signal acquisition and actuation module
ACT1986	E36 (Armrest storage compartment lighting)	Pass side SAM-Passenger-side signal acquisition and actuation module
ACT1987	Left foglamp	Dr side SAM-Driver signal acquisition and actuation module
ACT1988	Left front turn signal lamp	Dr side SAM-Driver signal acquisition and actuation module
ACT1989	K40/2kB (Circuit 15 relay)	Dr side SAM-Driver signal acquisition and actuation module
ACT1990	K40/2kC (Circuit 15R relay)	Dr side SAM-Driver signal acquisition and actuation module
ACT1991	Wake-up cable to control module N51/2 (ABC control module)	Dr side SAM-Driver signal acquisition and actuation module
ACT1992	Unlock trunk lid.	PSE-Pneumatic system equipment
ACT1993	Open or close central locking.	PSE-Pneumatic system equipment
ACT1994	Seat height	ESA FL-Electric seat adjustment front left
ACT1995	Voltage supply of component B48(Front passenger seat occupied and child seat recognition)	ESA FR-Electric seat adjustment front right
ACT1996	Center outlets,Diverter flap,Blending air flap:Left	AAC-Automatic air conditioning
ACT1997	Center outlets,Diverter flap,Blending air flap:Right	AAC-Automatic air conditioning

ACT1998	Side vent:Left	AAC-Automatic air conditioning
ACT1999	Side vent:Right	AAC-Automatic air conditioning
ACT2000	Heat exchanger shut-off motor	AAC-Automatic air conditioning
ACT2001	Actuation of the mechanical instrument pointer to the maximum position	ICM-Instrument cluster
ACT2002	Actuation of standing and parking lamps	Dr side SAM-Driver signal acquisition and actuation module
ACT2003	Actuation of low beam	Dr side SAM-Driver signal acquisition and actuation module
ACT2004	Actuation of high beam	Dr side SAM-Driver signal acquisition and actuation module
ACT2005	Actuation of fog lamp	Dr side SAM-Driver signal acquisition and actuation module
ACT2006	Actuation of turn signal lamp	Dr side SAM-Driver signal acquisition and actuation module
ACT2007	Actuation of actuator for Xenon high beam	Dr side SAM-Driver signal acquisition and actuation module
ACT2008	Actuation of side-marker lamp	Dr side SAM-Driver signal acquisition and actuation module
ACT2009	N10/1kN (Circuit 15 relay)	Dr side SAM-Driver signal acquisition and actuation module
ACT2010	Blower motor in control module box	Dr side SAM-Driver signal acquisition and actuation module
ACT2011	Wake-up cable to control module A7/3n1 (SBC control unit)	Dr side SAM-Driver signal acquisition and actuation module
ACT2012	Wake-up cable to control module N51 (AIRmatic with ADS control module)	Dr side SAM-Driver signal acquisition and actuation module
ACT2013	A31/1(Rear heating system delivery unit)	Pass side SAM-Passenger-side signal acquisition and actuation module
ACT2014	M13/5(Rear AC additional circulation pump(small))	Pass side SAM-Passenger-side signal acquisition and actuation module
ACT2015	N10/9kN(Circuit 15 relay)Terminal 15	Pass side SAM-Passenger-side signal acquisition and actuation module
ACT2016	N10/9kP(Circuit 15R relay)Circuit 15R	Pass side SAM-Passenger-side signal acquisition and actuation module
ACT2017	Control unit SBC	Pass side SAM-Passenger-side signal acquisition and actuation module

ACT2018	Relays Charge air cooler	Pass side SAM-Passenger-side signal acquisition and actuation module
ACT2019	Stowage compartment illumination	Rear SAM 1-Rear signal acquisition and actuation module1
ACT2020	Spotlight	Rear SAM 1-Rear signal acquisition and actuation module1
ACT2021	A75/2 (Right side window electric curtain)	Rear SAM 1-Rear signal acquisition and actuation module1
ACT2022	A75/3 (Partition wall electric curtain)	Rear SAM 1-Rear signal acquisition and actuation module1
ACT2023	Relays Refrigerator box	Rear SAM 2-Rear signal acquisition and actuation module2
ACT2024	Output Backup camera	MSS-Special vehicle multifunction control module
ACT2025	Output KI.30	MSS-Special vehicle multifunction control module
ACT2026	Output KI.58d	MSS-Special vehicle multifunction control module
ACT2027	Output KI.15/KI.15R/KI.15C	MSS-Special vehicle multifunction control module
ACT2028	Output Battery indicator	MSS-Special vehicle multifunction control module
ACT2029	Output Head restrain, 3rd rear seat	MSS-Special vehicle multifunction control module
ACT2030	Stationary heater	VBF-Front control panel
ACT2031	Blower of interior temperature sensor	HBF-Rear control field
ACT2032	Switch illumination.	BCG-Remote control(Rear control field)
ACT2033	Blower of interior temperature sensor.	BCG-Remote control(Rear control field)
ACT2034	SWITCH ON Left front reading lamp	OCP-Overhead control panel
ACT2035	SWITCH ON Right front reading lamp	OCP-Overhead control panel
ACT2036	Interior lights in rear compartment	CRN-Center roof node
ACT2037	Rear left reading lamp	CRN-Center roof node

ACT2038	Rear right reading lamp	CRN-Center roof node
ACT2039	Seat Height	ESA FL-Electric seat adjustment front left
ACT2040	Inclination	ESA FL-Electric seat adjustment front left
ACT2041	Head restraints inclination	ESA LR-Left rear electrical seat adjustment
ACT2042	Head restraints height adjustment	ESA LR-Left rear electrical seat adjustment
ACT2043	Function lighting in switch S104sl (Pulse switch)	OSB FL-Multicontour backrest front left
ACT2044	E17/3 (Left front door entry/exit lamp	DCM FL-Door control module front left
ACT2045	Door pocket illumination	DCM FL-Door control module front left
ACT2046	LED Seat heater	DCM FL-Door control module front left
ACT2047	LED Seat ventilation	DCM FL-Door control module front left
ACT2048	Trunk lid remote release	PSE-Pneumatic system equipment
ACT2049	Left center vent	AAC-Automatic air conditioning
ACT2050	Right center vent	AAC-Automatic air conditioning
ACT2051	M2/25 (Left front diffuse field flaps actuator motor)	AAC-Automatic air conditioning
ACT2052	M2/26 (Right front diffuse field flap actuator motor)	AAC-Automatic air conditioning
ACT2053	A32m2 (Activated charcoal filter flap adjustment motor)	AAC-Automatic air conditioning
ACT2054	Test LCD display.	AAC-Automatic air conditioning
ACT2055	M16/15 (Left footwell flap actuator motor)	REAR AC-Rear air conditioning
ACT2056	M16/16 (Right footwell flap actuator motor)	REAR AC-Rear air conditioning
ACT2057	M16/23 (Left rear center nozzle blending air flap actuator motor)	REAR AC-Rear air conditioning

ACT2058	M16/24 (Right rear center nozzle blending air flap actuator motor)	REAR AC-Rear air conditioning
ACT2059	M16/35 (Left rear diffuse field flap actuator motor)	REAR AC-Rear air conditioning
ACT2060	M16/36 (Right rear diffuse field flap actuator motor)	REAR AC-Rear air conditioning
ACT2061	M16/37 (Left B-pillar air flap open/close actuator motor)	REAR AC-Rear air conditioning
ACT2062	M16/38 (Right B-pillar air flap open/close actuator motor)	REAR AC-Rear air conditioning
ACT2063	M16/21 (Fresh air and recirculated air flap actuator motor)	REAR AC-Rear air conditioning
ACT2064	Booster blowerLeft	REAR AC-Rear air conditioning
ACT2065	Booster blowerRight	REAR AC-Rear air conditioning
ACT2066	Windscreen heater	REAR AC-Rear air conditioning
ACT2067	Video signal source test	AVC-Audio video controller
ACT2068	Audio signal source test	AVC-Audio video controller
ACT2069	Y62 (Fuel injectors cylinder1)	ME SFI-CNG compressed natural gas
ACT2070	Y62 (Fuel injectors cylinder2)	ME SFI-CNG compressed natural gas
ACT2071	Y62 (Fuel injectors cylinder3)	ME SFI-CNG compressed natural gas
ACT2072	Y62 (Fuel injectors cylinder4)	ME SFI-CNG compressed natural gas
ACT2073	Y107/1y1 (Gas cylinder 1 shutoff valve)-Y107/1y5 (Gas cylinder 5 shutoff valve)\nY107/2 (Gas safety shutoff valve)\nY107/3	ME SFI-CNG compressed natural gas

[illegible]

[illegible]

[illegible]

[illegible]

XTOOL

[illegible]