



Shenzhen Xtooltech Co., Ltd

Buick Function List V12.10

Tips and Instructions:

The programming function only supports H6PRO, H6PRO Master Edition products.

* This feature is new.

√ This feature is supported.

This feature is not supported.

※ This feature is partially supported.

| Year | Make | Model Series | System Name | Read ECU Information | Read Trouble Code | Clear Trouble Code | Live Data | Actuation Test | Special Functions |
|------|-------|--------------|--|----------------------|-------------------|--------------------|-----------|----------------|--|
| 2022 | Buick | Enclave | Amplifier | √ | √ | √ | √ | | |
| 2022 | Buick | Enclave | HVAC Control Module | √ | √ | √ | √ | √ | 0007 0129 |
| 2022 | Buick | Enclave | HVAC Controls | √ | √ | √ | √ | | |
| 2022 | Buick | Enclave | Radio Controls | √ | √ | √ | √ | | 0241 |
| 2022 | Buick | Enclave | Radio | √ | √ | √ | √ | √ | 0226 0267 0269 |
| 2022 | Buick | Enclave | Headlamp Control Module | √ | √ | √ | √ | √ | 0195 |
| 2022 | Buick | Enclave | Liftgate Control Module | √ | √ | √ | √ | √ | 0146 0169 |
| 2022 | Buick | Enclave | Seat Memory Control Module - Driver | √ | √ | √ | √ | √ | |
| 2022 | Buick | Enclave | Telematics Communication Interface Control Module | √ | √ | √ | √ | √ | 0755 |
| 2022 | Buick | Enclave | Video Processing Control Module | √ | √ | √ | √ | √ | |
| 2022 | Buick | Enclave | Transmission Control Module | √ | √ | √ | √ | √ | 0017 |
| 2022 | Buick | Enclave | Chassis Control Module | √ | √ | √ | √ | √ | 0014 0078 |
| 2022 | Buick | Enclave | Active Safety Control Module | √ | √ | √ | √ | | |
| 2022 | Buick | Enclave | Frontview Camera - Windshield | √ | √ | √ | √ | | 0196 |
| 2022 | Buick | Enclave | Forward Range Radar Sensor - Long Range | √ | √ | √ | √ | | 0260 |
| 2022 | Buick | Enclave | Engine Control Module | √ | √ | √ | √ | √ | 0263 0209 0115 0756 0086 0085 0757 0217 0258 0139 0006 |
| 2022 | Buick | Enclave | Instrument Cluster | √ | √ | √ | √ | √ | 0247 |
| 2022 | Buick | Enclave | Parking Assist Control Module | √ | √ | √ | √ | √ | 0247 0271 |
| 2022 | Buick | Enclave | Serial Data Gateway Module - Processor 1 | √ | √ | √ | | | |
| 2022 | Buick | Enclave | Serial Data Gateway Module - Processor 2 | √ | √ | √ | | | |
| 2022 | Buick | Enclave | Side Obstacle Detection Control Module - Left | √ | √ | √ | | √ | |
| 2022 | Buick | Enclave | Inflatable Restraint Sensing and Diagnostic Module | √ | √ | √ | √ | √ | 0172 0134 0111 0758 |
| 2022 | Buick | Enclave | Keyless Entry Control Module | √ | √ | √ | √ | √ | 0759 |
| 2022 | Buick | Enclave | Passenger Presence Module | √ | √ | √ | √ | √ | 0057 |

| | | | | | | | | | |
|------|-------|---------|--|---|---|---|---|---|--|
| 2022 | Buick | Enclave | Body Control Module | √ | √ | √ | √ | √ | 0199 0239 0161 0162 0163 0164 0165 0166 0167 0168 0242 0263 0203 0201 0208 0206 0083 0267 0160 0233 0150 |
| 2022 | Buick | Enclave | Electronic Brake Control Module | √ | √ | √ | √ | √ | 0225 0090 0111 0277 |
| 2022 | Buick | Enclave | Power Steering Control Module | √ | √ | √ | √ | √ | 0089 0084 |
| 2022 | Buick | Enclave | Suspension Control Module | √ | √ | √ | √ | √ | |
| 2022 | Buick | Encore | Front Seat Heating Control Module | √ | √ | √ | √ | √ | |
| 2022 | Buick | Encore | Telematics Communication Interface Control Module | √ | √ | √ | √ | √ | 0755 0259 0048 0011 |
| 2022 | Buick | Encore | HVAC Controls | √ | √ | √ | √ | √ | |
| 2022 | Buick | Encore | Radio | √ | √ | √ | √ | √ | 0150 0226 0269 0267 |
| 2022 | Buick | Encore | HVAC Control Module | √ | √ | √ | √ | √ | 0007 0129 |
| 2022 | Buick | Encore | Headlamp Control Module | √ | √ | √ | √ | √ | 0195 |
| 2022 | Buick | Encore | Seat Memory Control Module | √ | √ | √ | √ | √ | 0310 |
| 2022 | Buick | Encore | Instrument Cluster | √ | √ | √ | √ | √ | 0247 |
| 2022 | Buick | Encore | Parking Assist Control Module | √ | √ | √ | √ | √ | 0247 0271 |
| 2022 | Buick | Encore | Serial Data Gateway Module | √ | √ | √ | | | |
| 2022 | Buick | Encore | Side Obstacle Detection Control Module - Left | √ | √ | √ | | √ | |
| 2022 | Buick | Encore | Steering Column Lock Control Module | √ | √ | √ | √ | | |
| 2022 | Buick | Encore | Inflatable Restraint Sensing and Diagnostic Module | √ | √ | √ | √ | √ | 0172 0134 0111 0758 |
| 2022 | Buick | Encore | Keyless Entry Control Module | √ | √ | √ | √ | √ | 0759 |
| 2022 | Buick | Encore | Passenger Presence Module | √ | √ | √ | √ | √ | 0057 |
| 2022 | Buick | Encore | Frontview Camera - Windshield | √ | √ | √ | √ | √ | 0196 0084 0205 075A |
| 2022 | Buick | Encore | Transmission Control Module | √ | √ | √ | √ | √ | 0016 075C 0017 0036 |
| 2022 | Buick | Encore | Rear Drive Control Module | √ | √ | √ | √ | √ | 0003 075B |
| 2022 | Buick | Encore | Engine Control Module | √ | √ | √ | √ | √ | 0263 0209 0132 0115 0086 0212 0214 0217 0006 0144 0139 0757 0085 075D 075E 075F 0760 0756 0761 0213 0758 0259 0762 0764 |
| 2022 | Buick | Encore | Body Control Module | √ | √ | √ | √ | √ | 0199 0239 0161 0162 0163 0164 0165 0166 0167 0168 0242 0263 0203 0201 0208 0206 0083 0267 0160 0233 0150 |
| 2022 | Buick | Encore | Steering Wheel Angle Sensor Module | √ | √ | √ | | | 0093 0090 |
| 2022 | Buick | Encore | Electronic Brake Control Module | √ | √ | √ | √ | √ | 0090 |
| 2022 | Buick | Encore | Power Steering Control Module | √ | √ | √ | √ | √ | 0089 0084 0207 |
| 2022 | Buick | Encore | Amplifier | √ | √ | √ | √ | | |
| 2022 | Buick | Encore | Head-Up Display Module | √ | √ | √ | √ | √ | |
| 2022 | Buick | Encore | Side Obstacle Detection Control Module - Right | √ | √ | √ | | √ | |

| | | | | | | | | | |
|------|-------|----------|--|---|---|---|---|---|--|
| 2022 | Buick | Encore | Serial Data Gateway Module - Processor 1 | √ | √ | √ | | | |
| 2022 | Buick | Encore | Serial Data Gateway Module - Processor 2 | √ | √ | √ | | | |
| 2022 | Buick | Encore | Liftgate Control Module | √ | √ | √ | √ | √ | 0146 0169 |
| 2022 | Buick | Encore | Seat Memory Control Module - Driver | √ | √ | √ | √ | √ | |
| 2022 | Buick | Encore | Brake System Control Module | √ | √ | √ | √ | √ | 0766 0758 0767 0768 |
| 2022 | Buick | Envision | Audio Amplifier | √ | √ | √ | √ | | |
| 2022 | Buick | Envision | Heater and Air Conditioning User Interface Control - | √ | √ | √ | √ | | |
| 2022 | Buick | Envision | Radio | √ | √ | √ | √ | √ | 0769 |
| 2022 | Buick | Envision | Driver Seat Adjuster Memory Module | √ | √ | √ | √ | √ | |
| 2022 | Buick | Envision | Headlamp Control Module | √ | √ | √ | √ | | 0195 |
| 2022 | Buick | Envision | Rear Gate Module | √ | √ | √ | √ | | 0753 |
| 2022 | Buick | Envision | Telematics Control Module | √ | √ | √ | √ | | 0270 |
| 2022 | Buick | Envision | Restraints Control Module | √ | √ | √ | √ | √ | 0758 0134 |
| 2022 | Buick | Envision | Radio Controls | √ | √ | √ | √ | | |
| 2022 | Buick | Envision | Transmission Control Module | √ | √ | √ | √ | √ | 0019 076A |
| 2022 | Buick | Envision | Brake System Control Module | √ | √ | √ | √ | √ | 0767 0768 0766 0758 |
| 2022 | Buick | Envision | Power Steering Control Module | √ | √ | √ | √ | | 0766 |
| 2022 | Buick | Envision | Engine Control Module | √ | √ | √ | √ | √ | 0263 0209 075D 075E 076B 0760 076C 0115 076D 0761 0086 076E 0212 0217 0006 0144 |
| 2022 | Buick | Envision | Video Processing Module | √ | √ | √ | | | |
| 2022 | Buick | Envision | Wireless Accessory Charging Module | √ | √ | √ | √ | | |
| 2022 | Buick | Envision | Gear Shift Control Module | √ | | | | | |
| 2022 | Buick | Envision | Instrument Panel Cluster Control Module | √ | √ | √ | √ | √ | |
| 2022 | Buick | Envision | Parking Assist Control Module | √ | √ | √ | √ | √ | |
| 2022 | Buick | Envision | Lighting Control Module | √ | √ | √ | √ | √ | |
| 2022 | Buick | Envision | Serial Data Gateway Module | √ | √ | √ | | | |
| 2022 | Buick | Envision | Side Obstacle Detection Control Module - Left | √ | √ | √ | √ | | 076F |
| 2022 | Buick | Envision | Side Obstacle Detection Control Module - Right | √ | √ | √ | | | |
| 2022 | Buick | Envision | Restraints Occupant Classification System Module - Passenger | √ | √ | √ | √ | | 0057 |
| 2022 | Buick | Envision | Image Processing Module | √ | √ | √ | √ | | |
| 2022 | Buick | Envision | Frontview Camera - Windshield | √ | √ | √ | √ | | 0196 |
| 2022 | Buick | Envision | Forward Range Radar Sensor - Long Range | √ | √ | √ | √ | | 0260 |
| 2022 | Buick | Envision | Body Control Module | √ | √ | √ | √ | √ | 0263 0226 0754 0007 0129 0267 |
| 2022 | Buick | Envision | Rear Drive Control Module | √ | √ | √ | √ | | |
| 2021 | Buick | Enclave | Liftgate Control Module | √ | √ | √ | √ | √ | 0146 0169 |
| 2021 | Buick | Enclave | Seat Memory Control Module - Driver | √ | √ | √ | √ | √ | |
| 2021 | Buick | Enclave | Telematics Communication Interface Control Module | √ | √ | √ | √ | √ | 0755 |
| 2021 | Buick | Enclave | Video Processing Control Module | √ | √ | √ | √ | √ | |

| | | | | | | | | | |
|------|-------|---------|--|---|---|---|---|---|---|
| 2021 | Buick | Enclave | Engine Control Module | √ | √ | √ | √ | √ | 0263 0209 0115 0756 0086 0085 0757 0217 0258 0139 0006 |
| 2021 | Buick | Enclave | Transmission Control Module | √ | √ | √ | √ | √ | 0017 |
| 2021 | Buick | Enclave | Chassis Control Module | √ | √ | √ | √ | √ | 0014 0078 |
| 2021 | Buick | Enclave | Rear Drive Control Module | √ | √ | √ | √ | √ | 0003 |
| 2021 | Buick | Enclave | Instrument Cluster | √ | √ | √ | √ | √ | 0247 |
| 2021 | Buick | Enclave | Parking Assist Control Module | √ | √ | √ | √ | √ | 0247 0271 |
| 2021 | Buick | Enclave | Serial Data Gateway Module - Processor 1 | √ | √ | √ | | | |
| 2021 | Buick | Enclave | Serial Data Gateway Module - Processor 2 | √ | √ | √ | | | |
| 2021 | Buick | Enclave | Side Obstacle Detection Control Module - Left | √ | √ | √ | | √ | |
| 2021 | Buick | Enclave | Inflatable Restraint Sensing and Diagnostic Module | √ | √ | √ | √ | √ | 0172 0134 0111 0758 |
| 2021 | Buick | Enclave | Keyless Entry Control Module | √ | √ | √ | √ | √ | 0759 |
| 2021 | Buick | Enclave | Passenger Presence Module | √ | √ | √ | √ | √ | 0057 |
| 2021 | Buick | Enclave | Active Safety Control Module | √ | √ | √ | √ | | |
| 2021 | Buick | Enclave | Forward Range Radar Sensor - Long Range | √ | √ | √ | √ | | 0260 |
| 2021 | Buick | Enclave | Frontview Camera - Windshield | √ | √ | √ | √ | | 0196 |
| 2021 | Buick | Enclave | Radio | √ | √ | √ | √ | √ | 0226 0267 0269 |
| 2021 | Buick | Enclave | HVAC Controls | √ | √ | √ | √ | | |
| 2021 | Buick | Enclave | HVAC Control Module | √ | √ | √ | √ | √ | 0007 0129 |
| 2021 | Buick | Enclave | Amplifier | √ | √ | √ | √ | | |
| 2021 | Buick | Enclave | Radio Controls | √ | √ | √ | √ | | 0241 |
| 2021 | Buick | Enclave | Body Control Module | √ | √ | √ | √ | √ | 0199 0239 0161 0162 0163 0164 0165 0166 0167 0168 0242 0263 0203 0201 0208 0206 0083 0267 0160 0233 0150 |
| 2021 | Buick | Enclave | Electronic Brake Control Module | √ | √ | √ | √ | √ | 0225 0090 0111 0277 |
| 2021 | Buick | Enclave | Power Steering Control Module | √ | √ | √ | √ | | 0089 0084 |
| 2021 | Buick | Enclave | Suspension Control Module | √ | √ | √ | √ | √ | |
| 2021 | Buick | Encore | Front Seat Heating Control Module | √ | √ | √ | √ | √ | |
| 2021 | Buick | Encore | Headlamp Control Module | √ | √ | √ | √ | √ | 0195 |
| 2021 | Buick | Encore | Telematics Communication Interface Control Module | √ | √ | √ | √ | √ | 0755 0259 0048 0011 |
| 2021 | Buick | Encore | Instrument Cluster | √ | √ | √ | √ | √ | 0247 |
| 2021 | Buick | Encore | Steering Column Lock Control Module | √ | √ | √ | √ | | |
| 2021 | Buick | Encore | Parking Assist Control Module | √ | √ | √ | √ | √ | 0247 0271 |
| 2021 | Buick | Encore | Serial Data Gateway Module | √ | √ | √ | | | |
| 2021 | Buick | Encore | Side Obstacle Detection Control Module - Left | √ | √ | √ | | √ | |
| 2021 | Buick | Encore | Frontview Camera - Windshield | √ | √ | √ | √ | √ | 0196 0084 0205 075A |
| 2021 | Buick | Encore | Inflatable Restraint Sensing and Diagnostic Module | √ | √ | √ | √ | √ | 0172 0134 0111 0758 |
| 2021 | Buick | Encore | Keyless Entry Control Module | √ | √ | √ | √ | √ | 0759 |
| 2021 | Buick | Encore | Passenger Presence Module | √ | √ | √ | √ | √ | 0057 |

| | | | | | | | | | |
|------|-------|----------|--|---|---|---|---|---|---|
| 2021 | Buick | Encore | Electronic Brake Control Module | √ | √ | √ | √ | √ | 0090 |
| 2021 | Buick | Encore | Power Steering Control Module | √ | √ | √ | √ | | 0089 0084 0207 |
| 2021 | Buick | Encore | Steering Wheel Angle Sensor Module | √ | √ | √ | | | 0093 0090 |
| 2021 | Buick | Encore | Body Control Module | √ | √ | √ | √ | √ | 0199 0239 0161 0162 0163 0164 0165 0166 0167 0168 0242 0263 0203 0201 0208 0206 0083 0267 0160 0233 0150 |
| 2021 | Buick | Encore | Radio | √ | √ | √ | √ | √ | 0150 0226 0269 0267 |
| 2021 | Buick | Encore | HVAC Control Module | √ | √ | √ | √ | √ | 0007 0129 |
| 2021 | Buick | Encore | Amplifier | √ | √ | √ | √ | | |
| 2021 | Buick | Encore | Radio Controls | √ | √ | √ | √ | | 0241 |
| 2021 | Buick | Encore | Rear Drive Control Module | √ | √ | √ | √ | √ | 0003 075B |
| 2021 | Buick | Encore | Engine Control Module | √ | √ | √ | √ | √ | 0263 0209 0132 0115 0086 0212 0214 0217 0006 0144 0139 0757 0085 075D 075E 075F 0760 0756 0761 0213 0762 0258 0763 0764 0765 0156 0090 0067 |
| 2021 | Buick | Encore | HVAC Controls | √ | √ | √ | √ | | |
| 2021 | Buick | Encore | Transmission Control Module | √ | √ | √ | √ | √ | 0016 075C 0017 0036 |
| 2021 | Buick | Encore | Chassis Control Module | √ | √ | √ | √ | √ | 0217 |
| 2021 | Buick | Encore | Head-Up Display Module | √ | √ | √ | √ | √ | |
| 2021 | Buick | Encore | Side Obstacle Detection Control Module - Right | √ | √ | √ | | √ | |
| 2021 | Buick | Encore | Serial Data Gateway Module - Processor 1 | √ | √ | √ | | | |
| 2021 | Buick | Encore | Serial Data Gateway Module - Processor 2 | √ | √ | √ | | | |
| 2021 | Buick | Encore | Brake System Control Module | √ | √ | √ | √ | √ | 0766 0758 0767 0768 |
| 2021 | Buick | Encore | Video Processing Control Module | √ | √ | √ | √ | √ | |
| 2021 | Buick | Encore | Seat Memory Control Module - Driver | √ | √ | √ | √ | √ | |
| 2021 | Buick | Encore | Liftgate Control Module | √ | √ | √ | √ | √ | 0146 0169 |
| 2021 | Buick | Envision | Frontview Camera - Windshield | √ | √ | √ | √ | | 0196 |
| 2021 | Buick | Envision | Forward Range Radar Sensor - Long Range | √ | √ | √ | √ | | 0260 |
| 2021 | Buick | Envision | Driver Seat Adjuster Memory Module | √ | √ | √ | √ | √ | |
| 2021 | Buick | Envision | Headlamp Control Module | √ | √ | √ | √ | | 0195 |
| 2021 | Buick | Envision | Rear Gate Module | √ | √ | √ | √ | | 0753 |
| 2021 | Buick | Envision | Instrument Panel Cluster Control Module | √ | √ | √ | √ | √ | |
| 2021 | Buick | Envision | Parking Assist Control Module | √ | √ | √ | √ | √ | |
| 2021 | Buick | Envision | Serial Data Gateway Module | √ | √ | √ | | | |
| 2021 | Buick | Envision | Lighting Control Module | √ | √ | √ | √ | √ | |
| 2021 | Buick | Envision | Gear Shift Control Module | √ | | | | | |
| 2021 | Buick | Envision | Side Obstacle Detection Control Module - Left | √ | √ | √ | √ | | 076F |
| 2021 | Buick | Envision | Side Obstacle Detection Control Module - Right | √ | √ | √ | | | |

| | | | | | | | | | |
|------|-------|----------|---|---|---|---|---|---|---|
| 2021 | Buick | Envision | Body Control Module | √ | √ | √ | √ | √ | 0263 0226 0754 0007 0129 0267 |
| 2021 | Buick | Envision | Radio | √ | √ | √ | √ | √ | 0769 |
| 2021 | Buick | Envision | Restraints Control Module | √ | √ | √ | √ | √ | 0758 0134 |
| 2021 | Buick | Envision | Video Processing Module | √ | √ | √ | | | |
| 2021 | Buick | Envision | Wireless Accessory Charging Module | √ | √ | √ | √ | | |
| 2021 | Buick | Envision | Transmission Control Module | √ | √ | √ | √ | √ | 0019 076A |
| 2021 | Buick | Envision | Engine Control Module | √ | √ | √ | √ | √ | 0263 0209 075D 075E 076B 0760 076C 0115 076D 0761 0086 076E 0212 0217 0006 0144 |
| 2021 | Buick | Envision | Heater and Air Conditioning User Interface Control - | √ | √ | √ | √ | | |
| 2021 | Buick | Envision | Rear Drive Control Module | √ | √ | √ | √ | | |
| 2021 | Buick | Envision | Image Processing Module | √ | √ | √ | √ | | |
| 2021 | Buick | Envision | Brake System Control Module | √ | √ | √ | √ | √ | 0767 0768 0766 0758 |
| 2021 | Buick | Envision | Power Steering Control Module | √ | √ | √ | √ | | 0766 |
| 2021 | Buick | Envision | Telematics Control Module | √ | √ | √ | √ | | 0270 |
| 2021 | Buick | Envision | Restraints Occupant Classification System Module - Passenger | √ | √ | √ | √ | | 0057 |
| 2021 | Buick | Envision | Audio Amplifier | √ | √ | √ | √ | | |
| 2020 | Buick | Enclave | Transmission Control Module | √ | √ | √ | √ | √ | 0017 |
| 2020 | Buick | Enclave | Liftgate Control Module | √ | √ | √ | √ | √ | 0146 0169 |
| 2020 | Buick | Enclave | Telematics Communication Interface Control Module | √ | √ | √ | √ | √ | 0755 |
| 2020 | Buick | Enclave | Serial Data Gateway Module - Processor 1 | √ | √ | √ | | | |
| 2020 | Buick | Enclave | Serial Data Gateway Module - Processor 2 | √ | √ | √ | | | |
| 2020 | Buick | Enclave | Video Processing Control Module | √ | √ | √ | √ | √ | |
| 2020 | Buick | Enclave | Instrument Cluster | √ | √ | √ | √ | √ | 0247 |
| 2020 | Buick | Enclave | Parking Assist Control Module | √ | √ | √ | √ | √ | 0247 0271 |
| 2020 | Buick | Enclave | HVAC Control Module | √ | √ | √ | √ | √ | 0007 0129 |
| 2020 | Buick | Enclave | Seat Memory Control Module - Driver | √ | √ | √ | √ | √ | |
| 2020 | Buick | Enclave | Inflatable Restraint Sensing and Diagnostic Module | √ | √ | √ | √ | √ | 0172 0134 0111 0758 |
| 2020 | Buick | Enclave | Keyless Entry Control Module | √ | √ | √ | √ | √ | 0759 |
| 2020 | Buick | Enclave | Passenger Presence Module | √ | √ | √ | √ | √ | 0057 |
| 2020 | Buick | Enclave | Body Control Module | √ | √ | √ | √ | √ | 0199 0239 0161 0162 0163 0164 0165 0166 0167 0168 0242 0263 0203 0201 0208 0206 0083 0267 0160 0233 |
| 2020 | Buick | Enclave | Side Object Sensor Module - Left | √ | √ | √ | | √ | |
| 2020 | Buick | Enclave | Active Safety Control Module | √ | √ | √ | √ | | |
| 2020 | Buick | Enclave | Frontview Camera - Windshield | √ | √ | √ | √ | | 0196 |
| 2020 | Buick | Enclave | Forward Range Radar Sensor - Long Range | √ | √ | √ | √ | | 0260 |

| | | | | | | | | | |
|------|-------|---------|--|---|---|---|---|---|---|
| 2020 | Buick | Enclave | Short Range Radar Sensor - Left Front | √ | √ | √ | | | |
| 2020 | Buick | Enclave | Short Range Radar Sensor - Right Front | √ | √ | √ | | | |
| 2020 | Buick | Enclave | Short Range Radar Sensor - Rear Middle | √ | √ | √ | | | |
| 2020 | Buick | Enclave | Electronic Brake Control Module | √ | √ | √ | √ | √ | 0225 0090 0111 0277 |
| 2020 | Buick | Enclave | Power Steering Control Module | √ | √ | √ | √ | √ | 0089 0084 |
| 2020 | Buick | Enclave | Suspension Control Module | √ | √ | √ | √ | √ | |
| 2020 | Buick | Enclave | Amplifier | √ | √ | √ | √ | √ | |
| 2020 | Buick | Enclave | HVAC Controls | √ | √ | √ | √ | √ | |
| 2020 | Buick | Enclave | Radio | √ | √ | √ | √ | √ | 0226 0267 0269 |
| 2020 | Buick | Enclave | Radio Controls | √ | √ | √ | √ | √ | 0241 |
| 2020 | Buick | Enclave | Engine Control Module | √ | √ | √ | √ | √ | 0263 0156 0209 0006 0115 0756 0086 0085 0154 0217 0258 0236 |
| 2020 | Buick | Enclave | Rear Drive Control Module | √ | √ | √ | √ | √ | 0003 |
| 2020 | Buick | Enclave | Chassis Control Module | √ | √ | √ | √ | √ | 0014 0078 |
| 2020 | Buick | Encore | Frontview Camera - Windshield | √ | √ | √ | √ | √ | 0205 0196 075A 0084 |
| 2020 | Buick | Encore | Headlamp Control Module | √ | √ | √ | √ | √ | 0195 |
| 2020 | Buick | Encore | Telematics Communication Interface Control Module | √ | √ | √ | √ | √ | 0259 0048 0011 0010 |
| 2020 | Buick | Encore | Engine Control Module | √ | √ | √ | √ | √ | 0263 0156 0209 0020 0132 0067 0066 076D 0086 0213 0217 0006 0144 0258 0139 0115 0212 0214 0757 0085 075D 075E 075F 0760 0756 0761 0762 0763 |
| 2020 | Buick | Encore | Transmission Control Module | √ | √ | √ | √ | √ | 0017 0036 0016 075C |
| 2020 | Buick | Encore | Seat Memory Control Module - Driver | √ | √ | √ | √ | √ | |
| 2020 | Buick | Encore | Passenger Presence Module | √ | √ | √ | √ | √ | 0057 |
| 2020 | Buick | Encore | Keyless Entry Control Module | √ | √ | √ | √ | √ | 0759 |
| 2020 | Buick | Encore | Inflatable Restraint Sensing and Diagnostic Module | √ | √ | √ | √ | √ | 0172 0134 0111 0758 |
| 2020 | Buick | Encore | HVAC Controls | √ | √ | √ | √ | √ | |
| 2020 | Buick | Encore | Radio Controls | √ | √ | √ | √ | √ | 0241 |
| 2020 | Buick | Encore | Radio | √ | √ | √ | √ | √ | 0226 0150 0269 0267 |
| 2020 | Buick | Encore | Brake System Control Module | √ | √ | √ | √ | √ | 0766 0758 0767 0768 |
| 2020 | Buick | Encore | Power Steering Control Module | √ | √ | √ | √ | √ | 0207 0089 0084 |
| 2020 | Buick | Encore | Body Control Module | √ | √ | √ | √ | √ | 0199 0239 0161 0162 0163 0164 0165 0166 0167 0168 0242 0263 0203 0201 0208 0206 0083 0267 0160 0233 0158 |
| 2020 | Buick | Encore | Rear Drive Control Module | √ | √ | √ | √ | √ | 0003 075B |
| 2020 | Buick | Encore | Instrument Cluster | √ | √ | √ | √ | √ | 0247 |
| 2020 | Buick | Encore | Head-Up Display Module | √ | √ | √ | √ | √ | |

| | | | | | | | | | |
|------|-------|----------|--|---|---|---|---|---|---------------------|
| 2020 | Buick | Encore | Parking Assist Control Module | √ | √ | √ | √ | √ | 0247 0271 |
| 2020 | Buick | Encore | Side Object Sensor Module - Left | √ | √ | √ | | √ | |
| 2020 | Buick | Encore | Side Object Sensor Module - Right | √ | √ | √ | | √ | |
| 2020 | Buick | Encore | Serial Data Gateway Module - Processor 1 | √ | √ | √ | | | |
| 2020 | Buick | Encore | Serial Data Gateway Module - Processor 2 | √ | √ | √ | | | |
| 2020 | Buick | Encore | HVAC Control Module | √ | √ | √ | √ | √ | 0007 0129 |
| 2020 | Buick | Encore | Steering Column Lock Control Module | √ | √ | √ | √ | | |
| 2020 | Buick | Encore | Video Processing Control Module | √ | √ | √ | √ | √ | |
| 2020 | Buick | Encore | Liftgate Control Module | √ | √ | √ | √ | √ | 0146 0169 |
| 2020 | Buick | Encore | Amplifier | √ | √ | √ | √ | | |
| 2020 | Buick | Encore | Serial Data Gateway Module | √ | √ | √ | | | |
| 2020 | Buick | Encore | Electronic Brake Control Module | √ | √ | √ | √ | √ | 0090 |
| 2020 | Buick | Encore | Steering Wheel Angle Sensor Module | √ | √ | √ | | | 0093 0090 |
| 2020 | Buick | Encore | Trailer Lighting Control Module | √ | √ | √ | √ | √ | 0247 |
| 2020 | Buick | Encore | Seat Memory Control Module | √ | √ | √ | √ | √ | 0310 |
| 2020 | Buick | Encore | Front Seat Heating Control Module | √ | √ | √ | √ | √ | |
| 2020 | Buick | Encore | Human Machine Interface Control Module | √ | √ | √ | √ | √ | 0150 |
| 2020 | Buick | Encore | Chassis Control Module | √ | √ | √ | √ | √ | 0217 |
| 2020 | Buick | Envision | Transmission Control Module | √ | √ | √ | √ | √ | 0017 0036 |
| 2020 | Buick | Envision | Serial Data Gateway Module | √ | √ | √ | | | |
| 2020 | Buick | Envision | Instrument Cluster | √ | √ | √ | √ | √ | 0247 |
| 2020 | Buick | Envision | Parking Assist Control Module | √ | √ | √ | √ | √ | 0247 0271 |
| 2020 | Buick | Envision | Video Processing Control Module | √ | √ | √ | √ | √ | |
| 2020 | Buick | Envision | Inflatable Restraint Sensing and Diagnostic Module | √ | √ | √ | √ | √ | 0172 0134 0111 0758 |
| 2020 | Buick | Envision | Keyless Entry Control Module | √ | √ | √ | √ | √ | |
| 2020 | Buick | Envision | Passenger Presence Module | √ | √ | √ | √ | √ | 0057 |
| 2020 | Buick | Envision | Electronic Brake Control Module | √ | √ | √ | √ | √ | 0225 0090 0111 0229 |
| 2020 | Buick | Envision | Multi-Axis Acceleration Sensor Module | √ | √ | √ | | | 0111 |
| 2020 | Buick | Envision | Power Steering Control Module | √ | √ | √ | √ | | 0081 0080 0089 |
| 2020 | Buick | Envision | Steering Wheel Angle Sensor Module | √ | √ | √ | | | 0093 0090 |
| 2020 | Buick | Envision | Suspension Control Module | √ | √ | √ | √ | √ | |
| 2020 | Buick | Envision | Liftgate Control Module | √ | √ | √ | √ | √ | 0146 0169 |
| 2020 | Buick | Envision | Telematics Communication Interface Control Module | √ | √ | √ | √ | √ | 0259 0048 0011 0010 |
| 2020 | Buick | Envision | HVAC Control Module | √ | √ | √ | √ | √ | 0007 0129 |
| 2020 | Buick | Envision | Accessory DC/AC Power Inverter Module | √ | √ | √ | √ | √ | |
| 2020 | Buick | Envision | Seat Memory Control Module - Driver | √ | √ | √ | √ | √ | |
| 2020 | Buick | Envision | Amplifier | √ | √ | √ | √ | | |
| 2020 | Buick | Envision | Human Machine Interface Control Module | √ | √ | √ | √ | √ | 0150 |
| 2020 | Buick | Envision | HVAC Controls | √ | √ | √ | √ | √ | |
| 2020 | Buick | Envision | Radio | √ | √ | √ | √ | √ | 0226 0150 |
| 2020 | Buick | Envision | Radio Controls | √ | √ | √ | √ | | 0241 |
| 2020 | Buick | Envision | Active Safety Control Module | √ | √ | √ | √ | √ | |

| | | | | | | | | | |
|------|-------|----------|--|---|---|---|---|---|---|
| 2020 | Buick | Envision | Frontview Camera - Windshield | √ | √ | √ | √ | √ | 0205 0196 075A |
| 2020 | Buick | Envision | Body Control Module | √ | √ | √ | √ | √ | 0199 0239 0161 0162 0163 0164 0165 0166 0167 0168 0242 0263 0203 0201 0208 0206 0083 0267 0160 0233 0150 |
| 2020 | Buick | Envision | Side Object Sensor Module - Left | √ | √ | √ | | √ | |
| 2020 | Buick | Envision | Side Object Sensor Module - Right | √ | √ | √ | | √ | |
| 2020 | Buick | Envision | Forward Range Radar Sensor - Long Range | √ | √ | √ | √ | | 0260 |
| 2020 | Buick | Envision | Engine Control Module | √ | √ | √ | √ | √ | 0263 0156 0209 0076 0132 0067 0147 0115 0086 0154 0212 0214 0217 0006 0144 0258 0000 0100 0000 0000 |
| 2020 | Buick | Envision | Rear Drive Control Module | √ | √ | √ | √ | √ | 0003 |
| 2020 | Buick | Regal | Transmission Control Module | √ | √ | √ | √ | √ | 0017 0020 0084 |
| 2020 | Buick | Regal | Headlamp Control Module | √ | √ | √ | √ | √ | 0195 |
| 2020 | Buick | Regal | Liftgate Control Module | √ | √ | √ | √ | √ | 0146 0169 |
| 2020 | Buick | Regal | Telematics Communication Interface Control Module | √ | √ | √ | √ | √ | 0259 0048 0011 0010 |
| 2020 | Buick | Regal | Inflatable Restraint Sensing and Diagnostic Module | √ | √ | √ | √ | √ | 0172 0134 0111 0758 |
| 2020 | Buick | Regal | Keyless Entry Control Module | √ | √ | √ | √ | √ | 0759 |
| 2020 | Buick | Regal | Passenger Presence Module | √ | √ | √ | √ | √ | 0057 |
| 2020 | Buick | Regal | Engine Control Module | √ | √ | √ | √ | √ | 0263 0156 0209 0076 0132 0067 0147 0115 0086 0154 0212 0214 0217 0006 0144 0258 0000 0100 0000 0000 |
| 2020 | Buick | Regal | Side Object Sensor Module - Left | √ | √ | √ | | √ | |
| 2020 | Buick | Regal | Instrument Cluster | √ | √ | √ | √ | √ | 0247 |
| 2020 | Buick | Regal | Parking Assist Control Module | √ | √ | √ | √ | √ | 0247 0271 |
| 2020 | Buick | Regal | Serial Data Gateway Module | √ | √ | √ | | | |
| 2020 | Buick | Regal | Electronic Brake Control Module | √ | √ | √ | √ | √ | 0090 0111 0229 0225 |
| 2020 | Buick | Regal | Power Steering Control Module | √ | √ | √ | √ | | 0081 0080 0089 |
| 2020 | Buick | Regal | Suspension Control Module | √ | √ | √ | √ | √ | |
| 2020 | Buick | Regal | Active Safety Control Module | √ | √ | √ | √ | | |
| 2020 | Buick | Regal | Forward Range Radar Sensor - Long Range | √ | √ | √ | √ | | 0260 |
| 2020 | Buick | Regal | Frontview Camera - Windshield | √ | √ | √ | √ | | 0196 |
| 2020 | Buick | Regal | Seat Memory Control Module - Driver | √ | √ | √ | √ | √ | |
| 2020 | Buick | Regal | Body Control Module | √ | √ | √ | √ | √ | 0199 0239 0161 0162 0163 0164 0165 0166 0167 0168 0242 0263 0203 0201 0208 0206 0083 0267 0160 0233 0150 |
| 2020 | Buick | Regal | Amplifier | √ | √ | √ | √ | | |

| | | | | | | | | | |
|------|-------|---------|--|---|---|---|---|---|--|
| 2020 | Buick | Regal | HVAC Control Module | √ | √ | √ | √ | √ | 0007 0129 |
| 2020 | Buick | Regal | HVAC Controls | √ | √ | √ | √ | √ | |
| 2020 | Buick | Regal | Radio | √ | √ | √ | √ | √ | 0150 0226 0269 0267 |
| 2020 | Buick | Regal | Radio Controls | √ | √ | √ | √ | √ | 0241 |
| 2020 | Buick | Regal | Rear Drive Control Module | √ | √ | √ | √ | √ | 0003 |
| 2020 | Buick | Regal | Seat Memory Control Module - Passenger | √ | √ | √ | √ | √ | |
| 2019 | Buick | Cascada | Transmission Control Module | √ | √ | √ | √ | √ | 0017 0036 |
| 2019 | Buick | Cascada | Engine Control Module | √ | √ | √ | √ | √ | 0263 0156 0209 0020 0132 0067 0115 0086 0085 0154 0213 0221 0212 0214 0217 0006 |
| 2019 | Buick | Cascada | Headlamp Control Module | √ | √ | √ | √ | √ | 0195 |
| 2019 | Buick | Cascada | Telematics Communication Interface Control Module | √ | √ | √ | √ | √ | 0259 0048 0011 0010 |
| 2019 | Buick | Cascada | Chassis Control Module | √ | √ | √ | √ | √ | 0217 |
| 2019 | Buick | Cascada | Frontview Camera - Windshield | √ | √ | √ | √ | √ | 0205 0196 075A |
| 2019 | Buick | Cascada | HVAC Control Module | √ | √ | √ | √ | √ | 0007 0129 |
| 2019 | Buick | Cascada | Front Seat Heating Control Module | √ | √ | √ | √ | √ | |
| 2019 | Buick | Cascada | Electronic Brake Control Module | √ | √ | √ | √ | √ | 0225 0090 0111 0229 |
| 2019 | Buick | Cascada | Multi-Axis Acceleration Sensor Module | √ | √ | √ | | | 0112 0111 |
| 2019 | Buick | Cascada | Parking Brake Control Module | √ | √ | √ | √ | √ | 0229 |
| 2019 | Buick | Cascada | Power Steering Control Module | √ | √ | √ | √ | | 0089 0081 0080 |
| 2019 | Buick | Cascada | Steering Wheel Angle Sensor Module | √ | √ | √ | | | 0093 0090 |
| 2019 | Buick | Cascada | Inflatable Restraint Sensing and Diagnostic Module | √ | √ | √ | √ | √ | 0172 0134 0111 0758 |
| 2019 | Buick | Cascada | Body Control Module | √ | √ | √ | √ | √ | 0242 0263 0203 0201 0208 0206 0083 0160 |
| 2019 | Buick | Cascada | Radio | √ | √ | √ | √ | √ | |
| 2019 | Buick | Cascada | Digital Radio Receiver Control Module | √ | √ | √ | √ | √ | 0247 |
| 2019 | Buick | Cascada | Folding Top Control Module | √ | √ | √ | √ | √ | 0247 0004 0005 |
| 2019 | Buick | Cascada | Instrument Cluster | √ | √ | √ | √ | √ | 0247 |
| 2019 | Buick | Cascada | Parking Assist Control Module | √ | √ | √ | √ | √ | 0247 0271 |
| 2019 | Buick | Cascada | Headlamp High Beam Control Module | √ | √ | √ | √ | √ | 0247 |
| 2019 | Buick | Cascada | Passenger Presence Module | √ | √ | √ | √ | √ | 0057 |
| 2019 | Buick | Enclave | Transmission Control Module | √ | √ | √ | √ | √ | 0017 |
| 2019 | Buick | Enclave | Chassis Control Module | √ | √ | √ | √ | √ | 0014 0078 |
| 2019 | Buick | Enclave | Engine Control Module | √ | √ | √ | √ | √ | 0263 0156 0209 0006 0115 0756 0086 0085 0154 0217 0258 0236 |
| 2019 | Buick | Enclave | Liftgate Control Module | √ | √ | √ | √ | √ | 0146 0169 |
| 2019 | Buick | Enclave | Telematics Communication Interface Control Module | √ | √ | √ | √ | √ | 0259 0048 0011 0010 |
| 2019 | Buick | Enclave | HVAC Control Module | √ | √ | √ | √ | √ | 0007 0129 |
| 2019 | Buick | Enclave | Electronic Brake Control Module | √ | √ | √ | √ | √ | 0225 0090 0111 0277 |
| 2019 | Buick | Enclave | Power Steering Control Module | √ | √ | √ | √ | | 0089 0084 |

| | | | | | | | | | |
|------|-------|---------|--|---|---|---|---|---|---|
| 2019 | Buick | Enclave | Suspension Control Module | √ | √ | √ | √ | √ | |
| 2019 | Buick | Enclave | Seat Memory Control Module - Driver | √ | √ | √ | √ | √ | |
| 2019 | Buick | Enclave | Passenger Presence Module | √ | √ | √ | √ | √ | 0057 |
| 2019 | Buick | Enclave | Inflatable Restraint Sensing and Diagnostic Module | √ | √ | √ | √ | √ | 0172 0134 0111 0758 |
| 2019 | Buick | Enclave | Keyless Entry Control Module | √ | √ | √ | √ | √ | 0759 |
| 2019 | Buick | Enclave | Instrument Cluster | √ | √ | √ | √ | √ | 0247 |
| 2019 | Buick | Enclave | Left Side Object Detection Control Module | √ | √ | √ | √ | √ | |
| 2019 | Buick | Enclave | Parking Assist Control Module | √ | √ | √ | √ | √ | 0247 0271 |
| 2019 | Buick | Enclave | Frontview Camera - Windshield | √ | √ | √ | √ | √ | 0196 |
| 2019 | Buick | Enclave | Active Safety Control Module | √ | √ | √ | √ | √ | |
| 2019 | Buick | Enclave | Long Range Radar Sensor Module | √ | √ | √ | √ | √ | 0260 |
| 2019 | Buick | Enclave | Left Front Short Range Radar Sensor Module | √ | √ | √ | √ | √ | |
| 2019 | Buick | Enclave | Right Front Short Range Radar Sensor Module | √ | √ | √ | √ | √ | |
| 2019 | Buick | Enclave | Rear Short Range Radar Sensor Module | √ | √ | √ | √ | √ | |
| 2019 | Buick | Enclave | Amplifier | √ | √ | √ | √ | √ | |
| 2019 | Buick | Enclave | Human Machine Interface Control Module | √ | √ | √ | √ | √ | 0150 |
| 2019 | Buick | Enclave | HVAC Controls | √ | √ | √ | √ | √ | |
| 2019 | Buick | Enclave | Radio Controls | √ | √ | √ | √ | √ | 0241 |
| 2019 | Buick | Enclave | Radio | √ | √ | √ | √ | √ | 0226 0150 |
| 2019 | Buick | Enclave | Body Control Module | √ | √ | √ | √ | √ | 0199 0239 0161 0162 0163 0164 0165 0166 0167 0168 0242 0263 0203 0201 0208 0206 0083 0267 0160 0233 0150 |
| 2019 | Buick | Enclave | Video Processing Control Module | √ | √ | √ | √ | √ | |
| 2019 | Buick | Enclave | Rear Differential Clutch Control Module | √ | √ | √ | √ | √ | 0003 |
| 2019 | Buick | Enclave | Serial Data Gateway Module - Processor 1 | √ | √ | √ | √ | √ | |
| 2019 | Buick | Enclave | Serial Data Gateway Module - Processor 2 | √ | √ | √ | √ | √ | |
| 2019 | Buick | Encore | Transmission Control Module | √ | √ | √ | √ | √ | 0017 0036 |
| 2019 | Buick | Encore | Engine Control Module | √ | √ | √ | √ | √ | 0263 0156 0209 0020 0132 0067 0115 0086 0085 0154 0213 0221 0212 0214 0217 0006 0144 0258 0139 0066 0260 |
| 2019 | Buick | Encore | Headlamp Control Module | √ | √ | √ | √ | √ | 0195 |
| 2019 | Buick | Encore | Telematics Communication Interface Control Module | √ | √ | √ | √ | √ | 0259 0048 0011 0010 |
| 2019 | Buick | Encore | Steering Column Lock Control Module | √ | √ | √ | √ | √ | |
| 2019 | Buick | Encore | Chassis Control Module | √ | √ | √ | √ | √ | 0217 |
| 2019 | Buick | Encore | Trailer Lighting Control Module | √ | √ | √ | √ | √ | 0247 |
| 2019 | Buick | Encore | Electronic Brake Control Module | √ | √ | √ | √ | √ | 0090 |
| 2019 | Buick | Encore | Power Steering Control Module | √ | √ | √ | √ | √ | 0207 |
| 2019 | Buick | Encore | Steering Wheel Angle Sensor Module | √ | √ | √ | √ | √ | 0093 0090 |

| | | | | | | | | | |
|------|-------|----------|--|---|---|---|---|---|---|
| 2019 | Buick | Encore | Frontview Camera - Windshield | √ | √ | √ | √ | √ | 0205 0196 075A |
| 2019 | Buick | Encore | HVAC Control Module | √ | √ | √ | √ | √ | 0007 0129 |
| 2019 | Buick | Encore | Keyless Entry Control Module | √ | √ | √ | √ | √ | |
| 2019 | Buick | Encore | Passenger Presence Module | √ | √ | √ | √ | √ | 0057 |
| 2019 | Buick | Encore | Inflatable Restraint Sensing and Diagnostic Module | √ | √ | √ | √ | √ | 0172 0134 0111 0758 |
| 2019 | Buick | Encore | Instrument Cluster | √ | √ | √ | √ | √ | 0247 |
| 2019 | Buick | Encore | Left Side Object Detection Control Module | √ | √ | √ | √ | √ | |
| 2019 | Buick | Encore | Parking Assist Control Module | √ | √ | √ | √ | √ | 0247 0271 |
| 2019 | Buick | Encore | Serial Data Gateway Module | √ | √ | √ | √ | √ | |
| 2019 | Buick | Encore | Body Control Module | √ | √ | √ | √ | √ | 0199 0239 0161 0162 0163 0164 0165 0166 0167 0168 0242 0263 0203 0201 0208 0206 0083 0267 0160 0233 0150 |
| 2019 | Buick | Encore | Amplifier | √ | √ | √ | √ | √ | |
| 2019 | Buick | Encore | Human Machine Interface Control Module | √ | √ | √ | √ | √ | 0150 |
| 2019 | Buick | Encore | Radio | √ | √ | √ | √ | √ | 0226 0150 |
| 2019 | Buick | Encore | Radio Controls | √ | √ | √ | √ | √ | 0241 |
| 2019 | Buick | Encore | Front Seat Heating Control Module | √ | √ | √ | √ | √ | |
| 2019 | Buick | Encore | Rear Differential Clutch Control Module | √ | √ | √ | √ | √ | 0003 075B |
| 2019 | Buick | Encore | Seat Memory Control Module | √ | √ | √ | √ | √ | 0310 |
| 2019 | Buick | Envision | Transmission Control Module | √ | √ | √ | √ | √ | 0017 0036 |
| 2019 | Buick | Envision | Instrument Cluster | √ | √ | √ | √ | √ | 0247 |
| 2019 | Buick | Envision | Left Side Object Detection Control Module | √ | √ | √ | √ | √ | |
| 2019 | Buick | Envision | Parking Assist Control Module | √ | √ | √ | √ | √ | 0247 0271 |
| 2019 | Buick | Envision | Right Side Object Detection Control Module | √ | √ | √ | √ | √ | |
| 2019 | Buick | Envision | Serial Data Gateway Module | √ | √ | √ | √ | √ | |
| 2019 | Buick | Envision | Headlamp Control Module | √ | √ | √ | √ | √ | 0195 |
| 2019 | Buick | Envision | Liftgate Control Module | √ | √ | √ | √ | √ | 0146 0169 |
| 2019 | Buick | Envision | Telematics Communication Interface Control Module | √ | √ | √ | √ | √ | 0259 0048 0011 0010 |
| 2019 | Buick | Envision | HVAC Control Module | √ | √ | √ | √ | √ | 0007 0129 |
| 2019 | Buick | Envision | Engine Control Module | √ | √ | √ | √ | √ | 0263 0156 0209 0076 0132 0067 0147 0115 0086 0154 0212 0214 0217 0006 0144 0258 0006 0130 0000 0010 |
| 2019 | Buick | Envision | Accessory DC/AC Power Inverter Module | √ | √ | √ | √ | √ | |
| 2019 | Buick | Envision | Seat Memory Control Module - Driver | √ | √ | √ | √ | √ | |
| 2019 | Buick | Envision | Frontview Camera - Windshield | √ | √ | √ | √ | √ | 0205 0196 075A |
| 2019 | Buick | Envision | Active Safety Control Module | √ | √ | √ | √ | √ | |
| 2019 | Buick | Envision | Long Range Radar Sensor Module | √ | √ | √ | √ | √ | 0260 |
| 2019 | Buick | Envision | Video Processing Control Module | √ | √ | √ | √ | √ | |
| 2019 | Buick | Envision | Inflatable Restraint Sensing and Diagnostic Module | √ | √ | √ | √ | √ | 0172 0134 0111 0758 |

| | | | | | | | | | |
|------|-------|----------|---|---|---|---|---|---|---|
| 2019 | Buick | Envision | Passenger Presence Module | √ | √ | √ | √ | √ | 0057 |
| 2019 | Buick | Envision | Keyless Entry Control Module | √ | √ | √ | √ | √ | |
| 2019 | Buick | Envision | Body Control Module | √ | √ | √ | √ | √ | 0199 0239 0161 0162 0163 0164 0165 0166 0167 0168 0242 0263 0203 0201 0208 0206 0083 0267 0160 0233 0150 |
| 2019 | Buick | Envision | Multi-Axis Acceleration Sensor Module | √ | √ | √ | | | 0111 |
| 2019 | Buick | Envision | Rear Differential Clutch Control Module | √ | √ | √ | √ | √ | 0003 |
| 2019 | Buick | Envision | Steering Column Lock Control Module | √ | √ | √ | √ | | |
| 2019 | Buick | Envision | Amplifier | √ | √ | √ | √ | | |
| 2019 | Buick | Envision | Radio | √ | √ | √ | √ | √ | 0226 0150 |
| 2019 | Buick | Envision | Human Machine Interface Control Module | √ | √ | √ | √ | √ | 0150 |
| 2019 | Buick | Envision | HVAC Controls | √ | √ | √ | √ | √ | |
| 2019 | Buick | Envision | Radio Controls | √ | √ | √ | √ | | 0241 |
| 2019 | Buick | Envision | Electronic Brake Control Module | √ | √ | √ | √ | √ | 0225 0090 0111 0229 |
| 2019 | Buick | Envision | Steering Wheel Angle Sensor Module | √ | √ | √ | | | 0093 0090 |
| 2019 | Buick | Envision | Power Steering Control Module | √ | √ | √ | √ | | 0081 0080 0089 |
| 2019 | Buick | Envision | Suspension Control Module | √ | √ | √ | √ | √ | |
| 2019 | Buick | LaCrosse | Transmission Control Module | √ | √ | √ | √ | √ | 0017 0036 |
| 2019 | Buick | LaCrosse | Chassis Control Module | √ | √ | √ | √ | √ | 0014 0078 |
| 2019 | Buick | LaCrosse | Transmission Range Control Module | √ | √ | √ | √ | | 0014 0078 0013 |
| 2019 | Buick | LaCrosse | Hybrid/EV Powertrain Control Module 2 | √ | √ | √ | √ | √ | 0202 0218 |
| 2019 | Buick | LaCrosse | Hybrid/EV Powertrain Control Module 1 | √ | √ | √ | √ | √ | 0436 0263 |
| 2019 | Buick | LaCrosse | Engine Control Module | √ | √ | √ | √ | √ | 0263 0156 0209 0020 0132 0067 0115 0086 0154 0213 0214 0217 0258 0139 0006 0756 0005 0006 |
| 2019 | Buick | LaCrosse | Headlamp Control Module | √ | √ | √ | √ | √ | |
| 2019 | Buick | LaCrosse | Telematics Communication Interface Control Module | √ | √ | √ | √ | √ | 0259 0048 0011 0010 |
| 2019 | Buick | LaCrosse | Rear Differential Clutch Control Module | √ | √ | √ | √ | √ | 0003 |
| 2019 | Buick | LaCrosse | Brake Booster Control Module | √ | √ | √ | √ | | |
| 2019 | Buick | LaCrosse | Active Safety Control Module | √ | √ | √ | √ | √ | |
| 2019 | Buick | LaCrosse | Frontview Camera - Windshield | √ | √ | √ | √ | | 0196 |
| 2019 | Buick | LaCrosse | Long Range Radar Sensor Module | √ | √ | √ | √ | | 0260 |
| 2019 | Buick | LaCrosse | Body Control Module | √ | √ | √ | √ | √ | 0199 0239 0161 0162 0163 0164 0165 0166 0167 0168 0242 0263 0203 0201 0208 0206 0083 0267 0160 0233 0150 |
| 2019 | Buick | LaCrosse | Keyless Entry Control Module | √ | √ | √ | √ | √ | |
| 2019 | Buick | LaCrosse | Passenger Presence Module | √ | √ | √ | √ | √ | 0057 |

| | | | | | | | | | |
|------|-------|----------|--|---|---|---|---|---|---|
| 2019 | Buick | LaCrosse | Inflatable Restraint Sensing and Diagnostic Module | √ | √ | √ | √ | √ | 0172 0134 0111 0758 |
| 2019 | Buick | LaCrosse | Seat Memory Control Module - Driver | √ | √ | √ | √ | √ | |
| 2019 | Buick | LaCrosse | Amplifier | √ | √ | √ | √ | √ | |
| 2019 | Buick | LaCrosse | Human Machine Interface Control Module | √ | √ | √ | √ | √ | 0150 |
| 2019 | Buick | LaCrosse | HVAC Controls | √ | √ | √ | √ | √ | |
| 2019 | Buick | LaCrosse | Radio Controls | √ | √ | √ | √ | √ | 0241 |
| 2019 | Buick | LaCrosse | Radio | √ | √ | √ | √ | √ | 0226 0150 |
| 2019 | Buick | LaCrosse | HVAC Control Module | √ | √ | √ | √ | √ | 0007 0129 |
| 2019 | Buick | LaCrosse | Electronic Brake Control Module | √ | √ | √ | √ | √ | 0090 0111 0229 0225 |
| 2019 | Buick | LaCrosse | Power Steering Control Module | √ | √ | √ | √ | √ | 0081 0080 0089 |
| 2019 | Buick | LaCrosse | Suspension Control Module | √ | √ | √ | √ | √ | |
| 2019 | Buick | LaCrosse | Instrument Cluster | √ | √ | √ | √ | √ | 0247 |
| 2019 | Buick | LaCrosse | Left Side Object Detection Control Module | √ | √ | √ | √ | √ | |
| 2019 | Buick | LaCrosse | Parking Assist Control Module | √ | √ | √ | √ | √ | 0247 0271 |
| 2019 | Buick | LaCrosse | Right Side Object Detection Control Module | √ | √ | √ | √ | √ | |
| 2019 | Buick | LaCrosse | Serial Data Gateway Module | √ | √ | √ | √ | √ | |
| 2019 | Buick | Regal | Transmission Control Module | √ | √ | √ | √ | √ | 0020 0084 0017 |
| 2019 | Buick | Regal | Engine Control Module | √ | √ | √ | √ | √ | 0263 0156 0209 0076 0132 0067 0147 0115 0086 0154 0212 0214 0217 0006 0144 0258 |
| 2019 | Buick | Regal | Headlamp Control Module | √ | √ | √ | √ | √ | 0195 |
| 2019 | Buick | Regal | Telematics Communication Interface Control Module | √ | √ | √ | √ | √ | 0259 0048 0011 0010 |
| 2019 | Buick | Regal | Rear Differential Clutch Control Module | √ | √ | √ | √ | √ | 0003 |
| 2019 | Buick | Regal | HVAC Control Module | √ | √ | √ | √ | √ | 0007 0129 |
| 2019 | Buick | Regal | Seat Memory Control Module - Driver | √ | √ | √ | √ | √ | |
| 2019 | Buick | Regal | Instrument Cluster | √ | √ | √ | √ | √ | 0247 |
| 2019 | Buick | Regal | Left Side Object Detection Control Module | √ | √ | √ | √ | √ | |
| 2019 | Buick | Regal | Parking Assist Control Module | √ | √ | √ | √ | √ | 0247 0271 |
| 2019 | Buick | Regal | Serial Data Gateway Module | √ | √ | √ | √ | √ | |
| 2019 | Buick | Regal | Keyless Entry Control Module | √ | √ | √ | √ | √ | 0759 |
| 2019 | Buick | Regal | Inflatable Restraint Sensing and Diagnostic Module | √ | √ | √ | √ | √ | 0172 0134 0111 0758 |
| 2019 | Buick | Regal | Body Control Module | √ | √ | √ | √ | √ | 0199 0239 0161 0162 0163 0164 0165 0166 0167 0168 0242 0263 0203 0201 0208 0206 0083 0267 0160 0233 |
| 2019 | Buick | Regal | Passenger Presence Module | √ | √ | √ | √ | √ | 0057 |
| 2019 | Buick | Regal | Amplifier | √ | √ | √ | √ | √ | |
| 2019 | Buick | Regal | HVAC Controls | √ | √ | √ | √ | √ | |
| 2019 | Buick | Regal | Radio Controls | √ | √ | √ | √ | √ | 0241 |
| 2019 | Buick | Regal | Radio | √ | √ | √ | √ | √ | 0226 0267 0269 0150 |

| | | | | | | | | | |
|------|-------|---------|--|---|---|---|---|---|--|
| 2019 | Buick | Regal | Pedestrian Alert Sound Control Module | √ | √ | √ | √ | √ | |
| 2019 | Buick | Regal | Active Safety Control Module | √ | √ | √ | √ | | |
| 2019 | Buick | Regal | Long Range Radar Sensor Module | √ | √ | √ | √ | | 0260 |
| 2019 | Buick | Regal | Frontview Camera - Windshield | √ | √ | √ | √ | | 0196 |
| 2019 | Buick | Regal | Electronic Brake Control Module | √ | √ | √ | √ | √ | 0090 0111 0229 0225 |
| 2019 | Buick | Regal | Power Steering Control Module | √ | √ | √ | √ | | 0081 0080 0089 |
| 2019 | Buick | Regal | Suspension Control Module | √ | √ | √ | √ | √ | |
| 2019 | Buick | Regal | Liftgate Control Module | √ | √ | √ | √ | √ | 0146 0169 |
| 2019 | Buick | Regal | Seat Memory Control Module - Passenger | √ | √ | √ | √ | √ | |
| 2018 | Buick | Cascada | Folding Top Control Module | √ | √ | √ | √ | √ | 0247 0004 0005 |
| 2018 | Buick | Cascada | Instrument Cluster | √ | √ | √ | √ | √ | 0247 |
| 2018 | Buick | Cascada | Parking Assist Control Module | √ | √ | √ | √ | √ | 0247 0271 |
| 2018 | Buick | Cascada | Inflatable Restraint Sensing and Diagnostic Module | √ | √ | √ | √ | √ | 0172 0134 0111 0758 |
| 2018 | Buick | Cascada | Chassis Control Module | √ | √ | √ | √ | √ | 0217 |
| 2018 | Buick | Cascada | Frontview Camera Module | √ | √ | √ | √ | √ | 0247 0205 0196 075A |
| 2018 | Buick | Cascada | Headlamp Control Module | √ | √ | √ | √ | √ | 0195 |
| 2018 | Buick | Cascada | Telematics Communication Interface Control Module | √ | √ | √ | √ | √ | 0259 0048 0011 0010 |
| 2018 | Buick | Cascada | Transmission Control Module | √ | √ | √ | √ | √ | 0017 0036 |
| 2018 | Buick | Cascada | Body Control Module | √ | √ | √ | √ | √ | 0242 0263 0203 0201 0208 0206 0083 0160 |
| 2018 | Buick | Cascada | Radio | √ | √ | √ | √ | √ | |
| 2018 | Buick | Cascada | HVAC Control Module | √ | √ | √ | √ | √ | 0007 0129 |
| 2018 | Buick | Cascada | Electronic Brake Control Module | √ | √ | √ | √ | √ | 0225 0090 0111 0229 |
| 2018 | Buick | Cascada | Multi-Axis Acceleration Sensor Module | √ | √ | √ | | | 0112 0111 |
| 2018 | Buick | Cascada | Parking Brake Control Module | √ | √ | √ | √ | √ | 0229 |
| 2018 | Buick | Cascada | Power Steering Control Module | √ | √ | √ | √ | | 0089 0081 0080 |
| 2018 | Buick | Cascada | Steering Wheel Angle Sensor Module | √ | √ | √ | | | 0093 0090 |
| 2018 | Buick | Cascada | Front Seat Heating Control Module | √ | √ | √ | √ | √ | |
| 2018 | Buick | Cascada | Passenger Presence Module | √ | √ | √ | √ | √ | 0057 |
| 2018 | Buick | Cascada | Engine Control Module | √ | √ | √ | √ | √ | 0263 0156 0209 0020 0132 0067 0115 0086 0085 0154 0213 0221 0212 0214 0217 0006 |
| 2018 | Buick | Enclave | Liftgate Control Module | √ | √ | √ | √ | √ | 0146 0169 |
| 2018 | Buick | Enclave | Telematics Communication Interface Control Module | √ | √ | √ | √ | √ | 0259 0048 0011 0010 |
| 2018 | Buick | Enclave | Seat Memory Control Module - Driver | √ | √ | √ | √ | √ | 0310 |
| 2018 | Buick | Enclave | HVAC Control Module | √ | √ | √ | √ | √ | 0007 0129 |
| 2018 | Buick | Enclave | Engine Control Module | √ | √ | √ | √ | √ | 0263 0156 0209 0006 0115 0756 0086 0085 0154 0217 0258 0236 |
| 2018 | Buick | Enclave | Instrument Cluster | √ | √ | √ | √ | √ | 0247 |
| 2018 | Buick | Enclave | Left Side Object Detection Control Module | √ | √ | √ | | √ | |

| | | | | | | | | | |
|------|-------|---------|--|---|---|---|---|---|---|
| 2018 | Buick | Enclave | Serial Data Gateway Module | √ | √ | √ | | | |
| 2018 | Buick | Enclave | Parking Assist Control Module | √ | √ | √ | √ | √ | 0247 0271 |
| 2018 | Buick | Enclave | Active Safety Control Module | √ | √ | √ | √ | | |
| 2018 | Buick | Enclave | Frontview Camera Module | √ | √ | √ | √ | | 0196 |
| 2018 | Buick | Enclave | Left Front Short Range Radar Sensor Module | √ | √ | √ | | | |
| 2018 | Buick | Enclave | Long Range Radar Sensor Module | √ | √ | √ | √ | | 0260 |
| 2018 | Buick | Enclave | Right Front Short Range Radar Sensor Module | √ | √ | √ | | | |
| 2018 | Buick | Enclave | Rear Short Range Radar Sensor Module | √ | √ | √ | | | |
| 2018 | Buick | Enclave | Video Processing Control Module | √ | √ | √ | √ | √ | |
| 2018 | Buick | Enclave | Transmission Control Module | √ | √ | √ | √ | √ | 0017 |
| 2018 | Buick | Enclave | Chassis Control Module | √ | √ | √ | √ | √ | 0014 0078 |
| 2018 | Buick | Enclave | Body Control Module | √ | √ | √ | √ | √ | 0199 0239 0161 0162 0163 0164 0165 0166 0167 0168 0242 0263 0203 0201 0208 0206 0083 0267 0160 0233 0150 |
| 2018 | Buick | Enclave | Amplifier | √ | √ | √ | √ | | |
| 2018 | Buick | Enclave | Human Machine Interface Control Module | √ | √ | √ | √ | √ | 0150 |
| 2018 | Buick | Enclave | HVAC Controls | √ | √ | √ | √ | √ | |
| 2018 | Buick | Enclave | Radio Controls | √ | √ | √ | √ | | 0241 |
| 2018 | Buick | Enclave | Radio | √ | √ | √ | √ | √ | 0226 0150 |
| 2018 | Buick | Enclave | Electronic Brake Control Module | √ | √ | √ | √ | √ | 0225 0090 0111 0277 |
| 2018 | Buick | Enclave | Power Steering Control Module | √ | √ | √ | √ | | 0089 0084 |
| 2018 | Buick | Enclave | Suspension Control Module | √ | √ | √ | √ | √ | |
| 2018 | Buick | Enclave | Inflatable Restraint Sensing and Diagnostic Module | √ | √ | √ | √ | √ | 0172 0134 0111 0758 |
| 2018 | Buick | Enclave | Keyless Entry Control Module | √ | √ | √ | √ | √ | 0759 |
| 2018 | Buick | Enclave | Passenger Presence Module | √ | √ | √ | √ | √ | 0057 |
| 2018 | Buick | Enclave | Rear Differential Clutch Control Module | √ | √ | √ | √ | √ | 0003 |
| 2018 | Buick | Encore | Transmission Control Module | √ | √ | √ | √ | √ | 0017 0036 |
| 2018 | Buick | Encore | Headlamp Control Module | √ | √ | √ | √ | √ | 0195 |
| 2018 | Buick | Encore | Telematics Communication Interface Control Module | √ | √ | √ | √ | √ | 0259 0048 0011 0010 |
| 2018 | Buick | Encore | HVAC Control Module | √ | √ | √ | √ | √ | 0007 0129 |
| 2018 | Buick | Encore | Seat Memory Control Module | √ | √ | √ | √ | √ | 0310 |
| 2018 | Buick | Encore | Engine Control Module | √ | √ | √ | √ | √ | 0263 0156 0209 0020 0132 0067 0115 0086 0085 0154 0213 0221 0212 0214 0217 0006 0144 0258 0139 0066 0260 |
| 2018 | Buick | Encore | Front Seat Heating Control Module | √ | √ | √ | √ | √ | |
| 2018 | Buick | Encore | Radio | √ | √ | √ | √ | √ | 0226 0150 |
| 2018 | Buick | Encore | Passenger Presence Module | √ | √ | √ | √ | | 0057 |
| 2018 | Buick | Encore | Instrument Cluster | √ | √ | √ | √ | √ | 0247 |

| | | | | | | | | | |
|------|-------|----------|--|---|---|---|---|---|---|
| 2018 | Buick | Encore | Parking Assist Control Module | √ | √ | √ | √ | √ | 0247 0271 |
| 2018 | Buick | Encore | Left Side Object Detection Control Module | √ | √ | √ | | √ | |
| 2018 | Buick | Encore | Serial Data Gateway Module | √ | √ | √ | | | |
| 2018 | Buick | Encore | Trailer Lighting Control Module | √ | √ | √ | √ | √ | 0247 |
| 2018 | Buick | Encore | Inflatable Restraint Sensing and Diagnostic Module | √ | √ | √ | √ | √ | 0172 0134 0111 |
| 2018 | Buick | Encore | Keyless Entry Control Module | √ | √ | √ | √ | √ | |
| 2018 | Buick | Encore | Amplifier | √ | √ | √ | √ | | |
| 2018 | Buick | Encore | Human Machine Interface Control Module | √ | √ | √ | √ | √ | 0150 |
| 2018 | Buick | Encore | Electronic Brake Control Module | √ | √ | √ | √ | √ | 0090 |
| 2018 | Buick | Encore | Power Steering Control Module | √ | √ | √ | √ | | 0207 |
| 2018 | Buick | Encore | Steering Wheel Angle Sensor Module | √ | √ | √ | | | 0093 0090 |
| 2018 | Buick | Encore | Frontview Camera Module | √ | √ | √ | √ | √ | 0205 0196 075A |
| 2018 | Buick | Encore | Body Control Module | √ | √ | √ | √ | √ | 0199 0239 0161 0162 0163 0164 0165 0166 0167 0168 0242 0263 0203 0201 0208 0206 |
| 2018 | Buick | Encore | Chassis Control Module | √ | √ | √ | √ | √ | 0217 |
| 2018 | Buick | Encore | HVAC Controls | √ | √ | √ | √ | √ | |
| 2018 | Buick | Encore | Radio Controls | √ | √ | √ | √ | | 0241 |
| 2018 | Buick | Encore | Rear Differential Clutch Control Module | √ | √ | √ | √ | | 0003 075B |
| 2018 | Buick | Envision | Engine Control Module | √ | √ | √ | √ | √ | 0263 0156 0209 0020 0132 0067 0115 0086 0085 0154 0213 0221 0212 0214 0217 0006 0144 0258 0139 0076 |
| 2018 | Buick | Envision | Seat Memory Control Module - Driver | √ | √ | √ | √ | √ | 0310 |
| 2018 | Buick | Envision | Headlamp Control Module | √ | √ | √ | √ | √ | 0195 |
| 2018 | Buick | Envision | Liftgate Control Module | √ | √ | √ | √ | √ | 0146 0169 |
| 2018 | Buick | Envision | Telematics Communication Interface Control Module | √ | √ | √ | √ | √ | 0259 0048 0011 0010 |
| 2018 | Buick | Envision | Transmission Control Module | √ | √ | √ | √ | √ | 0017 0036 |
| 2018 | Buick | Envision | HVAC Control Module | √ | √ | √ | √ | √ | 0007 0129 |
| 2018 | Buick | Envision | Steering Column Lock Control Module | √ | √ | √ | √ | | |
| 2018 | Buick | Envision | Keyless Entry Control Module | √ | √ | √ | √ | √ | |
| 2018 | Buick | Envision | Instrument Cluster | √ | √ | √ | √ | √ | 0247 |
| 2018 | Buick | Envision | Left Side Object Detection Control Module | √ | √ | √ | | √ | |
| 2018 | Buick | Envision | Parking Assist Control Module | √ | √ | √ | √ | √ | 0247 0271 |
| 2018 | Buick | Envision | Right Side Object Detection Control Module | √ | √ | √ | | √ | |
| 2018 | Buick | Envision | Serial Data Gateway Module | √ | √ | √ | | | |
| 2018 | Buick | Envision | Active Safety Control Module | √ | √ | √ | √ | √ | |
| 2018 | Buick | Envision | Frontview Camera Module | √ | √ | √ | √ | √ | 0205 0196 075A |
| 2018 | Buick | Envision | Long Range Radar Sensor Module | √ | √ | √ | √ | | 0260 |
| 2018 | Buick | Envision | Video Processing Control Module | √ | √ | √ | √ | √ | |

| | | | | | | | | | |
|------|-------|----------|--|---|---|---|---|---|---|
| 2018 | Buick | Envision | Body Control Module | √ | √ | √ | √ | √ | 0199 0239 0161 0162 0163 0164 0165 0166 0167 0168 0242 0263 0203 0201 0208 0206 0083 0267 0160 0233 0150 |
| 2018 | Buick | Envision | Amplifier | √ | √ | √ | √ | | |
| 2018 | Buick | Envision | Human Machine Interface Control Module | √ | √ | √ | √ | √ | 0150 |
| 2018 | Buick | Envision | HVAC Controls | √ | √ | √ | √ | √ | |
| 2018 | Buick | Envision | Radio Controls | √ | √ | √ | √ | | 0241 |
| 2018 | Buick | Envision | Navigation Control Module | √ | √ | √ | √ | √ | |
| 2018 | Buick | Envision | Radio | √ | √ | √ | √ | √ | 0226 0150 |
| 2018 | Buick | Envision | Electronic Brake Control Module | √ | √ | √ | √ | √ | 0225 0090 0111 0229 |
| 2018 | Buick | Envision | Multi-Axis Acceleration Sensor Module | √ | √ | √ | | | 0111 |
| 2018 | Buick | Envision | Power Steering Control Module | √ | √ | √ | √ | | 0081 0080 0089 |
| 2018 | Buick | Envision | Steering Wheel Angle Sensor Module | √ | √ | √ | | | 0093 0090 |
| 2018 | Buick | Envision | Suspension Control Module | √ | √ | √ | √ | √ | |
| 2018 | Buick | Envision | Passenger Presence Module | √ | √ | √ | √ | √ | 0057 |
| 2018 | Buick | Envision | Inflatable Restraint Sensing and Diagnostic Module | √ | √ | √ | √ | √ | 0172 0134 0111 0758 |
| 2018 | Buick | Envision | Accessory DC/AC Power Inverter Module | √ | √ | √ | √ | √ | |
| 2018 | Buick | Envision | Rear Differential Clutch Control Module | √ | √ | √ | √ | √ | 0003 |
| 2018 | Buick | LaCrosse | Transmission Control Module | √ | √ | √ | √ | √ | 0017 0036 |
| 2018 | Buick | LaCrosse | Chassis Control Module | √ | √ | √ | √ | √ | 0014 0078 |
| 2018 | Buick | LaCrosse | HVAC Control Module | √ | √ | √ | √ | √ | 0007 0129 |
| 2018 | Buick | LaCrosse | Seat Memory Control Module - Driver | √ | √ | √ | √ | √ | 0310 |
| 2018 | Buick | LaCrosse | Headlamp Control Module | √ | √ | √ | √ | √ | |
| 2018 | Buick | LaCrosse | Telematics Communication Interface Control Module | √ | √ | √ | √ | √ | 0259 0048 0011 0010 |
| 2018 | Buick | LaCrosse | Electronic Brake Control Module | √ | √ | √ | √ | √ | 0090 0111 0229 0225 |
| 2018 | Buick | LaCrosse | Power Steering Control Module | √ | √ | √ | √ | | 0081 0080 0089 |
| 2018 | Buick | LaCrosse | Suspension Control Module | √ | √ | √ | √ | √ | |
| 2018 | Buick | LaCrosse | Brake Booster Control Module | √ | √ | √ | √ | | |
| 2018 | Buick | LaCrosse | Engine Control Module | √ | √ | √ | √ | √ | 0263 0156 0209 0020 0132 0067 0115 0086 0154 0213 0214 0217 0258 0139 0006 0756 0247 |
| 2018 | Buick | LaCrosse | Instrument Cluster | √ | √ | √ | √ | √ | 0247 |
| 2018 | Buick | LaCrosse | Left Side Object Detection Control Module | √ | √ | √ | | √ | |
| 2018 | Buick | LaCrosse | Right Side Object Detection Control Module | √ | √ | √ | | √ | |
| 2018 | Buick | LaCrosse | Parking Assist Control Module | √ | √ | √ | √ | √ | 0247 0271 |
| 2018 | Buick | LaCrosse | Serial Data Gateway Module | √ | √ | √ | | | |
| 2018 | Buick | LaCrosse | Keyless Entry Control Module | √ | √ | √ | √ | √ | |
| 2018 | Buick | LaCrosse | Inflatable Restraint Sensing and Diagnostic Module | √ | √ | √ | √ | √ | 0172 0134 0111 0758 |
| 2018 | Buick | LaCrosse | Passenger Presence Module | √ | √ | √ | √ | √ | 0057 |

| | | | | | | | | | |
|------|-------|----------|---|---|---|---|---|---|---|
| 2018 | Buick | LaCrosse | Human Machine Interface Control Module | √ | √ | √ | √ | √ | 0150 |
| 2018 | Buick | LaCrosse | Radio | √ | √ | √ | √ | √ | 0226 0150 |
| 2018 | Buick | LaCrosse | Amplifier | √ | √ | √ | √ | | |
| 2018 | Buick | LaCrosse | HVAC Controls | √ | √ | √ | √ | √ | |
| 2018 | Buick | LaCrosse | Radio Controls | √ | √ | √ | √ | | 0241 |
| 2018 | Buick | LaCrosse | Media Disc Player | √ | √ | √ | √ | √ | |
| 2018 | Buick | LaCrosse | Hybrid Powertrain Control Module | √ | √ | √ | √ | √ | 0436 0263 |
| 2018 | Buick | LaCrosse | Hybrid Powertrain Control Module 2 | √ | √ | √ | √ | √ | 0202 0218 |
| 2018 | Buick | LaCrosse | Rear Differential Clutch Control Module | √ | √ | √ | √ | √ | 0003 |
| 2018 | Buick | LaCrosse | Body Control Module | √ | √ | √ | √ | √ | 0199 0239 0161 0162 0163 0164 0165 0166 0167 0168 0242 0263 0203 0201 0208 0206 0083 0267 0160 0233 0150 |
| 2018 | Buick | LaCrosse | Active Safety Control Module | √ | √ | √ | √ | √ | |
| 2018 | Buick | LaCrosse | Long Range Radar Sensor Module | √ | √ | √ | √ | | 0260 |
| 2018 | Buick | LaCrosse | Video Processing Control Module | √ | √ | √ | √ | √ | |
| 2018 | Buick | LaCrosse | Frontview Camera Module | √ | √ | √ | √ | | 0196 |
| 2018 | Buick | LaCrosse | Pedestrian Alert Sound Control Module | √ | √ | √ | √ | √ | |
| 2018 | Buick | LaCrosse | Transmission Range Control Module | √ | √ | √ | √ | | 0014 0078 0013 |
| 2018 | Buick | Regal | Engine Control Module | √ | √ | √ | √ | √ | 0263 0156 0209 0076 0132 0067 0147 0115 0086 0154 0212 0214 0217 0006 0144 0258 0225 0128 0755 0008 |
| 2018 | Buick | Regal | Telematics Communication Interface Control Module | √ | √ | √ | √ | √ | 0259 0048 0011 0010 |
| 2018 | Buick | Regal | Human Machine Interface Control Module | √ | √ | √ | √ | √ | 0150 |
| 2018 | Buick | Regal | HVAC Controls | √ | √ | √ | √ | √ | |
| 2018 | Buick | Regal | Radio Controls | √ | √ | √ | √ | | 0241 |
| 2018 | Buick | Regal | HVAC Control Module | √ | √ | √ | √ | √ | 0007 0129 |
| 2018 | Buick | Regal | Seat Memory Control Module - Driver | √ | √ | √ | √ | √ | 0310 |
| 2018 | Buick | Regal | Chassis Control Module | √ | √ | √ | √ | √ | 0014 0078 |
| 2018 | Buick | Regal | Transmission Control Module | √ | √ | √ | √ | √ | 0020 0084 0017 |
| 2018 | Buick | Regal | Active Safety Control Module | √ | √ | √ | √ | | |
| 2018 | Buick | Regal | Frontview Camera Module | √ | √ | √ | √ | | 0196 |
| 2018 | Buick | Regal | Long Range Radar Sensor Module | √ | √ | √ | √ | | 0260 |
| 2018 | Buick | Regal | Instrument Cluster | √ | √ | √ | √ | √ | 0247 |
| 2018 | Buick | Regal | Left Side Object Detection Control Module | √ | √ | √ | | √ | |
| 2018 | Buick | Regal | Serial Data Gateway Module | √ | √ | √ | | | |
| 2018 | Buick | Regal | Parking Assist Control Module | √ | √ | √ | √ | √ | 0247 0271 |

| | | | | | | | | | |
|------|-------|---------|--|---|---|---|---|---|---|
| 2018 | Buick | Regal | Body Control Module | √ | √ | √ | √ | √ | 0199 0239 0161 0162 0163 0164 0165 0166 0167 0168 0242 0263 0203 0201 0208 0206 0083 0267 0160 0233 0150 |
| 2018 | Buick | Regal | Amplifier | √ | √ | √ | √ | | |
| 2018 | Buick | Regal | Pedestrian Alert Sound Control Module | √ | √ | √ | √ | √ | |
| 2018 | Buick | Regal | Radio | √ | √ | √ | √ | √ | 0226 0150 0269 0267 |
| 2018 | Buick | Regal | Rear Differential Clutch Control Module | √ | √ | √ | √ | √ | 0003 |
| 2018 | Buick | Regal | Keyless Entry Control Module | √ | √ | √ | √ | √ | 0759 |
| 2018 | Buick | Regal | Inflatable Restraint Sensing and Diagnostic Module | √ | √ | √ | √ | √ | 0172 0134 0111 0758 |
| 2018 | Buick | Regal | Passenger Presence Module | √ | √ | √ | √ | √ | 0057 |
| 2018 | Buick | Regal | Headlamp Control Module | √ | √ | √ | √ | √ | 0195 |
| 2018 | Buick | Regal | Electronic Brake Control Module | √ | √ | √ | √ | √ | 0090 0111 0229 0225 |
| 2018 | Buick | Regal | Power Steering Control Module | √ | √ | √ | √ | | 0081 0080 0089 |
| 2018 | Buick | Regal | Suspension Control Module | √ | √ | √ | √ | √ | |
| 2018 | Buick | Regal | Steering Column Lock Control Module | √ | √ | √ | √ | | |
| 2018 | Buick | Regal | Liftgate Control Module | √ | √ | √ | √ | √ | 0146 0169 |
| 2018 | Buick | Regal | Seat Memory Control Module - Passenger | √ | √ | √ | √ | √ | |
| 2018 | Buick | Verano | Telematics Communication Interface Control Module | √ | √ | √ | √ | √ | 0259 0048 0011 0010 |
| 2018 | Buick | Verano | Active Safety Control Module | √ | √ | √ | √ | √ | |
| 2018 | Buick | Verano | Frontview Camera Module | √ | √ | √ | √ | | 0205 0196 |
| 2018 | Buick | Verano | Long Range Radar Sensor Module | √ | √ | √ | √ | | 0260 |
| 2018 | Buick | Verano | Inflatable Restraint Sensing and Diagnostic Module | √ | √ | √ | √ | √ | 0172 0134 0111 0758 |
| 2018 | Buick | Verano | Body Control Module | √ | √ | √ | √ | √ | 0199 0239 0161 0162 0163 0164 0165 0166 0167 0168 0242 0263 0203 0201 0208 0206 0083 0267 0160 0233 0150 |
| 2017 | Buick | Cascada | Telematics Communication Interface Control Module | √ | √ | √ | √ | √ | 0259 0048 0011 0010 |
| 2017 | Buick | Cascada | Transmission Control Module | √ | √ | √ | √ | √ | 0017 0036 |
| 2017 | Buick | Cascada | Frontview Camera Module | √ | √ | √ | √ | √ | 0247 0205 0196 075A |
| 2017 | Buick | Cascada | Digital Radio Receiver Control Module | √ | √ | √ | √ | √ | 0247 |
| 2017 | Buick | Cascada | Radio | √ | √ | √ | √ | √ | |
| 2017 | Buick | Cascada | Multimedia Player Interface Module | √ | √ | √ | √ | | 0247 |
| 2017 | Buick | Cascada | Instrument Cluster | √ | √ | √ | √ | √ | 0247 |
| 2017 | Buick | Cascada | Folding Top Control Module | √ | √ | √ | √ | √ | 0247 0004 0005 |
| 2017 | Buick | Cascada | Parking Assist Control Module | √ | √ | √ | √ | √ | 0247 0271 |
| 2017 | Buick | Cascada | Body Control Module | √ | √ | √ | √ | √ | 0242 0263 0203 0201 0208 0206 0083 0160 |
| 2017 | Buick | Cascada | Inflatable Restraint Sensing and Diagnostic Module | √ | √ | √ | √ | √ | 0172 0134 0111 0758 |
| 2017 | Buick | Cascada | Passenger Presence Module | √ | √ | √ | √ | √ | 0057 |
| 2017 | Buick | Cascada | Chassis Control Module | √ | √ | √ | √ | √ | 0217 |

| | | | | | | | | | |
|------|-------|---------|--|---|---|---|---|---|--|
| 2017 | Buick | Cascada | Front Seat Heating Control Module | √ | √ | √ | √ | √ | |
| 2017 | Buick | Cascada | Headlamp Control Module | √ | √ | √ | √ | √ | 0195 |
| 2017 | Buick | Cascada | HVAC Control Module | √ | √ | √ | √ | √ | 0007 0129 |
| 2017 | Buick | Cascada | Engine Control Module | √ | √ | √ | √ | √ | 0263 0156 0209 0020 0132 0067 0115 0086 0085 0154 0213 0221 0212 0214 0217 0006 |
| 2017 | Buick | Cascada | Electronic Brake Control Module | √ | √ | √ | √ | √ | 0225 0090 0111 0229 |
| 2017 | Buick | Cascada | Parking Brake Control Module | √ | √ | √ | √ | √ | 0229 |
| 2017 | Buick | Cascada | Power Steering Control Module | √ | √ | √ | √ | | 0089 0081 0080 |
| 2017 | Buick | Cascada | Steering Wheel Angle Sensor Module | √ | √ | √ | | | 0093 0090 |
| 2017 | Buick | Cascada | Multi-Axis Acceleration Sensor Module | √ | √ | √ | | | 0112 0111 |
| 2017 | Buick | Enclave | Telematics Communication Interface Control Module | √ | √ | √ | √ | √ | 0259 0048 0011 0010 |
| 2017 | Buick | Enclave | Headlamp Control Module | √ | √ | √ | | | |
| 2017 | Buick | Enclave | Liftgate Control Module | √ | √ | √ | √ | | 0146 |
| 2017 | Buick | Enclave | Transmission Control Module | √ | √ | √ | √ | √ | 0016 |
| 2017 | Buick | Enclave | Parking Assist Control Module | √ | √ | √ | √ | √ | 0247 |
| 2017 | Buick | Enclave | Theft Deterrent Module | √ | √ | √ | √ | | |
| 2017 | Buick | Enclave | Instrument Cluster | √ | √ | √ | √ | √ | |
| 2017 | Buick | Enclave | Inflatable Restraint Sensing and Diagnostic Module | √ | √ | √ | √ | √ | 0172 0261 |
| 2017 | Buick | Enclave | Passenger Presence Module | √ | √ | √ | √ | | 0057 |
| 2017 | Buick | Enclave | Remote Control Door Lock Receiver | √ | √ | √ | √ | √ | 0204 0239 0161 0162 0163 0164 0159 0160 |
| 2017 | Buick | Enclave | Electronic Brake Control Module | √ | √ | √ | √ | √ | 0090 0225 0111 |
| 2017 | Buick | Enclave | Front Seat Heating Control Module | √ | √ | √ | √ | √ | |
| 2017 | Buick | Enclave | Frontview Camera Module | √ | √ | √ | √ | √ | 0205 0196 |
| 2017 | Buick | Enclave | Left Side Object Detection Control Module | √ | √ | √ | | √ | |
| 2017 | Buick | Enclave | Right Side Object Detection Control Module | √ | √ | √ | | √ | |
| 2017 | Buick | Enclave | Seat Memory Control Module | √ | √ | √ | √ | √ | |
| 2017 | Buick | Enclave | HVAC Control Module | √ | √ | √ | √ | √ | 0116 0007 0129 |
| 2017 | Buick | Enclave | Body Control Module | √ | √ | √ | √ | √ | 0263 0261 |
| 2017 | Buick | Enclave | Driver Door Switch Panel Control Module | √ | √ | √ | √ | √ | |
| 2017 | Buick | Enclave | Passenger Door Switch Panel Control Module | √ | √ | √ | √ | √ | |
| 2017 | Buick | Enclave | Personal Audio Link Control Module | √ | √ | √ | | | 0231 |
| 2017 | Buick | Enclave | Rear Audio Control Module | √ | √ | √ | √ | | |
| 2017 | Buick | Enclave | Radio | √ | √ | √ | √ | √ | |
| 2017 | Buick | Enclave | Digital Radio Receiver Control Module | √ | √ | √ | √ | √ | |
| 2017 | Buick | Enclave | Engine Control Module | √ | √ | √ | √ | √ | 0263 0209 0132 0067 0086 0217 0258 0212 |
| 2017 | Buick | Enclave | Rear Differential Clutch Control Module | √ | √ | √ | √ | √ | 0155 |
| 2017 | Buick | Encore | Telematics Communication Interface Control Module | √ | √ | √ | √ | √ | 0259 0048 0011 0010 |
| 2017 | Buick | Encore | Transmission Control Module | √ | √ | √ | √ | √ | 0017 0036 |

| | | | | | | | | | |
|------|-------|----------|--|---|---|---|---|---|---|
| 2017 | Buick | Encore | Instrument Cluster | √ | √ | √ | √ | √ | 0247 |
| 2017 | Buick | Encore | Amplifier | √ | √ | √ | √ | √ | |
| 2017 | Buick | Encore | Human Machine Interface Control Module | √ | √ | √ | √ | √ | 0150 |
| 2017 | Buick | Encore | Radio | √ | √ | √ | √ | √ | 0226 0150 |
| 2017 | Buick | Encore | Parking Assist Control Module | √ | √ | √ | √ | √ | 0247 0271 |
| 2017 | Buick | Encore | Trailer Interface Control Module | √ | √ | √ | √ | √ | 0247 |
| 2017 | Buick | Encore | Inflatable Restraint Sensing and Diagnostic Module | √ | √ | √ | √ | √ | 0172 0134 0111 |
| 2017 | Buick | Encore | Keyless Entry Control Module | √ | √ | √ | √ | √ | |
| 2017 | Buick | Encore | Passenger Presence Module | √ | √ | √ | √ | √ | 0057 |
| 2017 | Buick | Encore | Body Control Module | √ | √ | √ | √ | √ | 0199 0239 0161 0162 0163 0164 0165 0166 0167 0168 0242 0263 0203 0201 0208 0206 |
| 2017 | Buick | Encore | Left Side Object Detection Control Module | √ | √ | √ | √ | √ | |
| 2017 | Buick | Encore | Chassis Control Module | √ | √ | √ | √ | √ | 0217 |
| 2017 | Buick | Encore | Front Seat Heating Control Module | √ | √ | √ | √ | √ | |
| 2017 | Buick | Encore | Seat Memory Control Module | √ | √ | √ | √ | √ | 0310 |
| 2017 | Buick | Encore | Headlamp Control Module | √ | √ | √ | √ | √ | 0195 |
| 2017 | Buick | Encore | Engine Control Module | √ | √ | √ | √ | √ | 0263 0156 0209 0020 0132 0067 0115 0086 0085 0154 0213 0221 0212 0214 0217 0006 0144 0258 0139 0066 |
| 2017 | Buick | Encore | HVAC Control Module | √ | √ | √ | √ | √ | 0007 0129 |
| 2017 | Buick | Encore | Frontview Camera Module | √ | √ | √ | √ | √ | 0205 0196 075A |
| 2017 | Buick | Encore | Serial Data Gateway Module | √ | √ | √ | √ | √ | |
| 2017 | Buick | Encore | Electronic Brake Control Module | √ | √ | √ | √ | √ | 0090 |
| 2017 | Buick | Encore | Power Steering Control Module | √ | √ | √ | √ | √ | 0207 |
| 2017 | Buick | Encore | Steering Wheel Angle Sensor Module | √ | √ | √ | √ | √ | 0093 0090 |
| 2017 | Buick | Encore | Steering Column Lock Control Module | √ | √ | √ | √ | √ | |
| 2017 | Buick | Encore | Rear Differential Clutch Control Module | √ | √ | √ | √ | √ | 0003 075B |
| 2017 | Buick | Envision | Engine Control Module | √ | √ | √ | √ | √ | 0263 0156 0209 0076 0132 0067 0147 0115 0086 0154 0212 0214 0217 0006 0144 0258 0236 0139 0020 0085 |
| 2017 | Buick | Envision | Steering Column Lock Control Module | √ | √ | √ | √ | √ | |
| 2017 | Buick | Envision | Transmission Control Module | √ | √ | √ | √ | √ | 0017 0036 |
| 2017 | Buick | Envision | Headlamp Control Module | √ | √ | √ | √ | √ | 0195 |
| 2017 | Buick | Envision | Liftgate Control Module | √ | √ | √ | √ | √ | 0146 0169 |
| 2017 | Buick | Envision | Telematics Communication Interface Control Module | √ | √ | √ | √ | √ | 0259 0048 0011 0010 |
| 2017 | Buick | Envision | Amplifier | √ | √ | √ | √ | √ | |

| | | | | | | | | | |
|------|-------|----------|--|---|---|---|---|---|---|
| 2017 | Buick | Envision | Human Machine Interface Control Module | √ | √ | √ | √ | √ | 0150 |
| 2017 | Buick | Envision | Radio | √ | √ | √ | √ | √ | 0226 0150 |
| 2017 | Buick | Envision | Radio Controls | √ | √ | √ | √ | √ | 0241 |
| 2017 | Buick | Envision | HVAC Controls | √ | √ | √ | √ | √ | |
| 2017 | Buick | Envision | Instrument Cluster | √ | √ | √ | √ | √ | 0247 |
| 2017 | Buick | Envision | Parking Assist Control Module | √ | √ | √ | √ | √ | 0247 0271 |
| 2017 | Buick | Envision | Inflatable Restraint Sensing and Diagnostic Module | √ | √ | √ | √ | √ | 0172 0134 0111 0758 |
| 2017 | Buick | Envision | Keyless Entry Control Module | √ | √ | √ | √ | √ | |
| 2017 | Buick | Envision | Passenger Presence Module | √ | √ | √ | √ | √ | 0057 |
| 2017 | Buick | Envision | Body Control Module | √ | √ | √ | √ | √ | 0199 0239 0161 0162 0163 0164 0165 0166 0167 0168 0242 0263 0203 0201 0208 0206 0083 0267 0160 0233 0150 |
| 2017 | Buick | Envision | Left Side Object Detection Control Module | √ | √ | √ | | √ | |
| 2017 | Buick | Envision | Right Side Object Detection Control Module | √ | √ | √ | | √ | |
| 2017 | Buick | Envision | Rear Differential Clutch Control Module | √ | √ | √ | √ | √ | 0003 |
| 2017 | Buick | Envision | Seat Memory Control Module - Driver | √ | √ | √ | √ | √ | 0310 |
| 2017 | Buick | Envision | HVAC Control Module | √ | √ | √ | √ | √ | 0007 0129 |
| 2017 | Buick | Envision | Serial Data Gateway Module | √ | √ | √ | | | |
| 2017 | Buick | Envision | Electronic Brake Control Module | √ | √ | √ | √ | √ | 0225 0090 0111 0229 |
| 2017 | Buick | Envision | Multi-Axis Acceleration Sensor Module | √ | √ | √ | | | 0111 |
| 2017 | Buick | Envision | Power Steering Control Module | √ | √ | √ | √ | | 0081 0080 0089 |
| 2017 | Buick | Envision | Steering Wheel Angle Sensor Module | √ | √ | √ | | | 0093 0090 |
| 2017 | Buick | Envision | Active Safety Control Module | √ | √ | √ | √ | √ | |
| 2017 | Buick | Envision | Frontview Camera Module | √ | √ | √ | √ | √ | 0205 0196 075A |
| 2017 | Buick | Envision | Long Range Radar Sensor Module | √ | √ | √ | √ | | 0260 |
| 2017 | Buick | Envision | Video Processing Control Module | √ | √ | √ | √ | √ | |
| 2017 | Buick | Envision | Suspension Control Module | √ | √ | √ | √ | √ | |
| 2017 | Buick | Envision | Accessory DC/AC Power Inverter Module | √ | √ | √ | √ | √ | |
| 2017 | Buick | LaCrosse | Transmission Control Module | √ | √ | √ | √ | √ | 0017 0036 0020 0084 |
| 2017 | Buick | LaCrosse | Amplifier | √ | √ | √ | √ | | |
| 2017 | Buick | LaCrosse | Human Machine Interface Control Module | √ | √ | √ | √ | √ | 0150 |
| 2017 | Buick | LaCrosse | HVAC Controls | √ | √ | √ | √ | √ | |
| 2017 | Buick | LaCrosse | Radio Controls | √ | √ | √ | √ | √ | 0241 |
| 2017 | Buick | LaCrosse | Media Disc Player | √ | √ | √ | √ | √ | |
| 2017 | Buick | LaCrosse | Radio | √ | √ | √ | √ | √ | 0226 0150 |
| 2017 | Buick | LaCrosse | Infotainment Control Touchpad | √ | √ | √ | √ | √ | |
| 2017 | Buick | LaCrosse | Instrument Cluster | √ | √ | √ | √ | √ | 0247 |
| 2017 | Buick | LaCrosse | Active Safety Control Module | √ | √ | √ | √ | √ | |
| 2017 | Buick | LaCrosse | Frontview Camera Module | √ | √ | √ | √ | | 0196 |
| 2017 | Buick | LaCrosse | Left Side Object Detection Control Module | √ | √ | √ | | √ | |

| | | | | | | | | | |
|------|-------|----------|--|---|---|---|---|---|---|
| 2017 | Buick | LaCrosse | Right Side Object Detection Control Module | √ | √ | √ | √ | √ | |
| 2017 | Buick | LaCrosse | Seat Memory Control Module - Driver | √ | √ | √ | √ | √ | 0310 |
| 2017 | Buick | LaCrosse | Headlamp Control Module | √ | √ | √ | √ | √ | |
| 2017 | Buick | LaCrosse | Telematics Communication Interface Control Module | √ | √ | √ | √ | √ | 0259 0048 0011 0010 |
| 2017 | Buick | LaCrosse | Parking Assist Control Module | √ | √ | √ | √ | √ | 0247 0271 |
| 2017 | Buick | LaCrosse | Inflatable Restraint Sensing and Diagnostic Module | √ | √ | √ | √ | √ | 0172 0134 0111 0758 |
| 2017 | Buick | LaCrosse | Keyless Entry Control Module | √ | √ | √ | √ | √ | |
| 2017 | Buick | LaCrosse | Passenger Presence Module | √ | √ | √ | √ | √ | 0057 |
| 2017 | Buick | LaCrosse | Body Control Module | √ | √ | √ | √ | √ | 0199 0239 0161 0162 0163 0164 0165 0166 0167 0168 0242 0263 0203 0201 0208 0206 0083 0267 0160 0233 |
| 2017 | Buick | LaCrosse | Chassis Control Module | √ | √ | √ | √ | √ | 0014 0078 |
| 2017 | Buick | LaCrosse | Rear Differential Clutch Control Module | √ | √ | √ | √ | √ | 0003 |
| 2017 | Buick | LaCrosse | Engine Control Module | √ | √ | √ | √ | √ | 0263 0156 0209 0020 0132 0067 0115 0086 0154 0213 0214 0217 0258 0139 0006 0756 |
| 2017 | Buick | LaCrosse | HVAC Control Module | √ | √ | √ | √ | √ | 0007 0129 |
| 2017 | Buick | LaCrosse | Serial Data Gateway Module | √ | √ | √ | √ | √ | |
| 2017 | Buick | LaCrosse | Electronic Brake Control Module | √ | √ | √ | √ | √ | 0090 0111 0229 0225 |
| 2017 | Buick | LaCrosse | Power Steering Control Module | √ | √ | √ | √ | √ | 0081 0080 0089 |
| 2017 | Buick | LaCrosse | Suspension Control Module | √ | √ | √ | √ | √ | |
| 2017 | Buick | LaCrosse | Long Range Radar Sensor Module | √ | √ | √ | √ | √ | 0260 |
| 2017 | Buick | LaCrosse | Transmission Range Control Module | √ | √ | √ | √ | √ | 0014 0078 0013 |
| 2017 | Buick | Regal | Transmission Control Module | √ | √ | √ | √ | √ | 0016 0017 0036 |
| 2017 | Buick | Regal | Parking Assist Control Module | √ | √ | √ | √ | √ | 0247 |
| 2017 | Buick | Regal | Instrument Cluster | √ | √ | √ | √ | √ | 0247 |
| 2017 | Buick | Regal | Telematics Communication Interface Control Module | √ | √ | √ | √ | √ | 0259 0048 0011 0010 |
| 2017 | Buick | Regal | Inflatable Restraint Sensing and Diagnostic Module | √ | √ | √ | √ | √ | 0172 0134 0111 |
| 2017 | Buick | Regal | Keyless Entry Control Module | √ | √ | √ | √ | √ | |
| 2017 | Buick | Regal | Passenger Presence Module | √ | √ | √ | √ | √ | 0057 |
| 2017 | Buick | Regal | Front Seat Heating Control Module | √ | √ | √ | √ | √ | |
| 2017 | Buick | Regal | Frontview Camera Module | √ | √ | √ | √ | √ | 0205 0196 075A |
| 2017 | Buick | Regal | Left Side Object Detection Control Module | √ | √ | √ | √ | √ | |
| 2017 | Buick | Regal | Seat Memory Control Module | √ | √ | √ | √ | √ | 0310 |
| 2017 | Buick | Regal | Amplifier | √ | √ | √ | √ | √ | |
| 2017 | Buick | Regal | Human Machine Interface Control Module | √ | √ | √ | √ | √ | 0150 |
| 2017 | Buick | Regal | HVAC Controls | √ | √ | √ | √ | √ | |
| 2017 | Buick | Regal | Radio | √ | √ | √ | √ | √ | 0226 0150 |
| 2017 | Buick | Regal | Radio Controls | √ | √ | √ | √ | √ | 0241 |

| | | | | | | | | | |
|------|-------|--------|--|---|---|---|---|---|---|
| 2017 | Buick | Regal | Media Disc Player | √ | √ | √ | √ | √ | |
| 2017 | Buick | Regal | Body Control Module | √ | √ | √ | √ | √ | 0199 0239 0161 0162 0163 0164 0165 0166 0167 0168 0242 0263 0203 0201 0208 0206 0083 0267 0160 0233 0158 |
| 2017 | Buick | Regal | Engine Control Module | √ | √ | √ | √ | √ | 0263 0156 0209 0132 0067 0066 0086 0217 0258 0213 0212 |
| 2017 | Buick | Regal | Electronic Brake Control Module | √ | √ | √ | √ | √ | 0225 0090 0111 0277 |
| 2017 | Buick | Regal | Parking Brake Control Module | √ | √ | √ | √ | √ | 0229 |
| 2017 | Buick | Regal | Suspension Control Module | √ | √ | √ | √ | √ | |
| 2017 | Buick | Regal | Steering Wheel Angle Sensor Module | √ | √ | √ | | | 0093 0090 |
| 2017 | Buick | Regal | Power Steering Control Module | √ | √ | √ | √ | √ | 0081 0080 0089 |
| 2017 | Buick | Regal | Rear Differential Clutch Control Module | √ | √ | √ | √ | √ | |
| 2017 | Buick | Regal | HVAC Control Module | √ | √ | √ | √ | √ | 0007 0129 |
| 2017 | Buick | Regal | Distance Sensing Cruise Control Module | √ | √ | √ | √ | | 0047 |
| 2017 | Buick | Verano | Telematics Communication Interface Control Module | √ | √ | √ | √ | √ | 0259 0048 0011 0010 |
| 2017 | Buick | Verano | Radio | √ | √ | √ | √ | √ | |
| 2017 | Buick | Verano | Multimedia Player Interface Module | √ | √ | √ | √ | | 0247 |
| 2017 | Buick | Verano | Inflatable Restraint Sensing and Diagnostic Module | √ | √ | √ | √ | √ | 0172 0134 |
| 2017 | Buick | Verano | Keyless Entry Control Module | √ | √ | √ | √ | √ | |
| 2017 | Buick | Verano | Passenger Presence Module | √ | √ | √ | √ | | 0057 |
| 2017 | Buick | Verano | Instrument Cluster | √ | √ | √ | √ | √ | 0247 |
| 2017 | Buick | Verano | Parking Assist Control Module | √ | √ | √ | √ | √ | 0247 0271 |
| 2017 | Buick | Verano | Body Control Module | √ | √ | √ | √ | √ | 0242 0263 0203 0201 0208 0206 0083 0160 |
| 2017 | Buick | Verano | Left Side Object Detection Control Module | √ | √ | √ | | √ | |
| 2017 | Buick | Verano | Right Side Object Detection Control Module | √ | √ | √ | | √ | |
| 2017 | Buick | Verano | Chassis Control Module | √ | √ | √ | √ | √ | 0217 |
| 2017 | Buick | Verano | Electronic Brake Control Module | √ | √ | √ | √ | √ | 0225 0090 0111 |
| 2017 | Buick | Verano | Multi-Axis Acceleration Sensor Module | √ | √ | √ | | | 0112 0111 |
| 2017 | Buick | Verano | Parking Brake Control Module | √ | √ | √ | √ | √ | 0229 |
| 2017 | Buick | Verano | Power Steering Control Module | √ | √ | √ | √ | √ | 0089 0081 0080 |
| 2017 | Buick | Verano | Steering Wheel Angle Sensor Module | √ | √ | √ | | | 0093 0090 |
| 2017 | Buick | Verano | Front Seat Heating Control Module | √ | √ | √ | √ | √ | |
| 2017 | Buick | Verano | Engine Control Module | √ | √ | √ | √ | √ | 0263 0209 0132 0067 0086 0217 0258 0213 |
| 2017 | Buick | Verano | Transmission Control Module | √ | √ | √ | √ | √ | 0017 0036 |
| 2017 | Buick | Verano | HVAC Control Module | √ | √ | √ | √ | √ | 0007 0129 |
| 2017 | Buick | Verano | Active Safety Control Module | √ | √ | √ | √ | √ | |
| 2017 | Buick | Verano | Frontview Camera Module | √ | √ | √ | √ | √ | 0205 0196 075A |

| | | | | | | | | | |
|------|-------|---------|--|---|---|---|---|---|--|
| 2017 | Buick | Verano | Long Range Radar Sensor Module | √ | √ | √ | √ | | 0260 |
| 2016 | Buick | Cascada | Telematics Communication Interface Control Module | √ | √ | √ | √ | √ | 0259 0048 0011 0010 |
| 2016 | Buick | Cascada | Transmission Control Module | √ | √ | √ | √ | √ | 0017 0036 |
| 2016 | Buick | Cascada | Body Control Module | √ | √ | √ | √ | √ | 0242 0263 0203 0201 0208 0206 0083 0160 |
| 2016 | Buick | Cascada | Inflatable Restraint Sensing and Diagnostic Module | √ | √ | √ | √ | √ | 0172 0134 0111 0758 |
| 2016 | Buick | Cascada | Passenger Presence Module | √ | √ | √ | √ | √ | 0057 |
| 2016 | Buick | Cascada | HVAC Control Module | √ | √ | √ | √ | √ | 0007 0129 |
| 2016 | Buick | Cascada | Instrument Cluster | √ | √ | √ | √ | √ | 0247 |
| 2016 | Buick | Cascada | Parking Assist Control Module | √ | √ | √ | √ | √ | 0247 |
| 2016 | Buick | Cascada | Folding Top Control Module | √ | √ | √ | √ | √ | 0247 0004 0005 |
| 2016 | Buick | Cascada | Engine Control Module | √ | √ | √ | √ | √ | 0263 0156 0209 0020 0132 0067 0115 0086 0085 0154 0213 0221 0212 0214 0217 0006 |
| 2016 | Buick | Cascada | Multimedia Player Interface Module | √ | √ | √ | √ | | 0247 |
| 2016 | Buick | Cascada | Radio | √ | √ | √ | √ | √ | |
| 2016 | Buick | Cascada | Electronic Brake Control Module | √ | √ | √ | √ | √ | 0225 0090 0111 0229 |
| 2016 | Buick | Cascada | Multi-Axis Acceleration Sensor Module | √ | √ | √ | | | 0112 0111 |
| 2016 | Buick | Cascada | Power Steering Control Module | √ | √ | √ | √ | | 0089 0081 0080 |
| 2016 | Buick | Cascada | Steering Wheel Angle Sensor Module | √ | √ | √ | | | 0093 0090 |
| 2016 | Buick | Cascada | Front Seat Heating Control Module | √ | √ | √ | √ | √ | |
| 2016 | Buick | Cascada | Frontview Camera Module | √ | √ | √ | √ | √ | 0247 0205 0196 075A |
| 2016 | Buick | Cascada | Parking Brake Control Module | √ | √ | √ | √ | √ | 0229 |
| 2016 | Buick | Cascada | Headlamp Control Module | √ | √ | √ | √ | √ | 0195 |
| 2016 | Buick | Cascada | Chassis Control Module | √ | √ | √ | √ | √ | 0217 |
| 2016 | Buick | Enclave | Transmission Control Module | √ | √ | √ | √ | √ | 0016 |
| 2016 | Buick | Enclave | Telematics Communication Interface Control Module | √ | √ | √ | √ | √ | 0259 0048 0011 0010 |
| 2016 | Buick | Enclave | Head-Up Display Module | √ | √ | √ | √ | √ | |
| 2016 | Buick | Enclave | Instrument Cluster | √ | √ | √ | √ | √ | |
| 2016 | Buick | Enclave | Theft Deterrent Module | √ | √ | √ | √ | | |
| 2016 | Buick | Enclave | Headlamp Control Module | √ | √ | √ | | | |
| 2016 | Buick | Enclave | Liftgate Control Module | √ | √ | √ | √ | | 0146 |
| 2016 | Buick | Enclave | Digital Radio Receiver Control Module | √ | √ | √ | √ | √ | |
| 2016 | Buick | Enclave | Front Seat Heating Control Module | √ | √ | √ | √ | | |
| 2016 | Buick | Enclave | Frontview Camera Module | √ | √ | √ | √ | √ | 0205 0196 |
| 2016 | Buick | Enclave | Left Side Object Detection Control Module | √ | √ | √ | | √ | |
| 2016 | Buick | Enclave | Parking Assist Control Module | √ | √ | √ | √ | √ | 0247 |
| 2016 | Buick | Enclave | Right Side Object Detection Control Module | √ | √ | √ | | √ | |
| 2016 | Buick | Enclave | Seat Memory Control Module | √ | √ | √ | √ | √ | |
| 2016 | Buick | Enclave | HVAC Control Module | √ | √ | √ | √ | √ | 0116 0007 0129 |
| 2016 | Buick | Enclave | Body Control Module | √ | √ | √ | √ | √ | 0263 0261 |

| | | | | | | | | | |
|------|-------|----------|--|---|---|---|---|---|---|
| 2016 | Buick | Enclave | Remote Control Door Lock Receiver | √ | √ | √ | √ | √ | 0204 0239 0161 0162 0163 0164 0159 0160 |
| 2016 | Buick | Enclave | Passenger Presence Module | √ | √ | √ | √ | √ | 0057 |
| 2016 | Buick | Enclave | Inflatable Restraint Sensing and Diagnostic Module | √ | √ | √ | √ | √ | 0172 0261 |
| 2016 | Buick | Enclave | Rear Differential Clutch Control Module | √ | √ | √ | √ | √ | 0155 |
| 2016 | Buick | Enclave | Engine Control Module | √ | √ | √ | √ | √ | 0263 0209 0132 0067 0086 0217 0258 0212 |
| 2016 | Buick | Enclave | Driver Door Switch Panel Control Module | √ | √ | √ | √ | √ | |
| 2016 | Buick | Enclave | Passenger Door Switch Panel Control Module | √ | √ | √ | √ | √ | |
| 2016 | Buick | Enclave | Personal Audio Link Control Module | √ | √ | √ | √ | √ | 0231 |
| 2016 | Buick | Enclave | Radio | √ | √ | √ | √ | √ | |
| 2016 | Buick | Enclave | Rear Audio Control Module | √ | √ | √ | √ | √ | |
| 2016 | Buick | Enclave | Electronic Brake Control Module | √ | √ | √ | √ | √ | 0090 0225 0111 |
| 2016 | Buick | Encore | Transmission Control Module | √ | √ | √ | √ | √ | 0017 0036 |
| 2016 | Buick | Encore | Telematics Communication Interface Control Module | √ | √ | √ | √ | √ | 0259 0048 0011 0010 |
| 2016 | Buick | Encore | Instrument Cluster | √ | √ | √ | √ | √ | 0247 |
| 2016 | Buick | Encore | Engine Control Module | √ | √ | √ | √ | √ | 0263 0156 0209 0020 0132 0067 0115 0086 0085 0154 0213 0221 0212 0214 0217 0006 0144 0258 0139 0066 |
| 2016 | Buick | Encore | Body Control Module | √ | √ | √ | √ | √ | 0199 0239 0161 0162 0163 0164 0165 0166 0167 0168 0242 0263 0203 0201 0208 0206 |
| 2016 | Buick | Encore | Parking Assist Control Module | √ | √ | √ | √ | √ | 0247 0271 |
| 2016 | Buick | Encore | Front Seat Heating Control Module | √ | √ | √ | √ | √ | |
| 2016 | Buick | Encore | Frontview Camera Module | √ | √ | √ | √ | √ | 0205 0196 075A |
| 2016 | Buick | Encore | Left Side Object Detection Control Module | √ | √ | √ | √ | √ | |
| 2016 | Buick | Encore | Seat Memory Control Module | √ | √ | √ | √ | √ | 0310 |
| 2016 | Buick | Encore | Passenger Presence Module | √ | √ | √ | √ | √ | 0057 |
| 2016 | Buick | Encore | Inflatable Restraint Sensing and Diagnostic Module | √ | √ | √ | √ | √ | 0172 0134 0111 |
| 2016 | Buick | Encore | Radio | √ | √ | √ | √ | √ | |
| 2016 | Buick | Encore | Electronic Brake Control Module | √ | √ | √ | √ | √ | 0090 |
| 2016 | Buick | Encore | Power Steering Control Module | √ | √ | √ | √ | √ | 0207 |
| 2016 | Buick | Encore | Steering Wheel Angle Sensor Module | √ | √ | √ | √ | √ | 0093 0090 |
| 2016 | Buick | Encore | Chassis Control Module | √ | √ | √ | √ | √ | 0217 |
| 2016 | Buick | Encore | HVAC Control Module | √ | √ | √ | √ | √ | 0007 0129 |
| 2016 | Buick | Encore | Steering Column Lock Control Module | √ | √ | √ | √ | √ | |
| 2016 | Buick | Encore | Rear Differential Clutch Control Module | √ | √ | √ | √ | √ | 0003 075B |
| 2016 | Buick | Envision | Transmission Control Module | √ | √ | √ | √ | √ | 0017 0036 |

| | | | | | | | | | |
|------|-------|----------|--|---|---|---|---|---|--|
| 2016 | Buick | Envision | Engine Control Module | √ | √ | √ | √ | √ | 0263 0156 0209 0076 0132 0067 0147 0115 0086 0154 0212 0214 0217 0006 0144 0258 |
| 2016 | Buick | Envision | Telematics Communication Interface Control Module | √ | √ | √ | √ | √ | 0259 0048 0011 0010 |
| 2016 | Buick | Envision | Inflatable Restraint Sensing and Diagnostic Module | √ | √ | √ | √ | √ | 0172 0134 0111 0758 |
| 2016 | Buick | Envision | Keyless Entry Control Module | √ | √ | √ | √ | √ | |
| 2016 | Buick | Envision | Frontview Camera Module | √ | √ | √ | √ | √ | 0205 0196 075A |
| 2016 | Buick | Envision | Left Side Object Detection Control Module | √ | √ | √ | √ | √ | |
| 2016 | Buick | Envision | Parking Assist Control Module | √ | √ | √ | √ | √ | 0247 0271 |
| 2016 | Buick | Envision | Right Side Object Detection Control Module | √ | √ | √ | √ | √ | |
| 2016 | Buick | Envision | Seat Memory Control Module - Driver | √ | √ | √ | √ | √ | 0310 |
| 2016 | Buick | Envision | Headlamp Control Module | √ | √ | √ | √ | √ | 0195 |
| 2016 | Buick | Envision | Rear Differential Clutch Control Module | √ | √ | √ | √ | √ | 0003 |
| 2016 | Buick | Envision | Steering Column Lock Control Module | √ | √ | √ | √ | √ | |
| 2016 | Buick | Envision | Electronic Brake Control Module | √ | √ | √ | √ | √ | 0225 0090 0111 0229 |
| 2016 | Buick | Envision | Power Steering Control Module | √ | √ | √ | √ | √ | 0081 0080 0089 |
| 2016 | Buick | Envision | Multi-Axis Acceleration Sensor Module | √ | √ | √ | √ | √ | 0111 |
| 2016 | Buick | Envision | Steering Wheel Angle Sensor Module | √ | √ | √ | √ | √ | 0093 0090 |
| 2016 | Buick | Envision | Passenger Presence Module | √ | √ | √ | √ | √ | 0057 |
| 2016 | Buick | Envision | HVAC Control Module | √ | √ | √ | √ | √ | 0007 0129 |
| 2016 | Buick | Envision | Long Range Radar Sensor Module | √ | √ | √ | √ | √ | 0260 |
| 2016 | Buick | Envision | Body Control Module | √ | √ | √ | √ | √ | 0199 0239 0161 0162 0163 0164 0165 0166 0167 0168 0242 0263 0203 0201 0208 0206 |
| 2016 | Buick | Envision | Liftgate Control Module | √ | √ | √ | √ | √ | 0146 0169 |
| 2016 | Buick | Envision | Radio | √ | √ | √ | √ | √ | 0226 0150 |
| 2016 | Buick | Envision | Instrument Cluster | √ | √ | √ | √ | √ | 0247 |
| 2016 | Buick | Envision | Video Processing Control Module | √ | √ | √ | √ | √ | |
| 2016 | Buick | Envision | Human Machine Interface Control Module | √ | √ | √ | √ | √ | 0150 |
| 2016 | Buick | Envision | Amplifier | √ | √ | √ | √ | √ | |
| 2016 | Buick | Envision | Radio Controls | √ | √ | √ | √ | √ | 0241 |
| 2016 | Buick | Envision | HVAC Controls | √ | √ | √ | √ | √ | |
| 2016 | Buick | Envision | Suspension Control Module | √ | √ | √ | √ | √ | |
| 2016 | Buick | Envision | Accessory DC/AC Power Inverter Module | √ | √ | √ | √ | √ | |
| 2016 | Buick | Envision | Active Safety Control Module | √ | √ | √ | √ | √ | |
| 2016 | Buick | LaCrosse | Battery Energy Control Module | √ | √ | √ | √ | √ | |
| 2016 | Buick | LaCrosse | Drive Motor Control Module | √ | √ | √ | √ | √ | |
| 2016 | Buick | LaCrosse | Hybrid Powertrain Control Module | √ | √ | √ | √ | √ | 0263 |
| 2016 | Buick | LaCrosse | Telematics Communication Interface Control Module | √ | √ | √ | √ | √ | 0259 0048 0011 0010 |
| 2016 | Buick | LaCrosse | Head-Up Display Module | √ | √ | √ | √ | √ | |

| | | | | | | | | | |
|------|-------|----------|--|---|---|---|---|---|---|
| 2016 | Buick | LaCrosse | Instrument Cluster | √ | √ | √ | √ | √ | 0247 |
| 2016 | Buick | LaCrosse | Headlamp Control Module | √ | √ | √ | √ | √ | |
| 2016 | Buick | LaCrosse | Body Control Module | √ | √ | √ | √ | √ | 0199 0239 0161 0162 0163 0164 0165 0166 0167 0168 0242 0263 0203 0201 0208 0206 0202 0156 0200 0156 |
| 2016 | Buick | LaCrosse | Transmission Control Module | √ | √ | √ | √ | √ | 0017 0036 0016 |
| 2016 | Buick | LaCrosse | Frontview Camera Module | √ | √ | √ | √ | √ | 0205 0196 075A |
| 2016 | Buick | LaCrosse | Left Side Object Detection Control Module | √ | √ | √ | √ | √ | |
| 2016 | Buick | LaCrosse | Seat Memory Control Module - Driver | √ | √ | √ | √ | √ | 0310 |
| 2016 | Buick | LaCrosse | Parking Assist Control Module | √ | √ | √ | √ | √ | 0247 |
| 2016 | Buick | LaCrosse | Passenger Presence Module | √ | √ | √ | √ | √ | 0057 |
| 2016 | Buick | LaCrosse | Inflatable Restraint Sensing and Diagnostic Module | √ | √ | √ | √ | √ | 0172 0134 0111 |
| 2016 | Buick | LaCrosse | Keyless Entry Control Module | √ | √ | √ | √ | √ | |
| 2016 | Buick | LaCrosse | Chassis Control Module | √ | √ | √ | √ | √ | 0217 0095 0194 0245 |
| 2016 | Buick | LaCrosse | Engine Control Module | √ | √ | √ | √ | √ | 0209 0132 0067 0086 0217 0258 0263 0156 |
| 2016 | Buick | LaCrosse | Amplifier | √ | √ | √ | √ | √ | |
| 2016 | Buick | LaCrosse | Human Machine Interface Control Module | √ | √ | √ | √ | √ | 0150 |
| 2016 | Buick | LaCrosse | HVAC Controls | √ | √ | √ | √ | √ | |
| 2016 | Buick | LaCrosse | Radio Controls | √ | √ | √ | √ | √ | 0241 |
| 2016 | Buick | LaCrosse | Media Disc Player | √ | √ | √ | √ | √ | |
| 2016 | Buick | LaCrosse | Radio | √ | √ | √ | √ | √ | 0226 0150 |
| 2016 | Buick | LaCrosse | HVAC Control Module | √ | √ | √ | √ | √ | 0007 0129 |
| 2016 | Buick | LaCrosse | Distance Sensing Cruise Control Module | √ | √ | √ | √ | √ | 0047 |
| 2016 | Buick | LaCrosse | Electronic Brake Control Module | √ | √ | √ | √ | √ | 0225 0090 0111 0277 |
| 2016 | Buick | LaCrosse | Parking Brake Control Module | √ | √ | √ | √ | √ | 0229 |
| 2016 | Buick | LaCrosse | Steering Wheel Angle Sensor Module | √ | √ | √ | √ | √ | 0093 0090 |
| 2016 | Buick | LaCrosse | Suspension Control Module | √ | √ | √ | √ | √ | |
| 2016 | Buick | LaCrosse | Power Steering Control Module | √ | √ | √ | √ | √ | 0081 0080 0089 |
| 2016 | Buick | LaCrosse | Rear Audio Control Module | √ | √ | √ | √ | √ | |
| 2016 | Buick | LaCrosse | Infotainment Control Touchpad | √ | √ | √ | √ | √ | |
| 2016 | Buick | LaCrosse | Rear Differential Clutch Control Module | √ | √ | √ | √ | √ | |
| 2016 | Buick | Regal | Transmission Control Module | √ | √ | √ | √ | √ | 0016 0017 0036 |
| 2016 | Buick | Regal | Battery Energy Control Module | √ | √ | √ | √ | √ | |
| 2016 | Buick | Regal | Drive Motor Control Module | √ | √ | √ | √ | √ | |
| 2016 | Buick | Regal | Hybrid Powertrain Control Module | √ | √ | √ | √ | √ | 0263 |
| 2016 | Buick | Regal | Telematics Communication Interface Control Module | √ | √ | √ | √ | √ | 0259 0048 0011 0010 |
| 2016 | Buick | Regal | Instrument Cluster | √ | √ | √ | √ | √ | 0247 |
| 2016 | Buick | Regal | Rear Differential Clutch Control Module | √ | √ | √ | √ | √ | |

| | | | | | | | | | |
|------|-------|--------|--|---|---|---|---|---|--|
| 2016 | Buick | Regal | Body Control Module | √ | √ | √ | √ | √ | 0199 0239 0161 0162 0163 0164 0165 0166 0167 0168 0242 0263 0203 0201 0208 0206 |
| 2016 | Buick | Regal | Parking Assist Control Module | √ | √ | √ | √ | √ | 0247 |
| 2016 | Buick | Regal | Amplifier | √ | √ | √ | √ | √ | |
| 2016 | Buick | Regal | Human Machine Interface Control Module | √ | √ | √ | √ | √ | 0150 |
| 2016 | Buick | Regal | HVAC Controls | √ | √ | √ | √ | √ | |
| 2016 | Buick | Regal | Radio Controls | √ | √ | √ | √ | √ | 0241 |
| 2016 | Buick | Regal | Radio | √ | √ | √ | √ | √ | 0226 0150 |
| 2016 | Buick | Regal | Infotainment Control Touchpad | √ | √ | √ | √ | √ | |
| 2016 | Buick | Regal | Inflatable Restraint Sensing and Diagnostic Module | √ | √ | √ | √ | √ | 0172 0134 0111 |
| 2016 | Buick | Regal | Passenger Presence Module | √ | √ | √ | √ | √ | 0057 |
| 2016 | Buick | Regal | Keyless Entry Control Module | √ | √ | √ | √ | √ | |
| 2016 | Buick | Regal | Chassis Control Module | √ | √ | √ | √ | √ | 0217 |
| 2016 | Buick | Regal | Engine Control Module | √ | √ | √ | √ | √ | 0263 0156 0209 0132 0067 0066 0086 0217 0258 0213 0212 |
| 2016 | Buick | Regal | Front Seat Heating Control Module | √ | √ | √ | √ | √ | |
| 2016 | Buick | Regal | Frontview Camera Module | √ | √ | √ | √ | √ | 0205 0196 075A |
| 2016 | Buick | Regal | Left Side Object Detection Control Module | √ | √ | √ | √ | √ | |
| 2016 | Buick | Regal | Seat Memory Control Module | √ | √ | √ | √ | √ | 0310 |
| 2016 | Buick | Regal | Distance Sensing Cruise Control Module | √ | √ | √ | √ | √ | 0047 |
| 2016 | Buick | Regal | HVAC Control Module | √ | √ | √ | √ | √ | 0007 0129 |
| 2016 | Buick | Regal | Electronic Brake Control Module | √ | √ | √ | √ | √ | 0225 0090 0111 0277 |
| 2016 | Buick | Regal | Parking Brake Control Module | √ | √ | √ | √ | √ | 0229 |
| 2016 | Buick | Regal | Steering Wheel Angle Sensor Module | √ | √ | √ | √ | √ | 0093 0090 |
| 2016 | Buick | Regal | Suspension Control Module | √ | √ | √ | √ | √ | |
| 2016 | Buick | Regal | Power Steering Control Module | √ | √ | √ | √ | √ | 0081 0080 0089 |
| 2016 | Buick | Verano | Telematics Communication Interface Control Module | √ | √ | √ | √ | √ | 0259 0048 0011 0010 |
| 2016 | Buick | Verano | Instrument Cluster | √ | √ | √ | √ | √ | 0247 |
| 2016 | Buick | Verano | Front Seat Heating Control Module | √ | √ | √ | √ | √ | |
| 2016 | Buick | Verano | Frontview Camera Module | √ | √ | √ | √ | √ | 0205 0196 075A |
| 2016 | Buick | Verano | Left Side Object Detection Control Module | √ | √ | √ | √ | √ | |
| 2016 | Buick | Verano | Parking Assist Control Module | √ | √ | √ | √ | √ | 0247 0271 |
| 2016 | Buick | Verano | Right Side Object Detection Control Module | √ | √ | √ | √ | √ | |
| 2016 | Buick | Verano | HVAC Control Module | √ | √ | √ | √ | √ | 0007 0129 |
| 2016 | Buick | Verano | Body Control Module | √ | √ | √ | √ | √ | 0242 0263 0203 0201 0208 0206 0083 0160 |
| 2016 | Buick | Verano | Transmission Control Module | √ | √ | √ | √ | √ | 0017 0036 |
| 2016 | Buick | Verano | Keyless Entry Control Module | √ | √ | √ | √ | √ | |
| 2016 | Buick | Verano | Passenger Presence Module | √ | √ | √ | √ | √ | 0057 |

| | | | | | | | | | |
|------|-------|---------|--|---|---|---|---|---|--|
| 2016 | Buick | Verano | Inflatable Restraint Sensing and Diagnostic Module | √ | √ | √ | √ | √ | 0172 0134 |
| 2016 | Buick | Verano | Engine Control Module | √ | √ | √ | √ | √ | 0156 0209 0132 0067 0066 0086 0217 0258 |
| 2016 | Buick | Verano | Chassis Control Module | √ | √ | √ | √ | √ | 0217 |
| 2016 | Buick | Verano | Radio | √ | √ | √ | √ | √ | |
| 2016 | Buick | Verano | Multimedia Player Interface Module | √ | √ | √ | √ | √ | 0247 |
| 2016 | Buick | Verano | Electronic Brake Control Module | √ | √ | √ | √ | √ | 0225 0090 0111 |
| 2016 | Buick | Verano | Multi-Axis Acceleration Sensor Module | √ | √ | √ | | | 0112 0111 |
| 2016 | Buick | Verano | Parking Brake Control Module | √ | √ | √ | √ | √ | 0229 |
| 2016 | Buick | Verano | Steering Wheel Angle Sensor Module | √ | √ | √ | | | 0093 0090 |
| 2016 | Buick | Verano | Power Steering Control Module | √ | √ | √ | √ | √ | 0081 0080 0089 |
| 2015 | Buick | Enclave | Electronic Brake Control Module | √ | √ | √ | √ | √ | 0090 0225 0111 |
| 2015 | Buick | Enclave | Headlamp Control Module | √ | √ | √ | | | |
| 2015 | Buick | Enclave | Liftgate Control Module | √ | √ | √ | √ | | 0146 |
| 2015 | Buick | Enclave | Digital Radio Receiver Control Module | √ | √ | √ | √ | √ | |
| 2015 | Buick | Enclave | Telematics Communication Interface Control Module | √ | √ | √ | √ | √ | 0465 0259 0048 0011 |
| 2015 | Buick | Enclave | Engine Control Module | √ | √ | √ | √ | √ | 0263 0209 0132 0067 0086 0217 0258 0212 |
| 2015 | Buick | Enclave | Rear Differential Clutch Control Module | √ | √ | √ | √ | √ | 0155 |
| 2015 | Buick | Enclave | Front Seat Heating Control Module | √ | √ | √ | √ | √ | |
| 2015 | Buick | Enclave | Frontview Camera Module | √ | √ | √ | √ | √ | 0205 0196 |
| 2015 | Buick | Enclave | Left Side Object Detection Control Module | √ | √ | √ | | | |
| 2015 | Buick | Enclave | Parking Assist Control Module | √ | √ | √ | √ | √ | 0247 |
| 2015 | Buick | Enclave | Right Side Object Detection Control Module | √ | √ | √ | | | |
| 2015 | Buick | Enclave | Seat Memory Control Module | √ | √ | √ | √ | √ | |
| 2015 | Buick | Enclave | Transmission Control Module | √ | √ | √ | √ | √ | 0016 |
| 2015 | Buick | Enclave | Remote Control Door Lock Receiver | √ | √ | √ | √ | √ | 0204 0239 0161 0162 0163 0164 0159 0160 |
| 2015 | Buick | Enclave | Inflatable Restraint Sensing and Diagnostic Module | √ | √ | √ | √ | √ | 0172 0261 |
| 2015 | Buick | Enclave | Passenger Presence Module | √ | √ | √ | √ | | 0057 |
| 2015 | Buick | Enclave | Radio | √ | √ | √ | √ | √ | |
| 2015 | Buick | Enclave | Rear Audio Control Module | √ | √ | √ | √ | | |
| 2015 | Buick | Enclave | Personal Audio Link Control Module | √ | √ | √ | | | 0231 |
| 2015 | Buick | Enclave | Driver Door Switch Panel Control Module | √ | √ | √ | √ | √ | |
| 2015 | Buick | Enclave | Passenger Door Switch Panel Control Module | √ | √ | √ | √ | √ | |
| 2015 | Buick | Enclave | HVAC Control Module | √ | √ | √ | √ | √ | 0116 0007 0129 |
| 2015 | Buick | Enclave | Instrument Cluster | √ | √ | √ | √ | √ | |
| 2015 | Buick | Enclave | Theft Deterrent Module | √ | √ | √ | √ | | |
| 2015 | Buick | Enclave | Head-Up Display Module | √ | √ | √ | √ | √ | |
| 2015 | Buick | Enclave | Body Control Module | √ | √ | √ | √ | √ | 0263 0261 |
| 2015 | Buick | Encore | Telematics Communication Interface Control Module | √ | √ | √ | √ | √ | 0259 0048 0011 0010 |
| 2015 | Buick | Encore | Instrument Cluster | √ | √ | √ | √ | √ | 0247 |

| | | | | | | | | | |
|------|-------|----------|--|---|---|---|---|---|--|
| 2015 | Buick | Encore | Transmission Control Module | √ | √ | √ | √ | √ | 0017 0036 |
| 2015 | Buick | Encore | Engine Control Module | √ | √ | √ | √ | √ | 0263 0156 0209 0020 0132 0067 0066 076D 0086 0213 0217 0006 |
| 2015 | Buick | Encore | Electronic Brake Control Module | √ | √ | √ | √ | √ | 0090 |
| 2015 | Buick | Encore | Power Steering Control Module | √ | √ | √ | √ | √ | 0207 |
| 2015 | Buick | Encore | Steering Wheel Angle Sensor Module | √ | √ | √ | | | 0093 0090 |
| 2015 | Buick | Encore | Front Seat Heating Control Module | √ | √ | √ | √ | √ | |
| 2015 | Buick | Encore | Frontview Camera Module | √ | √ | √ | √ | √ | 0205 0196 075A |
| 2015 | Buick | Encore | Left Side Object Detection Control Module | √ | √ | √ | | √ | |
| 2015 | Buick | Encore | Parking Assist Control Module | √ | √ | √ | √ | √ | 0247 |
| 2015 | Buick | Encore | Seat Memory Control Module | √ | √ | √ | √ | √ | 0310 |
| 2015 | Buick | Encore | Rear Differential Clutch Control Module | √ | √ | √ | √ | | 0003 075B |
| 2015 | Buick | Encore | Passenger Presence Module | √ | √ | √ | √ | | 0057 |
| 2015 | Buick | Encore | Inflatable Restraint Sensing and Diagnostic Module | √ | √ | √ | √ | √ | 0172 0134 0111 |
| 2015 | Buick | Encore | Body Control Module | √ | √ | √ | √ | √ | 0199 0239 0161 0162 0163 0164 0165 0166 0167 0168 0242 0263 0203 0201 0208 0206 |
| 2015 | Buick | Encore | HVAC Control Module | √ | √ | √ | √ | √ | 0007 0129 |
| 2015 | Buick | Encore | Chassis Control Module | √ | √ | √ | √ | √ | 0217 |
| 2015 | Buick | Encore | Radio | √ | √ | √ | √ | √ | |
| 2015 | Buick | LaCrosse | Telematics Communication Interface Control Module | √ | √ | √ | √ | √ | 0259 0048 0011 0010 |
| 2015 | Buick | LaCrosse | Headlamp Control Module | √ | √ | √ | √ | √ | |
| 2015 | Buick | LaCrosse | Rear Differential Clutch Control Module | √ | √ | √ | √ | √ | |
| 2015 | Buick | LaCrosse | Chassis Control Module | √ | √ | √ | √ | √ | 0217 0095 0194 0245 |
| 2015 | Buick | LaCrosse | Instrument Cluster | √ | √ | √ | √ | √ | 0247 |
| 2015 | Buick | LaCrosse | Transmission Control Module | √ | √ | √ | √ | √ | 0017 0036 0016 |
| 2015 | Buick | LaCrosse | Keyless Entry Control Module | √ | √ | √ | √ | √ | |
| 2015 | Buick | LaCrosse | Inflatable Restraint Sensing and Diagnostic Module | √ | √ | √ | √ | √ | 0172 0134 0111 |
| 2015 | Buick | LaCrosse | Passenger Presence Module | √ | √ | √ | √ | | 0057 |
| 2015 | Buick | LaCrosse | HVAC Control Module | √ | √ | √ | √ | √ | 0007 0129 |
| 2015 | Buick | LaCrosse | Distance Sensing Cruise Control Module | √ | √ | √ | √ | | 0047 |
| 2015 | Buick | LaCrosse | Frontview Camera Module | √ | √ | √ | √ | √ | 0205 0196 075A |
| 2015 | Buick | LaCrosse | Left Side Object Detection Control Module | √ | √ | √ | | √ | |
| 2015 | Buick | LaCrosse | Parking Assist Control Module | √ | √ | √ | √ | √ | 0247 |
| 2015 | Buick | LaCrosse | Engine Control Module | √ | √ | √ | √ | √ | 0209 0132 0067 0086 0217 0258 0263 0156 |
| 2015 | Buick | LaCrosse | Drive Motor Control Module | √ | √ | √ | √ | | |
| 2015 | Buick | LaCrosse | Hybrid Powertrain Control Module | √ | √ | √ | √ | √ | 0263 |

| | | | | | | | | | |
|------|-------|----------|--|---|---|---|---|---|--|
| 2015 | Buick | LaCrosse | Body Control Module | √ | √ | √ | √ | √ | 0199 0239 0161 0162 0163 0164 0165 0166 0167 0168 0242 0263 0203 0201 0208 0206 |
| 2015 | Buick | LaCrosse | Head-Up Display Module | √ | √ | √ | √ | √ | |
| 2015 | Buick | LaCrosse | Electronic Brake Control Module | √ | √ | √ | √ | √ | 0225 0090 0111 0277 |
| 2015 | Buick | LaCrosse | Parking Brake Control Module | √ | √ | √ | √ | √ | 0229 |
| 2015 | Buick | LaCrosse | Steering Wheel Angle Sensor Module | √ | √ | √ | | | 0093 0090 |
| 2015 | Buick | LaCrosse | Suspension Control Module | √ | √ | √ | √ | √ | |
| 2015 | Buick | LaCrosse | Power Steering Control Module | √ | √ | √ | √ | √ | 0081 0080 0089 |
| 2015 | Buick | LaCrosse | Battery Energy Control Module | √ | | | √ | | |
| 2015 | Buick | LaCrosse | Radio | √ | √ | √ | √ | √ | 0226 0150 |
| 2015 | Buick | LaCrosse | Radio Controls | √ | √ | √ | √ | | 0241 |
| 2015 | Buick | LaCrosse | HVAC Controls | √ | √ | √ | √ | √ | |
| 2015 | Buick | LaCrosse | Human Machine Interface Control Module | √ | √ | √ | √ | √ | 0150 |
| 2015 | Buick | LaCrosse | Amplifier | √ | √ | √ | √ | | |
| 2015 | Buick | LaCrosse | Media Disc Player | √ | √ | √ | √ | √ | |
| 2015 | Buick | LaCrosse | Seat Memory Control Module - Driver | √ | √ | √ | √ | √ | 0310 |
| 2015 | Buick | Regal | Telematics Communication Interface Control Module | √ | √ | √ | √ | √ | 0259 0048 0011 0010 |
| 2015 | Buick | Regal | Battery Energy Control Module | √ | | | √ | | |
| 2015 | Buick | Regal | Rear Differential Clutch Control Module | √ | √ | √ | √ | √ | |
| 2015 | Buick | Regal | Chassis Control Module | √ | √ | √ | √ | √ | 0217 |
| 2015 | Buick | Regal | Instrument Cluster | √ | √ | √ | √ | √ | 0247 |
| 2015 | Buick | Regal | Transmission Control Module | √ | √ | √ | √ | √ | 0016 0017 0036 |
| 2015 | Buick | Regal | Keyless Entry Control Module | √ | √ | √ | √ | √ | |
| 2015 | Buick | Regal | Passenger Presence Module | √ | √ | √ | √ | | 0057 |
| 2015 | Buick | Regal | Inflatable Restraint Sensing and Diagnostic Module | √ | √ | √ | √ | √ | 0172 0134 0111 |
| 2015 | Buick | Regal | Amplifier | √ | √ | √ | √ | | |
| 2015 | Buick | Regal | Human Machine Interface Control Module | √ | √ | √ | √ | √ | 0150 |
| 2015 | Buick | Regal | HVAC Controls | √ | √ | √ | √ | √ | |
| 2015 | Buick | Regal | Radio Controls | √ | √ | √ | √ | | 0241 |
| 2015 | Buick | Regal | Radio | √ | √ | √ | √ | √ | 0226 0150 |
| 2015 | Buick | Regal | HVAC Control Module | √ | √ | √ | √ | √ | 0007 0129 |
| 2015 | Buick | Regal | Distance Sensing Cruise Control Module | √ | √ | √ | √ | | 0047 |
| 2015 | Buick | Regal | Front Seat Heating Control Module | √ | √ | √ | √ | √ | |
| 2015 | Buick | Regal | Frontview Camera Module | √ | √ | √ | √ | √ | 0205 0196 075A |
| 2015 | Buick | Regal | Left Side Object Detection Control Module | √ | √ | √ | | √ | |
| 2015 | Buick | Regal | Parking Assist Control Module | √ | √ | √ | √ | √ | 0247 |
| 2015 | Buick | Regal | Seat Memory Control Module | √ | √ | √ | √ | √ | 0310 |
| 2015 | Buick | Regal | Engine Control Module | √ | √ | √ | √ | √ | 0263 0156 0209 0132 0067 0066 0086 0217 0258 0213 0212 |

| | | | | | | | | | |
|------|-------|---------|--|---|---|---|---|---|---|
| 2015 | Buick | Regal | Drive Motor Control Module | √ | √ | √ | √ | | |
| 2015 | Buick | Regal | Hybrid Powertrain Control Module | √ | √ | √ | √ | √ | 0263 |
| 2015 | Buick | Regal | Body Control Module | √ | √ | √ | √ | √ | 0199 0239 0161 0162 0163 0164 0165 0166 0167 0168 0242 0263 0203 0201 0208 0206 0202 0158 0200 0157 |
| 2015 | Buick | Regal | Electronic Brake Control Module | √ | √ | √ | √ | √ | 0225 0090 0111 0277 |
| 2015 | Buick | Regal | Parking Brake Control Module | √ | √ | √ | √ | √ | 0229 |
| 2015 | Buick | Regal | Steering Wheel Angle Sensor Module | √ | √ | √ | | | 0093 0090 |
| 2015 | Buick | Regal | Suspension Control Module | √ | √ | √ | √ | √ | |
| 2015 | Buick | Regal | Power Steering Control Module | √ | √ | √ | √ | √ | 0081 0080 0089 |
| 2015 | Buick | Verano | Telematics Communication Interface Control Module | √ | √ | √ | √ | √ | 0259 0048 0011 0010 |
| 2015 | Buick | Verano | Transmission Control Module | √ | √ | √ | √ | √ | 0017 0036 |
| 2015 | Buick | Verano | Front Seat Heating Control Module | √ | √ | √ | √ | √ | |
| 2015 | Buick | Verano | Frontview Camera Module | √ | √ | √ | √ | √ | 0205 0196 075A |
| 2015 | Buick | Verano | Left Side Object Detection Control Module | √ | √ | √ | | √ | |
| 2015 | Buick | Verano | Parking Assist Control Module | √ | √ | √ | √ | √ | 0247 |
| 2015 | Buick | Verano | Right Side Object Detection Control Module | √ | √ | √ | | √ | |
| 2015 | Buick | Verano | Instrument Cluster | √ | √ | √ | √ | √ | 0247 |
| 2015 | Buick | Verano | Keyless Entry Control Module | √ | √ | √ | √ | √ | |
| 2015 | Buick | Verano | Inflatable Restraint Sensing and Diagnostic Module | √ | √ | √ | √ | √ | 0172 0134 |
| 2015 | Buick | Verano | Passenger Presence Module | √ | √ | √ | √ | | 0057 |
| 2015 | Buick | Verano | Engine Control Module | √ | √ | √ | √ | √ | 0156 0209 0132 0067 0066 0086 0217 0258 |
| 2015 | Buick | Verano | Chassis Control Module | √ | √ | √ | √ | √ | 0217 |
| 2015 | Buick | Verano | Body Control Module | √ | √ | √ | √ | √ | 0242 0263 0203 0201 0208 0206 0083 0160 |
| 2015 | Buick | Verano | Electronic Brake Control Module | √ | √ | √ | √ | √ | 0225 0090 0111 |
| 2015 | Buick | Verano | Parking Brake Control Module | √ | √ | √ | √ | √ | 0229 |
| 2015 | Buick | Verano | Multi-Axis Acceleration Sensor Module | √ | √ | √ | | | 0112 0111 |
| 2015 | Buick | Verano | Steering Wheel Angle Sensor Module | √ | √ | √ | | | 0093 0090 |
| 2015 | Buick | Verano | Power Steering Control Module | √ | √ | √ | √ | √ | 0081 0080 0089 |
| 2015 | Buick | Verano | HVAC Control Module | √ | √ | √ | √ | √ | 0007 0129 |
| 2015 | Buick | Verano | Radio | √ | √ | √ | √ | √ | |
| 2015 | Buick | Verano | Multimedia Player Interface Module | √ | √ | √ | √ | | 0247 |
| 2014 | Buick | Enclave | Transmission Control Module | √ | √ | √ | √ | √ | 0016 |
| 2014 | Buick | Enclave | Rear Differential Clutch Control Module | √ | √ | √ | √ | √ | 0155 |
| 2014 | Buick | Enclave | Body Control Module | √ | √ | √ | √ | √ | 0263 0261 |
| 2014 | Buick | Enclave | Instrument Cluster | √ | √ | √ | √ | √ | |
| 2014 | Buick | Enclave | Headlamp Control Module | √ | √ | √ | | | |
| 2014 | Buick | Enclave | Digital Radio Receiver Control Module | √ | √ | √ | √ | √ | |
| 2014 | Buick | Enclave | Telematics Communication Interface Control Module | √ | √ | √ | √ | √ | 0465 0259 0048 0011 |

| | | | | | | | | | |
|------|-------|---------|--|---|---|---|---|---|---|
| 2014 | Buick | Enclave | Liftgate Control Module | √ | √ | √ | √ | | 0146 |
| 2014 | Buick | Enclave | Remote Control Door Lock Receiver | √ | √ | √ | √ | √ | 0204 0239 0161 0162 0163 0164 0159 0160 |
| 2014 | Buick | Enclave | Theft Deterrent Module | √ | √ | √ | √ | | |
| 2014 | Buick | Enclave | Left Side Object Detection Control Module | √ | √ | √ | | √ | |
| 2014 | Buick | Enclave | Right Side Object Detection Control Module | √ | √ | √ | | √ | |
| 2014 | Buick | Enclave | Parking Assist Control Module | √ | √ | √ | √ | √ | 0247 |
| 2014 | Buick | Enclave | Seat Memory Control Module | √ | √ | √ | √ | √ | |
| 2014 | Buick | Enclave | HVAC Control Module | √ | √ | √ | √ | √ | 0116 0007 0129 |
| 2014 | Buick | Enclave | Radio | √ | √ | √ | √ | √ | |
| 2014 | Buick | Enclave | Rear Audio Control Module | √ | √ | √ | √ | | |
| 2014 | Buick | Enclave | Inflatable Restraint Sensing and Diagnostic Module | √ | √ | √ | √ | √ | 0172 0261 |
| 2014 | Buick | Enclave | Passenger Presence Module | √ | √ | √ | √ | | 0057 |
| 2014 | Buick | Enclave | Chassis Control Module | √ | √ | √ | √ | √ | 0217 0095 0194 |
| 2014 | Buick | Enclave | Engine Control Module | √ | √ | √ | √ | √ | 0263 0156 0209 0132 0067 0086 0217 0214 |
| 2014 | Buick | Enclave | Driver Door Switch Panel Control Module | √ | √ | √ | √ | √ | |
| 2014 | Buick | Enclave | Passenger Door Switch Panel Control Module | √ | √ | √ | √ | √ | |
| 2014 | Buick | Enclave | Electronic Brake Control Module | √ | √ | √ | √ | √ | 0090 0225 0111 |
| 2014 | Buick | Enclave | Front Seat Heating Control Module | √ | √ | √ | √ | | |
| 2014 | Buick | Enclave | Personal Audio Link Control Module | √ | √ | √ | | | 0231 |
| 2014 | Buick | Enclave | Frontview Camera Module | √ | √ | √ | √ | √ | 0205 0196 |
| 2014 | Buick | Encore | Telematics Communication Interface Control Module | √ | √ | √ | √ | √ | 0465 0259 0048 0011 |
| 2014 | Buick | Encore | Electronic Brake Control Module | √ | √ | √ | √ | √ | 0090 |
| 2014 | Buick | Encore | Power Steering Control Module | √ | √ | √ | √ | | 0207 |
| 2014 | Buick | Encore | Steering Wheel Angle Sensor Module | √ | √ | √ | | | 0093 0090 |
| 2014 | Buick | Encore | Engine Control Module | √ | √ | √ | √ | √ | 0263 0156 0209 0020 0132 0067 0066 076D 0086 0213 0217 0006 |
| 2014 | Buick | Encore | Transmission Control Module | √ | √ | √ | √ | √ | 0017 0036 |
| 2014 | Buick | Encore | Chassis Control Module | √ | √ | √ | √ | √ | 0217 0095 0194 |
| 2014 | Buick | Encore | Rear Differential Clutch Control Module | √ | √ | √ | √ | | 0003 075B |
| 2014 | Buick | Encore | Body Control Module | √ | √ | √ | √ | √ | 0242 0263 0203 0201 0208 0206 0083 0160 |
| 2014 | Buick | Encore | HVAC Control Module | √ | √ | √ | √ | √ | 0007 0129 |
| 2014 | Buick | Encore | Inflatable Restraint Sensing and Diagnostic Module | √ | √ | √ | √ | √ | 0172 0134 0111 |
| 2014 | Buick | Encore | Passenger Presence Module | √ | √ | √ | √ | | 0057 |
| 2014 | Buick | Encore | Instrument Cluster | √ | √ | √ | √ | √ | 0247 |
| 2014 | Buick | Encore | Front Seat Heating Control Module | √ | √ | √ | √ | √ | |
| 2014 | Buick | Encore | Frontview Camera Module | √ | √ | √ | √ | √ | 0205 0196 075A |
| 2014 | Buick | Encore | Left Side Object Detection Control Module | √ | √ | √ | | √ | |
| 2014 | Buick | Encore | Parking Assist Control Module | √ | √ | √ | √ | √ | 0247 |

| | | | | | | | | | |
|------|-------|----------|--|---|---|---|---|---|--|
| 2014 | Buick | Encore | Seat Memory Control Module | √ | √ | √ | √ | √ | 0310 |
| 2014 | Buick | Encore | Radio | √ | √ | √ | √ | √ | |
| 2014 | Buick | LaCrosse | Telematics Communication Interface Control Module | √ | √ | √ | √ | √ | 0465 0259 0048 0011 |
| 2014 | Buick | LaCrosse | Headlamp Control Module | √ | √ | √ | √ | √ | |
| 2014 | Buick | LaCrosse | Battery Energy Control Module | √ | | | √ | | |
| 2014 | Buick | LaCrosse | Drive Motor Control Module | √ | √ | √ | √ | | |
| 2014 | Buick | LaCrosse | Hybrid Powertrain Control Module | √ | √ | √ | √ | √ | 0263 |
| 2014 | Buick | LaCrosse | Transmission Control Module | √ | √ | √ | √ | √ | 0017 0036 0016 |
| 2014 | Buick | LaCrosse | Electronic Brake Control Module | √ | √ | √ | √ | √ | 0225 0090 0111 0277 |
| 2014 | Buick | LaCrosse | Parking Brake Control Module | √ | √ | √ | √ | √ | 0229 |
| 2014 | Buick | LaCrosse | Chassis Control Module | √ | √ | √ | √ | √ | 0217 0095 0194 |
| 2014 | Buick | LaCrosse | Rear Differential Clutch Control Module | √ | √ | √ | √ | √ | |
| 2014 | Buick | LaCrosse | Suspension Control Module | √ | √ | √ | √ | √ | |
| 2014 | Buick | LaCrosse | Steering Wheel Angle Sensor Module | √ | √ | √ | | | 0093 0090 |
| 2014 | Buick | LaCrosse | Multi-Axis Acceleration Sensor Module | √ | √ | √ | | | 0111 |
| 2014 | Buick | LaCrosse | Power Steering Control Module | √ | √ | √ | √ | √ | 0081 0080 0089 |
| 2014 | Buick | LaCrosse | Engine Control Module | √ | √ | √ | √ | √ | 0209 0132 0067 0086 0217 0258 0263 0156 |
| 2014 | Buick | LaCrosse | Inflatable Restraint Sensing and Diagnostic Module | √ | √ | √ | √ | √ | 0172 0134 0111 |
| 2014 | Buick | LaCrosse | Keyless Entry Control Module | √ | √ | √ | √ | √ | |
| 2014 | Buick | LaCrosse | Passenger Presence Module | √ | √ | √ | √ | | 0057 |
| 2014 | Buick | LaCrosse | Left Side Object Detection Control Module | √ | √ | √ | | √ | |
| 2014 | Buick | LaCrosse | Radio Controls | √ | √ | √ | √ | | 0241 |
| 2014 | Buick | LaCrosse | HVAC Controls | √ | √ | √ | √ | √ | |
| 2014 | Buick | LaCrosse | Seat Memory Control Module - Driver | √ | √ | √ | √ | √ | 0310 |
| 2014 | Buick | LaCrosse | Body Control Module | √ | √ | √ | √ | √ | 0199 0239 0161 0162 0163 0164 0165 0166 0167 0168 0242 0263 0203 0201 0208 0206 |
| 2014 | Buick | LaCrosse | HVAC Control Module | √ | √ | √ | √ | √ | 0007 0129 |
| 2014 | Buick | LaCrosse | Distance Sensing Cruise Control Module | √ | √ | √ | √ | | 0047 |
| 2014 | Buick | LaCrosse | Human Machine Interface Control Module | √ | √ | √ | √ | √ | 0150 |
| 2014 | Buick | LaCrosse | Radio | √ | √ | √ | √ | √ | 0226 0150 |
| 2014 | Buick | LaCrosse | Amplifier | √ | √ | √ | √ | | |
| 2014 | Buick | LaCrosse | Media Disc Player | √ | √ | √ | √ | √ | |
| 2014 | Buick | LaCrosse | Frontview Camera Module | √ | √ | √ | √ | √ | 0205 0196 075A |
| 2014 | Buick | LaCrosse | Parking Assist Control Module | √ | √ | √ | √ | √ | 0247 |
| 2014 | Buick | LaCrosse | Instrument Cluster | √ | √ | √ | √ | √ | 0247 |
| 2014 | Buick | LaCrosse | Head-Up Display Module | √ | √ | √ | √ | √ | |
| 2014 | Buick | Regal | Telematics Communication Interface Control Module | √ | √ | √ | √ | √ | 0465 0259 0048 0011 |
| 2014 | Buick | Regal | Hybrid Powertrain Control Module | √ | √ | √ | √ | √ | 0263 |
| 2014 | Buick | Regal | Drive Motor Control Module | √ | √ | √ | √ | | |

| | | | | | | | | | |
|------|-------|--------|--|---|---|---|---|---|--|
| 2014 | Buick | Regal | Battery Energy Control Module | √ | | | √ | | |
| 2014 | Buick | Regal | Transmission Control Module | √ | √ | √ | √ | √ | 0016 0017 0036 |
| 2014 | Buick | Regal | Chassis Control Module | √ | √ | √ | √ | √ | 0217 0095 0194 |
| 2014 | Buick | Regal | Radio | √ | √ | √ | √ | √ | 0226 0150 |
| 2014 | Buick | Regal | Rear Differential Clutch Control Module | √ | √ | √ | √ | √ | |
| 2014 | Buick | Regal | Engine Control Module | √ | √ | √ | √ | √ | 0263 0156 0209 0132 0067 0066 0086 0217 0258 0213 0212 |
| 2014 | Buick | Regal | Keyless Entry Control Module | √ | √ | √ | √ | √ | |
| 2014 | Buick | Regal | Passenger Presence Module | √ | √ | √ | √ | | 0057 |
| 2014 | Buick | Regal | Body Control Module | √ | √ | √ | √ | √ | 0199 0239 0161 0162 0163 0164 0165 0166 0167 0168 0242 0263 0203 0201 0208 0206 |
| 2014 | Buick | Regal | Inflatable Restraint Sensing and Diagnostic Module | √ | √ | √ | √ | √ | 0172 0134 0111 |
| 2014 | Buick | Regal | Electronic Brake Control Module | √ | √ | √ | √ | √ | 0225 0090 0111 0277 |
| 2014 | Buick | Regal | Parking Brake Control Module | √ | √ | √ | √ | √ | 0229 |
| 2014 | Buick | Regal | Instrument Cluster | √ | √ | √ | √ | √ | 0247 |
| 2014 | Buick | Regal | Front Seat Heating Control Module | √ | √ | √ | √ | √ | |
| 2014 | Buick | Regal | Frontview Camera Module | √ | √ | √ | √ | √ | 0205 0196 075A |
| 2014 | Buick | Regal | Left Side Object Detection Control Module | √ | √ | √ | | √ | |
| 2014 | Buick | Regal | Parking Assist Control Module | √ | √ | √ | √ | √ | 0247 |
| 2014 | Buick | Regal | Seat Memory Control Module | √ | √ | √ | √ | √ | 0310 |
| 2014 | Buick | Regal | Multi-Axis Acceleration Sensor Module | √ | √ | √ | | | 0111 |
| 2014 | Buick | Regal | HVAC Control Module | √ | √ | √ | √ | √ | 0007 0129 |
| 2014 | Buick | Regal | Distance Sensing Cruise Control Module | √ | √ | √ | √ | | 0047 |
| 2014 | Buick | Regal | Human Machine Interface Control Module | √ | √ | √ | √ | √ | 0150 |
| 2014 | Buick | Regal | Radio Controls | √ | √ | √ | √ | | 0241 |
| 2014 | Buick | Regal | HVAC Controls | √ | √ | √ | √ | √ | |
| 2014 | Buick | Regal | Amplifier | √ | √ | √ | √ | | |
| 2014 | Buick | Regal | Suspension Control Module | √ | √ | √ | √ | √ | |
| 2014 | Buick | Regal | Power Steering Control Module | √ | √ | √ | √ | | 0081 0080 0089 |
| 2014 | Buick | Regal | Steering Wheel Angle Sensor Module | √ | √ | √ | | | 0093 0090 |
| 2014 | Buick | Verano | Telematics Communication Interface Control Module | √ | √ | √ | √ | √ | 0465 0259 0048 0011 |
| 2014 | Buick | Verano | Transmission Control Module | √ | √ | √ | √ | √ | 0017 0036 |
| 2014 | Buick | Verano | Chassis Control Module | √ | √ | √ | √ | √ | 0217 0095 0194 |
| 2014 | Buick | Verano | Engine Control Module | √ | √ | √ | √ | √ | 0156 0209 0132 0067 0066 0086 0217 0258 |
| 2014 | Buick | Verano | Keyless Entry Control Module | √ | √ | √ | √ | √ | |
| 2014 | Buick | Verano | Inflatable Restraint Sensing and Diagnostic Module | √ | √ | √ | √ | √ | 0172 0134 |
| 2014 | Buick | Verano | Passenger Presence Module | √ | √ | √ | √ | | 0057 |

| | | | | | | | | | |
|------|-------|----------|--|---|---|---|---|---|--|
| 2014 | Buick | Verano | Body Control Module | √ | √ | √ | √ | √ | 0242 0263 0203 0201 0208 0206 0083 0160 |
| 2014 | Buick | Verano | Front Seat Heating Control Module | √ | √ | √ | √ | √ | |
| 2014 | Buick | Verano | Frontview Camera Module | √ | √ | √ | √ | √ | 0205 0196 075A |
| 2014 | Buick | Verano | Left Side Object Detection Control Module | √ | √ | √ | | √ | |
| 2014 | Buick | Verano | Right Side Object Detection Control Module | √ | √ | √ | | √ | |
| 2014 | Buick | Verano | Parking Assist Control Module | √ | √ | √ | √ | √ | 0247 |
| 2014 | Buick | Verano | Instrument Cluster | √ | √ | √ | √ | √ | 0247 |
| 2014 | Buick | Verano | HVAC Control Module | √ | √ | √ | √ | √ | 0007 0129 |
| 2014 | Buick | Verano | Parking Brake Control Module | √ | √ | √ | √ | √ | 0229 |
| 2014 | Buick | Verano | Steering Wheel Angle Sensor Module | √ | √ | √ | | | 0093 0090 |
| 2014 | Buick | Verano | Power Steering Control Module | √ | √ | √ | √ | √ | 0081 0080 0089 |
| 2014 | Buick | Verano | Electronic Brake Control Module | √ | √ | √ | √ | √ | 0225 0090 0111 |
| 2014 | Buick | Verano | Multi-Axis Acceleration Sensor Module | √ | √ | √ | | | 0112 0111 |
| 2014 | Buick | Verano | Radio | √ | √ | √ | √ | √ | |
| 2014 | Buick | Verano | Multimedia Player Interface Module | √ | √ | √ | √ | | 0247 |
| 2013 | Buick | Encore | Transmission Control Module | √ | √ | √ | √ | √ | 0017 |
| 2013 | Buick | Encore | Instrument Cluster | √ | √ | √ | √ | √ | 0301 |
| 2013 | Buick | Encore | Telematics Communication Interface Control Module | √ | √ | √ | √ | √ | 0465 0259 |
| 2013 | Buick | Encore | Front Seat Heating Control Module | √ | √ | √ | √ | √ | |
| 2013 | Buick | Encore | Parking Assist Control Module | √ | √ | √ | √ | √ | 0301 |
| 2013 | Buick | Encore | Inflatable Restraint Sensing and Diagnostic Module | √ | √ | √ | √ | √ | 0172 |
| 2013 | Buick | Encore | Fuel Pump Control Module | √ | √ | √ | √ | √ | 0217 |
| 2013 | Buick | Encore | Engine Control Module | √ | √ | √ | √ | √ | 0263 0323 0305 0020 0306 0067 0217 0337 |
| 2013 | Buick | Encore | Body Control Module | √ | √ | √ | √ | √ | 0243 0263 0203 0201 0208 0206 0297 0298 |
| 2013 | Buick | Encore | Passenger Presence Module | √ | √ | √ | √ | | 0322 |
| 2013 | Buick | Encore | Electronic Brake Control Module | √ | √ | √ | √ | √ | 0090 |
| 2013 | Buick | Encore | Multi-Axis Acceleration Sensor Module | √ | √ | √ | | | |
| 2013 | Buick | Encore | Power Steering Control Module | √ | √ | √ | √ | | |
| 2013 | Buick | Encore | Steering Wheel Angle Sensor Module | √ | √ | √ | | | |
| 2013 | Buick | Encore | HVAC Control Module | √ | √ | √ | √ | √ | 0311 0129 |
| 2013 | Buick | Encore | Rear Differential Clutch Control Module | √ | √ | √ | √ | √ | |
| 2013 | Buick | Encore | Radio | √ | √ | √ | √ | √ | |
| 2013 | Buick | Encore | Frontview Camera Module | √ | √ | √ | √ | √ | 0205 0196 |
| 2013 | Buick | Encore | Seat Memory Control Module | √ | √ | √ | √ | √ | 0310 |
| 2013 | Buick | LaCrosse | Engine Control Module | √ | √ | √ | √ | √ | 0305 0306 0067 0308 0217 0309 |
| 2013 | Buick | LaCrosse | Fuel Injector Control Module | √ | √ | √ | √ | √ | |
| 2013 | Buick | LaCrosse | Fuel Pump Control Module | √ | √ | √ | √ | √ | 0217 |
| 2013 | Buick | LaCrosse | Hybrid Powertrain Control Module | √ | √ | √ | √ | √ | 0263 |

| | | | | | | | | | |
|------|-------|----------|--|---|---|---|---|---|--|
| 2013 | Buick | LaCrosse | Transmission Control Module | √ | √ | √ | √ | √ | 0020 0106 |
| 2013 | Buick | LaCrosse | Rear Differential Clutch Control Module | √ | √ | √ | √ | √ | |
| 2013 | Buick | LaCrosse | Drive Motor Control Module | √ | √ | √ | √ | √ | |
| 2013 | Buick | LaCrosse | Electronic Brake Control Module | √ | √ | √ | √ | √ | 0225 0090 0111 |
| 2013 | Buick | LaCrosse | Parking Brake Control Module | √ | √ | √ | √ | √ | 0316 |
| 2013 | Buick | LaCrosse | Multi-Axis Acceleration Sensor Module | √ | √ | √ | | | 0112 0111 |
| 2013 | Buick | LaCrosse | Power Steering Control Module | √ | √ | √ | √ | | |
| 2013 | Buick | LaCrosse | Steering Wheel Angle Sensor Module | √ | √ | √ | | | |
| 2013 | Buick | LaCrosse | Suension Control Module | √ | √ | √ | √ | √ | |
| 2013 | Buick | LaCrosse | Body Control Module | √ | √ | √ | √ | √ | 0243 0263 0203 0201 0208 0206 0297 0298 |
| 2013 | Buick | LaCrosse | Inflatable Restraint Sensing and Diagnostic Module | √ | √ | √ | √ | √ | 0172 |
| 2013 | Buick | LaCrosse | Passenger Presence Module | √ | √ | √ | √ | | 0322 |
| 2013 | Buick | LaCrosse | Instrument Cluster | √ | √ | √ | √ | √ | 0301 |
| 2013 | Buick | LaCrosse | Head-Up Dilay Module | √ | √ | √ | √ | √ | |
| 2013 | Buick | LaCrosse | Headlamp Control Module | √ | √ | √ | √ | √ | |
| 2013 | Buick | LaCrosse | Radio | √ | √ | √ | √ | √ | |
| 2013 | Buick | LaCrosse | Multimedia Player Interface Module | √ | √ | √ | √ | | |
| 2013 | Buick | LaCrosse | Telematics Communication Interface Control Module | √ | √ | √ | √ | √ | 0465 0259 |
| 2013 | Buick | LaCrosse | HVAC Control Module | √ | √ | √ | √ | √ | 0311 0129 |
| 2013 | Buick | LaCrosse | Seat Memory Control Module | √ | √ | √ | √ | √ | 0310 |
| 2013 | Buick | LaCrosse | Front Seat Heating Control Module | √ | √ | √ | √ | √ | |
| 2013 | Buick | LaCrosse | Keyless Entry Control Module | √ | √ | √ | √ | √ | |
| 2013 | Buick | LaCrosse | Parking Assist Control Module | √ | √ | √ | √ | √ | 0301 |
| 2013 | Buick | LaCrosse | Steering Column Lock Control Module | √ | √ | √ | √ | | |
| 2013 | Buick | Regal | Engine Control Module | √ | √ | √ | √ | √ | 0305 0306 0067 0308 0217 0309 |
| 2013 | Buick | Regal | Fuel Injector Control Module | √ | √ | √ | √ | √ | |
| 2013 | Buick | Regal | Fuel Pump Control Module | √ | √ | √ | √ | √ | 0217 |
| 2013 | Buick | Regal | Hybrid Powertrain Control Module | √ | √ | √ | √ | √ | 0263 |
| 2013 | Buick | Regal | Transmission Control Module | √ | √ | √ | √ | √ | 0016 |
| 2013 | Buick | Regal | Rear Differential Clutch Control Module | √ | √ | √ | √ | √ | |
| 2013 | Buick | Regal | Drive Motor Control Module | √ | √ | √ | √ | | |
| 2013 | Buick | Regal | Electronic Brake Control Module | √ | √ | √ | √ | √ | 0225 0090 0111 |
| 2013 | Buick | Regal | Parking Brake Control Module | √ | √ | √ | √ | √ | 0316 |
| 2013 | Buick | Regal | Multi-Axis Acceleration Sensor Module | √ | √ | √ | | | 0111 0111 |
| 2013 | Buick | Regal | Power Steering Control Module | √ | √ | √ | √ | | |
| 2013 | Buick | Regal | Steering Wheel Angle Sensor Module | √ | √ | √ | | | |
| 2013 | Buick | Regal | Suension Control Module | √ | √ | √ | √ | √ | |
| 2013 | Buick | Regal | Body Control Module | √ | √ | √ | √ | √ | 0243 0263 0203 0201 0208 0206 0297 0298 |
| 2013 | Buick | Regal | Inflatable Restraint Sensing and Diagnostic Module | √ | √ | √ | √ | √ | 0172 |

| | | | | | | | | | |
|------|-------|---------------|--|---|---|---|---|---|--|
| 2013 | Buick | Regal | Passenger Presence Module | √ | √ | √ | √ | | 0322 |
| 2013 | Buick | Regal | Instrument Cluster | √ | √ | √ | √ | √ | 0301 |
| 2013 | Buick | Regal | Radio | √ | √ | √ | √ | √ | |
| 2013 | Buick | Regal | Multimedia Player Interface Module | √ | √ | √ | √ | | |
| 2013 | Buick | Regal | Telematics Communication Interface Control Module | √ | √ | √ | √ | √ | 0465 0259 |
| 2013 | Buick | Regal | HVAC Control Module | √ | √ | √ | √ | √ | 0311 0129 |
| 2013 | Buick | Verano | Fuel Pump Control Module | √ | √ | √ | √ | √ | 0217 |
| 2013 | Buick | Verano | Transmission Control Module | √ | √ | √ | √ | √ | 0020 0106 |
| 2013 | Buick | Verano | Electronic Brake Control Module | √ | √ | √ | √ | √ | 0225 0090 0111 |
| 2013 | Buick | Verano | Power Steering Control Module | √ | √ | √ | √ | | |
| 2013 | Buick | Verano | Instrument Cluster | √ | √ | √ | √ | √ | 0301 |
| 2013 | Buick | Verano | Telematics Communication Interface Control Module | √ | √ | √ | √ | √ | 0465 0259 |
| 2013 | Buick | Verano | HVAC Control Module | √ | √ | √ | √ | √ | 0311 0129 |
| 2013 | Buick | Verano | Front Seat Heating Control Module | √ | √ | √ | √ | √ | |
| 2013 | Buick | Verano | Parking Assist Control Module | √ | √ | √ | √ | √ | 0301 |
| 2013 | Buick | Verano | Left Side Object Detection Control Module | √ | √ | √ | | √ | |
| 2013 | Buick | Verano | Right Side Object Detection Control Module | √ | √ | √ | | √ | |
| 2013 | Buick | Verano | Parking Brake Control Module | √ | √ | √ | √ | √ | 0316 |
| 2013 | Buick | Verano | Inflatable Restraint Sensing and Diagnostic Module | √ | √ | √ | √ | √ | 0172 0172 |
| 2013 | Buick | Verano | Passenger Presence Module | √ | √ | √ | √ | | 0322 |
| 2013 | Buick | Verano | Keyless Entry Control Module | √ | √ | √ | √ | √ | |
| 2013 | Buick | Verano | Body Control Module | √ | √ | √ | √ | √ | 0243 0263 0203 0201 0208 0206 0297 0298 |
| 2013 | Buick | Verano | Radio | √ | √ | √ | √ | √ | |
| 2013 | Buick | Verano | Multimedia Player Interface Module | √ | √ | √ | √ | | |
| 2013 | Buick | Verano | Engine Control Module | √ | √ | √ | √ | √ | 0323 0305 0306 0067 0066 0308 0217 0309 |
| 2013 | Buick | Verano | Steering Wheel Angle Sensor Module | √ | √ | √ | | | |
| 2013 | Buick | Verano | Multi-Axis Acceleration Sensor Module | √ | √ | √ | | | 0111 0111 |
| 2013 | Buick | Enclave - AWD | Engine Control Module | √ | √ | √ | √ | √ | 0493 |
| 2013 | Buick | Enclave - AWD | Transmission control module | | √ | √ | √ | √ | |
| 2013 | Buick | Enclave - AWD | Fuel Pump Control Module | √ | √ | √ | √ | √ | |
| 2013 | Buick | Enclave - AWD | Digital radio receiver | √ | √ | √ | √ | √ | |
| 2013 | Buick | Enclave - AWD | Liftgate module | √ | √ | √ | √ | √ | |
| 2013 | Buick | Enclave - AWD | Vehicle comm. interface module | √ | √ | √ | √ | √ | 0494 0495 |
| 2013 | Buick | Enclave - AWD | Instrument panel cluster | √ | √ | √ | √ | √ | |
| 2013 | Buick | Enclave - AWD | Memory seat module | √ | √ | √ | √ | √ | |
| 2013 | Buick | Enclave - AWD | Park assist module | √ | √ | √ | √ | | |
| 2013 | Buick | Enclave - AWD | HVAC Control Module | √ | √ | √ | √ | √ | 0500 0526 |
| 2013 | Buick | Enclave - AWD | Rear HVAC/RSA | √ | √ | √ | √ | √ | |
| 2013 | Buick | Enclave - AWD | Headlamp Control Module | √ | √ | √ | | | |
| 2013 | Buick | Enclave - AWD | Supplemental inflatable restraint | √ | √ | √ | √ | √ | 0497 |

| | | | | | | | | | |
|------|-------|---------------|------------------------------------|---|---|---|---|---|---------------------|
| 2013 | Buick | Enclave - AWD | Driver door switch | √ | √ | √ | √ | √ | 0527 |
| 2013 | Buick | Enclave - AWD | Passenger door switch | √ | √ | √ | √ | √ | 0527 |
| 2013 | Buick | Enclave - AWD | Personal audio link module | √ | √ | √ | | | 0528 0529 |
| 2013 | Buick | Enclave - AWD | Radio | √ | √ | √ | √ | √ | |
| 2013 | Buick | Enclave - AWD | Passenger presence system | √ | √ | √ | √ | √ | |
| 2013 | Buick | Enclave - AWD | Remote control door lock receiver | √ | √ | √ | √ | √ | 0513 0159 |
| 2013 | Buick | Enclave - AWD | Theft Deterrent Module | √ | √ | √ | √ | | |
| 2013 | Buick | Enclave - AWD | Body Control Module | √ | √ | √ | √ | √ | 0499 0497 |
| 2013 | Buick | Enclave - AWD | Left side object detection module | √ | √ | √ | | √ | |
| 2013 | Buick | Enclave - AWD | Right side object detection module | √ | √ | √ | | √ | |
| 2013 | Buick | Enclave - AWD | Electronic Brake Control Module | √ | √ | √ | √ | √ | 0506 |
| 2013 | Buick | Enclave - AWD | Rear drive system | √ | √ | √ | √ | √ | 0530 |
| 2013 | Buick | Enclave - FWD | Engine Control Module | √ | √ | √ | √ | √ | 0493 |
| 2013 | Buick | Enclave - FWD | Transmission control module | | √ | √ | √ | √ | |
| 2013 | Buick | Enclave - FWD | Fuel Pump Control Module | √ | √ | √ | √ | √ | |
| 2013 | Buick | Enclave - FWD | Digital radio receiver | √ | √ | √ | √ | √ | |
| 2013 | Buick | Enclave - FWD | Liftgate module | √ | √ | √ | √ | √ | |
| 2013 | Buick | Enclave - FWD | Vehicle comm. interface module | √ | √ | √ | √ | √ | 0494 0495 |
| 2013 | Buick | Enclave - FWD | Instrument panel cluster | √ | √ | √ | √ | √ | |
| 2013 | Buick | Enclave - FWD | Memory seat module | √ | √ | √ | √ | √ | |
| 2013 | Buick | Enclave - FWD | Park assist module | √ | √ | √ | √ | | |
| 2013 | Buick | Enclave - FWD | HVAC Control Module | √ | √ | √ | √ | √ | 0500 0526 |
| 2013 | Buick | Enclave - FWD | Rear HVAC/RSA | √ | √ | √ | √ | √ | |
| 2013 | Buick | Enclave - FWD | Headlamp Control Module | √ | √ | √ | | | |
| 2013 | Buick | Enclave - FWD | Supplemental inflatable restraint | √ | √ | √ | √ | √ | 0497 |
| 2013 | Buick | Enclave - FWD | Driver door switch | √ | √ | √ | √ | √ | 0527 |
| 2013 | Buick | Enclave - FWD | Passenger door switch | √ | √ | √ | √ | √ | 0527 |
| 2013 | Buick | Enclave - FWD | Personal audio link module | √ | √ | √ | | | 0528 0529 |
| 2013 | Buick | Enclave - FWD | Radio | √ | √ | √ | √ | √ | |
| 2013 | Buick | Enclave - FWD | Passenger presence system | √ | √ | √ | √ | √ | |
| 2013 | Buick | Enclave - FWD | Remote control door lock receiver | √ | √ | √ | √ | √ | 0513 0159 |
| 2013 | Buick | Enclave - FWD | Theft Deterrent Module | √ | √ | √ | √ | | |
| 2013 | Buick | Enclave - FWD | Body Control Module | √ | √ | √ | √ | √ | 0499 0497 |
| 2013 | Buick | Enclave - FWD | Left side object detection module | √ | √ | √ | | √ | |
| 2013 | Buick | Enclave - FWD | Right side object detection module | √ | √ | √ | | √ | |
| 2013 | Buick | Enclave - FWD | Electronic Brake Control Module | √ | √ | √ | √ | √ | 0506 |
| 2013 | Buick | Enclave - FWD | Rear drive system | √ | √ | √ | √ | √ | 0530 |
| 2012 | Buick | LaCrosse | Engine Control Module | √ | √ | √ | √ | √ | 0323 0308 0217 0309 |
| 2012 | Buick | LaCrosse | Fuel Injector Control Module | √ | √ | √ | √ | √ | |
| 2012 | Buick | LaCrosse | Fuel Pump Control Module | √ | √ | √ | √ | √ | 0217 |
| 2012 | Buick | LaCrosse | Hybrid Powertrain Control Module | √ | √ | √ | √ | √ | 0263 |
| 2012 | Buick | LaCrosse | Transmission Control Module | √ | √ | √ | √ | √ | 0016 |

| | | | | | | | | | |
|------|-------|----------|--|---|---|---|---|---|--|
| 2012 | Buick | LaCrosse | Rear Differential Clutch Control Module | √ | √ | √ | √ | √ | |
| 2012 | Buick | LaCrosse | Drive Motor Control Module | √ | √ | √ | √ | | |
| 2012 | Buick | LaCrosse | Electronic Brake Control Module | √ | √ | √ | √ | √ | 0225 0090 0111 |
| 2012 | Buick | LaCrosse | Parking Brake Control Module | √ | √ | √ | √ | √ | 0316 |
| 2012 | Buick | LaCrosse | Multi-Axis Acceleration Sensor Module | √ | √ | √ | | | 0111 0111 |
| 2012 | Buick | LaCrosse | Power Steering Control Module | √ | √ | √ | √ | | 0081 0081 0080 0080 |
| 2012 | Buick | LaCrosse | Steering Wheel Angle Sensor Module | √ | √ | √ | | | 0093 0093 0090 0090 |
| 2012 | Buick | LaCrosse | Suension Control Module | √ | √ | √ | √ | √ | |
| 2012 | Buick | LaCrosse | Body Control Module | √ | √ | √ | √ | √ | 0243 0263 0203 0201 0208 0206 0297 0298 |
| 2012 | Buick | LaCrosse | Inflatable Restraint Sensing and Diagnostic Module | √ | √ | √ | √ | √ | 0172 |
| 2012 | Buick | LaCrosse | Passenger Presence Module | √ | √ | √ | √ | | 0322 |
| 2012 | Buick | LaCrosse | Instrument Cluster | √ | √ | √ | √ | √ | 0301 |
| 2012 | Buick | LaCrosse | Head-Up Dilay Module | √ | √ | √ | √ | √ | |
| 2012 | Buick | LaCrosse | Headlamp Control Module | √ | √ | √ | √ | √ | |
| 2012 | Buick | LaCrosse | Radio | √ | √ | √ | √ | √ | |
| 2012 | Buick | LaCrosse | Digital Radio Receiver Control Module | √ | √ | √ | √ | √ | 0301 0301 |
| 2012 | Buick | LaCrosse | Multimedia Player Interface Module | √ | √ | √ | √ | | |
| 2012 | Buick | LaCrosse | Mobile Telephone Control Module | √ | √ | √ | √ | √ | 0301 0301 |
| 2012 | Buick | LaCrosse | Telematics Communication Interface Control Module | √ | √ | √ | √ | √ | 0465 0259 |
| 2012 | Buick | LaCrosse | Remote Heater and Air Conditioning Control Module | √ | √ | √ | √ | √ | 0311 0129 |
| 2012 | Buick | LaCrosse | Seat Memory Control Module | √ | √ | √ | √ | √ | 0310 |
| 2012 | Buick | LaCrosse | Front Seat Heating Control Module | √ | √ | √ | √ | √ | |
| 2012 | Buick | LaCrosse | Rear Seat Heating Control Module | √ | √ | √ | √ | √ | |
| 2012 | Buick | LaCrosse | Keyless Entry Control Module | √ | √ | √ | √ | √ | |
| 2012 | Buick | LaCrosse | Parking Assist Control Module | √ | √ | √ | √ | √ | 0301 |
| 2012 | Buick | LaCrosse | Vehicle Direction Camera Control Module | √ | √ | √ | √ | √ | 0205 0447 |
| 2012 | Buick | LaCrosse | Steering Column Lock Control Module | √ | √ | √ | √ | | |
| 2012 | Buick | LaCrosse | Battery Energy Control Module | √ | | | √ | | |
| 2012 | Buick | LaCrosse | Left Side Object Detection Control Module | √ | √ | √ | √ | √ | |
| 2012 | Buick | LaCrosse | Right Side Object Detection Control Module | √ | √ | √ | √ | √ | |
| 2012 | Buick | Regal | Engine Control Module | √ | √ | √ | √ | √ | 0323 0308 0217 0309 |
| 2012 | Buick | Regal | Fuel Injector Control Module | √ | √ | √ | √ | √ | |
| 2012 | Buick | Regal | Fuel Pump Control Module | √ | √ | √ | √ | √ | 0217 |
| 2012 | Buick | Regal | Hybrid Powertrain Control Module | √ | √ | √ | √ | √ | 0263 |
| 2012 | Buick | Regal | Transmission Control Module | √ | √ | √ | √ | √ | 0016 |
| 2012 | Buick | Regal | Rear Differential Clutch Control Module | √ | √ | √ | √ | √ | |
| 2012 | Buick | Regal | Drive Motor Control Module | √ | √ | √ | √ | | |
| 2012 | Buick | Regal | Electronic Brake Control Module | √ | √ | √ | √ | √ | 0225 0090 0111 |
| 2012 | Buick | Regal | Parking Brake Control Module | √ | √ | √ | √ | √ | 0316 |
| 2012 | Buick | Regal | Multi-Axis Acceleration Sensor Module | √ | √ | √ | | | 0111 0111 |
| 2012 | Buick | Regal | Power Steering Control Module | √ | √ | √ | √ | | 0081 0081 0080 0080 |

| | | | | | | | | | |
|------|-------|--------|--|---|---|---|---|---|--|
| 2012 | Buick | Regal | Steering Wheel Angle Sensor Module | √ | √ | √ | | | 0093 0093 0090 0090 |
| 2012 | Buick | Regal | Suension Control Module | √ | √ | √ | √ | √ | |
| 2012 | Buick | Regal | Body Control Module | √ | √ | √ | √ | √ | 0243 0263 0203 0201 0208 0206 0297 0298 |
| 2012 | Buick | Regal | Inflatable Restraint Sensing and Diagnostic Module | √ | √ | √ | √ | √ | 0172 |
| 2012 | Buick | Regal | Passenger Presence Module | √ | √ | √ | √ | | 0322 |
| 2012 | Buick | Regal | Instrument Cluster | √ | √ | √ | √ | √ | 0301 |
| 2012 | Buick | Regal | Head-Up Dilay Module | √ | √ | √ | √ | √ | |
| 2012 | Buick | Regal | Headlamp Control Module | √ | √ | √ | √ | √ | |
| 2012 | Buick | Regal | Radio | √ | √ | √ | √ | √ | |
| 2012 | Buick | Regal | Digital Radio Receiver Control Module | √ | √ | √ | √ | √ | 0301 0301 |
| 2012 | Buick | Regal | Multimedia Player Interface Module | √ | √ | √ | √ | | |
| 2012 | Buick | Regal | Mobile Telephone Control Module | √ | √ | √ | √ | √ | 0301 0301 |
| 2012 | Buick | Regal | Telematics Communication Interface Control Module | √ | √ | √ | √ | √ | 0465 0259 |
| 2012 | Buick | Regal | Remote Heater and Air Conditioning Control Module | √ | √ | √ | √ | √ | 0311 0129 |
| 2012 | Buick | Regal | Seat Memory Control Module | √ | √ | √ | √ | √ | 0310 |
| 2012 | Buick | Regal | Front Seat Heating Control Module | √ | √ | √ | √ | √ | |
| 2012 | Buick | Regal | Rear Seat Heating Control Module | √ | √ | √ | √ | √ | |
| 2012 | Buick | Regal | Keyless Entry Control Module | √ | √ | √ | √ | √ | |
| 2012 | Buick | Regal | Parking Assist Control Module | √ | √ | √ | √ | √ | 0301 |
| 2012 | Buick | Regal | Vehicle Direction Camera Control Module | √ | √ | √ | √ | √ | 0205 0447 |
| 2012 | Buick | Regal | Steering Column Lock Control Module | √ | √ | √ | √ | | |
| 2012 | Buick | Regal | Battery Energy Control Module | √ | | | √ | | |
| 2012 | Buick | Regal | Left Side Object Detection Control Module | √ | √ | √ | √ | √ | |
| 2012 | Buick | Regal | Right Side Object Detection Control Module | √ | √ | √ | √ | √ | |
| 2012 | Buick | Verano | Engine Control Module | √ | √ | √ | √ | √ | 0323 0305 0306 0067 0263 0308 0217 |
| 2012 | Buick | Verano | Fuel Pump Control Module | √ | √ | √ | √ | √ | 0217 |
| 2012 | Buick | Verano | Transmission Control Module | √ | √ | √ | √ | √ | 0017 |
| 2012 | Buick | Verano | Electronic Brake Control Module | √ | √ | √ | √ | √ | 0225 0090 0111 |
| 2012 | Buick | Verano | Parking Brake Control Module | √ | √ | √ | √ | √ | 0316 |
| 2012 | Buick | Verano | Multi-Axis Acceleration Sensor Module | √ | √ | √ | | | 0111 0111 |
| 2012 | Buick | Verano | Power Steering Control Module | √ | √ | √ | √ | | 0081 0081 0080 0080 |
| 2012 | Buick | Verano | Steering Wheel Angle Sensor Module | √ | √ | √ | | | 0093 0093 0090 0090 |
| 2012 | Buick | Verano | Body Control Module | √ | √ | √ | √ | √ | 0263 0203 0201 0208 0206 0297 0298 0159 |
| 2012 | Buick | Verano | Inflatable Restraint Sensing and Diagnostic Module | √ | √ | √ | √ | √ | 0172 0172 |
| 2012 | Buick | Verano | Passenger Presence Module | √ | √ | √ | √ | | 0322 |
| 2012 | Buick | Verano | Instrument Cluster | √ | √ | √ | √ | √ | |
| 2012 | Buick | Verano | Headlamp Control Module | √ | √ | √ | √ | √ | |
| 2012 | Buick | Verano | Radio | √ | √ | √ | √ | √ | |
| 2012 | Buick | Verano | Telematics Communication Interface Control Module | √ | √ | √ | √ | √ | 0465 0259 |

| | | | | | | | | | |
|------|-------|---------------|---|---|---|---|---|---|-----------|
| 2012 | Buick | Verano | Remote Heater and Air Conditioning Control Module | √ | √ | √ | √ | √ | 0311 0129 |
| 2012 | Buick | Verano | Front Seat Heating Control Module | √ | √ | √ | √ | √ | |
| 2012 | Buick | Verano | Keyless Entry Control Module | √ | √ | √ | √ | √ | |
| 2012 | Buick | Verano | Parking Assist Control Module | √ | √ | √ | √ | √ | 0301 |
| 2012 | Buick | Enclave - AWD | Engine Control Module | √ | √ | √ | √ | √ | 0493 |
| 2012 | Buick | Enclave - AWD | Fuel Pump Control Module | √ | √ | √ | √ | √ | |
| 2012 | Buick | Enclave - AWD | Transmission control module | | √ | √ | √ | √ | |
| 2012 | Buick | Enclave - AWD | Digital radio receiver | √ | √ | √ | √ | √ | |
| 2012 | Buick | Enclave - AWD | Headlamp Control Module | √ | √ | √ | | | |
| 2012 | Buick | Enclave - AWD | Liftgate module | √ | √ | √ | √ | √ | |
| 2012 | Buick | Enclave - AWD | Rear HVAC/RSA | √ | √ | √ | √ | √ | |
| 2012 | Buick | Enclave - AWD | Vehicle comm. interface module | √ | √ | √ | √ | √ | 0494 0495 |
| 2012 | Buick | Enclave - AWD | Instrument panel cluster | √ | √ | √ | √ | √ | |
| 2012 | Buick | Enclave - AWD | Supplemental inflatable restraint | √ | √ | √ | √ | √ | 0497 |
| 2012 | Buick | Enclave - AWD | Passenger presence system | √ | √ | √ | √ | √ | |
| 2012 | Buick | Enclave - AWD | Driver door switch | √ | √ | √ | √ | √ | 0527 |
| 2012 | Buick | Enclave - AWD | Passenger door switch | √ | √ | √ | √ | √ | 0527 |
| 2012 | Buick | Enclave - AWD | Remote control door lock receiver | √ | √ | √ | √ | √ | 0513 0159 |
| 2012 | Buick | Enclave - AWD | Theft Deterrent Module | √ | √ | √ | √ | | |
| 2012 | Buick | Enclave - AWD | HVAC Control Module | √ | √ | √ | √ | √ | 0500 0526 |
| 2012 | Buick | Enclave - AWD | Body Control Module | √ | √ | √ | √ | √ | 0499 0497 |
| 2012 | Buick | Enclave - AWD | Radio | √ | √ | √ | √ | √ | |
| 2012 | Buick | Enclave - AWD | Personal audio link module | √ | √ | √ | | | 0528 0529 |
| 2012 | Buick | Enclave - AWD | Memory seat module | √ | √ | √ | √ | √ | |
| 2012 | Buick | Enclave - AWD | Park assist module | √ | √ | √ | √ | | |
| 2012 | Buick | Enclave - AWD | Electronic Brake Control Module | √ | √ | √ | √ | √ | 0506 |
| 2012 | Buick | Enclave - AWD | Rear drive system | √ | √ | √ | √ | √ | 0530 |
| 2012 | Buick | Enclave - FWD | Engine Control Module | √ | √ | √ | √ | √ | 0493 |
| 2012 | Buick | Enclave - FWD | Fuel Pump Control Module | √ | √ | √ | √ | √ | |
| 2012 | Buick | Enclave - FWD | Transmission control module | | √ | √ | √ | √ | |
| 2012 | Buick | Enclave - FWD | Digital radio receiver | √ | √ | √ | √ | √ | |
| 2012 | Buick | Enclave - FWD | Headlamp Control Module | √ | √ | √ | | | |
| 2012 | Buick | Enclave - FWD | Liftgate module | √ | √ | √ | √ | √ | |
| 2012 | Buick | Enclave - FWD | Rear HVAC/RSA | √ | √ | √ | √ | √ | |
| 2012 | Buick | Enclave - FWD | Vehicle comm. interface module | √ | √ | √ | √ | √ | 0494 0495 |
| 2012 | Buick | Enclave - FWD | Instrument panel cluster | √ | √ | √ | √ | √ | |
| 2012 | Buick | Enclave - FWD | Supplemental inflatable restraint | √ | √ | √ | √ | √ | 0497 |
| 2012 | Buick | Enclave - FWD | Passenger presence system | √ | √ | √ | √ | √ | |
| 2012 | Buick | Enclave - FWD | Driver door switch | √ | √ | √ | √ | √ | 0527 |
| 2012 | Buick | Enclave - FWD | Passenger door switch | √ | √ | √ | √ | √ | 0527 |
| 2012 | Buick | Enclave - FWD | Remote control door lock receiver | √ | √ | √ | √ | √ | 0513 0159 |
| 2012 | Buick | Enclave - FWD | Theft Deterrent Module | √ | √ | √ | √ | | |

| | | | | | | | | | |
|------|-------|---------------|--|---|---|---|---|---|--|
| 2012 | Buick | Enclave - FWD | HVAC Control Module | √ | √ | √ | √ | √ | 0500 0526 |
| 2012 | Buick | Enclave - FWD | Body Control Module | √ | √ | √ | √ | √ | 0499 0497 |
| 2012 | Buick | Enclave - FWD | Radio | √ | √ | √ | √ | √ | |
| 2012 | Buick | Enclave - FWD | Personal audio link module | √ | √ | √ | √ | √ | 0528 0529 |
| 2012 | Buick | Enclave - FWD | Memory seat module | √ | √ | √ | √ | √ | |
| 2012 | Buick | Enclave - FWD | Park assist module | √ | √ | √ | √ | √ | |
| 2012 | Buick | Enclave - FWD | Electronic Brake Control Module | √ | √ | √ | √ | √ | 0506 |
| 2012 | Buick | Enclave - FWD | Rear drive system | √ | √ | √ | √ | √ | 0530 |
| 2011 | Buick | LaCrosse | Engine Control Module | √ | √ | √ | √ | √ | 0323 0308 0217 0309 |
| 2011 | Buick | LaCrosse | Fuel Injector Control Module | √ | √ | √ | √ | √ | |
| 2011 | Buick | LaCrosse | Fuel Pump Control Module | √ | √ | √ | √ | √ | 0217 |
| 2011 | Buick | LaCrosse | Hybrid Powertrain Control Module | √ | √ | √ | √ | √ | 0263 |
| 2011 | Buick | LaCrosse | Transmission Control Module | √ | √ | √ | √ | √ | 0016 |
| 2011 | Buick | LaCrosse | Rear Differential Clutch Control Module | √ | √ | √ | √ | √ | |
| 2011 | Buick | LaCrosse | Drive Motor Control Module | √ | √ | √ | √ | √ | |
| 2011 | Buick | LaCrosse | Electronic Brake Control Module | √ | √ | √ | √ | √ | 0225 0090 0111 |
| 2011 | Buick | LaCrosse | Parking Brake Control Module | √ | √ | √ | √ | √ | 0316 |
| 2011 | Buick | LaCrosse | Multi-Axis Acceleration Sensor Module | √ | √ | √ | √ | √ | 0111 0111 |
| 2011 | Buick | LaCrosse | Power Steering Control Module | √ | √ | √ | √ | √ | 0081 0081 0080 0080 |
| 2011 | Buick | LaCrosse | Steering Wheel Angle Sensor Module | √ | √ | √ | √ | √ | 0093 0093 0090 0090 |
| 2011 | Buick | LaCrosse | Suension Control Module | √ | √ | √ | √ | √ | |
| 2011 | Buick | LaCrosse | Body Control Module | √ | √ | √ | √ | √ | 0243 0263 0203 0201 0208 0206 0297 0298 |
| 2011 | Buick | LaCrosse | Inflatable Restraint Sensing and Diagnostic Module | √ | √ | √ | √ | √ | 0172 |
| 2011 | Buick | LaCrosse | Passenger Presence Module | √ | √ | √ | √ | √ | 0322 |
| 2011 | Buick | LaCrosse | Instrument Cluster | √ | √ | √ | √ | √ | 0301 |
| 2011 | Buick | LaCrosse | Head-Up Dilay Module | √ | √ | √ | √ | √ | |
| 2011 | Buick | LaCrosse | Headlamp Control Module | √ | √ | √ | √ | √ | |
| 2011 | Buick | LaCrosse | Radio | √ | √ | √ | √ | √ | |
| 2011 | Buick | LaCrosse | Digital Radio Receiver Control Module | √ | √ | √ | √ | √ | 0301 0301 |
| 2011 | Buick | LaCrosse | Multimedia Player Interface Module | √ | √ | √ | √ | √ | |
| 2011 | Buick | LaCrosse | Mobile Telephone Control Module | √ | √ | √ | √ | √ | 0301 0301 |
| 2011 | Buick | LaCrosse | Telematics Communication Interface Control Module | √ | √ | √ | √ | √ | 0465 0259 |
| 2011 | Buick | LaCrosse | Remote Heater and Air Conditioning Control Module | √ | √ | √ | √ | √ | 0311 0129 |
| 2011 | Buick | LaCrosse | Seat Memory Control Module | √ | √ | √ | √ | √ | 0310 |
| 2011 | Buick | LaCrosse | Front Seat Heating Control Module | √ | √ | √ | √ | √ | |
| 2011 | Buick | LaCrosse | Rear Seat Heating Control Module | √ | √ | √ | √ | √ | |
| 2011 | Buick | LaCrosse | Keyless Entry Control Module | √ | √ | √ | √ | √ | |
| 2011 | Buick | LaCrosse | Parking Assist Control Module | √ | √ | √ | √ | √ | 0301 |
| 2011 | Buick | LaCrosse | Vehicle Direction Camera Control Module | √ | √ | √ | √ | √ | 0205 0447 |
| 2011 | Buick | LaCrosse | Steering Column Lock Control Module | √ | √ | √ | √ | √ | |
| 2011 | Buick | LaCrosse | Battery Energy Control Module | √ | √ | √ | √ | √ | |

| | | | | | | | | | |
|------|-------|----------|--|---|---|---|---|---|--|
| 2011 | Buick | LaCrosse | Left Side Object Detection Control Module | √ | √ | √ | √ | √ | |
| 2011 | Buick | LaCrosse | Right Side Object Detection Control Module | √ | √ | √ | √ | √ | |
| 2011 | Buick | Regal | Engine Control Module | √ | √ | √ | √ | √ | 0323 0308 0217 0309 |
| 2011 | Buick | Regal | Fuel Injector Control Module | √ | √ | √ | √ | √ | |
| 2011 | Buick | Regal | Fuel Pump Control Module | √ | √ | √ | √ | √ | 0217 |
| 2011 | Buick | Regal | Hybrid Powertrain Control Module | √ | √ | √ | √ | √ | 0263 |
| 2011 | Buick | Regal | Transmission Control Module | √ | √ | √ | √ | √ | 0016 |
| 2011 | Buick | Regal | Rear Differential Clutch Control Module | √ | √ | √ | √ | √ | |
| 2011 | Buick | Regal | Drive Motor Control Module | √ | √ | √ | √ | √ | |
| 2011 | Buick | Regal | Electronic Brake Control Module | √ | √ | √ | √ | √ | 0225 0090 0111 |
| 2011 | Buick | Regal | Parking Brake Control Module | √ | √ | √ | √ | √ | 0316 |
| 2011 | Buick | Regal | Multi-Axis Acceleration Sensor Module | √ | √ | √ | | | 0111 0111 |
| 2011 | Buick | Regal | Power Steering Control Module | √ | √ | √ | √ | | 0081 0081 0080 0080 |
| 2011 | Buick | Regal | Steering Wheel Angle Sensor Module | √ | √ | √ | | | 0093 0093 0090 0090 |
| 2011 | Buick | Regal | Suension Control Module | √ | √ | √ | √ | √ | |
| 2011 | Buick | Regal | Body Control Module | √ | √ | √ | √ | √ | 0243 0263 0203 0201 0208 0206 0297 0298 |
| 2011 | Buick | Regal | Inflatable Restraint Sensing and Diagnostic Module | √ | √ | √ | √ | √ | 0172 |
| 2011 | Buick | Regal | Passenger Presence Module | √ | √ | √ | √ | | 0322 |
| 2011 | Buick | Regal | Instrument Cluster | √ | √ | √ | √ | √ | 0301 |
| 2011 | Buick | Regal | Head-Up Dilay Module | √ | √ | √ | √ | √ | |
| 2011 | Buick | Regal | Headlamp Control Module | √ | √ | √ | √ | √ | |
| 2011 | Buick | Regal | Radio | √ | √ | √ | √ | √ | |
| 2011 | Buick | Regal | Digital Radio Receiver Control Module | √ | √ | √ | √ | √ | 0301 0301 |
| 2011 | Buick | Regal | Multimedia Player Interface Module | √ | √ | √ | √ | | |
| 2011 | Buick | Regal | Mobile Telephone Control Module | √ | √ | √ | √ | √ | 0301 0301 |
| 2011 | Buick | Regal | Telematics Communication Interface Control Module | √ | √ | √ | √ | √ | 0465 0259 |
| 2011 | Buick | Regal | Remote Heater and Air Conditioning Control Module | √ | √ | √ | √ | √ | 0311 0129 |
| 2011 | Buick | Regal | Seat Memory Control Module | √ | √ | √ | √ | √ | 0310 |
| 2011 | Buick | Regal | Front Seat Heating Control Module | √ | √ | √ | √ | √ | |
| 2011 | Buick | Regal | Rear Seat Heating Control Module | √ | √ | √ | √ | √ | |
| 2011 | Buick | Regal | Keyless Entry Control Module | √ | √ | √ | √ | √ | |
| 2011 | Buick | Regal | Parking Assist Control Module | √ | √ | √ | √ | √ | 0301 |
| 2011 | Buick | Regal | Vehicle Direction Camera Control Module | √ | √ | √ | √ | √ | 0205 0447 |
| 2011 | Buick | Regal | Steering Column Lock Control Module | √ | √ | √ | √ | | |
| 2011 | Buick | Regal | Battery Energy Control Module | √ | | | √ | | |
| 2011 | Buick | Regal | Left Side Object Detection Control Module | √ | √ | √ | √ | √ | |
| 2011 | Buick | Regal | Right Side Object Detection Control Module | √ | √ | √ | √ | √ | |
| 2011 | Buick | Lucerne | Transmission control module | | √ | √ | √ | √ | |
| 2011 | Buick | Lucerne | Engine Control Module | √ | √ | √ | √ | √ | 0493 |
| 2011 | Buick | Lucerne | Vehicle comm. interface module | √ | √ | √ | √ | √ | 0494 0495 0496 |
| 2011 | Buick | Lucerne | Radio | √ | √ | √ | √ | √ | |

| | | | | | | | | | |
|------|-------|---------------|------------------------------------|---|---|---|---|---|----------------|
| 2011 | Buick | Lucerne | Remote control door lock receiver | √ | √ | √ | √ | √ | 0513 0159 |
| 2011 | Buick | Lucerne | Theft Deterrent Module | √ | √ | √ | √ | | |
| 2011 | Buick | Lucerne | Left side object detection module | √ | √ | √ | √ | √ | |
| 2011 | Buick | Lucerne | Memory seat module | √ | √ | √ | √ | √ | |
| 2011 | Buick | Lucerne | Park assist module | √ | √ | √ | √ | | |
| 2011 | Buick | Lucerne | Right side object detection module | √ | √ | √ | √ | | |
| 2011 | Buick | Lucerne | Veh direction alert alarm warn mod | √ | √ | √ | √ | √ | |
| 2011 | Buick | Lucerne | Passenger presence system | √ | √ | √ | √ | | 0517 |
| 2011 | Buick | Lucerne | Supplemental inflatable restraint | √ | √ | √ | √ | √ | 0497 |
| 2011 | Buick | Lucerne | HVAC Control Module | √ | √ | √ | √ | √ | |
| 2011 | Buick | Lucerne | Digital radio receiver | √ | √ | √ | √ | √ | |
| 2011 | Buick | Lucerne | Driver door switch | √ | √ | √ | √ | √ | |
| 2011 | Buick | Lucerne | Passenger door switch | √ | √ | √ | √ | √ | |
| 2011 | Buick | Lucerne | Body Control Module | √ | √ | √ | √ | √ | 0499 0497 |
| 2011 | Buick | Lucerne | Instrument panel cluster | √ | √ | √ | √ | √ | 0494 0495 0496 |
| 2011 | Buick | Lucerne | Electronic Brake Control Module | √ | √ | √ | √ | √ | 0506 |
| 2011 | Buick | Lucerne | Electronic suspension control | √ | √ | √ | √ | √ | |
| 2011 | Buick | Enclave - AWD | Transmission control module | √ | √ | √ | √ | √ | |
| 2011 | Buick | Enclave - AWD | Engine Control Module | √ | √ | √ | √ | √ | |
| 2011 | Buick | Enclave - AWD | Fuel Pump Control Module | √ | √ | √ | √ | √ | |
| 2011 | Buick | Enclave - AWD | Vehicle comm. interface module | √ | √ | √ | √ | √ | 0494 0495 |
| 2011 | Buick | Enclave - AWD | Digital radio receiver | √ | √ | √ | √ | √ | |
| 2011 | Buick | Enclave - AWD | Body Control Module | | | | | | 0499 0497 |
| 2011 | Buick | Enclave - AWD | Headlamp Control Module | √ | √ | √ | | | |
| 2011 | Buick | Enclave - AWD | Liftgate module | √ | √ | √ | √ | √ | |
| 2011 | Buick | Enclave - AWD | Personal audio link module | √ | √ | √ | | | 0528 0529 |
| 2011 | Buick | Enclave - AWD | Radio | √ | √ | √ | √ | √ | |
| 2011 | Buick | Enclave - AWD | Remote control door lock receiver | √ | √ | √ | √ | √ | 0513 0159 |
| 2011 | Buick | Enclave - AWD | Theft Deterrent Module | √ | √ | √ | √ | | |
| 2011 | Buick | Enclave - AWD | Instrument panel cluster | √ | √ | √ | √ | √ | |
| 2011 | Buick | Enclave - AWD | Memory seat module | √ | √ | √ | √ | √ | |
| 2011 | Buick | Enclave - AWD | Park assist module | √ | √ | √ | √ | | |
| 2011 | Buick | Enclave - AWD | Passenger presence system | √ | √ | √ | √ | √ | |
| 2011 | Buick | Enclave - AWD | Supplemental inflatable restraint | √ | √ | √ | √ | √ | 0497 |
| 2011 | Buick | Enclave - AWD | HVAC Control Module | √ | √ | √ | √ | √ | 0500 0526 |
| 2011 | Buick | Enclave - AWD | Driver door switch | √ | √ | √ | √ | √ | 0527 |
| 2011 | Buick | Enclave - AWD | Passenger door switch | √ | √ | √ | √ | √ | 0527 |
| 2011 | Buick | Enclave - AWD | Rear HVAC/RSA | √ | √ | √ | √ | √ | |
| 2011 | Buick | Enclave - AWD | Electronic Brake Control Module | √ | √ | √ | √ | √ | 0506 |
| 2011 | Buick | Enclave - AWD | Rear drive system | √ | √ | √ | √ | √ | 0530 |
| 2011 | Buick | Enclave - FWD | Transmission control module | | √ | √ | √ | √ | |
| 2011 | Buick | Enclave - FWD | Engine Control Module | √ | √ | √ | √ | √ | |

| | | | | | | | | | |
|------|-------|---------------|--|---|---|---|---|---|--|
| 2011 | Buick | Enclave - FWD | Fuel Pump Control Module | √ | √ | √ | √ | √ | |
| 2011 | Buick | Enclave - FWD | Vehicle comm. interface module | √ | √ | √ | √ | √ | 0494 0495 |
| 2011 | Buick | Enclave - FWD | Digital radio receiver | √ | √ | √ | √ | √ | |
| 2011 | Buick | Enclave - FWD | Body Control Module | | | | | | 0499 0497 |
| 2011 | Buick | Enclave - FWD | Headlamp Control Module | √ | √ | √ | | | |
| 2011 | Buick | Enclave - FWD | Liftgate module | √ | √ | √ | √ | √ | |
| 2011 | Buick | Enclave - FWD | Personal audio link module | √ | √ | √ | | | 0528 0529 |
| 2011 | Buick | Enclave - FWD | Radio | √ | √ | √ | √ | √ | |
| 2011 | Buick | Enclave - FWD | Remote control door lock receiver | √ | √ | √ | √ | √ | 0513 0159 |
| 2011 | Buick | Enclave - FWD | Theft Deterrent Module | √ | √ | √ | √ | | |
| 2011 | Buick | Enclave - FWD | Instrument panel cluster | √ | √ | √ | √ | √ | |
| 2011 | Buick | Enclave - FWD | Memory seat module | √ | √ | √ | √ | √ | |
| 2011 | Buick | Enclave - FWD | Park assist module | √ | √ | √ | √ | | |
| 2011 | Buick | Enclave - FWD | Passenger presence system | √ | √ | √ | √ | √ | |
| 2011 | Buick | Enclave - FWD | Supplemental inflatable restraint | √ | √ | √ | √ | √ | 0497 |
| 2011 | Buick | Enclave - FWD | HVAC Control Module | √ | √ | √ | √ | √ | 0500 0526 |
| 2011 | Buick | Enclave - FWD | Driver door switch | √ | √ | √ | √ | √ | 0527 |
| 2011 | Buick | Enclave - FWD | Passenger door switch | √ | √ | √ | √ | √ | 0527 |
| 2011 | Buick | Enclave - FWD | Rear HVAC/RSA | √ | √ | √ | √ | √ | |
| 2011 | Buick | Enclave - FWD | Electronic Brake Control Module | √ | √ | √ | √ | √ | 0506 |
| 2011 | Buick | Enclave - FWD | Rear drive system | √ | √ | √ | √ | √ | 0530 |
| 2010 | Buick | Allure | Engine Control Module | √ | √ | √ | √ | √ | 0323 0308 0217 0309 |
| 2010 | Buick | Allure | Fuel Injector Control Module | √ | √ | √ | √ | √ | |
| 2010 | Buick | Allure | Fuel Pump Control Module | √ | √ | √ | √ | √ | 0217 |
| 2010 | Buick | Allure | Hybrid Powertrain Control Module | √ | √ | √ | √ | √ | 0263 |
| 2010 | Buick | Allure | Transmission Control Module | √ | √ | √ | √ | √ | 0016 |
| 2010 | Buick | Allure | Rear Differential Clutch Control Module | √ | √ | √ | √ | √ | |
| 2010 | Buick | Allure | Drive Motor Control Module | √ | √ | √ | √ | | |
| 2010 | Buick | Allure | Electronic Brake Control Module | √ | √ | √ | √ | √ | 0225 0090 0111 |
| 2010 | Buick | Allure | Parking Brake Control Module | √ | √ | √ | √ | √ | 0316 |
| 2010 | Buick | Allure | Multi-Axis Acceleration Sensor Module | √ | √ | √ | | | 0111 0111 |
| 2010 | Buick | Allure | Power Steering Control Module | √ | √ | √ | √ | | 0081 0081 0080 0080 |
| 2010 | Buick | Allure | Steering Wheel Angle Sensor Module | √ | √ | √ | | | 0093 0093 0090 0090 |
| 2010 | Buick | Allure | Suension Control Module | √ | √ | √ | √ | √ | |
| 2010 | Buick | Allure | Body Control Module | √ | √ | √ | √ | √ | 0243 0263 0203 0201 0208 0206 0297 0298 |
| 2010 | Buick | Allure | Inflatable Restraint Sensing and Diagnostic Module | √ | √ | √ | √ | √ | 0172 |
| 2010 | Buick | Allure | Passenger Presence Module | √ | √ | √ | √ | | 0322 |
| 2010 | Buick | Allure | Instrument Cluster | √ | √ | √ | √ | √ | 0301 |
| 2010 | Buick | Allure | Head-Up Dilay Module | √ | √ | √ | √ | √ | |
| 2010 | Buick | Allure | Headlamp Control Module | √ | √ | √ | √ | √ | |
| 2010 | Buick | Allure | Radio | √ | √ | √ | √ | √ | |

| | | | | | | | | | |
|------|-------|----------|--|---|---|---|---|---|--|
| 2010 | Buick | Allure | Digital Radio Receiver Control Module | √ | √ | √ | √ | √ | 0301 0301 |
| 2010 | Buick | Allure | Multimedia Player Interface Module | √ | √ | √ | √ | | |
| 2010 | Buick | Allure | Mobile Telephone Control Module | √ | √ | √ | √ | √ | 0301 0301 |
| 2010 | Buick | Allure | Telematics Communication Interface Control Module | √ | √ | √ | √ | √ | 0465 0259 |
| 2010 | Buick | Allure | Remote Heater and Air Conditioning Control Module | √ | √ | √ | √ | √ | 0311 0129 |
| 2010 | Buick | Allure | Seat Memory Control Module | √ | √ | √ | √ | √ | 0310 |
| 2010 | Buick | Allure | Front Seat Heating Control Module | √ | √ | √ | √ | √ | |
| 2010 | Buick | Allure | Rear Seat Heating Control Module | √ | √ | √ | √ | √ | |
| 2010 | Buick | Allure | Keyless Entry Control Module | √ | √ | √ | √ | √ | |
| 2010 | Buick | Allure | Parking Assist Control Module | √ | √ | √ | √ | √ | 0301 |
| 2010 | Buick | Allure | Vehicle Direction Camera Control Module | √ | √ | √ | √ | √ | 0205 0447 |
| 2010 | Buick | Allure | Steering Column Lock Control Module | √ | √ | √ | √ | | |
| 2010 | Buick | Allure | Battery Energy Control Module | √ | | | √ | | |
| 2010 | Buick | Allure | Left Side Object Detection Control Module | √ | √ | √ | √ | √ | |
| 2010 | Buick | Allure | Right Side Object Detection Control Module | √ | √ | √ | √ | √ | |
| 2010 | Buick | LaCrosse | Engine Control Module | √ | √ | √ | √ | √ | 0323 0308 0217 0309 |
| 2010 | Buick | LaCrosse | Fuel Injector Control Module | √ | √ | √ | √ | √ | |
| 2010 | Buick | LaCrosse | Fuel Pump Control Module | √ | √ | √ | √ | √ | 0217 |
| 2010 | Buick | LaCrosse | Hybrid Powertrain Control Module | √ | √ | √ | √ | √ | 0263 |
| 2010 | Buick | LaCrosse | Transmission Control Module | √ | √ | √ | √ | √ | 0016 |
| 2010 | Buick | LaCrosse | Rear Differential Clutch Control Module | √ | √ | √ | √ | √ | |
| 2010 | Buick | LaCrosse | Drive Motor Control Module | √ | √ | √ | √ | | |
| 2010 | Buick | LaCrosse | Electronic Brake Control Module | √ | √ | √ | √ | √ | 0225 0090 0111 |
| 2010 | Buick | LaCrosse | Parking Brake Control Module | √ | √ | √ | √ | √ | 0316 |
| 2010 | Buick | LaCrosse | Multi-Axis Acceleration Sensor Module | √ | √ | √ | | | 0111 0111 |
| 2010 | Buick | LaCrosse | Power Steering Control Module | √ | √ | √ | √ | | 0081 0081 0080 0080 |
| 2010 | Buick | LaCrosse | Steering Wheel Angle Sensor Module | √ | √ | √ | | | 0093 0093 0090 0090 |
| 2010 | Buick | LaCrosse | Suension Control Module | √ | √ | √ | √ | √ | |
| 2010 | Buick | LaCrosse | Body Control Module | √ | √ | √ | √ | √ | 0243 0263 0203 0201 0208 0206 0297 0298 |
| 2010 | Buick | LaCrosse | Inflatable Restraint Sensing and Diagnostic Module | √ | √ | √ | √ | √ | 0172 |
| 2010 | Buick | LaCrosse | Passenger Presence Module | √ | √ | √ | √ | | 0322 |
| 2010 | Buick | LaCrosse | Instrument Cluster | √ | √ | √ | √ | √ | 0301 |
| 2010 | Buick | LaCrosse | Head-Up Dilay Module | √ | √ | √ | √ | √ | |
| 2010 | Buick | LaCrosse | Headlamp Control Module | √ | √ | √ | √ | √ | |
| 2010 | Buick | LaCrosse | Radio | √ | √ | √ | √ | √ | |
| 2010 | Buick | LaCrosse | Digital Radio Receiver Control Module | √ | √ | √ | √ | √ | 0301 0301 |
| 2010 | Buick | LaCrosse | Multimedia Player Interface Module | √ | √ | √ | √ | | |
| 2010 | Buick | LaCrosse | Mobile Telephone Control Module | √ | √ | √ | √ | √ | 0301 0301 |
| 2010 | Buick | LaCrosse | Telematics Communication Interface Control Module | √ | √ | √ | √ | √ | 0465 0259 |
| 2010 | Buick | LaCrosse | Remote Heater and Air Conditioning Control Module | √ | √ | √ | √ | √ | 0311 0129 |
| 2010 | Buick | LaCrosse | Seat Memory Control Module | √ | √ | √ | √ | √ | 0310 |

| | | | | | | | | | |
|------|-------|---------------|--|---|---|---|---|---|----------------|
| 2010 | Buick | LaCrosse | Front Seat Heating Control Module | √ | √ | √ | √ | √ | |
| 2010 | Buick | LaCrosse | Rear Seat Heating Control Module | √ | √ | √ | √ | √ | |
| 2010 | Buick | LaCrosse | Keyless Entry Control Module | √ | √ | √ | √ | √ | |
| 2010 | Buick | LaCrosse | Parking Assist Control Module | √ | √ | √ | √ | √ | 0301 |
| 2010 | Buick | LaCrosse | Vehicle Direction Camera Control Module | √ | √ | √ | √ | √ | 0205 0447 |
| 2010 | Buick | LaCrosse | Steering Column Lock Control Module | √ | √ | √ | √ | √ | |
| 2010 | Buick | LaCrosse | Battery Energy Control Module | √ | | | √ | | |
| 2010 | Buick | LaCrosse | Left Side Object Detection Control Module | √ | √ | √ | √ | √ | |
| 2010 | Buick | LaCrosse | Right Side Object Detection Control Module | √ | √ | √ | √ | √ | |
| 2010 | Buick | Lucerne | Transmission control module | | √ | √ | √ | √ | |
| 2010 | Buick | Lucerne | Engine Control Module | √ | √ | √ | √ | √ | 0493 |
| 2010 | Buick | Lucerne | Digital radio receiver | √ | √ | √ | √ | √ | |
| 2010 | Buick | Lucerne | Radio | √ | √ | √ | √ | √ | |
| 2010 | Buick | Lucerne | Vehicle comm. interface module | √ | √ | √ | √ | √ | 0494 0495 0496 |
| 2010 | Buick | Lucerne | Remote control door lock receiver | √ | √ | √ | √ | √ | 0513 0159 |
| 2010 | Buick | Lucerne | Veh direction alert alarm warn mod | √ | √ | √ | √ | √ | |
| 2010 | Buick | Lucerne | Passenger presence system | √ | √ | √ | √ | √ | 0512 |
| 2010 | Buick | Lucerne | Supplemental inflatable restraint | √ | √ | √ | √ | √ | 0497 |
| 2010 | Buick | Lucerne | Left side object detection module | √ | √ | √ | √ | √ | |
| 2010 | Buick | Lucerne | Memory seat module | √ | √ | √ | √ | √ | |
| 2010 | Buick | Lucerne | Park assist module | √ | √ | √ | √ | √ | |
| 2010 | Buick | Lucerne | Right side object detection module | √ | √ | √ | √ | √ | |
| 2010 | Buick | Lucerne | Theft Deterrent Module | √ | √ | √ | √ | √ | |
| 2010 | Buick | Lucerne | Instrument panel cluster | √ | √ | √ | √ | √ | |
| 2010 | Buick | Lucerne | HVAC Control Module | √ | √ | √ | √ | √ | |
| 2010 | Buick | Lucerne | Driver door switch | √ | √ | √ | √ | √ | |
| 2010 | Buick | Lucerne | Passenger door switch | √ | √ | √ | √ | √ | |
| 2010 | Buick | Lucerne | Body Control Module | √ | √ | √ | √ | √ | 0499 0497 |
| 2010 | Buick | Lucerne | Electronic Brake Control Module | √ | √ | √ | √ | √ | 0506 |
| 2010 | Buick | Lucerne | Electronic suspension control | √ | √ | √ | √ | √ | |
| 2010 | Buick | Enclave - AWD | Transmission control module | | √ | √ | √ | √ | |
| 2010 | Buick | Enclave - AWD | Fuel Pump Control Module | √ | √ | √ | √ | √ | |
| 2010 | Buick | Enclave - AWD | Engine Control Module | √ | √ | √ | √ | √ | |
| 2010 | Buick | Enclave - AWD | Digital radio receiver | √ | √ | √ | √ | √ | |
| 2010 | Buick | Enclave - AWD | Radio | √ | √ | √ | √ | √ | |
| 2010 | Buick | Enclave - AWD | Rear HVAC/RSA | √ | √ | √ | √ | √ | |
| 2010 | Buick | Enclave - AWD | Vehicle comm. interface module | √ | √ | √ | √ | √ | 0494 0495 |
| 2010 | Buick | Enclave - AWD | Headlamp Control Module | √ | √ | √ | | | |
| 2010 | Buick | Enclave - AWD | Personal audio link module | √ | √ | √ | | | 0528 0529 |
| 2010 | Buick | Enclave - AWD | Remote control door lock receiver | √ | √ | √ | √ | √ | 0513 0159 |
| 2010 | Buick | Enclave - AWD | Passenger presence system | √ | √ | √ | √ | √ | |
| 2010 | Buick | Enclave - AWD | Supplemental inflatable restraint | √ | √ | √ | √ | √ | 0497 |

| | | | | | | | | | |
|------|-------|---------------|-----------------------------------|---|---|---|---|---|--|
| 2010 | Buick | Enclave - AWD | Memory seat module | √ | √ | √ | √ | √ | |
| 2010 | Buick | Enclave - AWD | Park assist module | √ | √ | √ | √ | | |
| 2010 | Buick | Enclave - AWD | Theft Deterrent Module | √ | √ | √ | √ | | |
| 2010 | Buick | Enclave - AWD | Instrument panel cluster | √ | √ | √ | √ | √ | |
| 2010 | Buick | Enclave - AWD | HVAC Control Module | √ | √ | √ | √ | √ | 0500 0526 |
| 2010 | Buick | Enclave - AWD | Driver door switch | √ | √ | √ | √ | √ | 0527 |
| 2010 | Buick | Enclave - AWD | Passenger door switch | √ | √ | √ | √ | √ | 0527 |
| 2010 | Buick | Enclave - AWD | Body Control Module | √ | √ | √ | √ | √ | 0499 0497 |
| 2010 | Buick | Enclave - AWD | Liftgate module | √ | √ | √ | √ | √ | |
| 2010 | Buick | Enclave - AWD | Electronic Brake Control Module | √ | √ | √ | √ | √ | 0506 |
| 2010 | Buick | Enclave - AWD | Rear drive system | √ | √ | √ | √ | √ | 0530 |
| 2010 | Buick | Enclave - FWD | Transmission control module | | √ | √ | √ | √ | |
| 2010 | Buick | Enclave - FWD | Fuel Pump Control Module | √ | √ | √ | √ | √ | |
| 2010 | Buick | Enclave - FWD | Engine Control Module | √ | √ | √ | √ | √ | |
| 2010 | Buick | Enclave - FWD | Digital radio receiver | √ | √ | √ | √ | √ | |
| 2010 | Buick | Enclave - FWD | Radio | √ | √ | √ | √ | √ | |
| 2010 | Buick | Enclave - FWD | Rear HVAC/RSA | √ | √ | √ | √ | √ | |
| 2010 | Buick | Enclave - FWD | Vehicle comm. interface module | √ | √ | √ | √ | √ | 0494 0495 |
| 2010 | Buick | Enclave - FWD | Headlamp Control Module | √ | √ | √ | | | |
| 2010 | Buick | Enclave - FWD | Personal audio link module | √ | √ | √ | | | 0528 0529 |
| 2010 | Buick | Enclave - FWD | Remote control door lock receiver | √ | √ | √ | √ | √ | 0513 0159 |
| 2010 | Buick | Enclave - FWD | Passenger presence system | √ | √ | √ | √ | √ | |
| 2010 | Buick | Enclave - FWD | Supplemental inflatable restraint | √ | √ | √ | √ | √ | 0497 |
| 2010 | Buick | Enclave - FWD | Memory seat module | √ | √ | √ | √ | √ | |
| 2010 | Buick | Enclave - FWD | Park assist module | √ | √ | √ | √ | | |
| 2010 | Buick | Enclave - FWD | Theft Deterrent Module | √ | √ | √ | √ | | |
| 2010 | Buick | Enclave - FWD | Instrument panel cluster | √ | √ | √ | √ | √ | |
| 2010 | Buick | Enclave - FWD | HVAC Control Module | √ | √ | √ | √ | √ | 0500 0526 |
| 2010 | Buick | Enclave - FWD | Driver door switch | √ | √ | √ | √ | √ | 0527 |
| 2010 | Buick | Enclave - FWD | Passenger door switch | √ | √ | √ | √ | √ | 0527 |
| 2010 | Buick | Enclave - FWD | Body Control Module | √ | √ | √ | √ | √ | 0499 0497 |
| 2010 | Buick | Enclave - FWD | Liftgate module | √ | √ | √ | √ | √ | |
| 2010 | Buick | Enclave - FWD | Electronic Brake Control Module | √ | √ | √ | √ | √ | 0506 |
| 2010 | Buick | Enclave - FWD | Rear drive system | √ | √ | √ | √ | √ | 0530 |
| 2009 | Buick | LaCrosse | Powertrain control module | √ | √ | √ | √ | √ | 0493 |
| 2009 | Buick | LaCrosse | Transmission control module | | √ | √ | √ | √ | |
| 2009 | Buick | LaCrosse | Engine Control Module | √ | √ | √ | √ | √ | 0493 |
| 2009 | Buick | LaCrosse | Remote control door lock receiver | √ | √ | √ | √ | √ | 0159 |
| 2009 | Buick | LaCrosse | Supplemental inflatable restraint | √ | √ | √ | √ | √ | 0515 |
| 2009 | Buick | LaCrosse | Radio | √ | √ | √ | √ | √ | 0573 0574 0575 0576 0577 0578 0579 0552 |
| 2009 | Buick | LaCrosse | Vehicle comm. interface module | √ | √ | √ | √ | √ | 0565 0495 |

| | | | | | | | | | |
|------|-------|-----------------------------|------------------------------------|---|---|---|---|---|--|
| 2009 | Buick | LaCrosse | Digital radio receiver | √ | √ | √ | √ | √ | 0516 |
| 2009 | Buick | LaCrosse | Body Control Module | √ | √ | √ | √ | √ | 0499 |
| 2009 | Buick | LaCrosse | HVAC Control Module | √ | √ | √ | √ | √ | 0500 |
| 2009 | Buick | LaCrosse | Instrument panel cluster | √ | √ | √ | √ | √ | 0159 |
| 2009 | Buick | LaCrosse | Electronic Brake Control Module | | √ | √ | √ | √ | 0506 |
| 2009 | Buick | LaCrosse (Allure in Canada) | Powertrain control module | √ | √ | √ | √ | √ | 0493 |
| 2009 | Buick | LaCrosse (Allure in Canada) | Transmission control module | | √ | √ | √ | √ | |
| 2009 | Buick | LaCrosse (Allure in Canada) | Engine Control Module | √ | √ | √ | √ | √ | 0493 |
| 2009 | Buick | LaCrosse (Allure in Canada) | Remote control door lock receiver | √ | √ | √ | √ | √ | 0159 |
| 2009 | Buick | LaCrosse (Allure in Canada) | Supplemental inflatable restraint | √ | √ | √ | √ | √ | 0515 |
| 2009 | Buick | LaCrosse (Allure in Canada) | Radio | √ | √ | √ | √ | √ | 0573 0574 0575 0576 0577 0578 0579 0552 |
| 2009 | Buick | LaCrosse (Allure in Canada) | Vehicle comm. interface module | √ | √ | √ | √ | √ | 0565 0495 |
| 2009 | Buick | LaCrosse (Allure in Canada) | Digital radio receiver | √ | √ | √ | √ | √ | 0516 |
| 2009 | Buick | LaCrosse (Allure in Canada) | Body Control Module | √ | √ | √ | √ | √ | 0499 |
| 2009 | Buick | LaCrosse (Allure in Canada) | HVAC Control Module | √ | √ | √ | √ | √ | 0500 |
| 2009 | Buick | LaCrosse (Allure in Canada) | Instrument panel cluster | √ | √ | √ | √ | √ | 0159 |
| 2009 | Buick | LaCrosse (Allure in Canada) | Electronic Brake Control Module | | √ | √ | √ | √ | 0506 |
| 2009 | Buick | Lucerne | Transmission control module | | √ | √ | √ | √ | |
| 2009 | Buick | Lucerne | Engine Control Module | √ | √ | √ | √ | √ | 0493 |
| 2009 | Buick | Lucerne | Passenger presence system | √ | √ | √ | √ | | 0512 |
| 2009 | Buick | Lucerne | Remote control door lock receiver | √ | √ | √ | √ | √ | 0513 0159 |
| 2009 | Buick | Lucerne | Supplemental inflatable restraint | √ | √ | √ | √ | √ | 0497 |
| 2009 | Buick | Lucerne | Theft Deterrent Module | √ | √ | √ | √ | | |
| 2009 | Buick | Lucerne | Radio | √ | √ | √ | √ | √ | |
| 2009 | Buick | Lucerne | Digital radio receiver | √ | √ | √ | √ | √ | |
| 2009 | Buick | Lucerne | Vehicle comm. interface module | √ | √ | √ | √ | √ | 0494 0495 0496 |
| 2009 | Buick | Lucerne | Veh direction alert alarm warn mod | √ | √ | √ | √ | √ | |
| 2009 | Buick | Lucerne | Left side object detection module | √ | √ | √ | √ | √ | |
| 2009 | Buick | Lucerne | Memory seat module | √ | √ | √ | √ | √ | |
| 2009 | Buick | Lucerne | Park assist module | √ | √ | √ | √ | √ | |
| 2009 | Buick | Lucerne | Right side object detection module | √ | √ | √ | √ | | |
| 2009 | Buick | Lucerne | Instrument panel cluster | √ | √ | √ | √ | √ | |
| 2009 | Buick | Lucerne | HVAC Control Module | √ | √ | √ | √ | √ | |
| 2009 | Buick | Lucerne | Driver door switch | √ | √ | √ | √ | √ | |
| 2009 | Buick | Lucerne | Passenger door switch | √ | √ | √ | √ | √ | |
| 2009 | Buick | Lucerne | Body Control Module | √ | √ | √ | √ | √ | 0499 0497 |
| 2009 | Buick | Lucerne | Electronic Brake Control Module | √ | √ | √ | √ | √ | 0506 |
| 2009 | Buick | Lucerne | Electronic suspension control | √ | √ | √ | √ | √ | |
| 2009 | Buick | Others | Immobilizer | | | | | | 0508 |
| 2009 | Buick | Others | Engine Control Module | √ | √ | √ | √ | √ | |
| 2009 | Buick | Others | Transmission control module | √ | √ | √ | √ | √ | |

| | | | | | | | | | |
|------|-------|---------------|-----------------------------------|---|---|---|---|---|-----------|
| 2009 | Buick | Enclave - AWD | Transmission control module | | √ | √ | √ | √ | |
| 2009 | Buick | Enclave - AWD | Engine Control Module | √ | √ | √ | √ | √ | |
| 2009 | Buick | Enclave - AWD | Passenger presence system | √ | √ | √ | √ | √ | |
| 2009 | Buick | Enclave - AWD | Remote control door lock receiver | √ | √ | √ | √ | √ | 0513 0159 |
| 2009 | Buick | Enclave - AWD | Rollover sensor | √ | √ | √ | √ | √ | 0541 |
| 2009 | Buick | Enclave - AWD | Supplemental inflatable restraint | √ | √ | √ | √ | √ | 0497 |
| 2009 | Buick | Enclave - AWD | Theft Deterrent Module | √ | √ | √ | √ | √ | |
| 2009 | Buick | Enclave - AWD | Personal audio link module | √ | √ | √ | | | 0528 0529 |
| 2009 | Buick | Enclave - AWD | Radio | √ | √ | √ | √ | √ | |
| 2009 | Buick | Enclave - AWD | Digital radio receiver | √ | √ | √ | √ | √ | |
| 2009 | Buick | Enclave - AWD | Headlamp Control Module | √ | √ | √ | | | |
| 2009 | Buick | Enclave - AWD | Rear HVAC/RSA | √ | √ | √ | √ | √ | |
| 2009 | Buick | Enclave - AWD | Vehicle comm. interface module | √ | √ | √ | √ | √ | 0494 0495 |
| 2009 | Buick | Enclave - AWD | Memory seat module | √ | √ | √ | √ | √ | |
| 2009 | Buick | Enclave - AWD | Park assist module | √ | √ | √ | √ | √ | |
| 2009 | Buick | Enclave - AWD | Liftgate module | √ | √ | √ | √ | √ | |
| 2009 | Buick | Enclave - AWD | Instrument panel cluster | √ | √ | √ | √ | √ | |
| 2009 | Buick | Enclave - AWD | HVAC Control Module | √ | √ | √ | √ | √ | 0500 0526 |
| 2009 | Buick | Enclave - AWD | Body Control Module | √ | √ | √ | √ | √ | 0499 0497 |
| 2009 | Buick | Enclave - AWD | Driver door switch | √ | √ | √ | √ | √ | 0527 |
| 2009 | Buick | Enclave - AWD | Passenger door switch | √ | √ | √ | √ | √ | 0527 |
| 2009 | Buick | Enclave - AWD | Electronic Brake Control Module | √ | √ | √ | √ | √ | 0506 |
| 2009 | Buick | Enclave - AWD | Rear drive system | √ | √ | √ | √ | √ | 0530 |
| 2009 | Buick | Enclave - FWD | Transmission control module | | √ | √ | √ | √ | |
| 2009 | Buick | Enclave - FWD | Engine Control Module | √ | √ | √ | √ | √ | |
| 2009 | Buick | Enclave - FWD | Passenger presence system | √ | √ | √ | √ | √ | |
| 2009 | Buick | Enclave - FWD | Remote control door lock receiver | √ | √ | √ | √ | √ | 0513 0159 |
| 2009 | Buick | Enclave - FWD | Rollover sensor | √ | √ | √ | √ | √ | 0541 |
| 2009 | Buick | Enclave - FWD | Supplemental inflatable restraint | √ | √ | √ | √ | √ | 0497 |
| 2009 | Buick | Enclave - FWD | Theft Deterrent Module | √ | √ | √ | √ | √ | |
| 2009 | Buick | Enclave - FWD | Personal audio link module | √ | √ | √ | | | 0528 0529 |
| 2009 | Buick | Enclave - FWD | Radio | √ | √ | √ | √ | √ | |
| 2009 | Buick | Enclave - FWD | Digital radio receiver | √ | √ | √ | √ | √ | |
| 2009 | Buick | Enclave - FWD | Headlamp Control Module | √ | √ | √ | | | |
| 2009 | Buick | Enclave - FWD | Rear HVAC/RSA | √ | √ | √ | √ | √ | |
| 2009 | Buick | Enclave - FWD | Vehicle comm. interface module | √ | √ | √ | √ | √ | 0494 0495 |
| 2009 | Buick | Enclave - FWD | Memory seat module | √ | √ | √ | √ | √ | |
| 2009 | Buick | Enclave - FWD | Park assist module | √ | √ | √ | √ | √ | |
| 2009 | Buick | Enclave - FWD | Liftgate module | √ | √ | √ | √ | √ | |
| 2009 | Buick | Enclave - FWD | Instrument panel cluster | √ | √ | √ | √ | √ | |
| 2009 | Buick | Enclave - FWD | HVAC Control Module | √ | √ | √ | √ | √ | 0500 0526 |
| 2009 | Buick | Enclave - FWD | Body Control Module | √ | √ | √ | √ | √ | 0499 0497 |

| | | | | | | | | | |
|------|-------|-----------------------------|------------------------------------|---|---|---|---|---|--|
| 2009 | Buick | Enclave - FWD | Driver door switch | √ | √ | √ | √ | √ | 0527 |
| 2009 | Buick | Enclave - FWD | Passenger door switch | √ | √ | √ | √ | √ | 0527 |
| 2009 | Buick | Enclave - FWD | Electronic Brake Control Module | √ | √ | √ | √ | √ | 0506 |
| 2009 | Buick | Enclave - FWD | Rear drive system | √ | √ | √ | √ | √ | 0530 |
| 2008 | Buick | LaCrosse | Powertrain control module | √ | √ | √ | √ | √ | 0493 |
| 2008 | Buick | LaCrosse | Engine Control Module | √ | √ | √ | √ | √ | |
| 2008 | Buick | LaCrosse | Transmission control module | √ | √ | √ | √ | √ | 0493 |
| 2008 | Buick | LaCrosse | Remote control door lock receiver | √ | √ | √ | √ | √ | 0159 |
| 2008 | Buick | LaCrosse | Supplemental inflatable restraint | √ | √ | √ | √ | √ | 0515 |
| 2008 | Buick | LaCrosse | Body Control Module | √ | √ | √ | √ | √ | 0499 |
| 2008 | Buick | LaCrosse | Radio | √ | √ | √ | √ | √ | 0573 0574 0575 0576 0577 0578 0579 0552 |
| 2008 | Buick | LaCrosse | Digital radio receiver | √ | √ | √ | √ | | 0516 |
| 2008 | Buick | LaCrosse | Vehicle comm. interface module | √ | √ | √ | √ | √ | 0565 0495 0585 |
| 2008 | Buick | LaCrosse | HVAC Control Module | √ | √ | √ | √ | √ | 0500 |
| 2008 | Buick | LaCrosse | Instrument panel cluster | √ | √ | √ | √ | √ | 0159 |
| 2008 | Buick | LaCrosse | Electronic Brake Control Module | √ | √ | √ | √ | √ | 0506 |
| 2008 | Buick | LaCrosse (Allure in Canada) | Powertrain control module | √ | √ | √ | √ | √ | 0493 |
| 2008 | Buick | LaCrosse (Allure in Canada) | Engine Control Module | √ | √ | √ | √ | √ | |
| 2008 | Buick | LaCrosse (Allure in Canada) | Transmission control module | √ | √ | √ | √ | √ | 0493 |
| 2008 | Buick | LaCrosse (Allure in Canada) | Remote control door lock receiver | √ | √ | √ | √ | √ | 0159 |
| 2008 | Buick | LaCrosse (Allure in Canada) | Supplemental inflatable restraint | √ | √ | √ | √ | √ | 0515 |
| 2008 | Buick | LaCrosse (Allure in Canada) | Body Control Module | √ | √ | √ | √ | √ | 0499 |
| 2008 | Buick | LaCrosse (Allure in Canada) | Radio | √ | √ | √ | √ | √ | 0573 0574 0575 0576 0577 0578 0579 0552 |
| 2008 | Buick | LaCrosse (Allure in Canada) | Digital radio receiver | √ | √ | √ | √ | | 0516 |
| 2008 | Buick | LaCrosse (Allure in Canada) | Vehicle comm. interface module | √ | √ | √ | √ | √ | 0565 0495 0585 |
| 2008 | Buick | LaCrosse (Allure in Canada) | HVAC Control Module | √ | √ | √ | √ | √ | 0500 |
| 2008 | Buick | LaCrosse (Allure in Canada) | Instrument panel cluster | √ | √ | √ | √ | √ | 0159 |
| 2008 | Buick | LaCrosse (Allure in Canada) | Electronic Brake Control Module | √ | √ | √ | √ | √ | 0506 |
| 2008 | Buick | Lucerne | Powertrain control module | √ | √ | √ | √ | √ | 0493 |
| 2008 | Buick | Lucerne | Engine Control Module | √ | √ | √ | √ | √ | 0493 |
| 2008 | Buick | Lucerne | Transmission control module | √ | √ | √ | √ | √ | 0493 |
| 2008 | Buick | Lucerne | Passenger presence system | √ | √ | √ | √ | | 0512 |
| 2008 | Buick | Lucerne | Remote control door lock receiver | √ | √ | √ | √ | √ | 0513 0159 |
| 2008 | Buick | Lucerne | Supplemental inflatable restraint | √ | √ | √ | √ | √ | 0497 |
| 2008 | Buick | Lucerne | Theft Deterrent Module | √ | √ | √ | √ | | |
| 2008 | Buick | Lucerne | Radio | √ | √ | √ | √ | √ | |
| 2008 | Buick | Lucerne | Veh direction alert alarm warn mod | √ | √ | √ | √ | √ | |
| 2008 | Buick | Lucerne | Digital radio receiver | √ | √ | √ | √ | | |
| 2008 | Buick | Lucerne | Vehicle comm. interface module | √ | √ | √ | √ | √ | 0494 0591 0565 0495 |
| 2008 | Buick | Lucerne | HVAC Control Module | √ | √ | √ | √ | √ | |

| | | | | | | | | | |
|------|-------|---------------|------------------------------------|---|---|---|---|---|---------------------|
| 2008 | Buick | Lucerne | Body Control Module | √ | √ | √ | √ | √ | 0499 0497 |
| 2008 | Buick | Lucerne | Left side object detection module | √ | √ | √ | √ | √ | |
| 2008 | Buick | Lucerne | Right side object detection module | √ | √ | √ | √ | √ | |
| 2008 | Buick | Lucerne | Memory seat module | √ | √ | √ | √ | √ | |
| 2008 | Buick | Lucerne | Park assist module | √ | √ | √ | √ | √ | |
| 2008 | Buick | Lucerne | Instrument panel cluster | √ | √ | √ | √ | √ | |
| 2008 | Buick | Lucerne | Driver door switch | √ | √ | √ | √ | √ | |
| 2008 | Buick | Lucerne | Passenger door switch | √ | √ | √ | √ | √ | 0512 |
| 2008 | Buick | Lucerne | Electronic Brake Control Module | √ | √ | √ | √ | √ | 0506 |
| 2008 | Buick | Lucerne | Electronic suspension control | √ | √ | √ | √ | √ | |
| 2008 | Buick | Others | Immobilizer | | | | | | 0508 |
| 2008 | Buick | Others | Engine Control Module | √ | √ | √ | √ | √ | 0507 |
| 2008 | Buick | Others | Transmission control module | √ | √ | √ | √ | √ | 0493 |
| 2008 | Buick | Enclave - AWD | Engine Control Module | √ | √ | √ | √ | √ | 0493 |
| 2008 | Buick | Enclave - AWD | Transmission control module | | √ | √ | √ | √ | |
| 2008 | Buick | Enclave - AWD | Passenger presence system | √ | √ | √ | √ | | 0537 |
| 2008 | Buick | Enclave - AWD | Remote control door lock receiver | √ | √ | √ | √ | √ | 0513 0159 |
| 2008 | Buick | Enclave - AWD | Rollover sensor | √ | √ | √ | √ | | 0541 |
| 2008 | Buick | Enclave - AWD | Supplemental inflatable restraint | √ | √ | √ | √ | √ | 0497 |
| 2008 | Buick | Enclave - AWD | Theft Deterrent Module | √ | √ | √ | √ | | |
| 2008 | Buick | Enclave - AWD | Memory seat module | √ | √ | √ | √ | √ | |
| 2008 | Buick | Enclave - AWD | Park assist module | √ | √ | √ | √ | √ | |
| 2008 | Buick | Enclave - AWD | HVAC Control Module | √ | √ | √ | √ | √ | 0500 0526 |
| 2008 | Buick | Enclave - AWD | Digital radio receiver | √ | √ | √ | √ | | |
| 2008 | Buick | Enclave - AWD | Radio | √ | √ | √ | √ | √ | |
| 2008 | Buick | Enclave - AWD | Vehicle comm. interface module | √ | √ | √ | √ | √ | 0494 0591 0565 0495 |
| 2008 | Buick | Enclave - AWD | Body Control Module | | | | | | 0499 0497 |
| 2008 | Buick | Enclave - AWD | Rear HVAC/RSA | √ | √ | √ | √ | √ | |
| 2008 | Buick | Enclave - AWD | Personal audio link module | √ | √ | √ | | | 0528 0529 |
| 2008 | Buick | Enclave - AWD | Driver door switch | √ | √ | √ | √ | √ | 0527 |
| 2008 | Buick | Enclave - AWD | Passenger door switch | √ | √ | √ | √ | √ | 0527 |
| 2008 | Buick | Enclave - AWD | Instrument panel cluster | | | | | √ | |
| 2008 | Buick | Enclave - AWD | Headlamp Control Module | √ | √ | √ | √ | √ | |
| 2008 | Buick | Enclave - AWD | Liftgate module | √ | √ | √ | √ | √ | |
| 2008 | Buick | Enclave - AWD | Electronic Brake Control Module | √ | √ | √ | √ | √ | 0506 |
| 2008 | Buick | Enclave - AWD | Rear drive system | √ | √ | √ | √ | √ | 0530 |
| 2008 | Buick | Enclave - FWD | Engine Control Module | √ | √ | √ | √ | √ | 0493 |
| 2008 | Buick | Enclave - FWD | Rear drive system | √ | √ | √ | √ | √ | 0530 |
| 2008 | Buick | Enclave - FWD | Passenger presence system | √ | √ | √ | √ | | 0537 |
| 2008 | Buick | Enclave - FWD | Remote control door lock receiver | √ | √ | √ | √ | √ | 0513 0159 |
| 2008 | Buick | Enclave - FWD | Rollover sensor | √ | √ | √ | √ | | 0541 |
| 2008 | Buick | Enclave - FWD | Supplemental inflatable restraint | √ | √ | √ | √ | √ | 0497 |

| | | | | | | | | | |
|------|-------|-----------------------------|-----------------------------------|---|---|---|---|---|--|
| 2008 | Buick | Enclave - FWD | Theft Deterrent Module | √ | √ | √ | √ | | |
| 2008 | Buick | Enclave - FWD | Memory seat module | √ | √ | √ | √ | √ | |
| 2008 | Buick | Enclave - FWD | Park assist module | √ | √ | √ | √ | √ | |
| 2008 | Buick | Enclave - FWD | HVAC Control Module | √ | √ | √ | √ | √ | 0500 0526 |
| 2008 | Buick | Enclave - FWD | Digital radio receiver | √ | √ | √ | √ | √ | |
| 2008 | Buick | Enclave - FWD | Radio | √ | √ | √ | √ | √ | |
| 2008 | Buick | Enclave - FWD | Vehicle comm. interface module | √ | √ | √ | √ | √ | 0494 0591 0565 0495 |
| 2008 | Buick | Enclave - FWD | Body Control Module | | | | | | 0499 0497 |
| 2008 | Buick | Enclave - FWD | Rear HVAC/RSA | √ | √ | √ | √ | √ | |
| 2008 | Buick | Enclave - FWD | Personal audio link module | √ | √ | √ | | | 0528 0529 |
| 2008 | Buick | Enclave - FWD | Driver door switch | √ | √ | √ | √ | √ | 0527 |
| 2008 | Buick | Enclave - FWD | Passenger door switch | √ | √ | √ | √ | √ | 0527 |
| 2008 | Buick | Enclave - FWD | Instrument panel cluster | | | | | √ | |
| 2008 | Buick | Enclave - FWD | Headlamp Control Module | √ | √ | √ | √ | √ | |
| 2008 | Buick | Enclave - FWD | Liftgate module | √ | √ | √ | √ | √ | |
| 2008 | Buick | Enclave - FWD | Electronic Brake Control Module | √ | √ | √ | √ | √ | 0506 |
| 2007 | Buick | LaCrosse | Powertrain control module | √ | √ | √ | √ | √ | |
| 2007 | Buick | LaCrosse | Transmission control module | | √ | √ | √ | √ | |
| 2007 | Buick | LaCrosse | Engine Control Module | √ | √ | √ | √ | √ | |
| 2007 | Buick | LaCrosse | Remote control door lock receiver | √ | √ | √ | √ | √ | 0159 |
| 2007 | Buick | LaCrosse | Supplemental inflatable restraint | √ | √ | √ | √ | √ | 0515 |
| 2007 | Buick | LaCrosse | Digital radio receiver | √ | √ | √ | √ | | 0516 |
| 2007 | Buick | LaCrosse | Body Control Module | √ | √ | √ | √ | √ | 0499 |
| 2007 | Buick | LaCrosse | Instrument panel cluster | √ | √ | √ | √ | √ | |
| 2007 | Buick | LaCrosse | HVAC Control Module | √ | √ | √ | √ | √ | 0500 |
| 2007 | Buick | LaCrosse | Radio | √ | √ | √ | √ | √ | 0573 0574 0575 0576 0577 0578 0579 0552 |
| 2007 | Buick | LaCrosse | Vehicle comm. interface module | √ | √ | √ | √ | √ | 0494 0591 0565 0495 |
| 2007 | Buick | LaCrosse | Electronic Brake Control Module | | | | √ | | 0506 |
| 2007 | Buick | LaCrosse (Allure in Canada) | Powertrain control module | √ | √ | √ | √ | √ | |
| 2007 | Buick | LaCrosse (Allure in Canada) | Transmission control module | | √ | √ | √ | √ | |
| 2007 | Buick | LaCrosse (Allure in Canada) | Engine Control Module | √ | √ | √ | √ | √ | |
| 2007 | Buick | LaCrosse (Allure in Canada) | Remote control door lock receiver | √ | √ | √ | √ | √ | 0159 |
| 2007 | Buick | LaCrosse (Allure in Canada) | Supplemental inflatable restraint | √ | √ | √ | √ | √ | 0515 |
| 2007 | Buick | LaCrosse (Allure in Canada) | Digital radio receiver | √ | √ | √ | √ | | 0516 |
| 2007 | Buick | LaCrosse (Allure in Canada) | Body Control Module | √ | √ | √ | √ | √ | 0499 |
| 2007 | Buick | LaCrosse (Allure in Canada) | Instrument panel cluster | √ | √ | √ | √ | √ | |
| 2007 | Buick | LaCrosse (Allure in Canada) | HVAC Control Module | √ | √ | √ | √ | √ | 0500 |
| 2007 | Buick | LaCrosse (Allure in Canada) | Radio | √ | √ | √ | √ | √ | 0573 0574 0575 0576 0577 0578 0579 0552 |
| 2007 | Buick | LaCrosse (Allure in Canada) | Vehicle comm. interface module | √ | √ | √ | √ | √ | 0494 0591 0565 0495 |
| 2007 | Buick | LaCrosse (Allure in Canada) | Electronic Brake Control Module | | | | √ | | 0506 |

| | | | | | | | | | |
|------|-------|------------------|-----------------------------------|---|---|---|---|---|---------------------|
| 2007 | Buick | Lucerne | Powertrain control module | √ | √ | √ | √ | √ | 0493 |
| 2007 | Buick | Lucerne | Transmission control module | | √ | √ | √ | √ | |
| 2007 | Buick | Lucerne | Engine Control Module | √ | √ | √ | √ | √ | 0493 |
| 2007 | Buick | Lucerne | Remote control door lock receiver | √ | √ | √ | √ | √ | 0513 0159 |
| 2007 | Buick | Lucerne | Supplemental inflatable restraint | √ | √ | √ | √ | √ | 0497 |
| 2007 | Buick | Lucerne | Theft Deterrent Module | √ | √ | √ | √ | | |
| 2007 | Buick | Lucerne | Passenger presence system | √ | √ | √ | √ | | 0512 |
| 2007 | Buick | Lucerne | Digital radio receiver | √ | √ | √ | √ | | |
| 2007 | Buick | Lucerne | Radio | √ | √ | √ | √ | √ | |
| 2007 | Buick | Lucerne | Body Control Module | √ | √ | √ | √ | √ | 0499 0497 |
| 2007 | Buick | Lucerne | Vehicle comm. interface module | √ | √ | √ | √ | √ | 0494 0591 0565 0495 |
| 2007 | Buick | Lucerne | HVAC Control Module | √ | √ | √ | √ | √ | |
| 2007 | Buick | Lucerne | Driver door switch | √ | √ | √ | √ | √ | |
| 2007 | Buick | Lucerne | Passenger door switch | √ | √ | √ | √ | √ | |
| 2007 | Buick | Lucerne | Instrument panel cluster | √ | √ | √ | √ | √ | |
| 2007 | Buick | Lucerne | Memory seat module | √ | √ | √ | √ | √ | |
| 2007 | Buick | Lucerne | Park assist module | √ | √ | √ | √ | √ | 0513 0159 |
| 2007 | Buick | Lucerne | Electronic Brake Control Module | √ | √ | √ | √ | √ | 0506 |
| 2007 | Buick | Lucerne | Electronic suspension control | √ | √ | √ | √ | √ | |
| 2007 | Buick | Rainier | Powertrain control module | | √ | √ | √ | √ | |
| 2007 | Buick | Rainier | Transmission control module | | √ | √ | √ | √ | |
| 2007 | Buick | Rainier | Engine Control Module | √ | √ | √ | √ | √ | 0493 |
| 2007 | Buick | Rainier | Supplemental inflatable restraint | √ | √ | √ | √ | √ | |
| 2007 | Buick | Rainier | Disc player and video delay | √ | √ | √ | | | |
| 2007 | Buick | Rainier | Radio | √ | √ | √ | √ | | |
| 2007 | Buick | Rainier | Rear seat audio | √ | √ | √ | √ | | |
| 2007 | Buick | Rainier | Digital radio receiver | √ | √ | √ | √ | | 0516 |
| 2007 | Buick | Rainier | Instrument panel cluster | √ | √ | √ | √ | √ | |
| 2007 | Buick | Rainier | Generator battery control module | √ | √ | √ | √ | √ | |
| 2007 | Buick | Rainier | Body Control Module | √ | √ | √ | √ | √ | 0550 |
| 2007 | Buick | Rainier | Driver door module | √ | √ | √ | √ | √ | |
| 2007 | Buick | Rainier | Driver seat module | √ | √ | √ | √ | √ | |
| 2007 | Buick | Rainier | HVAC Control Module | √ | √ | √ | √ | √ | |
| 2007 | Buick | Rainier | Passenger door module | √ | √ | √ | √ | √ | |
| 2007 | Buick | Rainier | Liftgate module | √ | √ | √ | √ | √ | 0159 |
| 2007 | Buick | Rainier | Vehicle comm. interface module | √ | √ | √ | √ | √ | 0494 0591 0565 0495 |
| 2007 | Buick | Rainier | Passenger presence system | √ | √ | √ | √ | √ | 0512 |
| 2007 | Buick | Rainier | Navigation radio | √ | √ | √ | √ | √ | 0525 |
| 2007 | Buick | Rainier | Electronic Brake Control Module | √ | √ | √ | √ | √ | |
| 2007 | Buick | Rainier | Transfer Case Control Module | √ | √ | √ | √ | √ | 0493 |
| 2007 | Buick | Rendezvous - FWD | Powertrain control module | √ | √ | √ | √ | √ | |
| 2007 | Buick | Rendezvous - FWD | Passenger presence system | | √ | √ | | | 0512 |

| | | | | | | | | | |
|------|-------|------------------|-----------------------------------|---|---|---|---|---|---------------------|
| 2007 | Buick | Rendezvous - FWD | Supplemental inflatable restraint | √ | √ | √ | √ | √ | 0515 |
| 2007 | Buick | Rendezvous - FWD | Theft Deterrent Module | √ | √ | √ | √ | | |
| 2007 | Buick | Rendezvous - FWD | Digital radio receiver | √ | √ | √ | √ | | 0516 |
| 2007 | Buick | Rendezvous - FWD | Disc player and video dilay | √ | √ | √ | | | |
| 2007 | Buick | Rendezvous - FWD | Radio | √ | √ | √ | √ | √ | 0573 0572 0574 0524 |
| 2007 | Buick | Rendezvous - FWD | HVAC Control Module | √ | √ | √ | √ | √ | |
| 2007 | Buick | Rendezvous - FWD | Instrument panel cluster | √ | √ | √ | √ | √ | |
| 2007 | Buick | Rendezvous - FWD | Body Control Module | √ | √ | √ | √ | √ | 0628 0637 0614 0515 |
| 2007 | Buick | Rendezvous - FWD | Head up dilay | √ | √ | √ | √ | | |
| 2007 | Buick | Rendezvous - FWD | Memory seat module | | √ | √ | √ | √ | |
| 2007 | Buick | Rendezvous - FWD | Vehicle comm. interface module | √ | √ | √ | √ | √ | 0494 0591 0565 0495 |
| 2007 | Buick | Rendezvous - FWD | Electronic Brake Control Module | | √ | √ | √ | √ | 0506 |
| 2007 | Buick | Terraza | Transmission control module | | √ | √ | √ | √ | |
| 2007 | Buick | Terraza | Engine Control Module | √ | √ | √ | √ | √ | 0493 |
| 2007 | Buick | Terraza | Supplemental inflatable restraint | √ | √ | √ | √ | √ | 0515 |
| 2007 | Buick | Terraza | Mobile digital media | | √ | √ | | | |
| 2007 | Buick | Terraza | Radio | √ | √ | √ | √ | √ | 0587 0524 0525 |
| 2007 | Buick | Terraza | Disc player and video dilay | √ | √ | √ | | | |
| 2007 | Buick | Terraza | Body Control Module | √ | √ | √ | √ | √ | 0499 |
| 2007 | Buick | Terraza | Left power sliding door module | √ | √ | √ | √ | √ | |
| 2007 | Buick | Terraza | Right power sliding door module | √ | √ | √ | √ | √ | |
| 2007 | Buick | Terraza | Memory seat module | √ | √ | √ | √ | √ | |
| 2007 | Buick | Terraza | HVAC Control Module | √ | √ | √ | √ | √ | |
| 2007 | Buick | Terraza | Vehicle comm. interface module | √ | √ | √ | √ | √ | 0494 0591 0565 0495 |
| 2007 | Buick | Terraza | Digital radio receiver | √ | √ | √ | √ | | 0516 |
| 2007 | Buick | Terraza | Passenger presence system | √ | √ | √ | √ | √ | 0512 |
| 2007 | Buick | Terraza | Navigation radio | √ | √ | √ | √ | √ | 0525 |
| 2007 | Buick | Terraza | Electronic Brake Control Module | | √ | √ | √ | √ | 0506 |
| 2007 | Buick | Terraza Ext. | Transmission control module | | √ | √ | √ | √ | |
| 2007 | Buick | Terraza Ext. | Engine Control Module | √ | √ | √ | √ | √ | 0493 |
| 2007 | Buick | Terraza Ext. | Supplemental inflatable restraint | √ | √ | √ | √ | √ | 0515 |
| 2007 | Buick | Terraza Ext. | Mobile digital media | | √ | √ | | | |
| 2007 | Buick | Terraza Ext. | Radio | √ | √ | √ | √ | √ | 0587 0524 0525 |
| 2007 | Buick | Terraza Ext. | Disc player and video dilay | √ | √ | √ | | | |
| 2007 | Buick | Terraza Ext. | Body Control Module | √ | √ | √ | √ | √ | 0499 |
| 2007 | Buick | Terraza Ext. | Left power sliding door module | √ | √ | √ | √ | √ | |
| 2007 | Buick | Terraza Ext. | Right power sliding door module | √ | √ | √ | √ | √ | |
| 2007 | Buick | Terraza Ext. | Memory seat module | √ | √ | √ | √ | √ | |
| 2007 | Buick | Terraza Ext. | HVAC Control Module | √ | √ | √ | √ | √ | |
| 2007 | Buick | Terraza Ext. | Vehicle comm. interface module | √ | √ | √ | √ | √ | 0494 0591 0565 0495 |
| 2007 | Buick | Terraza Ext. | Digital radio receiver | √ | √ | √ | √ | | 0516 |
| 2007 | Buick | Terraza Ext. | Passenger presence system | √ | √ | √ | √ | √ | 0512 |

| | | | | | | | | | |
|------|-------|-----------------------------|---------------------------------|---|---|---|---|---|---------------------|
| 2007 | Buick | Terraza Ext. | Navigation radio | √ | √ | √ | √ | √ | 0525 |
| 2007 | Buick | Terraza Ext. | Electronic Brake Control Module | | √ | √ | √ | √ | 0506 |
| 2006 | Buick | LaCrosse | HVAC systems - manual | √ | √ | √ | √ | √ | 0499 |
| 2006 | Buick | LaCrosse | HVAC systems - automatic | √ | √ | √ | √ | √ | 0500 |
| 2006 | Buick | LaCrosse | Antilock Braking System | √ | √ | √ | √ | √ | 0506 |
| 2006 | Buick | LaCrosse | Engine controls | | √ | √ | √ | √ | |
| 2006 | Buick | LaCrosse | Engine cooling | | √ | √ | √ | √ | |
| 2006 | Buick | LaCrosse | Engine electrical | √ | √ | √ | √ | √ | 0499 |
| 2006 | Buick | LaCrosse | Shift lock control | √ | √ | √ | √ | √ | 0499 |
| 2006 | Buick | LaCrosse | Automatic transaxle | √ | √ | √ | √ | √ | 0499 |
| 2006 | Buick | LaCrosse | Cellular communication | √ | √ | √ | √ | √ | 0494 0591 0565 0585 |
| 2006 | Buick | LaCrosse | Cruise Control | √ | √ | √ | √ | √ | |
| 2006 | Buick | LaCrosse | Entertainment | √ | √ | √ | √ | √ | 0516 |
| 2006 | Buick | LaCrosse | Horns | √ | √ | √ | √ | √ | 0499 |
| 2006 | Buick | LaCrosse | Instrument panel | √ | √ | √ | √ | √ | |
| 2006 | Buick | LaCrosse | Keyless entry | √ | √ | √ | √ | √ | 0499 |
| 2006 | Buick | LaCrosse | Lighting systems | √ | √ | √ | √ | √ | 0499 |
| 2006 | Buick | LaCrosse | Seats | √ | √ | √ | √ | √ | 0499 |
| 2006 | Buick | LaCrosse | Stationary windows | √ | √ | √ | √ | √ | 0499 |
| 2006 | Buick | LaCrosse | Theft deterrent | √ | √ | √ | √ | √ | 0499 |
| 2006 | Buick | LaCrosse | Wipers/washer systems | √ | √ | √ | √ | √ | 0499 |
| 2006 | Buick | LaCrosse | Seat belts | √ | √ | √ | √ | √ | 0639 0515 |
| 2006 | Buick | LaCrosse | SIR | √ | √ | √ | √ | √ | 0639 0515 |
| 2006 | Buick | LaCrosse (Allure in Canada) | HVAC systems - manual | √ | √ | √ | √ | √ | 0499 |
| 2006 | Buick | LaCrosse (Allure in Canada) | HVAC systems - automatic | √ | √ | √ | √ | √ | 0500 |
| 2006 | Buick | LaCrosse (Allure in Canada) | Antilock Braking System | √ | √ | √ | √ | √ | 0506 |
| 2006 | Buick | LaCrosse (Allure in Canada) | Engine controls | | √ | √ | √ | √ | |
| 2006 | Buick | LaCrosse (Allure in Canada) | Engine cooling | | √ | √ | √ | √ | |
| 2006 | Buick | LaCrosse (Allure in Canada) | Engine electrical | √ | √ | √ | √ | √ | 0499 |
| 2006 | Buick | LaCrosse (Allure in Canada) | Shift lock control | √ | √ | √ | √ | √ | 0499 |
| 2006 | Buick | LaCrosse (Allure in Canada) | Automatic transaxle | √ | √ | √ | √ | √ | 0499 |
| 2006 | Buick | LaCrosse (Allure in Canada) | Cellular communication | √ | √ | √ | √ | √ | 0494 0591 0565 0585 |
| 2006 | Buick | LaCrosse (Allure in Canada) | Cruise Control | √ | √ | √ | √ | √ | |
| 2006 | Buick | LaCrosse (Allure in Canada) | Entertainment | √ | √ | √ | √ | √ | 0516 |
| 2006 | Buick | LaCrosse (Allure in Canada) | Horns | √ | √ | √ | √ | √ | 0499 |
| 2006 | Buick | LaCrosse (Allure in Canada) | Instrument panel | √ | √ | √ | √ | √ | |
| 2006 | Buick | LaCrosse (Allure in Canada) | Keyless entry | √ | √ | √ | √ | √ | 0499 |
| 2006 | Buick | LaCrosse (Allure in Canada) | Lighting systems | √ | √ | √ | √ | √ | 0499 |
| 2006 | Buick | LaCrosse (Allure in Canada) | Seats | √ | √ | √ | √ | √ | 0499 |
| 2006 | Buick | LaCrosse (Allure in Canada) | Stationary windows | √ | √ | √ | √ | √ | 0499 |
| 2006 | Buick | LaCrosse (Allure in Canada) | Theft deterrent | √ | √ | √ | √ | √ | 0499 |
| 2006 | Buick | LaCrosse (Allure in Canada) | Wipers/washer systems | √ | √ | √ | √ | √ | 0499 |

| | | | | | | | | | |
|------|-------|-----------------------------|---------------------------------|---|---|---|---|---|---------------------|
| 2006 | Buick | LaCrosse (Allure in Canada) | Seat belts | √ | √ | √ | √ | √ | 0639 0515 |
| 2006 | Buick | LaCrosse (Allure in Canada) | SIR | √ | √ | √ | √ | √ | 0639 0515 |
| 2006 | Buick | Lucerne | HVAC systems - automatic | √ | √ | √ | √ | √ | |
| 2006 | Buick | Lucerne | HVAC systems - manual | √ | √ | √ | √ | √ | 0493 |
| 2006 | Buick | Lucerne | Steering | √ | √ | √ | √ | √ | |
| 2006 | Buick | Lucerne | Suension | | √ | √ | √ | √ | |
| 2006 | Buick | Lucerne | Antilock Braking System | √ | √ | √ | √ | √ | 0493 |
| 2006 | Buick | Lucerne | Hydraulic brakes | √ | √ | √ | | | |
| 2006 | Buick | Lucerne | Park brake | √ | √ | √ | √ | √ | 0506 |
| 2006 | Buick | Lucerne | Engine controls | √ | √ | √ | √ | √ | 0493 |
| 2006 | Buick | Lucerne | Engine cooling | √ | √ | √ | √ | √ | 0493 |
| 2006 | Buick | Lucerne | Engine electrical | √ | √ | √ | √ | √ | 0493 |
| 2006 | Buick | Lucerne | Shift lock control | √ | √ | √ | √ | | |
| 2006 | Buick | Lucerne | Automatic transaxle | √ | √ | √ | √ | √ | |
| 2006 | Buick | Lucerne | Body rear end | √ | √ | √ | √ | | |
| 2006 | Buick | Lucerne | Cellular communication | √ | √ | √ | √ | √ | 0494 0591 0565 0495 |
| 2006 | Buick | Lucerne | Cruise Control | √ | √ | √ | √ | √ | 0493 |
| 2006 | Buick | Lucerne | Door | √ | √ | √ | √ | √ | |
| 2006 | Buick | Lucerne | Entertainment | √ | √ | √ | √ | √ | |
| 2006 | Buick | Lucerne | Horns | √ | √ | √ | √ | | |
| 2006 | Buick | Lucerne | Instrument panel | √ | √ | √ | √ | √ | 0493 |
| 2006 | Buick | Lucerne | Keyless entry | √ | √ | √ | √ | √ | 0493 |
| 2006 | Buick | Lucerne | Lighting systems | √ | √ | √ | √ | | |
| 2006 | Buick | Lucerne | Body Control Module | √ | √ | √ | √ | | |
| 2006 | Buick | Lucerne | Seats | √ | √ | √ | √ | √ | |
| 2006 | Buick | Lucerne | Stationary windows | √ | √ | √ | √ | | |
| 2006 | Buick | Lucerne | Theft deterrent | √ | √ | √ | √ | √ | 0493 |
| 2006 | Buick | Lucerne | Wipers/washer systems | √ | √ | √ | √ | | |
| 2006 | Buick | Lucerne | Rear parking assist | √ | √ | √ | √ | √ | 0494 0591 0565 0495 |
| 2006 | Buick | Lucerne | Seat belts | √ | √ | √ | √ | √ | 0497 |
| 2006 | Buick | Lucerne | SIR | √ | √ | √ | √ | √ | 0497 |
| 2006 | Buick | Others | Powertrain | √ | √ | √ | √ | √ | 0493 |
| 2006 | Buick | Others | Electronic Brake Control Module | √ | √ | √ | √ | √ | 0506 |
| 2006 | Buick | Rainier | Powertrain | √ | √ | √ | √ | √ | 0493 |
| 2006 | Buick | Rainier | Disc player and video dilay | √ | √ | √ | | | |
| 2006 | Buick | Rainier | Digital radio receiver | √ | √ | √ | √ | | 0516 |
| 2006 | Buick | Rainier | Radio | √ | √ | √ | √ | | |
| 2006 | Buick | Rainier | Rear seat audio | √ | √ | √ | √ | | |
| 2006 | Buick | Rainier | Body Control Module | √ | √ | √ | √ | √ | 0550 |
| 2006 | Buick | Rainier | Instrument panel cluster | √ | √ | √ | √ | √ | |
| 2006 | Buick | Rainier | Driver door module | √ | √ | √ | √ | √ | |
| 2006 | Buick | Rainier | Driver seat module | √ | √ | √ | √ | √ | |

| | | | | | | | | | |
|------|-------|------------------|-----------------------------------|---|---|---|---|---|---------------------|
| 2006 | Buick | Rainier | Heating and air conditioning | √ | √ | √ | √ | √ | |
| 2006 | Buick | Rainier | Lift gate module | √ | √ | √ | √ | √ | |
| 2006 | Buick | Rainier | Passenger door module | √ | √ | √ | √ | √ | |
| 2006 | Buick | Rainier | Passenger presence system | | √ | √ | | | 0512 |
| 2006 | Buick | Rainier | Vehicle comm. interface module | √ | √ | √ | √ | √ | 0591 0494 0565 0585 |
| 2006 | Buick | Rainier | Supplemental inflatable restraint | √ | √ | √ | √ | √ | 0516 |
| 2006 | Buick | Rainier | Navigation radio | √ | √ | √ | √ | √ | 0525 |
| 2006 | Buick | Rainier | ABS/TCS/VSES | √ | √ | √ | √ | √ | 0493 |
| 2006 | Buick | Rainier - 2WD | Powertrain | √ | √ | √ | √ | √ | 0493 |
| 2006 | Buick | Rainier - 2WD | Disc player and video dilay | √ | √ | √ | | | |
| 2006 | Buick | Rainier - 2WD | Digital radio receiver | √ | √ | √ | √ | | 0516 |
| 2006 | Buick | Rainier - 2WD | Radio | √ | √ | √ | √ | | |
| 2006 | Buick | Rainier - 2WD | Rear seat audio | √ | √ | √ | √ | | |
| 2006 | Buick | Rainier - 2WD | Body Control Module | √ | √ | √ | √ | √ | 0550 |
| 2006 | Buick | Rainier - 2WD | Instrument panel cluster | √ | √ | √ | √ | √ | |
| 2006 | Buick | Rainier - 2WD | Driver door module | √ | √ | √ | √ | √ | |
| 2006 | Buick | Rainier - 2WD | Driver seat module | √ | √ | √ | √ | √ | |
| 2006 | Buick | Rainier - 2WD | Heating and air conditioning | √ | √ | √ | √ | √ | |
| 2006 | Buick | Rainier - 2WD | Lift gate module | √ | √ | √ | √ | √ | |
| 2006 | Buick | Rainier - 2WD | Passenger door module | √ | √ | √ | √ | √ | |
| 2006 | Buick | Rainier - 2WD | Passenger presence system | | √ | √ | | | 0512 |
| 2006 | Buick | Rainier - 2WD | Vehicle comm. interface module | √ | √ | √ | √ | √ | 0591 0494 0565 0585 |
| 2006 | Buick | Rainier - 2WD | Supplemental inflatable restraint | √ | √ | √ | √ | √ | 0516 |
| 2006 | Buick | Rainier - 2WD | Navigation radio | √ | √ | √ | √ | √ | 0525 |
| 2006 | Buick | Rainier - 2WD | ABS/TCS/VSES | √ | √ | √ | √ | √ | 0493 |
| 2006 | Buick | Rendezvous - AWD | Powertrain | √ | √ | √ | √ | √ | |
| 2006 | Buick | Rendezvous - AWD | Radio | √ | √ | √ | √ | √ | 0573 0574 0636 0572 |
| 2006 | Buick | Rendezvous - AWD | Disc player and video dilay | √ | √ | √ | | | |
| 2006 | Buick | Rendezvous - AWD | Digital radio receiver | √ | √ | √ | √ | | 0516 |
| 2006 | Buick | Rendezvous - AWD | Navigation radio | √ | √ | √ | √ | √ | 0525 |
| 2006 | Buick | Rendezvous - AWD | Vehicle theft deterrent | √ | √ | √ | √ | | |
| 2006 | Buick | Rendezvous - AWD | Passenger presence system | | √ | √ | | | 0512 |
| 2006 | Buick | Rendezvous - AWD | Body Control Module | | √ | √ | √ | √ | 0560 0515 0628 0637 |
| 2006 | Buick | Rendezvous - AWD | Head up dilay | | √ | √ | √ | | |
| 2006 | Buick | Rendezvous - AWD | Instrument panel cluster | | √ | √ | √ | √ | |
| 2006 | Buick | Rendezvous - AWD | Vehicle comm. interface module | √ | √ | √ | √ | √ | 0591 0494 0565 0585 |
| 2006 | Buick | Rendezvous - AWD | Supplemental inflatable restraint | √ | √ | √ | √ | √ | 0515 |
| 2006 | Buick | Rendezvous - AWD | Memory seat module | √ | √ | √ | √ | √ | 0573 0574 0636 0572 |
| 2006 | Buick | Rendezvous - AWD | Chassis | √ | √ | √ | √ | √ | 0506 |
| 2006 | Buick | Rendezvous - FWD | Powertrain | √ | √ | √ | √ | √ | |
| 2006 | Buick | Rendezvous - FWD | Radio | √ | √ | √ | √ | √ | 0573 0574 0636 0572 |
| 2006 | Buick | Rendezvous - FWD | Disc player and video dilay | √ | √ | √ | | | |

| | | | | | | | | | |
|------|-------|------------------|-----------------------------------|---|---|---|---|---|---------------------|
| 2006 | Buick | Rendezvous - FWD | Digital radio receiver | √ | √ | √ | √ | | 0516 |
| 2006 | Buick | Rendezvous - FWD | Navigation radio | √ | √ | √ | √ | √ | 0525 |
| 2006 | Buick | Rendezvous - FWD | Vehicle theft deterrent | √ | √ | √ | √ | | |
| 2006 | Buick | Rendezvous - FWD | Passenger presence system | | √ | √ | | | 0512 |
| 2006 | Buick | Rendezvous - FWD | Body Control Module | | √ | √ | √ | √ | 0560 0515 0628 0637 |
| 2006 | Buick | Rendezvous - FWD | Head up display | | √ | √ | √ | | |
| 2006 | Buick | Rendezvous - FWD | Instrument panel cluster | | √ | √ | √ | √ | |
| 2006 | Buick | Rendezvous - FWD | Vehicle comm. interface module | √ | √ | √ | √ | √ | 0591 0494 0565 0585 |
| 2006 | Buick | Rendezvous - FWD | Supplemental inflatable restraint | √ | √ | √ | √ | √ | 0515 |
| 2006 | Buick | Rendezvous - FWD | Memory seat module | √ | √ | √ | √ | √ | 0573 0574 0636 0572 |
| 2006 | Buick | Rendezvous - FWD | Chassis | √ | √ | √ | √ | √ | 0506 |
| 2006 | Buick | Terraza | HVAC systems - manual | √ | √ | √ | √ | √ | 0499 |
| 2006 | Buick | Terraza | Antilock Braking System | √ | √ | √ | √ | √ | 0506 |
| 2006 | Buick | Terraza | Engine controls | √ | √ | √ | √ | √ | 0493 |
| 2006 | Buick | Terraza | Engine cooling | √ | √ | √ | √ | √ | 0493 |
| 2006 | Buick | Terraza | Engine electrical | √ | √ | √ | √ | √ | 0499 |
| 2006 | Buick | Terraza | Shift lock control | √ | √ | √ | √ | √ | 0499 |
| 2006 | Buick | Terraza | Automatic transaxle | √ | √ | √ | √ | √ | 0499 |
| 2006 | Buick | Terraza | Cellular communication | √ | √ | √ | √ | √ | 0494 0591 0565 0585 |
| 2006 | Buick | Terraza | Cruise Control | √ | √ | √ | √ | √ | 0493 |
| 2006 | Buick | Terraza | Door | √ | √ | √ | √ | √ | |
| 2006 | Buick | Terraza | Entertainment | √ | √ | √ | √ | √ | 0516 |
| 2006 | Buick | Terraza | Horns | √ | √ | √ | √ | √ | 0499 |
| 2006 | Buick | Terraza | Instrument panel | √ | √ | √ | √ | √ | 0499 |
| 2006 | Buick | Terraza | Lighting systems | √ | √ | √ | √ | √ | 0499 |
| 2006 | Buick | Terraza | Navigation System | √ | √ | √ | √ | √ | 0525 |
| 2006 | Buick | Terraza | Seats | √ | √ | √ | √ | √ | |
| 2006 | Buick | Terraza | Stationary windows | √ | √ | √ | √ | √ | |
| 2006 | Buick | Terraza | Theft deterrent | √ | √ | √ | √ | √ | 0499 |
| 2006 | Buick | Terraza | Wipers/washer systems | √ | √ | √ | √ | √ | 0499 |
| 2006 | Buick | Terraza | Keyless entry | √ | √ | √ | √ | √ | 0499 |
| 2006 | Buick | Terraza | Seat belts | √ | √ | √ | √ | √ | 0639 0515 |
| 2006 | Buick | Terraza | SIR | √ | √ | √ | √ | √ | 0639 0515 |
| 2006 | Buick | Terraza - 4WD | HVAC systems - manual | √ | √ | √ | √ | √ | 0499 |
| 2006 | Buick | Terraza - 4WD | Antilock Braking System | √ | √ | √ | √ | √ | 0506 |
| 2006 | Buick | Terraza - 4WD | Engine controls | | √ | √ | √ | √ | |
| 2006 | Buick | Terraza - 4WD | Engine cooling | | √ | √ | √ | √ | |
| 2006 | Buick | Terraza - 4WD | Engine electrical | √ | √ | √ | √ | √ | 0499 |
| 2006 | Buick | Terraza - 4WD | Shift lock control | √ | √ | √ | √ | √ | 0499 |
| 2006 | Buick | Terraza - 4WD | Automatic transaxle | √ | √ | √ | √ | √ | 0499 |
| 2006 | Buick | Terraza - 4WD | Cellular communication | √ | √ | √ | √ | √ | 0494 0591 0565 0585 |
| 2006 | Buick | Terraza - 4WD | Cruise Control | √ | √ | √ | √ | √ | 0493 |

| | | | | | | | | | |
|------|-------|---------------|-----------------------------------|---|---|---|---|---|---------------------|
| 2006 | Buick | Terraza - 4WD | Door | √ | √ | √ | √ | √ | |
| 2006 | Buick | Terraza - 4WD | Entertainment | √ | √ | √ | √ | √ | 0516 |
| 2006 | Buick | Terraza - 4WD | Horns | √ | √ | √ | √ | √ | 0499 |
| 2006 | Buick | Terraza - 4WD | Instrument panel | √ | √ | √ | √ | √ | 0499 |
| 2006 | Buick | Terraza - 4WD | Keyless entry | √ | √ | √ | √ | √ | 0499 |
| 2006 | Buick | Terraza - 4WD | Lighting systems | √ | √ | √ | √ | √ | 0499 |
| 2006 | Buick | Terraza - 4WD | Navigation System | √ | √ | √ | √ | √ | 0525 |
| 2006 | Buick | Terraza - 4WD | Seats | √ | √ | √ | √ | √ | |
| 2006 | Buick | Terraza - 4WD | Stationary windows | √ | √ | √ | √ | √ | |
| 2006 | Buick | Terraza - 4WD | Theft deterrent | √ | √ | √ | √ | √ | 0499 |
| 2006 | Buick | Terraza - 4WD | Wipers/washer systems | √ | √ | √ | √ | √ | 0499 |
| 2006 | Buick | Terraza - 4WD | Seat belts | √ | √ | √ | √ | √ | 0639 0515 |
| 2006 | Buick | Terraza - 4WD | SIR | √ | √ | √ | √ | √ | 0639 0515 |
| 2006 | Buick | Terraza Ext. | HVAC systems - manual | √ | √ | √ | √ | √ | 0499 |
| 2006 | Buick | Terraza Ext. | Antilock Braking System | √ | √ | √ | √ | √ | 0506 |
| 2006 | Buick | Terraza Ext. | Engine controls | √ | √ | √ | √ | √ | |
| 2006 | Buick | Terraza Ext. | Engine cooling | √ | √ | √ | √ | √ | |
| 2006 | Buick | Terraza Ext. | Engine electrical | √ | √ | √ | √ | √ | 0499 |
| 2006 | Buick | Terraza Ext. | Shift lock control | √ | √ | √ | √ | √ | 0499 |
| 2006 | Buick | Terraza Ext. | Automatic transaxle | √ | √ | √ | √ | √ | 0499 |
| 2006 | Buick | Terraza Ext. | Cellular communication | √ | √ | √ | √ | √ | 0494 0591 0565 0585 |
| 2006 | Buick | Terraza Ext. | Cruise Control | √ | √ | √ | √ | √ | 0493 |
| 2006 | Buick | Terraza Ext. | Door | √ | √ | √ | √ | √ | |
| 2006 | Buick | Terraza Ext. | Entertainment | √ | √ | √ | √ | √ | 0516 |
| 2006 | Buick | Terraza Ext. | Horns | √ | √ | √ | √ | √ | 0499 |
| 2006 | Buick | Terraza Ext. | Instrument panel | √ | √ | √ | √ | √ | 0499 |
| 2006 | Buick | Terraza Ext. | Keyless entry | √ | √ | √ | √ | √ | 0499 |
| 2006 | Buick | Terraza Ext. | Lighting systems | √ | √ | √ | √ | √ | 0499 |
| 2006 | Buick | Terraza Ext. | Navigation System | √ | √ | √ | √ | √ | 0525 |
| 2006 | Buick | Terraza Ext. | Seats | √ | √ | √ | √ | √ | |
| 2006 | Buick | Terraza Ext. | Stationary windows | √ | √ | √ | √ | √ | |
| 2006 | Buick | Terraza Ext. | Theft deterrent | √ | √ | √ | √ | √ | 0499 |
| 2006 | Buick | Terraza Ext. | Wipers/washer systems | √ | √ | √ | √ | √ | 0499 |
| 2006 | Buick | Terraza Ext. | Seat belts | √ | √ | √ | √ | √ | 0639 0515 |
| 2006 | Buick | Terraza Ext. | SIR | √ | √ | √ | √ | √ | 0639 0515 |
| 2005 | Buick | Century | Powertrain | √ | √ | √ | √ | √ | |
| 2005 | Buick | Century | Supplemental inflatable restraint | √ | √ | √ | √ | √ | |
| 2005 | Buick | Century | Body Control Module | | √ | √ | √ | √ | 0614 0662 0628 |
| 2005 | Buick | Century | Radio | | √ | √ | √ | √ | 0573 0636 0572 |
| 2005 | Buick | Century | Vehicle comm. interface module | √ | √ | √ | √ | √ | 0647 0585 |
| 2005 | Buick | Century | Heating and air conditioning | | √ | √ | √ | √ | |
| 2005 | Buick | Century | Chassis | √ | √ | √ | √ | √ | 0506 |

| | | | | | | | | | |
|------|-------|-----------------------------|--------------------------|---|---|---|---|---|---------------------|
| 2005 | Buick | LaCrosse | HVAC systems - manual | | √ | √ | √ | √ | |
| 2005 | Buick | LaCrosse | HVAC systems - automatic | √ | √ | √ | √ | √ | 0500 |
| 2005 | Buick | LaCrosse | Brakes | √ | √ | √ | √ | √ | 0506 |
| 2005 | Buick | LaCrosse | Engine controls | | √ | √ | √ | √ | |
| 2005 | Buick | LaCrosse | Engine cooling | | √ | √ | √ | √ | |
| 2005 | Buick | LaCrosse | Engine electrical | √ | √ | √ | √ | √ | 0515 |
| 2005 | Buick | LaCrosse | Shift lock control | √ | √ | √ | √ | √ | 0499 |
| 2005 | Buick | LaCrosse | Automatic transaxle | √ | √ | √ | √ | √ | 0499 |
| 2005 | Buick | LaCrosse | Cellular communication | √ | √ | √ | √ | √ | 0494 0591 0565 0585 |
| 2005 | Buick | LaCrosse | Cruise Control | | √ | √ | √ | √ | |
| 2005 | Buick | LaCrosse | Entertainment | √ | √ | √ | √ | √ | 0516 |
| 2005 | Buick | LaCrosse | Horns | √ | √ | √ | √ | √ | 0499 |
| 2005 | Buick | LaCrosse | Instrument panel | √ | √ | √ | √ | √ | 0663 |
| 2005 | Buick | LaCrosse | Keyless entry | √ | √ | √ | √ | √ | 0499 |
| 2005 | Buick | LaCrosse | Lighting systems | √ | √ | √ | √ | √ | 0499 |
| 2005 | Buick | LaCrosse | Seats | √ | √ | √ | √ | √ | 0499 |
| 2005 | Buick | LaCrosse | Stationary windows | √ | √ | √ | √ | √ | 0499 |
| 2005 | Buick | LaCrosse | Theft deterrent | √ | √ | √ | √ | √ | 0499 |
| 2005 | Buick | LaCrosse | Wipers/washer systems | √ | √ | √ | √ | √ | 0499 |
| 2005 | Buick | LaCrosse | Seat belts | √ | √ | √ | √ | | 0515 |
| 2005 | Buick | LaCrosse | SIR | √ | √ | √ | √ | | 0515 |
| 2005 | Buick | LaCrosse (Allure in Canada) | HVAC systems - manual | | √ | √ | √ | √ | |
| 2005 | Buick | LaCrosse (Allure in Canada) | HVAC systems - automatic | √ | √ | √ | √ | √ | 0500 |
| 2005 | Buick | LaCrosse (Allure in Canada) | Brakes | √ | √ | √ | √ | √ | 0506 |
| 2005 | Buick | LaCrosse (Allure in Canada) | Engine controls | | √ | √ | √ | √ | |
| 2005 | Buick | LaCrosse (Allure in Canada) | Engine cooling | | √ | √ | √ | √ | |
| 2005 | Buick | LaCrosse (Allure in Canada) | Engine electrical | √ | √ | √ | √ | √ | 0515 |
| 2005 | Buick | LaCrosse (Allure in Canada) | Shift lock control | √ | √ | √ | √ | √ | 0499 |
| 2005 | Buick | LaCrosse (Allure in Canada) | Automatic transaxle | √ | √ | √ | √ | √ | 0499 |
| 2005 | Buick | LaCrosse (Allure in Canada) | Cellular communication | √ | √ | √ | √ | √ | 0494 0591 0565 0585 |
| 2005 | Buick | LaCrosse (Allure in Canada) | Cruise Control | | √ | √ | √ | √ | |
| 2005 | Buick | LaCrosse (Allure in Canada) | Entertainment | √ | √ | √ | √ | √ | 0516 |
| 2005 | Buick | LaCrosse (Allure in Canada) | Horns | √ | √ | √ | √ | √ | 0499 |
| 2005 | Buick | LaCrosse (Allure in Canada) | Instrument panel | √ | √ | √ | √ | √ | 0663 |
| 2005 | Buick | LaCrosse (Allure in Canada) | Keyless entry | √ | √ | √ | √ | √ | 0499 |
| 2005 | Buick | LaCrosse (Allure in Canada) | Lighting systems | √ | √ | √ | √ | √ | 0499 |
| 2005 | Buick | LaCrosse (Allure in Canada) | Seats | √ | √ | √ | √ | √ | 0499 |
| 2005 | Buick | LaCrosse (Allure in Canada) | Stationary windows | √ | √ | √ | √ | √ | 0499 |
| 2005 | Buick | LaCrosse (Allure in Canada) | Theft deterrent | √ | √ | √ | √ | √ | 0499 |
| 2005 | Buick | LaCrosse (Allure in Canada) | Wipers/washer systems | √ | √ | √ | √ | √ | 0499 |
| 2005 | Buick | LaCrosse (Allure in Canada) | Seat belts | √ | √ | √ | √ | | 0515 |
| 2005 | Buick | LaCrosse (Allure in Canada) | SIR | √ | √ | √ | √ | | 0515 |

| | | | | | | | | | |
|------|-------|-------------|-----------------------------------|---|---|---|---|---|--|
| 2005 | Buick | LeSabre | Powertrain | √ | √ | √ | √ | √ | |
| 2005 | Buick | LeSabre | Dash integration module | √ | √ | √ | √ | √ | 0614 0664 0615 0619 0665 0666 0618 0604 |
| 2005 | Buick | LeSabre | Head up dilay | √ | √ | √ | √ | √ | |
| 2005 | Buick | LeSabre | Rear integration module | √ | √ | √ | √ | √ | |
| 2005 | Buick | LeSabre | Vehicle comm. interface module | √ | √ | √ | √ | √ | 0591 0494 0565 0585 |
| 2005 | Buick | LeSabre | Driver door module | √ | √ | √ | √ | √ | |
| 2005 | Buick | LeSabre | CD changer | √ | √ | √ | √ | √ | |
| 2005 | Buick | LeSabre | Radio | √ | √ | √ | √ | √ | 0573 0574 0575 0576 0577 0578 0579 0636 |
| 2005 | Buick | LeSabre | Digital radio receiver | √ | √ | √ | √ | √ | 0516 |
| 2005 | Buick | LeSabre | Supplemental inflatable restraint | √ | √ | √ | √ | √ | 0605 |
| 2005 | Buick | LeSabre | Remote function actuation | √ | √ | √ | √ | √ | |
| 2005 | Buick | LeSabre | Vehicle theft deterrent | √ | √ | √ | √ | √ | |
| 2005 | Buick | LeSabre | Instrument panel cluster | √ | √ | √ | √ | √ | 0651 0650 |
| 2005 | Buick | LeSabre | Climate control panel | √ | √ | √ | √ | √ | |
| 2005 | Buick | LeSabre | Instrument panel module | √ | √ | √ | √ | √ | 0630 0667 |
| 2005 | Buick | LeSabre | DRP/ABS/TIM | √ | √ | √ | √ | √ | 0506 |
| 2005 | Buick | LeSabre | Powertrain | √ | √ | √ | √ | √ | |
| 2005 | Buick | LeSabre | Dash integration module | √ | √ | √ | √ | √ | 0614 0664 0615 0619 0665 0666 0618 0604 |
| 2005 | Buick | LeSabre | Head up dilay | √ | √ | √ | √ | √ | |
| 2005 | Buick | LeSabre | Rear integration module | √ | √ | √ | √ | √ | |
| 2005 | Buick | LeSabre | Vehicle comm. interface module | √ | √ | √ | √ | √ | 0591 0494 0565 0585 |
| 2005 | Buick | LeSabre | Driver door module | √ | √ | √ | √ | √ | |
| 2005 | Buick | LeSabre | CD changer | √ | √ | √ | √ | √ | |
| 2005 | Buick | LeSabre | Radio | √ | √ | √ | √ | √ | 0573 0574 0575 0576 0577 0578 0579 0636 |
| 2005 | Buick | LeSabre | Memory seat module | √ | √ | √ | √ | √ | |
| 2005 | Buick | LeSabre | Digital radio receiver | √ | √ | √ | √ | √ | 0516 |
| 2005 | Buick | LeSabre | Supplemental inflatable restraint | √ | √ | √ | √ | √ | 0605 |
| 2005 | Buick | LeSabre | Remote function actuation | √ | √ | √ | √ | √ | |
| 2005 | Buick | LeSabre | Vehicle theft deterrent | √ | √ | √ | √ | √ | |
| 2005 | Buick | LeSabre | Instrument panel cluster | √ | √ | √ | √ | √ | 0651 0650 |
| 2005 | Buick | LeSabre | Climate control panel | √ | √ | √ | √ | √ | |
| 2005 | Buick | LeSabre | Instrument panel module | √ | √ | √ | √ | √ | 0630 0667 |
| 2005 | Buick | LeSabre | DRP/ABS/TIM | √ | √ | √ | √ | √ | 0506 |
| 2005 | Buick | Park Avenue | Powertrain | √ | √ | √ | √ | √ | |
| 2005 | Buick | Park Avenue | Body Control Module | √ | √ | √ | √ | √ | 0614 0668 0550 |
| 2005 | Buick | Park Avenue | Memory seat module | √ | √ | √ | √ | √ | 0669 |
| 2005 | Buick | Park Avenue | Driver door module | √ | √ | √ | √ | √ | |
| 2005 | Buick | Park Avenue | Supplemental inflatable restraint | √ | √ | √ | √ | √ | 0515 |

| | | | | | | | | | |
|------|-------|------------------|-----------------------------------|---|---|---|---|---|---------------------|
| 2005 | Buick | Park Avenue | Remote function actuation | √ | | | √ | √ | |
| 2005 | Buick | Park Avenue | Vehicle theft deterrent | | √ | √ | √ | | |
| 2005 | Buick | Park Avenue | Heating and air conditioning | √ | √ | √ | √ | √ | 0630 |
| 2005 | Buick | Park Avenue | Vehicle comm. interface module | √ | √ | √ | √ | √ | 0647 0585 |
| 2005 | Buick | Park Avenue | DRP/ABS/TIM | | √ | √ | √ | √ | 0506 |
| 2005 | Buick | Rainier | Powertrain | √ | √ | √ | √ | √ | 0493 |
| 2005 | Buick | Rainier | Digital radio receiver | √ | √ | √ | √ | | 0516 |
| 2005 | Buick | Rainier | Vehicle comm. interface module | √ | √ | √ | √ | √ | 0591 0494 0565 0585 |
| 2005 | Buick | Rainier | Radio | √ | √ | √ | √ | | |
| 2005 | Buick | Rainier | Disc player and video dilay | √ | √ | √ | | | |
| 2005 | Buick | Rainier | Passenger presence system | | √ | √ | | | 0512 |
| 2005 | Buick | Rainier | Instrument panel cluster | √ | √ | √ | √ | √ | |
| 2005 | Buick | Rainier | Driver door module | √ | √ | √ | √ | √ | |
| 2005 | Buick | Rainier | Driver seat module | √ | √ | √ | √ | √ | |
| 2005 | Buick | Rainier | Heating and air conditioning | √ | √ | √ | √ | √ | |
| 2005 | Buick | Rainier | Lift gate module | √ | √ | √ | √ | √ | |
| 2005 | Buick | Rainier | Passenger door module | √ | √ | √ | √ | √ | |
| 2005 | Buick | Rainier | Rear seat audio | √ | √ | √ | √ | | |
| 2005 | Buick | Rainier | Body Control Module | √ | √ | √ | √ | √ | 0550 |
| 2005 | Buick | Rainier | Supplemental inflatable restraint | √ | √ | √ | √ | √ | 0516 |
| 2005 | Buick | Rainier | Navigation radio | √ | √ | √ | √ | √ | 0525 |
| 2005 | Buick | Rainier | ABS | √ | √ | √ | √ | √ | |
| 2005 | Buick | Rainier | 4WAL 3 sensor | √ | √ | √ | √ | √ | 0493 |
| 2005 | Buick | Rainier - 2WD | Powertrain | √ | √ | √ | √ | √ | 0493 |
| 2005 | Buick | Rainier - 2WD | Digital radio receiver | √ | √ | √ | √ | | 0516 |
| 2005 | Buick | Rainier - 2WD | Vehicle comm. interface module | √ | √ | √ | √ | √ | 0591 0494 0565 0585 |
| 2005 | Buick | Rainier - 2WD | Radio | √ | √ | √ | √ | | |
| 2005 | Buick | Rainier - 2WD | Disc player and video dilay | √ | √ | √ | | | |
| 2005 | Buick | Rainier - 2WD | Passenger presence system | | √ | √ | | | 0512 |
| 2005 | Buick | Rainier - 2WD | Instrument panel cluster | √ | √ | √ | √ | √ | |
| 2005 | Buick | Rainier - 2WD | Driver door module | √ | √ | √ | √ | √ | |
| 2005 | Buick | Rainier - 2WD | Driver seat module | √ | √ | √ | √ | √ | |
| 2005 | Buick | Rainier - 2WD | Heating and air conditioning | √ | √ | √ | √ | √ | |
| 2005 | Buick | Rainier - 2WD | Lift gate module | √ | √ | √ | √ | √ | |
| 2005 | Buick | Rainier - 2WD | Passenger door module | √ | √ | √ | √ | √ | |
| 2005 | Buick | Rainier - 2WD | Rear seat audio | √ | √ | √ | √ | | |
| 2005 | Buick | Rainier - 2WD | Body Control Module | √ | √ | √ | √ | √ | 0550 |
| 2005 | Buick | Rainier - 2WD | Supplemental inflatable restraint | √ | √ | √ | √ | √ | 0516 |
| 2005 | Buick | Rainier - 2WD | Navigation radio | √ | √ | √ | √ | √ | 0525 |
| 2005 | Buick | Rainier - 2WD | ABS | √ | √ | √ | √ | √ | |
| 2005 | Buick | Rainier - 2WD | 4WAL 3 sensor | √ | √ | √ | √ | √ | 0493 |
| 2005 | Buick | Rendezvous - AWD | Powertrain | √ | √ | √ | √ | √ | |

| | | | | | | | | | |
|------|-------|------------------|-----------------------------------|---|---|---|---|---|---------------------|
| 2005 | Buick | Rendezvous - AWD | Disc player and video delay | √ | √ | √ | | | |
| 2005 | Buick | Rendezvous - AWD | Digital radio receiver | √ | √ | √ | √ | | 0516 |
| 2005 | Buick | Rendezvous - AWD | Vehicle comm. interface module | √ | √ | √ | √ | √ | 0591 0494 0565 0585 |
| 2005 | Buick | Rendezvous - AWD | Radio | | | | | | 0524 |
| 2005 | Buick | Rendezvous - AWD | Heating and air conditioning | | √ | √ | √ | √ | |
| 2005 | Buick | Rendezvous - AWD | Vehicle theft deterrent | | √ | √ | √ | | |
| 2005 | Buick | Rendezvous - AWD | Passenger presence system | | √ | √ | | | 0512 |
| 2005 | Buick | Rendezvous - AWD | Head up display | | √ | √ | √ | | |
| 2005 | Buick | Rendezvous - AWD | Memory seat module | | √ | √ | √ | √ | |
| 2005 | Buick | Rendezvous - AWD | Instrument panel cluster | | √ | √ | √ | √ | |
| 2005 | Buick | Rendezvous - AWD | Body Control Module | √ | √ | √ | √ | √ | 0560 0515 0628 0614 |
| 2005 | Buick | Rendezvous - AWD | Navigation radio | √ | √ | √ | √ | √ | 0525 |
| 2005 | Buick | Rendezvous - AWD | Supplemental inflatable restraint | √ | √ | √ | √ | √ | 0515 |
| 2005 | Buick | Rendezvous - AWD | Chassis | √ | √ | √ | √ | √ | 0506 |
| 2005 | Buick | Rendezvous - FWD | Powertrain | √ | √ | √ | √ | √ | |
| 2005 | Buick | Rendezvous - FWD | Disc player and video delay | √ | √ | √ | | | |
| 2005 | Buick | Rendezvous - FWD | Digital radio receiver | √ | √ | √ | √ | | 0516 |
| 2005 | Buick | Rendezvous - FWD | Vehicle comm. interface module | √ | √ | √ | √ | √ | 0591 0494 0565 0585 |
| 2005 | Buick | Rendezvous - FWD | Radio | | | | | | 0524 |
| 2005 | Buick | Rendezvous - FWD | Heating and air conditioning | | √ | √ | √ | √ | |
| 2005 | Buick | Rendezvous - FWD | Vehicle theft deterrent | | √ | √ | √ | | |
| 2005 | Buick | Rendezvous - FWD | Passenger presence system | | √ | √ | | | 0512 |
| 2005 | Buick | Rendezvous - FWD | Head up display | | √ | √ | √ | | |
| 2005 | Buick | Rendezvous - FWD | Memory seat module | | √ | √ | √ | √ | |
| 2005 | Buick | Rendezvous - FWD | Instrument panel cluster | | √ | √ | √ | √ | |
| 2005 | Buick | Rendezvous - FWD | Body Control Module | √ | √ | √ | √ | √ | 0560 0515 0628 0614 |
| 2005 | Buick | Rendezvous - FWD | Navigation radio | √ | √ | √ | √ | √ | 0525 |
| 2005 | Buick | Rendezvous - FWD | Supplemental inflatable restraint | √ | √ | √ | √ | √ | 0515 |
| 2005 | Buick | Rendezvous - FWD | Chassis | √ | √ | √ | √ | √ | 0506 |
| 2005 | Buick | Terraza | HVAC | √ | √ | √ | √ | √ | 0499 |
| 2005 | Buick | Terraza | Brakes | | √ | √ | √ | √ | 0506 |
| 2005 | Buick | Terraza | Engine controls | | √ | √ | √ | √ | |
| 2005 | Buick | Terraza | Engine cooling | | √ | √ | √ | √ | |
| 2005 | Buick | Terraza | Engine electrical | √ | √ | √ | √ | √ | 0499 |
| 2005 | Buick | Terraza | Shift lock control | √ | √ | √ | √ | √ | 0499 |
| 2005 | Buick | Terraza | Automatic transaxle | | √ | √ | √ | √ | |
| 2005 | Buick | Terraza | Cellular communication | √ | √ | √ | √ | √ | 0494 0591 0565 0585 |
| 2005 | Buick | Terraza | Cruise Control | | √ | √ | √ | √ | |
| 2005 | Buick | Terraza | Door | √ | √ | √ | √ | √ | |
| 2005 | Buick | Terraza | Entertainment | √ | √ | √ | √ | √ | 0516 |
| 2005 | Buick | Terraza | Horns | √ | √ | √ | √ | √ | 0499 |
| 2005 | Buick | Terraza | Instrument panel | √ | √ | √ | √ | √ | 0499 |

| | | | | | | | | | |
|------|-------|---------------|------------------------|---|---|---|---|---|---------------------|
| 2005 | Buick | Terraza | Keyless entry | √ | √ | √ | √ | √ | 0499 |
| 2005 | Buick | Terraza | Lighting systems | √ | √ | √ | √ | √ | 0499 |
| 2005 | Buick | Terraza | Navigation System | √ | √ | √ | √ | √ | 0525 |
| 2005 | Buick | Terraza | Seats | √ | √ | √ | √ | √ | |
| 2005 | Buick | Terraza | Stationary windows | √ | √ | √ | √ | √ | |
| 2005 | Buick | Terraza | Theft deterrent | √ | √ | √ | √ | √ | 0499 |
| 2005 | Buick | Terraza | Wipers/washer systems | √ | √ | √ | √ | √ | 0499 |
| 2005 | Buick | Terraza | Seat belts | √ | √ | √ | √ | √ | 0515 |
| 2005 | Buick | Terraza | SIR | √ | √ | √ | √ | √ | 0512 |
| 2005 | Buick | Terraza - 4WD | HVAC | √ | √ | √ | √ | √ | 0499 |
| 2005 | Buick | Terraza - 4WD | Brakes | | √ | √ | √ | √ | 0506 |
| 2005 | Buick | Terraza - 4WD | Engine controls | | √ | √ | √ | √ | |
| 2005 | Buick | Terraza - 4WD | Engine cooling | | √ | √ | √ | √ | |
| 2005 | Buick | Terraza - 4WD | Engine electrical | √ | √ | √ | √ | √ | 0499 |
| 2005 | Buick | Terraza - 4WD | Shift lock control | √ | √ | √ | √ | √ | 0499 |
| 2005 | Buick | Terraza - 4WD | Automatic transaxle | | √ | √ | √ | √ | |
| 2005 | Buick | Terraza - 4WD | Cellular communication | √ | √ | √ | √ | √ | 0494 0591 0565 0585 |
| 2005 | Buick | Terraza - 4WD | Cruise Control | | √ | √ | √ | √ | |
| 2005 | Buick | Terraza - 4WD | Door | √ | √ | √ | √ | √ | |
| 2005 | Buick | Terraza - 4WD | Entertainment | √ | √ | √ | √ | √ | 0516 |
| 2005 | Buick | Terraza - 4WD | Horns | √ | √ | √ | √ | √ | 0499 |
| 2005 | Buick | Terraza - 4WD | Instrument panel | √ | √ | √ | √ | √ | 0499 |
| 2005 | Buick | Terraza - 4WD | Keyless entry | √ | √ | √ | √ | √ | 0499 |
| 2005 | Buick | Terraza - 4WD | Lighting systems | √ | √ | √ | √ | √ | 0499 |
| 2005 | Buick | Terraza - 4WD | Navigation System | √ | √ | √ | √ | √ | 0525 |
| 2005 | Buick | Terraza - 4WD | Seats | √ | √ | √ | √ | √ | |
| 2005 | Buick | Terraza - 4WD | Stationary windows | √ | √ | √ | √ | √ | |
| 2005 | Buick | Terraza - 4WD | Theft deterrent | √ | √ | √ | √ | √ | 0499 |
| 2005 | Buick | Terraza - 4WD | Wipers/washer systems | √ | √ | √ | √ | √ | 0499 |
| 2005 | Buick | Terraza - 4WD | Seat belts | √ | √ | √ | √ | √ | 0515 |
| 2005 | Buick | Terraza - 4WD | SIR | √ | √ | √ | √ | √ | 0512 |
| 2005 | Buick | Terraza Ext. | HVAC | √ | √ | √ | √ | √ | 0499 |
| 2005 | Buick | Terraza Ext. | Brakes | | √ | √ | √ | √ | 0506 |
| 2005 | Buick | Terraza Ext. | Engine controls | | √ | √ | √ | √ | |
| 2005 | Buick | Terraza Ext. | Engine cooling | | √ | √ | √ | √ | |
| 2005 | Buick | Terraza Ext. | Engine electrical | √ | √ | √ | √ | √ | 0499 |
| 2005 | Buick | Terraza Ext. | Shift lock control | √ | √ | √ | √ | √ | 0499 |
| 2005 | Buick | Terraza Ext. | Automatic transaxle | | √ | √ | √ | √ | |
| 2005 | Buick | Terraza Ext. | Cellular communication | √ | √ | √ | √ | √ | 0494 0591 0565 0585 |
| 2005 | Buick | Terraza Ext. | Cruise Control | | √ | √ | √ | √ | |
| 2005 | Buick | Terraza Ext. | Door | √ | √ | √ | √ | √ | |
| 2005 | Buick | Terraza Ext. | Entertainment | √ | √ | √ | √ | √ | 0516 |

| | | | | | | | | | |
|------|-------|--------------|-----------------------------------|---|---|---|---|---|--|
| 2005 | Buick | Terraza Ext. | Horns | √ | √ | √ | √ | √ | 0499 |
| 2005 | Buick | Terraza Ext. | Instrument panel | √ | √ | √ | √ | √ | 0499 |
| 2005 | Buick | Terraza Ext. | Keyless entry | √ | √ | √ | √ | √ | 0499 |
| 2005 | Buick | Terraza Ext. | Lighting systems | √ | √ | √ | √ | √ | 0499 |
| 2005 | Buick | Terraza Ext. | Navigation System | √ | √ | √ | √ | √ | 0525 |
| 2005 | Buick | Terraza Ext. | Seats | √ | √ | √ | √ | √ | |
| 2005 | Buick | Terraza Ext. | Stationary windows | √ | √ | √ | √ | √ | |
| 2005 | Buick | Terraza Ext. | Theft deterrent | √ | √ | √ | √ | √ | 0499 |
| 2005 | Buick | Terraza Ext. | Wipers/washer systems | √ | √ | √ | √ | √ | 0499 |
| 2005 | Buick | Terraza Ext. | Seat belts | √ | √ | √ | √ | √ | 0515 |
| 2005 | Buick | Terraza Ext. | SIR | √ | √ | √ | √ | √ | 0512 |
| 2004 | Buick | Century | Powertrain | √ | √ | √ | √ | √ | |
| 2004 | Buick | Century | Onstar | √ | √ | √ | √ | √ | 0647 0683 |
| 2004 | Buick | Century | Body Control Module | | √ | √ | √ | √ | 0614 0662 0628 0573 0636 0572 |
| 2004 | Buick | Century | Supplemental inflatable restraint | | √ | √ | √ | | 0515 |
| 2004 | Buick | Century | Chassis | √ | √ | √ | √ | √ | 0506 |
| 2004 | Buick | LeSabre | Powertrain | √ | √ | √ | √ | √ | |
| 2004 | Buick | LeSabre | Onstar | √ | √ | √ | √ | √ | 0647 0683 |
| 2004 | Buick | LeSabre | Digital radio receiver | √ | √ | √ | √ | | 0516 |
| 2004 | Buick | LeSabre | CD changer | √ | √ | √ | √ | | |
| 2004 | Buick | LeSabre | Climate control panel | | √ | √ | | | |
| 2004 | Buick | LeSabre | Dash integration module | | √ | √ | | | 0614 0664 0615 0619 0665 0666 0618 0604 |
| 2004 | Buick | LeSabre | Driver door module | √ | √ | √ | √ | √ | |
| 2004 | Buick | LeSabre | Head up dilay | | √ | √ | | √ | |
| 2004 | Buick | LeSabre | Instrument panel module | | √ | √ | | | 0630 0667 |
| 2004 | Buick | LeSabre | Rear integration module | | √ | √ | | | |
| 2004 | Buick | LeSabre | Remote function actuation | √ | √ | √ | √ | √ | |
| 2004 | Buick | LeSabre | Instrument panel cluster | | √ | √ | | √ | |
| 2004 | Buick | LeSabre | Radio | √ | √ | √ | √ | √ | 0573 0574 0575 0576 0577 0578 0579 0636 |
| 2004 | Buick | LeSabre | Vehicle theft deterrent | √ | √ | √ | √ | √ | |
| 2004 | Buick | LeSabre | Supplemental inflatable restraint | √ | √ | √ | √ | √ | 0604 |
| 2004 | Buick | LeSabre | DRP/ABS/TIM | | √ | √ | √ | √ | 0506 |
| 2004 | Buick | LeSabre | Powertrain | √ | √ | √ | √ | √ | |
| 2004 | Buick | LeSabre | Onstar | √ | √ | √ | √ | √ | 0647 0683 |
| 2004 | Buick | LeSabre | Digital radio receiver | √ | √ | √ | √ | | 0516 |
| 2004 | Buick | LeSabre | CD changer | √ | √ | √ | √ | | |
| 2004 | Buick | LeSabre | Climate control panel | | √ | √ | | | |
| 2004 | Buick | LeSabre | Dash integration module | | √ | √ | | | 0614 0664 0615 0619 0665 0666 0618 0604 |

| | | | | | | | | | |
|------|-------|-------------|-----------------------------------|---|---|---|---|---|--|
| 2004 | Buick | LeSabre | Driver door module | √ | √ | √ | √ | √ | |
| 2004 | Buick | LeSabre | Head up dilay | | √ | √ | | √ | |
| 2004 | Buick | LeSabre | Instrument panel module | | √ | √ | | | 0630 0667 |
| 2004 | Buick | LeSabre | Memory seat module | √ | √ | √ | √ | √ | |
| 2004 | Buick | LeSabre | Rear integration module | | √ | √ | | | |
| 2004 | Buick | LeSabre | Remote function actuation | √ | √ | √ | √ | √ | |
| 2004 | Buick | LeSabre | Instrument panel cluster | | √ | √ | | √ | |
| 2004 | Buick | LeSabre | Radio | √ | √ | √ | √ | √ | 0573 0574 0575 0576 0577 0578 0579 0636 |
| 2004 | Buick | LeSabre | Vehicle theft deterrent | √ | √ | √ | √ | √ | |
| 2004 | Buick | LeSabre | Supplemental inflatable restraint | √ | √ | √ | √ | √ | 0604 |
| 2004 | Buick | LeSabre | DRP/ABS/TIM | | √ | √ | √ | √ | 0506 |
| 2004 | Buick | Park Avenue | Powertrain | √ | √ | √ | √ | √ | |
| 2004 | Buick | Park Avenue | Onstar | √ | √ | √ | √ | | 0647 0495 0683 |
| 2004 | Buick | Park Avenue | Driver door module | √ | √ | √ | √ | √ | |
| 2004 | Buick | Park Avenue | Memory seat module | √ | √ | √ | √ | √ | 0669 |
| 2004 | Buick | Park Avenue | Heating and air conditioning | √ | √ | √ | √ | √ | 0630 |
| 2004 | Buick | Park Avenue | Remote function actuation | √ | | | √ | √ | |
| 2004 | Buick | Park Avenue | Body Control Module | √ | √ | √ | √ | √ | 0614 0668 0550 |
| 2004 | Buick | Park Avenue | Cellular telephone | √ | √ | √ | √ | | 0684 |
| 2004 | Buick | Park Avenue | Instrument panel cluster | √ | √ | √ | √ | √ | 0550 0550 |
| 2004 | Buick | Park Avenue | Vehicle theft deterrent | | √ | √ | √ | | |
| 2004 | Buick | Park Avenue | DRP/ABS/TIM | | √ | √ | √ | √ | 0506 |
| 2004 | Buick | Regal | Powertrain | √ | √ | √ | √ | √ | |
| 2004 | Buick | Regal | Onstar | √ | √ | √ | √ | √ | 0647 0683 |
| 2004 | Buick | Regal | Body Control Module | | √ | √ | √ | √ | 0614 0662 0628 0573 0636 0572 |
| 2004 | Buick | Regal | Supplemental inflatable restraint | | √ | √ | √ | | 0515 |
| 2004 | Buick | Regal | Chassis | √ | √ | √ | √ | √ | 0506 |
| 2004 | Buick | Rainier | Powertrain | √ | √ | √ | √ | √ | |
| 2004 | Buick | Rainier | Onstar | √ | √ | √ | √ | √ | 0647 0683 |
| 2004 | Buick | Rainier | Digital radio receiver | √ | √ | √ | √ | | 0516 |
| 2004 | Buick | Rainier | Body Control Module | √ | √ | √ | √ | √ | 0550 |
| 2004 | Buick | Rainier | Instrument panel cluster | √ | √ | √ | √ | √ | |
| 2004 | Buick | Rainier | Driver door module | √ | √ | √ | √ | √ | |
| 2004 | Buick | Rainier | Passenger door module | √ | √ | √ | √ | √ | |
| 2004 | Buick | Rainier | Driver seat module | √ | √ | √ | √ | √ | |
| 2004 | Buick | Rainier | Heating and air conditioning | √ | √ | √ | √ | √ | |
| 2004 | Buick | Rainier | Supplemental inflatable restraint | √ | √ | √ | √ | | 0531 |
| 2004 | Buick | Rainier | Amplifier (bose) | √ | √ | √ | √ | √ | |
| 2004 | Buick | Rainier | Radio | √ | √ | √ | √ | | 0524 |
| 2004 | Buick | Rainier | Rear seat audio | √ | √ | √ | √ | | |

| | | | | | | | | | |
|------|-------|------------------|-----------------------------------|---|---|---|---|---|--|
| 2004 | Buick | Rainier | Lift gate module | √ | √ | √ | √ | √ | |
| 2004 | Buick | Rainier | Rear seat entertainment | √ | √ | √ | √ | √ | 0550 |
| 2004 | Buick | Rainier | Navigation radio | √ | √ | √ | √ | √ | 0525 |
| 2004 | Buick | Rainier | ABS | √ | √ | √ | √ | √ | |
| 2004 | Buick | Rainier | 4WAL 3 sensor | √ | √ | √ | √ | √ | 0647 0683 |
| 2004 | Buick | Rainier - 2WD | Powertrain | √ | √ | √ | √ | √ | |
| 2004 | Buick | Rainier - 2WD | Onstar | √ | √ | √ | √ | √ | 0647 0683 |
| 2004 | Buick | Rainier - 2WD | Digital radio receiver | √ | √ | √ | √ | | 0516 |
| 2004 | Buick | Rainier - 2WD | Body Control Module | √ | √ | √ | √ | √ | 0550 |
| 2004 | Buick | Rainier - 2WD | Instrument panel cluster | √ | √ | √ | √ | √ | |
| 2004 | Buick | Rainier - 2WD | Driver door module | √ | √ | √ | √ | √ | |
| 2004 | Buick | Rainier - 2WD | Passenger door module | √ | √ | √ | √ | √ | |
| 2004 | Buick | Rainier - 2WD | Driver seat module | √ | √ | √ | √ | √ | |
| 2004 | Buick | Rainier - 2WD | Heating and air conditioning | √ | √ | √ | √ | √ | |
| 2004 | Buick | Rainier - 2WD | Supplemental inflatable restraint | √ | √ | √ | √ | | 0531 |
| 2004 | Buick | Rainier - 2WD | Amplifier (bose) | √ | √ | √ | √ | √ | |
| 2004 | Buick | Rainier - 2WD | Radio | √ | √ | √ | √ | | 0524 |
| 2004 | Buick | Rainier - 2WD | Rear seat audio | √ | √ | √ | √ | | |
| 2004 | Buick | Rainier - 2WD | Lift gate module | √ | √ | √ | √ | √ | |
| 2004 | Buick | Rainier - 2WD | Rear seat entertainment | √ | √ | √ | √ | √ | 0550 |
| 2004 | Buick | Rainier - 2WD | Navigation radio | √ | √ | √ | √ | √ | 0525 |
| 2004 | Buick | Rainier - 2WD | ABS | √ | √ | √ | √ | √ | |
| 2004 | Buick | Rainier - 2WD | 4WAL 3 sensor | √ | √ | √ | √ | √ | 0647 0683 |
| 2004 | Buick | Rendezvous - AWD | Powertrain | √ | √ | √ | √ | √ | |
| 2004 | Buick | Rendezvous - AWD | Onstar | √ | √ | √ | √ | √ | 0647 0683 |
| 2004 | Buick | Rendezvous - AWD | Digital radio receiver | √ | √ | √ | √ | | 0516 |
| 2004 | Buick | Rendezvous - AWD | Body Control Module | | √ | √ | √ | √ | 0560 0515 0628 0614 0573 0574 0636 0572 |
| 2004 | Buick | Rendezvous - AWD | Navigation radio | √ | √ | √ | √ | | 0525 |
| 2004 | Buick | Rendezvous - AWD | Supplemental inflatable restraint | | √ | √ | √ | | |
| 2004 | Buick | Rendezvous - AWD | Vehicle theft deterrent | | √ | √ | √ | | |
| 2004 | Buick | Rendezvous - AWD | Rear seat entertainment | √ | √ | √ | | | |
| 2004 | Buick | Rendezvous - AWD | Head up dilay | | √ | √ | | | |
| 2004 | Buick | Rendezvous - AWD | Radio | √ | √ | √ | √ | √ | 0573 0574 0636 0572 |
| 2004 | Buick | Rendezvous - AWD | Chassis | √ | √ | √ | √ | √ | 0506 |
| 2004 | Buick | Rendezvous - FWD | Powertrain | √ | √ | √ | √ | √ | |
| 2004 | Buick | Rendezvous - FWD | Onstar | √ | √ | √ | √ | √ | 0647 0683 |
| 2004 | Buick | Rendezvous - FWD | Digital radio receiver | √ | √ | √ | √ | | 0516 |
| 2004 | Buick | Rendezvous - FWD | Body Control Module | | √ | √ | √ | √ | 0560 0515 0628 0614 0573 0574 0636 0572 |
| 2004 | Buick | Rendezvous - FWD | Navigation radio | √ | √ | √ | √ | | 0525 |
| 2004 | Buick | Rendezvous - FWD | Supplemental inflatable restraint | | √ | √ | √ | | |

| | | | | | | | | | |
|------|-------|------------------|-----------------------------------|---|---|---|---|---|---|
| 2004 | Buick | Rendezvous - FWD | Vehicle theft deterrent | | √ | √ | √ | | |
| 2004 | Buick | Rendezvous - FWD | Rear seat entertainment | √ | √ | √ | | | |
| 2004 | Buick | Rendezvous - FWD | Head up display | | √ | √ | | | |
| 2004 | Buick | Rendezvous - FWD | Radio | √ | √ | √ | √ | √ | 0573 0574 0636 0572 |
| 2004 | Buick | Rendezvous - FWD | Chassis | √ | √ | √ | √ | √ | 0506 |
| 2003 | Buick | Century | Powertrain | √ | √ | √ | √ | √ | 0493 |
| 2003 | Buick | Century | Body Control Module | | √ | √ | √ | √ | 0614 0662 0690 0628 |
| 2003 | Buick | Century | Onstar | √ | √ | √ | √ | √ | 0647 0683 |
| 2003 | Buick | Century | Supplemental inflatable restraint | | √ | √ | √ | | 0515 |
| 2003 | Buick | Century | Chassis | √ | √ | √ | √ | √ | 0506 |
| 2003 | Buick | LeSabre | Powertrain | √ | √ | √ | √ | √ | 0493 |
| 2003 | Buick | LeSabre | Dash integration module | | | | √ | √ | 0651 0650 0573 0574 0575 0576 0577 0578 0579 0636 0572 0552 |
| 2003 | Buick | LeSabre | CD changer | | √ | √ | √ | √ | 0614 0664 0615 0619 0665 0666 0618 0604 |
| 2003 | Buick | LeSabre | Climate control panel | | √ | √ | √ | √ | |
| 2003 | Buick | LeSabre | Instrument panel module | | √ | √ | √ | √ | 0630 0667 |
| 2003 | Buick | LeSabre | Onstar | √ | √ | √ | √ | √ | 0647 0683 |
| 2003 | Buick | LeSabre | Digital radio receiver | √ | √ | √ | √ | | 0516 |
| 2003 | Buick | LeSabre | Remote function actuation | | √ | √ | | √ | |
| 2003 | Buick | LeSabre | Supplemental inflatable restraint | | √ | √ | | | |
| 2003 | Buick | LeSabre | Vehicle theft deterrent | | √ | √ | √ | √ | 0651 0650 0573 0574 0575 0576 0577 0578 0579 0636 0572 0552 |
| 2003 | Buick | LeSabre | Memory seat module | √ | √ | √ | √ | √ | 0647 0683 |
| 2003 | Buick | LeSabre | Rear integration module | | √ | √ | √ | √ | |
| 2003 | Buick | LeSabre | DRP/ABS/TIM | | √ | √ | √ | √ | 0506 |
| 2003 | Buick | Park Avenue | Powertrain | √ | √ | √ | √ | √ | 0493 |
| 2003 | Buick | Park Avenue | Body Control Module | | √ | √ | √ | √ | 0614 0668 0684 0630 |
| 2003 | Buick | Park Avenue | Onstar | √ | √ | √ | √ | | 0647 0683 |
| 2003 | Buick | Park Avenue | Personalization | | √ | √ | √ | √ | 0550 0550 |
| 2003 | Buick | Park Avenue | Vehicle theft deterrent | | √ | √ | | | |
| 2003 | Buick | Park Avenue | DRP/ABS/TIM | | √ | √ | √ | √ | 0506 |
| 2003 | Buick | Regal | Powertrain | √ | √ | √ | √ | √ | 0493 |
| 2003 | Buick | Regal | Body Control Module | | √ | √ | √ | √ | 0614 0662 0690 0628 |
| 2003 | Buick | Regal | Onstar | √ | √ | √ | √ | √ | 0647 0683 |
| 2003 | Buick | Regal | Supplemental inflatable restraint | | √ | √ | √ | | 0515 |
| 2003 | Buick | Regal | Chassis | √ | √ | √ | √ | √ | 0506 |
| 2003 | Buick | Rendezvous - AWD | Powertrain | √ | √ | √ | √ | √ | 0493 |
| 2003 | Buick | Rendezvous - AWD | Body Control Module | | √ | √ | √ | √ | 0560 0515 0628 0614 0573 0574 0636 0572 |

| | | | | | | | | | |
|------|-------|------------------|-----------------------------------|---|---|---|---|---|---|
| 2003 | Buick | Rendezvous - AWD | Onstar | √ | √ | √ | √ | √ | 0647 0683 |
| 2003 | Buick | Rendezvous - AWD | Digital radio receiver | √ | √ | √ | √ | √ | 0516 |
| 2003 | Buick | Rendezvous - AWD | Vehicle theft deterrent | | √ | √ | | | |
| 2003 | Buick | Rendezvous - AWD | Supplemental inflatable restraint | | √ | √ | √ | | |
| 2003 | Buick | Rendezvous - AWD | Rear seat entertainment | √ | √ | √ | √ | √ | 0560 0515 0628 0614 0573 0574 0636 0572 |
| 2003 | Buick | Rendezvous - AWD | Chassis | | √ | √ | √ | √ | 0506 |
| 2003 | Buick | Rendezvous - FWD | Powertrain | √ | √ | √ | √ | √ | 0493 |
| 2003 | Buick | Rendezvous - FWD | Body Control Module | | √ | √ | √ | √ | 0560 0515 0628 0614 0573 0574 0636 0572 |
| 2003 | Buick | Rendezvous - FWD | Onstar | √ | √ | √ | √ | √ | 0647 0683 |
| 2003 | Buick | Rendezvous - FWD | Digital radio receiver | √ | √ | √ | √ | √ | 0516 |
| 2003 | Buick | Rendezvous - FWD | Vehicle theft deterrent | | √ | √ | | | |
| 2003 | Buick | Rendezvous - FWD | Supplemental inflatable restraint | | √ | √ | √ | | |
| 2003 | Buick | Rendezvous - FWD | Rear seat entertainment | √ | √ | √ | √ | √ | 0560 0515 0628 0614 0573 0574 0636 0572 |
| 2003 | Buick | Rendezvous - FWD | Chassis | | √ | √ | √ | √ | 0506 |
| 2002 | Buick | Century | Powertrain | √ | √ | √ | √ | √ | 0493 |
| 2002 | Buick | Century | Body Control Module | | √ | √ | √ | √ | 0614 0662 0690 0628 |
| 2002 | Buick | Century | Onstar | √ | √ | √ | √ | √ | 0647 0683 |
| 2002 | Buick | Century | Supplemental inflatable restraint | | √ | √ | √ | | 0515 |
| 2002 | Buick | Century | Chassis | √ | √ | √ | √ | √ | 0506 |
| 2002 | Buick | Lesabre | Powertrain | √ | √ | √ | √ | √ | 0493 |
| 2002 | Buick | Lesabre | Dash integration module | | | | √ | √ | 0651 0650 |
| 2002 | Buick | Lesabre | CD changer | | √ | √ | √ | √ | 0614 0664 0615 0619 0665 0666 0618 0604 |
| 2002 | Buick | Lesabre | Instrument panel module | | √ | √ | √ | √ | 0630 0667 |
| 2002 | Buick | Lesabre | Radio | | | | √ | | 0573 0574 0575 0576 0577 0694 0695 0578 0579 0636 0572 0552 |
| 2002 | Buick | Lesabre | Onstar | √ | √ | √ | √ | | 0647 0683 |
| 2002 | Buick | Lesabre | Remote function actuation | | √ | √ | | √ | |
| 2002 | Buick | Lesabre | Supplemental inflatable restraint | | √ | √ | | | |
| 2002 | Buick | Lesabre | Vehicle theft deterrent | | √ | √ | √ | √ | 0651 0650 |
| 2002 | Buick | Lesabre | Memory seat module | √ | √ | √ | √ | √ | 0573 0574 0575 0576 0577 0694 0695 0578 0579 0636 0572 0552 |
| 2002 | Buick | Lesabre | Rear integration module | | √ | √ | √ | √ | |
| 2002 | Buick | Lesabre | DRP/ABS/TIM | | √ | √ | √ | √ | 0506 |
| 2002 | Buick | Park Avenue | Powertrain | √ | √ | √ | √ | √ | 0493 |
| 2002 | Buick | Park Avenue | Body Control Module | | √ | √ | √ | √ | 0614 0668 0684 0630 |
| 2002 | Buick | Park Avenue | Onstar | √ | √ | √ | √ | | 0647 0683 |

| | | | | | | | | | |
|------|-------|------------------|-----------------------------------|---|---|---|---|---|--|
| 2002 | Buick | Park Avenue | Personalization | | √ | √ | √ | √ | 0550 0550 |
| 2002 | Buick | Park Avenue | Vehicle theft deterrent | | √ | √ | | | |
| 2002 | Buick | Park Avenue | DRP/ABS/TIM | | √ | √ | √ | √ | 0506 |
| 2002 | Buick | Regal | Powertrain | √ | √ | √ | √ | √ | 0493 |
| 2002 | Buick | Regal | Body Control Module | | √ | √ | √ | √ | 0614 0662 0690 0628 |
| 2002 | Buick | Regal | Onstar | √ | √ | √ | √ | √ | 0647 0683 |
| 2002 | Buick | Regal | Supplemental inflatable restraint | | √ | √ | √ | | 0515 |
| 2002 | Buick | Regal | Chassis | √ | √ | √ | √ | √ | 0506 |
| 2002 | Buick | Rendezvous - AWD | Powertrain | √ | √ | √ | √ | √ | 0493 |
| 2002 | Buick | Rendezvous - AWD | Body Control Module | | √ | √ | √ | √ | 0560 0515 0628 0614 0705 0573 0574 0636 |
| 2002 | Buick | Rendezvous - AWD | Onstar | √ | √ | √ | √ | | 0647 0683 |
| 2002 | Buick | Rendezvous - AWD | Supplemental inflatable restraint | | √ | √ | | | |
| 2002 | Buick | Rendezvous - AWD | Vehicle theft deterrent | √ | √ | √ | √ | √ | 0560 0515 0628 0614 0705 0573 0574 0636 |
| 2002 | Buick | Rendezvous - AWD | Chassis | | √ | √ | √ | √ | 0506 |
| 2002 | Buick | Rendezvous - FWD | Powertrain | √ | √ | √ | √ | √ | 0493 |
| 2002 | Buick | Rendezvous - FWD | Body Control Module | | √ | √ | √ | √ | 0560 0515 0628 0614 0705 0573 0574 0636 |
| 2002 | Buick | Rendezvous - FWD | Onstar | √ | √ | √ | √ | | 0647 0683 |
| 2002 | Buick | Rendezvous - FWD | Supplemental inflatable restraint | | √ | √ | | | |
| 2002 | Buick | Rendezvous - FWD | Vehicle theft deterrent | √ | √ | √ | √ | √ | 0560 0515 0628 0614 0705 0573 0574 0636 |
| 2002 | Buick | Rendezvous - FWD | Chassis | | √ | √ | √ | √ | 0506 |
| 2001 | Buick | Century | Powertrain | √ | √ | √ | √ | √ | 0493 |
| 2001 | Buick | Century | Body Control Module | | √ | √ | √ | √ | 0614 0662 0690 |
| 2001 | Buick | Century | Onstar | √ | √ | √ | √ | | 0683 |
| 2001 | Buick | Century | Supplemental inflatable restraint | | √ | √ | √ | | 0515 |
| 2001 | Buick | Century | Chassis | √ | √ | √ | √ | √ | 0506 |
| 2001 | Buick | Lesabre | Powertrain | √ | √ | √ | √ | √ | 0493 |
| 2001 | Buick | Lesabre | Dash integration module | | | | √ | √ | 0650 0574 0576 |
| 2001 | Buick | Lesabre | CD changer | | √ | √ | √ | √ | 0614 0664 0615 0619 0665 0666 0618 0604 |
| 2001 | Buick | Lesabre | Instrument panel module | | √ | √ | √ | √ | 0630 0667 |
| 2001 | Buick | Lesabre | Radio | | | | | | 0525 |
| 2001 | Buick | Lesabre | Onstar | √ | √ | √ | √ | | 0683 |
| 2001 | Buick | Lesabre | Vehicle theft deterrent | | √ | √ | | | |
| 2001 | Buick | Lesabre | Supplemental inflatable restraint | | √ | √ | | | |
| 2001 | Buick | Lesabre | Remote function actuation | | √ | √ | √ | √ | 0650 0574 0576 |
| 2001 | Buick | Lesabre | Climate control panel | √ | √ | √ | √ | √ | 0525 |
| 2001 | Buick | Lesabre | Rear integration module | | √ | √ | √ | √ | |
| 2001 | Buick | Lesabre | DRP/ABS/TIM | | √ | √ | √ | √ | 0506 |

| | | | | | | | | | |
|------|-------|-------------|-----------------------------------|---|---|---|---|---|--|
| 2001 | Buick | Park Avenue | Powertrain | √ | √ | √ | √ | √ | 0493 |
| 2001 | Buick | Park Avenue | Body Control Module | | √ | √ | √ | √ | 0614 0668 0684 0630 |
| 2001 | Buick | Park Avenue | Onstar | √ | √ | √ | √ | | 0683 |
| 2001 | Buick | Park Avenue | Vehicle theft deterrent | | √ | √ | | | |
| 2001 | Buick | Park Avenue | Personalization | | √ | √ | √ | √ | 0550 0550 |
| 2001 | Buick | Park Avenue | DRP/ABS/TIM | | √ | √ | √ | √ | 0506 |
| 2001 | Buick | Regal | Powertrain | √ | √ | √ | √ | √ | 0493 |
| 2001 | Buick | Regal | Body Control Module | | √ | √ | √ | √ | 0614 0662 0690 |
| 2001 | Buick | Regal | Onstar | √ | √ | √ | √ | | 0683 |
| 2001 | Buick | Regal | Supplemental inflatable restraint | | √ | √ | √ | | 0515 |
| 2001 | Buick | Regal | Chassis | √ | √ | √ | √ | √ | 0506 |
| 2000 | Buick | Century | Powertrain | √ | √ | √ | √ | √ | 0493 |
| 2000 | Buick | Century | Body Control Module | | √ | √ | √ | √ | 0614 0662 0690 |
| 2000 | Buick | Century | Onstar | √ | √ | √ | √ | | 0683 |
| 2000 | Buick | Century | Supplemental inflatable restraint | | √ | √ | √ | | 0515 |
| 2000 | Buick | Century | Chassis | √ | √ | √ | | √ | 0506 |
| 2000 | Buick | Lesabre | Powertrain | √ | √ | √ | √ | √ | 0493 |
| 2000 | Buick | Lesabre | Dash integration module | | √ | √ | √ | √ | 0650 0574 0576 |
| 2000 | Buick | Lesabre | CD changer | | √ | √ | √ | √ | 0614 0664 0615 0619 0665 0666 0618 0604 0628 0604 0691 |
| 2000 | Buick | Lesabre | Instrument panel module | | √ | √ | √ | √ | 0630 0667 |
| 2000 | Buick | Lesabre | Radio | | | | | | 0525 |
| 2000 | Buick | Lesabre | Onstar | √ | √ | √ | √ | √ | 0683 |
| 2000 | Buick | Lesabre | Climate control panel | √ | √ | √ | √ | √ | 0525 |
| 2000 | Buick | Lesabre | Rear integration module | | √ | √ | √ | √ | |
| 2000 | Buick | Lesabre | DRP/ABS/TIM | | √ | √ | √ | √ | 0506 |
| 2000 | Buick | Park Avenue | Powertrain | √ | √ | √ | √ | √ | 0493 |
| 2000 | Buick | Park Avenue | Body Control Module | | √ | √ | √ | √ | 0614 0668 0684 0630 0531 0692 |
| 2000 | Buick | Park Avenue | Onstar | √ | √ | √ | √ | | 0683 |
| 2000 | Buick | Park Avenue | DRP/ABS/TIM | | √ | √ | √ | √ | 0506 |
| 2000 | Buick | Regal | Powertrain | √ | √ | √ | √ | √ | 0493 |
| 2000 | Buick | Regal | Body Control Module | | √ | √ | √ | √ | 0614 0662 0690 |
| 2000 | Buick | Regal | Onstar | √ | √ | √ | √ | | 0683 |
| 2000 | Buick | Regal | Supplemental inflatable restraint | | √ | √ | √ | | 0515 |
| 2000 | Buick | Regal | Chassis | √ | √ | √ | | √ | 0506 |
| 1999 | Buick | Century | Powertrain | √ | √ | √ | √ | √ | 0493 |
| 1999 | Buick | Century | Body Control Module | | √ | √ | √ | √ | 0614 0662 0690 0628 |
| 1999 | Buick | Century | Onstar | | √ | √ | √ | | 0683 |
| 1999 | Buick | Century | Onstar (VS-3B) | | √ | √ | √ | | |
| 1999 | Buick | Century | Supplemental inflatable restraint | | √ | √ | √ | | 0515 |

| | | | | | | | | | |
|------|-------|-------------|-----------------------------------|---|---|---|---|---|--|
| 1999 | Buick | Century | Chassis | √ | √ | √ | √ | √ | 0506 |
| 1999 | Buick | Lesabre | Powertrain | √ | √ | √ | √ | √ | 0493 |
| 1999 | Buick | Lesabre | Body Control Module | | √ | √ | √ | √ | 0614 0668 0550 0684 0550 0531 0692 |
| 1999 | Buick | Lesabre | Onstar | | √ | √ | √ | | 0683 |
| 1999 | Buick | Lesabre | Onstar (VS-3B) | | √ | √ | √ | | |
| 1999 | Buick | Lesabre | Remote function actuation | | √ | √ | √ | √ | 0711 0716 0717 0718 0719 0720 0721 0722 |
| 1999 | Buick | Lesabre | ABS | | √ | √ | | √ | 0641 0506 |
| 1999 | Buick | Park Avenue | Powertrain | √ | √ | √ | √ | √ | 0493 |
| 1999 | Buick | Park Avenue | Body Control Module | | √ | √ | √ | √ | 0614 0668 0550 0684 0550 0531 0692 |
| 1999 | Buick | Park Avenue | Onstar | | √ | √ | √ | | 0683 |
| 1999 | Buick | Park Avenue | Onstar (VS-3B) | | √ | √ | √ | | |
| 1999 | Buick | Park Avenue | ABS | | √ | √ | | √ | 0641 0506 |
| 1999 | Buick | Regal | Powertrain | √ | √ | √ | √ | √ | 0493 |
| 1999 | Buick | Regal | Body Control Module | | √ | √ | √ | √ | 0614 0662 0690 0628 |
| 1999 | Buick | Regal | Onstar | | √ | √ | √ | | 0683 |
| 1999 | Buick | Regal | Onstar (VS-3B) | | √ | √ | √ | | |
| 1999 | Buick | Regal | Supplemental inflatable restraint | | √ | √ | √ | √ | 0515 |
| 1999 | Buick | Regal | Chassis | √ | √ | √ | | √ | 0506 |
| 1999 | Buick | Riviera | Powertrain | √ | √ | √ | √ | √ | 0493 |
| 1999 | Buick | Riviera | Remote function actuation | | | | √ | √ | 0711 0716 0717 0718 0719 0720 0721 0722 |
| 1999 | Buick | Riviera | Onstar | | √ | √ | √ | | 0683 |
| 1999 | Buick | Riviera | Onstar (VS-3B) | | √ | √ | √ | | |
| 1998 | Buick | Century | Powertrain | √ | √ | √ | √ | √ | 0493 |
| 1998 | Buick | Century | Body Control Module | | √ | √ | √ | √ | 0614 0662 0690 |
| 1998 | Buick | Century | Onstar | | √ | √ | √ | | 0683 |
| 1998 | Buick | Century | Chassis | | √ | √ | | √ | |
| 1998 | Buick | Lesabre | Powertrain | √ | √ | √ | √ | √ | 0493 |
| 1998 | Buick | Lesabre | Body Control Module | | √ | √ | √ | √ | 0614 0668 0550 0684 0550 0531 0692 |
| 1998 | Buick | Lesabre | Onstar | | √ | √ | √ | | 0683 |
| 1998 | Buick | Lesabre | Remote function actuation | | | | √ | √ | 0711 0716 0717 0718 0719 0720 0721 0722 |
| 1998 | Buick | Lesabre | Entertainment & comfort bus | | √ | √ | √ | √ | 0683 |
| 1998 | Buick | Lesabre | ABS | | √ | √ | | √ | 0641 0506 |
| 1998 | Buick | Park Avenue | Powertrain | √ | √ | √ | √ | √ | 0493 |
| 1998 | Buick | Park Avenue | Body Control Module | | √ | √ | √ | √ | 0614 0668 0550 0684 0550 0531 0692 |
| 1998 | Buick | Park Avenue | Onstar | | √ | √ | √ | | 0683 |

| | | | | | | | | | |
|------|-------|-------------|---------------------------|---|---|---|---|---|--|
| 1998 | Buick | Park Avenue | ABS | | √ | √ | | √ | 0641 0506 |
| 1998 | Buick | Regal | Powertrain | √ | √ | √ | √ | √ | 0493 |
| 1998 | Buick | Regal | Body Control Module | | √ | √ | √ | √ | 0614 0662 0690 |
| 1998 | Buick | Regal | Onstar | | √ | √ | √ | | 0683 |
| 1998 | Buick | Regal | Chassis | | √ | √ | | √ | |
| 1998 | Buick | Riviera | Powertrain | √ | √ | √ | √ | √ | 0493 |
| 1998 | Buick | Riviera | Remote function actuation | | | | √ | √ | 0711 0716 0717 0718 0719 0720 0721 0722 |
| 1998 | Buick | Riviera | Onstar | | √ | √ | √ | | 0683 |
| 1998 | Buick | Skylark | Powertrain | √ | √ | √ | √ | √ | 0493 |
| 1998 | Buick | Skylark | Chassis | | √ | √ | √ | √ | |
| 1997 | Buick | Century | Powertrain | √ | √ | √ | √ | √ | 0493 |
| 1997 | Buick | Century | Body Control Module | | √ | √ | √ | √ | 0614 0662 0690 |
| 1997 | Buick | Lesabre | Powertrain | √ | √ | √ | √ | √ | 0493 |
| 1997 | Buick | Lesabre | Body Control Module | | √ | √ | √ | √ | 0614 0668 0550 0684 0550 0531 0692 |
| 1997 | Buick | Lesabre | Remote function actuation | | | | √ | √ | 0711 0716 0717 0718 0719 0720 0721 0722 |
| 1997 | Buick | Lesabre | ABS | | √ | √ | | √ | 0641 0506 |
| 1997 | Buick | Park Avenue | Powertrain | √ | √ | √ | √ | √ | 0493 |
| 1997 | Buick | Park Avenue | Body Control Module | | √ | √ | √ | √ | 0614 0668 0550 0684 0550 0531 0692 |
| 1997 | Buick | Park Avenue | ABS | | √ | √ | | √ | 0641 0506 |
| 1997 | Buick | Regal | Powertrain | √ | √ | √ | √ | √ | 0493 |
| 1997 | Buick | Regal | Body Control Module | | √ | √ | √ | √ | 0614 0662 0690 |
| 1997 | Buick | Riviera | Powertrain | √ | √ | √ | √ | √ | 0493 |
| 1997 | Buick | Riviera | Remote function actuation | | | | √ | √ | 0711 0716 0717 0718 0719 0720 0721 0722 |
| 1997 | Buick | Skylark | Powertrain | √ | √ | √ | √ | √ | 0493 |
| 1996 | Buick | Century | Powertrain | √ | √ | √ | √ | √ | |
| 1996 | Buick | Lesabre | Powertrain | √ | √ | √ | √ | √ | |
| 1996 | Buick | Lesabre | Remote function actuation | | | | √ | √ | 0711 0716 0717 0718 0719 0720 0721 0722 |
| 1996 | Buick | Park Avenue | Powertrain | √ | √ | √ | √ | √ | |
| 1996 | Buick | Park Avenue | Remote function actuation | | | | √ | √ | 0711 0716 0717 0718 0719 0720 0721 0722 |
| 1996 | Buick | Regal | Powertrain | √ | √ | √ | √ | √ | |
| 1996 | Buick | Riviera | Powertrain | √ | √ | √ | √ | √ | |
| 1996 | Buick | Riviera | Remote function actuation | | | | √ | √ | 0711 0716 0717 0718 0719 0720 0721 0722 |
| 1996 | Buick | Roadmaster | Powertrain | √ | √ | √ | √ | √ | |
| 1996 | Buick | Skylark | Powertrain | √ | √ | √ | √ | √ | |