



# Shenzhen Xtooltech Co., Ltd

## AUDI V28.14

Description: ○: All support by OBD      △: Partially support by OBD      □: All support (Disassembly)  
 ●: All support by OBD(Need accessories)      ▲: Partially support by OBD(Need accessories)      ■: Partially support (Disassembly)  
 ×: Not support      /:Unnecessary      ◎: Conditional support

Make	Area	Model	Year	Read PIN	Add Keys	All Keys Lost	Programme Remote	Other Functions
AUDI	Europe	A1 (8X/FT) 2011	2011-2014	○	●	□	○	1. Synchronize dashboard time 2. Read dashboard information 3. IMMO status
AUDI	Europe	A1 (8X/FT) 2011	2015-	○	●	□	○	1. Synchronize dashboard time 2. Read dashboard information 3. IMMO status
AUDI	Europe	A3/S3/RS3 (8L) 1997	1997-2003	■	△	△	△	
AUDI	Europe	A3/S3/RS3 (8P/FM) 2004	2004-2013/5	○	●	×	○	1. Synchronize dashboard time 2. Read dashboard information 3. IMMO status
AUDI	Europe	A3/S3/RS3 (8V/FF) 2013	2013/6-	/	●	×	/	1. Synchronize dashboard time 2. Read dashboard information 3. IMMO status
AUDI	Europe	A4/RS4 B6 (8E/8H) 2001	2001-2006	△	△	△	△	
AUDI	Europe	A4/RS4 B7 (8E/8H) 2004	2004-2008	△	△	△	△	
AUDI	Europe	A4/RS4 (8K/FL) 2008	2008-2013	/	●	×	/	1. End the key learning mode 2. Unlock the OEM key 3. IMMO status
AUDI	Europe	A4/RS4 (8K/FL) 2008	2013-2016/8	×	×	×	×	
AUDI	Europe	A5/RS5 (8F/8T/FH/FR) 2008	2008-2013	/	●	×	/	1. End the key learning mode 2. Unlock the OEM key 3. IMMO status
AUDI	Europe	A5/RS5 (8F/8T/FH/FR) 2008	2013-2016	×	×	×	×	
AUDI	Europe	A6/A11road/RS6 (4B) 1998	1998-2004	△	△	△	△	
AUDI	Europe	A6/A11road/RS6 (4F/FB) 2004	2004-2011	○	●	□	○	1. Unlock the key 2. IMMO status 3. Synchronize dashboard time
AUDI	Europe	A6/A11road/RS6 (4G/FC) 2011	2011-2018	/	●	×	/	1. End the key learning mode 2. Unlock the OEM key 3. IMMO status
AUDI	Europe	A7/RS7 (4G/FC) 2010	2010-2018	/	●	×	/	1. End the key learning mode 2. Unlock the OEM key 3. IMMO status

AUDI	Europe	A8/S8 (4D) 1997	1997-2003	△	△	△	△	
AUDI	Europe	A8/S8 (4E) 2003	2003-2010	×	×	×	×	
AUDI	Europe	A8/S8 (4H/FD) 2010	2010-2017	/	●	×	/	1. End the key learning mode 2. Unlock the OEM key 3. IMMO status
AUDI	Europe	Q2 (GA)	2017-	/	●	×	/	1. Synchronize dashboard time 2. Read dashboard information 3. IMMO status
AUDI	Europe	Q3/RSQ3 (8U/FS) 2012	2012-2015	○	●	□	○	1. Synchronize dashboard time 2. Read dashboard information 3. IMMO status
AUDI	Europe	Q3/RSQ3 (8U/FS) 2012	2015-	○	●	□	○	1. Synchronize dashboard time 2. Read dashboard information 3. IMMO status
AUDI	Europe	Q5 (8R/FP) 2009	2009-2011	/	●	×	/	1. End the key learning mode 2. Unlock the OEM key 3. IMMO status
AUDI	Europe	Q5 (8R/FP) 2009	2011-2017	×	×	×	×	
AUDI	Europe	Q7 (4L/FE) 2007	2007-2015	○	□	□	○	1. Synchronize dashboard time 2. Read dashboard information 3. IMMO status
AUDI	Europe	R8 (42/FG) 2006	2006-2015	○	●	×	○	1. Unlock the key 2. IMMO status 3. Synchronize dashboard time
AUDI	Europe	TT (8N) 1999	1999-2006	○	○	○	○	
AUDI	Europe	TT (8J/FK) 2007	2007-2015	○	●	×	○	1. Unlock the key 2. IMMO status 3. Synchronize dashboard time
FAW AUDI	China	A3/S3/RS3 (8V/FF) 2013	2013/06-	/	●	×	/	1. Unlock the key 2. IMMO status 3. Synchronize dashboard time
FAW AUDI	China	A3/S3/RS3 (8V/FF) 2001	2001-2008	△	△	△	△	
FAW AUDI	China	A4/RS4 (8K/FL) 2008	2008-2013	/	●	×	/	1. End the key learning mode 2. Unlock the OEM key 3. IMMO status
FAW AUDI	China	A4/RS4 (8K/FL) 2008	2013-2016	×	×	×	×	
FAW AUDI	China	A6/Allroad/RS6 (4B) 1998	1998-2004	△	△	△	△	
FAW AUDI	China	A6/Allroad/RS6 (4F/FB) 2004	2004-2011	○	□	□	○	1. Unlock the key 2. IMMO status 3. Synchronize dashboard time
FAW AUDI	China	A6/Allroad/RS6 (4G/FC) 2011	2011-2018	/	●	×	/	1. End the key learning mode 2. Unlock the OEM key 3. IMMO status

FAW AUDI	China	Q3/RSQ3 (8U/FS) 2012	2012-2015	○	●	□	○	1. Unlock the key 2. IMMO status 3. Synchronize dashboard time
FAW AUDI	China	Q3/RSQ3 (8U/FS) 2012	2015-	○	●	□	○	1. Unlock the key 2. IMMO status 3. Synchronize dashboard time
FAW AUDI	China	Q5 (8R/FP) 2009	2009-2011	/	●	×	/	1. End the key learning mode 2. Unlock the OEM key 3. IMMO status
FAW AUDI	China	Q5 (8R/FP) 2009	2011-2017	×	×	×	×	

*XTOOL*