



深圳市朗仁科技有限公司
Shenzhen Xtooltech Co., Ltd

Software Version: 26.18

| Automaker | Model/Protocol | Year | System | Function |
|------------|----------------|-----------|---------------------|--|
| China Ford | | | Pincode Calculate | |
| China Ford | Ecosport | | Immobiliser | 1.Add a key 2.Erase keys 3.All keys lost |
| China Ford | Escort | | Immobiliser | 1.Read number of keys 2.Add a key 3.All keys lost |
| China Ford | Focus | | Immobiliser(Type 1) | 1.All keys lost 2.Add a key 3.Program immobiliser and engine ECU |
| China Ford | Focus | | Immobiliser(Type 2) | 1.Add a key |
| China Ford | Focus | 2012-2013 | Immobiliser(Type 3) | 1.Add a key 2.Erase keys |
| China Ford | Focus | 2014- | Immobiliser(Type 4) | 1.Add a key 2.Erase keys 3.All keys lost |
| China Ford | Fiesta | -2013 | Immobiliser | 1.Add a key 2.Erase keys 3.Read number of keys |
| China Ford | Fiesta | 2013- | Immobiliser | 1.Add a key 2.Erase keys |

| | | | | |
|------------|-------------|-----------|-------------|---|
| China Ford | Kuga | | Immobiliser | 1.Add a key 2.Erase keys 3.All keys lost |
| China Ford | Mondeo(PWM) | | Immobiliser | 1.Current number of keys 2.All keys lost |
| China Ford | Mondeo | -2010 | Immobiliser | 1.Read number of keys 2.Add a key 3.Erase keys 4.All keys lost |
| China Ford | Mondeo | 2011- | Immobiliser | 1.Read number of keys 2.Add a key 3.Erase keys 4.All keys lost |
| China Ford | Mondeo | 2013- | Immobiliser | 1.Read number of keys 2.Add a key 3.All keys lost |
| China Ford | S-Max | -2010 | Immobiliser | 1.Read number of keys 2.Add a key 3.Erase keys 4.All keys lost |
| China Ford | S-Max | 2011- | Immobiliser | 1.Read number of keys 2.Add a key 3.Erase keys 4.All keys lost |
| China Ford | Transit | | Immobiliser | 1.Live data 2.Add a key 3.All keys lost |
| China Ford | Edge | 2007-2009 | Immobiliser | 1.Number of keys 2.All keys lost 3.Add a key |
| China Ford | Edge | 2010 | Immobiliser | 1.Number of keys 2.All keys lost 3.Add a key |

| | | | | |
|------------|-----------|-----------|------------------|--|
| China Ford | Edge | 2011 | Immobiliser | 1.Number of keys 2.All keys lost 3.Add a key |
| China Ford | Ecosport | | Smart key system | 1.All smart keys lost 2.Add a smart key |
| China Ford | Edge | -2015 | Smart key system | |
| China Ford | Edge | 2015- | Smart key system | 1.Read number of keys 2.Add a key 3.All keys lost |
| China Ford | Focus | | Smart key system | 1. Add a smart key 2.Erase smart keys 3.Help |
| China Ford | Kuga | | Smart key system | 1.Add a smart key 2.Erase smart keys 3.Help |
| China Ford | Mondeo | | Smart key system | 1.All smart keys lost 2.Add a smart key |
| China Ford | Mondeo | 2013- | Smart key system | 1.Read number of keys 2.Add a key 3.All keys lost |
| USA Ford | Crown Vic | 2005-2006 | Immobiliser | 1.Number of keys 2.Add a key 3.All Keys lost |
| USA Ford | Crown Vic | 2007- | Immobiliser | 1.Number of keys 2.Add a key 3.All Keys lost |
| USA Ford | E250 | | Immobiliser | 1.All keys lost 2.Add a key 3.Program immobiliser and engine ECU |
| USA Ford | Edge | 2007-2009 | Immobiliser | 1.Number of keys 2.All keys lost 3.Add a key |
| USA Ford | Edge | 2010 | Immobiliser | 1.Number of keys 2.All keys lost 3.Add a key |
| USA Ford | Edge | 2011- | Immobiliser | 1.Number of keys 2.All keys lost 3.Add a key |
| USA Ford | Escape | 2005-2007 | Immobiliser | 1.Number of keys 2.All keys lost 3.Add a key |

| | | | | |
|----------|-------------|-----------|-------------|--|
| USA Ford | Escape | 2008-2009 | Immobiliser | 1.Number of keys 2.Add a key 3.All keys lost |
| USA Ford | Escape | 2010- | Immobiliser | 1.Number of keys 2.All keys lost 3.Add a key |
| USA Ford | E-Series | 2008-2009 | Immobiliser | 1.Number of keys 2.Add a key 3.All Keys lost |
| USA Ford | E-Series | 2010 | Immobiliser | 1.Number of keys 2.All keys lost 3.Add a key |
| USA Ford | Expedition | 2005-2006 | Immobiliser | 1.Number of keys 2.Add a key 3.All Keys lost |
| USA Ford | Expedition | 2007-2008 | Immobiliser | 1.Number of keys 2.Add a key 3.All keys lost |
| USA Ford | Expedition | 2009-2012 | Immobiliser | 1.Number of keys 2.All keys lost 3.Add a key |
| USA Ford | Explorer | 2004-2005 | Immobiliser | 1.Number of keys 2.Add a key 3.All Keys lost |
| USA Ford | Explorer | 2006-2009 | Immobiliser | 1.Number of keys 2.Add a key 3.All keys lost |
| USA Ford | Explorer | 2010 | Immobiliser | 1.Number of keys 2.All keys lost 3.Add a key |
| USA Ford | Explorer | 2011- | Immobiliser | 1.Number of keys 2.All keys lost 3.Add a key |
| USA Ford | Expl. Start | 2007-2009 | Immobiliser | 1.Number of keys 2.Add a key 3.All Keys lost |
| USA Ford | Expl. Start | 2010- | Immobiliser | 1.Number of keys 2.All keys lost 3.Add a key |
| USA Ford | F-150 | 2004-2008 | Immobiliser | 1.Number of keys 2.Add a key 3.All Keys lost |

| | | | | |
|----------|-----------|-----------|-------------|--|
| USA Ford | F-150 | 2009-2010 | Immobiliser | 1.Number of keys 2.Add a key 3.All keys lost |
| USA Ford | F-150 | 2011- | Immobiliser | 1.Number of keys 2.All keys lost 3.Add a key |
| USA Ford | F-250 | 2004-2008 | Immobiliser | 1.Number of keys 2.Add a key 3.All Keys lost |
| USA Ford | F-250 | 2009-2010 | Immobiliser | 1.Number of keys 2.Add a key 3.All keys lost |
| USA Ford | F-250 | 2011- | Immobiliser | 1.Number of keys 2.All keys lost 3.Add a key |
| USA Ford | F-250 SD | 2008-2009 | Immobiliser | 1.Number of keys 2.Add a key 3.All keys lost |
| USA Ford | F-250 SD | 2010 | Immobiliser | 1.Number of keys 2.All keys lost 3.Add a key |
| USA Ford | F-250 SD | 2011- | Immobiliser | 1.Number of keys 2.All keys lost 3.Add a key |
| USA Ford | F-350 SD | 2008-2009 | Immobiliser | 1.Number of keys 2.Add a key 3.All keys lost |
| USA Ford | F-350 SD | 2010 | Immobiliser | 1.Number of keys 2.All keys lost 3.Add a key |
| USA Ford | F-350 SD | 2011- | Immobiliser | 1.Number of keys 2.All keys lost 3.Add a key |
| USA Ford | Fiesta | 2005-2010 | Immobiliser | 1.Number of keys 2.Add a key 3.All Keys lost |
| USA Ford | Fiesta | 2011 | Immobiliser | 1.Number of keys 2.All keys lost 3.Add a key |
| USA Ford | Five Hund | 2005-2007 | Immobiliser | 1.Number of keys 2.Add a key 3.All Keys lost |

| | | | | |
|----------|-----------|-----------|-------------|--|
| USA Ford | Flex | 2009 | Immobiliser | 1.Number of keys 2.Add a key 3.All Keys lost |
| USA Ford | Flex | 2010 | Immobiliser | 1.Number of keys 2.All keys lost 3.Add a key |
| USA Ford | Flex | 2011- | Immobiliser | 1.Number of keys 2.All keys lost 3.Add a key |
| USA Ford | Focus | 2005-2007 | Immobiliser | 1.Number of keys 2.Add a key 3.All Keys lost |
| USA Ford | Focus | 2008-2010 | Immobiliser | 1.Number of keys 2.Add a key 3.All Keys lost |
| USA Ford | Focus | 2011 | Immobiliser | 1.Number of keys 2.All keys lost 3.Add a key |
| USA Ford | Freestart | 2006- | Immobiliser | 1.Number of keys 2.Add a key 3.All Keys lost |
| USA Ford | Freestyle | 2005-2007 | Immobiliser | 1.Number of keys 2.Add a key 3.All Keys lost |
| USA Ford | Fusion | 2006-2009 | Immobiliser | 1.Number of keys 2.Add a key 3.All Keys lost |
| USA Ford | Fusion | 2010- | Immobiliser | 1.Number of keys 2.All keys lost 3.Add a key |
| USA Ford | Mustang | 2005-2009 | Immobiliser | 1.Number of keys 2.Add a key 3.All Keys lost |
| USA Ford | Mustang | 2009-2010 | Immobiliser | 1.Number of keys 2.Add a key 3.All keys lost |
| USA Ford | Mustang | 2010 | Immobiliser | 1.Number of keys 2.All keys lost 3.Add a key |
| USA Ford | Mustang | 2011- | Immobiliser | 1.Number of keys 2.All keys lost 3.Add a key |

| | | | | |
|----------|--------------|-----------|-----------------------------|---|
| USA Ford | Ranger | 2015 | Immobiliser | 1.Add key 2.Erase keys 3.All lost 4.Number of key |
| USA Ford | Ranger | 2007-2010 | Immobiliser | 1.Number of keys 2.Add a key 3.All keys lost |
| USA Ford | Taurus | 2004-2007 | Immobiliser | 1.Number of keys 2.Add a key 3.All Keys lost |
| USA Ford | Taurus | 2008-2009 | Immobiliser | 1.Number of keys 2.Add a key 3.All keys lost |
| USA Ford | Taurus | 2010- | Immobiliser | 1.Number of keys 2.All keys lost 3.Add a key |
| USA Ford | Taurus X | 2008-2009 | Immobiliser | 1.Number of keys 2.Add a key 3.All keys lost |
| USA Ford | Windstar | 2007- | Immobiliser | 1.Number of keys 2.Add a key 3.All Keys lost |
| USA Ford | Other models | | PCM immobilizer system(PWM) | 1.Current number of keys 2.All keys lost |
| USA Ford | Edge | | Smart key system | 1.Erase smart keys 2.Program smart keys |
| USA Ford | Explorer | 2011- | Smart key system | 1.Erase smart keys 2.Program smart keys |
| USA Ford | F-150 | 2011-2014 | Smart key system | 1.Erase smart keys 2.Program smart keys |
| USA Ford | F-150 | 2015- | Smart key system | |
| USA Ford | F-250 | 2011- | Smart key system | 1.Erase smart keys 2.Program smart keys |
| USA Ford | Flex | 2013- | Smart key system | 1.Erase smart keys 2.Program smart keys |
| USA Ford | Mustang | 2015- | Smart key system | 1.Read number of keys 2.Read security code 3.Add a key 4.All keys lost |
| USA Ford | Taurus | 2010- | Smart key system | 1.Erase smart keys 2.Program smart keys |

| | | | | |
|----------|-----------------|-----------|------------------|--|
| AUS Ford | C-Max | | Immobiliser | 1.Number of keys 2.Add a key 3.All Keys lost |
| AUS Ford | Cougar | | Immobiliser | 1.Current number of keys 2.All keys lost |
| AUS Ford | Courier(Petrol) | 1998-2000 | Immobiliser | 1.Current number of keys 2.All keys lost |
| AUS Ford | Courier(Petrol) | 2001-2008 | Immobiliser | 1.Number of keys 2.Add a key 3.All Keys lost |
| AUS Ford | Courier(Petrol) | 2008- | Immobiliser | 1.Add a key 2.Erase keys 3.Read number of keys |
| AUS Ford | Courier(Petrol) | 2008- | Smart key system | 1.Erase smart keys 2.Program smart keys |
| AUS Ford | Courier(Diesel) | 1998-2000 | Immobiliser | 1.Current number of keys 2.All keys lost |
| AUS Ford | Courier(Diesel) | 2001-2008 | Immobiliser | 1.Number of keys 2.Add a key 3.All Keys lost |
| AUS Ford | Courier(Diesel) | 2008- | Immobiliser | 1.Add a key 2.Erase keys 3.Read number of keys |
| AUS Ford | Courier(Diesel) | 2008- | Smart key system | 1.Erase smart keys 2.Program smart keys |
| AUS Ford | Escape | | Immobiliser | 1.Current number of keys 2.All keys lost |
| AUS Ford | Escape ZD | | Immobiliser | 1.Number of keys 2.Add a key 3.All Keys lost |
| AUS Ford | Fairlane(PCM) | | Immobiliser | 1.Parameter Reset |
| AUS Ford | Fairlane(BEM) | | Immobiliser | 1.All keys lost |
| AUS Ford | Fairmont(PCM) | | Immobiliser | 1.Parameter Reset |
| AUS Ford | Fairmont(BEM) | | Immobiliser | 1.All keys lost |
| AUS Ford | AUFalcon(PCM) | | Immobiliser | 1.Parameter Reset |
| AUS Ford | AUFalcon(BEM) | | Immobiliser | 1.All keys lost |
| AUS Ford | BA Falcon | | Immobiliser | 1.All Keys lost |
| AUS Ford | BF Falcon | | Immobiliser | 1.Number of keys 2.Add a key 3.All Keys lost |

| | | | | |
|----------|----------------|-----------|------------------|--|
| AUS Ford | Fiesta(Petrol) | 1998-2000 | Immobiliser | 1.Current number of keys 2.All keys lost |
| AUS Ford | Fiesta(Petrol) | 2001-2008 | Immobiliser | 1.Number of keys 2.Add a key 3.All Keys lost |
| AUS Ford | Fiesta(Petrol) | 2008-2012 | Immobiliser | 1.Add a key 2.Erase keys 3.Read number of keys |
| AUS Ford | Fiesta(Petrol) | 2008-2012 | Smart key system | 1.Erase smart keys 2.Program smart keys |
| AUS Ford | Fiesta(Diesel) | 1999-2001 | Immobiliser | 1.Current number of keys 2.All keys lost |
| AUS Ford | Fiesta(Diesel) | 2001-2008 | Immobiliser | 1.Number of keys 2.Add a key 3.All Keys lost |
| AUS Ford | Fiesta(Diesel) | 2008-2012 | Immobiliser | 1.Add a key 2.Erase keys 3.Read number of keys |
| AUS Ford | Fiesta(Diesel) | 2008-2012 | Smart key system | 1.Erase smart keys 2.Program smart keys |
| AUS Ford | Focus(Petrol) | 1998-2004 | Immobiliser | 1.Current number of keys 2.All keys lost |
| AUS Ford | Focus(Petrol) | 2005-2011 | Immobiliser | 1.Number of keys 2.Add a key 3.All Keys lost |
| AUS Ford | Focus(Petrol) | 2005-2011 | Smart key system | 1.Add a smart key 2.Erase smart keys 3.Help |
| AUS Ford | Focus(Petrol) | 2011- | Immobiliser | 1.Add a key 2.Erase keys 3.All keys lost |
| AUS Ford | Focus(Diesel) | 1998-2004 | Immobiliser | 1.Current number of keys 2.All keys lost |
| AUS Ford | Focus(Diesel) | 2005-2011 | Immobiliser | 1.Number of keys 2.Add a key 3.All Keys lost |
| AUS Ford | Focus(Diesel) | 2005-2011 | Smart key system | 1.Add a smart key 2.Erase smart keys 3.Help |
| AUS Ford | Focus(Diesel) | 2011- | Immobiliser | 1.Add a key 2.Erase keys 3.All keys lost |

| | | | | |
|----------|-----------------|-----------|------------------|--|
| AUS Ford | Fusion | | Immobiliser | 1.Number of keys 2.Add a key 3.All Keys lost |
| AUS Ford | KA(Petrol) | 1998-2000 | Immobiliser | 1.Current number of keys 2.All keys lost |
| AUS Ford | KA(Petrol) | 2002-2008 | Immobiliser | 1.Number of keys 2.Add a key 3.All Keys lost |
| AUS Ford | LTD(PCM) | | Immobiliser | 1.Parameter Reset |
| AUS Ford | LTD(BEM) | | Immobiliser | 1.All keys lost |
| AUS Ford | Maverick | 2001- | Immobiliser | 1.Current number of keys 2.All keys lost |
| AUS Ford | Mondeo(Petrol) | 1998- | Immobiliser | 1.Current number of keys 2.All keys lost |
| AUS Ford | Mondeo(Petrol) | 2007- | Immobiliser | 1.Number of keys 2.All keys lost 3.Add a key |
| AUS Ford | Mondeo(Petrol) | 2007- | Smart key system | 1.All smart keys lost 2.Add a smart key |
| AUS Ford | Mondeo(Diesel) | 1998- | Immobiliser | 1.Current number of keys 2.All keys lost |
| AUS Ford | Mondeo(Diesel) | 2007- | Immobiliser | 1.Number of keys 2.All keys lost 3.Add a key |
| AUS Ford | Mondeo(Diesel) | 2007- | Smart key system | 1.All smart keys lost 2.Add a smart key |
| AUS Ford | Puma(Petrol) | 1996- | Immobiliser | 1.Current number of keys 2.All keys lost |
| AUS Ford | Ranger | 2012- | Immobiliser | 1.Add key 2.Erase keys 3.All lost 4.Number of key |
| AUS Ford | Territory(SX) | | Immobiliser | 1.Number of keys 2.Add a key 3.All Keys lost |
| AUS Ford | Territory(SY) | | Immobiliser | 1.Number of keys 2.Add a key 3.All Keys lost |
| AUS Ford | Transit Connect | -2007 | Immobiliser | 1.Current number of keys 2.All keys lost |

| | | | | |
|-------------|-------------------------|-----------|-------------|---|
| AUS Ford | Transit Connect(Type 1) | 2007- | Immobiliser | 1.Add a key 2.Erase keys 3.Read number of keys |
| AUS Ford | Transit Connect(Type 2) | 2007- | Immobiliser | 1.Live data 2.Add a key 3.All keys lost |
| AUS Ford | Transit(Petrol) | 2000- | Immobiliser | 1.Current number of keys 2.All keys lost |
| AUS Ford | Transit(Petrol) | 2007- | Immobiliser | 1.Live data 2.Add a key 3.All keys lost |
| AUS Ford | Transit(Diesel) | 1998- | Immobiliser | 1.Current number of keys 2.All keys lost |
| AUS Ford | Transit(Diesel) | 2007- | Immobiliser | 1.Live data 2.Add a key 3.All keys lost |
| AUS Ford | Dura Torqu(Type 1) | | Immobiliser | 1.Current number of keys 2.All keys lost |
| AUS Ford | Epic(Type 1) | 1998- | Immobiliser | 1.Current number of keys 2.All keys lost |
| Brazil Ford | Courier | 2000-2006 | Immobiliser | 1.Current number of keys 2.All Keys Lost 3.Add Key 4.Parameter Reset |
| Brazil Ford | Courier | 2007-2009 | Immobiliser | 1.Number of keys 2.Add a key 3.All Keys lost |
| Brazil Ford | Ecosport | 2002-2006 | Immobiliser | 1.Current number of keys 2.All Keys Lost 3.Add Key 4.Parameter Reset |
| Brazil Ford | Ecosport | 2007-2012 | Immobiliser | 1.Number of keys 2.Add a key 3.All Keys lost |
| Brazil Ford | Ecosport | 2013-2014 | Immobiliser | 1.Add a key 2.Erase keys 3.Read number of keys |
| Brazil Ford | Ecosport | 2015-2018 | Immobiliser | 1. Read number of keys 2. Add a key 3. All keys lost |

| | | | | |
|-------------|----------|----------------|-------------|---|
| Brazil Ford | Ecosport | 2019- | Immobiliser | 1.Read number of keys 2.Program keys 3.Backup pFlash 4.Backup dFlash 5.Recover pFlash |
| Brazil Ford | Edge | 2007-2009 | Immobiliser | 1. Add key 2. Erase keys 3. All lost 4. Number of key |
| Brazil Ford | Edge | 2010 | Immobiliser | 1.Number of keys 2.All keys lost 3.Add a key |
| Brazil Ford | Edge | 2011-2014 | Immobiliser | 1.Number of keys 2.All keys lost 3.Add a key |
| Brazil Ford | Escort | 2000-2003 | Immobiliser | 1. Current number of keys 2.All Keys Lost 3.Add Key 4.Parameter Reset |
| Brazil Ford | Explorer | Type 1(VPW) | Immobiliser | 1. Current number of keys 2.All Keys Lost 3.Add Key 4.Parameter Reset |
| Brazil Ford | Explorer | Type 2(CAN) | Immobiliser | 1. Number of keys 2.Add a key 3.All Keys lost |
| Brazil Ford | Fiesta | 2000-2003 | Immobiliser | 1. Current number of keys 2.All Keys Lost 3.Add Key 4.Parameter Reset |
| Brazil Ford | Fiesta | 2003-2011 | Immobiliser | 1. Number of keys 2.Add a key 3.All Keys lost |
| Brazil Ford | Fiesta | 2011-2013 | Immobiliser | 1.Add a key 2.Erase keys 3.Read number of keys |
| Brazil Ford | Fiesta | 2013-2018 | Immobiliser | 1. Read number of keys 2. Add a key 3. All keys lost |
| Brazil Ford | Focus | 2000-2005(VPW) | Immobiliser | 1.Current number of keys 2.All Keys Lost 3.Add Key 4.Parameter Reset |

| | | | | |
|-------------|--------|----------------|-------------|---|
| Brazil Ford | Focus | 2000-2005(CAN) | Immobiliser | 1.Number of keys 2.Add a key 3.All Keys lost |
| Brazil Ford | Focus | 2006-2008 | Immobiliser | 1.All keys lost 2.Add a key 3.Program immobiliser and engine ECU |
| Brazil Ford | Focus | 2009-2011 | Immobiliser | 1.Add a key 2.All keys lost 3.Read number of keys |
| Brazil Ford | Focus | 2011-2012 | Immobiliser | 1.Add a key 2.Erase keys |
| Brazil Ford | Focus | 2013-2017 | Immobiliser | 1.Add a key 2.Erase keys 3.All keys lost |
| Brazil Ford | Fusion | 2007-2009 | Immobiliser | 1.Number of keys 2.Add a key 3.All Keys lost |
| Brazil Ford | Fusion | 2010-2011 | Immobiliser | 1.Number of keys 2.All keys lost 3.Add a key |
| Brazil Ford | Fusion | 2014-2016 | Immobiliser | 1.Read number of keys 2.Add a key 3.All keys lost |
| Brazil Ford | F-250 | Type 1(VPW) | Immobiliser | 1.Current number of keys 2.All Keys Lost 3.Add Key 4.Parameter Reset |
| Brazil Ford | F-250 | Type 2(CAN) | Immobiliser | 1.Number of keys 2.Add a key 3.All Keys lost |
| Brazil Ford | F-350 | Type 1(VPW) | Immobiliser | 1.Current number of keys 2.All Keys Lost 3.Add Key 4.Parameter Reset |
| Brazil Ford | F-350 | Type 2(CAN) | Immobiliser | 1.Number of keys 2.Add a key 3.All Keys lost |
| Brazil Ford | KA | 2000-2007 | Immobiliser | 1.Current number of keys 2.All Keys Lost 3.Add Key 4.Parameter Reset |

| | | | | |
|-------------|----------|-----------|------------------|---|
| Brazil Ford | KA | 2008-2011 | Immobiliser | 1.Number of keys 2.Add a key 3.All Keys lost |
| Brazil Ford | KA | 2015-2017 | Immobiliser | 1.Read number of keys 2.Add a key 3.All keys lost |
| Brazil Ford | KA | 2018- | Immobiliser | 1.Read number of keys 2.Program keys 3.Backup pFlash 4.Backup dFlash 5.Recover pFlash |
| Brazil Ford | Mondeo | 1999-2003 | Immobiliser | 1.Current number of keys 2.All Keys Lost 3.Add Key 4.Parameter Reset |
| Brazil Ford | Ranger | 2005-2009 | Immobiliser | 1.Number of keys 2.Add a key 3.All Keys lost |
| Brazil Ford | Ranger | 2012-2015 | Immobiliser | 1.Add key 2.Erase keys 3.All lost 4.Number of key |
| Brazil Ford | Ranger | 2016-2017 | Immobiliser | 1.Read number of keys 2.Add a key 3.All keys lost |
| Brazil Ford | Ranger | 2017- | Immobiliser | 1.Number of key(s) 2.Add a key 3.All keys lost |
| Brazil Ford | Transit | 2010-2013 | Immobiliser | 1. Live data 2. Add a key 3. All keys lost |
| Brazil Ford | Ecosport | 2015-2018 | Smart key system | 1. All smart keys lost 2. Add a smart key |
| Brazil Ford | Ecosport | 2018- | Smart key system | 1.Read number of keys 2.Program keys 3.Backup pFlash 4.Backup dFlash 5.Recover pFlash |
| Brazil Ford | Focus | 2011-2015 | Smart key system | 1. Add smart keys 2. All lost keys |

| | | | | |
|-------------|--------|-----------|------------------|---|
| Brazil Ford | Focus | 2016- | Smart key system | 1.Add keys 2.All keys lost 3.Read keys number |
| Brazil Ford | Fusion | 2014-2016 | Smart key system | 1. Read number of keys 2. Add a key 3. Erase keys |
| Brazil Ford | Fusion | 2017- | Smart key system | 1.Number of key(s) 2.Add a key 3.All keys lost |

XTOOL