



深圳市朗仁科技有限公司
Shenzhen Xtooltech Co., Ltd

Brilliance Function table V26.59

Car series	System type	System subtype	Contains models	Function menu		
Brilliance	Immobiliser	Mitsubishi Immobiliser	Old Zhonghua	1、 Read Trouble Code 2、 Clear Trouble Code 3、 Live Data 4、 Program keys 5、 Reset immobiliser		
			Zunchi			
			Junjie			
			Kubao			
			Junjie FRV			
			Junjie FSV			
		H330	1、 Read ECU Information 2、 Read Trouble Code 3、 Clear Trouble Code			
		Delphi Immobiliser		Zunchi		
		Junjie				
		Kubao	1、 Read ECU Information 2、 Read Trouble Code 3、 Clear Trouble Code 4、 Live Data 5、 Program function 5.1、 Program new system 5.2、 Program keys 5.3、 Replace immobiliser ECU 5.4、 Replace engine ECU 5.5、 Program mechanical key number 5.6、 Program engine VIN 5.7、 Program WSC 5.8、 Reset engine ECU 5.9、 Reset immobiliser			
		Siemens Immobiliser		Zunchi		
				Junjie		
				Kubao		
				Junjie FRV		
				Junjie FSV		
				Junjie CROSS		
				Junjie WAGON		
				H220		
				H230		
				H320		
				H3		
				H330		
				H530		
V3						
V3 (G3)						
V5						
H2						
F50						
Zhishang S30						
Zhishang S35						
		HuaSong 7	1、 Program keys 2、 Erase keys and add keys 3、 Program engine			
Smart key system		PEPS old smart key	FSV	1、 Program smart keys		
		PEPS new smart key	FSV	1、 Read Trouble Code 2、 Clear Trouble Code 3、 Program function 3.1、 Program smart keys 3.2、 Program new system 3.3、 Reset engine ECU 3.4、 Reset immobiliser		
					H330	
					H3	
				V3	1、 Program new PEPS 2、 Program keys	
				H530	1、 Program new system	
				V5	2、 Program smart keys	
				V3 (G3)	1、 Program new PEPS 2、 Program key 3、 Program new ESCL 4、 Program new EMS 5、 Reset PEPS 6、 Reset FOB 7、 Reset EMS 8、 read FOB status 9、 Program new system	
					V6	1、 Program smart key 2、 Reset smart key 3、 Reset PEPS 4、 Reset EMS 5、 Program EMS 6、 Program ESCL 7、 Program PEPS 8、 Program EMS and PEPS
Remote system		HuaSong 7	1、 All lost remote 2、 Program remote			