

Brand	Model	Year	Immo Type	Key Type	Read PIN	Add Keys	All Keys Lost	Program Remote	Other Functions
DFFENGSHEN	A30			Blade key	×	○	○	/	1. Replace the anti-theft controller 2. Replace EMS 3. Replace the anti-theft host and EMS 4. Rematch the faulty parts
DFFENGSHEN	A30			Blade key	×	○	○	○	1. Remote control matching after replacing the body
DFFENGSHEN	A60-A16/A14T			Smart key	/	○	○	/	1. Match ESCL 2. Match PEPS 3. Match EMS 4. New system matching
DFFENGSHEN	A60-A16/A14T			Blade key	/	○	○	/	1. Match BCM 2. Match EMS 3. New system matching 4. Matching faulty parts 5. Reset ECU
DFFENGSHEN	A60-HR16/MR20		Type 1	Blade key	○	○	○	○	1. Read fault code 2. Clear the fault code
DFFENGSHEN	A60-HR16/MR20		Type 2	Blade key	○	○	○	○	1. Clear fault code
DFFENGSHEN	A60-HR16/MR20			Smart key	○	○	○	/	1. Match steering lock
DFFENGSHEN	A60EV			Blade key	/	○	○	/	1. Match BCM 2. Match EMS 3. New system matching 4. Matching faulty parts 5. Reset ECU
DFFENGSHEN	A9			Smart key	○	○	○	/	
DFFENGSHEN	AX3			Blade key	/	○	○	○	
DFFENGSHEN	AX3			Blade key	×	○	○	/	1. Replace the anti-theft controller 2. Replace EMS 3. Replace the anti-theft host and EMS 4. Rematch the faulty parts
DFFENGSHEN	AX3			Smart key	/	○	○	/	1. Match ESCL 2. Match PEPS 3. Match EMS 4. New system matching
DFFENGSHEN	AX4			Blade key	/	○	○	○	
DFFENGSHEN	AX4			Blade key	×	○	○	/	1. Replace the anti-theft controller 2. Replace EMS 3. Replace the anti-theft host and EMS 4. Rematch the faulty parts
DFFENGSHEN	AX4			Smart key	/	○	○	/	1. Match ESCL 2. Match PEPS 3. Match EMS 4. New system matching
DFFENGSHEN	AX5			Smart key	/	○	○	/	1. Match ESCL 2. Match PEPS 3. Match EMS 4. New system matching
DFFENGSHEN	AX5			Blade key	/	○	○	/	1. Match BCM 2. Match EMS 3. New system matching 4. Matching faulty parts 5. Reset ECU
DFFENGSHEN	AX7			Smart key	/	○	○	/	1. Match ESCL 2. Match PEPS 3. Match EMS 4. New system matching
DFFENGSHEN	AX7			Blade key	/	○	○	/	1. Match BCM 2. Match EMS 3. New system matching 4. Matching faulty parts 5. Reset ECU
DFFENGSHEN	AX7 PHEV			Smart key	/	○	○	/	1. Match ESCL 2. Match PEPS 3. Match EMS 4. New system matching
DFFENGSHEN	AX7	2020		Smart key	/	○	○	/	1. Match ESCL 2. Match PEPS 3. Match EMS 4. New system matching
DFFENGSHEN	AX7 PRO			Smart key	/	○	○	/	1. Match BCM 2. Match EMS 3. Match ESCL 4. New match 5. Body module write configuration
DFFENGSHEN	AX7 PLUS			Smart key	/	○	○	/	1. Match BCM 2. Match EMS 3. Match ESCL 4. New match 5. Body module write configuration
DFFENGSHEN	D01			Blade key	×	○	○	/	
DFFENGSHEN	E70 (280)			Smart key	/	○	○	/	1. Match ESCL 2. Match PEPS
DFFENGSHEN	E70 (280)			Blade key	×	○	○	/	1. Match BCM

Brand	Model	Year	Immo Type	Key Type	Read PIN	Add Keys	All Keys Lost	Program Remote	Other Functions
DFFENGSHEN	E70 (300)			Smart key	/	○	○	/	1. Matching smart box 2. Match the steering column lock 3. After-sales faulty parts matching
DFFENGSHEN	E70 (300)			Blade key	/	○	○	/	1. Matching body computer
DFFENGSHEN	E70 (400/500)			Smart key	/	○	○	/	1. Matching smart box 2. Match the steering column lock 3. Smart box write configuration
DFFENGSHEN	E70 (400/500)			Blade key	/	○	○	/	1. Matching body computer 2. Body module write configuration
DFFENGSHEN	H30		Type 1	Blade key	×	○	○	☉	1. Decoder programming 2. Engine ECU matching 3. Key and engine initialization 4. Configuration
DFFENGSHEN	H30		Type 2	Blade key	×	○	○	/	1. Read ECU Information 2. Read Trouble Code 3. Clear Trouble Code 4. Live Data 5. New system matching 6. Anti-theft device ECU matching 7. Engine ECU matching 8. Immobilizer ECU reset 9. Engine ECU reset 10. Read VIN code 11. Key detection 12. Engine ECU detection 13. Programming engine VIN 14. Programming immobilizer VIN 15. Locking the immobilizer 16. LED status indicator
DFFENGSHEN	H30		Type 3	Blade key	×	○	○	/	1. Replace the anti-theft controller 2. Replace EMS 3. Replace the anti-theft host and EMS 4. Rematch the faulty parts
DFFENGSHEN	H30 CROSS		Type 1	Blade key	×	○	○	☉	1. Decoder programming 2. Engine ECU matching 3. Key and engine initialization 4. Configuration
DFFENGSHEN	H30 CROSS		Type 2	Blade key	×	○	○	/	1. Read ECU Information 2. Read Trouble Code 3. Clear Trouble Code 4. Live Data 5. New system matching 6. Anti-theft device ECU matching 7. Engine ECU matching 8. Immobilizer ECU reset 9. Engine ECU reset 10. Read VIN code 11. Key detection 12. Engine ECU detection 13. Programming engine VIN 14. Programming immobilizer VIN 15. Locking the immobilizer 16. LED status indicator
DFFENGSHEN	H30 CROSS		Type 3	Blade key	×	○	○	/	1. Replace the anti-theft controller 2. Replace EMS 3. Replace the anti-theft host and EMS 4. Rematch the failed parts
DFFENGSHEN	S30		Type 1	Blade key	×	○	○	☉	1. Decoder programming 2. Engine ECU matching 3. Key and engine initialization 4. Configuration
DFFENGSHEN	S30		Type 2	Blade key	×	○	○	/	1. Read ECU Information 2. Read Trouble Code 3. Clear Trouble Code 4. Live Data 5. New system matching 6. Anti-theft device ECU matching 7. Engine ECU matching 8. Immobilizer ECU reset 9. Engine ECU reset 10. Read VIN code 11. Key detection 12. Engine ECU detection 13. Programming engine VIN 14. Programming immobilizer VIN 15. Locking the immobilizer 16. LED status indicator
DFFENGSHEN	S30		Type 3	Blade key	×	○	○	/	1. Replace the anti-theft controller 2. Replace EMS 3. Replace the anti-theft host and EMS 4. Rematch the faulty parts
DFFENGSHEN	L60			Blade key	○	○	○	○	
DFFENGSHEN	L60			Smart key	○	○	○	/	

Brand	Model	Year	Immo Type	Key Type	Read PIN	Add Keys	All Keys Lost	Program Remote	Other Functions
DFFENGSHEN	Yixuan			Smart key	/	○	○	/	1.Match BCM 2.Match EMS 3.Match ESCL 4.New match 5.Body module write configuration
DFFENGSHEN	Yixuan			Blade key	/	○	○	/	1.Match BCM 2.Match EMS 3.New system matching 4.Matching faulty parts 5.Reset ECU
DFFENGSHEN	Yixuan GS			Smart key	/	○	○	/	1.Match BCM 2.Match EMS 3.Match ESCL 4.New match 5.Body module write configuration
DFFENGSHEN	Yixuan GS			Blade key	/	○	○	/	1.Match BCM 2.Match EMS 3.New system matching 4.Matching faulty parts 5.Reset ECU
DFFENGSHEN	Yixuan MAX			Smart key	/	○	○	/	1.Match BCM 2.Match EMS 3.Match ESCL 4.New match 5.Body module write configuration
DFFENGSHEN	Yixuan EV			Smart key	/	○	○	/	1.Match BCM 2.Match EMS 3.Match ESCL 4.New match 5.Body module write configuration