

Immobiliser Function List

Software Version: V18.12

Automaker	Model	System	Function
Isuzu	D-MAX	Immobiliser	1.Add key 2.Erase key 3.Reset immobilizer 4.Reset ECU 5.ECU Immo programing 6.Erase DTC 7.Live data 8.ECU identification
Isuzu	MU-7	Immobiliser	1.Add key 2.Erase key 3.Reset immobilizer 4.Reset ECU 5.ECU Immo programing 6.Erase DTC 7.Live data 8.ECU identification
Isuzu	D-MAX	Smart key system	1.Add key 2.Erase key 3.Erase DTC 4.Live data 5.ECU identification
Isuzu	MU-X	Smart key system	1.Add key 2.Erase key 3.Erase DTC 4.Live data 5.ECU identification