



LIFAN Function List V8.20

Tips and Instructions:

The programming function only supports H6PRO, H6PRO Master Edition products.

* This feature is new.

✓ This feature is supported.

This feature is not supported.

※ This feature is partially supported.

Model	System Name	Read ECU Information	Read Trouble Code	Clear Trouble Code	Live Data	Read Freeze Frame	Actuation Test	Special Functions
320	Engine Management System (ECM)/Delphi MT20U2	✓	✓	✓	✓	✓	✓	SP0000-SP0002
320	Engine Management System (ECM)/Sunlight Tech (China Longhui)	✓	✓	✓	✓		✓	SP0003-SP0011
320	Engine Management System (ECM)/UMC ME7.8.8	✓	✓	✓	✓		✓	
320	Engine Management System (ECM)/UMC 4415	✓	✓	✓	✓		✓	SP0012
320	Continuously variable transmission system (CVT)/Jianglu Rongda 1.3	✓	✓	✓	✓			SP0013-SP0021
320	Anti-lock brake system (ABS)/universal anti-lock brake system		✓	✓	✓		✓	SP0022
320	Anti-lock brake system (ABS)/Mando MGH25 anti-lock brake system	✓	✓	✓	✓		✓	
320	Airbag System (SRS)/Evergreen 1	✓	✓	✓	✓			
320	Airbag System (SRS)/Dongfang Jiule KD4.2	✓	✓	✓	✓			
320	Airbag System (SRS)/Evergreen 2	✓	✓	✓	✓			
320	Airbag System (SRS)/Evergreen 3	✓	✓	✓	✓			
320	Electric Power Steering System (EPS)/Elite 1.2	✓	✓	✓	✓			
330	Engine Management System (ECM)/UMC ME7.8.8	✓	✓	✓	✓		✓	
330	Continuously variable transmission system (CVT)/Jianglu Rongda 1.3	✓	✓	✓	✓			SP0023-SP0031
330	Anti-lock brake system (ABS)/universal anti-lock brake system		✓	✓	✓		✓	SP0032
330	Airbag system (SRS)/TAKATA K 2 circuit	✓	✓	✓	✓			SP0033-SP0034
330	Electric Power Steering System (EPS)/Elite 1.2	✓	✓	✓	✓			
520	Engine Management System (ECM)/Delphi MT20U2	✓	✓	✓	✓	✓	✓	SP0035-SP0037
520	Engine Management System (ECM)/Sunlight Tech (China Longhui)	✓	✓	✓	✓		✓	SP0038-SP0046
520	Engine Management System (ECM)/TRIFEC Engine System	✓	✓	✓	✓		✓	
520	Continuously variable transmission system (CVT)/Jianglu Rongda 1.3	✓	✓	✓	✓			SP0047-SP0055
520	Anti-lock brake system (ABS)/TRW TRW anti-lock brake system	✓	✓	✓	✓		✓	
520	Anti-lock brake system (ABS)/universal anti-lock brake system		✓	✓	✓		✓	SP0056
520	Anti-lock brake system (ABS)/Asia Pacific anti-lock brake system	✓	✓	✓	✓			
520	Airbag System (SRS)/Evergreen 2	✓	✓	✓	✓			
520	Airbag System (SRS)/Jinheng Airbag JH-ACU-4A	✓	✓	✓	✓			
520	Airbag System (SRS)/Evergreen 1	✓	✓	✓	✓			
520	Airbag System (SRS)/Jinheng	✓	✓	✓	✓			
520	Airbag System (SRS)/Evergreen 3	✓	✓	✓	✓			
520	Anti-theft system (IMMO)/Jicheng JIK001 (Delphi)	✓	✓	✓	✓			
520	Anti-theft system (IMMO)/Jicheng JIK009 (Sunshine Tektronix)	✓	✓	✓	✓			SP0057-SP0060
530	Engine Management System (ECM)/UMC ME7.8.8	✓	✓	✓	✓		✓	
530	Engine Management System (ECM)/UMC 4415 Engine System	✓	✓	✓	✓		✓	
530	Automatic transmission system/Continuously variable transmission system (CVT)	✓	✓	✓	✓			SP0061-SP0069
530	Anti-lock brake system/BOSCH ABS9/ESP9 CAN	✓	✓	✓	✓			SP0070-SP0097
530	Anti-lock brake system/BOSCH ABS9 530K anti-lock brake system	✓	✓	✓	✓		✓	SP0098-SP0099
530	Anti-lock brake system/Bosch anti-lock brake system (ABS8)	✓	✓	✓	✓		✓	
530	Airbag System/Dongfang Jiule Airbag	✓	✓	✓	✓			
530	Power Steering System/Jielong Electronic Power Steering System		✓	✓				
530	Anti-theft system/Jicheng (UMC)	✓	✓	✓	✓			SP0100-SP0103
620 series/620	Engine Management System (ECM)/Sunlight Tech (China Longhui)	✓	✓	✓	✓		✓	SP0104-SP0112
620 series/620	Engine Management System (ECM)/Delphi MT22.1	✓	✓	✓	✓		✓	SP0113
620 series/620	Engine Management System (ECM)/Delphi MT20U2	✓	✓	✓	✓	✓	✓	SP0114-SP0116
620 series/620	Engine Management System (ECM)/Delphi VVT ETC (National V)	✓	✓	✓	✓		✓	SP0117-SP0119
620 series/620	Engine Management System (ECM)/Delphi MT20U2/CNG	✓	✓	✓	✓	✓	✓	SP0120-SP0122
620 series/620	Engine Management System (ECM)/UMC ME7.8.8	✓	✓	✓	✓		✓	
620 series/620	Engine Management System (ECM)/UMC 4415	✓	✓	✓	✓		✓	SP0123
620 series/620	Continuously variable transmission system (CVT)/Jianglu Rongda 1.3	✓	✓	✓	✓			SP0124-SP0132
620 series/620	Anti-lock brake system (ABS)/universal		✓	✓	✓		✓	SP0133
620 series/620	Anti-lock brake system (ABS)/Mando MGH25	✓	✓	✓	✓		✓	
620 series/620	Airbag System (SRS)/Jin Heng (BOSCH ABS10)	✓	✓	✓	✓			SP0134-SP0136

620 series/620	Airbag System (SRS)/Jinheng	√	√	√	√			
620 series/620	Airbag System (SRS)/Evergreen 1	√	√	√	√			
620 series/620	Airbag System (SRS)/Evergreen 2	√	√	√	√			
620 series/620	Airbag System (SRS)/Evergreen 3	√	√	√	√			
620 series/620	Electric Power Steering System (EPS)/Elite 1.2	√	√	√	√			
620 series/620	Anti-theft system (IMMO)/Jicheng JIK009 (Sunshine Tektronix)	√	√	√	√			SP0137-SP0140
620 series/620	Anti-theft system (IMMO)/Jicheng JIK001 (Delphi)	√	√	√	√			
620 series/620CNG	Engine Management System (ECM)/Delphi MT2002/CNG	√	√	√	√	√	√	SP0141-SP0143
620 series/620CNG	Continuously variable transmission system (CVT)/Jianglu Rongda 1.3	√	√	√	√			SP0144-SP0152
620 series/620CNG	Anti-lock brake system (ABS)/universal	√	√	√	√		√	SP0153
620 series/620CNG	Anti-lock brake system (ABS)/Mando MGH25	√	√	√	√		√	
620 series/620CNG	Airbag System (SRS)/Jin Heng (BOSCH ABS10)	√	√	√	√			SP0154-SP0156
620 series/620CNG	Airbag System (SRS)/Jinheng	√	√	√	√			
620 series/620CNG	Airbag System (SRS)/Evergreen 1	√	√	√	√			
620 series/620CNG	Airbag System (SRS)/Evergreen 2	√	√	√	√			
620 series/620CNG	Airbag System (SRS)/Evergreen 3	√	√	√	√			
620 series/620CNG	Anti-theft system (IMMO)/Jicheng JIK001 (Delphi)	√	√	√	√			
620 series/620 second generation	Engine Control System (ECM)/UMC ME17.8.8	√	√	√	√		√	SP0157-SP0158
620 series/620 second generation	Engine Control System (ECM)/Delphi MT22.5	√	√	√	√		√	SP0159-SP0163
620 series/620 second generation	Transmission system (TCU)/Jianglu Rongda 1.3	√	√	√	√			SP0164-SP0172
620 series/620 second generation	Transmission system (TCU)/PUNCH continuously variable transmission system	√	√	√	√			SP0173-SP0174
620 series/620 second generation	Anti-lock brake system (ABS/ESP)/BOSCH ABS9/ESP9 CAN	√	√	√	√			SP0175-SP0202
620 series/620 second generation	Airbag system (SRS)/TAKATA K 2 circuit	√	√	√	√			SP0203-SP0204
620 series/620 second generation	Body Control System (BCM)/China Airlines BCM	√	√	√	√			SP0205-SP0215
620 series/620 second generation	Electric Power Steering System (EPS)/Henglong	√	√	√	√			SP0216-SP0222
620 series/620 second generation	Anti-theft system (IMMO)/keyless system PEPS		√	√				
630	Engine Management System (ECM)/UMC ME7.8.8	√	√	√	√		√	
630	Engine Management System (ECM)/Delphi VVT ETC (National V)	√	√	√	√		√	SP0223-SP0225
630	Continuously variable transmission system (CVT)/Jianglu Rongda 1.3	√	√	√	√			SP0226-SP0234
630	Anti-lock brake system (ABS)/universal anti-lock brake system		√	√	√		√	SP0235
630	Airbag System (SRS)/Jin Heng (BOSCH ABS10)	√	√	√	√			SP0236-SP0238
630	Airbag System (SRS)/Jinheng	√	√	√	√			
630	Electric Power Steering System (EPS)/Elite 1.2	√	√	√	√			
630	Anti-theft system (IMMO)/Jicheng (UMC)	√	√	√	√			SP0239-SP0242
720	Engine Management System (ECM)/UMC ME17.8.8	√	√	√	√		√	SP0243-SP0244
720	Engine Management System (ECM)/UMC ME7.8.8(720)	√	√	√	√		√	
720	Engine Management System (ECM)/Delphi VVT ETC (National V)	√	√	√	√		√	SP0245-SP0247
720	Engine Management System (ECM)/Delphi VVT ETC	√	√	√	√		√	SP0248-SP0250
720	Transmission system (TCU)/PUCH transmission system	√	√	√	√			SP0251-SP0252
720	Anti-lock brake system (ABS)/BOSCH ABS9/EP9 CAN		√	√	√			SP0253-SP0280
720	Anti-lock brake system (ABS)/BOSCH ABS9 720 CAN	√	√	√	√			SP0281-SP0308
720	Airbag System (SRS)/TAKATA CAN	√	√	√	√		√	SP0309-SP0311
720	FBCM Front Body Control System (HIRAIN) (FBCM)	√	√	√			√	SP0312
720	RBCM Rear Body Control System (HIRAIN) (RBCM)	√	√	√	√		√	SP0313
720	Anti-theft system (IMMO)/PEPS/RKE (HIRAIN)	√	√	√	√		√	SP0314-SP0315
720	Anti-theft system (IMMO)/Jicheng (UMC)	√	√	√	√			SP0316-SP0319
720	Instrumentation System (ICM)	√	√	√	√		√	
720	Air Conditioning System (AC)/A/C (Ruiyang)	√	√	√	√		√	
820	Engine Control System (ECM)/UMC ME17.8.8	√	√	√	√		√	SP0320-SP0321
820	Engine Control System (ECM)/Delphi MT22.5	√	√	√	√		√	SP0322-SP0326
820	Automatic transmission (TCU)/8AT TCU	√	√	√	√	√		SP0327-SP0331
820	Automatic transmission (TCU)/DSI TCU	√	√	√	√			SP0332-SP0334
820	Anti-lock brake system (ABS)/BOSCH ABS9/ESP9 CAN	√	√	√	√			SP0335-SP0362
820	Anti-lock brake system (ABS)/BOSCH ABS9 820 CAN	√	√	√	√			
820	Airbag System (TAKATA CAN) (SRS)	√	√	√	√			
820	FBCM Front Body Control System (HIRAIN) (FBCM)	√	√	√			√	SP0363
820	RBCM Rear Body Control System (HIRAIN) (RBCM)	√	√	√	√		√	SP0364
820	Anti-theft system/keyless (IMMO)/PEPS/HIRAIN PEPS	√	√	√	√		√	SP0365-SP0373
820	Anti-theft system/keyless (IMMO)/PEPS/AOZE PKE	√	√	√	√		√	SP0374-SP0380
820	Instrumentation (ICM)/Xintongda IC	√	√	√	√		√	SP0381-SP0383
820	Air Conditioning System (AC)/CAEA ATC	√	√	√	√		√	SP0384-SP0391

X50	Engine Management System (ECM)/UMC ME7.8.8	√	√	√	√		√	
X50	Engine Management System (ECM)/UMC 4415	√	√	√	√		√	SP0392
X50	Continuously variable transmission system (CVT)/Jianglu Rongda 1.3	√	√	√	√			SP0393-SP0401
X50	Anti-lock brake system (ABS)/BOSCH ABS9 530K	√	√	√	√			SP0402-SP0403
X50	Anti-lock brake system (ABS)/BOSCH ABS9/ESP9 CAN	√	√	√	√			SP0404-SP0431
X50	Airbag System (SRS)/Dongfang Jiule KD6.0	√	√	√	√			
X50	Electric Power Steering System (EPS)/Jielong		√	√				
X50	Anti-theft system (IMMO)/Wanchao PEPS/RKE (HIRAIN)	√	√	√	√		√	SP0432-SP0433
X50	Anti-theft system (IMMO)/Jicheng (UMC)	√	√	√	√			SP0434-SP0437
X60	Engine Management System (ECM)/UMC ME17.8.8	√	√	√	√		√	SP0438-SP0439
X60	Engine Management System (ECM)/UMC EMS Engine Management System	√	√	√	√		√	
X60	Engine Management System (ECM)/Delphi VVT ETC Engine System	√	√	√	√		√	SP0440-SP0442
X60	Engine Management System (ECM)/Delphi VVT ETC (National V)	√	√	√	√		√	SP0443-SP0445
X60	Automatic transmission (TCU)/Delphi TCM8 2.0 transmission system	√	√	√	√			
X60	Automatic transmission (TCU)/PUCH CVT transmission system	√	√	√	√			SP0446-SP0447
X60	Anti-lock brake system (ABS)/Jingxi Heavy Industry BWI DBC78	√	√	√	√		√	SP0448-SP0454
X60	Anti-lock brake system (ABS)/BOSCH ABS9/ESP9 CAN	√	√	√	√			SP0455-SP0482
X60	TAKATA K 6-circuit airbag system (SRS)	√	√	√	√			
X60	Anti-theft system (IMMO)/Jicheng anti-theft system JIK001 (Delphi)	√	√	√	√			
X60	Anti-theft system (IMMO)/Jicheng (UMC) anti-theft system	√	√	√	√			SP0483-SP0486
X70	Engine System (ECM)/UMC ME17.8.8	√	√	√	√		√	SP0487-SP0488
X70	Engine System (ECM)/Delphi Engine System	√	√	√	√		√	SP0489-SP0500
X70	Automatic Transmission System (TCU)	√	√	√	√			SP0501
X70	Electronic stability/anti-lock brake system (ESP/ABS)	√	√	√	√			SP0502-SP0517
X70	Airbag System (SRS)	√	√	√	√		√	SP0518-SP0521
X70	Body Control System (BCM)	√	√	√			√	SP0522-SP0524
X70	Anti-theft system (IMMO)	√	√	√			√	SP0525-SP0528
X70	Instrument cluster system (ICM)	√	√	√			√	SP0529-SP0531
X70	Tire Pressure Monitoring System (TPMS)	√	√	√	√		√	SP0532-SP0536
X80	Delphi Engine System (ECM)	√	√	√	√		√	SP0537-SP0539
X80	Automatic transmission control (DSI TCU)	√	√	√	√			SP0540-SP0542
X80	Anti-lock brake system (BOSCH) (ABS/ESP)	√	√	√	√			SP0543-SP0627
X80	Airbag System (TAKATA) (SRS)	√	√	√	√			SP0628-SP0630
X80	Front Body Control System (FBCM)	√	√	√			√	SP0631-SP0635
X80	Rear Body Control System (RBCM)	√	√	√			√	SP0636-SP0637
X80	Electric Power Steering System (JTEKT) (EPS)	√	√	√	√			SP0638-SP0644
X80	Anti-theft system (HIRAIN with PEPS) (IMMO)	√	√	√	√		√	SP0645
X80	Instrument System (DESAY) (IC)	√	√	√	√		√	SP0646-SP0662
X80	Air Conditioning System (AC)/Front Air Conditioning (CAEA ATC)	√	√	√	√		√	SP0663-SP0664
X80	Air Conditioning System (AC)/Rear Air Conditioning (CAEA RATC)	√	√	√	√		√	SP0665-SP0666
X80	Electronic Parking System (EPB)	√	√	√	√		√	SP0667-SP0692
X80	360-degree panoramic image system (AVM)	√	√	√		√	√	SP0693-SP0701
CY02C	Engine Management System (ECM)/UMC ME17.8.8	√	√	√	√		√	SP0702-SP0704
CY02C	Engine Management System (ECM)/Delphi	√	√	√	√		√	SP0705-SP0711
CY02C	Automatic Transmission Control (TCU)/WLY CVT TCU	√	√	√	√			SP0712
CY02C	Anti-lock brake system (ABS/ESP)/BOSCH ABS9/ESP9 CAN	√	√	√	√		√	SP0713-SP0719
CY02C	Airbag System (SRS)	√	√	√	√			SP0720
CY02C	Body Control System (BCM)	√	√	√			√	SP0721-SP0723
CY02C	Anti-theft system (IMMO)	√	√	√			√	SP0724-SP0727
CY02C	Instrumentation System (ICM)	√	√	√			√	SP0728-SP0730
CY02C	Tire Pressure Monitoring System (TPMS)	√	√	√	√			SP0731
CP08C	Engine Management System (EMS)	√	√	√	√		√	SP0732-SP0733
CP08C	Automatic Transmission System (TCU)	√	√	√	√			SP0734-SP0742
CP08C	Anti-lock brake system (ABS)	√	√	√	√			SP0743-SP0788
CP08C	Airbag System (SRS)	√	√	√	√			
CP08C	Body Control System (BCM)	√	√	√			√	SP0789-SP0790
CP08C	Electric Power Steering System (EPS)	√	√	√	√			SP0791-SP0798
CP08C	Anti-theft controller (IMMO)	√	√	√	√		√	SP0799
CP08C	Instrumentation System (ICM)	√	√	√			√	SP0800-SP0802
CP08C	Tire Pressure Monitoring System (TPMS)	√	√	√	√		√	SP0803-SP0807
CP08C	Electronic Parking System (EPB)	√	√	√	√			SP0808-SP0811
Maiwei	Engine System (ECM)/Delphi	√	√	√	√		√	SP0812-SP0814
Maiwei	Engine System (ECM)/UMC ME17.8.8	√	√	√	√		√	SP0815-SP0816
Maiwei	Anti-lock brake system (ABS/ESP)/ESP (BOSCH)	√	√	√	√			SP0817-SP0902
Maiwei	Anti-lock brake system (ABS/ESP)/Universal Seiko WX20/V5 anti-lock brake system	√	√	√	√		√	SP0903-SP0904
Maiwei	Airbag System (SRS)/Maiwei Airbag System	√	√	√	√			SP0905-SP0908
Maiwei	Body Control System (BCM)/Maiwei Body Control System	√	√	√				SP0909-SP0911
Maiwei	Electronic Power Steering System (EPS)/Yubei	√	√	√				SP0912-SP0914
Maiwei	Electronic Power Steering System (EPS)/Autonic	√	√	√				SP0915-SP0916
Maiwei	Anti-theft system (IMMO)/Maiwei anti-theft system	√	√	√				SP0917-SP0918

Maiwei	Instrumentation System (ICM)/Maiwei Instrumentation System	√	√	√	√			SP0919-SP0925
Maiwei	Tire Pressure Monitoring System (TPMS)	√	√	√	√			SP0926-SP0933
Maiwei	Internet of Vehicles System (TBOX)	√	√	√	√			SP0934-SP0937
Xuan Lang	Engine Management System (ECM)/Delphi	√	√	√	√		√	SP0938-SP0944
Xuan Lang	Engine Management System (ECM)/UMC ME17.8.8	√	√	√	√		√	SP0945-SP0947
Xuan Lang	Automatic Transmission Control (TCU)	√	√	√	√	√		SP0948-SP0952
Xuan Lang	Anti-lock brake system (ABS/ESP)/Universal Seiko WX20/V5	√	√	√	√		√	SP0953-SP0954
Xuan Lang	Anti-lock brake system (ABS/ESP)/Electronic Stability System (ESP) (BOSCH)	√	√	√	√			SP0955-SP1000
Xuan Lang	Airbag System (SRS)	√	√	√			√	SP1001-SP1004
Xuan Lang	Front Body Control System (FBCM)/Del FBCM	√	√	√			√	SP1005-SP1013
Xuan Lang	Front Body Control System (FBCM)/Wanchao FBCM	√	√	√			√	SP1014-SP1017
Xuan Lang	Rear Body Control System (RBCM)/Del RBCM	√	√	√				SP1018-SP1026
Xuan Lang	Anti-theft system (IMMO)	√	√	√	√			SP1027-SP1036
Xuan Lang	Instrumentation System (ICM)	√	√	√	√			SP1037-SP1044
Xuan Lang	Electronic Parking System (EPB)	√	√	√	√		√	SP1045-SP1046
Xuan Lang	360-degree panoramic system (AVM)	√	√	√	√			SP1047
Fengshun	Engine Management System (ECM)/Sunlight Tech (China Longhui)	√	√	√	√		√	SP1048-SP1056
Fengshun	Engine Management System (ECM)/Delphi MT20U2	√	√	√	√	√	√	SP1057-SP1059
Fengshun	Engine Management System (ECM)/Delphi MT20U2/CNG	√	√	√	√	√	√	SP1060-SP1062
Fengshun	Engine Management System (ECM)/UMC ME7.8.8 Engine System	√	√	√	√		√	
Fengshun	Anti-lock brake system (ABS)/Universal Seiko WX20/V5	√	√	√	√		√	SP1063-SP1064
Fengshun	Anti-lock braking system (ABS)/Universal Qianchao	√	√	√	√		√	SP1065-SP1068
Fengshun	Anti-lock brake system (ABS)/universal		√	√	√		√	SP1069
Fengshun	Airbag System (SRS)/Universal Seiko Airbag System	√	√	√	√		√	SP1070-SP1071
Fengshun	Electric Power Diagnosis System (EPS)/Chongqing Lifan Automobile EPS	√	√	√			√	
Fengshun	Electric Power Diagnosis System (EPS)/Autonic Electronic Steering System	√	√	√	√			
Fengshun	Anti-theft system (IMMO)/Jicheng JIK001 (Delphi)	√	√	√	√			
Fengshun	Anti-theft system (IMMO)/Jicheng JIK009 (Sunshine Tektronix)	√	√	√	√			SP1072-SP1075
Xingshun	Engine Management System (ECM)/Sunlight Tech (China Longhui)	√	√	√	√		√	SP1076-SP1084
Xingshun	Engine Management System (ECM)/UMC ME7.8.8 Engine System	√	√	√	√		√	
Xingshun	Anti-lock brake system (ABS)/Universal Seiko WX20/V5	√	√	√	√		√	SP1085-SP1086
Xingshun	Anti-lock brake system (ABS)/universal		√	√	√		√	SP1087
Xingshun	Electric Power Diagnosis System (EPS)/Chongqing Lifan Automobile EPS	√	√	√			√	
Xingshun	Anti-theft system (IMMO)/Jicheng JIK009 (Sunshine Tektronix)	√	√	√	√			SP1088-SP1091
Fushun	Engine Management System (ECM)/Sunlight Tech (China Longhui)	√	√	√	√		√	SP1092-SP1100
Fushun	Anti-theft system (IMMO)/Jicheng JIK009 (Sunshine Tektronix)	√	√	√	√			SP1101-SP1104
Fushun	Electric Power Assist System (EPS)	√	√	√			√	
Lotto	Engine System (ECM)/Electronic Injection ECU (B15)	√	√	√	√			
Lotto	Engine System (ECM)/Electronic Injection ECU (B12)	√	√	√	√			
Lotto	Anti-lock brake system (ABS)/Universal Seiko WX20/V5	√	√	√	√		√	SP1105-SP1106
Lotto	Airbag System (SRS)		√	√				
330 EV3	Battery Management System (BMS)	√	√	√	√	√	√	SP1107-SP1110
330 EV3	Battery Pack Data (BPD)				√			
330 EV3	Vehicle Control Unit (VCU)	√	√	√	√	√	√	SP1111-SP1113
330 EV3	Motor Controller (EMC)	√	√	√	√	√	√	SP1114-SP1117
330 EV3	Anti-lock brake system (ABS)		√	√	√		√	SP1118
330 EV3	Airbag System (SRS)	√	√	√	√			SP1119-SP1120
330 EV3	Electric Power Steering System (EPS)	√	√	√	√			
330 EV3	Instrumentation System (ICM)	√	√	√				SP1121-SP1125
620 EV2	Battery Management System (BMS)	√	√	√	√			SP1126-SP1129
620 EV2	Battery Pack Data (BPD)				√			
620 EV2	Vehicle Control Unit (VCU)	√	√	√	√	√	√	SP1130-SP1132
620 EV2	Motor Controller (EMC)	√	√	√	√	√		SP1133-SP1136
620 EV2	Electric compressor assembly (ECA)	√	√	√	√			SP1137-SP1139
620 EV2	Anti-lock brake system (ABS)	√	√	√	√			SP1140-SP1167
620 EV2	Airbag System (SRS)	√	√	√	√			SP1168-SP1169
620 EV2	Body Control System (BCM)	√	√	√	√			SP1170-SP1180
620 EV2	Electric Power Steering System (EPS)	√	√	√	√			SP1181-SP1187
620 EV2	Keyless Entry System (PEPS)	√	√	√	√		√	SP1188
620 EV2	Air Conditioning Panel (ATC)	√	√	√	√		√	SP1189-SP1192
650EV300	Battery Management System (BMS)	√	√	√	√			SP1193-SP1194
650EV300	Vehicle Control Unit (VCU)	√	√	√	√			SP1195-SP1196
650EV300	Power Control Unit (PCU)	√	√	√	√			SP1197-SP1199
650EV300	Anti-lock brake system (ABS)	√	√	√	√			SP1200-SP1227
650EV300	Airbag System (SRS)	√	√	√	√			
650EV300	Body Control System (BCM)	√	√	√	√			SP1228-SP1237
650EV300	Electric Power Steering System (EPS)	√	√	√	√			SP1238-SP1245
650EV300	Keyless Start System (PEPS)	√	√	√	√			SP1246

650EV300	Air Conditioning Panel (ATC)	√	√	√	√				SP1247-SP1250
6401 series electric car	Vehicle Control System (VCU)	√							
6401 series electric car	Airbag System (SRS)		√	√					
820EV4	Airbag System (SRS)	√	√	√	√				SP1251-SP1253
820EV4	Body Control System (BCM)/HIRAIN FBCM 820 Front Body Control System	√	√	√			√		SP1254-SP1256
820EV4	Body Control System (BCM)/HIRAIN RBCM 820 Rear Body Control System	√	√	√			√		SP1257-SP1258
820EV4	Electric Power Steering System (EPS)	√	√	√	√				SP1259-SP1265
820EV4	Keyless Start System (PEPS)	√	√	√	√		√		SP1266-SP1267
650EV Yitong Nebula	Battery Management System (BMS)	√	√	√	√				SP1268-SP1269
650EV Yitong Nebula	Vehicle Control Unit (VCU)	√	√	√	√				SP1270-SP1271
650EV Yitong Nebula	Power Control Unit (PCU)	√	√	√	√				SP1272-SP1274
650EV Yitong Nebula	Anti-lock brake system (ABS)	√	√	√	√				SP1275-SP1302
650EV Yitong Nebula	Airbag System (SRS)	√	√	√	√				SP1303-SP1304
650EV Yitong Nebula	Body Control System (BCM)	√	√	√					SP1305-SP1314
650EV Yitong Nebula	Electric Power Steering System (EPS)	√	√	√	√				SP1315-SP1322
650EV Yitong Nebula	Air Conditioning Panel (ATC)	√	√	√	√				SP1323-SP1326
Maiwei EV	Battery Management System (BMS)	√	√	√	√				
Maiwei EV	Vehicle Control Unit (VCU)	√	√	√	√				
650 Lemster	Battery Management System (BMS)	√	√	√	√				SP1327-SP1328
650 Lemster	Vehicle Control Unit (VCU)	√	√	√	√				SP1329-SP1330
650 Lemster	Power Control Unit (PCU)	√	√	√	√				SP1331-SP1333
650 Lemster	Anti-lock brake system (ABS)	√	√	√	√				SP1334-SP1361
650 Lemster	Airbag System (SRS)	√	√	√	√				SP1362-SP1363
650 Lemster	Body Control System (BCM)	√	√	√					SP1364-SP1373
650 Lemster	Electric Power Steering System (EPS)	√	√	√	√				SP1374-SP1381
650 Lemster	Keyless Start System (PEPS)	√	√	√	√				SP1382
5208EV	Vehicle Control Unit (VCU)				√				
5208EV	Battery Pack Data (BPD)/Battery Pack Data 1 (BPD)	√	√	√	√				
5208EV	Battery Pack Data (BPD)/Battery Pack Data 2 (BPD)	√	√	√	√				
5208EV	Battery Pack Data (BPD)/Battery Pack Data 3 (BPD)	√	√	√	√				
5208EV	Motor Control Unit (MCU)				√				
Fengshun	Battery Pack Data (BPD)				√				
Fengshun	Battery Pack Data 2 (BPD2)				√				

Special Functions List		
No.	Functions Name	System Name
SP0000	Tooth information learning	Delphi MT20U2
SP0001	Idle catalytic converter diagnosis	Delphi MT20U2
SP0002	Oxygen sensor feedback rationality diagnosis	Delphi MT20U2
SP0003	Reset all adaptive values	Sunlight Tech (China Longhui)
SP0004	Atmospheric correction value fed back by air intake signal	Sunlight Tech (China Longhui)
SP0005	Half of the adaptive value of knock ignition angle	Sunlight Tech (China Longhui)
SP0006	Throttle position adaptive value adjustment	Sunlight Tech (China Longhui)
SP0007	Addition/multiplication adaptive factor for injection time of each group of cylinders (oxygen sensor)	Sunlight Tech (China Longhui)
SP0008	Idle speed adaptive value	Sunlight Tech (China Longhui)
SP0009	Segment adaptive value of engine rough value	Sunlight Tech (China Longhui)
SP0010	The adaptive value of the engine rough value heated by the catalytic package	Sunlight Tech (China Longhui)
SP0011	Carbon canister adaptive	Sunlight Tech (China Longhui)
SP0012	Write VIN	UMC 4415
SP0013	Write forward clutch control offset value	Continuously variable transmission system (CVT)/Jianglu Rongda 1.3
SP0014	Write random access memory (RAM) and charged erasable read-only memory (EEPROM)	Continuously variable transmission system (CVT)/Jianglu Rongda 1.3
SP0015	Write random access memory (RAM)	Continuously variable transmission system (CVT)/Jianglu Rongda 1.3
SP0016	Write reverse clutch control offset value	Continuously variable transmission system (CVT)/Jianglu Rongda 1.3
SP0017	Write random access memory (RAM) and charged erasable read-only memory (EEPROM)	Continuously variable transmission system (CVT)/Jianglu Rongda 1.3
SP0018	Write random access memory (RAM)	Continuously variable transmission system (CVT)/Jianglu Rongda 1.3
SP0019	High idle speed	Continuously variable transmission system (CVT)/Jianglu Rongda 1.3
SP0020	Normal idling	Continuously variable transmission system (CVT)/Jianglu Rongda 1.3
SP0021	Write reset offline detection flag	Continuously variable transmission system (CVT)/Jianglu Rongda 1.3
SP0022	Brake exhaust	Universal anti-lock brake system
SP0023	Write forward clutch control offset value	Continuously variable transmission system (CVT)/Jianglu Rongda 1.3
SP0024	Write random access memory (RAM) and charged erasable read-only memory (EEPROM)	Continuously variable transmission system (CVT)/Jianglu Rongda 1.3
SP0025	Write random access memory (RAM)	Continuously variable transmission system (CVT)/Jianglu Rongda 1.3
SP0026	Write reverse clutch control offset value	Continuously variable transmission system (CVT)/Jianglu Rongda 1.3
SP0027	Write random access memory (RAM) and charged erasable read-only memory (EEPROM)	Continuously variable transmission system (CVT)/Jianglu Rongda 1.3
SP0028	Write random access memory (RAM)	Continuously variable transmission system (CVT)/Jianglu Rongda 1.3
SP0029	High idle speed	Continuously variable transmission system (CVT)/Jianglu Rongda 1.3
SP0030	Normal idling	Continuously variable transmission system (CVT)/Jianglu Rongda 1.3
SP0031	Write reset offline detection flag	Continuously variable transmission system (CVT)/Jianglu Rongda 1.3
SP0032	Brake exhaust	Anti-lock brake system (ABS)/universal anti-lock brake system
SP0033	Write VIN code	Airbag system (SRS)/TAKATA K 2 circuit
SP0034	Write the date of manufacture of the car	Airbag system (SRS)/TAKATA K 2 circuit
SP0035	Tooth information learning	Delphi MT20U2
SP0036	Idle catalytic converter diagnosis	Delphi MT20U2
SP0037	Oxygen sensor feedback rationality diagnosis	Delphi MT20U2
SP0038	Reset all adaptive values	Sunlight Tech (China Longhui)
SP0039	Atmospheric correction value fed back by air intake signal	Sunlight Tech (China Longhui)
SP0040	Half of the adaptive value of knock ignition angle	Sunlight Tech (China Longhui)
SP0041	Throttle position adaptive value adjustment	Sunlight Tech (China Longhui)
SP0042	Addition/multiplication adaptive factor for injection time of each group of cylinders (oxygen sensor)	Sunlight Tech (China Longhui)
SP0043	Idle speed adaptive value	Sunlight Tech (China Longhui)
SP0044	Segment adaptive value of engine rough value	Sunlight Tech (China Longhui)

SP0045	The adaptive value of the engine rough value heated by the catalytic package	Sunlight Tech (China Longhui)
SP0046	Carbon canister adaptive	Sunlight Tech (China Longhui)
SP0047	Write forward clutch control offset value	Continuously variable transmission system (CVT)/Jianglu Rongda 1.3
SP0048	Write random access memory (RAM) and charged erasable read-only memory (EEPROM)	Continuously variable transmission system (CVT)/Jianglu Rongda 1.3
SP0049	Write random access memory (RAM)	Continuously variable transmission system (CVT)/Jianglu Rongda 1.3
SP0050	Write reverse clutch control offset value	Continuously variable transmission system (CVT)/Jianglu Rongda 1.3
SP0051	Write random access memory (RAM) and charged erasable read-only memory (EEPROM)	Continuously variable transmission system (CVT)/Jianglu Rongda 1.3
SP0052	Write random access memory (RAM)	Continuously variable transmission system (CVT)/Jianglu Rongda 1.3
SP0053	High idle speed	Continuously variable transmission system (CVT)/Jianglu Rongda 1.3
SP0054	Normal idling	Continuously variable transmission system (CVT)/Jianglu Rongda 1.3
SP0055	Write reset offline detection flag	Continuously variable transmission system (CVT)/Jianglu Rongda 1.3
SP0056	Brake exhaust	Universal anti-lock brake system
SP0057	Write VIN code	Jicheng JIK009 (Sunshine Tektronix)
SP0058	Write repair station ID	Jicheng JIK009 (Sunshine Tektronix)
SP0059	Write programming date	Jicheng JIK009 (Sunshine Tektronix)
SP0060	Write diagnosis date	Jicheng JIK009 (Sunshine Tektronix)
SP0061	Write forward clutch control offset value	Continuously variable transmission system (CVT)
SP0062	Write random access memory (RAM) and charged erasable read-only memory (EEPROM)	Continuously variable transmission system (CVT)
SP0063	Write random access memory (RAM)	Continuously variable transmission system (CVT)
SP0064	Write reverse clutch control offset value	Continuously variable transmission system (CVT)
SP0065	Write random access memory (RAM) and charged erasable read-only memory (EEPROM)	Continuously variable transmission system (CVT)
SP0066	Write random access memory (RAM)	Continuously variable transmission system (CVT)
SP0067	High idle speed	Continuously variable transmission system (CVT)
SP0068	Normal idling	Continuously variable transmission system (CVT)
SP0069	Write reset offline detection flag	Continuously variable transmission system (CVT)
SP0070	Write VIN code	BOSCH ABS9/ESP9 CAN
SP0071	Write the spare part number of the vehicle manufacturer	BOSCH ABS9/ESP9 CAN
SP0072	Write the status of the hydraulic valve group	BOSCH ABS9/ESP9 CAN
SP0073	Write offline EOL status	BOSCH ABS9/ESP9 CAN
SP0074	Write variable code (electronic stability system only)	BOSCH ABS9/ESP9 CAN
SP0075	ECU reset	BOSCH ABS9/ESP9 CAN
SP0076	Exhaust and liquid	BOSCH ABS9/ESP9 CAN
SP0077	Artificial exhaust	BOSCH ABS9/ESP9 CAN
SP0078	Wheel speed sensor test	BOSCH ABS9/ESP9 CAN
SP0079	Speed limit disable/enable	BOSCH ABS9/ESP9 CAN
SP0080	Deactivate valve relay closed	BOSCH ABS9/ESP9 CAN
SP0081	External slope sensor correction (optional body electronic stability system)	BOSCH ABS9/ESP9 CAN
SP0082	Pump motor relay	BOSCH ABS9/ESP9 CAN
SP0083	Intake valve, front left	BOSCH ABS9/ESP9 CAN
SP0084	Outlet valve, front left	BOSCH ABS9/ESP9 CAN
SP0085	Intake valve, front right	BOSCH ABS9/ESP9 CAN
SP0086	Outlet valve, front right	BOSCH ABS9/ESP9 CAN
SP0087	Intake valve, rear right	BOSCH ABS9/ESP9 CAN
SP0088	Outlet valve, rear right	BOSCH ABS9/ESP9 CAN
SP0089	Intake valve, rear left	BOSCH ABS9/ESP9 CAN
SP0090	Outlet valve, rear left	BOSCH ABS9/ESP9 CAN
SP0091	Switching valve 1 (USV1) (only electronic stability system)	BOSCH ABS9/ESP9 CAN
SP0092	Switching valve 2 (USV2) (only electronic stability system)	BOSCH ABS9/ESP9 CAN
SP0093	High pressure solenoid valve 1 (HSV1) (only electronic stability system)	BOSCH ABS9/ESP9 CAN
SP0094	High pressure solenoid valve 2 (HSV2) (only electronic stability system)	BOSCH ABS9/ESP9 CAN
SP0095	Anti-lock brake system (ABS) safety light	BOSCH ABS9/ESP9 CAN
SP0096	Body electronic stability system safety (only body electronic stability system)	BOSCH ABS9/ESP9 CAN
SP0097	Electronic Brake Force Distribution (EBD) Safety Light	BOSCH ABS9/ESP9 CAN

SP0098	Exhaust function	BOSCH ABS9 530K anti-lock brake system
SP0099	ECU reset	BOSCH ABS9 530K anti-lock brake system
SP0100	Matching key	Jicheng (UMC)
SP0101	Matching anti-theft device	Jicheng (UMC)
SP0102	Match engine ECU	Jicheng (UMC)
SP0103	Match a full set of new systems	Jicheng (UMC)
SP0104	Reset all adaptive values	Sunlight Tech (China Longhui)
SP0105	Atmospheric correction value fed back by air intake signal	Sunlight Tech (China Longhui)
SP0106	Half of the adaptive value of knock ignition angle	Sunlight Tech (China Longhui)
SP0107	Throttle position adaptive value adjustment	Sunlight Tech (China Longhui)
SP0108	Addition/multiplication adaptive factor for injection time of each group of cylinders (oxygen sensor)	Sunlight Tech (China Longhui)
SP0109	Idle speed adaptive value	Sunlight Tech (China Longhui)
SP0110	Segment adaptive value of engine rough value	Sunlight Tech (China Longhui)
SP0111	The adaptive value of the engine rough value heated by the catalytic package	Sunlight Tech (China Longhui)
SP0112	Carbon canister adaptive	Sunlight Tech (China Longhui)
SP0113	Write VIN code	Delphi MT22.1
SP0114	Tooth information learning	Delphi MT20U2
SP0115	Idle catalytic converter diagnosis	Delphi MT20U2
SP0116	Oxygen sensor feedback rationality diagnosis	Delphi MT20U2
SP0117	Write VIN	Delphi VVT ETC (National V)
SP0118	Write the repair department code or test serial number	Delphi VVT ETC (National V)
SP0119	Write programming date	Delphi VVT ETC (National V)
SP0120	Tooth information learning	Delphi MT20U2/CNG
SP0121	Idle catalytic converter diagnosis	Delphi MT20U2/CNG
SP0122	Oxygen sensor feedback rationality diagnosis	Delphi MT20U2/CNG
SP0123	Write VIN	UMC 4415
SP0124	Write forward clutch control offset value	Continuously variable transmission system (CVT)/Jianglu Rongda 1.3
SP0125	Write random access memory (RAM) and charged erasable read-only memory (EEPROM)	Continuously variable transmission system (CVT)/Jianglu Rongda 1.3
SP0126	Write random access memory (RAM)	Continuously variable transmission system (CVT)/Jianglu Rongda 1.3
SP0127	Write reverse clutch control offset value	Continuously variable transmission system (CVT)/Jianglu Rongda 1.3
SP0128	Write random access memory (RAM) and charged erasable read-only memory (EEPROM)	Continuously variable transmission system (CVT)/Jianglu Rongda 1.3
SP0129	Write random access memory (RAM)	Continuously variable transmission system (CVT)/Jianglu Rongda 1.3
SP0130	High idle speed	Continuously variable transmission system (CVT)/Jianglu Rongda 1.3
SP0131	Normal idling	Continuously variable transmission system (CVT)/Jianglu Rongda 1.3
SP0132	Write reset offline detection flag	Continuously variable transmission system (CVT)/Jianglu Rongda 1.3
SP0133	Brake exhaust	universal
SP0134	Write vehicle production date	Jinheng (BOSCH ABS10)
SP0135	Write the last repair date	Jinheng (BOSCH ABS10)
SP0136	Write VIN code	Jinheng (BOSCH ABS10)
SP0137	Write VIN code	Jicheng JIK009 (Sunshine Tektronix)
SP0138	Write repair station ID	Jicheng JIK009 (Sunshine Tektronix)
SP0139	Write programming date	Jicheng JIK009 (Sunshine Tektronix)
SP0140	Write diagnosis date	Jicheng JIK009 (Sunshine Tektronix)
SP0141	Tooth information learning	Engine Management System (ECM)/Delphi MT20U2/CNG
SP0142	Idle catalytic converter diagnosis	Engine Management System (ECM)/Delphi MT20U2/CNG
SP0143	Oxygen sensor feedback rationality diagnosis	Engine Management System (ECM)/Delphi MT20U2/CNG
SP0144	Write forward clutch control offset value	Continuously variable transmission system (CVT)/Jianglu Rongda 1.3
SP0145	Write random access memory (RAM) and charged erasable read-only memory (EEPROM)	Continuously variable transmission system (CVT)/Jianglu Rongda 1.3
SP0146	Write random access memory (RAM)	Continuously variable transmission system (CVT)/Jianglu Rongda 1.3
SP0147	Write reverse clutch control offset value	Continuously variable transmission system (CVT)/Jianglu Rongda 1.3
SP0148	Write random access memory (RAM) and charged erasable read-only memory (EEPROM)	Continuously variable transmission system (CVT)/Jianglu Rongda 1.3
SP0149	Write random access memory (RAM)	Continuously variable transmission system (CVT)/Jianglu Rongda 1.3

SP0150	High idle speed	Continuously variable transmission system (CVT)/Jianglu Rongda 1.3
SP0151	Normal idling	Continuously variable transmission system (CVT)/Jianglu Rongda 1.3
SP0152	Write reset offline detection flag	Continuously variable transmission system (CVT)/Jianglu Rongda 1.3
SP0153	Brake exhaust	universal
SP0154	Write vehicle production date	Jinheng (BOSCH ABS10)
SP0155	Write the last repair date	Jinheng (BOSCH ABS10)
SP0156	Write VIN code	Jinheng (BOSCH ABS10)
SP0157	Write VIN code	UMC ME17.8.8
SP0158	ECU reset	UMC ME17.8.8
SP0159	Write VIN code	Delphi MT22.5
SP0160	Write repair shop code or test serial number	Delphi MT22.5
SP0161	Write programming date	Delphi MT22.5
SP0162	ECU reset	Delphi MT22.5
SP0163	Delphi engine gear information learning	Delphi MT22.5
SP0164	Write forward clutch control offset value	Transmission system (TCU)/Jianglu Rongda 1.3
SP0165	Write random access memory (RAM) and charged erasable read-only memory (EEPROM)	Transmission system (TCU)/Jianglu Rongda 1.3
SP0166	Write random access memory (RAM)	Transmission system (TCU)/Jianglu Rongda 1.3
SP0167	Write reverse clutch control offset value	Transmission system (TCU)/Jianglu Rongda 1.3
SP0168	Write random access memory (RAM) and charged erasable read-only memory (EEPROM)	Transmission system (TCU)/Jianglu Rongda 1.3
SP0169	Write random access memory (RAM)	Transmission system (TCU)/Jianglu Rongda 1.3
SP0170	High idle speed	Transmission system (TCU)/Jianglu Rongda 1.3
SP0171	Normal idling	Transmission system (TCU)/Jianglu Rongda 1.3
SP0172	Write reset offline detection flag	Transmission system (TCU)/Jianglu Rongda 1.3
SP0173	Clear self-learning value	Transmission system (TCU)/PUNCH continuously variable transmission system
SP0174	ECU reset	Transmission system (TCU)/PUNCH continuously variable transmission system
SP0175	Write VIN code	Anti-lock brake system (ABS/ESP)/BOSCH ABS9/ESP9 CAN
SP0176	Write the spare part number of the vehicle manufacturer	Anti-lock brake system (ABS/ESP)/BOSCH ABS9/ESP9 CAN
SP0177	Write the status of the hydraulic valve group	Anti-lock brake system (ABS/ESP)/BOSCH ABS9/ESP9 CAN
SP0178	Write offline EOL status	Anti-lock brake system (ABS/ESP)/BOSCH ABS9/ESP9 CAN
SP0179	Write variable code (electronic stability system only)	Anti-lock brake system (ABS/ESP)/BOSCH ABS9/ESP9 CAN
SP0180	ECU reset	Anti-lock brake system (ABS/ESP)/BOSCH ABS9/ESP9 CAN
SP0181	Exhaust and liquid	Anti-lock brake system (ABS/ESP)/BOSCH ABS9/ESP9 CAN
SP0182	Artificial exhaust	Anti-lock brake system (ABS/ESP)/BOSCH ABS9/ESP9 CAN
SP0183	Wheel speed sensor test	Anti-lock brake system (ABS/ESP)/BOSCH ABS9/ESP9 CAN
SP0184	Speed limit disable/enable	Anti-lock brake system (ABS/ESP)/BOSCH ABS9/ESP9 CAN
SP0185	Deactivate valve relay closed	Anti-lock brake system (ABS/ESP)/BOSCH ABS9/ESP9 CAN
SP0186	External slope sensor correction (optional body electronic stability system)	Anti-lock brake system (ABS/ESP)/BOSCH ABS9/ESP9 CAN
SP0187	Pump motor relay	Anti-lock brake system (ABS/ESP)/BOSCH ABS9/ESP9 CAN
SP0188	Intake valve, front left	Anti-lock brake system (ABS/ESP)/BOSCH ABS9/ESP9 CAN
SP0189	Outlet valve, front left	Anti-lock brake system (ABS/ESP)/BOSCH ABS9/ESP9 CAN
SP0190	Intake valve, front right	Anti-lock brake system (ABS/ESP)/BOSCH ABS9/ESP9 CAN
SP0191	Outlet valve, front right	Anti-lock brake system (ABS/ESP)/BOSCH ABS9/ESP9 CAN
SP0192	Intake valve, rear right	Anti-lock brake system (ABS/ESP)/BOSCH ABS9/ESP9 CAN
SP0193	Outlet valve, rear right	Anti-lock brake system (ABS/ESP)/BOSCH ABS9/ESP9 CAN

SP0194	Intake valve, rear left	Anti-lock brake system (ABS/ESP)/BOSCH ABS9/ESP9 CAN
SP0195	Outlet valve, rear left	Anti-lock brake system (ABS/ESP)/BOSCH ABS9/ESP9 CAN
SP0196	Switching valve 1 (USV1) (only electronic stability system)	Anti-lock brake system (ABS/ESP)/BOSCH ABS9/ESP9 CAN
SP0197	Switching valve 2 (USV2) (only electronic stability system)	Anti-lock brake system (ABS/ESP)/BOSCH ABS9/ESP9 CAN
SP0198	High pressure solenoid valve 1 (HSV1) (only electronic stability system)	Anti-lock brake system (ABS/ESP)/BOSCH ABS9/ESP9 CAN
SP0199	High pressure solenoid valve 2 (HSV2) (only electronic stability system)	Anti-lock brake system (ABS/ESP)/BOSCH ABS9/ESP9 CAN
SP0200	Anti-lock brake system (ABS) safety light	Anti-lock brake system (ABS/ESP)/BOSCH ABS9/ESP9 CAN
SP0201	Body electronic stability system safety (only body electronic stability system)	Anti-lock brake system (ABS/ESP)/BOSCH ABS9/ESP9 CAN
SP0202	Electronic Brake Force Distribution (EBD) Safety Light	Anti-lock brake system (ABS/ESP)/BOSCH ABS9/ESP9 CAN
SP0203	Write VIN code	Airbag system (SRS)/TAKATA K 2 circuit
SP0204	Write the date of manufacture of the car	Airbag system (SRS)/TAKATA K 2 circuit
SP0205	Write VIN code	Body Control System (BCM)/China Airlines BCM
SP0206	Write remote window rise	Body Control System (BCM)/China Airlines BCM
SP0207	Turn signal lights up	Body Control System (BCM)/China Airlines BCM
SP0208	Position light is on	Body Control System (BCM)/China Airlines BCM
SP0209	Low beam lights up	Body Control System (BCM)/China Airlines BCM
SP0210	Daytime running lights are on	Body Control System (BCM)/China Airlines BCM
SP0211	The key light is on	Body Control System (BCM)/China Airlines BCM
SP0212	Top light is on	Body Control System (BCM)/China Airlines BCM
SP0213	Battery voltage	Body Control System (BCM)/China Airlines BCM
SP0214	Write configuration information	Body Control System (BCM)/China Airlines BCM
SP0215	ECU reset	Body Control System (BCM)/China Airlines BCM
SP0216	Write VIN code	Electric Power Steering System (EPS)/Henglong
SP0217	Write system name	Electric Power Steering System (EPS)/Henglong
SP0218	Write part number	Electric Power Steering System (EPS)/Henglong
SP0219	Write ECU software number	Electric Power Steering System (EPS)/Henglong
SP0220	Write ECU hardware number	Electric Power Steering System (EPS)/Henglong
SP0221	Write ECU installation date	Electric Power Steering System (EPS)/Henglong
SP0222	Write ECU software version number	Electric Power Steering System (EPS)/Henglong
SP0223	Write VIN	Delphi VVT ETC (National V)
SP0224	Write the repair department code or test serial number	Delphi VVT ETC (National V)
SP0225	Write programming date	Delphi VVT ETC (National V)
SP0226	Write forward clutch control offset value	Jianglu Rongda 1.3
SP0227	Write random access memory (RAM) and charged erasable read-only memory (EEPROM)	Jianglu Rongda 1.3
SP0228	Write random access memory (RAM)	Jianglu Rongda 1.3
SP0229	Write reverse clutch control offset value	Jianglu Rongda 1.3
SP0230	Write random access memory (RAM) and charged erasable read-only memory (EEPROM)	Jianglu Rongda 1.3
SP0231	Write random access memory (RAM)	Jianglu Rongda 1.3
SP0232	High idle speed	Jianglu Rongda 1.3
SP0233	Normal idling	Jianglu Rongda 1.3
SP0234	Write reset offline detection flag	Jianglu Rongda 1.3
SP0235	Brake exhaust	Universal anti-lock brake system
SP0236	Write vehicle production date	Jinheng (BOSCH ABS10)
SP0237	Write the last repair date	Jinheng (BOSCH ABS10)
SP0238	Write VIN code	Jinheng (BOSCH ABS10)
SP0239	Matching key	Jicheng (UMC)
SP0240	Matching anti-theft device	Jicheng (UMC)
SP0241	Match engine ECU	Jicheng (UMC)
SP0242	Match a full set of new systems	Jicheng (UMC)
SP0243	Write VIN code	UMC ME17.8.8
SP0244	ECU reset	UMC ME17.8.8
SP0245	Write VIN	Delphi VVT ETC (National V)
SP0246	Write the repair department code or test serial number	Delphi VVT ETC (National V)
SP0247	Write programming date	Delphi VVT ETC (National V)
SP0248	Crankshaft position sensor target gear tooth error learning	Delphi VVT ETC
SP0249	Oxygen sensor offline diagnosis	Delphi VVT ETC
SP0250	Catalytic converter offline diagnosis	Delphi VVT ETC
SP0251	Clear self-learning value	Transmission system (TCU)/PUCH transmission system

SP0252	ECU reset	Transmission system (TCU)/PUCH transmission system
SP0253	Write VIN code	BOSCH ABS9/EPS9 CAN
SP0254	Write the spare part number of the vehicle manufacturer	BOSCH ABS9/EPS9 CAN
SP0255	Write the status of the hydraulic valve group	BOSCH ABS9/EPS9 CAN
SP0256	Write offline EOL status	BOSCH ABS9/EPS9 CAN
SP0257	Write variable code (electronic stability system only)	BOSCH ABS9/EPS9 CAN
SP0258	ECU reset	BOSCH ABS9/EPS9 CAN
SP0259	Exhaust and liquid	BOSCH ABS9/EPS9 CAN
SP0260	Artificial exhaust	BOSCH ABS9/EPS9 CAN
SP0261	Wheel speed sensor test	BOSCH ABS9/EPS9 CAN
SP0262	Speed limit disable/enable	BOSCH ABS9/EPS9 CAN
SP0263	Deactivate valve relay closed	BOSCH ABS9/EPS9 CAN
SP0264	External slope sensor correction (optional body electronic stability system)	BOSCH ABS9/EPS9 CAN
SP0265	Pump motor relay	BOSCH ABS9/EPS9 CAN
SP0266	Intake valve, front left	BOSCH ABS9/EPS9 CAN
SP0267	Outlet valve, front left	BOSCH ABS9/EPS9 CAN
SP0268	Intake valve, front right	BOSCH ABS9/EPS9 CAN
SP0269	Outlet valve, front right	BOSCH ABS9/EPS9 CAN
SP0270	Intake valve, rear right	BOSCH ABS9/EPS9 CAN
SP0271	Outlet valve, rear right	BOSCH ABS9/EPS9 CAN
SP0272	Intake valve, rear left	BOSCH ABS9/EPS9 CAN
SP0273	Outlet valve, rear left	BOSCH ABS9/EPS9 CAN
SP0274	Switching valve 1 (USV1) (only electronic stability system)	BOSCH ABS9/EPS9 CAN
SP0275	Switching valve 2 (USV2) (only electronic stability system)	BOSCH ABS9/EPS9 CAN
SP0276	High pressure solenoid valve 1 (HSV1) (only electronic stability system)	BOSCH ABS9/EPS9 CAN
SP0277	High pressure solenoid valve 2 (HSV2) (only electronic stability system)	BOSCH ABS9/EPS9 CAN
SP0278	Anti-lock brake system (ABS) safety light	BOSCH ABS9/EPS9 CAN
SP0279	Body electronic stability system safety (only body electronic stability system)	BOSCH ABS9/EPS9 CAN
SP0280	Electronic Brake Force Distribution (EBD) Safety Light	BOSCH ABS9/EPS9 CAN
SP0281	Write VIN code	BOSCH ABS9 720 CAN
SP0282	Write the spare part number of the vehicle manufacturer	BOSCH ABS9 720 CAN
SP0283	Write the status of the hydraulic valve group	BOSCH ABS9 720 CAN
SP0284	Write offline EOL status	BOSCH ABS9 720 CAN
SP0285	Write variable code (electronic stability system only)	BOSCH ABS9 720 CAN
SP0286	ECU reset	BOSCH ABS9 720 CAN
SP0287	Exhaust and liquid	BOSCH ABS9 720 CAN
SP0288	Artificial exhaust	BOSCH ABS9 720 CAN
SP0289	Wheel speed sensor test	BOSCH ABS9 720 CAN
SP0290	Speed limit disable/enable	BOSCH ABS9 720 CAN
SP0291	Deactivate valve relay closed	BOSCH ABS9 720 CAN
SP0292	External slope sensor correction (optional body electronic stability system)	BOSCH ABS9 720 CAN
SP0293	Pump motor relay	BOSCH ABS9 720 CAN
SP0294	Intake valve, front left	BOSCH ABS9 720 CAN
SP0295	Outlet valve, front left	BOSCH ABS9 720 CAN
SP0296	Intake valve, front right	BOSCH ABS9 720 CAN
SP0297	Outlet valve, front right	BOSCH ABS9 720 CAN
SP0298	Intake valve, rear right	BOSCH ABS9 720 CAN
SP0299	Outlet valve, rear right	BOSCH ABS9 720 CAN
SP0300	Intake valve, rear left	BOSCH ABS9 720 CAN
SP0301	Outlet valve, rear left	BOSCH ABS9 720 CAN
SP0302	Switching valve 1 (USV1) (only electronic stability system)	BOSCH ABS9 720 CAN
SP0303	Switching valve 2 (USV2) (only electronic stability system)	BOSCH ABS9 720 CAN
SP0304	High pressure solenoid valve 1 (HSV1) (only electronic stability system)	BOSCH ABS9 720 CAN
SP0305	High pressure solenoid valve 2 (HSV2) (only electronic stability system)	BOSCH ABS9 720 CAN
SP0306	Anti-lock brake system (ABS) safety light	BOSCH ABS9 720 CAN
SP0307	Body electronic stability system safety (only body electronic stability system)	BOSCH ABS9 720 CAN
SP0308	Electronic Brake Force Distribution (EBD) Safety Light	BOSCH ABS9 720 CAN
SP0309	ECU working mode setting	Airbag System (SRS)/TAKATA CAN

SP0310	Write vehicle production date	Airbag System (SRS)/TAKATA CAN
SP0311	Write vehicle chassis number	Airbag System (SRS)/TAKATA CAN
SP0312	ECU reset	FBCM Front Body Control System (HIRAIN) (FBCM)
SP0313	ECU reset	RBCM Rear Body Control System (HIRAIN) (RBCM)
SP0314	ECU reset	PEPS/RKE (HIRAIN)
SP0315	Write VIN code	PEPS/RKE (HIRAIN)
SP0316	Matching key	Jicheng (UMC)
SP0317	Matching anti-theft device	Jicheng (UMC)
SP0318	Match engine ECU	Jicheng (UMC)
SP0319	Match a full set of new systems	Jicheng (UMC)
SP0320	Write VIN code	UMC ME17.8.8
SP0321	ECU reset	UMC ME17.8.8
SP0322	Write VIN code	Delphi MT22.5
SP0323	Write repair shop code or test serial number	Delphi MT22.5
SP0324	Write programming date	Delphi MT22.5
SP0325	ECU reset	Delphi MT22.5
SP0326	Delphi engine gear information learning	Delphi MT22.5
SP0327	Subrom offline data learning	8AT TCU
SP0328	Clear TCU adaptive data	8AT TCU
SP0329	Write TCU part number	8AT TCU
SP0330	Write VIN number	8AT TCU
SP0331	ECU reset	8AT TCU
SP0332	Transmission TCU option (write VIN code)	DSI TCU
SP0333	ECU reset	DSI TCU
SP0334	Reset or clear the transmission TCU self-learning value	DSI TCU
SP0335	Write VIN code	BOSCH ABS9/ESP9 CAN
SP0336	Write the spare part number of the vehicle manufacturer	BOSCH ABS9/ESP9 CAN
SP0337	Write the status of the hydraulic valve group	BOSCH ABS9/ESP9 CAN
SP0338	Write offline EOL status	BOSCH ABS9/ESP9 CAN
SP0339	Write variable code (electronic stability system only)	BOSCH ABS9/ESP9 CAN
SP0340	ECU reset	BOSCH ABS9/ESP9 CAN
SP0341	Exhaust and liquid	BOSCH ABS9/ESP9 CAN
SP0342	Artificial exhaust	BOSCH ABS9/ESP9 CAN
SP0343	Wheel speed sensor test	BOSCH ABS9/ESP9 CAN
SP0344	Speed limit disable/enable	BOSCH ABS9/ESP9 CAN
SP0345	Deactivate valve relay closed	BOSCH ABS9/ESP9 CAN
SP0346	External slope sensor correction (optional body electronic stability system)	BOSCH ABS9/ESP9 CAN
SP0347	Pump motor relay	BOSCH ABS9/ESP9 CAN
SP0348	Intake valve, front left	BOSCH ABS9/ESP9 CAN
SP0349	Outlet valve, front left	BOSCH ABS9/ESP9 CAN
SP0350	Intake valve, front right	BOSCH ABS9/ESP9 CAN
SP0351	Outlet valve, front right	BOSCH ABS9/ESP9 CAN
SP0352	Intake valve, rear right	BOSCH ABS9/ESP9 CAN
SP0353	Outlet valve, rear right	BOSCH ABS9/ESP9 CAN
SP0354	Intake valve, rear left	BOSCH ABS9/ESP9 CAN
SP0355	Outlet valve, rear left	BOSCH ABS9/ESP9 CAN
SP0356	Switching valve 1 (USV1) (only electronic stability system)	BOSCH ABS9/ESP9 CAN
SP0357	Switching valve 2 (USV2) (only electronic stability system)	BOSCH ABS9/ESP9 CAN
SP0358	High pressure solenoid valve 1 (HSV1) (only electronic stability system)	BOSCH ABS9/ESP9 CAN
SP0359	High pressure solenoid valve 2 (HSV2) (only electronic stability system)	BOSCH ABS9/ESP9 CAN
SP0360	Anti-lock brake system (ABS) safety light	BOSCH ABS9/ESP9 CAN
SP0361	Body electronic stability system safety (only body electronic stability system)	BOSCH ABS9/ESP9 CAN
SP0362	Electronic Brake Force Distribution (EBD) Safety Light	BOSCH ABS9/ESP9 CAN
SP0363	ECU reset	FBCM Front Body Control System (HIRAIN) (FBCM)
SP0364	ECU reset	RBCM Rear Body Control System (HIRAIN) (RBCM)
SP0365	Write VIN code	HIRAIN PEPS
SP0366	Write configuration information	HIRAIN PEPS
SP0367	Write ECU manufacturing date	HIRAIN PEPS
SP0368	Write OEM part number	HIRAIN PEPS
SP0369	Write parameter configuration information	HIRAIN PEPS
SP0370	Erase memory	HIRAIN PEPS
SP0371	Cancel key information	HIRAIN PEPS
SP0372	Power on ESCL (electronic steering column) for 30 seconds	HIRAIN PEPS
SP0373	Perform TPMS self-positioning	HIRAIN PEPS
SP0374	Write VIN code	AOZE PKE

SP0375	Write ECU software number	AOZE PKE
SP0376	Write ECU manufacturing date	AOZE PKE
SP0377	Write car manufacturer part number	AOZE PKE
SP0378	Write parameter configuration information	AOZE PKE
SP0379	Write ECU software version number	AOZE PKE
SP0380	Write the number of remote keys that have been learned	AOZE PKE
SP0381	Write VIN code	New Tongda IC
SP0382	Write car manufacturer part number	New Tongda IC
SP0383	Write the date of manufacture of the car on the production line	New Tongda IC
SP0384	Write VIN code	CAEA ATC
SP0385	Write the ECU production date of the supplier's production line	CAEA ATC
SP0386	Write programming date	CAEA ATC
SP0387	Write repair shop code or diagnostic equipment number	CAEA ATC
SP0388	Write ECU loading date	CAEA ATC
SP0389	Write the date of vehicle manufacturing on the production line	CAEA ATC
SP0390	Write hardware version number	CAEA ATC
SP0391	Write ECU serial number	CAEA ATC
SP0392	Write VIN	UMC 4415
SP0393	Write forward clutch control offset value	Jianglu Rongda 1.3
SP0394	Write random access memory (RAM) and charged erasable read-only memory (EEPROM)	Jianglu Rongda 1.3
SP0395	Write random access memory (RAM)	Jianglu Rongda 1.3
SP0396	Write reverse clutch control offset value	Jianglu Rongda 1.3
SP0397	Write random access memory (RAM) and charged erasable read-only memory (EEPROM)	Jianglu Rongda 1.3
SP0398	Write random access memory (RAM)	Jianglu Rongda 1.3
SP0399	High idle speed	Jianglu Rongda 1.3
SP0400	Normal idling	Jianglu Rongda 1.3
SP0401	Write reset offline detection flag	Jianglu Rongda 1.3
SP0402	Exhaust function	BOSCH ABS9 530K
SP0403	ECU reset	BOSCH ABS9 530K
SP0404	Write VIN code	BOSCH ABS9/ESP9 CAN
SP0405	Write the spare part number of the vehicle manufacturer	BOSCH ABS9/ESP9 CAN
SP0406	Write the status of the hydraulic valve group	BOSCH ABS9/ESP9 CAN
SP0407	Write offline EOL status	BOSCH ABS9/ESP9 CAN
SP0408	Write variable code (electronic stability system only)	BOSCH ABS9/ESP9 CAN
SP0409	ECU reset	BOSCH ABS9/ESP9 CAN
SP0410	Exhaust and liquid	BOSCH ABS9/ESP9 CAN
SP0411	Artificial exhaust	BOSCH ABS9/ESP9 CAN
SP0412	Wheel speed sensor test	BOSCH ABS9/ESP9 CAN
SP0413	Speed limit disable/enable	BOSCH ABS9/ESP9 CAN
SP0414	Deactivate valve relay closed	BOSCH ABS9/ESP9 CAN
SP0415	External slope sensor correction (optional body electronic stability system)	BOSCH ABS9/ESP9 CAN
SP0416	Pump motor relay	BOSCH ABS9/ESP9 CAN
SP0417	Intake valve, front left	BOSCH ABS9/ESP9 CAN
SP0418	Outlet valve, front left	BOSCH ABS9/ESP9 CAN
SP0419	Intake valve, front right	BOSCH ABS9/ESP9 CAN
SP0420	Outlet valve, front right	BOSCH ABS9/ESP9 CAN
SP0421	Intake valve, rear right	BOSCH ABS9/ESP9 CAN
SP0422	Outlet valve, rear right	BOSCH ABS9/ESP9 CAN
SP0423	Intake valve, rear left	BOSCH ABS9/ESP9 CAN
SP0424	Outlet valve, rear left	BOSCH ABS9/ESP9 CAN
SP0425	Switching valve 1 (USV1) (only electronic stability system)	BOSCH ABS9/ESP9 CAN
SP0426	Switching valve 2 (USV2) (only electronic stability system)	BOSCH ABS9/ESP9 CAN
SP0427	High pressure solenoid valve 1 (HSV1) (only electronic stability system)	BOSCH ABS9/ESP9 CAN
SP0428	High pressure solenoid valve 2 (HSV2) (only electronic stability system)	BOSCH ABS9/ESP9 CAN
SP0429	Anti-lock brake system (ABS) safety light	BOSCH ABS9/ESP9 CAN
SP0430	Body electronic stability system safety (only body electronic stability system)	BOSCH ABS9/ESP9 CAN
SP0431	Electronic Brake Force Distribution (EBD) Safety Light	BOSCH ABS9/ESP9 CAN
SP0432	Write VIN code	Wanchao PEPS/RKE (HIRAIN)
SP0433	Write configuration information	Wanchao PEPS/RKE (HIRAIN)
SP0434	Matching key	Jicheng (UMC)

SP0435	Matching anti-theft device	Jicheng (UMC)
SP0436	Match engine ECU	Jicheng (UMC)
SP0437	Match a full set of new systems	Jicheng (UMC)
SP0438	Write VIN code	UMC ME17.8.8
SP0439	ECU reset	UMC ME17.8.8
SP0440	Crankshaft position sensor target gear tooth error learning	Delphi VVT ETC engine system
SP0441	Oxygen sensor offline diagnosis	Delphi VVT ETC engine system
SP0442	Catalytic converter offline diagnosis	Delphi VVT ETC engine system
SP0443	Write VIN	Delphi VVT ETC (National V)
SP0444	Write the repair department code or test serial number	Delphi VVT ETC (National V)
SP0445	Write programming date	Delphi VVT ETC (National V)
SP0446	Clear self-learning value	PUCH CVT transmission system
SP0447	ECU reset	PUCH CVT transmission system
SP0448	Internal exhaust	Jingxi Heavy Industry BWI DBC78
SP0449	Write customer part number	Jingxi Heavy Industry BWI DBC78
SP0450	Write customer part number suffix	Jingxi Heavy Industry BWI DBC78
SP0451	Write manufacturing code	Jingxi Heavy Industry BWI DBC78
SP0452	Write date code	Jingxi Heavy Industry BWI DBC78
SP0453	Write year code	Jingxi Heavy Industry BWI DBC78
SP0454	Write broadcast code	Jingxi Heavy Industry BWI DBC78
SP0455	Write VIN code	BOSCH ABS9/ESP9 CAN
SP0456	Write the spare part number of the vehicle manufacturer	BOSCH ABS9/ESP9 CAN
SP0457	Write the status of the hydraulic valve group	BOSCH ABS9/ESP9 CAN
SP0458	Write offline EOL status	BOSCH ABS9/ESP9 CAN
SP0459	Write variable code (electronic stability system only)	BOSCH ABS9/ESP9 CAN
SP0460	ECU reset	BOSCH ABS9/ESP9 CAN
SP0461	Exhaust and liquid	BOSCH ABS9/ESP9 CAN
SP0462	Artificial exhaust	BOSCH ABS9/ESP9 CAN
SP0463	Wheel speed sensor test	BOSCH ABS9/ESP9 CAN
SP0464	Speed limit disable/enable	BOSCH ABS9/ESP9 CAN
SP0465	Deactivate valve relay closed	BOSCH ABS9/ESP9 CAN
SP0466	External slope sensor correction (optional body electronic stability system)	BOSCH ABS9/ESP9 CAN
SP0467	Pump motor relay	BOSCH ABS9/ESP9 CAN
SP0468	Intake valve, front left	BOSCH ABS9/ESP9 CAN
SP0469	Outlet valve, front left	BOSCH ABS9/ESP9 CAN
SP0470	Intake valve, front right	BOSCH ABS9/ESP9 CAN
SP0471	Outlet valve, front right	BOSCH ABS9/ESP9 CAN
SP0472	Intake valve, rear right	BOSCH ABS9/ESP9 CAN
SP0473	Outlet valve, rear right	BOSCH ABS9/ESP9 CAN
SP0474	Intake valve, rear left	BOSCH ABS9/ESP9 CAN
SP0475	Outlet valve, rear left	BOSCH ABS9/ESP9 CAN
SP0476	Switching valve 1 (USV1) (only electronic stability system)	BOSCH ABS9/ESP9 CAN
SP0477	Switching valve 2 (USV2) (only electronic stability system)	BOSCH ABS9/ESP9 CAN
SP0478	High pressure solenoid valve 1 (HSV1) (only electronic stability system)	BOSCH ABS9/ESP9 CAN
SP0479	High pressure solenoid valve 2 (HSV2) (only electronic stability system)	BOSCH ABS9/ESP9 CAN
SP0480	Anti-lock brake system (ABS) safety light	BOSCH ABS9/ESP9 CAN
SP0481	Body electronic stability system safety (only body electronic stability system)	BOSCH ABS9/ESP9 CAN
SP0482	Electronic Brake Force Distribution (EBD) Safety Light	BOSCH ABS9/ESP9 CAN
SP0483	Matching key	Jicheng (UMC) anti-theft system
SP0484	Matching anti-theft device	Jicheng (UMC) anti-theft system
SP0485	Match engine ECU	Jicheng (UMC) anti-theft system
SP0486	Match a full set of new systems	Jicheng (UMC) anti-theft system
SP0487	Write VIN code	UMC ME17.8.8
SP0488	ECU reset	UMC ME17.8.8
SP0489	Write crankshaft adaptive cylinder 1, 2, 3, 4 (tooth error correction)	Delphi Engine System
SP0490	Write crankshaft adaptive sampling technology (tooth error correction)	Delphi Engine System
SP0491	Write factory mode count	Delphi Engine System
SP0492	Write VIN code	Delphi Engine System
SP0493	Write repair shop code or diagnostic equipment number	Delphi Engine System
SP0494	Write programming re-flash date	Delphi Engine System
SP0495	ECU reset	Delphi Engine System
SP0496	Read EBS battery ID	Delphi Engine System

SP0497	Read EBS serial number	Delphi Engine System
SP0498	Read EBS version number	Delphi Engine System
SP0499	Write EBS battery ID	Delphi Engine System
SP0500	Delphi engine gear information learning	Delphi Engine System
SP0501	Clear local adaptation table	Automatic Transmission System (TCU)
SP0502	Write VIN code	Electronic stability/anti-lock brake system (ESP/ABS)
SP0503	Write the spare part number of the vehicle manufacturer	Electronic stability/anti-lock brake system (ESP/ABS)
SP0504	Fill in the status of the hydraulic valve group	Electronic stability/anti-lock brake system (ESP/ABS)
SP0505	Write EOL status	Electronic stability/anti-lock brake system (ESP/ABS)
SP0506	Write Variant code (electronic stability system only)	Electronic stability/anti-lock brake system (ESP/ABS)
SP0507	ECU reset	Electronic stability/anti-lock brake system (ESP/ABS)
SP0508	Delayed actuator control	Electronic stability/anti-lock brake system (ESP/ABS)
SP0509	Venting and filling	Electronic stability/anti-lock brake system (ESP/ABS)
SP0510	Artificial exhaust	Electronic stability/anti-lock brake system (ESP/ABS)
SP0511	Actuator test	Electronic stability/anti-lock brake system (ESP/ABS)
SP0512	Dynamic Testing	Electronic stability/anti-lock brake system (ESP/ABS)
SP0513	Wheel speed sensor test	Electronic stability/anti-lock brake system (ESP/ABS)
SP0514	Speed limit disable/enable	Electronic stability/anti-lock brake system (ESP/ABS)
SP0515	Deactivate valve relay closed	Electronic stability/anti-lock brake system (ESP/ABS)
SP0516	Safety auxiliary system calibration (optional electronic stability system)	Electronic stability/anti-lock brake system (ESP/ABS)
SP0517	External slope sensor correction (optional body electronic stability system)	Electronic stability/anti-lock brake system (ESP/ABS)
SP0518	Write VIN code	Airbag System (SRS)
SP0519	Write ECU programming date	Airbag System (SRS)
SP0520	Write the last service date	Airbag System (SRS)
SP0521	ECU reset	Airbag System (SRS)
SP0522	Write VIN code	Body Control System (BCM)
SP0523	ECU reset	Body Control System (BCM)
SP0524	Write configuration information	Body Control System (BCM)
SP0525	Write VIN code	Anti-theft system (IMMO)
SP0526	Write the date of manufacture of the car on the production line	Anti-theft system (IMMO)
SP0527	Write configuration information	Anti-theft system (IMMO)
SP0528	ECU reset	Anti-theft system (IMMO)
SP0529	Write VIN code	Instrument cluster system (ICM)
SP0530	Write ECU loading date	Instrument cluster system (ICM)
SP0531	ECU reset	Instrument cluster system (ICM)
SP0532	Write VIN code	Tire Pressure Monitoring System (TPMS)
SP0533	Write the installation date of the ECU on the production line	Tire Pressure Monitoring System (TPMS)
SP0534	Write sensor ID	Tire Pressure Monitoring System (TPMS)
SP0535	Write dynamic low voltage alarm value	Tire Pressure Monitoring System (TPMS)
SP0536	ECU reset	Tire Pressure Monitoring System (TPMS)
SP0537	Write VIN	Delphi Engine System (ECM)
SP0538	ECU reset	Delphi Engine System (ECM)
SP0539	Delphi engine gear information learning	Delphi Engine System (ECM)
SP0540	Transmission TCU option (write VIN code)	Automatic transmission control (DSI TCU)
SP0541	Reset or clear the transmission TCU self-learning value	Automatic transmission control (DSI TCU)
SP0542	Reset TCU	Automatic transmission control (DSI TCU)
SP0543	Intake valve, front left	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0544	Exhaust valve, front left	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0545	Intake valve, front right	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0546	Exhaust valve, front right	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0547	Intake valve, rear right	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0548	Exhaust valve, rear right	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0549	Intake valve, rear left	Anti-lock brake system (BOSCH) (ABS/ESP)

SP0550	Exhaust valve, rear left	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0551	Intake valve, front left	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0552	Exhaust valve, front left	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0553	Intake valve, front right	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0554	Exhaust valve, front right	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0555	Intake valve, rear right	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0556	Exhaust valve, rear right	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0557	Intake valve, rear left	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0558	Exhaust valve, rear left	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0559	Intake valve, front left	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0560	Exhaust valve, front left	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0561	Intake valve, front right	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0562	Exhaust valve, front right	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0563	Intake valve, rear right	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0564	Exhaust valve, rear right	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0565	Intake valve, rear left	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0566	Exhaust valve, rear left	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0567	Intake valve, front left	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0568	Exhaust valve, front left	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0569	Intake valve, front right	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0570	Exhaust valve, front right	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0571	Intake valve, rear right	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0572	Exhaust valve, rear right	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0573	Intake valve, rear left	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0574	Exhaust valve, rear left	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0575	Intake valve, front left	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0576	Exhaust valve, front left	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0577	Intake valve, front right	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0578	Exhaust valve, front right	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0579	Intake valve, rear right	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0580	Exhaust valve, rear right	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0581	Intake valve, rear left	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0582	Exhaust valve, rear left	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0583	Venting and filling	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0584	Artificial exhaust	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0585	Pump motor relay	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0586	Intake valve, front left	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0587	Exhaust valve, front left	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0588	Intake valve, front right	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0589	Exhaust valve, front right	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0590	Intake valve, rear right	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0591	Exhaust valve, rear right	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0592	Intake valve, rear left	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0593	Exhaust valve, rear left	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0594	USV1 (electronic stability program only)	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0595	USV2 (only electronic stability program)	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0596	HSV1 (electronic stability program only)	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0597	HSV2 (electronic stability program only)	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0598	ABS safety light	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0599	Safety light for body electronic stability system (only body electronic stability system)	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0600	EBD safety light	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0601	Pump motor relay	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0602	Intake valve, front left	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0603	Exhaust valve, front left	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0604	Intake valve, front right	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0605	Exhaust valve, front right	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0606	Intake valve, rear right	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0607	Exhaust valve, rear right	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0608	Intake valve, rear left	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0609	Exhaust valve, rear left	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0610	USV1 (electronic stability program only)	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0611	USV2 (only electronic stability program)	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0612	HSV1 (electronic stability program only)	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0613	HSV2 (electronic stability program only)	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0614	ABS safety light	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0615	Safety light for body electronic stability system (only body electronic stability system)	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0616	EBD safety light	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0617	Wheel speed sensor test	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0618	Speed limit disable/enable	Anti-lock brake system (BOSCH) (ABS/ESP)

SP0619	Deactivate valve relay closed	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0620	SAS (steering angle sensor)	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0621	Yaw rate sensor calibration	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0622	Vehicle manufacturer spare part number	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0623	Vehicle Identification Number (VIN)	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0624	Fill in the status of the hydraulic valve group	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0625	EOL status	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0626	Variant code (electronic stability system only)	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0627	ECU reset	Anti-lock brake system (BOSCH) (ABS/ESP)
SP0628	ECU reset	Airbag System (TAKATA) (SRS)
SP0629	Lifan Vehicle Identification Number	Airbag System (TAKATA) (SRS)
SP0630	Lifan production line's vehicle production date	Airbag System (TAKATA) (SRS)
SP0631	ECU reset	Front Body Control System (FBCM)
SP0632	Write VIN code	Front Body Control System (FBCM)
SP0633	Anti-pinch configuration	Front Body Control System (FBCM)
SP0634	Automatic wiper configuration	Front Body Control System (FBCM)
SP0635	Speed lock configuration	Front Body Control System (FBCM)
SP0636	ECU reset	Rear Body Control System (RBCM)
SP0637	Write VIN code	Rear Body Control System (RBCM)
SP0638	Write the spare part number of the vehicle manufacturer	Electric Power Steering System (JTEKT) (EPS)
SP0639	Write the software number of the vehicle manufacturer	Electric Power Steering System (JTEKT) (EPS)
SP0640	Write the ECU software version number of the OEM	Electric Power Steering System (JTEKT) (EPS)
SP0641	Write vehicle identification symbol	Electric Power Steering System (JTEKT) (EPS)
SP0642	Write the ECU hardware part number of the vehicle manufacturer	Electric Power Steering System (JTEKT) (EPS)
SP0643	Write system name	Electric Power Steering System (JTEKT) (EPS)
SP0644	Write ECU installation date	Electric Power Steering System (JTEKT) (EPS)
SP0645	Write VIN code	Anti-theft system (HIRAIN with PEPS) (IMMO)
SP0646	Write VIN code	Instrument System (DESAY) (IC)
SP0647	Write ECU installation date	Instrument System (DESAY) (IC)
SP0648	MT/No 120 overspeed alarm/No HDC	Instrument System (DESAY) (IC)
SP0649	AT/No 120 overspeed alarm/No HDC	Instrument System (DESAY) (IC)
SP0650	MT/No 120 overspeed alarm/With HDC	Instrument System (DESAY) (IC)
SP0651	AT/without 120 overspeed alarm/with HDC	Instrument System (DESAY) (IC)
SP0652	MT/with 120 overspeed alarm/without HDC	Instrument System (DESAY) (IC)
SP0653	AT/with 120 overspeed alarm/without HDC	Instrument System (DESAY) (IC)
SP0654	MT/with 120 overspeed alarm/with HDC	Instrument System (DESAY) (IC)
SP0655	AT/with 120 overspeed alarm/with HDC	Instrument System (DESAY) (IC)
SP0656	Maintenance confirmation	Instrument System (DESAY) (IC)
SP0657	Maintenance reset	Instrument System (DESAY) (IC)
SP0658	First maintenance reminder: 3000 kilometers (default)	Instrument System (DESAY) (IC)
SP0659	First maintenance reminder: 5000 kilometers	Instrument System (DESAY) (IC)
SP0660	Routine insurance reminder mileage: 5000 kilometers (default)	Instrument System (DESAY) (IC)
SP0661	Routine insurance reminder mileage: 8000 kilometers	Instrument System (DESAY) (IC)
SP0662	Routine insurance reminder mileage: 10,000 kilometers	Instrument System (DESAY) (IC)
SP0663	Write VIN	Air Conditioning System (AC)/Front Air Conditioning (CAEA ATC)
SP0664	Date of vehicle manufacture on the LIFAN production line	Air Conditioning System (AC)/Front Air Conditioning (CAEA ATC)
SP0665	Write VIN	Air Conditioning System (AC)/Rear Air Conditioning (CAEA RATC)
SP0666	Date of vehicle manufacture on the LIFAN production line	Air Conditioning System (AC)/Rear Air Conditioning (CAEA RATC)
SP0667	ECU reset	Electronic Parking System (EPB)
SP0668	Write vehicle identification code VIN	Electronic Parking System (EPB)
SP0669	Write ECU installation date	Electronic Parking System (EPB)
SP0670	Write factory pattern	Electronic Parking System (EPB)
SP0671	Write gap self-adjusting kilometers	Electronic Parking System (EPB)
SP0672	Left actuator control	Electronic Parking System (EPB)
SP0673	application	Electronic Parking System (EPB)
SP0674	freed	Electronic Parking System (EPB)
SP0675	Separate	Electronic Parking System (EPB)
SP0676	Engage in	Electronic Parking System (EPB)
SP0677	Right actuator control	Electronic Parking System (EPB)
SP0678	application	Electronic Parking System (EPB)
SP0679	freed	Electronic Parking System (EPB)
SP0680	Separate	Electronic Parking System (EPB)
SP0681	Engage in	Electronic Parking System (EPB)
SP0682	EPB system actuator control	Electronic Parking System (EPB)
SP0683	application	Electronic Parking System (EPB)

SP0684	freed	Electronic Parking System (EPB)
SP0685	Separate	Electronic Parking System (EPB)
SP0686	Engage in	Electronic Parking System (EPB)
SP0687	G-Sensor calibration	Electronic Parking System (EPB)
SP0688	Assembly inspection	Electronic Parking System (EPB)
SP0689	application	Electronic Parking System (EPB)
SP0690	freed	Electronic Parking System (EPB)
SP0691	Separate	Electronic Parking System (EPB)
SP0692	Engage in	Electronic Parking System (EPB)
SP0693	Hardware reset	360-degree panoramic image system (AVM)
SP0694	Software reset	360-degree panoramic image system (AVM)
SP0695	Write vehicle identification code	360-degree panoramic image system (AVM)
SP0696	Write ECU installation date	360-degree panoramic image system (AVM)
SP0697	Write vehicle feature code	360-degree panoramic image system (AVM)
SP0698	Write body color configuration	360-degree panoramic image system (AVM)
SP0699	AVM panoramic automatic calibration	360-degree panoramic image system (AVM)
SP0700	AVM panoramic manual calibration	360-degree panoramic image system (AVM)
SP0701	Activate AVM panoramic system	360-degree panoramic image system (AVM)
SP0702	Write data	UMC ME17.8.8
SP0703	Vehicle identification code VIN	UMC ME17.8.8
SP0704	ECU reset	UMC ME17.8.8
SP0705	Write crankshaft adaptive cylinder 1, 2, 3, 4 (tooth error correction)	Delphi
SP0706	Write crankshaft adaptive sampling count (tooth error correction)	Delphi
SP0707	Write factory mode count	Delphi
SP0708	Write vehicle identification code VIN	Delphi
SP0709	Write repair shop code or diagnostic equipment number	Delphi
SP0710	Write programming re-flash date	Delphi
SP0711	ECU reset	Delphi
SP0712	Clear local adaptation table	WLY CVT TCU
SP0713	Write data	BOSCH ABS9/ESP9 CAN
SP0714	Vehicle manufacturer spare part number	BOSCH ABS9/ESP9 CAN
SP0715	Vehicle Identification Number (VIN)	BOSCH ABS9/ESP9 CAN
SP0716	Fill in the status of the hydraulic valve group	BOSCH ABS9/ESP9 CAN
SP0717	EOL status	BOSCH ABS9/ESP9 CAN
SP0718	Variant code (electronic stability system only)	BOSCH ABS9/ESP9 CAN
SP0719	ECU reset	BOSCH ABS9/ESP9 CAN
SP0720	ECU reset	Airbag System (SRS)
SP0721	Write VIN number	Body Control System (BCM)
SP0722	Write configuration information	Body Control System (BCM)
SP0723	ECU reset	Body Control System (BCM)
SP0724	Write VIN number	Anti-theft system (IMMO)
SP0725	Write the installation date of the ECU on the Lifan production line	Anti-theft system (IMMO)
SP0726	Write configuration information	Anti-theft system (IMMO)
SP0727	ECU reset	Anti-theft system (IMMO)
SP0728	Write vehicle identification code	Instrumentation System (ICM)
SP0729	Write ECU loading date	Instrumentation System (ICM)
SP0730	ECU reset	Instrumentation System (ICM)
SP0731	ECU reset	Tire Pressure Monitoring System (TPMS)
SP0732	Write VIN code	Engine Management System (EMS)
SP0733	ECU reset	Engine Management System (EMS)
SP0734	Write forward clutch control offset value	Automatic Transmission System (TCU)
SP0735	Write random access memory (RAM) and charged erasable read-only memory (EEPROM)	Automatic Transmission System (TCU)
SP0736	Write random access memory (RAM)	Automatic Transmission System (TCU)
SP0737	Write reverse clutch control offset value	Automatic Transmission System (TCU)
SP0738	Write random access memory (RAM) and charged erasable read-only memory (EEPROM)	Automatic Transmission System (TCU)
SP0739	Write random access memory (RAM)	Automatic Transmission System (TCU)
SP0740	High idle speed	Automatic Transmission System (TCU)
SP0741	Normal idling	Automatic Transmission System (TCU)
SP0742	Write reset offline detection flag	Automatic Transmission System (TCU)
SP0743	Write VIN code	Anti-lock brake system (ABS)
SP0744	Write the spare part number of the vehicle manufacturer	Anti-lock brake system (ABS)
SP0745	Write the status of the hydraulic valve group	Anti-lock brake system (ABS)
SP0746	Write offline EOL status	Anti-lock brake system (ABS)
SP0747	Write variable code (electronic stability system only)	Anti-lock brake system (ABS)
SP0748	ECU reset	Anti-lock brake system (ABS)
SP0749	Exhaust and liquid	Anti-lock brake system (ABS)

SP0750	Artificial exhaust	Anti-lock brake system (ABS)
SP0751	Wheel speed sensor test	Anti-lock brake system (ABS)
SP0752	Speed limit disable/enable	Anti-lock brake system (ABS)
SP0753	Deactivate valve relay closed	Anti-lock brake system (ABS)
SP0754	External slope sensor correction (optional body electronic stability system)	Anti-lock brake system (ABS)
SP0755	Actuator test	Anti-lock brake system (ABS)
SP0756	Pump motor relay	Anti-lock brake system (ABS)
SP0757	Intake valve, front left	Anti-lock brake system (ABS)
SP0758	Outlet valve, front left	Anti-lock brake system (ABS)
SP0759	Intake valve, front right	Anti-lock brake system (ABS)
SP0760	Outlet valve, front right	Anti-lock brake system (ABS)
SP0761	Intake valve, rear right	Anti-lock brake system (ABS)
SP0762	Outlet valve, rear right	Anti-lock brake system (ABS)
SP0763	Intake valve, rear left	Anti-lock brake system (ABS)
SP0764	Outlet valve, rear left	Anti-lock brake system (ABS)
SP0765	Switching valve 1 (USV1) (only electronic stability system)	Anti-lock brake system (ABS)
SP0766	Switching valve 2 (USV2) (only electronic stability system)	Anti-lock brake system (ABS)
SP0767	High pressure solenoid valve 1 (HSV1) (only electronic stability system)	Anti-lock brake system (ABS)
SP0768	High pressure solenoid valve 2 (HSV2) (only electronic stability system)	Anti-lock brake system (ABS)
SP0769	Anti-lock brake system (ABS) safety light	Anti-lock brake system (ABS)
SP0770	Body electronic stability system safety (only body electronic stability system)	Anti-lock brake system (ABS)
SP0771	Electronic Brake Force Distribution (EBD) Safety Light	Anti-lock brake system (ABS)
SP0772	Pump motor relay	Anti-lock brake system (ABS)
SP0773	Intake valve, front left	Anti-lock brake system (ABS)
SP0774	Outlet valve, front left	Anti-lock brake system (ABS)
SP0775	Intake valve, front right	Anti-lock brake system (ABS)
SP0776	Outlet valve, front right	Anti-lock brake system (ABS)
SP0777	Intake valve, rear right	Anti-lock brake system (ABS)
SP0778	Outlet valve, rear right	Anti-lock brake system (ABS)
SP0779	Intake valve, rear left	Anti-lock brake system (ABS)
SP0780	Outlet valve, rear left	Anti-lock brake system (ABS)
SP0781	Switching valve 1 (USV1) (only electronic stability system)	Anti-lock brake system (ABS)
SP0782	Switching valve 2 (USV2) (only electronic stability system)	Anti-lock brake system (ABS)
SP0783	High pressure solenoid valve 1 (HSV1) (only electronic stability system)	Anti-lock brake system (ABS)
SP0784	High pressure solenoid valve 2 (HSV2) (only electronic stability system)	Anti-lock brake system (ABS)
SP0785	Anti-lock brake system (ABS) safety light	Anti-lock brake system (ABS)
SP0786	Body electronic stability system safety (only body electronic stability system)	Anti-lock brake system (ABS)
SP0787	Electronic Brake Force Distribution (EBD) Safety Light	Anti-lock brake system (ABS)
SP0788	Delayed actuator control	Anti-lock brake system (ABS)
SP0789	Write VIN code	Body Control System (BCM)
SP0790	ECU reset	Body Control System (BCM)
SP0791	Write VIN code	Electric Power Steering System (EPS)
SP0792	Write system name	Electric Power Steering System (EPS)
SP0793	Write part number	Electric Power Steering System (EPS)
SP0794	Write ECU software number	Electric Power Steering System (EPS)
SP0795	Write ECU hardware number	Electric Power Steering System (EPS)
SP0796	Write ECU installation date	Electric Power Steering System (EPS)
SP0797	Write ECU software version number	Electric Power Steering System (EPS)
SP0798	Steering wheel angle median learning	Electric Power Steering System (EPS)
SP0799	Write VIN code	Anti-theft controller (IMMO)
SP0800	Write VIN code	Instrumentation System (ICM)
SP0801	Write ECU loading date	Instrumentation System (ICM)
SP0802	ECU reset	Instrumentation System (ICM)
SP0803	Write VIN code	Tire Pressure Monitoring System (TPMS)
SP0804	Write ECU installation date	Tire Pressure Monitoring System (TPMS)
SP0805	Write sensor ID	Tire Pressure Monitoring System (TPMS)
SP0806	Write dynamic low voltage alarm value	Tire Pressure Monitoring System (TPMS)
SP0807	ECU reset	Tire Pressure Monitoring System (TPMS)
SP0808	Write VIN code	Electronic Parking System (EPB)
SP0809	ECU reset	Electronic Parking System (EPB)

SP0810	Maintenance release	Electronic Parking System (EPB)
SP0811	Angle calibration	Electronic Parking System (EPB)
SP0812	Write VIN code	Delphi
SP0813	ECU reset	Delphi
SP0814	Delphi engine gear information learning	Delphi
SP0815	Write VIN code	UMC ME17.8.8
SP0816	ECU reset	UMC ME17.8.8
SP0817	Intake valve, front left	ESP (BOSCH)
SP0818	Exhaust valve, front left	ESP (BOSCH)
SP0819	Intake valve, front right	ESP (BOSCH)
SP0820	Exhaust valve, front right	ESP (BOSCH)
SP0821	Intake valve, rear right	ESP (BOSCH)
SP0822	Exhaust valve, rear right	ESP (BOSCH)
SP0823	Intake valve, rear left	ESP (BOSCH)
SP0824	Exhaust valve, rear left	ESP (BOSCH)
SP0825	Intake valve, front left	ESP (BOSCH)
SP0826	Exhaust valve, front left	ESP (BOSCH)
SP0827	Intake valve, front right	ESP (BOSCH)
SP0828	Exhaust valve, front right	ESP (BOSCH)
SP0829	Intake valve, rear right	ESP (BOSCH)
SP0830	Exhaust valve, rear right	ESP (BOSCH)
SP0831	Intake valve, rear left	ESP (BOSCH)
SP0832	Exhaust valve, rear left	ESP (BOSCH)
SP0833	Intake valve, front left	ESP (BOSCH)
SP0834	Exhaust valve, front left	ESP (BOSCH)
SP0835	Intake valve, front right	ESP (BOSCH)
SP0836	Exhaust valve, front right	ESP (BOSCH)
SP0837	Intake valve, rear right	ESP (BOSCH)
SP0838	Exhaust valve, rear right	ESP (BOSCH)
SP0839	Intake valve, rear left	ESP (BOSCH)
SP0840	Exhaust valve, rear left	ESP (BOSCH)
SP0841	Intake valve, front left	ESP (BOSCH)
SP0842	Exhaust valve, front left	ESP (BOSCH)
SP0843	Intake valve, front right	ESP (BOSCH)
SP0844	Exhaust valve, front right	ESP (BOSCH)
SP0845	Intake valve, rear right	ESP (BOSCH)
SP0846	Exhaust valve, rear right	ESP (BOSCH)
SP0847	Intake valve, rear left	ESP (BOSCH)
SP0848	Exhaust valve, rear left	ESP (BOSCH)
SP0849	Intake valve, front left	ESP (BOSCH)
SP0850	Exhaust valve, front left	ESP (BOSCH)
SP0851	Intake valve, front right	ESP (BOSCH)
SP0852	Exhaust valve, front right	ESP (BOSCH)
SP0853	Intake valve, rear right	ESP (BOSCH)
SP0854	Exhaust valve, rear right	ESP (BOSCH)
SP0855	Intake valve, rear left	ESP (BOSCH)
SP0856	Exhaust valve, rear left	ESP (BOSCH)
SP0857	Venting and filling	ESP (BOSCH)
SP0858	Artificial exhaust	ESP (BOSCH)
SP0859	Pump motor relay	ESP (BOSCH)
SP0860	Intake valve, front left	ESP (BOSCH)
SP0861	Exhaust valve, front left	ESP (BOSCH)
SP0862	Intake valve, front right	ESP (BOSCH)
SP0863	Exhaust valve, front right	ESP (BOSCH)
SP0864	Intake valve, rear right	ESP (BOSCH)
SP0865	Exhaust valve, rear right	ESP (BOSCH)
SP0866	Intake valve, rear left	ESP (BOSCH)
SP0867	Exhaust valve, rear left	ESP (BOSCH)
SP0868	USV1 (electronic stability program only)	ESP (BOSCH)
SP0869	USV2 (only electronic stability program)	ESP (BOSCH)
SP0870	HSV1 (electronic stability program only)	ESP (BOSCH)
SP0871	HSV2 (electronic stability program only)	ESP (BOSCH)
SP0872	ABS safety light	ESP (BOSCH)
SP0873	Safety light for body electronic stability system (only body electronic stability system)	ESP (BOSCH)
SP0874	EBD safety light	ESP (BOSCH)
SP0875	Pump motor relay	ESP (BOSCH)
SP0876	Intake valve, front left	ESP (BOSCH)
SP0877	Exhaust valve, front left	ESP (BOSCH)
SP0878	Intake valve, front right	ESP (BOSCH)
SP0879	Exhaust valve, front right	ESP (BOSCH)

SP0880	Intake valve, rear right	ESP (BOSCH)
SP0881	Exhaust valve, rear right	ESP (BOSCH)
SP0882	Intake valve, rear left	ESP (BOSCH)
SP0883	Exhaust valve, rear left	ESP (BOSCH)
SP0884	USV1 (electronic stability program only)	ESP (BOSCH)
SP0885	USV2 (only electronic stability program)	ESP (BOSCH)
SP0886	HSV1 (electronic stability program only)	ESP (BOSCH)
SP0887	HSV2 (electronic stability program only)	ESP (BOSCH)
SP0888	ABS safety light	ESP (BOSCH)
SP0889	Safety light for body electronic stability system (only body electronic stability system)	ESP (BOSCH)
SP0890	EBD safety light	ESP (BOSCH)
SP0891	Wheel speed sensor test	ESP (BOSCH)
SP0892	Speed limit disable/enable	ESP (BOSCH)
SP0893	Deactivate valve relay closed	ESP (BOSCH)
SP0894	SAS (steering angle sensor)	ESP (BOSCH)
SP0895	Yaw rate sensor calibration	ESP (BOSCH)
SP0896	Write data	ESP (BOSCH)
SP0897	Vehicle manufacturer spare part number	ESP (BOSCH)
SP0898	Vehicle Identification Number (VIN)	ESP (BOSCH)
SP0899	Fill in the status of the hydraulic valve group	ESP (BOSCH)
SP0900	EOL status	ESP (BOSCH)
SP0901	Variant code (electronic stability system only)	ESP (BOSCH)
SP0902	ECU reset	ESP (BOSCH)
SP0903	ECU reset	Wanxiang Seiko WX20/V5 anti-lock brake system
SP0904	BBS exhaust	Wanxiang Seiko WX20/V5 anti-lock brake system
SP0905	ECU reset	Airbag System (SRS)/Maiwei Airbag System
SP0906	Write VIN code	Airbag System (SRS)/Maiwei Airbag System
SP0907	Write ECU programming date	Airbag System (SRS)/Maiwei Airbag System
SP0908	Write the date of the last airbag module overhaul	Airbag System (SRS)/Maiwei Airbag System
SP0909	Write VIN code	Body Control System (BCM)/Maiwei Body Control System
SP0910	ECU reset	Body Control System (BCM)/Maiwei Body Control System
SP0911	Write programming date	Body Control System (BCM)/Maiwei Body Control System
SP0912	Angle sensor orientation centering	Yubei
SP0913	Center the steering wheel	Yubei
SP0914	Clear steering wheel alignment data	Yubei
SP0915	Torque sensor zero calibration	Otnik
SP0916	Zero calibration of angle sensor	Otnik
SP0917	Write VIN code	Anti-theft system (IMMO)/Maiwei anti-theft system
SP0918	Write ECU programming date	Anti-theft system (IMMO)/Maiwei anti-theft system
SP0919	Write VIN code	Instrumentation System (ICM)/Maiwei Instrumentation System
SP0920	Write ECU software number	Instrumentation System (ICM)/Maiwei Instrumentation System
SP0921	Write ECU software version number	Instrumentation System (ICM)/Maiwei Instrumentation System
SP0922	Write ECU programming date	Instrumentation System (ICM)/Maiwei Instrumentation System
SP0923	Write the installation date of the electronic control unit	Instrumentation System (ICM)/Maiwei Instrumentation System
SP0924	Write vehicle production date	Instrumentation System (ICM)/Maiwei Instrumentation System
SP0925	Write configuration information	Instrumentation System (ICM)/Maiwei Instrumentation System
SP0926	ECU reset	Tire Pressure Monitoring System (TPMS)
SP0927	Factory reset	Tire Pressure Monitoring System (TPMS)
SP0928	Start the reliability test of the tire pressure monitoring system	Tire Pressure Monitoring System (TPMS)
SP0929	After-sales learning tire pressure sensor	Tire Pressure Monitoring System (TPMS)
SP0930	Learn left front wheel	Tire Pressure Monitoring System (TPMS)
SP0931	Learn left rear wheel	Tire Pressure Monitoring System (TPMS)
SP0932	Learn right rear wheel	Tire Pressure Monitoring System (TPMS)
SP0933	Learn right front wheel	Tire Pressure Monitoring System (TPMS)
SP0934	Write VIN code	Internet of Vehicles System (TBOX)
SP0935	Write ECU installation date	Internet of Vehicles System (TBOX)
SP0936	Write car name	Internet of Vehicles System (TBOX)

SP0937	Write ECU software version number	Internet of Vehicles System (TBOX)
SP0938	Write crankshaft adaptive cylinder 1, 2, 3, 4 (tooth error correction)	Delphi
SP0939	Write crankshaft adaptive sampling count (tooth error correction)	Delphi
SP0940	Write factory mode count	Delphi
SP0941	Write vehicle identification code VIN	Delphi
SP0942	Write repair shop code or diagnostic equipment number	Delphi
SP0943	Write programming re-flash date	Delphi
SP0944	ECU reset	Delphi
SP0945	Vehicle Identification Number (VIN)	UMC ME17.8.8
SP0946	Write repair shop code	UMC ME17.8.8
SP0947	ECU reset	UMC ME17.8.8
SP0948	Subrom offline data learning	Automatic Transmission Control (TCU)
SP0949	Clear TCU adaptive data	Automatic Transmission Control (TCU)
SP0950	Write TCU part number	Automatic Transmission Control (TCU)
SP0951	Write VIN number	Automatic Transmission Control (TCU)
SP0952	ECU reset	Automatic Transmission Control (TCU)
SP0953	ECU reset	Wanxiang Seiko WX20/V5
SP0954	Artificial exhaust	Wanxiang Seiko WX20/V5
SP0955	Write VIN code	Electronic Stability System (ESP) (BOSCH)
SP0956	Write the spare part number of the vehicle manufacturer	Electronic Stability System (ESP) (BOSCH)
SP0957	Write the status of the hydraulic valve group	Electronic Stability System (ESP) (BOSCH)
SP0958	Write offline EOL status	Electronic Stability System (ESP) (BOSCH)
SP0959	Write variable code (electronic stability system only)	Electronic Stability System (ESP) (BOSCH)
SP0960	ECU reset	Electronic Stability System (ESP) (BOSCH)
SP0961	Exhaust and liquid	Electronic Stability System (ESP) (BOSCH)
SP0962	Artificial exhaust	Electronic Stability System (ESP) (BOSCH)
SP0963	Wheel speed sensor test	Electronic Stability System (ESP) (BOSCH)
SP0964	Speed limit disable/enable	Electronic Stability System (ESP) (BOSCH)
SP0965	Deactivate valve relay closed	Electronic Stability System (ESP) (BOSCH)
SP0966	External slope sensor correction (optional body electronic stability system)	Electronic Stability System (ESP) (BOSCH)
SP0967	Actuator test	Electronic Stability System (ESP) (BOSCH)
SP0968	Pump motor relay	Electronic Stability System (ESP) (BOSCH)
SP0969	Intake valve, front left	Electronic Stability System (ESP) (BOSCH)
SP0970	Outlet valve, front left	Electronic Stability System (ESP) (BOSCH)
SP0971	Intake valve, front right	Electronic Stability System (ESP) (BOSCH)
SP0972	Outlet valve, front right	Electronic Stability System (ESP) (BOSCH)
SP0973	Intake valve, rear right	Electronic Stability System (ESP) (BOSCH)
SP0974	Outlet valve, rear right	Electronic Stability System (ESP) (BOSCH)
SP0975	Intake valve, rear left	Electronic Stability System (ESP) (BOSCH)
SP0976	Outlet valve, rear left	Electronic Stability System (ESP) (BOSCH)
SP0977	Switching valve 1 (USV1) (only electronic stability system)	Electronic Stability System (ESP) (BOSCH)
SP0978	Switching valve 2 (USV2) (only electronic stability system)	Electronic Stability System (ESP) (BOSCH)
SP0979	High pressure solenoid valve 1 (HSV1) (only electronic stability system)	Electronic Stability System (ESP) (BOSCH)
SP0980	High pressure solenoid valve 2 (HSV2) (only electronic stability system)	Electronic Stability System (ESP) (BOSCH)
SP0981	Anti-lock brake system (ABS) safety light	Electronic Stability System (ESP) (BOSCH)
SP0982	Body electronic stability system safety (only body electronic stability system)	Electronic Stability System (ESP) (BOSCH)
SP0983	Electronic Brake Force Distribution (EBD) Safety Light	Electronic Stability System (ESP) (BOSCH)
SP0984	Pump motor relay	Electronic Stability System (ESP) (BOSCH)
SP0985	Intake valve, front left	Electronic Stability System (ESP) (BOSCH)
SP0986	Outlet valve, front left	Electronic Stability System (ESP) (BOSCH)
SP0987	Intake valve, front right	Electronic Stability System (ESP) (BOSCH)
SP0988	Outlet valve, front right	Electronic Stability System (ESP) (BOSCH)
SP0989	Intake valve, rear right	Electronic Stability System (ESP) (BOSCH)
SP0990	Outlet valve, rear right	Electronic Stability System (ESP) (BOSCH)
SP0991	Intake valve, rear left	Electronic Stability System (ESP) (BOSCH)
SP0992	Outlet valve, rear left	Electronic Stability System (ESP) (BOSCH)
SP0993	Switching valve 1 (USV1) (only electronic stability system)	Electronic Stability System (ESP) (BOSCH)
SP0994	Switching valve 2 (USV2) (only electronic stability system)	Electronic Stability System (ESP) (BOSCH)
SP0995	High pressure solenoid valve 1 (HSV1) (only electronic stability system)	Electronic Stability System (ESP) (BOSCH)

SP0996	High pressure solenoid valve 2 (HSV2) (only electronic stability system)	Electronic Stability System (ESP) (BOSCH)
SP0997	Anti-lock brake system (ABS) safety light	Electronic Stability System (ESP) (BOSCH)
SP0998	Body electronic stability system safety (only body electronic stability system)	Electronic Stability System (ESP) (BOSCH)
SP0999	Electronic Brake Force Distribution (EBD) Safety Light	Electronic Stability System (ESP) (BOSCH)
SP1000	Delayed actuator control	Electronic Stability System (ESP) (BOSCH)
SP1001	Write ECU installation date	Airbag System (SRS)
SP1002	Write VIN number	Airbag System (SRS)
SP1003	Write ECU programming date	Airbag System (SRS)
SP1004	ECU reset	Airbag System (SRS)
SP1005	Write ECU serial number	Del FBCM
SP1006	Write ECU programming date	Del FBCM
SP1007	Write vehicle identification number VIN	Del FBCM
SP1008	EMS confirmation	Del FBCM
SP1009	EMS matching	Del FBCM
SP1010	Key matching	Del FBCM
SP1011	Key erase	Del FBCM
SP1012	Engine SK erase	Del FBCM
SP1013	ECU reset	Del FBCM
SP1014	Write ECU serial number	Wanchao FBCM
SP1015	Write ECU programming date	Wanchao FBCM
SP1016	Write vehicle identification number VIN	Wanchao FBCM
SP1017	ECU reset	Wanchao FBCM
SP1018	Write the OEM software number	Rear Body Control System (RBCM)/Del RBCM
SP1019	Write the software version number of the host factory	Rear Body Control System (RBCM)/Del RBCM
SP1020	Write VIN number	Rear Body Control System (RBCM)/Del RBCM
SP1021	Write the ECU hardware number of the OEM	Rear Body Control System (RBCM)/Del RBCM
SP1022	Write ECU programming date	Rear Body Control System (RBCM)/Del RBCM
SP1023	Write ECU installation date	Rear Body Control System (RBCM)/Del RBCM
SP1024	Write vehicle configuration information	Rear Body Control System (RBCM)/Del RBCM
SP1025	Write radar mode configuration	Rear Body Control System (RBCM)/Del RBCM
SP1026	ECU reset	Rear Body Control System (RBCM)/Del RBCM
SP1027	Write the OEM software number	Anti-theft system (IMMO)
SP1028	Write the software version number of the host factory	Anti-theft system (IMMO)
SP1029	Write ECU serial number	Anti-theft system (IMMO)
SP1030	Write VIN number	Anti-theft system (IMMO)
SP1031	Write the ECU hardware number of the OEM	Anti-theft system (IMMO)
SP1032	Write ECU programming date	Anti-theft system (IMMO)
SP1033	Write ECU installation date	Anti-theft system (IMMO)
SP1034	Write vehicle configuration information	Anti-theft system (IMMO)
SP1035	Write remote control window configuration	Anti-theft system (IMMO)
SP1036	ECU reset	Anti-theft system (IMMO)
SP1037	Write VIN code	Instrumentation System (ICM)
SP1038	ECU reset	Instrumentation System (ICM)
SP1039	Write vehicle production date	Instrumentation System (ICM)
SP1040	Write ECU installation date	Instrumentation System (ICM)
SP1041	Write ECU programming date	Instrumentation System (ICM)
SP1042	Write ECU software number	Instrumentation System (ICM)
SP1043	Write ECU software version number	Instrumentation System (ICM)
SP1044	Write configuration information	Instrumentation System (ICM)
SP1045	Write body VIN number	Electronic Parking System (EPB)
SP1046	ECU reset	Electronic Parking System (EPB)
SP1047	ECU reset	360-degree panoramic system (AVM)
SP1048	Reset all adaptive values	Sunlight Tech (China Longhui)
SP1049	Atmospheric correction value fed back by air intake signal	Sunlight Tech (China Longhui)
SP1050	Half of the adaptive value of knock ignition angle	Sunlight Tech (China Longhui)
SP1051	Throttle position adaptive value adjustment	Sunlight Tech (China Longhui)
SP1052	Addition/multiplication adaptive factor for injection time of each group of cylinders (oxygen sensor)	Sunlight Tech (China Longhui)
SP1053	Idle speed adaptive value	Sunlight Tech (China Longhui)
SP1054	Segment adaptive value of engine rough value	Sunlight Tech (China Longhui)
SP1055	The adaptive value of the engine rough value heated by the catalytic package	Sunlight Tech (China Longhui)
SP1056	Carbon canister adaptive	Sunlight Tech (China Longhui)
SP1057	Tooth information learning	Delphi MT20U2
SP1058	Idle catalytic converter diagnosis	Delphi MT20U2
SP1059	Oxygen sensor feedback rationality diagnosis	Delphi MT20U2
SP1060	Tooth information learning	Delphi MT20U2/CNG
SP1061	Idle catalytic converter diagnosis	Delphi MT20U2/CNG

SP1062	Oxygen sensor feedback rationality diagnosis	Delphi MT20U2/CNG
SP1063	ECU reset	Wanxiang Seiko WX20/V5
SP1064	BBS exhaust	Wanxiang Seiko WX20/V5
SP1065	Hydraulic filling indicator	Wanxiang Qianchao
SP1066	Write EOL mark	Wanxiang Qianchao
SP1067	Wheel speed sensor test	Wanxiang Qianchao
SP1068	Supported LID	Wanxiang Qianchao
SP1069	Brake exhaust	universal
SP1070	Write VIN code	Airbag System (SRS)/Universal Seiko Airbag System
SP1071	Last repair date	Airbag System (SRS)/Universal Seiko Airbag System
SP1072	Write VIN code	Jicheng JIK009 (Sunshine Tektronix)
SP1073	Write repair station ID	Jicheng JIK009 (Sunshine Tektronix)
SP1074	Write programming date	Jicheng JIK009 (Sunshine Tektronix)
SP1075	Write diagnosis date	Jicheng JIK009 (Sunshine Tektronix)
SP1076	Reset all adaptive values	Sunlight Tech (China Longhui)
SP1077	Atmospheric correction value fed back by air intake signal	Sunlight Tech (China Longhui)
SP1078	Half of the adaptive value of knock ignition angle	Sunlight Tech (China Longhui)
SP1079	Throttle position adaptive value adjustment	Sunlight Tech (China Longhui)
SP1080	Addition/multiplication adaptive factor for injection time of each group of cylinders (oxygen sensor)	Sunlight Tech (China Longhui)
SP1081	Idle speed adaptive value	Sunlight Tech (China Longhui)
SP1082	Segment adaptive value of engine rough value	Sunlight Tech (China Longhui)
SP1083	The adaptive value of the engine rough value heated by the catalytic package	Sunlight Tech (China Longhui)
SP1084	Carbon canister adaptive	Sunlight Tech (China Longhui)
SP1085	ECU reset	Wanxiang Seiko WX20/V5
SP1086	BBS exhaust	Wanxiang Seiko WX20/V5
SP1087	Brake exhaust	universal
SP1088	Write VIN code	Anti-theft system (IMMO)/Jicheng JIK009 (Sunshine Tektronix)
SP1089	Write repair station ID	Anti-theft system (IMMO)/Jicheng JIK009 (Sunshine Tektronix)
SP1090	Write programming date	Anti-theft system (IMMO)/Jicheng JIK009 (Sunshine Tektronix)
SP1091	Write diagnosis date	Anti-theft system (IMMO)/Jicheng JIK009 (Sunshine Tektronix)
SP1092	Reset all adaptive values	Engine Management System (ECM)/Sunlight Tech (China Longhui)
SP1093	Atmospheric correction value fed back by air intake signal	Engine Management System (ECM)/Sunlight Tech (China Longhui)
SP1094	Half of the adaptive value of knock ignition angle	Engine Management System (ECM)/Sunlight Tech (China Longhui)
SP1095	Throttle position adaptive value adjustment	Engine Management System (ECM)/Sunlight Tech (China Longhui)
SP1096	Addition/multiplication adaptive factor for injection time of each group of cylinders (oxygen sensor)	Engine Management System (ECM)/Sunlight Tech (China Longhui)
SP1097	Idle speed adaptive value	Engine Management System (ECM)/Sunlight Tech (China Longhui)
SP1098	Segment adaptive value of engine rough value	Engine Management System (ECM)/Sunlight Tech (China Longhui)
SP1099	The adaptive value of the engine rough value heated by the catalytic package	Engine Management System (ECM)/Sunlight Tech (China Longhui)
SP1100	Carbon canister adaptive	Engine Management System (ECM)/Sunlight Tech (China Longhui)
SP1101	Write VIN code	Anti-theft system (IMMO)/Jicheng JIK009 (Sunshine Tektronix)
SP1102	Write repair station ID	Anti-theft system (IMMO)/Jicheng JIK009 (Sunshine Tektronix)
SP1103	Write programming date	Anti-theft system (IMMO)/Jicheng JIK009 (Sunshine Tektronix)
SP1104	Write diagnosis date	Anti-theft system (IMMO)/Jicheng JIK009 (Sunshine Tektronix)
SP1105	ECU reset	Anti-lock brake system (ABS)/Universal Seiko WX20/V5
SP1106	BBS exhaust	Anti-lock brake system (ABS)/Universal Seiko WX20/V5
SP1107	Write ECU installation date	Battery Management System (BMS)
SP1108	Write VIN	Battery Management System (BMS)

SP1109	Write ECU production date	Battery Management System (BMS)
SP1110	ECU reset	Battery Management System (BMS)
SP1111	Write ECU installation date	Vehicle Control Unit (VCU)
SP1112	Write VIN	Vehicle Control Unit (VCU)
SP1113	ECU reset	Vehicle Control Unit (VCU)
SP1114	Write ECU installation date	Motor Controller (EMC)
SP1115	Write VIN	Motor Controller (EMC)
SP1116	Write application software fingerprint data identifier	Motor Controller (EMC)
SP1117	ECU reset	Motor Controller (EMC)
SP1118	Brake exhaust	Anti-lock brake system (ABS)
SP1119	Write VIN code	Airbag System (SRS)
SP1120	Write the date of manufacture of the car	Airbag System (SRS)
SP1121	Write ECU installation date	Instrumentation System (ICM)
SP1122	Write VIN	Instrumentation System (ICM)
SP1123	Write vehicle loading date	Instrumentation System (ICM)
SP1124	ECU reset	Instrumentation System (ICM)
SP1125	TFT backlight detection	Instrumentation System (ICM)
SP1126	Write ECU installation date	Battery Management System (BMS)
SP1127	Write VIN	Battery Management System (BMS)
SP1128	Write ECU production date	Battery Management System (BMS)
SP1129	ECU reset	Battery Management System (BMS)
SP1130	Write ECU installation date	Vehicle Control Unit (VCU)
SP1131	Write VIN	Vehicle Control Unit (VCU)
SP1132	ECU reset	Vehicle Control Unit (VCU)
SP1133	Write ECU installation date	Motor Controller (EMC)
SP1134	Write VIN	Motor Controller (EMC)
SP1135	Write application software fingerprint data identifier	Motor Controller (EMC)
SP1136	ECU reset	Motor Controller (EMC)
SP1137	Write ECU installation date	Electric compressor assembly (ECA)
SP1138	Write VIN	Electric compressor assembly (ECA)
SP1139	ECU reset	Electric compressor assembly (ECA)
SP1140	Write VIN code	Anti-lock brake system (ABS)
SP1141	Write the spare part number of the vehicle manufacturer	Anti-lock brake system (ABS)
SP1142	Write the status of the hydraulic valve group	Anti-lock brake system (ABS)
SP1143	Write offline EOL status	Anti-lock brake system (ABS)
SP1144	Write variable code (electronic stability system only)	Anti-lock brake system (ABS)
SP1145	ECU reset	Anti-lock brake system (ABS)
SP1146	Exhaust and liquid	Anti-lock brake system (ABS)
SP1147	Artificial exhaust	Anti-lock brake system (ABS)
SP1148	Wheel speed sensor test	Anti-lock brake system (ABS)
SP1149	Speed limit disable/enable	Anti-lock brake system (ABS)
SP1150	Deactivate valve relay closed	Anti-lock brake system (ABS)
SP1151	External slope sensor correction (optional body electronic stability system)	Anti-lock brake system (ABS)
SP1152	Pump motor relay	Anti-lock brake system (ABS)
SP1153	Intake valve, front left	Anti-lock brake system (ABS)
SP1154	Outlet valve, front left	Anti-lock brake system (ABS)
SP1155	Intake valve, front right	Anti-lock brake system (ABS)
SP1156	Outlet valve, front right	Anti-lock brake system (ABS)
SP1157	Intake valve, rear right	Anti-lock brake system (ABS)
SP1158	Outlet valve, rear right	Anti-lock brake system (ABS)
SP1159	Intake valve, rear left	Anti-lock brake system (ABS)
SP1160	Outlet valve, rear left	Anti-lock brake system (ABS)
SP1161	Switching valve 1 (USV1) (only electronic stability system)	Anti-lock brake system (ABS)
SP1162	Switching valve 2 (USV2) (only electronic stability system)	Anti-lock brake system (ABS)
SP1163	High pressure solenoid valve 1 (HSV1) (only electronic stability system)	Anti-lock brake system (ABS)
SP1164	High pressure solenoid valve 2 (HSV2) (only electronic stability system)	Anti-lock brake system (ABS)
SP1165	Anti-lock brake system (ABS) safety light	Anti-lock brake system (ABS)
SP1166	Body electronic stability system safety (only body electronic stability system)	Anti-lock brake system (ABS)
SP1167	Electronic Brake Force Distribution (EBD) Safety Light	Anti-lock brake system (ABS)
SP1168	Write VIN code	Airbag System (SRS)
SP1169	Write the date of manufacture of the car	Airbag System (SRS)
SP1170	Write VIN code	Body Control System (BCM)
SP1171	Write remote window rise	Body Control System (BCM)
SP1172	Turn signal lights up	Body Control System (BCM)
SP1173	Position light is on	Body Control System (BCM)

SP1174	Low beam lights up	Body Control System (BCM)
SP1175	Daytime running lights are on	Body Control System (BCM)
SP1176	The key light is on	Body Control System (BCM)
SP1177	Top light is on	Body Control System (BCM)
SP1178	Battery voltage	Body Control System (BCM)
SP1179	Write configuration information	Body Control System (BCM)
SP1180	ECU reset	Body Control System (BCM)
SP1181	Write VIN code	Electric Power Steering System (EPS)
SP1182	Write system name	Electric Power Steering System (EPS)
SP1183	Write part number	Electric Power Steering System (EPS)
SP1184	Write ECU software number	Electric Power Steering System (EPS)
SP1185	Write ECU hardware number	Electric Power Steering System (EPS)
SP1186	Write ECU installation date	Electric Power Steering System (EPS)
SP1187	Write ECU software version number	Electric Power Steering System (EPS)
SP1188	Write VIN code	Keyless Entry System (PEPS)
SP1189	Write ECU installation date	Air Conditioning Panel (ATC)
SP1190	Write VIN	Air Conditioning Panel (ATC)
SP1191	Write vehicle name	Air Conditioning Panel (ATC)
SP1192	ECU reset	Air Conditioning Panel (ATC)
SP1193	Write VIN code	Battery Management System (BMS)
SP1194	ECU reset	Battery Management System (BMS)
SP1195	Write VIN code	Vehicle Control Unit (VCU)
SP1196	ECU reset	Vehicle Control Unit (VCU)
SP1197	Write VIN code	Power Control Unit (PCU)
SP1198	ECU reset	Power Control Unit (PCU)
SP1199	Write ECU serial number	Power Control Unit (PCU)
SP1200	Write VIN code	Anti-lock brake system (ABS)
SP1201	Write the spare part number of the vehicle manufacturer	Anti-lock brake system (ABS)
SP1202	Write the status of the hydraulic valve group	Anti-lock brake system (ABS)
SP1203	Write offline EOL status	Anti-lock brake system (ABS)
SP1204	Write variable code (electronic stability system only)	Anti-lock brake system (ABS)
SP1205	ECU reset	Anti-lock brake system (ABS)
SP1206	Exhaust and liquid	Anti-lock brake system (ABS)
SP1207	Artificial exhaust	Anti-lock brake system (ABS)
SP1208	Wheel speed sensor test	Anti-lock brake system (ABS)
SP1209	Speed limit disable/enable	Anti-lock brake system (ABS)
SP1210	Deactivate valve relay closed	Anti-lock brake system (ABS)
SP1211	External slope sensor correction (optional body electronic stability system)	Anti-lock brake system (ABS)
SP1212	Pump motor relay	Anti-lock brake system (ABS)
SP1213	Intake valve, front left	Anti-lock brake system (ABS)
SP1214	Outlet valve, front left	Anti-lock brake system (ABS)
SP1215	Intake valve, front right	Anti-lock brake system (ABS)
SP1216	Outlet valve, front right	Anti-lock brake system (ABS)
SP1217	Intake valve, rear right	Anti-lock brake system (ABS)
SP1218	Outlet valve, rear right	Anti-lock brake system (ABS)
SP1219	Intake valve, rear left	Anti-lock brake system (ABS)
SP1220	Outlet valve, rear left	Anti-lock brake system (ABS)
SP1221	Switching valve 1 (USV1) (only electronic stability system)	Anti-lock brake system (ABS)
SP1222	Switching valve 2 (USV2) (only electronic stability system)	Anti-lock brake system (ABS)
SP1223	High pressure solenoid valve 1 (HSV1) (only electronic stability system)	Anti-lock brake system (ABS)
SP1224	High pressure solenoid valve 2 (HSV2) (only electronic stability system)	Anti-lock brake system (ABS)
SP1225	Anti-lock brake system (ABS) safety light	Anti-lock brake system (ABS)
SP1226	Body electronic stability system safety (only body electronic stability system)	Anti-lock brake system (ABS)
SP1227	Electronic Brake Force Distribution (EBD) Safety Light	Anti-lock brake system (ABS)
SP1228	Write VIN code	Body Control System (BCM)
SP1229	Write remote window rise	Body Control System (BCM)
SP1230	ECU reset	Body Control System (BCM)
SP1231	Turn signal lights up	Body Control System (BCM)
SP1232	Position light is on	Body Control System (BCM)
SP1233	Low beam lights up	Body Control System (BCM)
SP1234	Daytime running lights are on	Body Control System (BCM)
SP1235	The key light is on	Body Control System (BCM)
SP1236	Top light is on	Body Control System (BCM)
SP1237	Battery voltage	Body Control System (BCM)
SP1238	Write VIN code	Electric Power Steering System (EPS)

SP1239	Write system name	Electric Power Steering System (EPS)
SP1240	Write part number	Electric Power Steering System (EPS)
SP1241	Write ECU software number	Electric Power Steering System (EPS)
SP1242	Write ECU hardware number	Electric Power Steering System (EPS)
SP1243	Write ECU installation date	Electric Power Steering System (EPS)
SP1244	Write ECU software version number	Electric Power Steering System (EPS)
SP1245	Steering wheel angle median learning	Electric Power Steering System (EPS)
SP1246	Write VIN code	Keyless Start System (PEPS)
SP1247	Write VIN code	Air Conditioning Panel (ATC)
SP1248	ECU reset	Air Conditioning Panel (ATC)
SP1249	Write ECU installation date	Air Conditioning Panel (ATC)
SP1250	Write vehicle name	Air Conditioning Panel (ATC)
SP1251	Write VIN code	Airbag System (SRS)
SP1252	ECU reset	Airbag System (SRS)
SP1253	Write vehicle production date	Airbag System (SRS)
SP1254	Write VIN code	HIRAIN FBCM 820 Front Body Control System
SP1255	ECU reset	HIRAIN FBCM 820 Front Body Control System
SP1256	Write anti-pinch function	HIRAIN FBCM 820 Front Body Control System
SP1257	Write VIN code	HIRAIN RBCM 820 rear body control system
SP1258	ECU reset	HIRAIN RBCM 820 rear body control system
SP1259	Write VIN code	Electric Power Steering System (EPS)
SP1260	Write ECU installation date	Electric Power Steering System (EPS)
SP1261	Write the spare part number of the vehicle manufacturer	Electric Power Steering System (EPS)
SP1262	Write the software number of the vehicle manufacturer	Electric Power Steering System (EPS)
SP1263	Write the ECU software version number of the OEM	Electric Power Steering System (EPS)
SP1264	Write the ECU hardware version number of the vehicle manufacturer	Electric Power Steering System (EPS)
SP1265	Write system name	Electric Power Steering System (EPS)
SP1266	Write VIN code	Keyless Start System (PEPS)
SP1267	Write parameter configuration information	Keyless Start System (PEPS)
SP1268	Write VIN code	Battery Management System (BMS)
SP1269	ECU reset	Battery Management System (BMS)
SP1270	Write VIN code	Vehicle Control Unit (VCU)
SP1271	ECU reset	Vehicle Control Unit (VCU)
SP1272	Write VIN code	Power Control Unit (PCU)
SP1273	ECU reset	Power Control Unit (PCU)
SP1274	Write ECU serial number	Power Control Unit (PCU)
SP1275	Write VIN code	Anti-lock brake system (ABS)
SP1276	Write the spare part number of the vehicle manufacturer	Anti-lock brake system (ABS)
SP1277	Write the status of the hydraulic valve group	Anti-lock brake system (ABS)
SP1278	Write offline EOL status	Anti-lock brake system (ABS)
SP1279	Write variable code (electronic stability system only)	Anti-lock brake system (ABS)
SP1280	ECU reset	Anti-lock brake system (ABS)
SP1281	Exhaust and liquid	Anti-lock brake system (ABS)
SP1282	Artificial exhaust	Anti-lock brake system (ABS)
SP1283	Wheel speed sensor test	Anti-lock brake system (ABS)
SP1284	Speed limit disable/enable	Anti-lock brake system (ABS)
SP1285	Deactivate valve relay closed	Anti-lock brake system (ABS)
SP1286	External slope sensor correction (optional body electronic stability system)	Anti-lock brake system (ABS)
SP1287	Pump motor relay	Anti-lock brake system (ABS)
SP1288	Intake valve, front left	Anti-lock brake system (ABS)
SP1289	Outlet valve, front left	Anti-lock brake system (ABS)
SP1290	Intake valve, front right	Anti-lock brake system (ABS)
SP1291	Outlet valve, front right	Anti-lock brake system (ABS)
SP1292	Intake valve, rear right	Anti-lock brake system (ABS)
SP1293	Outlet valve, rear right	Anti-lock brake system (ABS)
SP1294	Intake valve, rear left	Anti-lock brake system (ABS)
SP1295	Outlet valve, rear left	Anti-lock brake system (ABS)
SP1296	Switching valve 1 (USV1) (only electronic stability system)	Anti-lock brake system (ABS)
SP1297	Switching valve 2 (USV2) (only electronic stability system)	Anti-lock brake system (ABS)
SP1298	High pressure solenoid valve 1 (HSV1) (only electronic stability system)	Anti-lock brake system (ABS)
SP1299	High pressure solenoid valve 2 (HSV2) (only electronic stability system)	Anti-lock brake system (ABS)
SP1300	Anti-lock brake system (ABS) safety light	Anti-lock brake system (ABS)
SP1301	Body electronic stability system safety (only body electronic stability system)	Anti-lock brake system (ABS)
SP1302	Electronic Brake Force Distribution (EBD) Safety Light	Anti-lock brake system (ABS)

SP1303	Write VIN code	Airbag System (SRS)
SP1304	Write the date of manufacture of the car	Airbag System (SRS)
SP1305	Write VIN code	Body Control System (BCM)
SP1306	Write remote window rise	Body Control System (BCM)
SP1307	ECU reset	Body Control System (BCM)
SP1308	Turn signal lights up	Body Control System (BCM)
SP1309	Position light is on	Body Control System (BCM)
SP1310	Low beam lights up	Body Control System (BCM)
SP1311	Daytime running lights are on	Body Control System (BCM)
SP1312	The key light is on	Body Control System (BCM)
SP1313	Top light is on	Body Control System (BCM)
SP1314	Battery voltage	Body Control System (BCM)
SP1315	Write VIN code	Electric Power Steering System (EPS)
SP1316	Write system name	Electric Power Steering System (EPS)
SP1317	Write part number	Electric Power Steering System (EPS)
SP1318	Write ECU software number	Electric Power Steering System (EPS)
SP1319	Write ECU hardware number	Electric Power Steering System (EPS)
SP1320	Write ECU installation date	Electric Power Steering System (EPS)
SP1321	Write ECU software version number	Electric Power Steering System (EPS)
SP1322	Steering wheel angle median learning	Electric Power Steering System (EPS)
SP1323	Write VIN code	Air Conditioning Panel (ATC)
SP1324	ECU reset	Air Conditioning Panel (ATC)
SP1325	Write ECU installation date	Air Conditioning Panel (ATC)
SP1326	Write vehicle name	Air Conditioning Panel (ATC)
SP1327	Write VIN code	Battery Management System (BMS)
SP1328	ECU reset	Battery Management System (BMS)
SP1329	Write VIN code	Vehicle Control Unit (VCU)
SP1330	ECU reset	Vehicle Control Unit (VCU)
SP1331	Write VIN code	Power Control Unit (PCU)
SP1332	ECU reset	Power Control Unit (PCU)
SP1333	Write ECU serial number	Power Control Unit (PCU)
SP1334	Write VIN code	Anti-lock brake system (ABS)
SP1335	Write the spare part number of the vehicle manufacturer	Anti-lock brake system (ABS)
SP1336	Write the status of the hydraulic valve group	Anti-lock brake system (ABS)
SP1337	Write offline EOL status	Anti-lock brake system (ABS)
SP1338	Write variable code (electronic stability system only)	Anti-lock brake system (ABS)
SP1339	ECU reset	Anti-lock brake system (ABS)
SP1340	Exhaust and liquid	Anti-lock brake system (ABS)
SP1341	Artificial exhaust	Anti-lock brake system (ABS)
SP1342	Wheel speed sensor test	Anti-lock brake system (ABS)
SP1343	Speed limit disable/enable	Anti-lock brake system (ABS)
SP1344	Deactivate valve relay closed	Anti-lock brake system (ABS)
SP1345	External slope sensor correction (optional body electronic stability system)	Anti-lock brake system (ABS)
SP1346	Pump motor relay	Anti-lock brake system (ABS)
SP1347	Intake valve, front left	Anti-lock brake system (ABS)
SP1348	Outlet valve, front left	Anti-lock brake system (ABS)
SP1349	Intake valve, front right	Anti-lock brake system (ABS)
SP1350	Outlet valve, front right	Anti-lock brake system (ABS)
SP1351	Intake valve, rear right	Anti-lock brake system (ABS)
SP1352	Outlet valve, rear right	Anti-lock brake system (ABS)
SP1353	Intake valve, rear left	Anti-lock brake system (ABS)
SP1354	Outlet valve, rear left	Anti-lock brake system (ABS)
SP1355	Switching valve 1 (USV1) (only electronic stability system)	Anti-lock brake system (ABS)
SP1356	Switching valve 2 (USV2) (only electronic stability system)	Anti-lock brake system (ABS)
SP1357	High pressure solenoid valve 1 (HSV1) (only electronic stability system)	Anti-lock brake system (ABS)
SP1358	High pressure solenoid valve 2 (HSV2) (only electronic stability system)	Anti-lock brake system (ABS)
SP1359	Anti-lock brake system (ABS) safety light	Anti-lock brake system (ABS)
SP1360	Body electronic stability system safety (only body electronic stability system)	Anti-lock brake system (ABS)
SP1361	Electronic Brake Force Distribution (EBD) Safety Light	Anti-lock brake system (ABS)
SP1362	Write VIN code	Airbag System (SRS)
SP1363	Write the date of manufacture of the car	Airbag System (SRS)
SP1364	Write VIN code	Body Control System (BCM)
SP1365	Write remote window rise	Body Control System (BCM)
SP1366	ECU reset	Body Control System (BCM)
SP1367	Turn signal lights up	Body Control System (BCM)

SP1368	Position light is on	Body Control System (BCM)
SP1369	Low beam lights up	Body Control System (BCM)
SP1370	Daytime running lights are on	Body Control System (BCM)
SP1371	The key light is on	Body Control System (BCM)
SP1372	Top light is on	Body Control System (BCM)
SP1373	Battery voltage	Body Control System (BCM)
SP1374	Write VIN code	Electric Power Steering System (EPS)
SP1375	Write system name	Electric Power Steering System (EPS)
SP1376	Write part number	Electric Power Steering System (EPS)
SP1377	Write ECU software number	Electric Power Steering System (EPS)
SP1378	Write ECU hardware number	Electric Power Steering System (EPS)
SP1379	Write ECU installation date	Electric Power Steering System (EPS)
SP1380	Write ECU software version number	Electric Power Steering System (EPS)
SP1381	Steering wheel angle median learning	Electric Power Steering System (EPS)
SP1382	Write VIN code	Keyless Start System (PEPS)

