



## ROEWE Function List V10.50

### Tips and Instructions:

The programming function only supports H6PRO, H6PRO Master Edition products.

\* This feature is new.

✓ This feature is supported.

This feature is not supported.

※ This feature is partially supported.

Model	System Name	Read ECU Information	Read Trouble Code	Clear Trouble Code	Live Data	Read Freeze Frame	Actuation Test	Special Functions
ROEWE/15NEW	Engine control module (ECM)	✓	✓	✓	✓		✓	SP2221, SP2222
ROEWE/15NEW	Gearbox control module (TCM)	✓	✓	✓	✓			
ROEWE/15NEW	Anti-lock brake system / Dynamic stability control (SCS/ABS)	✓	✓	✓	✓			SP2227, SP2228, SP2229, SP2230, SP2231, SP2232, SP2233, SP2234, SP2235, SP2236
ROEWE/15NEW	Airbag control module (SDM)	✓	✓	✓	✓			
ROEWE/15NEW	Body control module (BCM)	✓	✓	✓	✓		✓	SP2219, SP2220
ROEWE/15NEW	Electronic power steering system (EPS)	✓	✓	✓	✓			SP2223
ROEWE/15NEW	Combination instrument (IPK)	✓	✓	✓	✓		✓	
ROEWE/15NEW	Air conditioning module (HVAC)	✓	✓	✓	✓		✓	SP2226
ROEWE/15NEW	Tire pressure monitoring system (TPMS)	✓	✓	✓	✓			
ROEWE/15NEW	Gateway module (GW)	✓	✓	✓	✓			SP2225
ROEWE/15NEW	Communication module (T-BOX)	✓	✓	✓	✓			
ROEWE/15NEW	Shock control module (SCU)	✓	✓	✓	✓		✓	
ROEWE/15NEW	Clutch cooling electronic oil pump (CCEOP)	✓	✓	✓	✓			
ROEWE/15NEW	Navigation entertainment system (FICM)	✓	✓	✓	✓			
ROEWE/15NEW	Front camera module (FVCM)	✓	✓	✓	✓			SP2224
ROEWE/15NEW	360 Panoramic image control module (AVM)	✓	✓	✓	✓			
ROEWE/ New 15 Without ADAS	Engine control module (ECM)	✓	✓	✓	✓		✓	SP2239, SP2240
ROEWE/ New 15 Without ADAS	Gearbox control module (TCM)	✓	✓	✓	✓			
ROEWE/ New 15 Without ADAS	Anti-lock brake system / Dynamic stability control (SCS/ABS)	✓	✓	✓	✓			SP2243, SP2244, SP2245, SP2246, SP2247, SP2248, SP2249, SP2250, SP2251, SP2252
ROEWE/ New 15 Without ADAS	Airbag control module (SDM)	✓	✓	✓	✓			
ROEWE/ New 15 Without ADAS	Body control module (BCM)	✓	✓	✓	✓		✓	SP2237, SP2238
ROEWE/ New 15 Without ADAS	Electronic power steering system (EPS)	✓	✓	✓	✓			SP2241
ROEWE/ New 15 Without ADAS	Combination instrument (IPK)	✓	✓	✓	✓		✓	
ROEWE/ New 15 Without ADAS	Air conditioning module (HVAC)	✓	✓	✓	✓		✓	SP2242
ROEWE/ New 15 Without ADAS	Tire pressure monitoring system (TPMS)	✓	✓	✓	✓			
ROEWE/ New 15 Without ADAS	Electronic steering pierlet lock (ESCL)	✓	✓	✓	✓			
ROEWE/ New 15 Without ADAS	Navigation entertainment system (FICM)	✓	✓	✓	✓			
ROEWE/ New RX3	Engine control module (ECM)	✓	✓	✓	✓		✓	SP2207, SP2208
ROEWE/ New RX3	Gearbox control module (TCM)	✓	✓	✓	✓			
ROEWE/ New RX3	Anti-lock brake system / Dynamic stability control (SCS/EPB)	✓	✓	✓	✓			SP2209, SP2210, SP2211, SP2212, SP2213, SP2214, SP2215, SP2216, SP2217
ROEWE/ New RX3	Airbag control module (SDM)	✓	✓	✓	✓			
ROEWE/ New RX3	Body control module (BCM)	✓	✓	✓	✓		✓	SP2204, SP2205, SP2206
ROEWE/ New RX3	Electronic steering power system (EPS)	✓	✓	✓	✓		✓	SP2218
ROEWE/ New RX3	Instrument module (IPK)	✓	✓	✓	✓		✓	
ROEWE/ New RX3	Air conditioning module (HVAC)	✓	✓	✓	✓		✓	
ROEWE/ New RX3	Tire pressure monitoring system (TPMS)	✓	✓	✓	✓			
ROEWE/ New RX3	Electronic steering pierlet lock (ESCL)	✓	✓	✓	✓			
ROEWE/ New RX3	Navigation entertainment system (FICM)	✓	✓	✓	✓			
ROEWE/ New RX3	360 Panoramic image control module (AVM)	✓	✓	✓	✓			
ROEWE/ New RX3 Bring ADAS	Engine control module (ECM)	✓	✓	✓	✓		✓	
ROEWE/ New RX3 Bring ADAS	Gearbox control module (TCM)	✓	✓	✓	✓			
ROEWE/ New RX3 Bring ADAS	Anti-lock brake system / Dynamic stability control (SCS)	✓	✓	✓	✓			
ROEWE/ New RX3 Bring ADAS	Airbag control module (SDM)	✓	✓	✓	✓			
ROEWE/ New RX3 Bring ADAS	Body control module (BCM)	✓	✓	✓	✓		✓	
ROEWE/ New RX3 Bring ADAS	Electronic steering power system (EPS)	✓	✓	✓	✓		✓	
ROEWE/ New RX3 Bring ADAS	Instrument module (IPK)	✓	✓	✓	✓		✓	
ROEWE/ New RX3 Bring ADAS	Air conditioning module (HVAC)	✓	✓	✓	✓		✓	
ROEWE/ New RX3 Bring ADAS	Tire pressure monitoring system (TPMS)	✓	✓	✓	✓			

ROEWE/ New RX3 Bring ADAS	Gateway module (GW)	✓	✓	✓	✓			
ROEWE/ New RX3 Bring ADAS	Communication module (T-BOX)	✓	✓	✓	✓			
ROEWE/ New RX3 Bring ADAS	Front camera module (FVCM)	✓	✓	✓	✓			
ROEWE/ New RX3 Bring ADAS	Forward detection radar module (FDR)	✓	✓	✓	✓			
ROEWE/ New RX3 Bring ADAS	Navigation entertainment system (FICM)	✓	✓	✓	✓			
ROEWE/ New RX3 Bring ADAS	360 Panoramic image control module (AVM)	✓	✓	✓	✓			
ROEWE/IMAX8	Engine management system (ECM)	✓	✓	✓	✓	✓		SP1457, SP1458, SP1459, SP1460, SP1461, SP1462, SP1463, SP1464
ROEWE/IMAX8	Gearbox control module (TCM)	✓	✓	✓	✓	✓		SP1465
ROEWE/IMAX8	Anti-lock brake system / Dynamic stability control (SCS)	✓	✓	✓	✓			SP1468, SP1469, SP1470, SP1471, SP1472, SP1473, SP1474, SP1475, SP1476, SP1477
ROEWE/IMAX8	Airbag control module (SDM)	✓	✓	✓	✓			
ROEWE/IMAX8	Body control module (BCM)	✓	✓	✓	✓	✓		SP1482
ROEWE/IMAX8	Electronic steering power system (EPS)	✓	✓	✓	✓	✓		
ROEWE/IMAX8	Combination instrument (IPK)	✓	✓	✓	✓			
ROEWE/IMAX8	Air conditioning control module (HVAC)	✓	✓	✓	✓	✓		SP1480
ROEWE/IMAX8	Keyless entry and key launch module (PEPS)	✓	✓	✓	✓			SP1481
ROEWE/IMAX8	Tire pressure monitoring system (TPMS)	✓	✓	✓	✓			SP1483
ROEWE/IMAX8	Gateway module (GW)	✓	✓	✓	✓			SP1454, SP1455
ROEWE/IMAX8	Corner sensor (SAS)	✓	✓	✓	✓			SP1478
ROEWE/IMAX8	Communication module (T-BOX)	✓	✓	✓	✓			SP1452, SP1453
ROEWE/IMAX8	Radar module (FDR)	✓	✓	✓	✓			SP1456
ROEWE/IMAX8	Seck detection module (SCU)	✓	✓	✓	✓	✓		
ROEWE/IMAX8	Action execution module (ACU)	✓	✓	✓	✓			SP1466, SP1467
ROEWE/IMAX8	Automatic parking assistance system (APA)	✓	✓	✓	✓			
ROEWE/IMAX8	Front camera module (FVCM)	✓	✓	✓	✓			SP1479
ROEWE/IMAX8	Seat heating and ventilation module (HVSMR)	✓	✓	✓	✓	✓		
ROEWE/IMAX8	Electric tail door control module (PLCM)	✓	✓	✓	✓			
ROEWE/IMAX8	Navigation entertainment system (FICM)	✓	✓	✓	✓			
ROEWE/IMAX8	Natural light control module (ALCM)	✓	✓	✓	✓	✓		
ROEWE/IMAX8	Mobile Rubik (SCCU)	✓	✓	✓	✓			
ROEWE/IMAX8	Rear driving assistance module (RDA)	✓	✓	✓	✓			
ROEWE/i6 MAX	Engine control module (ECM)	✓	✓	✓	✓	✓		SP1614, SP1615
ROEWE/i6 MAX	Gearbox control module (TCM)	✓	✓	✓	✓			
ROEWE/i6 MAX	Anti-lock brake system / Dynamic stability control (SCS)	✓	✓	✓	✓			SP1619, SP1620, SP1621, SP1622, SP1623, SP1624, SP1625, SP1626, SP1627, SP1628
ROEWE/i6 MAX	Airbag control module (SDM)	✓	✓	✓	✓			
ROEWE/i6 MAX	Body control module (BCM)	✓	✓	✓	✓	✓		SP1631
ROEWE/i6 MAX	Electronic steering power system (EPS)	✓	✓	✓	✓			SP1629
ROEWE/i6 MAX	Instrument module (IPK)	✓	✓	✓	✓	✓		SP1634
ROEWE/i6 MAX	Keyless entry and start system (PEPS)	✓	✓	✓	✓			SP1632
ROEWE/i6 MAX	Air conditioning module (HVAC)	✓	✓	✓	✓	✓		SP1633
ROEWE/i6 MAX	Tire pressure monitoring system (TPMS)	✓	✓	✓	✓			SP1635
ROEWE/i6 MAX	Gateway (GW)	✓	✓	✓	✓			SP1613
ROEWE/i6 MAX	Navigation entertainment system (FICM)	✓	✓	✓	✓			
ROEWE/i6 MAX	Switching control unit (SCU)	✓	✓	✓	✓	✓		
ROEWE/i6 MAX	Clutch cooling electronic oil pump (CCPOP)	✓	✓	✓	✓			
ROEWE/i6 MAX	Front camera module (FVCM/FDR)	✓	✓	✓	✓			
ROEWE/i6 MAX	Communication module (T-BOX)	✓	✓	✓	✓			SP1611, SP1612
ROEWE/i6 MAX	360 Panoramic image control module (AVM)	✓	✓	✓	✓			SP1636
ROEWE/i6 MAX	Rear driving assistance module (RDA)	✓	✓	✓	✓			
ROEWE/RX5 MAX	Engine control module (ECM)	✓	✓	✓	✓	✓		SP1241, SP1242, SP1243, SP1254, SP1255, SP1256, SP1257
ROEWE/RX5 MAX	Gearbox control module (TCM)	✓	✓	✓	✓			
ROEWE/RX5 MAX	Anti-lock brake system / Dynamic stability control (ABS/SCS)	✓	✓	✓	✓			SP1262, SP1263, SP1264, SP1265, SP1266, SP1267, SP1268, SP1269, SP1270
ROEWE/RX5 MAX	Airbag control module (SRS)	✓	✓	✓	✓			
ROEWE/RX5 MAX	Body control module (BCM)	✓	✓	✓	✓	✓		SP1275
ROEWE/RX5 MAX	Electronic power steering system (EPS)	✓	✓	✓	✓			SP1271
ROEWE/RX5 MAX	Instrument module (IPK)	✓	✓	✓	✓	✓		SP1278
ROEWE/RX5 MAX	Air conditioner controller (HVAC)	✓	✓	✓	✓	✓		SP1277
ROEWE/RX5 MAX	Keyless entry and start system (PEPS)	✓	✓	✓	✓			SP1276
ROEWE/RX5 MAX	Gateway module (GW)	✓	✓	✓	✓			SP1239, SP1240
ROEWE/RX5 MAX	Tire pressure monitoring system (TPMS)	✓	✓	✓	✓			SP1279
ROEWE/RX5 MAX	Four-wheel control module (TCCM)	✓	✓	✓	✓			SP1259
ROEWE/RX5 MAX	Seck detection module (SCU)	✓	✓	✓	✓	✓		SP1260, SP1261
ROEWE/RX5 MAX	Front camera module (FVCM)	✓	✓	✓	✓			SP1274
ROEWE/RX5 MAX	Navigation entertainment system (FICM)	✓	✓	✓	✓			
ROEWE/RX5 MAX	Communication module (T-BOX)	✓	✓	✓	✓			SP1237, SP1238
ROEWE/RX5 MAX	Electronic steering column lock (ESCL)	✓	✓	✓	✓			
ROEWE/RX5 MAX	Automatic parking system (APA)	✓	✓	✓	✓			
ROEWE/RX5 MAX	Electric tail door control module (PLCM)	✓	✓	✓	✓			
ROEWE/RX5 MAX	Natural light control module (ALCM)	✓	✓	✓	✓			
ROEWE/RX5 MAX	Forward detection radar module (FDR)	✓	✓	✓	✓			SP1272, SP1273
ROEWE/RX5 MAX	Rear driving assistance module (RDA)	✓	✓	✓	✓			
ROEWE/RX5 MAX	Seat memory module (MSM)	✓	✓	✓	✓	✓		
ROEWE/RX5 MAX	360 Panoramic image control module (AVM)	✓	✓	✓	✓			SP1280
ROEWE/i5	Engine management system (EMS)	✓	✓	✓	✓	✓		SP0754, SP0755
ROEWE/i5	Gearbox control module (TCM)	✓	✓	✓	✓			

ROEWE/i5	Anti-lock brake system / Dynamic stability control (ABS/SCS)	√	√	√	√			SP0763, SP0764, SP0765, SP0766, SP0767, SP0768, SP0769, SP0770, SP0771, SP0772
ROEWE/i5	Airbag control module (SRS)	√	√	√	√			
ROEWE/i5	Body control module (BCM)	√	√	√	√		√	SP0749, SP0750, SP0751, SP0752
ROEWE/i5	Electronic power steering system (EPS)	√	√	√	√			SP0776
ROEWE/i5	Instrument module (IPK)	√	√	√	√		√	SP0753
ROEWE/i5	Air conditioner controller (HVAC)	√	√	√	√		√	SP0777
ROEWE/i5	Tire pressure monitoring system (TPMS)	√	√	√	√			SP0773
ROEWE/i5	Communication module (T-BOX)	√	√	√	√			SP0746, SP0747
ROEWE/i5	Electronic steering column lock (ESCL)	√	√	√	√			
ROEWE/i5	Front camera module (FVCM)	√	√	√	√			SP0762
ROEWE/i5	Navigation entertainment system (FICM)	√	√	√	√			
ROEWE/i5	360 Panoramic image control module (AVM)	√	√	√	√			
ROEWE/i5	Security Bluetooth module (SBTM)	√	√	√	√			SP0748
ROEWE/i5 2020 Pay 1.5L	Engine management system (ECM)	√	√	√	√		√	
ROEWE/i5 2020 Pay 1.5L	Gearbox control module (TCM)	√	√	√	√			
ROEWE/i5 2020 Pay 1.5L	Anti-lock brake system / Dynamic stability control (SCS/ABS)	√	√	√	√			
ROEWE/i5 2020 Pay 1.5L	Airbag control module (SDM)	√	√	√	√			
ROEWE/i5 2020 Pay 1.5L	Body control module (BCM)	√	√	√	√		√	SP0778, SP0779
ROEWE/i5 2020 Pay 1.5L	Electronic steering power system (EPS)	√	√	√	√			SP0787
ROEWE/i5 2020 Pay 1.5L	Air conditioning control module (HVAC)	√	√	√	√		√	SP0788
ROEWE/i5 2020 Pay 1.5L	Combination instrument (IPK)	√	√	√	√		√	SP0780
ROEWE/i5 2020 Pay 1.5L	Communication module (T-BOX)	√	√	√	√			
ROEWE/i5 2020 Pay 1.5L	Front camera module (FVCM)	√	√	√	√			SP0785
ROEWE/i5 2020 Pay 1.5L	360 Panoramic image control module (AVM)	√	√	√	√			
ROEWE/i5 2020 Pay 1.5L	Navigation entertainment system (FICM)	√	√	√	√			
ROEWE/i5 2020 Pay 1.5L	Electronic steering pierlet lock (ESCL)	√	√	√	√			
ROEWE/i5 2020 Pay 1.5T	Engine management system (ECM)	√	√	√	√		√	
ROEWE/i5 2020 Pay 1.5T	Gearbox control module (TCM)	√	√	√	√			
ROEWE/i5 2020 Pay 1.5T	Anti-lock brake system / Dynamic stability control (SCS/ABS)	√	√	√	√		√	
ROEWE/i5 2020 Pay 1.5T	Airbag control module (SDM)	√	√	√	√			
ROEWE/i5 2020 Pay 1.5T	Seck detection module (SCU)	√	√	√	√		√	
ROEWE/i5 2020 Pay 1.5T	Body control module (BCM)	√	√	√	√		√	SP0800, SP0801
ROEWE/i5 2020 Pay 1.5T	Electronic steering power system (EPS)	√	√	√	√		√	SP0796
ROEWE/i5 2020 Pay 1.5T	Combination instrument (IPK)	√	√	√	√		√	SP0802
ROEWE/i5 2020 Pay 1.5T	Air conditioning control module (HVAC)	√	√	√	√		√	SP0799
ROEWE/i5 2020 Pay 1.5T	Gateway module (GW)	√	√	√	√			SP0789, SP0790
ROEWE/i5 2020 Pay 1.5T	Navigation entertainment system (FICM)	√	√	√	√			
ROEWE/i5 2020 Pay 1.5T	Front camera module (FVCM)	√	√	√	√			SP0798
ROEWE/i5 2020 Pay 1.5T	360 Panoramic image control module (AVM)	√	√	√	√			
ROEWE/i5 2020 Pay 1.5T	Communication module (T-BOX)	√	√	√	√			
ROEWE/i5 2020 Pay 1.5T	Clutch cooling electronic oil pump (CCEOP)	√	√	√	√			
ROEWE/RX8	Engine management system (EMS)	√	√	√	√		√	SP1821, SP1822, SP1823, SP1824
ROEWE/RX8	Gearbox control module (TCM)	√	√	√	√			SP1835
ROEWE/RX8	Anti-lock brake system / Dynamic stability control (ABS/SCS)	√	√	√	√			SP1844, SP1845, SP1846, SP1847
ROEWE/RX8	Airbag control module (SRS)	√	√	√	√			
ROEWE/RX8	Body control module (BCM)	√	√	√	√		√	SP1850
ROEWE/RX8	Instrument module (IPK)	√	√	√	√		√	SP1854
ROEWE/RX8	Air conditioner controller (HVAC)	√	√	√	√		√	SP1852
ROEWE/RX8	Keyless entry and start system (PEPS)	√	√	√	√			SP1853
ROEWE/RX8	Gateway module (GW)	√	√	√	√			SP1819, SP1820
ROEWE/RX8	Electronic park brake (EPB)	√	√	√	√		√	SP1837, SP1838, SP1839, SP1840, SP1841, SP1842, SP1843
ROEWE/RX8	Tire pressure monitoring system (TPMS)	√	√	√	√			SP1856
ROEWE/RX8	Steering sensor (SAS)	√	√	√	√			SP1848, SP1849
ROEWE/RX8	Navigation entertainment system (FICM)	√	√	√	√			
ROEWE/RX8	Front camera module (FVCM)	√	√	√	√			SP1836

ROEWE/RX8	Four-wheel control module (TCCM)	√	√	√	√			
ROEWE/RX8	Communication module (T-BOX)	√	√	√	√			SP1817, SP1818
ROEWE/RX8	Electric tail door control module (PLCM)	√	√	√	√	√		SP1851
ROEWE/RX8	Seat memory module (MSM)	√	√	√	√		√	
ROEWE/ New 950	Engine management system (EMS)		√	√	√			
ROEWE/ New 950	Gearbox control module (TCM)		√	√	√			
ROEWE/ New 950	Anti-lock brake system / Dynamic stability control (ABS/SCS)		√	√	√			
ROEWE/ New 950	Airbag module (SRS)	√	√	√	√			
ROEWE/ New 950	Electronic parking brake module (EPB)		√	√	√			
ROEWE/ New 950	Gateway (GW)		√	√	√			
ROEWE/ New 950	Navigation entertainment system (FICM)		√	√	√			
ROEWE/ New 950	Switching control unit (SCU)		√	√	√			
ROEWE/ New 950	Communication module (T-BOX)		√	√	√			
ROEWE/ New 950	Fuel system control module (FSCM)		√	√	√			
ROEWE/ New 950	Front camera module (FVCM)		√	√	√			
ROEWE/RX3	Engine management system (ECM)	√	√	√	√	√		SP2158, SP2159, SP2160
ROEWE/RX3	Gearbox control module (AT)	√	√	√	√			SP2170, SP2171
ROEWE/RX3	Anti-lock brake system / Dynamic stability control (ABS)	√	√	√	√			SP2175, SP2176
ROEWE/RX3	Airbag control module (SRS)	√	√	√	√			
ROEWE/RX3	Body control module (BCM)	√	√	√	√	√		SP2156, SP2157
ROEWE/RX3	Electronic power steering system (EPS)	√	√	√	√	√		SP2177
ROEWE/RX3	Instrument module (IPK)	√	√	√	√	√		SP2185
ROEWE/RX3	Air conditioning control module (AC)	√	√	√	√	√		SP2186
ROEWE/RX3	Tire pressure monitoring system (TPMS)	√	√	√	√	√		SP2187
ROEWE/RX3	Keyless entry and key launch module (PEPS)	√	√	√	√	√		SP1718
ROEWE/RX3	Electronic parking brake module (EPB)	√	√	√	√	√		SP2178, SP2179, SP2180, SP2181, SP2182, SP2183, SP2184
ROEWE/RX3	Navigation entertainment system (FICM)	√	√	√	√			
ROEWE/RX3	Communication module (TBOX)	√	√	√	√			SP2154, SP2155
ROEWE/i6	Engine control module (ECM)	√	√	√	√	√		SP1551, SP1552
ROEWE/i6	Gearbox control module (TCM)	√	√	√	√	√		SP1564
ROEWE/i6	Anti-lock brake system / Dynamic stability control (SCS)	√	√	√	√			SP1567, SP1568, SP1569, SP1570, SP1571, SP1572, SP1573, SP1574, SP1575, SP1576, SP1577
ROEWE/i6	Airbag control module (SDM)	√	√	√	√			
ROEWE/i6	Body control module (BCM)	√	√	√	√	√		SP1583
ROEWE/i6	Electronic steering power system (EPS)	√	√	√	√			SP1578
ROEWE/i6	Instrument module (IPK)	√	√	√	√	√		SP1584
ROEWE/i6	Keyless entry and start system (PEPS)	√	√	√	√			SP1582
ROEWE/i6	Air conditioning module (HVAC)	√	√	√	√	√		SP1581
ROEWE/i6	Tire pressure monitoring system (TPMS)	√	√	√	√			SP1585
ROEWE/i6	Gateway (GW)	√	√	√	√			SP1548, SP1549, SP1550
ROEWE/i6	Navigation entertainment system (FICM)	√	√	√	√			
ROEWE/i6	Parking auxiliary control module (PDC)	√	√	√	√	√		
ROEWE/i6	Front camera module (FVCM)	√	√	√	√			SP1580
ROEWE/i6	DC converter with power management (PMDC)	√	√	√	√			
ROEWE/i6	Electronic steering pierlet lock (ESCL)	√	√	√	√			
ROEWE/i6	Communication module (T-BOX)	√	√	√	√			SP1546, SP1547
ROEWE/i6	Dynamic headlight level adjustment (DHL)	√	√	√	√	√		SP1566
ROEWE/i6	360 Panoramic image control module (AVM)	√	√	√	√			
ROEWE/ Roewe 950	Engine control module (ECM)	√	√	√	√			SP0016, SP0017
ROEWE/ Roewe 950	Gearbox control module (AT)	√	√	√	√	√		
ROEWE/ Roewe 950	Anti-lock brake system (ABS)	√	√	√	√	√		SP0013, SP0014, SP0015
ROEWE/ Roewe 950	Airbag module (SRS)	√	√	√	√			
ROEWE/ Roewe 950	Body control module (BCM)	√	√	√	√	√		SP0008, SP0009
ROEWE/ Roewe 950	Instrument group (IPK)	√	√	√	√	√		SP0007
ROEWE/ Roewe 950	Keyless access control system (PEPS)	√	√	√	√	√		
ROEWE/ Roewe 950	Remote control heater and air conditioning control module (HVAC)	√	√	√	√	√		SP0006
ROEWE/ Roewe 950	Parking auxiliary control module (ICAC)	√	√	√	√	√		SP0005
ROEWE/ Roewe 950	Parking brake control module (PBCM)	√	√	√	√	√		SP0004
ROEWE/ Roewe 950	Multi-axis acceleration sensor module (MASM)		√	√				
ROEWE/ Roewe 950	Steering wheel angle sensor module (EPS)		√	√	√			SP0000, SP0001
ROEWE/ Roewe 950	Fuel pump control module (FPCM)	√	√	√	√	√		SP0003
ROEWE/ Roewe 950	Headlight control module (HCM)	√	√	√	√			
ROEWE/ Roewe 950	Radio (WIRELESS)	√	√	√	√		√	
ROEWE/ Roewe 950	Rear audio control module (RACM)	√	√	√	√			
ROEWE/ Roewe 950	Seat memory control module (SMCM)	√	√	√	√	√		
ROEWE/ Roewe 950	Rear seat heating control module (RSHCM)	√	√	√	√			
ROEWE/ Roewe 750	Engine system (EMS)	√	√	√	√			SP0018
ROEWE/ Roewe 750	Automatic gearbox system (AT)	√	√	√	√			SP0020
ROEWE/ Roewe 750	Anti-lock brake system (ABS)	√	√	√	√			SP0021, SP0022, SP0023, SP0024, SP0025, SP0026
ROEWE/ Roewe 750	Airbag system (SRS)	√	√	√				SP0027, SP0028, SP0029
ROEWE/ Roewe 750	Gateway anti-theft module (GW)		√	√	√	√		
ROEWE/ Roewe 550	Engine system (EMS)	√	√	√	√			SP0040
ROEWE/ Roewe 550	Automatic gearbox system (AT)	√	√	√	√			SP0033
ROEWE/ Roewe 550	Anti-lock brake system (ABS)	√	√	√	√	√		SP0032
ROEWE/ Roewe 550	Airbag system (SRS)	√	√	√	√			
ROEWE/ Roewe 550	Body control module (BCM)	√	√	√	√	√		SP0034, SP0035
ROEWE/ Roewe 550	Body and engine anti-theft system (IMMO)		√	√	√	√		
ROEWE/ Roewe 550	Digital instrument unit (IPK)	√	√	√	√	√		SP0179, SP0180
ROEWE/ Roewe 550	Auto-air conditioning (AC)	√	√	√	√	√		
ROEWE/ Roewe 550	Electronic steering pierlet lock (ESCL)	√	√	√	√			
ROEWE/ Roewe 550	Interior lamps and exterior lamps (ELIL)		√	√	√	√		SP0036
ROEWE/ Roewe 550	Car entertainment equipment (FICM)		√	√				
ROEWE/ Roewe 550	Navigation system (NAV)	√	√	√		√		

ROEWE/ Roewe 350/350S	Engine system (ECM)	√	√	√	√	√	SP0163
ROEWE/ Roewe 350/350S	Automatic gearbox (AT)	√	√	√	√		SP0168
ROEWE/ Roewe 350/350S	Anti-lock brake system (ABS)	√	√	√	√	√	SP0172
ROEWE/ Roewe 350/350S	Airbag system (SRS)	√	√	√	√		
ROEWE/ Roewe 350/350S	Body controller (BCM)	√	√	√	√	√	SP0038, SP0039
ROEWE/ Roewe 350/350S	Instrument unit (IPK)	√	√	√	√	√	SP0041
ROEWE/ Roewe 350/350S	Auto-air conditioning (AC)	√	√	√	√		
ROEWE/ Roewe 350/350S	Corner sensor (SAS)	√	√	√			SP0178
ROEWE/ Roewe 360(1.4T)	Engine system (ECM)	√	√	√	√	√	SP0107, SP0108, SP0109, SP0110
ROEWE/ Roewe 360(1.4T)	Automatic gearbox system (AT)	√	√	√	√		SP0111
ROEWE/ Roewe 360(1.4T)	Anti-lock brake system (ABS)	√	√	√	√		SP0112, SP0113, SP0114, SP0115
ROEWE/ Roewe 360(1.4T)	Airbag system (SRS)	√	√	√	√	√	
ROEWE/ Roewe 360(1.4T)	Electric power steering system (EPS)	√	√	√	√	√	SP0124
ROEWE/ Roewe 360(1.4T)	Instrument unit (IPK)	√	√	√	√	√	SP0119
ROEWE/ Roewe 360(1.4T)	Automatic air conditioning system (AC)	√	√	√	√	√	SP0125
ROEWE/ Roewe 360(1.4T)	Steering wheel corner sensor (SAS)	√	√	√	√		SP0128
ROEWE/ Roewe 360(1.4T)	Gateway (GW)	√	√	√	√	√	SP0126, SP0127
ROEWE/ Roewe 360(1.4T)	Car entertainment system (FICM)	√	√	√	√	√	
ROEWE/ Roewe 360(1.4T)	Communication module (TBOX)	√	√	√	√		SP0129, SP0130
ROEWE/ Roewe 360(1.5VCT/1.5T)	Engine system (ECM)	√	√	√	√	√	SP0131, SP0132, SP0133, SP0134
ROEWE/ Roewe 360(1.5VCT/1.5T)	Automatic gearbox system (AT)	√	√	√	√	√	SP0135
ROEWE/ Roewe 360(1.5VCT/1.5T)	Anti-lock brake system (ABS)	√	√	√	√		SP0136, SP0137
ROEWE/ Roewe 360(1.5VCT/1.5T)	Airbag system (SRS)	√	√	√	√	√	
ROEWE/ Roewe 360(1.5VCT/1.5T)	Body controller (BCM)	√	√	√	√	√	SP0141, SP0142, SP0143, SP0144
ROEWE/ Roewe 360(1.5VCT/1.5T)	Electric power steering system (EPS)	√	√	√	√		SP0718
ROEWE/ Roewe 360(1.5VCT/1.5T)	Instrument unit (IPK)	√	√	√	√	√	SP0140
ROEWE/ Roewe 360(1.5VCT/1.5T)	Steering wheel corner sensor (SAS)	√	√	√	√		SP0719, SP0720
ROEWE/ Roewe 360(1.5VCT/1.5T)	Car entertainment system (FICM)	√	√	√	√	√	
ROEWE/ Roewe 360(1.5VCT/1.5T)	Communication module (TBOX)	√	√	√	√		SP0702
ROEWE/ Roewe W5	Engine system (ECM)	√	√	√	√	√	
ROEWE/ Roewe W5	Automatic gearbox system (AT)	功能未知					
ROEWE/ Roewe W5	Anti-lock brake system (ABS)	√	√	√	√	√	SP0044, SP0045, SP0046
ROEWE/ Roewe W5	Airbag system (SRS)	√	√	√	√		
ROEWE/ Roewe W5	Body controller (BCM)	√	√	√	√	√	SP0047
ROEWE/ Roewe W5	Standard anti-theft module (IMMO)	√	√	√	√		
ROEWE/ Roewe W5	Substance box controller (TCCM)	√	√	√	√		
ROEWE/ Roewe W5	Switching control unit (SCU)	√	√	√	√		
ROEWE/ Roewe 750( New )	Engine system (ECM)	√	√	√	√		SP0040
ROEWE/ Roewe 750( New )	Automatic gearbox system (AT)	√	√	√	√		SP0037
ROEWE/ Roewe 750( New )	Anti-lock brake system (ABS)	√	√	√	√		
ROEWE/ Roewe 750( New )	Airbag system (SRS)	√	√	√			SP0027, SP0028, SP0029
ROEWE/ Roewe 750( New )	Body control system (BCM)	√	√	√	√	√	SP0034, SP0035
ROEWE/ Roewe 750( New )	Anti-theft system (IMMO)	√	√	√	√		
ROEWE/ Roewe 750( New )	Instrument unit (IPK)	√	√	√	√	√	SP0056, SP0057, SP0058
ROEWE/ Roewe 750( New )	Auto-air conditioning (AC)	√	√	√	√	√	
ROEWE/ Roewe 750( New )	Master switch (MLS)	√	√	√	√	√	
ROEWE/ Roewe new 550	Engine management system (EMS)	√	√	√	√	√	SP0063, SP0064
ROEWE/ Roewe new 550	Gearbox control unit (TCU)	√	√	√	√		
ROEWE/ Roewe new 550	Anti-lock / Dynamic stabilization control system (ABS/SCS)	√	√	√	√		
ROEWE/ Roewe new 550	Airbag system (SRS)	√	√	√	√		
ROEWE/ Roewe new 550	Body control module (BCM)	√	√	√	√	√	SP0074, SP0075, SP0076, SP0077

ROEWE/ Roewe new 550	Instrument unit (IPK)	√	√	√	√		√	SP0078
ROEWE/ Roewe new 550	Automatic air conditioning system (ATC)	√	√	√	√			
ROEWE/ Roewe new 550	Electronic air conditioner (ETC)	√	√	√	√			
ROEWE/ Roewe new 550	Electronic parking brake system (EPB)	√	√	√	√		√	SP0079, SP0080, SP0081, SP0082, SP0083, SP0084
ROEWE/ Roewe new 550	Electronic steering column lock (ESCL)	√	√	√	√			
ROEWE/ Roewe new 550	Switching control unit (SCU)	√	√	√	√		√	
ROEWE/ Roewe new 550	Adaptive large lamp system (AFS)	√	√	√	√			SP0085, SP0086
ROEWE/ Roewe new 550	Rain Sensor (RRS)	√	√	√	√			
ROEWE/ Roewe new 550	Parking distance control system (PDC)	√	√	√	√			
ROEWE/ Roewe new 550	Entertainment system (ICE)	√	√	√	√		√	
ROEWE/ Roewe new 550	Car wiring box (TBOX)	√	√	√	√		√	
ROEWE/RX5	Engine management system (EMS)	√	√	√	√		√	SP0889
ROEWE/RX5	Wave box control module (TCM)	√	√	√	√			SP0892, SP0893, SP0894, SP0895
ROEWE/RX5	Ignition control system / Car anti-lock brake system (SCS/ABS)	√	√	√	√			SP0899, SP0900, SP0901, SP0902
ROEWE/RX5	Airbag system (SDM)	√	√	√	√			
ROEWE/RX5	Body control module (BCM)	√	√	√	√		√	SP0916
ROEWE/RX5	Electric power steering (EPS)	√	√	√	√			SP0905
ROEWE/RX5	Instrument system (IPK)	√	√	√	√		√	SP0920
ROEWE/RX5	Air conditioning control module (ATC)	√	√	√	√		√	SP0919
ROEWE/RX5	Keyless entry module (PEPS)	√	√	√	√			SP0918
ROEWE/RX5	Tire pressure monitoring system (TPMS)	√	√	√	√			SP0921
ROEWE/RX5	Electronic parking brake system (EPB)	√	√	√	√			SP0906, SP0907, SP0908, SP0909
ROEWE/RX5	Gateway (GW)	√	√	√	√			SP0887, SP0888
ROEWE/RX5	Parking assist system (PDC)	√	√	√	√		√	
ROEWE/RX5	Electronic steering pierlet lock (ESCL)	√	√	√	√			
ROEWE/RX5	Entertainment system control module (FICM)	√	√	√	√			
ROEWE/RX5	Sub-box control module (TCCM)	√	√	√	√			SP0898
ROEWE/RX5	Car wiring box (TBOX)	√	√	√	√			SP0884, SP0885, SP0886
ROEWE/RX5	Start control unit (SCU)	√	√	√	√			
ROEWE/RX5	Forward camera module (FVCM)	√	√	√	√			SP0910
ROEWE/RX5	Steering angle sensor module (SAS)	√	√	√	√			SP0911, SP0912
ROEWE/RX5	Electric tail door control module (PLCM)	√	√	√	√		√	SP0917
ROEWE/RX5	Power Control Module (PMDC)	√	√	√	√			
ROEWE/RX5	Adaptive large lamp (DHL)	√	√	√	√		√	SP0913
ROEWE/RX5	Forward detection radar module (FDR)	√	√	√	√			SP0914, SP0915
ROEWE/RX5 Plus	Engine control module (ECM)	√	√	√	√		√	
ROEWE/RX5 Plus	Gearbox control module (TCM)	√	√	√	√		√	SP0928
ROEWE/RX5 Plus	Anti-lock brake system / Dynamic stability control (SCS/ABS)	√	√	√	√			SP0931, SP0932, SP0933, SP0934
ROEWE/RX5 Plus	Airbag control module (SDM)	√	√	√	√			
ROEWE/RX5 Plus	Body control module (BCM)	√	√	√	√		√	SP0945
ROEWE/RX5 Plus	Electric power steering (EPS)	√	√	√	√			SP0937
ROEWE/RX5 Plus	Instrument system (IPK)	√	√	√	√		√	SP0948
ROEWE/RX5 Plus	Keyless entry module (PEPS)	√	√	√	√			SP0946
ROEWE/RX5 Plus	Air conditioning module (HVAC)	√	√	√	√		√	SP0947
ROEWE/RX5 Plus	Electronic parking brake system (EPB)	√	√	√	√			SP0938, SP0939, SP0940, SP0941
ROEWE/RX5 Plus	Tire pressure monitoring system (TPMS)	√	√	√	√			SP0950
ROEWE/RX5 Plus	Gateway (GW)	√	√	√	√			SP0924
ROEWE/RX5 Plus	Car wiring box (T-BOX)	√	√	√	√			SP0922, SP0923
ROEWE/RX5 Plus	Start control unit (SCU)	√	√	√	√		√	SP0929, SP0930
ROEWE/RX5 Plus	Forward camera module (FVCM)	√	√	√	√			SP0942
ROEWE/E15F	Battery Management System (BMS)	√	√	√	√		√	SP2310
ROEWE/E15F	Vehicle Control Module (VCU)	√	√	√	√		√	SP2331
ROEWE/E15F	Charging Control Unit (CCU)	√	√	√	√			
ROEWE/E15F	Traction Motor Controller (TC)	√	√	√	√			SP2329
ROEWE/E15F	Anti-lock braking system/dynamic stability control (SCS/ABS)	√	√	√	√			SP2325, SP2326
ROEWE/E15F	Airbag Control Module (SDM)	√	√	√	√			
ROEWE/E15F	Body Control Module (BCM)	√	√	√	√		√	SP2309
ROEWE/E15F	Electronic Power Steering System (EPS)	√	√	√	√		√	SP2319
ROEWE/E15F	Combination meter (IPK)	√	√	√	√		√	
ROEWE/E15F	Electro-hydraulic braking system (EHBS)	√	√	√	√			
ROEWE/E15F	Gateway Module (GW)	√	√	√	√			SP2320, SP2321, SP2322
ROEWE/E15F	Air conditioning module (HVAC)	√	√	√	√		√	SP2323
ROEWE/E15F	Keyless Start Module (PEPS)	√	√	√	√			SP2324
ROEWE/E15F	Tire Pressure Monitoring System (TPMS)	√	√	√	√			SP2330
ROEWE/E15F	Electronic Handbrake Module (EPB)	√	√	√	√			SP2311, SP2312, SP2313, SP2314, SP2315, SP2316, SP2317, SP2318
ROEWE/E15F	Navigation Entertainment System (FICM)	√	√	√	√			
ROEWE/E15F	Shift Control Module (SCU)	√	√	√	√			
ROEWE/E15F	Communication Module (T-BOX)	√	√	√	√			SP2327, SP2328
ROEWE/E15 Face-changing version	Battery Management System (BMS)	√	√	√	√		√	SP2333
ROEWE/E15 Face-changing version	Charging Control Unit (CCU)	√	√	√	√			
ROEWE/E15 Face-changing version	Traction Motor Controller (TC)	√	√	√	√			SP2353
ROEWE/E15 Face-changing version	Anti-lock braking system/dynamic stability control (SCS/ABS)	√	√	√	√			SP2341, SP2342, SP2343, SP2344, SP2345, SP2346, SP2347, SP2348, SP2349, SP2350
ROEWE/E15 Face-changing version	Airbag Control Module (SDM)	√	√	√	√			
ROEWE/E15 Face-changing version	Body Control Module (BCM)	√	√	√	√		√	SP2332



ROEWE/Ei5 Face-changing version	Electronic Power Steering System (EPS)	√	√	√	√		√	SP2334
ROEWE/Ei5 Face-changing version	Combination meter (IPK)	√	√	√	√		√	SP2339
ROEWE/Ei5 Face-changing version	Gateway Module (GW)	√	√	√	√			SP2335, SP2336, SP2337
ROEWE/Ei5 Face-changing version	Air conditioning module (HVAC)	√	√	√	√		√	SP2338
ROEWE/Ei5 Face-changing version	Keyless Start Module (PEPS)	√	√	√	√			SP2340
ROEWE/Ei5 Face-changing version	Tire Pressure Monitoring System (TPMS)	√	√	√	√			SP2354
ROEWE/Ei5 Face-changing version	Shift Control Module (SCU)	√	√	√	√			
ROEWE/Ei5 Face-changing version	Communication Module (T-BOX)	√	√	√	√			SP2351, SP2352
ROEWE/Ei5 Face-changing version	Forward Detection Radar Module (FDR)	√	√	√	√			
ROEWE/Ei5 Face-changing version	Navigation Entertainment System (FICM)	√	√	√	√			
ROEWE/Ei5 Face-changing version	Front camera module (FVCM)	√	√	√	√			
ROEWE/ER6	Battery Management System (BMS)	√	√	√	√		√	
ROEWE/ER6	Vehicle Control Module (VCU)	√	√	√	√		√	SP1591
ROEWE/ER6	Traction Motor Controller (TC)	√	√	√	√			SP1592
ROEWE/ER6	Charging Control Unit (CCU)	√	√	√	√			
ROEWE/ER6	Anti-lock braking system/dynamic stability control (SCS)	√	√	√	√			SP1593, SP1594
ROEWE/ER6	Airbag Control Module (SDM)	√	√	√	√			
ROEWE/ER6	Body Control Module (BCM)	√	√	√	√		√	SP1606
ROEWE/ER6	Electronic Power Steering System (EPS)	√	√	√	√		√	SP1605
ROEWE/ER6	Instrument module (IPK)	√	√	√	√			SP1609
ROEWE/ER6	Keyless Entry and Start System (PEPS)	√	√	√	√			SP1607
ROEWE/ER6	Air Conditioning Module (HVAC)	√	√	√	√		√	SP1608
ROEWE/ER6	Tire Pressure Monitoring System (TPMS)	√	√	√	√			SP1610
ROEWE/ER6	Electronic Handbrake Module (EPB)	√	√	√	√		√	SP1596, SP1597, SP1598, SP1599, SP1600, SP1601, SP1602
ROEWE/ER6	Electro-hydraulic braking system (EHBS)	√	√	√	√			
ROEWE/ER6	Gateway(GW)	√	√	√	√			SP1588, SP1589, SP1590
ROEWE/ER6	Communication Module (T-BOX)	√	√	√	√			SP1586, SP1587
ROEWE/ER6	Shift Control Unit (SCU)	√	√	√	√		√	
ROEWE/ER6	Front camera module (FVCM)	√	√	√	√			SP1595
ROEWE/ER6	Forward Detection Radar Module (FDR)	√	√	√	√			SP1603, SP1604
ROEWE/ER6	Seat Memory Module (MSM)	√	√	√	√		√	
ROEWE/ER6	Reverse Driver Assistance Module (RDA)	√	√	√	√			
ROEWE/ER6	Navigation Entertainment System (FICM)	√	√	√	√			
ROEWE/CLEVER	Battery Management System (BMS)	√	√	√	√			
ROEWE/CLEVER	Shift Control Module (SCU)	√	√	√	√			
ROEWE/CLEVER	Vehicle Control Module (VCU)	√	√	√	√		√	SP1446
ROEWE/CLEVER	Traction Motor Controller (TC)	√	√	√	√			SP1447
ROEWE/CLEVER	Anti-lock Braking System (ABS)	√	√	√	√			SP1444
ROEWE/CLEVER	Airbag Control Module (SDM)	√	√	√	√			
ROEWE/CLEVER	Body Control Module (BCM)	√	√	√	√		√	SP1450, SP1451
ROEWE/CLEVER	Electric Power Steering (EPS)	√	√	√	√			SP1445
ROEWE/CLEVER	Combination Instrument (IPK)	√	√	√	√		√	SP1448
ROEWE/CLEVER	Air Conditioning Module (HVAC)	√	√	√	√		√	SP1449
ROEWE/CLEVER	Gateway(GW)	√	√	√	√			SP1442, SP1443
ROEWE/CLEVER	Communication Module (T-BOX)	√	√	√	√			SP1441
ROEWE/Ei6 Plus	Engine Management System (ECM)	√	√	√	√		√	SP1759, SP1760
ROEWE/Ei6 Plus	Battery Management System (BMS)	√	√	√	√		√	
ROEWE/Ei6 Plus	Car Charger (OBC)	√	√	√	√			
ROEWE/Ei6 Plus	DC/DC converter (DCDC)	√	√	√	√			
ROEWE/Ei6 Plus	Hybrid Control Unit (HCU)	√	√	√	√			SP1763, SP1764, SP1765, SP1766, SP1767, SP1768
ROEWE/Ei6 Plus	Shift Control Module (SCU)	√	√	√	√			
ROEWE/Ei6 Plus	Anti-lock braking system/dynamic stability control (SCS/ABS)	√	√	√	√			SP1769, SP1770, SP1771, SP1772, SP1773, SP1774, SP1775, SP1776, SP1777, SP1778
ROEWE/Ei6 Plus	Airbag Control Module (SDM)	√	√	√	√			
ROEWE/Ei6 Plus	Body Control Module (BCM)	√	√	√	√		√	SP1781
ROEWE/Ei6 Plus	Electric Power Steering (EPS)	√	√	√	√		√	SP1779
ROEWE/Ei6 Plus	Combination meter (IPK)	√	√	√	√		√	SP1784
ROEWE/Ei6 Plus	Keyless Entry and Keyless Start Module (PEPS)	√	√	√	√			SP1782
ROEWE/Ei6 Plus	Air Conditioning Module (HVAC)	√	√	√	√		√	SP1783
ROEWE/Ei6 Plus	Tire Pressure Monitoring System (TPMS)	√	√	√	√			SP1786
ROEWE/Ei6 Plus	Gateway(GW)	√	√	√	√			SP1755, SP1756
ROEWE/Ei6 Plus	Communication Module (T-BOX)	√	√	√	√			SP1757, SP1758
ROEWE/Ei6 Plus	Integrated Starter Control Module (ISC)	√	√	√	√		√	SP1761, SP1762
ROEWE/Ei6 Plus	Chassis Management Module (CMM)	√	√	√	√		√	
ROEWE/Ei6 Plus	Front camera module (FVCM)	√	√	√	√			SP1780
ROEWE/Ei6 Plus	Automatic Parking System/Parking Assist System (APA/PDC)	√	√	√	√			
ROEWE/Ei6 Plus	Electronic steering column lock (ESCL)	√	√	√	√			
ROEWE/Ei6 Plus	Entertainment System Control Module (FICM)	√	√	√	√			
ROEWE/Ei6 MAX	Engine Management System (ECM)	√	√	√	√		√	SP1798, SP1799
ROEWE/Ei6 MAX	Battery Management System (BMS)	√	√	√	√		√	
ROEWE/Ei6 MAX	Shift Control Module (SCU)	√	√	√	√		√	

ROEWE/Ei6 MAX	Hybrid Control Unit (HCU)	√	√	√	√		SP1791, SP1792, SP1793, SP1794, SP1795, SP1796, SP1797
ROEWE/Ei6 MAX	Charging Control Unit (CCU)	√	√	√	√		
ROEWE/Ei6 MAX	Anti-lock braking system/dynamic stability control (SCS/ABS)	√	√	√	√		SP1801, SP1802, SP1803, SP1804, SP1805, SP1806, SP1807, SP1808, SP1809, SP1810
ROEWE/Ei6 MAX	Airbag Control Module (SDM)	√	√	√	√		
ROEWE/Ei6 MAX	Body Control Module (BCM)	√	√	√	√	√	SP1811
ROEWE/Ei6 MAX	Electric Power Steering (EPS)	√	√	√	√	√	SP1800
ROEWE/Ei6 MAX	Combination instrument (IPK)	√	√	√	√	√	SP1814
ROEWE/Ei6 MAX	Keyless Entry and Keyless Start Module (PEPS)	√	√	√	√		SP1812
ROEWE/Ei6 MAX	Air Conditioning Module (HVAC)	√	√	√	√	√	SP1813
ROEWE/Ei6 MAX	Tire Pressure Monitoring System (TPMS)	√	√	√	√		SP1816
ROEWE/Ei6 MAX	Gateway(GW)	√	√	√	√		SP1789, SP1790
ROEWE/Ei6 MAX	Chassis Management Module (CMM)	√	√	√	√	√	
ROEWE/Ei6 MAX	Communication Module (T-BOX)	√	√	√	√		SP1787, SP1788
ROEWE/Ei6 MAX	Front camera module (FVCM)	√	√	√	√		SP0662
ROEWE/Ei6 MAX	Integrated Starter Control Module (ISC)	√	√	√	√	√	
ROEWE/Ei6 MAX	Electronic steering column lock (ESCL)	√	√	√	√		
ROEWE/Ei6 MAX	Entertainment System Control Module (FICM)	√	√	√	√		
ROEWE/MARVEL X	Battery Management Module (BMS)	√	√	√	√	√	
ROEWE/MARVEL X	Vehicle Control Module (VCU)	√	√	√	√	√	SP1334, SP1335
ROEWE/MARVEL X	Car Charger (OBC)	√	√	√	√		
ROEWE/MARVEL X	Variable Speed Motor Controller (GSMC)	√	√	√	√		
ROEWE/MARVEL X	High Voltage DC/DC Converter (HVDCCDC)	√	√	√	√		
ROEWE/MARVEL X	Traction Motor Controller (TC)	√	√	√	√		
ROEWE/MARVEL X	Gear Detection Module (SCU)	√	√	√	√		
ROEWE/MARVEL X	Anti-lock braking system/dynamic stability control (ABS/SCS)	√	√	√	√		SP1336, SP1337
ROEWE/MARVEL X	Airbag Control Module (SRS)	√	√	√	√		
ROEWE/MARVEL X	Body Control Module (BCM)	√	√	√	√	√	SP1350
ROEWE/MARVEL X	Electronic Power Steering System (EPS)	√	√	√	√		SP1338
ROEWE/MARVEL X	Instrument Module (IPK)	√	√	√	√		SP1353
ROEWE/MARVEL X	Air Conditioning Controller (HVAC)	√	√	√	√	√	SP1352
ROEWE/MARVEL X	Keyless Entry and Start System (PEPS)	√	√	√	√		SP1351
ROEWE/MARVEL X	Gateway Module (GW)	√	√	√	√		SP1331, SP1332, SP1333
ROEWE/MARVEL X	Electronic Handbrake Module (EPB)	√	√	√	√	√	SP1340, SP1341, SP1342, SP1343, SP1344, SP1345, SP1346
ROEWE/MARVEL X	Electro-hydraulic brake system (EHBS)	√	√	√	√		
ROEWE/MARVEL X	Tire Pressure Monitoring System (TPMS)	√	√	√	√		SP1354
ROEWE/MARVEL X	Rotation Angle Sensor (SAS)	√	√	√	√		
ROEWE/MARVEL X	Integrated Starter Control Module (ISC)	√	√	√	√		
ROEWE/MARVEL X	Front camera module (FVCM)	√	√	√	√		SP1339
ROEWE/MARVEL X	Navigation Entertainment System (FICM)	√	√	√	√		
ROEWE/MARVEL X	Communication Module (T-BOX)	√	√	√	√		SP1329, SP1330
ROEWE/MARVEL X	Forward Detection Radar Module (FDR)	√	√	√	√		SP1347, SP1348
ROEWE/MARVEL X	Point-to-point memory parking assist module (P2P)	√	√	√	√		SP1349
ROEWE/MARVEL X	Automatic Parking Assist System (APA)	√	√	√	√		
ROEWE/MARVEL X	Seat Memory Module (MSM)	√	√	√	√	√	
ROEWE/MARVEL X	Rearward Driving Assistance Module (RDA)	√	√	√	√		
ROEWE/MARVEL X	Electric tailgate control module (PLCM)	√	√	√	√		
ROEWE/MARVEL X	Natural Light Control Module (ALCM)	√	√	√	√	√	
ROEWE/MARVEL R	Battery Management System (BMS)	√	√	√	√	√	
ROEWE/MARVEL R	Vehicle Control Module (VCU)	√	√	√	√	√	SP1386
ROEWE/MARVEL R	Variable-speed motor controller (GSMC)	√	√	√	√		
ROEWE/MARVEL R	Traction Motor Controller (TC)	√	√	√	√		
ROEWE/MARVEL R	Shift Control Module (SCU)	√	√	√	√		
ROEWE/MARVEL R	Integrated Starter Control Module (ISC)	√	√	√	√		
ROEWE/MARVEL R	Anti-lock braking system/dynamic stability control (SCS/ABS)	√	√	√	√		
ROEWE/MARVEL R	Airbag Control Module (SDM)	√	√	√	√		
ROEWE/MARVEL R	Body Control Module (BCM)	√	√	√	√	√	SP1398
ROEWE/MARVEL R	Electric Power Steering (EPS)	√	√	√	√		SP1387
ROEWE/MARVEL R	Combination Instrument (IPK)	√	√	√	√		
ROEWE/MARVEL R	Keyless Entry and Keyless Start Module (PEPS)	√	√	√	√		SP1400
ROEWE/MARVEL R	Air Conditioning Module (HVAC)	√	√	√	√	√	SP1399
ROEWE/MARVEL R	Tire Pressure Monitoring System (TPMS)	√	√	√	√		SP1402
ROEWE/MARVEL R	Electro-hydraulic braking system (EHBS)	√	√	√	√		
ROEWE/MARVEL R	Electronic Handbrake Module (EPB)	√	√	√	√	√	SP1388, SP1389, SP1390, SP1391, SP1392, SP1393, SP1394
ROEWE/MARVEL R	Gateway(GW)	√	√	√	√		SP1383, SP1384, SP1385
ROEWE/MARVEL R	Communication Module (T-BOX)	√	√	√	√		SP1381, SP1382
ROEWE/MARVEL R	Communication Box (I-BOX)	√	√	√	√		
ROEWE/MARVEL R	Rotation Angle Sensor (SAC)	√	√	√	√		
ROEWE/MARVEL R	Radar Module (FDR)	√	√	√	√		SP1395, SP1396
ROEWE/MARVEL R	Front camera module (FVCM)	√	√	√	√		SP1397
ROEWE/MARVEL R	Point-to-point memory parking assist module (P2P)	√	√	√	√		
ROEWE/MARVEL R	Electric tailgate control module (PLCM)	√	√	√	√		
ROEWE/MARVEL R	Seat Memory Module (MSM)	√	√	√	√	√	
ROEWE/MARVEL R	360 panoramic image control module (AVM)	√	√	√	√		SP1401
ROEWE/MARVEL R	Entertainment System Control Module (FICM)	√	√	√	√		
ROEWE/MARVEL R	Pedestrian passing alarm control system (PACM)		√	√			
ROEWE/MARVEL R	Reverse Driver Assistance Module (RDA)	√	√	√	√		
ROEWE/MARVEL R	Natural Light Control Module (ALCM)	√	√	√	√	√	



ROEWE/MARVEL R	Automatic Parking System (APA)	√	√	√	√			
ROEWE/RX5 eMAX	Engine Control Module (ECM)	√	√	√	√		√	
ROEWE/RX5 eMAX	Battery Management Module (BMS)	√	√	√	√		√	
ROEWE/RX5 eMAX	Hybrid Control Unit (HCU)	√	√	√	√			SP1285, SP1286, SP1287, SP1288, SP1289, SP1290, SP1291
ROEWE/RX5 eMAX	Car Charger (OBC)	√	√	√	√			
ROEWE/RX5 eMAX	Integrated Starter Control Module (ISC)	√	√	√	√		√	SP1292, SP1293
ROEWE/RX5 eMAX	High Voltage DC/DC Converter (DCDC)	√	√	√	√			
ROEWE/RX5 eMAX	Anti-lock braking system/dynamic stability control (SCS/ABS)	√	√	√	√			SP1302, SP1303, SP1304, SP1305, SP1306, SP1307, SP1308, SP1309, SP1310
ROEWE/RX5 eMAX	Airbag Control Module (SDM)	√	√	√	√			
ROEWE/RX5 eMAX	Body Control Module (BCM)	√	√	√	√		√	SP1315
ROEWE/RX5 eMAX	Electronic Power Steering System (EPS)	√	√	√	√			SP1311
ROEWE/RX5 eMAX	Instrument Module (IPK)	√	√	√	√			
ROEWE/RX5 eMAX	Keyless Entry and Keyless Start Module (PEPS)	√	√	√	√			SP1316
ROEWE/RX5 eMAX	Air Conditioning Module (HVAC)	√	√	√	√		√	SP1317
ROEWE/RX5 eMAX	Tire Pressure Monitoring System (TPMS)	√	√	√	√			SP1318
ROEWE/RX5 eMAX	Shift Control Unit (SCU)	√	√	√	√		√	
ROEWE/RX5 eMAX	Gateway Module (GW)	√	√	√	√			SP1283, SP1284
ROEWE/RX5 eMAX	Communication Module (T-BOX)	√	√	√	√			SP1281, SP1282
ROEWE/RX5 eMAX	Automatic Parking Assist System (APA)	√	√	√	√			
ROEWE/RX5 eMAX	Forward Detection Radar Module (FDR)	√	√	√	√			SP1312, SP1313
ROEWE/RX5 eMAX	Front camera module (FVCM)	√	√	√	√			SP1314
ROEWE/RX5 eMAX	Chassis Management Module (CMM)	√	√	√	√		√	
ROEWE/RX5 eMAX	Electric tailgate control module (PLCM)	√	√	√	√			
ROEWE/RX5 eMAX	Seat Memory Module (MSM)	√	√	√	√		√	
ROEWE/RX5 eMAX	Electronic steering column lock (ESCL)	√	√	√	√			
ROEWE/RX5 eMAX	Rearward Driving Assistance Module (RDA)	√	√	√	√			
ROEWE/RX5 eMAX	Navigation and Entertainment System (FICM)	√	√	√	√			
ROEWE/RX5 eMAX	360 panoramic image control module (AVM)	√	√	√	√			SP1319
ROEWE/ERX5 (EV)	Battery Management Module (BMS)	√	√	√	√		√	
ROEWE/ERX5 (EV)	Vehicle Control Module (VCU)	√	√	√	√		√	SP1217
ROEWE/ERX5 (EV)	Car Charger (OBC)	√	√	√	√			
ROEWE/ERX5 (EV)	High Voltage DC/DC Converter (HVDCCDC)	√	√	√	√			
ROEWE/ERX5 (EV)	Traction Motor Controller (TC)	√	√	√	√			SP1218
ROEWE/ERX5 (EV)	Gear Detection Module (SCU)	√	√	√	√			
ROEWE/ERX5 (EV)	Anti-lock braking system/dynamic stability control (ABS/SCS)	√	√	√	√			SP1219, SP1220, SP1221
ROEWE/ERX5 (EV)	Airbag Control Module (SRS)	√	√	√	√			
ROEWE/ERX5 (EV)	Body Control Module (BCM)	√	√	√	√		√	SP1230
ROEWE/ERX5 (EV)	Electronic Power Steering System (EPS)	√	√	√	√			SP1222
ROEWE/ERX5 (EV)	Instrument Module (IPK)	√	√	√	√		√	SP1234
ROEWE/ERX5 (EV)	Air Conditioning Controller (HVAC)	√	√	√	√		√	SP1232
ROEWE/ERX5 (EV)	Keyless Entry and Start System (PEPS)	√	√	√	√			SP1231
ROEWE/ERX5 (EV)	Gateway Module (GW)	√	√	√	√			SP1214, SP1215, SP1216
ROEWE/ERX5 (EV)	Electronic Handbrake Module (EPB)	√	√	√	√			SP1225, SP1226, SP1227, SP1228
ROEWE/ERX5 (EV)	Tire Pressure Monitoring System (TPMS)	√	√	√	√			SP1236
ROEWE/ERX5 (EV)	Rotation Angle Sensor (SAS)	√	√	√	√			SP1223, SP1224
ROEWE/ERX5 (EV)	Front camera module (FVCM)	√	√	√	√			SP1229
ROEWE/ERX5 (EV)	Navigation Entertainment System (FICM)	√	√	√	√			
ROEWE/ERX5 (EV)	Communication Module (T-BOX)	√	√	√	√			SP1213
ROEWE/ERX5 (EV)	Dynamic headlight level adjustment (DHL)	√	√	√	√			
ROEWE/ERX5 (EV)	Automatic Parking System/Parking Assist System (APA/PDC)	√	√	√	√		√	
ROEWE/ERX5 (EV)	Electric tailgate control module (PLCM)	√	√	√	√		√	SP1235
ROEWE/ERX5 (EV) Plus	Battery Management Module (BMS)	√	√	√	√		√	
ROEWE/ERX5 (EV) Plus	Vehicle Control Module (VCU)	√	√	√	√		√	
ROEWE/ERX5 (EV) Plus	Traction Motor Controller (TC)	√	√	√	√			
ROEWE/ERX5 (EV) Plus	Gear detection module (SCU)	√	√	√	√		√	
ROEWE/ERX5 (EV) Plus	Anti-lock braking system/dynamic stability control (SCS)	√	√	√	√			
ROEWE/ERX5 (EV) Plus	Airbag Control Module (SDM)	√	√	√	√			
ROEWE/ERX5 (EV) Plus	Body Control Module (BCM)	√	√	√	√		√	
ROEWE/ERX5 (EV) Plus	Electronic Power Steering System (EPS)	√	√	√	√			
ROEWE/ERX5 (EV) Plus	Combination Instrument (IPK)	√	√	√	√		√	
ROEWE/ERX5 (EV) Plus	Keyless Entry and Keyless Start Module (PEPS)	√	√	√	√			
ROEWE/ERX5 (EV) Plus	Air Conditioning Module (HVAC)	√	√	√	√		√	
ROEWE/ERX5 (EV) Plus	Tire Pressure Monitoring System (TPMS)	√	√	√	√			
ROEWE/ERX5 (EV) Plus	Electro-hydraulic braking system (EHBS)	√	√	√	√			
ROEWE/ERX5 (EV) Plus	Electronic Handbrake Module (EPB)	√	√	√	√			
ROEWE/ERX5 (EV) Plus	Gateway Module (GW)	√	√	√	√			
ROEWE/ERX5 (EV) Plus	Front camera module (FVCM)	√	√	√	√			
ROEWE/ERX5 (EV) Plus	Communication Module (T-BOX)	√	√	√	√			
ROEWE/ERX5 (EV) Plus	Navigation and Entertainment System (FICM)	√	√	√	√			
ROEWE/ERX5 (EV) Plus	Electric tailgate control module (PLCM)	√	√	√	√			
ROEWE/Ei5	battery management module (BMS)	√	√	√	√		√	
ROEWE/Ei5	Vehicle Control Module (VCU)	√	√	√	√		√	SP1409
ROEWE/Ei5	DC/DC converter (DCDC)	√	√	√	√			
ROEWE/Ei5	Car Charger (OBC)	√	√	√	√			
ROEWE/Ei5	Traction Motor Controller (TC)	√	√	√	√			SP1408
ROEWE/Ei5	Electric Vehicle Communication Controller (EVCC)	√	√	√	√			
ROEWE/Ei5	Parking Motor Controller (EPMCU)	√	√	√	√			
ROEWE/Ei5	Charging Control Unit (CCU)	√	√	√	√			
ROEWE/Ei5	Anti-lock braking system/dynamic stability control (SCS/ABS)	√	√	√	√			SP1410, SP1411, SP1412, SP1413, SP1414, SP1415, SP1416, SP1417, SP1418
ROEWE/Ei5	Airbag Control Module (SDM)	√	√	√	√			

ROEWE/Ei5	Body Control Module (BCM)	✓	✓	✓	✓		✓	SP1436
ROEWE/Ei5	Electronic Power Steering System (EPS)	✓	✓	✓	✓			SP1419
ROEWE/Ei5	Combination Instrument (IPK)	✓	✓	✓	✓		✓	SP1439
ROEWE/Ei5	Keyless Entry and Keyless Start Module (PEPS)	✓	✓	✓	✓			SP1437
ROEWE/Ei5	Air conditioning control module (HVAC)	✓	✓	✓	✓		✓	SP1438
ROEWE/Ei5	Tire Pressure Monitoring System (TPMS)	✓	✓	✓	✓			SP1435
ROEWE/Ei5	Gateway Module (GW)	✓	✓	✓	✓			SP1405, SP1406, SP1407
ROEWE/Ei5	Electronic Handbrake Module (EPB)	✓	✓	✓	✓		✓	SP1428, SP1429, SP1430, SP1431, SP1432, SP1433, SP1434
ROEWE/Ei5	Electronic Handbrake Module (EHBS)	✓	✓	✓	✓			
ROEWE/Ei5	Shift Control Unit (SCU)	✓	✓	✓	✓			
ROEWE/Ei5	Front camera module (FVCM)	✓	✓	✓	✓			SP1420
ROEWE/Ei5	Airbag Control Module (FDR)	✓	✓	✓	✓			
ROEWE/Ei5	Electronic steering column lock (ESCL)	✓	✓	✓	✓			
ROEWE/Ei5	navigation and entertainment system (FICM)	✓	✓	✓	✓			
ROEWE/Ei5	Communication Module (T-BOX)	✓	✓	✓	✓			SP1403, SP1404
ROEWE/E950	Engine Management System (EMS)		✓	✓	✓			
ROEWE/E950	Battery Management Module (BMS)		✓	✓	✓			
ROEWE/E950	On-board charging module (OBC)		✓	✓	✓			
ROEWE/E950	Hybrid Control Unit (HCU)		✓	✓	✓			
ROEWE/E950	Traction Motor Controller (TC)		✓	✓	✓			
ROEWE/E950	Anti-lock braking system/dynamic stability control (ABS/SCS)		✓	✓	✓			
ROEWE/E950	Airbag Module (SRS)	✓	✓	✓	✓			
ROEWE/E950	Air Conditioning Control Module (ATC)		✓	✓	✓			
ROEWE/E950	Electronic Parking Brake Module (EPB)		✓	✓	✓			
ROEWE/E950	Gateway(GW)		✓	✓	✓			
ROEWE/E950	Navigation Entertainment System (FICM)		✓	✓	✓			
ROEWE/E950	Shift Control Unit (SCU)		✓	✓	✓			
ROEWE/E950	Communication Module (T-BOX)		✓	✓	✓			
ROEWE/E950	Electronic Oil Pump Motor Controller (EOPC)		✓	✓	✓			
ROEWE/E950	Integrated Starter Control Module (ISC)		✓	✓	✓			
ROEWE/E950	Front camera module (FVCM)		✓	✓	✓			
ROEWE/ei6	Engine Control Module (ECM)	✓	✓	✓	✓		✓	SP1734, SP1735
ROEWE/ei6	Battery Management Module (BMS)	✓	✓	✓	✓		✓	
ROEWE/ei6	Car Charger (OBC)	✓	✓	✓	✓			
ROEWE/ei6	Hybrid Control Unit (HCU)	✓	✓	✓	✓		✓	SP1727, SP1728, SP1729, SP1730, SP1731
ROEWE/ei6	Traction Motor Controller (TC)	✓	✓	✓	✓		✓	SP1732
ROEWE/ei6	Anti-lock braking system/dynamic stability control (SCS)	✓	✓	✓	✓			SP1736, SP1737, SP1738, SP1739, SP1740, SP1741, SP1742, SP1743, SP1744, SP1745, SP1746
ROEWE/ei6	Airbag Control Module (SDM)	✓	✓	✓	✓			
ROEWE/ei6	Body Control Module (BCM)	✓	✓	✓	✓		✓	SP1750
ROEWE/ei6	Electronic Power Steering System (EPS)	✓	✓	✓	✓			SP1747
ROEWE/ei6	Combination meter (IPK)	✓	✓	✓	✓		✓	SP1753
ROEWE/ei6	Gateway(GW)	✓	✓	✓	✓			SP1723, SP1724
ROEWE/ei6	Keyless Entry and Start System (PEPS)	✓	✓	✓	✓			SP1751
ROEWE/ei6	Air Conditioning Module (HVAC)	✓	✓	✓	✓		✓	SP1752
ROEWE/ei6	Electronic steering column lock (ESCL)	✓	✓	✓	✓			
ROEWE/ei6	Navigation Entertainment System (FICM)	✓	✓	✓	✓			
ROEWE/ei6	Communication module (T-BOX)	✓	✓	✓	✓			SP1725, SP1726
ROEWE/ei6	Integrated Starter Control Module (ISC)	✓	✓	✓	✓			SP1733
ROEWE/ei6	Shift Control Unit (SCU)	✓	✓	✓	✓			
ROEWE/ei6	Electronic Oil Pump Motor Controller (EOPC)	✓	✓	✓	✓			
ROEWE/ei6	Front camera module (FVCM)	✓	✓	✓	✓			SP1748
ROEWE/ei6	Automatic Parking System/Parking Assist System (APA/PDC)	✓	✓	✓	✓			

## Special Functions List

No.	Functions Name	System Name
SP0000	Reset Steering Wheel Angle Sensor	Roewe 950/Steering wheel angle sensor module (EPS)
SP0001	steering wheel angle sensor learn	Roewe 950/Steering wheel angle sensor module (EPS)
SP0003	fuel trim reset	Roewe 950/Fuel pump control module (FPCM)
SP0004	calibration	Roewe 950/Parking brake control module (PBCM)
SP0005	learning CAN bus configuration	Roewe 950/Parking auxiliary control module (ICAC)
SP0006	HVAC actuator learning	Roewe 950/Remote control heater and air conditioning control module (HVAC)
SP0007	learning CAN bus configuration	Roewe 950/Instrument group (IPK)
SP0008	brake pedal position sensor learn	Roewe 950/Body control module (BCM)
SP0009	Read the LIN bus device ID information	Roewe 950/Body control module (BCM)
SP0013	brake pressure sensor calibration	Roewe 950/Anti-lock brake system (ABS)
SP0014	yaw rate sensor learning	Roewe 950/Anti-lock brake system (ABS)
SP0015	steering wheel angle sensor learn	Roewe 950/Anti-lock brake system (ABS)
SP0016	Inspection/maintenance data	Roewe 950/Engine control module (ECM)
SP0017	Inspection/maintenance system status data	Roewe 950/Engine control module (ECM)
SP0018	adaptive value	Roewe 750/Engine system (EMS)
SP0020	Reset adaptive values	Roewe 750/Automatic gearbox system (AT)
SP0021	Brake bleed program	Roewe 750/Anti-lock brake system (ABS)
SP0022	On-board brake deflation	Roewe 750/Anti-lock brake system (ABS)
SP0023	ABS actuator automatic test	Roewe 750/Anti-lock brake system (ABS)
SP0024	Test ISO valve	Roewe 750/Anti-lock brake system (ABS)
SP0025	Test drain valve	Roewe 750/Anti-lock brake system (ABS)
SP0026	Test control components	Roewe 750/Anti-lock brake system (ABS)
SP0027	Activate/deactivate collision detection	Roewe 750/Airbag system (SRS)
SP0028	Activation airbag	Roewe 750/Airbag system (SRS)
SP0029	Disable airbag	Roewe 750/Airbag system (SRS)
SP0032	anti-lock braking system regulator bleed	Roewe 550/Anti-lock brake system (ABS)
SP0033	Reset adaptive values	Roewe 550/Automatic gearbox system (AT)
SP0034	Set the power mode	Roewe 550/Body control module (BCM)
SP0035	Sunroof initialization (manual method)	Roewe 550/Body control module (BCM)
SP0036	Front headlight test	Roewe 550/Interior lamps and exterior lamps (ELIL)
SP0037	adaptive value	Roewe 750( New )/Automatic gearbox system (AT)
SP0038	Set the power mode	Roewe 350/350S/Body controller (BCM)
SP0039	Sunroof initialization (manual method)	Roewe 350/350S/Body controller (BCM)
SP0040	Set the idle speed offset	Roewe 550/Engine system (EMS)
SP0041	Maintenance interval reset	Roewe 350/350S/Instrument unit (IPK)
SP0044	Calibration ABS/ESP sensor	Roewe W5/Anti-lock brake system (ABS)
SP0045	Clear configuration code	Roewe W5/Anti-lock brake system (ABS)
SP0046	ABS module bleed program	Roewe W5/Anti-lock brake system (ABS)
SP0047	Set the power mode	Roewe W5/Body controller (BCM)
SP0056	Odometer data reading	Roewe 750( New )/Instrument unit (IPK)
SP0057	Maintenance interval reset	Roewe 750( New )/Instrument unit (IPK)
SP0058	Meter self-test	Roewe 750( New )/Instrument unit (IPK)
SP0063	Diesel engine exhaust filter cleaning	Roewe new 550/Engine management system (EMS)
SP0064	start-stop system compulsory test,	Roewe new 550/Engine management system (EMS)
SP0074	matching key	Roewe new 550/Body control module (BCM)
SP0075	Delete the key	Roewe new 550/Body control module (BCM)
SP0076	Remaining unlocking time	Roewe new 550/Body control module (BCM)
SP0077	Power mode	Roewe new 550/Body control module (BCM)
SP0078	Maintenance interval reset	Roewe new 550/Instrument unit (IPK)
SP0079	Apply EPB left brake	Roewe new 550/Electronic parking brake system (EPB)
SP0080	Apply EPB right brakes	Roewe new 550/Electronic parking brake system (EPB)
SP0081	Apply EPB side brakes	Roewe new 550/Electronic parking brake system (EPB)
SP0082	EPB Release left side brake of EPB	Roewe new 550/Electronic parking brake system (EPB)
SP0083	EPB Release right side brake of	Roewe new 550/Electronic parking brake system (EPB)
SP0084	Release both side brakes of	Roewe new 550/Electronic parking brake system (EPB)

SP0085	Height sensor zero voltage self-learning	Roewe new 550/Adaptive large lamp system (AFS)
SP0086	corner auxiliary lighting test,	Roewe new 550/Adaptive large lamp system (AFS)
SP0087	Engine control module self-learning value reset	Roewe New 550 HYBRID /Engine Control Module (ECM)
SP0088	OFF online charging circuit request	Roewe New 550 HYBRID /Battery Management Module (BMS)
SP0089	Close main circuit relay request	Roewe New 550 HYBRID /Battery Management Module (BMS)
SP0090	Power mode	Roewe New 550 HYBRID /Body Control Module (BCM)
SP0091	Apply EPB left brake	Roewe New 550 HYBRID /Electronic Parking Brake System (EPB)
SP0092	Apply EPB right brakes	Roewe New 550 HYBRID /Electronic Parking Brake System (EPB)
SP0093	Apply EPB side brakes	Roewe New 550 HYBRID /Electronic Parking Brake System (EPB)
SP0094	EPB Release left side brake of EPB	Roewe New 550 HYBRID /Electronic Parking Brake System (EPB)
SP0095	EPB Release right side brake of	Roewe New 550 HYBRID /Electronic Parking Brake System (EPB)
SP0096	Release both side brakes of	Roewe New 550 HYBRID /Electronic Parking Brake System (EPB)
SP0097	Maintenance interval reset	Roewe New 550 HYBRID /Instrument unit (IPK)
SP0098	ISC acceleration test	Roewe New 550 HYBRID /Integrated Starter Control Module (ISC)
SP0099	ISC cooling system liquid filling exhaust	Roewe New 550 HYBRID /Integrated Starter Control Module (ISC)
SP0100	HCU self-learning	Roewe New 550 HYBRID /Hydraulic Control Unit (HCU)
SP0101	removal EDU valve assembly	Roewe New 550 HYBRID /Hydraulic Control Unit (HCU)
SP0102	EDU hydraulic system pressure relief	Roewe New 550 HYBRID /Hydraulic Control Unit (HCU)
SP0103	Hybrid system solenoid valve cleaning operation	Roewe New 550 HYBRID /Hydraulic Control Unit (HCU)
SP0104	Entertainment test system speaker	Roewe New 550 HYBRID /In-Car Entertainment System (ICE)
SP0105	Tire pressure monitoring system reset	Roewe New 550 HYBRID /Anti-lock brake system (ABS)
SP0106	External Yaw Sensor Calibration	Roewe New 550 HYBRID /Anti-lock brake system (ABS)
SP0107	Starter start-stop times reset	Roewe 360(1.4T)/Engine system (ECM)
SP0108	Battery ID write	Roewe 360(1.4T)/Engine system (ECM)
SP0109	Engine system adaptive learning value reset	Roewe 360(1.4T)/Engine system (ECM)
SP0110	engine throttle self-learning reset	Roewe 360(1.4T)/Engine system (ECM)
SP0111	Transmission control module quick learning	Roewe 360(1.4T)/Automatic gearbox system (AT)
SP0112	ABS maintenance exhaust	Roewe 360(1.4T)/Anti-lock brake system (ABS)
SP0113	Inertial measurement unit calibration	Roewe 360(1.4T)/Anti-lock brake system (ABS)
SP0114	TPMS reset	Roewe 360(1.4T)/Anti-lock brake system (ABS)
SP0115	yaw sensor learning	Roewe 360(1.4T)/Anti-lock brake system (ABS)
SP0119	Maintenance interval reset	Roewe 360(1.4T)/Instrument unit (IPK)
SP0174	Electric power steering system learning	Roewe 360(1.4T)/Electric power steering system (EPS)
SP0175	Air conditioning servo motor self-learning	Roewe 360(1.4T)/Automatic air conditioning system (AC)
SP0176	Set the system operation mode	Roewe 360(1.4T)/Gateway (GW)
SP0177	Brake pedal position sensor self-learning	Roewe 360(1.4T)/Gateway (GW)
SP0178	steering angle sensor calibration	Roewe 360(1.4T)/Steering wheel corner sensor (SAS)
SP0179	TBOX restart	Roewe 360(1.4T)/Communication module (TBOX)
SP0180	TBOX battery life calibration	Roewe 360(1.4T)/Communication module (TBOX)
SP0181	Starter start-stop times reset	Roewe 360(1.5VCT/1.5T)/Engine system (ECM)
SP0182	Battery ID write	Roewe 360(1.5VCT/1.5T)/Engine system (ECM)
SP0183	Engine system adaptive learning value reset	Roewe 360(1.5VCT/1.5T)/Engine system (ECM)
SP0184	engine throttle self-learning reset	Roewe 360(1.5VCT/1.5T)/Engine system (ECM)
SP0185	Transmission control unit reset learning value	Roewe 360(1.5VCT/1.5T)/Automatic gearbox system (AT)
SP0186	ABS maintenance exhaust	Roewe 360(1.5VCT/1.5T)/Anti-lock brake system (ABS)

SP0187	Inertial measurement unit calibration	Roewe 360(1.5VCT/1.5T)/Anti-lock brake system (ABS)
SP0190	Maintenance interval reset	Roewe 360(1.5VCT/1.5T)/Instrument unit (IPK)
SP0191	Power mode	Roewe 360(1.5VCT/1.5T)/Body controller (BCM)
SP0192	matching key	Roewe 360(1.5VCT/1.5T)/Body controller (BCM)
SP0193	Delete the key	Roewe 360(1.5VCT/1.5T)/Body controller (BCM)
SP0194	Remaining unlocking time	Roewe 360(1.5VCT/1.5T)/Body controller (BCM)
SP0195	Maintenance interval reset	E50/Instrument Unit (IPK)
SP0213	Reset all adaptive learning values	Roewe 350/350S/Engine system (ECM)
SP0218	Reset learning value	Roewe 350/350S/Automatic gearbox (AT)
SP0222	ABS maintenance exhaust	Roewe 350/350S/Anti-lock brake system (ABS)
SP0228	Steering angle sensor calibration	Roewe 350/350S/Corner sensor (SAS)
SP0229	Odometer data reading	Roewe 550/Digital instrument unit (IPK)
SP0230	Maintenance interval reset	Roewe 550/Digital instrument unit (IPK)
SP0403	Set the odometer offset	MG5/Combined instrument system (IPK)
SP0404	Meter self-test	MG5/Combined instrument system (IPK)
SP0405	Maintenance interval reset	MG5/Combined instrument system (IPK)
SP0406	Set the power mode	MG5/Body controller (BCM)
SP0407	Reset adaptive value Reset	MG5/Gearbox control unit (TCU)
SP0408	Set the idle speed offset	MG5/Engine control unit (ECM)
SP0410	Engine control module self-learning value reset	MG3/Engine management system (EMS)
SP0411	Engine control module idle speed bias	MG3/Engine management system (EMS)
SP0412	engine Control module ignition angle offset	MG3/Engine management system (EMS)
SP0413	Diagnose the speed limit	MG3/Anti-lock brake system (ABS)
SP0414	Valve relay	MG3/Anti-lock brake system (ABS)
SP0415	SCU EKA coding	MG3/Body control module (BCM)
SP0416	read the alarm Trigger event	MG3/Body control module (BCM)
SP0417	Brake bleed program	MG7-L/Anti-lock brake system (ABS)
SP0418	ABS actuator automatic test	MG7-L/Anti-lock brake system (ABS)
SP0420	Brake bleed program	MG6/Anti-lock brake system (ABS)
SP0435	matching key	MG5/Anti-theft system (IMMO)
SP0436	Delete the key	MG5/Anti-theft system (IMMO)
SP0446	Maintenance interval reset	MG TF/Combination instrument (IPK)
SP0447	Meter self-test	MG TF/Combination instrument (IPK)
SP0449	Hydraulic regulator exhaust	MG7-2009/Combination instrument (IPK)
SP0450	Calibration	MG7-2009/Steering angle sensor (SAS)
SP0451	Identify the key	MG7-2008/Gateway anti-theft module
SP0452	Brake bleed program	MG7-2009/Dynamic stability control (ESP)
SP0453	ABS actuator automatic test	MG7-2009/Dynamic stability control (ESP)
SP0454	Pump motor	MG7-2009/Dynamic stability control (ESP)
SP0455	Left front intake valve	MG7-2009/Dynamic stability control (ESP)
SP0456	Right front intake valve	MG7-2009/Dynamic stability control (ESP)
SP0457	Left rear intake valve,	MG7-2009/Dynamic stability control (ESP)
SP0458	right rear intake valve,	MG7-2009/Dynamic stability control (ESP)
SP0459	Left front exhaust valve	MG7-2009/Dynamic stability control (ESP)
SP0460	Right front exhaust Valve	MG7-2009/Dynamic stability control (ESP)
SP0461	Left rear exhaust valve	MG7-2009/Dynamic stability control (ESP)
SP0462	Rear right exhaust valve Rear	MG7-2009/Dynamic stability control (ESP)
SP0463	Auto SCS VSC test	MG7-2009/Dynamic stability control (ESP)
SP0464	USV 1	MG7-2009/Dynamic stability control (ESP)
SP0465	USV 2	MG7-2009/Dynamic stability control (ESP)
SP0466	HSV 1	MG7-2009/Dynamic stability control (ESP)
SP0467	HSV 2	MG7-2009/Dynamic stability control (ESP)
SP0485	Diesel engine exhaust filter cleaning	MG6 14 Year /Engine control management (ECM)
SP0486	Start-stop system mandatory test	MG6 14 Year /Engine control management (ECM)
SP0487	Height sensor zero voltage self-learning	MG6 14 Year /Adaptive steering headlight system (AFS)
SP0488	corner auxiliary lighting test,	MG6 14 Year /Adaptive steering headlight system (AFS)
SP0489	Power mode	MG6 14 Year /Body control module (BCM)
SP0490	Release left Side actuator	MG6 14 Year /Electronic parking brake system (EPB)
SP0491	Release right side actuator	MG6 14 Year /Electronic parking brake system (EPB)
SP0492	Enable left side actuator	MG6 14 Year /Electronic parking brake system (EPB)
SP0493	Enable right side actuator	MG6 14 Year /Electronic parking brake system (EPB)
SP0494	Enable both side actuators	MG6 14 Year /Electronic parking brake system (EPB)



SP0495	Release both side actuators	MG6 14 Year /Electronic parking brake system (EPB)
SP0496	Parking brake system actuator parts replacement	MG6 14 Year /Electronic parking brake system (EPB)
SP0497	acceleration sensor calibration	MG6 14 Year /Electronic parking brake system (EPB)
SP0498	External Yaw Sensor Calibration	MG6 14 Year /Dynamic stabilization control system (SCS/ABS)
SP0499	Indirect tire pressure monitoring system reset	MG6 14 Year /Dynamic stabilization control system (SCS/ABS)
SP0500	Refilling exhaust	MG6 14 Year /Dynamic stabilization control system (SCS/ABS)
SP0501	Adaptive learning value reset	MG6 14 Year /Automatic gearbox system (AT)
SP0502	Automatic transmission control unit quick learning	MG6 14 Year /Automatic gearbox system (AT)
SP0503	Read the SubRom data	MG6 14 Year /Automatic gearbox system (AT)
SP0504	Automatic transmission sensor test	MG6 14 Year /Automatic gearbox system (AT)
SP0505	wheel angle sensor to zero learn	MG6 14 Year /Steering wheel corner sensor (SAS)
SP0506	the steering angle sensor offset learning	MG6 14 Year /Steering wheel corner sensor (SAS)
SP0507	Engine control module self-learning value reset	MG6 13 Year /Engine control management (ECM)
SP0508	Engine module idle bias	MG6 13 Year /Engine control management (ECM)
SP0509	Battery ID write	MG6 13 Year /Engine control management (ECM)
SP0510	Power mode	MG6 13 Year /Body control module (BCM)
SP0511	Maintenance interval reset	MG6 13 Year /Instrument unit (IPK)
SP0512	Indirect tire pressure monitoring system reset	MG6 13 Year /Dynamic stabilization control system (SCS/ABS)
SP0513	AX sensor calibration	MG6 13 Year /Dynamic stabilization control system (SCS/ABS)
SP0517	Automatic transmission control unit self-learning	MG6 13 Year /Automatic gearbox system (AT)
SP0518	Automatic transmission control unit self-adaptive learning value reset	MG6 13 Year /Automatic gearbox system (AT)
SP0519	Read the SubROM data	MG6 13 Year /Automatic gearbox system (AT)
SP0520	Automatic transmission sensor test	MG6 13 Year /Automatic gearbox system (AT)
SP0521	Parking brake system actuator parts replacement	MG6 13 Year /Electronic parking brake system (EPB)
SP0522	acceleration sensor calibration	MG6 13 Year /Electronic parking brake system (EPB)
SP0523	Release both side actuators	MG6 13 Year /Electronic parking brake system (EPB)
SP0524	Enable left side actuator	MG6 13 Year /Electronic parking brake system (EPB)
SP0525	Enable right side actuator	MG6 13 Year /Electronic parking brake system (EPB)
SP0526	Release left Side actuator	MG6 13 Year /Electronic parking brake system (EPB)
SP0527	Release right side actuator	MG6 13 Year /Electronic parking brake system (EPB)
SP0528	Enable both side actuators	MG6 13 Year /Electronic parking brake system (EPB)
SP0536	Diesel engine exhaust filter cleaning	MG6 Eu Diesel( Diesel )/Engine control management (ECM)
SP0537	Start-stop system mandatory test	MG6 Eu Diesel( Diesel )/Engine control management (ECM)
SP0543	Maintenance mileage reset	MG GS( Rui Teng )/Combination instrument (IPK)
SP0544	Body control module operation mode adjustment	MG GS( Rui Teng )/Body control module (BCM)
SP0545	Air conditioning servo motor self-learning	MG GS( Rui Teng )/Air conditioning module (HVAC)
SP0548	Battery ID write	MG GT( Sharp ) (1.5L)/Engine management system (EMS)
SP0549	Starter start-stop times reset	MG GT( Sharp ) (1.5L)/Engine management system (EMS)
SP0550	Engine system adaptive learning value reset	MG GT( Sharp ) (1.5L)/Engine management system (EMS)
SP0551	engine throttle self-learning reset	MG GT( Sharp ) (1.5L)/Engine management system (EMS)
SP0552	Transmission control unit reset learning value	MG GT( Sharp ) (1.5L)/Automatic wave box system (AT)
SP0555	TPMS reset	MG GT( Sharp ) (1.5L)/Anti-lock brake system (ABS)



SP0556	ABS maintenance exhaust	MG GT( Sharp )(1.5L)/Anti-lock brake system (ABS)
SP0559	Power mode	MG GT( Sharp )(1.5L)/Body control module (BCM)
SP0560	Electric power steering system learning	MG GT( Sharp )(1.5L)/Electric power steering system (EPS)
SP0561	steering angle sensor calibration	MG GT( Sharp )(1.5L)/Steering angle sensor module (SAS)
SP0562	TBOX restart	MG GT( Sharp )(1.5L)/Car wiring box (TBOX)
SP0563	TBOX battery life calibration	MG GT( Sharp )(1.5L)/Car wiring box (TBOX)
SP0564	TBOX activation	MG GT( Sharp )(1.5L)/Car wiring box (TBOX)
SP0568	Battery ID write	MG GT( Sharp )(1.4T)/Engine management system (EMS)
SP0569	Starter start-stop times reset	MG GT( Sharp )(1.4T)/Engine management system (EMS)
SP0570	Engine system adaptive learning value reset	MG GT( Sharp )(1.4T)/Engine management system (EMS)
SP0571	engine throttle self-learning reset	MG GT( Sharp )(1.4T)/Engine management system (EMS)
SP0572	Transmission control module quick learning	MG GT( Sharp )(1.4T)/Automatic wave box system (AT)
SP0573	TPMS reset	MG GT( Sharp )(1.4T)/Anti-lock brake system (ABS)
SP0574	ABS maintenance exhaust	MG GT( Sharp )(1.4T)/Anti-lock brake system (ABS)
SP0577	Power mode	MG GT( Sharp )(1.4T)/Body control module (BCM)
SP0578	Meter self-test	MG GT( Sharp )(1.4T)/Instrument unit (IPK)
SP0579	Air conditioning servo motor self-learning	MG GT( Sharp )(1.4T)/Automatic air conditioning system (ATC)
SP0580	Set the system operation mode	MG GT( Sharp )(1.4T)/Gateway (GW)
SP0581	Brake pedal position sensor self-learning	MG GT( Sharp )(1.4T)/Gateway (GW)
SP0582	steering angle sensor calibration	MG GT( Sharp )(1.4T)/Steering angle sensor module (SAS)
SP0583	TBOX restart	MG GT( Sharp )(1.4T)/Car wiring box (TBOX)
SP0584	TBOX battery life calibration	MG GT( Sharp )(1.4T)/Car wiring box (TBOX)
SP0633	ECM (engine control module), adaptive reset	NEW MG GS/Engine control module (ECM)
SP0635	Maintenance interval reset	NEW MG GS/Instrument unit (IPK)
SP0636	Reset EEPROM	NEW MG GS/Wave box control module (TCM)
SP0637	Read the subROM	NEW MG GS/Wave box control module (TCM)
SP0638	Transmission sensor test	NEW MG GS/Wave box control module (TCM)
SP0639	Transmission self-learning	NEW MG GS/Wave box control module (TCM)
SP0640	Shift Fork Position Self-learning	NEW MG GS/Wave box control module (TCM)
SP0641	Clutch kiss point self-learning	NEW MG GS/Wave box control module (TCM)
SP0642	current mapping curve, clutch pressure self-learning,	NEW MG GS/Wave box control module (TCM)
SP0650	GW brake sensor zero point learning	NEW MG GS/Gateway (GW)
SP0651	GW setting power mode	NEW MG GS/Gateway (GW)
SP0652	TCCM on-demand self-test	NEW MG GS/Sub-box control module (TCCM)
SP0653	EPS (electric power steering) calibration	NEW MG GS/Electric power steering system (EPS)
SP0654	ABS (Anti-lock Braking System)/SCS (Vehicle Stability Control System) Brake bleed	NEW MG GS/Dynamic stabilization control system / Car anti-lock brake system (SCS/ABS)
SP0655	SCS pressure Sensor calibration	NEW MG GS/Dynamic stabilization control system / Car anti-lock brake system (SCS/ABS)
SP0656	a yaw sensor Calibration	NEW MG GS/Dynamic stabilization control system / Car anti-lock brake system (SCS/ABS)
SP0657	EPB (electronic parking brake) brake line adjustment	NEW MG GS/Electronic parking brake system (EPB)
SP0658	EPB (electronic parking brake) brake line fully released	NEW MG GS/Electronic parking brake system (EPB)
SP0659	ATC motor calibration	NEW MG GS/Air conditioning control module (HVAC)
SP0660	PEPS setting power mode	NEW MG GS/Keyless entry module (PEPS)
SP0661	BCM (body control module) power mode	NEW MG GS/Body control module (BCM)
SP0662	TBOX battery calibration	NEW MG GS/Communication module (TBOX)
SP0663	TBOX Bluetooth OTA lock on	NEW MG GS/Communication module (TBOX)
SP0664	TPMS (tire pressure monitoring system) learning	NEW MG GS/Tire pressure monitoring system (TPMS)
SP0711	GW setting power mode	MG3 ZERO(MCE3)/Gateway (GW)
SP0712	Forward camera module self-learning	Ei6 MAX/Front camera module (FVCM)
SP0752	TBOX restart	Roewe 360(1.5VCT/1.5T)/Communication module (TBOX)
SP0768	Electric power steering system learning	Roewe 360(1.5VCT/1.5T)/Electric power steering system (EPS)

SP0769	wheel angle sensor to zero learn	Roewe 360(1.5VCT/1.5T)/Steering wheel corner sensor (SAS)
SP0770	the steering angle sensor offset learning	Roewe 360(1.5VCT/1.5T)/Steering wheel corner sensor (SAS)
SP0796	TBOX restart	i5/Communication module (T-BOX)
SP0797	OTA Bluetooth lock open	i5/Communication module (T-BOX)
SP0798	OTA Bluetooth lock open	i5/Security Bluetooth module (SBTM)
SP0799	Body control module operation mode adjustment	i5/Body control module (BCM)
SP0800	Battery ID write	i5/Body control module (BCM)
SP0801	brake pedal position sensor zero eLearning	i5/Body control module (BCM)
SP0802	tire sensor self-learning,	i5/Body control module (BCM)
SP0803	Maintenance mileage reset	i5/Instrument module (IPK)
SP0804	engine throttle self-learning reset	i5/Engine management system (EMS)
SP0805	Engine control module self-learning value reset	i5/Engine management system (EMS)
SP0812	Forward camera module self-learning	i5/Front camera module (FVCM)
SP0813	parking brake system parts replacement	i5/Anti-lock brake system / Dynamic stability control (ABS/SCS)
SP0814	Pressure sensor learning	i5/Anti-lock brake system / Dynamic stability control (ABS/SCS)
SP0815	yaw sensor learning	i5/Anti-lock brake system / Dynamic stability control (ABS/SCS)
SP0816	ABS Add liquid exhaust	i5/Anti-lock brake system / Dynamic stability control (ABS/SCS)
SP0817	Release left Side actuator	i5/Anti-lock brake system / Dynamic stability control (ABS/SCS)
SP0818	Release right side actuator	i5/Anti-lock brake system / Dynamic stability control (ABS/SCS)
SP0819	Enable left side actuator	i5/Anti-lock brake system / Dynamic stability control (ABS/SCS)
SP0820	Enable right side actuator	i5/Anti-lock brake system / Dynamic stability control (ABS/SCS)
SP0821	Enable both side actuators	i5/Anti-lock brake system / Dynamic stability control (ABS/SCS)
SP0822	Release both side actuators	i5/Anti-lock brake system / Dynamic stability control (ABS/SCS)
SP0823	tire sensor self-learning,	i5/Tire pressure monitoring system (TPMS)
SP0826	Electric power steering system learning	i5/Electronic power steering system (EPS)
SP0827	Air conditioning damper actuator self-learning	i5/Air conditioner controller (HVAC)
SP0828	Body control module operation mode adjustment	i5 2020 Pay 1.5L/Body control module (BCM)
SP0829	tire sensor self-learning,	i5 2020 Pay 1.5L/Body control module (BCM)
SP0830	Maintenance mileage reset	i5 2020 Pay 1.5L/Combination instrument (IPK)
SP0835	Forward camera module self-learning	i5 2020 Pay 1.5L/Front camera module (FVCM)
SP0837	Electric power steering system learning	i5 2020 Pay 1.5L/Electronic steering power system (EPS)
SP0838	Air conditioning servo motor self-learning	i5 2020 Pay 1.5L/Air conditioning control module (HVAC)
SP0839	GW setting power mode	i5 2020 Pay 1.5T/Gateway module (GW)
SP0840	Battery ID write	i5 2020 Pay 1.5T/Gateway module (GW)
SP0846	Electric power steering system learning	i5 2020 Pay 1.5T/Electronic steering power system (EPS)
SP0848	Forward camera module self-learning	i5 2020 Pay 1.5T/Front camera module (FVCM)
SP0849	Air conditioning servo motor self-learning	i5 2020 Pay 1.5T/Air conditioning control module (HVAC)
SP0850	Body control module operation mode adjustment	i5 2020 Pay 1.5T/Body control module (BCM)
SP0851	tire sensor self-learning,	i5 2020 Pay 1.5T/Body control module (BCM)
SP0852	Maintenance mileage reset	i5 2020 Pay 1.5T/Combination instrument (IPK)
SP0854	Power mode adjustment	MG GS( Rui Teng )/Keyless entry and key launch module (PEPS)
SP0857	GW setting power mode	MG GS( Rui Teng )/Gateway module (GW)
SP0858	Gateway brake sensor zero learning	MG GS( Rui Teng )/Gateway module (GW)
SP0861	Automatic transmission self-learning	MG GS( Rui Teng )/Gearbox control module (TCM)
SP0862	Adaptive learning value reset	MG GS( Rui Teng )/Gearbox control module (TCM)
SP0863	Read the SubROM data	MG GS( Rui Teng )/Gearbox control module (TCM)
SP0864	Transmission sensor test sensor self-detection	MG GS( Rui Teng )/Gearbox control module (TCM)
SP0866	Four-wheel drive Control module self-test	MG GS( Rui Teng )/Four-wheel control module (TCCM)
SP0867	TBOX battery life calibration	MG GS( Rui Teng )/Communication module (TBOX)
SP0868	TBOX restart	MG GS( Rui Teng )/Communication module (TBOX)
SP0872	Pressure sensor learning	MG GS( Rui Teng )/Anti-lock brake system / Dynamic stability control (SCS/ABS)

SP0873	Indirect tire pressure system reset	MG GS( Rui Teng )/Anti-lock brake system / Dynamic stability control (SCS/ABS)
SP0874	yaw sensor learning	MG GS( Rui Teng )/Anti-lock brake system / Dynamic stability control (SCS/ABS)
SP0875	ABS Add liquid exhaust	MG GS( Rui Teng )/Anti-lock brake system / Dynamic stability control (SCS/ABS)
SP0878	Electric power steering system learning	MG GS( Rui Teng )/Electronic steering power system (EPS)
SP0879	wheel angle sensor to zero learn	MG GS( Rui Teng )/Corner sensor (SAS)
SP0880	the steering angle sensor offset learning	MG GS( Rui Teng )/Corner sensor (SAS)
SP0881	parking brake cable Adjustment of the parking brake cable	MG GS( Rui Teng )/Electronic hand brake module (EPB)
SP0882	Full release of the	MG GS( Rui Teng )/Electronic hand brake module (EPB)
SP0883	Electronic parking tension test	MG GS( Rui Teng )/Electronic hand brake module (EPB)
SP0884	Electronic parking release test	MG GS( Rui Teng )/Electronic hand brake module (EPB)
SP0885	DHL height sensor zero voltage self-learning	MG GS( Rui Teng )/Dynamic headlight level adjustment (AFS)
SP0909	TBOX restart	MG GS( Rui Teng )( Rui Teng Plus)/Communication module (T-BOX)
SP0910	OTA Bluetooth lock open	MG GS( Rui Teng )( Rui Teng Plus)/Communication module (T-BOX)
SP0911	GW setting power mode	MG GS( Rui Teng )( Rui Teng Plus)/Gateway module (GW)
SP0912	Gateway brake sensor zero learning	MG GS( Rui Teng )( Rui Teng Plus)/Gateway module (GW)
SP0913	Engine control module self-learning value reset	MG GS( Rui Teng )( Rui Teng Plus)/Engine control module (ECM)
SP0915	Automatic transmission self-learning	MG GS( Rui Teng )( Rui Teng Plus)/Gearbox control module (TCM)
SP0916	Adaptive learning value reset	MG GS( Rui Teng )( Rui Teng Plus)/Gearbox control module (TCM)
SP0917	Read the SubROM data	MG GS( Rui Teng )( Rui Teng Plus)/Gearbox control module (TCM)
SP0918	Transmission sensor test sensor self-detection	MG GS( Rui Teng )( Rui Teng Plus)/Gearbox control module (TCM)
SP0920	Four-wheel drive Control module self-test	MG GS( Rui Teng )( Rui Teng Plus)/Four-wheel control module (TCCM)
SP0921	Pressure sensor learning	MG GS( Rui Teng )( Rui Teng Plus)/Anti-lock brake system / Dynamic stability control (SCS/ABS)
SP0922	yaw sensor learning	MG GS( Rui Teng )( Rui Teng Plus)/Anti-lock brake system / Dynamic stability control (SCS/ABS)
SP0923	ABS Add liquid exhaust	MG GS( Rui Teng )( Rui Teng Plus)/Anti-lock brake system / Dynamic stability control (SCS/ABS)
SP0924	Electric power steering system learning	MG GS( Rui Teng )( Rui Teng Plus)/Electronic steering power system (EPS)
SP0925	parking brake cable Adjustment of the parking brake cable	MG GS( Rui Teng )( Rui Teng Plus)/Electronic hand brake module (EPB)
SP0926	Full release of the	MG GS( Rui Teng )( Rui Teng Plus)/Electronic hand brake module (EPB)
SP0927	Electronic parking tension test	MG GS( Rui Teng )( Rui Teng Plus)/Electronic hand brake module (EPB)
SP0928	Electronic parking release test	MG GS( Rui Teng )( Rui Teng Plus)/Electronic hand brake module (EPB)
SP0929	Body control module operation mode adjustment	MG GS( Rui Teng )( Rui Teng Plus)/Body control module (BCM)
SP0930	tire sensor self-learning,	MG GS( Rui Teng )( Rui Teng Plus)/Tire pressure monitoring system (TPMS)
SP0931	Air conditioning servo motor self-learning	MG GS( Rui Teng )( Rui Teng Plus)/Air conditioning module (HVAC)
SP0932	Power mode adjustment	MG GS( Rui Teng )( Rui Teng Plus)/Keyless entry and key launch module (PEPS)
SP0933	Maintenance mileage reset	MG GS( Rui Teng )( Rui Teng Plus)/Combination instrument (IPK)
SP0934	TBOX restart	RX5/Car wiring box (TBOX)
SP0935	OTA Bluetooth lock open	RX5/Car wiring box (TBOX)

SP0936	TBOX refresh port on	RX5/Car wiring box (TBOX)
SP0937	GW setting power mode	RX5/Gateway (GW)
SP0938	Gateway brake sensor zero learning	RX5/Gateway (GW)
SP0939	Brake pedal position sensor self-learning	RX5/Engine management system (EMS)
SP0942	Automatic transmission self-learning	RX5/Wave box control module (TCM)
SP0943	Adaptive learning value reset	RX5/Wave box control module (TCM)
SP0944	Read the SubROM data	RX5/Wave box control module (TCM)
SP0945	Transmission sensor test sensor self-detection	RX5/Wave box control module (TCM)
SP0948	Four-wheel drive Control module self-test	RX5/Sub-box control module (TCCM)
SP0949	Pressure sensor learning	RX5/Ignition control system / Car anti-lock brake system (SCS/ABS)
SP0950	yaw sensor learning	RX5/Ignition control system / Car anti-lock brake system (SCS/ABS)
SP0951	Indirect tire pressure system reset	RX5/Ignition control system / Car anti-lock brake system (SCS/ABS)
SP0952	ABS Add liquid exhaust	RX5/Ignition control system / Car anti-lock brake system (SCS/ABS)
SP0955	Electric power steering system learning	RX5/Electric power steering (EPS)
SP0956	parking brake cable Adjustment of the parking brake cable	RX5/Electronic parking brake system (EPB)
SP0957	Full release of the	RX5/Electronic parking brake system (EPB)
SP0958	Electronic parking tension test	RX5/Electronic parking brake system (EPB)
SP0959	Electronic parking release test	RX5/Electronic parking brake system (EPB)
SP0960	Forward camera module self-learning	RX5/Forward camera module (FVCM)
SP0961	wheel angle sensor to zero learn	RX5/Steering angle sensor module (SAS)
SP0962	the steering angle sensor offset learning	RX5/Steering angle sensor module (SAS)
SP0963	DHL height sensor zero voltage self-learning	RX5/Adaptive large lamp (DHL)
SP0964	Forward detection radar driving calibration	RX5/Forward detection radar module (FDR)
SP0965	of the forward detection radar Query the self-learning result of the forward detection radar driving calibration	RX5/Forward detection radar module (FDR)
SP0966	Body control module operation mode adjustment	RX5/Body control module (BCM)
SP0967	Electric tailgate self-learning	RX5/Electric tail door control module (PLCM)
SP0968	Power mode adjustment	RX5/Keyless entry module (PEPS)
SP0969	Air conditioning servo motor self-learning	RX5/Air conditioning control module (ATC)
SP0970	Maintenance mileage reset	RX5/Instrument system (IPK)
SP0971	tire sensor self-learning,	RX5/Tire pressure monitoring system (TPMS)
SP0972	TBOX restart	RX5 Plus/Car wiring box(T-BOX)
SP0973	OTA Bluetooth lock open	RX5 Plus/Car wiring box(T-BOX)
SP0974	GW setting power mode	RX5 Plus/Gateway(GW)
SP0978	Transmission control module quick learning	RX5 Plus/Gearbox control module(TCM)
SP0979	SCU executes gear self-learning	RX5 Plus/Start control unit(SCU)
SP0980	SCU clears gear learning value	RX5 Plus/Start control unit(SCU)
SP0981	Pressure sensor learning	RX5 Plus/Anti-lock brake system / Dynamic stability control (SCS/ABS)
SP0982	yaw sensor learning	RX5 Plus/Anti-lock brake system / Dynamic stability control (SCS/ABS)
SP0983	Indirect tire pressure system reset	RX5 Plus/Anti-lock brake system / Dynamic stability control (SCS/ABS)
SP0984	ABS Add liquid exhaust	RX5 Plus/Anti-lock brake system / Dynamic stability control (SCS/ABS)
SP0987	Electric power steering system learning	RX5 Plus/Electric power steering (EPS)
SP0988	parking brake cable Adjustment of the parking brake cable	RX5 Plus/Electronic parking brake system (EPB)
SP0989	Full release of the	RX5 Plus/Electronic parking brake system (EPB)
SP0990	Electronic parking tension test	RX5 Plus/Electronic parking brake system (EPB)
SP0991	Electronic parking release test	RX5 Plus/Electronic parking brake system (EPB)
SP0992	Forward camera module self-learning	RX5 Plus/Forward camera module (FVCM)
SP0995	Body control module operation mode adjustment	RX5 Plus/Body control module (BCM)
SP0996	Power mode adjustment	RX5 Plus/Keyless entry module (PEPS)
SP0997	Air conditioning servo motor self-learning	RX5 Plus/Air conditioning module (HVAC)
SP0998	Maintenance mileage reset	RX5 Plus/Instrument system (IPK)
SP1000	tire sensor self-learning,	RX5 Plus/Tire pressure monitoring system (TPMS)
SP1001	TBOX restart	MG HS/Communication module (TBOX)
SP1002	OTA Bluetooth lock open	MG HS/Communication module (TBOX)
SP1003	GW setting power mode	MG HS/Gateway system (GW)
SP1004	Gateway brake sensor zero learning	MG HS/Gateway system (GW)
SP1005	Battery ID write	MG HS/Gateway system (GW)
SP1006	Engine control module self-learning value reset	MG HS/Engine control management (ECM)
SP1022	Automatic transmission self-learning	MG HS/Transmission control module (TCM)
SP1023	Adaptive learning value reset	MG HS/Transmission control module (TCM)
SP1024	Read the SubROM data	MG HS/Transmission control module (TCM)
SP1025	Transmission sensor test sensor self-detection	MG HS/Transmission control module (TCM)
SP1028	Four-wheel drive Control module self-test	MG HS/Four-wheel control module (TCCM)

SP1031	yaw sensor learning	MG HS/Anti-lock brake system / Dynamic stability control (SCS/ABS)
SP1032	ABS Add liquid exhaust	MG HS/Anti-lock brake system / Dynamic stability control (SCS/ABS)
SP1042	parking brake cable Adjustment of the parking brake cable	MG HS/Electronic hand brake module (EPB)
SP1043	Full release of the	MG HS/Electronic hand brake module (EPB)
SP1044	Electronic parking tension test	MG HS/Electronic hand brake module (EPB)
SP1045	Electronic parking release test	MG HS/Electronic hand brake module (EPB)
SP1046	Electric power steering system learning	MG HS/Electronic steering power system (EPS)
SP1047	Forward camera module self-learning	MG HS/Front camera module (FVCM)
SP1048	Body control module operation mode adjustment	MG HS/Body control module (BCM)
SP1049	Power mode adjustment	MG HS/Keyless entry and start system (PEPS)
SP1050	Air conditioning servo motor self-learning	MG HS/Air conditioning control module (HVAC)
SP1051	Maintenance mileage reset	MG HS/Instrument module (IPK)
SP1054	tire sensor self-learning,	MG HS/Tire pressure monitoring system (TPMS)
SP1055	TBOX restart	MG EHS/Communication module (T-BOX)
SP1056	OTA Bluetooth lock open	MG EHS/Communication module (T-BOX)
SP1057	GW setting power mode	MG EHS/Gateway (GW)
SP1058	Gateway battery ID writing	MG EHS/Gateway (GW)
SP1059	Engine control module self-learning value reset	MG EHS/Engine management system (ECM)
SP1068	Clutch parameter self-learning	MG EHS/Hybrid control unit (HCU)
SP1069	Transmission gear selection reference point self-learning	MG EHS/Hybrid control unit (HCU)
SP1070	Transmission parameter self-learning	MG EHS/Hybrid control unit (HCU)
SP1071	Fast adaptive (manual method)	MG EHS/Hybrid control unit (HCU)
SP1072	Clear transmission parameters	MG EHS/Hybrid control unit (HCU)
SP1073	Clear clutch parameters	MG EHS/Hybrid control unit (HCU)
SP1074	Clear shift execution structure parameters	MG EHS/Hybrid control unit (HCU)
SP1075	Drive motor angle self-learning	MG EHS/Integrated starter control module (ISC)
SP1076	Electric drive transmission coolant exhausting	MG EHS/Integrated starter control module (ISC)
SP1077	parking brake system parts replacement	MG EHS/Dynamic stabilization control system (SCS/ABS)
SP1078	yaw sensor learning	MG EHS/Dynamic stabilization control system (SCS/ABS)
SP1079	ABS Add liquid exhaust	MG EHS/Dynamic stabilization control system (SCS/ABS)
SP1080	Release left Side actuator	MG EHS/Dynamic stabilization control system (SCS/ABS)
SP1081	Release right side actuator	MG EHS/Dynamic stabilization control system (SCS/ABS)
SP1082	Enable left side actuator	MG EHS/Dynamic stabilization control system (SCS/ABS)
SP1083	Enable right side actuator	MG EHS/Dynamic stabilization control system (SCS/ABS)
SP1084	Enable both side actuators	MG EHS/Dynamic stabilization control system (SCS/ABS)
SP1085	Release both side actuators	MG EHS/Dynamic stabilization control system (SCS/ABS)
SP1086	Electric power steering system learning	MG EHS/Electronic steering power system (EPS)
SP1087	Forward camera module self-learning	MG EHS/Front camera module (FVCM)
SP1088	Body control module operation mode adjustment	MG EHS/Body control module (BCM)
SP1089	Power mode adjustment	MG EHS/Keyless entry and key launch module (PEPS)
SP1090	Air conditioning servo motor self-learning	MG EHS/Air conditioning system ( Warm air , Ventilation and air conditioning ) (HVAC)
SP1091	tire sensor self-learning,	MG EHS/Tire pressure monitoring system (TPMS)
SP1092	TBOX restart	AS23PUK/Communication module (T-BOX)
SP1093	OTA Bluetooth lock open	AS23PUK/Communication module (T-BOX)
SP1094	GW setting power mode	AS23PUK/Gateway (GW)
SP1095	Gateway battery ID writing	AS23PUK/Gateway (GW)
SP1096	Engine control module self-learning value reset	AS23PUK/Engine management system (ECM)
SP1105	Clutch parameter self-learning	AS23PUK/Hybrid control unit (HCU)
SP1106	Transmission gear selection reference point self-learning	AS23PUK/Hybrid control unit (HCU)
SP1107	Transmission parameter self-learning	AS23PUK/Hybrid control unit (HCU)
SP1108	Fast adaptive (manual method)	AS23PUK/Hybrid control unit (HCU)
SP1109	Clear transmission parameters	AS23PUK/Hybrid control unit (HCU)
SP1110	Clear clutch parameters	AS23PUK/Hybrid control unit (HCU)
SP1111	Clear shift execution structure parameters	AS23PUK/Hybrid control unit (HCU)
SP1112	Drive motor angle self-learning	AS23PUK/Integrated starter control module (ISC)



SP1113	Electric drive transmission coolant exhausting	AS23PUK/Integrated starter control module (ISC)
SP1114	parking brake system parts replacement	AS23PUK/Dynamic stabilization control system (SCS/ABS)
SP1115	yaw sensor learning	AS23PUK/Dynamic stabilization control system (SCS/ABS)
SP1116	ABS Add liquid exhaust	AS23PUK/Dynamic stabilization control system (SCS/ABS)
SP1117	Release left Side actuator	AS23PUK/Dynamic stabilization control system (SCS/ABS)
SP1118	Release right side actuator	AS23PUK/Dynamic stabilization control system (SCS/ABS)
SP1119	Enable left side actuator	AS23PUK/Dynamic stabilization control system (SCS/ABS)
SP1120	Enable right side actuator	AS23PUK/Dynamic stabilization control system (SCS/ABS)
SP1121	Enable both side actuators	AS23PUK/Dynamic stabilization control system (SCS/ABS)
SP1122	Release both side actuators	AS23PUK/Dynamic stabilization control system (SCS/ABS)
SP1123	Electric power steering system learning	AS23PUK/Electronic steering power system (EPS)
SP1124	Forward camera module self-learning	AS23PUK/Front camera module (FVCM)
SP1125	Forward detection radar driving calibration	AS23PUK/Forward detection radar module (FDR)
SP1126	of the forward detection radar Query the self-learning result of the forward detection radar driving calibration	AS23PUK/Forward detection radar module (FDR)
SP1127	Body control module operation mode adjustment	AS23PUK/Body control module (BCM)
SP1128	Power mode adjustment	AS23PUK/Keyless entry and key launch module (PEPS)
SP1129	Air conditioning servo motor self-learning	AS23PUK/Air conditioning system ( Warm air , Ventilation and air conditioning ) (HVAC)
SP1130	Maintenance mileage reset	AS23PUK/Combination instrument (IPK)
SP1131	tire sensor self-learning,	AS23PUK/Tire pressure monitoring system (TPMS)
SP1132	360 panoramic image control module self-learning	AS23PUK/360 Panoramic image control module (AVM)
SP1133	TBOX restart	MG HS TT/Communication module (T-BOX)
SP1134	GW setting power mode	MG HS TT/Gateway (GW)
SP1135	Gateway brake sensor zero learning	MG HS TT/Gateway (GW)
SP1136	Battery ID write	MG HS TT/Gateway (GW)
SP1137	Engine control module self-learning value reset	MG HS TT/Engine management system (ECM)
SP1138	Engine start-stop times reset	MG HS TT/Engine management system (ECM)
SP1139	engine throttle self-learning reset	MG HS TT/Engine management system (ECM)
SP1141	parking brake system parts replacement	MG HS TT/Dynamic stabilization control system (SCS/ABS)
SP1142	yaw sensor learning	MG HS TT/Dynamic stabilization control system (SCS/ABS)
SP1143	ABS Add liquid exhaust	MG HS TT/Dynamic stabilization control system (SCS/ABS)
SP1144	Release left Side actuator	MG HS TT/Dynamic stabilization control system (SCS/ABS)
SP1145	Release right side actuator	MG HS TT/Dynamic stabilization control system (SCS/ABS)
SP1146	Enable left side actuator	MG HS TT/Dynamic stabilization control system (SCS/ABS)
SP1147	Enable right side actuator	MG HS TT/Dynamic stabilization control system (SCS/ABS)
SP1148	Enable both side actuators	MG HS TT/Dynamic stabilization control system (SCS/ABS)
SP1149	Forward detection radar driving calibration	MG HS TT/Radar module (FDR)
SP1150	of the forward detection radar Query the self-learning result of the forward detection radar driving calibration	MG HS TT/Radar module (FDR)
SP1151	Electric power steering system learning	MG HS TT/Electronic steering power system (EPS)
SP1152	Forward camera module self-learning	MG HS TT/Front camera module (FVCM)
SP1153	Body control module operation mode adjustment	MG HS TT/Body control module (BCM)
SP1154	Power mode adjustment	MG HS TT/Keyless entry and key launch module (PEPS)
SP1155	Air conditioning servo motor self-learning	MG HS TT/Air conditioning system ( Warm air , Ventilation and air conditioning ) (HVAC)
SP1156	Maintenance mileage reset	MG HS TT/Combination instrument (IPK)
SP1159	tire sensor self-learning,	MG HS TT/Tire pressure monitoring system (TPMS)



SP1160	GW setting power mode	MG HS UK/Gateway (GW)
SP1161	Gateway brake sensor zero learning	MG HS UK/Gateway (GW)
SP1162	Battery ID write	MG HS UK/Gateway (GW)
SP1163	Engine control module self-learning value reset	MG HS UK/Engine management system (ECM)
SP1174	Transmission control module quick learning	MG HS UK/Gearbox control module (TCM)
SP1181	parking brake system parts replacement	MG HS UK/Dynamic stabilization control system (SCS/ABS)
SP1182	yaw sensor learning	MG HS UK/Dynamic stabilization control system (SCS/ABS)
SP1183	ABS Add liquid exhaust	MG HS UK/Dynamic stabilization control system (SCS/ABS)
SP1184	Release left Side actuator	MG HS UK/Dynamic stabilization control system (SCS/ABS)
SP1185	Release right side actuator	MG HS UK/Dynamic stabilization control system (SCS/ABS)
SP1186	Enable left side actuator	MG HS UK/Dynamic stabilization control system (SCS/ABS)
SP1187	Enable right side actuator	MG HS UK/Dynamic stabilization control system (SCS/ABS)
SP1188	Enable both side actuators	MG HS UK/Dynamic stabilization control system (SCS/ABS)
SP1189	Release both side actuators	MG HS UK/Dynamic stabilization control system (SCS/ABS)
SP1190	Electric power steering system learning	MG HS UK/Electronic steering power system (EPS)
SP1191	Forward camera module self-learning	MG HS UK/Front camera module (FVCM)
SP1192	Forward detection radar driving calibration	MG HS UK/Radar module (FDR)
SP1193	of the forward detection radar Query the self-learning result of the forward detection radar driving calibration	MG HS UK/Radar module (FDR)
SP1194	Power mode adjustment	MG HS UK/Keyless entry and key launch module (PEPS)
SP1195	Air conditioning servo motor self-learning	MG HS UK/Air conditioning system ( Warm air , Ventilation and air conditioning ) (HVAC)
SP1196	Maintenance mileage reset	MG HS UK/Combination instrument (IPK)
SP1198	tire sensor self-learning,	MG HS UK/Tire pressure monitoring system (TPMS)
SP1199	TBOX restart	eRX5/Car Junction Box (TBOX)
SP1200	TBOX Bluetooth OTA lock on	eRX5/Car Junction Box (TBOX)
SP1201	Gateway brake sensor zero learning	eRX5/Gateway (GW)
SP1202	Battery ID write	eRX5/Gateway (GW)
SP1203	Engine control module self-learning value reset	eRX5/Engine Control Module (ECM)
SP1205	HCU synchronizer position learning	eRX5/Hybrid Control Unit (HCU)
SP1206	HCU clutch engagement point self-learning	eRX5/Hybrid Control Unit (HCU)
SP1207	Hybrid system solenoid valve cleaning operation	eRX5/Hybrid Control Unit (HCU)
SP1208	removal EDU valve assembly	eRX5/Hybrid Control Unit (HCU)
SP1209	EDU hydraulic system pressure relief	eRX5/Hybrid Control Unit (HCU)
SP1210	TM Motor angle self-learning	eRX5/Traction Control (TC)
SP1211	Electric drive transmission coolant exhausting	eRX5/Traction Control (TC)
SP1212	ISG motor angle self-learning	eRX5/Idle speed control system (ISC)
SP1213	ISG motor acceleration test	eRX5/Idle speed control system (ISC)
SP1214	Pressure sensor learning	eRX5/Ignition Control System (SCS)
SP1215	yaw sensor learning	eRX5/Ignition Control System (SCS)
SP1216	ABS Add liquid exhaust	eRX5/Ignition Control System (SCS)
SP1217	Electric power steering system learning	eRX5/Electric Power Steering System (EPS)
SP1218	parking brake cable Adjustment of the parking brake cable	eRX5/Electronic Parking Brake System (EPB)
SP1219	Full release of the	eRX5/Electronic Parking Brake System (EPB)
SP1220	Electronic parking tension test	eRX5/Electronic Parking Brake System (EPB)
SP1221	Electronic parking release test	eRX5/Electronic Parking Brake System (EPB)
SP1222	Forward camera module self-learning	eRX5/Front facing camera module (FVCM)
SP1223	wheel angle sensor to zero learn	eRX5/Steering Angle Sensor Module (SAS)
SP1224	the steering angle sensor offset learning	eRX5/Steering Angle Sensor Module (SAS)
SP1225	Body control module operation mode adjustment	eRX5/Body Control Module (BCM)
SP1226	Electric tailgate self-learning	eRX5/Electric tailgate control module (PLCM)
SP1227	Power mode adjustment	eRX5/Keyless Entry Module (PEPS)
SP1228	Air conditioning servo motor self-learning	eRX5/Temperature Controller (HVAC)
SP1229	Maintenance mileage reset	eRX5/Instrument unit (IPK)
SP1230	tire sensor self-learning,	eRX5/Tire Pressure Monitoring System (TPMS)
SP1231	TBOX restart	RX5 ePlus/Communication Module (T-BOX)
SP1232	OTA Bluetooth lock open	RX5 ePlus/Communication Module (T-BOX)
SP1233	Gateway brake sensor zero learning	RX5 ePlus/Gateway Module (GW)
SP1234	Battery ID write	RX5 ePlus/Gateway Module (GW)

SP1235	Clutch parameter self-learning	RX5 ePlus/Hybrid Control Unit (HCU)
SP1236	Transmission gear selection reference point self-learning	RX5 ePlus/Hybrid Control Unit (HCU)
SP1237	Transmission parameter self-learning	RX5 ePlus/Hybrid Control Unit (HCU)
SP1238	Clear transmission parameters	RX5 ePlus/Hybrid Control Unit (HCU)
SP1239	Clear clutch parameters	RX5 ePlus/Hybrid Control Unit (HCU)
SP1240	Clear shift execution structure parameters	RX5 ePlus/Hybrid Control Unit (HCU)
SP1241	Fast adaptive (manual method)	RX5 ePlus/Hybrid Control Unit (HCU)
SP1242	Drive motor angle self-learning	RX5 ePlus/Integrated Starter Control Module (ISC)
SP1243	Electric drive transmission coolant exhausting	RX5 ePlus/Integrated Starter Control Module (ISC)
SP1244	Engine control module self-learning value reset	RX5 ePlus/Engine Control Module (ECM)
SP1245	engine throttle self-learning reset	RX5 ePlus/Engine Control Module (ECM)
SP1246	Electric power steering system learning	RX5 ePlus/Electronic Power Steering System (EPS)
SP1247	parking brake system parts replacement	RX5 ePlus/Anti-lock braking system/dynamic stability control (SCS)
SP1248	yaw sensor learning	RX5 ePlus/Anti-lock braking system/dynamic stability control (SCS)
SP1249	ABS Add liquid exhaust	RX5 ePlus/Anti-lock braking system/dynamic stability control (SCS)
SP1250	Release left Side actuator	RX5 ePlus/Anti-lock braking system/dynamic stability control (SCS)
SP1251	Release right side actuator	RX5 ePlus/Anti-lock braking system/dynamic stability control (SCS)
SP1252	Enable left side actuator	RX5 ePlus/Anti-lock braking system/dynamic stability control (SCS)
SP1253	Enable right side actuator	RX5 ePlus/Anti-lock braking system/dynamic stability control (SCS)
SP1254	Enable both side actuators	RX5 ePlus/Anti-lock braking system/dynamic stability control (SCS)
SP1255	Release both side actuators	RX5 ePlus/Anti-lock braking system/dynamic stability control (SCS)
SP1256	Forward camera module self-learning	RX5 ePlus/Front camera module (FVCM)
SP1257	Body control module operation mode adjustment	RX5 ePlus/Body Control Module (BCM)
SP1258	Power mode adjustment	RX5 ePlus/Keyless Entry and Keyless Start Module (PEPS)
SP1259	tire sensor self-learning,	RX5 ePlus/Tire Pressure Monitoring System (TPMS)
SP1260	Air conditioning servo motor self-learning	RX5 ePlus/Air Conditioning Module (HVAC)
SP1263	OTA Bluetooth lock open	ERX5 (EV)/Communication Module (T-BOX)
SP1264	GW setting power mode	ERX5 (EV)/Gateway Module (GW)
SP1265	Gateway battery ID writing	ERX5 (EV)/Gateway Module (GW)
SP1266	brake pedal position sensor zero eLearning	ERX5 (EV)/Gateway Module (GW)
SP1267	Coolant filling and exhausting	ERX5 (EV)/ Vehicle Control Module (VCU)
SP1268	Drive motor angle self-learning	ERX5 (EV)/ Traction Motor Controller (TC)
SP1269	Dynamic Stability Control System Pressure Sensor Learning	ERX5 (EV)/Anti-lock braking system/dynamic stability control (ABS/SCS)
SP1270	yaw sensor learning	ERX5 (EV)/Anti-lock braking system/dynamic stability control (ABS/SCS)
SP1271	ABSSCS Add liquid exhaust	ERX5 (EV)/Anti-lock braking system/dynamic stability control (ABS/SCS)
SP1272	Electric power steering system learning	ERX5 (EV)/Electronic Power Steering System (EPS)
SP1273	wheel angle sensor to zero learn	ERX5 (EV)/Rotation Angle Sensor (SAS)
SP1274	the steering angle sensor offset learning	ERX5 (EV)/Rotation Angle Sensor (SAS)
SP1275	parking brake cable Adjustment of the parking brake cable	ERX5 (EV)/Electronic Handbrake Module (EPB)
SP1276	Full release of the	ERX5 (EV)/Electronic Handbrake Module (EPB)
SP1277	Electronic parking tension test	ERX5 (EV)/Electronic Handbrake Module (EPB)
SP1278	Electronic parking release test	ERX5 (EV)/Electronic Handbrake Module (EPB)
SP1279	Forward camera module self-learning	ERX5 (EV)/Front camera module (FVCM)
SP1280	Body control module operation mode adjustment	ERX5 (EV)/Body Control Module (BCM)
SP1281	Power mode adjustment	ERX5 (EV)/Keyless Entry and Start System (PEPS)
SP1282	Air conditioning servo motor self-learning	ERX5 (EV)/Air Conditioning Controller (HVAC)
SP1284	Maintenance mileage reset	ERX5 (EV)/Instrument Module (IPK)
SP1285	Electric tailgate self-learning	ERX5 (EV)/Electric tailgate control module (PLCM)
SP1286	tire sensor self-learning,	ERX5 (EV)/Tire Pressure Monitoring System (TPMS)
SP1287	TBOX restart	RX5 MAX/Communication module (T-BOX)
SP1288	OTA Bluetooth lock open	RX5 MAX/Communication module (T-BOX)

SP1289	GW setting power mode	RX5 MAX/Gateway module (GW)
SP1290	Battery ID write	RX5 MAX/Gateway module (GW)
SP1291	engine throttle self-learning reset	RX5 MAX/Engine control module (ECM)
SP1292	Engine control module self-learning value reset	RX5 MAX/Engine control module (ECM)
SP1293	Brake pedal position sensor self-learning	RX5 MAX/Engine control module (ECM)
SP1304	Automatic transmission self-learning	RX5 MAX/Gearbox control module (TCM)
SP1305	Adaptive learning value reset	RX5 MAX/Gearbox control module (TCM)
SP1306	Read the SubROM data	RX5 MAX/Gearbox control module (TCM)
SP1307	Transmission sensor test sensor self-detection	RX5 MAX/Gearbox control module (TCM)
SP1309	Four-wheel drive Control module self-test	RX5 MAX/Four-wheel control module (TCCM)
SP1310	SCU executes gear self-learning	RX5 MAX/Seck detection module (SCU)
SP1311	SCU clears gear learning value	RX5 MAX/Seck detection module (SCU)
SP1312	parking brake system parts replacement	RX5 MAX/Anti-lock brake system / Dynamic stability control (ABS/SCS)
SP1313	yaw sensor learning	RX5 MAX/Anti-lock brake system / Dynamic stability control (ABS/SCS)
SP1314	ABS Add liquid exhaust	RX5 MAX/Anti-lock brake system / Dynamic stability control (ABS/SCS)
SP1315	Release left Side actuator	RX5 MAX/Anti-lock brake system / Dynamic stability control (ABS/SCS)
SP1316	Release right side actuator	RX5 MAX/Anti-lock brake system / Dynamic stability control (ABS/SCS)
SP1317	Enable left side actuator	RX5 MAX/Anti-lock brake system / Dynamic stability control (ABS/SCS)
SP1318	Enable right side actuator	RX5 MAX/Anti-lock brake system / Dynamic stability control (ABS/SCS)
SP1319	Enable both side actuators	RX5 MAX/Anti-lock brake system / Dynamic stability control (ABS/SCS)
SP1320	Release both side actuators	RX5 MAX/Anti-lock brake system / Dynamic stability control (ABS/SCS)
SP1321	Electric power steering system learning	RX5 MAX/Electronic power steering system (EPS)
SP1322	Forward detection radar driving calibration	RX5 MAX/Forward detection radar module (FDR)
SP1323	of the forward detection radar Query the self-learning result of the forward detection radar driving calibration	RX5 MAX/Forward detection radar module (FDR)
SP1324	Forward camera module self-learning	RX5 MAX/Front camera module (FVCM)
SP1325	Body control module operation mode adjustment	RX5 MAX/Body control module (BCM)
SP1326	Power mode adjustment	RX5 MAX/Keyless entry and start system (PEPS)
SP1327	Air conditioning servo motor self-learning	RX5 MAX/Air conditioner controller (HVAC)
SP1328	Maintenance mileage reset	RX5 MAX/Instrument module (IPK)
SP1329	tire sensor self-learning,	RX5 MAX/Tire pressure monitoring system (TPMS)
SP1330	360 panoramic image control module self-learning	RX5 MAX/360 Panoramic image control module (AVM)
SP1331	TBOX restart	RX5 eMAX/Communication Module (T-BOX)
SP1332	OTA Bluetooth lock open	RX5 eMAX/Communication Module (T-BOX)
SP1333	GW setting power mode	RX5 eMAX/Gateway Module (GW)
SP1334	Battery ID write	RX5 eMAX/Gateway Module (GW)
SP1335	Clutch parameter self-learning	RX5 eMAX/Hybrid Control Unit (HCU)
SP1336	Transmission gear selection reference point self-learning	RX5 eMAX/Hybrid Control Unit (HCU)
SP1337	Transmission parameter self-learning	RX5 eMAX/Hybrid Control Unit (HCU)
SP1338	Clear transmission parameters	RX5 eMAX/Hybrid Control Unit (HCU)
SP1339	Clear clutch parameters	RX5 eMAX/Hybrid Control Unit (HCU)
SP1340	Clear shift execution structure parameters	RX5 eMAX/Hybrid Control Unit (HCU)
SP1341	Fast adaptive (manual method)	RX5 eMAX/Hybrid Control Unit (HCU)
SP1342	Drive motor angle self-learning	RX5 eMAX/Integrated Starter Control Module (ISC)
SP1343	Electric drive transmission coolant exhausting	RX5 eMAX/Integrated Starter Control Module (ISC)
SP1352	parking brake system parts replacement	RX5 eMAX/Anti-lock braking system/dynamic stability control (SCS/ABS)
SP1353	yaw sensor learning	RX5 eMAX/Anti-lock braking system/dynamic stability control (SCS/ABS)
SP1354	ABS Add liquid exhaust	RX5 eMAX/Anti-lock braking system/dynamic stability control (SCS/ABS)
SP1355	Release left Side actuator	RX5 eMAX/Anti-lock braking system/dynamic stability control (SCS/ABS)
SP1356	Release right side actuator	RX5 eMAX/Anti-lock braking system/dynamic stability control (SCS/ABS)
SP1357	Enable left side actuator	RX5 eMAX/Anti-lock braking system/dynamic stability control (SCS/ABS)
SP1358	Enable right side actuator	RX5 eMAX/Anti-lock braking system/dynamic stability control (SCS/ABS)

SP1359	Enable both side actuators	RX5 eMAX/Anti-lock braking system/dynamic stability control (SCS/ABS)
SP1360	Release both side actuators	RX5 eMAX/Anti-lock braking system/dynamic stability control (SCS/ABS)
SP1361	Electric power steering system learning	RX5 eMAX/Electronic Power Steering System (EPS)
SP1362	Forward detection radar driving calibration	RX5 eMAX/Forward Detection Radar Module (FDR)
SP1363	of the forward detection radar Query the self-learning result of the forward detection radar driving calibration	RX5 eMAX/Forward Detection Radar Module (FDR)
SP1364	Forward camera module self-learning	RX5 eMAX/Front camera module (FVCM)
SP1365	Body control module operation mode adjustment	RX5 eMAX/Body Control Module (BCM)
SP1366	Power mode adjustment	RX5 eMAX/Keyless Entry and Keyless Start Module (PEPS)
SP1367	Air conditioning servo motor self-learning	RX5 eMAX/Air Conditioning Module (HVAC)
SP1368	tire sensor self-learning,	RX5 eMAX/Tire Pressure Monitoring System (TPMS)
SP1369	360 panoramic image control module self-learning	RX5 eMAX/360 panoramic image control module (AVM)
SP1379	TBOX restart	MARVEL X/Communication Module (T-BOX)
SP1380	OTA Bluetooth lock open	MARVEL X/Communication Module (T-BOX)
SP1381	GW setting power mode	MARVEL X/Gateway Module (GW)
SP1382	Gateway brake sensor zero learning	MARVEL X/Gateway Module (GW)
SP1383	Gateway battery ID writing	MARVEL X/Gateway Module (GW)
SP1384	HCU synchronizer position learning	MARVEL X/ Vehicle Control Module (VCU)
SP1385	Coolant filling and exhausting	MARVEL X/ Vehicle Control Module (VCU)
SP1386	yaw sensor learning	MARVEL X/Anti-lock braking system/dynamic stability control (ABS/SCS)
SP1387	Refilling exhaust	MARVEL X/Anti-lock braking system/dynamic stability control (ABS/SCS)
SP1388	Electric power steering system learning	MARVEL X/Electronic Power Steering System (EPS)
SP1389	Forward camera module self-learning	MARVEL X/Front camera module (FVCM)
SP1390	parking brake system parts replacement	MARVEL X/Electronic Handbrake Module (EPB)
SP1391	Release left Side actuator	MARVEL X/Electronic Handbrake Module (EPB)
SP1392	Release right side actuator	MARVEL X/Electronic Handbrake Module (EPB)
SP1393	Enable left side actuator	MARVEL X/Electronic Handbrake Module (EPB)
SP1394	Enable right side actuator	MARVEL X/Electronic Handbrake Module (EPB)
SP1395	Enable both side actuators	MARVEL X/Electronic Handbrake Module (EPB)
SP1396	Release both side actuators	MARVEL X/Electronic Handbrake Module (EPB)
SP1397	Forward detection radar driving calibration	MARVEL X/Forward Detection Radar Module (FDR)
SP1398	of the forward detection radar Query the self-learning result of the forward detection radar driving calibration	MARVEL X/Forward Detection Radar Module (FDR)
SP1399	P2P positioning calibration	MARVEL X/Point-to-point memory parking assist module (P2P)
SP1400	Body control module operation mode adjustment	MARVEL X/Body Control Module (BCM)
SP1401	Power mode adjustment	MARVEL X/Keyless Entry and Start System (PEPS)
SP1402	Air conditioning servo motor self-learning	MARVEL X/Air Conditioning Controller (HVAC)
SP1403	Maintenance mileage reset	MARVEL X/Instrument Module (IPK)
SP1404	tire sensor self-learning,	MARVEL X/Tire Pressure Monitoring System (TPMS)
SP1431	TBOX restart	MARVEL R/Communication Module (T-BOX)
SP1432	OTA Bluetooth lock open	MARVEL R/Communication Module (T-BOX)
SP1433	GW setting power mode	MARVEL R/Gateway(GW)
SP1434	Gateway brake sensor zero learning	MARVEL R/Gateway(GW)
SP1435	Gateway battery ID writing	MARVEL R/Gateway(GW)
SP1436	Coolant filling and exhausting	MARVEL R/Vehicle Control Module (VCU)
SP1437	Electric power steering system learning	MARVEL R/Electric Power Steering (EPS)
SP1438	parking brake system parts replacement	MARVEL R/Electronic Handbrake Module (EPB)
SP1439	Release left Side actuator	MARVEL R/Electronic Handbrake Module (EPB)
SP1440	Release right side actuator	MARVEL R/Electronic Handbrake Module (EPB)
SP1441	Enable left side actuator	MARVEL R/Electronic Handbrake Module (EPB)
SP1442	Enable right side actuator	MARVEL R/Electronic Handbrake Module (EPB)
SP1443	Enable both side actuators	MARVEL R/Electronic Handbrake Module (EPB)
SP1444	Release both side actuators	MARVEL R/Electronic Handbrake Module (EPB)
SP1445	Forward detection radar driving calibration	MARVEL R/Radar Module (FDR)
SP1446	of the forward detection radar Query the self-learning result of the forward detection radar driving calibration	MARVEL R/Radar Module (FDR)
SP1447	Forward camera module self-learning	MARVEL R/Front camera module (FVCM)
SP1448	Body control module operation mode adjustment	MARVEL R/Body Control Module (BCM)
SP1449	Air conditioning servo motor self-learning	MARVEL R/Air Conditioning Module (HVAC)

SP1450	Power mode adjustment	MARVEL R/Keyless Entry and Keyless Start Module (PEPS)
SP1451	360 panoramic image control module self-learning	MARVEL R/360 panoramic image control module (AVM)
SP1452	tire sensor self-learning,	MARVEL R/Tire Pressure Monitoring System (TPMS)
SP1453	OTA Bluetooth lock open	Ei5/Communication Module (T-BOX)
SP1454	TBOX restart	Ei5/Communication Module (T-BOX)
SP1455	GW setting power mode	Ei5/Gateway Module (GW)
SP1456	Gateway brake sensor zero learning	Ei5/Gateway Module (GW)
SP1457	Gateway battery ID writing	Ei5/Gateway Module (GW)
SP1458	Drive motor angle self-learning	Ei5/ Traction Motor Controller (TC)
SP1459	Coolant filling and exhausting	Ei5/Vehicle Control Module (VCU)
SP1460	yaw sensor learning	Ei5/Anti-lock braking system/dynamic stability control (SCS/ABS)
SP1461	parking brake system parts replacement	Ei5/Anti-lock braking system/dynamic stability control (SCS/ABS)
SP1462	Refilling exhaust	Ei5/Anti-lock braking system/dynamic stability control (SCS/ABS)
SP1463	Release left Side actuator	Ei5/Anti-lock braking system/dynamic stability control (SCS/ABS)
SP1464	Release right side actuator	Ei5/Anti-lock braking system/dynamic stability control (SCS/ABS)
SP1465	Enable left side actuator	Ei5/Anti-lock braking system/dynamic stability control (SCS/ABS)
SP1466	Enable right side actuator	Ei5/Anti-lock braking system/dynamic stability control (SCS/ABS)
SP1467	Enable both side actuators	Ei5/Anti-lock braking system/dynamic stability control (SCS/ABS)
SP1468	Release both side actuators	Ei5/Anti-lock braking system/dynamic stability control (SCS/ABS)
SP1469	Electric power steering system learning	Ei5/Electronic Power Steering System (EPS)
SP1470	Forward camera module self-learning	Ei5/Front camera module (FVCM)
SP1478	parking brake system parts replacement	Ei5/Electronic Handbrake Module (EPB)
SP1479	Release left Side actuator	Ei5/Electronic Handbrake Module (EPB)
SP1480	Release right side actuator	Ei5/Electronic Handbrake Module (EPB)
SP1481	Enable left side actuator	Ei5/Electronic Handbrake Module (EPB)
SP1482	Enable right side actuator	Ei5/Electronic Handbrake Module (EPB)
SP1483	Enable both side actuators	Ei5/Electronic Handbrake Module (EPB)
SP1484	Release both side actuators	Ei5/Electronic Handbrake Module (EPB)
SP1485	tire sensor self-learning,	Ei5/Tire Pressure Monitoring System (TPMS)
SP1486	Body control module operation mode adjustment	Ei5/Body Control Module (BCM)
SP1487	Power mode adjustment	Ei5/Keyless Entry and Keyless Start Module (PEPS)
SP1488	Air conditioning damper actuator self-learning	Ei5/Air conditioning control module (HVAC)
SP1489	Maintenance mileage reset	Ei5/Combination Instrument (IPK)
SP1491	TBOX restart	CLEVER/Communication Module (T-BOX)
SP1492	Brake pedal position sensor self-learning	CLEVER/Gateway (GW)
SP1493	Gateway power mode adjustment	CLEVER/Gateway (GW)
SP1494	ABS/SCS Add liquid exhaust	CLEVER/Anti-lock Braking System (ABS)
SP1495	Electric power steering system learning	CLEVER/Electric Power Steering (EPS)
SP1496	Electric drive transmission coolant Filling and exhausting	CLEVER/Vehicle Control Module (VCU)
SP1497	Drive motor angle self-learning	CLEVER/ Traction Motor Controller (TC)
SP1498	Maintenance interval reset	CLEVER/Combination Instrument (IPK)
SP1499	Air conditioning damper actuator self-learning	CLEVER/Air Conditioning Module (HVAC)
SP1500	Body control module power mode adjustment	CLEVER/Body Control Module (BCM)
SP1501	tire sensor learning,	CLEVER/Body Control Module (BCM)
SP1502	TBOX restart	IMAX8/Communication module (T-BOX)
SP1503	OTA Bluetooth lock open	IMAX8/Communication module (T-BOX)
SP1504	Gateway power mode adjustment	IMAX8/Gateway module (GW)
SP1505	Battery ID write	IMAX8/Gateway module (GW)
SP1506	Forward detection radar self-learning	IMAX8/Radar module (FDR)
SP1507	Engine control module self-learning value reset	IMAX8/Engine management system (ECM)
SP1508	Electronic throttle self-learning	IMAX8/Engine management system (ECM)
SP1509	GPF learning value reset	IMAX8/Engine management system (ECM)
SP1510	GPF pressure sensor self-learning adaptive value reset	IMAX8/Engine management system (ECM)
SP1511	GPF model update	IMAX8/Engine management system (ECM)
SP1512	GPF learning value backup	IMAX8/Engine management system (ECM)
SP1513	GPF learning value write	IMAX8/Engine management system (ECM)
SP1514	GPF adaptation	IMAX8/Engine management system (ECM)



SP1515	Transmission self-learning value reset	IMAX8/Gearbox control module (TCM)
SP1516	ACU Clear gear self-learning	IMAX8/Action execution module (ACU)
SP1517	performs self-learning gear	IMAX8/Action execution module (ACU)
SP1518	yaw sensor learning	IMAX8/Anti-lock brake system / Dynamic stability control (SCS)
SP1519	ABS/SCS Add liquid exhaust	IMAX8/Anti-lock brake system / Dynamic stability control (SCS)
SP1520	Parking brake system actuator parts replacement	IMAX8/Anti-lock brake system / Dynamic stability control (SCS)
SP1521	Parking brake system function test	IMAX8/Anti-lock brake system / Dynamic stability control (SCS)
SP1522	Release the actuators on both sides of the parking brake system	IMAX8/Anti-lock brake system / Dynamic stability control (SCS)
SP1523	Activate the left actuator of the parking brake system	IMAX8/Anti-lock brake system / Dynamic stability control (SCS)
SP1524	on both sides of the parking brake system Activate the right actuator of the parking brake system	IMAX8/Anti-lock brake system / Dynamic stability control (SCS)
SP1525	parking brake system Release the left actuator of the parking brake system	IMAX8/Anti-lock brake system / Dynamic stability control (SCS)
SP1526	Release the right actuator of the	IMAX8/Anti-lock brake system / Dynamic stability control (SCS)
SP1527	Activate the actuators	IMAX8/Anti-lock brake system / Dynamic stability control (SCS)
SP1528	Steering angle sensor zero learning	IMAX8/Corner sensor (SAS)
SP1529	front-view camera module self-learning,	IMAX8/Front camera module (FVCM)
SP1530	Air conditioning damper actuator self-learning	IMAX8/Air conditioning control module (HVAC)
SP1531	Power mode adjustment	IMAX8/Keyless entry and key launch module (PEPS)
SP1532	Body control module operation mode adjustment	IMAX8/Body control module (BCM)
SP1533	tire sensor learning,	IMAX8/Tire pressure monitoring system (TPMS)
SP1554	wheel angle sensor to zero learn	Roewe New 550 HYBRID /Rotation Angle Sensor (SAS)
SP1555	the steering angle sensor offset learning	Roewe New 550 HYBRID /Rotation Angle Sensor (SAS)
SP1556	TBOX battery life calibration	MG6 14 Year /Communication module (TBOX)
SP1557	TBOX activation	MG6 14 Year /Communication module (TBOX)
SP1558	TBOX restart	MG6 14 Year /Communication module (TBOX)
SP1582	Maintenance mileage reset	IP2X TT/Instrument module (IPK)
SP1583	Power mode	IP2X TT/Body control module (BCM)
SP1584	Automatic transmission control unit quick learning	IP2X TT/Automatic transmission control module (TCM)
SP1585	Adaptive learning value reset	IP2X TT/Automatic transmission control module (TCM)
SP1586	Read the SubRom data	IP2X TT/Automatic transmission control module (TCM)
SP1587	Automatic transmission sensor test	IP2X TT/Automatic transmission control module (TCM)
SP1588	Release left Side actuator	IP2X TT/Electronic park brake (EPB)
SP1589	Release right side actuator	IP2X TT/Electronic park brake (EPB)
SP1590	Enable left side actuator	IP2X TT/Electronic park brake (EPB)
SP1591	Enable right side actuator	IP2X TT/Electronic park brake (EPB)
SP1592	Enable both side actuators	IP2X TT/Electronic park brake (EPB)
SP1593	Release both side actuators	IP2X TT/Electronic park brake (EPB)
SP1594	Refilling exhaust	IP2X TT/Anti-lock brake system / Dynamic stability control (ABS/SCS)
SP1596	OTA Bluetooth lock open	i6/Communication module (T-BOX)
SP1597	TBOX restart	i6/Communication module (T-BOX)
SP1598	GW setting power mode	i6/Gateway (GW)
SP1599	Gateway brake sensor zero learning	i6/Gateway (GW)
SP1600	Battery ID write	i6/Gateway (GW)
SP1601	Adaptive learning value reset	i6/Engine control module (ECM)
SP1602	Electronic throttle quick self-learning	i6/Engine control module (ECM)
SP1614	Transmission control module quick learning	i6/Gearbox control module (TCM)
SP1616	DHL height sensor zero voltage self-learning	i6/Dynamic headlight level adjustment (DHL)
SP1617	Indirect tire pressure system reset	i6/Anti-lock brake system / Dynamic stability control (SCS)
SP1618	parking brake system parts replacement	i6/Anti-lock brake system / Dynamic stability control (SCS)
SP1619	Pressure sensor learning	i6/Anti-lock brake system / Dynamic stability control (SCS)



SP1620	yaw sensor learning	i6/Anti-lock brake system / Dynamic stability control (SCS)
SP1621	ABS Add liquid exhaust	i6/Anti-lock brake system / Dynamic stability control (SCS)
SP1622	Release left Side actuator	i6/Anti-lock brake system / Dynamic stability control (SCS)
SP1623	Release right side actuator	i6/Anti-lock brake system / Dynamic stability control (SCS)
SP1624	Enable left side actuator	i6/Anti-lock brake system / Dynamic stability control (SCS)
SP1625	Enable right side actuator	i6/Anti-lock brake system / Dynamic stability control (SCS)
SP1626	Enable both side actuators	i6/Anti-lock brake system / Dynamic stability control (SCS)
SP1627	Release both side actuators	i6/Anti-lock brake system / Dynamic stability control (SCS)
SP1628	Electric power steering system learning	i6/Electronic steering power system (EPS)
SP1630	Forward camera module self-learning	i6/Front camera module (FVCM)
SP1631	Air conditioning servo motor self-learning	i6/Air conditioning module (HVAC)
SP1632	Power mode adjustment	i6/Keyless entry and start system (PEPS)
SP1633	Body control module operation mode adjustment	i6/Body control module (BCM)
SP1634	Maintenance mileage reset	i6/Instrument module (IPK)
SP1635	tire sensor self-learning,	i6/Tire pressure monitoring system (TPMS)
SP1636	TBOX restart	ER6/Communication Module (T-BOX)
SP1637	OTA Bluetooth lock open	ER6/Communication Module (T-BOX)
SP1638	GW setting power mode	ER6/Gateway (GW)
SP1639	Gateway battery ID writing	ER6/Gateway (GW)
SP1640	brake pedal position sensor zero eLearning	ER6/Gateway (GW)
SP1641	Coolant filling and exhausting	ER6/Vehicle Control Module (VCU)
SP1642	Drive motor angle self-learning	ER6/ Traction Motor Controller (TC)
SP1643	yaw sensor learning	ER6/Anti-lock braking system/dynamic stability control (SCS)
SP1644	ABS Add liquid exhaust	ER6/Anti-lock braking system/dynamic stability control (SCS)
SP1645	Forward camera module self-learning	ER6/Front camera module (FVCM)
SP1646	parking brake system parts replacement	ER6/Electronic Handbrake Module (EPB)
SP1647	Release left Side actuator	ER6/Electronic Handbrake Module (EPB)
SP1648	Release right side actuator	ER6/Electronic Handbrake Module (EPB)
SP1649	Enable left side actuator	ER6/Electronic Handbrake Module (EPB)
SP1650	Enable right side actuator	ER6/Electronic Handbrake Module (EPB)
SP1651	Enable both side actuators	ER6/Electronic Handbrake Module (EPB)
SP1652	Release both side actuators	ER6/Electronic Handbrake Module (EPB)
SP1653	Forward detection radar driving calibration	ER6/Forward Detection Radar Module (FDR)
SP1654	of the forward detection radar Query the self-learning result of the forward detection radar driving calibration	ER6/Forward Detection Radar Module (FDR)
SP1655	Electric power steering system learning	ER6/Electronic Power Steering System (EPS)
SP1656	Body control module operation mode adjustment	ER6/Body Control Module (BCM)
SP1657	Power mode adjustment	ER6/Keyless Entry and Start System (PEPS)
SP1658	Air conditioning servo motor self-learning	ER6/Air Conditioning Module (HVAC)
SP1659	Maintenance mileage reset	ER6/Instrument module (IPK)
SP1660	tire sensor self-learning,	ER6/Tire Pressure Monitoring System (TPMS)
SP1661	TBOX restart	i6 MAX/Communication module (T-BOX)
SP1662	OTA Bluetooth lock open	i6 MAX/Communication module (T-BOX)
SP1663	GW setting power mode	i6 MAX/Gateway (GW)
SP1664	Engine control module self-learning value reset	i6 MAX/Engine control module (ECM)
SP1665	engine throttle self-learning reset	i6 MAX/Engine control module (ECM)
SP1669	parking brake system parts replacement	i6 MAX/Anti-lock brake system / Dynamic stability control (SCS)
SP1670	Pressure sensor learning	i6 MAX/Anti-lock brake system / Dynamic stability control (SCS)
SP1671	yaw sensor learning	i6 MAX/Anti-lock brake system / Dynamic stability control (SCS)
SP1672	ABS Add liquid exhaust	i6 MAX/Anti-lock brake system / Dynamic stability control (SCS)
SP1673	Release left Side actuator	i6 MAX/Anti-lock brake system / Dynamic stability control (SCS)
SP1674	Release right side actuator	i6 MAX/Anti-lock brake system / Dynamic stability control (SCS)
SP1675	Enable left side actuator	i6 MAX/Anti-lock brake system / Dynamic stability control (SCS)

SP1676	Enable right side actuator	i6 MAX/Anti-lock brake system / Dynamic stability control (SCS)
SP1677	Enable both side actuators	i6 MAX/Anti-lock brake system / Dynamic stability control (SCS)
SP1678	Release both side actuators	i6 MAX/Anti-lock brake system / Dynamic stability control (SCS)
SP1679	Electric power steering system learning	i6 MAX/Electronic steering power system (EPS)
SP1681	Body control module operation mode adjustment	i6 MAX/Body control module (BCM)

XTOOL