



Shenzhen Xtooltech Co., Ltd

BAIC Senova Function List V8.50

Tips and Instructions:

The programming function only supports H6PRO, H6PRO Master Edition products.

* This feature is new.

✓ This feature is supported.

This feature is not supported.

※ This feature is partially supported.

Model	Model Series	System Name	Read ECU Information	Read Trouble Code	Clear Trouble Code	Live Data	Read Freeze Frame	Actuation Test	Special Functions
BAIC Senova	X25	Engine control module (EMS)	✓	✓	✓	✓	✓	✓	SP0161-SP0162
BAIC Senova	X25	Automatic transmission system (TCU)	✓	✓	✓	✓		✓	SP0183
BAIC Senova	X25	Anti lock braking system (ABS)	✓	✓	✓	✓		✓	SP0163-SP0165
BAIC Senova	X25	Airbag module (SDM)	✓	✓	✓	✓		✓	SP0166-SP0169
BAIC Senova	X25	Body electronic control module (BCM)	✓	✓	✓	✓		✓	SP0179-SP0180
BAIC Senova	X25	Electronic power steering module (EPS)	✓	✓	✓	✓			SP0175-SP0176
BAIC Senova	X25	Instrument cluster module (ICM)	✓	✓	✓	✓		✓	SP0170-SP0174
BAIC Senova	X25	Automatic air conditioning module (ACC)	✓	✓	✓	✓		✓	SP0177-SP0178
BAIC Senova	X25	Navigation module (hum) _ DVD)	✓	✓	✓	✓		✓	SP0181-SP0182
BAIC Senova	X25 (my 2016)	EMS (engine system)	✓	✓	✓	✓		✓	SP2387

BAIC Senova	X25 (my 2016)	TCU (automatic transmission system)	√	√	√	√		√	SP2368
BAIC Senova	X25 (my 2016)	ABS (anti lock braking system)	√	√	√	√		√	SP2369-SP2370
BAIC Senova	X25 (my 2016)	SDM (air bag)	√	√	√	√		√	SP2383-SP2385
BAIC Senova	X25 (my 2016)	BCM (body control system)	√	√	√	√		√	SP2371-SP2374
BAIC Senova	X25 (my 2016)	EPS (electronic power steering system)	√	√	√	√			SP2386
BAIC Senova	X25 (my 2016)	ICM (combination instrument)	√	√	√	√		√	SP2375-SP2379
BAIC Senova	X25 (my 2016)	AC (air conditioning system)	√	√	√	√		√	SP2380
BAIC Senova	X25 (my 2016)	Hum (DVD host)	√	√	√	√		√	SP2381-SP2382
BAIC Senova	X25 (2017 my)	EMS (engine system)	√	√	√	√		√	SP2387
BAIC Senova	X25 (2017 my)	TCU (automatic transmission system)	√	√	√	√		√	SP2388
BAIC Senova	X25 (2017 my)	ABS (anti lock braking system)	√	√	√	√		√	SP2389-SP2390
BAIC Senova	X25 (2017 my)	SDM (air bag)	√	√	√	√		√	SP2401-SP2403
BAIC Senova	X25 (2017 my)	BCM (body control system)	√	√	√	√		√	SP2392-SP2395
BAIC Senova	X25 (2017 my)	EPS (electronic power steering system)	√	√	√	√			SP2404
BAIC Senova	X25 (2017 my)	ICM (combination instrument)	√	√	√	√		√	SP2396-SP2400
BAIC Senova	X25 (2017 my)	Peps (keyless start system)	√	√	√	√		√	SP2391
BAIC Senova	X25 (2017 my)	AC (air conditioning system)	√	√	√	√		√	SP2405

BAIC Senova	X25 (2017 my)	Hum (DVD host)	√	√	√	√		√	SP2406-SP2407
BAIC Senova	X25 (2017 my)	ESCL (electronic steering column lock)	√	√	√	√			SP2408
BAIC Senova	X35	Engine control module (EMS)	√	√	√	√		√	SP0268-SP0269
BAIC Senova	X35	Automatic transmission module (TCU)	√	√	√	√		√	SP0279
BAIC Senova	X35	Brake hydraulic control module (ESP)	√	√	√	√		√	SP0273-SP0278
BAIC Senova	X35	Anti lock braking system (ABS)	√	√	√	√		√	SP0270-SP0272
BAIC Senova	X35	Air bag system (SDM)	√	√	√	√		√	SP0280-SP0283
BAIC Senova	X35	Body electronic control module (BCM)	√	√	√	√		√	SP0287-SP0292
BAIC Senova	X35	Electric power steering system (EPS)	√	√	√	√			SP0284-SP0286
BAIC Senova	X35	Combination instrument system (ICM)	√	√	√	√		√	SP0293-SP0298
BAIC Senova	X35	Air conditioning controller module (ACC)	√	√	√	√		√	SP0299-SP0300
BAIC Senova	X35	DVD navigation module (hum)	√	√	√	√		√	SP0301-SP0303
BAIC Senova	X35 (2016)	EMS (engine system)	√	√	√	√		√	SP2409
BAIC Senova	X35 (2016)	TCU (automatic transmission system)	√	√	√	√		√	SP2414
BAIC Senova	X35 (2016)	ABS (anti lock braking system)	√	√	√	√		√	SP2415-SP2416
BAIC Senova	X35 (2016)	ESP (body electronic stability system)	√	√	√	√		√	SP2417-SP2421
BAIC Senova	X35 (2016)	SDM (air bag)	√	√	√	√		√	SP2429-SP2431

BAIC Senova	X35 (2016)	BCM (body control system)	√	√	√	√			SP2410-SP2413
BAIC Senova	X35 (2016)	EPS (electronic power steering system)	√	√	√	√			SP2422-SP2423
BAIC Senova	X35 (2016)	ICM (combination instrument)	√	√	√	√		√	SP2424-SP2428
BAIC Senova	X35 (2016)	ATC (automatic air conditioning system)	√	√	√	√		√	SP2434
BAIC Senova	X35 (2016)	Hum (DVD host)	√	√	√	√		√	SP2432-SP2433
BAIC Senova	X55	Engine control module (EMS)	√	√	√	√	√	√	SP0363
BAIC Senova	X55	Automatic transmission module (TCU)	√	√	√	√		√	SP0200
BAIC Senova	X55	Brake hydraulic control module (ESP)	√	√	√	√		√	SP0197
BAIC Senova	X55	Air bag system (SDM)	√	√	√	√		√	SP0166-SP0169
BAIC Senova	X55	Body electronic control module (BCM)	√	√	√	√	√	√	SP0198
BAIC Senova	X55	Electric power steering system (EPS)	√	√	√	√			
BAIC Senova	X55	Combination instrument system (ICM)	√	√	√	√		√	SP0084-SP0088
BAIC Senova	X55	Keyless start system (peps)	√	√	√	√		√	SP0201-SP0203
BAIC Senova	X55	Air conditioning controller module (ACC)	√	√	√	√		√	SP0157
BAIC Senova	X55	Tire pressure monitoring system (TPMS)	√	√	√	√			SP0204
BAIC Senova	X55	Electronic steering column module (ESCL)	√	√	√	√			
BAIC Senova	X55	Automatic headlamp system (AHL)	√	√	√	√		√	

BAIC Senova	X55	DVD navigation module (hum)	√	√	√	√		√	SP0205
BAIC Senova	X55	T module (Tbox)	√	√	√	√		√	SP0199
BAIC Senova	New x55 (Zhixing	Engine control module (EMS)	√	√	√	√		√	SP0304-SP0306
BAIC Senova	New x55 (Zhixing	Automatic transmission module (TCU)	√	√	√	√		√	SP0200
BAIC Senova	New x55 (Zhixing	Brake hydraulic control module (ESP)	√	√	√	√		√	SP0197
BAIC Senova	New x55 (Zhixing	Air bag system (SDM)	√	√	√	√		√	SP2249-SP2252
BAIC Senova	New x55 (Zhixing	Body electronic control module (BCM)	√	√	√	√		√	SP2243-SP2248
BAIC Senova	New x55 (Zhixing	Electric power steering system (EPS)	√	√	√	√			
BAIC Senova	New x55 (Zhixing	Instrument cluster module (ICM)	√	√	√	√		√	SP2198-SP2202
BAIC Senova	New x55 (Zhixing	Keyless start system (peps)	√	√	√	√		√	SP2226-SP2228
BAIC Senova	New x55 (Zhixing	Electric air conditioning (EAC)	√	√	√	√		√	SP2257
BAIC Senova	New x55 (Zhixing	Automatic air conditioning (AAC)	√	√	√	√		√	SP2229-SP2230
BAIC Senova	New x55 (Zhixing	Tire pressure monitoring system (TPMS)	√	√	√	√			SP2258-SP2264
BAIC Senova	New x55 (Zhixing	Electronic brake system (EPB)	√	√	√	√		√	SP2212-SP2217
BAIC Senova	New x55 (Zhixing	Gateway (GW)	√	√	√	√			SP2239-SP2242
BAIC Senova	New x55 (Zhixing	DVD navigation module (hum)	√	√	√	√		√	SP2253-SP2256
BAIC Senova	New x55 (Zhixing	Electronic steering column module (ESCL)	√	√	√	√			SP2224-SP2225

BAIC Senova	New x55 (Zhixing	Panoramic image module (AVM)	√	√	√				SP2237-SP2238
BAIC Senova	New x55 (Zhixing	Front seat heating module (FSH)	√	√	√				SP2265-SP2266
BAIC Senova	Shenbao Zhixing	EMS (engine system)	√	√	√	√		√	SP3241-SP3242
BAIC Senova	Shenbao Zhixing	TCU (automatic transmission system)	√	√	√	√		√	SP3243-SP3245
BAIC Senova	Shenbao Zhixing	ESP (body electronic stability system)	√	√	√	√		√	SP3252-SP3256
BAIC Senova	Shenbao Zhixing	SDM (air bag)	√	√	√	√		√	SP3264-SP3266
BAIC Senova	Shenbao Zhixing	BCM (body control system)	√	√	√	√			SP3247-SP3251
BAIC Senova	Shenbao Zhixing	EPS (electronic power steering system)	√	√	√	√			SP3262-SP3263
BAIC Senova	Shenbao Zhixing	IPC (combination instrument)	√	√	√	√		√	SP3257-SP3261
BAIC Senova	Shenbao Zhixing	Peps (keyless start system)	√	√	√	√		√	SP3246
BAIC Senova	Shenbao Zhixing	ATC (automatic air conditioning system)	√	√	√	√		√	SP3293-SP3294
BAIC Senova	Shenbao Zhixing	EAC (electric air conditioning system)	√	√	√	√		√	SP3295
BAIC Senova	Shenbao Zhixing	TPMS (tire pressure monitoring system)	√	√	√	√			SP3271-SP3292
BAIC Senova	Shenbao Zhixing	EPB (electronic parking brake system)	√	√	√	√		√	SP3303-SP3306
BAIC Senova	Shenbao Zhixing	GW (Gateway System)	√	√	√	√			SP3268-SP3270
BAIC Senova	Shenbao Zhixing	ESCL (electronic steering column lock)	√	√	√	√			SP3267
BAIC Senova	Shenbao Zhixing	Hum (DVD host)	√	√	√	√		√	SP3296-SP3301

BAIC Senova	Shenbao Zhixing	FSH (front seat heating system)	√	√	√				SP3302
BAIC Senova	Shenbao Zhixing	AVM (panoramic image module)	√	√	√	√			SP3307
BAIC Senova	Shenbao Zhixing	T-box (t module)	√	√	√	√		√	SP3308-SP3310
BAIC Senova	X65	Engine control module (EMS)	√	√	√	√	√	√	SP0108-SP0109
BAIC Senova	X65	Automatic transmission control unit (TCU)	√	√	√	√		√	SP0116-SP0117
BAIC Senova	X65	Brake hydraulic control module (ESP)	√	√	√	√		√	SP0121-SP0125
BAIC Senova	X65	Anti lock braking system (ABS)	√	√	√	√		√	SP0118-SP0120
BAIC Senova	X65	Airbag (SRS)	√	√	√	√		√	SP0126-SP0129
BAIC Senova	X65	Body electronic control module (BCM)	√	√	√	√		√	SP0130-SP0135
BAIC Senova	X65	Combination instrument (ICM)	√	√	√	√		√	SP0146-SP0150
BAIC Senova	X65	Keyless start controller (peps)	√	√	√	√		√	SP0136-SP0138
BAIC Senova	X65	Air conditioning controller (AC)	√	√	√	√		√	SP0157
BAIC Senova	X65	Tire pressure monitoring system (TPMS)	√	√	√	√			SP0139-SP0143
BAIC Senova	X65	Panoramic image module (AVM)	√	√	√	√		√	SP0151-SP0153
BAIC Senova	X65	Automatic headlamp system (AHL)	√	√	√	√		√	SP0144-SP0145
BAIC Senova	X65	Navigation module (DVD)	√	√	√	√		√	SP0154-SP0156
BAIC Senova	X65	Electronic steering column lock (ESCL)	√	√	√	√			SP0083

BAIC Senova	X65	Driver's seat module (DSM)	√	√	√	√		√	SP0158-SP0160
BAIC Senova	X65	T module (Tbox)	√	√	√	√			SP0110-SP0115
BAIC Senova	D20	Mitsubishi engine electronic control mo	√	√	√	√		√	
BAIC Senova	D20	Powertrain engine electronic control mo	√	√	√	√		√	
BAIC Senova	D20	Automatic transmission module (TCU)	√	√	√	√		√	
BAIC Senova	D20	Brake hydraulic control module (ESP)	√	√	√	√		√	SP0261-SP0267
BAIC Senova	D20	Anti lock braking system (ABS)	√	√	√	√		√	SP0221-SP0222
BAIC Senova	D20	Air bag system (SDM)	√	√	√	√		√	SP0215
BAIC Senova	D20	Body electronic control module (BCM)	√	√	√	√		√	
BAIC Senova	D20	Electric power steering system (EPS)	√	√	√	√			
BAIC Senova	D20	Combination instrument system (ICM)	√	√	√	√		√	SP0216-SP0220
BAIC Senova	D50	Engine control module (EMS)	√	√	√	√	√	√	SP0000-SP0002
BAIC Senova	D50	Automatic transmission control unit (TC	√	√	√	√		√	SP0008-SP0009
BAIC Senova	D50	Anti lock braking system (ABS)	√	√	√	√		√	SP0003
BAIC Senova	D50	Brake hydraulic control module (contine	√	√	√	√		√	SP0017-SP0022
BAIC Senova	D50	Brake hydraulic control module (Jingxi)	√	√	√	√		√	SP0023-SP0026
BAIC Senova	D50	Airbag (SRS)	√	√	√	√		√	SP0004-SP0007

BAIC Senova	D50	Body electronic control module (BCM)	√	√	√	√		√	SP0010-SP0013
BAIC Senova	D50	Combination instrument (ICM)	√	√	√	√		√	SP0029-SP0034
BAIC Senova	D50	Keyless start controller (peps)	√	√	√	√		√	SP0014-SP0016
BAIC Senova	D50	Air conditioning controller (AC)	√	√	√	√		√	SP0052-SP0053
BAIC Senova	D50	Tire pressure monitoring system (TPMS)	√	√	√	√			SP0035-SP0039
BAIC Senova	D50	Navigation module (DVD)	√	√	√	√		√	SP0050-SP0051
BAIC Senova	D50	Electronic steering column lock (ESCL)	√	√	√	√			SP0027-SP0028
BAIC Senova	D50	T module (Tbox)	√	√	√	√		√	SP0044-SP0049
BAIC Senova	D50	Central display (HUD)	√	√	√	√		√	SP0040-SP0043
BAIC Senova	New d50	Engine control module (EMS)	√	√	√	√		√	SP0304-SP0306
BAIC Senova	New d50	Automatic transmission module (TCU)	√	√	√	√		√	SP0200
BAIC Senova	New d50	Instrument cluster module (ICM)	√	√	√	√		√	SP2198-SP2202
BAIC Senova	New d50	Body electronic control module (BCM)	√	√	√	√		√	SP2203-SP2208
BAIC Senova	New d50	Air bag system (SDM)	√	√	√	√			SP2209-SP2211
BAIC Senova	New d50	Brake hydraulic control module (ESP)	√	√	√	√		√	SP0273-SP0278
BAIC Senova	New d50	Electronic brake system (EPB)	√	√	√	√		√	SP2212-SP2217
BAIC Senova	New d50	Henglong electric power steering system	√	√	√	√			SP2218-SP2221

BAIC Senova	New d50	North Henan electric power steering sys	√	√	√	√			SP2222-SP2223
BAIC Senova	New d50	Electronic steering column module (ESCL	√	√	√	√			SP2224-SP2225
BAIC Senova	New d50	Keyless start system (peps)	√	√	√	√		√	SP2226-SP2228
BAIC Senova	New d50	Air conditioning panel (APC)	√	√	√	√			
BAIC Senova	New d50	Air conditioning controller module (EAC	√	√	√	√		√	SP2229-SP2230
BAIC Senova	New d50	DVD navigation module (hum)	√	√	√	√		√	SP2231-SP2233
BAIC Senova	New d50	Reversing radar control module (PAS)	√	√	√	√			SP2234-SP2236
BAIC Senova	New d50	Panoramic image module (AVM)	√	√	√				SP2237-SP2238
BAIC Senova	New d50	Gateway (GW)	√	√	√	√			SP2239-SP2242
BAIC Senova	New d50	Engine system (United)	√	√	√	√		√	SP3176-SP3179
BAIC Senova	New d50	Engine system (marilli)	√	√	√	√		√	SP3180-SP3181
BAIC Senova	New d50	TCU (automatic transmission system)	√	√	√	√			SP3201-SP3203
BAIC Senova	New d50	ESP (body electronic stability system)	√	√	√	√		√	SP3187-SP3192
BAIC Senova	New d50	SDM (air bag)	√	√	√	√		√	SP3193-SP3195
BAIC Senova	New d50	BCM (body control system)	√	√	√	√			SP3182-SP3185
BAIC Senova	New d50	Henglong brushless EPS (electronic power	√	√	√	√			SP3204-SP3206
BAIC Senova	New d50	Henglong brush EPS (electronic power st	√	√	√	√			SP3207-SP3208

BAIC Senova	New d50	North Henan brushless EPS (electronic p	√	√	√	√		√	SP3209-SP3210
BAIC Senova	New d50	North Henan brush EPS (electronic power	√	√	√	√			SP3211-SP3212
BAIC Senova	New d50	IPC (combination instrument)	√	√	√	√		√	SP3196-SP3200
BAIC Senova	New d50	Peps (keyless start system)	√	√	√	√		√	SP3186
BAIC Senova	New d50	ATC (automatic air conditioning system)	√	√	√	√		√	SP3213-SP3214
BAIC Senova	New d50	EAC (electric air conditioning system)	√	√	√	√		√	SP3215
BAIC Senova	New d50	EPB (electronic parking brake system)	√	√	√	√		√	SP3232-SP3234
BAIC Senova	New d50	GW (Gateway System)	√	√	√	√			SP3224-SP3226
BAIC Senova	New d50	Hum (DVD host)	√	√	√	√		√	SP3216-SP3219
BAIC Senova	New d50	ESCL (electronic steering column lock)	√	√	√	√			SP3220
BAIC Senova	New d50	DVR (vehicle data recorder)	√	√	√				SP3221-SP3223
BAIC Senova	New d50	Pas (reversing radar system)	√	√	√	√			SP3227-SP3230
BAIC Senova	New d50	AVM (panoramic image module)	√	√	√	√			SP3231
BAIC Senova	New d50	T-box (t module)	√	√	√	√		√	SP3235-SP3237
BAIC Senova	New d50	ALC (atmosphere lamp)	√	√	√	√		√	SP3238-SP3240
BAIC Senova	D60	Engine control module (EMS)	√	√	√	√		√	SP0054-SP0056
BAIC Senova	D60	Automatic transmission control unit (TC	√	√	√	√		√	SP0057

BAIC Senova	D60	Brake hydraulic control module (ESP)	√	√	√	√		√	SP0062-SP0067
BAIC Senova	D60	Air bag (SDM)	√	√	√	√		√	SP0058-SP0061
BAIC Senova	D60	Body electronic control module (BCM)	√	√	√	√		√	SP0068-SP0071
BAIC Senova	D60	Combination instrument (ICM)	√	√	√	√		√	SP0084-SP0088
BAIC Senova	D60	Keyless start controller (peps)	√	√	√	√		√	SP0072-SP0074
BAIC Senova	D60	Air conditioning controller (HVAC)	√	√	√	√		√	SP0080-SP0082
BAIC Senova	D60	Electric air conditioner (AC)	√	√	√	√		√	SP0105-SP0107
BAIC Senova	D60	Tire pressure monitoring system (TPMS)	√	√	√	√			SP0075-SP0079
BAIC Senova	D60	Electronic steering column lock (ESCL)	√	√	√	√			SP0083
BAIC Senova	D60	Driver's seat module (DSM)	√	√	√	√		√	SP0096-SP0097
BAIC Senova	D60	T module (Tbox)	√	√	√	√		√	SP0099-SP0104
BAIC Senova	D60	Reversing radar side view assist (SVA &	√	√	√	√			SP0098
BAIC Senova	D60	Navigation module (DVD)	√	√	√	√		√	SP0093-SP0095
BAIC Senova	D60	Automatic headlamp system (AHL)	√	√	√	√		√	SP0089-SP0092
BAIC Senova	D70	Engine control module (EMS)	√	√	√	√		√	SP0192
BAIC Senova	D70	Automatic transmission control unit (TC	√	√	√	√		√	SP0191
BAIC Senova	D70	Brake hydraulic control module (ESP)	√	√	√	√		√	SP0190

BAIC Senova	D70	Air bag system (SDM)	√	√	√	√		√	
BAIC Senova	D70	Body electronic control system	√	√	√	√		√	SP0193
BAIC Senova	D70	Body electronic control system (Lear)	√	√	√	√		√	SP0211-SP0214
BAIC Senova	D70	Combination instrument (ICM)	√	√	√	√		√	SP0207
BAIC Senova	D70	Keyless start controller (peps)	√	√	√	√		√	SP0189
BAIC Senova	D70	Air conditioning controller (AC)	√	√	√	√		√	SP0194-SP0195
BAIC Senova	D70	Tire pressure monitoring system (TPMS)	√	√	√	√			SP0209
BAIC Senova	D70	Rear view camera (RVC)	√	√	√	√			SP0196
BAIC Senova	D70	Reversing radar side view assist (SVA &	√	√	√	√			SP0098
BAIC Senova	D70	Navigation module (DVD)	√	√	√	√		√	SP0184-SP0185
BAIC Senova	D70	Electronic steering column lock (ESCL)	√	√	√	√			SP0187-SP0188
BAIC Senova	D70	Automatic headlamp system (AHL)	√	√	√	√		√	SP0186
BAIC Senova	D70	Driver's seat module (DSM)	√	√	√	√		√	SP0206
BAIC Senova	D70	T module (Tbox)	√	√	√	√		√	SP0208
BAIC Senova	D70 performance	EMS (engine system)	√	√	√	√		√	SP2435-SP2436
BAIC Senova	D70 performance	TCU (automatic transmission system)	√	√	√	√		√	SP2449
BAIC Senova	D70 performance	ESP (body electronic stability system)	√	√	√	√		√	SP2443-SP2448

BAIC Senova	D70 performance	SRS (air bag)	√	√	√	√		√	SP2458-SP2460
BAIC Senova	D70 performance	BCM (body control system)	√	√	√	√		√	SP2437-SP2441
BAIC Senova	D70 performance	ICM (combination instrument)	√	√	√	√		√	SP2450-SP2454
BAIC Senova	D70 performance	Peps (keyless start system)	√	√	√	√		√	SP2442
BAIC Senova	D70 performance	AC (air conditioning system)	√	√	√	√		√	SP2455
BAIC Senova	D70 performance	AHL (headlight height adjustment system)	√	√	√	√		√	SP2456
BAIC Senova	D70 performance	DSM (seat memory module)	√	√	√	√		√	SP2457
BAIC Senova	D70 performance	Hum (DVD host)	√	√	√	√		√	SP2461
BAIC Senova	D70 performance	ESCL (electronic steering column lock)	√	√	√	√			SP2462-SP2463
BAIC Senova	D70 performance	Pas (reversing radar system)	√	√	√	√			SP2464-SP2469
BAIC Senova	D70 performance	RVC (reverse camera system)	√	√	√	√			SP2470
BAIC Senova	D80	Engine control module (EMS)	√	√	√	√		√	SP0192
BAIC Senova	D80	Automatic transmission module (TCU)	√	√	√	√		√	SP0191
BAIC Senova	D80	Brake hydraulic control module (ESP)	√	√	√	√		√	SP0190
BAIC Senova	D80	Air bag system (SDM)	√	√	√	√		√	
BAIC Senova	D80	Body electronic control module (BCM)	√	√	√	√		√	SP0193
BAIC Senova	D80	Combination instrument system (ICM)	√	√	√	√		√	SP0207

BAIC Senova	D80	Keyless start system (peps)	√	√	√	√		√	SP0189
BAIC Senova	D80	Air conditioning controller module (AC)	√	√	√	√		√	SP0210
BAIC Senova	D80	Tire pressure monitoring system (TPMS)	√	√	√	√			SP0209
BAIC Senova	D80	Electronic steering column module (ESCL)	√	√	√	√			SP0083
BAIC Senova	D80	Automatic headlamp system (AHL)	√	√	√	√		√	SP0186
BAIC Senova	D80	Driver's seat module (DSM)	√	√	√	√		√	SP0206
BAIC Senova	D80	T module (Tbox)	√	√	√	√		√	SP0208
BAIC Senova	D80	DVD navigation module (hum)	√	√	√	√		√	
BAIC Senova	D80	Reversing radar system (SVA & PAS)	√	√	√	√			SP0098
BAIC Senova	D80	Rear camera control module (RVC)	√	√	√	√			SP0196
BAIC Senova	X7	Gateway (GW)	√	√	√	√	√	√	SP3434-SP3438
BAIC Senova	X7	Engine control system (EMS)	√	√	√	√	√	√	SP3322-SP3325
BAIC Senova	X7	Automatic transmission module (TCU)	√	√	√	√	√		SP3339-SP3348
BAIC Senova	X7	Anti lock braking system / electronic s	√	√	√	√		√	SP3315-SP3321
BAIC Senova	X7	Electronic stability system (ESP)	√	√	√	√		√	SP3421-SP3430
BAIC Senova	X7	Electric power steering (EPS)	√	√	√	√	√		SP3416-SP3420
BAIC Senova	X7	Air bag system (SDM)	√	√	√	√		√	SP3336-SP3338

BAIC Senova	X7	Tire pressure monitoring system (TPMS)	√	√	√	√			SP2258-SP2264
BAIC Senova	X7	Body electronic control module (BCM)	√	√	√	√	√	√	SP3382-SP3390
BAIC Senova	X7	Keyless start system (peps)	√	√	√	√		√	SP3328-SP3331
BAIC Senova	X7	Electronic steering column module (ESCL)	√	√	√	√			SP2224-SP2225
BAIC Senova	X7	Vehicle communication module (Tbox)	√	√	√	√		√	SP3349-SP3351
BAIC Senova	X7	Front detection camera (MPC)	√	√	√	√	√		SP3474-SP3478
BAIC Senova	X7	Panoramic image module (AVM)	√	√	√		√		SP3375-SP3381
BAIC Senova	X7	Automatic air conditioning (AAC)	√	√	√	√		√	SP3355-SP3358
BAIC Senova	X7	Adaptive cruise (ACC)	√	√	√	√		√	SP3311-SP3314
BAIC Senova	X7	Atmosphere lamp control module (ALC)	√	√	√	√		√	SP3359-SP3363
BAIC Senova	X7	Digital power amplifier (AMP)	√	√	√				SP3364-SP3367
BAIC Senova	X7	Automatic parking (APA)	√	√	√				SP3368-SP3371
BAIC Senova	X7	Air conditioning panel (APC)	√	√	√	√			SP3372-SP3374
BAIC Senova	X7	Central control module (CCP)	√	√	√				SP3391-SP3393
BAIC Senova	X7	Driver's seat control module (DSM)	√	√	√			√	SP3394-SP3404
BAIC Senova	X7	Seat ventilation heating module (fshvm)	√	√	√				SP3431-SP3433
BAIC Senova	X7	Entertainment host (hum)	√	√	√	√			SP3439-SP3444

BAIC Senova	X7	Combination instrument system (ICM)	√	√	√	√		√	SP3445-SP3450
BAIC Senova	X7	Left headlamp controller (lclfl)	√	√	√	√		√	SP3451-SP3454
BAIC Senova	X7	Right headlamp controller (LCFR)	√	√	√	√		√	SP3455-SP3458
BAIC Senova	X7	Rear left headlamp controller (lclrl)	√	√	√				SP3459-SP3463
BAIC Senova	X7	Right rear headlamp controller (lclrr)	√	√	√				SP3464-SP3468
BAIC Senova	X7	Middle and rear tail lamp controller (LCR)	√	√	√				SP3469-SP3473
BAIC Senova	X7	4 & 8 inch parking aid module (PAS)	√	√	√	√			SP2267-SP2269
BAIC Senova	X7	12 inch parking aid module (PAS)	√	√	√	√			SP3326-SP3327
BAIC Senova	X7	Vehicle data recorder (DVR)	√	√	√	√			SP3405-SP3415
BAIC Senova	X7	Intelligent tail door module (PTM)	√	√	√	√		√	SP3332-SP3333
BAIC Senova	X7	Electronic shifter (SBW)	√	√	√	√	√		SP3334-SP3335
BAIC Senova	X7	Vehicle control panel (VCS)	√	√	√	√		√	SP3352-SP3353
BAIC Senova	X7	Wireless charging module (WCM)	√	√	√				SP3354
BAIC Senova	Shen Bao Zhixing	EMS (combined electric engine system)	√	√	√	√		√	SP2471-SP2472
BAIC Senova	Shen Bao Zhixing	TCU (automatic transmission system)	√	√	√	√			SP2473-SP2474
BAIC Senova	Shen Bao Zhixing	ESP (body electronic stability system)	√	√	√	√		√	SP2487-SP2491
BAIC Senova	Shen Bao Zhixing	SRS (air bag)	√	√	√	√		√	SP2496-SP2498

BAIC Senova	Shen Bao Zhixing	BCM (body control system)	√	√	√	√			SP2476-SP2481
BAIC Senova	Shen Bao Zhixing	EPS (electronic power steering system)	√	√	√	√			SP2492-SP2494
BAIC Senova	Shen Bao Zhixing	ICM (combination instrument)	√	√	√	√		√	SP2482-SP2486
BAIC Senova	Shen Bao Zhixing	Peps (keyless start system)	√	√	√	√		√	SP2475
BAIC Senova	Shen Bao Zhixing	AC (air conditioning system)	√	√	√	√		√	SP2499-SP2500
BAIC Senova	Shen Bao Zhixing	TPMS (tire pressure monitoring system)	√	√	√	√			SP2511-SP2532
BAIC Senova	Shen Bao Zhixing	GW (Gateway System)	√	√	√	√			SP2501-SP2503
BAIC Senova	Shen Bao Zhixing	ESCL (electronic steering column lock)	√	√	√	√			SP2495
BAIC Senova	Shen Bao Zhixing	Hum (DVD host)	√	√	√	√		√	SP2504-SP2507
BAIC Senova	Shen Bao Zhixing	Tbox (remote monitoring system)	√	√	√	√		√	SP2508-SP2510
BAIC Senova	Shen Bao Zhixing	DVR (vehicle data recorder)	√	√	√				SP2533-SP2535
BAIC Senova	Shen Bao Zhixing	Pas (reversing radar system)	√	√	√	√			SP2536-SP2539
BAIC Senova	Shen Bao Zhixing	ACP (air conditioning panel)	√	√	√	√			SP2540
BAIC Senova	Shen Bao Zhixing	AVM (panoramic image system)	√	√	√	√			SP2541

Special Functions List

No.	Functions Name	System Name
SP0000	Write Vin	Engine control module (EMS)
SP0001	Write programming date	Engine control module (EMS)
SP0002	Throttle learning	Engine control module (EMS)
SP0003	Write Vin	Anti lock braking system (ABS)
SP0004	Write VIN code	Airbag (SRS)
SP0005	Write programming date	Airbag (SRS)
SP0006	Configuration of Airbag ECU	Airbag (SRS)
SP0007	Configuration of airbag initiation state	Airbag (SRS)
SP0008	Replace ECU	Automatic transmission control unit (TCU)
SP0009	Vehicle configuration code	Automatic transmission control unit (TCU)
SP0010	Write VIN code	Body electronic control module (BCM)
SP0011	Write programming date	Body electronic control module (BCM)
SP0012	Vehicle configuration code	Body electronic control module (BCM)
SP0013	Body function configuration	Body electronic control module (BCM)
SP0014	Write Vin	Keyless start controller (peps)
SP0015	Write programming date	Keyless start controller (peps)
SP0016	Vehicle network configuration	Keyless start controller (peps)
SP0017	Write Vin	Brake hydraulic control module (continental)
SP0018	Vehicle configuration	Brake hydraulic control module (continental)
SP0019	Calibration of lateral acceleration sensor	Brake hydraulic control module (continental)
SP0020	Pressure sensor calibration	Brake hydraulic control module (continental)
SP0021	Steering wheel angle sensor calibration	Brake hydraulic control module (continental)
SP0022	exhaust	Brake hydraulic control module (continental)
SP0023	Write Vin	Brake hydraulic control module (Jingxi)
SP0024	Write programming date	Brake hydraulic control module (Jingxi)
SP0025	Steering wheel angle sensor calibration	Brake hydraulic control module (Jingxi)
SP0026	exhaust	Brake hydraulic control module (Jingxi)
SP0027	Write Vin	Electronic steering column lock (ESCL)
SP0028	Write programming date	Electronic steering column lock (ESCL)
SP0029	Write Vin	Combination instrument (ICM)
SP0030	Write programming date	Combination instrument (ICM)
SP0031	Vehicle configuration code	Combination instrument (ICM)
SP0032	Function configuration of combination instrument	Combination instrument (ICM)

SP0033	service mileage configuration	Combination instrument (ICM)
SP0034	Mileage backup	Combination instrument (ICM)
SP0035	Write Vin	Tire pressure monitoring system (TPMS)
SP0036	Write programming date	Tire pressure monitoring system (TPMS)
SP0037	Tire pressure sensor replacement	Tire pressure monitoring system (TPMS)
SP0038	Tire pressure sensor exchange	Tire pressure monitoring system (TPMS)
SP0039	Tire pressure sensor learning	Tire pressure monitoring system (TPMS)
SP0040	Write Vin	Central display (HUD)
SP0041	Write programming date	Central display (HUD)
SP0042	Vehicle configuration code	Central display (HUD)
SP0043	central display function configuration	Central display (HUD)
SP0044	Write Vin	T module (Tbox)
SP0045	Write programming date	T module (Tbox)
SP0046	configuration option	T module (Tbox)
SP0047	Working mode setting	T module (Tbox)
SP0048	T module number set	T module (Tbox)
SP0049	T module volume default value set	T module (Tbox)
SP0050	Write Vin	Navigation module (DVD)
SP0051	Write programming date	Navigation module (DVD)
SP0052	Write Vin	Air conditioning controller (AC)
SP0053	Write programming date	Air conditioning controller (AC)
SP0054	Write Vin	Engine control module (EMS)
SP0055	Write programming date	Engine control module (EMS)
SP0056	Dental information learning	Engine control module (EMS)
SP0057	Write Vin	Automatic transmission control unit (TCU)
SP0058	Write VIN code	Air bag (SDM)
SP0059	Write programming date	Air bag (SDM)
SP0060	Special Functions	Air bag (SDM)
SP0061	Ignition on / off	Air bag (SDM)
SP0062	Write Vin	Brake hydraulic control module (ESP)
SP0063	Write programming date	Brake hydraulic control module (ESP)
SP0064	ESP exhaust	Brake hydraulic control module (ESP)
SP0065	Steering angle sensor calibration	Brake hydraulic control module (ESP)
SP0066	Yaw rate sensor calibration	Brake hydraulic control module (ESP)
SP0067	ESP configuration	Brake hydraulic control module (ESP)
SP0068	Write Vin	Body electronic control module (BCM)
SP0069	Vehicle configuration code	Body electronic control module (BCM)

SP0070	Initial setting of body electronic control module	Body electronic control module (BCM)
SP0071	Static network settings	Body electronic control module (BCM)
SP0072	Write VIN code	Keyless start controller (peps)
SP0073	Write programming date	Keyless start controller (peps)
SP0074	Vehicle network configuration	Keyless start controller (peps)
SP0075	Write Vin	Tire pressure monitoring system (TPMS)
SP0076	Write programming date	Tire pressure monitoring system (TPMS)
SP0077	Tire pressure sensor replacement	Tire pressure monitoring system (TPMS)
SP0078	Transposition of tire pressure sensor	Tire pressure monitoring system (TPMS)
SP0079	Tire pressure sensor learning	Tire pressure monitoring system (TPMS)
SP0080	Write Vin	Air conditioning controller (HVAC)
SP0081	Write programming date	Air conditioning controller (HVAC)
SP0082	Calibration of stepping motor	Air conditioning controller (HVAC)
SP0083	Write Vin	Electronic steering column module (ESCL)
SP0084	Write Vin	Combination instrument (ICM)
SP0085	Write programming date	Combination instrument (ICM)
SP0086	Vehicle coding configuration	Combination instrument (ICM)
SP0087	Function configuration of combination instrument	Combination instrument (ICM)
SP0088	service mileage set	Combination instrument (ICM)
SP0089	Write Vin	Automatic headlamp system (AHL)
SP0090	Write programming date	Automatic headlamp system (AHL)
SP0091	Chassis zero point correction	Automatic headlamp system (AHL)
SP0092	sensor zero point value	Automatic headlamp system (AHL)
SP0093	Write Vin	Navigation module (DVD)
SP0094	Write programming date	Navigation module (DVD)
SP0095	Option configuration	Navigation module (DVD)
SP0096	Write Vin	Driver's seat module (DSM)
SP0097	Write programming date	Driver's seat module (DSM)
SP0098	Write Vin	Reversing radar system (SVA & PAS)
SP0099	Write Vin	T module (Tbox)
SP0100	Write programming date	T module (Tbox)
SP0101	configuration option	T module (Tbox)
SP0102	Working mode setting	T module (Tbox)
SP0103	T module number set	T module (Tbox)
SP0104	T module volume default value set	T module (Tbox)
SP0105	Write Vin	Electric air conditioner (AC)
SP0106	Write programming date	Electric air conditioner (AC)

SP0107	Calibration of stepping motor	Electric air conditioner (AC)
SP0108	Write Vin	Engine control module (EMS)
SP0109	Dental information learning	Engine control module (EMS)
SP0110	Write Vin	T module (Tbox)
SP0111	Write programming date	T module (Tbox)
SP0112	configuration option	T module (Tbox)
SP0113	Working mode setting	T module (Tbox)
SP0114	T module number set	T module (Tbox)
SP0115	T module volume default value set	T module (Tbox)
SP0116	Write Vin	Automatic transmission control unit (TCU)
SP0117	Learning in the open	Automatic transmission control unit (TCU)
SP0118	Write Vin	Anti lock braking system (ABS)
SP0119	Write programming date	Anti lock braking system (ABS)
SP0120	ABS exhaust	Anti lock braking system (ABS)
SP0121	Write Vin	Brake hydraulic control module (ESP)
SP0122	Write programming date	Brake hydraulic control module (ESP)
SP0123	Vehicle configuration	Brake hydraulic control module (ESP)
SP0124	Steering wheel angle sensor calibration	Brake hydraulic control module (ESP)
SP0125	exhaust	Brake hydraulic control module (ESP)
SP0126	Write Vin	Airbag (SRS)
SP0127	Write programming date	Airbag (SRS)
SP0128	ECU configuration	Airbag (SRS)
SP0129	Start / disable ECU	Airbag (SRS)
SP0130	Write Vin	Body electronic control module (BCM)
SP0131	Write programming date	Body electronic control module (BCM)
SP0132	Vehicle configuration code	Body electronic control module (BCM)
SP0133	Initialization setting of body electronic control module	Body electronic control module (BCM)
SP0134	Static network settings	Body electronic control module (BCM)
SP0135	Control time setting	Body electronic control module (BCM)
SP0136	Write Vin	Keyless start controller (peps)
SP0137	Write programming date	Keyless start controller (peps)
SP0138	Vehicle network configuration	Keyless start controller (peps)
SP0139	Write Vin	Tire pressure monitoring system (TPMS)
SP0140	Write programming date	Tire pressure monitoring system (TPMS)
SP0141	Tire pressure sensor replacement	Tire pressure monitoring system (TPMS)
SP0142	Transposition of tire pressure sensor	Tire pressure monitoring system (TPMS)
SP0143	Tire pressure sensor learning	Tire pressure monitoring system (TPMS)
SP0144	Write Vin	Automatic headlamp system (AHL)

SP0145	Write programming date	Automatic headlamp system (AHL)
SP0146	Write Vin	Combination instrument (ICM)
SP0147	Write programming date	Combination instrument (ICM)
SP0148	Vehicle coding configuration	Combination instrument (ICM)
SP0149	Function configuration of combination instrument	Combination instrument (ICM)
SP0150	service mileage set	Combination instrument (ICM)
SP0151	Write Vin	Panoramic image module (AVM)
SP0152	Write programming date	Panoramic image module (AVM)
SP0153	configuration option	Panoramic image module (AVM)
SP0154	Write Vin	Navigation module (DVD)
SP0155	Write programming date	Navigation module (DVD)
SP0156	Option configuration	Navigation module (DVD)
SP0157	Write Vin	Air conditioning controller (AC)
SP0158	Write Vin	Driver's seat module (DSM)
SP0159	Write programming date	Driver's seat module (DSM)
SP0160	Body configuration	Driver's seat module (DSM)
SP0161	Write VIN code	Engine control module (EMS)
SP0162	Write programming date	Engine control module (EMS)
SP0163	Write VIN code	Anti lock braking system (ABS)
SP0164	Write programming date	Anti lock braking system (ABS)
SP0165	ABS exhaust	Anti lock braking system (ABS)
SP0166	Write Vin	Air bag system (SDM)
SP0167	Write programming date	Air bag system (SDM)
SP0168	Configuration of Airbag ECU	Air bag system (SDM)
SP0169	Configuration of airbag initiation state	Air bag system (SDM)
SP0170	Write Vin	Instrument cluster module (ICM)
SP0171	Write programming date	Instrument cluster module (ICM)
SP0172	EOL configuration	Instrument cluster module (ICM)
SP0173	service mileage set	Instrument cluster module (ICM)
SP0174	Mileage pulse count setting	Instrument cluster module (ICM)
SP0175	Write Vin	Electronic power steering module (EPS)
SP0176	Write programming date	Electronic power steering module (EPS)
SP0177	Write Vin	Automatic air conditioning module (ACC)
SP0178	Write programming date	Automatic air conditioning module (ACC)
SP0179	Write Vin	Body electronic control module (BCM)
SP0180	Write programming date	Body electronic control module (BCM)
SP0181	Write VIN code	Navigation module (hum) DVD)
SP0182	Write programming date	Navigation module (hum) DVD)
SP0183	Write Vin	Automatic transmission system (TCU)
SP0184	Write Vin	Navigation module (DVD)
SP0185	Write programming date	Navigation module (DVD)
SP0186	Write Vin	Automatic headlamp system (AHL)
SP0187	Write Vin	Electronic steering column lock (ESCL)

SP0188	Write programming date	Electronic steering column lock (ESCL)
SP0189	Write VIN code	Keyless start system (peps)
SP0190	Write Vin	Brake hydraulic control module (ESP)
SP0191	Write Vin	Automatic transmission module (TCU)
SP0192	Write Vin	Engine control module (EMS)
SP0193	Write Vin	Body electronic control module (BCM)
SP0194	Write Vin	Air conditioning controller (AC)
SP0195	Write programming date	Air conditioning controller (AC)
SP0196	Write Vin	Rear camera control module (RVC)
SP0197	Write VIN code	Brake hydraulic control module (ESP)
SP0198	Write VIN code	Body electronic control module (BCM)
SP0199	Write Vin	T module (Tbox)
SP0200	Write Vin	Automatic transmission module (TCU)
SP0201	Write Vin	Keyless start system (peps)
SP0202	Write programming date	Keyless start system (peps)
SP0203	Vehicle network configuration	Keyless start system (peps)
SP0204	Write Vin	Tire pressure monitoring system (TPMS)
SP0205	Write VIN code	DVD navigation module (hum)
SP0206	Write Vin	Driver's seat module (DSM)
SP0207	Write Vin	Combination instrument system (ICM)
SP0208	Write Vin	T module (Tbox)
SP0209	Write VIN code	Tire pressure monitoring system (TPMS)
SP0210	Write Vin	Air conditioning controller module (AC)
SP0211	Write Vin	Body electronic control system (Lear)
SP0212	Write programming date	Body electronic control system (Lear)
SP0213	Modify programming end block	Body electronic control system (Lear)
SP0214	Static network settings	Body electronic control system (Lear)
SP0215	Write VIN code	Air bag (SDM)
SP0216	Write VIN code	Combination instrument (ICM)
SP0217	Function configuration of combination instrument	Combination instrument (ICM)
SP0218	Display brightness configuration	Combination instrument (ICM)
SP0219	service mileage configuration	Combination instrument (ICM)
SP0220	Maintenance mileage learning	Combination instrument (ICM)
SP0221	Write VIN code	anti-lock brake system (ABS)
SP0222	ABS exhaust	anti-lock brake system (ABS)
SP0223	Write Vin	Body electronic control module (BCM)
SP0224	Write Vin	Combination instrument (ICM)
SP0225	Write Vin	Electronic control unit of engine
SP0226	Write Vin	Air bag (SDM)
SP0227	Write Vin	Engine electronic control unit (J5)
SP0228	Write Vin	Engine control module (EMS)

SP0229	Dental information learning	Engine control module (EMS)
SP0230	Write VIN code	Brake hydraulic control module (ESP)
SP0231	Write programming date	Brake hydraulic control module (ESP)
SP0232	ABS exhaust	Brake hydraulic control module (ESP)
SP0233	Vehicle configuration (ESP only)	Brake hydraulic control module (ESP)
SP0234	Yaw rate sensor calibration	Brake hydraulic control module (ESP)
SP0235	Steering angle sensor calibration	Brake hydraulic control module (ESP)
SP0236	Write Vin	Left front door module (DCU) LF)
SP0237	Write VIN code	Instrument cluster module (IPC)
SP0238	Static network configuration	Instrument cluster module (IPC)
SP0239	Vehicle configuration code	Instrument cluster module (IPC)
SP0240	Function configuration	Instrument cluster module (IPC)
SP0241	Write Vin	Air bag system (SDM)
SP0242	Write Vin	Right front door module (DCU) RF)
SP0243	Vehicle configuration code	Right front door module (DCU) RF)
SP0244	Function configuration	Right front door module (DCU) RF)
SP0245	Write Vin	Left rear door module (DCU) LR)
SP0246	Vehicle configuration code	Left rear door module (DCU) LR)
SP0247	Write Vin	Right rear door module (DCU) RR)
SP0248	Write programming date	Right rear door module (DCU) RR)
SP0249	Vehicle configuration code	Right rear door module (DCU) RR)
SP0250	Write Vin	Reversing video module (RVC)
SP0251	Vehicle configuration code	Reversing video module (RVC)
SP0252	Write Vin	Automatic transmission module (TCU)
SP0253	Vehicle configuration code	Automatic transmission module (TCU)
SP0254	Write Vin	Tire pressure monitoring system (TPMS)
SP0255	Write programming date	Tire pressure monitoring system (TPMS)
SP0256	Tire pressure sensor replacement	Tire pressure monitoring system (TPMS)
SP0257	Transposition of tire pressure sensor	Tire pressure monitoring system (TPMS)
SP0258	Tire pressure sensor learning	Tire pressure monitoring system (TPMS)
SP0259	Write Vin	Gateway (GW)
SP0260	Write Vin	Body electronic control module (BCM)
SP0261	Write Vin	Brake hydraulic control module (ESP)
SP0262	Write programming date	Brake hydraulic control module (ESP)
SP0263	ESP exhaust	Brake hydraulic control module (ESP)

SP0264	Steering angle sensor calibration	Brake hydraulic control module (ESP)
SP0265	Yaw rate sensor calibration	Brake hydraulic control module (ESP)
SP0266	Tpmf reset	Brake hydraulic control module (ESP)
SP0267	ESP configuration	Brake hydraulic control module (ESP)
SP0268	Write VIN code	Engine control module (EMS)
SP0269	Write programming date	Engine control module (EMS)
SP0270	Write VIN code	Anti lock braking system (ABS)
SP0271	Write programming date	Anti lock braking system (ABS)
SP0272	ABS exhaust	Anti lock braking system (ABS)
SP0273	Write VIN code	Brake hydraulic control module (ESP)
SP0274	Write programming date	Brake hydraulic control module (ESP)
SP0275	ABS exhaust	Brake hydraulic control module (ESP)
SP0276	Function configuration	Brake hydraulic control module (ESP)
SP0277	Yaw rate sensor calibration	Brake hydraulic control module (ESP)
SP0278	Indirect tire pressure calibration	Brake hydraulic control module (ESP)
SP0279	Write VIN code	Automatic transmission module (TCU)
SP0280	Write VIN code	Air bag system (SDM)
SP0281	Write programming date	Air bag system (SDM)
SP0282	Configuration of Airbag ECU	Air bag system (SDM)
SP0283	Configuration of airbag initiation state	Air bag system (SDM)
SP0284	Write VIN code	Electric power steering system (EPS)
SP0285	Write programming date	Electric power steering system (EPS)
SP0286	Calibration of angle sensor	Electric power steering system (EPS)
SP0287	Write VIN code	Body electronic control module (BCM)
SP0288	Write programming date	Body electronic control module (BCM)
SP0289	Vehicle configuration code	Body electronic control module (BCM)
SP0290	Static network settings	Body electronic control module (BCM)
SP0291	Function configuration	Body electronic control module (BCM)
SP0292	ECU matching	Body electronic control module (BCM)
SP0293	Write VIN code	Combination instrument system (ICM)
SP0294	Write programming date	Combination instrument system (ICM)
SP0295	Vehicle configuration code	Combination instrument system (ICM)
SP0296	ICM function configuration	Combination instrument system (ICM)
SP0297	EOL configuration	Combination instrument system (ICM)
SP0298	service mileage set	Combination instrument system (ICM)
SP0299	Write VIN code	Air conditioning controller module (ACC)
SP0300	Write programming date	Air conditioning controller module (ACC)
SP0301	Write VIN code	DVD navigation module (hum)
SP0302	Write programming date	DVD navigation module (hum)

SP0303	Option configuration	DVD navigation module (hum)
SP0304	Write VIN code	Engine control module (EMS)
SP0305	Write programming date	Engine control module (EMS)
SP0306	Vehicle configuration code	Engine control module (EMS)
SP0307	Write VIN code	Brake hydraulic control module (ESP)
SP0308	ABS exhaust	Brake hydraulic control module (ESP)
SP0309	Vehicle configuration	Brake hydraulic control module (ESP)
SP0310	Yaw rate sensor calibration	Brake hydraulic control module (ESP)
SP0311	Indirect tire pressure calibration	Brake hydraulic control module (ESP)
SP0312	Apbmi calibration function	Brake hydraulic control module (ESP)
SP0313	Write VIN code	Automatic transmission module (TCU)
SP0314	Write programming date	Automatic transmission module (TCU)
SP0315	Clear clutch self-learning value	Automatic transmission module (TCU)
SP0316	Write VIN code	Air bag system (SDM)
SP0317	Offline configuration	Air bag system (SDM)
SP0318	Write VIN code	Electric power steering system (EPS)
SP0319	Write programming date	Electric power steering system (EPS)
SP0320	Calibration of angle sensor	Electric power steering system (EPS)
SP0321	Write VIN code	Electronic steering column module (ESCL)
SP0322	Write VIN code	Body electronic control module (BCM)
SP0323	Write programming date	Body electronic control module (BCM)
SP0324	BCM function configuration	Body electronic control module (BCM)
SP0325	Body static network configuration	Body electronic control module (BCM)
SP0326	ECU matching	Body electronic control module (BCM)
SP0327	Delete BCM match	Body electronic control module (BCM)
SP0328	Write VIN code	Combination instrument system (ICM)
SP0329	Write programming date	Combination instrument system (ICM)
SP0330	Maintenance mileage interval	Combination instrument system (ICM)
SP0331	ICM function configuration	Combination instrument system (ICM)
SP0332	Write VIN code	Keyless start system (peps)
SP0333	Write programming date	Keyless start system (peps)
SP0334	Vehicle network configuration	Keyless start system (peps)
SP0335	Write VIN code	Automatic headlamp system (AHL)
SP0336	Write programming date	Automatic headlamp system (AHL)
SP0337	Chassis zero point correction	Automatic headlamp system (AHL)
SP0338	Write VIN code	Air conditioning controller module (ACC)
SP0339	Write VIN code	Panoramic image module (AVM)

SP0340	Write VIN code	DVD navigation module (hum)
SP0341	Option configuration	DVD navigation module (hum)
SP0342	Write VIN code	Reversing radar control module (PAS)
SP0343	Write VIN code	Engine control module (EMS)
SP0344	Write VIN code	Automatic transmission module (TCU)
SP0345	Write VIN code	Air bag system (SDM)
SP0346	Write Vin	Body electronic control module (BCM)
SP0347	Write VIN code	Combination instrument system (ICM)
SP0348	Write VIN code	Brake hydraulic control module (ESP)
SP0349	Write VIN code	Keyless start system (peps)
SP0350	Write Vin	Tire pressure monitoring system (TPMS)
SP0351	Write Vin	Gateway (GW)
SP0352	Write Vin	Electronic steering column lock (ESCL)
SP0353	Write Vin	Automatic headlamp system (AHL)
SP0354	Write VIN code	Central control module (CCP)
SP0355	Write Vin	Left front door side door module (DCU) LF)
SP0356	Write Vin	Left rear door control module (DCU) LR)
SP0357	Write Vin	Right front door side door module (DCU) RF)
SP0358	Write Vin	Right rear door control module (DCU) RR)
SP0359	Write Vin	Video entertainment system (EHC)
SP0360	Write Vin	Reversing radar control module (PAS)
SP0361	Write Vin	Reverse video control module (RVC)
SP0362	Write Vin	Driver's seat control module (DSM)
SP0363	Write Vin	Engine control module (EMS)
SP0364	Write Vin	Engine control module (EMS)
SP0365	Write programming date	Engine control module (EMS)
SP0366	Dental information learning	Engine control module (EMS)
SP0367	Write Vin	Automatic transmission system (at)
SP0368	Write programming date	Automatic transmission system (at)
SP0369	Vehicle configuration code	Automatic transmission system (at)
SP0370	Write Vin	ABS anti lock braking system
SP0371	Write programming date	ABS anti lock braking system
SP0372	ABS exhaust	ABS anti lock braking system
SP0373	Write Vin	ESP electronic stability system
SP0374	Write programming date	ESP electronic stability system
SP0375	Vehicle configuration (ESP only)	ESP electronic stability system
SP0376	Yaw rate sensor calibration	ESP electronic stability system
SP0377	Steering angle sensor calibration	ESP electronic stability system
SP0378	Write Vin	Airbag system (SRS)
SP0379	Write Vin	Instrument panel system (ICM / IP)
SP0380	Vehicle configuration code	Instrument panel system (ICM / IP)
SP0381	Function configuration	Instrument panel system (ICM / IP)

SP0382	Static network configuration	Instrument panel system (ICM / IP)
SP0383	service mileage set	Instrument panel system (ICM / IP)
SP0384	Write Vin	Tire pressure monitoring system (TPMS)
SP0385	Write programming date	Tire pressure monitoring system (TPMS)
SP0386	Tire pressure sensor replacement	Tire pressure monitoring system (TPMS)
SP0387	Transposition of tire pressure sensor	Tire pressure monitoring system (TPMS)
SP0388	Tire pressure sensor learning	Tire pressure monitoring system (TPMS)
SP0389	Write Vin	Body control module (BCM)
SP0390	Write programming date	Body control module (BCM)
SP0391	Vehicle configuration code	Body control module (BCM)
SP0392	Static network configuration	Body control module (BCM)
SP0393	Function configuration	Body control module (BCM)
SP0394	Collision configuration	Body control module (BCM)
SP0395	Number of collisions	Body control module (BCM)
SP0396	Write Vin	Gateway (GW)
SP0397	Write programming date	Gateway (GW)
SP0398	Function configuration	Gateway (GW)
SP0399	Write Vin	Left front door module (DCU) LF)
SP0400	Vehicle configuration code	Left front door module (DCU) LF)
SP0401	Function configuration	Left front door module (DCU) LF)
SP0402	Write Vin	Right front door module (DCU) RF)
SP0403	Write programming date	Right front door module (DCU) RF)
SP0404	Vehicle configuration code	Right front door module (DCU) RF)
SP0405	Function configuration	Right front door module (DCU) RF)
SP0406	Write Vin	Left rear door module (DCU) LR)
SP0407	Write programming date	Left rear door module (DCU) LR)
SP0408	Vehicle configuration code	Left rear door module (DCU) LR)
SP0409	Write Vin	Right rear door module (DCU) RR)
SP0410	Write programming date	Right rear door module (DCU) RR)
SP0411	Vehicle configuration code	Right rear door module (DCU) RR)
SP0412	Write Vin	Reversing video module (RVC)
SP0413	Write programming date	Reversing video module (RVC)
SP0414	Vehicle configuration code	Reversing video module (RVC)
SP0415	Write Vin	Anti lock braking system (ABS)
SP0416	Write VIN code	Airbag system (SRS)
SP0417	Write programming date	Airbag system (SRS)
SP0418	SDM enable function	Airbag system (SRS)
SP0419	Write VIN code	Instrument panel system (ICM / IP)

SP0420	Write programming date	Instrument panel system (ICM / IP)
SP0421	Option configuration	Instrument panel system (ICM / IP)
SP0422	service mileage set	Instrument panel system (ICM / IP)
SP0423	Vehicle configuration code	Instrument panel system (ICM / IP)
SP0424	Write VIN code	Headlamp adjustment module (AHL)
SP0425	Write programming date	Headlamp adjustment module (AHL)
SP0426	Chassis zero point correction	Headlamp adjustment module (AHL)
SP0427	Engine configuration	Headlamp adjustment module (AHL)
SP0428	Write Vin	Body control system (BCM)
SP0429	Write programming date	Body control system (BCM)
SP0430	Vehicle configuration code	Body control system (BCM)
SP0431	Static network configuration	Body control system (BCM)
SP0432	Function configuration	Body control system (BCM)
SP0433	Collision configuration	Body control system (BCM)
SP0434	Write Vin	Gateway (GW)
SP0435	Write programming date	Gateway (GW)
SP0436	Function configuration	Gateway (GW)
SP0437	Write Vin	Central control module (CCP)
SP0438	Write programming date	Central control module (CCP)
SP0439	Write Vin	Left front door module (DCU) LF)
SP0440	Write programming date	Left front door module (DCU) LF)
SP0441	Vehicle configuration code	Left front door module (DCU) LF)
SP0442	Function configuration	Left front door module (DCU) LF)
SP0443	Write Vin	Right front door module (DCU) RF)
SP0444	Write programming date	Right front door module (DCU) RF)
SP0445	Vehicle configuration code	Right front door module (DCU) RF)
SP0446	Function configuration	Right front door module (DCU) RF)
SP0447	Write Vin	Front body control module (fbcm)
SP0448	Write programming date	Front body control module (fbcm)
SP0449	Vehicle configuration code	Front body control module (fbcm)
SP0450	Function configuration	Front body control module (fbcm)
SP0451	Write Vin	Rear body control module (RBCM)
SP0452	Write programming date	Rear body control module (RBCM)
SP0453	Vehicle configuration code	Rear body control module (RBCM)
SP0454	Function configuration	Rear body control module (RBCM)
SP0455	Write VIN code	engine control module (EMS)
SP0456	Write VIN code	body control module (BCM)
SP0457	Write programming date	body control module (BCM)
SP0458	Vehicle configuration code	body control module (BCM)
SP0459	Write VIN code	automatic transmission control unit (TCU)

SP0460	Clear clutch self-learning value	automatic transmission control unit (TCU)
SP0461	Write VIN code	brake liquid control module (ESP)
SP0462	exhaust	brake liquid control module (ESP)
SP0463	Write VIN code	instrument cluster module (ICM)
SP0464	Vehicle configuration code	instrument cluster module (ICM)
SP0465	service mileage set	instrument cluster module (ICM)
SP0466	Write Vin	supplemental restraint system (SRS) (SDM)
SP0467	Airbag initiation status setting	supplemental restraint system (SRS) (SDM)
SP0468	Write VIN code	passive entry passive start (PEPS)
SP0469	Angle zero calibration	Electronic power steering (Henglong)
SP0470	Clear angle zero data	Electronic power steering (Henglong)
SP0471	Write VIN code	Electronic power steering (Henglong)
SP0472	Angle zero calibration	Electronic power steering (longrun)
SP0473	Clear angle zero data	Electronic power steering (longrun)
SP0474	Write VIN code	Electronic power steering (longrun)
SP0475	Write Vin	electronic steering column lock (ESCL)
SP0476	Write Vin	air conditioning controller module
SP0477	Write VIN code	DVD navigation module (HUM)
SP0478	Write VIN code	engine system (EMS)
SP0479	Write VIN code	automatic transmission (AT) system
SP0480	Write programming date	automatic transmission (AT) system
SP0481	Write vehicle characteristic code	automatic transmission (AT) system
SP0482	ECU hardware reset	automatic transmission (AT) system
SP0483	Reset adaptation	automatic transmission (AT) system
SP0484	Write VIN code	automatic headlight system
SP0485	Chassis zero point correction	automatic headlight system
SP0486	Write VIN code	electronic steering column lock (ESCL)
SP0487	ECU software programming	electronic steering column lock (ESCL)
SP0488	Write programming date	electronic steering column lock (ESCL)
SP0489	Write VIN code	body control module (BCM)
SP0490	Function configuration - manual configuration	body control module (BCM)
SP0491	Function configuration - automatic configuration	body control module (BCM)
SP0492	Write VIN code	passive entry passive start (PEPS)
SP0493	Vehicle network configuration	passive entry passive start (PEPS)
SP0494	Write VIN code	electronic stability program (ESP)
SP0495	Vehicle configuration (ESP)	electronic stability program (ESP)
SP0496	Accumulator exhaust	electronic stability program (ESP)
SP0497	Four wheel exhaust	electronic stability program (ESP)

SP0498	Steering wheel angle sensor calibration (ESP)	electronic stability program (ESP)
SP0499	Write VIN code	tire pressure monitor system (TPMS)
SP0500	Tire pressure sensor replacement	tire pressure monitor system (TPMS)
SP0501	Transposition of tire pressure sensor	tire pressure monitor system (TPMS)
SP0502	Tire sensor learning	tire pressure monitor system (TPMS)
SP0503	Write VIN code	supplemental restraint system (SRS)
SP0504	Function configuration - manual configuration	supplemental restraint system (SRS)
SP0505	Function configuration - automatic configuration	supplemental restraint system (SRS)
SP0506	Write VIN code	instrument board system (ICM/IP)
SP0507	Function configuration - automatic configuration	instrument board system (ICM/IP)
SP0508	Function configuration - manual configuration	instrument board system (ICM/IP)
SP0509	Write VIN code	engine system (EMS)
SP0510	Write programming date	engine system (EMS)
SP0511	Write VIN code	automatic transmission (AT) system
SP0512	Write programming date	automatic transmission (AT) system
SP0513	Write vehicle characteristic code	automatic transmission (AT) system
SP0514	ECU hardware reset	automatic transmission (AT) system
SP0515	Reset adaptation	automatic transmission (AT) system
SP0516	Write VIN code	supplemental restraint system (SRS)
SP0517	Write programming date	supplemental restraint system (SRS)
SP0518	Function configuration	supplemental restraint system (SRS)
SP0519	Write VIN code	electronic stability program (ESP)
SP0520	Write programming date	electronic stability program (ESP)
SP0521	ECU software reset	electronic stability program (ESP)
SP0522	Tire pressure (DDS) reset	electronic stability program (ESP)
SP0523	Calibration procedure	electronic stability program (ESP)
SP0524	Write VIN code	instrument board system (ICM/IP)
SP0525	Write programming date	instrument board system (ICM/IP)
SP0526	Vehicle configuration	instrument board system (ICM/IP)
SP0527	network configuration	instrument board system (ICM/IP)
SP0528	service mileage set	instrument board system (ICM/IP)
SP0529	Write total mileage	instrument board system (ICM/IP)
SP0530	Write VIN code	automatic air conditioning system
SP0531	Write programming date	automatic air conditioning system
SP0532	Write VIN code	Electronic power steering (Henglong)
SP0533	Write programming date	Electronic power steering (Henglong)
SP0534	ECU software reset	Electronic power steering (Henglong)

SP0535	Angle zero calibration	Electronic power steering (Henglong)
SP0536	Clear angle median data	Electronic power steering (Henglong)
SP0537	Write VIN code	Electronic power steering (longrun)
SP0538	Write programming date	Electronic power steering (longrun)
SP0539	Angle zero calibration	Electronic power steering (longrun)
SP0540	Clear angle median data	Electronic power steering (longrun)
SP0541	Write VIN code	electronic steering column lock (ESCL)
SP0542	ECU software reset	electronic steering column lock (ESCL)
SP0543	Write VIN code	body control module (BCM)
SP0544	Write programming date	body control module (BCM)
SP0545	ECU software reset	body control module (BCM)
SP0546	Vehicle configuration	body control module (BCM)
SP0547	network configuration	body control module (BCM)
SP0548	Write VIN code	passive entry passive start (PEPS)
SP0549	Write programming date	passive entry passive start (PEPS)
SP0550	ECU hardware reset	passive entry passive start (PEPS)
SP0551	Function configuration	passive entry passive start (PEPS)
SP0552	Write VIN code	central control infotainment system (EHU)
SP0553	Write programming date	central control infotainment system (EHU)
SP0554	ECU software reset	central control infotainment system (EHU)
SP0555	Function configuration	central control infotainment system (EHU)
SP0556	Software information update	Low configuration of Jicheng body controller (BCM)
SP0557	Standard pressure value writing	tire pressure monitor system (TPMS)
SP0558	The high voltage alarm compensation value is written	tire pressure monitor system (TPMS)
SP0559	Write tire pressure ID	tire pressure monitor system (TPMS)
SP0560	Vin code writing	Baolong tire pressure monitor system (TPMS)
SP0561	Standard pressure value writing	Baolong tire pressure monitor system (TPMS)
SP0562	High voltage alarm compensation value writing	Baolong tire pressure monitor system (TPMS)
SP0563	Write VIN code	Body control system (BCM)
SP0564	Read and write tire pressure ID	Body control system (BCM)
SP0565	Write VIN code	ETEC body control system (BCM)
SP0566	Write application software fingerprint data identifier	Combined electric engine system
SP0567	Vin code writing	Combined electric engine system
SP0568	Workshop code	Combined electric engine system
SP0569	Vin code writing	Delphi engine system
SP0570	Read write configuration	United electric vehicle body control system
SP0571	Read and write tire pressure sensor ID	United electric vehicle body control system

SP0572	Vin code writing	EtAc body control system
SP0573	Steering wheel position calibration	Power steering system in North Henan
SP0574	Internal exhaust	Anti lock braking system
SP0575	Internal exhaust	Bosch electronic stability system
SP0576	Acceleration sensor calibration	Bosch electronic stability system
SP0577	Configuration information writing	Bosch electronic stability system
SP0578	Steering wheel position calibration	Elida power steering system
SP0579	Vin code writing	supplemental restraint system (SRS)
SP0580	Ignition function setting	supplemental restraint system (SRS)
SP0581	Main airbag	supplemental restraint system (SRS)
SP0582	main/secondary airbag	supplemental restraint system (SRS)
SP0583	main/secondary airbag + left/right warning device	supplemental restraint system (SRS)
SP0584	main/secondary airbag + left/right side airbag + left/right crash sensor	supplemental restraint system (SRS)
SP0585	main/secondary airbag + left/right warning device + left/right side airbag + left/right crash sensor	supplemental restraint system (SRS)
SP0586	Standard pressure value writing	tire pressure monitor system (TPMS)
SP0587	High voltage alarm compensation value writing	tire pressure monitor system (TPMS)
SP0588	Write tire pressure ID	tire pressure monitor system (TPMS)
SP0589	Write VIN code	instrument display system
SP0590	Read write configuration	instrument display system
SP0591	Write VIN code	ORG transmission system (5AT)
SP0592	Write VIN code	Engine system (Visteon 415a)
SP0593	Reset all adaptions	BJ415A China Vagon engine svstem
SP0594	Atmospheric correction value fed back by air intake signal	BJ415A China Vagon engine system
SP0595	Half of the adaptive value of detonation ignition angle	BJ415A China Vagon engine system
SP0596	Throttle position adaptive value adjustment	BJ415A China Vagon engine system

SP0597	Additive / multiplicative adaptive factor of injection time for each cylinder row (oxygen sensor)	BJ415A China Vagon engine system
SP0598	Idle speed adaptive value	BJ415A China Vagon engine system
SP0599	Segment adaptive value of engine rough value	BJ415A China Vagon engine system
SP0600	Adaptive value of rough value of engine heated by catalytic package	BJ415A China Vagon engine system
SP0601	Carbon canister adaptation	BJ415A China Vagon engine system
SP0602	Idle speed - carbon oxide correction	BJ415A China Vagon engine system
SP0603	Target idle offset	BJ415A China Vagon engine system
SP0604	Drive control unit	BJ415A China Vagon engine system
SP0605	Traction control system	BJ415A China Vagon engine system
SP0606	speed	BJ415A China Vagon engine system
SP0607	Write calibration test serial number	BJ415A China Vagon engine system
SP0608	Write calibration data write date	BJ415A China Vagon engine system
SP0609	Write VIN code	BJ415A China Vagon engine system
SP0610	Write test serial number (ECU software)	BJ415A China Vagon engine system
SP0611	Write ECU software write date	BJ415A China Vagon engine system
SP0612	Write VIN code	Continental electronic engine system
SP0613	Vin programming	Delphi (bj415b, bj415c, bj418b) engine system
SP0614	Dental information learning	Delphi (bj415b, bj415c, bj418b) engine system
SP0615	Delphi broadcast code	469 engine system (Delphi)
SP0616	Vehicle identification code	469 engine system (Delphi)
SP0617	Repair shop or tester number	469 engine system (Delphi)
SP0618	Programming date	469 engine system (Delphi)
SP0619	ECU reset: power on	United Electronics dam15
SP0620	ECU reset: initial initialization	United Electronics dam15
SP0621	Write VIN code	United Electronics dam15
SP0622	Write the date of the last ECU overhaul	Bosch supplemental restraint system (SRS)
SP0623	Write in vehicle chassis number	Bosch supplemental restraint system (SRS)
SP0624	Software reset	Bosch supplemental restraint system (SRS)
SP0625	ECU reset	Engine system (United Electronics)
SP0626	Write VIN code	Engine system (United Electronics)

SP0627	ECU reset	469 engine system (UAES)
SP0628	Write VIN code	469 engine system (UAES)
SP0629	Delphi broadcast code	2.0T engine system (MT80)
SP0630	Vehicle identification code	2.0T engine system (MT80)
SP0631	Workshop code or diagnostic instrument serial number	2.0T engine system (MT80)
SP0632	Programming date	2.0T engine system (MT80)
SP0633	User end mode part number	2.0T engine system (MT80)
SP0634	Write VIN code	Liandian mel788 engine system
SP0635	Application software fingerprint data identifier	Combined electric engine system (EMS)
SP0636	Vehicle identification number (VIN)	Combined electric engine system (EMS)
SP0637	Workshop code	Combined electric engine system (EMS)
SP0638	Vin code programming	Combined electric engine system (EMS)
SP0639	Configure door closed but not locked prompt to open	Combined electric engine system (EMS)
SP0640	Configure the door closed but not locked to prompt closing	Combined electric engine system (EMS)
SP0641	Factory Reset	Combined electric engine system (EMS)
SP0642	Configure the door closed not locked prompt query	Combined electric engine system (EMS)
SP0643	Network protocol version information	Chongqing Qingshan AMT
SP0644	boot software version	Chongqing Qingshan AMT
SP0645	Application layer data version	Chongqing Qingshan AMT
SP0646	Current diagnostic mode	Chongqing Qingshan AMT
SP0647	Spare parts logistics information of vehicle manufacturer	Chongqing Qingshan AMT
SP0648	System supplier information	Chongqing Qingshan AMT
SP0649	VIN	Chongqing Qingshan AMT
SP0650	Vehicle ECU Hardware Information	Chongqing Qingshan AMT
SP0651	TCU hardware supplier information	Chongqing Qingshan AMT
SP0652	Transmission number	Chongqing Qingshan AMT
SP0653	TCU software name	Chongqing Qingshan AMT
SP0654	TCU software version	Chongqing Qingshan AMT

SP0655	Repair code or diagnostic instrument serial number	Chongqing Qingshan AMT
SP0656	Program version information	Chongqing Qingshan AMT
SP0657	Calibration version information	Chongqing Qingshan AMT
SP0658	Write clutch half joint	Chongqing Qingshan AMT
SP0659	Gearbox learning	Chongqing Qingshan AMT
SP0660	Clutch physical point self learning	Chongqing Qingshan AMT
SP0661	Clutch half node self learning	Chongqing Qingshan AMT
SP0662	Software reset	Chongqing Qingshan AMT
SP0663	Calibration function (this function is only applicable to high configuration vehicles with angle sensor)	North Henan power steering system (EPS)
SP0664	Steering wheel position calibration	Elida power steering system (EPS)
SP0665	Internal exhaust	anti-lock brake system (ABS)
SP0666	Ehcu production code	anti-lock brake system (ABS)
SP0667	EHCUC date code	anti-lock brake system (ABS)
SP0668	Ehcu play code	anti-lock brake system (ABS)
SP0669	Customer part number	anti-lock brake system (ABS)
SP0670	Software reset	Bosch supplemental restraint system (SRS)
SP0671	Write vehicle production date	Bosch supplemental restraint system (SRS)
SP0672	Write the date of the last ECU overhaul	Bosch supplemental restraint system (SRS)
SP0673	Write in vehicle chassis number	Bosch supplemental restraint system (SRS)
SP0674	Write vehicle production date	Bosch airbag system (SRS)
SP0675	Write the date of the last ECU overhaul	Bosch airbag system (SRS)
SP0676	Vin code	Delphi mt62.1 engine system
SP0677	repair shop number or test serial number	Delphi mt62.1 engine system
SP0678	Programming date	Delphi mt62.1 engine system
SP0679	Write VIN code	Delphi engine system (EMS)
SP0680	Write VIN code	Electric power steering (EPS)
SP0681	Write VIN code	passive entry passive start (PEPS)
SP0682	Write vehicle configuration	passive entry passive start (PEPS)
SP0683	Write VIN code	Front body control system (fbcu)
SP0684	Write vehicle configuration	Front body control system (fbcu)
SP0685	Write VIN code	rear body control module (RBCM)

SP0686	Write vehicle configuration	rear body control module (RBCM)
SP0687	FWD 1.5T+6MT	Electronic stability system (ESC)
SP0688	FWD 1.5T+5MT	Electronic stability system (ESC)
SP0689	FWD 1.5T+CVT	Electronic stability system (ESC)
SP0690	FWD 2.0T+6MT	Electronic stability system (ESC)
SP0691	FWD 2.0T+6AT	Electronic stability system (ESC)
SP0692	AWD 2.0T+6AT	Electronic stability system (ESC)
SP0693	Write VIN code	instrument system (IC)
SP0694	Write VIN code	air conditioning system
SP0695	Write vehicle configuration	air conditioning system
SP0696	Calibration function	Dunyang AVM (point A)
SP0697	Calibration function	lane departure warning (LDW)
SP0698	Inclination calibration	electronic parking brake (EPB)
SP0699	Left actuator release test	electronic parking brake (EPB)
SP0700	Right actuator release test	electronic parking brake (EPB)
SP0701	Left actuator recovery test	electronic parking brake (EPB)
SP0702	Right actuator recovery test	electronic parking brake (EPB)
SP0703	Write vehicle configuration	electronic parking brake (EPB)
SP0704	Write VIN code	Bunch transmission system (CVT)
SP0705	Write ABS configuration	Bunch transmission system (CVT)
SP0706	Write ESP configuration	Bunch transmission system (CVT)
SP0707	Replace ECU	electric power steering (EPS)
SP0708	Angle zero calibration	electric power steering (EPS)
SP0709	SAS steering angle sensor calibration	electric power steering (EPS)
SP0710	Replace ECU	air conditioning system (ACC)
SP0711	Replace ECU	multi media interface (MMI)
SP0712	Write configuration	multi media interface (MMI)
SP0713	Write VIN code	BWI anti-lock brake system (ABS)
SP0714	Write programming date	BWI anti-lock brake system (ABS)
SP0715	Vehicle configuration code	BWI anti-lock brake system (ABS)
SP0716	Software reset	Bosch supplemental restraint system (SRS)
SP0717	Write vehicle production date	Bosch supplemental restraint system (SRS)
SP0718	Write the date of the last ECU overhaul	Bosch supplemental restraint system (SRS)
SP0719	Write VIN code	Bosch supplemental restraint system (SRS)
SP0720	Steering wheel position calibration	Yilida electric power steering (EPS)
SP0721	Internal exhaust	anti-lock brake system (ABS)
SP0722	Ehcu production code	anti-lock brake system (ABS)

SP0723	EHCUC date code	anti-lock brake system (ABS)
SP0724	Ehcu play code	anti-lock brake system (ABS)
SP0725	Customer part number	anti-lock brake system (ABS)
SP0726	Write VIN code	instrument cluster module (ICM)
SP0727	Maintenance mileage writing	instrument cluster module (ICM)
SP0728	Total mileage write in	instrument cluster module (ICM)
SP0729	Write VIN code	warm air heating system (PTC)
SP0730	ECU reset	drive motor system (MCU)
SP0731	Write Vin	drive motor system (MCU)
SP0732	Write application fingerprint	drive motor system (MCU)
SP0733	ECU reset	integrated controller (VMS)
SP0734	Write Vin	integrated controller (VMS)
SP0735	Write application fingerprint	integrated controller (VMS)
SP0736	Write Vin	vehicle control unit (VCU)
SP0737	Write application fingerprint	vehicle control unit (VCU)
SP0738	Write Vin	charger control system (CHG)
SP0739	Write application fingerprint	charger control system (CHG)
SP0740	Write Vin	Drive motor system (MCU) (produced before April 1, 2017)
SP0741	Write application fingerprint	Drive motor system (MCU) (produced before April 1, 2017)
SP0742	Write Vin	drive motor system (MCU) (manufactured after Apr., 1st, 2017)
SP0743	Write application fingerprint	drive motor system (MCU) (manufactured after Apr., 1st, 2017)
SP0744	Write motor code	drive motor system (MCU) (manufactured after Apr., 1st, 2017)
SP0745	Write Vin	battery high voltage management system (BCU)
SP0746	Write application fingerprint	battery high voltage management system (BCU)
SP0747	Write Vin	battery high voltage management system (BCU) (manufactured after Apr., 1st, 2017)
SP0748	Write application fingerprint	battery high voltage management system (BCU) (manufactured after Apr., 1st, 2017)
SP0749	Write motor code	battery high voltage management system (BCU) (manufactured after Apr., 1st, 2017)
SP0750	Write Vin	compressor controller (EAS)
SP0751	Write application fingerprint	compressor controller (EAS)
SP0752	ECU reset	remote monitor system (RMS)
SP0753	Write Vin	remote monitor system (RMS)
SP0754	Write application fingerprint	remote monitor system (RMS)
SP0755	Write Vin	charger control system (CHG)

SP0756	Write application fingerprint	charger control system (CHG)
SP0757	Write Vin	battery management system (BMS)
SP0758	Write Vin	instrument cluster module (ICM)
SP0759	Write the total mileage	instrument cluster module (ICM)
SP0760	Remaining maintenance mileage	instrument cluster module (ICM)
SP0761	Write Vin	charger control system (CHG)
SP0762	Write application fingerprint	charger control system (CHG)
SP0763	Write Vin	Battery high voltage management system (BCU) (produced before April 1, 2017)
SP0764	Write application fingerprint	Battery high voltage management system (BCU) (produced before April 1, 2017)
SP0765	Write Vin	battery management system (BMS)
SP0766	Write Battery Code	battery management system (BMS)
SP0767	Write Vin	drive motor system (MCU)
SP0768	Write Vin	Drive motor system (MCU) (produced after April 1, 2017)
SP0769	Write application fingerprint	Drive motor system (MCU) (produced after April 1, 2017)
SP0770	Write motor code	Drive motor system (MCU) (produced after April 1, 2017)
SP0771	Write Vin	warm air heating system (PTC)
SP0772	Write application fingerprint	warm air heating system (PTC)
SP0773	Write Vin	Electric power steering system a (EPS)
SP0774	Write application fingerprint	Electric power steering system a (EPS)
SP0775	Write Vin	vehicle control unit (VCU)
SP0776	Write Vin	Power battery system (BMS Ppst)
SP0777	Write VIN code	instrument cluster module (ICM)
SP0778	Write application fingerprint	instrument cluster module (ICM)
SP0779	Write in remaining maintenance mileage	instrument cluster module (ICM)
SP0780	Total mileage write in	instrument cluster module (ICM)
SP0781	reversing radar configuration	instrument cluster module (ICM)
SP0782	Write Vin	on-board charger (OBC)
SP0783	Write application fingerprint	on-board charger (OBC)
SP0784	Write Vin	Power battery system (BMS Besk)
SP0785	Write Vin	central control infotainment system (EHU)
SP0786	Write application fingerprint	central control infotainment system (EHU)
SP0787	Write Vin	Drive motor system (MCU) (produced after April 1, 2017)

SP0788	Write application fingerprint	Drive motor system (MCU) (produced after April 1, 2017)
SP0789	Write motor code	Drive motor system (MCU) (produced after April 1, 2017)
SP0790	Write Vin	air conditioning system (ECC)
SP0791	Write real time voltage of EAS over current	compressor controller (EAS)
SP0792	Write real-time current of EAS over-current	compressor controller (EAS)
SP0793	Write the high over-current speed of EAS	compressor controller (EAS)
SP0794	Write the low over-current speed of EAS	compressor controller (EAS)
SP0795	Write bus overvoltage	compressor controller (EAS)
SP0796	Write bus undervoltage	compressor controller (EAS)
SP0797	Write real time voltage of EAS locked rotor bus	compressor controller (EAS)
SP0798	Write the real-time current value of EAS locked rotor	compressor controller (EAS)
SP0799	Write high locked rotor speed of EAS	compressor controller (EAS)
SP0800	Write low locked rotor speed of EAS	compressor controller (EAS)
SP0801	Write the fault bus voltage of EAS power tube	compressor controller (EAS)
SP0802	Write fault current of EAS power transistor	compressor controller (EAS)
SP0803	Write Vin	central control display (T-BOX)
SP0804	Write application fingerprint	central control display (T-BOX)
SP0805	Time sharing lease mode	central control display (T-BOX)
SP0806	Write Vin	body control module (BCM)
SP0807	Write vehicle definition bitmap	body control module (BCM)
SP0808	Write Vin	battery management system (BMS)
SP0809	Write Vin	Power battery system (BMS) (produced after April 1, 2017)
SP0810	Write Battery Code	Power battery system (BMS) (produced after April 1, 2017)
SP0811	Write Vin	electric power steering (EPS)
SP0812	Write application fingerprint	electric power steering (EPS)
SP0813	Write Vin	drive motor system (MCU)
SP0814	Write VIN code	instrument cluster module (ICM)
SP0815	Write application fingerprint	instrument cluster module (ICM)
SP0816	Write in remaining maintenance mileage	instrument cluster module (ICM)

SP0817	Total mileage write in	instrument cluster module (ICM)
SP0818	reversing radar configuration	instrument cluster module (ICM)
SP0819	Write Vin	battery management system (BMS)
SP0820	Write Vin	warm air heating system (PTC)
SP0821	Write application fingerprint	warm air heating system (PTC)
SP0822	Write Vin	instrument cluster module (ICM)
SP0823	Maintenance mileage writing (maintenance return to zero)	instrument cluster module (ICM)
SP0824	Write total mileage	instrument cluster module (ICM)
SP0825	Write Vin	central control system (HUM)
SP0826	Write Vin	electric power steering (EPS)
SP0827	Write Vin	anti-lock brake system (ABS)
SP0828	Write VIN code	body control module (BCM)
SP0829	Write vehicle definition bitmap	body control module (BCM)
SP0830	Replace the BCM	body control module (BCM)
SP0831	Day light switch	body control module (BCM)
SP0832	Write Vin	Driving motor system (MCU) (Funeng Battery + Juvi motor) (produced after April 1, 2017)
SP0833	Write application fingerprint	Driving motor system (MCU) (Funeng Battery + Juvi motor) (produced after April 1, 2017)
SP0834	Write motor code	Driving motor system (MCU) (Funeng Battery + Juvi motor) (produced after April 1, 2017)
SP0835	Write Vin	Driving motor system (MCU) (Prader Battery + Juvi motor) (produced after April 1, 2017)
SP0836	Write application fingerprint	Driving motor system (MCU) (Prader Battery + Juvi motor) (produced after April 1, 2017)
SP0837	Write motor code	Driving motor system (MCU) (Prader Battery + Juvi motor) (produced after April 1, 2017)
SP0838	Write Vin	Power battery system (BMS) (produced before April 1, 2017)
SP0839	Write Vin	Power battery system (BMS) (Funeng Battery + Juvi motor) (produced after April 1, 2017)
SP0840	Write Battery Code	Power battery system (BMS) (Funeng Battery + Juvi motor) (produced after April 1, 2017)
SP0841	Write Vin	Power battery system (BMS) (Prader Battery + Juvi motor) (produced after April 1, 2017)
SP0842	Write Battery Code	Power battery system (BMS) (Prader Battery + Juvi motor) (produced after April 1, 2017)
SP0843	Write Vin	pedestrians warning system (VSP)
SP0844	Write Vin	charging port management module (CMU)
SP0845	Write Vin	drive motor system (MCU)
SP0846	Write application fingerprint	drive motor system (MCU)
SP0847	Write Vin	Drive motor system (MCU) (produced after April 1, 2017)

SP0848	Write application fingerprint	Drive motor system (MCU) (produced after April 1, 2017)
SP0849	Write motor code	Drive motor system (MCU) (produced after April 1, 2017)
SP0850	Write Vin	instrument cluster module (ICM)
SP0851	Write application fingerprint	instrument cluster module (ICM)
SP0852	Maintenance mileage writing	instrument cluster module (ICM)
SP0853	Total mileage write in	instrument cluster module (ICM)
SP0854	Write Vin	air conditioning system (ECC)
SP0855	Write application fingerprint	air conditioning system (ECC)
SP0856	Write Vin	battery management system (BMS)
SP0857	Write application fingerprint	battery management system (BMS)
SP0858	Write Vin	Power battery system (BMS) (produced after April 1, 2017)
SP0859	Write Battery Code	Power battery system (BMS) (produced after April 1, 2017)
SP0860	Write Vin	Electric power steering system B (EPS)
SP0861	Write Vin	@#brake liquid control module (ESP Continental)
SP0862	Write OEM unique configuration 1	@#brake liquid control module (ESP BWI)
SP0863	Write application data identifier	@#brake liquid control module (ESP BWI)
SP0864	Write the vehicle manufacturer's spare part number	@#brake liquid control module (ESP BWI)
SP0865	Write Vin	@#brake liquid control module (ESP BWI)
SP0866	Write calibration date information	@#brake liquid control module (ESP BWI)
SP0867	Write ECU installation date data identifier	@#brake liquid control module (ESP BWI)
SP0868	Write OEM unique configuration 2	@#brake liquid control module (ESP BWI)
SP0869	Write OEM unique configuration 3	@#brake liquid control module (ESP BWI)
SP0870	Write back to supplier ehcu	@#brake liquid control module (ESP BWI)
SP0871	Write factory run count	@#brake liquid control module (ESP BWI)
SP0872	Write Vin	@#anti-lock brake system (ABS)
SP0873	Write Vin	body control module (BCM)
SP0874	Write application fingerprint	body control module (BCM)
SP0875	Write pin	body control module (BCM)
SP0876	Write ESK code	body control module (BCM)
SP0877	Replace the BCM	body control module (BCM)
SP0878	Write VIN code	supplemental restraint system (SRS) (SDM)
SP0879	Write production date	supplemental restraint system (SRS) (SDM)

SP0880	Run / disable ECU ignition	supplemental restraint system (SRS) (SDM)
SP0881	Write VIN code	passive entry passive start (PEPS)
SP0882	Write VIN code	electronic steering column lock (ESCL)
SP0883	Write user type	electronic steering column lock (ESCL)
SP0884	Write VIN code	tire pressure monitor system (TPMS)
SP0885	Write tire sensor ID: left front	tire pressure monitor system (TPMS)
SP0886	Write tire sensor ID: right front	tire pressure monitor system (TPMS)
SP0887	Write tire sensor ID: rear left	tire pressure monitor system (TPMS)
SP0888	Write tire sensor ID: right rear	tire pressure monitor system (TPMS)
SP0889	Tire sensor learning: left front	tire pressure monitor system (TPMS)
SP0890	Tire sensor learning: right front	tire pressure monitor system (TPMS)
SP0891	Tire sensor learning: rear left	tire pressure monitor system (TPMS)
SP0892	Tire sensor learning: right rear	tire pressure monitor system (TPMS)
SP0893	Tire sensor position exchange:left front,right front	tire pressure monitor system (TPMS)
SP0894	Tire sensor position exchange: left front, right rear	tire pressure monitor system (TPMS)
SP0895	Tire sensor position exchange: left front, left rear	tire pressure monitor system (TPMS)
SP0896	Tire sensor position exchange: right front, right rear	tire pressure monitor system (TPMS)
SP0897	Tire sensor position exchange: right front, left rear	tire pressure monitor system (TPMS)
SP0898	Tire sensor position exchange: right rear, left rear	tire pressure monitor system (TPMS)
SP0899	Delete front left tire sensor	tire pressure monitor system (TPMS)
SP0900	Remove front right tire sensor	tire pressure monitor system (TPMS)
SP0901	Delete rear left tire sensor	tire pressure monitor system (TPMS)
SP0902	Remove rear right tire sensor	tire pressure monitor system (TPMS)
SP0903	Delete all tire sensors	tire pressure monitor system (TPMS)
SP0904	Write VIN code	central display (MFD)

SP0905	Write vehicle definition bitmap	central display (MFD)
SP0906	Write real time voltage of EAS over current	compressor controller (EAS)
SP0907	Write real-time current of EAS over-current	compressor controller (EAS)
SP0908	Write operation overvoltage	compressor controller (EAS)
SP0909	Write operation undervoltage	compressor controller (EAS)
SP0910	Write standby overvoltage	compressor controller (EAS)
SP0911	Write standby undervoltage	compressor controller (EAS)
SP0912	Write the real-time voltage value of communication fault	compressor controller (EAS)
SP0913	Write real time current value of communication fault	compressor controller (EAS)
SP0914	Write the overpower downfrequency real-time current value	compressor controller (EAS)
SP0915	Write abnormal real time current value	compressor controller (EAS)
SP0916	Write VIN code	brake liquid control module (ESP)
SP0917	Steering angle zero calibration	brake liquid control module (ESP)
SP0918	Write VIN code	automatic headlight levelling system
SP0919	Chassis zero point correction	automatic headlight levelling system
SP0920	Write VIN code	passive entry passive start (PEPS)
SP0921	Write VIN code	supplemental restraint system (SRS) (SDM)
SP0922	Write VIN code	Rear view camera (RVC)
SP0923	Write VIN code	reversing radar - side view assist system (SVA-PAS)
SP0924	Write VIN code	DVD navigation module (EHU)
SP0925	Write VIN code	electronic steering column lock (ESCL)
SP0926	C70/45mm	electronic steering column lock (ESCL)
SP0927	C60/45mm	electronic steering column lock (ESCL)
SP0928	C50/45mm	electronic steering column lock (ESCL)
SP0929	Write VIN code	tire pressure monitor system (TPMS)
SP0930	Write VIN code	driver seat module (DSM)
SP0931	Write VIN code	T module
SP0932	Write VIN code	Body electronic control module (Lear) (BCM)
SP0933	Write VIN code	Body electronic control module (United Power) (BCM)
SP0934	Write VIN code	Power battery system (BMS) (produced before April 1, 2017)

SP0935	Write VIN code	Power battery system (BMS) (produced after April 1, 2017)
SP0936	Write application fingerprint	Power battery system (BMS) (produced after April 1, 2017)
SP0937	Write Battery Code	Power battery system (BMS) (produced after April 1, 2017)
SP0938	Write VIN code	Drive motor system (MCU) (produced before April 1, 2017)
SP0939	Write VIN code	Drive motor system (MCU) (produced after April 1, 2017)
SP0940	Write motor code	Drive motor system (MCU) (produced after April 1, 2017)
SP0941	Write VIN code	remote monitor system (RMS)
SP0942	Write VIN code	on-board charger (OBC)
SP0943	Write VIN code	electric power steering (EPS)
SP0944	Steering angle zero calibration	electric power steering (EPS)
SP0945	Write VIN code	instrument cluster module (ICM)
SP0946	Write the total mileage	instrument cluster module (ICM)
SP0947	Write VIN code	entertainment head unit (EHU)
SP0948	Write VIN code	anti-lock brake system (ABS)
SP0949	Write VIN code	supplemental restraint system (SRS) (SDM)
SP0950	Write VIN code	pedestrians proximity voice warning (VSP)
SP0953	Write VIN code	air conditioning system (ECC)
SP0954	Write VIN code	Power battery system (BMS) (produced before April 1, 2017)
SP0955	Write VIN code	Drive motor system (MCU) (produced before April 1, 2017)
SP0956	Write VIN code	remote monitor system (RMS)
SP0957	Write VIN code	on-board charger (OBC)
SP0958	Write VIN code	instrument cluster module (ICM)
SP0959	Write VIN code	pedestrians proximity voice warning (VSP)
SP0960	Write VIN code	vehicle control unit (VCU)
SP0961	Write VIN code	Power battery system (BMS) (produced before April 1, 2017)
SP0962	Write VIN code	Power battery system (BMS) (produced after April 1, 2017)
SP0963	Write Battery Code	Power battery system (BMS) (produced after April 1, 2017)
SP0964	Write VIN code	Drive motor system (MCU) (produced before April 1, 2017)
SP0965	Write application fingerprint	Drive motor system (MCU) (produced before April 1, 2017)
SP0966	Write VIN code	Drive motor system (MCU) (produced after April 1, 2017)
SP0967	Write Battery Code	Drive motor system (MCU) (produced after April 1, 2017)
SP0968	Write application fingerprint	Drive motor system (MCU) (produced after April 1, 2017)

SP0969	Write VIN code	remote monitor system (RMS)
SP0970	Write VIN code	instrument cluster module (ICM)
SP0971	Write total mileage	instrument cluster module (ICM)
SP0972	Write in remaining maintenance mileage	instrument cluster module (ICM)
SP0973	Write VIN code	electric power steering (EPS)
SP0974	Write VIN code	air conditioning system (ECC)
SP0975	Write VIN code	pedestrians proximity voice warning (VSP)
SP0976	Write VIN code	compressor controller (EAS)
SP0977	Write bus real time voltage 1	compressor controller (EAS)
SP0978	Write compressor real time current 1	compressor controller (EAS)
SP0979	Write compressor real time current 2	compressor controller (EAS)
SP0980	Write compressor real time current 3	compressor controller (EAS)
SP0981	Write bus real time voltage 2	compressor controller (EAS)
SP0982	Write bus real time voltage 3	compressor controller (EAS)
SP0983	Write bus real time voltage 4	compressor controller (EAS)
SP0984	Write compressor real time current 4	compressor controller (EAS)
SP0985	Write bus real time current	compressor controller (EAS)
SP0986	Write bus real time voltage 5	compressor controller (EAS)
SP0987	Write VIN code	on-board charger (OBC)
SP0988	Write VIN code	brake liquid control module (ESP)
SP0989	Fill incomplete	brake liquid control module (ESP)
SP0990	The filling is complete and correct	brake liquid control module (ESP)
SP0991	Fill complete but incorrect	brake liquid control module (ESP)
SP0992	Bosch distribution	brake liquid control module (ESP)
SP0993	Write EOL status	brake liquid control module (ESP)
SP0994	Fill incomplete	brake liquid control module (ESP)
SP0995	The filling is complete and correct	brake liquid control module (ESP)
SP0996	Fill complete but incorrect	brake liquid control module (ESP)
SP0997	Bosch distribution	brake liquid control module (ESP)
SP0998	Write engine displacement	brake liquid control module (ESP)
SP0999	Write VIN code	automatic headlight levelling system
SP1000	Chassis zero point correction	automatic headlight levelling system

SP1001	Write VIN code	passive entry passive start (PEPS)
SP1002	Write VIN code	supplemental restraint system (SRS) (SDM)
SP1003	Write VIN code	entertainment head unit (HUM)
SP1004	Write VIN code	Rear view camera (RVC)
SP1005	Write VIN code	side view assist system - reversing radar (SVA-PAS)
SP1006	Write VIN code	electronic steering column lock (ESCL)
SP1007	Write user type	electronic steering column lock (ESCL)
SP1008	Write VIN code	tire pressure monitor system (TPMS)
SP1009	Write tire sensor ID: left front	tire pressure monitor system (TPMS)
SP1010	Write tire sensor ID: right front	tire pressure monitor system (TPMS)
SP1011	Write tire sensor ID: rear left	tire pressure monitor system (TPMS)
SP1012	Write tire sensor ID: right rear	tire pressure monitor system (TPMS)
SP1013	Tire sensor learning: left front	tire pressure monitor system (TPMS)
SP1014	Tire sensor learning: right front	tire pressure monitor system (TPMS)
SP1015	Tire sensor learning: rear left	tire pressure monitor system (TPMS)
SP1016	Tire sensor learning: right rear	tire pressure monitor system (TPMS)
SP1017	Tire sensor position exchange: left front, right front	tire pressure monitor system (TPMS)
SP1018	Tire sensor position exchange: left front, right rear	tire pressure monitor system (TPMS)
SP1019	Tire sensor position exchange: left front, right rear	tire pressure monitor system (TPMS)
SP1020	Tire sensor position exchange: right front, left rear	tire pressure monitor system (TPMS)
SP1021	Tire sensor position exchange: right front, left rear	tire pressure monitor system (TPMS)
SP1022	Tire sensor position exchange: right rear, left rear	tire pressure monitor system (TPMS)
SP1023	Delete front left tire sensor	tire pressure monitor system (TPMS)
SP1024	Remove front right tire sensor	tire pressure monitor system (TPMS)
SP1025	Delete rear left tire sensor	tire pressure monitor system (TPMS)

SP1026	Remove rear right tire sensor	tire pressure monitor system (TPMS)
SP1027	Delete all tire sensors	tire pressure monitor system (TPMS)
SP1028	Write VIN code	driver seat module (DSM)
SP1029	Write TLA timer time	driver seat module (DSM)
SP1030	Dwell time of write button	driver seat module (DSM)
SP1031	Number of write end point restudy	driver seat module (DSM)
SP1032	Write VIN code	body control module (BCM)
SP1033	Write vehicle definition bitmap	body control module (BCM)
SP1034	Write application fingerprint	body control module (BCM)
SP1035	Write VIN code	vehicle control unit (VCU)
SP1036	Write VIN code	battery management system (BMS)
SP1037	Write Battery Code	battery management system (BMS)
SP1038	Write VIN code	drive motor system (MCU)
SP1039	Write motor code	drive motor system (MCU)
SP1040	Write VIN code	on-board charger (OBC)
SP1041	Write VIN code	remote monitor system (T-BOX)
SP1042	Time sharing lease mode	remote monitor system (T-BOX)
SP1043	Write VIN code	pedestrians proximity voice warning (VSP)
SP1044	Write VSP default volume	pedestrians proximity voice warning (VSP)
SP1045	Write VIN code	Rear view camera (RVC)
SP1046	Write VIN code	warm air heating system (PTC)
SP1047	Write VIN code	compressor controller (EAS)
SP1048	Write VIN code	entertainment head unit (EHU)
SP1049	Write VIN code	electric power steering (EPS)
SP1050	Write VIN code	anti-lock brake system (ABS)
SP1051	Write VIN code	electronic parking brake (EPB)
SP1052	Write VIN code	air conditioning system (ECC)
SP1053	Write VIN code	instrument cluster module (ICM)
SP1054	Total mileage	instrument cluster module (ICM)
SP1055	Remaining maintenance mileage	instrument cluster module (ICM)
SP1056	Write VIN code	passive entry passive start (PEPS)
SP1057	Write vehicle status	passive entry passive start (PEPS)
SP1058	Write learning state	passive entry passive start (PEPS)
SP1059	Write VIN code	supplemental restraint system (SRS) (SDM)
SP1060	Write customer mode	supplemental restraint system (SRS) (SDM)
SP1061	Equipped with driver's airbag	supplemental restraint system (SRS) (SDM)
SP1062	Equipped with passenger airbag	supplemental restraint system (SRS) (SDM)
SP1063	Configure driver seat belt pretensioner	supplemental restraint system (SRS) (SDM)

SP1064	Equipped with seat belt pretensioner	supplemental restraint system (SRS) (SDM)
SP1065	Equipped with driver's side airbag	supplemental restraint system (SRS) (SDM)
SP1066	Equipped with passenger side airbags	supplemental restraint system (SRS) (SDM)
SP1067	Equipped with driver's air curtain	supplemental restraint system (SRS) (SDM)
SP1068	Equipped with passenger air curtain	supplemental restraint system (SRS) (SDM)
SP1069	Configure driver side peripheral acceleration sensor	supplemental restraint system (SRS) (SDM)
SP1070	Configuration of passenger side peripheral acceleration sensor	supplemental restraint system (SRS) (SDM)
SP1071	Configuration of driver side front impact acceleration sensor	supplemental restraint system (SRS) (SDM)
SP1072	Equipped with passenger side front impact acceleration sensor	supplemental restraint system (SRS) (SDM)
SP1073	Configure system warning lamp (via can)	supplemental restraint system (SRS) (SDM)
SP1074	Configure collision output (via can)	supplemental restraint system (SRS) (SDM)
SP1075	Write VIN code	cabin electrical drive controller (UEC)
SP1076	Write VIN code	tire pressure monitor system (TPMS)
SP1077	Write left front wheel sensor ID	tire pressure monitor system (TPMS)
SP1078	Write right front wheel sensor ID	tire pressure monitor system (TPMS)
SP1079	Write left rear wheel sensor ID	tire pressure monitor system (TPMS)
SP1080	Write right rear wheel sensor ID	tire pressure monitor system (TPMS)
SP1081	Write learning left front wheel sensor ID	tire pressure monitor system (TPMS)
SP1082	Write learning right front wheel sensor ID	tire pressure monitor system (TPMS)
SP1083	Write learning left rear wheel sensor ID	tire pressure monitor system (TPMS)
SP1084	Write learning right rear wheel sensor ID	tire pressure monitor system (TPMS)
SP1085	Write ECU system initialization	tire pressure monitor system (TPMS)
SP1086	Write VIN code	reversing radar - side view assist system (SVA-PAS)
SP1087	Write VIN code	body control module (BCM)

SP1088	Write vehicle characteristic symbol	body control module (BCM)
SP1089	Write VIN code	vehicle battery control unit (VBU)
SP1090	Write VIN code	drive motor system (MCU)
SP1091	Write application fingerprint	drive motor system (MCU)
SP1092	Write VIN code	battery high voltage management system (BCU)
SP1093	Write Battery Code	battery high voltage management system (BCU)
SP1094	Write VIN code	on-board charger (OBC)
SP1095	Write VIN code	remote monitor system (RMS)
SP1096	Write VIN code	anti-lock brake system (ABS)
SP1097	Write VIN code	instrument cluster module (ICM)
SP1098	Write the total mileage	instrument cluster module (ICM)
SP1099	Write VIN code	vehicle control unit (VCU)
SP1100	Write VIN code	pedestrians proximity voice warning (VSP)
SP1101	Write VIN code	vehicle control unit (VCU)
SP1102	Write VIN code	drive motor system (MCU)
SP1103	Write motor code	drive motor system (MCU)
SP1104	Write VIN code	battery management system (BMS)
SP1105	Write Battery Code	battery management system (BMS)
SP1106	Write VIN code	air conditioning system (ECC)
SP1107	Write VIN code	compressor controller (EAS)
SP1108	Write VIN code	warm air heating system (PTC)
SP1109	Write VIN code	remote monitor system (RMS)
SP1110	Write VIN code	on-board charger (OBC)
SP1111	Write VIN code	passive entry passive start (PEPS)
SP1112	Offline ESCL learning	passive entry passive start (PEPS)
SP1113	After sales replacement of VCU	passive entry passive start (PEPS)
SP1114	Replace peeps after sale	passive entry passive start (PEPS)
SP1115	Write VIN code	vehicle control unit (VCU)
SP1116	Write VIN code	drive motor system (MCU)
SP1117	Write motor code	drive motor system (MCU)
SP1118	Write VIN code	anti-lock brake system (ABS)
SP1119	Write VIN code	body control module (BCM)
SP1120	Write vehicle characteristic symbol	body control module (BCM)
SP1121	Offline configuration	body control module (BCM)
SP1122	Write VIN code	compressor controller (EAS)
SP1123	Write VIN code	air conditioning system (ECC)
SP1124	Write VIN code	around view monitor (AVM)
SP1125	Write VIN code	on-board charger (OBC)
SP1126	Write VIN code	passive entry passive start (PEPS)
SP1127	Offline ESCL learning	passive entry passive start (PEPS)
SP1128	After sales replacement of VCU	passive entry passive start (PEPS)
SP1129	Replace peeps after sale	passive entry passive start (PEPS)
SP1130	Write VIN code	remote monitor system (T-BOX)
SP1131	Time sharing lease mode	remote monitor system (T-BOX)

SP1132	Write VIN code	external intelligent electric box (UEC)
SP1133	Write VIN code	auto parking system (APA)
SP1134	Write VIN code	entertainment head unit (HUM)
SP1135	Read write configuration	entertainment head unit (HUM)
SP1136	Write VIN code	electric power steering (EPS)
SP1137	Write VIN code	instrument cluster module (ICM)
SP1138	Total mileage	instrument cluster module (ICM)
SP1139	Remaining maintenance mileage	instrument cluster module (ICM)
SP1140	Read write offline configuration	instrument cluster module (ICM)
SP1141	Write VIN code	gateway system
SP1142	Write VIN code	warm air heating system (PTC)
SP1143	Write VIN code	Rear view camera (RVC)
SP1144	Write VIN code	supplemental restraint system (SRS) (SDM)
SP1145	Write customer mode	supplemental restraint system (SRS) (SDM)
SP1146	Read write configuration	supplemental restraint system (SRS) (SDM)
SP1147	Write VIN code	tire pressure monitor system (TPMS)
SP1148	Write left front wheel sensor ID	tire pressure monitor system (TPMS)
SP1149	Write right front wheel sensor ID	tire pressure monitor system (TPMS)
SP1150	Write left rear wheel sensor ID	tire pressure monitor system (TPMS)
SP1151	Write right rear wheel sensor ID	tire pressure monitor system (TPMS)
SP1152	Tire sensor learning: left front	tire pressure monitor system (TPMS)
SP1153	Tire sensor learning: right front	tire pressure monitor system (TPMS)
SP1154	Tire sensor learning: rear left	tire pressure monitor system (TPMS)
SP1155	Tire sensor learning: right rear	tire pressure monitor system (TPMS)
SP1156	Write ECU system initialization	tire pressure monitor system (TPMS)
SP1157	Write VIN code	low speed driving pedestrian prompt system (VSP)
SP1158	Write VSP default volume	low speed driving pedestrian prompt system (VSP)
SP1159	Write VIN code	vehicle control unit (VCU)
SP1160	Data terminal communication loss handling mode configuration	vehicle control unit (VCU)
SP1161	Write VIN code	battery management system (BMS)
SP1162	Write Battery Code	battery management system (BMS)
SP1163	Write VIN code	drive motor system (MCU)

SP1164	Write motor code	drive motor system (MCU)
SP1165	Write application fingerprint	drive motor system (MCU)
SP1166	Write VIN code	on-board charger (OBC)
SP1167	Write VIN code	air conditioning control system (ECC)
SP1168	Write VIN code	warm air heating system (PTC)
SP1169	Write VIN code	remote monitor system (RMS)
SP1170	Write application fingerprint	remote monitor system (RMS)
SP1171	Write VIN code	instrument cluster module (ICM)
SP1172	Write the total mileage	instrument cluster module (ICM)
SP1173	Remaining maintenance mileage	instrument cluster module (ICM)
SP1174	Write VIN code	air conditioning compressor control system (EAS)
SP1175	Write VIN code	anti-lock brake system (ABS)
SP1176	Fill incomplete	anti-lock brake system (ABS)
SP1177	The filling is complete and correct	anti-lock brake system (ABS)
SP1178	Fill complete but incorrect	anti-lock brake system (ABS)
SP1179	Bosch distribution	anti-lock brake system (ABS)
SP1180	Fill incomplete	anti-lock brake system (ABS)
SP1181	The filling is complete and correct	anti-lock brake system (ABS)
SP1182	Fill complete but incorrect	anti-lock brake system (ABS)
SP1183	Bosch distribution	anti-lock brake system (ABS)
SP1184	Write VIN code	body control module (BCM)
SP1185	Write vehicle definition bitmap	body control module (BCM)
SP1186	Replace the BCM	body control module (BCM)
SP1187	Day light switch	body control module (BCM)
SP1188	not configured	body control module (BCM)
SP1189	Configured	body control module (BCM)
SP1190	not configured	body control module (BCM)
SP1191	Configured	body control module (BCM)
SP1192	not configured	body control module (BCM)
SP1193	Configured	body control module (BCM)
SP1194	not configured	body control module (BCM)
SP1195	Configured	body control module (BCM)
SP1196	not configured	body control module (BCM)
SP1197	Configured	body control module (BCM)
SP1198	not configured	body control module (BCM)
SP1199	Configured	body control module (BCM)
SP1200	not configured	body control module (BCM)
SP1201	Configured	body control module (BCM)
SP1202	0 no pas	body control module (BCM)
SP1203	1 Hard-PAS	body control module (BCM)

SP1204	2 CAN-PAS	body control module (BCM)
SP1205	0 no pas	body control module (BCM)
SP1206	1 Hard-PAS	body control module (BCM)
SP1207	2 CAN-PAS	body control module (BCM)
SP1208	Write Vin	charging port management module (CMU)
SP1209	Write VIN code	low voltage charging system (DC/DC)
SP1210	Write VIN code	electronic steering column lock (ESCL)
SP1211	C70/45mm	electronic steering column lock (ESCL)
SP1212	C60/45mm	electronic steering column lock (ESCL)
SP1213	C50/45mm	electronic steering column lock (ESCL)
SP1214	Write VIN code	passive entry passive start (PEPS)
SP1215	not active	passive entry passive start (PEPS)
SP1216	activation	passive entry passive start (PEPS)
SP1217	not active	passive entry passive start (PEPS)
SP1218	activation	passive entry passive start (PEPS)
SP1219	0	passive entry passive start (PEPS)
SP1220	1	passive entry passive start (PEPS)
SP1221	two	passive entry passive start (PEPS)
SP1222	four	passive entry passive start (PEPS)
SP1223	not active	passive entry passive start (PEPS)
SP1224	activation	passive entry passive start (PEPS)
SP1225	not active	passive entry passive start (PEPS)
SP1226	activation	passive entry passive start (PEPS)
SP1227	not active	passive entry passive start (PEPS)
SP1228	activation	passive entry passive start (PEPS)
SP1229	not active	passive entry passive start (PEPS)
SP1230	activation	passive entry passive start (PEPS)
SP1231	not active	passive entry passive start (PEPS)
SP1232	activation	passive entry passive start (PEPS)
SP1233	not active	passive entry passive start (PEPS)
SP1234	activation	passive entry passive start (PEPS)
SP1235	not active	passive entry passive start (PEPS)
SP1236	activation	passive entry passive start (PEPS)
SP1237	Write VIN code	supplemental restraint system (SRS) (SDM)
SP1238	Enable airbag	supplemental restraint system (SRS) (SDM)
SP1239	No airbags	supplemental restraint system (SRS) (SDM)
SP1240	8-way configuration of airbag controller (for trendy version)	supplemental restraint system (SRS) (SDM)
SP1241	Airbag controller configuration writing 4-way (applicable to new wind version and new fashion version)	supplemental restraint system (SRS) (SDM)
SP1242	Write VIN code	entertainment head unit (EHU)
SP1243	Write VIN code	vehicle control unit (VCU)
SP1244	Write VIN code	drive motor system (MCU)
SP1245	Write motor code	drive motor system (MCU)

SP1246	Write application fingerprint	drive motor system (MCU)
SP1247	Write VIN code	battery management system (BMS)
SP1248	Write Battery Code	battery management system (BMS)
SP1249	Write VIN code	charger control system (CHG)
SP1250	Write VIN code	electric power steering (EPS)
SP1251	Write VIN code	instrument cluster module (ICM)
SP1252	Write in remaining maintenance mileage	instrument cluster module (ICM)
SP1253	Write total mileage	instrument cluster module (ICM)
SP1254	Write VIN code	air conditioning system (ECC)
SP1255	Write real time voltage of EAS over current	compressor controller (EAS)
SP1256	Write real-time current of EAS over-current	compressor controller (EAS)
SP1257	Write operation overvoltage	compressor controller (EAS)
SP1258	Write operation undervoltage	compressor controller (EAS)
SP1259	Write standby overvoltage	compressor controller (EAS)
SP1260	Write standby undervoltage	compressor controller (EAS)
SP1261	Write the real-time voltage value of communication fault	compressor controller (EAS)
SP1262	Write real time current value of communication fault	compressor controller (EAS)
SP1263	Write real-time current value of over-power frequency reduction	compressor controller (EAS)
SP1264	Write abnormal real time current value	compressor controller (EAS)
SP1265	Write VIN code	warm air heating system (PTC)
SP1266	Write VIN code	pedestrians warning system (VSP)
SP1267	Write VIN code	slow charge couple management module (CMU)
SP1268	Write VIN code	tire pressure monitor system (TPMS)
SP1269	Write left front wheel sensor ID	tire pressure monitor system (TPMS)
SP1270	Write right front wheel sensor ID	tire pressure monitor system (TPMS)
SP1271	Write left rear wheel sensor ID	tire pressure monitor system (TPMS)
SP1272	Write right rear wheel sensor ID	tire pressure monitor system (TPMS)
SP1273	Tire sensor learning: left front	tire pressure monitor system (TPMS)
SP1274	Tire sensor learning: right front	tire pressure monitor system (TPMS)

SP1275	Tire sensor learning: rear left	tire pressure monitor system (TPMS)
SP1276	Tire sensor learning: right rear	tire pressure monitor system (TPMS)
SP1277	Write ECU system initialization	tire pressure monitor system (TPMS)
SP1278	Write VIN code	anti-lock brake system (ABS)
SP1279	Write VIN code	vehicle control unit (VCU)
SP1280	Write VIN code	vehicle control unit (VCU)
SP1281	Data terminal communication loss handling mode configuration	vehicle control unit (VCU)
SP1282	Write VIN code	Dajun drive motor system (MCU)
SP1283	Write motor code	Dajun drive motor system (MCU)
SP1284	Write VIN code	Intel drive motor system (MCU)
SP1285	Write motor code	Intel drive motor system (MCU)
SP1286	Write VIN code	battery management system (BMS)
SP1287	Write 30 bits of battery code	battery management system (BMS)
SP1288	Write Battery Code 34 bits	battery management system (BMS)
SP1289	Write power battery SOC	battery management system (BMS)
SP1290	Write VIN code	electric power steering (EPS)
SP1291	Steering angle zero calibration	electric power steering (EPS)
SP1292	Write VIN code	instrument cluster module (ICM)
SP1293	Write total mileage	instrument cluster module (ICM)
SP1294	Write in maintenance mileage	instrument cluster module (ICM)
SP1295	With this configuration	instrument cluster module (ICM)
SP1296	No such configuration	instrument cluster module (ICM)
SP1297	With this configuration	instrument cluster module (ICM)
SP1298	No such configuration	instrument cluster module (ICM)
SP1299	With this configuration	instrument cluster module (ICM)
SP1300	No such configuration	instrument cluster module (ICM)
SP1301	With this configuration	instrument cluster module (ICM)
SP1302	No such configuration	instrument cluster module (ICM)
SP1303	With this configuration	instrument cluster module (ICM)
SP1304	No such configuration	instrument cluster module (ICM)
SP1305	With this configuration	instrument cluster module (ICM)
SP1306	No such configuration	instrument cluster module (ICM)
SP1307	No such configuration	instrument cluster module (ICM)
SP1308	only rear radar	instrument cluster module (ICM)
SP1309	Front of band radar	instrument cluster module (ICM)
SP1310	Left rudder	instrument cluster module (ICM)
SP1311	Right rudder	instrument cluster module (ICM)
SP1312	With this configuration	instrument cluster module (ICM)
SP1313	No such configuration	instrument cluster module (ICM)

SP1314	With this configuration	instrument cluster module (ICM)
SP1315	No such configuration	instrument cluster module (ICM)
SP1316	Grade 10	instrument cluster module (ICM)
SP1317	Grade 9	instrument cluster module (ICM)
SP1318	Grade 8	instrument cluster module (ICM)
SP1319	Grade 7	instrument cluster module (ICM)
SP1320	Grade 6	instrument cluster module (ICM)
SP1321	Grade 5	instrument cluster module (ICM)
SP1322	open	instrument cluster module (ICM)
SP1323	close	instrument cluster module (ICM)
SP1324	digital	instrument cluster module (ICM)
SP1325	Pointer type	instrument cluster module (ICM)
SP1326	With this configuration	instrument cluster module (ICM)
SP1327	No such configuration	instrument cluster module (ICM)
SP1328	With this configuration	instrument cluster module (ICM)
SP1329	No such configuration	instrument cluster module (ICM)
SP1330	With this configuration	instrument cluster module (ICM)
SP1331	No such configuration	instrument cluster module (ICM)
SP1332	With this configuration	instrument cluster module (ICM)
SP1333	No such configuration	instrument cluster module (ICM)
SP1334	With this configuration	instrument cluster module (ICM)
SP1335	No such configuration	instrument cluster module (ICM)
SP1336	Grade 10	instrument cluster module (ICM)
SP1337	Grade 9	instrument cluster module (ICM)
SP1338	Grade 8	instrument cluster module (ICM)
SP1339	Grade 7	instrument cluster module (ICM)
SP1340	Grade 6	instrument cluster module (ICM)
SP1341	Grade 5	instrument cluster module (ICM)
SP1342	Write VIN code	passive entry passive start (PEPS)
SP1343	Offline ESCL learning	passive entry passive start (PEPS)
SP1344	After sales replacement of VCU	passive entry passive start (PEPS)
SP1345	Replace peps after sale	passive entry passive start (PEPS)
SP1346	Write VIN code	air conditioning system (ECC)
SP1347	Write VIN code	remote monitor system (RMS)
SP1348	Write VIN code	electronically controlled booster and brake master cylinder assembly (NBS)
SP1349	Write VIN code	entertainment head unit (EHU)
SP1350	Write VIN code	drive motor system (MCU)
SP1351	Write motor code	drive motor system (MCU)
SP1352	Write VIN code	battery management system (BMS)
SP1353	Write motor code	battery management system (BMS)
SP1354	Write VIN code	Henglong brushless electric power steering (EPS)
SP1355	Sensor zero calibration	Henglong brushless electric power steering (EPS)
SP1356	Write VIN code	remote monitor system (T-BOX)
SP1357	Time sharing lease mode	remote monitor system (T-BOX)
SP1358	Write VIN code	instrument cluster module (ICM)

SP1359	Total mileage learning	instrument cluster module (ICM)
SP1360	Total mileage write in	instrument cluster module (ICM)
SP1361	Maintenance mileage writing	instrument cluster module (ICM)
SP1362	Write mileage backup count	instrument cluster module (ICM)
SP1363	Timeshare	instrument cluster module (ICM)
SP1364	Online version (without ESP)	instrument cluster module (ICM)
SP1365	Online version (optional body stability control ESP)	instrument cluster module (ICM)
SP1366	Low configuration - intelligent new version (without ESP)	instrument cluster module (ICM)
SP1367	Low configuration - intelligent new version (optional body stability control ESP)	instrument cluster module (ICM)
SP1368	Medium configuration (without V2V / v2l charging function and body stability control ESP)	instrument cluster module (ICM)
SP1369	Medium configuration (optional V2V / v2l charging function and body stability control ESP)	instrument cluster module (ICM)
SP1370	Original low configuration - Zhifeng Version (without V2V / v2l charging function, esp, LDW)	instrument cluster module (ICM)
SP1371	Original low configuration - Zhifeng Version (optional V2V / v2l charging function, esp, LDW)	instrument cluster module (ICM)
SP1372	High configuration - Zhishang version 1	instrument cluster module (ICM)
SP1373	High configuration - Zhishang 2	instrument cluster module (ICM)
SP1374	Write VIN code	on-board charger (OBC)
SP1375	Write VIN code	Direct current converter controller (DC/DC)
SP1376	Write VIN code	air conditioning system (ECC)
SP1377	Write VIN code	compressor controller (EAS)
SP1378	Write VIN code	warm air heating system (PTC)
SP1379	Write VIN code	ABS
SP1380	Fill incomplete	ABS

SP1381	The filling is complete and correct	ABS
SP1382	Fill complete but incorrect	ABS
SP1383	Bosch distribution	ABS
SP1384	Fill incomplete	ABS
SP1385	The filling is complete and correct	ABS
SP1386	Fill complete but incorrect	ABS
SP1387	Bosch distribution	ABS
SP1388	Write VIN code	Anti lock braking 2 (ABS)
SP1389	Fill incomplete	Anti lock braking 2 (ABS)
SP1390	The filling is complete and correct	Anti lock braking 2 (ABS)
SP1391	Fill complete but incorrect	Anti lock braking 2 (ABS)
SP1392	Bosch distribution	Anti lock braking 2 (ABS)
SP1393	Fill incomplete	Anti lock braking 2 (ABS)
SP1394	The filling is complete and correct	Anti lock braking 2 (ABS)
SP1395	Fill complete but incorrect	Anti lock braking 2 (ABS)
SP1396	Bosch distribution	Anti lock braking 2 (ABS)
SP1397	Write VIN code	body control module (BCM)
SP1398	Write SC code	body control module (BCM)
SP1399	Write internal diagnostic code	body control module (BCM)
SP1400	Write total mileage backup counter	body control module (BCM)
SP1401	Write VIN code	electronic steering column lock (ESCL)
SP1402	Write VIN code	tire pressure monitor system (TPMS)
SP1403	Write tire sensor ID: left front	tire pressure monitor system (TPMS)
SP1404	Write tire sensor ID: right front	tire pressure monitor system (TPMS)
SP1405	Write tire sensor ID: rear left	tire pressure monitor system (TPMS)
SP1406	Write tire sensor ID: right rear	tire pressure monitor system (TPMS)
SP1407	Tire sensor position exchange: left front, right front	tire pressure monitor system (TPMS)
SP1408	Tire sensor position exchange: left front, right rear	tire pressure monitor system (TPMS)
SP1409	Tire sensor position exchange: left front, right rear	tire pressure monitor system (TPMS)

SP1410	Tire sensor position exchange: right front, left rear	tire pressure monitor system (TPMS)
SP1411	Tire sensor position exchange: right front, left rear	tire pressure monitor system (TPMS)
SP1412	Tire sensor position exchange: right rear, left rear	tire pressure monitor system (TPMS)
SP1413	Tire sensor learning: left front	tire pressure monitor system (TPMS)
SP1414	Tire sensor learning: right front	tire pressure monitor system (TPMS)
SP1415	Tire sensor learning: rear left	tire pressure monitor system (TPMS)
SP1416	Tire sensor learning: right rear	tire pressure monitor system (TPMS)
SP1417	Delete front left tire sensor	tire pressure monitor system (TPMS)
SP1418	Remove front right tire sensor	tire pressure monitor system (TPMS)
SP1419	Delete rear left tire sensor	tire pressure monitor system (TPMS)
SP1420	Remove rear right tire sensor	tire pressure monitor system (TPMS)
SP1421	Delete all tire sensors	tire pressure monitor system (TPMS)
SP1422	Write VIN code	electronic gear controller (ESK)
SP1423	Write VIN code	pedestrians proximity voice warning (VSP)
SP1424	Write VIN code	Gear P parking system (PCU)
SP1425	Write VIN code	charging port management module (CMU)
SP1426	Write VIN code	vacuum pump controller (VBP)
SP1427	Write VIN code	central control infotainment system assembly (EHU)
SP1428	Timeshare	central control infotainment system assembly (EHU)
SP1429	Online version	central control infotainment system assembly (EHU)
SP1430	Low configuration smart new version	central control infotainment system assembly (EHU)
SP1431	Zhongpei	central control infotainment system assembly (EHU)
SP1432	Original low configuration - Zhifeng Version (without Lane Departure Warning System)	central control infotainment system assembly (EHU)

SP1433	In situ configuration - Smart wind Version (optional Lane Departure Warning System)	central control infotainment system assembly (EHU)
SP1434	High configuration - Zhishang Version (without Lane Departure Warning System)	central control infotainment system assembly (EHU)
SP1435	High configuration - Zhishang Version (optional Lane Departure Warning System)	central control infotainment system assembly (EHU)
SP1436	Write VIN code	power battery water pump controller (EWP-B)
SP1437	Normal state	power battery water pump controller (EWP-B)
SP1438	Over temperature state	power battery water pump controller (EWP-B)
SP1439	Over voltage state	power battery water pump controller (EWP-B)
SP1440	Under voltage state	power battery water pump controller (EWP-B)
SP1441	Over current fault	power battery water pump controller (EWP-B)
SP1442	Open circuit fault	power battery water pump controller (EWP-B)
SP1443	Write low voltage power supply voltage	power battery water pump controller (EWP-B)
SP1444	Write pump motor current	power battery water pump controller (EWP-B)
SP1445	Write VIN code	air conditioning heating water pump controller (EWP-H)
SP1446	Normal state	air conditioning heating water pump controller (EWP-H)
SP1447	Over temperature state	air conditioning heating water pump controller (EWP-H)
SP1448	Over voltage state	air conditioning heating water pump controller (EWP-H)
SP1449	Under voltage state	air conditioning heating water pump controller (EWP-H)
SP1450	Over current fault	air conditioning heating water pump controller (EWP-H)
SP1451	Open circuit fault	air conditioning heating water pump controller (EWP-H)
SP1452	Write low voltage power supply voltage	air conditioning heating water pump controller (EWP-H)
SP1453	Write pump motor current	air conditioning heating water pump controller (EWP-H)
SP1454	Write VIN code	drive system water pump controller (EWP-FD)
SP1455	Normal state	drive system water pump controller (EWP-FD)
SP1456	Over temperature state	drive system water pump controller (EWP-FD)
SP1457	Over voltage state	drive system water pump controller (EWP-FD)
SP1458	Under voltage state	drive system water pump controller (EWP-FD)
SP1459	Over current fault	drive system water pump controller (EWP-FD)
SP1460	Open circuit fault	drive system water pump controller (EWP-FD)

SP1461	Write low voltage power supply voltage	drive system water pump controller (EWP-FD)
SP1462	Write pump motor current	drive system water pump controller (EWP-FD)
SP1463	Write VIN code	parking assist reversing controller (PAS)
SP1464	Write VIN code	passive entry passive start (PEPS)
SP1465	not active	passive entry passive start (PEPS)
SP1466	activation	passive entry passive start (PEPS)
SP1467	not active	passive entry passive start (PEPS)
SP1468	activation	passive entry passive start (PEPS)
SP1469	0	passive entry passive start (PEPS)
SP1470	1	passive entry passive start (PEPS)
SP1471	2	passive entry passive start (PEPS)
SP1472	4	passive entry passive start (PEPS)
SP1473	not active	passive entry passive start (PEPS)
SP1474	activation	passive entry passive start (PEPS)
SP1475	not active	passive entry passive start (PEPS)
SP1476	activation	passive entry passive start (PEPS)
SP1477	not active	passive entry passive start (PEPS)
SP1478	activation	passive entry passive start (PEPS)
SP1479	not active	passive entry passive start (PEPS)
SP1480	activation	passive entry passive start (PEPS)
SP1481	not active	passive entry passive start (PEPS)
SP1482	activation	passive entry passive start (PEPS)
SP1483	not active	passive entry passive start (PEPS)
SP1484	activation	passive entry passive start (PEPS)
SP1485	not active	passive entry passive start (PEPS)
SP1486	activation	passive entry passive start (PEPS)
SP1487	Write VIN code	supplemental restraint system (SRS) (SDM)
SP1488	Enable airbag	supplemental restraint system (SRS) (SDM)
SP1489	No airbags	supplemental restraint system (SRS) (SDM)
SP1490	Write airbag configuration	supplemental restraint system (SRS) (SDM)
SP1491	Write airbag configuration (R500 smart wind version)	supplemental restraint system (SRS) (SDM)
SP1492	Write VIN code	driving recorder (DVR)
SP1493	Write VIN code	electronic parking brake (EPB)
SP1494	Write VIN code	around view monitor (AVM)
SP1495	AVM calibration	around view monitor (AVM)
SP1496	Determine the coordinates	around view monitor (AVM)
SP1497	Cancel coordinates	around view monitor (AVM)
SP1498	The current view is the front camera, switch the view to the rear camera	around view monitor (AVM)
SP1499	Up (1)	around view monitor (AVM)
SP1500	Down (1)	around view monitor (AVM)

SP1501	Left (1)	around view monitor (AVM)
SP1502	Right (1)	around view monitor (AVM)
SP1503	Up (20)	around view monitor (AVM)
SP1504	Down (20)	around view monitor (AVM)
SP1505	Left (20)	around view monitor (AVM)
SP1506	Right (20)	around view monitor (AVM)
SP1507	Write vehicle variable configuration (R500 smart wind version)	around view monitor (AVM)
SP1508	C51D	around view monitor (AVM)
SP1509	C53D	around view monitor (AVM)
SP1510	C40D	around view monitor (AVM)
SP1511	C53D Grille 2	around view monitor (AVM)
SP1512	C62X	around view monitor (AVM)
SP1513	MT	around view monitor (AVM)
SP1514	At or CVT	around view monitor (AVM)
SP1515	not configured	around view monitor (AVM)
SP1516	Configured	around view monitor (AVM)
SP1517	not configured	around view monitor (AVM)
SP1518	Configured	around view monitor (AVM)
SP1519	not configured	around view monitor (AVM)
SP1520	Configured	around view monitor (AVM)
SP1521	not configured	around view monitor (AVM)
SP1522	Configured	around view monitor (AVM)
SP1523	Chinese 汉语	around view monitor (AVM)
SP1524	English	around view monitor (AVM)
SP1525	Abaric Arabic	around view monitor (AVM)
SP1526	Spanish	around view monitor (AVM)
SP1527	ESP	around view monitor (AVM)
SP1528	ABS	around view monitor (AVM)
SP1529	Write VIN code	gateway system
SP1530	not configured	gateway system
SP1531	to configure	gateway system
SP1532	not configured	gateway system
SP1533	to configure	gateway system
SP1534	not configured	gateway system
SP1535	to configure	gateway system
SP1536	not configured	gateway system
SP1537	to configure	gateway system
SP1538	not configured	gateway system
SP1539	to configure	gateway system
SP1540	not configured	gateway system
SP1541	to configure	gateway system
SP1542	not configured	gateway system
SP1543	to configure	gateway system
SP1544	not configured	gateway system
SP1545	to configure	gateway system
SP1546	not configured	gateway system
SP1547	to configure	gateway system

SP1548	not configured	gateway system
SP1549	to configure	gateway system
SP1550	not configured	gateway system
SP1551	to configure	gateway system
SP1552	No TPMS	gateway system
SP1553	Indirect TPMS (default)	gateway system
SP1554	Direct TPMS	gateway system
SP1555	not configured	gateway system
SP1556	to configure	gateway system
SP1557	not configured	gateway system
SP1558	to configure	gateway system
SP1559	not configured	gateway system
SP1560	to configure	gateway system
SP1561	not configured	gateway system
SP1562	to configure	gateway system
SP1563	not configured	gateway system
SP1564	to configure	gateway system
SP1565	not configured	gateway system
SP1566	to configure	gateway system
SP1567	not configured	gateway system
SP1568	to configure	gateway system
SP1569	not configured	gateway system
SP1570	to configure	gateway system
SP1571	not configured	gateway system
SP1572	to configure	gateway system
SP1573	not configured	gateway system
SP1574	to configure	gateway system
SP1575	Write VIN code	seat heating control unit (FSH)
SP1576	Write VIN code	front camera controller (MPC)
SP1577	Write VIN code	battery management system (BMS)
SP1578	Write Battery Code	battery management system (BMS)
SP1579	Write VIN code	drive motor system (MCU)
SP1580	Write motor code	drive motor system (MCU)
SP1581	not handled	drive motor system (MCU)
SP1582	Speed limit treatment	drive motor system (MCU)
SP1583	Write VIN code	on-board charger (OBC)
SP1584	Write VIN code	air conditioning system (ECC)
SP1585	Write VIN code	compressor controller (EAS)
SP1586	Write VIN code	warm air heating system (PTC)
SP1587	Write VIN code	instrument cluster module (ICM)
SP1588	Total mileage write in	instrument cluster module (ICM)
SP1589	Maintenance mileage writing	instrument cluster module (ICM)
SP1590	Write mileage backup count	instrument cluster module (ICM)
SP1591	Write VIN code	Central control system (EHU)
SP1592	Write VIN code	pedestrians alarm (VSP)
SP1593	Write VIN code	slow charge couple management module (CMU)
SP1594	Write VIN code	Direct current converter controller (DC/DC)

SP1595	Write VIN code	vacuum pump controller (VBP)
SP1596	Write VIN code	remote monitor system (T-BOX)
SP1597	Time sharing lease mode	remote monitor system (T-BOX)
SP1598	Write VIN code	Gear P parking system (PCU)
SP1599	Write VIN code	water pump controller (EWP)
SP1600	Write VIN code	adaptive cruise control (ACC)
SP1601	Write passive vertical calibration deviation angle	adaptive cruise control (ACC)
SP1602	Write passive horizontal calibration deviation angle	adaptive cruise control (ACC)
SP1603	C53F(1R1V)	adaptive cruise control (ACC)
SP1604	C53F(1R)	adaptive cruise control (ACC)
SP1605	C62X(1R1V)	adaptive cruise control (ACC)
SP1606	C62X(1R)	adaptive cruise control (ACC)
SP1607	C40DB(1R1V)	adaptive cruise control (ACC)
SP1608	C40DB(1R)	adaptive cruise control (ACC)
SP1609	C51EB(1R1V)	adaptive cruise control (ACC)
SP1610	C51EB(1R)	adaptive cruise control (ACC)
SP1611	Write VIN code	anti-lock brake system and electronic stability program (ESP)
SP1612	Fill incomplete	anti-lock brake system and electronic stability program (ESP)
SP1613	The filling is complete and correct	anti-lock brake system and electronic stability program (ESP)
SP1614	Fill complete but incorrect	anti-lock brake system and electronic stability program (ESP)
SP1615	Bosch distribution	anti-lock brake system and electronic stability program (ESP)
SP1616	Fill incomplete	anti-lock brake system and electronic stability program (ESP)
SP1617	The filling is complete and correct	anti-lock brake system and electronic stability program (ESP)
SP1618	Fill complete but incorrect	anti-lock brake system and electronic stability program (ESP)
SP1619	Bosch distribution	anti-lock brake system and electronic stability program (ESP)
SP1620	Write VIN code	body control module (BCM)
SP1621	Write vehicle characteristic ID code	body control module (BCM)
SP1622	Replace the BCM	body control module (BCM)
SP1623	Replace the BCM_New test	body control module (BCM)
SP1624	BCM function configuration 1 and 2	body control module (BCM)
SP1625	Vehicle network configuration	body control module (BCM)
SP1626	MT	body control module (BCM)

SP1627	6AT	body control module (BCM)
SP1628	CVT-Punch	body control module (BCM)
SP1629	Write VIN code	tire pressure monitor system (TPMS)
SP1630	Write tire sensor ID: left front	tire pressure monitor system (TPMS)
SP1631	Write tire sensor ID: right front	tire pressure monitor system (TPMS)
SP1632	Write tire sensor ID: rear left	tire pressure monitor system (TPMS)
SP1633	Write tire sensor ID: right rear	tire pressure monitor system (TPMS)
SP1634	Tire sensor position exchange: left front, right front	tire pressure monitor system (TPMS)
SP1635	Tire sensor position exchange: left front, right rear	tire pressure monitor system (TPMS)
SP1636	Tire sensor position exchange: left front, left rear	tire pressure monitor system (TPMS)
SP1637	Tire sensor position exchange: right front, right rear	tire pressure monitor system (TPMS)
SP1638	Tire sensor position exchange: right front, left rear	tire pressure monitor system (TPMS)
SP1639	Tire sensor position exchange: right rear, left rear	tire pressure monitor system (TPMS)
SP1640	Tire sensor learning: left front	tire pressure monitor system (TPMS)
SP1641	Tire sensor learning: right front	tire pressure monitor system (TPMS)
SP1642	Tire sensor learning: rear left	tire pressure monitor system (TPMS)
SP1643	Tire sensor learning: right rear	tire pressure monitor system (TPMS)
SP1644	Delete front left tire sensor	tire pressure monitor system (TPMS)
SP1645	Remove front right tire sensor	tire pressure monitor system (TPMS)
SP1646	Delete rear left tire sensor	tire pressure monitor system (TPMS)
SP1647	Remove rear right tire sensor	tire pressure monitor system (TPMS)
SP1648	Delete all tire sensors	tire pressure monitor system (TPMS)
SP1649	Write VIN code	passive entry passive start (PEPS)
SP1650	not active	passive entry passive start (PEPS)
SP1651	activation	passive entry passive start (PEPS)
SP1652	not active	passive entry passive start (PEPS)

SP1653	activation	passive entry passive start (PEPS)
SP1654	0	passive entry passive start (PEPS)
SP1655	1	passive entry passive start (PEPS)
SP1656	2	passive entry passive start (PEPS)
SP1657	4	passive entry passive start (PEPS)
SP1658	not active	passive entry passive start (PEPS)
SP1659	activation	passive entry passive start (PEPS)
SP1660	not active	passive entry passive start (PEPS)
SP1661	activation	passive entry passive start (PEPS)
SP1662	not active	passive entry passive start (PEPS)
SP1663	activation	passive entry passive start (PEPS)
SP1664	not active	passive entry passive start (PEPS)
SP1665	activation	passive entry passive start (PEPS)
SP1666	not active	passive entry passive start (PEPS)
SP1667	activation	passive entry passive start (PEPS)
SP1668	not active	passive entry passive start (PEPS)
SP1669	activation	passive entry passive start (PEPS)
SP1670	not active	passive entry passive start (PEPS)
SP1671	activation	passive entry passive start (PEPS)
SP1672	Write VIN code	electronic parking brake (EPB)
SP1673	EOL detection	electronic parking brake (EPB)
SP1674	Write VIN code	electronic steering column lock (ESCL)
SP1675	Write VIN code	supplemental restraint system (SRS) (SDM)
SP1676	Write production date	supplemental restraint system (SRS) (SDM)
SP1677	Enable airbag	supplemental restraint system (SRS) (SDM)
SP1678	No airbags	supplemental restraint system (SRS) (SDM)
SP1679	Write VIN code	electric power steering (EPS)
SP1680	Write initial position of steering wheel	electric power steering (EPS)
SP1681	Write system test number	electric power steering (EPS)
SP1682	Write VIN code	around view monitor (AVM)
SP1683	AVM calibration	around view monitor (AVM)
SP1684	Determine the coordinates	around view monitor (AVM)
SP1685	Cancel coordinates	around view monitor (AVM)
SP1686	The current view is the front camera, switch the view to the rear camera	around view monitor (AVM)
SP1687	Up (1)	around view monitor (AVM)
SP1688	Down (1)	around view monitor (AVM)
SP1689	Left (1)	around view monitor (AVM)
SP1690	Right (1)	around view monitor (AVM)
SP1691	Up (20)	around view monitor (AVM)
SP1692	Down (20)	around view monitor (AVM)
SP1693	Left (20)	around view monitor (AVM)
SP1694	Right (20)	around view monitor (AVM)
SP1695	forced return	around view monitor (AVM)

SP1696	C51D	around view monitor (AVM)
SP1697	C53D	around view monitor (AVM)
SP1698	C40D	around view monitor (AVM)
SP1699	C53D Grille 2	around view monitor (AVM)
SP1700	C62X	around view monitor (AVM)
SP1701	MT	around view monitor (AVM)
SP1702	At or CVT	around view monitor (AVM)
SP1703	not configured	around view monitor (AVM)
SP1704	Configured	around view monitor (AVM)
SP1705	not configured	around view monitor (AVM)
SP1706	Configured	around view monitor (AVM)
SP1707	not configured	around view monitor (AVM)
SP1708	Configured	around view monitor (AVM)
SP1709	not configured	around view monitor (AVM)
SP1710	Configured	around view monitor (AVM)
SP1711	Chinese	around view monitor (AVM)
SP1712	English	around view monitor (AVM)
SP1713	Abaric Arabic	around view monitor (AVM)
SP1714	Spanish	around view monitor (AVM)
SP1715	ESP	around view monitor (AVM)
SP1716	ABS	around view monitor (AVM)
SP1717	Write VIN code	gateway system
SP1718	not configured	gateway system
SP1719	to configure	gateway system
SP1720	not configured	gateway system
SP1721	to configure	gateway system
SP1722	not configured	gateway system
SP1723	to configure	gateway system
SP1724	not configured	gateway system
SP1725	to configure	gateway system
SP1726	not configured	gateway system
SP1727	to configure	gateway system
SP1728	not configured	gateway system
SP1729	to configure	gateway system
SP1730	ABS	gateway system
SP1731	ESP	gateway system
SP1732	not configured	gateway system
SP1733	to configure	gateway system
SP1734	not configured	gateway system
SP1735	to configure	gateway system
SP1736	not configured	gateway system
SP1737	to configure	gateway system
SP1738	not configured	gateway system
SP1739	to configure	gateway system
SP1740	No TPMS	gateway system
SP1741	Indirect TPMS (default)	gateway system
SP1742	Direct TPMS	gateway system
SP1743	not configured	gateway system
SP1744	to configure	gateway system

SP1745	not configured	gateway system
SP1746	to configure	gateway system
SP1747	not configured	gateway system
SP1748	to configure	gateway system
SP1749	not configured	gateway system
SP1750	to configure	gateway system
SP1751	not configured	gateway system
SP1752	to configure	gateway system
SP1753	not configured	gateway system
SP1754	to configure	gateway system
SP1755	not configured	gateway system
SP1756	to configure	gateway system
SP1757	not configured	gateway system
SP1758	to configure	gateway system
SP1759	not configured	gateway system
SP1760	to configure	gateway system
SP1761	not configured	gateway system
SP1762	to configure	gateway system
SP1763	not configured	gateway system
SP1764	to configure	gateway system
SP1765	Write VIN code	seat heating control unit (FSH)
SP1766	Write VIN code	front camera controller (MPC)
SP1767	C40DB	front camera controller (MPC)
SP1768	C51EB	front camera controller (MPC)
SP1769	C53F	front camera controller (MPC)
SP1770	C62X	front camera controller (MPC)
SP1771	Write VIN code	electronic gear shift system (ETRS)
SP1772	Write VIN code	bi-directional on-board charger (OBC)
SP1773	Write in the part assembly number	bi-directional on-board charger (OBC)
SP1774	Write VIN code	drive motor system (MCU)
SP1775	Write motor code	drive motor system (MCU)
SP1776	not handled	drive motor system (MCU)
SP1777	Speed limit treatment	drive motor system (MCU)
SP1778	nothing	drive motor system (MCU)
SP1779	yes	drive motor system (MCU)
SP1780	Write VIN code	pedestrians alarm (VSP)
SP1781	Write VIN code	instrument cluster module (ICM)
SP1782	Total mileage write in	instrument cluster module (ICM)
SP1783	Maintenance mileage writing	instrument cluster module (ICM)
SP1784	China	instrument cluster module (ICM)
SP1785	chinese	instrument cluster module (ICM)
SP1786	not configured	instrument cluster module (ICM)
SP1787	to configure	instrument cluster module (ICM)
SP1788	not configured	instrument cluster module (ICM)
SP1789	to configure	instrument cluster module (ICM)
SP1790	not configured	instrument cluster module (ICM)
SP1791	to configure	instrument cluster module (ICM)

SP1792	not configured	instrument cluster module (ICM)
SP1793	to configure	instrument cluster module (ICM)
SP1794	not configured	instrument cluster module (ICM)
SP1795	to configure	instrument cluster module (ICM)
SP1796	not configured	instrument cluster module (ICM)
SP1797	to configure	instrument cluster module (ICM)
SP1798	not configured	instrument cluster module (ICM)
SP1799	to configure	instrument cluster module (ICM)
SP1800	not configured	instrument cluster module (ICM)
SP1801	to configure	instrument cluster module (ICM)
SP1802	not configured	instrument cluster module (ICM)
SP1803	to configure	instrument cluster module (ICM)
SP1804	not configured	instrument cluster module (ICM)
SP1805	to configure	instrument cluster module (ICM)
SP1806	not configured	instrument cluster module (ICM)
SP1807	to configure	instrument cluster module (ICM)
SP1808	not configured	instrument cluster module (ICM)
SP1809	to configure	instrument cluster module (ICM)
SP1810	not configured	instrument cluster module (ICM)
SP1811	to configure	instrument cluster module (ICM)
SP1812	not configured	instrument cluster module (ICM)
SP1813	to configure	instrument cluster module (ICM)
SP1814	not configured	instrument cluster module (ICM)
SP1815	to configure	instrument cluster module (ICM)
SP1816	not configured	instrument cluster module (ICM)
SP1817	to configure	instrument cluster module (ICM)
SP1818	not configured	instrument cluster module (ICM)
SP1819	to configure	instrument cluster module (ICM)
SP1820	not configured	instrument cluster module (ICM)
SP1821	to configure	instrument cluster module (ICM)
SP1822	Write VIN code	gateway controller
SP1823	Write ECU configuration (did 0xf1a1)	gateway controller
SP1824	Write function configuration (did 0x0c7f)	gateway controller
SP1825	Write VIN code	air conditioning system (ECC)
SP1826	Write VIN code	compressor controller (EAS)
SP1827	Write VIN code	power battery water pump controller (EWP-B)
SP1828	Normal state	power battery water pump controller (EWP-B)
SP1829	Over temperature state	power battery water pump controller (EWP-B)
SP1830	Over voltage state	power battery water pump controller (EWP-B)
SP1831	Under voltage state	power battery water pump controller (EWP-B)
SP1832	Over current fault	power battery water pump controller (EWP-B)
SP1833	Open circuit fault	power battery water pump controller (EWP-B)
SP1834	Write low voltage power supply voltage	power battery water pump controller (EWP-B)
SP1835	Write pump motor current	power battery water pump controller (EWP-B)

SP1836	Write VIN code	air conditioning heating water pump controller (EWP-H)
SP1837	Normal state	air conditioning heating water pump controller (EWP-H)
SP1838	Over temperature state	air conditioning heating water pump controller (EWP-H)
SP1839	Over voltage state	air conditioning heating water pump controller (EWP-H)
SP1840	Under voltage state	air conditioning heating water pump controller (EWP-H)
SP1841	Over current fault	air conditioning heating water pump controller (EWP-H)
SP1842	Open circuit fault	air conditioning heating water pump controller (EWP-H)
SP1843	Write low voltage power supply voltage	air conditioning heating water pump controller (EWP-H)
SP1844	Write pump motor current	air conditioning heating water pump controller (EWP-H)
SP1845	Write VIN code	drive system water pump controller (EWP-FD)
SP1846	Normal state	drive system water pump controller (EWP-FD)
SP1847	Over temperature state	drive system water pump controller (EWP-FD)
SP1848	Over voltage state	drive system water pump controller (EWP-FD)
SP1849	Under voltage state	drive system water pump controller (EWP-FD)
SP1850	Over current fault	drive system water pump controller (EWP-FD)
SP1851	Open circuit fault	drive system water pump controller (EWP-FD)
SP1852	Write low voltage power supply voltage	drive system water pump controller (EWP-FD)
SP1853	Write pump motor current	drive system water pump controller (EWP-FD)
SP1854	Write VIN code	rear LED large screen module (RLM)
SP1855	Write in the part assembly number	rear LED large screen module (RLM)
SP1856	Write VIN code	front LED large screen module (FLM)
SP1857	Write in the part assembly number	front LED large screen module (FLM)
SP1858	Write VIN code	water heating electric heater (WTC)
SP1859	Write VIN code	grille controller (GCS)
SP1860	Write VIN code	tire pressure monitor system (TPMS)
SP1861	Write left front wheel position transmitter ID	tire pressure monitor system (TPMS)
SP1862	Write right front wheel position transmitter ID	tire pressure monitor system (TPMS)
SP1863	Write left rear wheel bit transmitter ID	tire pressure monitor system (TPMS)
SP1864	Write right rear wheel bit transmitter ID	tire pressure monitor system (TPMS)
SP1865	Tire sensor position exchange: left front, right front	tire pressure monitor system (TPMS)

SP1866	Tire sensor position exchange: left front, right rear	tire pressure monitor system (TPMS)
SP1867	Tire sensor position exchange: left front, left rear	tire pressure monitor system (TPMS)
SP1868	Tire sensor position exchange: right front, right rear	tire pressure monitor system (TPMS)
SP1869	Tire sensor position exchange: right front, left rear	tire pressure monitor system (TPMS)
SP1870	Tire sensor position exchange: right rear, left rear	tire pressure monitor system (TPMS)
SP1871	Write standard pressure	tire pressure monitor system (TPMS)
SP1872	Write VIN code	parking distance control (PDC)
SP1873	Write VIN code	passive entry passive start (PEPS)
SP1874	nothing	passive entry passive start (PEPS)
SP1875	yes	passive entry passive start (PEPS)
SP1876	nothing	passive entry passive start (PEPS)
SP1877	yes	passive entry passive start (PEPS)
SP1878	Write VIN code	electronic stability program (ESP)
SP1879	Fill incomplete	electronic stability program (ESP)
SP1880	The filling is complete and correct	electronic stability program (ESP)
SP1881	Fill complete but incorrect	electronic stability program (ESP)
SP1882	Bosch distribution	electronic stability program (ESP)
SP1883	Fill incomplete	electronic stability program (ESP)
SP1884	The filling is complete and correct	electronic stability program (ESP)
SP1885	Fill complete but incorrect	electronic stability program (ESP)
SP1886	Bosch distribution	electronic stability program (ESP)
SP1887	nothing	electronic stability program (ESP)
SP1888	yes	electronic stability program (ESP)
SP1889	nothing	electronic stability program (ESP)
SP1890	yes	electronic stability program (ESP)
SP1891	nothing	electronic stability program (ESP)
SP1892	yes	electronic stability program (ESP)
SP1893	nothing	electronic stability program (ESP)
SP1894	yes	electronic stability program (ESP)
SP1895	nothing	electronic stability program (ESP)
SP1896	yes	electronic stability program (ESP)
SP1897	nothing	electronic stability program (ESP)
SP1898	yes	electronic stability program (ESP)
SP1899	Calibration of yaw rate sensor	electronic stability program (ESP)

SP1900	Write VIN code	electronic gear shift (ESK)
SP1901	Write VIN code	supplemental restraint system (SRS) (SDM)
SP1902	Write vehicle production date (0d80)	supplemental restraint system (SRS) (SDM)
SP1903	Write client mode (0d8d)	supplemental restraint system (SRS) (SDM)
SP1904	Write software update date (0d82)	supplemental restraint system (SRS) (SDM)
SP1905	Write controller serial number (0d84)	supplemental restraint system (SRS) (SDM)
SP1906	not configured	supplemental restraint system (SRS) (SDM)
SP1907	Configured	supplemental restraint system (SRS) (SDM)
SP1908	not configured	supplemental restraint system (SRS) (SDM)
SP1909	Configured	supplemental restraint system (SRS) (SDM)
SP1910	not configured	supplemental restraint system (SRS) (SDM)
SP1911	Configured	supplemental restraint system (SRS) (SDM)
SP1912	not configured	supplemental restraint system (SRS) (SDM)
SP1913	Configured	supplemental restraint system (SRS) (SDM)
SP1914	not configured	supplemental restraint system (SRS) (SDM)
SP1915	Configured	supplemental restraint system (SRS) (SDM)
SP1916	not configured	supplemental restraint system (SRS) (SDM)
SP1917	Configured	supplemental restraint system (SRS) (SDM)
SP1918	not configured	supplemental restraint system (SRS) (SDM)
SP1919	Configured	supplemental restraint system (SRS) (SDM)
SP1920	not configured	supplemental restraint system (SRS) (SDM)
SP1921	Configured	supplemental restraint system (SRS) (SDM)
SP1922	not configured	supplemental restraint system (SRS) (SDM)
SP1923	Configured	supplemental restraint system (SRS) (SDM)
SP1924	not configured	supplemental restraint system (SRS) (SDM)
SP1925	Configured	supplemental restraint system (SRS) (SDM)
SP1926	not configured	supplemental restraint system (SRS) (SDM)
SP1927	Configured	supplemental restraint system (SRS) (SDM)
SP1928	not configured	supplemental restraint system (SRS) (SDM)
SP1929	Configured	supplemental restraint system (SRS) (SDM)
SP1930	not configured	supplemental restraint system (SRS) (SDM)
SP1931	Configured	supplemental restraint system (SRS) (SDM)
SP1932	not configured	supplemental restraint system (SRS) (SDM)
SP1933	Configured	supplemental restraint system (SRS) (SDM)
SP1934	not configured	supplemental restraint system (SRS) (SDM)
SP1935	Configured	supplemental restraint system (SRS) (SDM)
SP1936	not configured	supplemental restraint system (SRS) (SDM)
SP1937	Configured	supplemental restraint system (SRS) (SDM)
SP1938	not configured	supplemental restraint system (SRS) (SDM)
SP1939	Configured	supplemental restraint system (SRS) (SDM)
SP1940	not configured	supplemental restraint system (SRS) (SDM)
SP1941	Configured	supplemental restraint system (SRS) (SDM)
SP1942	not configured	supplemental restraint system (SRS) (SDM)
SP1943	Configured	supplemental restraint system (SRS) (SDM)
SP1944	not configured	supplemental restraint system (SRS) (SDM)

SP1945	Configured	supplemental restraint system (SRS) (SDM)
SP1946	Write VIN code	electronic steering column lock (ESCL)
SP1947	Write VIN code	electric power steering (EPS)
SP1948	Steering angle sensor calibration	electric power steering (EPS)
SP1949	Write VIN code	electronic parking brake (EPB)
SP1950	Write VIN code	entertainment head unit (EHU)
SP1951	China	entertainment head unit (EHU)
SP1952	chinese	entertainment head unit (EHU)
SP1953	nothing	entertainment head unit (EHU)
SP1954	yes	entertainment head unit (EHU)
SP1955	nothing	entertainment head unit (EHU)
SP1956	yes	entertainment head unit (EHU)
SP1957	nothing	entertainment head unit (EHU)
SP1958	yes	entertainment head unit (EHU)
SP1959	nothing	entertainment head unit (EHU)
SP1960	yes	entertainment head unit (EHU)
SP1961	nothing	entertainment head unit (EHU)
SP1962	yes	entertainment head unit (EHU)
SP1963	nothing	entertainment head unit (EHU)
SP1964	yes	entertainment head unit (EHU)
SP1965	nothing	entertainment head unit (EHU)
SP1966	yes	entertainment head unit (EHU)
SP1967	nothing	entertainment head unit (EHU)
SP1968	yes	entertainment head unit (EHU)
SP1969	nothing	entertainment head unit (EHU)
SP1970	yes	entertainment head unit (EHU)
SP1971	nothing	entertainment head unit (EHU)
SP1972	yes	entertainment head unit (EHU)
SP1973	nothing	entertainment head unit (EHU)
SP1974	yes	entertainment head unit (EHU)
SP1975	nothing	entertainment head unit (EHU)
SP1976	yes	entertainment head unit (EHU)
SP1977	nothing	entertainment head unit (EHU)
SP1978	yes	entertainment head unit (EHU)
SP1979	nothing	entertainment head unit (EHU)
SP1980	yes	entertainment head unit (EHU)
SP1981	nothing	entertainment head unit (EHU)
SP1982	yes	entertainment head unit (EHU)
SP1983	nothing	entertainment head unit (EHU)
SP1984	yes	entertainment head unit (EHU)
SP1985	6	entertainment head unit (EHU)
SP1986	8	entertainment head unit (EHU)
SP1987	nothing	entertainment head unit (EHU)
SP1988	yes	entertainment head unit (EHU)
SP1989	nothing	entertainment head unit (EHU)
SP1990	yes	entertainment head unit (EHU)
SP1991	nothing	entertainment head unit (EHU)
SP1992	yes	entertainment head unit (EHU)

SP1993	nothing	entertainment head unit (EHU)
SP1994	yes	entertainment head unit (EHU)
SP1995	Write VIN code	driving recorder (DVR)
SP1996	Write VIN code	remote control driving receiver (BTM)
SP1997	Write BTM remote driving distance	remote control driving receiver (BTM)
SP1998	Write the distance between BTM and paired bluetooth	remote control driving receiver (BTM)
SP1999	Write VIN code	body control module (BCM)
SP2000	nothing	body control module (BCM)
SP2001	yes	body control module (BCM)
SP2002	nothing	body control module (BCM)
SP2003	yes	body control module (BCM)
SP2004	nothing	body control module (BCM)
SP2005	yes	body control module (BCM)
SP2006	nothing	body control module (BCM)
SP2007	yes	body control module (BCM)
SP2008	nothing	body control module (BCM)
SP2009	yes	body control module (BCM)
SP2010	Write VIN code	around view monitor (AVM)
SP2011		1 around view monitor (AVM)
SP2012		2 around view monitor (AVM)
SP2013		3 around view monitor (AVM)
SP2014		4 around view monitor (AVM)
SP2015		5 around view monitor (AVM)
SP2016		6 around view monitor (AVM)
SP2017		7 around view monitor (AVM)
SP2018	Write ECU main software version number	around view monitor (AVM)
SP2019	Write into ECU software ERP	around view monitor (AVM)
SP2020	Write VIN code	auto parking system (APA)
SP2021	Write VIN code	ambient light controller (ALM)
SP2022	Atmosphere lamp assignment slave node ID	ambient light controller (ALM)
SP2023	Write VIN code	front camera controller (MPC)
SP2024	Write VIN code	medium-range millimeter-wave radar (MRR)
SP2025	Write VIN code	battery management system (BMS)
SP2026	Write Battery Code	battery management system (BMS)
SP2027	Write vehicle function mark	battery management system (BMS)
SP2028	Write VIN code	drive motor system (MCU)
SP2029	Write motor code	drive motor system (MCU)
SP2030	Write VIN code	battery management system (BMS)
SP2031	Write Battery Code	battery management system (BMS)
SP2032	Write VIN code	Henglong brushless electric power steering (EPS)

SP2033	Sensor zero calibration	Henglong brushless electric power steering (EPS)
SP2034	Write VIN code	instrument cluster module (ICM)
SP2035	Total mileage learning	instrument cluster module (ICM)
SP2036	Total mileage write in	instrument cluster module (ICM)
SP2037	Maintenance mileage writing	instrument cluster module (ICM)
SP2038	Write mileage backup count	instrument cluster module (ICM)
SP2039	Write configuration options	instrument cluster module (ICM)
SP2040	Write VIN code	air conditioning system (ECC)
SP2041	Write VIN code	ABS
SP2042	Fill incomplete	ABS
SP2043	The filling is complete and correct	ABS
SP2044	Fill complete but incorrect	ABS
SP2045	Bosch distribution	ABS
SP2046	Fill incomplete	ABS
SP2047	The filling is complete and correct	ABS
SP2048	Fill complete but incorrect	ABS
SP2049	Bosch distribution	ABS
SP2050	Write VIN code	Anti lock braking 2 (ABS)
SP2051	Fill incomplete	Anti lock braking 2 (ABS)
SP2052	The filling is complete and correct	Anti lock braking 2 (ABS)
SP2053	Fill complete but incorrect	Anti lock braking 2 (ABS)
SP2054	Bosch distribution	Anti lock braking 2 (ABS)
SP2055	Fill incomplete	Anti lock braking 2 (ABS)
SP2056	The filling is complete and correct	Anti lock braking 2 (ABS)
SP2057	Fill complete but incorrect	Anti lock braking 2 (ABS)
SP2058	Bosch distribution	Anti lock braking 2 (ABS)
SP2059	Write VIN code	body control module (BCM)
SP2060	Write SC code	body control module (BCM)
SP2061	Write internal diagnostic code	body control module (BCM)
SP2062	Write total mileage backup counter	body control module (BCM)
SP2063	Function configuration (Zhichao version)	body control module (BCM)
SP2064	Static network configuration (Zhichao version)	body control module (BCM)

SP2065	Function configuration 1	body control module (BCM)
SP2066	Function configuration 2	body control module (BCM)
SP2067	Static network configuration	body control module (BCM)
SP2068	Write VIN code	electronic gear controller (ESK)
SP2069	Write VIN code	pedestrians proximity voice warning (VSP)
SP2070	Write VIN code	central control infotainment system assembly (EHU)
SP2071	Write option configuration	central control infotainment system assembly (EHU)
SP2072	Write VIN code	drive motor system (MCU)
SP2073	Write motor code	drive motor system (MCU)
SP2074	Write VIN code	battery management system (BMS)
SP2075	Write Battery Code	battery management system (BMS)
SP2076	Write VIN code	around view monitor (AVM)
SP2077	Write VIN code	electronic parking brake (EPB)
SP2078	Write VIN code	on-board charger (OBC)
SP2079	Write VIN code	entertainment head unit (EHU)
SP2080	Offline configuration	entertainment head unit (EHU)
SP2081	Write VIN code	instrument cluster module (ICM)
SP2082	Total mileage	instrument cluster module (ICM)
SP2083	Remaining maintenance mileage	instrument cluster module (ICM)
SP2084	Write VIN code	gateway system
SP2085	Function configuration	gateway system
SP2086	Write VIN code	instrument panel fuse box (IEC)
SP2087	IEC vehicle age alarm function configuration	instrument panel fuse box (IEC)
SP2088	Steering angle sensor calibration	steering angle sensor calibration
SP2089	Write VIN code	battery management system (BMS)
SP2090	Write Battery Code	battery management system (BMS)
SP2091	Write VIN code	drive motor system (MCU)
SP2092	Write motor code	drive motor system (MCU)
SP2093	Write VIN code	remote monitor system (T-BOX)
SP2094	Time sharing lease mode	remote monitor system (T-BOX)
SP2095	Write VIN code	instrument cluster module (ICM)
SP2096	Total mileage learning	instrument cluster module (ICM)
SP2097	Total mileage write in	instrument cluster module (ICM)
SP2098	Maintenance mileage writing	instrument cluster module (ICM)
SP2099	Write mileage backup count	instrument cluster module (ICM)
SP2100	Configuration function	instrument cluster module (ICM)
SP2101	Write VIN code	passive entry passive start (PEPS)
SP2102	Write vehicle management status	passive entry passive start (PEPS)

SP2103	Write vehicle network configuration word	passive entry passive start (PEPS)
SP2104	Vehicle network configuration	passive entry passive start (PEPS)
SP2105	Write VIN code	battery management system (BMS)
SP2106	Write Battery Code	battery management system (BMS)
SP2107	Write VIN code	drive motor system (MCU)
SP2108	Write motor code	drive motor system (MCU)
SP2109	Data terminal communication loss handling mode configuration	drive motor system (MCU)
SP2110	Write VIN code	air conditioning system (ECC)
SP2111	Write VIN code	Central control system (EHU)
SP2112	Configuration function	Central control system (EHU)
SP2113	Write VIN code	instrument cluster module (ICM)
SP2114	Total mileage learning	instrument cluster module (ICM)
SP2115	Total mileage write in	instrument cluster module (ICM)
SP2116	Maintenance mileage writing	instrument cluster module (ICM)
SP2117	Write mileage backup count	instrument cluster module (ICM)
SP2118	Configuration function	instrument cluster module (ICM)
SP2119	Write VIN code	mobile phone wireless charging (PWC)
SP2120	Write VIN code	Water heating electric heater system(WTC-B)
SP2121	Write VIN code	Water heating electric heater system (wtc-h)
SP2122	Write VIN code	body control module (BCM)
SP2123	Write vehicle characteristic ID code	body control module (BCM)
SP2124	BCM function configuration 1	body control module (BCM)
SP2125	BCM function configuration 2	body control module (BCM)
SP2126	Vehicle network configuration	body control module (BCM)
SP2127	Write VIN code	anti-lock brake system and electronic stability program (ESP)
SP2128	Write fill status	anti-lock brake system and electronic stability program (ESP)
SP2129	Write EOL status	anti-lock brake system and electronic stability program (ESP)
SP2130	Vehicle configuration	anti-lock brake system and electronic stability program (ESP)
SP2131	Calibration of yaw angle sensor	anti-lock brake system and electronic stability program (ESP)
SP2132	Write VIN code	air conditioning control panel (APC)
SP2133	Write VIN code	electric power steering (EPS)
SP2134	Write initial position of steering wheel	electric power steering (EPS)

SP2135	Write VIN code	parking assist reversing controller (PAS)
SP2136	Write vehicle definition bitmap	parking assist reversing controller (PAS)
SP2137	Write VIN code	battery management system (BMS)
SP2138	Write Battery Code	battery management system (BMS)
SP2139	Write power battery SOC	battery management system (BMS)
SP2140	Total charging ampere hour	battery management system (BMS)
SP2141	Write power battery mileage	battery management system (BMS)
SP2142	Write VIN code	instrument cluster module (ICM)
SP2143	Total mileage	instrument cluster module (ICM)
SP2144	Remaining maintenance mileage	instrument cluster module (ICM)
SP2145	configuration parameter	instrument cluster module (ICM)
SP2146	Write VIN code	drive motor system (MCU)
SP2147	Write VIN code	tire pressure monitor system (TPMS)
SP2148	Set up tire exchange	tire pressure monitor system (TPMS)
SP2149	Write left front wheel position transmitter ID	tire pressure monitor system (TPMS)
SP2150	Write right front wheel position transmitter ID	tire pressure monitor system (TPMS)
SP2151	Write left rear wheel bit transmitter ID	tire pressure monitor system (TPMS)
SP2152	Write right rear wheel bit transmitter ID	tire pressure monitor system (TPMS)
SP2153	Write VIN code	vehicle control unit (VCU)
SP2154	Write VIN code	battery management system (BMS)
SP2155	Write Battery Code	battery management system (BMS)
SP2156	Write power battery SOC	battery management system (BMS)
SP2157	Write VIN code	vehicle control unit (VCU)
SP2158	Configuration of terminal communication loss handling mode	vehicle control unit (VCU)
SP2159	Write VIN code	battery management system (BMS)
SP2160	Write Battery Code	battery management system (BMS)
SP2161	Write power battery SOC	battery management system (BMS)
SP2162	Write VIN code	Da Jun drive motor system (MCU)
SP2163	Write motor code	Da Jun drive motor system (MCU)
SP2164	Write VIN code	electronically controlled booster and brake master cylinder assembly (NBS)
SP2165	Check push rod zero position (push rod zero position calibration)	electronically controlled booster and brake master cylinder assembly (NBS)
SP2166	Load matching	electronically controlled booster and brake master cylinder assembly (NBS)
SP2167	Static output limit function	electronically controlled booster and brake master cylinder assembly (NBS)
SP2168	Write VIN code	electric power steering (EPS)

SP2169	Write VIN code	entertainment head unit high configuration (EHU)
SP2170	Function configuration	entertainment head unit high configuration (EHU)
SP2171	Write VIN code	battery management system (BMS)
SP2172	Write Battery Code	battery management system (BMS)
SP2173	Write VIN code	drive motor system (MCU)
SP2174	Write motor code	drive motor system (MCU)
SP2175	Write motor configuration.	drive motor system (MCU)
SP2176	Write application fingerprint	drive motor system (MCU)
SP2177	Write VIN code	on-board charger (OBC)
SP2178	Write VIN code	entertainment head unit (EHU)
SP2179	Configuration function	entertainment head unit (EHU)
SP2180	Write VIN code	instrument cluster module (ICM)
SP2181	Total mileage	instrument cluster module (ICM)
SP2182	Remaining maintenance mileage	instrument cluster module (ICM)
SP2183	Write configuration word	instrument cluster module (ICM)
SP2184	Write VIN code	warm air heating system (PTC)
SP2185	VCU single pedal configuration byte (EHU)	warm air heating system (PTC)
SP2186	Configuration of terminal communication loss handling mode	warm air heating system (PTC)
SP2187	Write VIN code	vehicle control unit (VCU)
SP2188	Write VIN code	compressor controller (EAS)
SP2189	Write VIN code	electric power steering (EPS)
SP2190	Angle zero	electric power steering (EPS)
SP2191	Clear angle zero	electric power steering (EPS)
SP2192	Write VIN code	internal ambient light (ALC)
SP2193	Auto assign ID	internal ambient light (ALC)
SP2194	ALC function configuration	internal ambient light (ALC)
SP2195	Vehicle network configuration	internal ambient light (ALC)
SP2196	Steering angle sensor calibration	steering angle sensor (SAS)
SP2197	Steering angle sensor calibration	steering angle sensor (SAS)
SP2198	Write Vin	Instrument cluster module (ICM)
SP2199	Vehicle configuration code	Instrument cluster module (ICM)
SP2200	Vehicle configuration	Instrument cluster module (ICM)
SP2201	Write in maintenance mileage	Instrument cluster module (ICM)
SP2202	Mileage pulse count setting	Instrument cluster module (ICM)

SP2203	Write VIN code	Body electronic control module (BCM)
SP2204	Write programming date	Body electronic control module (BCM)
SP2205	Vehicle configuration code	Body electronic control module (BCM)
SP2206	Static network settings	Body electronic control module (BCM)
SP2207	Function configuration	Body electronic control module (BCM)
SP2208	Function configuration 2	Body electronic control module (BCM)
SP2209	Write VIN code	Air bag system (SDM)
SP2210	enable/disable airbag	Air bag system (SDM)
SP2211	Configuration of Airbag ECU	Air bag system (SDM)
SP2212	Left actuator control	Electronic brake system (EPB)
SP2213	Right actuator control	Electronic brake system (EPB)
SP2214	EPB system actuator control	Electronic brake system (EPB)
SP2215	G sensor calibration	Electronic brake system (EPB)
SP2216	Assembly inspection	Electronic brake system (EPB)
SP2217	Vehicle variable configuration	Electronic brake system (EPB)
SP2218	Angle calibration	Henglong electric power steering system (EPS) _ HL)
SP2219	Recalibration of angle zero position	Henglong electric power steering system (EPS) _ HL)
SP2220	Write VIN code	Henglong electric power steering system (EPS) _ HL)
SP2221	Option configuration	Henglong electric power steering system (EPS) _ HL)
SP2222	Angle zero calibration	North Henan electric power steering system (EPS) YB)
SP2223	Write VIN code	North Henan electric power steering system (EPS) YB)
SP2224	Write Vin	Electronic steering column module (ESCL)
SP2225	Software reset	Electronic steering column module (ESCL)
SP2226	Write Vin	Keyless start system (peps)
SP2227	Write programming date	Keyless start system (peps)
SP2228	Vehicle network configuration	Keyless start system (peps)
SP2229	Write VIN code	Air conditioning controller module (EAC)
SP2230	Write programming date	Air conditioning controller module (EAC)
SP2231	Function configuration	DVD navigation module (hum)
SP2232	HUM configuration	DVD navigation module (hum)
SP2233	Write VIN code	DVD navigation module (hum)
SP2234	Obstacle distance detection	Reversing radar control module (PAS)
SP2235	Write Vin	Reversing radar control module (PAS)
SP2236	Option configuration	Reversing radar control module (PAS)
SP2237	Write Vin	Panoramic image module (AVM)
SP2238	Option configuration	Panoramic image module (AVM)

SP2239	Write VIN code	Gateway (GW)
SP2240	Write programming date	Gateway (GW)
SP2241	Vehicle configuration code	Gateway (GW)
SP2242	network configuration	Gateway (GW)
SP2243	Write Vin	Body electronic control module (BCM)
SP2244	Write programming date	Body electronic control module (BCM)
SP2245	Vehicle configuration code	Body electronic control module (BCM)
SP2246	BCM function configuration	Body electronic control module (BCM)
SP2247	BCM function configuration 2	Body electronic control module (BCM)
SP2248	Body network configuration	Body electronic control module (BCM)
SP2249	Write Vin	Air bag system (SDM)
SP2250	Write programming date	Air bag system (SDM)
SP2251	Configuration of Airbag ECU	Air bag system (SDM)
SP2252	Airbag initiation status setting	Air bag system (SDM)
SP2253	Write VIN code	DVD navigation module (hum)
SP2254	Write programming date	DVD navigation module (hum)
SP2255	Option configuration	DVD navigation module (hum)
SP2256	Instrument type configuration	DVD navigation module (hum)
SP2257	Write VIN code	Electric air conditioning (EAC)
SP2258	Write Vin	Tire pressure monitoring system (TPMS)
SP2259	Write programming date	Tire pressure monitoring system (TPMS)
SP2260	Write standard tire pressure	Tire pressure monitoring system (TPMS)
SP2261	Tire pressure sensor replacement	Tire pressure monitoring system (TPMS)
SP2262	Transposition of tire pressure sensor	Tire pressure monitoring system (TPMS)
SP2263	Tire pressure sensor learning	Tire pressure monitoring system (TPMS)
SP2264	Hardware reset	Tire pressure monitoring system (TPMS)
SP2265	Write VIN code	Front seat heating module (FSH)
SP2266	Write programming date	Front seat heating module (FSH)
SP2267	Obstacle distance detection	4 & 8 inch parking aid module (PAS)
SP2268	Write Vin	4 & 8 inch parking aid module (PAS)
SP2269	Option configuration	4 & 8 inch parking aid module (PAS)
SP2270	Write Vin	Gasoline engine control module (EMS)
SP2271	Dental information learning	Gasoline engine control module (EMS)
SP2272	Write VIN code	Diesel engine control module (EMS)
SP2273	Write programming date	Diesel engine control module (EMS)

SP2274	Nozzle matching	Diesel engine control module (EMS)
SP2275	Write VIN code	ZF transmission module
SP2276	Reset adaptive value	ZF transmission module
SP2277	Write VIN code	Instrument cluster module (ICM)
SP2278	Write programming date	Instrument cluster module (ICM)
SP2279	Write vehicle configuration code	Instrument cluster module (ICM)
SP2280	Write PPK	Instrument cluster module (ICM)
SP2281	Write in maintenance mileage	Instrument cluster module (ICM)
SP2282	Write configuration information	Instrument cluster module (ICM)
SP2283	Read / write ECU configuration	Air bag system (SDM)
SP2284	enable/disable ECU ignition	Air bag system (SDM)
SP2285	Write VIN code	Air bag system (SDM)
SP2286	Write programming date	Air bag system (SDM)
SP2287	Write vehicle feature information	Air bag system (SDM)
SP2288	Write Vin	Body electronic control module (BCM)
SP2289	Write programming date	Body electronic control module (BCM)
SP2290	Vehicle configuration code	Body electronic control module (BCM)
SP2291	Static network configuration	Body electronic control module (BCM)
SP2292	Function configuration	Body electronic control module (BCM)
SP2293	Collision configuration	Body electronic control module (BCM)
SP2294	Configuration of left and right rudders	Body electronic control module (BCM)
SP2295	Number of collisions	Body electronic control module (BCM)
SP2296	Write VIN code	Left front door module (DCU) LF)
SP2297	Write programming date	Left front door module (DCU) LF)
SP2298	Write vehicle feature information	Left front door module (DCU) LF)
SP2299	Function configuration	Left front door module (DCU) LF)
SP2300	Configuration of left and right rudders	Left front door module (DCU) LF)
SP2301	Write VIN code	Right front door module (DCU) RF)
SP2302	Write programming date	Right front door module (DCU) RF)
SP2303	Write vehicle feature information	Right front door module (DCU) RF)
SP2304	Function configuration	Right front door module (DCU) RF)
SP2305	Configuration of left and right rudders	Right front door module (DCU) RF)
SP2306	Write VIN code	Left rear door module (DCU) LR)
SP2307	Write programming date	Left rear door module (DCU) LR)
SP2308	Write vehicle feature information	Left rear door module (DCU) LR)

SP2309	Write VIN code	Right rear door module (DCU) RR)
SP2310	Write programming date	Right rear door module (DCU) RR)
SP2311	Write vehicle feature information	Right rear door module (DCU) RR)
SP2312	Write Vin	Tire pressure monitoring system (TPMS)
SP2313	Write programming date	Tire pressure monitoring system (TPMS)
SP2314	Tire pressure sensor replacement	Tire pressure monitoring system (TPMS)
SP2315	Transposition of tire pressure sensor	Tire pressure monitoring system (TPMS)
SP2316	Tire pressure sensor learning	Tire pressure monitoring system (TPMS)
SP2317	Write VIN code	Brake hydraulic control module (ESP)
SP2318	Write programming date	Brake hydraulic control module (ESP)
SP2319	Vehicle configuration (ESP only)	Brake hydraulic control module (ESP)
SP2320	Yaw rate sensor calibration	Brake hydraulic control module (ESP)
SP2321	Steering angle sensor calibration	Brake hydraulic control module (ESP)
SP2322	Write VIN code	Anti lock braking module (ABS)
SP2323	Write programming date	Anti lock braking module (ABS)
SP2324	ABS exhaust	Anti lock braking module (ABS)
SP2325	Vehicle configuration (ABS only)	Anti lock braking module (ABS)
SP2326	Write clearance self adjusting kilometers	Electronic brake system (EPB)
SP2327	Vehicle configuration	Electronic brake system (EPB)
SP2328	Left actuator control	Electronic brake system (EPB)
SP2329	Right actuator control	Electronic brake system (EPB)
SP2330	EPB system actuator control	Electronic brake system (EPB)
SP2331	G sensor calibration	Electronic brake system (EPB)
SP2332	Assembly inspection	Electronic brake system (EPB)
SP2333	Vehicle network configuration	Keyless start system (peps)
SP2334	Write VIN code	Keyless start system (peps)
SP2335	Write programming date	Keyless start system (peps)
SP2336	Write maximum uid code	Keyless start system (peps)
SP2337	Write vehicle status	Keyless start system (peps)
SP2338	Write Vin	Electronic steering column module (ESCL)
SP2339	Write programming date	Electronic steering column module (ESCL)
SP2340	Vehicle configuration	Electronic steering column module (ESCL)
SP2341	Write programming date	Air conditioning controller module (ACC)
SP2342	Write vehicle feature information	Air conditioning controller module (ACC)
SP2343	Write programming date	Air conditioning panel (ACP)
SP2344	Write vehicle feature information	Air conditioning panel (ACP)

SP2345	Write Vin	Reversing video module (RVC)
SP2346	Write programming date	Reversing video module (RVC)
SP2347	ESP configuration	Reversing video module (RVC)
SP2348	Write VIN code	Reversing radar system (PAS)
SP2349	Write programming date	Off road information module (orim)
SP2350	Write vehicle feature information	Off road information module (orim)
SP2351	Vehicle configuration	Off road information module (orim)
SP2352	Write VIN code	Streaming media rearview mirror (SVM)
SP2353	Write programming date	Streaming media rearview mirror (SVM)
SP2354	Write vehicle feature information	Streaming media rearview mirror (SVM)
SP2355	Function configuration	Video entertainment system (EHC)
SP2356	Write VIN code	Video entertainment system (EHC)
SP2357	Write programming date	Video entertainment system (EHC)
SP2358	Write vehicle feature information	Video entertainment system (EHC)
SP2359	Function configuration	Vehicle data recorder (DVR)
SP2360	Write VIN code	Vehicle data recorder (DVR)
SP2361	Write programming date	Vehicle data recorder (DVR)
SP2362	Write vehicle feature information	Vehicle data recorder (DVR)
SP2363	Write VIN code	Gateway (GW)
SP2364	Write programming date	Gateway (GW)
SP2365	Function configuration	Gateway (GW)
SP2366	Write VIN code	Can (SDM)
SP2367	Airbag module learning (0d8d)	Can (SDM)
SP2368	Write VIN code	TCU (automatic transmission system)
SP2369	Write VIN code	ABS (anti lock braking system)
SP2370	ABS exhaust (anti lock exhaust)	ABS (anti lock braking system)
SP2371	Write VIN code	BCM (body control system)
SP2372	Vehicle configuration code	BCM (body control system)
SP2373	Vehicle configuration	BCM (body control system)
SP2374	Static network configuration	BCM (body control system)
SP2375	Write VIN code	ICM (combination instrument)
SP2376	Vehicle configuration code	ICM (combination instrument)
SP2377	EOL configuration	ICM (combination instrument)
SP2378	Vehicle configuration	ICM (combination instrument)
SP2379	Maintenance mileage setting (maintenance return to zero)	ICM (combination instrument)
SP2380	Write VIN code	AC (air conditioning system)
SP2381	Write VIN code	Hum (DVD host)
SP2382	Function configuration	Hum (DVD host)

SP2383	Write VIN code	SDM (air bag)
SP2384	ECU configuration - Airbag	SDM (air bag)
SP2385	Enable / disable airbags	SDM (air bag)
SP2386	Write VIN code	EPS (electronic power steering system)
SP2387	Vehicle configuration code	EMS (engine system)
SP2388	Write VIN code	TCU (automatic transmission system)
SP2389	Write VIN code	ABS (anti lock braking system)
SP2390	ABS exhaust (anti lock exhaust)	ABS (anti lock braking system)
SP2391	Write VIN code	Peps (keyless start system)
SP2392	Write VIN code	BCM (body control system)
SP2393	Vehicle configuration code	BCM (body control system)
SP2394	Vehicle configuration	BCM (body control system)
SP2395	Static network configuration	BCM (body control system)
SP2396	Write VIN code	ICM (combination instrument)
SP2397	Vehicle configuration code	ICM (combination instrument)
SP2398	EOL configuration	ICM (combination instrument)
SP2399	Vehicle configuration	ICM (combination instrument)
SP2400	Maintenance mileage setting (maintenance return to zero)	ICM (combination instrument)
SP2401	Write VIN code	SDM (air bag)
SP2402	ECU configuration - Airbag	SDM (air bag)
SP2403	Enable / disable airbags	SDM (air bag)
SP2404	Write VIN code	EPS (electronic power steering system)
SP2405	Write VIN code	AC (air conditioning system)
SP2406	Write VIN code	Hum (DVD host)
SP2407	Function configuration	Hum (DVD host)
SP2408	Write VIN code	ESCL (electronic steering column lock)
SP2409	Vehicle configuration code	EMS (engine system)
SP2410	Write VIN code	BCM (body control system)
SP2411	Vehicle configuration code	BCM (body control system)
SP2412	Vehicle configuration	BCM (body control system)
SP2413	Static network configuration	BCM (body control system)
SP2414	Write VIN code	TCU (automatic transmission system)
SP2415	Write VIN code	ABS (anti lock braking system)
SP2416	ABS exhaust (anti lock exhaust)	ABS (anti lock braking system)

SP2417	Write VIN code	ESP (body electronic stability system)
SP2418	ESP exhaust	ESP (body electronic stability system)
SP2419	Function configuration	ESP (body electronic stability system)
SP2420	Calibration of yaw rate sensor	ESP (body electronic stability system)
SP2421	Indirect tire pressure calibration	ESP (body electronic stability system)
SP2422	Write VIN code	EPS (electronic power steering system)
SP2423	Steering angle sensor calibration	EPS (electronic power steering system)
SP2424	Write VIN code	ICM (combination instrument)
SP2425	Vehicle configuration code	ICM (combination instrument)
SP2426	EOL configuration	ICM (combination instrument)
SP2427	Vehicle configuration	ICM (combination instrument)
SP2428	Maintenance mileage setting (maintenance return to zero)	ICM (combination instrument)
SP2429	Write VIN code	SDM (air bag)
SP2430	ECU configuration - Airbag	SDM (air bag)
SP2431	Enable / disable airbags	SDM (air bag)
SP2432	Write VIN code	Hum (DVD host)
SP2433	Function configuration	Hum (DVD host)
SP2434	Write VIN code	ATC (automatic air conditioning system)
SP2435	Read and write VIN code	EMS (engine system)
SP2436	Dental information learning	EMS (engine system)
SP2437	Read and write VIN code	BCM (body control system)
SP2438	Write vehicle configuration code	BCM (body control system)
SP2439	Static network settings	BCM (body control system)
SP2440	Initial setting of body electronic control module	BCM (body control system)
SP2441	Auto off delay time or position light off delay time	BCM (body control system)
SP2442	Read and write VIN code	Peps (keyless start system)
SP2443	Read and write VIN code	ESP (body electronic stability system)
SP2444	ESP exhaust	ESP (body electronic stability system)
SP2445	Vehicle configuration	ESP (body electronic stability system)
SP2446	Calibration of yaw rate sensor	ESP (body electronic stability system)
SP2447	Steering angle sensor calibration	ESP (body electronic stability system)
SP2448	Indirect tire pressure calibration	ESP (body electronic stability system)

SP2449	Write VIN code	TCU (automatic transmission system)
SP2450	Read and write VIN code	ICM (combination instrument)
SP2451	Write vehicle configuration code	ICM (combination instrument)
SP2452	Function configuration	ICM (combination instrument)
SP2453	Maintenance mileage setting (maintenance return to zero)	ICM (combination instrument)
SP2454	Fast write function matching	ICM (combination instrument)
SP2455	Read and write VIN code	AC (air conditioning system)
SP2456	Read and write VIN code	AHL (headlight height adjustment system)
SP2457	Read and write VIN code	DSM (seat memory module)
SP2458	Read and write VIN code	SRS (air bag)
SP2459	ECU configuration - Airbag	SRS (air bag)
SP2460	Enable / disable airbags	SRS (air bag)
SP2461	Read and write VIN code	Hum (DVD host)
SP2462	Read and write VIN code	ESCL (electronic steering column lock)
SP2463	Function configuration	ESCL (electronic steering column lock)
SP2464	Read and write VIN code	Pas (reversing radar system)
SP2465	Function configuration	Pas (reversing radar system)
SP2466	ECU self test	Pas (reversing radar system)
SP2467	PAS self test	Pas (reversing radar system)
SP2468	Can self test	Pas (reversing radar system)
SP2469	SVA self test	Pas (reversing radar system)
SP2470	Read and write VIN code	RVC (reverse camera system)
SP2471	Read and write VIN code	EMS (combined electric engine system)
SP2472	Write vehicle configuration code	EMS (combined electric engine system)
SP2473	Read and write VIN code	TCU (automatic transmission system)
SP2474	Clear clutch self-learning value	TCU (automatic transmission system)
SP2475	Read and write VIN code	Peps (keyless start system)
SP2476	Read and write VIN code	BCM (body control system)
SP2477	Write vehicle configuration code	BCM (body control system)
SP2478	Body function configuration 1	BCM (body control system)
SP2479	Body function configuration 2	BCM (body control system)
SP2480	Static network configuration	BCM (body control system)
SP2481	ODO backup count	BCM (body control system)
SP2482	Read and write VIN code	ICM (combination instrument)
SP2483	Write vehicle configuration code	ICM (combination instrument)
SP2484	Vehicle configuration	ICM (combination instrument)

SP2485	Mileage learning	ICM (combination instrument)
SP2486	Maintenance mileage setting (maintenance return to zero)	ICM (combination instrument)
SP2487	Read and write VIN code	ESP (body electronic stability system)
SP2488	ESP exhaust	ESP (body electronic stability system)
SP2489	Function configuration	ESP (body electronic stability system)
SP2490	Calibration of yaw rate sensor	ESP (body electronic stability system)
SP2491	Apbmi calibration function	ESP (body electronic stability system)
SP2492	Read and write VIN code	EPS (electronic power steering system)
SP2493	Function configuration	EPS (electronic power steering system)
SP2494	Steering angle sensor calibration (steering angle learning)	EPS (electronic power steering system)
SP2495	Read and write VIN code	ESCL (electronic steering column lock)
SP2496	Read and write VIN code	SRS (air bag)
SP2497	ECU configuration - Airbag	SRS (air bag)
SP2498	Enable / disable airbags	SRS (air bag)
SP2499	Read and write VIN code	AC (air conditioning system)
SP2500	Vehicle configuration	AC (air conditioning system)
SP2501	Read and write VIN code	GW (Gateway System)
SP2502	Write vehicle configuration code	GW (Gateway System)
SP2503	network configuration	GW (Gateway System)
SP2504	Read and write VIN code	Hum (DVD host)
SP2505	Write engine number (smart car)	Hum (DVD host)
SP2506	Hum configuration (smart car)	Hum (DVD host)
SP2507	Function configuration	Hum (DVD host)
SP2508	Read and write VIN code	Tbox (remote monitoring system)
SP2509	EOL node configuration	Tbox (remote monitoring system)
SP2510	EOL function configuration	Tbox (remote monitoring system)
SP2511	Read and write VIN code	TPMS (tire pressure monitoring system)
SP2512	Tire pressure sensor (5th generation-10 system)	TPMS (tire pressure monitoring system)
SP2513	Tire pressure sensor (6th generation-16)	TPMS (tire pressure monitoring system)
SP2514	Left front tire sensor ID	TPMS (tire pressure monitoring system)
SP2515	Front right tire sensor ID	TPMS (tire pressure monitoring system)
SP2516	Left rear tire sensor ID	TPMS (tire pressure monitoring system)

SP2517	Rear right tire sensor ID	TPMS (tire pressure monitoring system)
SP2518	Left front tire sensor ID	TPMS (tire pressure monitoring system)
SP2519	Front right tire sensor ID	TPMS (tire pressure monitoring system)
SP2520	Left rear tire sensor ID	TPMS (tire pressure monitoring system)
SP2521	Rear right tire sensor ID	TPMS (tire pressure monitoring system)
SP2522	Front left and right	TPMS (tire pressure monitoring system)
SP2523	Back left and right	TPMS (tire pressure monitoring system)
SP2524	Left side forward backward swap	TPMS (tire pressure monitoring system)
SP2525	Right side forward backward swap	TPMS (tire pressure monitoring system)
SP2526	Front left back right swap	TPMS (tire pressure monitoring system)
SP2527	Front right rear left swap	TPMS (tire pressure monitoring system)
SP2528	Left front tire	TPMS (tire pressure monitoring system)
SP2529	Right front tire	TPMS (tire pressure monitoring system)
SP2530	Rear left tire	TPMS (tire pressure monitoring system)
SP2531	Rear right tire	TPMS (tire pressure monitoring system)
SP2532	Tire pressure standard value setting	TPMS (tire pressure monitoring system)
SP2533	Read and write VIN code	DVR (vehicle data recorder)
SP2534	Write vehicle configuration code	DVR (vehicle data recorder)
SP2535	Function configuration	DVR (vehicle data recorder)
SP2536	Read and write VIN code	Pas (reversing radar system)
SP2537	Write vehicle configuration code	Pas (reversing radar system)
SP2538	Function configuration	Pas (reversing radar system)
SP2539	Obstacle distance detection	Pas (reversing radar system)
SP2540	Read and write VIN code	ACP (air conditioning panel)
SP2541	Read and write VIN code	AVM (panoramic image system)
SP2542	Write VIN code	EMS (engine system)
SP2543	Read all injectors	EMS (engine system)
SP2544	Read write injector 1	EMS (engine system)
SP2545	Read write injector 2	EMS (engine system)
SP2546	Read write injector 3	EMS (engine system)
SP2547	Read write injector 4	EMS (engine system)
SP2548	Cylinder 1	EMS (engine system)
SP2549	Cylinder 2	EMS (engine system)
SP2550	Cylinder 3	EMS (engine system)
SP2551	Cylinder 4	EMS (engine system)
SP2552	Read and write VIN code	Peps (keyless start system)

SP2553	Read and write VIN code	BCM (body control system)
SP2554	Write vehicle configuration code	BCM (body control system)
SP2555	Vehicle function configuration	BCM (body control system)
SP2556	Static network configuration	BCM (body control system)
SP2557	Collision status settings	BCM (body control system)
SP2558	Number of collisions	BCM (body control system)
SP2559	Read and write VIN code	ABS (anti lock braking system)
SP2560	ABS exhaust (anti lock exhaust)	ABS (anti lock braking system)
SP2561	Vehicle configuration	ABS (anti lock braking system)
SP2562	Read and write VIN code	ESP (body electronic stability system)
SP2563	ESP exhaust	ESP (body electronic stability system)
SP2564	Function configuration	ESP (body electronic stability system)
SP2565	Calibration of yaw rate sensor	ESP (body electronic stability system)
SP2566	Steering angle sensor calibration	ESP (body electronic stability system)
SP2567	Read and write VIN code	IPC (combination instrument)
SP2568	Write vehicle configuration code	IPC (combination instrument)
SP2569	Vehicle function configuration	IPC (combination instrument)
SP2570	Maintenance mileage setting (maintenance return to zero)	IPC (combination instrument)
SP2571	Read and write VIN code	ESCL (electronic steering column lock)
SP2572	Vehicle configuration	ESCL (electronic steering column lock)
SP2573	Read and write VIN code	DCU LF (left front door module)
SP2574	Write vehicle configuration code	DCU LF (left front door module)
SP2575	Function configuration	DCU LF (left front door module)
SP2576	Read and write VIN code	DCU RF (right front door module)
SP2577	Write vehicle configuration code	DCU RF (right front door module)
SP2578	Function configuration	DCU RF (right front door module)
SP2579	Read and write VIN code	DCU LR (left rear door module)
SP2580	Write vehicle configuration code	DCU LR (left rear door module)
SP2581	Read and write VIN code	DCU RR (right rear door module)
SP2582	Write vehicle configuration code	DCU RR (right rear door module)
SP2583	Read and write VIN code	GW (Gateway System)
SP2584	Function configuration	GW (Gateway System)
SP2585	Read and write VIN code	SDM (air bag)

SP2586	Write vehicle configuration code	SDM (air bag)
SP2587	ECU configuration - Airbag	SDM (air bag)
SP2588	Enable / disable airbags	SDM (air bag)
SP2589	Read and write VIN code	TPMS (tire pressure monitoring system)
SP2590	Tire pressure sensor (5th generation-10 system)	TPMS (tire pressure monitoring system)
SP2591	Left front tire sensor ID	TPMS (tire pressure monitoring system)
SP2592	Front right tire sensor ID	TPMS (tire pressure monitoring system)
SP2593	Left rear tire sensor ID	TPMS (tire pressure monitoring system)
SP2594	Rear right tire sensor ID	TPMS (tire pressure monitoring system)
SP2595	Tire pressure sensor (6th generation-16)	TPMS (tire pressure monitoring system)
SP2596	Left front tire sensor ID	TPMS (tire pressure monitoring system)
SP2597	Front right tire sensor ID	TPMS (tire pressure monitoring system)
SP2598	Left rear tire sensor ID	TPMS (tire pressure monitoring system)
SP2599	Rear right tire sensor ID	TPMS (tire pressure monitoring system)
SP2600	Front left and right	TPMS (tire pressure monitoring system)
SP2601	Back left and right	TPMS (tire pressure monitoring system)
SP2602	Left side forward backward swap	TPMS (tire pressure monitoring system)
SP2603	Right side forward backward swap	TPMS (tire pressure monitoring system)
SP2604	Front left back right swap	TPMS (tire pressure monitoring system)
SP2605	Front right rear left swap	TPMS (tire pressure monitoring system)
SP2606	Left front tire	TPMS (tire pressure monitoring system)
SP2607	Right front tire	TPMS (tire pressure monitoring system)
SP2608	Rear left tire	TPMS (tire pressure monitoring system)
SP2609	Rear right tire	TPMS (tire pressure monitoring system)
SP2610	Tire pressure standard value setting	TPMS (tire pressure monitoring system)
SP2611	Read and write VIN code	Orim (off road information module)
SP2612	Write vehicle configuration code	Orim (off road information module)
SP2613	Function configuration	Orim (off road information module)
SP2614	Read and write VIN code	Pas (reversing radar system)

SP2615	Write vehicle configuration code	Pas (reversing radar system)
SP2616	Read and write VIN code	RVC (reverse camera system)
SP2617	Function configuration	RVC (reverse camera system)
SP2618	Read and write VIN code	Hum (DVD host)
SP2619	Write vehicle configuration code	Hum (DVD host)
SP2620	Function configuration	Hum (DVD host)
SP2621	Read and write VIN code	EPB (electronic parking brake system)
SP2622	Option configuration	EPB (electronic parking brake system)
SP2623	Actuator detection	EPB (electronic parking brake system)
SP2624	Calibration of slope sensor	EPB (electronic parking brake system)
SP2625	Read and write VIN code	AC (air conditioning system)
SP2626	Write vehicle configuration code	AC (air conditioning system)
SP2627	Read and write VIN code	ACP (air conditioning panel)
SP2628	Read and write VIN code	AWD (four wheel drive controller)
SP2629	Read and write VIN code	EMS (engine system)
SP2630	EMS configuration	EMS (engine system)
SP2631	Throttle forced self learning	EMS (engine system)
SP2632	Clear clutch self-learning value	TCU (automatic transmission system)
SP2633	Read and write VIN code	Peps (keyless start system)
SP2634	Read and write VIN code	BCM (body control system)
SP2635	Write vehicle configuration code	BCM (body control system)
SP2636	Vehicle function configuration	BCM (body control system)
SP2637	Static network configuration	BCM (body control system)
SP2638	Collision status settings	BCM (body control system)
SP2639	Number of collisions	BCM (body control system)
SP2640	Read and write VIN code	ABS (anti lock braking system)
SP2641	ABS exhaust (anti lock exhaust)	ABS (anti lock braking system)
SP2642	Vehicle configuration	ABS (anti lock braking system)
SP2643	Read and write VIN code	ESP (body electronic stability system)
SP2644	ESP exhaust	ESP (body electronic stability system)
SP2645	Function configuration	ESP (body electronic stability system)
SP2646	Calibration of yaw rate sensor	ESP (body electronic stability system)
SP2647	Steering angle sensor calibration	ESP (body electronic stability system)
SP2648	Read and write VIN code	IPC (combination instrument)
SP2649	Write vehicle configuration code	IPC (combination instrument)

SP2650	Vehicle function configuration	IPC (combination instrument)
SP2651	Maintenance mileage setting (maintenance return to zero)	IPC (combination instrument)
SP2652	Read and write VIN code	ESCL (electronic steering column lock)
SP2653	Vehicle configuration	ESCL (electronic steering column lock)
SP2654	Read and write VIN code	DCU LF (left front door module)
SP2655	Write vehicle configuration code	DCU LF (left front door module)
SP2656	Function configuration	DCU LF (left front door module)
SP2657	Read and write VIN code	DCU RF (right front door module)
SP2658	Write vehicle configuration code	DCU RF (right front door module)
SP2659	Function configuration	DCU RF (right front door module)
SP2660	Read and write VIN code	DCU LR (left rear door module)
SP2661	Write vehicle configuration code	DCU LR (left rear door module)
SP2662	Read and write VIN code	DCU RR (right rear door module)
SP2663	Write vehicle configuration code	DCU RR (right rear door module)
SP2664	Read and write VIN code	GW (Gateway System)
SP2665	Function configuration	GW (Gateway System)
SP2666	Read and write VIN code	SDM (air bag)
SP2667	Write vehicle configuration code	SDM (air bag)
SP2668	ECU configuration - Airbag	SDM (air bag)
SP2669	Enable / disable airbags	SDM (air bag)
SP2670	Read and write VIN code	TPMS (tire pressure monitoring system)
SP2671	Tire pressure sensor (5th generation-10 system)	TPMS (tire pressure monitoring system)
SP2672	Left front tire sensor ID	TPMS (tire pressure monitoring system)
SP2673	Front right tire sensor ID	TPMS (tire pressure monitoring system)
SP2674	Left rear tire sensor ID	TPMS (tire pressure monitoring system)
SP2675	Rear right tire sensor ID	TPMS (tire pressure monitoring system)
SP2676	Tire pressure sensor (6th generation-16)	TPMS (tire pressure monitoring system)
SP2677	Left front tire sensor ID	TPMS (tire pressure monitoring system)
SP2678	Front right tire sensor ID	TPMS (tire pressure monitoring system)
SP2679	Left rear tire sensor ID	TPMS (tire pressure monitoring system)

SP2680	Rear right tire sensor ID	TPMS (tire pressure monitoring system)
SP2681	Front left and right	TPMS (tire pressure monitoring system)
SP2682	Back left and right	TPMS (tire pressure monitoring system)
SP2683	Left side forward backward swap	TPMS (tire pressure monitoring system)
SP2684	Right side forward backward swap	TPMS (tire pressure monitoring system)
SP2685	Front left back right swap	TPMS (tire pressure monitoring system)
SP2686	Front right rear left swap	TPMS (tire pressure monitoring system)
SP2687	Left front tire	TPMS (tire pressure monitoring system)
SP2688	Right front tire	TPMS (tire pressure monitoring system)
SP2689	Rear left tire	TPMS (tire pressure monitoring system)
SP2690	Rear right tire	TPMS (tire pressure monitoring system)
SP2691	Tire pressure standard value setting	TPMS (tire pressure monitoring system)
SP2692	Read and write VIN code	Orim (off road information module)
SP2693	Write vehicle configuration code	Orim (off road information module)
SP2694	Function configuration	Orim (off road information module)
SP2695	Read and write VIN code	Pas (reversing radar system)
SP2696	Write vehicle configuration code	Pas (reversing radar system)
SP2697	Read and write VIN code	RVC (reverse camera system)
SP2698	Function configuration	RVC (reverse camera system)
SP2699	Read and write VIN code	Hum (DVD host)
SP2700	Write vehicle configuration code	Hum (DVD host)
SP2701	Function configuration	Hum (DVD host)
SP2702	Read and write VIN code	EPB (electronic parking brake system)
SP2703	Option configuration	EPB (electronic parking brake system)
SP2704	Actuator detection	EPB (electronic parking brake system)
SP2705	Calibration of slope sensor	EPB (electronic parking brake system)
SP2706	Read and write VIN code	AC (air conditioning system)
SP2707	Write vehicle configuration code	AC (air conditioning system)
SP2708	Read and write VIN code	ACP (air conditioning panel)
SP2709	Read and write VIN code	AWD (four wheel drive controller)
SP2710	Read and write VIN code	EMS (engine system)
SP2711	Dental information learning	EMS (engine system)
SP2712	Read and write VIN code	TCU (automatic transmission system)
SP2713	Write vehicle configuration code	TCU (automatic transmission system)
SP2714	Read and write VIN code	BCM (body control system)

SP2715	Write vehicle configuration code	BCM (body control system)
SP2716	Function configuration	BCM (body control system)
SP2717	Static network configuration	BCM (body control system)
SP2718	Collision status settings	BCM (body control system)
SP2719	Number of collisions	BCM (body control system)
SP2720	Read and write VIN code	Peps (keyless start system)
SP2721	Read and write VIN code	ESP (body electronic stability system)
SP2722	ESP exhaust	ESP (body electronic stability system)
SP2723	Function configuration	ESP (body electronic stability system)
SP2724	Calibration of yaw rate sensor	ESP (body electronic stability system)
SP2725	Steering angle sensor calibration	ESP (body electronic stability system)
SP2726	Read and write VIN code	IPC (combination instrument)
SP2727	Write vehicle configuration code	IPC (combination instrument)
SP2728	Function configuration	IPC (combination instrument)
SP2729	Maintenance mileage setting (maintenance return to zero)	IPC (combination instrument)
SP2730	Read and write VIN code	DCU LF (left front door module)
SP2731	Write vehicle configuration code	DCU LF (left front door module)
SP2732	Function configuration	DCU LF (left front door module)
SP2733	Read and write VIN code	DCU RF (right front door module)
SP2734	Write vehicle configuration code	DCU RF (right front door module)
SP2735	Function configuration	DCU RF (right front door module)
SP2736	Read and write VIN code	DCU LR (left rear door module)
SP2737	Write vehicle configuration code	DCU LR (left rear door module)
SP2738	Read and write VIN code	DCU RR (right rear door module)
SP2739	Write vehicle configuration code	DCU RR (right rear door module)
SP2740	Read and write VIN code	RVC (reverse camera system)
SP2741	Read and write VIN code	Pas (reversing radar system)
SP2742	Write vehicle configuration code	Pas (reversing radar system)
SP2743	Read and write VIN code	SDM (air bag)
SP2744	SDM working mode configuration	SDM (air bag)
SP2745	Read and write VIN code	GW (Gateway System)
SP2746	Function configuration	GW (Gateway System)
SP2747	Read and write VIN code	AHL (headlight height adjustment system)
SP2748	Function configuration	AHL (headlight height adjustment system)

SP2749	Chassis zero point correction	AHL (headlight height adjustment system)
SP2750	Read and write VIN code	CCP (central control panel)
SP2751	Read and write VIN code	ESCL (electronic steering column lock)
SP2752	Vehicle configuration	ESCL (electronic steering column lock)
SP2753	Read and write VIN code	Hum (DVD host)
SP2754	Radio frequency range setting	Hum (DVD host)
SP2755	Function configuration	Hum (DVD host)
SP2756	Read and write VIN code	TPMS (tire pressure monitoring system)
SP2757	Tire pressure sensor (5th generation-10 system)	TPMS (tire pressure monitoring system)
SP2758	Tire pressure sensor (6th generation-16)	TPMS (tire pressure monitoring system)
SP2759	Left front tire sensor ID	TPMS (tire pressure monitoring system)
SP2760	Front right tire sensor ID	TPMS (tire pressure monitoring system)
SP2761	Left rear tire sensor ID	TPMS (tire pressure monitoring system)
SP2762	Rear right tire sensor ID	TPMS (tire pressure monitoring system)
SP2763	Left front tire sensor ID	TPMS (tire pressure monitoring system)
SP2764	Front right tire sensor ID	TPMS (tire pressure monitoring system)
SP2765	Left rear tire sensor ID	TPMS (tire pressure monitoring system)
SP2766	Rear right tire sensor ID	TPMS (tire pressure monitoring system)
SP2767	Front left and right	TPMS (tire pressure monitoring system)
SP2768	Back left and right	TPMS (tire pressure monitoring system)
SP2769	Left side forward backward swap	TPMS (tire pressure monitoring system)
SP2770	Right side forward backward swap	TPMS (tire pressure monitoring system)
SP2771	Front left back right swap	TPMS (tire pressure monitoring system)
SP2772	Front right rear left swap	TPMS (tire pressure monitoring system)
SP2773	Left front tire	TPMS (tire pressure monitoring system)
SP2774	Right front tire	TPMS (tire pressure monitoring system)
SP2775	Rear left tire	TPMS (tire pressure monitoring system)
SP2776	Rear right tire	TPMS (tire pressure monitoring system)
SP2777	Tire pressure standard value setting	TPMS (tire pressure monitoring system)
SP2778	Read and write VIN code	DSM (seat memory module)
SP2779	Read and write VIN code	EMS (engine system)

SP2780	Dental information learning	EMS (engine system)
SP2781	Read and write VIN code	TCU (automatic transmission system)
SP2782	Write vehicle configuration code	TCU (automatic transmission system)
SP2783	Read and write VIN code	BCM (body control system)
SP2784	Write vehicle configuration code	BCM (body control system)
SP2785	Function configuration	BCM (body control system)
SP2786	Static network configuration	BCM (body control system)
SP2787	Collision status settings	BCM (body control system)
SP2788	Number of collisions	BCM (body control system)
SP2789	Read and write VIN code	Peps (keyless start system)
SP2790	Read and write VIN code	ESP (body electronic stability system)
SP2791	ESP exhaust	ESP (body electronic stability system)
SP2792	Function configuration	ESP (body electronic stability system)
SP2793	Calibration of yaw rate sensor	ESP (body electronic stability system)
SP2794	Steering angle sensor calibration	ESP (body electronic stability system)
SP2795	Read and write VIN code	IPC (combination instrument)
SP2796	Write vehicle configuration code	IPC (combination instrument)
SP2797	Function configuration	IPC (combination instrument)
SP2798	Maintenance mileage setting (maintenance return to zero)	IPC (combination instrument)
SP2799	Read and write VIN code	DCU LF (left front door module)
SP2800	Write vehicle configuration code	DCU LF (left front door module)
SP2801	Function configuration	DCU LF (left front door module)
SP2802	Read and write VIN code	DCU RF (right front door module)
SP2803	Write vehicle configuration code	DCU RF (right front door module)
SP2804	Function configuration	DCU RF (right front door module)
SP2805	Read and write VIN code	DCU LR (left rear door module)
SP2806	Write vehicle configuration code	DCU LR (left rear door module)
SP2807	Read and write VIN code	DCU RR (right rear door module)
SP2808	Write vehicle configuration code	DCU RR (right rear door module)
SP2809	Read and write VIN code	RVC (reverse camera system)
SP2810	Read and write VIN code	Pas (reversing radar system)
SP2811	Write vehicle configuration code	Pas (reversing radar system)
SP2812	Read and write VIN code	SDM (air bag)

SP2813	SDM working mode configuration	SDM (air bag)
SP2814	Read and write VIN code	GW (Gateway System)
SP2815	Function configuration	GW (Gateway System)
SP2816	Read and write VIN code	AHL (headlight height adjustment system)
SP2817	Function configuration	AHL (headlight height adjustment system)
SP2818	Chassis zero point correction	AHL (headlight height adjustment system)
SP2819	Read and write VIN code	CCP (central control panel)
SP2820	Read and write VIN code	ESCL (electronic steering column lock)
SP2821	Vehicle configuration	ESCL (electronic steering column lock)
SP2822	Read and write VIN code	Hum (DVD host)
SP2823	Radio frequency range setting	Hum (DVD host)
SP2824	Function configuration	Hum (DVD host)
SP2825	Read and write VIN code	TPMS (tire pressure monitoring system)
SP2826	Tire pressure sensor (5th generation-10 system)	TPMS (tire pressure monitoring system)
SP2827	Tire pressure sensor (6th generation-16)	TPMS (tire pressure monitoring system)
SP2828	Left front tire sensor ID	TPMS (tire pressure monitoring system)
SP2829	Front right tire sensor ID	TPMS (tire pressure monitoring system)
SP2830	Left rear tire sensor ID	TPMS (tire pressure monitoring system)
SP2831	Rear right tire sensor ID	TPMS (tire pressure monitoring system)
SP2832	Left front tire sensor ID	TPMS (tire pressure monitoring system)
SP2833	Front right tire sensor ID	TPMS (tire pressure monitoring system)
SP2834	Left rear tire sensor ID	TPMS (tire pressure monitoring system)
SP2835	Rear right tire sensor ID	TPMS (tire pressure monitoring system)
SP2836	Front left and right	TPMS (tire pressure monitoring system)
SP2837	Back left and right	TPMS (tire pressure monitoring system)
SP2838	Left side forward backward swap	TPMS (tire pressure monitoring system)
SP2839	Right side forward backward swap	TPMS (tire pressure monitoring system)
SP2840	Front left back right swap	TPMS (tire pressure monitoring system)
SP2841	Front right rear left swap	TPMS (tire pressure monitoring system)
SP2842	Left front tire	TPMS (tire pressure monitoring system)
SP2843	Right front tire	TPMS (tire pressure monitoring system)
SP2844	Rear left tire	TPMS (tire pressure monitoring system)

SP2845	Rear right tire	TPMS (tire pressure monitoring system)
SP2846	Tire pressure standard value setting	TPMS (tire pressure monitoring system)
SP2847	Read and write VIN code	DSM (seat memory module)
SP2848	Read and write VIN code	DVR (vehicle data recorder)
SP2849	Write vehicle configuration code	DVR (vehicle data recorder)
SP2850	Function configuration	DVR (vehicle data recorder)
SP2851	Read and write VIN code	SVM (streaming media system)
SP2852	Write vehicle configuration code	SVM (streaming media system)
SP2853	Chassis zero point correction	AHL (headlight height adjustment system)
SP2854	Read and write VIN code	BCM (light controller)
SP2855	Read and write VIN code	Hum (DVD host)
SP2856	Read and write VIN code	Pas (radar controller)
SP2857	Function configuration	Pas (radar controller)
SP2858	ECU self test	Pas (radar controller)
SP2859	PAS self test	Pas (radar controller)
SP2860	Can self test	Pas (radar controller)
SP2861	Read and write VIN code	GW (Gateway System)
SP2862	Write vehicle configuration code	GW (Gateway System)
SP2863	Read and write VIN code	OBD GW (OBD gateway)
SP2864	Write vehicle configuration code	OBD GW (OBD gateway)
SP2865	Read and write VIN code	Hum (DVD host)
SP2866	Read and write VIN code	Pas (radar controller)
SP2867	Function configuration	Pas (radar controller)
SP2868	ECU self test	Pas (radar controller)
SP2869	PAS self test	Pas (radar controller)
SP2870	Can self test	Pas (radar controller)
SP2871	Read and write VIN code	GW (Gateway System)
SP2872	Write vehicle configuration code	GW (Gateway System)
SP2873	Read and write VIN code	EMS (engine system)
SP2874	Dental information learning	EMS (engine system)
SP2875	GPF regeneration	EMS (engine system)
SP2876	GPF mileage synchronization control	EMS (engine system)
SP2877	Read and write VIN code	TCU (automatic transmission system)
SP2878	Write vehicle configuration code	TCU (automatic transmission system)
SP2879	Read and write VIN code	Peps (keyless start system)
SP2880	Read and write VIN code	BCM (body control system)
SP2881	Write vehicle configuration code	BCM (body control system)

SP2882	Vehicle function configuration	BCM (body control system)
SP2883	Static network configuration	BCM (body control system)
SP2884	Collision status settings	BCM (body control system)
SP2885	Number of collisions	BCM (body control system)
SP2886	Configuration of left and right rudders	BCM (body control system)
SP2887	Read and write VIN code	ABS (anti lock braking system)
SP2888	ABS exhaust (anti lock exhaust)	ABS (anti lock braking system)
SP2889	Vehicle configuration	ABS (anti lock braking system)
SP2890	Read and write VIN code	ESP (body electronic stability system)
SP2891	ESP exhaust	ESP (body electronic stability system)
SP2892	Function configuration	ESP (body electronic stability system)
SP2893	Calibration of yaw rate sensor	ESP (body electronic stability system)
SP2894	Steering angle sensor calibration	ESP (body electronic stability system)
SP2895	Read and write VIN code	IPC (combination instrument)
SP2896	Write vehicle configuration code	IPC (combination instrument)
SP2897	Vehicle function configuration	IPC (combination instrument)
SP2898	Maintenance mileage setting (maintenance return to zero)	IPC (combination instrument)
SP2899	Read and write VIN code	ESCL (electronic steering column lock)
SP2900	Vehicle configuration	ESCL (electronic steering column lock)
SP2901	Read and write VIN code	DCU LF (left front door module)
SP2902	Write vehicle configuration code	DCU LF (left front door module)
SP2903	Function configuration	DCU LF (left front door module)
SP2904	Configuration of left and right rudders	DCU LF (left front door module)
SP2905	Read and write VIN code	DCU LR (left rear door module)
SP2906	Write vehicle configuration code	DCU LR (left rear door module)
SP2907	Read and write VIN code	DCU RF (right front door module)
SP2908	Write vehicle configuration code	DCU RF (right front door module)
SP2909	Function configuration	DCU RF (right front door module)
SP2910	Read and write VIN code	DCU RR (right rear door module)
SP2911	Write vehicle configuration code	DCU RR (right rear door module)
SP2912	Read and write VIN code	DVR (vehicle data recorder)
SP2913	Write vehicle configuration code	DVR (vehicle data recorder)

SP2914	Function configuration	DVR (vehicle data recorder)
SP2915	Read and write VIN code	GW (Gateway System)
SP2916	Function configuration	GW (Gateway System)
SP2917	Read and write VIN code	SDM (air bag)
SP2918	Write vehicle configuration code	SDM (air bag)
SP2919	ECU configuration - Airbag	SDM (air bag)
SP2920	Enable / disable airbags	SDM (air bag)
SP2921	Read and write VIN code	TPMS (tire pressure monitoring system)
SP2922	Tire pressure sensor (5th generation-10 system)	TPMS (tire pressure monitoring system)
SP2923	Left front tire sensor ID	TPMS (tire pressure monitoring system)
SP2924	Front right tire sensor ID	TPMS (tire pressure monitoring system)
SP2925	Left rear tire sensor ID	TPMS (tire pressure monitoring system)
SP2926	Rear right tire sensor ID	TPMS (tire pressure monitoring system)
SP2927	Tire pressure sensor (6th generation-16)	TPMS (tire pressure monitoring system)
SP2928	Left front tire sensor ID	TPMS (tire pressure monitoring system)
SP2929	Front right tire sensor ID	TPMS (tire pressure monitoring system)
SP2930	Left rear tire sensor ID	TPMS (tire pressure monitoring system)
SP2931	Rear right tire sensor ID	TPMS (tire pressure monitoring system)
SP2932	Front left and right	TPMS (tire pressure monitoring system)
SP2933	Back left and right	TPMS (tire pressure monitoring system)
SP2934	Left side forward backward swap	TPMS (tire pressure monitoring system)
SP2935	Right side forward backward swap	TPMS (tire pressure monitoring system)
SP2936	Front left back right swap	TPMS (tire pressure monitoring system)
SP2937	Front right rear left swap	TPMS (tire pressure monitoring system)
SP2938	Left front tire	TPMS (tire pressure monitoring system)
SP2939	Right front tire	TPMS (tire pressure monitoring system)
SP2940	Rear left tire	TPMS (tire pressure monitoring system)
SP2941	Rear right tire	TPMS (tire pressure monitoring system)
SP2942	Tire pressure standard value setting	TPMS (tire pressure monitoring system)
SP2943	Read and write VIN code	SVM (streaming media system)

SP2944	Write vehicle configuration code	SVM (streaming media system)
SP2945	Read and write VIN code	Orim (off road information module)
SP2946	Write vehicle configuration code	Orim (off road information module)
SP2947	Function configuration	Orim (off road information module)
SP2948	Read and write VIN code	Pas (reversing radar system)
SP2949	Write vehicle configuration code	Pas (reversing radar system)
SP2950	Read and write VIN code	RVC (reverse camera system)
SP2951	Function configuration	RVC (reverse camera system)
SP2952	Read and write VIN code	Hum (DVD host)
SP2953	Write vehicle configuration code	Hum (DVD host)
SP2954	Function configuration	Hum (DVD host)
SP2955	Read and write VIN code	EPB (electronic parking brake system)
SP2956	Option configuration	EPB (electronic parking brake system)
SP2957	Actuator detection	EPB (electronic parking brake system)
SP2958	Calibration of slope sensor	EPB (electronic parking brake system)
SP2959	Read and write VIN code	AC (air conditioning system)
SP2960	Write vehicle configuration code	AC (air conditioning system)
SP2961	Read and write VIN code	ACP (air conditioning panel)
SP2962	Read and write VIN code	EMS (engine system)
SP2963	Dental information learning	EMS (engine system)
SP2964	GPF regeneration	EMS (engine system)
SP2965	GPF mileage synchronization control	EMS (engine system)
SP2966	Read and write VIN code	TCU (automatic transmission system)
SP2967	Write vehicle configuration code	TCU (automatic transmission system)
SP2968	Read and write VIN code	BCM (body control system)
SP2969	Write vehicle configuration code	BCM (body control system)
SP2970	Function configuration	BCM (body control system)
SP2971	Static network configuration	BCM (body control system)
SP2972	Collision status settings	BCM (body control system)
SP2973	Number of collisions	BCM (body control system)
SP2974	Read and write VIN code	Peps (keyless start system)
SP2975	Read and write VIN code	ESP (body electronic stability system)
SP2976	ESP exhaust	ESP (body electronic stability system)
SP2977	Function configuration	ESP (body electronic stability system)
SP2978	Calibration of yaw rate sensor	ESP (body electronic stability system)

SP2979	Steering angle sensor calibration	ESP (body electronic stability system)
SP2980	Read and write VIN code	IPC (combination instrument)
SP2981	Write vehicle configuration code	IPC (combination instrument)
SP2982	Function configuration	IPC (combination instrument)
SP2983	Maintenance mileage setting (maintenance return to zero)	IPC (combination instrument)
SP2984	Read and write VIN code	DCU LF (left front door module)
SP2985	Write vehicle configuration code	DCU LF (left front door module)
SP2986	Function configuration	DCU LF (left front door module)
SP2987	Read and write VIN code	DCU RF (right front door module)
SP2988	Write vehicle configuration code	DCU RF (right front door module)
SP2989	Function configuration	DCU RF (right front door module)
SP2990	Read and write VIN code	DCU LR (left rear door module)
SP2991	Write vehicle configuration code	DCU LR (left rear door module)
SP2992	Read and write VIN code	DCU RR (right rear door module)
SP2993	Write vehicle configuration code	DCU RR (right rear door module)
SP2994	Read and write VIN code	RVC (reverse camera system)
SP2995	Read and write VIN code	Pas (reversing radar system)
SP2996	Write vehicle configuration code	Pas (reversing radar system)
SP2997	Vehicle configuration	Pas (reversing radar system)
SP2998	Read and write VIN code	SDM (air bag)
SP2999	SDM working mode configuration	SDM (air bag)
SP3000	Read and write VIN code	GW (Gateway System)
SP3001	Function configuration	GW (Gateway System)
SP3002	Read and write VIN code	AHL (headlight height adjustment system)
SP3003	Function configuration	AHL (headlight height adjustment system)
SP3004	Chassis zero point correction	AHL (headlight height adjustment system)
SP3005	Read and write VIN code	CCP (central control panel)
SP3006	Read and write VIN code	ESCL (electronic steering column lock)
SP3007	Vehicle configuration	ESCL (electronic steering column lock)
SP3008	Read and write VIN code	Hum (DVD host)
SP3009	Radio frequency range setting	Hum (DVD host)
SP3010	Function configuration	Hum (DVD host)
SP3011	Read and write VIN code	TPMS (tire pressure monitoring system)
SP3012	Tire pressure sensor (5th generation-10 system)	TPMS (tire pressure monitoring system)

SP3013	Tire pressure sensor (6th generation-16)	TPMS (tire pressure monitoring system)
SP3014	Left front tire sensor ID	TPMS (tire pressure monitoring system)
SP3015	Front right tire sensor ID	TPMS (tire pressure monitoring system)
SP3016	Left rear tire sensor ID	TPMS (tire pressure monitoring system)
SP3017	Rear right tire sensor ID	TPMS (tire pressure monitoring system)
SP3018	Left front tire sensor ID	TPMS (tire pressure monitoring system)
SP3019	Front right tire sensor ID	TPMS (tire pressure monitoring system)
SP3020	Left rear tire sensor ID	TPMS (tire pressure monitoring system)
SP3021	Rear right tire sensor ID	TPMS (tire pressure monitoring system)
SP3022	Front left and right	TPMS (tire pressure monitoring system)
SP3023	Back left and right	TPMS (tire pressure monitoring system)
SP3024	Left side forward backward swap	TPMS (tire pressure monitoring system)
SP3025	Right side forward backward swap	TPMS (tire pressure monitoring system)
SP3026	Front left back right swap	TPMS (tire pressure monitoring system)
SP3027	Front right rear left swap	TPMS (tire pressure monitoring system)
SP3028	Left front tire	TPMS (tire pressure monitoring system)
SP3029	Right front tire	TPMS (tire pressure monitoring system)
SP3030	Rear left tire	TPMS (tire pressure monitoring system)
SP3031	Rear right tire	TPMS (tire pressure monitoring system)
SP3032	Tire pressure standard value setting	TPMS (tire pressure monitoring system)
SP3033	Read and write VIN code	DSM (seat memory module)
SP3034	Read and write VIN code	DVR (vehicle data recorder)
SP3035	Write vehicle configuration code	DVR (vehicle data recorder)
SP3036	Function configuration	DVR (vehicle data recorder)
SP3037	Read and write VIN code	SVM (streaming media system)
SP3038	Write vehicle configuration code	SVM (streaming media system)
SP3039	Read and write VIN code	Engine system (hitachi-g5)
SP3040	Read and write VIN code	Engine system
SP3041	Write vehicle configuration code	Engine system
SP3042	Read and write VIN code	Transmission system (tcu-6at)
SP3043	Gap learning	Transmission system (tcu-6at)
SP3044	Read and write VIN code	Transmission system (tcu-cvt)

SP3045	Clear clutch self-learning value	Transmission system (tcu-cvt)
SP3046	Clutch self learning (adaptive learning)	Transmission system (tcu-cvt)
SP3047	Read and write VIN code	Peps (keyless start system)
SP3048	Read and write VIN code	BCM (body control system)
SP3049	Write vehicle configuration code	BCM (body control system)
SP3050	Body function configuration 1	BCM (body control system)
SP3051	Body function configuration 2	BCM (body control system)
SP3052	Static network configuration	BCM (body control system)
SP3053	ODO backup count	BCM (body control system)
SP3054	Read and write VIN code	IPC (combination instrument)
SP3055	Write vehicle configuration code	IPC (combination instrument)
SP3056	Vehicle configuration	IPC (combination instrument)
SP3057	Mileage learning	IPC (combination instrument)
SP3058	Maintenance mileage setting (maintenance return to zero)	IPC (combination instrument)
SP3059	Read and write VIN code	ESP (body electronic stability system)
SP3060	ESP exhaust	ESP (body electronic stability system)
SP3061	Function configuration	ESP (body electronic stability system)
SP3062	Calibration of yaw rate sensor	ESP (body electronic stability system)
SP3063	Apbmi calibration function	ESP (body electronic stability system)
SP3064	Read and write VIN code	EPS (electronic power steering)
SP3065	EPS (electric power steering) configuration	EPS (electronic power steering)
SP3066	Steering angle sensor calibration (steering angle learning)	EPS (electronic power steering)
SP3067	Read and write VIN code	ESCL (electronic steering column lock)
SP3068	Read and write VIN code	SDM (air bag)
SP3069	ECU configuration - Airbag	SDM (air bag)
SP3070	Enable / disable airbags	SDM (air bag)
SP3071	Read and write VIN code	ATC (automatic air conditioning system)
SP3072	Vehicle configuration	ATC (automatic air conditioning system)
SP3073	Read and write VIN code	GW (Gateway System)
SP3074	Write vehicle configuration code	GW (Gateway System)
SP3075	network configuration	GW (Gateway System)
SP3076	Read and write VIN code	Hum (DVD host)

SP3077	Write engine number (smart car)	Hum (DVD host)
SP3078	Hum configuration (smart car)	Hum (DVD host)
SP3079	Function configuration	Hum (DVD host)
SP3080	Read and write VIN code	T-box (t module)
SP3081	EOL node configuration	T-box (t module)
SP3082	EOL function configuration	T-box (t module)
SP3083	Read and write VIN code	TPMS (tire pressure monitoring system)
SP3084	Tire pressure sensor (5th generation-10 system)	TPMS (tire pressure monitoring system)
SP3085	Tire pressure sensor (6th generation-16)	TPMS (tire pressure monitoring system)
SP3086	Left front tire sensor ID	TPMS (tire pressure monitoring system)
SP3087	Front right tire sensor ID	TPMS (tire pressure monitoring system)
SP3088	Left rear tire sensor ID	TPMS (tire pressure monitoring system)
SP3089	Rear right tire sensor ID	TPMS (tire pressure monitoring system)
SP3090	Left front tire sensor ID	TPMS (tire pressure monitoring system)
SP3091	Front right tire sensor ID	TPMS (tire pressure monitoring system)
SP3092	Left rear tire sensor ID	TPMS (tire pressure monitoring system)
SP3093	Rear right tire sensor ID	TPMS (tire pressure monitoring system)
SP3094	Front left and right	TPMS (tire pressure monitoring system)
SP3095	Back left and right	TPMS (tire pressure monitoring system)
SP3096	Left side forward backward swap	TPMS (tire pressure monitoring system)
SP3097	Right side forward backward swap	TPMS (tire pressure monitoring system)
SP3098	Front left back right swap	TPMS (tire pressure monitoring system)
SP3099	Front right rear left swap	TPMS (tire pressure monitoring system)
SP3100	Left front tire	TPMS (tire pressure monitoring system)
SP3101	Right front tire	TPMS (tire pressure monitoring system)
SP3102	Rear left tire	TPMS (tire pressure monitoring system)
SP3103	Rear right tire	TPMS (tire pressure monitoring system)
SP3104	Tire pressure standard value setting	TPMS (tire pressure monitoring system)
SP3105	Read and write VIN code	DVR (vehicle data recorder)
SP3106	Write vehicle configuration code	DVR (vehicle data recorder)

SP3107	Function configuration	DVR (vehicle data recorder)
SP3108	Read and write VIN code	Pas (reversing radar system)
SP3109	Write vehicle configuration code	Pas (reversing radar system)
SP3110	Function configuration	Pas (reversing radar system)
SP3111	Obstacle distance detection	Pas (reversing radar system)
SP3112	Read and write VIN code	ACP (air conditioning panel)
SP3113	Read and write VIN code	AVM (panoramic image module)
SP3114	Read and write VIN code	MPC (front end camera controller)
SP3115	Vehicle configuration	MPC (front end camera controller)
SP3116	Initial dynamic calibration (calibration without calibration plate)	MPC (front end camera controller)
SP3117	Read and write VIN code	MRR (medium range radar system)
SP3118	Vehicle configuration	MRR (medium range radar system)
SP3119	Production mode	MRR (medium range radar system)
SP3120	Heating mode	MRR (medium range radar system)
SP3121	After sales calibration	MRR (medium range radar system)
SP3122	Read and write VIN code	ALC (atmosphere lamp)
SP3123	Function configuration	ALC (atmosphere lamp)
SP3124	Vehicle network configuration	ALC (atmosphere lamp)
SP3125	Read and write VIN code	Lcfl (left front lamp)
SP3126	Vehicle configuration	Lcfl (left front lamp)
SP3127	Read and write VIN code	LCFR (right headlamp)
SP3128	Vehicle configuration	LCFR (right headlamp)
SP3129	Read and write VIN code	Lcrl (left rear lamp)
SP3130	Vehicle configuration	Lcrl (left rear lamp)
SP3131	Read and write VIN code	Lcrr (right rear lamp)
SP3132	Vehicle configuration	Lcrr (right rear lamp)
SP3133	Read and write VIN code	Engine system (liandian ems-g5)
SP3134	Write vehicle configuration code	Engine system (liandian ems-g5)
SP3135	Read and write VIN code	Engine system
SP3136	Write vehicle configuration code	Engine system
SP3137	Read and write VIN code	BCM (body control system)
SP3138	Write vehicle configuration code	BCM (body control system)
SP3139	Vehicle configuration (1)	BCM (body control system)
SP3140	Vehicle configuration (2)	BCM (body control system)
SP3141	Write vehicle configuration (1) parameters	BCM (body control system)

SP3142	Write vehicle configuration (2) parameters	BCM (body control system)
SP3143	Static network configuration	BCM (body control system)
SP3144	Read and write VIN code	Transmission system (Aisin)
SP3145	Read and write VIN code	Transmission system (Bunge)
SP3146	Write vehicle configuration code	Transmission system (Bunge)
SP3147	Clear clutch self-learning value	Transmission system (Bunge)
SP3148	Clutch self learning (adaptive learning)	Transmission system (Bunge)
SP3149	Read and write VIN code	ESP (body electronic stability system)
SP3150	ESP exhaust	ESP (body electronic stability system)
SP3151	Function configuration	ESP (body electronic stability system)
SP3152	Calibration of yaw rate sensor	ESP (body electronic stability system)
SP3153	Indirect tire pressure calibration	ESP (body electronic stability system)
SP3154	Read and write VIN code	EPS (electronic power steering)
SP3155	Steering angle sensor calibration	EPS (electronic power steering)
SP3156	Read and write VIN code	IPC (combination instrument)
SP3157	Write vehicle configuration code	IPC (combination instrument)
SP3158	EOL configuration	IPC (combination instrument)
SP3159	Vehicle configuration	IPC (combination instrument)
SP3160	Mileage learning	IPC (combination instrument)
SP3161	Maintenance mileage setting (maintenance return to zero)	IPC (combination instrument)
SP3162	Read and write VIN code	SDM (air bag)
SP3163	ECU configuration - Airbag	SDM (air bag)
SP3164	Enable / disable airbags	SDM (air bag)
SP3165	Read and write VIN code	Hum (DVD host)
SP3166	Write engine number (smart car)	Hum (DVD host)
SP3167	Hum configuration (smart car)	Hum (DVD host)
SP3168	Function configuration	Hum (DVD host)
SP3169	Read and write VIN code	AC (air conditioning system)
SP3170	Read and write VIN code	ACP (air conditioning panel)
SP3171	Read and write VIN code	AVM (panoramic image module)
SP3172	Read and write VIN code	EPB (electronic parking brake system)
SP3173	Function configuration	EPB (electronic parking brake system)
SP3174	Actuator detection	EPB (electronic parking brake system)

SP3175	Calibration of slope sensor	EPB (electronic parking brake system)
SP3176	Read and write VIN code	Engine system (United)
SP3177	Write vehicle configuration code	Engine system (United)
SP3178	DVE self learning	Engine system (United)
SP3179	VVT self learning	Engine system (United)
SP3180	Read and write VIN code	Engine system (marilli)
SP3181	Write vehicle configuration code	Engine system (marilli)
SP3182	Read and write VIN code	BCM (body control system)
SP3183	Write vehicle configuration code	BCM (body control system)
SP3184	Vehicle function configuration	BCM (body control system)
SP3185	Static network configuration	BCM (body control system)
SP3186	Read and write VIN code	Peps (keyless start system)
SP3187	Read and write VIN code	ESP (body electronic stability system)
SP3188	ESP exhaust	ESP (body electronic stability system)
SP3189	Function configuration	ESP (body electronic stability system)
SP3190	Calibration of yaw rate sensor	ESP (body electronic stability system)
SP3191	Indirect tire pressure calibration	ESP (body electronic stability system)
SP3192	Apbmi calibration function	ESP (body electronic stability system)
SP3193	Read and write VIN code	SDM (air bag)
SP3194	ECU configuration - Airbag	SDM (air bag)
SP3195	Enable / disable airbags	SDM (air bag)
SP3196	Read and write VIN code	IPC (combination instrument)
SP3197	Write vehicle configuration code	IPC (combination instrument)
SP3198	Vehicle configuration	IPC (combination instrument)
SP3199	Mileage learning	IPC (combination instrument)
SP3200	Maintenance mileage setting (maintenance return to zero)	IPC (combination instrument)
SP3201	Read and write VIN code	TCU (automatic transmission system)
SP3202	Write vehicle configuration code	TCU (automatic transmission system)
SP3203	Clear clutch self-learning value	TCU (automatic transmission system)
SP3204	Read and write VIN code	Henglong brushless EPS (electronic power steering)
SP3205	EPS (electric power steering) configuration	Henglong brushless EPS (electronic power steering)

SP3206	Angle zero calibration (steering angle learning)	Henglong brushless EPS (electronic power steering)
SP3207	Read and write VIN code	Henglong brush EPS (electronic power steering)
SP3208	Angle zero calibration (steering angle learning)	Henglong brush EPS (electronic power steering)
SP3209	Read and write VIN code	North Henan brushless EPS (electronic power steering)
SP3210	Angle zero calibration (steering angle learning)	North Henan brushless EPS (electronic power steering)
SP3211	Read and write VIN code	North Henan brush EPS (electronic power steering)
SP3212	Angle zero calibration (steering angle learning)	North Henan brush EPS (electronic power steering)
SP3213	Read and write VIN code	ATC (automatic air conditioning system)
SP3214	Vehicle configuration	ATC (automatic air conditioning system)
SP3215	Read and write VIN code	EAC (electric air conditioning system)
SP3216	Read and write VIN code	Hum (DVD host)
SP3217	Function configuration	Hum (DVD host)
SP3218	Hum configuration (smart car)	Hum (DVD host)
SP3219	Write engine number (smart car)	Hum (DVD host)
SP3220	Read and write VIN code	ESCL (electronic steering column lock)
SP3221	Read and write VIN code	DVR (vehicle data recorder)
SP3222	Write vehicle configuration code	DVR (vehicle data recorder)
SP3223	Function configuration	DVR (vehicle data recorder)
SP3224	Read and write VIN code	GW (Gateway System)
SP3225	Write vehicle configuration code	GW (Gateway System)
SP3226	network configuration	GW (Gateway System)
SP3227	Read and write VIN code	Pas (reversing radar system)
SP3228	Write vehicle configuration code	Pas (reversing radar system)
SP3229	Function configuration	Pas (reversing radar system)
SP3230	Obstacle distance detection	Pas (reversing radar system)
SP3231	Read and write VIN code	AVM (panoramic image module)
SP3232	Read and write VIN code	EPB (electronic parking brake system)
SP3233	Actuator detection	EPB (electronic parking brake system)
SP3234	Calibration of slope sensor	EPB (electronic parking brake system)
SP3235	Read and write VIN code	T-box (t module)
SP3236	EOL node configuration	T-box (t module)
SP3237	EOL function configuration	T-box (t module)

SP3238	Read and write VIN code	ALC (atmosphere lamp)
SP3239	Function configuration	ALC (atmosphere lamp)
SP3240	Vehicle network configuration	ALC (atmosphere lamp)
SP3241	Read and write VIN code	EMS (engine system)
SP3242	Write vehicle configuration code	EMS (engine system)
SP3243	Read and write VIN code	TCU (automatic transmission system)
SP3244	Write vehicle configuration code	TCU (automatic transmission system)
SP3245	Clear clutch self-learning value	TCU (automatic transmission system)
SP3246	Read and write VIN code	Peps (keyless start system)
SP3247	Read and write VIN code	BCM (body control system)
SP3248	Vehicle configuration code	BCM (body control system)
SP3249	Body function configuration 1	BCM (body control system)
SP3250	Body function configuration 2	BCM (body control system)
SP3251	Static network configuration	BCM (body control system)
SP3252	Read and write VIN code	ESP (body electronic stability system)
SP3253	ESP exhaust	ESP (body electronic stability system)
SP3254	Function configuration	ESP (body electronic stability system)
SP3255	Calibration of yaw rate sensor	ESP (body electronic stability system)
SP3256	Indirect tire pressure calibration	ESP (body electronic stability system)
SP3257	Read and write VIN code	IPC (combination instrument)
SP3258	Write vehicle configuration code	IPC (combination instrument)
SP3259	Vehicle configuration	IPC (combination instrument)
SP3260	Mileage learning	IPC (combination instrument)
SP3261	Maintenance mileage setting (maintenance return to zero)	IPC (combination instrument)
SP3262	Read and write VIN code	EPS (electronic power steering system)
SP3263	Steering angle sensor calibration (steering angle learning)	EPS (electronic power steering system)
SP3264	Read and write VIN code	SDM (air bag)
SP3265	ECU configuration - Airbag	SDM (air bag)
SP3266	Enable / disable airbags	SDM (air bag)
SP3267	Read and write VIN code	ESCL (electronic steering column lock)
SP3268	Read and write VIN code	GW (Gateway System)
SP3269	Write vehicle configuration code	GW (Gateway System)

SP3270	network configuration	GW (Gateway System)
SP3271	Read and write VIN code	TPMS (tire pressure monitoring system)
SP3272	Tire pressure sensor (5th generation-10 system)	TPMS (tire pressure monitoring system)
SP3273	Tire pressure sensor (6th generation-16)	TPMS (tire pressure monitoring system)
SP3274	Left front tire sensor ID	TPMS (tire pressure monitoring system)
SP3275	Front right tire sensor ID	TPMS (tire pressure monitoring system)
SP3276	Left rear tire sensor ID	TPMS (tire pressure monitoring system)
SP3277	Rear right tire sensor ID	TPMS (tire pressure monitoring system)
SP3278	Left front tire sensor ID	TPMS (tire pressure monitoring system)
SP3279	Front right tire sensor ID	TPMS (tire pressure monitoring system)
SP3280	Left rear tire sensor ID	TPMS (tire pressure monitoring system)
SP3281	Rear right tire sensor ID	TPMS (tire pressure monitoring system)
SP3282	Front left and right	TPMS (tire pressure monitoring system)
SP3283	Back left and right	TPMS (tire pressure monitoring system)
SP3284	Left side forward backward swap	TPMS (tire pressure monitoring system)
SP3285	Right side forward backward swap	TPMS (tire pressure monitoring system)
SP3286	Front left back right swap	TPMS (tire pressure monitoring system)
SP3287	Front right rear left swap	TPMS (tire pressure monitoring system)
SP3288	Left front tire	TPMS (tire pressure monitoring system)
SP3289	Right front tire	TPMS (tire pressure monitoring system)
SP3290	Rear left tire	TPMS (tire pressure monitoring system)
SP3291	Rear right tire	TPMS (tire pressure monitoring system)
SP3292	Tire pressure standard value setting	TPMS (tire pressure monitoring system)
SP3293	Read and write VIN code	ATC (automatic air conditioning system)
SP3294	Vehicle configuration	ATC (automatic air conditioning system)
SP3295	Read and write VIN code	EAC (electric air conditioning system)
SP3296	Read and write VIN code	Hum (DVD host)
SP3297	Function configuration	Hum (DVD host)
SP3298	Hum configuration (smart car)	Hum (DVD host)
SP3299	Write engine number (smart car)	Hum (DVD host)

SP3300	Write function configuration parameters	Hum (DVD host)
SP3301	Write hum configuration parameters (smart car)	Hum (DVD host)
SP3302	Read and write VIN code	FSH (front seat heating system)
SP3303	Read and write VIN code	EPB (electronic parking brake system)
SP3304	Function configuration	EPB (electronic parking brake system)
SP3305	Actuator detection	EPB (electronic parking brake system)
SP3306	Calibration of slope sensor	EPB (electronic parking brake system)
SP3307	Read and write VIN code	AVM (panoramic image module)
SP3308	Read and write VIN code	T-box (t module)
SP3309	EOL node configuration	T-box (t module)
SP3310	EOL function configuration	T-box (t module)
SP3311	Write VIN code	Adaptive cruise (ACC)
SP3312	Write programming date	Adaptive cruise (ACC)
SP3313	Vehicle type	Adaptive cruise (ACC)
SP3314	After sales calibration	Adaptive cruise (ACC)
SP3315	Write VIN code	Anti lock braking system / electronic stability system (ABS / ESP)
SP3316	Write programming date	Anti lock braking system / electronic stability system (ABS / ESP)
SP3317	exhaust	Anti lock braking system / electronic stability system (ABS / ESP)
SP3318	Steering angle sensor calibration	Anti lock braking system / electronic stability system (ABS / ESP)
SP3319	Yaw rate sensor calibration	Anti lock braking system / electronic stability system (ABS / ESP)
SP3320	Vehicle configuration (ESP only)	Anti lock braking system / electronic stability system (ABS / ESP)
SP3321	Tpmf reset	Anti lock braking system / electronic stability system (ABS / ESP)
SP3322	Write VIN code	Engine control system (EMS)
SP3323	Write programming date	Engine control system (EMS)
SP3324	Vehicle configuration code	Engine control system (EMS)
SP3325	VVT learning	Engine control system (EMS)
SP3326	Obstacle distance detection	12 inch parking aid module (PAS)
SP3327	Write Vin	12 inch parking aid module (PAS)
SP3328	Write Vin	Keyless start system (peps)
SP3329	Write programming date	Keyless start system (peps)
SP3330	Vehicle network configuration	Keyless start system (peps)
SP3331	Antenna data configuration	Keyless start system (peps)
SP3332	Write VIN code	Intelligent tail door module (PTM)

SP3333	software configuration	Intelligent tail door module (PTM)
SP3334	Write VIN code	Electronic shifter (SBW)
SP3335	Self learning calibration	Electronic shifter (SBW)
SP3336	Write VIN code	Air bag system (SDM)
SP3337	Enable / disable airbags	Air bag system (SDM)
SP3338	Configuration of Airbag ECU	Air bag system (SDM)
SP3339	Write VIN code	Automatic transmission module (TCU)
SP3340	Write programming date	Automatic transmission module (TCU)
SP3341	Vehicle configuration code	Automatic transmission module (TCU)
SP3342	Vehicle parameters	Automatic transmission module (TCU)
SP3343	Clutch solenoid valve flushing	Automatic transmission module (TCU)
SP3344	Self learning of fork position	Automatic transmission module (TCU)
SP3345	Self learning of clutch contact point	Automatic transmission module (TCU)
SP3346	Self learning of clutch active curve	Automatic transmission module (TCU)
SP3347	EEPROM reset	Automatic transmission module (TCU)
SP3348	Read subrom	Automatic transmission module (TCU)
SP3349	Write Vin	Vehicle communication module (Tbox)
SP3350	EOL node configuration	Vehicle communication module (Tbox)
SP3351	Function configuration	Vehicle communication module (Tbox)
SP3352	Write Vin	Vehicle control panel (VCS)
SP3353	Function configuration	Vehicle control panel (VCS)
SP3354	Write Vin	Wireless charging module (WCM)
SP3355	Write VIN code	Automatic air conditioning (AAC)
SP3356	Write programming date	Automatic air conditioning (AAC)
SP3357	Write configuration information	Automatic air conditioning (AAC)
SP3358	ECU hardware reset	Automatic air conditioning (AAC)
SP3359	Write VIN code	Atmosphere lamp control module (ALC)
SP3360	Write programming date	Atmosphere lamp control module (ALC)
SP3361	ECU hardware reset	Atmosphere lamp control module (ALC)
SP3362	Function configuration	Atmosphere lamp control module (ALC)
SP3363	Body network configuration	Atmosphere lamp control module (ALC)
SP3364	Write VIN code	Digital power amplifier (AMP)
SP3365	Write programming date	Digital power amplifier (AMP)
SP3366	ECU hardware reset	Digital power amplifier (AMP)
SP3367	Function configuration	Digital power amplifier (AMP)
SP3368	Write VIN code	Automatic parking (APA)
SP3369	Write programming date	Automatic parking (APA)
SP3370	ECU hardware reset	Automatic parking (APA)
SP3371	Function configuration	Automatic parking (APA)

SP3372	Write VIN code	Air conditioning panel (APC)
SP3373	Write programming date	Air conditioning panel (APC)
SP3374	ECU hardware reset	Air conditioning panel (APC)
SP3375	Write VIN code	Panoramic image module (AVM)
SP3376	Write programming date	Panoramic image module (AVM)
SP3377	ECU hardware reset	Panoramic image module (AVM)
SP3378	Vehicle code changing configuration	Panoramic image module (AVM)
SP3379	Body color configuration	Panoramic image module (AVM)
SP3380	After sales calibration	Panoramic image module (AVM)
SP3381	Offline calibration	Panoramic image module (AVM)
SP3382	Write VIN code	Body electronic control module (BCM)
SP3383	Write programming date	Body electronic control module (BCM)
SP3384	Write vehicle characteristics	Body electronic control module (BCM)
SP3385	Write transportation mode	Body electronic control module (BCM)
SP3386	Write ODO backup counter	Body electronic control module (BCM)
SP3387	ECU hardware reset	Body electronic control module (BCM)
SP3388	BCM function configuration 1	Body electronic control module (BCM)
SP3389	BCM function configuration 2	Body electronic control module (BCM)
SP3390	network configuration	Body electronic control module (BCM)
SP3391	Write VIN code	Central control module (CCP)
SP3392	Write programming date	Central control module (CCP)
SP3393	ECU hardware reset	Central control module (CCP)
SP3394	Write VIN code	Driver's seat control module (DSM)
SP3395	Write programming date	Driver's seat control module (DSM)
SP3396	ECU hardware reset	Driver's seat control module (DSM)
SP3397	ECU software reset	Driver's seat control module (DSM)
SP3398	Function configuration	Driver's seat control module (DSM)
SP3399	Driver's seat heating control	Driver's seat control module (DSM)
SP3400	Co driver seat heating control	Driver's seat control module (DSM)
SP3401	Driver seat ventilation control	Driver's seat control module (DSM)
SP3402	Co driver seat ventilation control	Driver's seat control module (DSM)
SP3403	Steering wheel heating control	Driver's seat control module (DSM)
SP3404	Restore default parameter settings	Driver's seat control module (DSM)
SP3405	Write VIN code	Vehicle data recorder (DVR)
SP3406	Write programming date	Vehicle data recorder (DVR)

SP3407	Network node configuration	Vehicle data recorder (DVR)
SP3408	ECU hardware reset	Vehicle data recorder (DVR)
SP3409	Reset Ethernet port configuration	Vehicle data recorder (DVR)
SP3410	Read Ethernet PHY register	Vehicle data recorder (DVR)
SP3411	Read Ethernet PHY register extension	Vehicle data recorder (DVR)
SP3412	Ethernet cable diagnosis	Vehicle data recorder (DVR)
SP3413	Enable Ethernet test mode	Vehicle data recorder (DVR)
SP3414	Ethernet PHY loopback test (internal loopback mode)	Vehicle data recorder (DVR)
SP3415	Ethernet PHY loopback test (external loopback mode)	Vehicle data recorder (DVR)
SP3416	Write VIN code	Electric power steering (EPS)
SP3417	Write programming date	Electric power steering (EPS)
SP3418	Variable configuration	Electric power steering (EPS)
SP3419	SAS calibration	Electric power steering (EPS)
SP3420	ECU hardware reset	Electric power steering (EPS)
SP3421	Write VIN code	Electronic stability system (ESP)
SP3422	Write programming date	Electronic stability system (ESP)
SP3423	Write the vacuum and filling status	Electronic stability system (ESP)
SP3424	Write EOL status	Electronic stability system (ESP)
SP3425	Write variable code	Electronic stability system (ESP)
SP3426	Vacuumizing and filling	Electronic stability system (ESP)
SP3427	ABS exhaust	Electronic stability system (ESP)
SP3428	Yaw rate sensor calibration	Electronic stability system (ESP)
SP3429	Indirect tire pressure calibration	Electronic stability system (ESP)
SP3430	ECU software reset	Electronic stability system (ESP)
SP3431	Write VIN code	Seat ventilation heating module (fshvm)
SP3432	Write programming date	Seat ventilation heating module (fshvm)
SP3433	ECU hardware reset	Seat ventilation heating module (fshvm)
SP3434	Write VIN code	Gateway (GW)
SP3435	Write programming date	Gateway (GW)
SP3436	ECU hardware reset	Gateway (GW)
SP3437	Network node configuration	Gateway (GW)
SP3438	Function configuration	Gateway (GW)
SP3439	Write VIN code	Entertainment host (hum)
SP3440	Write programming date	Entertainment host (hum)
SP3441	Write the engine number	Entertainment host (hum)

SP3442	ECU hardware reset	Entertainment host (hum)
SP3443	Offline function configuration 1	Entertainment host (hum)
SP3444	Offline function configuration 2	Entertainment host (hum)
SP3445	Write VIN code	Combination instrument system (ICM)
SP3446	Write programming date	Combination instrument system (ICM)
SP3447	ECU hardware reset	Combination instrument system (ICM)
SP3448	Optional function configuration	Combination instrument system (ICM)
SP3449	Write PPK	Combination instrument system (ICM)
SP3450	Write ODO backup counter	Combination instrument system (ICM)
SP3451	Write VIN code	Left headlamp controller (lcfl)
SP3452	Write programming date	Left headlamp controller (lcfl)
SP3453	ECU hardware reset	Left headlamp controller (lcfl)
SP3454	Function configuration	Left headlamp controller (lcfl)
SP3455	Write VIN code	Right headlamp controller (LCFR)
SP3456	Write programming date	Right headlamp controller (LCFR)
SP3457	ECU hardware reset	Right headlamp controller (LCFR)
SP3458	Function configuration	Right headlamp controller (LCFR)
SP3459	Write VIN code	Rear left headlamp controller (lcrl)
SP3460	Write programming date	Rear left headlamp controller (lcrl)
SP3461	ECU hardware reset	Rear left headlamp controller (lcrl)
SP3462	ECU software reset	Rear left headlamp controller (lcrl)
SP3463	Function configuration	Rear left headlamp controller (lcrl)
SP3464	Write VIN code	Right rear headlamp controller (lcrr)
SP3465	Write programming date	Right rear headlamp controller (lcrr)
SP3466	ECU hardware reset	Right rear headlamp controller (lcrr)
SP3467	ECU software reset	Right rear headlamp controller (lcrr)
SP3468	Function configuration	Right rear headlamp controller (lcrr)
SP3469	Write VIN code	Middle and rear tail lamp controller (LCRM)
SP3470	Write programming date	Middle and rear tail lamp controller (LCRM)
SP3471	ECU hardware reset	Middle and rear tail lamp controller (LCRM)
SP3472	ECU software reset	Middle and rear tail lamp controller (LCRM)
SP3473	Function configuration	Middle and rear tail lamp controller (LCRM)
SP3474	Write VIN code	Front detection camera (MPC)
SP3475	Write programming date	Front detection camera (MPC)
SP3476	ECU hardware reset	Front detection camera (MPC)
SP3477	Function configuration	Front detection camera (MPC)
SP3478	Initial dynamic calibration (calibration without calibration board)	Front detection camera (MPC)