



Shenzhen Xtooltech Co., Ltd

DFFG Function List V7.90

Tips and Instructions:

The programming function only supports H6PRO, H6PRO Master Edition products.

* This feature is new.

✓ This feature is supported.

✗ This feature is not supported.

※ This feature is partially supported.

Model	Model Series	System Name	Read ECU Information	Read Trouble Code	Clear Trouble Code	Live Data	Read Freeze Frame	Actuation Test	Special Functions
DFFG	New 580	Engine Management System (EMS)	✓	✓	✓	✓	✓	✓	SP0881-SP0894
DFFG	New 580	Transmission Controller (TCU)	✓	✓	✓	✓			
DFFG	New 580	Body Control Module (BCM)	✓	✓	✓	✓		✓	SP0895-SP0905
DFFG	New 580	Airbag Controller (ABM)	✓	✓	✓	✓		✓	SP0906-SP0913
DFFG	New 580	Anti-lock brake system/electronic stability system (ABS/ESP)	✓	✓	✓	✓			SP0914-SP0928
DFFG	New 580	Electronic Power Steering (EPS)	✓	✓	✓	✓			SP0929-SP0937
DFFG	New 580	Electronic Parking Controller (EPB)	✓	✓	✓	✓		✓	SP0938-SP0950
DFFG	New 580	Electronic steering column lock (ESCL)	✓	✓	✓	✓			SP0951-SP0954
DFFG	New 580	Instrument (IC)	✓	✓	✓	✓		✓	SP0955-SP0961
DFFG	New 580	Infotainment System (IVI)	✓	✓	✓	✓			SP0962-SP0969
DFFG	New 580	Electric tailgate controller (PLG)	✓	✓	✓	✓		✓	SP0970-SP0972
DFFG	New 580	Seat Controller (DSM)	✓	✓	✓				SP0973-SP0977
DFFG	New 580	Wireless charging (WCM)	✓	✓	✓				SP0978-SP0980
DFFG	New 580	Short-range millimeter wave radar 1 (SRR R1)	✓	✓	✓				SP0981-SP0987
DFFG	New 580	Short-range millimeter wave radar 2 (SRR R2)	✓	✓	✓				SP0988-SP0994
DFFG	New 580	Mid-range millimeter wave radar (MRR)	✓	✓	✓	✓			SP0995-SP0999
DFFG	New 580	Shift controller (GSM)	✓	✓	✓			✓	SP1000-SP1005
DFFG	New 580	Shift actuator (SBW)	✓	✓	✓	✓		✓	SP1006-SP1012
DFFG	New 580	Window anti-pinch controller (APM)	✓	✓	✓	✓		✓	SP1013-SP1015
DFFG	Scenery 580	Engine Management System (EMS)/Delphi Engine System (MT22.3)	✓	✓	✓	✓	✓	✓	SP1016-SP1020
DFFG	Scenery 580	Engine Management System (EMS)/Delphi Engine System (MT62.1G)	✓	✓	✓	✓	✓	✓	SP1021-SP1030
DFFG	Scenery 580	Engine Management System (EMS)/Delphi Engine System (MT62.1U)	✓	✓	✓	✓	✓	✓	SP1031-SP1041
DFFG	Scenery 580	Engine Management System (EMS)/UMC Engine System (ME1788)	✓	✓	✓	✓	✓	✓	SP1042
DFFG	Scenery 580	Engine Management System (EMS)/UMC Engine System MG1UA008 (UP8)	✓	✓	✓	✓		✓	SP1043-SP1056
DFFG	Scenery 580	Automatic Transmission System (TCU)/Automatic Transmission System (VT5)	✓	✓	✓	✓	✓		SP1057-SP1064
DFFG	Scenery 580	Automatic Transmission System (TCU)/Automatic Transmission System (VT3)	✓	✓	✓	✓	✓	✓	SP1065-SP1077
DFFG	Scenery 580	Automatic Transmission System (TCU)/Automatic Transmission System (RDC27)	✓	✓	✓	✓	✓	✓	SP1078-SP1085
DFFG	Scenery 580	Anti-lock brake system/Electronic Stability System (ESP)	✓	✓	✓	✓	✓		SP1086-SP1090
DFFG	Scenery 580	Airbag system (ABM)	✓	✓	✓	✓			SP1091-SP1093
DFFG	Scenery 580	Body Control System (BCM)	✓	✓	✓	✓			
DFFG	Scenery 580	Electronic Power Steering System (EPS)	✓	✓	✓	✓	✓		SP1094-SP1100
DFFG	Scenery 580	Combination Instrument System (IC)	✓	✓	✓	✓	✓	✓	SP1101-SP1104
DFFG	Scenery 580	Keyless Start System (PEPS)	✓	✓	✓	✓		✓	SP1105-SP1107
DFFG	Scenery 580	Air Conditioning System (AC)	✓	✓	✓	✓			SP1108
DFFG	Scenery 580	Electronic Parking System (EPB)/Bethel EPB	✓	✓	✓	✓		✓	SP1109-SP1118
DFFG	Scenery 580	Electronic Parking System (EPB)/Libang EPB	✓	✓	✓	✓			SP1119-SP1121
DFFG	Scenery 580	Panoramic Parking System (AVM)	✓	✓	✓	✓			SP1122-SP1124
DFFG	Scenery 580	Audio Entertainment System (RRM)	✓	✓	✓	✓			SP1125-SP1128
DFFG	Scenery 580	Electric Back Door Controller (PLG)	✓	✓	✓				
DFFG	Scenery 580	Internet of Vehicles Control System (T-BOX)	✓	✓	✓	✓		✓	SP1129-SP1130
DFFG	Landscape 580Pro	Engine Management System (EMS)/Delphi Engine System (MT22.3)	✓	✓	✓	✓	✓	✓	SP1131-SP1135
DFFG	Landscape 580Pro	Engine Management System (EMS)/Delphi Engine System (MT62.1G)	✓	✓	✓	✓	✓	✓	SP1136-SP1146
DFFG	Landscape 580Pro	Engine Management System (EMS)/Delphi Engine System (MT92.1)	✓	✓	✓	✓	✓	✓	SP1147-SP1157
DFFG	Landscape 580Pro	Engine Management System (EMS)/UMC Engine System MG1UA008 (UP8)	✓	✓	✓	✓		✓	SP1158-SP1171
DFFG	Landscape 580Pro	Automatic Transmission System (TCU)/Automatic Transmission System (VT5)	✓	✓	✓	✓	✓		SP1172-SP1179

DFFG	Landscape 580Pro	Automatic Transmission System (TCU)/Automatic Transmission System (RDC27)	√	√	√	√	√	√	SP1180-SP1187
DFFG	Landscape 580Pro	Automatic Transmission System (TCU)/Automatic Transmission System (VT3)	√	√	√		√		SP1188-SP1192
DFFG	Landscape 580Pro	Anti-lock brake system/Electronic Stability System (ESP)	√	√	√	√			
DFFG	Landscape 580Pro	Airbag system (ABM)	√	√	√			√	SP1193-SP1200
DFFG	Landscape 580Pro	Body Controller (BCM)	√	√	√	√		√	SP1201-SP1210
DFFG	Landscape 580Pro	Electronic Power Steering System (EPS)	√	√	√	√			
DFFG	Landscape 580Pro	Combination Instrument System (IC)	√	√	√	√		√	SP1211-SP1216
DFFG	Landscape 580Pro	Air Conditioning System (AC)	√	√	√	√			SP1217-SP1218
DFFG	Landscape 580Pro	Electronic Parking System (EPB)	√	√	√	√			
DFFG	Landscape 580Pro	Audio Entertainment System (RRM)	√	√	√				SP1219-SP1223
DFFG	Landscape 580Pro	Internet of Vehicles Control System (T-BOX)	√	√	√	√		√	SP1224-SP1226
DFFG	Landscape 580Pro	Electric tailgate (PLG)	√	√	√	√		√	SP1227-SP1228
DFFG	Landscape 580Pro	Panoramic Parking System (AVM)	√	√	√		√	√	SP1229-SP1232
DFFG	Landscape 580Pro	Multi-function camera (MPC)	√	√	√	√	√		SP1233-SP1243
DFFG	Landscape 580Pro	Shift actuator (SBW)	√	√	√	√	√	√	SP1244-SP1246
DFFG	Landscape 580Pro	Shift controller (GSM)	√	√	√	√		√	SP1247-SP1248
DFFG	Landscape 580Pro	Multiple Switch Controller (MSC)	√	√	√	√		√	SP1249-SP1252
DFFG	Landscape 580Pro	Ambient Light Controller (ALC)	√	√	√			√	SP1253-SP1254
DFFG	scenery 500	Engine Management System (EMS)/Delphi Engine System (MT62, IU)	√	√	√	√	√	√	SP1255-SP1265
DFFG	scenery 500	Engine Management System (EMS)/UMC Engine System MG1UA008 (UP8)	√	√	√	√		√	SP1266-SP1279
DFFG	scenery 500	Transmission Control Unit (TCU)/Rongda Transmission Control Unit (TCU)	√	√	√	√	√	√	SP1280
DFFG	scenery 500	Transmission Control Unit (TCU)/Punzi Transmission Control Unit (TCU)	√	√	√	√	√		SP1281-SP1283
DFFG	scenery 500	Airbag system (ABM)	√	√	√			√	SP1284-SP1290
DFFG	scenery 500	Body Control Module (BCM)	√	√	√	√		√	SP1291-SP1303
DFFG	scenery 500	Electronic Power Steering (EPS)	√	√	√	√	√		SP1304-SP1309
DFFG	scenery 500	Combination Instrument (IC)	√	√	√	√		√	SP1310-SP1314
DFFG	scenery 500	Air Conditioning (AC)	√	√	√	√		√	SP1315-SP1316
DFFG	scenery 500	Electric parking brake system (EPB)	√	√	√	√	√	√	SP1317-SP1334
DFFG	scenery 500	Electronic Stability System (ESC)	√	√	√	√	√	√	SP1335-SP1336
DFFG	scenery 500	Multi-function camera (MPC)	√	√	√	√	√	√	SP1337-SP1347
DFFG	scenery 500	Audio Entertainment System (RRM)	√	√	√				SP1348-SP1352
DFFG	scenery 500	Driving Recorder (DVR)	√	√	√				SP1353-SP1356
DFFG	scenery 500	Panoramic Parking (AVM)	√	√	√		√	√	SP1357-SP1360
DFFG	scenery 500	Radar Controller (PDC)	√	√	√	√			SP1361-SP1364
DFFG	scenery 500	Driving Recorder (DVR)	√	√	√				SP1365-SP1368
DFFG	scenery 500	Remote communication unit (T-BOX)	√	√	√	√		√	SP1369-SP1373
DFFG	scenery 500	Electric Back Door (PLG)	√	√	√	√		√	SP1374-SP1375
DFFG	scenery 500	Seat Controller (DSM)	√	√	√				SP1376-SP1379
DFFG	Shengguang 370/Shengguang 370 Annual Model	Engine Management System (EMS)	√	√	√	√	√	√	SP1380-SP1384
DFFG	Shengguang 370/Shengguang 370 Annual Model	Automatic Transmission System (TCU)	√	√	√	√	√	√	SP1385-SP1397
DFFG	Shengguang 370/Shengguang 370 Annual Model	Anti-lock brake system/Electronic Stability System (ESP)	√	√	√	√	√		SP1398-SP1402
DFFG	Shengguang 370/Shengguang 370 Annual Model	Airbag system (ABM)	√	√	√	√			
DFFG	Shengguang 370/Shengguang 370 Annual Model	Body Control System (BCM)	√	√	√	√		√	SP1403-SP1409
DFFG	Shengguang 370/Shengguang 370 Annual Model	Electronic Power Steering System (EPS)	√	√	√	√			SP1410-SP1414
DFFG	Shengguang 370/Shengguang 370 Annual Model	Combination Instrument System (IC)	√	√	√	√	√	√	SP1415-SP1418
DFFG	Shengguang 370/Shengguang 370 Annual Model	Keyless Start System (PEPS)	√	√	√	√		√	SP1419-SP1421
DFFG	Shengguang 370/Shengguang 370 Annual Model	Air Conditioning System (AC)	√	√	√	√			SP1422
DFFG	Shengguang 370/Shengguang 370 Annual Model	Tire Pressure Matching System (TPMS)							SP1423-SP1445
DFFG	Shengguang 370/Shengguang 370 Annual Model	Electronic Parking System (EPB)	√	√	√	√			SP1446-SP1448
DFFG	Shengguang 370/Shengguang 370 Annual Model	Audio Entertainment System (RRM)	√	√	√	√			SP1449-SP1452
DFFG	Shengguang 370/Shengguang 370 Intelligent	Engine Management System (EMS)	√	√	√	√	√	√	SP1453-SP1457
DFFG	Shengguang 370/Shengguang 370 Intelligent	Automatic Transmission System (TCU)/Automatic Transmission (CVT)	√	√	√	√	√	√	SP1458-SP1470
DFFG	Shengguang 370/Shengguang 370 Intelligent	Automatic transmission system (TCU)/automatic transmission (4AT)	√	√	√	√			SP1471-SP1474
DFFG	Shengguang 370/Shengguang 370 Intelligent	Anti-lock brake system/Electronic Stability System (ESP)	√	√	√	√	√		SP1475-SP1479
DFFG	Shengguang 370/Shengguang 370 Intelligent	Airbag system (ABM)	√	√	√	√			
DFFG	Shengguang 370/Shengguang 370 Intelligent	Body Control System (BCM)	√	√	√	√		√	SP1480-SP1486
DFFG	Shengguang 370/Shengguang 370 Intelligent	Electronic Power Steering System (EPS)	√	√	√	√	√		SP1487-SP1493
DFFG	Shengguang 370/Shengguang 370 Intelligent	Combination Instrument System (IC)	√	√	√	√	√	√	SP1494-SP1497
DFFG	Shengguang 370/Shengguang 370 Intelligent	Keyless Start System (PEPS)	√	√	√	√			SP1498-SP1500
DFFG	Shengguang 370/Shengguang 370 Intelligent	Air Conditioning System (AC)	√	√	√	√			SP1501
DFFG	Shengguang 370/Shengguang 370 Intelligent	Tire Pressure Matching System (TPMS)							SP1502-SP1524
DFFG	Shengguang 370/Shengguang 370 Intelligent	Electronic Parking System (EPB)	√	√	√	√			SP1525-SP1527
DFFG	Shengguang 370/Shengguang 370 Intelligent	Panoramic Parking System (AVM)	√	√	√	√			SP1528-SP1530
DFFG	Shengguang 370/Shengguang 370 Intelligent	Audio Entertainment System (RRM)	√	√	√	√			SP1531-SP1534
DFFG	Scenery 370/Scenery 370 Ordinary	Engine Management System (EMS)/Bosch EDC17C53 Engine	√	√	√	√	√	√	SP1535-SP1546
DFFG	Scenery 370/Scenery 370 Ordinary	Engine Management System (EMS)/Bosch EDC17C63 Engine	√	√	√	√	√	√	SP1547-SP1558
DFFG	Scenery 370/Scenery 370 Ordinary	Engine Management System (EMS)/United Electronic ME788 Engine System	√	√	√	√		√	SP1559-SP1560

DFFG	Scenery 370/Scenery 370 Ordinary	Engine Management System (EMS)/United Electronic ME1788 Engine System	✓	✓	✓	✓	✓	✓	SP1561-SP1562
DFFG	Scenery 370/Scenery 370 Ordinary	Engine Management System (EMS)/Delphi MT22.3 (ETC) Engine System	✓	✓	✓	✓	✓	✓	SP1563-SP1568
DFFG	Scenery 370/Scenery 370 Ordinary	Anti-lock brake system (ABS)	✓	✓	✓	✓	✓	✓	SP1569-SP1578
DFFG	Scenery 370/Scenery 370 Ordinary	Airbag system (ABM)	✓	✓	✓	✓	✓	✓	
DFFG	Scenery 370/Scenery 370 Ordinary	Electronic Power Steering (EPS)	✓	✓	✓	✓	✓	✓	SP1579-SP1580
DFFG	Scenery 370/Scenery 370 Ordinary	Tire Pressure Matching System (TPMS)							SP1581-SP1603
DFFG	Scenery 360	Engine Management System (EMS)/Bosch EDC17C53 Engine	✓	✓	✓	✓	✓	✓	SP1604-SP1615
DFFG	Scenery 360	Engine Management System (EMS)/Bosch EDC17C63 Engine	✓	✓	✓	✓	✓	✓	SP1616-SP1627
DFFG	Scenery 360	Engine Management System (EMS)/United Electronic ME788 Engine System	✓	✓	✓	✓	✓	✓	SP1628-SP1629
DFFG	Scenery 360	Engine Management System (EMS)/United Electronic ME1788 Engine System	✓	✓	✓	✓	✓	✓	SP1630-SP1631
DFFG	Scenery 360	Engine Management System (EMS)/Delphi MT22.3 (ETC) Engine System	✓	✓	✓	✓	✓	✓	SP1632-SP1637
DFFG	Scenery 360	Anti-lock brake system (ABS)/BOSCH ABS 9.0	✓	✓	✓	✓	✓	✓	SP1638-SP1647
DFFG	Scenery 360	Anti-lock brake system (ABS)/Asia-Pacific integral hydraulic ABS	✓	✓	✓	✓	✓	✓	SP1648-SP1649
DFFG	Scenery 360	Anti-lock brake system (ABS)/Asia Pacific ABS	✓	✓	✓	✓	✓	✓	
DFFG	Scenery 360	Airbag system (ABM)	✓	✓	✓	✓	✓	✓	
DFFG	Scenery 360	Electronic Power Steering (EPS)	✓	✓	✓	✓	✓	✓	SP1650-SP1651
DFFG	Scenery 330	Engine Management System (EMS)/Delphi Engine System (MT62.1U)	✓	✓	✓	✓	✓	✓	SP1652-SP1662
DFFG	Scenery 330	Engine Management System (EMS)/Bosch EDC17C53 Engine	✓	✓	✓	✓	✓	✓	SP1663-SP1674
DFFG	Scenery 330	Engine Management System (EMS)/Bosch EDC17C63 Engine	✓	✓	✓	✓	✓	✓	SP1675-SP1686
DFFG	Scenery 330	Engine Management System (EMS)/Delphi Engine System (MT22.3)	✓	✓	✓	✓	✓	✓	SP1687-SP1692
DFFG	Scenery 330	Engine Management System (EMS)/UMC Engine System (ME1788)	✓	✓	✓	✓	✓	✓	SP1693-SP1694
DFFG	Scenery 330	Engine Management System (EMS)/Delphi Engine System (MT22.1)	✓	✓	✓	✓	✓	✓	SP1695-SP1700
DFFG	Scenery 330	Siemens Transmission System (TCU)	✓	✓	✓	✓	✓	✓	SP1701-SP1705
DFFG	Scenery 330	Anti-lock brake system (ABS)/BOSCH ABS 9.0	✓	✓	✓	✓	✓	✓	SP1706-SP1715
DFFG	Scenery 330	Anti-lock brake system (ABS)/BOSCH ABS (three-channel)	✓	✓	✓	✓	✓	✓	SP1716-SP1726
DFFG	Scenery 330	Airbag system (ABM)	✓	✓	✓	✓	✓	✓	
DFFG	Scenery 330	Electronic Power Steering (EPS)	✓	✓	✓	✓	✓	✓	SP1727-SP1728
DFFG	Scenery 330	Tire Pressure Matching System (TPMS)							SP1729-SP1751
DFFG	Scenery S560/Scenery S560	Engine Management System (EMS)/UMC Engine System (ME1788)	✓	✓	✓	✓	✓	✓	SP1752
DFFG	Scenery S560/Scenery S560	Engine Management System (EMS)/UMC Engine System MG1UA008 (UP8)	✓	✓	✓	✓	✓	✓	SP1753-SP1766
DFFG	Scenery S560/Scenery S560	Engine Management System (EMS)/Delphi Engine System (MT62.1G)	✓	✓	✓	✓	✓	✓	SP1767-SP1776
DFFG	Scenery S560/Scenery S560	Engine Management System (EMS)/Delphi Engine System (MT62.1U)	✓	✓	✓	✓	✓	✓	SP1777-SP1787
DFFG	Scenery S560/Scenery S560	Engine Management System (EMS)/Delphi MT62.3 Engine System	✓	✓	✓	✓	✓	✓	SP1788-SP1798
DFFG	Scenery S560/Scenery S560	Automatic Transmission System (TCU)/Automatic Transmission System (VT3)	✓	✓	✓	✓	✓	✓	SP1799-SP1811
DFFG	Scenery S560/Scenery S560	Automatic Transmission System (TCU)/Automatic Transmission System (RDC18)	✓	✓	✓	✓	✓	✓	SP1812-SP1816
DFFG	Scenery S560/Scenery S560	Anti-lock brake system/Electronic Stability System (ESP)	✓	✓	✓	✓	✓	✓	SP1817-SP1821
DFFG	Scenery S560/Scenery S560	Airbag (ACU)	✓	✓	✓	✓	✓	✓	
DFFG	Scenery S560/Scenery S560	Body Control System (BCM)	✓	✓	✓	✓	✓	✓	SP1822-SP1829
DFFG	Scenery S560/Scenery S560	Electronic Power Steering (EPS)	✓	✓	✓	✓	✓	✓	SP1830-SP1834
DFFG	Scenery S560/Scenery S560	Combination Instrument System (IC)	✓	✓	✓	✓	✓	✓	SP1835-SP1838
DFFG	Scenery S560/Scenery S560	Air Conditioning System (AC)	✓	✓	✓	✓	✓	✓	SP1839
DFFG	Scenery S560/Scenery S560	Electronic Parking System (EPB)	✓	✓	✓	✓	✓	✓	SP1840-SP1849
DFFG	Scenery S560/Scenery S560	Panoramic Parking System (AVM)	✓	✓	✓	✓	✓	✓	SP1850-SP1852
DFFG	Scenery S560/Scenery S560	Audio Entertainment System (RRM)	✓	✓	✓	✓	✓	✓	SP1853-SP1856
DFFG	Scenery S560/Scenery S560	Internet of Vehicles Control System (I-BOX)	✓	✓	✓	✓	✓	✓	
DFFG	Scenery S560/ Scenery S560 2019	Engine Management System (EMS)/UMC Engine	✓	✓	✓	✓	✓	✓	SP1857-SP1870
DFFG	Scenery S560/ Scenery S560 2019	Engine Management System (EMS)/Delphi Engine System	✓	✓	✓	✓	✓	✓	SP1871-SP1881
DFFG	Scenery S560/ Scenery S560 2019	Automatic Transmission System (TCU)	✓	✓	✓	✓	✓	✓	SP1882-SP1889
DFFG	Scenery S560/ Scenery S560 2019	Anti-lock brake system/Electronic Stability System (ESP)	✓	✓	✓	✓	✓	✓	
DFFG	Scenery S560/ Scenery S560 2019	Airbag (ACU)	✓	✓	✓	✓	✓	✓	
DFFG	Scenery S560/ Scenery S560 2019	Body Control System (BCM)/Body Control System 1	✓	✓	✓	✓	✓	✓	SP1890-SP1900

DFFG	Scenery S560/ Scenery S560 2019	Body Control System (BCM)/Body Control System 2	✓	✓	✓	✓	✓	✓	SP1901-SP1908
DFFG	Scenery S560/ Scenery S560 2019	Electronic Power Steering (EPS)	✓	✓	✓	✓	✓	✓	SP1909-SP1913
DFFG	Scenery S560/ Scenery S560 2019	Combination Instrument System (IC)	✓	✓	✓	✓	✓	✓	SP1914-SP1918
DFFG	Scenery S560/ Scenery S560 2019	Air Conditioning System (AC)	✓	✓	✓	✓	✓	✓	SP1919-SP1920
DFFG	Scenery S560/ Scenery S560 2019	Electronic Parking System (EPB)	✓	✓	✓	✓	✓	✓	
DFFG	Scenery S560/ Scenery S560 2019	Audio Entertainment System (RRM)	✓	✓	✓	✓	✓	✓	SP1921-SP1925
DFFG	Scenery S560/ Scenery S560 2019	Internet of Vehicles Control System (I-BOX)	✓	✓	✓	✓	✓	✓	SP1926-SP1928
DFFG	Scenery ix7	Engine Management System (EMS)	✓	✓	✓	✓	✓	✓	SP1929-SP1942
DFFG	Scenery ix7	Transmission Controller (TCU)	✓	✓	✓	✓	✓	✓	SP1943-SP1948
DFFG	Scenery ix7	Body Control Module (BCM)	✓	✓	✓	✓	✓	✓	SP1949-SP1959
DFFG	Scenery ix7	Electronic Power Steering (EPS)	✓	✓	✓	✓	✓	✓	SP1960-SP1966
DFFG	Scenery ix7	Combination Instrument (IC)	✓	✓	✓	✓	✓	✓	SP1967-SP1972
DFFG	Scenery ix7	Electronic Stability System (ESP)	✓	✓	✓	✓	✓	✓	SP1973-SP1984
DFFG	Scenery ix7	Air Conditioning System (AC)	✓	✓	✓	✓	✓	✓	SP1985-SP1986
DFFG	Scenery ix7	Electronic Parking Controller (EPB)	✓	✓	✓	✓	✓	✓	SP1987-SP1999
DFFG	Scenery ix7	Gateway system (GW)	✓	✓	✓	✓	✓	✓	SP2000-SP2002
DFFG	Scenery ix7	Four-wheel drive controller (4WD)	✓	✓	✓	✓	✓	✓	SP2003-SP2006
DFFG	Scenery ix7	Shift controller (GSM)	✓	✓	✓	✓	✓	✓	SP2007-SP2008
DFFG	Scenery ix7	Shift actuator (SBW)	✓	✓	✓	✓	✓	✓	SP2009-SP2011
DFFG	Scenery ix7	Mid-range millimeter wave radar (MRR)	✓	✓	✓	✓	✓	✓	SP2012-SP2014
DFFG	Scenery ix7	Multi-function camera (MPC)	✓	✓	✓	✓	✓	✓	SP2015-SP2020
DFFG	Scenery ix7	Airbag Controller (ABM)	✓	✓	✓	✓	✓	✓	SP2021-SP2028
DFFG	Scenery ix7	Electric tailgate controller (PLG)	✓	✓	✓	✓	✓	✓	SP2029-SP2030
DFFG	Scenery ix7	Telematics module (T-BOX)	✓	✓	✓	✓	✓	✓	SP2031-SP2033
DFFG	Scenery ix7	Central Control Panel (CCP)	✓	✓	✓	✓	✓	✓	SP2034-SP2035
DFFG	Scenery ix7	Head up display (HUD)	✓	✓	✓	✓	✓	✓	SP2036-SP2038
DFFG	Scenery ix7	Audio Entertainment System (RRM)	✓	✓	✓	✓	✓	✓	SP2039-SP2043
DFFG	Scenery ix7	Multiple Switch Controller (MSC)	✓	✓	✓	✓	✓	✓	SP2044-SP2047
DFFG	Scenery ix7	Driving Recorder (DVR)	✓	✓	✓	✓	✓	✓	SP2048-SP2051
DFFG	Scenery ix7	Parking sensor (PDC)	✓	✓	✓	✓	✓	✓	SP2052-SP2055
DFFG	Scenery ix7	Panoramic Parking (AVM)	✓	✓	✓	✓	✓	✓	SP2056-SP2059
DFFG	Scenery ix7	Adaptive headlights (AFS)	✓	✓	✓	✓	✓	✓	SP2060-SP2064
DFFG	Scenery ix7	Electronic steering column lock (ESCL)	✓	✓	✓	✓	✓	✓	SP2065-SP2067
DFFG	Scenery ix7	Seat Controller (DSM)	✓	✓	✓	✓	✓	✓	SP2068-SP2069
DFFG	Scenery ix7	Wireless Charge Controller (WCM)	✓	✓	✓	✓	✓	✓	SP2070-SP2071
DFFG	Scenery ix5	Engine Management System (EMS)/UMC Engine System (ME1788)	✓	✓	✓	✓	✓	✓	SP2072-SP2073
DFFG	Scenery ix5	Engine Management System (EMS)/UMC Engine System MG1UA008 (UP8)	✓	✓	✓	✓	✓	✓	SP2074-SP2087
DFFG	Scenery ix5	Engine Management System (EMS)/Delphi Engine System (MT62.1G)	✓	✓	✓	✓	✓	✓	SP2088-SP2098
DFFG	Scenery ix5	Engine Management System (EMS)/Delphi Engine System (MT92.1)	✓	✓	✓	✓	✓	✓	SP2099-SP2109
DFFG	Scenery ix5	Automatic Transmission System (TCU)/Automatic Transmission System (VT5)	✓	✓	✓	✓	✓	✓	SP2110-SP2117
DFFG	Scenery ix5	Automatic Transmission System (TCU)/Automatic Transmission System (RDC27)	✓	✓	✓	✓	✓	✓	SP2118-SP2125
DFFG	Scenery ix5	Automatic Transmission System (TCU)/Automatic Transmission System (VT3)	✓	✓	✓	✓	✓	✓	SP2126-SP2138
DFFG	Scenery ix5	Anti-lock brake system/Electronic Stability System (ESP)	✓	✓	✓	✓	✓	✓	
DFFG	Scenery ix5	Airbag (ABM)	✓	✓	✓	✓	✓	✓	SP2139
DFFG	Scenery ix5	Body Control System (BCM)	✓	✓	✓	✓	✓	✓	SP2140-SP2149
DFFG	Scenery ix5	Electronic Power Steering (EPS)	✓	✓	✓	✓	✓	✓	SP2150-SP2155
DFFG	Scenery ix5	Combination Instrument System (IC)	✓	✓	✓	✓	✓	✓	SP2156-SP2162
DFFG	Scenery ix5	Air Conditioning System (AC)	✓	✓	✓	✓	✓	✓	SP2163-SP2164
DFFG	Scenery ix5	Electronic Parking System (EPB)	✓	✓	✓	✓	✓	✓	SP2165-SP2179
DFFG	Scenery ix5	Driving Recorder (DVR)	✓	✓	✓	✓	✓	✓	SP2180-SP2183
DFFG	Scenery ix5	Panoramic Parking System (AVM)	✓	✓	✓	✓	✓	✓	SP2184-SP2187
DFFG	Scenery ix5	Electronic shifter (GSM)	✓	✓	✓	✓	✓	✓	SP2188-SP2189
DFFG	Scenery ix5	Multi-function camera (MPC)	✓	✓	✓	✓	✓	✓	SP2190-SP2200
DFFG	Scenery ix5	Parking sensor (PDC)	✓	✓	✓	✓	✓	✓	SP2201-SP2204
DFFG	Scenery ix5	Electric tailgate (PLG)	✓	✓	✓	✓	✓	✓	SP2205-SP2206
DFFG	Scenery ix5	Audio Entertainment System (RRM)	✓	✓	✓	✓	✓	✓	SP2207-SP2211
DFFG	Scenery ix5	Shift actuator (SBW)	✓	✓	✓	✓	✓	✓	SP2212-SP2214
DFFG	Scenery ix5	Internet of Vehicles Control System (I-BOX)	✓	✓	✓	✓	✓	✓	SP2215-SP2217
DFFG	Scenery ix5	Main driver's seat controller (DSM Z)	✓	✓	✓	✓	✓	✓	SP2218-SP2219
DFFG	Scenery ix5	Front passenger seat controller (DSM F)	✓	✓	✓	✓	✓	✓	SP2220-SP2221
DFFG	Scenery ix5	Wireless Charge Controller (WCM)	✓	✓	✓	✓	✓	✓	SP2222-SP2223
DFFG	Landscape ix5 power upgrade	Engine Management System (EMS)/Delphi Engine System	✓	✓	✓	✓	✓	✓	SP2224-SP2234
DFFG	Landscape ix5 power upgrade	Engine Management System (EMS)/UMC Engine System	✓	✓	✓	✓	✓	✓	SP2235-SP2248
DFFG	Landscape ix5 power upgrade	Automatic Transmission System (TCU)/Automatic Transmission (Pivot)	✓	✓	✓	✓	✓	✓	SP2249-SP2254
DFFG	Landscape ix5 power upgrade	Automatic Transmission System (TCU)/Automatic Transmission (Landai)	✓	✓	✓	✓	✓	✓	SP2255-SP2258
DFFG	Landscape ix5 power upgrade	Anti-lock brake system/Electronic Stability System (ESP)	✓	✓	✓	✓	✓	✓	SP2259-SP2268
DFFG	Landscape ix5 power upgrade	Airbag Controller (ABM)	✓	✓	✓	✓	✓	✓	SP2269-SP2276
DFFG	Landscape ix5 power upgrade	Body Control Module (BCM)	✓	✓	✓	✓	✓	✓	SP2277-SP2287

DFFG	Landscape ix5 power upgrade	Electronic Power Steering (EPS)	✓	✓	✓	✓	✓		SP2288-SP2293
DFFG	Landscape ix5 power upgrade	Combination Instrument (IC)	✓	✓	✓	✓	✓	✓	SP2294-SP2299
DFFG	Landscape ix5 power upgrade	Air Conditioning System (AC)	✓	✓	✓	✓	✓	✓	SP2300-SP2301
DFFG	Landscape ix5 power upgrade	Electronic Parking System (EPB)	✓	✓	✓	✓	✓	✓	SP2302-SP2318
DFFG	Landscape ix5 power upgrade	Gateway system (GW)	✓	✓	✓	✓	✓	✓	SP2319-SP2321
DFFG	Landscape ix5 power upgrade	Shift controller (GSM)	✓	✓	✓	✓	✓	✓	SP2322-SP2323
DFFG	Landscape ix5 power upgrade	Shift actuator (SBW)	✓	✓	✓	✓	✓	✓	SP2324-SP2326
DFFG	Landscape ix5 power upgrade	Four-wheel drive controller (AWD)	✓	✓	✓	✓	✓	✓	SP2327-SP2330
DFFG	Landscape ix5 power upgrade	Telematics module (T-BOX)	✓	✓	✓	✓	✓	✓	SP2331-SP2333
DFFG	Landscape ix5 power upgrade	Wireless Charge Controller (WCM)	✓	✓	✓	✓	✓	✓	SP2334-SP2335
DFFG	Landscape ix5 power upgrade	Multiple Switch Controller (MSC)	✓	✓	✓	✓	✓	✓	SP2336-SP2339
DFFG	Landscape ix5 power upgrade	Audio Entertainment System (RRM)	✓	✓	✓	✓	✓	✓	SP2340-SP2344
DFFG	Landscape ix5 power upgrade	Panoramic Parking (AVM)	✓	✓	✓	✓	✓	✓	SP2345-SP2348
DFFG	Landscape ix5 power upgrade	Parking sensor (PDC)	✓	✓	✓	✓	✓	✓	SP2349-SP2352
DFFG	Landscape ix5 power upgrade	Driving Recorder (DVR)	✓	✓	✓	✓	✓	✓	SP2353-SP2356
DFFG	Landscape ix5 power upgrade	Electric tailgate controller (PLG)	✓	✓	✓	✓	✓	✓	SP2357-SP2358
DFFG	Landscape ix5 power upgrade	Seat Controller (DSM)	✓	✓	✓	✓	✓	✓	SP2359-SP2360
DFFG	Landscape ix5 power upgrade	Electronic steering column lock (ESCL)	✓	✓	✓	✓	✓	✓	SP2361-SP2363
DFFG	E1	Battery Pack Data (BPD)	✓	✓	✓	✓	✓	✓	
DFFG	E1	Vehicle Controller (EVC)	✓	✓	✓	✓	✓	✓	SP2364-SP2368
DFFG	E1	Power Electronic Box (PEB)	✓	✓	✓	✓	✓	✓	SP2369
DFFG	E1	Direct Current Converter (DCDC)	✓	✓	✓	✓	✓	✓	SP2370
DFFG	E1	On-board charger (OBC)	✓	✓	✓	✓	✓	✓	SP2371
DFFG	E1	Battery Management System (BMS)	✓	✓	✓	✓	✓	✓	SP2372-SP2373
DFFG	E1	Body Control Module (BCM)	✓	✓	✓	✓	✓	✓	SP2374-SP2382
DFFG	E1	Vehicle Voice Control (VSP)	✓	✓	✓	✓	✓	✓	SP2383-SP2386
DFFG	E1	Airbag Controller (ACU)	✓	✓	✓	✓	✓	✓	SP2387-SP2390
DFFG	E1	Dashboard (IP)/Dashboard L1 (IP1)	✓	✓	✓	✓	✓	✓	SP2391-SP2402
DFFG	E1	Dashboard (IP)/Dashboard L2 (IP2)	✓	✓	✓	✓	✓	✓	SP2403-IP2409
DFFG	E1	Electronic Power Steering (EPS)	✓	✓	✓	✓	✓	✓	SP2410-SP2411
DFFG	E1	Anti-lock braking system (ABS)	✓	✓	✓	✓	✓	✓	SP2412-SP2426
DFFG	E1	Multimedia (AUDIO)	✓	✓	✓	✓	✓	✓	SP2427-SP2430
DFFG	E1	Remote communication module (TBOX)	✓	✓	✓	✓	✓	✓	SP2431-SP2434
DFFG	E1	Security Gateway 3 (S-GW3)	✓	✓	✓	✓	✓	✓	SP2435-SP2436
DFFG	Scenerv 580HEV	Engine Management System (EMS)	✓	✓	✓	✓	✓	✓	SP2437-SP2440
DFFG	Scenerv 580HEV	Battery Management System (BMS)	✓	✓	✓	✓	✓	✓	SP2441
DFFG	Scenerv 580HEV	Motor Controller (PEU1)	✓	✓	✓	✓	✓	✓	SP2442-SP2445
DFFG	Scenerv 580HEV	Motor Controller (PEU2)	✓	✓	✓	✓	✓	✓	SP2446-SP2449
DFFG	Scenerv 580HEV	Hybrid Vehicle Controller (HCU)	✓	✓	✓	✓	✓	✓	SP2450-SP2453
DFFG	Scenerv 580HEV	Anti-lock brake system/Electronic Stability System (ESP)	✓	✓	✓	✓	✓	✓	SP2454-SP2461
DFFG	Scenerv 580HEV	Airbag (ABM)	✓	✓	✓	✓	✓	✓	SP2462-SP2464
DFFG	Scenerv 580HEV	Body Control System (BCM)	✓	✓	✓	✓	✓	✓	SP2465-SP2475
DFFG	Scenerv 580HEV	Electronic Power Steering System (EPS)	✓	✓	✓	✓	✓	✓	
DFFG	Scenerv 580HEV	Combination Instrument (IC)	✓	✓	✓	✓	✓	✓	SP2476-SP2479
DFFG	Scenerv 580HEV	Air Conditioning System (AC)	✓	✓	✓	✓	✓	✓	SP2480
DFFG	Scenerv 580HEV	Thermal Management Controller (HMC)	✓	✓	✓	✓	✓	✓	SP2481-SP2482
DFFG	Scenerv 580HEV	Electronic Hand Brake System (EPB)	✓	✓	✓	✓	✓	✓	SP2483-SP2484
DFFG	Scenerv 580HEV	On-board charger (OBC)	✓	✓	✓	✓	✓	✓	
DFFG	Scenerv 580HEV	Synthetic Tank Oil Pump Controller (OPC)	✓	✓	✓	✓	✓	✓	
DFFG	Scenerv 580HEV	Electronic parking lock controller (EPL)	✓	✓	✓	✓	✓	✓	SP2485-SP2488
DFFG	Scenerv 580HEV	Shifter module (GSM)	✓	✓	✓	✓	✓	✓	SP2489
DFFG	Scenerv 580HEV	Audio Entertainment System (RRM)	✓	✓	✓	✓	✓	✓	SP2490-SP2494
DFFG	Scenerv 580HEV	Telematics control module (T-BOX)	✓	✓	✓	✓	✓	✓	SP2495-SP2497
DFFG	Scenerv 580HEV	Compressor Control Unit (CCU)	✓	✓	✓	✓	✓	✓	SP2498-SP2499
DFFG	Scenerv 580HEV	Panoramic Parking System (AVM)	✓	✓	✓	✓	✓	✓	SP2500
DFFG	Scenerv 580HEV	Electric tailgate controller (PLG)	✓	✓	✓	✓	✓	✓	
DFFG	Scenerv 580 PHEV	Engine Management System (EMS)	✓	✓	✓	✓	✓	✓	SP2501-SP2504
DFFG	Scenerv 580 PHEV	Battery Management System (BMS)	✓	✓	✓	✓	✓	✓	SP2505-SP2506
DFFG	Scenerv 580 PHEV	Motor Controller (PEU1)	✓	✓	✓	✓	✓	✓	SP2507-SP2510
DFFG	Scenerv 580 PHEV	Motor Controller (PEU2)	✓	✓	✓	✓	✓	✓	SP2511-SP2514
DFFG	Scenerv 580 PHEV	Hybrid Vehicle Controller (HCU)	✓	✓	✓	✓	✓	✓	SP2515-SP2518
DFFG	Scenerv 580 PHEV	Anti-lock brake system/Electronic Stability System (ESP)	✓	✓	✓	✓	✓	✓	SP2519-SP2526
DFFG	Scenerv 580 PHEV	Airbag (ABM)	✓	✓	✓	✓	✓	✓	SP2527-SP2529
DFFG	Scenerv 580 PHEV	Body Control System (BCM)	✓	✓	✓	✓	✓	✓	SP2530-SP2540
DFFG	Scenerv 580 PHEV	Electronic Power Steering System (EPS)	✓	✓	✓	✓	✓	✓	
DFFG	Scenerv 580 PHEV	Combination Instrument (IC)	✓	✓	✓	✓	✓	✓	SP2541-SP2544
DFFG	Scenerv 580 PHEV	Air Conditioning System (AC)	✓	✓	✓	✓	✓	✓	SP2545
DFFG	Scenerv 580 PHEV	Thermal Management Controller (HMC)	✓	✓	✓	✓	✓	✓	SP2546-SP2547
DFFG	Scenerv 580 PHEV	Electronic Hand Brake System (EPB)	✓	✓	✓	✓	✓	✓	SP2548-SP2549
DFFG	Scenerv 580 PHEV	On-board charger (OBC)	✓	✓	✓	✓	✓	✓	
DFFG	Scenerv 580 PHEV	Synthetic Tank Oil Pump Controller (OPC)	✓	✓	✓	✓	✓	✓	
DFFG	Scenerv 580 PHEV	Thermistor heater (PTCH)	✓	✓	✓	✓	✓	✓	SP2550
DFFG	Scenerv 580 PHEV	Electronic parking lock controller (EPL)	✓	✓	✓	✓	✓	✓	SP2551-SP2554
DFFG	Scenerv 580 PHEV	Shifter module (GSM)	✓	✓	✓	✓	✓	✓	SP2555
DFFG	Scenerv 580 PHEV	Audio Entertainment System (RRM)	✓	✓	✓	✓	✓	✓	SP2556-SP2560
DFFG	Scenerv 580 PHEV	Telematics control module (T-BOX)	✓	✓	✓	✓	✓	✓	SP2561-SP2563
DFFG	Scenerv 580 PHEV	Compressor Control Unit (CCU)	✓	✓	✓	✓	✓	✓	SP2564-SP2565
DFFG	Scenerv 580 PHEV	Panoramic Parking System (AVM)	✓	✓	✓	✓	✓	✓	SP2566
DFFG	Scenerv 580 PHEV	Electric tailgate controller (PLG)	✓	✓	✓	✓	✓	✓	
DFFG	Scenerv E3	Battery Pack Data (BPD)	✓	✓	✓	✓	✓	✓	
DFFG	Scenerv E3	Battery Management System (BMS)/Kelie Battery Management System	✓	✓	✓	✓	✓	✓	

DFFG	Scenery E3	Battery Management System (BMS)/Hangsheng Battery Management System	√	√	√	√			
DFFG	Scenery E3	Vehicle Controller (VCU)	√	√	√	√	√	√	SP2567-SP2569
DFFG	Scenery E3	Motor Control Unit (MCU)	√	√	√	√			SP2570-SP2574
DFFG	Scenery E3	Electronic Stability System (ABS/ESC)/Electronic Stability System (ABS)	√	√	√	√			SP2575
DFFG	Scenery E3	Electronic Stability System (ABS/ESC)/Electronic Stability System (ESC)	√	√	√	√	√		SP2576-SP2584
DFFG	Scenery E3	Airbag system (ABM)	√	√	√	√		√	SP2585-SP2591
DFFG	Scenery E3	Body Control Module (BCM)	√	√	√	√		√	SP2592-SP2601
DFFG	Scenery E3	Electronic Power Steering (EPS)	√	√	√	√	√		SP2602-SP2607
DFFG	Scenery E3	Combination Instrument (IC)	√	√	√	√		√	SP2608-SP2613
DFFG	Scenery E3	Air Conditioning (AC)	√	√	√	√		√	SP2614-SP2615
DFFG	Scenery E3	Electric parking brake system (EPB)	√	√	√	√	√	√	SP2616-SP2632
DFFG	Scenery E3	Direct Current Converter (DCDC)	√	√	√	√	√		SP2633-SP2636
DFFG	Scenery E3	On-board charger (OBC)	√	√	√	√	√		SP2637
DFFG	Scenery E3	Electronic parking lock controller (EPL)	√	√	√			√	SP2638-SP2640
DFFG	Scenery E3	Multi-function camera (MPC)	√	√	√	√	√	√	SP2641-SP2651
DFFG	Scenery E3	Thermal Management Controller (HMC)/Ruiyang Thermal Management Controller	√	√	√	√		√	SP2652
DFFG	Scenery E3	Thermal Management Controller (HMC)/Daming Thermal Management Controller	√	√	√	√		√	SP2653
DFFG	Scenery E3	Shifter module (GSM)	√	√	√	√	√	√	SP2654-SP2658
DFFG	Scenery E3	Remote communication unit (T-BOX)	√	√	√	√		√	SP2659-SP2663
DFFG	Scenery E3	Electric Back Door (PLG)	√	√	√	√		√	SP2664-SP2665
DFFG	Scenery E3	Radar Controller (PDC)	√	√	√	√			SP2666-SP2669
DFFG	Scenery E3	Audio Entertainment System (RRM)	√	√	√				SP2670-SP2674
DFFG	Scenery E3	Panoramic Parking (AVM)	√	√	√		√	√	SP2675-SP2678
DFFG	Scenery E3	Main driver's seat controller (DSM Z)	√	√	√				SP2679-SP2682
DFFG	Scenery E3	Front passenger seat controller (DSM F)	√	√	√				SP2683
DFFG	Scenery E3	Driving Recorder (DVR)	√	√	√				SP2684-SP2687
DFFG	Scenery E3	Wireless Charge Controller (WCM)	√	√	√				SP2688-SP2689
DFFG	Scenery 360EV	Battery Management System (BMS)	√	√	√	√		√	
DFFG	Scenery 360EV	Vehicle Controller (VCU)	√	√	√	√	√		SP2690
DFFG	Scenery 360EV	Motor Control Unit (MCU)	√	√	√	√	√	√	SP2691
DFFG	Scenery 360EV	Anti-lock brake system (ABS)/BOSCH ABS 9.0	√	√	√	√		√	SP2692-SP2701
DFFG	Scenery 360EV	Anti-lock brake system (ABS)/Asia-Pacific integral hydraulic ABS	√	√	√	√		√	SP2702-SP2703
DFFG	Scenery 360EV	Anti-lock brake system (ABS)/Asia-Pacific ABS	√	√	√	√		√	
DFFG	Scenery 360EV	Airbag system (ABM)	√	√	√	√			SP2704-SP2706
DFFG	Scenery 360EV	Instrument (IC)	√	√	√		√		SP2707
DFFG	Scenery 360EV	Audio Entertainment System (RRM)	√	√	√				SP2708-SP2712
DFFG	Scenery 360EV	Telematics module (T-BOX)	√	√	√	√	√	√	SP2713-SP2715

Special Functions List

No.	Functions Name	System Name
SP0000	Read VIN code	Delphi MT22.1 engine system
SP0001	Write VIN code	Delphi MT22.1 engine system
SP0002	Delphi Broadcasting Code	Delphi MT22.1 engine system
SP0003	Vehicle identification code	Delphi MT22.1 engine system
SP0004	Repair shop number or tester number	Delphi MT22.1 engine system
SP0005	ECU reset	Delphi MT22.1 engine system
SP0006	Delphi Broadcasting Code	Delphi MT22.1.1 engine system
SP0007	Vehicle identification code	Delphi MT22.1.1 engine system
SP0008	Repair shop number or tester number	Delphi MT22.1.1 engine system
SP0009	Write VIN code	Delphi MT62.3 engine system
SP0010	Write repair department code or test serial number	Delphi MT62.3 engine system
SP0011	Hardware reset	Delphi MT62.3 engine system
SP0012	Software reset	Delphi MT62.3 engine system
SP0013	Read battery sensor battery ID	Delphi MT62.3 engine system
SP0014	Read the battery sensor serial number	Delphi MT62.3 engine system
SP0015	Read the battery sensor version number	Delphi MT62.3 engine system
SP0016	Write battery sensor battery ID	Delphi MT62.3 engine system
SP0017	Routine control GPF regeneration	Delphi MT62.3 engine system
SP0018	Routine control mileage reset	Delphi MT62.3 engine system
SP0019	Write carbon load quality and GPF ash mileage	Delphi MT62.3 engine system
SP0020	Write VIN code	Delphi Engine System (MT62.1U)
SP0021	Write repair department code or test serial number	Delphi Engine System (MT62.1U)
SP0022	Hardware reset	Delphi Engine System (MT62.1U)
SP0023	Software reset	Delphi Engine System (MT62.1U)
SP0024	Read battery sensor battery ID	Delphi Engine System (MT62.1U)
SP0025	Read the battery sensor serial number	Delphi Engine System (MT62.1U)
SP0026	Read the battery sensor version number	Delphi Engine System (MT62.1U)
SP0027	Write battery sensor battery ID	Delphi Engine System (MT62.1U)
SP0028	Routine control GPF regeneration	Delphi Engine System (MT62.1U)
SP0029	Routine control mileage reset	Delphi Engine System (MT62.1U)
SP0030	Write carbon load quality and GPF ash mileage	Delphi Engine System (MT62.1U)
SP0031	Write VIN code	UMC M781M780
SP0032	ECU power off reset	UMC M781M780
SP0033	Read VIN code	Delphi MT22.3 (ETC) engine system
SP0034	Write VIN code	Delphi MT22.3 (ETC) engine system
SP0035	Delphi Broadcasting Code	Delphi MT22.3 (ETC) engine system
SP0036	Vehicle identification code	Delphi MT22.3 (ETC) engine system
SP0037	Repair shop number or tester number	Delphi MT22.3 (ETC) engine system
SP0038	ECU reset	Delphi MT22.3 (ETC) engine system
SP0039	Write VIN code	Rvoden Engine System
SP0040	Hardware reset	Rvoden Engine System
SP0041	One-click after-sales matching	Ryoden Engine System
SP0042	Steering angle and yaw rate calibration (ESP only)	Anti-lock brake system/electronic brake stabilization system (ESP)
SP0043	Automatic exhaust	Anti-lock brake system/electronic brake stabilization system (ESP)
SP0044	Speed limit	Anti-lock brake system/electronic brake stabilization system (ESP)
SP0045	ECU reset	Anti-lock brake system/electronic brake stabilization system (ESP)
SP0046	ECU reset	Universal ABS
SP0047	Read VIN code	Electronic Power Steering (EPS)
SP0048	Write VIN code	Electronic Power Steering (EPS)
SP0049	Four-wheeled vehicle	Tire Pressure Matching System (TPMS)
SP0050	Six-wheeler	Tire Pressure Matching System (TPMS)
SP0051	Left front wheel	Tire Pressure Matching System (TPMS)
SP0052	Right front wheel	Tire Pressure Matching System (TPMS)
SP0053	Right rear wheel	Tire Pressure Matching System (TPMS)
SP0054	Left rear wheel	Tire Pressure Matching System (TPMS)
SP0055	Left front wheel	Tire Pressure Matching System (TPMS)
SP0056	Right front wheel	Tire Pressure Matching System (TPMS)
SP0057	Right rear outer wheel	Tire Pressure Matching System (TPMS)

SP0058	Right rear inner wheel	Tire Pressure Matching System (TPMS)
SP0059	Left rear inner wheel	Tire Pressure Matching System (TPMS)
SP0060	Left rear outer wheel	Tire Pressure Matching System (TPMS)
SP0061	Left front wheel	Tire Pressure Matching System (TPMS)
SP0062	Right front wheel	Tire Pressure Matching System (TPMS)
SP0063	Right rear wheel	Tire Pressure Matching System (TPMS)
SP0064	Left rear wheel	Tire Pressure Matching System (TPMS)
SP0065	Left front wheel	Tire Pressure Matching System (TPMS)
SP0066	Right front wheel	Tire Pressure Matching System (TPMS)
SP0067	Right rear outer wheel	Tire Pressure Matching System (TPMS)
SP0068	Right rear inner wheel	Tire Pressure Matching System (TPMS)
SP0069	Left rear inner wheel	Tire Pressure Matching System (TPMS)
SP0070	Left rear outer wheel	Tire Pressure Matching System (TPMS)
SP0071	Alarm value setting	Tire Pressure Matching System (TPMS)
SP0072	Read VIN code	Delphi MT22.1 engine system
SP0073	Write VIN code	Delphi MT22.1 engine system
SP0074	Delphi Broadcasting Code	Delphi MT22.1 engine system
SP0075	Vehicle identification code	Delphi MT22.1 engine system
SP0076	Repair shop number or tester number	Delphi MT22.1 engine system
SP0077	ECU reset	Delphi MT22.1 engine system
SP0078	Delphi Broadcasting Code	Delphi MT22.1.1 engine system
SP0079	Vehicle identification code	Delphi MT22.1.1 engine system
SP0080	Repair shop number or tester number	Delphi MT22.1.1 engine system
SP0081	Write VIN code	Delphi MT62.3 engine system
SP0082	Write repair department code or test serial number	Delphi MT62.3 engine system
SP0083	Hardware reset	Delphi MT62.3 engine system
SP0084	Software reset	Delphi MT62.3 engine system
SP0085	Read battery sensor battery ID	Delphi MT62.3 engine system
SP0086	Read the battery sensor serial number	Delphi MT62.3 engine system
SP0087	Read the battery sensor version number	Delphi MT62.3 engine system
SP0088	Write battery sensor battery ID	Delphi MT62.3 engine system
SP0089	Routine control GPF regeneration	Delphi MT62.3 engine system
SP0090	Routine control mileage reset	Delphi MT62.3 engine system
SP0091	Write carbon load quality and GPF ash mileage	Delphi MT62.3 engine system
SP0092	Write VIN code	Delphi Engine System (MT62.1U)
SP0093	Write repair department code or test serial number	Delphi Engine System (MT62.1U)
SP0094	Hardware reset	Delphi Engine System (MT62.1U)
SP0095	Software reset	Delphi Engine System (MT62.1U)
SP0096	Read battery sensor battery ID	Delphi Engine System (MT62.1U)
SP0097	Read the battery sensor serial number	Delphi Engine System (MT62.1U)
SP0098	Read the battery sensor version number	Delphi Engine System (MT62.1U)
SP0099	Write battery sensor battery ID	Delphi Engine System (MT62.1U)
SP0100	Routine control GPF regeneration	Delphi Engine System (MT62.1U)
SP0101	Routine control mileage reset	Delphi Engine System (MT62.1U)
SP0102	Write carbon load quality and GPF ash mileage	Delphi Engine System (MT62.1U)
SP0103	Write VIN code	UMC M781M780
SP0104	ECU power off reset	UMC M781M780
SP0105	Read VIN code	Delphi MT22.3 (ETC) engine system
SP0106	Write VIN code	Delphi MT22.3 (ETC) engine system
SP0107	Delphi Broadcasting Code	Delphi MT22.3 (ETC) engine system
SP0108	Vehicle identification code	Delphi MT22.3 (ETC) engine system
SP0109	Repair shop number or tester number	Delphi MT22.3 (ETC) engine system
SP0110	ECU reset	Delphi MT22.3 (ETC) engine system
SP0111	Write VIN code	Ryoden Engine System
SP0112	Hardware reset	Ryoden Engine System
SP0113	One-click after-sales matching	Ryoden Engine System
SP0114	Read VIN code	Electronic Power Steering (EPS)
SP0115	Write VIN code	Electronic Power Steering (EPS)
SP0116	Steering angle and yaw rate calibration (ESP only)	Electronic brake stabilization system (ABS/ESC)
SP0117	Automatic exhaust	Electronic brake stabilization system (ABS/ESC)
SP0118	Speed limit	Electronic brake stabilization system (ABS/ESC)
SP0119	ECU reset	Electronic brake stabilization system (ABS/ESC)

SP0120	Four-wheeled vehicle	Tire Pressure Matching System (TPMS)
SP0121	Six-wheeler	Tire Pressure Matching System (TPMS)
SP0122	Left front wheel	Tire Pressure Matching System (TPMS)
SP0123	Right front wheel	Tire Pressure Matching System (TPMS)
SP0124	Right rear wheel	Tire Pressure Matching System (TPMS)
SP0125	Left rear wheel	Tire Pressure Matching System (TPMS)
SP0126	Left front wheel	Tire Pressure Matching System (TPMS)
SP0127	Right front wheel	Tire Pressure Matching System (TPMS)
SP0128	Right rear outer wheel	Tire Pressure Matching System (TPMS)
SP0129	Right rear inner wheel	Tire Pressure Matching System (TPMS)
SP0130	Left rear inner wheel	Tire Pressure Matching System (TPMS)
SP0131	Left rear outer wheel	Tire Pressure Matching System (TPMS)
SP0132	Left front wheel	Tire Pressure Matching System (TPMS)
SP0133	Right front wheel	Tire Pressure Matching System (TPMS)
SP0134	Right rear wheel	Tire Pressure Matching System (TPMS)
SP0135	Left rear wheel	Tire Pressure Matching System (TPMS)
SP0136	Left front wheel	Tire Pressure Matching System (TPMS)
SP0137	Right front wheel	Tire Pressure Matching System (TPMS)
SP0138	Right rear outer wheel	Tire Pressure Matching System (TPMS)
SP0139	Right rear inner wheel	Tire Pressure Matching System (TPMS)
SP0140	Left rear inner wheel	Tire Pressure Matching System (TPMS)
SP0141	Left rear outer wheel	Tire Pressure Matching System (TPMS)
SP0142	Alarm value setting	Tire Pressure Matching System (TPMS)
SP0143	Read VIN code	Delphi MT22.1 engine system
SP0144	Write VIN code	Delphi MT22.1 engine system
SP0145	Delphi Broadcasting Code	Delphi MT22.1 engine system
SP0146	Vehicle identification code	Delphi MT22.1 engine system
SP0147	Repair shop number or tester number	Delphi MT22.1 engine system
SP0148	ECU reset	Delphi MT22.1 engine system
SP0149	Delphi Broadcasting Code	Delphi MT22.1.1 engine system
SP0150	Vehicle identification code	Delphi MT22.1.1 engine system
SP0151	Repair shop number or tester number	Delphi MT22.1.1 engine system
SP0152	Write VIN code	Delphi Engine System (MT62.1U)
SP0153	Write repair department code or test serial number	Delphi Engine System (MT62.1U)
SP0154	Hardware reset	Delphi Engine System (MT62.1U)
SP0155	Software reset	Delphi Engine System (MT62.1U)
SP0156	Read battery sensor battery ID	Delphi Engine System (MT62.1U)
SP0157	Read the battery sensor serial number	Delphi Engine System (MT62.1U)
SP0158	Read the battery sensor version number	Delphi Engine System (MT62.1U)
SP0159	Write battery sensor battery ID	Delphi Engine System (MT62.1U)
SP0160	Routine control GPF regeneration	Delphi Engine System (MT62.1U)
SP0161	Routine control mileage reset	Delphi Engine System (MT62.1U)
SP0162	Write carbon load quality and GPF ash mileage	Delphi Engine System (MT62.1U)
SP0163	Write VIN code	UMC M781M780
SP0164	ECU power off reset	UMC M781M780
SP0165	Read VIN code	Delphi MT22.3 (ETC) engine system
SP0166	Write VIN code	Delphi MT22.3 (ETC) engine system
SP0167	Delphi Broadcasting Code	Delphi MT22.3 (ETC) engine system
SP0168	Vehicle identification code	Delphi MT22.3 (ETC) engine system
SP0169	Repair shop number or tester number	Delphi MT22.3 (ETC) engine system
SP0170	ECU reset	Delphi MT22.3 (ETC) engine system
SP0171	Write VIN code	Ryoden Engine System
SP0172	Hardware reset	Ryoden Engine System
SP0173	One-click after-sales matching	Ryoden Engine System
SP0174	Steering angle and yaw rate calibration (ESP only)	Electronic brake stabilization system (ABS/ESC)
SP0175	Automatic exhaust	Electronic brake stabilization system (ABS/ESC)
SP0176	Speed limit	Electronic brake stabilization system (ABS/ESC)
SP0177	ECU reset	Electronic brake stabilization system (ABS/ESC)
SP0178	Read VIN code	Electronic Power Steering (EPS)
SP0179	Write VIN code	Electronic Power Steering (EPS)
SP0180	Four-wheeled vehicle	Tire Pressure Matching System (TPMS)
SP0181	Six-wheeler	Tire Pressure Matching System (TPMS)
SP0182	Left front wheel	Tire Pressure Matching System (TPMS)
SP0183	Right front wheel	Tire Pressure Matching System (TPMS)
SP0184	Right rear wheel	Tire Pressure Matching System (TPMS)
SP0185	Left rear wheel	Tire Pressure Matching System (TPMS)
SP0186	Left front wheel	Tire Pressure Matching System (TPMS)
SP0187	Right front wheel	Tire Pressure Matching System (TPMS)
SP0188	Right rear outer wheel	Tire Pressure Matching System (TPMS)
SP0189	Right rear inner wheel	Tire Pressure Matching System (TPMS)
SP0190	Left rear inner wheel	Tire Pressure Matching System (TPMS)

SP0191	Left rear outer wheel	Tire Pressure Matching System (TPMS)
SP0192	Left front wheel	Tire Pressure Matching System (TPMS)
SP0193	Right front wheel	Tire Pressure Matching System (TPMS)
SP0194	Right rear wheel	Tire Pressure Matching System (TPMS)
SP0195	Left rear wheel	Tire Pressure Matching System (TPMS)
SP0196	Left front wheel	Tire Pressure Matching System (TPMS)
SP0197	Right front wheel	Tire Pressure Matching System (TPMS)
SP0198	Right rear outer wheel	Tire Pressure Matching System (TPMS)
SP0199	Right rear inner wheel	Tire Pressure Matching System (TPMS)
SP0200	Left rear inner wheel	Tire Pressure Matching System (TPMS)
SP0201	Left rear outer wheel	Tire Pressure Matching System (TPMS)
SP0202	Alarm value setting	Tire Pressure Matching System (TPMS)
SP0203	Read VIN code	Delphi MT22.1 (IAC) engine system
SP0204	Write VIN code	Delphi MT22.1 (IAC) engine system
SP0205	Delphi Broadcasting Code	Delphi MT22.1 (IAC) engine system
SP0206	Vehicle identification code	Delphi MT22.1 (IAC) engine system
SP0207	Repair shop number or tester number	Delphi MT22.1 (IAC) engine system
SP0208	ECU reset	Delphi MT22.1 (IAC) engine system
SP0209	Delphi Broadcasting Code	Delphi MT22.1.1 engine system
SP0210	Vehicle identification code	Delphi MT22.1.1 engine system
SP0211	Repair shop number or tester number	Delphi MT22.1.1 engine system
SP0212	Write VIN code	Delphi Engine System (MT62.1U)
SP0213	Write repair department code or test serial number	Delphi Engine System (MT62.1U)
SP0214	Hardware reset	Delphi Engine System (MT62.1U)
SP0215	Software reset	Delphi Engine System (MT62.1U)
SP0216	Read battery sensor battery ID	Delphi Engine System (MT62.1U)
SP0217	Read the battery sensor serial number	Delphi Engine System (MT62.1U)
SP0218	Read the battery sensor version number	Delphi Engine System (MT62.1U)
SP0219	Write battery sensor battery ID	Delphi Engine System (MT62.1U)
SP0220	Routine control GPF regeneration	Delphi Engine System (MT62.1U)
SP0221	Routine control mileage reset	Delphi Engine System (MT62.1U)
SP0222	Write carbon load quality and GPF ash mileage	Delphi Engine System (MT62.1U)
SP0223	Write VIN code	UMC M781M780
SP0224	ECU power off reset	UMC M781M780
SP0225	Read VIN code	Delphi MT22.3 (ETC) engine system
SP0226	Write VIN code	Delphi MT22.3 (ETC) engine system
SP0227	Delphi Broadcasting Code	Delphi MT22.3 (ETC) engine system
SP0228	Vehicle identification code	Delphi MT22.3 (ETC) engine system
SP0229	Repair shop number or tester number	Delphi MT22.3 (ETC) engine system
SP0230	ECU reset	Delphi MT22.3 (ETC) engine system
SP0231	Write VIN code	Ryoden Engine System
SP0232	Hardware reset	Ryoden Engine System
SP0233	One-click after-sales matching	Ryoden Engine System
SP0234	ECU reset	Electronic Brake Stability System (ABS/ESC)/Universal ABS
SP0235	Steering angle and yaw rate calibration (ESP only)	Electronic Brake Stability System (ABS/ESC)/Anti-lock Brake (ABS)
SP0236	Automatic exhaust	Electronic Brake Stability System (ABS/ESC)/Anti-lock Brake (ABS)
SP0237	Speed limit	Electronic Brake Stability System (ABS/ESC)/Anti-lock Brake (ABS)
SP0238	ECU reset	Electronic Brake Stability System (ABS/ESC)/Anti-lock Brake (ABS)
SP0239	Read VIN code	Electronic Power Steering (EPS)
SP0240	Write VIN code	Electronic Power Steering (EPS)
SP0241	Four-wheeled vehicle	Tire Pressure Matching System (TPMS)
SP0242	Six-wheeler	Tire Pressure Matching System (TPMS)
SP0243	Left front wheel	Tire Pressure Matching System (TPMS)
SP0244	Right front wheel	Tire Pressure Matching System (TPMS)
SP0245	Right rear wheel	Tire Pressure Matching System (TPMS)
SP0246	Left rear wheel	Tire Pressure Matching System (TPMS)
SP0247	Left front wheel	Tire Pressure Matching System (TPMS)
SP0248	Right front wheel	Tire Pressure Matching System (TPMS)
SP0249	Right rear outer wheel	Tire Pressure Matching System (TPMS)
SP0250	Right rear inner wheel	Tire Pressure Matching System (TPMS)
SP0251	Left rear inner wheel	Tire Pressure Matching System (TPMS)
SP0252	Left rear outer wheel	Tire Pressure Matching System (TPMS)
SP0253	Left front wheel	Tire Pressure Matching System (TPMS)
SP0254	Right front wheel	Tire Pressure Matching System (TPMS)
SP0255	Right rear wheel	Tire Pressure Matching System (TPMS)
SP0256	Left rear wheel	Tire Pressure Matching System (TPMS)
SP0257	Left front wheel	Tire Pressure Matching System (TPMS)
SP0258	Right front wheel	Tire Pressure Matching System (TPMS)
SP0259	Right rear outer wheel	Tire Pressure Matching System (TPMS)
SP0260	Right rear inner wheel	Tire Pressure Matching System (TPMS)

SP0261	Left rear inner wheel	Tire Pressure Matching System (TPMS)
SP0262	Left rear outer wheel	Tire Pressure Matching System (TPMS)
SP0263	Alarm value setting	Tire Pressure Matching System (TPMS)
SP0264	Write VIN code	Delphi Engine System (MT62.1U)
SP0265	Write repair department code or test serial number	Delphi Engine System (MT62.1U)
SP0266	Hardware reset	Delphi Engine System (MT62.1U)
SP0267	Software reset	Delphi Engine System (MT62.1U)
SP0268	Read battery sensor battery ID	Delphi Engine System (MT62.1U)
SP0269	Read the battery sensor serial number	Delphi Engine System (MT62.1U)
SP0270	Read the battery sensor version number	Delphi Engine System (MT62.1U)
SP0271	Write battery sensor battery ID	Delphi Engine System (MT62.1U)
SP0272	Routine control GPF regeneration	Delphi Engine System (MT62.1U)
SP0273	Routine control mileage reset	Delphi Engine System (MT62.1U)
SP0274	Write carbon load quality and GPF ash mileage	Delphi Engine System (MT62.1U)
SP0275	Read VIN code	Delphi MT22.1 (IAC) engine system
SP0276	Write VIN code	Delphi MT22.1 (IAC) engine system
SP0277	Delphi Broadcasting Code	Delphi MT22.1 (IAC) engine system
SP0278	Vehicle identification code	Delphi MT22.1 (IAC) engine system
SP0279	Repair shop number or tester number	Delphi MT22.1 (IAC) engine system
SP0280	ECU reset	Delphi MT22.1 (IAC) engine system
SP0281	Delphi Broadcasting Code	Delphi MT22.1.1 engine system
SP0282	Vehicle identification code	Delphi MT22.1.1 engine system
SP0283	Repair shop number or tester number	Delphi MT22.1.1 engine system
SP0284	Write VIN code	UMC M781M780
SP0285	ECU power off reset	UMC M781M780
SP0286	Read VIN code	Delphi MT22.3 (ETC) engine system
SP0287	Write VIN code	Delphi MT22.3 (ETC) engine system
SP0288	Delphi Broadcasting Code	Delphi MT22.3 (ETC) engine system
SP0289	Vehicle identification code	Delphi MT22.3 (ETC) engine system
SP0290	Repair shop number or tester number	Delphi MT22.3 (ETC) engine system
SP0291	ECU reset	Delphi MT22.3 (ETC) engine system
SP0292	Steering angle and yaw rate calibration (ESP only)	Anti-lock brake system/electronic brake stabilization system
SP0293	Automatic exhaust	Anti-lock brake system/electronic brake stabilization system
SP0294	Speed limit	Anti-lock brake system/electronic brake stabilization system
SP0295	ECU reset	Anti-lock brake system/electronic brake stabilization system
SP0296	ECU reset	Universal ABS
SP0297	Read VIN code	Electronic Power Steering (EPS)
SP0298	Write VIN code	Electronic Power Steering (EPS)
SP0299	Four-wheeled vehicle	Tire Pressure Matching System (TPMS)
SP0300	Six-wheeler	Tire Pressure Matching System (TPMS)
SP0301	Left front wheel	Tire Pressure Matching System (TPMS)
SP0302	Right front wheel	Tire Pressure Matching System (TPMS)
SP0303	Right rear wheel	Tire Pressure Matching System (TPMS)
SP0304	Left rear wheel	Tire Pressure Matching System (TPMS)
SP0305	Left front wheel	Tire Pressure Matching System (TPMS)
SP0306	Right front wheel	Tire Pressure Matching System (TPMS)
SP0307	Right rear outer wheel	Tire Pressure Matching System (TPMS)
SP0308	Right rear inner wheel	Tire Pressure Matching System (TPMS)
SP0309	Left rear inner wheel	Tire Pressure Matching System (TPMS)
SP0310	Left rear outer wheel	Tire Pressure Matching System (TPMS)
SP0311	Left front wheel	Tire Pressure Matching System (TPMS)
SP0312	Right front wheel	Tire Pressure Matching System (TPMS)
SP0313	Right rear wheel	Tire Pressure Matching System (TPMS)
SP0314	Left rear wheel	Tire Pressure Matching System (TPMS)
SP0315	Left front wheel	Tire Pressure Matching System (TPMS)
SP0316	Right front wheel	Tire Pressure Matching System (TPMS)
SP0317	Right rear outer wheel	Tire Pressure Matching System (TPMS)
SP0318	Right rear inner wheel	Tire Pressure Matching System (TPMS)
SP0319	Left rear inner wheel	Tire Pressure Matching System (TPMS)
SP0320	Left rear outer wheel	Tire Pressure Matching System (TPMS)
SP0321	Alarm value setting	Tire Pressure Matching System (TPMS)
SP0322	Read VIN code	Delphi MT22.1 (IAC) engine system
SP0323	Write VIN code	Delphi MT22.1 (IAC) engine system
SP0324	Delphi Broadcasting Code	Delphi MT22.1 (IAC) engine system
SP0325	Vehicle identification code	Delphi MT22.1 (IAC) engine system
SP0326	Repair shop number or tester number	Delphi MT22.1 (IAC) engine system
SP0327	ECU reset	Delphi MT22.1 (IAC) engine system
SP0328	Delphi Broadcasting Code	Delphi MT22.1.1 engine system

SP0329	Vehicle identification code	Delphi MT22.1.1 engine system
SP0330	Repair shop number or tester number	Delphi MT22.1.1 engine system
SP0331	Write VIN code	Delphi Engine System (MT62.1U)
SP0332	Write repair department code or test serial number	Delphi Engine System (MT62.1U)
SP0333	Hardware reset	Delphi Engine System (MT62.1U)
SP0334	Software reset	Delphi Engine System (MT62.1U)
SP0335	Read battery sensor battery ID	Delphi Engine System (MT62.1U)
SP0336	Read the battery sensor serial number	Delphi Engine System (MT62.1U)
SP0337	Read the battery sensor version number	Delphi Engine System (MT62.1U)
SP0338	Write battery sensor battery ID	Delphi Engine System (MT62.1U)
SP0339	Routine control GPF regeneration	Delphi Engine System (MT62.1U)
SP0340	Routine control mileage reset	Delphi Engine System (MT62.1U)
SP0341	Write carbon load quality and GPF ash mileage	Delphi Engine System (MT62.1U)
SP0342	Write VIN code	UMC M781M780
SP0343	ECU power off reset	UMC M781M780
SP0344	Read VIN code	Delphi MT22.3 (ETC) engine system
SP0345	Write VIN code	Delphi MT22.3 (ETC) engine system
SP0346	Delphi Broadcasting Code	Delphi MT22.3 (ETC) engine system
SP0347	Vehicle identification code	Delphi MT22.3 (ETC) engine system
SP0348	Repair shop number or tester number	Delphi MT22.3 (ETC) engine system
SP0349	ECU reset	Delphi MT22.3 (ETC) engine system
SP0350	Steering angle and yaw rate calibration (ESP only)	Anti-lock brake system/electronic brake stabilization system
SP0351	Automatic exhaust	Anti-lock brake system/electronic brake stabilization system
SP0352	Speed limit	Anti-lock brake system/electronic brake stabilization system
SP0353	ECU reset	Anti-lock brake system/electronic brake stabilization system
SP0354	ECU reset	Universal ABS
SP0355	Read VIN code	Electronic Power Steering (EPS)
SP0356	Write VIN code	Electronic Power Steering (EPS)
SP0357	Four-wheeled vehicle	Tire Pressure Matching System (TPMS)
SP0358	Six-wheeler	Tire Pressure Matching System (TPMS)
SP0359	Left front wheel	Tire Pressure Matching System (TPMS)
SP0360	Right front wheel	Tire Pressure Matching System (TPMS)
SP0361	Right rear wheel	Tire Pressure Matching System (TPMS)
SP0362	Left rear wheel	Tire Pressure Matching System (TPMS)
SP0363	Left front wheel	Tire Pressure Matching System (TPMS)
SP0364	Right front wheel	Tire Pressure Matching System (TPMS)
SP0365	Right rear outer wheel	Tire Pressure Matching System (TPMS)
SP0366	Right rear inner wheel	Tire Pressure Matching System (TPMS)
SP0367	Left rear inner wheel	Tire Pressure Matching System (TPMS)
SP0368	Left rear outer wheel	Tire Pressure Matching System (TPMS)
SP0369	Left front wheel	Tire Pressure Matching System (TPMS)
SP0370	Right front wheel	Tire Pressure Matching System (TPMS)
SP0371	Right rear wheel	Tire Pressure Matching System (TPMS)
SP0372	Left rear wheel	Tire Pressure Matching System (TPMS)
SP0373	Left front wheel	Tire Pressure Matching System (TPMS)
SP0374	Right front wheel	Tire Pressure Matching System (TPMS)
SP0375	Right rear outer wheel	Tire Pressure Matching System (TPMS)
SP0376	Right rear inner wheel	Tire Pressure Matching System (TPMS)
SP0377	Left rear inner wheel	Tire Pressure Matching System (TPMS)
SP0378	Left rear outer wheel	Tire Pressure Matching System (TPMS)
SP0379	Alarm value setting	Tire Pressure Matching System (TPMS)
SP0380	Read VIN code	Delphi MT22.1 (IAC) engine system
SP0381	Write VIN code	Delphi MT22.1 (IAC) engine system
SP0382	Delphi Broadcasting Code	Delphi MT22.1 (IAC) engine system
SP0383	Vehicle identification code	Delphi MT22.1 (IAC) engine system
SP0384	Repair shop number or tester number	Delphi MT22.1 (IAC) engine system
SP0385	ECU reset	Delphi MT22.1 (IAC) engine system
SP0386	Delphi Broadcasting Code	Delphi MT22.1.1 engine system
SP0387	Vehicle identification code	Delphi MT22.1.1 engine system
SP0388	Repair shop number or tester number	Delphi MT22.1.1 engine system
SP0389	Write VIN code	Delphi Engine System (MT62.1U)
SP0390	Write repair department code or test serial number	Delphi Engine System (MT62.1U)
SP0391	Hardware reset	Delphi Engine System (MT62.1U)
SP0392	Software reset	Delphi Engine System (MT62.1U)
SP0393	Read battery sensor battery ID	Delphi Engine System (MT62.1U)
SP0394	Read the battery sensor serial number	Delphi Engine System (MT62.1U)

SP0395	Read the battery sensor version number	Delphi Engine System (MT62.1U)
SP0396	Write battery sensor battery ID	Delphi Engine System (MT62.1U)
SP0397	Routine control GPF regeneration	Delphi Engine System (MT62.1U)
SP0398	Routine control mileage reset	Delphi Engine System (MT62.1U)
SP0399	Write carbon load quality and GPF ash mileage	Delphi Engine System (MT62.1U)
SP0400	Write VIN code	UMC M781M780
SP0401	ECU power off reset	UMC M781M780
SP0402	Read VIN code	Delphi MT22.3 (ETC) engine system
SP0403	Write VIN code	Delphi MT22.3 (ETC) engine system
SP0404	Delphi Broadcasting Code	Delphi MT22.3 (ETC) engine system
SP0405	Vehicle identification code	Delphi MT22.3 (ETC) engine system
SP0406	Repair shop number or tester number	Delphi MT22.3 (ETC) engine system
SP0407	ECU reset	Delphi MT22.3 (ETC) engine system
SP0408	ECU reset	Bosch EDC17C53 engine
SP0409	Read VIN code	Bosch EDC17C53 engine
SP0410	Write VIN code	Bosch EDC17C53 engine
SP0411	EGR (abandoned recirculation) zero trigger learning	Bosch EDC17C53 engine
SP0412	Clear ZFC learning value	Bosch EDC17C53 engine
SP0413	Injector data flashing	Bosch EDC17C53 engine
SP0414	Read all injector data	Bosch EDC17C53 engine
SP0415	Write all injector data	Bosch EDC17C53 engine
SP0416	Write #1 injector data	Bosch EDC17C53 engine
SP0417	Write #2 injector data	Bosch EDC17C53 engine
SP0418	Write #3 injector data	Bosch EDC17C53 engine
SP0419	Write #4 injector data	Bosch EDC17C53 engine
SP0420	Read VIN code	Bosch EDC17C63 engine
SP0421	Write VIN code	Bosch EDC17C63 engine
SP0422	EGR (abandoned recirculation) zero trigger learning	Bosch EDC17C63 engine
SP0423	Clear ZFC learning value	Bosch EDC17C63 engine
SP0424	Injector data flashing	Bosch EDC17C63 engine
SP0425	Read all injector data	Bosch EDC17C63 engine
SP0426	Write all injector data	Bosch EDC17C63 engine
SP0427	Write #1 injector data	Bosch EDC17C63 engine
SP0428	Write #2 injector data	Bosch EDC17C63 engine
SP0429	Write #3 injector data	Bosch EDC17C63 engine
SP0430	Write #4 injector data	Bosch EDC17C63 engine
SP0431	ECU reset	Bosch EDC17C63 engine
SP0432	Steering angle and yaw rate calibration (ESP only)	Anti-lock brake system/electronic brake stabilization system
SP0433	Automatic exhaust	Anti-lock brake system/electronic brake stabilization system
SP0434	Speed limit	Anti-lock brake system/electronic brake stabilization system
SP0435	ECU reset	Anti-lock brake system/electronic brake stabilization system
SP0436	ECU reset	Universal ABS
SP0437	ECU reset	Airbag system (ABM)
SP0438	Write the last overhaul date of ECU	Airbag system (ABM)
SP0439	Write vehicle chassis number (VIN code)	Airbag system (ABM)
SP0440	Read VIN code	Electronic Power Steering (EPS)
SP0441	Write VIN code	Electronic Power Steering (EPS)
SP0442	Four-wheeled vehicle	Tire Pressure Matching System (TPMS)
SP0443	Six-wheeler	Tire Pressure Matching System (TPMS)
SP0444	Left front wheel	Tire Pressure Matching System (TPMS)
SP0445	Right front wheel	Tire Pressure Matching System (TPMS)
SP0446	Right rear wheel	Tire Pressure Matching System (TPMS)
SP0447	Left rear wheel	Tire Pressure Matching System (TPMS)
SP0448	Left front wheel	Tire Pressure Matching System (TPMS)
SP0449	Right front wheel	Tire Pressure Matching System (TPMS)
SP0450	Right rear outer wheel	Tire Pressure Matching System (TPMS)
SP0451	Right rear inner wheel	Tire Pressure Matching System (TPMS)
SP0452	Left rear inner wheel	Tire Pressure Matching System (TPMS)
SP0453	Left rear outer wheel	Tire Pressure Matching System (TPMS)
SP0454	Left front wheel	Tire Pressure Matching System (TPMS)
SP0455	Right front wheel	Tire Pressure Matching System (TPMS)
SP0456	Right rear wheel	Tire Pressure Matching System (TPMS)
SP0457	Left rear wheel	Tire Pressure Matching System (TPMS)
SP0458	Left front wheel	Tire Pressure Matching System (TPMS)
SP0459	Right front wheel	Tire Pressure Matching System (TPMS)
SP0460	Right rear outer wheel	Tire Pressure Matching System (TPMS)
SP0461	Right rear inner wheel	Tire Pressure Matching System (TPMS)
SP0462	Left rear inner wheel	Tire Pressure Matching System (TPMS)
SP0463	Left rear outer wheel	Tire Pressure Matching System (TPMS)
SP0464	Alarm value setting	Tire Pressure Matching System (TPMS)
SP0465	Read VIN code	Delphi MT22.1 engine system
SP0466	Write VIN code	Delphi MT22.1 engine system
SP0467	Delphi Broadcasting Code	Delphi MT22.1 engine system

SP0468	Vehicle identification code	Delphi MT22.1 engine system
SP0469	Repair shop number or tester number	Delphi MT22.1 engine system
SP0470	ECU reset	Delphi MT22.1 engine system
SP0471	Delphi Broadcasting Code	Delphi MT22.1.1 engine system
SP0472	Vehicle identification code	Delphi MT22.1.1 engine system
SP0473	Repair shop number or tester number	Delphi MT22.1.1 engine system
SP0474	Write VIN code	Delphi Engine System (MT62.1U)
SP0475	Write repair department code or test serial number	Delphi Engine System (MT62.1U)
SP0476	Hardware reset	Delphi Engine System (MT62.1U)
SP0477	Software reset	Delphi Engine System (MT62.1U)
SP0478	Read battery sensor battery ID	Delphi Engine System (MT62.1U)
SP0479	Read the battery sensor serial number	Delphi Engine System (MT62.1U)
SP0480	Read the battery sensor version number	Delphi Engine System (MT62.1U)
SP0481	Write battery sensor battery ID	Delphi Engine System (MT62.1U)
SP0482	Routine control GPF regeneration	Delphi Engine System (MT62.1U)
SP0483	Routine control mileage reset	Delphi Engine System (MT62.1U)
SP0484	Write carbon load quality and GPF ash mileage	Delphi Engine System (MT62.1U)
SP0485	Write VIN code	UMC M781M780
SP0486	ECU power off reset	UMC M781M780
SP0487	Read VIN code	Delphi MT22.3 (ETC) engine system
SP0488	Write VIN code	Delphi MT22.3 (ETC) engine system
SP0489	Delphi Broadcasting Code	Delphi MT22.3 (ETC) engine system
SP0490	Vehicle identification code	Delphi MT22.3 (ETC) engine system
SP0491	Repair shop number or tester number	Delphi MT22.3 (ETC) engine system
SP0492	ECU reset	Delphi MT22.3 (ETC) engine system
SP0493	Steering angle and yaw rate calibration (ESP only)	Electronic Brake Stability System (ESP)
SP0494	Automatic exhaust	Electronic Brake Stability System (ESP)
SP0495	Speed limit	Electronic Brake Stability System (ESP)
SP0496	ECU reset	Electronic Brake Stability System (ESP)
SP0497	Read VIN code	Electronic Power Steering (EPS)
SP0498	Write VIN code	Electronic Power Steering (EPS)
SP0499	Four-wheeler vehicle	Tire Pressure Matching System (TPMS)
SP0500	Six-wheeler	Tire Pressure Matching System (TPMS)
SP0501	Left front wheel	Tire Pressure Matching System (TPMS)
SP0502	Right front wheel	Tire Pressure Matching System (TPMS)
SP0503	Right rear wheel	Tire Pressure Matching System (TPMS)
SP0504	Left rear wheel	Tire Pressure Matching System (TPMS)
SP0505	Left front wheel	Tire Pressure Matching System (TPMS)
SP0506	Right front wheel	Tire Pressure Matching System (TPMS)
SP0507	Right rear outer wheel	Tire Pressure Matching System (TPMS)
SP0508	Right rear inner wheel	Tire Pressure Matching System (TPMS)
SP0509	Left rear inner wheel	Tire Pressure Matching System (TPMS)
SP0510	Left rear outer wheel	Tire Pressure Matching System (TPMS)
SP0511	Left front wheel	Tire Pressure Matching System (TPMS)
SP0512	Right front wheel	Tire Pressure Matching System (TPMS)
SP0513	Right rear wheel	Tire Pressure Matching System (TPMS)
SP0514	Left rear wheel	Tire Pressure Matching System (TPMS)
SP0515	Left front wheel	Tire Pressure Matching System (TPMS)
SP0516	Right front wheel	Tire Pressure Matching System (TPMS)
SP0517	Right rear outer wheel	Tire Pressure Matching System (TPMS)
SP0518	Right rear inner wheel	Tire Pressure Matching System (TPMS)
SP0519	Left rear inner wheel	Tire Pressure Matching System (TPMS)
SP0520	Left rear outer wheel	Tire Pressure Matching System (TPMS)
SP0521	Alarm value setting	Tire Pressure Matching System (TPMS)
SP0522	Read VIN code	Delphi MT22.1 (IAC) engine system
SP0523	Write VIN code	Delphi MT22.1 (IAC) engine system
SP0524	Delphi Broadcasting Code	Delphi MT22.1 (IAC) engine system
SP0525	Vehicle identification code	Delphi MT22.1 (IAC) engine system
SP0526	Repair shop number or tester number	Delphi MT22.1 (IAC) engine system
SP0527	ECU reset	Delphi MT22.1 (IAC) engine system
SP0528	Delphi Broadcasting Code	Delphi MT22.1.1 engine system
SP0529	Vehicle identification code	Delphi MT22.1.1 engine system
SP0530	Repair shop number or tester number	Delphi MT22.1.1 engine system
SP0531	Write VIN code	Delphi Engine System (MT62.1U)
SP0532	Write repair department code or test serial number	Delphi Engine System (MT62.1U)
SP0533	Hardware reset	Delphi Engine System (MT62.1U)

SP0534	Software reset	Delphi Engine System (MT62.1U)
SP0535	Read battery sensor battery ID	Delphi Engine System (MT62.1U)
SP0536	Read the battery sensor serial number	Delphi Engine System (MT62.1U)
SP0537	Read the battery sensor version number	Delphi Engine System (MT62.1U)
SP0538	Write battery sensor battery ID	Delphi Engine System (MT62.1U)
SP0539	Routine control GPF regeneration	Delphi Engine System (MT62.1U)
SP0540	Routine control mileage reset	Delphi Engine System (MT62.1U)
SP0541	Write carbon load quality and GPF ash mileage	Delphi Engine System (MT62.1U)
SP0542	Write VIN code	UMC M781M780
SP0543	ECU power off reset	UMC M781M780
SP0544	Read VIN code	Delphi MT22.3 (ETC) engine system
SP0545	Write VIN code	Delphi MT22.3 (ETC) engine system
SP0546	Delphi Broadcasting Code	Delphi MT22.3 (ETC) engine system
SP0547	Vehicle identification code	Delphi MT22.3 (ETC) engine system
SP0548	Repair shop number or tester number	Delphi MT22.3 (ETC) engine system
SP0549	ECU reset	Delphi MT22.3 (ETC) engine system
SP0550	Steering angle and yaw rate calibration (ESP only)	Electronic Brake Stability System (ESP)
SP0551	Automatic exhaust	Electronic Brake Stability System (ESP)
SP0552	Speed limit	Electronic Brake Stability System (ESP)
SP0553	ECU reset	Electronic Brake Stability System (ESP)
SP0554	Read VIN code	Electronic Power Steering (EPS)
SP0555	Write VIN code	Electronic Power Steering (EPS)
SP0556	Four-wheeled vehicle	Tire Pressure Matching System (TPMS)
SP0557	Six-wheeler	Tire Pressure Matching System (TPMS)
SP0558	Left front wheel	Tire Pressure Matching System (TPMS)
SP0559	Right front wheel	Tire Pressure Matching System (TPMS)
SP0560	Right rear wheel	Tire Pressure Matching System (TPMS)
SP0561	Left rear wheel	Tire Pressure Matching System (TPMS)
SP0562	Left front wheel	Tire Pressure Matching System (TPMS)
SP0563	Right front wheel	Tire Pressure Matching System (TPMS)
SP0564	Right rear outer wheel	Tire Pressure Matching System (TPMS)
SP0565	Right rear inner wheel	Tire Pressure Matching System (TPMS)
SP0566	Left rear inner wheel	Tire Pressure Matching System (TPMS)
SP0567	Left rear outer wheel	Tire Pressure Matching System (TPMS)
SP0568	Left front wheel	Tire Pressure Matching System (TPMS)
SP0569	Right front wheel	Tire Pressure Matching System (TPMS)
SP0570	Right rear wheel	Tire Pressure Matching System (TPMS)
SP0571	Left rear wheel	Tire Pressure Matching System (TPMS)
SP0572	Left front wheel	Tire Pressure Matching System (TPMS)
SP0573	Right front wheel	Tire Pressure Matching System (TPMS)
SP0574	Right rear outer wheel	Tire Pressure Matching System (TPMS)
SP0575	Right rear inner wheel	Tire Pressure Matching System (TPMS)
SP0576	Left rear inner wheel	Tire Pressure Matching System (TPMS)
SP0577	Left rear outer wheel	Tire Pressure Matching System (TPMS)
SP0578	Alarm value setting	Tire Pressure Matching System (TPMS)
SP0579	Read VIN code	Delphi MT22.1 (IAC) engine system
SP0580	Write VIN code	Delphi MT22.1 (IAC) engine system
SP0581	Delphi Broadcasting Code	Delphi MT22.1 (IAC) engine system
SP0582	Vehicle identification code	Delphi MT22.1 (IAC) engine system
SP0583	Repair shop number or tester number	Delphi MT22.1 (IAC) engine system
SP0584	ECU reset	Delphi MT22.1 (IAC) engine system
SP0585	Delphi Broadcasting Code	Delphi MT22.1.1 engine system
SP0586	Vehicle identification code	Delphi MT22.1.1 engine system
SP0587	Repair shop number or tester number	Delphi MT22.1.1 engine system
SP0588	Write VIN code	UMC M781M780
SP0589	ECU power off reset	UMC M781M780
SP0590	Read VIN code	Delphi MT22.3 (ETC) engine system
SP0591	Write VIN code	Delphi MT22.3 (ETC) engine system
SP0592	Delphi Broadcasting Code	Delphi MT22.3 (ETC) engine system
SP0593	Vehicle identification code	Delphi MT22.3 (ETC) engine system
SP0594	Repair shop number or tester number	Delphi MT22.3 (ETC) engine system
SP0595	ECU reset	Delphi MT22.3 (ETC) engine system
SP0596	Write VIN code	Rvoden Engine System
SP0597	Hardware reset	Rvoden Engine System
SP0598	Steering angle and yaw rate calibration (ESP only)	Anti-lock brake system/Electronic Stability System (ESP)
SP0599	Automatic exhaust	Anti-lock brake system/Electronic Stability System (ESP)
SP0600	Speed limit	Anti-lock brake system/Electronic Stability System (ESP)

SP0601	ECU reset	Anti-lock brake system/Electronic Stability System (ESP)
SP0602	ECU reset	Universal ABS
SP0603	ECU reset	Bosch Airbag System
SP0604	Write the last overhaul date of ECU	Bosch Airbag System
SP0605	Write vehicle chassis number (VIN code)	Bosch Airbag System
SP0606	ECU reset	Takata Airbag System
SP0607	Offline detection	Takata Airbag System
SP0608	Read VIN code	Electronic Power Steering (EPS)
SP0609	Write VIN code	Electronic Power Steering (EPS)
SP0610	Read VIN code	Delphi MT22.1 (IAC) engine system
SP0611	Write VIN code	Delphi MT22.1 (IAC) engine system
SP0612	Delphi Broadcasting Code	Delphi MT22.1 (IAC) engine system
SP0613	Vehicle identification code	Delphi MT22.1 (IAC) engine system
SP0614	Repair shop number or tester number	Delphi MT22.1 (IAC) engine system
SP0615	ECU reset	Delphi MT22.1 (IAC) engine system
SP0616	Delphi Broadcasting Code	Delphi MT22.1.1 engine system
SP0617	Vehicle identification code	Delphi MT22.1.1 engine system
SP0618	Repair shop number or tester number	Delphi MT22.1.1 engine system
SP0619	Write VIN code	UMC M781M780
SP0620	ECU power off reset	UMC M781M780
SP0621	Read VIN code	Delphi MT22.3 (ETC) engine system
SP0622	Write VIN code	Delphi MT22.3 (ETC) engine system
SP0623	Delphi Broadcasting Code	Delphi MT22.3 (ETC) engine system
SP0624	Vehicle identification code	Delphi MT22.3 (ETC) engine system
SP0625	Repair shop number or tester number	Delphi MT22.3 (ETC) engine system
SP0626	ECU reset	Delphi MT22.3 (ETC) engine system
SP0627	Write VIN code	Rvoden Engine System
SP0628	Hardware reset	Rvoden Engine System
SP0629	Steering angle and yaw rate calibration (ESP only)	Anti-lock brake system/Electronic Stability System (ESP)
SP0630	Automatic exhaust	Anti-lock brake system/Electronic Stability System (ESP)
SP0631	Speed limit	Anti-lock brake system/Electronic Stability System (ESP)
SP0632	ECU reset	Anti-lock brake system/Electronic Stability System (ESP)
SP0633	ECU reset	Universal ABS
SP0634	ECU reset	Bosch Airbag System
SP0635	Write the last overhaul date of ECU	Bosch Airbag System
SP0636	Write vehicle chassis number (VIN code)	Bosch Airbag System
SP0637	ECU reset	Takata Airbag System
SP0638	Offline detection	Takata Airbag System
SP0639	Read VIN code	Electronic Power Steering (EPS)
SP0640	Write VIN code	Electronic Power Steering (EPS)
SP0641	Read VIN code	Delphi MT22.1 (IAC) engine system
SP0642	Write VIN code	Delphi MT22.1 (IAC) engine system
SP0643	Delphi Broadcasting Code	Delphi MT22.1 (IAC) engine system
SP0644	Vehicle identification code	Delphi MT22.1 (IAC) engine system
SP0645	Repair shop number or tester number	Delphi MT22.1 (IAC) engine system
SP0646	ECU reset	Delphi MT22.1 (IAC) engine system
SP0647	Delphi Broadcasting Code	Delphi MT22.1.1 engine system
SP0648	Vehicle identification code	Delphi MT22.1.1 engine system
SP0649	Repair shop number or tester number	Delphi MT22.1.1 engine system
SP0650	Write VIN code	UMC M781M780
SP0651	ECU power off reset	UMC M781M780
SP0652	Read VIN code	Delphi MT22.3 (ETC) engine system
SP0653	Write VIN code	Delphi MT22.3 (ETC) engine system
SP0654	Delphi Broadcasting Code	Delphi MT22.3 (ETC) engine system
SP0655	Vehicle identification code	Delphi MT22.3 (ETC) engine system
SP0656	Repair shop number or tester number	Delphi MT22.3 (ETC) engine system
SP0657	ECU reset	Delphi MT22.3 (ETC) engine system
SP0658	Write VIN code	Rvoden Engine System
SP0659	Hardware reset	Rvoden Engine System
SP0660	Steering angle and yaw rate calibration (ESP only)	Anti-lock brake system/Electronic Stability System (ESP)
SP0661	Automatic exhaust	Anti-lock brake system/Electronic Stability System (ESP)
SP0662	Speed limit	Anti-lock brake system/Electronic Stability System (ESP)
SP0663	ECU reset	Anti-lock brake system/Electronic Stability System (ESP)
SP0664	ECU reset	Universal ABS

SP0665	ECU reset	Bosch Airbag System
SP0666	Write the last overhaul date of ECU	Bosch Airbag System
SP0667	Write vehicle chassis number (VIN code)	Bosch Airbag System
SP0668	ECU reset	Takata Airbag System
SP0669	Offline detection	Takata Airbag System
SP0670	Read VIN code	Electronic Power Steering (EPS)
SP0671	Write VIN code	Electronic Power Steering (EPS)
SP0672	Four-wheeled vehicle	Tire Pressure Matching System (TPMS)
SP0673	Six-wheeler	Tire Pressure Matching System (TPMS)
SP0674	Left front wheel	Tire Pressure Matching System (TPMS)
SP0675	Right front wheel	Tire Pressure Matching System (TPMS)
SP0676	Right rear wheel	Tire Pressure Matching System (TPMS)
SP0677	Left rear wheel	Tire Pressure Matching System (TPMS)
SP0678	Left front wheel	Tire Pressure Matching System (TPMS)
SP0679	Right front wheel	Tire Pressure Matching System (TPMS)
SP0680	Right rear outer wheel	Tire Pressure Matching System (TPMS)
SP0681	Right rear inner wheel	Tire Pressure Matching System (TPMS)
SP0682	Left rear inner wheel	Tire Pressure Matching System (TPMS)
SP0683	Left rear outer wheel	Tire Pressure Matching System (TPMS)
SP0684	Left front wheel	Tire Pressure Matching System (TPMS)
SP0685	Right front wheel	Tire Pressure Matching System (TPMS)
SP0686	Right rear wheel	Tire Pressure Matching System (TPMS)
SP0687	Left rear wheel	Tire Pressure Matching System (TPMS)
SP0688	Left front wheel	Tire Pressure Matching System (TPMS)
SP0689	Right front wheel	Tire Pressure Matching System (TPMS)
SP0690	Right rear outer wheel	Tire Pressure Matching System (TPMS)
SP0691	Right rear inner wheel	Tire Pressure Matching System (TPMS)
SP0692	Left rear inner wheel	Tire Pressure Matching System (TPMS)
SP0693	Left rear outer wheel	Tire Pressure Matching System (TPMS)
SP0694	Alarm value setting	Tire Pressure Matching System (TPMS)
SP0695	Read VIN code	Delphi MT22.1 (IAC) engine system
SP0696	Write VIN code	Delphi MT22.1 (IAC) engine system
SP0697	Delphi Broadcasting Code	Delphi MT22.1 (IAC) engine system
SP0698	Vehicle identification code	Delphi MT22.1 (IAC) engine system
SP0699	Repair shop number or tester number	Delphi MT22.1 (IAC) engine system
SP0700	ECU reset	Delphi MT22.1 (IAC) engine system
SP0701	Delphi Broadcasting Code	Delphi MT22.1.1 engine system
SP0702	Vehicle identification code	Delphi MT22.1.1 engine system
SP0703	Repair shop number or tester number	Delphi MT22.1.1 engine system
SP0704	Write VIN code	UMC M781M780
SP0705	ECU power off reset	UMC M781M780
SP0706	Read VIN code	Delphi MT22.3 (ETC) engine system
SP0707	Write VIN code	Delphi MT22.3 (ETC) engine system
SP0708	Delphi Broadcasting Code	Delphi MT22.3 (ETC) engine system
SP0709	Vehicle identification code	Delphi MT22.3 (ETC) engine system
SP0710	Repair shop number or tester number	Delphi MT22.3 (ETC) engine system
SP0711	ECU reset	Delphi MT22.3 (ETC) engine system
SP0712	Write VIN code	Ryoden Engine System
SP0713	Hardware reset	Ryoden Engine System
SP0714	ECU reset	Universal ABS
SP0715	Read VIN code	Electronic Power Steering (EPS)
SP0716	Write VIN code	Electronic Power Steering (EPS)
SP0717	Four-wheeled vehicle	Tire Pressure Matching System (TPMS)
SP0718	Six-wheeler	Tire Pressure Matching System (TPMS)
SP0719	Left front wheel	Tire Pressure Matching System (TPMS)
SP0720	Right front wheel	Tire Pressure Matching System (TPMS)
SP0721	Right rear wheel	Tire Pressure Matching System (TPMS)
SP0722	Left rear wheel	Tire Pressure Matching System (TPMS)
SP0723	Left front wheel	Tire Pressure Matching System (TPMS)
SP0724	Right front wheel	Tire Pressure Matching System (TPMS)
SP0725	Right rear outer wheel	Tire Pressure Matching System (TPMS)
SP0726	Right rear inner wheel	Tire Pressure Matching System (TPMS)
SP0727	Left rear inner wheel	Tire Pressure Matching System (TPMS)
SP0728	Left rear outer wheel	Tire Pressure Matching System (TPMS)
SP0729	Left front wheel	Tire Pressure Matching System (TPMS)
SP0730	Right front wheel	Tire Pressure Matching System (TPMS)
SP0731	Right rear wheel	Tire Pressure Matching System (TPMS)
SP0732	Left rear wheel	Tire Pressure Matching System (TPMS)
SP0733	Left front wheel	Tire Pressure Matching System (TPMS)
SP0734	Right front wheel	Tire Pressure Matching System (TPMS)
SP0735	Right rear outer wheel	Tire Pressure Matching System (TPMS)
SP0736	Right rear inner wheel	Tire Pressure Matching System (TPMS)
SP0737	Left rear inner wheel	Tire Pressure Matching System (TPMS)
SP0738	Left rear outer wheel	Tire Pressure Matching System (TPMS)
SP0739	Alarm value setting	Tire Pressure Matching System (TPMS)
SP0740	Read VIN code	Delphi MT22.1 (IAC) engine system
SP0741	Write VIN code	Delphi MT22.1 (IAC) engine system
SP0742	Delphi Broadcasting Code	Delphi MT22.1 (IAC) engine system
SP0743	Vehicle identification code	Delphi MT22.1 (IAC) engine system
SP0744	Repair shop number or tester number	Delphi MT22.1 (IAC) engine system
SP0745	ECU reset	Delphi MT22.1 (IAC) engine system

SP0746	Delphi Broadcasting Code	Delphi MT22.1.1 engine system
SP0747	Vehicle identification code	Delphi MT22.1.1 engine system
SP0748	Repair shop number or tester number	Delphi MT22.1.1 engine system
SP0749	Write VIN code	UMC M781M780
SP0750	ECU power off reset	UMC M781M780
SP0751	Read VIN code	Delphi MT22.3 (ETC) engine system
SP0752	Write VIN code	Delphi MT22.3 (ETC) engine system
SP0753	Delphi Broadcasting Code	Delphi MT22.3 (ETC) engine system
SP0754	Vehicle identification code	Delphi MT22.3 (ETC) engine system
SP0755	Repair shop number or tester number	Delphi MT22.3 (ETC) engine system
SP0756	ECU reset	Delphi MT22.3 (ETC) engine system
SP0757	Write VIN code	Rvoden Engine System
SP0758	Hardware reset	Rvoden Engine System
SP0759	Steering angle and yaw rate calibration (ESP only)	Anti-lock brake system/Electronic Stability System (ESP)
SP0760	Automatic exhaust	Anti-lock brake system/Electronic Stability System (ESP)
SP0761	Speed limit	Anti-lock brake system/Electronic Stability System (ESP)
SP0762	ECU reset	Anti-lock brake system/Electronic Stability System (ESP)
SP0763	ECU reset	Universal ABS
SP0764	ECU reset	Bosch Airbag System
SP0765	Write the last overhaul date of ECU	Bosch Airbag System
SP0766	Write vehicle chassis number (VIN code)	Bosch Airbag System
SP0767	ECU reset	Takata Airbag System
SP0768	Offline detection	Takata Airbag System
SP0769	Read VIN code	Electronic Power Steering (EPS)
SP0770	Write VIN code	Electronic Power Steering (EPS)
SP0771	Four-wheeled vehicle	Tire Pressure Matching System (TPMS)
SP0772	Six-wheeler	Tire Pressure Matching System (TPMS)
SP0773	Left front wheel	Tire Pressure Matching System (TPMS)
SP0774	Right front wheel	Tire Pressure Matching System (TPMS)
SP0775	Right rear wheel	Tire Pressure Matching System (TPMS)
SP0776	Left rear wheel	Tire Pressure Matching System (TPMS)
SP0777	Left front wheel	Tire Pressure Matching System (TPMS)
SP0778	Right front wheel	Tire Pressure Matching System (TPMS)
SP0779	Right rear outer wheel	Tire Pressure Matching System (TPMS)
SP0780	Right rear inner wheel	Tire Pressure Matching System (TPMS)
SP0781	Left rear inner wheel	Tire Pressure Matching System (TPMS)
SP0782	Left rear outer wheel	Tire Pressure Matching System (TPMS)
SP0783	Left front wheel	Tire Pressure Matching System (TPMS)
SP0784	Right front wheel	Tire Pressure Matching System (TPMS)
SP0785	Right rear wheel	Tire Pressure Matching System (TPMS)
SP0786	Left rear wheel	Tire Pressure Matching System (TPMS)
SP0787	Left front wheel	Tire Pressure Matching System (TPMS)
SP0788	Right front wheel	Tire Pressure Matching System (TPMS)
SP0789	Right rear outer wheel	Tire Pressure Matching System (TPMS)
SP0790	Right rear inner wheel	Tire Pressure Matching System (TPMS)
SP0791	Left rear inner wheel	Tire Pressure Matching System (TPMS)
SP0792	Left rear outer wheel	Tire Pressure Matching System (TPMS)
SP0793	Alarm value setting	Tire Pressure Matching System (TPMS)
SP0794	Read VIN code	Delphi MT22.1 (IAC) engine system
SP0795	Write VIN code	Delphi MT22.1 (IAC) engine system
SP0796	Delphi Broadcasting Code	Delphi MT22.1 (IAC) engine system
SP0797	Vehicle identification code	Delphi MT22.1 (IAC) engine system
SP0798	Repair shop number or tester number	Delphi MT22.1 (IAC) engine system
SP0799	ECU reset	Delphi MT22.1 (IAC) engine system
SP0800	Delphi Broadcasting Code	Delphi MT22.1.1 engine system
SP0801	Vehicle identification code	Delphi MT22.1.1 engine system
SP0802	Repair shop number or tester number	Delphi MT22.1.1 engine system
SP0803	Write VIN code	UMC M781M780
SP0804	ECU power off reset	UMC M781M780
SP0805	Read VIN code	Delphi MT22.3 (ETC) engine system
SP0806	Write VIN code	Delphi MT22.3 (ETC) engine system
SP0807	Delphi Broadcasting Code	Delphi MT22.3 (ETC) engine system
SP0808	Vehicle identification code	Delphi MT22.3 (ETC) engine system
SP0809	Repair shop number or tester number	Delphi MT22.3 (ETC) engine system
SP0810	ECU reset	Delphi MT22.3 (ETC) engine system
SP0811	Steering angle and yaw rate calibration (ESP only)	Anti-lock brake system/Electronic Stability System (ESP)
SP0812	Automatic exhaust	Anti-lock brake system/Electronic Stability System (ESP)
SP0813	Speed limit	Anti-lock brake system/Electronic Stability System (ESP)
SP0814	ECU reset	Anti-lock brake system/Electronic Stability System (ESP)

SP0815	ECU reset	Universal ABS
SP0816	ECU reset	Airbag system (ABM)
SP0817	Write the last overhaul date of ECU	Airbag system (ABM)
SP0818	Write vehicle chassis number (VIN code)	Airbag system (ABM)
SP0819	Read VIN code	Electronic Power Steering (EPS)
SP0820	Write VIN code	Electronic Power Steering (EPS)
SP0821	Steering angle and yaw rate calibration (ESP only)	Anti-lock brake system (ESP/ABS)/electronic stability system (ESP)
SP0822	Automatic exhaust	Anti-lock brake system (ESP/ABS)/electronic stability system (ESP)
SP0823	Speed limit	Anti-lock brake system (ESP/ABS)/electronic stability system (ESP)
SP0824	ECU reset	Anti-lock brake system (ESP/ABS)/electronic stability system (ESP)
SP0825	ECU reset	Anti-lock brake system (ESP/ABS)/Universal anti-lock brake (ABS)
SP0826	Steering angle and yaw rate calibration (ESP only)	Anti-lock brake system (ESP/ABS)/electronic stability system (ESP)
SP0827	Automatic exhaust	Anti-lock brake system (ESP/ABS)/electronic stability system (ESP)
SP0828	Speed limit	Anti-lock brake system (ESP/ABS)/electronic stability system (ESP)
SP0829	ECU reset	Anti-lock brake system (ESP/ABS)/electronic stability system (ESP)
SP0830	ECU reset	Anti-lock brake system (ESP/ABS)/Universal anti-lock brake (ABS)
SP0831	Steering angle and yaw rate calibration (ESP only)	Universal Anti-lock Brake (ESP/ABS)/Electronic Stability System (ESP)
SP0832	Automatic exhaust	Universal Anti-lock Brake (ESP/ABS)/Electronic Stability System (ESP)
SP0833	Speed limit	Universal Anti-lock Brake (ESP/ABS)/Electronic Stability System (ESP)
SP0834	ECU reset	Universal Anti-lock Brake (ESP/ABS)/Electronic Stability System (ESP)
SP0835	ECU reset	Universal Anti-lock Brake (ESP/ABS)/Universal Anti-lock Brake (ABS)
SP0836	Steering angle and yaw rate calibration (ESP only)	Anti-lock brake system (ESP/ABS)/electronic stability system (ESP)
SP0837	Automatic exhaust	Anti-lock brake system (ESP/ABS)/electronic stability system (ESP)
SP0838	Speed limit	Anti-lock brake system (ESP/ABS)/electronic stability system (ESP)
SP0839	ECU reset	Anti-lock brake system (ESP/ABS)/electronic stability system (ESP)
SP0840	ECU reset	Anti-lock brake system (ESP/ABS)/Universal anti-lock brake (ABS)
SP0841	Write VIN code	Vehicle Controller (VCU)
SP0842	Write motor number	Vehicle Controller (VCU)
SP0843	Steering angle and yaw rate calibration (ESP only)	Anti-lock brake system/electronic brake stabilization system
SP0844	Automatic exhaust	Anti-lock brake system/electronic brake stabilization system
SP0845	Speed limit	Anti-lock brake system/electronic brake stabilization system
SP0846	ECU reset	Anti-lock brake system/electronic brake stabilization system
SP0847	ECU reset	Universal ABS
SP0848	Write the last overhaul date of ECU	Airbag System (SRS)
SP0849	Write vehicle chassis number (VIN code)	Airbag System (SRS)
SP0850	ECU reset	Airbag System (SRS)
SP0851	Read VIN code	Electronic Power Steering (EPS)
SP0852	Write VIN code	Electronic Power Steering (EPS)
SP0853	Four-wheeled vehicle	Tire Pressure Matching System (TPMS)
SP0854	Six-wheeler	Tire Pressure Matching System (TPMS)
SP0855	Left front wheel	Tire Pressure Matching System (TPMS)
SP0856	Right front wheel	Tire Pressure Matching System (TPMS)
SP0857	Right rear wheel	Tire Pressure Matching System (TPMS)
SP0858	Left rear wheel	Tire Pressure Matching System (TPMS)
SP0859	Left front wheel	Tire Pressure Matching System (TPMS)
SP0860	Right front wheel	Tire Pressure Matching System (TPMS)
SP0861	Right rear outer wheel	Tire Pressure Matching System (TPMS)
SP0862	Right rear inner wheel	Tire Pressure Matching System (TPMS)
SP0863	Left rear inner wheel	Tire Pressure Matching System (TPMS)

SP0864	Left rear outer wheel	Tire Pressure Matching System (TPMS)
SP0865	Left front wheel	Tire Pressure Matching System (TPMS)
SP0866	Right front wheel	Tire Pressure Matching System (TPMS)
SP0867	Right rear wheel	Tire Pressure Matching System (TPMS)
SP0868	Left rear wheel	Tire Pressure Matching System (TPMS)
SP0869	Left front wheel	Tire Pressure Matching System (TPMS)
SP0870	Right front wheel	Tire Pressure Matching System (TPMS)
SP0871	Right rear outer wheel	Tire Pressure Matching System (TPMS)
SP0872	Right rear inner wheel	Tire Pressure Matching System (TPMS)
SP0873	Left rear inner wheel	Tire Pressure Matching System (TPMS)
SP0874	Left rear outer wheel	Tire Pressure Matching System (TPMS)
SP0875	Alarm value setting	Tire Pressure Matching System (TPMS)
SP0876	Steering angle and yaw rate calibration (ESP only)	Anti-lock brake system (ESP/ABS)/electronic stability system (ESP)
SP0877	Automatic exhaust	Anti-lock brake system (ESP/ABS)/electronic stability system (ESP)
SP0878	Speed limit	Anti-lock brake system (ESP/ABS)/electronic stability system (ESP)
SP0879	ECU reset	Anti-lock brake system (ESP/ABS)/electronic stability system (ESP)
SP0880	ECU reset	Anti-lock brake system (ESP/ABS)/Universal anti-lock brake (ABS)
SP0881	Write VIN code	Engine Management System (EMS)
SP0882	Hardware reset	Engine Management System (EMS)
SP0883	Variable valve timing learning	Engine Management System (EMS)
SP0884	Reset particle load and accumulating ash load	Engine Management System (EMS)
SP0885	Reset GPF differential pressure learning value	Engine Management System (EMS)
SP0886	GPF regeneration test mode	Engine Management System (EMS)
SP0887	New ECU write particle load	Engine Management System (EMS)
SP0888	New ECU write cumulative gray load	Engine Management System (EMS)
SP0889	The new ECU writes the self-learning value of the differential pressure sensor	Engine Management System (EMS)
SP0890	Read software label	Engine Management System (EMS)
SP0891	Read (battery) ECU serial number	Engine Management System (EMS)
SP0892	Read battery code	Engine Management System (EMS)
SP0893	Write battery code	Engine Management System (EMS)
SP0894	Off-line test of fuel vapor leakage (DTESK diagnosis)	Engine Management System (EMS)
SP0895	Write VIN code	Body Control Module (BCM)
SP0896	Automatically write configuration information	Body Control Module (BCM)
SP0897	Manually write vehicle electrical configuration	Body Control Module (BCM)
SP0898	Write antenna threshold	Body Control Module (BCM)
SP0899	Write tire pressure sensor ID	Body Control Module (BCM)
SP0900	Write tire pressure alarm threshold	Body Control Module (BCM)
SP0901	Hardware reset	Body Control Module (BCM)
SP0902	Learn tire pressure sensor	Body Control Module (BCM)
SP0903	Tire swap	Body Control Module (BCM)
SP0904	Antenna self-test	Body Control Module (BCM)
SP0905	Engineering mode	Body Control Module (BCM)
SP0906	Write VIN code	Airbag Controller (ABM)
SP0907	Automatically write configuration information	Airbag Controller (ABM)
SP0908	Manually write vehicle electrical configuration	Airbag Controller (ABM)
SP0909	Write to activate the ignition mode	Airbag Controller (ABM)
SP0910	Write airbag configuration	Airbag Controller (ABM)
SP0911	Hardware reset	Airbag Controller (ABM)
SP0912	Software reset	Airbag Controller (ABM)
SP0913	Engineering mode	Airbag Controller (ABM)
SP0914	Write VIN code	Electronic Stability System (ABS/ESP)
SP0915	Manually write configuration information	Electronic Stability System (ABS/ESP)
SP0916	Automatically write configuration information	Electronic Stability System (ABS/ESP)
SP0917	Write hydraulic filling status	Electronic Stability System (ABS/ESP)
SP0918	Write offline detection status	Electronic Stability System (ABS/ESP)

SP0919	Manually write gearbox information	Electronic Stability System (ABS/ESP)
SP0920	Automatically write gearbox information	Electronic Stability System (ABS/ESP)
SP0921	Hardware reset	Electronic Stability System (ABS/ESP)
SP0922	Software reset	Electronic Stability System (ABS/ESP)
SP0923	Artificial exhaust	Electronic Stability System (ABS/ESP)
SP0924	Speed limit enable/disable	Electronic Stability System (ABS/ESP)
SP0925	Valve relay closed	Electronic Stability System (ABS/ESP)
SP0926	Wheel speed sensor test	Electronic Stability System (ABS/ESP)
SP0927	Inertial sensor calibration (ESP only)	Electronic Stability System (ABS/ESP)
SP0928	Engineering mode	Electronic Stability System (ABS/ESP)
SP0929	Write VIN code	Electronic Power Steering (EPS)
SP0930	Manually write configuration information	Electronic Power Steering (EPS)
SP0931	Automatically write configuration information	Electronic Power Steering (EPS)
SP0932	Hardware reset	Electronic Power Steering (EPS)
SP0933	Software reset	Electronic Power Steering (EPS)
SP0934	Steering angle calibration	Electronic Power Steering (EPS)
SP0935	Erase steering angle calibration	Electronic Power Steering (EPS)
SP0936	Erase soft limit	Electronic Power Steering (EPS)
SP0937	Engineering mode	Electronic Power Steering (EPS)
SP0938	Manually write configuration information	Electronic Parking Controller (EPB)
SP0939	Automatically write configuration information	Electronic Parking Controller (EPB)
SP0940	Hardware reset	Electronic Parking Controller (EPB)
SP0941	Maintenance open	Electronic Parking Controller (EPB)
SP0942	Maintenance shutdown	Electronic Parking Controller (EPB)
SP0943	Assembly inspection	Electronic Parking Controller (EPB)
SP0944	Clamping of actuators on both sides	Electronic Parking Controller (EPB)
SP0945	Release of the actuators on both sides	Electronic Parking Controller (EPB)
SP0946	Clamping of left actuator	Electronic Parking Controller (EPB)
SP0947	Clamping by the right actuator	Electronic Parking Controller (EPB)
SP0948	Left side actuator release	Electronic Parking Controller (EPB)
SP0949	Right side actuator release	Electronic Parking Controller (EPB)
SP0950	Engineering mode	Electronic Parking Controller (EPB)
SP0951	data input	Electronic steering column lock (ESCL)
SP0952	Write VIN code	Electronic steering column lock (ESCL)
SP0953	Hardware reset	Electronic steering column lock (ESCL)
SP0954	Engineering mode	Electronic steering column lock (ESCL)
SP0955	Write VIN code	Instrument (IC)
SP0956	Manually write configuration information	Instrument (IC)
SP0957	Automatically write configuration information	Instrument (IC)
SP0958	Write maintenance mileage	Instrument (IC)
SP0959	Hardware reset	Instrument (IC)
SP0960	Software reset	Instrument (IC)
SP0961	Engineering mode	Instrument (IC)
SP0962	Write VIN code	Infotainment System (IVI)
SP0963	Write work mode	Infotainment System (IVI)
SP0964	Write TBOX PDID number	Infotainment System (IVI)
SP0965	Has the BOX successfully logged in to the background and successfully downloaded the digital certificate?	Infotainment System (IVI)
SP0966	Manually write configuration information	Infotainment System (IVI)
SP0967	Automatically write configuration information	Infotainment System (IVI)
SP0968	Hardware reset	Infotainment System (IVI)
SP0969	Software reset	Infotainment System (IVI)
SP0970	Hardware reset	Electric tailgate controller (PLG)
SP0971	Software reset	Electric tailgate controller (PLG)
SP0972	Engineering mode	Electric tailgate controller (PLG)
SP0973	Manually write configuration information	Seat Controller (DSM)
SP0974	Automatically write configuration information	Seat Controller (DSM)
SP0975	Hardware reset	Seat Controller (DSM)
SP0976	Software reset	Seat Controller (DSM)
SP0977	Engineering mode	Seat Controller (DSM)

SP0978	Hardware reset	Wireless charging (WCM)
SP0979	Software reset	Wireless charging (WCM)
SP0980	Engineering mode	Wireless charging (WCM)
SP0981	Write VIN code	Short-range millimeter wave radar 1 (SRR_R1)
SP0982	Manually write configuration information	Short-range millimeter wave radar 1 (SRR_R1)
SP0983	Automatically write configuration information	Short-range millimeter wave radar 1 (SRR_R1)
SP0984	Hardware reset	Short-range millimeter wave radar 1 (SRR_R1)
SP0985	Software reset	Short-range millimeter wave radar 1 (SRR_R1)
SP0986	Offline calibration	Short-range millimeter wave radar 1 (SRR_R1)
SP0987	Engineering mode	Short-range millimeter wave radar 1 (SRR_R1)
SP0988	Write VIN code	Short-range millimeter wave radar 2 (SRR_R2)
SP0989	Manually write configuration information	Short-range millimeter wave radar 2 (SRR_R2)
SP0990	Automatically write configuration information	Short-range millimeter wave radar 2 (SRR_R2)
SP0991	Hardware reset	Short-range millimeter wave radar 2 (SRR_R2)
SP0992	Software reset	Short-range millimeter wave radar 2 (SRR_R2)
SP0993	Offline calibration	Short-range millimeter wave radar 2 (SRR_R2)
SP0994	Engineering mode	Short-range millimeter wave radar 2 (SRR_R2)
SP0995	Write VIN code	Mid-range millimeter wave radar (MRR)
SP0996	Manually write configuration information	Mid-range millimeter wave radar (MRR)
SP0997	Automatically write configuration information	Mid-range millimeter wave radar (MRR)
SP0998	Hardware reset	Mid-range millimeter wave radar (MRR)
SP0999	Engineering mode	Mid-range millimeter wave radar (MRR)
SP1000	Write VIN code	Shift controller (GSM)
SP1001	Manually write configuration information	Shift controller (GSM)
SP1002	Automatically write configuration information	Shift controller (GSM)
SP1003	Hardware reset	Shift controller (GSM)
SP1004	Software reset	Shift controller (GSM)
SP1005	Engineering mode	Shift controller (GSM)
SP1006	Write VIN code	Shift actuator (SBW)
SP1007	Manually write configuration information	Shift actuator (SBW)
SP1008	Automatically write configuration information	Shift actuator (SBW)
SP1009	Hardware reset	Shift actuator (SBW)
SP1010	Software reset	Shift actuator (SBW)
SP1011	Self-learning	Shift actuator (SBW)
SP1012	Engineering mode	Shift actuator (SBW)
SP1013	Hardware reset	Window anti-pinch controller (APM)
SP1014	Anti-pinch self-learning routine	Window anti-pinch controller (APM)
SP1015	Engineering mode	Window anti-pinch controller (APM)
SP1016	Crankshaft adaptive cylinder-1,2,3,4	Delphi Engine System (MT22.3)
SP1017	Crankshaft adaptive sampling counter	Delphi Engine System (MT22.3)
SP1018	Manufacture counter	Delphi Engine System (MT22.3)
SP1019	Write VIN code	Delphi Engine System (MT22.3)
SP1020	Write repair department code or test serial number	Delphi Engine System (MT22.3)
SP1021	Crankshaft adaptive cylinder-1,2,3,4	Delphi Engine System (MT62.1G)
SP1022	Crankshaft adaptive sampling counter	Delphi Engine System (MT62.1G)
SP1023	Manufacture counter	Delphi Engine System (MT62.1G)
SP1024	Write VIN code	Delphi Engine System (MT62.1G)
SP1025	Write repair department code or test serial number	Delphi Engine System (MT62.1G)
SP1026	Hardware reset	Delphi Engine System (MT62.1G)
SP1027	Read battery sensor battery ID	Delphi Engine System (MT62.1G)
SP1028	Read the battery sensor serial number	Delphi Engine System (MT62.1G)
SP1029	Read the battery sensor version number	Delphi Engine System (MT62.1G)
SP1030	Write battery sensor battery ID	Delphi Engine System (MT62.1G)
SP1031	Write VIN code	Delphi Engine System (MT62.1U)

SP1032	Write repair department code or test serial number	Delphi Engine System (MT62.1U)
SP1033	Hardware reset	Delphi Engine System (MT62.1U)
SP1034	Software reset	Delphi Engine System (MT62.1U)
SP1035	Read battery sensor battery ID	Delphi Engine System (MT62.1U)
SP1036	Read the battery sensor serial number	Delphi Engine System (MT62.1U)
SP1037	Read the battery sensor version number	Delphi Engine System (MT62.1U)
SP1038	Write battery sensor battery ID	Delphi Engine System (MT62.1U)
SP1039	Routine control GPF regeneration	Delphi Engine System (MT62.1U)
SP1040	Routine control mileage reset	Delphi Engine System (MT62.1U)
SP1041	Write carbon load quality and GPF ash mileage	Delphi Engine System (MT62.1U)
SP1042	Write VIN code	UMC Engine System (ME1788)
SP1043	Write VIN code	UMC Engine System MG1UA008 (UP8)
SP1044	Hardware reset	UMC Engine System MG1UA008 (UP8)
SP1045	Variable valve timing learning	UMC Engine System MG1UA008 (UP8)
SP1046	Reset particle load and accumulating ash load	UMC Engine System MG1UA008 (UP8)
SP1047	Reset GPF differential pressure learning value	UMC Engine System MG1UA008 (UP8)
SP1048	GPF regeneration test mode	UMC Engine System MG1UA008 (UP8)
SP1049	New ECU write particle load	UMC Engine System MG1UA008 (UP8)
SP1050	New ECU write cumulative gray load	UMC Engine System MG1UA008 (UP8)
SP1051	The new ECU writes the self-learning value of the differential pressure sensor	UMC Engine System MG1UA008 (UP8)
SP1052	Read software label	UMC Engine System MG1UA008 (UP8)
SP1053	Read (battery) ECU serial number	UMC Engine System MG1UA008 (UP8)
SP1054	Read battery code	UMC Engine System MG1UA008 (UP8)
SP1055	Write battery code	UMC Engine System MG1UA008 (UP8)
SP1056	Off-line test of fuel vapor leakage (DTESK diagnosis)	UMC Engine System MG1UA008 (UP8)
SP1057	Write VIN code	Automatic transmission system (VT5)
SP1058	Write repair department code or test serial number	Automatic transmission system (VT5)
SP1059	Manually write configuration information	Automatic transmission system (VT5)
SP1060	Automatically write configuration information	Automatic transmission system (VT5)
SP1061	Hardware reset	Automatic transmission system (VT5)
SP1062	Switch key reset	Automatic transmission system (VT5)
SP1063	Software reset	Automatic transmission system (VT5)
SP1064	Clutch self-learning value reset	Automatic transmission system (VT5)
SP1065	Write VIN code	Automatic transmission system (VT3)
SP1066	Clear clutch self-learning value	Automatic transmission system (VT3)
SP1067	Clutch self-learning (manual method 1)	Automatic transmission system (VT3)
SP1068	Clutch self-learning (manual method 2)	Automatic transmission system (VT3)
SP1069	D file self-learning	Automatic transmission system (VT3)
SP1070	R file self-learning	Automatic transmission system (VT3)
SP1071	Manually write vehicle electrical configuration	Automatic transmission system (VT3)
SP1072	Automatically write vehicle electrical configuration	Automatic transmission system (VT3)
SP1073	Hardware reset	Automatic transmission system (VT3)
SP1074	Forward clutch solenoid valve current control value adaptive value	Automatic transmission system (VT3)
SP1075	Reverse clutch solenoid valve current control value adaptive value	Automatic transmission system (VT3)
SP1076	Clear offline detection flag	Automatic transmission system (VT3)
SP1077	Reset offline detection flag	Automatic transmission system (VT3)
SP1078	Write VIN code	Automatic transmission system (RDC27)
SP1079	Manually write vehicle electrical configuration	Automatic transmission system (RDC27)
SP1080	Automatically write vehicle electrical configuration	Automatic transmission system (RDC27)
SP1081	Hardware reset	Automatic transmission system (RDC27)

SP1082	Forward clutch solenoid valve current control value adaptive value	Automatic transmission system (RDC27)
SP1083	Reverse clutch solenoid valve current control value adaptive value	Automatic transmission system (RDC27)
SP1084	Clear offline detection flag	Automatic transmission system (RDC27)
SP1085	Reset offline detection flag	Automatic transmission system (RDC27)
SP1086	Manually write vehicle electrical configuration (ESP only)	Electronic Stability System (ESP)
SP1087	Automatically write vehicle electrical configuration (ESP only)	Electronic Stability System (ESP)
SP1088	Steering angle calibration (ESP only)	Electronic Stability System (ESP)
SP1089	Yaw rate calibration (ESP only)	Electronic Stability System (ESP)
SP1090	ECU reset	Electronic Stability System (ESP)
SP1091	Write the last overhaul date of ECU	Airbag system (ABM)
SP1092	Write vehicle chassis number (VIN code)	Airbag system (ABM)
SP1093	ECU reset	Airbag system (ABM)
SP1094	Write VIN code	Electronic Power Steering System (EPS)
SP1095	Write car manufacturer spare part number data identifier	Electronic Power Steering System (EPS)
SP1096	Clear the angle median data	Electronic Power Steering System (EPS)
SP1097	Corner zero calibration	Electronic Power Steering System (EPS)
SP1098	Torque zero calibration	Electronic Power Steering System (EPS)
SP1099	Hardware reset	Electronic Power Steering System (EPS)
SP1100	Software reset	Electronic Power Steering System (EPS)
SP1101	Hardware reset	Combination Instrument System (IC)
SP1102	Software reset	Combination Instrument System (IC)
SP1103	Manually write vehicle electrical configuration	Combination Instrument System (IC)
SP1104	Automatically write vehicle electrical configuration	Combination Instrument System (IC)
SP1105	Write VIN code	Keyless Start System (PEPS)
SP1106	Manually write vehicle electrical configuration	Keyless Start System (PEPS)
SP1107	Automatically write vehicle electrical configuration	Keyless Start System (PEPS)
SP1108	ECU reset	Air Conditioning System (AC)
SP1109	Left actuator control	Bethel EPB
SP1110	Right actuator control	Bethel EPB
SP1111	EPB system actuator control	Bethel EPB
SP1112	G-Sensor calibration	Bethel EPB
SP1113	Assembly inspection	Bethel EPB
SP1114	EPB performs maintenance release	Bethel EPB
SP1115	Manually write vehicle electrical configuration	Bethel EPB
SP1116	Automatically write vehicle electrical configuration	Bethel EPB
SP1117	Hardware reset	Bethel EPB
SP1118	Software reset	Bethel EPB
SP1119	Hardware reset	Libang EPB
SP1120	EPB performs maintenance release	Libang EPB
SP1121	Zero point angle calibration	Libang EPB
SP1122	Manually write vehicle electrical configuration	Panoramic Parking System (AVM)
SP1123	Automatically write vehicle electrical configuration	Panoramic Parking System (AVM)
SP1124	ECU reset	Panoramic Parking System (AVM)
SP1125	Manually write vehicle electrical configuration	Audio Entertainment System (RRM)
SP1126	Automatically write vehicle electrical configuration	Audio Entertainment System (RRM)
SP1127	Hardware reset	Audio Entertainment System (RRM)
SP1128	Software reset	Audio Entertainment System (RRM)
SP1129	Manually write vehicle electrical configuration	Internet of Vehicles Control System (T-BOX)
SP1130	Automatically write vehicle electrical configuration	Internet of Vehicles Control System (T-BOX)
SP1131	Crankshaft adaptive cylinder-1,2,3,4	Delphi Engine System (MT22.3)

SP1132	Crankshaft adaptive sampling counter	Delphi Engine System (MT22.3)
SP1133	Manufacture counter	Delphi Engine System (MT22.3)
SP1134	Write VIN code	Delphi Engine System (MT22.3)
SP1135	Write repair department code or test serial number	Delphi Engine System (MT22.3)
SP1136	Write VIN code	Delphi Engine System (MT62.1G)
SP1137	Write repair department code or test serial number	Delphi Engine System (MT62.1G)
SP1138	Hardware reset	Delphi Engine System (MT62.1G)
SP1139	Software reset	Delphi Engine System (MT62.1G)
SP1140	Read battery sensor battery ID	Delphi Engine System (MT62.1G)
SP1141	Read the battery sensor serial number	Delphi Engine System (MT62.1G)
SP1142	Read the battery sensor version number	Delphi Engine System (MT62.1G)
SP1143	Write battery sensor battery ID	Delphi Engine System (MT62.1G)
SP1144	Routine control GPF regeneration	Delphi Engine System (MT62.1G)
SP1145	Routine control mileage reset	Delphi Engine System (MT62.1G)
SP1146	Write carbon load quality and GPF ash mileage	Delphi Engine System (MT62.1G)
SP1147	Write VIN code	Delphi Engine System (MT92.1)
SP1148	Write repair department code or test serial number	Delphi Engine System (MT92.1)
SP1149	Hardware reset	Delphi Engine System (MT92.1)
SP1150	Software reset	Delphi Engine System (MT92.1)
SP1151	Read battery sensor battery ID	Delphi Engine System (MT92.1)
SP1152	Read the battery sensor serial number	Delphi Engine System (MT92.1)
SP1153	Read battery sensor version	Delphi Engine System (MT92.1)
SP1154	Write battery sensor battery ID	Delphi Engine System (MT92.1)
SP1155	Routine control GPF regeneration	Delphi Engine System (MT92.1)
SP1156	Routine control mileage reset	Delphi Engine System (MT92.1)
SP1157	Write carbon load quality and GPF ash mileage	Delphi Engine System (MT92.1)
SP1158	Write VIN code	UMC Engine System MG1UA008 (UP8)
SP1159	Hardware reset	UMC Engine System MG1UA008 (UP8)
SP1160	Variable valve timing learning	UMC Engine System MG1UA008 (UP8)
SP1161	Reset particle load and accumulating ash load	UMC Engine System MG1UA008 (UP8)
SP1162	Reset GPF differential pressure learning value	UMC Engine System MG1UA008 (UP8)
SP1163	GPF regeneration test mode	UMC Engine System MG1UA008 (UP8)
SP1164	New ECU write particle load	UMC Engine System MG1UA008 (UP8)
SP1165	New ECU write cumulative gray load	UMC Engine System MG1UA008 (UP8)
SP1166	The new ECU writes the self-learning value of the differential pressure sensor	UMC Engine System MG1UA008 (UP8)
SP1167	Read software label	UMC Engine System MG1UA008 (UP8)
SP1168	Read (battery) ECU serial number	UMC Engine System MG1UA008 (UP8)
SP1169	Read battery code	UMC Engine System MG1UA008 (UP8)
SP1170	Write battery code	UMC Engine System MG1UA008 (UP8)
SP1171	Off-line test of fuel vapor leakage (DTESK diagnosis)	UMC Engine System MG1UA008 (UP8)
SP1172	Write VIN code	Automatic transmission system (VT5)
SP1173	Write repair department code or test serial number	Automatic transmission system (VT5)
SP1174	Manually write configuration information	Automatic transmission system (VT5)
SP1175	Automatically write configuration information	Automatic transmission system (VT5)
SP1176	Hardware reset	Automatic transmission system (VT5)
SP1177	Switch key reset	Automatic transmission system (VT5)
SP1178	Software reset	Automatic transmission system (VT5)
SP1179	Clutch self-learning value reset	Automatic transmission system (VT5)
SP1180	Write VIN code	Automatic transmission system (RDC27)
SP1181	Manually write vehicle electrical configuration	Automatic transmission system (RDC27)
SP1182	Automatically write vehicle electrical configuration	Automatic transmission system (RDC27)

SP1183	Hardware reset	Automatic transmission system (RDC27)
SP1184	Forward clutch solenoid valve current control value adaptive value	Automatic transmission system (RDC27)
SP1185	Reverse clutch solenoid valve current control value adaptive value	Automatic transmission system (RDC27)
SP1186	Clear offline detection flag	Automatic transmission system (RDC27)
SP1187	Reset offline detection flag	Automatic transmission system (RDC27)
SP1188	Write VIN code	Automatic transmission system (VT3)
SP1189	Write repair department code or test serial number	Automatic transmission system (VT3)
SP1190	Manually write configuration information	Automatic transmission system (VT3)
SP1191	Automatically write configuration information	Automatic transmission system (VT3)
SP1192	Hardware reset	Automatic transmission system (VT3)
SP1193	Write VIN code	Airbag system (ABM)
SP1194	Write airbag exclusive configuration	Airbag system (ABM)
SP1195	Write to activate the ignition mode	Airbag system (ABM)
SP1196	Write airbag configuration	Airbag system (ABM)
SP1197	Manually write configuration information	Airbag system (ABM)
SP1198	Automatically write configuration information	Airbag system (ABM)
SP1199	Hardware reset	Airbag system (ABM)
SP1200	Software reset	Airbag system (ABM)
SP1201	Write antenna threshold	Body Controller (BCM)
SP1202	Write tire pressure sensor ID	Body Controller (BCM)
SP1203	Clear all tire pressure sensor IDs	Body Controller (BCM)
SP1204	Manually write configuration information	Body Controller (BCM)
SP1205	Automatically write configuration information	Body Controller (BCM)
SP1206	Hardware reset	Body Controller (BCM)
SP1207	After-sales function	Body Controller (BCM)
SP1208	Learn tire pressure sensor	Body Controller (BCM)
SP1209	Tire swap	Body Controller (BCM)
SP1210	Read the number of keys	Body Controller (BCM)
SP1211	Write VIN code	Combination Instrument System (IC)
SP1212	Shielded average fuel consumption	Combination Instrument System (IC)
SP1213	Manually write configuration information	Combination Instrument System (IC)
SP1214	Automatically write configuration information	Combination Instrument System (IC)
SP1215	Hardware reset	Combination Instrument System (IC)
SP1216	Software reset	Combination Instrument System (IC)
SP1217	Hardware reset	Air Conditioning System (AC)
SP1218	Software reset	Air Conditioning System (AC)
SP1219	Write VIN code	Audio Entertainment System (RRM)
SP1220	Manually write configuration information	Audio Entertainment System (RRM)
SP1221	Automatically write configuration information	Audio Entertainment System (RRM)
SP1222	Hardware reset	Audio Entertainment System (RRM)
SP1223	Software reset	Audio Entertainment System (RRM)
SP1224	Manually write configuration information	Internet of Vehicles Control System (T-BOX)
SP1225	Automatically write configuration information	Internet of Vehicles Control System (T-BOX)
SP1226	Hardware reset	Internet of Vehicles Control System (T-BOX)
SP1227	Hardware reset	Electric tailgate (PLG)
SP1228	Software reset	Electric tailgate (PLG)
SP1229	Manually write configuration information	Panoramic Parking System (AVM)
SP1230	Automatically write configuration information	Panoramic Parking System (AVM)
SP1231	Hardware reset	Panoramic Parking System (AVM)
SP1232	Software reset	Panoramic Parking System (AVM)
SP1233	Write VIN code	Multi-function camera (MPC)

SP1234	Write sensitivity configuration factory value	Multi-function camera (MPC)
SP1235	Write switch configuration factory value	Multi-function camera (MPC)
SP1236	Write area code to configure factory value	Multi-function camera (MPC)
SP1237	Write function configuration	Multi-function camera (MPC)
SP1238	Write VIN lock	Multi-function camera (MPC)
SP1239	Write calibration tracking field	Multi-function camera (MPC)
SP1240	Manually write configuration information	Multi-function camera (MPC)
SP1241	Automatically write configuration information	Multi-function camera (MPC)
SP1242	Hardware reset	Multi-function camera (MPC)
SP1243	Service point SPC calibration	Multi-function camera (MPC)
SP1244	Hardware reset	Shift actuator (SBW)
SP1245	Software reset	Shift actuator (SBW)
SP1246	self-study	Shift actuator (SBW)
SP1247	Hardware reset	Shift controller (GSM)
SP1248	Software reset	Shift controller (GSM)
SP1249	Manually write configuration information	Multiple Switch Controller (MSC)
SP1250	Automatically write configuration information	Multiple Switch Controller (MSC)
SP1251	Hardware reset	Multiple Switch Controller (MSC)
SP1252	Software reset	Multiple Switch Controller (MSC)
SP1253	Hardware reset	Ambient Light Controller (ALC)
SP1254	Software reset	Ambient Light Controller (ALC)
SP1255	Write VIN code	Delphi Engine System (MT62.1U)
SP1256	Write repair department code or test serial number	Delphi Engine System (MT62.1U)
SP1257	Hardware reset	Delphi Engine System (MT62.1U)
SP1258	Software reset	Delphi Engine System (MT62.1U)
SP1259	Read battery sensor battery ID	Delphi Engine System (MT62.1U)
SP1260	Read the battery sensor serial number	Delphi Engine System (MT62.1U)
SP1261	Read the battery sensor version number	Delphi Engine System (MT62.1U)
SP1262	Write battery sensor battery ID	Delphi Engine System (MT62.1U)
SP1263	Routine control GPF regeneration	Delphi Engine System (MT62.1U)
SP1264	Routine control mileage reset	Delphi Engine System (MT62.1U)
SP1265	Write carbon load quality and GPF ash mileage	Delphi Engine System (MT62.1U)
SP1266	Write VIN code	UMC Engine System MG1UA008 (UP8)
SP1267	Hardware reset	UMC Engine System MG1UA008 (UP8)
SP1268	Variable valve timing learning	UMC Engine System MG1UA008 (UP8)
SP1269	Reset particle load and accumulating ash load	UMC Engine System MG1UA008 (UP8)
SP1270	Reset GPF differential pressure learning value	UMC Engine System MG1UA008 (UP8)
SP1271	GPF regeneration test mode	UMC Engine System MG1UA008 (UP8)
SP1272	New ECU write particle load	UMC Engine System MG1UA008 (UP8)
SP1273	New ECU write cumulative gray load	UMC Engine System MG1UA008 (UP8)
SP1274	The new ECU writes the self-learning value of the differential pressure sensor	UMC Engine System MG1UA008 (UP8)
SP1275	Read software label	UMC Engine System MG1UA008 (UP8)
SP1276	Read (battery) ECU serial number	UMC Engine System MG1UA008 (UP8)
SP1277	Read battery code	UMC Engine System MG1UA008 (UP8)
SP1278	Write battery code	UMC Engine System MG1UA008 (UP8)
SP1279	Off-line test of fuel vapor leakage (DTESK diagnosis)	UMC Engine System MG1UA008 (UP8)
SP1280	Write VIN code	Rongda Transmission Control Unit (TCU)
SP1281	Write VIN code	Punch Transmission Control Unit (TCU)
SP1282	Hardware reset	Punch Transmission Control Unit (TCU)
SP1283	Software reset	Punch Transmission Control Unit (TCU)
SP1284	Write VIN code	Airbag system (ABM)
SP1285	Write airbag exclusive configuration	Airbag system (ABM)
SP1286	Write to activate the ignition mode	Airbag system (ABM)
SP1287	Write airbag configuration	Airbag system (ABM)

SP1288	Manually write configuration information	Airbag system (ABM)
SP1289	Automatically write configuration information	Airbag system (ABM)
SP1290	Hardware reset	Airbag system (ABM)
SP1291	Write ECU serial number	Body Control Module (BCM)
SP1292	Write VIN code	Body Control Module (BCM)
SP1293	Write antenna threshold	Body Control Module (BCM)
SP1294	Write tire pressure sensor ID	Body Control Module (BCM)
SP1295	Manually write configuration information	Body Control Module (BCM)
SP1296	Automatically write configuration information	Body Control Module (BCM)
SP1297	Hardware reset	Body Control Module (BCM)
SP1298	After-sales function	Body Control Module (BCM)
SP1299	Check key status	Body Control Module (BCM)
SP1300	Anti-pinch module learning	Body Control Module (BCM)
SP1301	Anti-pinch function canceled	Body Control Module (BCM)
SP1302	Learn tire pressure sensor	Body Control Module (BCM)
SP1303	Read the number of keys	Body Control Module (BCM)
SP1304	Write VIN code	Electronic Power Steering (EPS)
SP1305	Hardware reset	Electronic Power Steering (EPS)
SP1306	Software reset	Electronic Power Steering (EPS)
SP1307	Corner zero calibration	Electronic Power Steering (EPS)
SP1308	Torque zero calibration	Electronic Power Steering (EPS)
SP1309	Clear the angle median data	Electronic Power Steering (EPS)
SP1310	Write VIN code	Combination Instrument (IC)
SP1311	Manually write configuration information	Combination Instrument (IC)
SP1312	Automatically write configuration information	Combination Instrument (IC)
SP1313	Hardware reset	Combination Instrument (IC)
SP1314	Software reset	Combination Instrument (IC)
SP1315	Hardware reset	Air Conditioning (AC)
SP1316	Software reset	Air Conditioning (AC)
SP1317	Write controller installation date	Electric parking brake system (EPB)
SP1318	Manually write gearbox information	Electric parking brake system (EPB)
SP1319	Automatically write gearbox information	Electric parking brake system (EPB)
SP1320	Manually write configuration information	Electric parking brake system (EPB)
SP1321	Automatically write configuration information	Electric parking brake system (EPB)
SP1322	Hardware reset	Electric parking brake system (EPB)
SP1323	After-sales function	Electric parking brake system (EPB)
SP1324	One-click after-sales matching	Electric parking brake system (EPB)
SP1325	Read parking brake status	Electric parking brake system (EPB)
SP1326	Maintenance open	Electric parking brake system (EPB)
SP1327	Maintenance shutdown	Electric parking brake system (EPB)
SP1328	Assembly inspection	Electric parking brake system (EPB)
SP1329	Two calipers clamping	Electric parking brake system (EPB)
SP1330	Two calipers release	Electric parking brake system (EPB)
SP1331	Left caliper clamping	Electric parking brake system (EPB)
SP1332	Right caliper clamping	Electric parking brake system (EPB)
SP1333	Left caliper release	Electric parking brake system (EPB)
SP1334	Right caliper release	Electric parking brake system (EPB)
SP1335	Hardware reset	Electronic Stability System (ESC)
SP1336	Software reset	Electronic Stability System (ESC)
SP1337	VIN code	Multi-function camera (MPC)
SP1338	ECU serial number data identifier	Multi-function camera (MPC)
SP1339	Sensitivity configuration factory value	Multi-function camera (MPC)
SP1340	Switch configuration factory value	Multi-function camera (MPC)
SP1341	Area code configuration factory value	Multi-function camera (MPC)
SP1342	Speed configuration factory value	Multi-function camera (MPC)
SP1343	Driver sensitivity selection value	Multi-function camera (MPC)
SP1344	Driver switch selection value	Multi-function camera (MPC)
SP1345	Driver area code selection value	Multi-function camera (MPC)
SP1346	Driver speed configuration selection value	Multi-function camera (MPC)

SP1347	Calibration tracking domain	Multi-function camera (MPC)
SP1348	Write VIN code	Audio Entertainment System (RRM)
SP1349	Manually write configuration information	Audio Entertainment System (RRM)
SP1350	Automatically write configuration information	Audio Entertainment System (RRM)
SP1351	Hardware reset	Audio Entertainment System (RRM)
SP1352	Software reset	Audio Entertainment System (RRM)
SP1353	Manually write configuration information	Driving Recorder (DVR)
SP1354	Automatically write configuration information	Driving Recorder (DVR)
SP1355	Hardware reset	Driving Recorder (DVR)
SP1356	Software reset	Driving Recorder (DVR)
SP1357	Manually write configuration information	Panoramic Parking (AVM)
SP1358	Automatically write configuration information	Panoramic Parking (AVM)
SP1359	Hardware reset	Panoramic Parking (AVM)
SP1360	Software reset	Panoramic Parking (AVM)
SP1361	Manually write configuration information	Radar Controller (PDC)
SP1362	Automatically write configuration information	Radar Controller (PDC)
SP1363	Hardware reset	Radar Controller (PDC)
SP1364	Software reset	Radar Controller (PDC)
SP1365	Manually write configuration information	Driving Recorder (DVR)
SP1366	Automatically write configuration information	Driving Recorder (DVR)
SP1367	Hardware reset	Driving Recorder (DVR)
SP1368	Software reset	Driving Recorder (DVR)
SP1369	Write VIN code	Remote communication unit (T-BOX)
SP1370	Manually write configuration information	Remote communication unit (T-BOX)
SP1371	Automatically write configuration information	Remote communication unit (T-BOX)
SP1372	Hardware reset	Remote communication unit (T-BOX)
SP1373	Software reset	Remote communication unit (T-BOX)
SP1374	Hardware reset	Electric Back Door (PLG)
SP1375	Software reset	Electric Back Door (PLG)
SP1376	Manually write configuration information	Seat Controller (DSM)
SP1377	Automatically write configuration information	Seat Controller (DSM)
SP1378	Hardware reset	Seat Controller (DSM)
SP1379	Software reset	Seat Controller (DSM)
SP1380	Write VIN code	Engine Management System (EMS)
SP1381	Write repair department code or test serial number	Engine Management System (EMS)
SP1382	Crankshaft adaptive cylinder-1,2,3,4	Engine Management System (EMS)
SP1383	Crankshaft adaptive sampling counter	Engine Management System (EMS)
SP1384	Manufacture counter	Engine Management System (EMS)
SP1385	Write VIN code	Automatic Transmission System (TCU)
SP1386	Clear clutch self-learning value	Automatic Transmission System (TCU)
SP1387	Clutch self-learning (manual method 1)	Automatic Transmission System (TCU)
SP1388	Clutch self-learning (manual method 2)	Automatic Transmission System (TCU)
SP1389	D file self-learning	Automatic Transmission System (TCU)
SP1390	R file self-learning	Automatic Transmission System (TCU)
SP1391	Manually write vehicle electrical configuration	Automatic Transmission System (TCU)
SP1392	Automatically write vehicle electrical configuration	Automatic Transmission System (TCU)
SP1393	Hardware reset	Automatic Transmission System (TCU)
SP1394	Forward clutch solenoid valve current control value adaptive value	Automatic Transmission System (TCU)
SP1395	Reverse clutch solenoid valve current control value adaptive value	Automatic Transmission System (TCU)
SP1396	Clear offline detection flag	Automatic Transmission System (TCU)
SP1397	Reset offline detection flag	Automatic Transmission System (TCU)

SP1398	Manually write vehicle electrical configuration (ESP only)	Electronic Stability System (ESP)
SP1399	Automatically write vehicle electrical configuration (ESP only)	Electronic Stability System (ESP)
SP1400	Steering angle calibration (ESP only)	Electronic Stability System (ESP)
SP1401	Yaw rate calibration (ESP only)	Electronic Stability System (ESP)
SP1402	ECU reset	Electronic Stability System (ESP)
SP1403	Write VIN code	Body Control System (BCM)
SP1404	Manually write vehicle electrical configuration	Body Control System (BCM)
SP1405	Automatically write vehicle electrical configuration	Body Control System (BCM)
SP1406	Tire pressure sensor learning	Body Control System (BCM)
SP1407	Tire swap	Body Control System (BCM)
SP1408	Non-workshop operation	Body Control System (BCM)
SP1409	Workshop operation	Body Control System (BCM)
SP1410	Write VIN code	Electronic Power Steering System (EPS)
SP1411	Hardware reset	Electronic Power Steering System (EPS)
SP1412	Software reset	Electronic Power Steering System (EPS)
SP1413	Corner zero calibration	Electronic Power Steering System (EPS)
SP1414	Clear the angle median data	Electronic Power Steering System (EPS)
SP1415	Hardware reset	Combination Instrument System (IC)
SP1416	Software reset	Combination Instrument System (IC)
SP1417	Manually write vehicle electrical configuration	Combination Instrument System (IC)
SP1418	Automatically write vehicle electrical configuration	Combination Instrument System (IC)
SP1419	Write VIN code	Keyless Start System (PEPS)
SP1420	Manually write vehicle electrical configuration	Keyless Start System (PEPS)
SP1421	Automatically write vehicle electrical configuration	Keyless Start System (PEPS)
SP1422	ECU reset	Air Conditioning System (AC)
SP1423	Four-wheeled vehicle	Tire Pressure Matching System (TPMS)
SP1424	Six-wheeler	Tire Pressure Matching System (TPMS)
SP1425	Left front wheel	Tire Pressure Matching System (TPMS)
SP1426	Right front wheel	Tire Pressure Matching System (TPMS)
SP1427	Right rear wheel	Tire Pressure Matching System (TPMS)
SP1428	Left rear wheel	Tire Pressure Matching System (TPMS)
SP1429	Left front wheel	Tire Pressure Matching System (TPMS)
SP1430	Right front wheel	Tire Pressure Matching System (TPMS)
SP1431	Right rear outer wheel	Tire Pressure Matching System (TPMS)
SP1432	Right rear inner wheel	Tire Pressure Matching System (TPMS)
SP1433	Left rear inner wheel	Tire Pressure Matching System (TPMS)
SP1434	Left rear outer wheel	Tire Pressure Matching System (TPMS)
SP1435	Left front wheel	Tire Pressure Matching System (TPMS)
SP1436	Right front wheel	Tire Pressure Matching System (TPMS)
SP1437	Right rear wheel	Tire Pressure Matching System (TPMS)
SP1438	Left rear wheel	Tire Pressure Matching System (TPMS)
SP1439	Left front wheel	Tire Pressure Matching System (TPMS)
SP1440	Right front wheel	Tire Pressure Matching System (TPMS)
SP1441	Right rear outer wheel	Tire Pressure Matching System (TPMS)
SP1442	Right rear inner wheel	Tire Pressure Matching System (TPMS)
SP1443	Left rear inner wheel	Tire Pressure Matching System (TPMS)
SP1444	Left rear outer wheel	Tire Pressure Matching System (TPMS)
SP1445	Alarm value setting	Tire Pressure Matching System (TPMS)
SP1446	Hardware reset	Electronic Parking System (EPB)
SP1447	EPB performs maintenance release	Electronic Parking System (EPB)
SP1448	Zero point angle calibration	Electronic Parking System (EPB)
SP1449	Manually write vehicle electrical configuration	Audio Entertainment System (RRM)
SP1450	Automatically write vehicle electrical configuration	Audio Entertainment System (RRM)
SP1451	Hardware reset	Audio Entertainment System (RRM)
SP1452	Software reset	Audio Entertainment System (RRM)
SP1453	Crankshaft adaptive cylinder-1,2,3,4	Engine Management System (EMS)
SP1454	Crankshaft adaptive sampling counter	Engine Management System (EMS)
SP1455	Manufacture counter	Engine Management System (EMS)
SP1456	Write VIN code	Engine Management System (EMS)
SP1457	Write repair department code or test serial number	Engine Management System (EMS)
SP1458	Write VIN code	Automatic transmission (CVT)
SP1459	Clear clutch self-learning value	Automatic transmission (CVT)
SP1460	Clutch self-learning (manual method 1)	Automatic transmission (CVT)

SP1461	Clutch self-learning (manual method 2)	Automatic transmission (CVT)
SP1462	D file self-learning	Automatic transmission (CVT)
SP1463	R file self-learning	Automatic transmission (CVT)
SP1464	Manually write vehicle electrical configuration	Automatic transmission (CVT)
SP1465	Automatically write vehicle electrical configuration	Automatic transmission (CVT)
SP1466	Hardware reset	Automatic transmission (CVT)
SP1467	Forward clutch solenoid valve current control value adaptive value	Automatic transmission (CVT)
SP1468	Reverse clutch solenoid valve current control value adaptive value	Automatic transmission (CVT)
SP1469	Clear offline detection flag	Automatic transmission (CVT)
SP1470	Reset offline detection flag	Automatic transmission (CVT)
SP1471	Write the repair station code or test equipment serial number	Automatic transmission (4AT)
SP1472	Write VIN code	Automatic transmission (4AT)
SP1473	Manually write vehicle electrical configuration	Automatic transmission (4AT)
SP1474	Automatically write vehicle electrical configuration	Automatic transmission (4AT)
SP1475	Manually write vehicle electrical configuration (ESP only)	Electronic Stability System (ESP)
SP1476	Automatically write vehicle electrical configuration (ESP only)	Electronic Stability System (ESP)
SP1477	Steering angle calibration (ESP only)	Electronic Stability System (ESP)
SP1478	Yaw rate calibration (ESP only)	Electronic Stability System (ESP)
SP1479	ECU reset	Electronic Stability System (ESP)
SP1480	Write VIN code	Body Control System (BCM)
SP1481	Manually write vehicle electrical configuration	Body Control System (BCM)
SP1482	Automatically write vehicle electrical configuration	Body Control System (BCM)
SP1483	Tire pressure sensor learning	Body Control System (BCM)
SP1484	Tire swap	Body Control System (BCM)
SP1485	Non-workshop operation	Body Control System (BCM)
SP1486	Workshop operation	Body Control System (BCM)
SP1487	Write VIN code	Electronic Power Steering System (EPS)
SP1488	Write car manufacturer spare part number data identifier	Electronic Power Steering System (EPS)
SP1489	Clear the angle median data	Electronic Power Steering System (EPS)
SP1490	Corner zero calibration	Electronic Power Steering System (EPS)
SP1491	Torque zero calibration	Electronic Power Steering System (EPS)
SP1492	Hardware reset	Electronic Power Steering System (EPS)
SP1493	Software reset	Electronic Power Steering System (EPS)
SP1494	Hardware reset	Combination Instrument System (IC)
SP1495	Software reset	Combination Instrument System (IC)
SP1496	Manually write vehicle electrical configuration	Combination Instrument System (IC)
SP1497	Automatically write vehicle electrical configuration	Combination Instrument System (IC)
SP1498	Write VIN code	Keyless Start System (PEPS)
SP1499	Manually write vehicle electrical configuration	Keyless Start System (PEPS)
SP1500	Automatically write vehicle electrical configuration	Keyless Start System (PEPS)
SP1501	ECU reset	Air Conditioning System (AC)
SP1502	Four-wheeled vehicle	Tire Pressure Matching System (TPMS)
SP1503	Six-wheeler	Tire Pressure Matching System (TPMS)
SP1504	Left front wheel	Tire Pressure Matching System (TPMS)
SP1505	Right front wheel	Tire Pressure Matching System (TPMS)
SP1506	Right rear wheel	Tire Pressure Matching System (TPMS)
SP1507	Left rear wheel	Tire Pressure Matching System (TPMS)
SP1508	Left front wheel	Tire Pressure Matching System (TPMS)
SP1509	Right front wheel	Tire Pressure Matching System (TPMS)
SP1510	Right rear outer wheel	Tire Pressure Matching System (TPMS)
SP1511	Right rear inner wheel	Tire Pressure Matching System (TPMS)
SP1512	Left rear inner wheel	Tire Pressure Matching System (TPMS)
SP1513	Left rear outer wheel	Tire Pressure Matching System (TPMS)
SP1514	Left front wheel	Tire Pressure Matching System (TPMS)
SP1515	Right front wheel	Tire Pressure Matching System (TPMS)
SP1516	Right rear wheel	Tire Pressure Matching System (TPMS)

SP1517	Left rear wheel	Tire Pressure Matching System (TPMS)
SP1518	Left front wheel	Tire Pressure Matching System (TPMS)
SP1519	Right front wheel	Tire Pressure Matching System (TPMS)
SP1520	Right rear outer wheel	Tire Pressure Matching System (TPMS)
SP1521	Right rear inner wheel	Tire Pressure Matching System (TPMS)
SP1522	Left rear inner wheel	Tire Pressure Matching System (TPMS)
SP1523	Left rear outer wheel	Tire Pressure Matching System (TPMS)
SP1524	Alarm value setting	Tire Pressure Matching System (TPMS)
SP1525	Hardware reset	Electronic Parking System (EPB)
SP1526	EPB performs maintenance release	Electronic Parking System (EPB)
SP1527	Zero point angle calibration	Electronic Parking System (EPB)
SP1528	Manually write vehicle electrical configuration	Panoramic Parking System (AVM)
SP1529	Automatically write vehicle electrical configuration	Panoramic Parking System (AVM)
SP1530	ECU reset	Panoramic Parking System (AVM)
SP1531	Manually write vehicle electrical configuration	Audio Entertainment System (RRM)
SP1532	Automatically write vehicle electrical configuration	Audio Entertainment System (RRM)
SP1533	Hardware reset	Audio Entertainment System (RRM)
SP1534	Software reset	Audio Entertainment System (RRM)
SP1535	ECU reset	Bosch EDC17C53 engine
SP1536	Read VIN code	Bosch EDC17C53 engine
SP1537	Write VIN code	Bosch EDC17C53 engine
SP1538	EGR (abandoned recirculation) zero trigger learning	Bosch EDC17C53 engine
SP1539	Clear ZFC learning value	Bosch EDC17C53 engine
SP1540	Injector data flashing	Bosch EDC17C53 engine
SP1541	Read all injector data	Bosch EDC17C53 engine
SP1542	Write all injector data	Bosch EDC17C53 engine
SP1543	Write #1 injector data	Bosch EDC17C53 engine
SP1544	Write #2 injector data	Bosch EDC17C53 engine
SP1545	Write #3 injector data	Bosch EDC17C53 engine
SP1546	Write #4 injector data	Bosch EDC17C53 engine
SP1547	Read VIN code	Bosch EDC17C63 engine
SP1548	Write VIN code	Bosch EDC17C63 engine
SP1549	EGR (abandoned recirculation) zero trigger learning	Bosch EDC17C63 engine
SP1550	Clear ZFC learning value	Bosch EDC17C63 engine
SP1551	Injector data flashing	Bosch EDC17C63 engine
SP1552	Read all injector data	Bosch EDC17C63 engine
SP1553	Write all injector data	Bosch EDC17C63 engine
SP1554	Write #1 injector data	Bosch EDC17C63 engine
SP1555	Write #2 injector data	Bosch EDC17C63 engine
SP1556	Write #3 injector data	Bosch EDC17C63 engine
SP1557	Write #4 injector data	Bosch EDC17C63 engine
SP1558	ECU reset	Bosch EDC17C63 engine
SP1559	Write VIN code	United Electronics ME788 Engine System
SP1560	ECU power off reset	United Electronics ME788 Engine System
SP1561	ECU reset: power on	United Electronics ME1788 Engine System
SP1562	ECU reset: first initialization	United Electronics ME1788 Engine System
SP1563	Read VIN code	Delphi MT22.3 (ETC) engine system
SP1564	Write VIN code	Delphi MT22.3 (ETC) engine system
SP1565	Delphi Broadcasting Code	Delphi MT22.3 (ETC) engine system
SP1566	Vehicle identification code	Delphi MT22.3 (ETC) engine system
SP1567	Repair shop number or tester number	Delphi MT22.3 (ETC) engine system
SP1568	ECU reset	Delphi MT22.3 (ETC) engine system
SP1569	Repair exhaust	Anti-lock brake system (ABS)
SP1570	Wheel speed sensor test	Anti-lock brake system (ABS)
SP1571	Read VIN code	Anti-lock brake system (ABS)
SP1572	Write VIN code	Anti-lock brake system (ABS)
SP1573	Incomplete raise	Anti-lock brake system (ABS)
SP1574	Filling is complete, the system is available	Anti-lock brake system (ABS)
SP1575	Filling is complete, the system is unavailable	Anti-lock brake system (ABS)
SP1576	EOL test is not completed	Anti-lock brake system (ABS)
SP1577	The EOL test is complete and the system is available	Anti-lock brake system (ABS)
SP1578	The EOL test is complete and the system is unavailable	Anti-lock brake system (ABS)
SP1579	Read VIN code	Electronic Power Steering (EPS)
SP1580	Write VIN code	Electronic Power Steering (EPS)
SP1581	Four-wheeled vehicle	Tire Pressure Matching System (TPMS)
SP1582	Six-wheeler	Tire Pressure Matching System (TPMS)
SP1583	Left front wheel	Tire Pressure Matching System (TPMS)

SP1584	Right front wheel	Tire Pressure Matching System (TPMS)
SP1585	Right rear wheel	Tire Pressure Matching System (TPMS)
SP1586	Left rear wheel	Tire Pressure Matching System (TPMS)
SP1587	Left front wheel	Tire Pressure Matching System (TPMS)
SP1588	Right front wheel	Tire Pressure Matching System (TPMS)
SP1589	Right rear outer wheel	Tire Pressure Matching System (TPMS)
SP1590	Right rear inner wheel	Tire Pressure Matching System (TPMS)
SP1591	Left rear inner wheel	Tire Pressure Matching System (TPMS)
SP1592	Left rear outer wheel	Tire Pressure Matching System (TPMS)
SP1593	Left front wheel	Tire Pressure Matching System (TPMS)
SP1594	Right front wheel	Tire Pressure Matching System (TPMS)
SP1595	Right rear wheel	Tire Pressure Matching System (TPMS)
SP1596	Left rear wheel	Tire Pressure Matching System (TPMS)
SP1597	Left front wheel	Tire Pressure Matching System (TPMS)
SP1598	Right front wheel	Tire Pressure Matching System (TPMS)
SP1599	Right rear outer wheel	Tire Pressure Matching System (TPMS)
SP1600	Right rear inner wheel	Tire Pressure Matching System (TPMS)
SP1601	Left rear inner wheel	Tire Pressure Matching System (TPMS)
SP1602	Left rear outer wheel	Tire Pressure Matching System (TPMS)
SP1603	Alarm value setting	Tire Pressure Matching System (TPMS)
SP1604	ECU reset	Bosch EDC17C53 engine
SP1605	Read VIN code	Bosch EDC17C53 engine
SP1606	Write VIN code	Bosch EDC17C53 engine
SP1607	EGR (abandoned recirculation) zero trigger learning	Bosch EDC17C53 engine
SP1608	Clear ZFC learning value	Bosch EDC17C53 engine
SP1609	Injector data flashing	Bosch EDC17C53 engine
SP1610	Read all injector data	Bosch EDC17C53 engine
SP1611	Write all injector data	Bosch EDC17C53 engine
SP1612	Write #1 injector data	Bosch EDC17C53 engine
SP1613	Write #2 injector data	Bosch EDC17C53 engine
SP1614	Write #3 injector data	Bosch EDC17C53 engine
SP1615	Write #4 injector data	Bosch EDC17C53 engine
SP1616	Read VIN code	Bosch EDC17C63 engine
SP1617	Write VIN code	Bosch EDC17C63 engine
SP1618	EGR (abandoned recirculation) zero trigger learning	Bosch EDC17C63 engine
SP1619	Clear ZFC learning value	Bosch EDC17C63 engine
SP1620	Injector data flashing	Bosch EDC17C63 engine
SP1621	Read all injector data	Bosch EDC17C63 engine
SP1622	Write all injector data	Bosch EDC17C63 engine
SP1623	Write #1 injector data	Bosch EDC17C63 engine
SP1624	Write #2 injector data	Bosch EDC17C63 engine
SP1625	Write #3 injector data	Bosch EDC17C63 engine
SP1626	Write #4 injector data	Bosch EDC17C63 engine
SP1627	ECU reset	Bosch EDC17C63 engine
SP1628	Write VIN code	United Electronics ME788 Engine System
SP1629	ECU power off reset	United Electronics ME788 Engine System
SP1630	ECU reset: power on	United Electronics ME1788 Engine System
SP1631	ECU reset: first initialization	United Electronics ME1788 Engine System
SP1632	Read VIN code	Delphi MT22.3 (ETC) engine system
SP1633	Write VIN code	Delphi MT22.3 (ETC) engine system
SP1634	Delphi Broadcasting Code	Delphi MT22.3 (ETC) engine system
SP1635	Vehicle identification code	Delphi MT22.3 (ETC) engine system
SP1636	Repair shop number or tester number	Delphi MT22.3 (ETC) engine system
SP1637	ECU reset	Delphi MT22.3 (ETC) engine system
SP1638	Repair exhaust	BOSCH ABS 9.0
SP1639	Wheel speed sensor test	BOSCH ABS 9.0
SP1640	Read VIN code	BOSCH ABS 9.0
SP1641	Write VIN code	BOSCH ABS 9.0
SP1642	Incomplete raise	BOSCH ABS 9.0
SP1643	Filling is complete, the system is available	BOSCH ABS 9.0
SP1644	Filling is complete, the system is unavailable	BOSCH ABS 9.0
SP1645	EOL test is not completed	BOSCH ABS 9.0
SP1646	The EOL test is complete and the system is available	BOSCH ABS 9.0
SP1647	The EOL test is complete and the system is unavailable	BOSCH ABS 9.0
SP1648	Read VIN code	Asia-Pacific integral hydraulic ABS
SP1649	Write VIN code	Asia-Pacific integral hydraulic ABS
SP1650	Read VIN code	Electronic Power Steering (EPS)
SP1651	Write VIN code	Electronic Power Steering (EPS)
SP1652	Write VIN code	Delphi Engine System (MT62.1U)
SP1653	Write repair department code or test serial number	Delphi Engine System (MT62.1U)
SP1654	Hardware reset	Delphi Engine System (MT62.1U)
SP1655	Software reset	Delphi Engine System (MT62.1U)
SP1656	Read battery sensor battery ID	Delphi Engine System (MT62.1U)

SP1657	Read the battery sensor serial number	Delphi Engine System (MT62.1U)
SP1658	Read the battery sensor version number	Delphi Engine System (MT62.1U)
SP1659	Write battery sensor battery ID	Delphi Engine System (MT62.1U)
SP1660	Routine control GPF regeneration	Delphi Engine System (MT62.1U)
SP1661	Routine control mileage reset	Delphi Engine System (MT62.1U)
SP1662	Write carbon load quality and GPF ash mileage	Delphi Engine System (MT62.1U)
SP1663	ECU reset	Bosch EDC17C53 engine
SP1664	Read VIN code	Bosch EDC17C53 engine
SP1665	Write VIN code	Bosch EDC17C53 engine
SP1666	EGR (abandoned recirculation) zero trigger learning	Bosch EDC17C53 engine
SP1667	Clear ZFC learning value	Bosch EDC17C53 engine
SP1668	Injector data flashing	Bosch EDC17C53 engine
SP1669	Read all injector data	Bosch EDC17C53 engine
SP1670	Write all injector data	Bosch EDC17C53 engine
SP1671	Write #1 injector data	Bosch EDC17C53 engine
SP1672	Write #2 injector data	Bosch EDC17C53 engine
SP1673	Write #3 injector data	Bosch EDC17C53 engine
SP1674	Write #4 injector data	Bosch EDC17C53 engine
SP1675	Read VIN code	Bosch EDC17C63 engine
SP1676	Write VIN code	Bosch EDC17C63 engine
SP1677	EGR (abandoned recirculation) zero trigger learning	Bosch EDC17C63 engine
SP1678	Clear ZFC learning value	Bosch EDC17C63 engine
SP1679	Injector data flashing	Bosch EDC17C63 engine
SP1680	Read all injector data	Bosch EDC17C63 engine
SP1681	Write all injector data	Bosch EDC17C63 engine
SP1682	Write #1 injector data	Bosch EDC17C63 engine
SP1683	Write #2 injector data	Bosch EDC17C63 engine
SP1684	Write #3 injector data	Bosch EDC17C63 engine
SP1685	Write #4 injector data	Bosch EDC17C63 engine
SP1686	ECU reset	Bosch EDC17C63 engine
SP1687	Read VIN code	Delphi Engine System (MT22.3)
SP1688	Write VIN code	Delphi Engine System (MT22.3)
SP1689	Delphi Broadcasting Code	Delphi Engine System (MT22.3)
SP1690	Vehicle identification code	Delphi Engine System (MT22.3)
SP1691	Repair shop number or tester number	Delphi Engine System (MT22.3)
SP1692	ECU reset	Delphi Engine System (MT22.3)
SP1693	ECU reset: power on	UMC Engine System (ME1788)
SP1694	ECU reset: first initialization	UMC Engine System (ME1788)
SP1695	Read VIN code	Delphi Engine System (MT22.1)
SP1696	Write VIN code	Delphi Engine System (MT22.1)
SP1697	Delphi Broadcasting Code	Delphi Engine System (MT22.1)
SP1698	Vehicle identification code	Delphi Engine System (MT22.1)
SP1699	Repair shop number or tester number	Delphi Engine System (MT22.1)
SP1700	ECU reset	Delphi Engine System (MT22.1)
SP1701	Write VIN code	Siemens Transmission System (TCU)
SP1702	Gearbox self-learning	Siemens Transmission System (TCU)
SP1703	Clutch joint point self-learning	Siemens Transmission System (TCU)
SP1704	Clutch separation point self-learning	Siemens Transmission System (TCU)
SP1705	Clutch contact point self-learning	Siemens Transmission System (TCU)
SP1706	Repair exhaust	BOSCH ABS 9.0
SP1707	Wheel speed sensor test	BOSCH ABS 9.0
SP1708	Read VIN code	BOSCH ABS 9.0
SP1709	Write VIN code	BOSCH ABS 9.0
SP1710	Incomplete raise	BOSCH ABS 9.0
SP1711	Filling is complete, the system is available	BOSCH ABS 9.0
SP1712	Filling is complete, the system is unavailable	BOSCH ABS 9.0
SP1713	EOL test is not completed	BOSCH ABS 9.0
SP1714	The EOL test is complete and the system is available	BOSCH ABS 9.0
SP1715	The EOL test is complete and the system is unavailable	BOSCH ABS 9.0
SP1716	Read VIN code	BOSCH ABS (three channels)
SP1717	Write VIN code	BOSCH ABS (three channels)
SP1718	Write to VSO	BOSCH ABS (three channels)
SP1719	Incomplete raise	BOSCH ABS (three channels)
SP1720	Filling is complete, the system is available	BOSCH ABS (three channels)

SP1721	Filling is complete, the system is unavailable	BOSCH ABS (three channels)
SP1722	EOL test is not completed	BOSCH ABS (three channels)
SP1723	The EOL test is complete and the system is available	BOSCH ABS (three channels)
SP1724	The EOL test is complete and the system is unavailable	BOSCH ABS (three channels)
SP1725	Repair exhaust	BOSCH ABS (three channels)
SP1726	ECU reset	BOSCH ABS (three channels)
SP1727	Read VIN code	Electronic Power Steering (EPS)
SP1728	Write VIN code	Electronic Power Steering (EPS)
SP1729	Four-wheeled vehicle	Tire Pressure Matching System (TPMS)
SP1730	Six-wheeler	Tire Pressure Matching System (TPMS)
SP1731	Left front wheel	Tire Pressure Matching System (TPMS)
SP1732	Right front wheel	Tire Pressure Matching System (TPMS)
SP1733	Right rear wheel	Tire Pressure Matching System (TPMS)
SP1734	Left rear wheel	Tire Pressure Matching System (TPMS)
SP1735	Left front wheel	Tire Pressure Matching System (TPMS)
SP1736	Right front wheel	Tire Pressure Matching System (TPMS)
SP1737	Right rear outer wheel	Tire Pressure Matching System (TPMS)
SP1738	Right rear inner wheel	Tire Pressure Matching System (TPMS)
SP1739	Left rear inner wheel	Tire Pressure Matching System (TPMS)
SP1740	Left rear outer wheel	Tire Pressure Matching System (TPMS)
SP1741	Left front wheel	Tire Pressure Matching System (TPMS)
SP1742	Right front wheel	Tire Pressure Matching System (TPMS)
SP1743	Right rear wheel	Tire Pressure Matching System (TPMS)
SP1744	Left rear wheel	Tire Pressure Matching System (TPMS)
SP1745	Left front wheel	Tire Pressure Matching System (TPMS)
SP1746	Right front wheel	Tire Pressure Matching System (TPMS)
SP1747	Right rear outer wheel	Tire Pressure Matching System (TPMS)
SP1748	Right rear inner wheel	Tire Pressure Matching System (TPMS)
SP1749	Left rear inner wheel	Tire Pressure Matching System (TPMS)
SP1750	Left rear outer wheel	Tire Pressure Matching System (TPMS)
SP1751	Alarm value setting	Tire Pressure Matching System (TPMS)
SP1752	Write VIN code	UMC Engine System (ME1788)
SP1753	Write VIN code	UMC Engine System MG1UA008 (UP8)
SP1754	Hardware reset	UMC Engine System MG1UA008 (UP8)
SP1755	Variable valve timing learning	UMC Engine System MG1UA008 (UP8)
SP1756	Reset particle load and accumulating ash load	UMC Engine System MG1UA008 (UP8)
SP1757	Reset GPF differential pressure learning value	UMC Engine System MG1UA008 (UP8)
SP1758	GPF regeneration test mode	UMC Engine System MG1UA008 (UP8)
SP1759	New ECU write particle load	UMC Engine System MG1UA008 (UP8)
SP1760	New ECU write cumulative gray load	UMC Engine System MG1UA008 (UP8)
SP1761	The new ECU writes the self-learning value of the differential pressure sensor	UMC Engine System MG1UA008 (UP8)
SP1762	Read software label	UMC Engine System MG1UA008 (UP8)
SP1763	Read (battery) ECU serial number	UMC Engine System MG1UA008 (UP8)
SP1764	Read battery code	UMC Engine System MG1UA008 (UP8)
SP1765	Write battery code	UMC Engine System MG1UA008 (UP8)
SP1766	Off-line test of fuel vapor leakage (DTESK diagnosis)	UMC Engine System MG1UA008 (UP8)
SP1767	Crankshaft adaptive cylinder-1,2,3,4	Delphi Engine System (MT62.1G)
SP1768	Crankshaft adaptive sampling counter	Delphi Engine System (MT62.1G)
SP1769	Manufacture counter	Delphi Engine System (MT62.1G)
SP1770	Write VIN code	Delphi Engine System (MT62.1G)
SP1771	Write repair department code or test serial number	Delphi Engine System (MT62.1G)
SP1772	Hardware reset	Delphi Engine System (MT62.1G)
SP1773	Read battery sensor battery ID	Delphi Engine System (MT62.1G)
SP1774	Read the battery sensor serial number	Delphi Engine System (MT62.1G)
SP1775	Read the battery sensor version number	Delphi Engine System (MT62.1G)
SP1776	Write battery sensor battery ID	Delphi Engine System (MT62.1G)
SP1777	Write VIN code	Delphi Engine System (MT62.1U)
SP1778	Write repair department code or test serial number	Delphi Engine System (MT62.1U)
SP1779	Hardware reset	Delphi Engine System (MT62.1U)
SP1780	Software reset	Delphi Engine System (MT62.1U)
SP1781	Read battery sensor battery ID	Delphi Engine System (MT62.1U)
SP1782	Read the battery sensor serial number	Delphi Engine System (MT62.1U)
SP1783	Read the battery sensor version number	Delphi Engine System (MT62.1U)
SP1784	Write battery sensor battery ID	Delphi Engine System (MT62.1U)

SP1785	Routine control GPF regeneration	Delphi Engine System (MT62.1U)
SP1786	Routine control mileage reset	Delphi Engine System (MT62.1U)
SP1787	Write carbon load quality and GPF ash mileage	Delphi Engine System (MT62.1U)
SP1788	Write VIN code	Delphi MT62.3 engine system
SP1789	Write repair department code or test serial number	Delphi MT62.3 engine system
SP1790	Hardware reset	Delphi MT62.3 engine system
SP1791	Software reset	Delphi MT62.3 engine system
SP1792	Read battery sensor battery ID	Delphi MT62.3 engine system
SP1793	Read the battery sensor serial number	Delphi MT62.3 engine system
SP1794	Read the battery sensor version number	Delphi MT62.3 engine system
SP1795	Write battery sensor battery ID	Delphi MT62.3 engine system
SP1796	Routine control GPF regeneration	Delphi MT62.3 engine system
SP1797	Routine control mileage reset	Delphi MT62.3 engine system
SP1798	Write carbon load quality and GPF ash mileage	Delphi MT62.3 engine system
SP1799	Write VIN code	Automatic transmission system (VT3)
SP1800	Clear clutch self-learning value	Automatic transmission system (VT3)
SP1801	Clutch self-learning (manual method 1)	Automatic transmission system (VT3)
SP1802	Clutch self-learning (manual method 2)	Automatic transmission system (VT3)
SP1803	D file self-learning	Automatic transmission system (VT3)
SP1804	R file self-learning	Automatic transmission system (VT3)
SP1805	Manually write vehicle electrical configuration	Automatic transmission system (VT3)
SP1806	Automatically write vehicle electrical configuration	Automatic transmission system (VT3)
SP1807	Hardware reset	Automatic transmission system (VT3)
SP1808	Forward clutch solenoid valve current control value adaptive value	Automatic transmission system (VT3)
SP1809	Reverse clutch solenoid valve current control value adaptive value	Automatic transmission system (VT3)
SP1810	Clear offline detection flag	Automatic transmission system (VT3)
SP1811	Reset offline detection flag	Automatic transmission system (VT3)
SP1812	Write VIN code	Automatic transmission system (RDC18)
SP1813	Write repair department code or test serial number	Automatic transmission system (RDC18)
SP1814	Manually write vehicle electrical configuration	Automatic transmission system (RDC18)
SP1815	Automatically write vehicle electrical configuration	Automatic transmission system (RDC18)
SP1816	Adaptive reset	Automatic transmission system (RDC18)
SP1817	Manually write vehicle electrical configuration (ESP only)	Electronic Stability System (ESP)
SP1818	Automatically write vehicle electrical configuration (ESP only)	Electronic Stability System (ESP)
SP1819	Steering angle calibration (ESP only)	Electronic Stability System (ESP)
SP1820	Yaw rate calibration (ESP only)	Electronic Stability System (ESP)
SP1821	ECU reset	Electronic Stability System (ESP)
SP1822	Manually write vehicle electrical configuration	Body Control System (BCM)
SP1823	Automatically write vehicle electrical configuration	Body Control System (BCM)
SP1824	Write VIN code	Body Control System (BCM)
SP1825	Write antenna threshold	Body Control System (BCM)
SP1826	Tire pressure sensor learning	Body Control System (BCM)
SP1827	Tire swap	Body Control System (BCM)
SP1828	Non-workshop operation	Body Control System (BCM)
SP1829	Workshop operation	Body Control System (BCM)
SP1830	Write VIN code	Electronic Power Steering (EPS)
SP1831	Hardware reset	Electronic Power Steering (EPS)
SP1832	Software reset	Electronic Power Steering (EPS)
SP1833	Corner zero calibration	Electronic Power Steering (EPS)
SP1834	Clear the angle median data	Electronic Power Steering (EPS)
SP1835	Hardware reset	Combination Instrument System (IC)

SP1836	Software reset	Combination Instrument System (IC)
SP1837	Manually write vehicle electrical configuration	Combination Instrument System (IC)
SP1838	Automatically write vehicle electrical configuration	Combination Instrument System (IC)
SP1839	ECU reset	Air Conditioning System (AC)
SP1840	Left actuator control	Electronic Parking System (EPB)
SP1841	Right actuator control	Electronic Parking System (EPB)
SP1842	EPB system actuator control	Electronic Parking System (EPB)
SP1843	G-Sensor calibration	Electronic Parking System (EPB)
SP1844	Assembly inspection	Electronic Parking System (EPB)
SP1845	EPB performs maintenance release	Electronic Parking System (EPB)
SP1846	Manually write vehicle electrical configuration	Electronic Parking System (EPB)
SP1847	Automatically write vehicle electrical configuration	Electronic Parking System (EPB)
SP1848	Hardware reset	Electronic Parking System (EPB)
SP1849	Software reset	Electronic Parking System (EPB)
SP1850	Manually write vehicle electrical configuration	Panoramic Parking System (AVM)
SP1851	Automatically write vehicle electrical configuration	Panoramic Parking System (AVM)
SP1852	ECU reset	Panoramic Parking System (AVM)
SP1853	Manually write vehicle electrical configuration	Audio Entertainment System (RRM)
SP1854	Automatically write vehicle electrical configuration	Audio Entertainment System (RRM)
SP1855	Hardware reset	Audio Entertainment System (RRM)
SP1856	Software reset	Audio Entertainment System (RRM)
SP1857	Write VIN code	UMC Engine
SP1858	Hardware reset	UMC Engine
SP1859	Variable valve timing learning	UMC Engine
SP1860	Reset particle load and accumulating ash load	UMC Engine
SP1861	Reset GPF differential pressure learning value	UMC Engine
SP1862	GPF regeneration test mode	UMC Engine
SP1863	New ECU write particle load	UMC Engine
SP1864	New ECU write cumulative gray load	UMC Engine
SP1865	The new ECU writes the self-learning value of the differential pressure sensor	UMC Engine
SP1866	Read software label	UMC Engine
SP1867	Read (battery) ECU serial number	UMC Engine
SP1868	Read battery code	UMC Engine
SP1869	Write battery code	UMC Engine
SP1870	Off-line test of fuel vapor leakage (DTESK diagnosis)	UMC Engine
SP1871	Write VIN code	Delphi Engine System
SP1872	Write repair department code or test serial number	Delphi Engine System
SP1873	Hardware reset	Delphi Engine System
SP1874	Software reset	Delphi Engine System
SP1875	Read battery sensor battery ID	Delphi Engine System
SP1876	Read the battery sensor serial number	Delphi Engine System
SP1877	Read the battery sensor version number	Delphi Engine System
SP1878	Write battery sensor battery ID	Delphi Engine System
SP1879	Routine control GPF regeneration	Delphi Engine System
SP1880	Routine control mileage reset	Delphi Engine System
SP1881	Write carbon load quality and GPF ash mileage	Delphi Engine System
SP1882	Write VIN code	Automatic Transmission System (TCU)
SP1883	Manually write vehicle electrical configuration	Automatic Transmission System (TCU)
SP1884	Automatically write vehicle electrical configuration	Automatic Transmission System (TCU)
SP1885	Hardware reset	Automatic Transmission System (TCU)
SP1886	Forward clutch solenoid valve current control value adaptive value	Automatic Transmission System (TCU)

SP1887	Reverse clutch solenoid valve current control value adaptive value	Automatic Transmission System (TCU)
SP1888	Clear offline detection flag	Automatic Transmission System (TCU)
SP1889	Reset offline detection flag	Automatic Transmission System (TCU)
SP1890	Write VIN code	Body Control System 1
SP1891	Write antenna threshold	Body Control System 1
SP1892	Write tire pressure sensor ID	Body Control System 1
SP1893	Clear all tire pressure sensor IDs	Body Control System 1
SP1894	Manually write configuration information	Body Control System 1
SP1895	Automatically write configuration information	Body Control System 1
SP1896	Hardware reset	Body Control System 1
SP1897	After-sales function	Body Control System 1
SP1898	Learn tire pressure sensor	Body Control System 1
SP1899	Tire swap	Body Control System 1
SP1900	Read the number of keys	Body Control System 1
SP1901	Manually write vehicle electrical configuration	Body Control System 2
SP1902	Automatically write vehicle electrical configuration	Body Control System 2
SP1903	Write VIN code	Body Control System 2
SP1904	Write antenna threshold	Body Control System 2
SP1905	Tire pressure sensor learning	Body Control System 2
SP1906	Tire swap	Body Control System 2
SP1907	Non-workshop operation	Body Control System 2
SP1908	Workshop operation	Body Control System 2
SP1909	Write VIN code	Electronic Power Steering (EPS)
SP1910	Hardware reset	Electronic Power Steering (EPS)
SP1911	Software reset	Electronic Power Steering (EPS)
SP1912	Corner zero calibration	Electronic Power Steering (EPS)
SP1913	Clear the angle median data	Electronic Power Steering (EPS)
SP1914	Write VIN code	Combination Instrument System (IC)
SP1915	Hardware reset	Combination Instrument System (IC)
SP1916	Software reset	Combination Instrument System (IC)
SP1917	Manually write vehicle electrical configuration	Combination Instrument System (IC)
SP1918	Automatically write vehicle electrical configuration	Combination Instrument System (IC)
SP1919	Hardware reset	Air Conditioning System (AC)
SP1920	Software reset	Air Conditioning System (AC)
SP1921	Write VIN code	Audio Entertainment System (RRM)
SP1922	Manually write configuration information	Audio Entertainment System (RRM)
SP1923	Automatically write configuration information	Audio Entertainment System (RRM)
SP1924	Hardware reset	Audio Entertainment System (RRM)
SP1925	Software reset	Audio Entertainment System (RRM)
SP1926	Manually write configuration information	Internet of Vehicles Control System (T-BOX)
SP1927	Automatically write configuration information	Internet of Vehicles Control System (T-BOX)
SP1928	Hardware reset	Internet of Vehicles Control System (T-BOX)
SP1929	Write VIN code	Engine Management System (EMS)
SP1930	Hardware reset	Engine Management System (EMS)
SP1931	Variable valve timing learning	Engine Management System (EMS)
SP1932	Reset particle load and accumulating ash load	Engine Management System (EMS)
SP1933	Reset GPF differential pressure learning value	Engine Management System (EMS)
SP1934	GPF regeneration test mode	Engine Management System (EMS)
SP1935	New ECU write particle load	Engine Management System (EMS)
SP1936	New ECU write cumulative gray load	Engine Management System (EMS)
SP1937	The new ECU writes the self-learning value of the differential pressure sensor	Engine Management System (EMS)
SP1938	Read software label	Engine Management System (EMS)
SP1939	Read (battery) ECU serial number	Engine Management System (EMS)
SP1940	Read battery code	Engine Management System (EMS)
SP1941	Write battery code	Engine Management System (EMS)

SP1942	Off-line test of fuel vapor leakage (DTESK diagnosis)	Engine Management System (EMS)
SP1943	Write VIN code	Transmission Controller (TCU)
SP1944	Hardware reset	Transmission Controller (TCU)
SP1945	After-sales function	Transmission Controller (TCU)
SP1946	Erase EOL data	Transmission Controller (TCU)
SP1947	Write solenoid valve offset	Transmission Controller (TCU)
SP1948	Check EOL data integrity	Transmission Controller (TCU)
SP1949	Write antenna threshold	Body Control Module (BCM)
SP1950	Write tire pressure sensor ID	Body Control Module (BCM)
SP1951	Write ECU serial number	Body Control Module (BCM)
SP1952	Write ECU manufacturing date	Body Control Module (BCM)
SP1953	Manually write configuration information	Body Control Module (BCM)
SP1954	Automatically write configuration information	Body Control Module (BCM)
SP1955	Hardware reset	Body Control Module (BCM)
SP1956	After-sales function	Body Control Module (BCM)
SP1957	Learn tire pressure sensor	Body Control Module (BCM)
SP1958	Tire swap	Body Control Module (BCM)
SP1959	Read the number of keys	Body Control Module (BCM)
SP1960	Write VIN code	Electronic Power Steering (EPS)
SP1961	Manually write configuration information	Electronic Power Steering (EPS)
SP1962	Automatically write configuration information	Electronic Power Steering (EPS)
SP1963	Hardware reset	Electronic Power Steering (EPS)
SP1964	Steering angle calibration	Electronic Power Steering (EPS)
SP1965	Erase steering angle calibration	Electronic Power Steering (EPS)
SP1966	Erase soft limit	Electronic Power Steering (EPS)
SP1967	Write VIN code	Combination Instrument (IC)
SP1968	Manually write configuration information	Combination Instrument (IC)
SP1969	Automatically write configuration information	Combination Instrument (IC)
SP1970	Write maintenance mileage	Combination Instrument (IC)
SP1971	Hardware reset	Combination Instrument (IC)
SP1972	Software reset	Combination Instrument (IC)
SP1973	Write VIN code	Electronic Stability System (ESP)
SP1974	Write annotated status	Electronic Stability System (ESP)
SP1975	Write EOL status	Electronic Stability System (ESP)
SP1976	Manually write gearbox information	Electronic Stability System (ESP)
SP1977	Automatically write gearbox information	Electronic Stability System (ESP)
SP1978	Manually write configuration information	Electronic Stability System (ESP)
SP1979	Automatically write configuration information	Electronic Stability System (ESP)
SP1980	Software reset	Electronic Stability System (ESP)
SP1981	Wheel speed sensor test	Electronic Stability System (ESP)
SP1982	Speed limit off	Electronic Stability System (ESP)
SP1983	Speed limit enable	Electronic Stability System (ESP)
SP1984	Yaw rate calibration (ESP only)	Electronic Stability System (ESP)
SP1985	Hardware reset	Air Conditioning System (AC)
SP1986	Software reset	Air Conditioning System (AC)
SP1987	Manually write configuration information	Electronic Parking Controller (EPB)
SP1988	Automatically write configuration information	Electronic Parking Controller (EPB)
SP1989	Hardware reset	Electronic Parking Controller (EPB)
SP1990	Read brake status	Electronic Parking Controller (EPB)
SP1991	Maintenance open	Electronic Parking Controller (EPB)
SP1992	Maintenance shutdown	Electronic Parking Controller (EPB)
SP1993	Assembly inspection	Electronic Parking Controller (EPB)
SP1994	Both brakes open	Electronic Parking Controller (EPB)
SP1995	Both brakes closed	Electronic Parking Controller (EPB)
SP1996	Left brake open	Electronic Parking Controller (EPB)
SP1997	Right brake open	Electronic Parking Controller (EPB)
SP1998	Left brake closed	Electronic Parking Controller (EPB)
SP1999	Right brake closed	Electronic Parking Controller (EPB)
SP2000	Manually write configuration information	Gateway system (GW)
SP2001	Automatically write configuration information	Gateway system (GW)

SP2002	Hardware reset	Gateway system (GW)
SP2003	Write programming date	Four-wheel drive controller (4WD)
SP2004	Manually write configuration information	Four-wheel drive controller (4WD)
SP2005	Automatically write configuration information	Four-wheel drive controller (4WD)
SP2006	Hardware reset	Four-wheel drive controller (4WD)
SP2007	Hardware reset	Shift controller (GSM)
SP2008	Software reset	Shift controller (GSM)
SP2009	Hardware reset	Shift actuator (SBW)
SP2010	Software reset	Shift actuator (SBW)
SP2011	SBW self-learning	Shift actuator (SBW)
SP2012	Manually write configuration information	Mid-range millimeter wave radar (MRR)
SP2013	Automatically write configuration information	Mid-range millimeter wave radar (MRR)
SP2014	Software reset	Mid-range millimeter wave radar (MRR)
SP2015	Write VIN code	Multi-function camera (MPC)
SP2016	Manually write configuration information	Multi-function camera (MPC)
SP2017	Automatically write configuration information	Multi-function camera (MPC)
SP2018	Hardware reset	Multi-function camera (MPC)
SP2019	Switch key reset	Multi-function camera (MPC)
SP2020	Software reset	Multi-function camera (MPC)
SP2021	Write VIN code	Airbag Controller (ABM)
SP2022	Write airbag exclusive configuration	Airbag Controller (ABM)
SP2023	Write to activate the ignition mode	Airbag Controller (ABM)
SP2024	Write airbag configuration	Airbag Controller (ABM)
SP2025	Manually write configuration information	Airbag Controller (ABM)
SP2026	Automatically write configuration information	Airbag Controller (ABM)
SP2027	Hardware reset	Airbag Controller (ABM)
SP2028	Software reset	Airbag Controller (ABM)
SP2029	Hardware reset	Electric tailgate controller (PLG)
SP2030	Software reset	Electric tailgate controller (PLG)
SP2031	Manually write configuration information	Telematics module (T-BOX)
SP2032	Automatically write configuration information	Telematics module (T-BOX)
SP2033	Hardware reset	Telematics module (T-BOX)
SP2034	Hardware reset	Central Control Panel (CCP)
SP2035	Software reset	Central Control Panel (CCP)
SP2036	Manually write configuration information	Head up display (HUD)
SP2037	Automatically write configuration information	Head up display (HUD)
SP2038	Hardware reset	Head up display (HUD)
SP2039	Write VIN code	Audio Entertainment System (RRM)
SP2040	Manually write configuration information	Audio Entertainment System (RRM)
SP2041	Automatically write configuration information	Audio Entertainment System (RRM)
SP2042	Hardware reset	Audio Entertainment System (RRM)
SP2043	Software reset	Audio Entertainment System (RRM)
SP2044	Manually write configuration information	Multiple Switch Controller (MSC)
SP2045	Automatically write configuration information	Multiple Switch Controller (MSC)
SP2046	Hardware reset	Multiple Switch Controller (MSC)
SP2047	Software reset	Multiple Switch Controller (MSC)
SP2048	Manually write configuration information	Driving Recorder (DVR)
SP2049	Automatically write configuration information	Driving Recorder (DVR)
SP2050	Hardware reset	Driving Recorder (DVR)
SP2051	Software reset	Driving Recorder (DVR)
SP2052	Manually write configuration information	Parking sensor (PDC)
SP2053	Automatically write configuration information	Parking sensor (PDC)
SP2054	Hardware reset	Parking sensor (PDC)
SP2055	Software reset	Parking sensor (PDC)

SP2056	Manually write configuration information	Panoramic Parking (AVM)
SP2057	Automatically write configuration information	Panoramic Parking (AVM)
SP2058	Hardware reset	Panoramic Parking (AVM)
SP2059	Software reset	Panoramic Parking (AVM)
SP2060	data input	Adaptive headlights (AFS)
SP2061	Manually write configuration information	Adaptive headlights (AFS)
SP2062	Automatically write configuration information	Adaptive headlights (AFS)
SP2063	Hardware reset	Adaptive headlights (AFS)
SP2064	Zero calibration	Adaptive headlights (AFS)
SP2065	data input	Electronic steering column lock (ESCL)
SP2066	Write VIN code	Electronic steering column lock (ESCL)
SP2067	Hardware reset	Electronic steering column lock (ESCL)
SP2068	Hardware reset	Seat Controller (DSM)
SP2069	Software reset	Seat Controller (DSM)
SP2070	Hardware reset	Wireless Charge Controller (WCM)
SP2071	Software reset	Wireless Charge Controller (WCM)
SP2072	Write VIN code	UMC Engine System (ME1788)
SP2073	Hardware reset	UMC Engine System (ME1788)
SP2074	Write VIN code	UMC Engine System MG1UA008 (UP8)
SP2075	Hardware reset	UMC Engine System MG1UA008 (UP8)
SP2076	Variable valve timing learning	UMC Engine System MG1UA008 (UP8)
SP2077	Reset particle load and accumulating ash load	UMC Engine System MG1UA008 (UP8)
SP2078	Reset GPF differential pressure learning value	UMC Engine System MG1UA008 (UP8)
SP2079	GPF regeneration test mode	UMC Engine System MG1UA008 (UP8)
SP2080	New ECU write particle load	UMC Engine System MG1UA008 (UP8)
SP2081	New ECU write cumulative gray load	UMC Engine System MG1UA008 (UP8)
SP2082	The new ECU writes the self-learning value of the differential pressure sensor	UMC Engine System MG1UA008 (UP8)
SP2083	Read software label	UMC Engine System MG1UA008 (UP8)
SP2084	Read (battery) ECU serial number	UMC Engine System MG1UA008 (UP8)
SP2085	Read battery code	UMC Engine System MG1UA008 (UP8)
SP2086	Write battery code	UMC Engine System MG1UA008 (UP8)
SP2087	Off-line test of fuel vapor leakage (DTESK diagnosis)	UMC Engine System MG1UA008 (UP8)
SP2088	Write VIN code	Delphi Engine System (MT62.1G)
SP2089	Write repair department code or test serial number	Delphi Engine System (MT62.1G)
SP2090	Hardware reset	Delphi Engine System (MT62.1G)
SP2091	Software reset	Delphi Engine System (MT62.1G)
SP2092	Read battery sensor battery ID	Delphi Engine System (MT62.1G)
SP2093	Read the battery sensor serial number	Delphi Engine System (MT62.1G)
SP2094	Read the battery sensor version number	Delphi Engine System (MT62.1G)
SP2095	Write battery sensor battery ID	Delphi Engine System (MT62.1G)
SP2096	Routine control GPF regeneration	Delphi Engine System (MT62.1G)
SP2097	Routine control mileage reset	Delphi Engine System (MT62.1G)
SP2098	Write carbon load quality and GPF ash mileage	Delphi Engine System (MT62.1G)
SP2099	Write VIN code	Delphi Engine System (MT92.1)
SP2100	Write repair department code or test serial number	Delphi Engine System (MT92.1)
SP2101	Hardware reset	Delphi Engine System (MT92.1)
SP2102	Software reset	Delphi Engine System (MT92.1)
SP2103	Read battery sensor battery ID	Delphi Engine System (MT92.1)
SP2104	Read the battery sensor serial number	Delphi Engine System (MT92.1)
SP2105	Read battery sensor version	Delphi Engine System (MT92.1)
SP2106	Write battery sensor battery ID	Delphi Engine System (MT92.1)
SP2107	Routine control GPF regeneration	Delphi Engine System (MT92.1)
SP2108	Routine control mileage reset	Delphi Engine System (MT92.1)
SP2109	Write carbon load quality and GPF ash mileage	Delphi Engine System (MT92.1)
SP2110	Write VIN code	Automatic transmission system (VT5)

SP2111	Write repair department code or test serial number	Automatic transmission system (VT5)
SP2112	Manually write configuration information	Automatic transmission system (VT5)
SP2113	Automatically write configuration information	Automatic transmission system (VT5)
SP2114	Hardware reset	Automatic transmission system (VT5)
SP2115	Switch key reset	Automatic transmission system (VT5)
SP2116	Software reset	Automatic transmission system (VT5)
SP2117	Clutch self-learning value reset	Automatic transmission system (VT5)
SP2118	Write VIN code	Automatic transmission system (RDC27)
SP2119	Manually write vehicle electrical configuration	Automatic transmission system (RDC27)
SP2120	Automatically write vehicle electrical configuration	Automatic transmission system (RDC27)
SP2121	Hardware reset	Automatic transmission system (RDC27)
SP2122	Forward clutch solenoid valve current control value adaptive value	Automatic transmission system (RDC27)
SP2123	Reverse clutch solenoid valve current control value adaptive value	Automatic transmission system (RDC27)
SP2124	Clear offline detection flag	Automatic transmission system (RDC27)
SP2125	Reset offline detection flag	Automatic transmission system (RDC27)
SP2126	Write VIN code	Automatic transmission system (VT3)
SP2127	Clear clutch self-learning value	Automatic transmission system (VT3)
SP2128	Clutch self-learning (manual method 1)	Automatic transmission system (VT3)
SP2129	Clutch self-learning (manual method 2)	Automatic transmission system (VT3)
SP2130	D file self-learning	Automatic transmission system (VT3)
SP2131	R file self-learning	Automatic transmission system (VT3)
SP2132	Manually write vehicle electrical configuration	Automatic transmission system (VT3)
SP2133	Automatically write vehicle electrical configuration	Automatic transmission system (VT3)
SP2134	Hardware reset	Automatic transmission system (VT3)
SP2135	Forward clutch solenoid valve current control value adaptive value	Automatic transmission system (VT3)
SP2136	Reverse clutch solenoid valve current control value adaptive value	Automatic transmission system (VT3)
SP2137	Clear offline detection flag	Automatic transmission system (VT3)
SP2138	Reset offline detection flag	Automatic transmission system (VT3)
SP2139	Hardware reset	Airbag (ABM)
SP2140	Write VIN code	Body Control System (BCM)
SP2141	Write antenna threshold	Body Control System (BCM)
SP2142	Write tire pressure sensor ID	Body Control System (BCM)
SP2143	Clear all tire pressure sensor IDs	Body Control System (BCM)
SP2144	Manually write configuration information	Body Control System (BCM)
SP2145	Automatically write configuration information	Body Control System (BCM)
SP2146	Hardware reset	Body Control System (BCM)
SP2147	After-sales function	Body Control System (BCM)
SP2148	Learn tire pressure sensor	Body Control System (BCM)
SP2149	Tire swap	Body Control System (BCM)
SP2150	Write VIN code	Electronic Power Steering (EPS)
SP2151	Hardware reset	Electronic Power Steering (EPS)
SP2152	Software reset	Electronic Power Steering (EPS)
SP2153	Corner zero calibration	Electronic Power Steering (EPS)
SP2154	Torque zero calibration	Electronic Power Steering (EPS)
SP2155	Clear the angle median data	Electronic Power Steering (EPS)
SP2156	Shielded average fuel consumption	Combination Instrument System (IC)
SP2157	Manually write configuration information	Combination Instrument System (IC)
SP2158	Automatically write configuration information	Combination Instrument System (IC)
SP2159	E-party initialization	Combination Instrument System (IC)
SP2160	Write VIN code	Combination Instrument System (IC)
SP2161	Hardware reset	Combination Instrument System (IC)
SP2162	Software reset	Combination Instrument System (IC)
SP2163	Hardware reset	Air Conditioning System (AC)
SP2164	Software reset	Air Conditioning System (AC)

SP2165	Write controller installation date	Electronic Parking System (EPB)
SP2166	Manually write configuration information	Electronic Parking System (EPB)
SP2167	Automatically write configuration information	Electronic Parking System (EPB)
SP2168	Hardware reset	Electronic Parking System (EPB)
SP2169	After-sales function	Electronic Parking System (EPB)
SP2170	Read parking brake status	Electronic Parking System (EPB)
SP2171	Maintenance open	Electronic Parking System (EPB)
SP2172	Maintenance shutdown	Electronic Parking System (EPB)
SP2173	Assembly inspection	Electronic Parking System (EPB)
SP2174	Two calipers clamping	Electronic Parking System (EPB)
SP2175	Two calipers release	Electronic Parking System (EPB)
SP2176	Left caliper clamping	Electronic Parking System (EPB)
SP2177	Right caliper clamping	Electronic Parking System (EPB)
SP2178	Left caliper release	Electronic Parking System (EPB)
SP2179	Right caliper release	Electronic Parking System (EPB)
SP2180	Manually write configuration information	Driving Recorder (DVR)
SP2181	Automatically write configuration information	Driving Recorder (DVR)
SP2182	Hardware reset	Driving Recorder (DVR)
SP2183	Software reset	Driving Recorder (DVR)
SP2184	Manually write configuration information	Panoramic Parking System (AVM)
SP2185	Automatically write configuration information	Panoramic Parking System (AVM)
SP2186	Hardware reset	Panoramic Parking System (AVM)
SP2187	Software reset	Panoramic Parking System (AVM)
SP2188	Hardware reset	Electronic shifter (GSM)
SP2189	Software reset	Electronic shifter (GSM)
SP2190	Write VIN code	Multi-function camera (MPC)
SP2191	Write sensitivity configuration factory value	Multi-function camera (MPC)
SP2192	Write switch configuration factory value	Multi-function camera (MPC)
SP2193	Write area code to configure factory value	Multi-function camera (MPC)
SP2194	Write function configuration	Multi-function camera (MPC)
SP2195	Write VIN lock	Multi-function camera (MPC)
SP2196	Write calibration tracking field	Multi-function camera (MPC)
SP2197	Manually write configuration information	Multi-function camera (MPC)
SP2198	Automatically write configuration information	Multi-function camera (MPC)
SP2199	Hardware reset	Multi-function camera (MPC)
SP2200	Service point SPC calibration	Multi-function camera (MPC)
SP2201	Manually write configuration information	Parking sensor (PDC)
SP2202	Automatically write configuration information	Parking sensor (PDC)
SP2203	Hardware reset	Parking sensor (PDC)
SP2204	Software reset	Parking sensor (PDC)
SP2205	Hardware reset	Electric tailgate (PLG)
SP2206	Software reset	Electric tailgate (PLG)
SP2207	Write VIN code	Audio Entertainment System (RRM)
SP2208	Manually write configuration information	Audio Entertainment System (RRM)
SP2209	Automatically write configuration information	Audio Entertainment System (RRM)
SP2210	Hardware reset	Audio Entertainment System (RRM)
SP2211	Software reset	Audio Entertainment System (RRM)
SP2212	Hardware reset	Shift actuator (SBW)
SP2213	Software reset	Shift actuator (SBW)
SP2214	self-study	Shift actuator (SBW)
SP2215	Manually write configuration information	Internet of Vehicles Control System (T-BOX)
SP2216	Automatically write configuration information	Internet of Vehicles Control System (T-BOX)
SP2217	Hardware reset	Internet of Vehicles Control System (T-BOX)
SP2218	Hardware reset	Main driver's seat controller (DSM Z)
SP2219	Software reset	Main driver's seat controller (DSM Z)
SP2220	Hardware reset	Front passenger seat controller (DSM F)

SP2221	Software reset	Front passenger seat controller (DSM F)
SP2222	Hardware reset	Wireless Charge Controller (WCM)
SP2223	Software reset	Wireless Charge Controller (WCM)
SP2224	Write VIN code	Delphi Engine System
SP2225	Write repair department code or test serial number	Delphi Engine System
SP2226	Hardware reset	Delphi Engine System
SP2227	Software reset	Delphi Engine System
SP2228	Read battery sensor battery ID	Delphi Engine System
SP2229	Read the battery sensor serial number	Delphi Engine System
SP2230	Read battery sensor version	Delphi Engine System
SP2231	Write battery sensor battery ID	Delphi Engine System
SP2232	Routine control GPF regeneration	Delphi Engine System
SP2233	Routine control mileage reset	Delphi Engine System
SP2234	Write carbon load quality and GPF ash mileage	Delphi Engine System
SP2235	Write VIN code	UMC Engine System
SP2236	Hardware reset	UMC Engine System
SP2237	Variable valve timing learning	UMC Engine System
SP2238	Reset particle load and accumulating ash load	UMC Engine System
SP2239	Reset GPF differential pressure learning value	UMC Engine System
SP2240	GPF regeneration test mode	UMC Engine System
SP2241	New ECU write particle load	UMC Engine System
SP2242	New ECU write cumulative gray load	UMC Engine System
SP2243	The new ECU writes the self-learning value of the differential pressure sensor	UMC Engine System
SP2244	Read software label	UMC Engine System
SP2245	Read (battery) ECU serial number	UMC Engine System
SP2246	Read battery code	UMC Engine System
SP2247	Write battery code	UMC Engine System
SP2248	Off-line test of fuel vapor leakage (DTESK diagnosis)	UMC Engine System
SP2249	Write VIN code	Automatic transmission (Pivot)
SP2250	Hardware reset	Automatic transmission (Pivot)
SP2251	After-sales function	Automatic transmission (Pivot)
SP2252	Erase EOL data	Automatic transmission (Pivot)
SP2253	Write solenoid valve offset	Automatic transmission (Pivot)
SP2254	Check EOL data integrity	Automatic transmission (Pivot)
SP2255	Write VIN code	Automatic transmission (Landai)
SP2256	Manually write configuration information	Automatic transmission (Landai)
SP2257	Automatically write configuration information	Automatic transmission (Landai)
SP2258	Hardware reset	Automatic transmission (Landai)
SP2259	Manually write configuration information	Electronic Stability System (ESP)
SP2260	Automatically write configuration information	Electronic Stability System (ESP)
SP2261	Software reset	Electronic Stability System (ESP)
SP2262	Lateral acceleration sensor calibration (ESC)	Electronic Stability System (ESP)
SP2263	Longitudinal acceleration sensor calibration (ESC)	Electronic Stability System (ESP)
SP2264	Exhaust phase	Electronic Stability System (ESP)
SP2265	Filling stage	Electronic Stability System (ESP)
SP2266	Fill-in stage	Electronic Stability System (ESP)
SP2267	Automatic drainage	Electronic Stability System (ESP)
SP2268	Hydraulic pump test	Electronic Stability System (ESP)
SP2269	Write VIN code	Airbag Controller (ABM)
SP2270	Write airbag exclusive configuration	Airbag Controller (ABM)
SP2271	Write to activate the ignition mode	Airbag Controller (ABM)
SP2272	Write airbag configuration	Airbag Controller (ABM)
SP2273	Manually write configuration information	Airbag Controller (ABM)

SP2274	Automatically write configuration information	Airbag Controller (ABM)
SP2275	Hardware reset	Airbag Controller (ABM)
SP2276	Software reset	Airbag Controller (ABM)
SP2277	Write antenna threshold	Body Control Module (BCM)
SP2278	Write tire pressure sensor ID	Body Control Module (BCM)
SP2279	Write ECU serial number	Body Control Module (BCM)
SP2280	Write ECU manufacturing date	Body Control Module (BCM)
SP2281	Manually write configuration information	Body Control Module (BCM)
SP2282	Automatically write configuration information	Body Control Module (BCM)
SP2283	Hardware reset	Body Control Module (BCM)
SP2284	After-sales function	Body Control Module (BCM)
SP2285	Learn tire pressure sensor	Body Control Module (BCM)
SP2286	Tire swap	Body Control Module (BCM)
SP2287	Read the number of keys	Body Control Module (BCM)
SP2288	Write VIN code	Electronic Power Steering (EPS)
SP2289	Hardware reset	Electronic Power Steering (EPS)
SP2290	Software reset	Electronic Power Steering (EPS)
SP2291	Steering angle calibration	Electronic Power Steering (EPS)
SP2292	Erase steering angle calibration	Electronic Power Steering (EPS)
SP2293	Erase soft limit	Electronic Power Steering (EPS)
SP2294	Write VIN code	Combination Instrument (IC)
SP2295	Manually write configuration information	Combination Instrument (IC)
SP2296	Automatically write configuration information	Combination Instrument (IC)
SP2297	Write maintenance mileage	Combination Instrument (IC)
SP2298	Hardware reset	Combination Instrument (IC)
SP2299	Software reset	Combination Instrument (IC)
SP2300	Hardware reset	Air Conditioning System (AC)
SP2301	Software reset	Air Conditioning System (AC)
SP2302	Write controller installation date	Electronic Parking System (EPB)
SP2303	Manually write gearbox information	Electronic Parking System (EPB)
SP2304	Automatically write gearbox information	Electronic Parking System (EPB)
SP2305	Manually write configuration information	Electronic Parking System (EPB)
SP2306	Automatically write configuration information	Electronic Parking System (EPB)
SP2307	Hardware reset	Electronic Parking System (EPB)
SP2308	After-sales function	Electronic Parking System (EPB)
SP2309	Read parking brake status	Electronic Parking System (EPB)
SP2310	Maintenance open	Electronic Parking System (EPB)
SP2311	Maintenance shutdown	Electronic Parking System (EPB)
SP2312	Assembly inspection	Electronic Parking System (EPB)
SP2313	Two calipers clamping	Electronic Parking System (EPB)
SP2314	Two calipers release	Electronic Parking System (EPB)
SP2315	Left caliper clamping	Electronic Parking System (EPB)
SP2316	Right caliper clamping	Electronic Parking System (EPB)
SP2317	Left caliper release	Electronic Parking System (EPB)
SP2318	Right caliper release	Electronic Parking System (EPB)
SP2319	Manually write configuration information	Gateway system (GW)
SP2320	Automatically write configuration information	Gateway system (GW)
SP2321	Hardware reset	Gateway system (GW)
SP2322	Hardware reset	Shift controller (GSM)
SP2323	Software reset	Shift controller (GSM)
SP2324	Hardware reset	Shift actuator (SBW)
SP2325	Software reset	Shift actuator (SBW)
SP2326	SBW self-learning	Shift actuator (SBW)
SP2327	Write programming date	Four-wheel drive controller (AWD)
SP2328	Manually write configuration information	Four-wheel drive controller (AWD)
SP2329	Automatically write configuration information	Four-wheel drive controller (AWD)
SP2330	Hardware reset	Four-wheel drive controller (AWD)
SP2331	Manually write configuration information	Telematics module (T-BOX)
SP2332	Automatically write configuration information	Telematics module (T-BOX)
SP2333	Hardware reset	Telematics module (T-BOX)
SP2334	Hardware reset	Wireless Charge Controller (WCM)

SP2335	Software reset	Wireless Charge Controller (WCM)
SP2336	Manually write configuration information	Multiple Switch Controller (MSC)
SP2337	Automatically write configuration information	Multiple Switch Controller (MSC)
SP2338	Hardware reset	Multiple Switch Controller (MSC)
SP2339	Software reset	Multiple Switch Controller (MSC)
SP2340	Write VIN code	Audio Entertainment System (RRM)
SP2341	Manually write configuration information	Audio Entertainment System (RRM)
SP2342	Automatically write configuration information	Audio Entertainment System (RRM)
SP2343	Hardware reset	Audio Entertainment System (RRM)
SP2344	Software reset	Audio Entertainment System (RRM)
SP2345	Manually write configuration information	Panoramic Parking (AVM)
SP2346	Automatically write configuration information	Panoramic Parking (AVM)
SP2347	Hardware reset	Panoramic Parking (AVM)
SP2348	Software reset	Panoramic Parking (AVM)
SP2349	Manually write configuration information	Parking sensor (PDC)
SP2350	Automatically write configuration information	Parking sensor (PDC)
SP2351	Hardware reset	Parking sensor (PDC)
SP2352	Software reset	Parking sensor (PDC)
SP2353	Manually write configuration information	Driving Recorder (DVR)
SP2354	Automatically write configuration information	Driving Recorder (DVR)
SP2355	Hardware reset	Driving Recorder (DVR)
SP2356	Software reset	Driving Recorder (DVR)
SP2357	Hardware reset	Electric tailgate controller (PLG)
SP2358	Software reset	Electric tailgate controller (PLG)
SP2359	Hardware reset	Seat Controller (DSM)
SP2360	Software reset	Seat Controller (DSM)
SP2361	data input	Electronic steering column lock (ESCL)
SP2362	Write VIN code	Electronic steering column lock (ESCL)
SP2363	Hardware reset	Electronic steering column lock (ESCL)
SP2364	Write VIN code	Vehicle Controller (EVC)
SP2365	Write configuration code	Vehicle Controller (EVC)
SP2366	Static test	Vehicle Controller (EVC)
SP2367	Reset the VPM counter	Vehicle Controller (EVC)
SP2368	Copy the VPM counter	Vehicle Controller (EVC)
SP2369	Write VIN code	Power Electronic Box (PEB)
SP2370	Write VIN code	Direct Current Converter (DCDC)
SP2371	Write VIN code	On-board charger (OBC)
SP2372	Write VIN code	Battery Management System (BMS)
SP2373	Write BIN code	Battery Management System (BMS)
SP2374	Write VIN code	Body Control Module (BCM)
SP2375	Read configuration information	Body Control Module (BCM)
SP2376	Write configuration information (single item write)	Body Control Module (BCM)
SP2377	Write configuration code (load configuration write)	Body Control Module (BCM)
SP2378	Left front wheel ID	Body Control Module (BCM)
SP2379	Right front wheel ID	Body Control Module (BCM)
SP2380	Right rear wheel ID	Body Control Module (BCM)
SP2381	Rear left wheel ID	Body Control Module (BCM)
SP2382	Tire pressure matching	Body Control Module (BCM)
SP2383	Write VIN code	Vehicle Voice Control (VSP)
SP2384	Read configuration information	Vehicle Voice Control (VSP)
SP2385	Write configuration information (single item write)	Vehicle Voice Control (VSP)
SP2386	Write configuration code (load configuration write)	Vehicle Voice Control (VSP)
SP2387	Write VIN code	Airbag Controller (ACU)
SP2388	Read configuration	Airbag Controller (ACU)
SP2389	Write configuration information (single item write)	Airbag Controller (ACU)
SP2390	Write configuration code (load configuration write)	Airbag Controller (ACU)
SP2391	Write VIN code	Dashboard L1 (IP1)
SP2392	Read configuration	Dashboard L1 (IP1)
SP2393	Write configuration information (single item write)	Dashboard L1 (IP1)

SP2394	Write configuration code (load configuration write)	Dashboard L1 (IP1)
SP2395	Write network configuration B1	Dashboard L1 (IP1)
SP2396	Write network configuration B2	Dashboard L1 (IP1)
SP2397	Write network configuration B3	Dashboard L1 (IP1)
SP2398	Write network configuration B4	Dashboard L1 (IP1)
SP2399	Driving information reset	Dashboard L1 (IP1)
SP2400	Mileage information synchronization	Dashboard L1 (IP1)
SP2401	Maintenance information reset	Dashboard L1 (IP1)
SP2402	Computer initialization	Dashboard L1 (IP1)
SP2403	Write VIN code	Dashboard L2 (IP2)
SP2404	Read configuration	Dashboard L2 (IP2)
SP2405	Write configuration information (single item write)	Dashboard L2 (IP2)
SP2406	Write configuration code (load configuration write)	Dashboard L2 (IP2)
SP2407	Driving information reset	Dashboard L2 (IP2)
SP2408	Mileage information synchronization	Dashboard L2 (IP2)
SP2409	Maintenance information reset	Dashboard L2 (IP2)
SP2410	Write VIN code	Electronic Power Steering (EPS)
SP2411	Steering wheel angle calibration	Electronic Power Steering (EPS)
SP2412	Write VIN code	Anti-lock braking system (ABS)
SP2413	Read configuration information	Anti-lock braking system (ABS)
SP2414	Write configuration information (single item write)	Anti-lock braking system (ABS)
SP2415	Write configuration code (load configuration write)	Anti-lock braking system (ABS)
SP2416	FR (front right) hydraulic wheel inspection	Anti-lock braking system (ABS)
SP2417	FL (front left) hydraulic wheel inspection	Anti-lock braking system (ABS)
SP2418	RR (rear right) hydraulic wheel inspection	Anti-lock braking system (ABS)
SP2419	RL (left rear) hydraulic wheel inspection	Anti-lock braking system (ABS)
SP2420	Angle sensor calibration	Anti-lock braking system (ABS)
SP2421	Check target gear teeth	Anti-lock braking system (ABS)
SP2422	Steering wheel angle sensor	Anti-lock braking system (ABS)
SP2423	Lateral acceleration sensor	Anti-lock braking system (ABS)
SP2424	Master cylinder pressure sensor	Anti-lock braking system (ABS)
SP2425	Longitudinal acceleration sensor	Anti-lock braking system (ABS)
SP2426	Hydraulic oil filling and draining	Anti-lock braking system (ABS)
SP2427	Write VIN code	Multimedia (AUDIO)
SP2428	Read configuration	Multimedia (AUDIO)
SP2429	Write configuration information (single item write)	Multimedia (AUDIO)
SP2430	Write configuration code (load configuration write)	Multimedia (AUDIO)
SP2431	Write VIN code	Remote communication module (TBOX)
SP2432	Read configuration information	Remote communication module (TBOX)
SP2433	Write configuration information (single item write)	Remote communication module (TBOX)
SP2434	Write configuration code (load configuration write)	Remote communication module (TBOX)
SP2435	Write VIN code	Security Gateway 3 (S-GW3)
SP2436	Write configuration information	Security Gateway 3 (S-GW3)
SP2437	Write VIN code	Engine Management System (EMS)
SP2438	Write repair department code or test serial number	Engine Management System (EMS)
SP2439	Hardware reset	Engine Management System (EMS)
SP2440	Software reset	Engine Management System (EMS)
SP2441	Hardware reset	Battery Management System (BMS)
SP2442	Hardware reset	Motor Controller (PEU1)
SP2443	Software reset	Motor Controller (PEU1)

SP2444	Clear offset angle	Motor Controller (PEU1)
SP2445	Initial value of offset angle	Motor Controller (PEU1)
SP2446	Hardware reset	Motor Controller (PEU2)
SP2447	Software reset	Motor Controller (PEU2)
SP2448	Clear offset angle	Motor Controller (PEU2)
SP2449	Initial value of offset angle	Motor Controller (PEU2)
SP2450	Write VIN code	Hybrid Vehicle Controller (HCU)
SP2451	Manually write configuration information	Hybrid Vehicle Controller (HCU)
SP2452	Automatically write configuration information	Hybrid Vehicle Controller (HCU)
SP2453	Hardware reset	Hybrid Vehicle Controller (HCU)
SP2454	Write VIN code	Electronic Stability System (ESP)
SP2455	Write annotated status	Electronic Stability System (ESP)
SP2456	Write EOL status	Electronic Stability System (ESP)
SP2457	Software reset	Electronic Stability System (ESP)
SP2458	Wheel speed sensor test	Electronic Stability System (ESP)
SP2459	Speed limit off	Electronic Stability System (ESP)
SP2460	Speed limit enable	Electronic Stability System (ESP)
SP2461	Yaw rate calibration (ESP only)	Electronic Stability System (ESP)
SP2462	Write ECU client mode	Airbag (ABM)
SP2463	Hardware reset	Airbag (ABM)
SP2464	Software reset	Airbag (ABM)
SP2465	Write VIN code	Body Control System (BCM)
SP2466	Write antenna threshold	Body Control System (BCM)
SP2467	Write tire pressure sensor ID	Body Control System (BCM)
SP2468	Clear all tire pressure sensor IDs	Body Control System (BCM)
SP2469	Manually write configuration information	Body Control System (BCM)
SP2470	Automatically write configuration information	Body Control System (BCM)
SP2471	Hardware reset	Body Control System (BCM)
SP2472	After-sales function	Body Control System (BCM)
SP2473	Learn tire pressure sensor	Body Control System (BCM)
SP2474	Tire swap	Body Control System (BCM)
SP2475	Read the number of remote control keys	Body Control System (BCM)
SP2476	Manually write configuration information	Combination Instrument (IC)
SP2477	Automatically write configuration information	Combination Instrument (IC)
SP2478	Hardware reset	Combination Instrument (IC)
SP2479	Software reset	Combination Instrument (IC)
SP2480	Hardware reset	Air Conditioning System (AC)
SP2481	Write ECU manufacturing date	Thermal Management Controller (HMC)
SP2482	Hardware reset	Thermal Management Controller (HMC)
SP2483	Hardware reset	Electronic Hand Brake System (EPB)
SP2484	EPB performs maintenance release	Electronic Hand Brake System (EPB)
SP2485	Write EPL to automatically calibrate the maximum position AD value	Electronic parking lock controller (EPL)
SP2486	Write EPL to automatically calibrate the minimum position AD value	Electronic parking lock controller (EPL)
SP2487	Write EPL initialization command	Electronic parking lock controller (EPL)
SP2488	Hardware reset	Electronic parking lock controller (EPL)
SP2489	Hardware reset	Shifter module (GSM)
SP2490	Write VIN code	Audio Entertainment System (RRM)
SP2491	Manually write configuration information	Audio Entertainment System (RRM)
SP2492	Automatically write configuration information	Audio Entertainment System (RRM)
SP2493	Hardware reset	Audio Entertainment System (RRM)
SP2494	Software reset	Audio Entertainment System (RRM)
SP2495	Manually write configuration information	Telematics control module (T-BOX)
SP2496	Automatically write configuration information	Telematics control module (T-BOX)
SP2497	Hardware reset	Telematics control module (T-BOX)
SP2498	Hardware reset	Compressor Control Unit (CCU)
SP2499	Software reset	Compressor Control Unit (CCU)
SP2500	Software reset	Panoramic Parking System (AVM)
SP2501	Write VIN code	Engine Management System (EMS)

SP2502	Write repair department code or test serial number	Engine Management System (EMS)
SP2503	Hardware reset	Engine Management System (EMS)
SP2504	Software reset	Engine Management System (EMS)
SP2505	Hardware reset	Battery Management System (BMS)
SP2506	Software reset	Battery Management System (BMS)
SP2507	Hardware reset	Motor Controller (PEU1)
SP2508	Software reset	Motor Controller (PEU1)
SP2509	Clear offset angle	Motor Controller (PEU1)
SP2510	Initial value of offset angle	Motor Controller (PEU1)
SP2511	Hardware reset	Motor Controller (PEU2)
SP2512	Software reset	Motor Controller (PEU2)
SP2513	Clear offset angle	Motor Controller (PEU2)
SP2514	Initial value of offset angle	Motor Controller (PEU2)
SP2515	Write VIN code	Hybrid Vehicle Controller (HCU)
SP2516	Manually write configuration information	Hybrid Vehicle Controller (HCU)
SP2517	Automatically write configuration information	Hybrid Vehicle Controller (HCU)
SP2518	Hardware reset	Hybrid Vehicle Controller (HCU)
SP2519	Write VIN code	Electronic Stability System (ESP)
SP2520	Write annotated status	Electronic Stability System (ESP)
SP2521	Write EOL status	Electronic Stability System (ESP)
SP2522	Software reset	Electronic Stability System (ESP)
SP2523	Wheel speed sensor test	Electronic Stability System (ESP)
SP2524	Speed limit off	Electronic Stability System (ESP)
SP2525	Speed limit enable	Electronic Stability System (ESP)
SP2526	Yaw rate calibration (ESP only)	Electronic Stability System (ESP)
SP2527	Write ECU client mode	Airbag (ABM)
SP2528	Hardware reset	Airbag (ABM)
SP2529	Software reset	Airbag (ABM)
SP2530	Write VIN code	Body Control System (BCM)
SP2531	Write antenna threshold	Body Control System (BCM)
SP2532	Write tire pressure sensor ID	Body Control System (BCM)
SP2533	Clear all tire pressure sensor IDs	Body Control System (BCM)
SP2534	Manually write configuration information	Body Control System (BCM)
SP2535	Automatically write configuration information	Body Control System (BCM)
SP2536	Hardware reset	Body Control System (BCM)
SP2537	After-sales function	Body Control System (BCM)
SP2538	Learn tire pressure sensor	Body Control System (BCM)
SP2539	Tire swap	Body Control System (BCM)
SP2540	Read the number of remote control keys	Body Control System (BCM)
SP2541	Manually write configuration information	Combination Instrument (IC)
SP2542	Automatically write configuration information	Combination Instrument (IC)
SP2543	Hardware reset	Combination Instrument (IC)
SP2544	Software reset	Combination Instrument (IC)
SP2545	Hardware reset	Air Conditioning System (AC)
SP2546	Write ECU manufacturing date	Thermal Management Controller (HMC)
SP2547	Hardware reset	Thermal Management Controller (HMC)
SP2548	Hardware reset	Electronic Hand Brake System (EPB)
SP2549	EPB performs maintenance release	Electronic Hand Brake System (EPB)
SP2550	Hardware reset	Thermistor heater (PTCH)
SP2551	Write EPL to automatically calibrate the maximum position AD value	Electronic parking lock controller (EPL)
SP2552	Write EPL to automatically calibrate the minimum position AD value	Electronic parking lock controller (EPL)
SP2553	Write EPL initialization command	Electronic parking lock controller (EPL)
SP2554	Hardware reset	Electronic parking lock controller (EPL)
SP2555	Hardware reset	Shifter module (GSM)
SP2556	Write VIN code	Audio Entertainment System (RRM)
SP2557	Manually write configuration information	Audio Entertainment System (RRM)
SP2558	Automatically write configuration information	Audio Entertainment System (RRM)
SP2559	Hardware reset	Audio Entertainment System (RRM)
SP2560	Software reset	Audio Entertainment System (RRM)
SP2561	Manually write configuration information	Telematics control module (T-BOX)

SP2562	Automatically write configuration information	Telematics control module (T-BOX)
SP2563	Hardware reset	Telematics control module (T-BOX)
SP2564	Hardware reset	Compressor Control Unit (CCU)
SP2565	Software reset	Compressor Control Unit (CCU)
SP2566	Software reset	Panoramic Parking System (AVM)
SP2567	Write VIN code	Vehicle Controller (VCU)
SP2568	Manually write configuration information	Vehicle Controller (VCU)
SP2569	Automatically write configuration information	Vehicle Controller (VCU)
SP2570	Hardware reset	Motor Control Unit (MCU)
SP2571	Switch key reset	Motor Control Unit (MCU)
SP2572	Software reset	Motor Control Unit (MCU)
SP2573	Manually write configuration information	Motor Control Unit (MCU)
SP2574	Automatically write configuration information	Motor Control Unit (MCU)
SP2575	Software reset	ESC/Electronic Stability System (ESC)
SP2576	Write annotated status	ESC/Electronic Stability System (ESC)
SP2577	Write EOL status	ESC/Electronic Stability System (ESC)
SP2578	Write configuration information	ESC/Electronic Stability System (ESC)
SP2579	Software reset	ESC/Electronic Stability System (ESC)
SP2580	Wheel speed sensor test	ESC/Electronic Stability System (ESC)
SP2581	Speed limit off	ESC/Electronic Stability System (ESC)
SP2582	Speed limit enable	ESC/Electronic Stability System (ESC)
SP2583	Inertial sensor calibration (ESP only)	ESC/Electronic Stability System (ESC)
SP2584	Repair exhaust	ESC/Electronic Stability System (ESC)
SP2585	Write VIN code	Airbag system (ABM)
SP2586	Write airbag exclusive configuration	Airbag system (ABM)
SP2587	Write to activate the ignition mode	Airbag system (ABM)
SP2588	Write airbag configuration	Airbag system (ABM)
SP2589	Manually write configuration information	Airbag system (ABM)
SP2590	Automatically write configuration information	Airbag system (ABM)
SP2591	Hardware reset	Airbag system (ABM)
SP2592	Write ECU serial number	Body Control Module (BCM)
SP2593	Write VIN code	Body Control Module (BCM)
SP2594	Write antenna threshold	Body Control Module (BCM)
SP2595	Write tire pressure sensor ID	Body Control Module (BCM)
SP2596	Clear all tire pressure sensor IDs	Body Control Module (BCM)
SP2597	Manually write configuration information	Body Control Module (BCM)
SP2598	Automatically write configuration information	Body Control Module (BCM)
SP2599	Hardware reset	Body Control Module (BCM)
SP2600	After-sales function	Body Control Module (BCM)
SP2601	Learn tire pressure sensor	Body Control Module (BCM)
SP2602	Write VIN code	Electronic Power Steering (EPS)
SP2603	Hardware reset	Electronic Power Steering (EPS)
SP2604	Software reset	Electronic Power Steering (EPS)
SP2605	Corner zero calibration	Electronic Power Steering (EPS)
SP2606	Torque zero calibration	Electronic Power Steering (EPS)
SP2607	Clear the angle median data	Electronic Power Steering (EPS)
SP2608	Write VIN code	Combination Instrument (IC)
SP2609	Write maintenance mileage	Combination Instrument (IC)
SP2610	Manually write configuration information	Combination Instrument (IC)
SP2611	Automatically write configuration information	Combination Instrument (IC)
SP2612	Hardware reset	Combination Instrument (IC)
SP2613	Software reset	Combination Instrument (IC)
SP2614	Hardware reset	Air Conditioning (AC)
SP2615	Software reset	Air Conditioning (AC)
SP2616	Manually write configuration information	Electric parking brake system (EPB)
SP2617	Automatically write configuration information	Electric parking brake system (EPB)
SP2618	Hardware reset	Electric parking brake system (EPB)
SP2619	Clamping	Electric parking brake system (EPB)
SP2620	freed	Electric parking brake system (EPB)
SP2621	Increased gap	Electric parking brake system (EPB)
SP2622	Narrow the gap	Electric parking brake system (EPB)

SP2623	Clamping	Electric parking brake system (EPB)
SP2624	freed	Electric parking brake system (EPB)
SP2625	Increased gap	Electric parking brake system (EPB)
SP2626	Narrow the gap	Electric parking brake system (EPB)
SP2627	Clamping	Electric parking brake system (EPB)
SP2628	freed	Electric parking brake system (EPB)
SP2629	Increased gap	Electric parking brake system (EPB)
SP2630	Narrow the gap	Electric parking brake system (EPB)
SP2631	G-sensor calibration	Electric parking brake system (EPB)
SP2632	Assembly inspection	Electric parking brake system (EPB)
SP2633	Hardware reset	Direct Current Converter (DCDC)
SP2634	Software reset	Direct Current Converter (DCDC)
SP2635	Manually write configuration information	Direct Current Converter (DCDC)
SP2636	Automatically write configuration information	Direct Current Converter (DCDC)
SP2637	Hardware reset	On-board charger (OBC)
SP2638	Hardware reset	Electronic parking lock controller (EPL)
SP2639	Switch key reset	Electronic parking lock controller (EPL)
SP2640	Software reset	Electronic parking lock controller (EPL)
SP2641	VIN code	Multi-function camera (MPC)
SP2642	ECU serial number data identifier	Multi-function camera (MPC)
SP2643	Sensitivity configuration factory value	Multi-function camera (MPC)
SP2644	Switch configuration factory value	Multi-function camera (MPC)
SP2645	Area code configuration factory value	Multi-function camera (MPC)
SP2646	Speed configuration factory value	Multi-function camera (MPC)
SP2647	Driver sensitivity selection value	Multi-function camera (MPC)
SP2648	Driver switch selection value	Multi-function camera (MPC)
SP2649	Driver area code selection value	Multi-function camera (MPC)
SP2650	Driver speed configuration selection value	Multi-function camera (MPC)
SP2651	Calibration tracking domain	Multi-function camera (MPC)
SP2652	Hardware reset	Ruivang Thermal Management Controller
SP2653	Software reset	Daming Thermal Management Controller
SP2654	Write VIN code	Shifter module (GSM)
SP2655	Manually write configuration information	Shifter module (GSM)
SP2656	Automatically write configuration information	Shifter module (GSM)
SP2657	Hardware reset	Shifter module (GSM)
SP2658	Software reset	Shifter module (GSM)
SP2659	Write VIN code	Remote communication unit (T-BOX)
SP2660	Manually write configuration information	Remote communication unit (T-BOX)
SP2661	Automatically write configuration information	Remote communication unit (T-BOX)
SP2662	Hardware reset	Remote communication unit (T-BOX)
SP2663	Software reset	Remote communication unit (T-BOX)
SP2664	Hardware reset	Electric Back Door (PLG)
SP2665	Software reset	Electric Back Door (PLG)
SP2666	Manually write configuration information	Radar Controller (PDC)
SP2667	Automatically write configuration information	Radar Controller (PDC)
SP2668	Hardware reset	Radar Controller (PDC)
SP2669	Software reset	Radar Controller (PDC)
SP2670	Write VIN code	Audio Entertainment System (RRM)
SP2671	Manually write configuration information	Audio Entertainment System (RRM)
SP2672	Automatically write configuration information	Audio Entertainment System (RRM)
SP2673	Hardware reset	Audio Entertainment System (RRM)
SP2674	Software reset	Audio Entertainment System (RRM)
SP2675	Manually write configuration information	Panoramic Parking (AVM)
SP2676	Automatically write configuration information	Panoramic Parking (AVM)
SP2677	Hardware reset	Panoramic Parking (AVM)
SP2678	Software reset	Panoramic Parking (AVM)

SP2679	Manually write configuration information	Main driver's seat controller (DSM_Z)
SP2680	Automatically write configuration information	Main driver's seat controller (DSM_Z)
SP2681	Hardware reset	Main driver's seat controller (DSM_Z)
SP2682	Software reset	Main driver's seat controller (DSM_Z)
SP2683	Hardware reset	Front passenger seat controller (DSM_F)
SP2684	Manually write configuration information	Driving Recorder (DVR)
SP2685	Automatically write configuration information	Driving Recorder (DVR)
SP2686	Hardware reset	Driving Recorder (DVR)
SP2687	Software reset	Driving Recorder (DVR)
SP2688	Hardware reset	Wireless Charge Controller (WCM)
SP2689	Software reset	Wireless Charge Controller (WCM)
SP2690	Write VIN code	Vehicle Controller (VCU)
SP2691	Write motor number	Motor Control Unit (MCU)
SP2692	Repair exhaust	BOSCH ABS 9.0
SP2693	Wheel speed sensor test	BOSCH ABS 9.0
SP2694	Read VIN code	BOSCH ABS 9.0
SP2695	Write VIN code	BOSCH ABS 9.0
SP2696	Incomplete raise	BOSCH ABS 9.0
SP2697	Filling is complete, the system is available	BOSCH ABS 9.0
SP2698	Filling is complete, the system is unavailable	BOSCH ABS 9.0
SP2699	EOL test is not completed	BOSCH ABS 9.0
SP2700	The EOL test is complete and the system is available	BOSCH ABS 9.0
SP2701	The EOL test is complete and the system is unavailable	BOSCH ABS 9.0
SP2702	Read VIN code	Asia-Pacific integral hydraulic ABS
SP2703	Write VIN code	Asia-Pacific integral hydraulic ABS
SP2704	Write the last overhaul date of ECU	Airbag system (ABM)
SP2705	Write vehicle chassis number (VIN code)	Airbag system (ABM)
SP2706	ECU reset	Airbag system (ABM)
SP2707	Write VIN code	Instrument (IC)
SP2708	Write VIN code	Audio Entertainment System (RRM)
SP2709	Manually write configuration information	Audio Entertainment System (RRM)
SP2710	Automatically write configuration information	Audio Entertainment System (RRM)
SP2711	Hardware reset	Audio Entertainment System (RRM)
SP2712	Software reset	Audio Entertainment System (RRM)
SP2713	Manually write configuration information	Telematics module (T-BOX)
SP2714	Automatically write configuration information	Telematics module (T-BOX)
SP2715	Hardware reset	Telematics module (T-BOX)