



# Shenzhen Xtooltech Co., Ltd

## Fiat Function List V11.40

### Tips and Instructions:

The programming function only supports H6PRO, H6PRO Master Edition products.

- \* This feature is new.
- ✓ This feature is supported.
- ✗ This feature is not supported.
- ※ This feature is partially supported.

Vehicle	Model	Year/model	System	Read ECU Information	Read Trouble Code	Clear Trouble Code	Live Data	Action test	Special Functions
FIAT	500	2019	PCM (Powertrain Control Module)	✓	✓	✓	✓	✓	sp00001, sp00002, sp00003, sp00004, sp00005, sp00006, sp00007, sp00008, sp00009, sp00010
FIAT	500	2019	TCM (Transmission Control Module)	✓	✓	✓	✓	✓	sp00011, sp00012, sp00013, sp00014, sp00015
FIAT	500	2019	ABS (Anti-Lock Braking System)	✓	✓	✓	✓	✓	sp00016, sp00017
FIAT	500	2019	SRS (Supplemental Inflatable Restraint System, ORC)	✓	✓	✓	✓		
FIAT	500	2019	BCM (Body Control Module)	✓	✓	✓	✓		sp00018
FIAT	500	2019	HVAC (Heating Ventilation Air-Conditioning And Cooling)	✓	✓	✓	✓	✓	sp00019
FIAT	500	2019	IC (Instrument Cluster)	✓	✓	✓	✓	✓	sp00020, sp00021, sp00022, sp00023
FIAT	500	2019	RADIO (RADIO)	✓	✓	✓	✓		sp00024
FIAT	500	2019	Electronic Parking (EPB)	✓	✓	✓			
FIAT	500	2019	EPS (Electric Power Steering)	✓	✓	✓	✓	✓	sp00025, sp00026
FIAT	500	2019	VTM (Vehicle Tracking Module)	✓	✓	✓	✓		
FIAT	500	2019	CTM (Convergence Telematic Module)	✓	✓	✓	✓	✓	sp00027
FIAT	500	2019	TPMS (Tire Pressure Monitoring System)	✓	✓	✓	✓	✓	sp00028, sp00029, sp00030, sp00031, sp00032, sp00033, sp00034, sp00035,
FIAT	500	2019	Regenerative brake controller module (RBC)	✓	✓	✓	✓		
FIAT	500	2018	PCM (Powertrain Control Module)	✓	✓	✓	✓	✓	sp00037, sp00038, sp00039, sp00040, sp00041, sp00042, sp00043, sp00044,
FIAT	500	2018	TCM (Transmission Control Module)	✓	✓	✓	✓		sp00047, sp00048, sp00049, sp00050, sp00051
FIAT	500	2018	ABS (Anti-Lock Braking System)	✓	✓	✓	✓	✓	sp00052, sp00053
FIAT	500	2018	SRS (Supplemental Inflatable Restraint System, ORC)	✓	✓	✓	✓		
FIAT	500	2018	BCM (Body Control Module)	✓	✓	✓	✓		sp00054
FIAT	500	2018	HVAC (Heating Ventilation Air-Conditioning And Cooling)	✓	✓	✓	✓	✓	sp00055
FIAT	500	2018	IC (Instrument Cluster)	✓	✓	✓	✓	✓	sp00056, sp00057, sp00058, sp00059
FIAT	500	2018	RADIO (RADIO)	✓	✓	✓	✓		sp00060
FIAT	500	2018	Electronic Parking (EPB)	✓	✓	✓			
FIAT	500	2018	EPS (Electric Power Steering)	✓	✓	✓	✓	✓	sp00061, sp00062
FIAT	500	2018	VTM (Vehicle Tracking Module)	✓	✓	✓	✓		
FIAT	500	2018	CTM (Convergence Telematic Module)	✓	✓	✓	✓	✓	sp00063
FIAT	500	2018	TPMS (Tire Pressure Monitoring System)	✓	✓	✓	✓	✓	sp00064, sp00065, sp00066, sp00067, sp00068, sp00069, sp00070, sp00071, sp00072
FIAT	500	2018	Regenerative brake controller module (RBC)	✓	✓	✓	✓		
FIAT	500	2017	PCM (Powertrain Control Module)	✓	✓	✓	✓	✓	sp00073, sp00074, sp00075, sp00076, sp00077, sp00078, sp00079, sp00080,
FIAT	500	2017	TCM (Transmission Control Module)	✓	✓	✓	✓		sp00083, sp00084, sp00085, sp00086, sp00087
FIAT	500	2017	ABS (Anti-Lock Braking System)	✓	✓	✓	✓	✓	sp00088, sp00089
FIAT	500	2017	SRS (Supplemental Inflatable Restraint System, ORC)	✓	✓	✓	✓		

FIAT	500	2017	BCM (Body Control Module)	✓	✓	✓	✓		sp00090
FIAT	500	2017	HVAC (Heating Ventilation Air-Conditioning And Cooling)	✓	✓	✓	✓	✓	sp00091
FIAT	500	2017	IC (Instrument Cluster)	✓	✓	✓	✓	✓	sp00092, sp00093, sp00094, sp00095
FIAT	500	2017	RADIO (RADIO)	✓	✓	✓	✓		sp00096
FIAT	500	2017	Electronic Parking(EPB)	✓	✓	✓	✓		
FIAT	500	2017	EPS (Electric Power Steering)	✓	✓	✓	✓	✓	sp00097, sp00098
FIAT	500	2017	VTM (Vehicle Tracking Module)	✓	✓	✓	✓	✓	
FIAT	500	2017	CTM (Convergence Telematic Module)	✓	✓	✓	✓	✓	sp00099
FIAT	500	2017	TPMS (Tire Pressure Monitoring System)	✓	✓	✓	✓	✓	sp00100, sp00101, sp00102, sp00103, sp00104, sp00105, sp00106, sp00107,
FIAT	500	2017	Regenerative brake controller module(RBC)	✓	✓	✓	✓		
FIAT	500	2016	PCM (Powertrain Control Module)	✓	✓	✓	✓	✓	sp00109, sp00110, sp00111, sp00112, sp00113, sp00114, sp00115, sp00116, sp00117, sp00118
FIAT	500	2016	TCM (Transmission Control Module)	✓	✓	✓	✓		sp00119, sp00120, sp00121, sp00122, sp00123
FIAT	500	2016	ABS (Anti-Lock Braking System)	✓	✓	✓	✓	✓	sp00124, sp00125
FIAT	500	2016	SRS (Supplemental Inflatable Restraint System, ORC)	✓	✓	✓	✓		
FIAT	500	2016	BCM (Body Control Module)	✓	✓	✓	✓		sp00126
FIAT	500	2016	HVAC (Heating Ventilation Air-Conditioning And Cooling)	✓	✓	✓	✓	✓	sp00127
FIAT	500	2016	IC (Instrument Cluster)	✓	✓	✓	✓	✓	sp00128, sp00129, sp00130, sp00131
FIAT	500	2016	RADIO (RADIO)	✓	✓	✓	✓	✓	sp00132
FIAT	500	2016	Electronic Parking(EPB)	✓	✓	✓	✓		
FIAT	500	2016	EPS (Electric Power Steering)	✓	✓	✓	✓	✓	sp00133, sp00134
FIAT	500	2016	VTM (Vehicle Tracking Module)	✓	✓	✓	✓		
FIAT	500	2016	CTM (Convergence Telematic Module)	✓	✓	✓	✓	✓	sp00135
FIAT	500	2016	TPMS (Tire Pressure Monitoring System)	✓	✓	✓	✓	✓	sp00136, sp00137, sp00138, sp00139, sp00140, sp00141, sp00142, sp00143,
FIAT	500	2016	Regenerative brake controller module(RBC)	✓	✓	✓	✓		
FIAT	500	2015	PCM (Powertrain Control Module)	✓	✓	✓	✓	✓	sp00145, sp00146, sp00147, sp00148, sp00149, sp00150, sp00151, sp00152
FIAT	500	2015	TCM (Transmission Control Module)	✓	✓	✓	✓		sp00153, sp00154, sp00155, sp00156, sp00157
FIAT	500	2015	ABS (Anti-Lock Braking System)	✓	✓	✓	✓	✓	sp00158, sp00159
FIAT	500	2015	SRS (Supplemental Inflatable Restraint System, ORC)	✓	✓	✓	✓		
FIAT	500	2015	VTM (Vehicle Tracking Module)	✓	✓	✓	✓		
FIAT	500	2015	TPMS (Tire Pressure Monitoring System)	✓	✓	✓	✓	✓	sp00160, sp00161, sp00162, sp00163, sp00164, sp00165, sp00166, sp00167,
FIAT	500	2015	RADIO (RADIO)	✓	✓	✓	✓		sp00169
FIAT	500	2015	IC (Instrument Cluster)	✓	✓	✓	✓	✓	sp00170, sp00171, sp00172, sp00173
FIAT	500	2015	HVAC (Heating Ventilation Air-Conditioning And Cooling)	✓	✓	✓	✓	✓	sp00174
FIAT	500	2015	EPS (Electric Power Steering)	✓	✓	✓	✓	✓	sp00175, sp00176
FIAT	500	2015	EPB (Electrical Parking Brake)	✓	✓	✓			
FIAT	500	2015	CTM (Convergence Telematic Module)	✓	✓	✓	✓	✓	sp00177
FIAT	500	2015	BCM (Body Control Module)	✓	✓	✓	✓		sp00178
FIAT	500	2014	PCM (Powertrain Control Module)	✓	✓	✓	✓	✓	
FIAT	500	2014	TCM (Transmission Control Module)	✓	✓	✓	✓		sp00179, sp00180, sp00181, sp00182, sp00183
FIAT	500	2014	ABS (Anti-Lock Braking System)	✓	✓	✓	✓	✓	sp00184, sp00185
FIAT	500	2014	SRS (Supplemental Inflatable Restraint System, ORC)	✓	✓	✓	✓		
FIAT	500	2014	VTM (Vehicle Tracking Module)	✓	✓	✓	✓		
FIAT	500	2014	TPMS (Tire Pressure Monitoring System)	✓	✓	✓	✓	✓	sp00186, sp00187, sp00188, sp00189, sp00190, sp00191, sp00192, sp00193,
FIAT	500	2014	RADIO (RADIO)	✓	✓	✓	✓		sp00195
FIAT	500	2014	IC (Instrument Cluster)	✓	✓	✓	✓	✓	sp00196, sp00197, sp00198, sp00199
FIAT	500	2014	HVAC (Heating Ventilation Air-Conditioning And Cooling)	✓	✓	✓	✓	✓	sp00200

FIAT	500	2014	EPS (Electric Power Steering)	✓	✓	✓	✓	✓	sp00201, sp00202
FIAT	500	2014	EPB (Electrical Parking Brake)	✓	✓	✓			
FIAT	500	2014	CTM (Convergence Telematic Module)	✓	✓	✓	✓	✓	sp00203
FIAT	500	2014	BCM (Body Control Module)	✓	✓	✓	✓		sp00204
FIAT	500	2013	PCM (Powertrain Control Module)	✓	✓	✓	✓	✓	sp00205, sp00206, sp00207, sp00208, sp00209, sp00210, sp00211, sp00212,
FIAT	500	2013	TCM (Transmission Control Module)	✓	✓	✓	✓		sp00215, sp00216, sp00217, sp00218, sp00219
FIAT	500	2013	ABS (Anti-Lock Braking System)	✓	✓	✓	✓	✓	sp00220, sp00221
FIAT	500	2013	SRS (Supplemental Inflatable Restraint System, ORC)	✓	✓	✓	✓	✓	
FIAT	500	2013	VTM (Vehicle Tracking Module)	✓	✓	✓	✓		
FIAT	500	2013	TPMS (Tire Pressure Monitoring System)	✓	✓	✓	✓	✓	sp00222, sp00223, sp00224, sp00225, sp00226, sp00227, sp00228, sp00229,
FIAT	500	2013	RADIO (RADIO)	✓	✓	✓	✓		sp00231
FIAT	500	2013	IC (Instrument Cluster)	✓	✓	✓	✓	✓	sp00232, sp00233, sp00234, sp00235
FIAT	500	2013	HVAC (Heating Ventilation Air-Conditioning And Cooling)	✓	✓	✓	✓	✓	sp00236
FIAT	500	2013	EPS (Electric Power Steering)	✓	✓	✓	✓	✓	sp00237, sp00238
FIAT	500	2013	EPB (Electrical Parking Brake)	✓	✓	✓			
FIAT	500	2013	CTM (Convergence Telematic Module)	✓	✓	✓	✓	✓	sp00239
FIAT	500	2013	BCM (Body Control Module)	✓	✓	✓	✓		sp00240
FIAT	500	2012	PCM (Powertrain Control Module)	✓	✓	✓	✓	✓	sp00241, sp00242, sp00243, sp00244, sp00245, sp00246, sp00247, sp00248,
FIAT	500	2012	TCM (Transmission Control Module)	✓	✓	✓	✓		sp00251, sp00252, sp00253, sp00254, sp00255
FIAT	500	2012	ABS (Anti-Lock Braking System)	✓	✓	✓	✓	✓	sp00256, sp00257
FIAT	500	2012	SRS (Supplemental Inflatable Restraint System, ORC)	✓	✓	✓	✓		
FIAT	500	2012	VTM (Vehicle Tracking Module)	✓	✓	✓	✓		
FIAT	500	2012	TPMS (Tire Pressure Monitoring System)	✓	✓	✓	✓	✓	sp00258, sp00259, sp00260, sp00261, sp00262, sp00263, sp00264, sp00265,
FIAT	500	2012	RADIO (RADIO)	✓	✓	✓	✓		sp00267
FIAT	500	2012	IC (Instrument Cluster)	✓	✓	✓	✓	✓	sp00268, sp00269, sp00270, sp00271
FIAT	500	2012	HVAC (Heating Ventilation Air-Conditioning And Cooling)	✓	✓	✓	✓	✓	sp00272
FIAT	500	2012	EPS (Electric Power Steering)	✓	✓	✓	✓	✓	sp00273, sp00274
FIAT	500	2012	EPB (Electrical Parking Brake)	✓	✓	✓			
FIAT	500	2012	CTM (Convergence Telematic Module)	✓	✓	✓	✓	✓	sp00275
FIAT	500	2012	BCM (Body Control Module)	✓	✓	✓	✓		sp00276
FIAT	500E(500)	2015	Electronic Vehicle Control Unit(EVCU)		✓	✓			
FIAT	500E(500)	2015	BCM (Body Control Module)	✓	✓	✓	✓		sp00277
FIAT	500E(500)	2015	IC (Instrument Cluster)	✓	✓	✓	✓	✓	sp00278, sp00279, sp00280, sp00281
FIAT	500E(500)	2015	HVAC (Heating Ventilation Air-Conditioning And Cooling)	✓	✓	✓	✓	✓	sp00282
FIAT	500E(500)	2015	SRS (Supplemental Inflatable Restraint System, ORC)	✓	✓	✓	✓		
FIAT	500E(500)	2015	ABS (Anti-Lock Braking System)	✓	✓	✓	✓	✓	sp00283, sp00284
FIAT	500E(500)	2015	TPMS (Tire Pressure Monitoring System)	✓	✓	✓	✓	✓	sp00285, sp00286, sp00287, sp00288, sp00289, sp00290, sp00291, sp00292,
FIAT	500E(500)	2015	CTM (Convergence Telematic Module)	✓	✓	✓	✓	✓	sp00294
FIAT	500E(500)	2015	EPS (Electric Power Steering)	✓	✓	✓	✓	✓	sp00295, sp00296
FIAT	500E(500)	2015	Electronic Parking(EPB)	✓	✓	✓			
FIAT	500E(500)	2015	RADIO (RADIO)	✓	✓	✓	✓		sp00297
FIAT	500E(500)	2015	VTM (Vehicle Tracking Module)	✓	✓	✓	✓		
FIAT	500E(500)	2015	Battery Pack Control Module(BPCM)		✓	✓			
FIAT	500E(500)	2015	ESM (Electronic Shifter Module)		✓	✓			
FIAT	500E(500)	2015	Electric Air Conditioning Compressor (EAC)		✓	✓			
FIAT	500E(500)	2015	On-Board Charging Module(OBCM)		✓	✓			
FIAT	500E(500)	2015	Power Inverter Module(PIM)		✓	✓			
FIAT	500E(500)	2015	Regenerative Brake Controller Module(RBC)		✓	✓			

FIAT	500E	2015	Electronic Vehicle Control Unit(EVCU)		✓	✓			
FIAT	500E	2015	BCM (Body Control Module)	✓	✓	✓	✓		sp00298
FIAT	500E	2015	IC (Instrument Cluster)	✓	✓	✓	✓	✓	sp00299, sp00300, sp00301, sp00302
FIAT	500E	2015	HVAC (Heating Ventilation Air-Conditioning And Cooling)	✓	✓	✓	✓	✓	sp00303
FIAT	500E	2015	SRS (Supplemental Inflatable Restraint System, ORC)	✓	✓	✓	✓		
FIAT	500E	2015	ABS (Anti-Lock Braking System)	✓	✓	✓	✓	✓	sp00304, sp00305
FIAT	500E	2015	TPMS (Tire Pressure Monitoring System)	✓	✓	✓	✓	✓	sp00306, sp00307, sp00308, sp00309, sp00310, sp00311, sp00312, sp00313, sp00314
FIAT	500E	2015	CTM (Convergence Telematic Module)	✓	✓	✓	✓	✓	sp00315
FIAT	500E	2015	EPS (Electric Power Steering)	✓	✓	✓	✓	✓	sp00316, sp00317
FIAT	500E	2015	Electronic Parking(EPB)	✓	✓	✓			
FIAT	500E	2015	RADIO (RADIO)	✓	✓	✓	✓		sp00318
FIAT	500E	2015	VTM (Vehicle Tracking Module)	✓	✓	✓	✓		
FIAT	500E	2015	Battery Pack Control Module(BPCM)		✓	✓			
FIAT	500E	2015	ESM (Electronic Shifter Module)		✓	✓			
FIAT	500E	2015	Electric Air Conditioning Compressor(EAC)		✓	✓			
FIAT	500E	2015	On-Board Charging Module(OBCM)		✓	✓			
FIAT	500E	2015	Power Inverter Module(PIM)		✓	✓			
FIAT	500E	2015	Regenerative Brake Controller Module(RBC)		✓	✓			
FIAT	500BEV	2021	Electronic Vehicle Control Unit(EVCU)		✓	✓			
FIAT	500BEV	2021	BCM (Body Control Module)		✓	✓			
FIAT	500BEV	2021	IPC (Instrument Panel)		✓	✓			
FIAT	500BEV	2021	ACC (Adaptive Cruise Control)		✓	✓			
FIAT	500BEV	2021	Telematics Box Module 2(TBM2)		✓	✓			
FIAT	500BEV	2021	Battery Pack Control Module(BPCM)		✓	✓			
FIAT	500BEV	2021	ESM (Electronic Shifter Module)		✓	✓			
FIAT	500BEV	2021	Window Smart Motor-Driver (WSMD)		✓	✓			
FIAT	500BEV	2021	Window Smart Motor-Passenger (WSMP)		✓	✓			
FIAT	500BEV	2021	Sunroof Control Module(RCU)		✓	✓			
FIAT	500BEV	2021	Integrated Dual Charging Module(IDC)		✓	✓			
FIAT	500BEV	2021	AMP (Amplifier)		✓	✓			
FIAT	500BEV	2021	ICS (Integrated Center Stack)		✓	✓			
FIAT	500BEV	2021	HVAC (Heat, Ventilation And A/C)		✓	✓			
FIAT	500BEV	2021	ETM (Entertainment Telematic Module)		✓	✓			
FIAT	500BEV	2021	Driver Door LatchModule (DDLML)		✓	✓			
FIAT	500BEV	2021	Passenger Door Latch Module(PDLM)		✓	✓			
FIAT	500BEV	2021	Display Module(DSM)		✓	✓			
FIAT	500BEV	2021	EMCM (Entertainment Multimedia Control Module)		✓	✓			
FIAT	500BEV	2021	SRS (Supplemental Inflatable Restraint System, ORC)		✓	✓			
FIAT	500BEV	2021	ABS (Anti-Lock Braking System)		✓	✓			
FIAT	500BEV	2021	EPS (Electric Power Steering)		✓	✓			
FIAT	500BEV	2021	PAM (Parking Aid Module)		✓	✓			
FIAT	500BEV	2021	HALF (Haptical Lane Feedback)		✓	✓			
FIAT	500BEV	2020	Electronic Vehicle Control Unit(EVCU)		✓	✓			
FIAT	500BEV	2020	BCM (Body Control Module)		✓	✓			
FIAT	500BEV	2020	IPC (Instrument Panel)		✓	✓			
FIAT	500BEV	2020	ACC (Adaptive Cruise Control)		✓	✓			
FIAT	500BEV	2020	Telematics Box Module 2(TBM2)		✓	✓			
FIAT	500BEV	2020	Battery Pack Control Module(BPCM)		✓	✓			
FIAT	500BEV	2020	ESM (Electronic Shifter Module)		✓	✓			
FIAT	500BEV	2020	Window Smart Motor-Driver (WSMD)		✓	✓			
FIAT	500BEV	2020	Window Smart Motor-Passenger (WSMP)		✓	✓			
FIAT	500BEV	2020	Sunroof Control Module(RCU)		✓	✓			
FIAT	500BEV	2020	Integrated Dual Charging Module(IDC)		✓	✓			
FIAT	500BEV	2020	AMP (Amplifier)		✓	✓			
FIAT	500BEV	2020	ICS (Integrated Center Stack)		✓	✓			

FIAT	500BEV	2020	HVAC (Heat, Ventilation And A/C)		✓	✓				
FIAT	500BEV	2020	ETM (Entertainment Telematic Module)		✓	✓				
FIAT	500BEV	2020	Driver Door LatchModule (DDLML)		✓	✓				
FIAT	500BEV	2020	Passenger Door Latch Module (PDLML)		✓	✓				
FIAT	500BEV	2020	Display Module (DSM)		✓	✓				
FIAT	500BEV	2020	EMCM (Entertainment Multimedia Control Module)		✓	✓				
FIAT	500BEV	2020	SRS (Supplemental Inflatable Restraint System, ORC)		✓	✓				
FIAT	500BEV	2020	ABS (Anti-Lock Braking System)		✓	✓				
FIAT	500BEV	2020	EPS (Electric Power Steering)		✓	✓				
FIAT	500BEV	2020	PAM (Parking Aid Module)		✓	✓				
FIAT	500BEV	2020	HALF (Haptical Lane Feedback)		✓	✓				
FIAT	Argo	2022	ECM (Engine Control Module)	✓	✓	✓	✓	✓	sp00319, sp00320, sp00321, sp00322, sp00323, sp00324, sp00325, sp00326,	
FIAT	Argo	2022	TCM (Transmission Control Module)	✓	✓	✓	✓		sp00334	
FIAT	Argo	2022	ABS (Anti-Lock Braking System)	✓	✓	✓	✓	✓	sp00335, sp00336, sp00337, sp00338	
FIAT	Argo	2022	BCM (Body Control Module)	✓	✓	✓	✓	✓	sp00339, sp00340, sp00341	
FIAT	Argo	2022	RBSS (Right Blind Spot Sensor)	✓	✓	✓	✓	✓		
FIAT	Argo	2022	ETM (Entertainment Telematic Module)	✓	✓	✓	✓	✓		
FIAT	Argo	2022	LBSS (Left Blind Spot Sensor)	✓	✓	✓	✓	✓		
FIAT	Argo	2022	AMP (Amplifier)	✓	✓	✓	✓	✓		
FIAT	Argo	2022	IC (Instrument Cluster)	✓	✓	✓	✓	✓	sp00342, sp00343, sp00344	
FIAT	Argo	2022	CSWM (Comfort Seat Wheel Module)	✓	✓	✓	✓	✓	sp00345	
FIAT	Argo	2022	DTCM (Drive Train Control Module)	✓	✓	✓	✓		sp00346, sp00347	
FIAT	Argo	2022	ACC (Adaptive Cruise Control)	✓	✓	✓	✓	✓		
FIAT	Argo	2022	ESM (Electronic Shifter Module)	✓	✓	✓	✓	✓	sp00348, sp00349	
FIAT	Argo	2022	RRM (Radio Receiver Module)	✓	✓	✓	✓	✓	sp00350, sp00351, sp00352	
FIAT	Argo	2022	HVAC (Heating Ventilation Air-Conditioning And Cooling)	✓	✓	✓	✓	✓	sp00353	
FIAT	Argo	2022	RFH (Radio Frequency Hub)	✓	✓	✓	✓	✓	sp00354, sp00355	
FIAT	Argo	2022	EPS (Electric Power Steering)	✓	✓	✓	✓		sp00356	
FIAT	Argo	2022	ESL (Electronic Steering Lock)	✓	✓	✓	✓			
FIAT	Argo	2022	SRS (Supplemental Inflatable Restraint System, ORC)	✓	✓	✓	✓			
FIAT	Argo	2022	PAM (Parking Aid Module)	✓	✓	✓	✓		sp00357, sp00358	
FIAT	Argo	2022	HALF (Haptical Lane Feedback)	✓	✓	✓	✓		sp00359	
FIAT	Argo	2022	DMM (Doors Management Module)	✓	✓	✓	✓			
FIAT	Argo	2021	ECM (Engine Control Module)	✓	✓	✓	✓	✓	sp00360, sp00361, sp00362, sp00363, sp00364, sp00365, sp00366, sp00367,	
FIAT	Argo	2021	TCM (Transmission Control Module)	✓	✓	✓	✓		sp00375	
FIAT	Argo	2021	ABS (Anti-Lock Braking System)	✓	✓	✓	✓	✓	sp00376, sp00377, sp00378, sp00379	
FIAT	Argo	2021	BCM (Body Control Module)	✓	✓	✓	✓	✓	sp00380, sp00381, sp00382	
FIAT	Argo	2021	RBSS (Right Blind Spot Sensor)	✓	✓	✓	✓	✓		
FIAT	Argo	2021	ETM (Entertainment Telematic Module)	✓	✓	✓	✓	✓		
FIAT	Argo	2021	LBSS (Left Blind Spot Sensor)	✓	✓	✓	✓	✓		
FIAT	Argo	2021	AMP (Amplifier)	✓	✓	✓	✓	✓		
FIAT	Argo	2021	IC (Instrument Cluster)	✓	✓	✓	✓	✓	sp00383, sp00384, sp00385	
FIAT	Argo	2021	CSWM (Comfort Seat Wheel Module)	✓	✓	✓	✓	✓	sp00386	
FIAT	Argo	2021	DTCM (Drive Train Control Module)	✓	✓	✓	✓		sp00387, sp00388	
FIAT	Argo	2021	ACC (Adaptive Cruise Control)	✓	✓	✓	✓	✓		
FIAT	Argo	2021	ESM (Electronic Shifter Module)	✓	✓	✓	✓	✓	sp00389, sp00390	
FIAT	Argo	2021	RRM (Radio Receiver Module)	✓	✓	✓	✓	✓	sp00391, sp00392, sp00393	
FIAT	Argo	2021	HVAC (Heating Ventilation Air-Conditioning And Cooling)	✓	✓	✓	✓	✓	sp00394	
FIAT	Argo	2021	RFH (Radio Frequency Hub)	✓	✓	✓	✓	✓	sp00395, sp00396	
FIAT	Argo	2021	EPS (Electric Power Steering)	✓	✓	✓	✓		sp00397	

FIAT	Argo	2021	ESL (Electronic Steering Lock)	✓	✓	✓	✓		
FIAT	Argo	2021	SRS (Supplemental Inflatable Restraint System, ORC)	✓	✓	✓	✓		
FIAT	Argo	2021	PAM (Parking Aid Module)	✓	✓	✓	✓		sp00398, sp00399
FIAT	Argo	2021	HALF (Haptical Lane Feedback)	✓	✓	✓	✓		sp00400
FIAT	Argo	2021	DMM (Doors Management Module)	✓	✓	✓	✓		
FIAT	Argo	2020	ECM (Engine Control Module)	✓	✓	✓	✓	✓	sp00401, sp00402, sp00403, sp00404, sp00405, sp00406, sp00407, sp00408,
FIAT	Argo	2020	TCM (Transmission Control Module)	✓	✓	✓	✓	✓	sp00416
FIAT	Argo	2020	ABS (Anti-Lock Braking System)	✓	✓	✓	✓	✓	sp00417, sp00418, sp00419, sp00420
FIAT	Argo	2020	BCM (Body Control Module)	✓	✓	✓	✓	✓	sp00421, sp00422, sp00423
FIAT	Argo	2020	RBSS (Right Blind Spot Sensor)	✓	✓	✓	✓	✓	
FIAT	Argo	2020	ETM (Entertainment Telematic Module)	✓	✓	✓	✓	✓	
FIAT	Argo	2020	LBSS (Left Blind Spot Sensor)	✓	✓	✓	✓	✓	
FIAT	Argo	2020	AMP (Amplifier)	✓	✓	✓	✓	✓	
FIAT	Argo	2020	IC (Instrument Cluster)	✓	✓	✓	✓	✓	sp00424, sp00425, sp00426
FIAT	Argo	2020	CSWM (Comfort Seat Wheel Module)	✓	✓	✓	✓	✓	sp00427
FIAT	Argo	2020	DTCM (Drive Train Control Module)	✓	✓	✓	✓	✓	sp00428, sp00429
FIAT	Argo	2020	ACC (Adaptive Cruise Control)	✓	✓	✓	✓	✓	
FIAT	Argo	2020	ESM (Electronic Shifter Module)	✓	✓	✓	✓	✓	sp00430, sp00431
FIAT	Argo	2020	RRM (Radio Receiver Module)	✓	✓	✓	✓	✓	sp00432, sp00433, sp00434
FIAT	Argo	2020	HVAC (Heating Ventilation Air-Conditioning And Cooling)	✓	✓	✓	✓	✓	sp00435
FIAT	Argo	2020	RFH (Radio Frequency Hub)	✓	✓	✓	✓	✓	sp00436, sp00437
FIAT	Argo	2020	EPS (Electric Power Steering)	✓	✓	✓	✓		sp00438
FIAT	Argo	2020	ESL (Electronic Steering Lock)	✓	✓	✓	✓		
FIAT	Argo	2020	SRS (Supplemental Inflatable Restraint System, ORC)	✓	✓	✓	✓		
FIAT	Argo	2020	PAM (Parking Aid Module)	✓	✓	✓	✓		sp00439, sp00440
FIAT	Argo	2020	HALF (Haptical Lane Feedback)	✓	✓	✓	✓		sp00441
FIAT	Argo	2020	DMM (Doors Management Module)	✓	✓	✓	✓		
FIAT	Argo	2019	ECM (Engine Control Module)	✓	✓	✓	✓	✓	sp00442, sp00443, sp00444, sp00445, sp00446, sp00447, sp00448, sp00449,
FIAT	Argo	2019	TCM (Transmission Control Module)	✓	✓	✓	✓		sp00457
FIAT	Argo	2019	ABS (Anti-Lock Braking System)	✓	✓	✓	✓	✓	sp00458, sp00459, sp00460, sp00461
FIAT	Argo	2019	BCM (Body Control Module)	✓	✓	✓	✓	✓	sp00462, sp00463, sp00464
FIAT	Argo	2019	RBSS (Right Blind Spot Sensor)	✓	✓	✓	✓	✓	
FIAT	Argo	2019	ETM (Entertainment Telematic Module)	✓	✓	✓	✓	✓	
FIAT	Argo	2019	LBSS (Left Blind Spot Sensor)	✓	✓	✓	✓	✓	
FIAT	Argo	2019	AMP (Amplifier)	✓	✓	✓	✓	✓	
FIAT	Argo	2019	IC (Instrument Cluster)	✓	✓	✓	✓	✓	sp00465, sp00466, sp00467
FIAT	Argo	2019	CSWM (Comfort Seat Wheel Module)	✓	✓	✓	✓	✓	sp00468
FIAT	Argo	2019	DTCM (Drive Train Control Module)	✓	✓	✓	✓		sp00469, sp00470
FIAT	Argo	2019	ACC (Adaptive Cruise Control)	✓	✓	✓	✓	✓	
FIAT	Argo	2019	ESM (Electronic Shifter Module)	✓	✓	✓	✓	✓	sp00471, sp00472
FIAT	Argo	2019	RRM (Radio Receiver Module)	✓	✓	✓	✓	✓	sp00473, sp00474, sp00475
FIAT	Argo	2019	HVAC (Heating Ventilation Air-Conditioning And Cooling)	✓	✓	✓	✓	✓	sp00476
FIAT	Argo	2019	RFH (Radio Frequency Hub)	✓	✓	✓	✓	✓	sp00477, sp00478
FIAT	Argo	2019	EPS (Electric Power Steering)	✓	✓	✓	✓	✓	sp00479
FIAT	Argo	2019	ESL (Electronic Steering Lock)	✓	✓	✓	✓		
FIAT	Argo	2019	SRS (Supplemental Inflatable Restraint System, ORC)	✓	✓	✓	✓		
FIAT	Argo	2019	PAM (Parking Aid Module)	✓	✓	✓	✓	✓	sp00480, sp00481
FIAT	Argo	2019	HALF (Haptical Lane Feedback)	✓	✓	✓	✓		sp00482
FIAT	Argo	2019	DMM (Doors Management Module)	✓	✓	✓	✓		
FIAT	Argo	2018	ECM (Engine Control Module)	✓	✓	✓	✓	✓	sp00483, sp00484, sp00485, sp00486, sp00487, sp00488, sp00489, sp00490,
FIAT	Argo	2018	TCM (Transmission Control Module)	✓	✓	✓	✓		sp00498
FIAT	Argo	2018	ABS (Anti-Lock Braking System)	✓	✓	✓	✓	✓	sp00499, sp00500, sp00501, sp00502
FIAT	Argo	2018	BCM (Body Control Module)	✓	✓	✓	✓	✓	sp00503, sp00504, sp00505

FIAT	Argo	2018	RBSS (Right Blind Spot Sensor)	✓	✓	✓	✓	✓	
FIAT	Argo	2018	ETM (Entertainment Telematic Module)	✓	✓	✓	✓	✓	
FIAT	Argo	2018	LBSS (Left Blind Spot Sensor)	✓	✓	✓	✓	✓	
FIAT	Argo	2018	AMP (Amplifier)	✓	✓	✓	✓	✓	
FIAT	Argo	2018	IC (Instrument Cluster)	✓	✓	✓	✓	✓	sp00506, sp00507, sp00508
FIAT	Argo	2018	CSWM (Comfort Seat Wheel Module)	✓	✓	✓	✓	✓	sp00509
FIAT	Argo	2018	DTCM (Drive Train Control Module)	✓	✓	✓	✓	✓	sp00510, sp00511
FIAT	Argo	2018	ACC (Adaptive Cruise Control)	✓	✓	✓	✓	✓	
FIAT	Argo	2018	ESM (Electronic Shifter Module)	✓	✓	✓	✓	✓	sp00512, sp00513
FIAT	Argo	2018	RRM (Radio Receiver Module)	✓	✓	✓	✓	✓	sp00514, sp00515, sp00516
FIAT	Argo	2018	HVAC (Heating Ventilation Air-Conditioning And Cooling)	✓	✓	✓	✓	✓	sp00517
FIAT	Argo	2018	RFH (Radio Frequency Hub)	✓	✓	✓	✓	✓	sp00518, sp00519
FIAT	Argo	2018	EPS (Electric Power Steering)	✓	✓	✓	✓	✓	sp00520
FIAT	Argo	2018	ESL (Electronic Steering Lock)	✓	✓	✓	✓	✓	
FIAT	Argo	2018	SRS (Supplemental Inflatable Restraint System, ORC)	✓	✓	✓	✓	✓	
FIAT	Argo	2018	PAM (Parking Aid Module)	✓	✓	✓	✓	✓	sp00521, sp00522
FIAT	Argo	2018	HALF (Haptical Lane Feedback)	✓	✓	✓	✓	✓	sp00523
FIAT	Argo	2018	DMM (Doors Management Module)	✓	✓	✓	✓	✓	
FIAT	500L	2020	ECM (Engine Control Module)	✓	✓	✓	✓	✓	sp00524, sp00525, sp00526, sp00527, sp00528, sp00529, sp00530, sp00531,
FIAT	500L	2020	TCM (Transmission Control Module)	✓	✓	✓	✓	✓	
FIAT	500L	2020	ABS (Anti-Lock Braking System)	✓	✓	✓	✓	✓	sp00534, sp00535, sp00536
FIAT	500L	2020	BCM (Body Control Module)	✓	✓	✓	✓	✓	
FIAT	500L	2020	EPS (Electric Power Steering)	✓	✓	✓	✓	✓	sp00537
FIAT	500L	2020	IC (Instrument Cluster)	✓	✓	✓	✓	✓	sp00538, sp00539, sp00540
FIAT	500L	2020	SRS (Supplemental Inflatable Restraint System, ORC)	✓	✓	✓	✓	✓	
FIAT	500L	2020	HVAC (Heating Ventilation Air-Conditioning And Cooling)	✓	✓	✓	✓	✓	
FIAT	500L	2020	CMM (Collision Mitigation Module)	✓	✓	✓	✓	✓	
FIAT	500L	2020	ETM (Entertainment Telematic Module)	✓	✓	✓	✓	✓	sp00541, sp00542, sp00543
FIAT	500L	2020	PAM (Parking Aid Module)	✓	✓	✓	✓	✓	sp00544, sp00545
FIAT	500L	2020	TPMS (Tire Pressure Monitoring System)	✓	✓	✓	✓	✓	sp00546, sp00547, sp00548, sp00549, sp00550, sp00551, sp00552, sp00553,
FIAT	500L	2020	ESM (Electronic Shifter Module)	✓	✓	✓	✓	✓	
FIAT	500L	2019	ECM (Engine Control Module)	✓	✓	✓	✓	✓	sp00555, sp00556, sp00557, sp00558, sp00559, sp00560, sp00561, sp00562,
FIAT	500L	2019	TCM (Transmission Control Module)	✓	✓	✓	✓	✓	
FIAT	500L	2019	ABS (Anti-Lock Braking System)	✓	✓	✓	✓	✓	sp00565, sp00566, sp00567
FIAT	500L	2019	BCM (Body Control Module)	✓	✓	✓	✓	✓	
FIAT	500L	2019	EPS (Electric Power Steering)	✓	✓	✓	✓	✓	sp00568
FIAT	500L	2019	IC (Instrument Cluster)	✓	✓	✓	✓	✓	sp00569, sp00570, sp00571
FIAT	500L	2019	SRS (Supplemental Inflatable Restraint System, ORC)	✓	✓	✓	✓	✓	
FIAT	500L	2019	HVAC (Heating Ventilation Air-Conditioning And Cooling)	✓	✓	✓	✓	✓	
FIAT	500L	2019	CMM (Collision Mitigation Module)	✓	✓	✓	✓	✓	
FIAT	500L	2019	ETM (Entertainment Telematic Module)	✓	✓	✓	✓	✓	sp00572, sp00573, sp00574
FIAT	500L	2019	PAM (Parking Aid Module)	✓	✓	✓	✓	✓	sp00575, sp00576
FIAT	500L	2019	TPMS (Tire Pressure Monitoring System)	✓	✓	✓	✓	✓	sp00577, sp00578, sp00579, sp00580, sp00581, sp00582, sp00583, sp00584,
FIAT	500L	2019	ESM (Electronic Shifter Module)	✓	✓	✓	✓	✓	
FIAT	500L	2018	ECM (Engine Control Module)	✓	✓	✓	✓	✓	sp00586, sp00587, sp00588, sp00589, sp00590, sp00591, sp00592
FIAT	500L	2018	TCM (Transmission Control Module)	✓	✓	✓	✓	✓	
FIAT	500L	2018	ABS (Anti-Lock Braking System)	✓	✓	✓	✓	✓	sp00593, sp00594, sp00595
FIAT	500L	2018	SRS (Supplemental Inflatable Restraint System, ORC)	✓	✓	✓	✓	✓	
FIAT	500L	2018	TPMS (Tire Pressure Monitoring System)	✓	✓	✓	✓	✓	sp00596, sp00597, sp00598, sp00599, sp00600, sp00601, sp00602, sp00603,
FIAT	500L	2018	PAM (Parking Assistant Module)	✓	✓	✓	✓	✓	sp00605, sp00606

FIAT	500L	2018	IC (Instrument Cluster)	✓	✓	✓	✓	✓	sp00607, sp00608, sp00609, sp00610, sp00611
FIAT	500L	2018	HVAC (Heating Ventilation Air-Conditioning And Cooling)	✓	✓	✓	✓	✓	
FIAT	500L	2018	ETM (Entertainment Telematic Module)	✓	✓	✓	✓	✓	sp00612, sp00613, sp00614
FIAT	500L	2018	ESM (Electronic Shifter Module)	✓	✓	✓	✓		
FIAT	500L	2018	EPS (Electric Power Steering)	✓	✓	✓	✓		sp00615
FIAT	500L	2018	BCM (Body Control Module)	✓	✓	✓	✓		
FIAT	500L	2017	ECM (Engine Control Module)	✓	✓	✓	✓	✓	sp00616, sp00617, sp00618, sp00619, sp00620, sp00621, sp00622, sp00623,
FIAT	500L	2017	TCM (Transmission Control Module)	✓	✓	✓	✓	✓	
FIAT	500L	2017	ABS (Anti-Lock Braking System)	✓	✓	✓	✓	✓	sp00626, sp00627, sp00628
FIAT	500L	2017	BCM (Body Control Module)	✓	✓	✓	✓		
FIAT	500L	2017	EPS (Electric Power Steering)	✓	✓	✓	✓		sp00629
FIAT	500L	2017	IC (Instrument Cluster)	✓	✓	✓	✓	✓	sp00630, sp00631, sp00632, sp00633, sp00634
FIAT	500L	2017	SRS (Supplemental Inflatable Restraint System, ORC)	✓	✓	✓	✓		
FIAT	500L	2017	HVAC (Heating Ventilation Air-Conditioning And Cooling)	✓	✓	✓	✓	✓	
FIAT	500L	2017	CMM (Collision Mitigation Module)	✓	✓	✓	✓		
FIAT	500L	2017	ETM (Entertainment Telematic Module)	✓	✓	✓	✓	✓	sp00635, sp00636, sp00637
FIAT	500L	2017	PAM (Parking Aid Module)	✓	✓	✓	✓		sp00638, sp00639
FIAT	500L	2017	TPMS (Tire Pressure Monitoring System)	✓	✓	✓	✓	✓	sp00640, sp00641, sp00642, sp00643, sp00644, sp00645, sp00646, sp00647,
FIAT	500L	2017	ESM (Electronic Shifter Module)	✓	✓	✓	✓		
FIAT	500L	2016	ECM (Engine Control Module)	✓	✓	✓	✓	✓	sp00649, sp00650, sp00651, sp00652, sp00653, sp00654, sp00655, sp00656,
FIAT	500L	2016	TCM (Transmission Control Module)	✓	✓	✓	✓	✓	
FIAT	500L	2016	ABS (Anti-Lock Braking System)	✓	✓	✓	✓		sp00659, sp00660, sp00661
FIAT	500L	2016	BCM (Body Control Module)	✓	✓	✓	✓		
FIAT	500L	2016	EPS (Electric Power Steering)	✓	✓	✓	✓		sp00662
FIAT	500L	2016	IC (Instrument Cluster)	✓	✓	✓	✓	✓	sp00663, sp00664, sp00665, sp00666, sp00667
FIAT	500L	2016	SRS (Supplemental Inflatable Restraint System, ORC)	✓	✓	✓	✓		
FIAT	500L	2016	HVAC (Heating Ventilation Air-Conditioning And Cooling)	✓	✓	✓	✓	✓	
FIAT	500L	2016	CMM (Collision Mitigation Module)	✓	✓	✓	✓		
FIAT	500L	2016	ETM (Entertainment Telematic Module)	✓	✓	✓	✓	✓	sp00668, sp00669, sp00670
FIAT	500L	2016	PAM (Parking Aid Module)	✓	✓	✓	✓		sp00671, sp00672
FIAT	500L	2016	TPMS (Tire Pressure Monitoring System)	✓	✓	✓	✓	✓	sp00673, sp00674, sp00675, sp00676, sp00677, sp00678, sp00679, sp00680, sp00681
FIAT	500L	2016	ESM (Electronic Shifter Module)	✓	✓	✓	✓		
FIAT	500L	2015	ECM (Engine Control Module)	✓	✓	✓	✓	✓	sp00682, sp00683, sp00684, sp00685, sp00686, sp00687, sp00688
FIAT	500L	2015	TCM (Transmission Control Module)	✓	✓	✓	✓	✓	
FIAT	500L	2015	ABS (Anti-Lock Braking System)	✓	✓	✓	✓		sp00689, sp00690, sp00691
FIAT	500L	2015	SRS (Supplemental Inflatable Restraint System, ORC)	✓	✓	✓	✓		
FIAT	500L	2015	TPMS (Tire Pressure Monitoring System)	✓	✓	✓	✓	✓	sp00692, sp00693, sp00694, sp00695, sp00696, sp00697, sp00698, sp00699,
FIAT	500L	2015	PAM (Parking Assistant Module)	✓	✓	✓	✓		sp00701, sp00702
FIAT	500L	2015	IC (Instrument Cluster)	✓	✓	✓	✓	✓	sp00703, sp00704, sp00705, sp00706, sp00707
FIAT	500L	2015	HVAC (Heating Ventilation Air-Conditioning And Cooling)	✓	✓	✓	✓	✓	
FIAT	500L	2015	ETM (Entertainment Telematic Module)	✓	✓	✓	✓	✓	sp00708, sp00709, sp00710
FIAT	500L	2015	ESM (Electronic Shifter Module)	✓	✓	✓	✓		
FIAT	500L	2015	EPS (Electric Power Steering)	✓	✓	✓	✓		sp00711
FIAT	500L	2015	BCM (Body Control Module)	✓	✓	✓	✓		
FIAT	500L	2014	PCM (Powertrain Control Module)	✓	✓	✓	✓	✓	
FIAT	500L	2014	TCM (Transmission Control Module)	✓	✓	✓	✓	✓	
FIAT	500L	2014	ABS (Anti-Lock Braking System)	✓	✓	✓	✓		sp00712, sp00713, sp00714
FIAT	500L	2014	SRS (Supplemental Inflatable Restraint System, ORC)	✓	✓	✓	✓	✓	
FIAT	500L	2014	TPMS (Tire Pressure Monitoring System)	✓	✓	✓	✓	✓	sp00715, sp00716, sp00717, sp00718, sp00719, sp00720, sp00721, sp00722,



FIAT	500L	2014	PAM (Parking Aid Module)	✓	✓	✓	✓		sp00724, sp00725
FIAT	500L	2014	IC (Instrument Cluster)	✓	✓	✓	✓	✓	sp00726, sp00727, sp00728, sp00729, sp00730
FIAT	500L	2014	HVAC (Heating Ventilation Air-Conditioning And Cooling)	✓	✓	✓	✓	✓	
FIAT	500L	2014	ETM (Entertainment Telematic Module)	✓	✓	✓	✓	✓	sp00731, sp00732, sp00733
FIAT	500L	2014	ESM (Electronic Shifter Module)	✓	✓	✓	✓		
FIAT	500L	2014	EPS (Electric Power Steering)	✓	✓	✓	✓		sp00734
FIAT	500L	2014	BCM (Body Control Module)	✓	✓	✓	✓		
FIAT	500L	2012	BCM (Body Control Module)	✓	✓	✓	✓		
FIAT	500L	2012	ECM (Engine Control Module)	✓	✓	✓	✓	✓	sp00735, sp00736, sp00737, sp00738, sp00739, sp00740, sp00741, sp00742,
FIAT	500L	2012	TCM (Transmission Control Module)	✓	✓	✓	✓		sp00746, sp00747, sp00748, sp00749
FIAT	500L	2012	ABS (Anti-Lock Braking System)	✓	✓	✓	✓		sp00750, sp00751, sp00752
FIAT	500L	2012	TPMS (Tire Pressure Monitoring System)	✓	✓	✓	✓	✓	sp00753, sp00754, sp00755, sp00756, sp00757, sp00758, sp00759, sp00760,
FIAT	500L	2012	SRS (Supplemental Inflatable Restraint System, ORC)	✓	✓	✓	✓		
FIAT	500L	2012	PAM (Parking Assistant Module)	✓	✓	✓	✓		sp00762, sp00763
FIAT	500L	2012	IC (Instrument Cluster)	✓	✓	✓	✓	✓	sp00764, sp00765, sp00766, sp00767, sp00768
FIAT	500L	2012	HVAC (Heating Ventilation Air-Conditioning And Cooling)	✓	✓	✓	✓	✓	
FIAT	500L	2012	ETM (Entertainment Telematic Module)	✓	✓	✓	✓	✓	sp00769, sp00770, sp00771
FIAT	500L	2012	EPS (Electric Power Steering)	✓	✓	✓	✓		sp00772
FIAT	500L	2012	CMM (Collision Mitigation Module)	✓	✓	✓	✓	✓	
FIAT	500X	2022	ECM (Engine Control Module)	✓	✓	✓	✓	✓	sp00773, sp00774, sp00775, sp00776, sp00777, sp00778, sp00779, sp00780,
FIAT	500X	2022	TCM (Transmission Control Module)	✓	✓	✓	✓		sp00788
FIAT	500X	2022	ABS (Anti-Lock Braking System)	✓	✓	✓	✓	✓	sp00789, sp00790, sp00791, sp00792
FIAT	500X	2022	BCM (Body Control Module )	✓	✓	✓	✓	✓	sp00793, sp00794, sp00795
FIAT	500X	2022	RRM (Radio Receiver Module)	✓	✓	✓	✓	✓	sp00796, sp00797, sp00798
FIAT	500X	2022	RFH (Radio Frequency Hub)	✓	✓	✓	✓	✓	sp00799, sp00800
FIAT	500X	2022	RBSS (Right Blind Spot Sensor)	✓	✓	✓	✓	✓	
FIAT	500X	2022	DTCM (Drive Train Control Module)	✓	✓	✓	✓		sp00801, sp00802
FIAT	500X	2022	ORC (Occupant Restraint)	✓	✓	✓	✓	✓	
FIAT	500X	2022	LBSS (Left Blind Spot Sensor)	✓	✓	✓	✓	✓	
FIAT	500X	2022	IC (Instrument Cluster)	✓	✓	✓	✓	✓	sp00803, sp00804, sp00805
FIAT	500X	2022	HVAC (Heating Ventilation Air-Conditioning And Cooling)	✓	✓	✓	✓	✓	sp00806
FIAT	500X	2022	EPS (Electric Power Steering)	✓	✓	✓	✓		sp00807
FIAT	500X	2022	ETM (Entertainment Telematic Module)	✓	✓	✓	✓	✓	
FIAT	500X	2022	ESM (Electronic Shifter Module)	✓	✓	✓	✓	✓	sp00808, sp00809
FIAT	500X	2022	ESL (Electronic Steering Lock)	✓	✓	✓	✓		
FIAT	500X	2022	PAM (Parking Aid Module)	✓	✓	✓	✓		sp00810, sp00811
FIAT	500X	2022	HALF (Haptical Lane Feedback)	✓	✓	✓	✓		sp00812
FIAT	500X	2022	CSWM (Comfort Seat Wheel Module)	✓	✓	✓	✓	✓	sp00813
FIAT	500X	2022	AMP (Amplifier)	✓	✓	✓	✓	✓	
FIAT	500X	2022	ACC (Adaptive Cruise Control)	✓	✓	✓	✓	✓	
FIAT	500X	2022	DMM (Doors Management Module)	✓	✓	✓	✓		
FIAT	500X	2021	ECM (Engine Control Module)	✓	✓	✓	✓	✓	sp00814, sp00815, sp00816, sp00817, sp00818, sp00819, sp00820, sp00821,
FIAT	500X	2021	TCM (Transmission Control Module)	✓	✓	✓	✓		sp00829
FIAT	500X	2021	ABS (Anti-Lock Braking System)	✓	✓	✓	✓	✓	sp00830, sp00831, sp00832, sp00833
FIAT	500X	2021	BCM (Body Control Module )	✓	✓	✓	✓	✓	sp00834, sp00835, sp00836
FIAT	500X	2021	RRM (Radio Receiver Module)	✓	✓	✓	✓	✓	sp00837, sp00838, sp00839
FIAT	500X	2021	RFH (Radio Frequency Hub)	✓	✓	✓	✓	✓	sp00840, sp00841
FIAT	500X	2021	RBSS (Right Blind Spot Sensor)	✓	✓	✓	✓	✓	
FIAT	500X	2021	DTCM (Drive Train Control Module)	✓	✓	✓	✓		sp00842, sp00843
FIAT	500X	2021	ORC (Occupant Restraint)	✓	✓	✓	✓		
FIAT	500X	2021	LBSS (Left Blind Spot Sensor)	✓	✓	✓	✓	✓	

FIAT	500X	2021	IC (Instrument Cluster)	✓	✓	✓	✓	✓	sp00844, sp00845, sp00846
FIAT	500X	2021	HVAC (Heating Ventilation Air-Conditioning And Cooling)	✓	✓	✓	✓	✓	sp00847
FIAT	500X	2021	EPS (Electric Power Steering)	✓	✓	✓	✓	✓	sp00848
FIAT	500X	2021	ETM (Entertainment Telematic Module)	✓	✓	✓	✓	✓	
FIAT	500X	2021	ESM (Electronic Shifter Module)	✓	✓	✓	✓	✓	sp00849, sp00850
FIAT	500X	2021	ESL (Electronic Steering Lock)	✓	✓	✓	✓	✓	
FIAT	500X	2021	PAM (Parking Aid Module)	✓	✓	✓	✓	✓	sp00851, sp00852
FIAT	500X	2021	HALF (Haptical Lane Feedback)	✓	✓	✓	✓	✓	sp00853
FIAT	500X	2021	CSWM (Comfort Seat Wheel Module)	✓	✓	✓	✓	✓	sp00854
FIAT	500X	2021	AMP (Amplifier)	✓	✓	✓	✓	✓	
FIAT	500X	2021	ACC (Adaptive Cruise Control)	✓	✓	✓	✓	✓	
FIAT	500X	2021	DMM (Doors Management Module)	✓	✓	✓	✓	✓	
FIAT	500X	2020	ECM (Engine Control Module)	✓	✓	✓	✓	✓	sp00855, sp00856, sp00857, sp00858, sp00859, sp00860, sp00861, sp00862, sp00863, sp00864, sp00865, sp00866, sp00867, sp00868, sp00869
FIAT	500X	2020	TCM (Transmission Control Module)	✓	✓	✓	✓	✓	sp00870
FIAT	500X	2020	ABS (Anti-Lock Braking System)	✓	✓	✓	✓	✓	sp00871, sp00872, sp00873, sp00874
FIAT	500X	2020	BCM (Body Control Module )	✓	✓	✓	✓	✓	sp00875, sp00876, sp00877
FIAT	500X	2020	RRM (Radio Receiver Module)	✓	✓	✓	✓	✓	sp00878, sp00879, sp00880
FIAT	500X	2020	RFH (Radio Frequency Hub)	✓	✓	✓	✓	✓	sp00881, sp00882
FIAT	500X	2020	RBSS (Right Blind Spot Sensor)	✓	✓	✓	✓	✓	
FIAT	500X	2020	DTCM (Drive Train Control Module)	✓	✓	✓	✓	✓	sp00883, sp00884
FIAT	500X	2020	ORC (Occupant Restraint)	✓	✓	✓	✓	✓	
FIAT	500X	2020	LBSS (Left Blind Spot Sensor)	✓	✓	✓	✓	✓	
FIAT	500X	2020	IC (Instrument Cluster)	✓	✓	✓	✓	✓	sp00885, sp00886, sp00887
FIAT	500X	2020	HVAC (Heating Ventilation Air-Conditioning And Cooling)	✓	✓	✓	✓	✓	sp00888
FIAT	500X	2020	EPS (Electric Power Steering)	✓	✓	✓	✓	✓	sp00889
FIAT	500X	2020	ETM (Entertainment Telematic Module)	✓	✓	✓	✓	✓	
FIAT	500X	2020	ESM (Electronic Shifter Module)	✓	✓	✓	✓	✓	sp00890, sp00891
FIAT	500X	2020	ESL (Electronic Steering Lock)	✓	✓	✓	✓	✓	
FIAT	500X	2020	PAM (Parking Aid Module)	✓	✓	✓	✓	✓	sp00892, sp00893
FIAT	500X	2020	HALF (Haptical Lane Feedback)	✓	✓	✓	✓	✓	sp00894
FIAT	500X	2020	CSWM (Comfort Seat Wheel Module)	✓	✓	✓	✓	✓	sp00895
FIAT	500X	2020	AMP (Amplifier)	✓	✓	✓	✓	✓	
FIAT	500X	2020	ACC (Adaptive Cruise Control)	✓	✓	✓	✓	✓	
FIAT	500X	2020	DMM (Doors Management Module)	✓	✓	✓	✓	✓	
FIAT	500X	2019	ECM (Engine Control Module)	✓	✓	✓	✓	✓	sp00896, sp00897, sp00898, sp00899, sp00900, sp00901, sp00902, sp00903,
FIAT	500X	2019	TCM (Transmission Control Module)	✓	✓	✓	✓	✓	sp00911
FIAT	500X	2019	ABS (Anti-Lock Braking System)	✓	✓	✓	✓	✓	sp00912, sp00913, sp00914, sp00915
FIAT	500X	2019	BCM (Body Control Module )	✓	✓	✓	✓	✓	sp00916, sp00917, sp00918
FIAT	500X	2019	RRM (Radio Receiver Module)	✓	✓	✓	✓	✓	sp00919, sp00920, sp00921
FIAT	500X	2019	RFH (Radio Frequency Hub)	✓	✓	✓	✓	✓	sp00922, sp00923
FIAT	500X	2019	RBSS (Right Blind Spot Sensor)	✓	✓	✓	✓	✓	
FIAT	500X	2019	PAM (Parking Aid Module)	✓	✓	✓	✓	✓	sp00924, sp00925
FIAT	500X	2019	ORC (Occupant Restraint)	✓	✓	✓	✓	✓	
FIAT	500X	2019	LBSS (Left Blind Spot Sensor)	✓	✓	✓	✓	✓	
FIAT	500X	2019	IC (Instrument Cluster)	✓	✓	✓	✓	✓	sp00926, sp00927, sp00928
FIAT	500X	2019	HVAC (Heating Ventilation Air-Conditioning And Cooling)	✓	✓	✓	✓	✓	sp00929
FIAT	500X	2019	HALF (Haptical Lane Feedback)	✓	✓	✓	✓	✓	sp00930
FIAT	500X	2019	ETM (Entertainment Telematic Module)	✓	✓	✓	✓	✓	
FIAT	500X	2019	ESM (Electronic Shifter Module)	✓	✓	✓	✓	✓	sp00931, sp00932
FIAT	500X	2019	ESL (Electronic Steering Lock)	✓	✓	✓	✓	✓	
FIAT	500X	2019	EPS (Electric Power Steering)	✓	✓	✓	✓	✓	sp00933
FIAT	500X	2019	DTCM (Drive Train Control Module)	✓	✓	✓	✓	✓	sp00934, sp00935
FIAT	500X	2019	CSWM (Comfort Seat Wheel Module)	✓	✓	✓	✓	✓	sp00936

FIAT	500X	2019	AMP (Amplifier)	✓	✓	✓	✓	✓	
FIAT	500X	2019	ACC (Adaptive Cruise Control)	✓	✓	✓	✓	✓	
FIAT	500X	2019	DMM (Doors Management Module)	✓	✓	✓	✓	✓	
FIAT	500X	2018	ECM (Engine Control Module)	✓	✓	✓	✓	✓	sp00937, sp00938, sp00939, sp00940, sp00941, sp00942, sp00943, sp00944,
FIAT	500X	2018	TCM (Transmission Control Module)	✓	✓	✓	✓	✓	sp00952
FIAT	500X	2018	ABS (Anti-Lock Braking System)	✓	✓	✓	✓	✓	sp00953, sp00954, sp00955, sp00956
FIAT	500X	2018	BCM (Body Control Module )	✓	✓	✓	✓	✓	sp00957, sp00958, sp00959
FIAT	500X	2018	RRM (Radio Receiver Module)	✓	✓	✓	✓	✓	sp00960, sp00961, sp00962
FIAT	500X	2018	RFH (Radio Frequency Hub)	✓	✓	✓	✓	✓	sp00963, sp00964
FIAT	500X	2018	RBSS (Right Blind Spot Sensor)	✓	✓	✓	✓	✓	
FIAT	500X	2018	DTCM (Drive Train Control Module)	✓	✓	✓	✓	✓	sp00965, sp00966
FIAT	500X	2018	ORC (Occupant Restraint)	✓	✓	✓	✓	✓	
FIAT	500X	2018	LBSS (Left Blind Spot Sensor)	✓	✓	✓	✓	✓	
FIAT	500X	2018	IC (Instrument Cluster)	✓	✓	✓	✓	✓	sp00967, sp00968, sp00969
FIAT	500X	2018	HVAC (Heating Ventilation Air-Conditioning And Cooling)	✓	✓	✓	✓	✓	sp00970
FIAT	500X	2018	EPS (Electric Power Steering)	✓	✓	✓	✓	✓	sp00971
FIAT	500X	2018	ETM (Entertainment Telematic Module)	✓	✓	✓	✓	✓	
FIAT	500X	2018	ESM (Electronic Shifter Module)	✓	✓	✓	✓	✓	sp00972, sp00973
FIAT	500X	2018	ESL (Electronic Steering Lock)	✓	✓	✓	✓	✓	
FIAT	500X	2018	PAM (Parking Aid Module)	✓	✓	✓	✓	✓	sp00974, sp00975
FIAT	500X	2018	HALF (Haptical Lane Feedback)	✓	✓	✓	✓	✓	sp00976
FIAT	500X	2018	CSWM (Comfort Seat Wheel Module)	✓	✓	✓	✓	✓	sp00977
FIAT	500X	2018	AMP (Amplifier)	✓	✓	✓	✓	✓	
FIAT	500X	2018	ACC (Adaptive Cruise Control)	✓	✓	✓	✓	✓	
FIAT	500X	2018	DMM (Doors Management Module)	✓	✓	✓	✓	✓	
FIAT	500X	2017	ECM (Engine Control Module)	✓	✓	✓	✓	✓	sp00978, sp00979, sp00980, sp00981, sp00982, sp00983, sp00984, sp00985,
FIAT	500X	2017	TCM (Transmission Control Module)	✓	✓	✓	✓	✓	sp00993
FIAT	500X	2017	ABS (Anti-Lock Braking System)	✓	✓	✓	✓	✓	sp00994, sp00995, sp00996, sp00997
FIAT	500X	2017	BCM (Body Control Module )	✓	✓	✓	✓	✓	sp00998, sp00999, sp01000
FIAT	500X	2017	RRM (Radio Receiver Module)	✓	✓	✓	✓	✓	sp01001, sp01002, sp01003
FIAT	500X	2017	RFH (Radio Frequency Hub)	✓	✓	✓	✓	✓	sp01004, sp01005
FIAT	500X	2017	RBSS (Right Blind Spot Sensor)	✓	✓	✓	✓	✓	
FIAT	500X	2017	PAM (Parking Aid Module)	✓	✓	✓	✓	✓	sp01006, sp01007
FIAT	500X	2017	ORC (Occupant Restraint)	✓	✓	✓	✓	✓	
FIAT	500X	2017	LBSS (Left Blind Spot Sensor)	✓	✓	✓	✓	✓	
FIAT	500X	2017	IC (Instrument Cluster)	✓	✓	✓	✓	✓	sp01008, sp01009, sp01010
FIAT	500X	2017	HVAC (Heating Ventilation Air-Conditioning And Cooling)	✓	✓	✓	✓	✓	sp01011
FIAT	500X	2017	HALF (Haptical Lane Feedback)	✓	✓	✓	✓	✓	sp01012
FIAT	500X	2017	ETM (Entertainment Telematic Module)	✓	✓	✓	✓	✓	
FIAT	500X	2017	ESM (Electronic Shifter Module)	✓	✓	✓	✓	✓	sp01013, sp01014
FIAT	500X	2017	ESL (Electronic Steering Lock)	✓	✓	✓	✓	✓	
FIAT	500X	2017	EPS (Electric Power Steering)	✓	✓	✓	✓	✓	sp01015
FIAT	500X	2017	DTCM (Drive Train Control Module)	✓	✓	✓	✓	✓	sp01016, sp01017
FIAT	500X	2017	CSWM (Comfort Seat Wheel Module)	✓	✓	✓	✓	✓	sp01018
FIAT	500X	2017	AMP (Amplifier)	✓	✓	✓	✓	✓	
FIAT	500X	2017	ACC (Adaptive Cruise Control)	✓	✓	✓	✓	✓	
FIAT	500X	2017	DMM (Doors Management Module)	✓	✓	✓	✓	✓	
FIAT	500X	2016	ECM (Engine Control Module)	✓	✓	✓	✓	✓	sp01019, sp01020, sp01021, sp01022, sp01023, sp01024, sp01025, sp01026,
FIAT	500X	2016	TCM (Transmission Control Module)	✓	✓	✓	✓	✓	sp01034
FIAT	500X	2016	ABS (Anti-Lock Braking System)	✓	✓	✓	✓	✓	sp01035, sp01036, sp01037, sp01038
FIAT	500X	2016	BCM (Body Control Module )	✓	✓	✓	✓	✓	sp01039, sp01040, sp01041
FIAT	500X	2016	RRM (Radio Receiver Module)	✓	✓	✓	✓	✓	sp01042, sp01043, sp01044
FIAT	500X	2016	RFH (Radio Frequency Hub)	✓	✓	✓	✓	✓	sp01045, sp01046
FIAT	500X	2016	RBSS (Right Blind Spot Sensor)	✓	✓	✓	✓	✓	
FIAT	500X	2016	PAM (Parking Aid Module)	✓	✓	✓	✓	✓	sp01047, sp01048

FIAT	500X	2016	ORC (Occupant Restraint)	✓	✓	✓	✓		
FIAT	500X	2016	LBSS (Left Blind Spot Sensor)	✓	✓	✓	✓	✓	
FIAT	500X	2016	IC (Instrument Cluster)	✓	✓	✓	✓	✓	sp01049, sp01050, sp01051
FIAT	500X	2016	HVAC (Heating Ventilation Air-Conditioning And Cooling)	✓	✓	✓	✓	✓	sp01052
FIAT	500X	2016	HALF (Haptical Lane Feedback)	✓	✓	✓	✓		sp01053
FIAT	500X	2016	ETM (Entertainment Telematic Module)	✓	✓	✓	✓	✓	
FIAT	500X	2016	ESM (Electronic Shifter Module)	✓	✓	✓	✓	✓	sp01054, sp01055
FIAT	500X	2016	ESL (Electronic Steering Lock)	✓	✓	✓	✓		
FIAT	500X	2016	EPS (Electric Power Steering)	✓	✓	✓	✓		sp01056
FIAT	500X	2016	DTCM (Drive Train Control Module)	✓	✓	✓	✓		sp01057, sp01058
FIAT	500X	2016	CSWM (Comfort Seat Wheel Module)	✓	✓	✓	✓	✓	sp01059
FIAT	500X	2016	AMP (Amplifier)	✓	✓	✓	✓	✓	
FIAT	500X	2016	ACC (Adaptive Cruise Control)	✓	✓	✓	✓	✓	
FIAT	500X	2016	DMM (Doors Management Module)	✓	✓	✓	✓		
FIAT	500X	2015	ECM (Engine Control Module)	✓	✓	✓	✓	✓	sp01060, sp01061, sp01062, sp01063, sp01064, sp01065, sp01066, sp01067, sp01075
FIAT	500X	2015	TCM (Transmission Control Module)	✓	✓	✓	✓		
FIAT	500X	2015	ABS (Anti-Lock Braking System)	✓	✓	✓	✓	✓	sp01076, sp01077, sp01078, sp01079
FIAT	500X	2015	BCM (Body Control Module )	✓	✓	✓	✓	✓	sp01080, sp01081, sp01082
FIAT	500X	2015	RRM (Radio Receiver Module)	✓	✓	✓	✓	✓	sp01083, sp01084, sp01085
FIAT	500X	2015	RFH (Radio Frequency Hub)	✓	✓	✓	✓	✓	sp01086, sp01087
FIAT	500X	2015	RBSS (Right Blind Spot Sensor)	✓	✓	✓	✓	✓	
FIAT	500X	2015	PAM (Parking Aid Module)	✓	✓	✓	✓		sp01088, sp01089
FIAT	500X	2015	ORC (Occupant Restraint)	✓	✓	✓	✓		
FIAT	500X	2015	LBSS (Left Blind Spot Sensor)	✓	✓	✓	✓	✓	
FIAT	500X	2015	IC (Instrument Cluster)	✓	✓	✓	✓	✓	sp01090, sp01091, sp01092
FIAT	500X	2015	HVAC (Heating Ventilation Air-Conditioning And Cooling)	✓	✓	✓	✓	✓	sp01093
FIAT	500X	2015	HALF (Haptical Lane Feedback)	✓	✓	✓	✓		sp01094
FIAT	500X	2015	ETM (Entertainment Telematic Module)	✓	✓	✓	✓	✓	
FIAT	500X	2015	ESM (Electronic Shifter Module)	✓	✓	✓	✓	✓	sp01095, sp01096
FIAT	500X	2015	ESL (Electronic Steering Lock)	✓	✓	✓	✓		
FIAT	500X	2015	EPS (Electric Power Steering)	✓	✓	✓	✓		sp01097
FIAT	500X	2015	DTCM (Drive Train Control Module)	✓	✓	✓	✓		sp01098, sp01099
FIAT	500X	2015	CSWM (Comfort Seat Wheel Module)	✓	✓	✓	✓	✓	sp01100
FIAT	500X	2015	AMP (Amplifier)	✓	✓	✓	✓	✓	
FIAT	500X	2015	ACC (Adaptive Cruise Control)	✓	✓	✓	✓	✓	
FIAT	500X	2015	DMM (Doors Management Module)	✓	✓	✓	✓		
FIAT	Cronos	2022	ECM (Engine Control Module)	✓	✓	✓	✓	✓	sp01101, sp01102, sp01103, sp01104, sp01105, sp01106, sp01107, sp01108, sp01116
FIAT	Cronos	2022	TCM (Transmission Control Module)	✓	✓	✓	✓		
FIAT	Cronos	2022	IC (Instrument Cluster)	✓	✓	✓	✓	✓	sp01117, sp01118, sp01119
FIAT	Cronos	2022	BCM (Body Control Module)	✓	✓	✓	✓	✓	sp01120, sp01121, sp01122
FIAT	Cronos	2022	SRS (Supplemental Inflatable Restraint System, ORC)	✓	✓	✓	✓		
FIAT	Cronos	2022	ABS (Anti-Lock Braking System)	✓	✓	✓	✓	✓	sp01123, sp01124, sp01125, sp01126
FIAT	Cronos	2022	DMM (Doors Management Module)	✓	✓	✓	✓		
FIAT	Cronos	2022	EPS (Electric Power Steering)	✓	✓	✓	✓		sp01127
FIAT	Cronos	2022	ESM (Electronic Shifter Module)	✓	✓	✓	✓	✓	sp01128, sp01129
FIAT	Cronos	2022	ETM (Entertainment Telematic Module)	✓	✓	✓	✓	✓	
FIAT	Cronos	2022	HVAC (Heating Ventilation Air-Conditioning And Cooling)	✓	✓	✓	✓	✓	sp01130
FIAT	Cronos	2022	PAM (Parking Aid Module)	✓	✓	✓	✓		sp01131, sp01132
FIAT	Cronos	2022	RFH (Radio Frequency Hub)	✓	✓	✓	✓	✓	sp01133, sp01134
FIAT	Cronos	2021	ECM (Engine Control Module)	✓	✓	✓	✓	✓	sp01135, sp01136, sp01137, sp01138, sp01139, sp01140, sp01141, sp01142, sp01150
FIAT	Cronos	2021	TCM (Transmission Control Module)	✓	✓	✓	✓		
FIAT	Cronos	2021	IC (Instrument Cluster)	✓	✓	✓	✓	✓	sp01151, sp01152, sp01153
FIAT	Cronos	2021	BCM (Body Control Module)	✓	✓	✓	✓	✓	sp01154, sp01155, sp01156
FIAT	Cronos	2021	SRS (Supplemental Inflatable Restraint System, ORC)	✓	✓	✓	✓		
FIAT	Cronos	2021	ABS (Anti-Lock Braking System)	✓	✓	✓	✓	✓	sp01157, sp01158, sp01159, sp01160
FIAT	Cronos	2021	DMM (Doors Management Module)	✓	✓	✓	✓		
FIAT	Cronos	2021	EPS (Electric Power Steering)	✓	✓	✓	✓		sp01161

FIAT	Cronos	2021	ESM (Electronic Shifter Module)	✓	✓	✓	✓	✓	sp01162, sp01163
FIAT	Cronos	2021	ETM (Entertainment Telematic Module)	✓	✓	✓	✓	✓	
FIAT	Cronos	2021	HVAC (Heating Ventilation Air-Conditioning And Cooling)	✓	✓	✓	✓	✓	sp01164
FIAT	Cronos	2021	PAM (Parking Aid Module)	✓	✓	✓	✓	✓	sp01165, sp01166
FIAT	Cronos	2021	RFH (Radio Frequency Hub)	✓	✓	✓	✓	✓	sp01167, sp01168
FIAT	Cronos	2020	ECM (Engine Control Module)	✓	✓	✓	✓	✓	sp01169, sp01170, sp01171, sp01172, sp01173, sp01174, sp01175, sp01176,
FIAT	Cronos	2020	TCM (Transmission Control Module)	✓	✓	✓	✓	✓	sp01184
FIAT	Cronos	2020	IC (Instrument Cluster)	✓	✓	✓	✓	✓	sp01185, sp01186, sp01187
FIAT	Cronos	2020	BCM (Body Control Module)	✓	✓	✓	✓	✓	sp01188, sp01189, sp01190
FIAT	Cronos	2020	SRS (Supplemental Inflatable Restraint System, ORC)	✓	✓	✓	✓	✓	
FIAT	Cronos	2020	ABS (Anti-Lock Braking System)	✓	✓	✓	✓	✓	sp01191, sp01192, sp01193, sp01194
FIAT	Cronos	2020	DMM (Doors Management Module)	✓	✓	✓	✓	✓	
FIAT	Cronos	2020	EPS (Electric Power Steering)	✓	✓	✓	✓	✓	sp01195
FIAT	Cronos	2020	ESM (Electronic Shifter Module)	✓	✓	✓	✓	✓	sp01196, sp01197
FIAT	Cronos	2020	ETM (Entertainment Telematic Module)	✓	✓	✓	✓	✓	
FIAT	Cronos	2020	HVAC (Heating Ventilation Air-Conditioning And Cooling)	✓	✓	✓	✓	✓	sp01198
FIAT	Cronos	2020	PAM (Parking Aid Module)	✓	✓	✓	✓	✓	sp01199, sp01200
FIAT	Cronos	2020	RFH (Radio Frequency Hub)	✓	✓	✓	✓	✓	sp01201, sp01202
FIAT	Cronos	2019	ECM (Engine Control Module)	✓	✓	✓	✓	✓	sp01203, sp01204, sp01205, sp01206, sp01207, sp01208, sp01209, sp01210,
FIAT	Cronos	2019	TCM (Transmission Control Module)	✓	✓	✓	✓	✓	sp01218
FIAT	Cronos	2019	IC (Instrument Cluster)	✓	✓	✓	✓	✓	sp01219, sp01220, sp01221
FIAT	Cronos	2019	BCM (Body Control Module)	✓	✓	✓	✓	✓	sp01222, sp01223, sp01224
FIAT	Cronos	2019	SRS (Supplemental Inflatable Restraint System, ORC)	✓	✓	✓	✓	✓	
FIAT	Cronos	2019	ABS (Anti-Lock Braking System)	✓	✓	✓	✓	✓	sp01225, sp01226, sp01227, sp01228
FIAT	Cronos	2019	DMM (Doors Management Module)	✓	✓	✓	✓	✓	
FIAT	Cronos	2019	EPS (Electric Power Steering)	✓	✓	✓	✓	✓	sp01229
FIAT	Cronos	2019	ESM (Electronic Shifter Module)	✓	✓	✓	✓	✓	sp01230, sp01231
FIAT	Cronos	2019	ETM (Entertainment Telematic Module)	✓	✓	✓	✓	✓	
FIAT	Cronos	2019	HVAC (Heating Ventilation Air-Conditioning And Cooling)	✓	✓	✓	✓	✓	sp01232
FIAT	Cronos	2019	PAM (Parking Aid Module)	✓	✓	✓	✓	✓	sp01233, sp01234
FIAT	Cronos	2019	RFH (Radio Frequency Hub)	✓	✓	✓	✓	✓	sp01235, sp01236
FIAT	Cronos	2018	ECM (Engine Control Module)	✓	✓	✓	✓	✓	sp01237, sp01238, sp01239, sp01240, sp01241, sp01242, sp01243, sp01244,
FIAT	Cronos	2018	TCM (Transmission Control Module)	✓	✓	✓	✓	✓	sp01252
FIAT	Cronos	2018	IC (Instrument Cluster)	✓	✓	✓	✓	✓	sp01253, sp01254, sp01255
FIAT	Cronos	2018	BCM (Body Control Module)	✓	✓	✓	✓	✓	sp01256, sp01257, sp01258
FIAT	Cronos	2018	SRS (Supplemental Inflatable Restraint System, ORC)	✓	✓	✓	✓	✓	
FIAT	Cronos	2018	ABS (Anti-Lock Braking System)	✓	✓	✓	✓	✓	sp01259, sp01260, sp01261, sp01262
FIAT	Cronos	2018	DMM (Doors Management Module)	✓	✓	✓	✓	✓	
FIAT	Cronos	2018	EPS (Electric Power Steering)	✓	✓	✓	✓	✓	sp01263
FIAT	Cronos	2018	ESM (Electronic Shifter Module)	✓	✓	✓	✓	✓	sp01264, sp01265
FIAT	Cronos	2018	ETM (Entertainment Telematic Module)	✓	✓	✓	✓	✓	
FIAT	Cronos	2018	HVAC (Heating Ventilation Air-Conditioning And Cooling)	✓	✓	✓	✓	✓	sp01266
FIAT	Cronos	2018	PAM (Parking Aid Module)	✓	✓	✓	✓	✓	sp01267, sp01268
FIAT	Cronos	2018	RFH (Radio Frequency Hub)	✓	✓	✓	✓	✓	sp01269, sp01270
FIAT	BARCETTA	16V ASPIRATO	Bosch 5.3 ABS	✓	✓	✓	✓	✓	
FIAT	BARCETTA	16V ASPIRATO	Hitachi MPI Injection	✓	✓	✓	✓	✓	
FIAT	BARCETTA	16V ASPIRATO	Hitachi MPI Injection (Eng. 1.8 16V '98)	✓	✓	✓	✓	✓	
FIAT	BARCETTA	16V ASPIRATO	TRW MY 97 Air Bag (2F-2P-1)	✓	✓	✓	✓	✓	
FIAT	BARCETTA	16V ASPIRATO	TRW MY 97 Air Bag (2F-2P)	✓	✓	✓	✓	✓	
FIAT	BARCETTA	16V ASPIRATO CF3	Bosch 5.3 ABS	✓	✓	✓	✓	✓	

FIAT	BARCETTA	16V ASPIRATO CF3	Hitachi EOBD Injection	✓	✓	✓	✓		
FIAT	BARCETTA	16V ASPIRATO CF3	TRW MY 97 Air Bag (2F-2P)	✓	✓	✓	✓		
FIAT	BARCETTA	16V ASPIRATO CF3	TRW MY 97 Air Bag (2F-2P-1)	✓	✓	✓	✓		
FIAT	BRAVO (198)	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (Eng. 1.4)	✓	✓	✓	✓		
FIAT	BRAVO (198)	1.4 16V	Bosch Motronic Injection Me7.9.10 / SDU CF5/EOBD LPG (Eng. 1.4)	✓	✓	✓	✓		
FIAT	BRAVO (198)	1.4 16V	Bosch Motronic ME7.3H4M EOBD Injection	✓	✓	✓	✓		
FIAT	BRAVO (198)	1.4 16V	Injection Landi Renzo LCO2 Gas	✓	✓	✓	✓		
FIAT	BRAVO (198)	1.4 16V	Convergence Lauberhorn C1	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	1.4 16V	Marelli 3 Connect (Multi-Model)	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	1.4 16V	Marelli Instrument Panel 3	✓	✓	✓	✓		
FIAT	BRAVO (198)	1.4 16V	Marelli Radio Navigator	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	1.4 16V	Marelli/Microsoft Convergence	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	1.4 16V	Marelli/Microsoft C3 Convergence	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	1.4 16V	Bosch 8 ABS	✓	✓	✓	✓		
FIAT	BRAVO (198)	1.4 16V	Bosch 8 ASR ABS	✓	✓	✓	✓		
FIAT	BRAVO (198)	1.4 16V	Bosch 8 VDC ABS	✓	✓	✓	✓		
FIAT	BRAVO (198)	1.4 16V	CONTINENTAL Airbag (Proxy)	✓	✓	✓	✓		
FIAT	BRAVO (198)	1.4 16V	Marelli Body Computer 8	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	1.4 16V	SIEMENS Airbag 1 (Proxi)	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	1.4 16V	TRW Lane Control Control Unit (HALF)	✓	✓	✓	✓		
FIAT	BRAVO (198)	1.4 16V	Driver's Seat Lear 3	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	1.4 16V	Marelli Climate Control	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	1.4 16V	Passenger's Seat Lear 3	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	1.4 16V	TRW3 Electric Steering	✓	✓	✓	✓		
FIAT	BRAVO (198)	1.4 16V	Bosch Parking Control Unit (1)	✓	✓	✓	✓		
FIAT	BRAVO (198)	1.4 16V	Tyre Pressure Control TRW 2	✓	✓	✓	✓		
FIAT	BRAVO (198)	1.4 16V	Litronic Discharge Headlamp (Left)	✓	✓	✓	✓		
FIAT	BRAVO (198)	1.4 16V	Litronic Discharge Headlamp (Right)	✓	✓	✓	✓		
FIAT	BRAVO (198)	1.4 TURBO 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (Eng. 1.4)	✓	✓	✓	✓		
FIAT	BRAVO (198)	1.4 TURBO 16V	Magneti Marelli Injection IAW 8GMF CF5/EOBD (Eng. 1.4)	✓	✓	✓	✓		
FIAT	BRAVO (198)	1.4 TURBO 16V	Marelli SELESPEED CFC300 Automatic Gearbox	✓	✓	✓	✓		
FIAT	BRAVO (198)	1.4 TURBO 16V	Convergence Lauberhorn C1	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	1.4 TURBO 16V	Marelli 3 Connect (Multi-Model)	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	1.4 TURBO 16V	Marelli Instrument Panel 3	✓	✓	✓	✓		
FIAT	BRAVO (198)	1.4 TURBO 16V	Marelli Radio Navigator	✓	✓	✓	✓	✓	

FIAT	BRAVO (198)	1.4 TURBO 16V	Marelli/Microsoft Convergence	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	1.4 TURBO 16V	Marelli/Microsoft C3 Convergence	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	1.4 TURBO 16V	Bosch 8 ABS	✓	✓	✓	✓		
FIAT	BRAVO (198)	1.4 TURBO 16V	Bosch 8 ASR ABS	✓	✓	✓	✓		
FIAT	BRAVO (198)	1.4 TURBO 16V	Bosch 8 VDC ABS	✓	✓	✓	✓		
FIAT	BRAVO (198)	1.4 TURBO 16V	CONTINENTAL Airbag (Proxy)	✓	✓	✓	✓		
FIAT	BRAVO (198)	1.4 TURBO 16V	Marelli Body Computer 8	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	1.4 TURBO 16V	SIEMENS Airbag 1 (Proxi)	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	1.4 TURBO 16V	TRW Lane Control Control Unit (HALF)	✓	✓	✓	✓		
FIAT	BRAVO (198)	1.4 TURBO 16V	Driver's Seat Lear 3	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	1.4 TURBO 16V	Marelli Climate Control	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	1.4 TURBO 16V	Marelli/Microsoft C3 Convergence	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	1.4 TURBO 16V	Passenger's Seat Lear 3	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	1.4 TURBO 16V	TRW3 Electric Steering	✓	✓	✓	✓		
FIAT	BRAVO (198)	1.4 TURBO 16V	Marelli/Microsoft Convergence	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	1.4 TURBO 16V	Bosch Parking Control Unit (1)	✓	✓	✓	✓		
FIAT	BRAVO (198)	1.4 TURBO 16V	Tyre Pressure Control TRW 2	✓	✓	✓	✓		
FIAT	BRAVO (198)	1.4 TURBO 16V	Litronic Discharge Headlamp (Left)	✓	✓	✓	✓		
FIAT	BRAVO (198)	1.4 TURBO 16V	Litronic Discharge Headlamp (Right)	✓	✓	✓	✓		
FIAT	BRAVO (198)	1.6 MJET 16V	Bosch Diese Injection EDC16C39 CF5/E0BD (1.6/1.9/2.0 Eng.)	✓	✓	✓	✓		
FIAT	BRAVO (198)	1.6 MJET 16V	Marelli SELESPEED CFC300 Automatic Gearbox	✓	✓	✓	✓		
FIAT	BRAVO (198)	1.6 MJET 16V	Convergence Lauberhorn C1	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	1.6 MJET 16V	Marelli 3 Connect (Multi-Model)	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	1.6 MJET 16V	Marelli Instrument Panel 3	✓	✓	✓	✓		
FIAT	BRAVO (198)	1.6 MJET 16V	Marelli Radio Navigator	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	1.6 MJET 16V	Marelli/Microsoft Convergence	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	1.6 MJET 16V	Marelli/Microsoft C3 Convergence	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	1.6 MJET 16V	Bosch 8 ABS	✓	✓	✓	✓		
FIAT	BRAVO (198)	1.6 MJET 16V	Bosch 8 ASR ABS	✓	✓	✓	✓		
FIAT	BRAVO (198)	1.6 MJET 16V	Bosch 8 VDC ABS	✓	✓	✓	✓		
FIAT	BRAVO (198)	1.6 MJET 16V	CONTINENTAL Airbag (Proxy)	✓	✓	✓	✓		
FIAT	BRAVO (198)	1.6 MJET 16V	Marelli Body Computer 8	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	1.6 MJET 16V	SIEMENS Airbag 1 (Proxi)	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	1.6 MJET 16V	TRW Lane Control Control Unit (HALF)	✓	✓	✓	✓		
FIAT	BRAVO (198)	1.6 MJET 16V	Driver's Seat Lear 3	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	1.6 MJET 16V	Marelli Climate Control	✓	✓	✓	✓	✓	

FIAT	BRAVO (198)	1.6 MJET 16V	Marelli/Microsoft C3 Convergence	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	1.6 MJET 16V	Passenger's Seat Lear 3	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	1.6 MJET 16V	TRW3 Electric Steering	✓	✓	✓	✓		
FIAT	BRAVO (198)	1.6 MJET 16V	Marelli/Microsoft Convergence	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	1.6 MJET 16V	Bosch Parking Control Unit (1)	✓	✓	✓	✓		
FIAT	BRAVO (198)	1.6 MJET 16V	Tyre Pressure Control TRW 2	✓	✓	✓	✓		
FIAT	BRAVO (198)	1.6 MJET 16V	Litronic Discharge Headlamp (Left)	✓	✓	✓	✓		
FIAT	BRAVO (198)	1.6 MJET 16V	Litronic Discharge Headlamp (Right)	✓	✓	✓	✓		
FIAT	BRAVO (198)	1.9 MJET 16V	Bosch Diesel Injection EDC16C39 CF4/EOBD (Eng. 1.9/2.4)	✓	✓	✓	✓		
FIAT	BRAVO (198)	1.9 MJET 16V	Convergence Lauberhorn C1	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	1.9 MJET 16V	Marelli 3 Connect (Multi-Model)	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	1.9 MJET 16V	Marelli Instrument Panel 3	✓	✓	✓	✓		
FIAT	BRAVO (198)	1.9 MJET 16V	Marelli Radio Navigator	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	1.9 MJET 16V	Marelli/Microsoft Convergence	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	1.9 MJET 16V	Marelli/Microsoft C3 Convergence	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	1.9 MJET 16V	Bosch 8 ABS	✓	✓	✓	✓		
FIAT	BRAVO (198)	1.9 MJET 16V	Bosch 8 ASR ABS	✓	✓	✓	✓		
FIAT	BRAVO (198)	1.9 MJET 16V	Bosch 8 VDC ABS	✓	✓	✓	✓		
FIAT	BRAVO (198)	1.9 MJET 16V	CONTINENTAL Airbag (Proxy)	✓	✓	✓	✓		
FIAT	BRAVO (198)	1.9 MJET 16V	Marelli Body Computer 8	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	1.9 MJET 16V	SIEMENS Airbag 1 (Proxi)	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	1.9 MJET 16V	TRW Lane Control Control Unit (HALF)	✓	✓	✓	✓		
FIAT	BRAVO (198)	1.9 MJET 16V	Driver's Seat Lear 3	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	1.9 MJET 16V	Marelli Climate Control	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	1.9 MJET 16V	Marelli/Microsoft C3 Convergence	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	1.9 MJET 16V	Passenger's Seat Lear 3	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	1.9 MJET 16V	TRW3 Electric Steering	✓	✓	✓	✓		
FIAT	BRAVO (198)	1.9 MJET 16V	Marelli/Microsoft Convergence	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	1.9 MJET 16V	Bosch Parking Control Unit (1)	✓	✓	✓	✓		
FIAT	BRAVO (198)	1.9 MJET 16V	Tyre Pressure Control TRW 2	✓	✓	✓	✓		
FIAT	BRAVO (198)	1.9 MJET 16V	Litronic Discharge Headlamp (Left)	✓	✓	✓	✓		
FIAT	BRAVO (198)	1.9 MJET 16V	Litronic Discharge Headlamp (Right)	✓	✓	✓	✓		
FIAT	BRAVO (198)	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/EOBD (Eng. 1.9/2.4)	✓	✓	✓	✓		
FIAT	BRAVO (198)	1.9 MJET 8V	Convergence Lauberhorn C1	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	1.9 MJET 8V	Marelli 3 Connect (Multi-Model)	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	1.9 MJET 8V	Marelli Instrument Panel 3	✓	✓	✓	✓		
FIAT	BRAVO (198)	1.9 MJET 8V	Marelli Radio Navigator	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	1.9 MJET 8V	Marelli/Microsoft Convergence	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	1.9 MJET 8V	Marelli/Microsoft C3 Convergence	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	1.9 MJET 8V	Bosch 8 ABS	✓	✓	✓	✓		
FIAT	BRAVO (198)	1.9 MJET 8V	Bosch 8 ASR ABS	✓	✓	✓	✓		
FIAT	BRAVO (198)	1.9 MJET 8V	Bosch 8 VDC ABS	✓	✓	✓	✓		
FIAT	BRAVO (198)	1.9 MJET 8V	CONTINENTAL Airbag (Proxy)	✓	✓	✓	✓		
FIAT	BRAVO (198)	1.9 MJET 8V	Marelli Body Computer 8	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	1.9 MJET 8V	SIEMENS Airbag 1 (Proxi)	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	1.9 MJET 8V	TRW Lane Control Control Unit (HALF)	✓	✓	✓	✓		
FIAT	BRAVO (198)	1.9 MJET 8V	Driver's Seat Lear 3	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	1.9 MJET 8V	Marelli Climate Control	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	1.9 MJET 8V	Marelli/Microsoft C3 Convergence	✓	✓	✓	✓	✓	



FIAT	BRAVO (198)	1.9 MJET 8V	Passenger's Seat Lear 3	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	1.9 MJET 8V	TRW3 Electric Steering	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	1.9 MJET 8V	Marelli/Microsoft Convergence	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	1.9 MJET 8V	Bosch Parking Control Unit (1)	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	1.9 MJET 8V	Tyre Pressure Control TRW 2	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	1.9 MJET 8V	Litronic Discharge Headlamp (Left)	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	1.9 MJET 8V	Litronic Discharge Headlamp (Right)	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	2.0 MJET 16V	Bosch Diese Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 Eng.)	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	2.0 MJET 16V	Convergence Lauberhorn C1	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	2.0 MJET 16V	Marelli 3 Connect (Multi-Model)	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	2.0 MJET 16V	Marelli Instrument Panel 3	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	2.0 MJET 16V	Marelli Radio Navigator	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	2.0 MJET 16V	Marelli/Microsoft Convergence	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	2.0 MJET 16V	Marelli/Microsoft C3 Convergence	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	2.0 MJET 16V	Bosch 8 ABS	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	2.0 MJET 16V	Bosch 8 ASR ABS	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	2.0 MJET 16V	Bosch 8 VDC ABS	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	2.0 MJET 16V	CONTINENTAL Airbag (Proxy)	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	2.0 MJET 16V	Marelli Body Computer 8	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	2.0 MJET 16V	SIEMENS Airbag 1 (Proxi)	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	2.0 MJET 16V	TRW Lane Control Control Unit (HALF)	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	2.0 MJET 16V	Driver's Seat Lear 3	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	2.0 MJET 16V	Marelli Climate Control	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	2.0 MJET 16V	Marelli/Microsoft C3 Convergence	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	2.0 MJET 16V	Passenger's Seat Lear 3	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	2.0 MJET 16V	TRW3 Electric Steering	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	2.0 MJET 16V	Marelli/Microsoft Convergence	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	2.0 MJET 16V	Bosch Parking Control Unit (1)	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	2.0 MJET 16V	Tyre Pressure Control TRW 2	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	2.0 MJET 16V	Litronic Discharge Headlamp (Left)	✓	✓	✓	✓	✓	
FIAT	BRAVO (198)	2.0 MJET 16V	Litronic Discharge Headlamp (Right)	✓	✓	✓	✓	✓	
FIAT	BRAVO-BRAVA	*01 100 16V CF3	Borletti MCC55F Climate Control	✓	✓	✓	✓	✓	
FIAT	BRAVO-BRAVA	*01 100 16V CF3	BREED MY 97 Air Bag (2F)	✓	✓	✓	✓	✓	
FIAT	BRAVO-BRAVA	*01 100 16V CF3	BREED MY 97 Air Bag (2F-2L-S)	✓	✓	✓	✓	✓	
FIAT	BRAVO-BRAVA	*01 100 16V CF3	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	✓	✓	✓	✓	✓	
FIAT	BRAVO-BRAVA	*01 100 16V CF3	Teves ABS MK20/MK70	✓	✓	✓	✓	✓	
FIAT	BRAVO-BRAVA	*01 100 16V CF3	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	✓	✓	✓	✓	✓	
FIAT	BRAVO-BRAVA	*01 100 16V CF3	BREED MY 97 Air Bag (2F-S)	✓	✓	✓	✓	✓	
FIAT	BRAVO-BRAVA	*01 100 16V CF3	BREED MY 97 Air Bag (2F-2L)	✓	✓	✓	✓	✓	
FIAT	BRAVO-BRAVA	*01 115 16V CF3	Borletti MCC55F Climate Control	✓	✓	✓	✓	✓	
FIAT	BRAVO-BRAVA	*01 115 16V CF3	BREED MY 97 Air Bag (2F)	✓	✓	✓	✓	✓	
FIAT	BRAVO-BRAVA	*01 115 16V CF3	BREED MY 97 Air Bag (2F-2L-S)	✓	✓	✓	✓	✓	
FIAT	BRAVO-BRAVA	*01 115 16V CF3	BREED MY 97 Air Bag (2F-S)	✓	✓	✓	✓	✓	
FIAT	BRAVO-BRAVA	*01 115 16V CF3	Hitachi EOBD Injection	✓	✓	✓	✓	✓	
FIAT	BRAVO-BRAVA	*01 115 16V CF3	Teves ABS MK20/MK70	✓	✓	✓	✓	✓	
FIAT	BRAVO-BRAVA	*01 115 16V CF3	BREED MY 97 Air Bag (2F-2L)	✓	✓	✓	✓	✓	
FIAT	BRAVO-BRAVA	*01 80 16V CF3	Borletti MCC55F Climate Control	✓	✓	✓	✓	✓	
FIAT	BRAVO-BRAVA	*01 80 16V CF3	Bosch Motronic ME7.3H4 EOBD Injection	✓	✓	✓	✓	✓	
FIAT	BRAVO-BRAVA	*01 80 16V CF3	BREED MY 97 Air Bag (2F)	✓	✓	✓	✓	✓	
FIAT	BRAVO-BRAVA	*01 80 16V CF3	BREED MY 97 Air Bag (2F-2L-S)	✓	✓	✓	✓	✓	
FIAT	BRAVO-BRAVA	*01 80 16V CF3	Teves ABS MK20/MK70	✓	✓	✓	✓	✓	
FIAT	BRAVO-BRAVA	*01 80 16V CF3	BREED MY 97 Air Bag (2F-S)	✓	✓	✓	✓	✓	
FIAT	BRAVO-BRAVA	*01 80 16V CF3	BREED MY 97 Air Bag (2F-2L)	✓	✓	✓	✓	✓	
FIAT	BRAVO-BRAVA	*01 JTD 100 CF3	Borletti MCC55F Climate Control	✓	✓	✓	✓	✓	
FIAT	BRAVO-BRAVA	*01 JTD 100 CF3	Bosch EDC15 CF3/EOBD Diesel Injection (Eng. 1.9/2.4)	✓	✓	✓	✓	✓	
FIAT	BRAVO-BRAVA	*01 JTD 100 CF3	BREED MY 97 Air Bag (2F)	✓	✓	✓	✓	✓	
FIAT	BRAVO-BRAVA	*01 JTD 100 CF3	BREED MY 97 Air Bag (2F-2L-S)	✓	✓	✓	✓	✓	

FIAT	BRAVO-BRAVA	'01 JTD 100 CF3	Teves ABS MK20/MK70	✓	✓	✓			
FIAT	BRAVO-BRAVA	'01 JTD 100 CF3	BREED MY 97 Air Bag (2F-S)	✓	✓	✓	✓		
FIAT	BRAVO-BRAVA	'01 JTD 100 CF3	BREED MY 97 Air Bag (2F-2L)	✓	✓	✓	✓		
FIAT	BRAVO-BRAVA	'99 100 16V	Borletti MCC55F Climate Control	✓	✓	✓			
FIAT	BRAVO-BRAVA	'99 100 16V	BREED MY 97 Air Bag (2F)	✓	✓	✓	✓		
FIAT	BRAVO-BRAVA	'99 100 16V	BREED MY 97 Air Bag (2F-2L-S)	✓	✓	✓	✓		
FIAT	BRAVO-BRAVA	'99 100 16V	Teves ABS MK20/MK70	✓	✓	✓			
FIAT	BRAVO-BRAVA	'99 100 16V	Magneti Marelli IAW 49F Injection (1.6 Eng.)	✓	✓	✓	✓		
FIAT	BRAVO-BRAVA	'99 100 16V	BREED MY 97 Air Bag (2F-S)	✓	✓	✓	✓		
FIAT	BRAVO-BRAVA	'99 100 16V	BREED MY 97 Air Bag (2F-2L)	✓	✓	✓	✓		
FIAT	BRAVO-BRAVA	'99 115 16V	Borletti MCC55F Climate Control	✓	✓	✓			
FIAT	BRAVO-BRAVA	'99 115 16V	BREED MY 97 Air Bag (2F)	✓	✓	✓	✓		
FIAT	BRAVO-BRAVA	'99 115 16V	BREED MY 97 Air Bag (2F-2L-S)	✓	✓	✓	✓		
FIAT	BRAVO-BRAVA	'99 115 16V	BREED MY 97 Air Bag (2F-S)	✓	✓	✓	✓		
FIAT	BRAVO-BRAVA	'99 115 16V	Hitachi MPI Injection (Eng. 1.8 16V '98)	✓	✓	✓	✓		
FIAT	BRAVO-BRAVA	'99 115 16V	Teves ABS MK20/MK70	✓	✓	✓			
FIAT	BRAVO-BRAVA	'99 115 16V	BREED MY 97 Air Bag (2F-2L)	✓	✓	✓	✓		
FIAT	BRAVO-BRAVA	'99 155 20V	Borletti MCC55F Climate Control	✓	✓	✓			
FIAT	BRAVO-BRAVA	'99 155 20V	Bosch Motronic ME3.1 Injection (Eng. 2.0 20V)	✓	✓	✓	✓		
FIAT	BRAVO-BRAVA	'99 155 20V	BREED MY 97 Air Bag (2F)	✓	✓	✓	✓		
FIAT	BRAVO-BRAVA	'99 155 20V	BREED MY 97 Air Bag (2F-2L-S)	✓	✓	✓	✓		
FIAT	BRAVO-BRAVA	'99 155 20V	Teves ABS MK20/MK70	✓	✓	✓			
FIAT	BRAVO-BRAVA	'99 155 20V	BREED MY 97 Air Bag (2F-S)	✓	✓	✓	✓		
FIAT	BRAVO-BRAVA	'99 155 20V	BREED MY 97 Air Bag (2F-2L)	✓	✓	✓	✓		
FIAT	BRAVO-BRAVA	'99 80 16V	Borletti MCC55F Climate Control	✓	✓	✓			
FIAT	BRAVO-BRAVA	'99 80 16V	Bosch Motronic M1.5.5 Injection (Eng. 1.2 16V)	✓	✓	✓	✓		
FIAT	BRAVO-BRAVA	'99 80 16V	BREED MY 97 Air Bag (2F)	✓	✓	✓	✓		
FIAT	BRAVO-BRAVA	'99 80 16V	BREED MY 97 Air Bag (2F-2L-S)	✓	✓	✓	✓		
FIAT	BRAVO-BRAVA	'99 80 16V	Teves ABS MK20/MK70	✓	✓	✓			
FIAT	BRAVO-BRAVA	'99 80 16V	BREED MY 97 Air Bag (2F-S)	✓	✓	✓	✓		
FIAT	BRAVO-BRAVA	'99 80 16V	BREED MY 97 Air Bag (2F-2L)	✓	✓	✓	✓		
FIAT	BRAVO-BRAVA	'99 JTD 105	Borletti MCC55F Climate Control	✓	✓	✓			
FIAT	BRAVO-BRAVA	'99 JTD 105	Bosch Diesel EDC 15 Injection (1.9 TD D.I. Engine)	✓	✓	✓	✓		
FIAT	BRAVO-BRAVA	'99 JTD 105	BREED MY 97 Air Bag (2F)	✓	✓	✓	✓		
FIAT	BRAVO-BRAVA	'99 JTD 105	BREED MY 97 Air Bag (2F-2L-S)	✓	✓	✓	✓		
FIAT	BRAVO-BRAVA	'99 JTD 105	Teves ABS MK20/MK70	✓	✓	✓			
FIAT	BRAVO-BRAVA	'99 JTD 105	BREED MY 97 Air Bag (2F-S)	✓	✓	✓	✓		
FIAT	BRAVO-BRAVA	'99 JTD 105	BREED MY 97 Air Bag (2F-2L)	✓	✓	✓	✓		
FIAT	BRAVO-BRAVA	1.6 16V	BREED MY 97 Air Bag (2F)	✓	✓	✓	✓		
FIAT	BRAVO-BRAVA	1.6 16V	BREED MY 97 Air Bag (2F-2L-S)	✓	✓	✓	✓		
FIAT	BRAVO-BRAVA	1.6 16V	Teves ABS MK20/MK70	✓	✓	✓			
FIAT	BRAVO-BRAVA	1.6 16V	BREED MY 97 Air Bag (2F-S)	✓	✓	✓	✓		
FIAT	BRAVO-BRAVA	1.8 16V	BREED MY 97 Air Bag (2F)	✓	✓	✓	✓		
FIAT	BRAVO-BRAVA	1.8 16V	BREED MY 97 Air Bag (2F-2L-S)	✓	✓	✓	✓		
FIAT	BRAVO-BRAVA	1.8 16V	BREED MY 97 Air Bag (2F-S)	✓	✓	✓	✓		
FIAT	BRAVO-BRAVA	1.8 16V	Hitachi MPI Injection	✓	✓	✓	✓		
FIAT	BRAVO-BRAVA	1.8 16V	Teves ABS MK20/MK70	✓	✓	✓			
FIAT	BRAVO-BRAVA	1.9 D	BREED MY 97 Air Bag (2F)	✓	✓	✓	✓		
FIAT	BRAVO-BRAVA	1.9 D	BREED MY 97 Air Bag (2F-2L-S)	✓	✓	✓	✓		
FIAT	BRAVO-BRAVA	1.9 D	Teves ABS MK20/MK70	✓	✓	✓			
FIAT	BRAVO-BRAVA	1.9 D	BREED MY 97 Air Bag (2F-S)	✓	✓	✓	✓		
FIAT	BRAVO-BRAVA	1.9 TD 100CV	Borletti MCC55F Climate Control	✓	✓	✓			
FIAT	BRAVO-BRAVA	1.9 TD 100CV	BREED MY 97 Air Bag (2F)	✓	✓	✓	✓		
FIAT	BRAVO-BRAVA	1.9 TD 100CV	Teves ABS MK20/MK70	✓	✓	✓			
FIAT	BRAVO-BRAVA	1.9 TD 100CV	BREED MY 97 Air Bag (2F-S)	✓	✓	✓	✓		
FIAT	BRAVO-BRAVA	1.9 TD 100CV	BREED MY 97 Air Bag (2F-2L-S)	✓	✓	✓	✓		
FIAT	BRAVO-BRAVA	1.9 TD 75CV	Borletti MCC55F Climate Control	✓	✓	✓			
FIAT	BRAVO-BRAVA	1.9 TD 75CV	Teves ABS MK20/MK70	✓	✓	✓			

FIAT	BRAVO-BRAVA	1.9 TD 75CV	BREED MY 97 Air Bag (2F-S)	✓	✓	✓	✓		
FIAT	BRAVO-BRAVA	1.9 TD 75CV	BREED MY 97 Air Bag (2F-2L-S)	✓	✓	✓	✓		
FIAT	BRAVO-BRAVA	1.9 TD 75CV	BREED MY 97 Air Bag (2F)	✓	✓	✓	✓		
FIAT	BRAVO VAN	1.6 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 Eng.)	✓	✓	✓	✓		
FIAT	BRAVO VAN	1.6 MJET 16V	Marelli SELESPEED CFC300 Automatic Gearbox	✓	✓	✓	✓		
FIAT	BRAVO VAN	1.6 MJET 16V	Convergence Lauberhorn C1	✓	✓	✓	✓	✓	
FIAT	BRAVO VAN	1.6 MJET 16V	Marelli 3 Connect (Multi-Model)	✓	✓	✓	✓	✓	
FIAT	BRAVO VAN	1.6 MJET 16V	Marelli Instrument Panel 3	✓	✓	✓	✓		
FIAT	BRAVO VAN	1.6 MJET 16V	Marelli Radio Navigator	✓	✓	✓	✓	✓	
FIAT	BRAVO VAN	1.6 MJET 16V	Marelli/Microsoft Convergence	✓	✓	✓	✓	✓	
FIAT	BRAVO VAN	1.6 MJET 16V	Marelli/Microsoft C3 Convergence	✓	✓	✓	✓	✓	
FIAT	BRAVO VAN	1.6 MJET 16V	Bosch 8 ABS	✓	✓	✓	✓		
FIAT	BRAVO VAN	1.6 MJET 16V	Bosch 8 ASR ABS	✓	✓	✓	✓		
FIAT	BRAVO VAN	1.6 MJET 16V	Bosch 8 VDC ABS	✓	✓	✓	✓		
FIAT	BRAVO VAN	1.6 MJET 16V	Marelli Body Computer 8	✓	✓	✓	✓	✓	
FIAT	BRAVO VAN	1.6 MJET 16V	SIEMENS Airbag 1 (Proxi)	✓	✓	✓	✓	✓	
FIAT	BRAVO VAN	1.6 MJET 16V	TRW Lane Control Control Unit (HALF)	✓	✓	✓	✓		
FIAT	BRAVO VAN	1.6 MJET 16V	Driver's Seat Lear 3	✓	✓	✓	✓	✓	
FIAT	BRAVO VAN	1.6 MJET 16V	Marelli Climate Control	✓	✓	✓	✓	✓	
FIAT	BRAVO VAN	1.6 MJET 16V	Passenger's Seat Lear 3	✓	✓	✓	✓	✓	
FIAT	BRAVO VAN	1.6 MJET 16V	TRW 3 Electric Steering	✓	✓	✓	✓		
FIAT	BRAVO VAN	1.6 MJET 16V	Bosch Parking Control Unit (1)	✓	✓	✓	✓		
FIAT	BRAVO VAN	1.6 MJET 16V	Tyre Pressure Control TRW 2	✓	✓	✓	✓		
FIAT	BRAVO VAN	1.6 MJET 16V	Litronic Discharge Headlamp (Left)	✓	✓	✓	✓		
FIAT	BRAVO VAN	1.6 MJET 16V	Litronic Discharge Headlamp (Right)	✓	✓	✓	✓		
FIAT	CINQUECENTO/500/595	2007	ECM (Engine Control Module)	✓	✓	✓	✓	✓	sp01271, sp01272, sp01273, sp01274, sp01275, sp01276, sp01277, sp01278,
FIAT	CINQUECENTO/500/595	2007	TCM (Transmission Control Module)	✓	✓	✓	✓	✓	sp01281, sp01282, sp01283, sp01284
FIAT	CINQUECENTO/500/595	2007	ABS (Anti-Lock Braking System)	✓	✓	✓	✓	✓	sp01285
FIAT	CINQUECENTO/500/595	2007	SRS (Supplemental Inflatable Restraint System, ORC)	✓	✓	✓	✓	✓	
FIAT	CINQUECENTO/500/595	2007	PAM (Parking Assistant Module)	✓	✓	✓	✓		sp01286, sp01287
FIAT	CINQUECENTO/500/595	2007	IC (Instrument Cluster)	✓	✓	✓	✓	✓	sp01288, sp01289, sp01290, sp01291, sp01292
FIAT	CINQUECENTO/500/595	2007	HVAC (Heating Ventilation Air-Conditioning And Cooling)	✓	✓	✓	✓	✓	sp01293
FIAT	CINQUECENTO/500/595	2007	ETM (Entertainment Telematic Module)	✓	✓	✓	✓	✓	sp01294
FIAT	CINQUECENTO/500/595	2007	EPS (Electric Power Steering)	✓	✓	✓	✓		sp01295
FIAT	CINQUECENTO/500/595	2007	CTM (Convergence Telematic Module)	✓	✓	✓	✓	✓	sp01296
FIAT	CINQUECENTO/500/595	2007	BCM (Body Control Module )	✓	✓	✓	✓	✓	sp01297
FIAT	CINQUECENTO/500/595	2007	AHM (Additional Heater Module)	✓	✓	✓	✓		
FIAT	COUPE'	*01 1.8 16V CF3	TRW MY 97 Airbag (2F-1)	✓	✓	✓	✓		
FIAT	COUPE'	*01 1.8 16V CF3	Borletti MCC55F Climate Control	✓	✓	✓	✓		
FIAT	COUPE'	*01 1.8 16V CF3	Bosch 5.3 ABS	✓	✓	✓	✓		
FIAT	COUPE'	*01 1.8 16V CF3	Hitachi EOBD Injection	✓	✓	✓	✓		
FIAT	COUPE'	*01 1.8 16V CF3	TRW MY 97 Airbag (2F-2P-2L-1)	✓	✓	✓	✓		
FIAT	COUPE'	*01 1.8 16V CF3	TRW MY 97 Airbag (2F)	✓	✓	✓	✓		
FIAT	COUPE'	*96 1.8 16V	Borletti MCC55F Climate Control	✓	✓	✓	✓		
FIAT	COUPE'	*96 1.8 16V	Bosch 5.3 ABS	✓	✓	✓	✓		
FIAT	COUPE'	*96 1.8 16V	Hitachi MPI Injection	✓	✓	✓	✓		
FIAT	COUPE'	*96 1.8 16V	TRW MY 97 Airbag (2F)	✓	✓	✓	✓		
FIAT	COUPE'	*96 2.0 20V	Borletti MCC55F Climate Control	✓	✓	✓	✓		
FIAT	COUPE'	*96 2.0 20V	Bosch 5.3 ABS	✓	✓	✓	✓		
FIAT	COUPE'	*96 2.0 TURBO 20V	Borletti MCC55F Climate Control	✓	✓	✓	✓		
FIAT	COUPE'	*96 2.0 TURBO 20V	Bosch 5.3 ABS	✓	✓	✓	✓		
FIAT	COUPE'	*98 1.8 16V	TRW MY 97 Airbag (2F-1)	✓	✓	✓	✓		
FIAT	COUPE'	*98 1.8 16V	Borletti MCC55F Climate Control	✓	✓	✓	✓		
FIAT	COUPE'	*98 1.8 16V	Bosch 5.3 ABS	✓	✓	✓	✓		
FIAT	COUPE'	*98 1.8 16V	Hitachi MPI Injection (Eng. 1.8 16V '98)	✓	✓	✓	✓		
FIAT	COUPE'	*98 1.8 16V	TRW MY 97 Airbag (2F-2P-2L-1)	✓	✓	✓	✓		

FIAT	COUPE'	'98 1.8 16V	TRW MY 97 Airbag (2F)	✓	✓	✓	✓		
FIAT	COUPE'	'98 2.0 20V	TRW MY 97 Airbag (2F-1)	✓	✓	✓	✓		
FIAT	COUPE'	'98 2.0 20V	Borletti MCC55F Climate Control	✓	✓	✓			
FIAT	COUPE'	'98 2.0 20V	Bosch 5.3 ABS	✓	✓	✓			
FIAT	COUPE'	'98 2.0 20V	Bosch Motronic ME3.1 Injection (Eng. 2.0 20V)	✓	✓	✓	✓		
FIAT	COUPE'	'98 2.0 20V	TRW MY 97 Airbag (2F-2P-2L-1)	✓	✓	✓	✓		
FIAT	COUPE'	'98 2.0 20V	TRW MY 97 Airbag (2F)	✓	✓	✓	✓		
FIAT	COUPE'	16V ASPIRATO	TRW MY 97 Airbag (2F)	✓	✓	✓	✓		
FIAT	COUPE'	16V TURBO	TRW MY 97 Airbag (2F)	✓	✓	✓	✓		
FIAT	CROMA (154)	'92 2.0 I.E 16V	Bosch 5.3 ABS	✓	✓	✓			
FIAT	CROMA (194)	1.8 16V	Siemens VDO CF4/EOBD Injection (Eng. 1.8)	✓	✓	✓	✓	✓	
FIAT	CROMA (194)	1.8 16V	Instrument Panel Marelli 2	✓	✓	✓	✓	✓	
FIAT	CROMA (194)	1.8 16V	Marelli 3 Connect (Multi-Model)	✓	✓	✓	✓	✓	
FIAT	CROMA (194)	1.8 16V	Marelli Radio Navigator	✓	✓	✓	✓	✓	
FIAT	CROMA (194)	1.8 16V	Air Bag TRW MY 03 (2F-2P-2L-2T-1G-1)	✓	✓	✓	✓	✓	
FIAT	CROMA (194)	1.8 16V	Air Bag TRW MY 03 (2F-4P-4L-2T-1G-1)	✓	✓	✓	✓	✓	
FIAT	CROMA (194)	1.8 16V	Body Computer Marelli 3	✓	✓	✓	✓	✓	
FIAT	CROMA (194)	1.8 16V	Electronic Key TRW (Tag Reader)	✓	✓	✓	✓	✓	
FIAT	CROMA (194)	1.8 16V	Steering Lock TRW 2	✓	✓	✓	✓		
FIAT	CROMA (194)	1.8 16V	TRW MY 03 Airbag (2F-2P-1)	✓	✓	✓	✓	✓	
FIAT	CROMA (194)	1.8 16V	TRW MY 03 Airbag (2F-2P-2T-1)	✓	✓	✓	✓	✓	
FIAT	CROMA (194)	1.8 16V	TRW Lucas ABS	✓	✓	✓	✓		
FIAT	CROMA (194)	1.8 16V	ESP TRW Lucas ABS	✓	✓	✓	✓		
FIAT	CROMA (194)	1.8 16V	Driver's Seat Lear 2	✓	✓	✓	✓	✓	
FIAT	CROMA (194)	1.8 16V	Marelli/Microsoft C3 Convergence	✓	✓	✓	✓	✓	
FIAT	CROMA (194)	1.8 16V	Marelli/Microsoft Convergence	✓	✓	✓	✓	✓	
FIAT	CROMA (194)	1.8 16V	Passenger Seat Lear 2	✓	✓	✓	✓	✓	
FIAT	CROMA (194)	1.8 16V	Valeo Climate Control (Two-Zone)	✓	✓	✓	✓	✓	
FIAT	CROMA (194)	1.8 16V	Poor Steering TRW 2	✓	✓	✓	✓		
FIAT	CROMA (194)	1.8 16V	Boot G.E. PROCOND 3	✓	✓	✓	✓	✓	
FIAT	CROMA (194)	1.8 16V	Driver's Door G.E. PROCOND 3	✓	✓	✓	✓	✓	
FIAT	CROMA (194)	1.8 16V	Tyre Pressure Control TRW2	✓	✓	✓	✓		
FIAT	CROMA (194)	1.8 16V	Passenger Door G.E. PROCOND 3	✓	✓	✓	✓	✓	
FIAT	CROMA (194)	1.8 16V	Valeo Parking Control Unit	✓	✓	✓	✓		
FIAT	CROMA (194)	1.8 16V	Litronic Discharge Headlamp (Left)	✓	✓	✓	✓		
FIAT	CROMA (194)	1.8 16V	Litronic Discharge Headlamp (Right)	✓	✓	✓	✓		
FIAT	CROMA (194)	1.9 MJET 16V	Automatic Gearbox AISIN AF40-6	✓	✓	✓	✓		
FIAT	CROMA (194)	1.9 MJET 16V	Bosch Diesel Injection EDC16C39 CF4/EOBD (Eng. 1.9/2.4)	✓	✓	✓	✓		
FIAT	CROMA (194)	1.9 MJET 16V	Instrument Panel Marelli 2	✓	✓	✓	✓	✓	
FIAT	CROMA (194)	1.9 MJET 16V	Marelli 3 Connect (Multi-Model)	✓	✓	✓	✓	✓	
FIAT	CROMA (194)	1.9 MJET 16V	Marelli Radio Navigator	✓	✓	✓	✓	✓	
FIAT	CROMA (194)	1.9 MJET 16V	Air Bag TRW MY 03 (2F-2P-2L-2T-1G-1)	✓	✓	✓	✓	✓	
FIAT	CROMA (194)	1.9 MJET 16V	Air Bag TRW MY 03 (2F-4P-4L-2T-1G-1)	✓	✓	✓	✓	✓	
FIAT	CROMA (194)	1.9 MJET 16V	Body Computer Marelli 3	✓	✓	✓	✓	✓	

FIAT	CROMA (194)	1.9 MJET 16V	Electronic Key TRW (Teg Reader)	✓	✓	✓	✓	✓
FIAT	CROMA (194)	1.9 MJET 16V	Steering Lock TRW 2	✓	✓	✓	✓	
FIAT	CROMA (194)	1.9 MJET 16V	TRW MY 03 Airbag (2F-2P-I)	✓	✓	✓	✓	✓
FIAT	CROMA (194)	1.9 MJET 16V	TRW MY 03 Airbag (2F-2P-2T-I)	✓	✓	✓	✓	✓
FIAT	CROMA (194)	1.9 MJET 16V	TRW Lucas ABS	✓	✓	✓	✓	
FIAT	CROMA (194)	1.9 MJET 16V	ESP TRW Lucas ABS	✓	✓	✓	✓	
FIAT	CROMA (194)	1.9 MJET 16V	Driver's Seat Lear 2	✓	✓	✓	✓	✓
FIAT	CROMA (194)	1.9 MJET 16V	Marelli/Microsoft C3 Convergence	✓	✓	✓	✓	✓
FIAT	CROMA (194)	1.9 MJET 16V	Marelli/Microsoft Convergence	✓	✓	✓	✓	✓
FIAT	CROMA (194)	1.9 MJET 16V	Passenger Seat Lear 2	✓	✓	✓	✓	✓
FIAT	CROMA (194)	1.9 MJET 16V	Valeo Climate Control (Two-Zone)	✓	✓	✓	✓	✓
FIAT	CROMA (194)	1.9 MJET 16V	Poor Steering TRW 2	✓	✓	✓	✓	
FIAT	CROMA (194)	1.9 MJET 16V	Boot G.E. PROCOND 3	✓	✓	✓	✓	✓
FIAT	CROMA (194)	1.9 MJET 16V	Driver's Door G.E. PROCOND 3	✓	✓	✓	✓	✓
FIAT	CROMA (194)	1.9 MJET 16V	Tyre Pressure Control TRW2	✓	✓	✓	✓	
FIAT	CROMA (194)	1.9 MJET 16V	Passenger Door G.E. PROCOND 3	✓	✓	✓	✓	✓
FIAT	CROMA (194)	1.9 MJET 16V	Valeo Parking Control Unit	✓	✓	✓	✓	
FIAT	CROMA (194)	1.9 MJET 16V	Litronic Discharge Headlamp (Left)	✓	✓	✓	✓	
FIAT	CROMA (194)	1.9 MJET 16V	Litronic Discharge Headlamp (Right)	✓	✓	✓	✓	
FIAT	CROMA (194)	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/E0BD (Eng. 1.9/2.4)	✓	✓	✓	✓	
FIAT	CROMA (194)	1.9 MJET 8V	Instrument Panel Marelli 2	✓	✓	✓	✓	✓
FIAT	CROMA (194)	1.9 MJET 8V	Marelli 3 Connect (Multi-Model)	✓	✓	✓	✓	✓
FIAT	CROMA (194)	1.9 MJET 8V	Marelli Radio Navigator	✓	✓	✓	✓	✓
FIAT	CROMA (194)	1.9 MJET 8V	Air Bag TRW MY 03 (2F-2P-2L-2T-1G-I)	✓	✓	✓	✓	✓
FIAT	CROMA (194)	1.9 MJET 8V	Air Bag TRW MY 03 (2F-4P-4L-2T-1G-I)	✓	✓	✓	✓	✓
FIAT	CROMA (194)	1.9 MJET 8V	Body Computer Marelli 3	✓	✓	✓	✓	✓
FIAT	CROMA (194)	1.9 MJET 8V	Electronic Key TRW (Teg Reader)	✓	✓	✓	✓	✓
FIAT	CROMA (194)	1.9 MJET 8V	Steering Lock TRW 2	✓	✓	✓	✓	
FIAT	CROMA (194)	1.9 MJET 8V	TRW MY 03 Airbag (2F-2P-I)	✓	✓	✓	✓	✓
FIAT	CROMA (194)	1.9 MJET 8V	TRW MY 03 Airbag (2F-2P-2T-I)	✓	✓	✓	✓	✓
FIAT	CROMA (194)	1.9 MJET 8V	TRW Lucas ABS	✓	✓	✓	✓	
FIAT	CROMA (194)	1.9 MJET 8V	ESP TRW Lucas ABS	✓	✓	✓	✓	
FIAT	CROMA (194)	1.9 MJET 8V	Driver's Seat Lear 2	✓	✓	✓	✓	✓
FIAT	CROMA (194)	1.9 MJET 8V	Marelli/Microsoft C3 Convergence	✓	✓	✓	✓	✓
FIAT	CROMA (194)	1.9 MJET 8V	Marelli/Microsoft Convergence	✓	✓	✓	✓	✓
FIAT	CROMA (194)	1.9 MJET 8V	Passenger Seat Lear 2	✓	✓	✓	✓	✓
FIAT	CROMA (194)	1.9 MJET 8V	Valeo Climate Control (Two-Zone)	✓	✓	✓	✓	✓
FIAT	CROMA (194)	1.9 MJET 8V	Poor Steering TRW 2	✓	✓	✓	✓	
FIAT	CROMA (194)	1.9 MJET 8V	Boot G.E. PROCOND 3	✓	✓	✓	✓	✓
FIAT	CROMA (194)	1.9 MJET 8V	Driver's Door G.E. PROCOND 3	✓	✓	✓	✓	✓

FIAT	CROMA (194)	1.9 MJET 8V	Tyre Pressure Control TRW2	✓	✓	✓	✓		
FIAT	CROMA (194)	1.9 MJET 8V	Passenger Door G.E. PROCOND 3	✓	✓	✓	✓	✓	
FIAT	CROMA (194)	1.9 MJET 8V	Valeo Parking Control Unit	✓	✓	✓	✓		
FIAT	CROMA (194)	1.9 MJET 8V	Litronic Discharge Headlamp (Left)	✓	✓	✓	✓		
FIAT	CROMA (194)	1.9 MJET 8V	Litronic Discharge Headlamp (Right)	✓	✓	✓	✓		
FIAT	CROMA (194)	2.2 16V	AISIN YLII 5 Automatic Gearbox (1)	✓	✓	✓	✓		
FIAT	CROMA (194)	2.2 16V	Mortorola Injection CF4/E0BD (Eng. 2.2)	✓	✓	✓	✓		
FIAT	CROMA (194)	2.2 16V	Instrument Panel Marelli 2	✓	✓	✓	✓	✓	
FIAT	CROMA (194)	2.2 16V	Marelli 3 Connect (Multi-Model)	✓	✓	✓	✓	✓	
FIAT	CROMA (194)	2.2 16V	Marelli Radio Navigator	✓	✓	✓	✓	✓	
FIAT	CROMA (194)	2.2 16V	Air Bag TRW MY 03 (2F-2P-2L-2T-1G-1)	✓	✓	✓	✓	✓	
FIAT	CROMA (194)	2.2 16V	Air Bag TRW MY 03 (2F-4P-4L-2T-1G-1)	✓	✓	✓	✓	✓	
FIAT	CROMA (194)	2.2 16V	Body Computer Marelli 3	✓	✓	✓	✓	✓	
FIAT	CROMA (194)	2.2 16V	Electronic Key TRW (Teg Reader)	✓	✓	✓	✓	✓	
FIAT	CROMA (194)	2.2 16V	Steering Lock TRW 2	✓	✓	✓	✓		
FIAT	CROMA (194)	2.2 16V	TRW MY 03 Airbag (2F-2P-1)	✓	✓	✓	✓	✓	
FIAT	CROMA (194)	2.2 16V	TRW MY 03 Airbag (2F-2P-2T-1)	✓	✓	✓	✓	✓	
FIAT	CROMA (194)	2.2 16V	TRW Lucas ABS	✓	✓	✓	✓		
FIAT	CROMA (194)	2.2 16V	ESP TRW Lucas ABS	✓	✓	✓	✓		
FIAT	CROMA (194)	2.2 16V	Driver's Seat Lear 2	✓	✓	✓	✓	✓	
FIAT	CROMA (194)	2.2 16V	Marelli/Microsoft C3 Convergence	✓	✓	✓	✓	✓	
FIAT	CROMA (194)	2.2 16V	Marelli/Microsoft Convergence	✓	✓	✓	✓	✓	
FIAT	CROMA (194)	2.2 16V	Passenger Seat Lear 2	✓	✓	✓	✓	✓	
FIAT	CROMA (194)	2.2 16V	Valeo Climate Control (Two-Zone)	✓	✓	✓	✓	✓	
FIAT	CROMA (194)	2.2 16V	Poor Steering TRW 2	✓	✓	✓	✓		
FIAT	CROMA (194)	2.2 16V	Boot G.E. PROCOND 3	✓	✓	✓	✓	✓	
FIAT	CROMA (194)	2.2 16V	Driver's Door G.E. PROCOND 3	✓	✓	✓	✓	✓	
FIAT	CROMA (194)	2.2 16V	Tyre Pressure Control TRW2	✓	✓	✓	✓		
FIAT	CROMA (194)	2.2 16V	Passenger Door G.E. PROCOND 3	✓	✓	✓	✓	✓	
FIAT	CROMA (194)	2.2 16V	Valeo Parking Control Unit	✓	✓	✓	✓		
FIAT	CROMA (194)	2.2 16V	Litronic Discharge Headlamp (Left)	✓	✓	✓	✓		

FIAT	CROMA (194)	2.2 16V	Litronic Discharge Headlamp (Right)	✓	✓	✓	✓		
FIAT	CROMA (194)	2.4 MJET 20V	Automatic Gearbox AISIN AF40-6	✓	✓	✓	✓		
FIAT	CROMA (194)	2.4 MJET 20V	Bosch Diesel Injection EDC16C39 CF4/EOBD (Eng. 1.9/2.4)	✓	✓	✓	✓		
FIAT	CROMA (194)	2.4 MJET 20V	Instrument Panel Marelli 2	✓	✓	✓	✓	✓	
FIAT	CROMA (194)	2.4 MJET 20V	Marelli 3 Connect (Multi-Model)	✓	✓	✓	✓	✓	
FIAT	CROMA (194)	2.4 MJET 20V	Marelli Radio Navigator	✓	✓	✓	✓	✓	
FIAT	CROMA (194)	2.4 MJET 20V	Air Bag TRW MY 03 (2F-2P-2L-2T-1G-1)	✓	✓	✓	✓	✓	
FIAT	CROMA (194)	2.4 MJET 20V	Air Bag TRW MY 03 (2F-4P-4L-2T-1G-1)	✓	✓	✓	✓	✓	
FIAT	CROMA (194)	2.4 MJET 20V	Body Computer Marelli 3	✓	✓	✓	✓	✓	
FIAT	CROMA (194)	2.4 MJET 20V	Electronic Key TRW (Teg Reader)	✓	✓	✓	✓	✓	
FIAT	CROMA (194)	2.4 MJET 20V	Steering Lock TRW 2	✓	✓	✓	✓		
FIAT	CROMA (194)	2.4 MJET 20V	TRW MY 03 Airbag (2F-2P-I)	✓	✓	✓	✓	✓	
FIAT	CROMA (194)	2.4 MJET 20V	TRW MY 03 Airbag (2F-2P-2T-I)	✓	✓	✓	✓	✓	
FIAT	CROMA (194)	2.4 MJET 20V	TRW Lucas ABS	✓	✓	✓	✓		
FIAT	CROMA (194)	2.4 MJET 20V	ESP TRW Lucas ABS	✓	✓	✓	✓		
FIAT	CROMA (194)	2.4 MJET 20V	Driver's Seat Lear 2	✓	✓	✓	✓	✓	
FIAT	CROMA (194)	2.4 MJET 20V	Marelli/Microsoft C3 Convergence	✓	✓	✓	✓	✓	
FIAT	CROMA (194)	2.4 MJET 20V	Marelli/Microsoft Convergence	✓	✓	✓	✓	✓	
FIAT	CROMA (194)	2.4 MJET 20V	Passenger Seat Lear 2	✓	✓	✓	✓	✓	
FIAT	CROMA (194)	2.4 MJET 20V	Valeo Climate Control (Two-Zone)	✓	✓	✓	✓	✓	
FIAT	CROMA (194)	2.4 MJET 20V	Poor Steering TRW 2	✓	✓	✓	✓		
FIAT	CROMA (194)	2.4 MJET 20V	Boot G.E. PROCOND 3	✓	✓	✓	✓	✓	
FIAT	CROMA (194)	2.4 MJET 20V	Driver's Door G.E. PROCOND 3	✓	✓	✓	✓	✓	
FIAT	CROMA (194)	2.4 MJET 20V	Tyre Pressure Control TRW2	✓	✓	✓	✓	✓	
FIAT	CROMA (194)	2.4 MJET 20V	Passenger Door G.E. PROCOND 3	✓	✓	✓	✓	✓	
FIAT	CROMA (194)	2.4 MJET 20V	Valeo Parking Control Unit	✓	✓	✓	✓		
FIAT	CROMA (194)	2.4 MJET 20V	Litronic Discharge Headlamp (Left)	✓	✓	✓	✓		
FIAT	CROMA (194)	2.4 MJET 20V	Litronic Discharge Headlamp (Right)	✓	✓	✓	✓		
FIAT	DOBLO'	2015	ECM (Engine Control Module)	✓	✓	✓	✓	✓	sp01298, sp01299, sp01300, sp01301, sp01302, sp01303, sp01304, sp01305,
FIAT	DOBLO'	2015	TCM (Transmission Control Module)	✓	✓	✓	✓	✓	sp01320, sp01321, sp01322
FIAT	DOBLO'	2015	ABS (Anti-Lock Braking System)	✓	✓	✓	✓	✓	sp01323, sp01324, sp01325
FIAT	DOBLO'	2015	SRS (Supplemental Inflatable Restraint System, ORC)	✓	✓	✓	✓		
FIAT	DOBLO'	2015	TPMS (Tire Pressure Monitoring System)	✓	✓	✓	✓	✓	sp01326, sp01327, sp01328, sp01329, sp01330, sp01331, sp01332, sp01333, sp01334
FIAT	DOBLO'	2015	RADIO (RADIO)	✓	✓	✓	✓	✓	sp01335, sp01336, sp01337
FIAT	DOBLO'	2015	PAM (Parking Assistant Module)	✓	✓	✓	✓		sp01338, sp01339
FIAT	DOBLO'	2015	IPC (Instrument Panel Cluster)	✓	✓	✓	✓	✓	sp01340, sp01341, sp01342, sp01343, sp01344
FIAT	DOBLO'	2015	HVAC (Heating Ventilation Air-Conditioning And Cooling)	✓	✓	✓	✓	✓	sp01345
FIAT	DOBLO'	2015	ETM (Entertainment Telematic Module)	✓	✓	✓	✓	✓	sp01346, sp01347, sp01348, sp01349
FIAT	DOBLO'	2015	CTM (Convergence Telematic Module)	✓	✓	✓	✓	✓	sp01350
FIAT	DOBLO'	2015	BCM (Body Control Module )	✓	✓	✓	✓	✓	sp01351
FIAT	DOBLO'	2015	AHM (Additional Heater Module)	✓	✓	✓	✓		
FIAT	DOBLO'	2008	ECM (Engine Control Module)	✓	✓	✓	✓	✓	sp01352, sp01353, sp01354
FIAT	DOBLO'	2008	TCM (Transmission Control Module)	✓	✓	✓	✓	✓	sp01355, sp01356, sp01357
FIAT	DOBLO'	2008	ABS (Anti-Lock Braking System)	✓	✓	✓	✓	✓	sp01358, sp01359, sp01360, sp01361, sp01362

FIAT	DOBLO'	2008	SRS (Supplemental Inflatable Restraint System, ORC)	✓	✓	✓	✓	✓	
FIAT	DOBLO'	2008	TPMS (Tire Pressure Monitoring System)	✓	✓	✓	✓	✓	sp01363, sp01364, sp01365, sp01366, sp01367, sp01368, sp01369, sp01370,
FIAT	DOBLO'	2008	PAM (Parking Assistant Module)	✓	✓	✓	✓		sp01372, sp01373
FIAT	DOBLO'	2008	IC (Instrument Cluster)	✓	✓	✓	✓	✓	sp01374, sp01375, sp01376, sp01377, sp01378
FIAT	DOBLO'	2008	HVAC (Heating Ventilation Air-Conditioning And Cooling)	✓	✓	✓	✓	✓	sp01379
FIAT	DOBLO'	2008	CTM (Convergence Telematic Module)	✓	✓	✓	✓	✓	
FIAT	DOBLO'	2008	BCM (Body Control Module )	✓	✓	✓	✓	✓	sp01380
FIAT	DOBLO'	2008	AHM (Additional Heater Module)	✓	✓	✓	✓		
FIAT	DUCATO	2018	ECM (Engine Control Module)	✓	✓	✓	✓	✓	sp01381, sp01382, sp01383, sp01384, sp01385, sp01386, sp01387, sp01388,
FIAT	DUCATO	2018	TCM (Transmission Control Module)	✓	✓	✓	✓	✓	
FIAT	DUCATO	2018	ABS (Anti-Lock Braking System)	✓	✓	✓	✓	✓	sp01399, sp01400, sp01401, sp01402
FIAT	DUCATO	2018	SRS (Supplemental Inflatable Restraint System, ORC)	✓	✓	✓	✓		
FIAT	DUCATO	2018	TTM (Trailer Tow Module)	✓	✓	✓	✓	✓	
FIAT	DUCATO	2018	TPMS (Tire Pressure Monitoring System)	✓	✓	✓	✓	✓	sp01403, sp01404, sp01405, sp01406, sp01407, sp01408, sp01409, sp01410,
FIAT	DUCATO	2018	RADIO (RADIO)	✓	✓	✓	✓	✓	sp01414, sp01415, sp01416
FIAT	DUCATO	2018	PAM (Parking Aid Module)	✓	✓	✓	✓		sp01417, sp01418
FIAT	DUCATO	2018	IC (Instrument Cluster)	✓	✓	✓	✓	✓	sp01419, sp01420, sp01421, sp01422, sp01423
FIAT	DUCATO	2018	BCM (Body Control Module)	✓	✓	✓	✓	✓	
FIAT	DUCATO	2018	HVAC (Heating Ventilation Air-Conditioning And Cooling)	✓	✓	✓	✓	✓	sp01424
FIAT	DUCATO	2018	ETM (Entertainment Telematic Module)	✓	✓	✓	✓	✓	sp01425, sp01426, sp01427, sp01428
FIAT	DUCATO	2018	EPS (Electric Power Steering)	✓	✓	✓	✓		
FIAT	DUCATO	2018	HALF (Haptical Lane Feedback)	✓	✓	✓	✓		sp01429
FIAT	DUCATO	2014	ECM (Engine Control Module)	✓	✓	✓	✓	✓	sp01430, sp01431, sp01432, sp01433, sp01434, sp01435, sp01436, sp01437,
FIAT	DUCATO	2014	TCM (Transmission Control Module)	✓	✓	✓	✓	✓	
FIAT	DUCATO	2014	ABS (Anti-Lock Braking System)	✓	✓	✓	✓	✓	sp01448, sp01449, sp01450, sp01451
FIAT	DUCATO	2014	SRS (Supplemental Inflatable Restraint System, ORC)	✓	✓	✓	✓		
FIAT	DUCATO	2014	TTM (Trailer Tow Module)	✓	✓	✓	✓	✓	
FIAT	DUCATO	2014	TPMS (Tire Pressure Monitoring System)	✓	✓	✓	✓	✓	sp01452, sp01453, sp01454, sp01455, sp01456, sp01457, sp01458, sp01459,
FIAT	DUCATO	2014	RADIO (RADIO)	✓	✓	✓	✓	✓	sp01463, sp01464, sp01465
FIAT	DUCATO	2014	PAM (Parking Aid Module)	✓	✓	✓	✓		sp01466, sp01467
FIAT	DUCATO	2014	IC (Instrument Cluster)	✓	✓	✓	✓	✓	sp01468, sp01469, sp01470, sp01471, sp01472
FIAT	DUCATO	2014	HVAC (Heating Ventilation Air-Conditioning And Cooling)	✓	✓	✓	✓	✓	sp01473
FIAT	DUCATO	2014	HALF (Haptical Lane Feedback)	✓	✓	✓	✓		sp01474
FIAT	DUCATO	2014	ETM (Entertainment Telematic Module)	✓	✓	✓	✓	✓	sp01475, sp01476, sp01477, sp01478
FIAT	DUCATO	2014	EPS (Electric Power Steering)	✓	✓	✓	✓		
FIAT	DUCATO	2014	BCM (Body Control Module )	✓	✓	✓	✓	✓	
FIAT	Aegea/Tipo	2017	ECM (Engine Control Module)	✓	✓	✓	✓	✓	sp01479, sp01480, sp01481, sp01482, sp01483, sp01484, sp01485, sp01486,
FIAT	Aegea/Tipo	2017	TCM (Transmission Control Module)	✓	✓	✓	✓	✓	sp01503, sp01504, sp01505
FIAT	Aegea/Tipo	2017	ABS (Anti-Lock Braking System)	✓	✓	✓	✓	✓	sp01506
FIAT	Aegea/Tipo	2017	SRS (Supplemental Inflatable Restraint System, ORC)	✓	✓	✓	✓		
FIAT	Aegea/Tipo	2017	RRM (Radio Receiver Module)	✓	✓	✓	✓	✓	sp01507, sp01508, sp01509
FIAT	Aegea/Tipo	2017	PAM (Parking Assistant Module)	✓	✓	✓	✓		sp01510, sp01511
FIAT	Aegea/Tipo	2017	IC (Instrument Cluster)	✓	✓	✓	✓	✓	sp01512, sp01513, sp01514
FIAT	Aegea/Tipo	2017	HVAC (Heating Ventilation Air-Conditioning And Cooling)	✓	✓	✓	✓	✓	sp01515
FIAT	Aegea/Tipo	2017	ETM (Entertainment Telematic Module)	✓	✓	✓	✓	✓	
FIAT	Aegea/Tipo	2017	ESM (Electronic Shifter Module)	✓	✓	✓	✓	✓	sp01516, sp01517
FIAT	Aegea/Tipo	2017	EPS (Electric Power Steering)	✓	✓	✓	✓		
FIAT	Aegea/Tipo	2017	BCM (Body Control Module)	✓	✓	✓	✓	✓	



FIAT	Aegea/Tipo	2017	AHM (Additional Heater Module)	✓	✓	✓	✓		
FIAT	Aegea/Tipo	2017	ACC (Adaptive Cruise Control)	✓	✓	✓	✓	✓	
FIAT	Aegea/Tipo	2016	ECM (Engine Control Module)	✓	✓	✓	✓	✓	sp01518, sp01519, sp01520, sp01521, sp01522, sp01523, sp01524, sp01525,
FIAT	Aegea/Tipo	2016	TCM (Transmission Control Module)	✓	✓	✓	✓	✓	sp01542, sp01543, sp01544
FIAT	Aegea/Tipo	2016	ABS (Anti-Lock Braking System)	✓	✓	✓	✓	✓	sp01545
FIAT	Aegea/Tipo	2016	SRS (Supplemental Inflatable Restraint System, ORC)	✓	✓	✓	✓	✓	
FIAT	Aegea/Tipo	2016	RRM (Radio Receiver Module)	✓	✓	✓	✓	✓	sp01546, sp01547, sp01548
FIAT	Aegea/Tipo Sedan/HB/SW	2016	PAM (Parking Assistant Module)	✓	✓	✓	✓	✓	sp01549, sp01550
FIAT	Aegea/Tipo	2016	IC (Instrument Cluster)	✓	✓	✓	✓	✓	sp01551, sp01552, sp01553
FIAT	Aegea/Tipo	2016	HVAC (Heating Ventilation Air-Conditioning And Cooling)	✓	✓	✓	✓	✓	sp01554
FIAT	Aegea/Tipo Sedan/HB/SW	2016	ETM (Entertainment Telematic Module)	✓	✓	✓	✓	✓	
FIAT	Aegea/Tipo	2016	ESM (Electronic Shifter Module)	✓	✓	✓	✓	✓	sp01555, sp01556
FIAT	Aegea/Tipo	2016	EPS (Electric Power Steering)	✓	✓	✓	✓	✓	
FIAT	Aegea/Tipo	2016	BCM (Body Control Module)	✓	✓	✓	✓	✓	
FIAT	Aegea/Tipo	2016	AHM (Additional Heater Module)	✓	✓	✓	✓	✓	
FIAT	Aegea/Tipo	2016	ACC (Adaptive Cruise Control)	✓	✓	✓	✓	✓	
FIAT	Aegea/Tipo Sedan/HB/SW	2015	ECM (Engine Control Module)	✓	✓	✓	✓	✓	sp01557, sp01558, sp01559, sp01560, sp01561, sp01562, sp01563, sp01564,
FIAT	Aegea/Tipo	2015	TCM (Transmission Control Module)	✓	✓	✓	✓	✓	sp01565, sp01566, sp01567, sp01568, sp01569, sp01570, sp01571, sp01572,
FIAT	Aegea/Tipo	2015	ABS (Anti-Lock Braking System)	✓	✓	✓	✓	✓	sp01584
FIAT	Aegea/Tipo Sedan/HB/SW	2015	SRS (Supplemental Inflatable Restraint System, ORC)	✓	✓	✓	✓	✓	
FIAT	Aegea/Tipo	2015	RRM (Radio Receiver Module)	✓	✓	✓	✓	✓	sp01585, sp01586, sp01587
FIAT	Aegea/Tipo	2015	PAM (Parking Assistant Module)	✓	✓	✓	✓	✓	sp01588, sp01589
FIAT	Aegea/Tipo	2015	IC (Instrument Cluster)	✓	✓	✓	✓	✓	sp01590, sp01591, sp01592
FIAT	Aegea/Tipo	2015	HVAC (Heating Ventilation Air-Conditioning And Cooling)	✓	✓	✓	✓	✓	sp01593
FIAT	Aegea/Tipo	2015	ETM (Entertainment Telematic Module)	✓	✓	✓	✓	✓	
FIAT	Aegea/Tipo	2015	ESM (Electronic Shifter Module)	✓	✓	✓	✓	✓	sp01594, sp01595
FIAT	Aegea/Tipo	2015	EPS (Electric Power Steering)	✓	✓	✓	✓	✓	
FIAT	Aegea/Tipo	2015	BCM (Body Control Module)	✓	✓	✓	✓	✓	
FIAT	Aegea/Tipo	2015	AHM (Additional Heater Module)	✓	✓	✓	✓	✓	
FIAT	Aegea/Tipo Sedan/HB/SW	2015	ACC (Adaptive Cruise Control)	✓	✓	✓	✓	✓	
FIAT	FIORINO QUBO	2018	ECM (Engine Control Module)	✓	✓	✓	✓	✓	sp01596, sp01597, sp01598, sp01599, sp01600, sp01601, sp01602, sp01603,
FIAT	FIORINO QUBO	2018	TCM (Transmission Control Module)	✓	✓	✓	✓	✓	sp01615, sp01616, sp01617
FIAT	FIORINO QUBO	2018	ABS (Anti-Lock Braking System)	✓	✓	✓	✓	✓	sp01618, sp01619, sp01620
FIAT	FIORINO QUBO	2018	SRS (Supplemental Inflatable Restraint System, ORC)	✓	✓	✓	✓	✓	
FIAT	FIORINO QUBO	2018	PAM (Parking Aid Module)	✓	✓	✓	✓	✓	sp01621, sp01622
FIAT	FIORINO QUBO	2018	IC (Instrument Cluster)	✓	✓	✓	✓	✓	sp01623, sp01624, sp01625
FIAT	FIORINO QUBO	2018	CTM (Convergence Telematic Module)	✓	✓	✓	✓	✓	sp01626
FIAT	FIORINO QUBO	2018	BCM (Body Control Module )	✓	✓	✓	✓	✓	
FIAT	FIORINO QUBO	2018	AHM (Additional Heater Module)	✓	✓	✓	✓	✓	
FIAT	FIORINO QUBO	2008	ECM (Engine Control Module)	✓	✓	✓	✓	✓	sp01627, sp01628, sp01629, sp01630, sp01631, sp01632, sp01633, sp01634,
FIAT	FIORINO QUBO	2008	TCM (Transmission Control Module)	✓	✓	✓	✓	✓	sp01646, sp01647, sp01648
FIAT	FIORINO QUBO	2008	ABS (Anti-Lock Braking System)	✓	✓	✓	✓	✓	sp01649, sp01650, sp01651
FIAT	FIORINO QUBO	2008	SRS (Supplemental Inflatable Restraint System, ORC)	✓	✓	✓	✓	✓	
FIAT	FIORINO QUBO	2008	PAM (Parking Aid Module)	✓	✓	✓	✓	✓	sp01652, sp01653
FIAT	FIORINO QUBO	2008	IC (Instrument Cluster)	✓	✓	✓	✓	✓	sp01654, sp01655, sp01656
FIAT	FIORINO QUBO	2008	CTM (Convergence Telematic Module)	✓	✓	✓	✓	✓	sp01657
FIAT	FIORINO QUBO	2008	BCM (Body Control Module )	✓	✓	✓	✓	✓	
FIAT	FIORINO QUBO	2008	AHM (Additional Heater Module)	✓	✓	✓	✓	✓	
FIAT	FREEMONT	2016	PCM (Powertrain Control Module)	✓	✓	✓	✓	✓	sp01658, sp01659, sp01660, sp01661, sp01662, sp01663, sp01664, sp01665
FIAT	FREEMONT	2016	TCM (Transmission Control Module)	✓	✓	✓	✓	✓	
FIAT	FREEMONT	2016	ABS (Anti-Lock Braking System)	✓	✓	✓	✓	✓	sp01666, sp01667

FIAT	FREEMONT	2016	SRS (Supplemental Inflatable Restraint System, ORC)	✓	✓	✓	✓		sp01668, sp01669, sp01670
FIAT	FREEMONT	2016	VTM (Vehicle Tracking Module)	✓	✓	✓	✓		
FIAT	FREEMONT	2016	VES3 (Last Row Screen)	✓	✓	✓	✓	✓	
FIAT	FREEMONT	2016	TPMS (Tire Pressure Monitoring System)	✓	✓	✓	✓		sp01671
FIAT	FREEMONT	2016	TGW (Telematic Gateway Radio)	✓	✓	✓	✓		
FIAT	FREEMONT	2016	SCCM (Steering Column Control Module)	✓	✓	✓	✓		
FIAT	FREEMONT	2016	RFH (Radio Frequency Hub)	✓	✓	✓	✓		
FIAT	FREEMONT	2016	PDM (Passenger Door Module)	✓	✓	✓	✓		
FIAT	FREEMONT	2016	ITM (Intrusion)	✓	✓	✓	✓	✓	
FIAT	FREEMONT	2016	ICS (Integrated Center Stack)	✓	✓	✓	✓		
FIAT	FREEMONT	2016	IC (Instrument Cluster)	✓	✓	✓	✓	✓	
FIAT	FREEMONT	2016	HVAC (Heating Ventilation Air-Conditioning And Cooling)	✓	✓	✓	✓		sp01672
FIAT	FREEMONT	2016	HSM (Heated Seat Module)	✓	✓	✓	✓	✓	
FIAT	FREEMONT	2016	HFM (Hands Free Module (Cell Phone))	✓	✓	✓	✓		
FIAT	FREEMONT	2016	EPPM (Electronic Pedestrian Protection Module)	✓	✓	✓	✓		sp01673
FIAT	FREEMONT	2016	EPB (Electrical Parking Brake)	✓	✓	✓	✓	✓	sp01674, sp01675
FIAT	FREEMONT	2016	DTCM (Drive Train Control Module)	✓	✓	✓	✓	✓	
FIAT	FREEMONT	2016	DDM (Driver Door Module)	✓	✓	✓	✓	✓	
FIAT	FREEMONT	2016	BCM (Body Control Module)	✓	✓	✓	✓		sp01676, sp01677, sp01678
FIAT	FREEMONT	2016	AMP (Amplifier)	✓	✓	✓	✓		
FIAT	FREEMONT	2015	PCM (Powertrain Control Module)	✓	✓	✓	✓	✓	sp01679, sp01680, sp01681, sp01682, sp01683, sp01684, sp01685, sp01686
FIAT	FREEMONT	2015	TCM (Transmission Control Module)	✓	✓	✓	✓		
FIAT	FREEMONT	2015	ABS (Anti-Lock Braking System)	✓	✓	✓	✓		sp01687, sp01688
FIAT	FREEMONT	2015	SRS (Supplemental Inflatable Restraint System, ORC)	✓	✓	✓	✓		sp01689, sp01690, sp01691
FIAT	FREEMONT	2015	VTM (Vehicle Tracking Module)	✓	✓	✓	✓		
FIAT	FREEMONT	2015	VES3 (Last Row Screen)	✓	✓	✓	✓	✓	
FIAT	FREEMONT	2015	TPMS (Tire Pressure Monitoring System)	✓	✓	✓	✓		sp01692, sp01693, sp01694, sp01695, sp01696, sp01697, sp01698, sp01699
FIAT	FREEMONT	2015	TGW (Telematic Gateway Radio)	✓	✓	✓	✓		
FIAT	FREEMONT	2015	SCCM (Steering Column Control Module)	✓	✓	✓	✓		
FIAT	FREEMONT	2015	RFH (Radio Frequency Hub)	✓	✓	✓	✓		
FIAT	FREEMONT	2015	PDM (Passenger Door Module)	✓	✓	✓	✓		
FIAT	FREEMONT	2015	ITM (Intrusion)	✓	✓	✓	✓	✓	
FIAT	FREEMONT	2015	ICS (Integrated Center Stack)	✓	✓	✓	✓		
FIAT	FREEMONT	2015	IC (Instrument Cluster)	✓	✓	✓	✓	✓	
FIAT	FREEMONT	2015	HVAC (Heating Ventilation Air-Conditioning And Cooling)	✓	✓	✓	✓		sp01700
FIAT	FREEMONT	2015	HSM (Heated Seat Module)	✓	✓	✓	✓	✓	
FIAT	FREEMONT	2015	HFM (Hands Free Module (Cell Phone))	✓	✓	✓	✓		
FIAT	FREEMONT	2015	EPPM (Electronic Pedestrian Protection Module)	✓	✓	✓	✓		sp01701
FIAT	FREEMONT	2015	EPB (Electrical Parking Brake)	✓	✓	✓	✓	✓	sp01702, sp01703
FIAT	FREEMONT	2015	DTCM (Drive Train Control Module)	✓	✓	✓	✓	✓	
FIAT	FREEMONT	2015	DDM (Driver Door Module)	✓	✓	✓	✓	✓	
FIAT	FREEMONT	2015	BCM (Body Control Module )	✓	✓	✓	✓		sp01704, sp01705, sp01706
FIAT	FREEMONT	2015	AMP (Amplifier)	✓	✓	✓	✓		
FIAT	FREEMONT	2014	PCM (Powertrain Control Module)	✓	✓	✓	✓		sp01707, sp01708, sp01709, sp01710, sp01711, sp01712, sp01713, sp01714, sp01715, sp01716, sp01717
FIAT	FREEMONT	2014	TCM (Transmission Control Module)	✓	✓	✓	✓		
FIAT	FREEMONT	2014	ABS (Anti-Lock Braking System)	✓	✓	✓	✓		sp01718, sp01719
FIAT	FREEMONT	2014	SRS (Supplemental Inflatable Restraint System, ORC)	✓	✓	✓	✓		sp01720, sp01721, sp01722

FIAT	FREEMONT	2014	VTM (Vehicle Tracking Module)	✓	✓	✓	✓		
FIAT	FREEMONT	2014	VES3 (Last Row Screen)	✓	✓	✓	✓	✓	
FIAT	FREEMONT	2014	TPMS (Tire Pressure Monitoring System)	✓	✓	✓	✓		sp01723, sp01724, sp01725, sp01726, sp01727, sp01728
FIAT	FREEMONT	2014	TGW (Telematic Gateway Radio)	✓	✓	✓	✓		
FIAT	FREEMONT	2014	SCCM (Steering Column Control Module)	✓	✓	✓	✓		
FIAT	FREEMONT	2014	RFH (Radio Frequency Hub)	✓	✓	✓	✓		
FIAT	FREEMONT	2014	PDM (Passenger Door Module)	✓	✓	✓	✓		
FIAT	FREEMONT	2014	ITM (Intrusion)	✓	✓	✓	✓	✓	
FIAT	FREEMONT	2014	ICS (Integrated Center Stack)	✓	✓	✓	✓		
FIAT	FREEMONT	2014	IC (Instrument Cluster)	✓	✓	✓	✓	✓	
FIAT	FREEMONT	2014	HVAC (Heating Ventilation Air-Conditioning And Cooling)	✓	✓	✓	✓	✓	sp01729
FIAT	FREEMONT	2014	HSM (Heated Seat Module)	✓	✓	✓	✓	✓	
FIAT	FREEMONT	2014	HFM (Hands Free Module (Cell Phone))	✓	✓	✓	✓	✓	
FIAT	FREEMONT	2014	EPPM (Electronic Pedestrian Protection Module)	✓	✓	✓	✓	✓	sp01730
FIAT	FREEMONT	2014	EPB (Electrical Parking Brake)	✓	✓	✓	✓	✓	sp01731, sp01732
FIAT	FREEMONT	2014	DTCM (Drive Train Control Module)	✓	✓	✓	✓	✓	
FIAT	FREEMONT	2014	DDM (Driver Door Module)	✓	✓	✓	✓	✓	
FIAT	FREEMONT	2014	BCM (Body Control Module )	✓	✓	✓	✓		sp01733, sp01734, sp01735
FIAT	FREEMONT	2014	AMP (Amplifier)	✓	✓	✓	✓	✓	
FIAT	FREEMONT	2013	PCM (Powertrain Control Module)	✓	✓	✓	✓	✓	sp01736, sp01737, sp01738, sp01739, sp01740, sp01741, sp01742, sp01743
FIAT	FREEMONT	2013	TCM (Transmission Control Module)	✓	✓	✓	✓		
FIAT	FREEMONT	2013	ABS (Anti-Lock Braking System)	✓	✓	✓	✓		sp01744, sp01745
FIAT	FREEMONT	2013	SRS (Supplemental Inflatable Restraint System, ORC)	✓	✓	✓	✓		sp01746, sp01747, sp01748
FIAT	FREEMONT	2013	VTM (Vehicle Tracking Module)	✓	✓	✓	✓		
FIAT	FREEMONT	2013	VES3 (Last Row Screen)	✓	✓	✓	✓	✓	
FIAT	FREEMONT	2013	TPMS (Tire Pressure Monitoring System)	✓	✓	✓	✓	✓	sp01749, sp01750, sp01751, sp01752, sp01753, sp01754
FIAT	FREEMONT	2013	TGW (Telematic Gateway Radio)	✓	✓	✓	✓		
FIAT	FREEMONT	2013	SCCM (Steering Column Control Module)	✓	✓	✓	✓		
FIAT	FREEMONT	2013	RFH (Radio Frequency Hub)	✓	✓	✓	✓		
FIAT	FREEMONT	2013	PDM (Passenger Door Module)	✓	✓	✓	✓		
FIAT	FREEMONT	2013	ITM (Intrusion)	✓	✓	✓	✓	✓	
FIAT	FREEMONT	2013	ICS (Integrated Center Stack)	✓	✓	✓	✓		
FIAT	FREEMONT	2013	IC (Instrument Cluster)	✓	✓	✓	✓	✓	
FIAT	FREEMONT	2013	HVAC (Heating Ventilation Air-Conditioning And Cooling)	✓	✓	✓	✓	✓	sp01755
FIAT	FREEMONT	2013	HSM (Heated Seat Module)	✓	✓	✓	✓	✓	
FIAT	FREEMONT	2013	HFM (Hands Free Module (Cell Phone))	✓	✓	✓	✓	✓	
FIAT	FREEMONT	2013	EPPM (Electronic Pedestrian Protection Module)	✓	✓	✓	✓	✓	sp01756
FIAT	FREEMONT	2013	EPB (Electrical Parking Brake)	✓	✓	✓	✓	✓	sp01757, sp01758
FIAT	FREEMONT	2013	DTCM (Drive Train Control Module)	✓	✓	✓	✓	✓	
FIAT	FREEMONT	2013	DDM (Driver Door Module)	✓	✓	✓	✓	✓	
FIAT	FREEMONT	2013	BCM (Body Control Module )	✓	✓	✓	✓		sp01759, sp01760, sp01761
FIAT	FREEMONT	2013	AMP (Amplifier)	✓	✓	✓	✓	✓	
FIAT	FREEMONT	2012	PCM (Powertrain Control Module)	✓	✓	✓	✓	✓	sp01762, sp01763, sp01764, sp01765, sp01766, sp01767, sp01768, sp01769
FIAT	FREEMONT	2012	TCM (Transmission Control Module)	✓	✓	✓	✓		
FIAT	FREEMONT	2012	ABS (Anti-Lock Braking System)	✓	✓	✓	✓		sp01770, sp01771
FIAT	FREEMONT	2012	SRS (Supplemental Inflatable Restraint System, ORC)	✓	✓	✓	✓		sp01772, sp01773, sp01774
FIAT	FREEMONT	2012	VES3 (Last Row Screen)	✓	✓	✓	✓	✓	
FIAT	FREEMONT	2012	TPMS (Tire Pressure Monitoring System)	✓	✓	✓	✓		sp01775, sp01776, sp01777, sp01778, sp01779, sp01780
FIAT	FREEMONT	2012	TGW (Telematic Gateway Radio)	✓	✓	✓	✓		
FIAT	FREEMONT	2012	SCCM (Steering Column Control Module)	✓	✓	✓	✓		
FIAT	FREEMONT	2012	RFH (Radio Frequency Hub)	✓	✓	✓	✓		
FIAT	FREEMONT	2012	PDM (Passenger Door Module)	✓	✓	✓	✓		
FIAT	FREEMONT	2012	ITM (Intrusion)	✓	✓	✓	✓	✓	
FIAT	FREEMONT	2012	ICS (Integrated Center Stack)	✓	✓	✓	✓		

FIAT	FREEMONT	2012	IC (Instrument Cluster)	✓	✓	✓	✓	✓	
FIAT	FREEMONT	2012	HVAC (Heating Ventilation Air-Conditioning And Cooling)	✓	✓	✓	✓	✓	sp01781
FIAT	FREEMONT	2012	HSM (Heated Seat Module)	✓	✓	✓	✓	✓	
FIAT	FREEMONT	2012	HFM (Hands Free Module (Cell Phone))	✓	✓	✓	✓	✓	
FIAT	FREEMONT	2012	EPPM (Electronic Pedestrian Protection Module)	✓	✓	✓	✓	✓	sp01782
FIAT	FREEMONT	2012	EPB (Electrical Parking Brake)	✓	✓	✓	✓	✓	sp01783, sp01784
FIAT	FREEMONT	2012	DTCM (Drive Train Control Module)	✓	✓	✓	✓	✓	
FIAT	FREEMONT	2012	DDM (Driver Door Module)	✓	✓	✓	✓	✓	
FIAT	FREEMONT	2012	BCM (Body Control Module )	✓	✓	✓	✓	✓	sp01785, sp01786, sp01787
FIAT	FREEMONT	2012	AMP (Amplifier)	✓	✓	✓	✓	✓	
FIAT	FREEMONT	2011	PCM (Powertrain Control Module)	✓	✓	✓	✓	✓	sp01788, sp01789, sp01790, sp01791, sp01792, sp01793, sp01794, sp01795
FIAT	FREEMONT	2011	ABS (Anti-Lock Braking System)	✓	✓	✓	✓	✓	sp01796, sp01797
FIAT	FREEMONT	2011	SRS (Supplemental Inflatable Restraint System, ORC)	✓	✓	✓	✓	✓	sp01798, sp01799, sp01800
FIAT	FREEMONT	2011	BCM (Body Control Module )	✓	✓	✓	✓	✓	sp01801, sp01802, sp01803
FIAT	FREEMONT	2011	VES3 (Last Row Screen)	✓	✓	✓	✓	✓	
FIAT	FREEMONT	2011	TPMS (Tire Pressure Monitoring System)	✓	✓	✓	✓	✓	sp01804, sp01805, sp01806, sp01807, sp01808, sp01809
FIAT	FREEMONT	2011	TGW (Telematic Gateway Radio)	✓	✓	✓	✓	✓	
FIAT	FREEMONT	2011	SCCM (Steering Column Control Module)	✓	✓	✓	✓	✓	
FIAT	FREEMONT	2011	RFH (Radio Frequency Hub)	✓	✓	✓	✓	✓	
FIAT	FREEMONT	2011	PDM (Passenger Door Module)	✓	✓	✓	✓	✓	
FIAT	FREEMONT	2011	ITM (Intrusion)	✓	✓	✓	✓	✓	
FIAT	FREEMONT	2011	ICS (Integrated Center Stack)	✓	✓	✓	✓	✓	
FIAT	FREEMONT	2011	IC (Instrument Cluster)	✓	✓	✓	✓	✓	
FIAT	FREEMONT	2011	HVAC (Heating Ventilation Air-Conditioning And Cooling)	✓	✓	✓	✓	✓	sp01810
FIAT	FREEMONT	2011	HSM (Heated Seat Module)	✓	✓	✓	✓	✓	
FIAT	FREEMONT	2011	HFM (Hands Free Module (Cell Phone))	✓	✓	✓	✓	✓	
FIAT	FREEMONT	2011	EPB (Electrical Parking Brake)	✓	✓	✓	✓	✓	sp01811, sp01812
FIAT	FREEMONT	2011	DTCM (Drive Train Control Module)	✓	✓	✓	✓	✓	
FIAT	FREEMONT	2011	DDM (Driver Door Module)	✓	✓	✓	✓	✓	
FIAT	FREEMONT	2011	AMP (Amplifier)	✓	✓	✓	✓	✓	
FIAT	FULLBACK	2017	PCM (Powertrain Control Module)	✓	✓	✓	✓	✓	sp01813, sp01814, sp01815, sp01816, sp01817, sp01818, sp01819, sp01820
FIAT	FULLBACK	2017	TCM (Transmission Control Module)	✓	✓	✓	✓	✓	
FIAT	FULLBACK	2017	ABS (Anti-Lock Braking System)	✓	✓	✓	✓	✓	sp01821, sp01822
FIAT	FULLBACK	2017	SRS (Supplemental Inflatable Restraint System, ORC)	✓	✓	✓	✓	✓	
FIAT	FULLBACK	2017	BCM (Body Control Module)	✓	✓	✓	✓	✓	sp01823, sp01824, sp01825
FIAT	FULLBACK	2017	RFH (Radio Frequency Hub)	✓	✓	✓	✓	✓	
FIAT	FULLBACK	2017	EPPM (Electronic Pedestrian Protection Module)	✓	✓	✓	✓	✓	sp01826
FIAT	FULLBACK	2017	DDM (Driver Door Module)	✓	✓	✓	✓	✓	
FIAT	FULLBACK	2017	IC (Instrument Cluster)	✓	✓	✓	✓	✓	
FIAT	FULLBACK	2017	SCCM (Steering Column Control Module)	✓	✓	✓	✓	✓	
FIAT	FULLBACK	2017	TPMS (Tire Pressure Monitoring System)	✓	✓	✓	✓	✓	sp01827
FIAT	FULLBACK	2017	HVAC (Heating Ventilation Air-Conditioning And Cooling)	✓	✓	✓	✓	✓	
FIAT	FULLBACK	2017	AMP (Amplifier)	✓	✓	✓	✓	✓	
FIAT	FULLBACK	2017	PDM (Passenger Door Module)	✓	✓	✓	✓	✓	
FIAT	FULLBACK	2017	Electronic Parking(EPB)	✓	✓	✓	✓	✓	sp01828, sp01829
FIAT	FULLBACK	2017	VTM (Vehicle Tracking Module)	✓	✓	✓	✓	✓	
FIAT	FULLBACK	2017	HFM (Hands Free Module (Cell Phone))	✓	✓	✓	✓	✓	
FIAT	FULLBACK	2017	HSM (Heated Seat Module)	✓	✓	✓	✓	✓	
FIAT	FULLBACK	2017	ICS (Integrated Center Stack)	✓	✓	✓	✓	✓	
FIAT	FULLBACK	2017	Vehicle Entertainment Module 3(the last row of screens) (VES)	✓	✓	✓	✓	✓	
FIAT	FULLBACK	2017	DTCM (Drive Train Control Module)	✓	✓	✓	✓	✓	
FIAT	FULLBACK	2017	TGW (Telematic Gateway Radio)	✓	✓	✓	✓	✓	
FIAT	FULLBACK	2017	ITM (Intrusion)	✓	✓	✓	✓	✓	
FIAT	FULLBACK	2017	Body Control Module and Central Gateway(BCMCGW)	✓	✓	✓	✓	✓	

FIAT	FULLBACK	2017	FFCM (Forward Facing Camera Module)		✓	✓			
FIAT	FULLBACK	2016	PCM (Powertrain Control Module)	✓	✓	✓	✓	✓	sp01830, sp01831, sp01832, sp01833, sp01834, sp01835, sp01836, sp01837
FIAT	FULLBACK	2016	TCM (Transmission Control Module)	✓	✓	✓	✓	✓	
FIAT	FULLBACK	2016	ABS (Anti-Lock Braking System)	✓	✓	✓	✓		sp01838, sp01839
FIAT	FULLBACK	2016	SAS (Steering Angle Sensor)	✓	✓	✓	✓		
FIAT	FULLBACK	2016	HVAC (Heating Ventilation Air-Conditioning And Cooling)	✓	✓	✓	✓	✓	
FIAT	FULLBACK	2016	SRS (Supplemental Inflatable Restraint System, ORC)	✓	✓	✓	✓		sp01840, sp01841, sp01842
FIAT	FULLBACK	2016	IC (Instrument Cluster)	✓	✓	✓	✓	✓	
FIAT	FULLBACK	2016	FFCM (Forward Facing Camera Module)		✓	✓			
FIAT	FULLBACK	2016	DTCM (Drive Train Control Module)	✓	✓	✓	✓	✓	
FIAT	FULLBACK	2016	RFH (Radio Frequency Hub)	✓	✓	✓	✓	✓	
FIAT	FULLBACK	2016	Body Control Module and Central Gateway(BCMCGW)	✓	✓	✓	✓	✓	
FIAT	Grande PUNTO	1.2 8V	Marelli IAW 5SF3 Injection (EP Eng. 8V) Outside EEC	✓	✓	✓	✓	✓	
FIAT	Grande PUNTO	1.2 8V	Marelli Injection IAW 5SF3 CF4/E0BD (EP Eng. 8V)	✓	✓	✓	✓	✓	
FIAT	Grande PUNTO	1.2 8V	Marelli Injection IAW 5SF8 CF5/E0BD (EP Eng. 8V)	✓	✓	✓	✓	✓	
FIAT	Grande PUNTO	1.2 8V	Marelli Cluster (EP)	✓	✓	✓	✓	✓	
FIAT	Grande PUNTO	1.2 8V	Marelli Instrument Cluster (EP) 3	✓	✓	✓	✓	✓	
FIAT	Grande PUNTO	1.2 8V	Marelli/Microsoft C3 (EP) Convergence	✓	✓	✓	✓	✓	
FIAT	Grande PUNTO	1.2 8V	Marelli/Microsoft Convergence (EP)	✓	✓	✓	✓	✓	
FIAT	Grande PUNTO	1.2 8V	Bosch ABS 8 ESP (EP)	✓	✓	✓	✓	✓	
FIAT	Grande PUNTO	1.2 8V	Bosch ABS 8 ESP (EP) 2	✓	✓	✓	✓	✓	
FIAT	Grande PUNTO	1.2 8V	Continental Airbag (EP-Proxi) 2	✓	✓	✓	✓	✓	
FIAT	Grande PUNTO	1.2 8V	Delphi (EP) 3 Body Computer	✓	✓	✓	✓	✓	
FIAT	Grande PUNTO	1.2 8V	TRW Airbag (EP - Proxi)	✓	✓	✓	✓	✓	
FIAT	Grande PUNTO	1.2 8V	Delphi Body Computer (EP)	✓	✓	✓	✓	✓	
FIAT	Grande PUNTO	1.2 8V	Delphi Body Computer (EP) 4	✓	✓	✓	✓	✓	
FIAT	Grande PUNTO	1.2 8V	DELPHI (EP) 2 Power Steering	✓	✓	✓	✓		
FIAT	Grande PUNTO	1.2 8V	Delphi (EP) 3 Electric Steering	✓	✓	✓	✓		
FIAT	Grande PUNTO	1.2 8V	Denso Climate Control (EP)	✓	✓	✓	✓	✓	
FIAT	Grande PUNTO	1.2 8V	Denso Heater (EP)	✓	✓	✓	✓	✓	
FIAT	Grande PUNTO	1.2 8V	Trw Tyre Pressure Control (EP)	✓	✓	✓	✓	✓	
FIAT	Grande PUNTO	1.2 8V	VALEO Parking Control Unit (EP) 2	✓	✓	✓	✓	✓	
FIAT	Grande PUNTO	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP Eng. 1.3 JTD) 2	✓	✓	✓	✓	✓	
FIAT	Grande PUNTO	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/E0BD (EP Eng. 1.3 JTD)	✓	✓	✓	✓	✓	
FIAT	Grande PUNTO	1.3 MJET 16V	Marelli SELESPEED CFC300 (EP) Automatic Gearbox	✓	✓	✓	✓	✓	
FIAT	Grande PUNTO	1.3 MJET 16V	Marelli Cluster (EP)	✓	✓	✓	✓	✓	
FIAT	Grande PUNTO	1.3 MJET 16V	Marelli Instrument Cluster (EP) 3	✓	✓	✓	✓	✓	
FIAT	Grande PUNTO	1.3 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	✓	✓	✓	✓	✓	
FIAT	Grande PUNTO	1.3 MJET 16V	Marelli/Microsoft Convergence (EP)	✓	✓	✓	✓	✓	
FIAT	Grande PUNTO	1.3 MJET 16V	Bosch ABS 8 ESP (EP)	✓	✓	✓	✓		
FIAT	Grande PUNTO	1.3 MJET 16V	Bosch ABS 8 ESP (EP) 2	✓	✓	✓	✓		
FIAT	Grande PUNTO	1.3 MJET 16V	Continental Airbag (EP-Proxi) 2	✓	✓	✓	✓	✓	
FIAT	Grande PUNTO	1.3 MJET 16V	Delphi (EP) 3 Body Computer	✓	✓	✓	✓	✓	
FIAT	Grande PUNTO	1.3 MJET 16V	TRW Airbag (EP - Proxi)	✓	✓	✓	✓	✓	
FIAT	Grande PUNTO	1.3 MJET 16V	Delphi Body Computer (EP)	✓	✓	✓	✓	✓	
FIAT	Grande PUNTO	1.3 MJET 16V	Delphi Body Computer (EP) 4	✓	✓	✓	✓	✓	
FIAT	Grande PUNTO	1.3 MJET 16V	DELPHI (EP) 2 Power Steering	✓	✓	✓	✓		
FIAT	Grande PUNTO	1.3 MJET 16V	Delphi (EP) 3 Electric Steering	✓	✓	✓	✓		
FIAT	Grande PUNTO	1.3 MJET 16V	Denso Climate Control (EP)	✓	✓	✓	✓	✓	
FIAT	Grande PUNTO	1.3 MJET 16V	Denso Heater (EP)	✓	✓	✓	✓	✓	

FIAT	Grande PUNTO	1.3 MJET 16V	Trw Tyre Pressure Control (EP)	✓	✓	✓	✓	✓
FIAT	Grande PUNTO	1.3 MJET 16V	VALEO Parking Control Unit (EP) 2	✓	✓	✓	✓	✓
FIAT	Grande PUNTO	1.4 16V	Bosch Injection Motronic Me7.6.3 CF4/E0BD (EP Eng. 16V)	✓	✓	✓	✓	✓
FIAT	Grande PUNTO	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/E0BD (EP Eng. 1.4)	✓	✓	✓	✓	✓
FIAT	Grande PUNTO	1.4 16V	Bosch Motronic Me7.6.3 Injection (EP Eng. 16V) Outside EEC	✓	✓	✓	✓	✓
FIAT	Grande PUNTO	1.4 16V	Marelli Cluster (EP)	✓	✓	✓	✓	✓
FIAT	Grande PUNTO	1.4 16V	Marelli Instrument Cluster (EP) 3	✓	✓	✓	✓	✓
FIAT	Grande PUNTO	1.4 16V	Marelli/Microsoft C3 (EP) Convergence	✓	✓	✓	✓	✓
FIAT	Grande PUNTO	1.4 16V	Marelli/Microsoft Convergence (EP)	✓	✓	✓	✓	✓
FIAT	Grande PUNTO	1.4 16V	Bosch ABS 8 ESP (EP)	✓	✓	✓	✓	✓
FIAT	Grande PUNTO	1.4 16V	Bosch ABS 8 ESP (EP) 2	✓	✓	✓	✓	✓
FIAT	Grande PUNTO	1.4 16V	Continental Airbag (EP-Proxy) 2	✓	✓	✓	✓	✓
FIAT	Grande PUNTO	1.4 16V	Delphi (EP) 3 Body Computer	✓	✓	✓	✓	✓
FIAT	Grande PUNTO	1.4 16V	TRW Airbag (EP - Proxi)	✓	✓	✓	✓	✓
FIAT	Grande PUNTO	1.4 16V	Delphi Body Computer (EP)	✓	✓	✓	✓	✓
FIAT	Grande PUNTO	1.4 16V	Delphi Body Computer (EP) 4	✓	✓	✓	✓	✓
FIAT	Grande PUNTO	1.4 16V	DELPHI (EP) 2 Power Steering	✓	✓	✓	✓	✓
FIAT	Grande PUNTO	1.4 16V	Delphi (EP) 3 Electric Steering	✓	✓	✓	✓	✓
FIAT	Grande PUNTO	1.4 16V	Denso Climate Control (EP)	✓	✓	✓	✓	✓
FIAT	Grande PUNTO	1.4 16V	Denso Heater (EP)	✓	✓	✓	✓	✓
FIAT	Grande PUNTO	1.4 16V	Trw Tyre Pressure Control (EP)	✓	✓	✓	✓	✓
FIAT	Grande PUNTO	1.4 16V	VALEO Parking Control Unit (EP) 2	✓	✓	✓	✓	✓
FIAT	Grande PUNTO	1.4 8V	Automatic Gearbox Marelli SELESPEED CFC328 2	✓	✓	✓	✓	✓
FIAT	Grande PUNTO	1.4 8V	Injection Landi Renzo LCO2 Gas	✓	✓	✓	✓	✓
FIAT	Grande PUNTO	1.4 8V	Magneti Marelli Injection 5SF8 / SDU CF5/E0BD LPG (EP)	✓	✓	✓	✓	✓
FIAT	Grande PUNTO	1.4 8V	Magneti Marelli Injection IAW 5SF8 Natural Power (EP Eng. 8V)	✓	✓	✓	✓	✓
FIAT	Grande PUNTO	1.4 8V	Marelli Injection IAW 5SF8 CF5/E0BD (EP Eng. 8V)	✓	✓	✓	✓	✓
FIAT	Grande PUNTO	1.4 8V	Marelli Injection IAW 5SF3 CP4/E0BD (EP Eng. 8V)	✓	✓	✓	✓	✓
FIAT	Grande PUNTO	1.4 8V	Marelli IAW 5SF3 Injection (EP Eng. 8V) Outside EEC	✓	✓	✓	✓	✓
FIAT	Grande PUNTO	1.4 8V	Magneti Marelli Injection IAW 5SF9 CF5/E0BD (EP Eng. 8V)	✓	✓	✓	✓	✓
FIAT	Grande PUNTO	1.4 8V	Marelli Cluster (EP)	✓	✓	✓	✓	✓
FIAT	Grande PUNTO	1.4 8V	Marelli Instrument Cluster (EP) 3	✓	✓	✓	✓	✓
FIAT	Grande PUNTO	1.4 8V	Marelli/Microsoft C3 (EP) Convergence	✓	✓	✓	✓	✓
FIAT	Grande PUNTO	1.4 8V	Marelli/Microsoft Convergence (EP)	✓	✓	✓	✓	✓
FIAT	Grande PUNTO	1.4 8V	Bosch ABS 8 ESP (EP)	✓	✓	✓	✓	✓
FIAT	Grande PUNTO	1.4 8V	Bosch ABS 8 ESP (EP) 2	✓	✓	✓	✓	✓
FIAT	Grande PUNTO	1.4 8V	Continental Airbag (EP-Proxy) 2	✓	✓	✓	✓	✓
FIAT	Grande PUNTO	1.4 8V	Delphi (EP) 3 Body Computer	✓	✓	✓	✓	✓
FIAT	Grande PUNTO	1.4 8V	TRW Airbag (EP - Proxi)	✓	✓	✓	✓	✓
FIAT	Grande PUNTO	1.4 8V	Delphi Body Computer (EP)	✓	✓	✓	✓	✓
FIAT	Grande PUNTO	1.4 8V	Delphi Body Computer (EP) 4	✓	✓	✓	✓	✓
FIAT	Grande PUNTO	1.4 8V	DELPHI (EP) 2 Power Steering	✓	✓	✓	✓	✓
FIAT	Grande PUNTO	1.4 8V	Delphi (EP) 3 Electric Steering	✓	✓	✓	✓	✓
FIAT	Grande PUNTO	1.4 8V	Denso Climate Control (EP)	✓	✓	✓	✓	✓
FIAT	Grande PUNTO	1.4 8V	Denso Heater (EP)	✓	✓	✓	✓	✓
FIAT	Grande PUNTO	1.4 8V	Trw Tyre Pressure Control (EP)	✓	✓	✓	✓	✓
FIAT	Grande PUNTO	1.4 8V	VALEO Parking Control Unit (EP) 2	✓	✓	✓	✓	✓
FIAT	Grande PUNTO	1.4 TURBO 16V	Bosch Motronic Injection Me7.9.10 CF5/E0BD (EP Eng. 1.4)	✓	✓	✓	✓	✓
FIAT	Grande PUNTO	1.4 TURBO 16V	Marelli Cluster (EP)	✓	✓	✓	✓	✓
FIAT	Grande PUNTO	1.4 TURBO 16V	Marelli Instrument Cluster (EP) 3	✓	✓	✓	✓	✓
FIAT	Grande PUNTO	1.4 TURBO 16V	Marelli/Microsoft C3 (EP) Convergence	✓	✓	✓	✓	✓
FIAT	Grande PUNTO	1.4 TURBO 16V	Marelli/Microsoft Convergence (EP)	✓	✓	✓	✓	✓
FIAT	Grande PUNTO	1.4 TURBO 16V	Bosch ABS 8 ESP (EP)	✓	✓	✓	✓	✓
FIAT	Grande PUNTO	1.4 TURBO 16V	Bosch ABS 8 ESP (EP) 2	✓	✓	✓	✓	✓
FIAT	Grande PUNTO	1.4 TURBO 16V	Continental Airbag (EP-Proxy) 2	✓	✓	✓	✓	✓
FIAT	Grande PUNTO	1.4 TURBO 16V	Delphi (EP) 3 Body Computer	✓	✓	✓	✓	✓

FIAT	Grande PUNTO	1.4 TURBO 16V	TRW Airbag (EP - Proxi)	✓	✓	✓	✓	✓	
FIAT	Grande PUNTO	1.4 TURBO 16V	Delphi Body Computer (EP)	✓	✓	✓	✓	✓	
FIAT	Grande PUNTO	1.4 TURBO 16V	Delphi Body Computer (EP) 4	✓	✓	✓	✓	✓	
FIAT	Grande PUNTO	1.4 TURBO 16V	DELPHI (EP) 2 Power Steering	✓	✓	✓	✓		
FIAT	Grande PUNTO	1.4 TURBO 16V	Delphi (EP) 3 Electric Steering	✓	✓	✓	✓		
FIAT	Grande PUNTO	1.4 TURBO 16V	Denso Climate Control (EP)	✓	✓	✓	✓	✓	
FIAT	Grande PUNTO	1.4 TURBO 16V	Denso Heater (EP)	✓	✓	✓	✓	✓	
FIAT	Grande PUNTO	1.4 TURBO 16V	Trw Tyre Pressure Control (EP)	✓	✓	✓	✓	✓	
FIAT	Grande PUNTO	1.4 TURBO 16V	VALEO Parking Control Unit (EP) 2	✓	✓	✓	✓		
FIAT	Grande PUNTO	1.6 MJET 16V	Diesel Bosch Injection EDC16C39 CF5/EOBD CAN (EP 1.6/2.0 Eng.)	✓	✓	✓	✓	✓	
FIAT	Grande PUNTO	1.6 MJET 16V	Marelli Instrument Cluster (EP) 3	✓	✓	✓	✓	✓	
FIAT	Grande PUNTO	1.6 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	✓	✓	✓	✓	✓	
FIAT	Grande PUNTO	1.6 MJET 16V	Marelli/Microsoft Convergence (EP)	✓	✓	✓	✓	✓	
FIAT	Grande PUNTO	1.6 MJET 16V	Bosch ABS 8 ESP (EP) 2	✓	✓	✓	✓		
FIAT	Grande PUNTO	1.6 MJET 16V	Continental Airbag (EP-Proxy) 2	✓	✓	✓	✓	✓	
FIAT	Grande PUNTO	1.6 MJET 16V	Delphi (EP) 3 Body Computer	✓	✓	✓	✓	✓	
FIAT	Grande PUNTO	1.6 MJET 16V	Delphi Body Computer (EP) 4	✓	✓	✓	✓	✓	
FIAT	Grande PUNTO	1.6 MJET 16V	Delphi (EP) 3 Electric Steering	✓	✓	✓	✓	✓	
FIAT	Grande PUNTO	1.6 MJET 16V	Denso Climate Control (EP)	✓	✓	✓	✓	✓	
FIAT	Grande PUNTO	1.6 MJET 16V	Denso Heater (EP)	✓	✓	✓	✓	✓	
FIAT	Grande PUNTO	1.6 MJET 16V	Trw Tyre Pressure Control (EP)	✓	✓	✓	✓	✓	
FIAT	Grande PUNTO	1.6 MJET 16V	VALEO Parking Control Unit (EP) 2	✓	✓	✓	✓		
FIAT	Grande PUNTO	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/EOBD CAN (EP Eng. 1.9)	✓	✓	✓	✓	✓	
FIAT	Grande PUNTO	1.9 MJET 8V	Bosch EDC16C39 CAN Diesel Injection (EP Eng. 1.9) Outside EEC	✓	✓	✓	✓	✓	
FIAT	Grande PUNTO	1.9 MJET 8V	Marelli Cluster (EP)	✓	✓	✓	✓	✓	
FIAT	Grande PUNTO	1.9 MJET 8V	Marelli Instrument Cluster (EP) 3	✓	✓	✓	✓	✓	
FIAT	Grande PUNTO	1.9 MJET 8V	Marelli/Microsoft C3 (EP) Convergence	✓	✓	✓	✓	✓	
FIAT	Grande PUNTO	1.9 MJET 8V	Marelli/Microsoft Convergence (EP)	✓	✓	✓	✓	✓	
FIAT	Grande PUNTO	1.9 MJET 8V	Bosch ABS 8 ESP (EP)	✓	✓	✓	✓		
FIAT	Grande PUNTO	1.9 MJET 8V	Bosch ABS 8 ESP (EP) 2	✓	✓	✓	✓		
FIAT	Grande PUNTO	1.9 MJET 8V	Continental Airbag (EP-Proxy) 2	✓	✓	✓	✓	✓	
FIAT	Grande PUNTO	1.9 MJET 8V	Delphi (EP) 3 Body Computer	✓	✓	✓	✓	✓	
FIAT	Grande PUNTO	1.9 MJET 8V	TRW Airbag (EP - Proxi)	✓	✓	✓	✓	✓	
FIAT	Grande PUNTO	1.9 MJET 8V	Delphi Body Computer (EP)	✓	✓	✓	✓	✓	
FIAT	Grande PUNTO	1.9 MJET 8V	Delphi Body Computer (EP) 4	✓	✓	✓	✓	✓	
FIAT	Grande PUNTO	1.9 MJET 8V	DELPHI (EP) 2 Power Steering	✓	✓	✓	✓		
FIAT	Grande PUNTO	1.9 MJET 8V	Delphi (EP) 3 Electric Steering	✓	✓	✓	✓		
FIAT	Grande PUNTO	1.9 MJET 8V	Denso Climate Control (EP)	✓	✓	✓	✓	✓	
FIAT	Grande PUNTO	1.9 MJET 8V	Denso Heater (EP)	✓	✓	✓	✓	✓	
FIAT	Grande PUNTO	1.9 MJET 8V	Trw Tyre Pressure Control (EP)	✓	✓	✓	✓	✓	
FIAT	Grande PUNTO	1.9 MJET 8V	VALEO Parking Control Unit (EP) 2	✓	✓	✓	✓		
FIAT	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli 6F3 EOBD CAN Diesel Injection (EP Eng. 1.3 JTD) 2	✓	✓	✓	✓	✓	
FIAT	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Diesel Injection 8DF CF5/EOBD (EP Eng. 1.3 JTD)	✓	✓	✓	✓	✓	
FIAT	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli SELESPEED CFC300 (EP) Automatic Gearbox	✓	✓	✓	✓		
FIAT	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Cluster (EP)	✓	✓	✓	✓	✓	
FIAT	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli Instrument Cluster (EP) 3	✓	✓	✓	✓	✓	
FIAT	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli/Microsoft C3 (EP) Convergence	✓	✓	✓	✓	✓	
FIAT	GRANDE PUNTO VAN	1.3 MJET 16V	Marelli/Microsoft Convergence (EP)	✓	✓	✓	✓	✓	
FIAT	GRANDE PUNTO VAN	1.3 MJET 16V	Bosch ABS 8 ESP (EP)	✓	✓	✓	✓		
FIAT	GRANDE PUNTO VAN	1.3 MJET 16V	Bosch ABS 8 ESP (EP) 2	✓	✓	✓	✓		
FIAT	GRANDE PUNTO VAN	1.3 MJET 16V	Continental Airbag (EP-Proxy) 2	✓	✓	✓	✓	✓	
FIAT	GRANDE PUNTO VAN	1.3 MJET 16V	Delphi (EP) 3 Body Computer	✓	✓	✓	✓	✓	
FIAT	GRANDE PUNTO VAN	1.3 MJET 16V	Delphi Body Computer (EP)	✓	✓	✓	✓	✓	
FIAT	GRANDE PUNTO VAN	1.3 MJET 16V	Delphi Body Computer (EP) 4	✓	✓	✓	✓	✓	
FIAT	GRANDE PUNTO VAN	1.3 MJET 16V	DELPHI (EP) 2 Power Steering	✓	✓	✓	✓		
FIAT	GRANDE PUNTO VAN	1.3 MJET 16V	Delphi (EP) 3 Electric Steering	✓	✓	✓	✓		

FIAT	GRANDE PUNTO VAN	1.3 MJET 16V	Denso Climate Control (EP)	✓	✓	✓	✓	✓	
FIAT	GRANDE PUNTO VAN	1.3 MJET 16V	Denso Heater (EP)	✓	✓	✓	✓	✓	
FIAT	GRANDE PUNTO VAN	1.3 MJET 16V	Trw Tyre Pressure Control (EP)	✓	✓	✓	✓	✓	
FIAT	GRANDE PUNTO VAN	1.3 MJET 16V	VALEO Parking Control Unit (EP) 2	✓	✓	✓	✓	✓	
FIAT	GRANDE PUNTO VAN	1.4 8V	Automatic Gearbox Marelli SELESPEED CFC328 2	✓	✓	✓	✓	✓	
FIAT	GRANDE PUNTO VAN	1.4 8V	Injection Landi Renzo LCO2 Gas	✓	✓	✓	✓	✓	
FIAT	GRANDE PUNTO VAN	1.4 8V	Magneti Marelli Injection 5SF8 / SDU CF5/EOBD LPG (EP)	✓	✓	✓	✓	✓	
FIAT	GRANDE PUNTO VAN	1.4 8V	Magneti Marelli Injection IAW 5SF8 Natural Power (EP Eng. 8V)	✓	✓	✓	✓	✓	
FIAT	GRANDE PUNTO VAN	1.4 8V	Marelli Injection IAW 5SF8 CF5/EOBD (EP Eng. 8V)	✓	✓	✓	✓	✓	
FIAT	GRANDE PUNTO VAN	1.4 8V	Marelli Injection IAW 5SF3 CP4/EOBD (EP Eng. 8V)	✓	✓	✓	✓	✓	
FIAT	GRANDE PUNTO VAN	1.4 8V	Marelli IAW 5SF3 Injection (EP Eng. 8V) Outside EEC	✓	✓	✓	✓	✓	
FIAT	GRANDE PUNTO VAN	1.4 8V	Magneti Marelli Injection IAW 5SF9 CF5/EOBD (EP Eng. 8V)	✓	✓	✓	✓	✓	
FIAT	GRANDE PUNTO VAN	1.4 8V	Marelli Cluster (EP)	✓	✓	✓	✓	✓	
FIAT	GRANDE PUNTO VAN	1.4 8V	Marelli Instrument Cluster (EP) 3	✓	✓	✓	✓	✓	
FIAT	GRANDE PUNTO VAN	1.4 8V	Marelli/Microsoft C3 (EP) Convergence	✓	✓	✓	✓	✓	
FIAT	GRANDE PUNTO VAN	1.4 8V	Marelli/Microsoft Convergence (EP)	✓	✓	✓	✓	✓	
FIAT	GRANDE PUNTO VAN	1.4 8V	Bosch ABS 8 ESP (EP)	✓	✓	✓	✓	✓	
FIAT	GRANDE PUNTO VAN	1.4 8V	Bosch ABS 8 ESP (EP) 2	✓	✓	✓	✓	✓	
FIAT	GRANDE PUNTO VAN	1.4 8V	Continental Airbag (EP-Proxi) 2	✓	✓	✓	✓	✓	
FIAT	GRANDE PUNTO VAN	1.4 8V	Delphi (EP) 3 Body Computer	✓	✓	✓	✓	✓	
FIAT	GRANDE PUNTO VAN	1.4 8V	TRW Airbag (EP - Proxi)	✓	✓	✓	✓	✓	
FIAT	GRANDE PUNTO VAN	1.4 8V	Delphi Body Computer (EP)	✓	✓	✓	✓	✓	
FIAT	GRANDE PUNTO VAN	1.4 8V	Delphi Body Computer (EP) 4	✓	✓	✓	✓	✓	
FIAT	GRANDE PUNTO VAN	1.4 8V	DELPHI (EP) 2 Power Steering	✓	✓	✓	✓	✓	
FIAT	GRANDE PUNTO VAN	1.4 8V	Delphi (EP) 3 Electric Steering	✓	✓	✓	✓	✓	
FIAT	GRANDE PUNTO VAN	1.4 8V	Denso Climate Control (EP)	✓	✓	✓	✓	✓	
FIAT	GRANDE PUNTO VAN	1.4 8V	Denso Heater (EP)	✓	✓	✓	✓	✓	
FIAT	GRANDE PUNTO VAN	1.4 8V	Trw Tyre Pressure Control (EP)	✓	✓	✓	✓	✓	
FIAT	GRANDE PUNTO VAN	1.4 8V	VALEO Parking Control Unit (EP) 2	✓	✓	✓	✓	✓	
FIAT	IDEA	1.2 16V	Bosch Motronic ME7.3H4M EOBD Injection	✓	✓	✓	✓	✓	
FIAT	IDEA	1.2 16V	Marelli 3 Connect (Multi-Model)	✓	✓	✓	✓	✓	
FIAT	IDEA	1.2 16V	Marelli Instrument Panel (Comfort)	✓	✓	✓	✓	✓	
FIAT	IDEA	1.2 16V	Marelli Instrument Panel (Modal)	✓	✓	✓	✓	✓	
FIAT	IDEA	1.2 16V	Bosch 8 ABS	✓	✓	✓	✓	✓	
FIAT	IDEA	1.2 16V	Bosch 8 VDC ABS	✓	✓	✓	✓	✓	
FIAT	IDEA	1.2 16V	Marelli 7 Body Computer	✓	✓	✓	✓	✓	
FIAT	IDEA	1.2 16V	Marelli Body Computer 1	✓	✓	✓	✓	✓	
FIAT	IDEA	1.2 16V	TRW MY 03 Airbag (2F-2P-1)	✓	✓	✓	✓	✓	
FIAT	IDEA	1.2 16V	TRW MY 03 Airbag (2F-2P-2T-1)	✓	✓	✓	✓	✓	
FIAT	IDEA	1.2 16V	TRW MY 03 Airbag (2F-2P-2L-2T-1)	✓	✓	✓	✓	✓	
FIAT	IDEA	1.2 16V	Denso Climate Control 1 (Two-Zone)	✓	✓	✓	✓	✓	
FIAT	IDEA	1.2 16V	Marelli/Microsoft Convergence	✓	✓	✓	✓	✓	
FIAT	IDEA	1.2 16V	TRW 1 Power Steering	✓	✓	✓	✓	✓	
FIAT	IDEA	1.2 16V	TRW 3 Electric Steering	✓	✓	✓	✓	✓	
FIAT	IDEA	1.2 16V	G.E. PROCOND Boot	✓	✓	✓	✓	✓	
FIAT	IDEA	1.2 16V	G.E. PROCOND Driver's Door	✓	✓	✓	✓	✓	
FIAT	IDEA	1.2 16V	Single Driver's Door G.E. PROCOND	✓	✓	✓	✓	✓	
FIAT	IDEA	1.2 16V	G.E. PROCOND Passenger Door	✓	✓	✓	✓	✓	
FIAT	IDEA	1.2 16V	Valeo Parking Control Unit	✓	✓	✓	✓	✓	
FIAT	IDEA	1.2 16V	Single Bitron Driver's Door	✓	✓	✓	✓	✓	
FIAT	IDEA	1.3 JTD	Automatic Gearbox Marelli SELESPEED CFC308F	✓	✓	✓	✓	✓	
FIAT	IDEA	1.3 JTD	Marelli 6JF EOBD Diesel Injection (Eng. 1.3 JTD)	✓	✓	✓	✓	✓	
FIAT	IDEA	1.3 JTD	Marelli Automatic Gearbox SELESPEED CFC208F (1)	✓	✓	✓	✓	✓	
FIAT	IDEA	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (Eng. 1.3 JTD)	✓	✓	✓	✓	✓	
FIAT	IDEA	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (Eng. 1.3 JTD)	✓	✓	✓	✓	✓	
FIAT	IDEA	1.3 JTD	Marelli 3 Connect (Multi-Model)	✓	✓	✓	✓	✓	



FIAT	IDEA	1.3 JTD	Marelli Instrument Panel (Comfort)	✓	✓	✓	✓	✓	
FIAT	IDEA	1.3 JTD	Marelli Instrument Panel (Modal)	✓	✓	✓	✓	✓	
FIAT	IDEA	1.3 JTD	Bosch 8 ABS	✓	✓	✓	✓		
FIAT	IDEA	1.3 JTD	Bosch 8 VDC ABS	✓	✓	✓	✓		
FIAT	IDEA	1.3 JTD	Marelli 7 Body Computer	✓	✓	✓	✓	✓	
FIAT	IDEA	1.3 JTD	Marelli Body Computer 1	✓	✓	✓	✓	✓	
FIAT	IDEA	1.3 JTD	TRW MY 03 Airbag (2F-2P-I)	✓	✓	✓	✓	✓	
FIAT	IDEA	1.3 JTD	TRW MY 03 Airbag (2F-2P-2T-1)	✓	✓	✓	✓	✓	
FIAT	IDEA	1.3 JTD	TRW MY 03 Airbag (2F-2P-2L-2T-1)	✓	✓	✓	✓	✓	
FIAT	IDEA	1.3 JTD	Denso Climate Control 1 (Two-Zone)	✓	✓	✓	✓	✓	
FIAT	IDEA	1.3 JTD	Marelli/Microsoft Convergence	✓	✓	✓	✓	✓	
FIAT	IDEA	1.3 JTD	TRW 1 Power Steering	✓	✓	✓	✓		
FIAT	IDEA	1.3 JTD	TRW 3 Electric Steering	✓	✓	✓	✓		
FIAT	IDEA	1.3 JTD	G.E. PROCOND Boot	✓	✓	✓	✓	✓	
FIAT	IDEA	1.3 JTD	G.E. PROCOND Driver's Door	✓	✓	✓	✓	✓	
FIAT	IDEA	1.3 JTD	Single Driver's Door G.E. PROCOND	✓	✓	✓	✓	✓	
FIAT	IDEA	1.3 JTD	G.E. PROCOND Passenger Door	✓	✓	✓	✓	✓	
FIAT	IDEA	1.3 JTD	Valeo Parking Control Unit	✓	✓	✓	✓		
FIAT	IDEA	1.3 JTD	Single Bitron Driver's Door	✓	✓	✓	✓	✓	
FIAT	IDEA	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (Eng. 1.4)	✓	✓	✓	✓		
FIAT	IDEA	1.4 16V	Bosch Motronic ME7.3H4M EOBD Injection	✓	✓	✓	✓		
FIAT	IDEA	1.4 16V	Marelli SELESPEED CFC228F Automatic Gearbox	✓	✓	✓	✓		
FIAT	IDEA	1.4 16V	Marelli SELESPEED CFC328 Automatic Gearbox	✓	✓	✓	✓		
FIAT	IDEA	1.4 16V	Marelli 3 Connect (Multi-Model)	✓	✓	✓	✓	✓	
FIAT	IDEA	1.4 16V	Marelli Instrument Panel (Comfort)	✓	✓	✓	✓	✓	
FIAT	IDEA	1.4 16V	Marelli Instrument Panel (Modal)	✓	✓	✓	✓	✓	
FIAT	IDEA	1.4 16V	Bosch 8 ABS	✓	✓	✓	✓		
FIAT	IDEA	1.4 16V	Bosch 8 VDC ABS	✓	✓	✓	✓		
FIAT	IDEA	1.4 16V	Marelli 7 Body Computer	✓	✓	✓	✓	✓	
FIAT	IDEA	1.4 16V	Marelli Body Computer 1	✓	✓	✓	✓	✓	
FIAT	IDEA	1.4 16V	TRW MY 03 Airbag (2F-2P-I)	✓	✓	✓	✓	✓	
FIAT	IDEA	1.4 16V	TRW MY 03 Airbag (2F-2P-2T-1)	✓	✓	✓	✓	✓	
FIAT	IDEA	1.4 16V	TRW MY 03 Airbag (2F-2P-2L-2T-1)	✓	✓	✓	✓	✓	
FIAT	IDEA	1.4 16V	Denso Climate Control 1 (Two-Zone)	✓	✓	✓	✓	✓	
FIAT	IDEA	1.4 16V	Marelli/Microsoft Convergence	✓	✓	✓	✓	✓	
FIAT	IDEA	1.4 16V	TRW 1 Power Steering	✓	✓	✓	✓		
FIAT	IDEA	1.4 16V	TRW 3 Electric Steering	✓	✓	✓	✓		
FIAT	IDEA	1.4 16V	G.E. PROCOND Boot	✓	✓	✓	✓	✓	
FIAT	IDEA	1.4 16V	G.E. PROCOND Driver's Door	✓	✓	✓	✓	✓	
FIAT	IDEA	1.4 16V	Single Driver's Door G.E. PROCOND	✓	✓	✓	✓	✓	
FIAT	IDEA	1.4 16V	G.E. PROCOND Passenger Door	✓	✓	✓	✓	✓	
FIAT	IDEA	1.4 16V	Valeo Parking Control Unit	✓	✓	✓	✓		
FIAT	IDEA	1.4 16V	Single Bitron Driver's Door	✓	✓	✓	✓	✓	
FIAT	IDEA	1.4 8V	Injection Landi Renzo LC02 Gas	✓	✓	✓	✓		
FIAT	IDEA	1.4 8V	Injection,Bosch Motronic Me7.9.9 (1.4 Eng.)	✓	✓	✓	✓		
FIAT	IDEA	1.4 8V	Magneti Marelli Injection 5SF8 / SDU CF5/EOBD LPG	✓	✓	✓	✓		
FIAT	IDEA	1.4 8V	Magneti Marelli Injection IAW 5SF CF4/EOBD (Eng. 1.4 8V)	✓	✓	✓	✓		
FIAT	IDEA	1.4 8V	Marelli 3 Connect (Multi-Model)	✓	✓	✓	✓	✓	
FIAT	IDEA	1.4 8V	Marelli Instrument Panel (Comfort)	✓	✓	✓	✓	✓	
FIAT	IDEA	1.4 8V	Marelli Instrument Panel (Modal)	✓	✓	✓	✓	✓	
FIAT	IDEA	1.4 8V	Bosch 8 ABS	✓	✓	✓	✓		
FIAT	IDEA	1.4 8V	Bosch 8 VDC ABS	✓	✓	✓	✓		
FIAT	IDEA	1.4 8V	Marelli 7 Body Computer	✓	✓	✓	✓	✓	
FIAT	IDEA	1.4 8V	Marelli Body Computer 1	✓	✓	✓	✓	✓	

FIAT	IDEA	1.4 8V	TRW MY 03 Airbag (2F-2P-1)	✓	✓	✓	✓	✓	
FIAT	IDEA	1.4 8V	TRW MY 03 Airbag (2F-2P-2T-1)	✓	✓	✓	✓	✓	
FIAT	IDEA	1.4 8V	TRW MY 03 Airbag (2F-2P-2L-2T-1)	✓	✓	✓	✓	✓	
FIAT	IDEA	1.4 8V	Denso Climate Control 1 (Two-Zone)	✓	✓	✓	✓	✓	
FIAT	IDEA	1.4 8V	Marelli/Microsoft Convergence	✓	✓	✓	✓	✓	
FIAT	IDEA	1.4 8V	TRW 1 Power Steering	✓	✓	✓	✓		
FIAT	IDEA	1.4 8V	TRW 3 Electric Steering	✓	✓	✓	✓		
FIAT	IDEA	1.4 8V	G.E. PROCOND Boot	✓	✓	✓	✓	✓	
FIAT	IDEA	1.4 8V	G.E. PROCOND Driver's Door	✓	✓	✓	✓	✓	
FIAT	IDEA	1.4 8V	Single Driver's Door G.E. PROCOND	✓	✓	✓	✓	✓	
FIAT	IDEA	1.4 8V	G.E. PROCOND Passenger Door	✓	✓	✓	✓	✓	
FIAT	IDEA	1.4 8V	Valeo Parking Control Unit	✓	✓	✓	✓		
FIAT	IDEA	1.6 16V	Marelli/Marelli IAW 7GF Injection	✓	✓	✓	✓		
FIAT	IDEA	1.6 16V	Convergence Lauberhorn Cl	✓	✓	✓	✓	✓	
FIAT	IDEA	1.6 16V	Marelli Instrument Panel (Palio RST2)	✓	✓	✓	✓	✓	
FIAT	IDEA	1.6 16V	Marelli/Microsoft Convergence	✓	✓	✓	✓	✓	
FIAT	IDEA	1.6 16V	Bosch 8 ABS	✓	✓	✓	✓		
FIAT	IDEA	1.6 16V	Bosch 8 VDC ABS	✓	✓	✓	✓		
FIAT	IDEA	1.6 16V	Marelli 7 Body Computer	✓	✓	✓	✓	✓	
FIAT	IDEA	1.6 16V	Marelli Body Computer 2	✓	✓	✓	✓	✓	
FIAT	IDEA	1.6 16V	TRW MY 97 Airbag (2F-1)	✓	✓	✓	✓		
FIAT	IDEA	1.6 16V	Trw MY 97 Airbag (2F-2L-1)	✓	✓	✓	✓		
FIAT	IDEA	1.6 16V	Valeo Parking Control Unit	✓	✓	✓	✓		
FIAT	IDEA	1.6 MJET 16V	Bosch Diese Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 Eng.)	✓	✓	✓	✓		
FIAT	IDEA	1.6 MJET 16V	Marelli 3 Connect (Multi-Model)	✓	✓	✓	✓	✓	
FIAT	IDEA	1.6 MJET 16V	Marelli Instrument Panel (Comfort)	✓	✓	✓	✓	✓	
FIAT	IDEA	1.6 MJET 16V	Marelli Instrument Panel (Modal)	✓	✓	✓	✓	✓	
FIAT	IDEA	1.6 MJET 16V	Bosch 8 ABS	✓	✓	✓	✓		
FIAT	IDEA	1.6 MJET 16V	Bosch 8 VDC ABS	✓	✓	✓	✓		
FIAT	IDEA	1.6 MJET 16V	Marelli 7 Body Computer	✓	✓	✓	✓	✓	
FIAT	IDEA	1.6 MJET 16V	TRW MY 03 Airbag (2F-2P-1)	✓	✓	✓	✓	✓	
FIAT	IDEA	1.6 MJET 16V	TRW MY 03 Airbag (2F-2P-2T-1)	✓	✓	✓	✓	✓	
FIAT	IDEA	1.6 MJET 16V	TRW MY 03 Airbag (2F-2P-2L-2T-1)	✓	✓	✓	✓	✓	
FIAT	IDEA	1.6 MJET 16V	Denso Climate Control 1 (Two-Zone)	✓	✓	✓	✓	✓	
FIAT	IDEA	1.6 MJET 16V	Marelli/Microsoft Convergence	✓	✓	✓	✓	✓	
FIAT	IDEA	1.6 MJET 16V	TRW 1 Power Steering	✓	✓	✓	✓		
FIAT	IDEA	1.6 MJET 16V	TRW 3 Electric Steering	✓	✓	✓	✓		
FIAT	IDEA	1.6 MJET 16V	G.E. PROCOND Boot	✓	✓	✓	✓	✓	
FIAT	IDEA	1.6 MJET 16V	G.E. PROCOND Driver's Door	✓	✓	✓	✓	✓	
FIAT	IDEA	1.6 MJET 16V	Single Driver's Door G.E. PROCOND	✓	✓	✓	✓	✓	
FIAT	IDEA	1.6 MJET 16V	G.E. PROCOND Passenger Door	✓	✓	✓	✓	✓	
FIAT	IDEA	1.6 MJET 16V	Valeo Parking Control Unit	✓	✓	✓	✓		
FIAT	IDEA	1.8 8V	Delphi MT27E Injection (Eng. 1.8 8V)	✓	✓	✓	✓		
FIAT	IDEA	1.8 8V	Convergence Lauberhorn Cl	✓	✓	✓	✓	✓	
FIAT	IDEA	1.8 8V	Marelli Instrument Panel (Palio RST2)	✓	✓	✓	✓	✓	
FIAT	IDEA	1.8 8V	Marelli/Microsoft Convergence	✓	✓	✓	✓	✓	
FIAT	IDEA	1.8 8V	Bosch 8 ABS	✓	✓	✓	✓		
FIAT	IDEA	1.8 8V	Bosch 8 VDC ABS	✓	✓	✓	✓		
FIAT	IDEA	1.8 8V	Marelli 7 Body Computer	✓	✓	✓	✓	✓	
FIAT	IDEA	1.8 8V	Marelli Body Computer 2	✓	✓	✓	✓	✓	
FIAT	IDEA	1.8 8V	TRW MY 97 Airbag (2F-1)	✓	✓	✓	✓		
FIAT	IDEA	1.8 8V	Trw MY 97 Airbag (2F-2L-1)	✓	✓	✓	✓		
FIAT	IDEA	1.8 8V	Valeo Parking Control Unit	✓	✓	✓	✓		
FIAT	IDEA	1.9 JTD	Bosch EDC16C9 CF3/EOBD Diesel Injection (1.9 Eng.)	✓	✓	✓	✓		
FIAT	IDEA	1.9 JTD	Bosch EDC16C9 CF4/EOBD Diesel Injection (1.9 Eng.)	✓	✓	✓	✓		

FIAT	IDEA	1.9 JTD	Marelli 3 Connect (Multi-Model)	✓	✓	✓	✓	✓	
FIAT	IDEA	1.9 JTD	Marelli Instrument Panel (Comfort)	✓	✓	✓	✓	✓	
FIAT	IDEA	1.9 JTD	Marelli Instrument Panel (Modal)	✓	✓	✓	✓	✓	
FIAT	IDEA	1.9 JTD	Bosch 8 ABS	✓	✓	✓	✓		
FIAT	IDEA	1.9 JTD	Bosch 8 VDC ABS	✓	✓	✓	✓		
FIAT	IDEA	1.9 JTD	Marelli 7 Body Computer	✓	✓	✓	✓	✓	
FIAT	IDEA	1.9 JTD	Marelli Body Computer 1	✓	✓	✓	✓	✓	
FIAT	IDEA	1.9 JTD	TRW MY 03 Airbag (2F-2P-1)	✓	✓	✓	✓	✓	
FIAT	IDEA	1.9 JTD	TRW MY 03 Airbag (2F-2P-2T-1)	✓	✓	✓	✓	✓	
FIAT	IDEA	1.9 JTD	TRW MY 03 Airbag (2F-2P-2L-2T-1)	✓	✓	✓	✓	✓	
FIAT	IDEA	1.9 JTD	Denso Climate Control 1 (Two-Zone)	✓	✓	✓	✓	✓	
FIAT	IDEA	1.9 JTD	Marelli/Microsoft Convergence	✓	✓	✓	✓	✓	
FIAT	IDEA	1.9 JTD	TRW 1 Power Steering	✓	✓	✓	✓		
FIAT	IDEA	1.9 JTD	TRW 3 Electric Steering	✓	✓	✓	✓		
FIAT	IDEA	1.9 JTD	G.E. PROCOND Boot	✓	✓	✓	✓	✓	
FIAT	IDEA	1.9 JTD	G.E. PROCOND Driver's Door	✓	✓	✓	✓	✓	
FIAT	IDEA	1.9 JTD	Single Driver's Door G.E. PROCOND	✓	✓	✓	✓	✓	
FIAT	IDEA	1.9 JTD	G.E. PROCOND Passenger Door	✓	✓	✓	✓	✓	
FIAT	IDEA	1.9 JTD	Valeo Parking Control Unit	✓	✓	✓	✓	✓	
FIAT	IDEA	1.9 JTD	Single Bitron Driver's Door	✓	✓	✓	✓	✓	
FIAT	IDEA VAN	1.3 JTD	Automatic Gearbox Marelli SELESPEED CFC308F	✓	✓	✓	✓		
FIAT	IDEA VAN	1.3 JTD	Marelli 6JF EOBD Diesel Injection (Eng. 1.3 JTD)	✓	✓	✓	✓		
FIAT	IDEA VAN	1.3 JTD	Marelli Automatic Gearbox SELESPEED CFC208F (1)	✓	✓	✓	✓		
FIAT	IDEA VAN	1.3 JTD	Marelli Diesel Injection 8DF CF5/EOBD (Eng. 1.3 JTD)	✓	✓	✓	✓		
FIAT	IDEA VAN	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (Eng. 1.3 JTD)	✓	✓	✓	✓		
FIAT	IDEA VAN	1.3 JTD	Marelli 3 Connect (Multi-Model)	✓	✓	✓	✓	✓	
FIAT	IDEA VAN	1.3 JTD	Marelli Instrument Panel (Comfort)	✓	✓	✓	✓	✓	
FIAT	IDEA VAN	1.3 JTD	Marelli Instrument Panel (Modal)	✓	✓	✓	✓	✓	
FIAT	IDEA VAN	1.3 JTD	Bosch 8 ABS	✓	✓	✓	✓		
FIAT	IDEA VAN	1.3 JTD	Bosch 8 VDC ABS	✓	✓	✓	✓		
FIAT	IDEA VAN	1.3 JTD	Marelli 7 Body Computer	✓	✓	✓	✓	✓	
FIAT	IDEA VAN	1.3 JTD	Marelli Body Computer 1	✓	✓	✓	✓	✓	
FIAT	IDEA VAN	1.3 JTD	TRW MY 03 Airbag (2F-2P-1)	✓	✓	✓	✓	✓	
FIAT	IDEA VAN	1.3 JTD	TRW MY 03 Airbag (2F-2P-2T-1)	✓	✓	✓	✓	✓	
FIAT	IDEA VAN	1.3 JTD	TRW MY 03 Airbag (2F-2P-2L-2T-1)	✓	✓	✓	✓	✓	
FIAT	IDEA VAN	1.3 JTD	Denso Climate Control 1 (Two-Zone)	✓	✓	✓	✓	✓	
FIAT	IDEA VAN	1.3 JTD	Marelli/Microsoft Convergence	✓	✓	✓	✓	✓	
FIAT	IDEA VAN	1.3 JTD	TRW 1 Power Steering	✓	✓	✓	✓		
FIAT	IDEA VAN	1.3 JTD	TRW 3 Electric Steering	✓	✓	✓	✓		
FIAT	IDEA VAN	1.3 JTD	G.E. PROCOND Boot	✓	✓	✓	✓	✓	
FIAT	IDEA VAN	1.3 JTD	G.E. PROCOND Driver's Door	✓	✓	✓	✓	✓	
FIAT	IDEA VAN	1.3 JTD	G.E. PROCOND Passenger Door	✓	✓	✓	✓	✓	
FIAT	IDEA VAN	1.3 JTD	Valeo Parking Control Unit	✓	✓	✓	✓		
FIAT	IDEA VAN	1.3 JTD	Single Bitron Driver's Door	✓	✓	✓	✓	✓	
FIAT	IDEA VAN	1.4 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (Eng. 1.4)	✓	✓	✓	✓		
FIAT	IDEA VAN	1.4 16V	Bosch Motronic ME7.3H4M EOBD Injection	✓	✓	✓	✓		
FIAT	IDEA VAN	1.4 16V	Marelli SELESPEED CFC228F Automatic Gearbox	✓	✓	✓	✓		
FIAT	IDEA VAN	1.4 16V	Marelli SELESPEED CFC328 Automatic Gearbox	✓	✓	✓	✓		
FIAT	IDEA VAN	1.4 16V	Marelli 3 Connect (Multi-Model)	✓	✓	✓	✓	✓	
FIAT	IDEA VAN	1.4 16V	Marelli Instrument Panel (Comfort)	✓	✓	✓	✓	✓	
FIAT	IDEA VAN	1.4 16V	Marelli Instrument Panel (Modal)	✓	✓	✓	✓	✓	
FIAT	IDEA VAN	1.4 16V	Bosch 8 ABS	✓	✓	✓	✓		
FIAT	IDEA VAN	1.4 16V	Bosch 8 VDC ABS	✓	✓	✓	✓		
FIAT	IDEA VAN	1.4 16V	Marelli 7 Body Computer	✓	✓	✓	✓	✓	
FIAT	IDEA VAN	1.4 16V	Marelli Body Computer 1	✓	✓	✓	✓	✓	
FIAT	IDEA VAN	1.4 16V	TRW MY 03 Airbag (2F-2P-1)	✓	✓	✓	✓	✓	

FIAT	IDEA VAN	1.4 16V	TRW MY 03 Airbag (2F-2P-2T-I)	✓	✓	✓	✓	✓
FIAT	IDEA VAN	1.4 16V	TRW MY 03 Airbag (2F-2P-2L-2T-I)	✓	✓	✓	✓	✓
FIAT	IDEA VAN	1.4 16V	Denso Climate Control 1 (Two-Zone)	✓	✓	✓	✓	✓
FIAT	IDEA VAN	1.4 16V	Marelli/Microsoft Convergence	✓	✓	✓	✓	✓
FIAT	IDEA VAN	1.4 16V	TRW 1 Power Steering	✓	✓	✓	✓	
FIAT	IDEA VAN	1.4 16V	TRW 3 Electric Steering	✓	✓	✓	✓	
FIAT	IDEA VAN	1.4 16V	G.E. PROCOND Boot	✓	✓	✓	✓	✓
FIAT	IDEA VAN	1.4 16V	G.E. PROCOND Driver's Door	✓	✓	✓	✓	✓
FIAT	IDEA VAN	1.4 16V	G.E. PROCOND Passenger Door	✓	✓	✓	✓	✓
FIAT	IDEA VAN	1.4 16V	Valeo Parking Control Unit	✓	✓	✓	✓	
FIAT	IDEA VAN	1.4 16V	Single Bitron Driver's Door	✓	✓	✓	✓	✓
FIAT	LINEA	1.3 JTD	Autoliv 1 Airbag (Proxi)	✓	✓	✓	✓	✓
FIAT	LINEA	1.3 JTD	Bosch 8 ABS	✓	✓	✓	✓	
FIAT	LINEA	1.3 JTD	Bosch 8 VDC ABS	✓	✓	✓	✓	
FIAT	LINEA	1.3 JTD	Bosch Parking Control Unit (1)	✓	✓	✓	✓	
FIAT	LINEA	1.3 JTD	Marelli Body Computer 9	✓	✓	✓	✓	✓
FIAT	LINEA	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (Eng. 1.3 JTD)	✓	✓	✓	✓	
FIAT	LINEA	1.3 JTD	Marelli Instrument Panel 3	✓	✓	✓	✓	
FIAT	LINEA	1.3 JTD	Marelli SELESPEED CFC300 Automatic Gearbox	✓	✓	✓	✓	
FIAT	LINEA	1.3 JTD	Marelli/Microsoft Convergence	✓	✓	✓	✓	✓
FIAT	LINEA	1.3 JTD	Climate Control Denso 2 (Single - Zone)	✓	✓	✓	✓	✓
FIAT	LINEA	1.4 16V	Autoliv 1 Airbag (Proxi)	✓	✓	✓	✓	✓
FIAT	LINEA	1.4 16V	Bosch 8 ABS	✓	✓	✓	✓	
FIAT	LINEA	1.4 16V	Bosch 8 VDC ABS	✓	✓	✓	✓	
FIAT	LINEA	1.4 16V	Bosch Injection Motronic Me7.9.10 PDA (Eng. 1.4)	✓	✓	✓	✓	
FIAT	LINEA	1.4 16V	Marelli Body Computer 9	✓	✓	✓	✓	✓
FIAT	LINEA	1.4 16V	Marelli Instrument Panel 3	✓	✓	✓	✓	
FIAT	LINEA	1.4 16V	Bosch Parking Control Unit (1)	✓	✓	✓	✓	
FIAT	LINEA	1.4 16V	Marelli/Microsoft Convergence	✓	✓	✓	✓	✓
FIAT	LINEA	1.4 16V	Climate Control Denso 2 (Single - Zone)	✓	✓	✓	✓	✓
FIAT	LINEA	1.4 8V	Autoliv 1 Airbag (Proxi)	✓	✓	✓	✓	✓
FIAT	LINEA	1.4 8V	Bosch 8 ABS	✓	✓	✓	✓	
FIAT	LINEA	1.4 8V	Bosch 8 VDC ABS	✓	✓	✓	✓	
FIAT	LINEA	1.4 8V	Bosch Parking Control Unit (1)	✓	✓	✓	✓	
FIAT	LINEA	1.4 8V	Marelli Body Computer 9	✓	✓	✓	✓	✓
FIAT	LINEA	1.4 8V	Marelli Instrument Panel 3	✓	✓	✓	✓	
FIAT	LINEA	1.4 8V	Marelli/Microsoft Convergence	✓	✓	✓	✓	✓
FIAT	LINEA	1.4 8V	Magneti Marelli Injection IAW 5SF CF4/EOBD (Eng. 1.4 8V)	✓	✓	✓	✓	
FIAT	LINEA	1.4 8V	Climate Control Denso 2 (Single - Zone)	✓	✓	✓	✓	✓
FIAT	LINEA	1.4 TURBO 16V	Autoliv 1 Airbag (Proxi)	✓	✓	✓	✓	✓
FIAT	LINEA	1.4 TURBO 16V	Bosch 8 ABS	✓	✓	✓	✓	
FIAT	LINEA	1.4 TURBO 16V	Bosch 8 VDC ABS	✓	✓	✓	✓	
FIAT	LINEA	1.4 TURBO 16V	Bosch Motronic Injection Me7.9.10 CF5/EOBD (Eng. 1.4)	✓	✓	✓	✓	
FIAT	LINEA	1.4 TURBO 16V	Marelli Body Computer 9	✓	✓	✓	✓	✓
FIAT	LINEA	1.4 TURBO 16V	Marelli Instrument Panel 3	✓	✓	✓	✓	
FIAT	LINEA	1.4 TURBO 16V	Bosch Parking Control Unit (1)	✓	✓	✓	✓	
FIAT	LINEA	1.4 TURBO 16V	Marelli/Microsoft Convergence	✓	✓	✓	✓	✓
FIAT	LINEA	1.4 TURBO 16V	Climate Control Denso 2 (Single - Zone)	✓	✓	✓	✓	✓
FIAT	LINEA	1.6 16V	Autoliv 1 Airbag (Proxi)	✓	✓	✓	✓	✓
FIAT	LINEA	1.6 16V	Automatic Gearbox Marelli SELESPEED CFC319	✓	✓	✓	✓	
FIAT	LINEA	1.6 16V	Bosch 8 ABS	✓	✓	✓	✓	
FIAT	LINEA	1.6 16V	Bosch 8 VDC ABS	✓	✓	✓	✓	
FIAT	LINEA	1.6 16V	Marelli Body Computer 9	✓	✓	✓	✓	✓
FIAT	LINEA	1.6 16V	Marelli Instrument Panel 3	✓	✓	✓	✓	

FIAT	LINEA	1.6 16V	Bosch Parking Control Unit (1)	✓	✓	✓	✓		
FIAT	LINEA	1.6 16V	Marelli/Microsoft Convergence	✓	✓	✓	✓	✓	
FIAT	LINEA	1.6 16V	Magneti Marelli IAW 59F 5SF8/5SF9 Tritec Injection	✓	✓	✓	✓		
FIAT	LINEA	1.6 16V	Climate Control Denso 2 (Single - Zone)	✓	✓	✓	✓	✓	
FIAT	LINEA	1.6 JTD	Autoliv 1 Airbag (Proxi)	✓	✓	✓	✓	✓	
FIAT	LINEA	1.6 JTD	Bosch 8 ABS	✓	✓	✓	✓		
FIAT	LINEA	1.6 JTD	Bosch 8 VDC ABS	✓	✓	✓	✓		
FIAT	LINEA	1.6 JTD	Bosch Diese Injection EDC16C39 CF5/E0BD (1.6/1.9/2.0 Eng.)	✓	✓	✓	✓		
FIAT	LINEA	1.6 JTD	Marelli Body Computer 9	✓	✓	✓	✓	✓	
FIAT	LINEA	1.6 JTD	Marelli Instrument Panel 3	✓	✓	✓	✓		
FIAT	LINEA	1.6 JTD	Bosch Parking Control Unit (1)	✓	✓	✓	✓		
FIAT	LINEA	1.6 JTD	Marelli/Microsoft Convergence	✓	✓	✓	✓	✓	
FIAT	LINEA	1.6 JTD	Climate Control Denso 2 (Single - Zone)	✓	✓	✓	✓	✓	
FIAT	LINEA	1.8 16V	Autoliv 1 Airbag (Proxi)	✓	✓	✓	✓	✓	
FIAT	LINEA	1.8 16V	Automatic Gearbox Marelli SELESPEED CFC319	✓	✓	✓	✓		
FIAT	LINEA	1.8 16V	Bosch 8 ABS	✓	✓	✓	✓		
FIAT	LINEA	1.8 16V	Bosch 8 VDC ABS	✓	✓	✓	✓		
FIAT	LINEA	1.8 16V	Marelli Body Computer 9	✓	✓	✓	✓	✓	
FIAT	LINEA	1.8 16V	Marelli Instrument Panel 3	✓	✓	✓	✓		
FIAT	LINEA	1.8 16V	Bosch Parking Control Unit (1)	✓	✓	✓	✓		
FIAT	LINEA	1.8 16V	Marelli/Microsoft Convergence	✓	✓	✓	✓	✓	
FIAT	LINEA	1.8 16V	Magneti Marelli IAW 76F Injection	✓	✓	✓	✓		
FIAT	LINEA	1.8 16V	Climate Control Denso 2 (Single - Zone)	✓	✓	✓	✓	✓	
FIAT	LINEA	1.9 16V	Autoliv 1 Airbag (Proxi)	✓	✓	✓	✓	✓	
FIAT	LINEA	1.9 16V	Automatic Gearbox Marelli SELESPEED CFC319	✓	✓	✓	✓		
FIAT	LINEA	1.9 16V	Bosch 8 ABS	✓	✓	✓	✓		
FIAT	LINEA	1.9 16V	Bosch 8 VDC ABS	✓	✓	✓	✓		
FIAT	LINEA	1.9 16V	Marelli Body Computer 9	✓	✓	✓	✓	✓	
FIAT	LINEA	1.9 16V	Marelli Instrument Panel 3	✓	✓	✓	✓		
FIAT	LINEA	1.9 16V	Bosch Parking Control Unit (1)	✓	✓	✓	✓		
FIAT	LINEA	1.9 16V	Marelli/Microsoft Convergence	✓	✓	✓	✓	✓	
FIAT	LINEA	1.9 16V	Magneti Marelli Injection IAW 4SF	✓	✓	✓	✓		
FIAT	LINEA	1.9 16V	Climate Control Denso 2 (Single - Zone)	✓	✓	✓	✓	✓	
FIAT	MAREA	*01 100 16V CF3	Allied MY 97 Air Bag (2F-2P-S)	✓	✓	✓	✓		
FIAT	MAREA	*01 100 16V CF3	Allied MY 97 Air Bag (2F-2P)	✓	✓	✓	✓		
FIAT	MAREA	*01 100 16V CF3	Borletti MCC55F Climate Control	✓	✓	✓	✓		

FIAT	MAREA	'01 100 16V CF3	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	✓	✓	✓	✓		
FIAT	MAREA	'01 100 16V CF3	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	✓	✓	✓	✓		
FIAT	MAREA	'01 100 16V CF3	BREED MY 97 Air Bag (2F-2P-2L-S)	✓	✓	✓	✓		
FIAT	MAREA	'01 100 16V CF3	BREED MY 97 Air Bag (2F-2P-2L)	✓	✓	✓	✓		
FIAT	MAREA	'01 150 20V CF3	Allied MY 97 Air Bag (2F-2P-S)	✓	✓	✓	✓		
FIAT	MAREA	'01 150 20V CF3	Allied MY 97 Air Bag (2F-2P)	✓	✓	✓	✓		
FIAT	MAREA	'01 150 20V CF3	Borletti MCC55F Climate Control	✓	✓	✓	✓		
FIAT	MAREA	'01 150 20V CF3	Bosch Motronic Me3.1 EOBD Injection (Eng. 2.0/2.4 20V)	✓	✓	✓	✓		
FIAT	MAREA	'01 150 20V CF3	Injection - Bosch Motronic Me3.1 (Eng. 2.0/2.4 20V) Outside EEC	✓	✓	✓	✓		
FIAT	MAREA	'01 150 20V CF3	BREED MY 97 Air Bag (2F-2P-2L-S)	✓	✓	✓	✓		
FIAT	MAREA	'01 150 20V CF3	BREED MY 97 Air Bag (2F-2P-2L)	✓	✓	✓	✓		
FIAT	MAREA	'01 JTD 110 CF3	Allied MY 97 Air Bag (2F-2P-S)	✓	✓	✓	✓		
FIAT	MAREA	'01 JTD 110 CF3	Allied MY 97 Air Bag (2F-2P)	✓	✓	✓	✓		
FIAT	MAREA	'01 JTD 110 CF3	Borletti MCC55F Climate Control	✓	✓	✓	✓		
FIAT	MAREA	'01 JTD 110 CF3	Bosch EDC15 CF3/EOBD Diesel Injection (Eng. 1.9/2.4)	✓	✓	✓	✓		
FIAT	MAREA	'01 JTD 110 CF3	BREED MY 97 Air Bag (2F-2P-2L-S)	✓	✓	✓	✓		
FIAT	MAREA	'01 JTD 110 CF3	BREED MY 97 Air Bag (2F-2P-2L)	✓	✓	✓	✓		
FIAT	MAREA	'99 100 16V	Allied MY 97 Air Bag (2F-2P-S)	✓	✓	✓	✓		
FIAT	MAREA	'99 100 16V	Allied MY 97 Air Bag (2F-2P)	✓	✓	✓	✓		
FIAT	MAREA	'99 100 16V	Magneti Marelli IAW 4GF Injection (Blu-Power)	✓	✓	✓	✓		
FIAT	MAREA	'99 100 16V	Magneti Marelli IAW 49F Injection (1.6 Eng.)	✓	✓	✓	✓		
FIAT	MAREA	'99 100 16V	Borletti MCC55F Climate Control	✓	✓	✓	✓		
FIAT	MAREA	'99 100 16V	BREED MY 97 Air Bag (2F-2P-2L-S)	✓	✓	✓	✓		
FIAT	MAREA	'99 100 16V	BREED MY 97 Air Bag (2F-2P-2L)	✓	✓	✓	✓		
FIAT	MAREA	'99 115 16V	Allied MY 97 Air Bag (2F-2P-S)	✓	✓	✓	✓		
FIAT	MAREA	'99 115 16V	Allied MY 97 Air Bag (2F-2P)	✓	✓	✓	✓		
FIAT	MAREA	'99 115 16V	Borletti MCC55F Climate Control	✓	✓	✓	✓		
FIAT	MAREA	'99 115 16V	Hitachi MPI Injection (Eng. 1.8 16V '98)	✓	✓	✓	✓		
FIAT	MAREA	'99 115 16V	BREED MY 97 Air Bag (2F-2P-2L-S)	✓	✓	✓	✓		
FIAT	MAREA	'99 115 16V	BREED MY 97 Air Bag (2F-2P-2L)	✓	✓	✓	✓		
FIAT	MAREA	'99 155 20V	Allied MY 97 Air Bag (2F-2P-S)	✓	✓	✓	✓		
FIAT	MAREA	'99 155 20V	Allied MY 97 Air Bag (2F-2P)	✓	✓	✓	✓		
FIAT	MAREA	'99 155 20V	Borletti MCC55F Climate Control	✓	✓	✓	✓		
FIAT	MAREA	'99 155 20V	Bosch Motronic ME3.1 Injection (Eng. 2.0 20V)	✓	✓	✓	✓		
FIAT	MAREA	'99 155 20V	BREED MY 97 Air Bag (2F-2P-2L-S)	✓	✓	✓	✓		
FIAT	MAREA	'99 155 20V	BREED MY 97 Air Bag (2F-2P-2L)	✓	✓	✓	✓		
FIAT	MAREA	'99 80 16V	Allied MY 97 Air Bag (2F-2P-S)	✓	✓	✓	✓		
FIAT	MAREA	'99 80 16V	Allied MY 97 Air Bag (2F-2P)	✓	✓	✓	✓		
FIAT	MAREA	'99 80 16V	Borletti MCC55F Climate Control	✓	✓	✓	✓		
FIAT	MAREA	'99 80 16V	Bosch Motronic M1.5.5 Injection (Eng. 1.2 16V)	✓	✓	✓	✓		
FIAT	MAREA	'99 80 16V	BREED MY 97 Air Bag (2F-2P-2L-S)	✓	✓	✓	✓		
FIAT	MAREA	'99 80 16V	BREED MY 97 Air Bag (2F-2P-2L)	✓	✓	✓	✓		
FIAT	MAREA	'99 JTD 105	Allied MY 97 Air Bag (2F-2P-S)	✓	✓	✓	✓		

FIAT	MAREA	'99 JTD 105	Allied MY 97 Air Bag (2F-2P)	✓	✓	✓	✓		
FIAT	MAREA	'99 JTD 105	Borletti MCC55F Climate Control	✓	✓	✓	✓		
FIAT	MAREA	'99 JTD 105	Bosch Diesel EDC15 Injection (1.9 TD D.I. Engine)	✓	✓	✓	✓		
FIAT	MAREA	'99 JTD 105	BREED MY 97 Air Bag (2F-2P-2L-S)	✓	✓	✓	✓		
FIAT	MAREA	'99 JTD 105	BREED MY 97 Air Bag (2F-2P-2L)	✓	✓	✓	✓		
FIAT	MAREA	'99 JTD 130	Allied MY 97 Air Bag (2F-2P-S)	✓	✓	✓	✓		
FIAT	MAREA	'99 JTD 130	Allied MY 97 Air Bag (2F-2P)	✓	✓	✓	✓		
FIAT	MAREA	'99 JTD 130	Borletti MCC55F Climate Control	✓	✓	✓	✓		
FIAT	MAREA	'99 JTD 130	Bosch EDC 15 Diesel Injection (2.4 TD D.I. Engine)	✓	✓	✓	✓		
FIAT	MAREA	'99 JTD 130	BREED MY 97 Air Bag (2F-2P-2L-S)	✓	✓	✓	✓		
FIAT	MAREA	'99 JTD 130	BREED MY 97 Air Bag (2F-2P-2L)	✓	✓	✓	✓		
FIAT	MAREA	1.4 12V	Allied MY 97 Air Bag (2F-2P-S)	✓	✓	✓	✓		
FIAT	MAREA	1.4 12V	Allied MY 97 Air Bag (2F-2P)	✓	✓	✓	✓		
FIAT	MAREA	1.4 12V	Borletti MCC55F Climate Control	✓	✓	✓	✓		
FIAT	MAREA	1.6 16V	Allied MY 97 Air Bag (2F-2P-S)	✓	✓	✓	✓		
FIAT	MAREA	1.6 16V	Allied MY 97 Air Bag (2F-2P)	✓	✓	✓	✓		
FIAT	MAREA	1.6 16V	Borletti MCC55F Climate Control	✓	✓	✓	✓		
FIAT	MAREA	1.6 16V	BREED MY 97 Air Bag (2F-2P-2L-S)	✓	✓	✓	✓		
FIAT	MAREA	1.6 16V GASOLINA	Allied MY 97 Air Bag (2F-2P-S)	✓	✓	✓	✓		
FIAT	MAREA	1.6 16V GASOLINA	Allied MY 97 Air Bag (2F-2P)	✓	✓	✓	✓		
FIAT	MAREA	1.6 16V GASOLINA	Borletti MCC55F Climate Control	✓	✓	✓	✓		
FIAT	MAREA	1.6 16V GASOLINA	BREED MY 97 Air Bag (2F-2P-2L-S)	✓	✓	✓	✓		
FIAT	MAREA	1.8 16V	Allied MY 97 Air Bag (2F-2P-S)	✓	✓	✓	✓		
FIAT	MAREA	1.8 16V	Allied MY 97 Air Bag (2F-2P)	✓	✓	✓	✓		
FIAT	MAREA	1.8 16V	Borletti MCC55F Climate Control	✓	✓	✓	✓		
FIAT	MAREA	1.8 16V	Hitachi MPI Injection	✓	✓	✓	✓		
FIAT	MAREA	1.8 16V	BREED MY 97 Air Bag (2F-2P-2L-S)	✓	✓	✓	✓		
FIAT	MAREA	1.9 TD 100 CV	Allied MY 97 Air Bag (2F-2P-S)	✓	✓	✓	✓		
FIAT	MAREA	1.9 TD 100 CV	Allied MY 97 Air Bag (2F-2P)	✓	✓	✓	✓		
FIAT	MAREA	1.9 TD 100 CV	Borletti MCC55F Climate Control	✓	✓	✓	✓		
FIAT	MAREA	1.9 TD 100 CV	BREED MY 97 Air Bag (2F-2P-2L-S)	✓	✓	✓	✓		
FIAT	MAREA	1.9 TD 75 CV	Allied MY 97 Air Bag (2F-2P-S)	✓	✓	✓	✓		
FIAT	MAREA	1.9 TD 75 CV	Allied MY 97 Air Bag (2F-2P)	✓	✓	✓	✓		
FIAT	MAREA	1.9 TD 75 CV	Borletti MCC55F Climate Control	✓	✓	✓	✓		
FIAT	MAREA	1.9 TD 75 CV	BREED MY 97 Air Bag (2F-2P-2L-S)	✓	✓	✓	✓		
FIAT	MAREA	2.0 20V	Allied MY 97 Air Bag (2F-2P-S)	✓	✓	✓	✓		
FIAT	MAREA	2.0 20V	Allied MY 97 Air Bag (2F-2P)	✓	✓	✓	✓		
FIAT	MAREA	2.0 20V	Borletti MCC55F Climate Control	✓	✓	✓	✓		
FIAT	MAREA	2.4 TD	Allied MY 97 Air Bag (2F-2P-S)	✓	✓	✓	✓		
FIAT	MAREA	2.4 TD	Allied MY 97 Air Bag (2F-2P)	✓	✓	✓	✓		
FIAT	MAREA	2.4 TD	Borletti MCC55F Climate Control	✓	✓	✓	✓		
FIAT	MAREA	2.4 TD	BREED MY 97 Air Bag (2F-2P-2L-S)	✓	✓	✓	✓		
FIAT	MOBI	2022	ECM (Engine Control Module)	✓	✓	✓	✓	✓	sp01843, sp01844, sp01845, sp01846, sp01847
FIAT	MOBI	2022	TCM (Transmission Control Module)	✓	✓	✓	✓	✓	sp01848, sp01849, sp01850, sp01851, sp01852, sp01853, sp01854, sp01855,
FIAT	MOBI	2022	ABS (Anti Lock Brakes)	✓	✓	✓	✓	✓	sp01858
FIAT	MOBI	2022	ORC (Occupant Restraint)	✓	✓	✓	✓	✓	sp01859
FIAT	MOBI	2022	PAM (Parking Aid Module)	✓	✓	✓	✓	✓	
FIAT	MOBI	2022	LTM (Low Telematic Module)	✓	✓	✓	✓	✓	sp01860
FIAT	MOBI	2022	IPC (Instrument Panel Cluster)	✓	✓	✓	✓	✓	
FIAT	MOBI	2022	ETM (Entertainment Telematic Module)	✓	✓	✓	✓	✓	sp01861, sp01862
FIAT	MOBI	2022	EPS (Electric Power Steering)	✓	✓	✓	✓	✓	
FIAT	MOBI	2022	DMM (Doors Management Module)	✓	✓	✓	✓	✓	sp01863, sp01864, sp01865
FIAT	MOBI	2022	BCM (Body Control Module)	✓	✓	✓	✓	✓	✓
FIAT	MOBI	2021	ECM (Engine Control Module)	✓	✓	✓	✓	✓	sp01872, sp01873, sp01874, sp01875, sp01876
FIAT	MOBI	2021	TCM (Transmission Control Module)	✓	✓	✓	✓	✓	sp01877, sp01878, sp01879, sp01880, sp01881, sp01882, sp01883, sp01884,
FIAT	MOBI	2021	ABS (Anti Lock Brakes)	✓	✓	✓	✓	✓	sp01887
FIAT	MOBI	2021	ORC (Occupant Restraint)	✓	✓	✓	✓	✓	sp01888

FIAT	MOBI	2021	PAM (Parking Aid Module)	✓	✓	✓	✓		
FIAT	MOBI	2021	LTM (Low Telematic Module)	✓	✓	✓	✓	✓	sp01889
FIAT	MOBI	2021	IPC (Instrument Panel Cluster)	✓	✓	✓	✓	✓	
FIAT	MOBI	2021	ETM (Entertainment Telematic Module)	✓	✓	✓	✓	✓	sp01890, sp01891
FIAT	MOBI	2021	EPS (Electric Power Steering)	✓	✓	✓	✓	✓	
FIAT	MOBI	2021	DMM (Doors Management Module)	✓	✓	✓	✓	✓	sp01892, sp01893, sp01894
FIAT	MOBI	2021	BCM (Body Control Module)	✓	✓	✓	✓	✓	✓
FIAT	MOBI	2020	ECM (Engine Control Module)	✓	✓	✓	✓	✓	sp01901, sp01902, sp01903, sp01904, sp01905
FIAT	MOBI	2020	TCM (Transmission Control Module)	✓	✓	✓	✓		sp01906, sp01907, sp01908, sp01909, sp01910, sp01911, sp01912, sp01913,
FIAT	MOBI	2020	ABS (Anti Lock Brakes)	✓	✓	✓	✓	✓	sp01916
FIAT	MOBI	2020	ORC (Occupant Restraint)	✓	✓	✓	✓	✓	sp01917
FIAT	MOBI	2020	PAM (Parking Aid Module)	✓	✓	✓	✓		
FIAT	MOBI	2020	LTM (Low Telematic Module)	✓	✓	✓	✓	✓	sp01918
FIAT	MOBI	2020	IPC (Instrument Panel Cluster)	✓	✓	✓	✓	✓	
FIAT	MOBI	2020	ETM (Entertainment Telematic Module)	✓	✓	✓	✓	✓	sp01919, sp01920
FIAT	MOBI	2020	EPS (Electric Power Steering)	✓	✓	✓	✓	✓	
FIAT	MOBI	2020	DMM (Doors Management Module)	✓	✓	✓	✓	✓	sp01921, sp01922, sp01923
FIAT	MOBI	2020	BCM (Body Control Module)	✓	✓	✓	✓	✓	✓
FIAT	MOBI	2019	ECM (Engine Control Module)	✓	✓	✓	✓	✓	sp01930, sp01931, sp01932, sp01933, sp01934
FIAT	MOBI	2019	TCM (Transmission Control Module)	✓	✓	✓	✓		sp01935, sp01936, sp01937, sp01938, sp01939, sp01940, sp01941, sp01942,
FIAT	MOBI	2019	ABS (Anti Lock Brakes)	✓	✓	✓	✓	✓	sp01945
FIAT	MOBI	2019	ORC (Occupant Restraint)	✓	✓	✓	✓	✓	sp01946
FIAT	MOBI	2019	PAM (Parking Aid Module)	✓	✓	✓	✓	✓	
FIAT	MOBI	2019	LTM (Low Telematic Module)	✓	✓	✓	✓	✓	sp01947
FIAT	MOBI	2019	IPC (Instrument Panel Cluster)	✓	✓	✓	✓	✓	
FIAT	MOBI	2019	ETM (Entertainment Telematic Module)	✓	✓	✓	✓	✓	sp01948, sp01949
FIAT	MOBI	2019	EPS (Electric Power Steering)	✓	✓	✓	✓	✓	
FIAT	MOBI	2019	DMM (Doors Management Module)	✓	✓	✓	✓	✓	sp01950, sp01951, sp01952
FIAT	MOBI	2019	BCM (Body Control Module)	✓	✓	✓	✓	✓	✓
FIAT	MOBI	2018	ECM (Engine Control Module)	✓	✓	✓	✓	✓	sp01959, sp01960, sp01961, sp01962, sp01963
FIAT	MOBI	2018	TCM (Transmission Control Module)	✓	✓	✓	✓		sp01964, sp01965, sp01966, sp01967, sp01968, sp01969, sp01970, sp01971,
FIAT	MOBI	2018	ABS (Anti Lock Brakes)	✓	✓	✓	✓	✓	sp01974
FIAT	MOBI	2018	ORC (Occupant Restraint)	✓	✓	✓	✓	✓	sp01975
FIAT	MOBI	2018	PAM (Parking Aid Module)	✓	✓	✓	✓	✓	
FIAT	MOBI	2018	LTM (Low Telematic Module)	✓	✓	✓	✓	✓	sp01976
FIAT	MOBI	2018	IPC (Instrument Panel Cluster)	✓	✓	✓	✓	✓	
FIAT	MOBI	2018	ETM (Entertainment Telematic Module)	✓	✓	✓	✓	✓	sp01977, sp01978
FIAT	MOBI	2018	EPS (Electric Power Steering)	✓	✓	✓	✓	✓	
FIAT	MOBI	2018	DMM (Doors Management Module)	✓	✓	✓	✓	✓	sp01979, sp01980, sp01981
FIAT	MOBI	2018	BCM (Body Control Module)	✓	✓	✓	✓	✓	✓
FIAT	MOBI	2017	ECM (Engine Control Module)	✓	✓	✓	✓	✓	sp01988, sp01989, sp01990, sp01991, sp01992
FIAT	MOBI	2017	TCM (Transmission Control Module)	✓	✓	✓	✓	✓	sp01993, sp01994, sp01995, sp01996, sp01997, sp01998, sp01999, sp02000,
FIAT	MOBI	2017	ABS (Anti Lock Brakes)	✓	✓	✓	✓	✓	sp02003
FIAT	MOBI	2017	ORC (Occupant Restraint)	✓	✓	✓	✓		sp02004
FIAT	MOBI	2017	PAM (Parking Aid Module)	✓	✓	✓	✓		
FIAT	MOBI	2017	LTM (Low Telematic Module)	✓	✓	✓	✓	✓	sp02005



FIAT	MOBI	2017	IPC (Instrument Panel Cluster)	✓	✓	✓	✓	✓	
FIAT	MOBI	2017	ETM (Entertainment Telematic Module)	✓	✓	✓	✓	✓	sp02006, sp02007
FIAT	MOBI	2017	EPS (Electric Power Steering)	✓	✓	✓	✓	✓	
FIAT	MOBI	2017	DMM (Doors Management Module)	✓	✓	✓	✓	✓	sp02008, sp02009, sp02010
FIAT	MOBI	2017	BCM (Body Control Module)		✓	✓	✓	✓	✓
FIAT	MOBI	2016	ECM (Engine Control Module)	✓	✓	✓	✓	✓	sp02017, sp02018, sp02019, sp02020, sp02021
FIAT	MOBI	2016	TCM (Transmission Control Module)	✓	✓	✓	✓	✓	sp02022, sp02023, sp02024, sp02025, sp02026, sp02027, sp02028, sp02029,
FIAT	MOBI	2016	ABS (Anti Lock Brakes)	✓	✓	✓	✓	✓	sp02032
FIAT	MOBI	2016	ORC (Occupant Restraint)	✓	✓	✓	✓	✓	sp02033
FIAT	MOBI	2016	PAM (Parking Aid Module)	✓	✓	✓	✓	✓	
FIAT	MOBI	2016	LTM (Low Telematic Module)	✓	✓	✓	✓	✓	sp02034
FIAT	MOBI	2016	IPC (Instrument Panel Cluster)	✓	✓	✓	✓	✓	
FIAT	MOBI	2016	ETM (Entertainment Telematic Module)	✓	✓	✓	✓	✓	sp02035, sp02036
FIAT	MOBI	2016	EPS (Electric Power Steering)	✓	✓	✓	✓	✓	
FIAT	MOBI	2016	DMM (Doors Management Module)	✓	✓	✓	✓	✓	sp02037, sp02038, sp02039
FIAT	MOBI	2016	BCM (Body Control Module)		✓	✓	✓	✓	✓
FIAT	MULTIPLA	*02 1.6 16V	Borletti MCC55F Climate Control	✓	✓	✓			
FIAT	MULTIPLA	*02 1.6 16V	Bosch 5.3 ABS	✓	✓	✓			
FIAT	MULTIPLA	*02 1.6 16V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	✓	✓	✓	✓		
FIAT	MULTIPLA	*02 1.6 16V	Marelli Code 2 Electronic Key	✓	✓	✓	✓		
FIAT	MULTIPLA	*02 1.6 16V	SIEMENS Airbag MY 99 (2F-2P-2L-2T-1)	✓	✓	✓	✓		
FIAT	MULTIPLA	*02 1.6 16V	SIEMENS Airbag MY 99 (2F-2P-1)	✓	✓	✓	✓		
FIAT	MULTIPLA	*02 1.6 16V	SIEMENS Airbag MY 99 (2F-2P-2L-1)	✓	✓	✓	✓		
FIAT	MULTIPLA	*02 1.6 16V	VAS 97/2 Door Lock RF Alarm/Receiver	✓	✓	✓			
FIAT	MULTIPLA	*02 1.9 JTD	Borletti MCC55F Climate Control	✓	✓	✓			
FIAT	MULTIPLA	*02 1.9 JTD	Bosch 5.3 ABS	✓	✓	✓			
FIAT	MULTIPLA	*02 1.9 JTD	Bosch ABS 5.7 VDC	✓	✓	✓	✓		
FIAT	MULTIPLA	*02 1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/EOBD (Eng. 1.9/2.4)	✓	✓	✓	✓		
FIAT	MULTIPLA	*02 1.9 JTD	Marelli Code 2 Electronic Key	✓	✓	✓	✓		
FIAT	MULTIPLA	*02 1.9 JTD	SIEMENS Airbag MY 99 (2F-2P-2L-2T-1)	✓	✓	✓	✓		
FIAT	MULTIPLA	*02 1.9 JTD	SIEMENS Airbag MY 99 (2F-2P-1)	✓	✓	✓	✓		
FIAT	MULTIPLA	*02 1.9 JTD	SIEMENS Airbag MY 99 (2F-2P-2L-1)	✓	✓	✓	✓		
FIAT	MULTIPLA	*02 1.9 JTD	Bosch EDC 15 CF3/EOBD Diesel Injection (Eng. 1.9/2.4)	✓	✓	✓	✓		
FIAT	MULTIPLA	*02 1.9 JTD	VAS 97/2 Door Lock RF Alarm/Receiver	✓	✓	✓			
FIAT	MULTIPLA	*02 BIPOWER-GPOWER	Borletti MCC55F Climate Control	✓	✓	✓			
FIAT	MULTIPLA	*02 BIPOWER-GPOWER	Bosch 5.3 ABS	✓	✓	✓			
FIAT	MULTIPLA	*02 BIPOWER-GPOWER	Gas Injection Metatron 5D0 EOBD	✓	✓	✓	✓		
FIAT	MULTIPLA	*02 BIPOWER-GPOWER	Magneti Marelli IAW 4EF/4AF Gas Injection	✓	✓	✓	✓		
FIAT	MULTIPLA	*02 BIPOWER-GPOWER	Marelli Code 2 Electronic Key	✓	✓	✓	✓		
FIAT	MULTIPLA	*02 BIPOWER-GPOWER	SIEMENS Airbag MY 99 (2F-2P-2L-2T-1)	✓	✓	✓	✓		
FIAT	MULTIPLA	*02 BIPOWER-GPOWER	SIEMENS Airbag MY 99 (2F-2P-1)	✓	✓	✓	✓		
FIAT	MULTIPLA	*02 BIPOWER-GPOWER	SIEMENS Airbag MY 99 (2F-2P-2L-1)	✓	✓	✓	✓		
FIAT	MULTIPLA	*02 BIPOWER-GPOWER	VAS 97/2 Door Lock RF Alarm/Receiver	✓	✓	✓			
FIAT	MULTIPLA	*02 BLUPOWER	Borletti MCC55F Climate Control	✓	✓	✓			
FIAT	MULTIPLA	*02 BLUPOWER	Bosch 5.3 ABS	✓	✓	✓			
FIAT	MULTIPLA	*02 BLUPOWER	Marelli Code 2 Electronic Key	✓	✓	✓	✓		
FIAT	MULTIPLA	*02 BLUPOWER	SIEMENS Airbag MY 99 (2F-2P-2L-2T-1)	✓	✓	✓	✓		
FIAT	MULTIPLA	*02 BLUPOWER	SIEMENS Airbag MY 99 (2F-2P-1)	✓	✓	✓	✓		

FIAT	MULTIPLA	'02 BLUPOWER	SIEMENS Airbag MY 99 (2F-2P-2L-1)	✓	✓	✓	✓		
FIAT	MULTIPLA	'02 BLUPOWER	VAS 97/2 Door Lock RF Alarm/Receiver	✓	✓	✓			
FIAT	MULTIPLA	1.6 16V	Borletti MCC55F Climate Control	✓	✓	✓			
FIAT	MULTIPLA	1.6 16V	Bosch 5.3 ABS	✓	✓	✓			
FIAT	MULTIPLA	1.6 16V	BREED MY 97 Air Bag (3F-2L-1)	✓	✓	✓	✓		
FIAT	MULTIPLA	1.6 16V	BREED MY 97 Air Bag (3F-1)	✓	✓	✓	✓		
FIAT	MULTIPLA	1.6 16V	Marelli Code 2 Electronic Key	✓	✓	✓	✓		
FIAT	MULTIPLA	1.6 16V	VAS 97/2 Door Lock RF Alarm/Receiver	✓	✓	✓			
FIAT	MULTIPLA	1.6 16V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	✓	✓	✓	✓		
FIAT	MULTIPLA	1.6 16V	Magneti Marelli IAW 49F Injection (1.6 Eng.)	✓	✓	✓	✓		
FIAT	MULTIPLA	1.9 JTD	Borletti MCC55F Climate Control	✓	✓	✓			
FIAT	MULTIPLA	1.9 JTD	Bosch 5.3 ABS	✓	✓	✓			
FIAT	MULTIPLA	1.9 JTD	Bosch Diesel EDC15 Injection (1.9 TD D. I. Engine)	✓	✓	✓	✓		
FIAT	MULTIPLA	1.9 JTD	Bosch EDC15 CF3/EOBD Diesel Injection (Eng. 1.9/2.4)	✓	✓	✓	✓		
FIAT	MULTIPLA	1.9 JTD	Marelli Code 2 Electronic Key	✓	✓	✓	✓		
FIAT	MULTIPLA	1.9 JTD	VAS 97/2 Door Lock RF Alarm/Receiver	✓	✓	✓			
FIAT	MULTIPLA	1.9 JTD	BREED MY 97 Air Bag (3F-1)	✓	✓	✓	✓		
FIAT	MULTIPLA	1.9 JTD	BREED MY 97 Air Bag (3F-2L-1)	✓	✓	✓	✓		
FIAT	MULTIPLA	BIPOWER	Borletti MCC55F Climate Control	✓	✓	✓			
FIAT	MULTIPLA	BIPOWER	Bosch 5.3 ABS	✓	✓	✓			
FIAT	MULTIPLA	BIPOWER	BREED MY 97 Air Bag (3F-2L-1)	✓	✓	✓	✓		
FIAT	MULTIPLA	BIPOWER	BREED MY 97 Air Bag (3F-1)	✓	✓	✓	✓		
FIAT	MULTIPLA	BIPOWER	Marelli Code 2 Electronic Key	✓	✓	✓	✓		
FIAT	MULTIPLA	BIPOWER	VAS 97/2 Door Lock RF Alarm/Receiver	✓	✓	✓			
FIAT	MULTIPLA	BIPOWER	Magneti Marelli IAW 4GF Injection (Bi-Power)	✓	✓	✓	✓		
FIAT	MULTIPLA	BIPOWER	Magneti Marelli IAW 4EF/4AF Gas Injection	✓	✓	✓	✓		
FIAT	MULTIPLA	BLUPOWER	Borletti MCC55F Climate Control	✓	✓	✓			
FIAT	MULTIPLA	BLUPOWER	Bosch 5.3 ABS	✓	✓	✓			
FIAT	MULTIPLA	BLUPOWER	BREED MY 97 Air Bag (3F-2L-1)	✓	✓	✓	✓		
FIAT	MULTIPLA	BLUPOWER	BREED MY 97 Air Bag (3F-1)	✓	✓	✓	✓		
FIAT	MULTIPLA	BLUPOWER	Marelli Code 2 Electronic Key	✓	✓	✓	✓		
FIAT	MULTIPLA	BLUPOWER	VAS 97/2 Door Lock RF Alarm/Receiver	✓	✓	✓			
FIAT	MULTIPLA	BLUPOWER	Magneti Marelli IAW 4GF Injection (Blu-Power)	✓	✓	✓	✓		
FIAT	MULTIPLA VAN	'02 1.6 16V	Borletti MCC55F Climate Control	✓	✓	✓			
FIAT	MULTIPLA VAN	'02 1.6 16V	Bosch 5.3 ABS	✓	✓	✓			
FIAT	MULTIPLA VAN	'02 1.6 16V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	✓	✓	✓	✓		
FIAT	MULTIPLA VAN	'02 1.6 16V	Marelli Code 2 Electronic Key	✓	✓	✓	✓		
FIAT	MULTIPLA VAN	'02 1.6 16V	SIEMENS Airbag MY 99 (2F-2P-2L-2T-1)	✓	✓	✓	✓		
FIAT	MULTIPLA VAN	'02 1.6 16V	SIEMENS Airbag MY 99 (2F-2P-1)	✓	✓	✓	✓		
FIAT	MULTIPLA VAN	'02 1.6 16V	SIEMENS Airbag MY 99 (2F-2P-2L-1)	✓	✓	✓	✓		
FIAT	MULTIPLA VAN	'02 1.6 16V	VAS 97/2 Door Lock RF Alarm/Receiver	✓	✓	✓			
FIAT	MULTIPLA VAN	'02 1.9 JTD	Borletti MCC55F Climate Control	✓	✓	✓			
FIAT	MULTIPLA VAN	'02 1.9 JTD	Bosch 5.3 ABS	✓	✓	✓			
FIAT	MULTIPLA VAN	'02 1.9 JTD	Bosch ABS 5.7 VDC	✓	✓	✓	✓		
FIAT	MULTIPLA VAN	'02 1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/EOBD (Eng. 1.9/2.4)	✓	✓	✓	✓		
FIAT	MULTIPLA VAN	'02 1.9 JTD	Marelli Code 2 Electronic Key	✓	✓	✓	✓		
FIAT	MULTIPLA VAN	'02 1.9 JTD	SIEMENS Airbag MY 99 (2F-2P-2L-2T-1)	✓	✓	✓	✓		
FIAT	MULTIPLA VAN	'02 1.9 JTD	SIEMENS Airbag MY 99 (2F-2P-1)	✓	✓	✓	✓		
FIAT	MULTIPLA VAN	'02 1.9 JTD	SIEMENS Airbag MY 99 (2F-2P-2L-1)	✓	✓	✓	✓		
FIAT	MULTIPLA VAN	'02 1.9 JTD	Bosch EDC15 CF3/EOBD Diesel Injection (Eng. 1.9/2.4)	✓	✓	✓	✓		
FIAT	MULTIPLA VAN	'02 1.9 JTD	VAS 97/2 Door Lock RF Alarm/Receiver	✓	✓	✓			
FIAT	MULTIPLA VAN	'02 BIPOWER-GPOWER	Borletti MCC55F Climate Control	✓	✓	✓			
FIAT	MULTIPLA VAN	'02 BIPOWER-GPOWER	Bosch 5.3 ABS	✓	✓	✓			
FIAT	MULTIPLA VAN	'02 BIPOWER-GPOWER	Gas Injection Metatron 5D0 EOBD	✓	✓	✓	✓		

FIAT	MULTIPLA VAN	'02 BIPOWER-GPOWER	Magneti Marelli IAW 4EF/4AF Gas Injection	✓	✓	✓	✓		
FIAT	MULTIPLA VAN	'02 BIPOWER-GPOWER	Marelli Code 2 Electronic Key	✓	✓	✓	✓		
FIAT	MULTIPLA VAN	'02 BIPOWER-GPOWER	SIEMENS Airbag MY 99 (2F-2P-2L-2T-1)	✓	✓	✓	✓		
FIAT	MULTIPLA VAN	'02 BIPOWER-GPOWER	SIEMENS Airbag MY 99 (2F-2P-1)	✓	✓	✓	✓		
FIAT	MULTIPLA VAN	'02 BIPOWER-GPOWER	SIEMENS Airbag MY 99 (2F-2P-2L-1)	✓	✓	✓	✓		
FIAT	MULTIPLA VAN	'02 BIPOWER-GPOWER	VAS 97/2 Door Lock RF Alarm/Receiver	✓	✓	✓	✓		
FIAT	Novo Uno FL	2022	ECM (Engine Control Module)	✓	✓	✓	✓	✓	sp02046, sp02047, sp02048, sp02049, sp02050, sp02051, sp02052, sp02053,
FIAT	Novo Uno FL	2022	TCM (Transmission Control Module)	✓	✓	✓	✓	✓	sp02057, sp02058, sp02059, sp02060, sp02061, sp02062, sp02063, sp02064,
FIAT	Novo Uno FL	2022	ABS (Anti-Lock Braking System)	✓	✓	✓	✓	✓	sp02067
FIAT	Novo Uno FL	2022	SRS (Supplemental Inflatable Restraint System, ORC)	✓	✓	✓	✓	✓	sp02068
FIAT	Novo Uno FL	2022	BCM (Body Control Module)	✓	✓	✓	✓	✓	sp02069, sp02070, sp02071, sp02072, sp02073, sp02074
FIAT	Novo Uno FL	2022	EPS (Electric Power Steering)	✓	✓	✓	✓	✓	
FIAT	Novo Uno FL	2022	IPC (Instrument Panel Cluster)	✓	✓	✓	✓	✓	
FIAT	Novo Uno FL	2022	PAM (Parking Aid Module)	✓	✓	✓	✓	✓	
FIAT	Novo Uno FL	2022	DMM (Doors Management Module)	✓	✓	✓	✓	✓	sp02075, sp02076, sp02077
FIAT	Novo Uno FL	2021	ECM (Engine Control Module)	✓	✓	✓	✓	✓	sp02078, sp02079, sp02080, sp02081, sp02082, sp02083, sp02084, sp02085,
FIAT	Novo Uno FL	2021	TCM (Transmission Control Module)	✓	✓	✓	✓	✓	sp02089, sp02090, sp02091, sp02092, sp02093, sp02094, sp02095, sp02096,
FIAT	Novo Uno FL	2021	ABS (Anti-Lock Braking System)	✓	✓	✓	✓	✓	sp02099
FIAT	Novo Uno FL	2021	SRS (Supplemental Inflatable Restraint System, ORC)	✓	✓	✓	✓	✓	sp02100
FIAT	Novo Uno FL	2021	BCM (Body Control Module)	✓	✓	✓	✓	✓	sp02101, sp02102, sp02103, sp02104, sp02105, sp02106
FIAT	Novo Uno FL	2021	EPS (Electric Power Steering)	✓	✓	✓	✓	✓	
FIAT	Novo Uno FL	2021	IPC (Instrument Panel Cluster)	✓	✓	✓	✓	✓	
FIAT	Novo Uno FL	2021	PAM (Parking Aid Module)	✓	✓	✓	✓	✓	
FIAT	Novo Uno FL	2021	DMM (Doors Management Module)	✓	✓	✓	✓	✓	sp02107, sp02108, sp02109
FIAT	Novo Uno FL	2020	ECM (Engine Control Module)	✓	✓	✓	✓	✓	sp02110, sp02111, sp02112, sp02113, sp02114, sp02115, sp02116, sp02117,
FIAT	Novo Uno FL	2020	TCM (Transmission Control Module)	✓	✓	✓	✓	✓	sp02121, sp02122, sp02123, sp02124, sp02125, sp02126, sp02127, sp02128,
FIAT	Novo Uno FL	2020	ABS (Anti-Lock Braking System)	✓	✓	✓	✓	✓	sp02131
FIAT	Novo Uno FL	2020	SRS (Supplemental Inflatable Restraint System, ORC)	✓	✓	✓	✓	✓	sp02132
FIAT	Novo Uno FL	2020	BCM (Body Control Module)	✓	✓	✓	✓	✓	sp02133, sp02134, sp02135, sp02136, sp02137, sp02138
FIAT	Novo Uno FL	2020	EPS (Electric Power Steering)	✓	✓	✓	✓	✓	
FIAT	Novo Uno FL	2020	IPC (Instrument Panel Cluster)	✓	✓	✓	✓	✓	
FIAT	Novo Uno FL	2020	PAM (Parking Aid Module)	✓	✓	✓	✓	✓	
FIAT	Novo Uno FL	2020	DMM (Doors Management Module)	✓	✓	✓	✓	✓	sp02139, sp02140, sp02141
FIAT	Novo Uno FL	2019	ECM (Engine Control Module)	✓	✓	✓	✓	✓	sp02142, sp02143, sp02144, sp02145, sp02146, sp02147, sp02148, sp02149,
FIAT	Novo Uno FL	2019	TCM (Transmission Control Module)	✓	✓	✓	✓	✓	sp02153, sp02154, sp02155, sp02156, sp02157, sp02158, sp02159, sp02160,
FIAT	Novo Uno FL	2019	ABS (Anti-Lock Braking System)	✓	✓	✓	✓	✓	sp02163
FIAT	Novo Uno FL	2019	SRS (Supplemental Inflatable Restraint System, ORC)	✓	✓	✓	✓	✓	sp02164
FIAT	Novo Uno FL	2019	BCM (Body Control Module)	✓	✓	✓	✓	✓	sp02165, sp02166, sp02167, sp02168, sp02169, sp02170
FIAT	Novo Uno FL	2019	EPS (Electric Power Steering)	✓	✓	✓	✓	✓	
FIAT	Novo Uno FL	2019	IPC (Instrument Panel Cluster)	✓	✓	✓	✓	✓	
FIAT	Novo Uno FL	2019	PAM (Parking Aid Module)	✓	✓	✓	✓	✓	
FIAT	Novo Uno FL	2019	DMM (Doors Management Module)	✓	✓	✓	✓	✓	sp02171, sp02172, sp02173
FIAT	Novo Uno FL	2018	ECM (Engine Control Module)	✓	✓	✓	✓	✓	sp02174, sp02175, sp02176, sp02177, sp02178, sp02179, sp02180, sp02181,
FIAT	Novo Uno FL	2018	TCM (Transmission Control Module)	✓	✓	✓	✓	✓	sp02185, sp02186, sp02187, sp02188, sp02189, sp02190, sp02191, sp02192,
FIAT	Novo Uno FL	2018	ABS (Anti-Lock Braking System)	✓	✓	✓	✓	✓	sp02195
FIAT	Novo Uno FL	2018	SRS (Supplemental Inflatable Restraint System, ORC)	✓	✓	✓	✓	✓	sp02196
FIAT	Novo Uno FL	2018	BCM (Body Control Module)	✓	✓	✓	✓	✓	sp02197, sp02198, sp02199, sp02200, sp02201, sp02202
FIAT	Novo Uno FL	2018	EPS (Electric Power Steering)	✓	✓	✓	✓	✓	
FIAT	Novo Uno FL	2018	IPC (Instrument Panel Cluster)	✓	✓	✓	✓	✓	
FIAT	Novo Uno FL	2018	PAM (Parking Aid Module)	✓	✓	✓	✓	✓	
FIAT	Novo Uno FL	2018	DMM (Doors Management Module)	✓	✓	✓	✓	✓	sp02203, sp02204, sp02205
FIAT	Novo Uno FL	2017	ECM (Engine Control Module)	✓	✓	✓	✓	✓	sp02206, sp02207, sp02208, sp02209, sp02210, sp02211, sp02212, sp02213,
FIAT	Novo Uno FL	2017	TCM (Transmission Control Module)	✓	✓	✓	✓	✓	sp02217, sp02218, sp02219, sp02220, sp02221, sp02222, sp02223, sp02224,
FIAT	Novo Uno FL	2017	ABS (Anti Lock Brakes)	✓	✓	✓	✓	✓	sp02227
FIAT	Novo Uno FL	2017	ORC (Occupant Restraint)	✓	✓	✓	✓	✓	sp02228
FIAT	Novo Uno FL	2017	PAM (Parking Aid Module)	✓	✓	✓	✓	✓	

FIAT	Novo Uno FL	2017	IPC (Instrument Panel Cluster)	✓	✓	✓	✓	✓	
FIAT	Novo Uno FL	2017	EPS (Electric Power Steering)	✓	✓	✓	✓	✓	
FIAT	Novo Uno FL	2017	DMM (Doors Management Module)	✓	✓	✓	✓	✓	sp02229, sp02230, sp02231
FIAT	Novo Uno FL	2017	BCM (Body Control Module)	✓	✓	✓	✓	✓	✓
FIAT	Novo Uno FL	2016	ECM (Engine Control Module)	✓	✓	✓	✓	✓	sp02238, sp02239, sp02240, sp02241
FIAT	Novo Uno FL	2016	TCM (Transmission Control Module)	✓	✓	✓	✓	✓	sp02242, sp02243
FIAT	Novo Uno FL	2016	ABS (Anti-Lock Braking System)	✓	✓	✓	✓	✓	sp02244
FIAT	Novo Uno FL	2016	SRS (Supplemental Inflatable Restraint System, ORC)	✓	✓	✓	✓		
FIAT	Novo Uno FL	2016	TRM (Teg Reader Module)	✓	✓	✓	✓		
FIAT	Novo Uno FL	2016	SCCM (Steering Column Control Module)	✓	✓	✓	✓		
FIAT	Novo Uno FL	2016	RFH (Radio Frequency Hub)	✓	✓	✓	✓	✓	
FIAT	Novo Uno FL	2016	RADIO (RADIO)	✓	✓	✓	✓		
FIAT	Novo Uno FL	2016	PAM (Parking Aid Module)	✓	✓	✓	✓	✓	sp02245, sp02246
FIAT	Novo Uno FL	2016	ICS (Integrated Center Stack)	✓	✓	✓	✓	✓	
FIAT	Novo Uno FL	2016	IC (Instrument Cluster)	✓	✓	✓	✓	✓	sp02247, sp02248, sp02249, sp02250, sp02251
FIAT	Novo Uno FL	2016	HVAC (Heating Ventilation Air-Conditioning And Cooling)	✓	✓	✓	✓		sp02252
FIAT	Novo Uno FL	2016	ESM (Electronic Shifter Module)	✓	✓	✓	✓		
FIAT	Novo Uno FL	2016	ESL (Electronic Steering Lock)	✓	✓	✓	✓		
FIAT	Novo Uno FL	2016	EPS (Electric Power Steering)	✓	✓	✓	✓		
FIAT	Novo Uno FL	2016	EDM (External Disc Module)	✓	✓	✓		✓	
FIAT	Novo Uno FL	2016	CTM (Convergence Telematic Module)	✓	✓	✓			
FIAT	Novo Uno FL	2016	BCM (Body Control Module )	✓	✓	✓	✓	✓	sp02253
FIAT	Novo Uno FL	2015	TRW MY 97 Airbag (2F-1)	✓	✓	✓	✓	✓	
FIAT	Novo Uno FL	2015	Bosch 5.3 ABS	✓	✓	✓	✓		
FIAT	Novo Uno FL	2015	Bosch Motronic ME7.3 H4 Injection	✓	✓	✓	✓		
FIAT	OTTIMO	2014	ECM (Engine Control Module)	✓	✓	✓	✓	✓	sp02254, sp02255, sp02256, sp02257
FIAT	OTTIMO	2014	TCM (Transmission Control Module)	✓	✓	✓	✓		sp02258, sp02259
FIAT	OTTIMO	2014	ABS (Anti-Lock Braking System)	✓	✓	✓	✓	✓	sp02260
FIAT	OTTIMO	2014	SRS (Supplemental Inflatable Restraint System, ORC)	✓	✓	✓	✓	✓	
FIAT	OTTIMO	2014	TRM (Teg Reader Module)	✓	✓	✓	✓		
FIAT	OTTIMO	2014	SCCM (Steering Column Control Module)	✓	✓	✓	✓		
FIAT	OTTIMO	2014	RFH (Radio Frequency Hub)	✓	✓	✓	✓	✓	
FIAT	OTTIMO	2014	RADIO (RADIO)	✓	✓	✓	✓		
FIAT	OTTIMO	2014	PAM (Parking Aid Module)	✓	✓	✓	✓		sp02261, sp02262
FIAT	OTTIMO	2014	ICS (Integrated Center Stack)	✓	✓	✓	✓	✓	
FIAT	OTTIMO	2014	IC (Instrument Cluster)	✓	✓	✓	✓	✓	sp02263, sp02264, sp02265, sp02266, sp02267
FIAT	OTTIMO	2014	HVAC (Heating Ventilation Air-Conditioning And Cooling)	✓	✓	✓	✓		sp02268
FIAT	OTTIMO	2014	ESM (Electronic Shifter Module)	✓	✓	✓	✓		
FIAT	OTTIMO	2014	ESL (Electronic Steering Lock)	✓	✓	✓	✓		
FIAT	OTTIMO	2014	EPS (Electric Power Steering)	✓	✓	✓	✓		
FIAT	OTTIMO	2014	EDM (External Disc Module)	✓	✓	✓		✓	
FIAT	OTTIMO	2014	CTM (Convergence Telematic Module)	✓	✓	✓			
FIAT	OTTIMO	2014	BCM (Body Control Module )	✓	✓	✓	✓	✓	sp02269
FIAT	PALIO	1.2 16V	TRW MY 97 Airbag (2F-1)	✓	✓	✓	✓	✓	
FIAT	PALIO	1.2 16V	Bosch 5.3 ABS	✓	✓	✓	✓		
FIAT	PALIO	1.2 16V	Bosch Motronic ME7.3 H4 Injection	✓	✓	✓	✓		
FIAT	PALIO	1.9 D	TRW MY 97 Airbag (2F-1)	✓	✓	✓	✓	✓	
FIAT	PALIO	1.9 D	Bosch 5.3 ABS	✓	✓	✓	✓		
FIAT	PALIO	1.9 D	Lucas Epic DCU3F Diesel Injection	✓	✓	✓	✓		
FIAT	PALIO	1108 BENZINA	TRW MY 97 Airbag (2F-1)	✓	✓	✓	✓		
FIAT	PALIO	1108 BENZINA	Bosch 5.3 ABS	✓	✓	✓	✓		
FIAT	PALIO	1242 BENZINA	TRW MY 97 Airbag (2F-1)	✓	✓	✓	✓		
FIAT	PALIO	1242 BENZINA	Bosch 5.3 ABS	✓	✓	✓	✓		
FIAT	PALIO	1242 BENZINA	TRW MY 97 Airbag (2F)	✓	✓	✓	✓		

FIAT	PALIO	1242 BENZINA	Magneti Marelli IAW 59F Injection	✓	✓	✓	✓		
FIAT	PALIO	1242 BENZINA	Magneti Marelli IAW 49F Injection (Eng. 1.2)	✓	✓	✓	✓		
FIAT	PALIO	1242 BENZINA CF3	TRW MY 97 Airbag (2F-1)	✓	✓	✓	✓		
FIAT	PALIO	1242 BENZINA CF3	Bosch 5.3 ABS	✓	✓	✓	✓		
FIAT	PALIO	1242 BENZINA CF3	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	✓	✓	✓	✓		
FIAT	PALIO	1242 BENZINA CF3	TRW MY 97 Airbag (2F)	✓	✓	✓	✓		
FIAT	PALIO	1242 BENZINA CF3	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	✓	✓	✓	✓		
FIAT	PALIO	1299 BENZINA	TRW MY 97 Airbag (2F-1)	✓	✓	✓	✓		
FIAT	PALIO	1299 BENZINA	Bosch 5.3 ABS	✓	✓	✓	✓		
FIAT	PALIO	1299 BENZINA	TRW MY 97 Airbag (2F)	✓	✓	✓	✓		
FIAT	PALIO	1372 BENZINA	TRW MY 97 Airbag (2F-1)	✓	✓	✓	✓		
FIAT	PALIO	1372 BENZINA	Bosch 5.3 ABS	✓	✓	✓	✓		
FIAT	PALIO	1372 BENZINA	TRW MY 97 Airbag (2F)	✓	✓	✓	✓		
FIAT	PALIO	1497 ALCOOL	TRW MY 97 Airbag (2F-1)	✓	✓	✓	✓		
FIAT	PALIO	1497 ALCOOL	Bosch 5.3 ABS	✓	✓	✓	✓		
FIAT	PALIO	1497 ALCOOL	TRW MY 97 Airbag (2F)	✓	✓	✓	✓		
FIAT	PALIO	1497 GASOLINA	TRW MY 97 Airbag (2F-1)	✓	✓	✓	✓		
FIAT	PALIO	1497 GASOLINA	Bosch 5.3 ABS	✓	✓	✓	✓		
FIAT	PALIO	1497 GASOLINA	TRW MY 97 Airbag (2F)	✓	✓	✓	✓		
FIAT	PALIO	1580 16V BENZ. CF3	TRW MY 97 Airbag (2F-1)	✓	✓	✓	✓		
FIAT	PALIO	1580 16V BENZ. CF3	Bosch 5.3 ABS	✓	✓	✓	✓		
FIAT	PALIO	1580 16V BENZ. CF3	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	✓	✓	✓	✓		
FIAT	PALIO	1580 16V BENZ. CF3	TRW MY 97 Airbag (2F)	✓	✓	✓	✓		
FIAT	PALIO	1580 16V BENZ. CF3	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	✓	✓	✓	✓		
FIAT	PALIO	1580 16V BENZINA	TRW MY 97 Airbag (2F-1)	✓	✓	✓	✓		
FIAT	PALIO	1580 16V BENZINA	Bosch 5.3 ABS	✓	✓	✓	✓		
FIAT	PALIO	1580 16V BENZINA	TRW MY 97 Airbag (2F)	✓	✓	✓	✓		
FIAT	PALIO	1580 16V BENZINA	Magneti Marelli IAW 49F Injection (1.6 Eng.)	✓	✓	✓	✓		
FIAT	PALIO	1580 16V GASOLINA	TRW MY 97 Airbag (2F-1)	✓	✓	✓	✓		
FIAT	PALIO	1580 16V GASOLINA	Bosch 5.3 ABS	✓	✓	✓	✓		
FIAT	PALIO	1580 16V GASOLINA	TRW MY 97 Airbag (2F)	✓	✓	✓	✓		
FIAT	PALIO	1580 8V BENZINA	TRW MY 97 Airbag (2F-1)	✓	✓	✓	✓		
FIAT	PALIO	1580 8V BENZINA	Bosch 5.3 ABS	✓	✓	✓	✓		
FIAT	PALIO	1580 8V BENZINA	TRW MY 97 Airbag (2F)	✓	✓	✓	✓		
FIAT	PALIO	1580 8V BENZINA	Magneti Marelli IAW 49F Injection (1.6 Eng.)	✓	✓	✓	✓		
FIAT	PALIO	994 ALCOOL	TRW MY 97 Airbag (2F-1)	✓	✓	✓	✓		
FIAT	PALIO	994 ALCOOL	Bosch 5.3 ABS	✓	✓	✓	✓		
FIAT	PALIO	994 ALCOOL	TRW MY 97 Airbag (2F)	✓	✓	✓	✓		
FIAT	PALIO	994 BENZINA	TRW MY 97 Airbag (2F-1)	✓	✓	✓	✓		
FIAT	PALIO	994 BENZINA	Bosch 5.3 ABS	✓	✓	✓	✓		
FIAT	PALIO	994 GASOLINA	TRW MY 97 Airbag (2F-1)	✓	✓	✓	✓		
FIAT	PALIO	994 GASOLINA	Bosch 5.3 ABS	✓	✓	✓	✓		
FIAT	PALIO	994 GASOLINA	TRW MY 97 Airbag (2F)	✓	✓	✓	✓		
FIAT	PALIO	999 GASOLINA	TRW MY 97 Airbag (2F-1)	✓	✓	✓	✓		
FIAT	PALIO	999 GASOLINA	Bosch 5.3 ABS	✓	✓	✓	✓		
FIAT	PALIO	999 GASOLINA	Magneti Marelli IAW 59F Injection	✓	✓	✓	✓		
FIAT	PALIO	999 GASOLINA	TRW MY 97 Airbag (2F)	✓	✓	✓	✓		
FIAT	PALIO	TD	TRW MY 97 Airbag (2F-1)	✓	✓	✓	✓		
FIAT	PALIO	TD	Bosch 5.3 ABS	✓	✓	✓	✓		
FIAT	PALIO	TD	TRW MY 97 Airbag (2F)	✓	✓	✓	✓		
FIAT	PALIO FLP	1.4 8V	Bosch 5.3 ABS	✓	✓	✓	✓		
FIAT	PALIO FLP	1.4 8V	Magneti Marelli Injection IAW 4SF	✓	✓	✓	✓		
FIAT	PALIO FLP	1.4 8V	Magneti Marelli Injection IAW 4SFG	✓	✓	✓	✓		
FIAT	PALIO FLP	1.4 8V	MARELLI Instrument Panel G1 (Palio '08)	✓	✓	✓	✓	✓	

FIAT	PALIO FLP	1.4 8V	TRW MY 97 Airbag (2F-1)	✓	✓	✓	✓		
FIAT	PALIO FLP	1.4 8V	Trw MY 97 Airbag (2F-2L-1)	✓	✓	✓	✓		
FIAT	PALIO FLP	1.8 8V	Bosch 5.3 ABS	✓	✓	✓			
FIAT	PALIO FLP	1.8 8V	Delphi MT27E Injection (Eng. 1.8 8V)	✓	✓	✓	✓		
FIAT	PALIO FLP	1.8 8V	MARELLI Instrument Panel G1 (Palio '08)	✓	✓	✓	✓	✓	
FIAT	PALIO FLP	1.8 8V	Trw MY 97 Airbag (2F-2L-1)	✓	✓	✓	✓		
FIAT	PALIO FLP	1.8 8V	TRW MY 97 Airbag (2F-1)	✓	✓	✓	✓		
FIAT	PALIO RST	1.0 16V	TRW MY 97 Airbag (2F-1)	✓	✓	✓	✓		
FIAT	PALIO RST	1.0 16V	Bosch 5.3 ABS	✓	✓	✓			
FIAT	PALIO RST	1.0 16V	Bosch Motronic ME7.3 H4 Injection	✓	✓	✓	✓		
FIAT	PALIO RST	1.0 16V	Delphi/Marelli Body Computer	✓	✓	✓	✓	✓	
FIAT	PALIO RST	1.0 16V	Injection - Magneti Marelli IAW 5NF EOBD	✓	✓	✓	✓		
FIAT	PALIO RST	1.0 16V	Marelli Cluster (Palio RST)	✓	✓	✓	✓	✓	
FIAT	PALIO RST	1.0 8V	TRW MY 97 Airbag (2F-1)	✓	✓	✓	✓		
FIAT	PALIO RST	1.0 8V	Bosch 5.3 ABS	✓	✓	✓			
FIAT	PALIO RST	1.0 8V	Delphi/Marelli Body Computer	✓	✓	✓	✓	✓	
FIAT	PALIO RST	1.0 8V	Marelli Cluster (Palio RST)	✓	✓	✓	✓	✓	
FIAT	PALIO RST	1.0 8V	Magneti Marelli Injection IAW 4SF	✓	✓	✓	✓		
FIAT	PALIO RST	1.0 8V	Magnenti Marelli IAW 59F Injection	✓	✓	✓	✓		
FIAT	PALIO RST	1.2 16V	TRW MY 97 Airbag (2F-1)	✓	✓	✓	✓		
FIAT	PALIO RST	1.2 16V	Bosch 5.3 ABS	✓	✓	✓			
FIAT	PALIO RST	1.2 16V	Bosch Motronic ME7.3 H4 Injection	✓	✓	✓	✓		
FIAT	PALIO RST	1.2 16V	Bosch Motronic ME7.3H4 EOBD Injection	✓	✓	✓	✓		
FIAT	PALIO RST	1.2 16V	Injection-Bosch Motronic Me7.3H4M Outside EEC	✓	✓	✓	✓		
FIAT	PALIO RST	1.2 16V	Marelli Cluster (Palio RST)	✓	✓	✓	✓	✓	
FIAT	PALIO RST	1.2 16V	FUJI SG-CVT Automatic Transmission	✓	✓	✓	✓		
FIAT	PALIO RST	1.2 16V	Delphi/Marelli Body Computer	✓	✓	✓	✓	✓	
FIAT	PALIO RST	1.2 8V	TRW MY 97 Airbag (2F-1)	✓	✓	✓	✓		
FIAT	PALIO RST	1.2 8V	Bosch 5.3 ABS	✓	✓	✓			
FIAT	PALIO RST	1.2 8V	Delphi/Marelli Body Computer	✓	✓	✓	✓	✓	
FIAT	PALIO RST	1.2 8V	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	✓	✓	✓	✓		
FIAT	PALIO RST	1.2 8V	Marelli Cluster (Palio RST)	✓	✓	✓	✓	✓	
FIAT	PALIO RST	1.2 8V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	✓	✓	✓	✓		
FIAT	PALIO RST	1.2 8V	Magneti Marelli IAW 49F Injection (Eng. 1.2)	✓	✓	✓	✓		
FIAT	PALIO RST	1.3 JTD	TRW MY 97 Airbag (2F-1)	✓	✓	✓	✓		
FIAT	PALIO RST	1.3 JTD	Bosch 5.3 ABS	✓	✓	✓			
FIAT	PALIO RST	1.3 JTD	Delphi/Marelli Body Computer	✓	✓	✓	✓	✓	
FIAT	PALIO RST	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (Eng. 1.3 JTD)	✓	✓	✓	✓		
FIAT	PALIO RST	1.3 JTD	Marelli 6JF EOBD Diesel Injection (Eng. 1.3 JTD)	✓	✓	✓	✓		
FIAT	PALIO RST	1.3 JTD	Marelli Cluster (Palio RST)	✓	✓	✓	✓	✓	
FIAT	PALIO RST	1.5 8V	TRW MY 97 Airbag (2F-1)	✓	✓	✓	✓		
FIAT	PALIO RST	1.5 8V	Bosch 5.3 ABS	✓	✓	✓			
FIAT	PALIO RST	1.5 8V	Delphi Engine Signals Control Unit	✓	✓	✓	✓		
FIAT	PALIO RST	1.5 8V	Delphi/Marelli Body Computer	✓	✓	✓	✓	✓	
FIAT	PALIO RST	1.5 8V	SIEMENS Airbag MY 99 (2F-1)	✓	✓	✓	✓		
FIAT	PALIO RST	1.5 8V	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	✓	✓	✓	✓		
FIAT	PALIO RST	1.5 8V	Marelli Cluster (Palio RST)	✓	✓	✓	✓	✓	
FIAT	PALIO RST	1.5 8V	Magnenti Marelli IAW 59F Injection	✓	✓	✓	✓		
FIAT	PALIO RST	1.5 8V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	✓	✓	✓	✓		

FIAT	PALIO RST	1.6 16V	TRW MY 97 Airbag (2F-1)	✓	✓	✓	✓		
FIAT	PALIO RST	1.6 16V	Bosch 5.3 ABS	✓	✓	✓			
FIAT	PALIO RST	1.6 16V	Delphi/Marelli Body Computer	✓	✓	✓	✓	✓	
FIAT	PALIO RST	1.6 16V	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	✓	✓	✓	✓		
FIAT	PALIO RST	1.6 16V	Marelli Cluster (Palio RST)	✓	✓	✓	✓	✓	
FIAT	PALIO RST	1.6 16V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	✓	✓	✓	✓		
FIAT	PALIO RST	1.6 16V	Magneti Marelli IAW 49F Injection (Eng. 1.2)	✓	✓	✓	✓		
FIAT	PALIO RST	1.6 16V	Magneti Marelli IAW 49F Injection (1.6 Eng.)	✓	✓	✓	✓		
FIAT	PALIO RST	1.6 8V	TRW MY 97 Airbag (2F-1)	✓	✓	✓	✓		
FIAT	PALIO RST	1.6 8V	Bosch 5.3 ABS	✓	✓	✓			
FIAT	PALIO RST	1.6 8V	Delphi/Marelli Body Computer	✓	✓	✓	✓	✓	
FIAT	PALIO RST	1.6 8V	Marelli Cluster (Palio RST)	✓	✓	✓	✓	✓	
FIAT	PALIO RST	1.6 8V	Magneti Marelli IAW 49F Injection (1.6 Eng.)	✓	✓	✓	✓		
FIAT	PALIO RST	1.7 TD	TRW MY 97 Airbag (2F-1)	✓	✓	✓	✓		
FIAT	PALIO RST	1.7 TD	Bosch 5.3 ABS	✓	✓	✓			
FIAT	PALIO RST	1.7 TD	Delphi Engine Signals Control Unit	✓	✓	✓	✓		
FIAT	PALIO RST	1.7 TD	Marelli Cluster (Palio RST)	✓	✓	✓	✓	✓	
FIAT	PALIO RST	1.7 TD	Delphi/Marelli Body Computer	✓	✓	✓	✓	✓	
FIAT	PALIO RST	1.9 D	TRW MY 97 Airbag (2F-1)	✓	✓	✓	✓		
FIAT	PALIO RST	1.9 D	Bosch 5.3 ABS	✓	✓	✓			
FIAT	PALIO RST	1.9 D	Delphi/Marelli Body Computer	✓	✓	✓	✓	✓	
FIAT	PALIO RST	1.9 D	Marelli Cluster (Palio RST)	✓	✓	✓	✓	✓	
FIAT	PALIO RST	1.9 D	Lucas Epic DCU3F Diesel Injection	✓	✓	✓	✓		
FIAT	PALIO RST	1.9 JTD	TRW MY 97 Airbag (2F-1)	✓	✓	✓	✓		
FIAT	PALIO RST	1.9 JTD	Bosch 5.3 ABS	✓	✓	✓			
FIAT	PALIO RST	1.9 JTD	Bosch EDC15 CF3/EOBD Diesel Injection (Eng. 1.9/2.4)	✓	✓	✓	✓		
FIAT	PALIO RST	1.9 JTD	Delphi/Marelli Body Computer	✓	✓	✓	✓	✓	
FIAT	PALIO RST	1.9 JTD	Marelli Cluster (Palio RST)	✓	✓	✓	✓	✓	
FIAT	PALIO RST	994	TRW MY 97 Airbag (2F-1)	✓	✓	✓	✓		
FIAT	PALIO RST	994	Bosch 5.3 ABS	✓	✓	✓			
FIAT	PALIO RST	994	Delphi Engine Signals Control Unit	✓	✓	✓	✓		
FIAT	PALIO RST	994	Delphi/Marelli Body Computer	✓	✓	✓	✓	✓	
FIAT	PALIO RST	994	Marelli Cluster (Palio RST)	✓	✓	✓	✓	✓	
FIAT	PALIO RST 2	1.0 8V	Bosch 8 ABS	✓	✓	✓	✓		
FIAT	PALIO RST 2	1.0 8V	Marelli Body Computer 2	✓	✓	✓	✓	✓	
FIAT	PALIO RST 2	1.0 8V	Marelli Instrument Panel (Palio RST2)	✓	✓	✓	✓	✓	
FIAT	PALIO RST 2	1.0 8V	TRW MY 97 Airbag (2F-1)	✓	✓	✓	✓		
FIAT	PALIO RST 2	1.0 8V	Trw MY 97 Airbag (2F-2L-1)	✓	✓	✓	✓		
FIAT	PALIO RST 2	1.0 8V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	✓	✓	✓	✓		
FIAT	PALIO RST 2	1.1 8V	Bosch 5.3 ABS	✓	✓	✓			
FIAT	PALIO RST 2	1.1 8V	Bosch 8 ABS	✓	✓	✓	✓		
FIAT	PALIO RST 2	1.1 8V	Marelli Body Computer 2	✓	✓	✓	✓	✓	
FIAT	PALIO RST 2	1.1 8V	Marelli Instrument Panel (Palio RST2)	✓	✓	✓	✓	✓	
FIAT	PALIO RST 2	1.1 8V	SIEMENS Airbag MY 99 (2F-1)	✓	✓	✓	✓		
FIAT	PALIO RST 2	1.1 8V	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	✓	✓	✓	✓		
FIAT	PALIO RST 2	1.1 8V	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	✓	✓	✓	✓		
FIAT	PALIO RST 2	1.2 16V	Bosch 5.3 ABS	✓	✓	✓			
FIAT	PALIO RST 2	1.2 16V	Bosch 8 ABS	✓	✓	✓	✓		
FIAT	PALIO RST 2	1.2 16V	Bosch Motronic ME7.3H4 Injection	✓	✓	✓	✓		
FIAT	PALIO RST 2	1.2 16V	Marelli Body Computer 2	✓	✓	✓	✓	✓	
FIAT	PALIO RST 2	1.2 16V	Marelli Instrument Panel (Palio RST2)	✓	✓	✓	✓	✓	
FIAT	PALIO RST 2	1.2 16V	TRW MY 97 Airbag (2F-1)	✓	✓	✓	✓		
FIAT	PALIO RST 2	1.2 16V	Trw MY 97 Airbag (2F-2L-1)	✓	✓	✓	✓		
FIAT	PALIO RST 2	1.3 JTD	Bosch 5.3 ABS	✓	✓	✓			
FIAT	PALIO RST 2	1.3 JTD	Bosch 8 ABS	✓	✓	✓	✓		
FIAT	PALIO RST 2	1.3 JTD	Marelli Body Computer 2	✓	✓	✓	✓	✓	
FIAT	PALIO RST 2	1.3 JTD	Marelli Diesel Injection 6F3 EOBD (Eng. 1.3 JTD)	✓	✓	✓	✓		

FIAT	PALIO RST 2	1.3 JTD	Marelli Instrument Panel (Palio RST2)	✓	✓	✓	✓	✓	
FIAT	PALIO RST 2	1.3 JTD	TRW MY 97 Airbag (2F-1)	✓	✓	✓	✓		
FIAT	PALIO RST 2	1.3 JTD	Trw MY 97 Airbag (2F-2L-1)	✓	✓	✓	✓		
FIAT	PALIO RST 2	1.4 8V	Bosch 5.3 ABS	✓	✓	✓	✓		
FIAT	PALIO RST 2	1.4 8V	Bosch 8 ABS	✓	✓	✓	✓		
FIAT	PALIO RST 2	1.4 8V	Marelli Body Computer 2	✓	✓	✓	✓	✓	
FIAT	PALIO RST 2	1.4 8V	Marelli Instrument Panel (Palio RST2)	✓	✓	✓	✓	✓	
FIAT	PALIO RST 2	1.4 8V	TRW MY 97 Airbag (2F-1)	✓	✓	✓	✓		
FIAT	PALIO RST 2	1.4 8V	Trw MY 97 Airbag (2F-2L-1)	✓	✓	✓	✓		
FIAT	PALIO RST 2	1.4 8V	Magneti Marelli Injection IAW 5SF CF4/E0BD (Eng. 1.4 8V)	✓	✓	✓	✓		
FIAT	PALIO RST 2	1.4 8V	Magneti Marelli Injection IAW 4SFG	✓	✓	✓	✓		
FIAT	PALIO RST 2	1.4 8V	Magneti Marelli Injection IAW 4SF	✓	✓	✓	✓		
FIAT	PALIO RST 2	1.4 8V	Magneti Marelli IAW 5SF Injection (Eng. 1.4 8V) Extra EEC	✓	✓	✓	✓		
FIAT	PALIO RST 2	1.6 16V	Bosch 5.3 ABS	✓	✓	✓			
FIAT	PALIO RST 2	1.6 16V	Bosch 8 ABS	✓	✓	✓	✓		
FIAT	PALIO RST 2	1.6 16V	Marelli Body Computer 2	✓	✓	✓	✓	✓	
FIAT	PALIO RST 2	1.6 16V	Marelli Instrument Panel (Palio RST2)	✓	✓	✓	✓	✓	
FIAT	PALIO RST 2	1.6 16V	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	✓	✓	✓	✓		
FIAT	PALIO RST 2	1.6 16V	TRW MY 97 Airbag (2F-1)	✓	✓	✓	✓		
FIAT	PALIO RST 2	1.6 16V	Trw MY 97 Airbag (2F-2L-1)	✓	✓	✓	✓		
FIAT	PALIO RST 2	1.6 16V	Magneti Marelli IAW 59F 5SF8/5SF9 Tritex Injection	✓	✓	✓	✓		
FIAT	PALIO RST 2	1.7 TD	Bosch 5.3 ABS	✓	✓	✓			
FIAT	PALIO RST 2	1.7 TD	Bosch 8 ABS	✓	✓	✓	✓		
FIAT	PALIO RST 2	1.7 TD	Marelli Body Computer 2	✓	✓	✓	✓	✓	
FIAT	PALIO RST 2	1.7 TD	Marelli Instrument Panel (Palio RST2)	✓	✓	✓	✓	✓	
FIAT	PALIO RST 2	1.7 TD	TRW MY 97 Airbag (2F-1)	✓	✓	✓	✓		
FIAT	PALIO RST 2	1.7 TD	Trw MY 97 Airbag (2F-2L-1)	✓	✓	✓	✓		
FIAT	PALIO RST 2	1.8 8V	Bosch 5.3 ABS	✓	✓	✓			
FIAT	PALIO RST 2	1.8 8V	Bosch 8 ABS	✓	✓	✓	✓		
FIAT	PALIO RST 2	1.8 8V	Delphi MT27E Injection (Eng. 1.8 8V)	✓	✓	✓	✓		
FIAT	PALIO RST 2	1.8 8V	Marelli Body Computer 2	✓	✓	✓	✓	✓	
FIAT	PALIO RST 2	1.8 8V	Marelli Instrument Panel (Palio RST2)	✓	✓	✓	✓	✓	
FIAT	PALIO RST 2	1.8 8V	TRW MY 97 Airbag (2F-1)	✓	✓	✓	✓		
FIAT	PALIO RST 2	1.8 8V	Trw MY 97 Airbag (2F-2L-1)	✓	✓	✓	✓		
FIAT	PALIO RST 2	1.8 8V	Magneti Marelli Injection IAW 4SF	✓	✓	✓	✓		
FIAT	PALIO RST 2	1.9 D	Bosch 5.3 ABS	✓	✓	✓			
FIAT	PALIO RST 2	1.9 D	Bosch 8 ABS	✓	✓	✓	✓		
FIAT	PALIO RST 2	1.9 D	Marelli Body Computer 2	✓	✓	✓	✓	✓	
FIAT	PALIO RST 2	1.9 D	Marelli Instrument Panel (Palio RST2)	✓	✓	✓	✓	✓	
FIAT	PALIO RST 2	1.9 D	SIEMENS Airbag MY 99 (2F-1)	✓	✓	✓	✓		
FIAT	PALIO RST 2	1.9 D	Lucas Epic DCU3F Diesel Injection	✓	✓	✓	✓		
FIAT	PANDA	2012	BCM (Body Control Module)	✓	✓	✓	✓		sp02270
FIAT	PANDA	2012	PCM (Powertrain Control Module)	✓	✓	✓	✓	✓	sp02271, sp02272, sp02273
FIAT	PANDA	2012	TCM (Transmission Control Module)	✓	✓	✓	✓		sp02274, sp02275, sp02276
FIAT	PANDA	2012	ABS (Anti-Lock Braking System)	✓	✓	✓	✓	✓	sp02277
FIAT	PANDA	2012	SRS (Supplemental Inflatable Restraint System, ORC)	✓	✓	✓	✓		
FIAT	PANDA	2012	PTS (Parktronic)	✓	✓	✓	✓		sp02278, sp02279
FIAT	PANDA	2012	IC (Instrument Cluster)	✓	✓	✓	✓		sp02280, sp02281, sp02282, sp02283, sp02284
FIAT	PANDA	2012	HVAC (Heating Ventilation Air-Conditioning And Cooling)	✓	✓	✓	✓		sp02285
FIAT	PANDA	2012	EPS (Electric Power Steering)	✓	✓	✓	✓		
FIAT	PANDA	2012	CTM (Convergence Telematic Module)	✓	✓	✓	✓	✓	
FIAT	PANDA	2012	CMM (Collision Mitigation Module)	✓	✓	✓	✓		
FIAT	PANDA	2012	CCM (Control Couple Module)	✓	✓	✓	✓		
FIAT	PANDA	2012	AHM (Additional Heater Module)	✓	✓	✓	✓		
FIAT	PERLA	1.7 8V	Bosch 5.3 ABS	✓	✓	✓			



FIAT	PERLA	1.7 8V	Bosch 8 ABS	✓	✓	✓	✓		
FIAT	PERLA	1.7 8V	Marelli Body Computer 2	✓	✓	✓	✓	✓	
FIAT	PERLA	1.7 8V	Marelli Automatic Gearbox SELESPEED CFC208F (1)	✓	✓	✓	✓		
FIAT	PERLA	1.7 8V	Marelli Instrument Panel (Palio RST2)	✓	✓	✓	✓	✓	
FIAT	PERLA	1.7 8V	SIEMENS Airbag MY 99 (2F-I)	✓	✓	✓	✓		
FIAT	PERLA	1.7 8V	Magneti Marelli IAW 4SFC CF3 Injection	✓	✓	✓	✓		
FIAT	PUNTO EVO	2009	ECM (Engine Control Module)	✓	✓	✓	✓	✓	sp02286, sp02287, sp02288, sp02289, sp02290, sp02291, sp02292, sp02293,
FIAT	PUNTO EVO	2009	TCM (Transmission Control Module)	✓	✓	✓	✓	✓	sp02296, sp02297, sp02298, sp02299
FIAT	PUNTO EVO	2009	ABS (Anti-Lock Braking System)	✓	✓	✓	✓	✓	sp02300, sp02301, sp02302
FIAT	PUNTO EVO	2009	SRS (Supplemental Inflatable Restraint System, ORC)	✓	✓	✓	✓	✓	
FIAT	PUNTO EVO	2009	TPMS (Tire Pressure Monitoring System)	✓	✓	✓	✓	✓	sp02303, sp02304, sp02305, sp02306, sp02307, sp02308, sp02309, sp02310
FIAT	PUNTO EVO	2009	TBM (Telematic Box Module)	✓	✓	✓	✓		
FIAT	PUNTO EVO	2009	PAM (Parking Aid Module)	✓	✓	✓	✓		sp02311, sp02312
FIAT	PUNTO EVO	2009	IC (Instrument Cluster)	✓	✓	✓	✓	✓	sp02313, sp02314, sp02315, sp02316, sp02317
FIAT	PUNTO EVO	2009	HVAC (Heating Ventilation Air-Conditioning And Cooling)	✓	✓	✓	✓	✓	sp02318
FIAT	PUNTO EVO	2009	EPS (Electric Power Steering)	✓	✓	✓	✓		
FIAT	PUNTO EVO	2009	CTM (Convergence Telematic Module)	✓	✓	✓	✓	✓	sp02319
FIAT	PUNTO EVO	2009	BCM (Body Control Module )	✓	✓	✓	✓	✓	sp02320
FIAT	PUNTO EVO	2009	AHM (Additional Heater Module)	✓	✓	✓	✓		
FIAT	QUBO	2008	ECM (Engine Control Module)	✓	✓	✓	✓	✓	sp02321, sp02322, sp02323, sp02324, sp02325, sp02326, sp02327, sp02328,
FIAT	QUBO	2008	TCM (Transmission Control Module)	✓	✓	✓	✓	✓	sp02340, sp02341, sp02342
FIAT	QUBO	2008	ABS (Anti-Lock Braking System)	✓	✓	✓	✓	✓	sp02343, sp02344, sp02345
FIAT	QUBO	2008	SRS (Supplemental Inflatable Restraint System, ORC)	✓	✓	✓	✓	✓	
FIAT	QUBO	2008	IC (Instrument Cluster)	✓	✓	✓	✓	✓	sp02346, sp02347, sp02348
FIAT	QUBO	2008	BCM (Body Control Module)	✓	✓	✓	✓	✓	
FIAT	QUBO	2008	CTM (Convergence Telematic Module)	✓	✓	✓	✓	✓	sp02349
FIAT	QUBO	2008	AHM (Additional Heater Module)	✓	✓	✓	✓		sp02350, sp02351
FIAT	QUBO	2008	PAM (Parking Aid Module)	✓	✓	✓	✓		
FIAT	SCUDO (222)	'00 2.0 16V	Siemens AL4 TA2000 PSA Automatic Gearbox	✓	✓	✓	✓		
FIAT	SCUDO (222)	'00 2.0 16V	Magneti Marelli MM4.8P PSA Injection	✓	✓	✓	✓		
FIAT	SCUDO (222)	'00 2.0 JTD	Siemens AL4 TA2000 PSA Automatic Gearbox	✓	✓	✓	✓		
FIAT	SCUDO (222)	'00 2.0 JTD	Bosch EDC15 PSA Diesel Injection (Eng. 2.0 8V)	✓	✓	✓	✓		
FIAT	SCUDO (222)	'00 2.0 JTD	Bosch EDC15 PSA Diesel Injection (2.0 8V V60 Eng.)	✓	✓	✓	✓		
FIAT	SCUDO (222)	'00 2.0 JTD	Bosch EDC15 PSA Diesel Injection (Eng. 16V)	✓	✓	✓	✓		
FIAT	SCUDO (222)	'00 2.0 JTD	WEBASTO Heater (PSA)	✓	✓	✓	✓		
FIAT	SCUDO (222)	2.0 16V	Bosch Motronic MP7.3 Injection	✓	✓	✓	✓		
FIAT	SCUDO (272)	1.6 JTD 16V	Bosch Diesel Injection EDC16C34 CF4/EOBD (Eng. 1.6)	✓	✓	✓	✓		
FIAT	SCUDO (272)	1.6 JTD 16V	Johnson/Borg Multi-Function Screen	✓	✓	✓	✓		
FIAT	SCUDO (272)	1.6 JTD 16V	Marelli Connect PSA RT5 (CAN)	✓	✓	✓	✓		
FIAT	SCUDO (272)	1.6 JTD 16V	Marelli Instrument Panel PSA 2 (CAN)	✓	✓	✓	✓	✓	
FIAT	SCUDO (272)	1.6 JTD 16V	PSA Marelli Connect (CAN)	✓	✓	✓	✓	✓	
FIAT	SCUDO (272)	1.6 JTD 16V	ABS Bosch 8.1 PSA (CAN)	✓	✓	✓	✓		
FIAT	SCUDO (272)	1.6 JTD 16V	Bosch ABS 8 ESP PSA 2 (CAN)	✓	✓	✓	✓		
FIAT	SCUDO (272)	1.6 JTD 16V	Bosch ABS 8 PSA (CAN)	✓	✓	✓	✓		
FIAT	SCUDO (272)	1.6 JTD 16V	Bosch ABS 8.1 ESP PSA (CAN)	✓	✓	✓	✓		
FIAT	SCUDO (272)	1.6 JTD 16V	BOSCH/TEMIC Airbag (CAN)	✓	✓	✓	✓		
FIAT	SCUDO (272)	1.6 JTD 16V	Valeo Body Computer 2 (BSI CAN)					✓	
FIAT	SCUDO (272)	1.6 JTD 16V	Johnson EV Body COMPUTER (BSI CAN)	✓	✓	✓	✓		
FIAT	SCUDO (272)	1.6 JTD 16V	Delphi Alarm	✓	✓	✓	✓		

FIAT	SCUDO (272)	1.6 JTD 16V	Blaupunkt Radio	✓	✓	✓	✓		
FIAT	SCUDO (272)	1.6 JTD 16V	Bosch Luminosity/Rain Sensor	✓	✓	✓	✓		
FIAT	SCUDO (272)	1.6 JTD 16V	Clarion CD Magazine (CAN)	✓	✓	✓	✓		
FIAT	SCUDO (272)	1.6 JTD 16V	Denso Climate Control PSA 2 (CAN)	✓	✓	✓	✓		
FIAT	SCUDO (272)	1.6 JTD 16V	Siemens USB Box Control Unit	✓	✓	✓	✓		
FIAT	SCUDO (272)	1.6 JTD 16V	HPI Power Steering	✓	✓	✓	✓		
FIAT	SCUDO (272)	1.6 JTD 16V	HERMAN BECKER Navigator Auto Radio	✓	✓	✓	✓		
FIAT	SCUDO (272)	1.6 JTD 16V	Denso PSA Climate Control (Rear)	✓	✓	✓	✓		
FIAT	SCUDO (272)	1.6 JTD 16V	Delphi Multi-Function Switch (COM2005)	✓	✓	✓	✓	✓	
FIAT	SCUDO (272)	1.6 JTD 16V	PSA Valeo Parking Control Unit (CAN)	✓	✓	✓	✓	✓	
FIAT	SCUDO (272)	1.6 JTD 16V	Siemens PSA Viva Voce	✓	✓	✓	✓		
FIAT	SCUDO (272)	1.6 JTD 16V	Wabco Air Springs	✓	✓	✓	✓		
FIAT	SCUDO (272)	2.0 JTD 16V	Delphi DCM3.5 CF5 Diesel Injection (2.0 Eng.)	✓	✓	✓	✓		
FIAT	SCUDO (272)	2.0 JTD 16V	Siemens Diesel Injection SID803 CF4/E0BD (Eng. 16V)	✓	✓	✓	✓		
FIAT	SCUDO (272)	2.0 JTD 16V	Johnson/Borg Multi-Function Screen	✓	✓	✓	✓		
FIAT	SCUDO (272)	2.0 JTD 16V	Marelli Connect PSA RT5 (CAN)	✓	✓	✓	✓		
FIAT	SCUDO (272)	2.0 JTD 16V	Marelli Instrument Panel PSA 2 (CAN)	✓	✓	✓	✓	✓	
FIAT	SCUDO (272)	2.0 JTD 16V	PSA Marelli Connect (CAN)	✓	✓	✓	✓	✓	
FIAT	SCUDO (272)	2.0 JTD 16V	ABS Bosch 8.1 PSA (CAN)	✓	✓	✓	✓		
FIAT	SCUDO (272)	2.0 JTD 16V	Bosch ABS 8 ESP PSA 2 (CAN)	✓	✓	✓	✓		
FIAT	SCUDO (272)	2.0 JTD 16V	Bosch ABS 8 PSA (CAN)	✓	✓	✓	✓		
FIAT	SCUDO (272)	2.0 JTD 16V	Bosch ABS 8.1 ESP PSA (CAN)	✓	✓	✓	✓		
FIAT	SCUDO (272)	2.0 JTD 16V	BOSCH/TEMIC Airbag (CAN)	✓	✓	✓	✓		
FIAT	SCUDO (272)	2.0 JTD 16V	Valeo Body Computer 2 (BSI CAN)	✓	✓	✓	✓		
FIAT	SCUDO (272)	2.0 JTD 16V	Johnson EV Body COMPUTER (BSI CAN)	✓	✓	✓	✓		
FIAT	SCUDO (272)	2.0 JTD 16V	Johnson EV CF5 Body Computer (BSI CAN)	✓	✓	✓	✓		
FIAT	SCUDO (272)	2.0 JTD 16V	Delphi Alarm	✓	✓	✓	✓		
FIAT	SCUDO (272)	2.0 JTD 16V	Blaupunkt Radio	✓	✓	✓	✓		
FIAT	SCUDO (272)	2.0 JTD 16V	Bosch Luminosity/Rain Sensor	✓	✓	✓	✓		
FIAT	SCUDO (272)	2.0 JTD 16V	Clarion CD Magazine (CAN)	✓	✓	✓	✓		
FIAT	SCUDO (272)	2.0 JTD 16V	Denso Climate Control PSA 2 (CAN)	✓	✓	✓	✓		
FIAT	SCUDO (272)	2.0 JTD 16V	Siemens USB Box Control Unit	✓	✓	✓	✓		
FIAT	SCUDO (272)	2.0 JTD 16V	HPI Power Steering	✓	✓	✓	✓		
FIAT	SCUDO (272)	2.0 JTD 16V	HERMAN BECKER Navigator Auto Radio	✓	✓	✓	✓		
FIAT	SCUDO (272)	2.0 JTD 16V	Denso PSA Climate Control (Rear)	✓	✓	✓	✓		
FIAT	SCUDO (272)	2.0 JTD 16V	Delphi Multi-Function Switch (COM2005)	✓	✓	✓	✓	✓	
FIAT	SCUDO (272)	2.0 JTD 16V	PSA Valeo Parking Control Unit (CAN)	✓	✓	✓	✓	✓	
FIAT	SCUDO (272)	2.0 JTD 16V	Siemens PSA Viva Voce	✓	✓	✓	✓		
FIAT	SCUDO (272)	2.0 JTD 16V	Wabco Air Springs	✓	✓	✓	✓		
FIAT	SEDICI	1.6 16V	Automatic Gearbox SZK 2		✓	✓	✓		
FIAT	SEDICI	1.6 16V	Bosch ABS ESP SZK	✓	✓	✓	✓		
FIAT	SEDICI	1.6 16V	Bosch ABS SZK	✓	✓	✓	✓		
FIAT	SEDICI	1.6 16V	Bosch Petrol Injection SZK CF5/E0BD (Eng. 1.6)		✓	✓	✓		
FIAT	SEDICI	1.6 16V	Siemens Airbag SZK	✓	✓	✓	✓		
FIAT	SEDICI	1.6 16V	Petrol Injection Denzo SZK (Eng. 1.6) 2		✓	✓	✓	✓	
FIAT	SEDICI	1.6 16V	Electric Steering Mitsubishi SZK 2	✓	✓	✓	✓		
FIAT	SEDICI	1.6 16V	SZK Automatic Gearbox		✓	✓	✓		
FIAT	SEDICI	1.6 16V	Mitsubishi SZK Electric Steering	✓	✓	✓	✓		
FIAT	SEDICI	1.6 16V	Diamond Active Control Unit 4WD SZK	✓	✓	✓	✓		
FIAT	SEDICI	1.6 16V	Denso SZK Climate Control	✓	✓	✓	✓		
FIAT	SEDICI	1.6 16V	Denso SZK Petrol Injection (Eng. 1.6)		✓	✓	✓		
FIAT	SEDICI	1.6 16V	Calsonic-Kansei Body Computer SZK	✓	✓	✓	✓	✓	
FIAT	SEDICI	1.6 16V	Calsonic-Kansei Body Computer SZK 2	✓	✓	✓	✓	✓	
FIAT	SEDICI	1.9 MJET 8V	Bosch ABS ESP SZK	✓	✓	✓	✓		
FIAT	SEDICI	1.9 MJET 8V	Bosch ABS SZK	✓	✓	✓	✓		
FIAT	SEDICI	1.9 MJET 8V	Bosch Diesel Injection EDC16C39 CF4/E0BD SZK (Eng. 1.9)	✓	✓	✓	✓		
FIAT	SEDICI	1.9 MJET 8V	Calsonic-Kansei Body Computer SZK	✓	✓	✓	✓	✓	
FIAT	SEDICI	1.9 MJET 8V	Siemens Airbag SZK	✓	✓	✓	✓		

FIAT	SEDICI	1.9 MJET 8V	SZK Electronic Key	✓	✓	✓	✓		
FIAT	SEDICI	1.9 MJET 8V	Mitsubishi SZK Electric Steering	✓	✓	✓	✓		
FIAT	SEDICI	1.9 MJET 8V	Diamond Active Control Unit 4WD SZK	✓	✓	✓	✓		
FIAT	SEDICI	1.9 MJET 8V	Denso SZK Climate Control	✓	✓	✓	✓		
FIAT	SEDICI	1.9 MJET 8V	DENSO SZK Heater	✓	✓	✓	✓		
FIAT	SEDICI	2.0 MJET 16V	ASTI SZK Heater	✓	✓	✓	✓		
FIAT	SEDICI	2.0 MJET 16V	Bosch ABS ESP SZK	✓	✓	✓	✓		
FIAT	SEDICI	2.0 MJET 16V	Bosch ABS SZK	✓	✓	✓	✓		
FIAT	SEDICI	2.0 MJET 16V	Bosch Diesel Injection EDC16C39 CF5/EOBD SZK (Eng. 2.0)	✓	✓	✓	✓		
FIAT	SEDICI	2.0 MJET 16V	Siemens Airbag SZK	✓	✓	✓	✓		
FIAT	SEDICI	2.0 MJET 16V	SZK Electronic Key	✓	✓	✓	✓		
FIAT	SEDICI	2.0 MJET 16V	Mitsubishi SZK Electric Steering	✓	✓	✓	✓		
FIAT	SEDICI	2.0 MJET 16V	Diamond Active Control Unit 4WD SZK	✓	✓	✓	✓		
FIAT	SEDICI	2.0 MJET 16V	Denso SZK Climate Control	✓	✓	✓	✓		
FIAT	SEDICI	2.0 MJET 16V	Calsonic-Kansei Body Computer SZK 2	✓	✓	✓	✓	✓	
FIAT	SEICENTO	1108	TRW MY 97 Airbag (2F-1)	✓	✓	✓	✓		
FIAT	SEICENTO	1108	Bosch 5.3 ABS	✓	✓	✓	✓		
FIAT	SEICENTO	1108	Delphi Code 2 Electronic Key	✓	✓	✓	✓		
FIAT	SEICENTO	1108	Trw MY 97 Airbag (2F-2L-1)	✓	✓	✓	✓		
FIAT	SEICENTO	1108 CF3	TRW MY 97 Airbag (2F-1)	✓	✓	✓	✓		
FIAT	SEICENTO	1108 CF3	Bosch 5.3 ABS	✓	✓	✓	✓		
FIAT	SEICENTO	1108 CF3	Delphi Code 2 Electronic Key	✓	✓	✓	✓		
FIAT	SEICENTO	1108 CF3	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	✓	✓	✓	✓		
FIAT	SEICENTO	1108 CF3	Trw MY 97 Airbag (2F-2L-1)	✓	✓	✓	✓		
FIAT	SEICENTO	1108 CF3	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	✓	✓	✓	✓		
FIAT	SEICENTO	899	TRW MY 97 Airbag (2F-1)	✓	✓	✓	✓		
FIAT	SEICENTO	899	Bosch 5.3 ABS	✓	✓	✓	✓		
FIAT	SEICENTO	899	Delphi Code 2 Electronic Key	✓	✓	✓	✓		
FIAT	SEICENTO	899	Trw MY 97 Airbag (2F-2L-1)	✓	✓	✓	✓		
FIAT	SEICENTO	CITYMATIC	TRW MY 97 Airbag (2F-1)	✓	✓	✓	✓		
FIAT	SEICENTO	CITYMATIC	Bosch 5.3 ABS	✓	✓	✓	✓		
FIAT	SEICENTO	CITYMATIC	Delphi Code 2 Electronic Key	✓	✓	✓	✓		
FIAT	SEICENTO	CITYMATIC	Trw MY 97 Airbag (2F-2L-1)	✓	✓	✓	✓		
FIAT	SEICENTO	ELETTRA	TRW MY 97 Airbag (2F-1)	✓	✓	✓	✓		
FIAT	SEICENTO	ELETTRA	Delphi Code 2 Electronic Key	✓	✓	✓	✓		
FIAT	SEICENTO	ELETTRA	Trw MY 97 Airbag (2F-2L-1)	✓	✓	✓	✓		
FIAT	SEICENTO VAN	1108 CF3	Bosch 5.3 ABS	✓	✓	✓	✓		
FIAT	SEICENTO VAN	1108 CF3	Delphi Code 2 Electronic Key	✓	✓	✓	✓		
FIAT	SEICENTO VAN	1108 CF3	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	✓	✓	✓	✓		
FIAT	SEICENTO VAN	1108 CF3	TRW MY 97 Airbag (2F-1)	✓	✓	✓	✓		
FIAT	SEICENTO VAN	1108 CF3	Trw MY 97 Airbag (2F-2L-1)	✓	✓	✓	✓		
FIAT	SEICENTO VAN	1108 CF3	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD Injection	✓	✓	✓	✓		
FIAT	SPIDER	2020	PCM (Powertrain Control Module)	✓	✓	✓	✓	✓	
FIAT	SPIDER	2020	TCM (Transmission Control Module)	✓	✓	✓	✓	✓	
FIAT	SPIDER	2020	ABS (Anti-Lock Braking System)	✓	✓	✓	✓		
FIAT	SPIDER	2020	IC (Instrument Cluster)	✓	✓	✓	✓		
FIAT	SPIDER	2020	SRS (Supplemental Inflatable Restraint System, ORC)	✓	✓	✓	✓		
FIAT	SPIDER	2020	BCM (Body Control Module)	✓	✓	✓	✓		
FIAT	SPIDER	2020	EPS (Electric Power Steering)	✓	✓	✓	✓		
FIAT	SPIDER	2020	RFH (Radio Frequency Hub)	✓	✓	✓	✓		
FIAT	SPIDER	2020	AFLS (Adaptive Front Lighting System)	✓	✓	✓	✓		
FIAT	SPIDER	2020	ETM (Entertainment Telematic Module)	✓	✓	✓	✓		
FIAT	SPIDER	2020	AMP (Amplifier)	✓	✓	✓	✓		
FIAT	SPIDER	2020	Lighting Power Module (LSM)	✓	✓	✓	✓		
FIAT	SPIDER	2020	HVAC (Heat, Ventilation And A/C)	✓	✓	✓	✓	✓	
FIAT	SPIDER	2020	BSM (Blind Spot Module)	✓	✓	✓	✓		
FIAT	SPIDER	2019	PCM (Powertrain Control Module)	✓	✓	✓	✓	✓	
FIAT	SPIDER	2019	TCM (Transmission Control Module)	✓	✓	✓	✓	✓	
FIAT	SPIDER	2019	ABS (Anti-Lock Braking System)	✓	✓	✓	✓		

FIAT	SPIDER	2019	IC (Instrument Cluster)	✓	✓	✓	✓		
FIAT	SPIDER	2019	SRS (Supplemental Inflatable Restraint System, ORC)	✓	✓	✓	✓		
FIAT	SPIDER	2019	BCM (Body Control Module)	✓	✓	✓	✓		
FIAT	SPIDER	2019	EPS (Electric Power Steering)	✓	✓	✓	✓		
FIAT	SPIDER	2019	RFH (Radio Frequency Hub)	✓	✓	✓	✓		
FIAT	SPIDER	2019	AFLS (Adaptive Front Lighting System)	✓	✓	✓	✓		
FIAT	SPIDER	2019	ETM (Entertainment Telematic Module)	✓	✓	✓	✓		
FIAT	SPIDER	2019	AMP (Amplifier)	✓	✓	✓	✓		
FIAT	SPIDER	2019	Lighting Power Module (LSM)	✓	✓	✓	✓		
FIAT	SPIDER	2019	HVAC (Heat, Ventilation And A/C)	✓	✓	✓	✓	✓	
FIAT	SPIDER	2019	BSM (Blind Spot Module)	✓	✓	✓	✓	✓	
FIAT	SPIDER	2018	PCM (Powertrain Control Module)	✓	✓	✓	✓	✓	
FIAT	SPIDER	2018	TCM (Transmission Control Module)	✓	✓	✓	✓	✓	
FIAT	SPIDER	2018	ABS (Anti-Lock Braking System)	✓	✓	✓	✓	✓	
FIAT	SPIDER	2018	IC (Instrument Cluster)	✓	✓	✓	✓		
FIAT	SPIDER	2018	SRS (Supplemental Inflatable Restraint System, ORC)	✓	✓	✓	✓		
FIAT	SPIDER	2018	BCM (Body Control Module)	✓	✓	✓	✓		
FIAT	SPIDER	2018	EPS (Electric Power Steering)	✓	✓	✓	✓		
FIAT	SPIDER	2018	RFH (Radio Frequency Hub)	✓	✓	✓	✓		
FIAT	SPIDER	2018	AFLS (Adaptive Front Lighting System)	✓	✓	✓	✓		
FIAT	SPIDER	2018	ETM (Entertainment Telematic Module)	✓	✓	✓	✓		
FIAT	SPIDER	2018	AMP (Amplifier)	✓	✓	✓	✓		
FIAT	SPIDER	2018	Lighting Power Module (LSM)	✓	✓	✓	✓		
FIAT	SPIDER	2018	HVAC (Heat, Ventilation And A/C)	✓	✓	✓	✓	✓	
FIAT	SPIDER	2018	BSM (Blind Spot Module)	✓	✓	✓	✓	✓	
FIAT	SPIDER	2017	PCM (Powertrain Control Module)	✓	✓	✓	✓	✓	
FIAT	SPIDER	2017	TCM (Transmission Control Module)	✓	✓	✓	✓	✓	
FIAT	SPIDER	2017	ABS (Anti-Lock Braking System)	✓	✓	✓	✓	✓	
FIAT	SPIDER	2017	IC (Instrument Cluster)	✓	✓	✓	✓	✓	
FIAT	SPIDER	2017	SRS (Supplemental Inflatable Restraint System, ORC)	✓	✓	✓	✓	✓	
FIAT	SPIDER	2017	BCM (Body Control Module)	✓	✓	✓	✓	✓	
FIAT	SPIDER	2017	EPS (Electric Power Steering)	✓	✓	✓	✓	✓	
FIAT	SPIDER	2017	RFH (Radio Frequency Hub)	✓	✓	✓	✓	✓	
FIAT	SPIDER	2017	AFLS (Adaptive Front Lighting System)	✓	✓	✓	✓	✓	
FIAT	SPIDER	2017	ETM (Entertainment Telematic Module)	✓	✓	✓	✓	✓	
FIAT	SPIDER	2017	AMP (Amplifier)	✓	✓	✓	✓	✓	
FIAT	SPIDER	2017	Lighting Power Module (LSM)	✓	✓	✓	✓	✓	
FIAT	SPIDER	2017	HVAC (Heat, Ventilation And A/C)	✓	✓	✓	✓	✓	✓
FIAT	SPIDER	2017	BSM (Blind Spot Module)	✓	✓	✓	✓	✓	✓
FIAT	STILO	1.2 16V	Bosch Motronic ME7.3H4M EOBD Injection	✓	✓	✓	✓	✓	
FIAT	STILO	1.2 16V	Marelli Connect 2	✓	✓	✓	✓	✓	✓
FIAT	STILO	1.2 16V	Visteon Instrument Panel	✓	✓	✓	✓	✓	✓
FIAT	STILO	1.2 16V	Bosch 8 ABS	✓	✓	✓	✓	✓	
FIAT	STILO	1.2 16V	Bosch 8 VDC ABS	✓	✓	✓	✓	✓	
FIAT	STILO	1.2 16V	Bosch ABS 5.7	✓	✓	✓	✓	✓	
FIAT	STILO	1.2 16V	Bosch ABS 5.7 ASR/TC	✓	✓	✓	✓	✓	
FIAT	STILO	1.2 16V	Marelli MF Body Computer	✓	✓	✓	✓	✓	✓
FIAT	STILO	1.2 16V	SIEMENS MY 99 Airbag (2F-4P-4L-2T-I-S-C)	✓	✓	✓	✓	✓	
FIAT	STILO	1.2 16V	SIEMENS MY 99 Airbag (2F-2P-I-S-C)	✓	✓	✓	✓	✓	
FIAT	STILO	1.2 16V	SIEMENS MY 99 Airbag (2F-2P-I-C)	✓	✓	✓	✓	✓	
FIAT	STILO	1.2 16V	SIEMENS MY 99 Airbag (2F-2P-2L-I-C)	✓	✓	✓	✓	✓	
FIAT	STILO	1.2 16V	SIEMENS MY 99 Airbag (2F-2P-2L-2T-I-S-C)	✓	✓	✓	✓	✓	
FIAT	STILO	1.2 16V	SIEMENS MY 99 Airbag (2F-2P-2L-2T-I-C)	✓	✓	✓	✓	✓	
FIAT	STILO	1.2 16V	Bosch ABS 5.7 VDC	✓	✓	✓	✓	✓	
FIAT	STILO	1.2 16V	TRW Steering Lock	✓	✓	✓	✓	✓	
FIAT	STILO	1.2 16V	DELPHI MF Passive Entry	✓	✓	✓	✓	✓	
FIAT	STILO	1.2 16V	Lear Driving Seat	✓	✓	✓	✓	✓	
FIAT	STILO	1.2 16V	Lear Passenger Seat	✓	✓	✓	✓	✓	

FIAT	STILO	1.2 16V	Marelli Climate Control	✓	✓	✓	✓	✓	
FIAT	STILO	1.2 16V	TRW Electric Drive	✓	✓	✓	✓		
FIAT	STILO	1.2 16V	TRW 1 Power Steering	✓	✓	✓	✓		
FIAT	STILO	1.2 16V	BITRON Boot	✓	✓	✓	✓	✓	
FIAT	STILO	1.2 16V	BITRON Driver's Door	✓	✓	✓	✓	✓	
FIAT	STILO	1.2 16V	BITRON Passenger Door	✓	✓	✓	✓	✓	
FIAT	STILO	1.2 16V	Bosch Discharge Headlamp (Left)	✓	✓	✓	✓		
FIAT	STILO	1.2 16V	G.E. PROCOND Driver's Door	✓	✓	✓	✓	✓	
FIAT	STILO	1.2 16V	G.E. PROCOND Boot	✓	✓	✓	✓	✓	
FIAT	STILO	1.2 16V	Bosch Discharge Headlamp (Right)	✓	✓	✓	✓		
FIAT	STILO	1.2 16V	G.E. PROCOND Passenger Door	✓	✓	✓	✓	✓	
FIAT	STILO	1.2 16V	Valeo Parking Control Unit	✓	✓	✓	✓		
FIAT	STILO	1.4 16V	Bosch Motronic ME7.3H4M EOBD Injection	✓	✓	✓	✓		
FIAT	STILO	1.4 16V	Marelli Connect 2	✓	✓	✓	✓	✓	
FIAT	STILO	1.4 16V	Visteon Instrument Panel	✓	✓	✓	✓	✓	
FIAT	STILO	1.4 16V	Bosch 8 ABS	✓	✓	✓	✓		
FIAT	STILO	1.4 16V	Bosch 8 VDC ABS	✓	✓	✓	✓		
FIAT	STILO	1.4 16V	Bosch ABS 5.7	✓	✓	✓	✓		
FIAT	STILO	1.4 16V	DELPHI MF Passive Entry	✓	✓	✓	✓		
FIAT	STILO	1.4 16V	Marelli MF Body Computer	✓	✓	✓	✓	✓	
FIAT	STILO	1.4 16V	Marelli 5 Body Computer	✓	✓	✓	✓	✓	
FIAT	STILO	1.4 16V	SIEMENS MY 99 Airbag (2F-4P-4L-2T-I-S-C)	✓	✓	✓	✓		
FIAT	STILO	1.4 16V	SIEMENS MY 99 Airbag (2F-2P-I-S-C)	✓	✓	✓	✓		
FIAT	STILO	1.4 16V	SIEMENS MY 99 Airbag (2F-2P-I-C)	✓	✓	✓	✓		
FIAT	STILO	1.4 16V	SIEMENS MY 99 Airbag (2F-2P-2L-I-C)	✓	✓	✓	✓		
FIAT	STILO	1.4 16V	SIEMENS MY 99 Airbag (2F-2P-2L-2T-I-S-C)	✓	✓	✓	✓		
FIAT	STILO	1.4 16V	SIEMENS MY 99 Airbag (2F-2P-2L-2T-I-C)	✓	✓	✓	✓		
FIAT	STILO	1.4 16V	TRW Steering Lock	✓	✓	✓	✓		
FIAT	STILO	1.4 16V	Lear Driving Seat	✓	✓	✓	✓		
FIAT	STILO	1.4 16V	Lear Passenger Seat	✓	✓	✓	✓		
FIAT	STILO	1.4 16V	Marelli Climate Control	✓	✓	✓	✓	✓	
FIAT	STILO	1.4 16V	TRW Electric Drive	✓	✓	✓	✓		
FIAT	STILO	1.4 16V	TRW 3 Electric Steering	✓	✓	✓	✓		
FIAT	STILO	1.4 16V	TRW 1 Power Steering	✓	✓	✓	✓		
FIAT	STILO	1.4 16V	BITRON Boot	✓	✓	✓	✓	✓	
FIAT	STILO	1.4 16V	Bitron Doors Control	✓	✓	✓	✓	✓	
FIAT	STILO	1.4 16V	BITRON Driver's Door	✓	✓	✓	✓	✓	
FIAT	STILO	1.4 16V	BITRON Passenger Door	✓	✓	✓	✓	✓	
FIAT	STILO	1.4 16V	G.E. PROCOND Driver's Door	✓	✓	✓	✓	✓	
FIAT	STILO	1.4 16V	G.E. PROCOND Boot	✓	✓	✓	✓	✓	
FIAT	STILO	1.4 16V	Bosch Discharge Headlamp (Left)	✓	✓	✓	✓		
FIAT	STILO	1.4 16V	Bosch Discharge Headlamp (Right)	✓	✓	✓	✓		
FIAT	STILO	1.4 16V	G.E. PROCOND Passenger Door	✓	✓	✓	✓	✓	
FIAT	STILO	1.4 16V	Valeo Parking Control Unit	✓	✓	✓	✓		
FIAT	STILO	1.6 16V	Injection - Magneti Marelli IAW 5NF EOBD	✓	✓	✓	✓		
FIAT	STILO	1.6 16V	Magneti Marelli IAW 5NF Injection Outside EEC	✓	✓	✓	✓		
FIAT	STILO	1.6 16V	Magneti Marelli Injection IAW 5SF CF4/EOBD (Eng. 1.6 16V)	✓	✓	✓	✓		
FIAT	STILO	1.6 16V	Marelli Connect 2	✓	✓	✓	✓	✓	
FIAT	STILO	1.6 16V	Visteon Instrument Panel	✓	✓	✓	✓	✓	
FIAT	STILO	1.6 16V	Bosch 8 ABS	✓	✓	✓	✓		
FIAT	STILO	1.6 16V	Bosch 8 VDC ABS	✓	✓	✓	✓		
FIAT	STILO	1.6 16V	Bosch ABS 5.7	✓	✓	✓	✓		
FIAT	STILO	1.6 16V	Bosch ABS 5.7 ASR/TC	✓	✓	✓	✓		
FIAT	STILO	1.6 16V	Marelli MF Body Computer	✓	✓	✓	✓	✓	
FIAT	STILO	1.6 16V	Marelli 5 Body Computer	✓	✓	✓	✓	✓	
FIAT	STILO	1.6 16V	SIEMENS MY 99 Airbag (2F-4P-4L-2T-I-S-C)	✓	✓	✓	✓		
FIAT	STILO	1.6 16V	SIEMENS MY 99 Airbag (2F-2P-I-S-C)	✓	✓	✓	✓		
FIAT	STILO	1.6 16V	SIEMENS MY 99 Airbag (2F-2P-I-C)	✓	✓	✓	✓		
FIAT	STILO	1.6 16V	SIEMENS MY 99 Airbag (2F-2P-2L-I-C)	✓	✓	✓	✓		
FIAT	STILO	1.6 16V	SIEMENS MY 99 Airbag (2F-2P-2L-2T-I-S-C)	✓	✓	✓	✓		

FIAT	STILO	1.6 16V	SIEMENS MY 99 Airbag (2F-2P-2L-2T-I-C)	✓	✓	✓	✓		
FIAT	STILO	1.6 16V	Bosch ABS 5.7 VDC	✓	✓	✓	✓		
FIAT	STILO	1.6 16V	TRW Steering Lock	✓	✓	✓	✓		
FIAT	STILO	1.6 16V	DELPHI MF Passive Entry	✓	✓	✓	✓		
FIAT	STILO	1.6 16V	Lear Driving Seat	✓	✓	✓	✓		
FIAT	STILO	1.6 16V	Lear Passenger Seat	✓	✓	✓	✓		
FIAT	STILO	1.6 16V	Marelli Climate Control	✓	✓	✓	✓	✓	
FIAT	STILO	1.6 16V	TRW Electric Drive	✓	✓	✓	✓		
FIAT	STILO	1.6 16V	TRW 3 Electric Steering	✓	✓	✓	✓		
FIAT	STILO	1.6 16V	TRW 1 Power Steering	✓	✓	✓	✓		
FIAT	STILO	1.6 16V	BITRON Boot	✓	✓	✓	✓	✓	
FIAT	STILO	1.6 16V	Bitron Doors Control	✓	✓	✓	✓	✓	
FIAT	STILO	1.6 16V	BITRON Driver's Door	✓	✓	✓	✓	✓	
FIAT	STILO	1.6 16V	BITRON Passenger Door	✓	✓	✓	✓	✓	
FIAT	STILO	1.6 16V	G.E. PROCOND Driver's Door	✓	✓	✓	✓	✓	
FIAT	STILO	1.6 16V	G.E. PROCOND Boot	✓	✓	✓	✓	✓	
FIAT	STILO	1.6 16V	Bosch Discharge Headlamp (Left)	✓	✓	✓	✓		
FIAT	STILO	1.6 16V	Bosch Discharge Headlamp (Right)	✓	✓	✓	✓		
FIAT	STILO	1.6 16V	G.E. PROCOND Passenger Door	✓	✓	✓	✓	✓	
FIAT	STILO	1.6 16V	Valeo Parking Control Unit	✓	✓	✓	✓		
FIAT	STILO	1.8 16V	Delphi MT25E Injection (Eng. 1.8)	✓	✓	✓	✓		
FIAT	STILO	1.8 16V	Hitachi EOBD Injection	✓	✓	✓	✓		
FIAT	STILO	1.8 16V	Injection - Hitachi MPI Outside EEC	✓	✓	✓	✓		
FIAT	STILO	1.8 16V	Marelli Connect 2	✓	✓	✓	✓	✓	
FIAT	STILO	1.8 16V	Visteon Instrument Panel	✓	✓	✓	✓	✓	
FIAT	STILO	1.8 16V	Bosch 8 ABS	✓	✓	✓	✓		
FIAT	STILO	1.8 16V	Bosch 8 VDC ABS	✓	✓	✓	✓		
FIAT	STILO	1.8 16V	Bosch ABS 5.7	✓	✓	✓	✓		
FIAT	STILO	1.8 16V	Bosch ABS 5.7 ASR/TC	✓	✓	✓	✓		
FIAT	STILO	1.8 16V	Marelli MF Body Computer	✓	✓	✓	✓	✓	
FIAT	STILO	1.8 16V	Marelli 5 Body Computer	✓	✓	✓	✓	✓	
FIAT	STILO	1.8 16V	SIEMENS MY 99 Airbag (2F-4P-4L-2T-I-S-C)	✓	✓	✓	✓		
FIAT	STILO	1.8 16V	SIEMENS MY 99 Airbag (2F-2P-I-S-C)	✓	✓	✓	✓		
FIAT	STILO	1.8 16V	SIEMENS MY 99 Airbag (2F-2P-I-C)	✓	✓	✓	✓		
FIAT	STILO	1.8 16V	SIEMENS MY 99 Airbag (2F-2P-2L-I-C)	✓	✓	✓	✓		
FIAT	STILO	1.8 16V	SIEMENS MY 99 Airbag (2F-2P-2L-2T-I-S-C)	✓	✓	✓	✓		
FIAT	STILO	1.8 16V	SIEMENS MY 99 Airbag (2F-2P-2L-2T-I-C)	✓	✓	✓	✓		
FIAT	STILO	1.8 16V	Bosch ABS 5.7 VDC	✓	✓	✓	✓		
FIAT	STILO	1.8 16V	TRW Steering Lock	✓	✓	✓	✓		
FIAT	STILO	1.8 16V	DELPHI MF Passive Entry	✓	✓	✓	✓		
FIAT	STILO	1.8 16V	Lear Driving Seat	✓	✓	✓	✓		
FIAT	STILO	1.8 16V	Lear Passenger Seat	✓	✓	✓	✓		
FIAT	STILO	1.8 16V	Marelli Climate Control	✓	✓	✓	✓	✓	
FIAT	STILO	1.8 16V	TRW Electric Drive	✓	✓	✓	✓		
FIAT	STILO	1.8 16V	TRW 3 Electric Steering	✓	✓	✓	✓		
FIAT	STILO	1.8 16V	TRW 1 Power Steering	✓	✓	✓	✓		
FIAT	STILO	1.8 16V	BITRON Boot	✓	✓	✓	✓	✓	
FIAT	STILO	1.8 16V	Bitron Doors Control	✓	✓	✓	✓	✓	
FIAT	STILO	1.8 16V	BITRON Driver's Door	✓	✓	✓	✓	✓	
FIAT	STILO	1.8 16V	BITRON Passenger Door	✓	✓	✓	✓	✓	
FIAT	STILO	1.8 16V	G.E. PROCOND Driver's Door	✓	✓	✓	✓	✓	
FIAT	STILO	1.8 16V	G.E. PROCOND Boot	✓	✓	✓	✓	✓	
FIAT	STILO	1.8 16V	Bosch Discharge Headlamp (Left)	✓	✓	✓	✓		
FIAT	STILO	1.8 16V	Bosch Discharge Headlamp (Right)	✓	✓	✓	✓		
FIAT	STILO	1.8 16V	G.E. PROCOND Passenger Door	✓	✓	✓	✓	✓	
FIAT	STILO	1.8 16V	Valeo Parking Control Unit	✓	✓	✓	✓		
FIAT	STILO	1.8 8V	Delphi MT25E Injection (Eng. 1.8)	✓	✓	✓	✓		
FIAT	STILO	1.8 8V	Marelli Connect 2	✓	✓	✓	✓	✓	
FIAT	STILO	1.8 8V	Visteon Instrument Panel	✓	✓	✓	✓	✓	
FIAT	STILO	1.8 8V	Bosch 8 ABS	✓	✓	✓	✓		
FIAT	STILO	1.8 8V	Bosch 8 VDC ABS	✓	✓	✓	✓		

FIAT	STILO	1.8 8V	DELPHI MF Passive Entry	✓	✓	✓	✓		
FIAT	STILO	1.8 8V	Marelli MF Body Computer	✓	✓	✓	✓	✓	
FIAT	STILO	1.8 8V	SIEMENS MY 99 Airbag (2F-2P-I-C)	✓	✓	✓	✓		
FIAT	STILO	1.8 8V	SIEMENS MY 99 Airbag (2F-2P-2L-I-C)	✓	✓	✓	✓		
FIAT	STILO	1.8 8V	SIEMENS MY 99 Airbag (2F-2P-2L-2T-I-C)	✓	✓	✓	✓		
FIAT	STILO	1.8 8V	TRW Steering Lock	✓	✓	✓	✓		
FIAT	STILO	1.8 8V	Lear Driving Seat	✓	✓	✓	✓		
FIAT	STILO	1.8 8V	Lear Passenger Seat	✓	✓	✓	✓		
FIAT	STILO	1.8 8V	Marelli Climate Control	✓	✓	✓	✓	✓	
FIAT	STILO	1.8 8V	TRW 1 Power Steering	✓	✓	✓	✓		
FIAT	STILO	1.8 8V	Bosch Discharge Headlamp (Left)	✓	✓	✓	✓		
FIAT	STILO	1.8 8V	Bosch Discharge Headlamp (Right)	✓	✓	✓	✓		
FIAT	STILO	1.8 8V	G.E. PROCOND Driver's Door	✓	✓	✓	✓	✓	
FIAT	STILO	1.8 8V	G.E. PROCOND Boot	✓	✓	✓	✓	✓	
FIAT	STILO	1.8 8V	G.E. PROCOND Passenger Door	✓	✓	✓	✓	✓	
FIAT	STILO	1.8 8V	Valeo Parking Control Unit	✓	✓	✓	✓		
FIAT	STILO	1.9 JTD	Bosch Diesel Injection EDC16C39 CF4/E0BD (Eng. 1.9/2.4)	✓	✓	✓	✓		
FIAT	STILO	1.9 JTD	Bosch EDC15 CF3/E0BD Diesel Injection (Eng. 1.9/2.4)	✓	✓	✓	✓		
FIAT	STILO	1.9 JTD	Marelli Connect 2	✓	✓	✓	✓	✓	
FIAT	STILO	1.9 JTD	Visteon Instrument Panel	✓	✓	✓	✓	✓	
FIAT	STILO	1.9 JTD	Bosch 8 ABS	✓	✓	✓	✓		
FIAT	STILO	1.9 JTD	Bosch 8 VDC ABS	✓	✓	✓	✓		
FIAT	STILO	1.9 JTD	Bosch ABS 5.7	✓	✓	✓	✓		
FIAT	STILO	1.9 JTD	Bosch ABS 5.7 ASR/TC	✓	✓	✓	✓		
FIAT	STILO	1.9 JTD	Marelli MF Body Computer	✓	✓	✓	✓	✓	
FIAT	STILO	1.9 JTD	Marelli 5 Body Computer	✓	✓	✓	✓	✓	
FIAT	STILO	1.9 JTD	SIEMENS MY 99 Airbag (2F-4P-4L-2T-I-S-C)	✓	✓	✓	✓		
FIAT	STILO	1.9 JTD	SIEMENS MY 99 Airbag (2F-2P-I-S-C)	✓	✓	✓	✓		
FIAT	STILO	1.9 JTD	SIEMENS MY 99 Airbag (2F-2P-I-C)	✓	✓	✓	✓		
FIAT	STILO	1.9 JTD	SIEMENS MY 99 Airbag (2F-2P-2L-I-C)	✓	✓	✓	✓		
FIAT	STILO	1.9 JTD	SIEMENS MY 99 Airbag (2F-2P-2L-2T-I-S-C)	✓	✓	✓	✓		
FIAT	STILO	1.9 JTD	SIEMENS MY 99 Airbag (2F-2P-2L-2T-I-C)	✓	✓	✓	✓		
FIAT	STILO	1.9 JTD	Bosch ABS 5.7 VDC	✓	✓	✓	✓		
FIAT	STILO	1.9 JTD	TRW Steering Lock	✓	✓	✓	✓		
FIAT	STILO	1.9 JTD	DELPHI MF Passive Entry	✓	✓	✓	✓		
FIAT	STILO	1.9 JTD	Lear Driving Seat	✓	✓	✓	✓		
FIAT	STILO	1.9 JTD	Lear Passenger Seat	✓	✓	✓	✓		
FIAT	STILO	1.9 JTD	Marelli Climate Control	✓	✓	✓	✓	✓	
FIAT	STILO	1.9 JTD	TRW Electric Drive	✓	✓	✓	✓		
FIAT	STILO	1.9 JTD	TRW 3 Electric Steering	✓	✓	✓	✓		
FIAT	STILO	1.9 JTD	TRW 1 Power Steering	✓	✓	✓	✓		
FIAT	STILO	1.9 JTD	BITRON Boot	✓	✓	✓	✓	✓	
FIAT	STILO	1.9 JTD	Bitron Doors Control	✓	✓	✓	✓	✓	
FIAT	STILO	1.9 JTD	BITRON Driver's Door	✓	✓	✓	✓	✓	
FIAT	STILO	1.9 JTD	BITRON Passenger Door	✓	✓	✓	✓	✓	
FIAT	STILO	1.9 JTD	G.E. PROCOND Driver's Door	✓	✓	✓	✓	✓	
FIAT	STILO	1.9 JTD	G.E. PROCOND Boot	✓	✓	✓	✓	✓	
FIAT	STILO	1.9 JTD	Bosch Discharge Headlamp (Left)	✓	✓	✓	✓		
FIAT	STILO	1.9 JTD	Bosch Discharge Headlamp (Right)	✓	✓	✓	✓		
FIAT	STILO	1.9 JTD	G.E. PROCOND Passenger Door	✓	✓	✓	✓	✓	
FIAT	STILO	1.9 JTD	Valeo Parking Control Unit	✓	✓	✓	✓		
FIAT	STILO	1.9 JTD 16V	Bosch Diesel Injection EDC16C39 CF4/E0BD (Eng. 1.9/2.4)	✓	✓	✓	✓		
FIAT	STILO	1.9 JTD 16V	Bosch EDC16 CF3/E0BD Diesel Injection (1.9/2.4 Eng.)	✓	✓	✓	✓		
FIAT	STILO	1.9 JTD 16V	Marelli Connect 2	✓	✓	✓	✓	✓	
FIAT	STILO	1.9 JTD 16V	Visteon Instrument Panel	✓	✓	✓	✓	✓	
FIAT	STILO	1.9 JTD 16V	Bosch 8 ABS	✓	✓	✓	✓		
FIAT	STILO	1.9 JTD 16V	Bosch 8 VDC ABS	✓	✓	✓	✓		

FIAT	STILO	1.9 JTD 16V	Bosch ABS 5.7	✓	✓	✓	✓		
FIAT	STILO	1.9 JTD 16V	DELPHI MF Passive Entry	✓	✓	✓	✓		
FIAT	STILO	1.9 JTD 16V	Marelli MF Body Computer	✓	✓	✓	✓	✓	
FIAT	STILO	1.9 JTD 16V	Marelli 5 Body Computer	✓	✓	✓	✓	✓	
FIAT	STILO	1.9 JTD 16V	SIEMENS MY 99 Airbag (2F-4P-4L-2T-I-S-C)	✓	✓	✓	✓		
FIAT	STILO	1.9 JTD 16V	SIEMENS MY 99 Airbag (2F-2P-I-S-C)	✓	✓	✓	✓		
FIAT	STILO	1.9 JTD 16V	SIEMENS MY 99 Airbag (2F-2P-I-C)	✓	✓	✓	✓		
FIAT	STILO	1.9 JTD 16V	SIEMENS MY 99 Airbag (2F-2P-2L-I-C)	✓	✓	✓	✓		
FIAT	STILO	1.9 JTD 16V	SIEMENS MY 99 Airbag (2F-2P-2L-2T-I-S-C)	✓	✓	✓	✓		
FIAT	STILO	1.9 JTD 16V	SIEMENS MY 99 Airbag (2F-2P-2L-2T-I-C)	✓	✓	✓	✓		
FIAT	STILO	1.9 JTD 16V	TRW Steering Lock	✓	✓	✓	✓		
FIAT	STILO	1.9 JTD 16V	Lear Driving Seat	✓	✓	✓	✓		
FIAT	STILO	1.9 JTD 16V	Lear Passenger Seat	✓	✓	✓	✓		
FIAT	STILO	1.9 JTD 16V	Marelli Climate Control	✓	✓	✓	✓	✓	
FIAT	STILO	1.9 JTD 16V	TRW Electric Drive	✓	✓	✓	✓		
FIAT	STILO	1.9 JTD 16V	TRW 3 Electric Steering	✓	✓	✓	✓		
FIAT	STILO	1.9 JTD 16V	TRW 1 Power Steering	✓	✓	✓	✓		
FIAT	STILO	1.9 JTD 16V	BITRON Boot	✓	✓	✓	✓	✓	
FIAT	STILO	1.9 JTD 16V	Bitron Doors Control	✓	✓	✓	✓	✓	
FIAT	STILO	1.9 JTD 16V	BITRON Driver's Door	✓	✓	✓	✓	✓	
FIAT	STILO	1.9 JTD 16V	BITRON Passenger Door	✓	✓	✓	✓	✓	
FIAT	STILO	1.9 JTD 16V	G.E. PROCOND Driver's Door	✓	✓	✓	✓	✓	
FIAT	STILO	1.9 JTD 16V	G.E. PROCOND Boot	✓	✓	✓	✓	✓	
FIAT	STILO	1.9 JTD 16V	Bosch Discharge Headlamp (Left)	✓	✓	✓	✓		
FIAT	STILO	1.9 JTD 16V	Bosch Discharge Headlamp (Right)	✓	✓	✓	✓		
FIAT	STILO	1.9 JTD 16V	G.E. PROCOND Passenger Door	✓	✓	✓	✓	✓	
FIAT	STILO	1.9 JTD 16V	Valeo Parking Control Unit	✓	✓	✓	✓		
FIAT	STILO	2.4 20V	Bosch Motronic Me3.1 EOBD Injection (Eng. 2.0/2.4 20V)	✓	✓	✓	✓		
FIAT	STILO	2.4 20V	Injection - Bosch Motronic Me3.1 (Eng. 2.0/2.4 20V) Outside	✓	✓	✓	✓		
FIAT	STILO	2.4 20V	Marelli Connect 2	✓	✓	✓	✓	✓	
FIAT	STILO	2.4 20V	Visteon Instrument Panel	✓	✓	✓	✓	✓	
FIAT	STILO	2.4 20V	Bosch 8 ABS	✓	✓	✓	✓		
FIAT	STILO	2.4 20V	Bosch 8 VDC ABS	✓	✓	✓	✓		
FIAT	STILO	2.4 20V	Bosch ABS 5.7	✓	✓	✓	✓		
FIAT	STILO	2.4 20V	Bosch ABS 5.7 ASR/TC	✓	✓	✓	✓		
FIAT	STILO	2.4 20V	Marelli MF Body Computer	✓	✓	✓	✓	✓	
FIAT	STILO	2.4 20V	SIEMENS MY 99 Airbag (2F-4P-4L-2T-I-S-C)	✓	✓	✓	✓		
FIAT	STILO	2.4 20V	SIEMENS MY 99 Airbag (2F-2P-I-S-C)	✓	✓	✓	✓		
FIAT	STILO	2.4 20V	SIEMENS MY 99 Airbag (2F-2P-I-C)	✓	✓	✓	✓		
FIAT	STILO	2.4 20V	SIEMENS MY 99 Airbag (2F-2P-2L-I-C)	✓	✓	✓	✓		
FIAT	STILO	2.4 20V	SIEMENS MY 99 Airbag (2F-2P-2L-2T-I-S-C)	✓	✓	✓	✓		
FIAT	STILO	2.4 20V	SIEMENS MY 99 Airbag (2F-2P-2L-2T-I-C)	✓	✓	✓	✓		
FIAT	STILO	2.4 20V	Bosch ABS 5.7 VDC	✓	✓	✓	✓		
FIAT	STILO	2.4 20V	TRW Steering Lock	✓	✓	✓	✓		
FIAT	STILO	2.4 20V	DELPHI MF Passive Entry	✓	✓	✓	✓		
FIAT	STILO	2.4 20V	Bosch Adaptive Cruise Control	✓	✓	✓	✓		
FIAT	STILO	2.4 20V	Lear Driving Seat	✓	✓	✓	✓		
FIAT	STILO	2.4 20V	Lear Passenger Seat	✓	✓	✓	✓		
FIAT	STILO	2.4 20V	Marelli Climate Control	✓	✓	✓	✓	✓	
FIAT	STILO	2.4 20V	TRW Electric Drive	✓	✓	✓	✓		
FIAT	STILO	2.4 20V	TRW 1 Power Steering	✓	✓	✓	✓		
FIAT	STILO	2.4 20V	BITRON Boot	✓	✓	✓	✓	✓	
FIAT	STILO	2.4 20V	BITRON Driver's Door	✓	✓	✓	✓	✓	
FIAT	STILO	2.4 20V	BITRON Passenger Door	✓	✓	✓	✓	✓	
FIAT	STILO	2.4 20V	Bosch Discharge Headlamp (Left)	✓	✓	✓	✓		
FIAT	STILO	2.4 20V	G.E. PROCOND Driver's Door	✓	✓	✓	✓	✓	



FIAT	STILO	2.4 20V	G.E. PROCOND Boot	✓	✓	✓	✓	✓	
FIAT	STILO	2.4 20V	Bosch Discharge Headlamp (Right)	✓	✓	✓	✓		
FIAT	STILO	2.4 20V	G.E. PROCOND Passenger Door	✓	✓	✓	✓	✓	
FIAT	STILO	2.4 20V	Valeo Parking Control Unit	✓	✓	✓	✓		
FIAT	STILO	SELESPEED	Bosch Motronic Me3.1 EOBD Injection (Eng. 2.0/2.4 20V)	✓	✓	✓	✓		
FIAT	STILO	SELESPEED	Marelli SELESPEED FC209F Automatic Gearbox	✓	✓	✓	✓		
FIAT	STILO	SELESPEED	Marelli Connect 2	✓	✓	✓	✓	✓	
FIAT	STILO	SELESPEED	Visteon Instrument Panel	✓	✓	✓	✓	✓	
FIAT	STILO	SELESPEED	Bosch 8 ABS	✓	✓	✓	✓		
FIAT	STILO	SELESPEED	Bosch 8 VDC ABS	✓	✓	✓	✓		
FIAT	STILO	SELESPEED	Bosch ABS 5.7	✓	✓	✓	✓		
FIAT	STILO	SELESPEED	Bosch ABS 5.7 ASR/TC	✓	✓	✓	✓		
FIAT	STILO	SELESPEED	Marelli MF Body Computer	✓	✓	✓	✓	✓	
FIAT	STILO	SELESPEED	SIEMENS MY 99 Airbag (2F-4P-4L-2T-I-S-C)	✓	✓	✓	✓		
FIAT	STILO	SELESPEED	SIEMENS MY 99 Airbag (2F-2P-I-S-C)	✓	✓	✓	✓		
FIAT	STILO	SELESPEED	SIEMENS MY 99 Airbag (2F-2P-I-C)	✓	✓	✓	✓		
FIAT	STILO	SELESPEED	SIEMENS MY 99 Airbag (2F-2P-2L-I-C)	✓	✓	✓	✓		
FIAT	STILO	SELESPEED	SIEMENS MY 99 Airbag (2F-2P-2L-2T-I-S-C)	✓	✓	✓	✓		
FIAT	STILO	SELESPEED	SIEMENS MY 99 Airbag (2F-2P-2L-2T-I-C)	✓	✓	✓	✓		
FIAT	STILO	SELESPEED	Bosch ABS 5.7 VDC	✓	✓	✓	✓		
FIAT	STILO	SELESPEED	TRW Steering Lock	✓	✓	✓	✓		
FIAT	STILO	SELESPEED	DELPHI MF Passive Entry	✓	✓	✓	✓		
FIAT	STILO	SELESPEED	Bosch Adaptive Cruise Control	✓	✓	✓	✓		
FIAT	STILO	SELESPEED	Lear Driving Seat	✓	✓	✓	✓		
FIAT	STILO	SELESPEED	Lear Passenger Seat	✓	✓	✓	✓		
FIAT	STILO	SELESPEED	Marelli Climate Control	✓	✓	✓	✓	✓	
FIAT	STILO	SELESPEED	TRW Electric Drive	✓	✓	✓	✓		
FIAT	STILO	SELESPEED	TRW 1 Power Steering	✓	✓	✓	✓		
FIAT	STILO	SELESPEED	BITRON Boot	✓	✓	✓	✓	✓	
FIAT	STILO	SELESPEED	BITRON Driver's Door	✓	✓	✓	✓	✓	
FIAT	STILO	SELESPEED	BITRON Passenger Door	✓	✓	✓	✓	✓	
FIAT	STILO	SELESPEED	Bosch Discharge Headlamp (Left)	✓	✓	✓	✓		
FIAT	STILO	SELESPEED	G.E. PROCOND Driver's Door	✓	✓	✓	✓	✓	
FIAT	STILO	SELESPEED	G.E. PROCOND Boot	✓	✓	✓	✓	✓	
FIAT	STILO	SELESPEED	Bosch Discharge Headlamp (Right)	✓	✓	✓	✓		
FIAT	STILO	SELESPEED	G.E. PROCOND Passenger Door	✓	✓	✓	✓	✓	
FIAT	STILO	SELESPEED	Valeo Parking Control Unit	✓	✓	✓	✓		
FIAT	STILO VAN	1.9 JTD 16V	Bosch Diesel Injection EDC16C39 CF4/EOBD (Eng. 1.9/2.4)	✓	✓	✓	✓		
FIAT	STILO VAN	1.9 JTD 16V	Bosch EDC16 CF3/EOBD Diesel Injection (1.9/2.4 Eng.)	✓	✓	✓	✓		
FIAT	STILO VAN	1.9 JTD 16V	Marelli Connect 2	✓	✓	✓	✓	✓	
FIAT	STILO VAN	1.9 JTD 16V	Visteon Instrument Panel	✓	✓	✓	✓	✓	
FIAT	STILO VAN	1.9 JTD 16V	Bosch 8 ABS	✓	✓	✓	✓		
FIAT	STILO VAN	1.9 JTD 16V	Bosch 8 VDC ABS	✓	✓	✓	✓		
FIAT	STILO VAN	1.9 JTD 16V	Bosch ABS 5.7	✓	✓	✓	✓		
FIAT	STILO VAN	1.9 JTD 16V	DELPHI MF Passive Entry	✓	✓	✓	✓		
FIAT	STILO VAN	1.9 JTD 16V	Marelli MF Body Computer	✓	✓	✓	✓	✓	
FIAT	STILO VAN	1.9 JTD 16V	Marelli 5 Body Computer	✓	✓	✓	✓	✓	
FIAT	STILO VAN	1.9 JTD 16V	SIEMENS MY 99 Airbag (2F-4P-4L-2T-I-S-C)	✓	✓	✓	✓		
FIAT	STILO VAN	1.9 JTD 16V	SIEMENS MY 99 Airbag (2F-2P-I-S-C)	✓	✓	✓	✓		
FIAT	STILO VAN	1.9 JTD 16V	SIEMENS MY 99 Airbag (2F-2P-I-C)	✓	✓	✓	✓		
FIAT	STILO VAN	1.9 JTD 16V	SIEMENS MY 99 Airbag (2F-2P-2L-I-C)	✓	✓	✓	✓		
FIAT	STILO VAN	1.9 JTD 16V	SIEMENS MY 99 Airbag (2F-2P-2L-2T-I-S-C)	✓	✓	✓	✓		
FIAT	STILO VAN	1.9 JTD 16V	SIEMENS MY 99 Airbag (2F-2P-2L-2T-I-C)	✓	✓	✓	✓		
FIAT	STILO VAN	1.9 JTD 16V	TRW Steering Lock	✓	✓	✓	✓		
FIAT	STILO VAN	1.9 JTD 16V	Lear Driving Seat	✓	✓	✓	✓		

FIAT	STILO VAN	1.9 JTD 16V	Lear Passenger Seat	✓	✓	✓	✓		
FIAT	STILO VAN	1.9 JTD 16V	Marelli Climate Control	✓	✓	✓	✓	✓	
FIAT	STILO VAN	1.9 JTD 16V	TRW Electric Drive	✓	✓	✓	✓		
FIAT	STILO VAN	1.9 JTD 16V	TRW 3 Electric Steering	✓	✓	✓	✓		
FIAT	STILO VAN	1.9 JTD 16V	TRW 1 Power Steering	✓	✓	✓	✓		
FIAT	STILO VAN	1.9 JTD 16V	BITRON Boot	✓	✓	✓	✓	✓	
FIAT	STILO VAN	1.9 JTD 16V	Bitron Doors Control	✓	✓	✓	✓	✓	
FIAT	STILO VAN	1.9 JTD 16V	BITRON Driver's Door	✓	✓	✓	✓	✓	
FIAT	STILO VAN	1.9 JTD 16V	BITRON Passenger Door	✓	✓	✓	✓	✓	
FIAT	STILO VAN	1.9 JTD 16V	G.E. PROCOND Driver's Door	✓	✓	✓	✓	✓	
FIAT	STILO VAN	1.9 JTD 16V	G.E. PROCOND Boot	✓	✓	✓	✓	✓	
FIAT	STILO VAN	1.9 JTD 16V	Bosch Discharge Headlamp (Left)	✓	✓	✓	✓		
FIAT	STILO VAN	1.9 JTD 16V	Bosch Discharge Headlamp (Right)	✓	✓	✓	✓		
FIAT	STILO VAN	1.9 JTD 16V	G.E. PROCOND Passenger Door	✓	✓	✓	✓	✓	
FIAT	STILO VAN	1.9 JTD 16V	Valeo Parking Control Unit	✓	✓	✓	✓		
FIAT	STRADA	2022	ECM (Engine Control Module)		✓	✓			
FIAT	STRADA	2022	ABS (Anti-Lock Braking System)		✓	✓			
FIAT	STRADA	2022	SRS (Supplemental Inflatable Restraint System, ORC)		✓	✓			
FIAT	STRADA	2022	BCM (Body Control Module)		✓	✓			
FIAT	STRADA	2021	ECM (Engine Control Module)		✓	✓			
FIAT	STRADA	2021	ABS (Anti-Lock Braking System)		✓	✓			
FIAT	STRADA	2021	SRS (Supplemental Inflatable Restraint System, ORC)		✓	✓			
FIAT	STRADA	2021	BCM (Body Control Module)		✓	✓			
FIAT	STRADA	2020	ECM (Engine Control Module)		✓	✓			
FIAT	STRADA	2020	ABS (Anti-Lock Braking System)		✓	✓			
FIAT	STRADA	2020	SRS (Supplemental Inflatable Restraint System, ORC)		✓	✓			
FIAT	STRADA	2020	BCM (Body Control Module)		✓	✓			
FIAT	STRADA	Old Models (Before 2007)	Bosch 5.3 ABS	✓	✓	✓			
FIAT	STRADA	Old Models (Before 2007)	Bosch 8 ABS	✓	✓	✓	✓		
FIAT	STRADA	Old Models (Before 2007)	Marelli Body Computer 2	✓	✓	✓	✓	✓	
FIAT	STRADA	Old Models (Before 2007)	Marelli Diesel Injection 6F3 EOB (Eng. 1.3 JTD)	✓	✓	✓	✓		
FIAT	STRADA	Old Models (Before 2007)	Marelli Instrument Panel (Palio RST2)	✓	✓	✓	✓	✓	
FIAT	STRADA	Old Models (Before 2007)	TRW MY 97 Airbag (2F-1)	✓	✓	✓	✓		
FIAT	STRADA	Old Models (Before 2007)	Trw MY 97 Airbag (2F-2L-1)	✓	✓	✓	✓		
FIAT	STRADA	Old Models (Before 2007)	Bosch 8 ABS	✓	✓	✓	✓		
FIAT	STRADA	Old Models (Before 2007)	Marelli Body Computer 2	✓	✓	✓	✓	✓	
FIAT	STRADA	Old Models (Before 2007)	Marelli Instrument Panel (Palio RST2)	✓	✓	✓	✓	✓	
FIAT	STRADA	Old Models (Before 2007)	TRW MY 97 Airbag (2F-1)	✓	✓	✓	✓		
FIAT	STRADA	Old Models (Before 2007)	Trw MY 97 Airbag (2F-2L-1)	✓	✓	✓	✓		
FIAT	STRADA	Old Models (Before 2007)	Magneti Marelli Injection IAW 4SF	✓	✓	✓	✓		
FIAT	STRADA	Old Models (Before 2007)	Bosch 8 ABS	✓	✓	✓	✓		
FIAT	STRADA	Old Models (Before 2007)	Marelli Body Computer 2	✓	✓	✓	✓	✓	
FIAT	STRADA	Old Models (Before 2007)	Marelli Instrument Panel (Palio RST2)	✓	✓	✓	✓	✓	
FIAT	STRADA	Old Models (Before 2007)	TRW MY 97 Airbag (2F-1)	✓	✓	✓	✓		
FIAT	STRADA	Old Models (Before 2007)	Trw MY 97 Airbag (2F-2L-1)	✓	✓	✓	✓		
FIAT	STRADA	Old Models (Before 2007)	Magneti Marelli IAW 59F 5SF8/5SF9 Tritec Injection	✓	✓	✓	✓		
FIAT	TALENTO	2016	ECM (Engine Control Module)	✓	✓	✓	✓	✓	
FIAT	TALENTO	2016	ABS (Anti-Lock Braking System)	✓	✓	✓	✓	✓	
FIAT	TALENTO	2016	SRS (Supplemental Inflatable Restraint System, ORC)	✓	✓	✓	✓	✓	
FIAT	TALENTO	2016	BCM (Body Control Module)	✓	✓	✓	✓		
FIAT	TALENTO	2016	IPC (Instrument Panel)	✓	✓	✓	✓		
FIAT	TALENTO	2016	PAM (Parking Aid Module)	✓	✓	✓	✓		
FIAT	TALENTO	2016	HFM (Hands Free Module (Cell Phone))	✓	✓	✓	✓		
FIAT	TALENTO	2016	AHM (Additional Heater Module)	✓	✓	✓	✓		
FIAT	TALENTO	2016	RADIO (RADIO)	✓	✓	✓	✓		
FIAT	TALENTO	2016	EPS (Electric Power Steering)	✓	✓	✓	✓		
FIAT	TALENTO	2016	Adaptive Module(ATA)	✓	✓	✓	✓		
FIAT	TALENTO	2016	HVAC (Heat, Ventilation And A/C)	✓	✓	✓	✓	✓	
FIAT	TALENTO	2016	Energy Management Module(EMM)	✓	✓	✓	✓		
FIAT	TALENTO	2016	Dose Control Unit(DCU)	✓	✓	✓	✓	✓	

FIAT	TORO	2022	ECM (Engine Control Module)	√	√	√	√	√	sp02352, sp02353, sp02354, sp02355, sp02356, sp02357
FIAT	TORO	2022	EPS (Electric Power Steering)	√	√	√	√		sp02358
FIAT	TORO	2022	TCM (Transmission Control Module)	√	√	√	√		
FIAT	TORO	2022	ABS (Anti Lock Brakes)	√	√	√	√	√	
FIAT	TORO	2022	TTM (Trailer Tow Module)	√	√	√	√	√	
FIAT	TORO	2022	RFH (Radio Frequency Hub)	√	√	√	√	√	sp02359, sp02360
FIAT	TORO	2022	RBSS (Right Blind Spot Sensor)	√	√	√	√	√	
FIAT	TORO	2022	PAM (Parking Aid Module)	√	√	√	√		sp02361, sp02362
FIAT	TORO	2022	ORC (Occupant Restraint)	√	√	√	√		
FIAT	TORO	2022	LBSS (Left Blind Spot Sensor)	√	√	√	√	√	
FIAT	TORO	2022	IPC (Instrument Panel Cluster)	√	√	√	√	√	sp02363
FIAT	TORO	2022	HVAC (Heat, Ventilation And A/C)	√	√	√	√	√	sp02364
FIAT	TORO	2022	HALF (Haptical Lane Feedback)	√	√	√	√		sp02365
FIAT	TORO	2022	ETM (Entertainment Telematic Module)	√	√	√	√	√	
FIAT	TORO	2022	ESM (Electronic Shifter Module)	√	√	√	√	√	sp02366, sp02367
FIAT	TORO	2022	DTCM (Drive Train Control Module)	√	√	√	√		
FIAT	TORO	2022	DMM (Doors Management Module)	√	√	√	√		sp02368, sp02369
FIAT	TORO	2022	BCM (Body Control Module)	√	√	√	√	√	√
FIAT	TORO	2022	AMP (Amplifier)	√	√	√	√	√	
FIAT	TORO	2021	ECM (Engine Control Module)	√	√	√	√	√	sp02377, sp02378, sp02379, sp02380, sp02381, sp02382
FIAT	TORO	2021	EPS (Electric Power Steering)	√	√	√	√		sp02383
FIAT	TORO	2021	TCM (Transmission Control Module)	√	√	√	√		
FIAT	TORO	2021	ABS (Anti Lock Brakes)	√	√	√	√	√	
FIAT	TORO	2021	TTM (Trailer Tow Module)	√	√	√	√	√	
FIAT	TORO	2021	RFH (Radio Frequency Hub)	√	√	√	√	√	sp02384, sp02385
FIAT	TORO	2021	RBSS (Right Blind Spot Sensor)	√	√	√	√	√	
FIAT	TORO	2021	PAM (Parking Aid Module)	√	√	√	√		sp02386, sp02387
FIAT	TORO	2021	ORC (Occupant Restraint)	√	√	√	√		
FIAT	TORO	2021	LBSS (Left Blind Spot Sensor)	√	√	√	√	√	
FIAT	TORO	2021	IPC (Instrument Panel Cluster)	√	√	√	√	√	sp02388
FIAT	TORO	2021	HVAC (Heat, Ventilation And A/C)	√	√	√	√	√	sp02389
FIAT	TORO	2021	HALF (Haptical Lane Feedback)	√	√	√	√		sp02390
FIAT	TORO	2021	ETM (Entertainment Telematic Module)	√	√	√	√	√	
FIAT	TORO	2021	ESM (Electronic Shifter Module)	√	√	√	√	√	sp02391, sp02392
FIAT	TORO	2021	DTCM (Drive Train Control Module)	√	√	√	√		
FIAT	TORO	2021	DMM (Doors Management Module)	√	√	√	√		sp02393, sp02394
FIAT	TORO	2021	BCM (Body Control Module)	√	√	√	√	√	√
FIAT	TORO	2021	AMP (Amplifier)	√	√	√	√	√	
FIAT	TORO	2020	ECM (Engine Control Module)	√	√	√	√	√	sp02402, sp02403, sp02404, sp02405, sp02406, sp02407
FIAT	TORO	2020	EPS (Electric Power Steering)	√	√	√	√		sp02408
FIAT	TORO	2020	TCM (Transmission Control Module)	√	√	√	√		
FIAT	TORO	2020	ABS (Anti Lock Brakes)	√	√	√	√	√	
FIAT	TORO	2020	TTM (Trailer Tow Module)	√	√	√	√	√	
FIAT	TORO	2020	RFH (Radio Frequency Hub)	√	√	√	√	√	sp02409, sp02410
FIAT	TORO	2020	RBSS (Right Blind Spot Sensor)	√	√	√	√	√	
FIAT	TORO	2020	PAM (Parking Aid Module)	√	√	√	√		sp02411, sp02412
FIAT	TORO	2020	ORC (Occupant Restraint)	√	√	√	√		
FIAT	TORO	2020	LBSS (Left Blind Spot Sensor)	√	√	√	√	√	
FIAT	TORO	2020	IPC (Instrument Panel Cluster)	√	√	√	√	√	sp02413
FIAT	TORO	2020	HVAC (Heat, Ventilation And A/C)	√	√	√	√	√	sp02414
FIAT	TORO	2020	HALF (Haptical Lane Feedback)	√	√	√	√		sp02415
FIAT	TORO	2020	ETM (Entertainment Telematic Module)	√	√	√	√	√	
FIAT	TORO	2020	ESM (Electronic Shifter Module)	√	√	√	√	√	sp02416, sp02417
FIAT	TORO	2020	DTCM (Drive Train Control Module)	√	√	√	√		
FIAT	TORO	2020	DMM (Doors Management Module)	√	√	√	√		sp02418, sp02419
FIAT	TORO	2020	BCM (Body Control Module)	√	√	√	√	√	√
FIAT	TORO	2020	AMP (Amplifier)	√	√	√	√	√	
FIAT	TORO	2019	ECM (Engine Control Module)	√	√	√	√	√	sp02427, sp02428, sp02429, sp02430, sp02431, sp02432
FIAT	TORO	2019	EPS (Electric Power Steering)	√	√	√	√		sp02433
FIAT	TORO	2019	TCM (Transmission Control Module)	√	√	√	√		
FIAT	TORO	2019	ABS (Anti Lock Brakes)	√	√	√	√	√	

FIAT	TORO	2019	TTM (Trailer Tow Module)	✓	✓	✓	✓	✓	
FIAT	TORO	2019	RFH (Radio Frequency Hub)	✓	✓	✓	✓	✓	sp02434, sp02435
FIAT	TORO	2019	RBSS (Right Blind Spot Sensor)	✓	✓	✓	✓	✓	
FIAT	TORO	2019	PAM (Parking Aid Module)	✓	✓	✓	✓	✓	sp02436, sp02437
FIAT	TORO	2019	ORC (Occupant Restraint)	✓	✓	✓	✓	✓	
FIAT	TORO	2019	LBSS (Left Blind Spot Sensor)	✓	✓	✓	✓	✓	
FIAT	TORO	2019	IPC (Instrument Panel Cluster)	✓	✓	✓	✓	✓	sp02438
FIAT	TORO	2019	HVAC (Heat, Ventilation And A/C)	✓	✓	✓	✓	✓	sp02439
FIAT	TORO	2019	HALF (Haptical Lane Feedback)	✓	✓	✓	✓	✓	sp02440
FIAT	TORO	2019	ETM (Entertainment Telematic Module)	✓	✓	✓	✓	✓	
FIAT	TORO	2019	ESM (Electronic Shifter Module)	✓	✓	✓	✓	✓	sp02441, sp02442
FIAT	TORO	2019	DTCM (Drive Train Control Module)	✓	✓	✓	✓	✓	
FIAT	TORO	2019	DMM (Doors Management Module)	✓	✓	✓	✓	✓	sp02443, sp02444
FIAT	TORO	2019	BCM (Body Control Module)	✓	✓	✓	✓	✓	✓
FIAT	TORO	2019	AMP (Amplifier)	✓	✓	✓	✓	✓	
FIAT	TORO	2018	ECM (Engine Control Module)	✓	✓	✓	✓	✓	sp02452, sp02453, sp02454, sp02455, sp02456, sp02457
FIAT	TORO	2018	EPS (Electric Power Steering)	✓	✓	✓	✓	✓	sp02458
FIAT	TORO	2018	TCM (Transmission Control Module)	✓	✓	✓	✓	✓	
FIAT	TORO	2018	ABS (Anti Lock Brakes)	✓	✓	✓	✓	✓	
FIAT	TORO	2018	TTM (Trailer Tow Module)	✓	✓	✓	✓	✓	
FIAT	TORO	2018	RFH (Radio Frequency Hub)	✓	✓	✓	✓	✓	sp02459, sp02460
FIAT	TORO	2018	RBSS (Right Blind Spot Sensor)	✓	✓	✓	✓	✓	
FIAT	TORO	2018	PAM (Parking Aid Module)	✓	✓	✓	✓	✓	sp02461, sp02462
FIAT	TORO	2018	ORC (Occupant Restraint)	✓	✓	✓	✓	✓	
FIAT	TORO	2018	LBSS (Left Blind Spot Sensor)	✓	✓	✓	✓	✓	
FIAT	TORO	2018	IPC (Instrument Panel Cluster)	✓	✓	✓	✓	✓	sp02463
FIAT	TORO	2018	HVAC (Heat, Ventilation And A/C)	✓	✓	✓	✓	✓	sp02464
FIAT	TORO	2018	HALF (Haptical Lane Feedback)	✓	✓	✓	✓	✓	sp02465
FIAT	TORO	2018	ETM (Entertainment Telematic Module)	✓	✓	✓	✓	✓	
FIAT	TORO	2018	ESM (Electronic Shifter Module)	✓	✓	✓	✓	✓	sp02466, sp02467
FIAT	TORO	2018	DTCM (Drive Train Control Module)	✓	✓	✓	✓	✓	
FIAT	TORO	2018	DMM (Doors Management Module)	✓	✓	✓	✓	✓	sp02468, sp02469
FIAT	TORO	2018	BCM (Body Control Module)	✓	✓	✓	✓	✓	✓
FIAT	TORO	2018	AMP (Amplifier)	✓	✓	✓	✓	✓	
FIAT	TORO	2017	ECM (Engine Control Module)	✓	✓	✓	✓	✓	sp02477, sp02478, sp02479, sp02480, sp02481, sp02482
FIAT	TORO	2017	EPS (Electric Power Steering)	✓	✓	✓	✓	✓	sp02483
FIAT	TORO	2017	TCM (Transmission Control Module)	✓	✓	✓	✓	✓	
FIAT	TORO	2017	ABS (Anti Lock Brakes)	✓	✓	✓	✓	✓	
FIAT	TORO	2017	TTM (Trailer Tow Module)	✓	✓	✓	✓	✓	
FIAT	TORO	2017	RFH (Radio Frequency Hub)	✓	✓	✓	✓	✓	sp02484, sp02485
FIAT	TORO	2017	RBSS (Right Blind Spot Sensor)	✓	✓	✓	✓	✓	
FIAT	TORO	2017	PAM (Parking Aid Module)	✓	✓	✓	✓	✓	sp02486, sp02487
FIAT	TORO	2017	ORC (Occupant Restraint)	✓	✓	✓	✓	✓	
FIAT	TORO	2017	LBSS (Left Blind Spot Sensor)	✓	✓	✓	✓	✓	
FIAT	TORO	2017	IPC (Instrument Panel Cluster)	✓	✓	✓	✓	✓	sp02488
FIAT	TORO	2017	HVAC (Heat, Ventilation And A/C)	✓	✓	✓	✓	✓	sp02489
FIAT	TORO	2017	HALF (Haptical Lane Feedback)	✓	✓	✓	✓	✓	sp02490
FIAT	TORO	2017	ETM (Entertainment Telematic Module)	✓	✓	✓	✓	✓	
FIAT	TORO	2017	ESM (Electronic Shifter Module)	✓	✓	✓	✓	✓	sp02491, sp02492
FIAT	TORO	2017	DTCM (Drive Train Control Module)	✓	✓	✓	✓	✓	
FIAT	TORO	2017	DMM (Doors Management Module)	✓	✓	✓	✓	✓	sp02493, sp02494
FIAT	TORO	2017	BCM (Body Control Module)	✓	✓	✓	✓	✓	✓
FIAT	TORO	2017	AMP (Amplifier)	✓	✓	✓	✓	✓	
FIAT	TORO	2016	ECM (Engine Control Module)	✓	✓	✓	✓	✓	sp02502, sp02503, sp02504, sp02505, sp02506, sp02507
FIAT	TORO	2016	TCM (Transmission Control Module)	✓	✓	✓	✓	✓	sp02508, sp02509
FIAT	TORO	2016	ABS (Anti-Lock Braking System)	✓	✓	✓	✓	✓	
FIAT	TORO	2016	SRS (Supplemental Inflatable Restraint System, ORC)	✓	✓	✓	✓	✓	
FIAT	TORO	2016	BCM (Body Control Module)	✓	✓	✓	✓	✓	sp02510, sp02511, sp02512, sp02513, sp02514
FIAT	TORO	2016	IC (Instrument Cluster)	✓	✓	✓	✓	✓	sp02515

FIAT	TORO	2016	TTM (Trailer Tow Module)	✓	✓	✓	✓	✓	
FIAT	TORO	2016	ETM (Entertainment Telematic Module)	✓	✓	✓	✓	✓	
FIAT	TORO	2016	RFH (Radio Frequency Hub)	✓	✓	✓	✓	✓	sp02516, sp02517
FIAT	TORO	2016	HALF (Haptical Lane Feedback)	✓	✓	✓	✓	✓	sp02518
FIAT	TORO	2016	DMM (Doors Management Module)	✓	✓	✓	✓	✓	sp02519, sp02520
FIAT	TORO	2016	LBSS (Left Blind Spot Sensor)	✓	✓	✓	✓	✓	
FIAT	TORO	2016	EPS (Electric Power Steering)	✓	✓	✓	✓	✓	sp02521
FIAT	TORO	2016	DTCM (Drive Train Control Module)	✓	✓	✓	✓	✓	
FIAT	TORO	2016	PAM (Parking Assistant Module)	✓	✓	✓	✓	✓	sp02522, sp02523
FIAT	TORO	2016	AMP (Amplifier)	✓	✓	✓	✓	✓	
FIAT	TORO	2016	HVAC (Heating Ventilation Air-Conditioning And Cooling)	✓	✓	✓	✓	✓	sp02524
FIAT	TORO	2016	RBSS (Right Blind Spot Sensor)	✓	✓	✓	✓	✓	
FIAT	TORO	2016	ESM (Electronic Shifter Module)	✓	✓	✓	✓	✓	sp02525, sp02526
FIAT	ULYSSE	'00 2.0 16V	Magneti Marelli MM4.8P PSA Injection	✓	✓	✓	✓	✓	
FIAT	ULYSSE	'00 2.0 JTD	Bosch EDC15 PSA Diesel Injection (Eng. 2.0 8V)	✓	✓	✓	✓	✓	
FIAT	ULYSSE	'00 2.0 JTD	Bosch EDC15 PSA Diesel Injection (2.0 8V V60 Eng.)	✓	✓	✓	✓	✓	
FIAT	ULYSSE	'00 2.0 JTD	Bosch EDC15 PSA Diesel Injection (Eng. 16V)	✓	✓	✓	✓	✓	
FIAT	ULYSSE	'00 2.0 JTD	WEBASTO Heater (PSA)	✓	✓	✓	✓	✓	
FIAT	ULYSSE	'98 2.0 16V	Bosch Motronic MP7.3 Injection	✓	✓	✓	✓	✓	
FIAT	ULYSSE '02	2.0 16V	Magneti Marelli MM4MP2 PSA Injection	✓	✓	✓	✓	✓	
FIAT	ULYSSE '02	2.0 16V	Magneti Marelli MM6LP PSA Injection	✓	✓	✓	✓	✓	
FIAT	ULYSSE '02	2.0 16V	Siemens AL4 TA2000 V PSA Automatic Gearbox	✓	✓	✓	✓	✓	
FIAT	ULYSSE '02	2.0 16V	Marelli DAV PSA Connect Control	✓	✓	✓	✓	✓	
FIAT	ULYSSE '02	2.0 16V	Marelli Odometer W. Lamps (BTO)	✓	✓	✓	✓	✓	
FIAT	ULYSSE '02	2.0 16V	Marelli PSA Connect	✓	✓	✓	✓	✓	
FIAT	ULYSSE '02	2.0 16V	Marelli PSA Instrument Panel	✓	✓	✓	✓	✓	
FIAT	ULYSSE '02	2.0 16V	Sagem Multi-Function Screen	✓	✓	✓	✓	✓	
FIAT	ULYSSE '02	2.0 16V	Bosch 5.7 ESP PSA ABS	✓	✓	✓	✓	✓	
FIAT	ULYSSE '02	2.0 16V	Bitron PSA Driver's Seat	✓	✓	✓	✓	✓	
FIAT	ULYSSE '02	2.0 16V	Clarion CD Changer	✓	✓	✓	✓	✓	
FIAT	ULYSSE '02	2.0 16V	Clarion/Philips Sound System	✓	✓	✓	✓	✓	
FIAT	ULYSSE '02	2.0 16V	Marelli PSA Climate Control	✓	✓	✓	✓	✓	
FIAT	ULYSSE '02	2.0 16V	Eaton Multi-Switch Stalk Unit (COM2000)	✓	✓	✓	✓	✓	
FIAT	ULYSSE '02	2.0 16V	Inalfa Central Sunroof	✓	✓	✓	✓	✓	
FIAT	ULYSSE '02	2.0 16V	Inalfa Front Sunroof	✓	✓	✓	✓	✓	
FIAT	ULYSSE '02	2.0 16V	Inalfa Rear Sunroof	✓	✓	✓	✓	✓	
FIAT	ULYSSE '02	2.0 16V	Marelli PSA Driver's Door	✓	✓	✓	✓	✓	
FIAT	ULYSSE '02	2.0 16V	Marelli PSA Passenger's Door	✓	✓	✓	✓	✓	
FIAT	ULYSSE '02	2.0 16V	Valeo PSA Parking Control Unit	✓	✓	✓	✓	✓	
FIAT	ULYSSE '02	2.0 16V	Valeo PSA Discharge Headlamp (LH)	✓	✓	✓	✓	✓	
FIAT	ULYSSE '02	2.0 16V	Valeo PSA Discharge Headlamp (RH)	✓	✓	✓	✓	✓	
FIAT	ULYSSE '02	2.0 16V	Texton Sliding Doors	✓	✓	✓	✓	✓	
FIAT	ULYSSE '02	2.0 JTD 16V	Bosch EDC15 PSA Diesel Injection (Eng. 16V)	✓	✓	✓	✓	✓	
FIAT	ULYSSE '02	2.0 JTD 16V	Siemens AL4 TA2000 V PSA Automatic Gearbox	✓	✓	✓	✓	✓	
FIAT	ULYSSE '02	2.0 JTD 16V	Marelli DAV PSA Connect Control	✓	✓	✓	✓	✓	

## Special Functions List

No.	Functions Name	System Name
sp00001	Air-Conditioning Self Learning	PCM (Powertrain Control Module)
sp00002	Reset Accelerator Pedal Adaptives	PCM (Powertrain Control Module)
sp00003	Brake Switch Learn	PCM (Powertrain Control Module)
sp00004	Clutch Pedal Learn	PCM (Powertrain Control Module)
sp00005	Check PCM Odometer	PCM (Powertrain Control Module)
sp00006	Emissions Rolls Test Mode	PCM (Powertrain Control Module)
sp00007	Air-Conditioning Self Learning	PCM (Powertrain Control Module)
sp00008	Reset ECU	PCM (Powertrain Control Module)
sp00009	Reset Memory	PCM (Powertrain Control Module)
sp00010	Reset Memory	PCM (Powertrain Control Module)
sp00011	ECU Replacement With Value Transfer	TCM (Transmission Control Module)
sp00012	Bleed Hydraulic Circuit	TCM (Transmission Control Module)
sp00013	Hydraulic Circuit Depressurization	TCM (Transmission Control Module)
sp00014	Learn Clutches Contact Point	TCM (Transmission Control Module)
sp00015	Quick Learn	TCM (Transmission Control Module)
sp00016	ABS Static Test	ABS (Anti-Lock Braking System)
sp00017	Longitudinal G-Sensor Calibration Test	ABS (Anti-Lock Braking System)
sp00018	Exit Shipping Mode	BCM (Body Control Module)
sp00019	Self Learning Motor Test	HVAC (Heating Ventilation Air-Conditioning And Cooling)
sp00020	IPC Enable Seatbelt Minder Chime	IC (Instrument Cluster)
sp00021	Reset Service Information	IC (Instrument Cluster)
sp00022	IPC Disable Seatbelt Minder Chime	IC (Instrument Cluster)
sp00023	IPC Replacement	IC (Instrument Cluster)
sp00024	RADIO Proxi Configuration	RFH (Radio Frequency Hub)
sp00025	Clear Steering Pull Compensation	EPS (Electric Power Steering)
sp00026	Initialize EPS	EPS (Electric Power Steering)
sp00027	CTM Proxi Configuration	CTM (Convergence Telematic Module)
sp00028	Clear TPM Warnings	TPMS (Tire Pressure Monitoring System)
sp00029	Clear TPM Sensor Rolls Test Results	TPMS (Tire Pressure Monitoring System)
sp00030	TPM FGA Proxi Configuration	TPMS (Tire Pressure Monitoring System)
sp00031	Update Front And Rear Axle Nominal Tire Pressure Values	TPMS (Tire Pressure Monitoring System)
sp00032	Program Left Front Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp00033	Program Left Rear Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp00034	Program Right Front Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp00035	Program Right Rear Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp00036	TPM Sensor Rolls Test	TPMS (Tire Pressure Monitoring System)
sp00037	Air-Conditioning Self Learning	PCM (Powertrain Control Module)
sp00038	Reset Accelerator Pedal Adaptives	PCM (Powertrain Control Module)
sp00039	Brake Switch Learn	PCM (Powertrain Control Module)
sp00040	Clutch Pedal Learn	PCM (Powertrain Control Module)
sp00041	Check PCM Odometer	PCM (Powertrain Control Module)
sp00042	Emissions Rolls Test Mode	PCM (Powertrain Control Module)
sp00043	Air-Conditioning Self Learning	PCM (Powertrain Control Module)
sp00044	Reset ECU	PCM (Powertrain Control Module)
sp00045	Reset Memory	PCM (Powertrain Control Module)
sp00046	Reset Memory	PCM (Powertrain Control Module)

sp00047	ECU Replacement With Value Transfer	TCM (Transmission Control Module)
sp00048	Bleed Hydraulic Circuit	TCM (Transmission Control Module)
sp00049	Hydraulic Circuit Depressurization	TCM (Transmission Control Module)
sp00050	Learn Clutches Contact Point	TCM (Transmission Control Module)
sp00051	Quick Learn	TCM (Transmission Control Module)
sp00052	ABS Static Test	ABS (Anti-Lock Braking System)
sp00053	Longitudinal G-Sensor Calibration Test	ABS (Anti-Lock Braking System)
sp00054	Exit Shipping Mode	BCM (Body Control Module)
sp00055	Self Learning Motor Test	HVAC (Heating Ventilation Air-Conditioning And Cooling)
sp00056	IPC Enable Seatbelt Minder Chime	IC (Instrument Cluster)
sp00057	Reset Service Information	IC (Instrument Cluster)
sp00058	IPC Disable Seatbelt Minder Chime	IC (Instrument Cluster)
sp00059	IPC Replacement	IC (Instrument Cluster)
sp00060	RADIO Proxi Configuration	RFH (Radio Frequency Hub)
sp00061	Clear Steering Pull Compensation	EPS (Electric Power Steering)
sp00062	Initialize EPS	EPS (Electric Power Steering)
sp00063	CTM Proxi Configuration	CTM (Convergence Telematic Module)
sp00064	Clear TPM Warnings	TPMS (Tire Pressure Monitoring System)
sp00065	Clear TPM Sensor Rolls Test Results	TPMS (Tire Pressure Monitoring System)
sp00066	TPM FGA Proxi Configuration	TPMS (Tire Pressure Monitoring System)
sp00067	Update Front And Rear Axle Nominal Tire Pressure Values	TPMS (Tire Pressure Monitoring System)
sp00068	Program Left Front Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp00069	Program Left Rear Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp00070	Program Right Front Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp00071	Program Right Rear Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp00072	TPM Sensor Rolls Test	TPMS (Tire Pressure Monitoring System)
sp00073	Air-Conditioning Self Learning	PCM (Powertrain Control Module)
sp00074	Reset Accelerator Pedal Adaptives	PCM (Powertrain Control Module)
sp00075	Brake Switch Learn	PCM (Powertrain Control Module)
sp00076	Clutch Pedal Learn	PCM (Powertrain Control Module)
sp00077	Check PCM Odometer	PCM (Powertrain Control Module)
sp00078	Emissions Rolls Test Mode	PCM (Powertrain Control Module)
sp00079	Air-Conditioning Self Learning	PCM (Powertrain Control Module)
sp00080	Reset ECU	PCM (Powertrain Control Module)
sp00081	Reset Memory	PCM (Powertrain Control Module)
sp00082	Reset Memory	PCM (Powertrain Control Module)
sp00083	ECU Replacement With Value Transfer	TCM (Transmission Control Module)
sp00084	Bleed Hydraulic Circuit	TCM (Transmission Control Module)
sp00085	Hydraulic Circuit Depressurization	TCM (Transmission Control Module)
sp00086	Learn Clutches Contact Point	TCM (Transmission Control Module)
sp00087	Quick Learn	TCM (Transmission Control Module)
sp00088	ABS Static Test	ABS (Anti-Lock Braking System)
sp00089	Longitudinal G-Sensor Calibration Test	ABS (Anti-Lock Braking System)
sp00090	Exit Shipping Mode	BCM (Body Control Module)
sp00091	Self Learning Motor Test	HVAC (Heating Ventilation Air-Conditioning And Cooling)
sp00092	IPC Enable Seatbelt Minder Chime	IC (Instrument Cluster)
sp00093	Reset Service Information	IC (Instrument Cluster)
sp00094	IPC Disable Seatbelt Minder Chime	IC (Instrument Cluster)
sp00095	IPC Replacement	IC (Instrument Cluster)
sp00096	RADIO Proxi Configuration	RFH (Radio Frequency Hub)
sp00097	Clear Steering Pull Compensation	EPS (Electric Power Steering)
sp00098	Initialize EPS	EPS (Electric Power Steering)

sp00099	CTM Proxi Configuration	CTM (Convergence Telematic Module)
sp00100	Clear TPM Warnings	TPMS (Tire Pressure Monitoring System)
sp00101	Clear TPM Sensor Rolls Test Results	TPMS (Tire Pressure Monitoring System)
sp00102	TPM FGA Proxi Configuration	TPMS (Tire Pressure Monitoring System)
sp00103	Update Front And Rear Axle Nominal Tire Pressure Values	TPMS (Tire Pressure Monitoring System)
sp00104	Program Left Front Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp00105	Program Left Rear Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp00106	Program Right Front Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp00107	Program Right Rear Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp00108	TPM Sensor Rolls Test	TPMS (Tire Pressure Monitoring System)
sp00109	Air-Conditioning Self Learning	PCM (Powertrain Control Module)
sp00110	Reset Accelerator Pedal Adaptives	PCM (Powertrain Control Module)
sp00111	Brake Switch Learn	PCM (Powertrain Control Module)
sp00112	Clutch Pedal Learn	PCM (Powertrain Control Module)
sp00113	Check PCM Odometer	PCM (Powertrain Control Module)
sp00114	Emissions Rolls Test Mode	PCM (Powertrain Control Module)
sp00115	Air-Conditioning Self Learning	PCM (Powertrain Control Module)
sp00116	Reset ECU	PCM (Powertrain Control Module)
sp00117	Reset Memory	PCM (Powertrain Control Module)
sp00118	Reset Memory	PCM (Powertrain Control Module)
sp00119	ECU Replacement With Value Transfer	TCM (Transmission Control Module)
sp00120	Bleed Hydraulic Circuit	TCM (Transmission Control Module)
sp00121	Hydraulic Circuit Depressurization	TCM (Transmission Control Module)
sp00122	Learn Clutches Contact Point	TCM (Transmission Control Module)
sp00123	Quick Learn	TCM (Transmission Control Module)
sp00124	ABS Static Test	ABS (Anti-Lock Braking System)
sp00125	Longitudinal G-Sensor Calibration Test	ABS (Anti-Lock Braking System)
sp00126	Exit Shipping Mode	BCM (Body Control Module)
sp00127	Self Learning Motor Test	HVAC (Heating Ventilation Air-Conditioning And Cooling)
sp00128	IPC Enable Seatbelt Minder Chime	IC (Instrument Cluster)
sp00129	Reset Service Information	IC (Instrument Cluster)
sp00130	IPC Disable Seatbelt Minder Chime	IC (Instrument Cluster)
sp00131	IPC Replacement	IC (Instrument Cluster)
sp00132	RADIO Proxi Configuration	RFH (Radio Frequency Hub)
sp00133	Clear Steering Pull Compensation	EPS (Electric Power Steering)
sp00134	Initialize EPS	EPS (Electric Power Steering)
sp00135	CTM Proxi Configuration	CTM (Convergence Telematic Module)
sp00136	Clear TPM Warnings	TPMS (Tire Pressure Monitoring System)
sp00137	Clear TPM Sensor Rolls Test Results	TPMS (Tire Pressure Monitoring System)
sp00138	TPM FGA Proxi Configuration	TPMS (Tire Pressure Monitoring System)
sp00139	Update Front And Rear Axle Nominal Tire Pressure Values	TPMS (Tire Pressure Monitoring System)
sp00140	Program Left Front Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp00141	Program Left Rear Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp00142	Program Right Front Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp00143	Program Right Rear Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp00144	TPM Sensor Rolls Test	TPMS (Tire Pressure Monitoring System)
sp00145	Reset Accelerator Pedal Adaptives	PCM (Powertrain Control Module)
sp00146	Brake Switch Learn	PCM (Powertrain Control Module)
sp00147	Clutch Pedal Learn	PCM (Powertrain Control Module)
sp00148	Air-Conditioning Self Learning	PCM (Powertrain Control Module)
sp00149	Throttle Body Self Learning	PCM (Powertrain Control Module)
sp00150	Reset ECU	PCM (Powertrain Control Module)



sp00151	Reset Learn Flag Wheel Tooth	PCM (Powertrain Control Module)
sp00152	Differential Pressure Sensor Replac.	PCM (Powertrain Control Module)
sp00153	ECU Replacement With Value Transfer	TCM (Transmission Control Module)
sp00154	Bleed Hydraulic Circuit	TCM (Transmission Control Module)
sp00155	Hydraulic Circuit Depressurization	TCM (Transmission Control Module)
sp00156	Learn Clutches Contact Point	TCM (Transmission Control Module)
sp00157	Quick Learn	TCM (Transmission Control Module)
sp00158	ABS Static Test	ABS (Anti-Lock Braking System)
sp00159	Longitudinal G-Sensor Calibration Test	ABS (Anti-Lock Braking System)
sp00160	Clear TPM Warnings	TPMS (Tire Pressure Monitoring System)
sp00161	Clear TPM Sensor Rolls Test Results	TPMS (Tire Pressure Monitoring System)
sp00162	TPM FGA Proxi Configuration	TPMS (Tire Pressure Monitoring System)
sp00163	Update Front And Rear Axle Nominal Tire Pressure Values	TPMS (Tire Pressure Monitoring System)
sp00164	Program Left Front Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp00165	Program Left Rear Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp00166	Program Right Front Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp00167	Program Right Rear Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp00168	TPM Sensor Rolls Test	TPMS (Tire Pressure Monitoring System)
sp00169	RADIO Proxi Configuration	RADIO (RADIO)
sp00170	IPC Enable Seatbelt Minder Chime	IC (Instrument Cluster)
sp00171	Reset Service Information	IC (Instrument Cluster)
sp00172	IPC Disable Seatbelt Minder Chime	IC (Instrument Cluster)
sp00173	IPC Replacement	IC (Instrument Cluster)
sp00174	Self Learning Motor Test	HVAC (Heating Ventilation Air-Conditioning And Cooling)
sp00175	Clear Steering Pull Compensation	EPS (Electric Power Steering)
sp00176	Initialize EPS	EPS (Electric Power Steering)
sp00177	CTM Proxi Configuration	CTM (Convergence Telematic Module)
sp00178	Exit Shipping Mode	BCM (Body Control Module)
sp00179	ECU Replacement With Value Transfer	TCM (Transmission Control Module)
sp00180	Bleed Hydraulic Circuit	TCM (Transmission Control Module)
sp00181	Hydraulic Circuit Depressurization	TCM (Transmission Control Module)
sp00182	Learn Clutches Contact Point	TCM (Transmission Control Module)
sp00183	Quick Learn	TCM (Transmission Control Module)
sp00184	ABS Static Test	ABS (Anti-Lock Braking System)
sp00185	Longitudinal G-Sensor Calibration Test	ABS (Anti-Lock Braking System)
sp00186	Clear TPM Warnings	TPMS (Tire Pressure Monitoring System)
sp00187	Clear TPM Sensor Rolls Test Results	TPMS (Tire Pressure Monitoring System)
sp00188	TPM FGA Proxi Configuration	TPMS (Tire Pressure Monitoring System)
sp00189	Update Front And Rear Axle Nominal Tire Pressure Values	TPMS (Tire Pressure Monitoring System)
sp00190	Program Left Front Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp00191	Program Left Rear Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp00192	Program Right Front Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp00193	Program Right Rear Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp00194	TPM Sensor Rolls Test	TPMS (Tire Pressure Monitoring System)
sp00195	RADIO Proxi Configuration	RADIO (RADIO)
sp00196	IPC Enable Seatbelt Minder Chime	IC (Instrument Cluster)
sp00197	Reset Service Information	IC (Instrument Cluster)
sp00198	IPC Disable Seatbelt Minder Chime	IC (Instrument Cluster)
sp00199	IPC Replacement	IC (Instrument Cluster)
sp00200	Self Learning Motor Test	HVAC (Heating Ventilation Air-Conditioning And Cooling)
sp00201	Clear Steering Pull Compensation	EPS (Electric Power Steering)
sp00202	Initialize EPS	EPS (Electric Power Steering)

sp00203	CTM Proxi Configuration	CTM (Convergence Telematic Module)
sp00204	Exit Shipping Mode	BCM (Body Control Module)
sp00205	Reset Accelerator Pedal Adaptives	PCM (Powertrain Control Module)
sp00206	Brake Switch Learn	PCM (Powertrain Control Module)
sp00207	Clutch Pedal Learn	PCM (Powertrain Control Module)
sp00208	Check PCM Odometer	PCM (Powertrain Control Module)
sp00209	Emissions Rolls Test Mode	PCM (Powertrain Control Module)
sp00210	Clear Misfire TLC	PCM (Powertrain Control Module)
sp00211	Air-Conditioning Self Learning	PCM (Powertrain Control Module)
sp00212	Throttle Body Self Learning	PCM (Powertrain Control Module)
sp00213	Reset ECU	PCM (Powertrain Control Module)
sp00214	Reset Memory	PCM (Powertrain Control Module)
sp00215	ECU Replacement With Value Transfer	TCM (Transmission Control Module)
sp00216	Bleed Hydraulic Circuit	TCM (Transmission Control Module)
sp00217	Hydraulic Circuit Depressurization	TCM (Transmission Control Module)
sp00218	Learn Clutches Contact Point	TCM (Transmission Control Module)
sp00219	Quick Learn	TCM (Transmission Control Module)
sp00220	ABS Static Test	ABS (Anti-Lock Braking System)
sp00221	Longitudinal G-Sensor Calibration Test	ABS (Anti-Lock Braking System)
sp00222	Clear TPM Warnings	TPMS (Tire Pressure Monitoring System)
sp00223	Clear TPM Sensor Rolls Test Results	TPMS (Tire Pressure Monitoring System)
sp00224	TPM FGA Proxi Configuration	TPMS (Tire Pressure Monitoring System)
sp00225	Update Front And Rear Axle Nominal Tire Pressure Values	TPMS (Tire Pressure Monitoring System)
sp00226	Program Left Front Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp00227	Program Left Rear Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp00228	Program Right Front Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp00229	Program Right Rear Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp00230	TPM Sensor Rolls Test	TPMS (Tire Pressure Monitoring System)
sp00231	RADIO Proxi Configuration	RADIO (RADIO)
sp00232	IPC Enable Seatbelt Minder Chime	IC (Instrument Cluster)
sp00233	Reset Service Information	IC (Instrument Cluster)
sp00234	IPC Disable Seatbelt Minder Chime	IC (Instrument Cluster)
sp00235	IPC Replacement	IC (Instrument Cluster)
sp00236	Self Learning Motor Test	HVAC (Heating Ventilation Air-Conditioning And Cooling)
sp00237	Clear Steering Pull Compensation	EPS (Electric Power Steering)
sp00238	Initialize EPS	EPS (Electric Power Steering)
sp00239	CTM Proxi Configuration	CTM (Convergence Telematic Module)
sp00240	Exit Shipping Mode	BCM (Body Control Module)
sp00241	Reset Accelerator Pedal Adaptives	PCM (Powertrain Control Module)
sp00242	Brake Switch Learn	PCM (Powertrain Control Module)
sp00243	Clutch Pedal Learn	PCM (Powertrain Control Module)
sp00244	Check PCM Odometer	PCM (Powertrain Control Module)
sp00245	Emissions Rolls Test Mode	PCM (Powertrain Control Module)
sp00246	Clear Misfire TLC	PCM (Powertrain Control Module)
sp00247	Air-Conditioning Self Learning	PCM (Powertrain Control Module)
sp00248	Throttle Body Self Learning	PCM (Powertrain Control Module)
sp00249	Reset ECU	PCM (Powertrain Control Module)
sp00250	Reset Memory	PCM (Powertrain Control Module)
sp00251	ECU Replacement With Value Transfer	TCM (Transmission Control Module)
sp00252	Bleed Hydraulic Circuit	TCM (Transmission Control Module)
sp00253	Hydraulic Circuit Depressurization	TCM (Transmission Control Module)
sp00254	Learn Clutches Contact Point	TCM (Transmission Control Module)

sp00255	Quick Learn	TCM (Transmission Control Module)
sp00256	ABS Static Test	ABS (Anti-Lock Braking System)
sp00257	Longitudinal G-Sensor Calibration Test	ABS (Anti-Lock Braking System)
sp00258	Clear TPM Warnings	TPMS (Tire Pressure Monitoring System)
sp00259	Clear TPM Sensor Rolls Test Results	TPMS (Tire Pressure Monitoring System)
sp00260	TPM FGA Proxi Configuration	TPMS (Tire Pressure Monitoring System)
sp00261	Update Front And Rear Axle Nominal Tire Pressure Values	TPMS (Tire Pressure Monitoring System)
sp00262	Program Left Front Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp00263	Program Left Rear Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp00264	Program Right Front Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp00265	Program Right Rear Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp00266	TPM Sensor Rolls Test	TPMS (Tire Pressure Monitoring System)
sp00267	RADIO Proxi Configuration	RADIO (RADIO)
sp00268	IPC Enable Seatbelt Minder Chime	IC (Instrument Cluster)
sp00269	Reset Service Information	IC (Instrument Cluster)
sp00270	IPC Disable Seatbelt Minder Chime	IC (Instrument Cluster)
sp00271	IPC Replacement	IC (Instrument Cluster)
sp00272	Self Learning Motor Test	HVAC (Heating Ventilation Air-Conditioning And Cooling)
sp00273	Clear Steering Pull Compensation	EPS (Electric Power Steering)
sp00274	Initialize EPS	EPS (Electric Power Steering)
sp00275	CTM Proxi Configuration	CTM (Convergence Telematic Module)
sp00276	Exit Shipping Mode	BCM (Body Control Module)
sp00277	Exit Shipping Mode	BCM (Body Control Module)
sp00278	IPC Enable Seatbelt Minder Chime	IC (Instrument Cluster)
sp00279	Reset Service Information	IC (Instrument Cluster)
sp00280	IPC Disable Seatbelt Minder Chime	IC (Instrument Cluster)
sp00281	IPC Replacement	IC (Instrument Cluster)
sp00282	Self Learning Motor Test	HVAC (Heating Ventilation Air-Conditioning And Cooling)
sp00283	ABS Static Test	ABS (Anti-Lock Braking System)
sp00284	Longitudinal G-Sensor Calibration Test	ABS (Anti-Lock Braking System)
sp00285	Clear TPM Warnings	TPMS (Tire Pressure Monitoring System)
sp00286	Clear TPM Sensor Rolls Test Results	TPMS (Tire Pressure Monitoring System)
sp00287	TPM FGA Proxi Configuration	TPMS (Tire Pressure Monitoring System)
sp00288	Update Front And Rear Axle Nominal Tire Pressure Values	TPMS (Tire Pressure Monitoring System)
sp00289	Program Left Front Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp00290	Program Left Rear Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp00291	Program Right Front Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp00292	Program Right Rear Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp00293	TPM Sensor Rolls Test	TPMS (Tire Pressure Monitoring System)
sp00294	CTM Proxi Configuration	CTM (Convergence Telematic Module)
sp00295	Clear Steering Pull Compensation	EPS (Electric Power Steering)
sp00296	Initialize EPS	EPS (Electric Power Steering)
sp00297	RADIO Proxi Configuration	RFH (Radio Frequency Hub)
sp00298	Exit Shipping Mode	BCM (Body Control Module)
sp00299	IPC Enable Seatbelt Minder Chime	IC (Instrument Cluster)
sp00300	Reset Service Information	IC (Instrument Cluster)
sp00301	IPC Disable Seatbelt Minder Chime	IC (Instrument Cluster)
sp00302	IPC Replacement	IC (Instrument Cluster)
sp00303	Self Learning Motor Test	HVAC (Heating Ventilation Air-Conditioning And Cooling)
sp00304	ABS Static Test	ABS (Anti-Lock Braking System)
sp00305	Longitudinal G-Sensor Calibration Test	ABS (Anti-Lock Braking System)
sp00306	Clear TPM Warnings	TPMS (Tire Pressure Monitoring System)

sp00307	Clear TPM Sensor Rolls Test Results	TPMS (Tire Pressure Monitoring System)
sp00308	TPM FGA Proxi Configuration	TPMS (Tire Pressure Monitoring System)
sp00309	Update Front And Rear Axle Nominal Tire Pressure Values	TPMS (Tire Pressure Monitoring System)
sp00310	Program Left Front Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp00311	Program Left Rear Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp00312	Program Right Front Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp00313	Program Right Rear Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp00314	TPM Sensor Rolls Test	TPMS (Tire Pressure Monitoring System)
sp00315	CTM Proxi Configuration	CTM (Convergence Telematic Module)
sp00316	Clear Steering Pull Compensation	EPS (Electric Power Steering)
sp00317	Initialize EPS	EPS (Electric Power Steering)
sp00318	RADIO Proxi Configuration	RFH (Radio Frequency Hub)
sp00319	Intake Manifold Replacement	ECM (Engine Control Module)
sp00320	Clutch Group And/Or Clutch Potentiometer Replacement	ECM (Engine Control Module)
sp00321	Phonic Wheel Replacement	ECM (Engine Control Module)
sp00322	Intelligent Alternator (IAM) Replacement	ECM (Engine Control Module)
sp00323	Neutral Signal Learn	ECM (Engine Control Module)
sp00324	Fuel Supply System Components Replacement	ECM (Engine Control Module)
sp00325	Motorized Throttle Replacement	ECM (Engine Control Module)
sp00326	Factory VIN code lock	ECM (Engine Control Module)
sp00327	Control Unit Reprogramming	ECM (Engine Control Module)
sp00328	Self-Adaptive Parameters Reset	ECM (Engine Control Module)
sp00329	Proxi Alignment Procedure	ECM (Engine Control Module)
sp00330	Injector/S Replacement	ECM (Engine Control Module)
sp00331	Self-Adaptive Parameters Reset	ECM (Engine Control Module)
sp00332	Self-Learnt Functions Reset	ECM (Engine Control Module)
sp00333	Motorized Throttle Self Learning Command	ECM (Engine Control Module)
sp00334	Proxi Alignment Procedure	TCM (Transmission Control Module)
sp00335	ECU Substitution	ABS (Anti-Lock Braking System)
sp00336	Longitudinal And Lateral Sensor Calibration	ABS (Anti-Lock Braking System)
sp00337	Pressure Sensor Calibration	ABS (Anti-Lock Braking System)
sp00338	TPMS Reset Calibration	ABS (Anti-Lock Braking System)
sp00339	Fire Protection System Activate	BCM (Body Control Module)
sp00340	LIN Line Request Check	BCM (Body Control Module)
sp00341	Ultrasonic Sensors Check	BCM (Body Control Module)
sp00342	Reset Odometer	IC (Instrument Cluster)
sp00343	Reset Service Information	IC (Instrument Cluster)
sp00344	Last Service Date	IC (Instrument Cluster)
sp00345	Factory VIN code lock	CSWM (Comfort Seat Wheel Module)
sp00346	Factory VIN code lock	DTCM (Drive Train Control Module)
sp00347	Proxi Alignment Procedure	DTCM (Drive Train Control Module)
sp00348	Proxi Alignment Procedure	ESM (Electronic Shifter Module)
sp00349	Factory VIN code lock	ESM (Electronic Shifter Module)
sp00350	Power Down	RRM (Radio Receiver Module)
sp00351	Power On And Disable User Inputs	RRM (Radio Receiver Module)
sp00352	Reset Parameters To Default	RRM (Radio Receiver Module)
sp00353	Self Learning Motors Test	HVAC (Heating Ventilation Air-Conditioning And Cooling)
sp00354	Clear TPM Sensor Audit	RFH (Radio Frequency Hub)
sp00355	Clear TPM Sensor Warnings	RFH (Radio Frequency Hub)
sp00356	Steering Angle Sensor	EPS (Electric Power Steering)
sp00357	Trailer Hook Presence Disabling	PAM (Parking Aid Module)
sp00358	Trailer Hook Presence Enabling	PAM (Parking Aid Module)

sp00359	Service Single Pole Calibration	HALF (Haptical Lane Feedback)
sp00360	Intake Manifold Replacement	ECM (Engine Control Module)
sp00361	Clutch Group And/Or Clutch Potentiometer Replacement	ECM (Engine Control Module)
sp00362	Phonic Wheel Replacement	ECM (Engine Control Module)
sp00363	Intelligent Alternator (IAM) Replacement	ECM (Engine Control Module)
sp00364	Neutral Signal Learn	ECM (Engine Control Module)
sp00365	Fuel Supply System Components Replacement	ECM (Engine Control Module)
sp00366	Motorized Throttle Replacement	ECM (Engine Control Module)
sp00367	Factory VIN code lock	ECM (Engine Control Module)
sp00368	Control Unit Reprogramming	ECM (Engine Control Module)
sp00369	Self-Adaptive Parameters Reset	ECM (Engine Control Module)
sp00370	Proxi Alignment Procedure	ECM (Engine Control Module)
sp00371	Injector/S Replacement	ECM (Engine Control Module)
sp00372	Self-Adaptive Parameters Reset	ECM (Engine Control Module)
sp00373	Self-Learnt Functions Reset	ECM (Engine Control Module)
sp00374	Motorized Throttle Self Learning Command	ECM (Engine Control Module)
sp00375	Proxi Alignment Procedure	TCM (Transmission Control Module)
sp00376	ECU Substitution	ABS (Anti-Lock Braking System)
sp00377	Longitudinal And Lateral Sensor Calibration	ABS (Anti-Lock Braking System)
sp00378	Pressure Sensor Calibration	ABS (Anti-Lock Braking System)
sp00379	TPMS Reset Calibration	ABS (Anti-Lock Braking System)
sp00380	Fire Protection System Activate	BCM (Body Control Module)
sp00381	LIN Line Request Check	BCM (Body Control Module)
sp00382	Ultrasonic Sensors Check	BCM (Body Control Module)
sp00383	Reset Odometer	IC (Instrument Cluster)
sp00384	Reset Service Information	IC (Instrument Cluster)
sp00385	Last Service Date	IC (Instrument Cluster)
sp00386	Factory VIN code lock	CSWM (Comfort Seat Wheel Module)
sp00387	Factory VIN code lock	DTCM (Drive Train Control Module)
sp00388	Proxi Alignment Procedure	DTCM (Drive Train Control Module)
sp00389	Proxi Alignment Procedure	ESM (Electronic Shifter Module)
sp00390	Factory VIN code lock	ESM (Electronic Shifter Module)
sp00391	Power Down	RRM (Radio Receiver Module)
sp00392	Power On And Disable User Inputs	RRM (Radio Receiver Module)
sp00393	Reset Parameters To Default	RRM (Radio Receiver Module)
sp00394	Self Learning Motors Test	HVAC (Heating Ventilation Air-Conditioning And Cooling)
sp00395	Clear TPM Sensor Audit	RFH (Radio Frequency Hub)
sp00396	Clear TPM Sensor Warnings	RFH (Radio Frequency Hub)
sp00397	Steering Angle Sensor	EPS (Electric Power Steering)
sp00398	Trailer Hook Presence Disabling	PAM (Parking Aid Module)
sp00399	Trailer Hook Presence Enabling	PAM (Parking Aid Module)
sp00400	Service Single Pole Calibration	HALF (Haptical Lane Feedback)
sp00401	Intake Manifold Replacement	ECM (Engine Control Module)
sp00402	Clutch Group And/Or Clutch Potentiometer Replacement	ECM (Engine Control Module)
sp00403	Phonic Wheel Replacement	ECM (Engine Control Module)
sp00404	Intelligent Alternator (IAM) Replacement	ECM (Engine Control Module)
sp00405	Neutral Signal Learn	ECM (Engine Control Module)
sp00406	Fuel Supply System Components Replacement	ECM (Engine Control Module)
sp00407	Motorized Throttle Replacement	ECM (Engine Control Module)
sp00408	Factory VIN code lock	ECM (Engine Control Module)
sp00409	Control Unit Reprogramming	ECM (Engine Control Module)
sp00410	Self-Adaptive Parameters Reset	ECM (Engine Control Module)

sp00411	Proxi Alignment Procedure	ECM (Engine Control Module)
sp00412	Injector/S Replacement	ECM (Engine Control Module)
sp00413	Self-Adaptive Parameters Reset	ECM (Engine Control Module)
sp00414	Self-Learnt Functions Reset	ECM (Engine Control Module)
sp00415	Motorized Throttle Self Learning Command	ECM (Engine Control Module)
sp00416	Proxi Alignment Procedure	TCM (Transmission Control Module)
sp00417	ECU Substitution	ABS (Anti-Lock Braking System)
sp00418	Longitudinal And Lateral Sensor Calibration	ABS (Anti-Lock Braking System)
sp00419	Pressure Sensor Calibration	ABS (Anti-Lock Braking System)
sp00420	TPMS Reset Calibration	ABS (Anti-Lock Braking System)
sp00421	Fire Protection System Activate	BCM (Body Control Module)
sp00422	LIN Line Request Check	BCM (Body Control Module)
sp00423	Ultrasonic Sensors Check	BCM (Body Control Module)
sp00424	Reset Odometer	IC (Instrument Cluster)
sp00425	Reset Service Information	IC (Instrument Cluster)
sp00426	Last Service Date	IC (Instrument Cluster)
sp00427	Factory VIN code lock	CSWM (Comfort Seat Wheel Module)
sp00428	Factory VIN code lock	DTCM (Drive Train Control Module)
sp00429	Proxi Alignment Procedure	DTCM (Drive Train Control Module)
sp00430	Proxi Alignment Procedure	ESM (Electronic Shifter Module)
sp00431	Factory VIN code lock	ESM (Electronic Shifter Module)
sp00432	Power Down	RRM (Radio Receiver Module)
sp00433	Power On And Disable User Inputs	RRM (Radio Receiver Module)
sp00434	Reset Parameters To Default	RRM (Radio Receiver Module)
sp00435	Self Learning Motors Test	HVAC (Heating Ventilation Air-Conditioning And Cooling)
sp00436	Clear TPM Sensor Audit	RFH (Radio Frequency Hub)
sp00437	Clear TPM Sensor Warnings	RFH (Radio Frequency Hub)
sp00438	Steering Angle Sensor	EPS (Electric Power Steering)
sp00439	Trailer Hook Presence Disabling	PAM (Parking Aid Module)
sp00440	Trailer Hook Presence Enabling	PAM (Parking Aid Module)
sp00441	Service Single Pole Calibration	HALF (Haptical Lane Feedback)
sp00442	Intake Manifold Replacement	ECM (Engine Control Module)
sp00443	Clutch Group And/Or Clutch Potentiometer Replacement	ECM (Engine Control Module)
sp00444	Phonic Wheel Replacement	ECM (Engine Control Module)
sp00445	Intelligent Alternator (IAM) Replacement	ECM (Engine Control Module)
sp00446	Neutral Signal Learn	ECM (Engine Control Module)
sp00447	Fuel Supply System Components Replacement	ECM (Engine Control Module)
sp00448	Motorized Throttle Replacement	ECM (Engine Control Module)
sp00449	Factory VIN code lock	ECM (Engine Control Module)
sp00450	Control Unit Reprogramming	ECM (Engine Control Module)
sp00451	Self-Adaptive Parameters Reset	ECM (Engine Control Module)
sp00452	Proxi Alignment Procedure	ECM (Engine Control Module)
sp00453	Injector/S Replacement	ECM (Engine Control Module)
sp00454	Self-Adaptive Parameters Reset	ECM (Engine Control Module)
sp00455	Self-Learnt Functions Reset	ECM (Engine Control Module)
sp00456	Motorized Throttle Self Learning Command	ECM (Engine Control Module)
sp00457	Proxi Alignment Procedure	TCM (Transmission Control Module)
sp00458	ECU Substitution	ABS (Anti-Lock Braking System)
sp00459	Longitudinal And Lateral Sensor Calibration	ABS (Anti-Lock Braking System)
sp00460	Pressure Sensor Calibration	ABS (Anti-Lock Braking System)
sp00461	TPMS Reset Calibration	ABS (Anti-Lock Braking System)
sp00462	Fire Protection System Activate	BCM (Body Control Module)

sp00463	LIN Line Request Check	BCM (Body Control Module)
sp00464	Ultrasonic Sensors Check	BCM (Body Control Module)
sp00465	Reset Odometer	IC (Instrument Cluster)
sp00466	Reset Service Information	IC (Instrument Cluster)
sp00467	Last Service Date	IC (Instrument Cluster)
sp00468	Factory VIN code lock	CSWM (Comfort Seat Wheel Module)
sp00469	Factory VIN code lock	DTCM (Drive Train Control Module)
sp00470	Proxi Alignment Procedure	DTCM (Drive Train Control Module)
sp00471	Proxi Alignment Procedure	ESM (Electronic Shifter Module)
sp00472	Factory VIN code lock	ESM (Electronic Shifter Module)
sp00473	Power Down	RRM (Radio Receiver Module)
sp00474	Power On And Disable User Inputs	RRM (Radio Receiver Module)
sp00475	Reset Parameters To Default	RRM (Radio Receiver Module)
sp00476	Self Learning Motors Test	HVAC (Heating Ventilation Air-Conditioning And Cooling)
sp00477	Clear TPM Sensor Audit	RFH (Radio Frequency Hub)
sp00478	Clear TPM Sensor Warnings	RFH (Radio Frequency Hub)
sp00479	Steering Angle Sensor	EPS (Electric Power Steering)
sp00480	Trailer Hook Presence Disabling	PAM (Parking Aid Module)
sp00481	Trailer Hook Presence Enabling	PAM (Parking Aid Module)
sp00482	Service Single Pole Calibration	HALF (Haptical Lane Feedback)
sp00483	Deactivation Of The Power Limitation Function	ECM (Engine Control Module)
sp00484	Motorised Throttle Replacement	ECM (Engine Control Module)
sp00485	Supercharging System Components Replacement	ECM (Engine Control Module)
sp00486	Intake Manifold Replacement	ECM (Engine Control Module)
sp00487	Clutch Group And/Or Clutch Potentiometer Replacement	ECM (Engine Control Module)
sp00488	Self-Learnt Functions Reset	ECM (Engine Control Module)
sp00489	Phonic Wheel Replacement	ECM (Engine Control Module)
sp00490	Intelligent Alternator (IAM) Replacement	ECM (Engine Control Module)
sp00491	Neutral Signal Learn	ECM (Engine Control Module)
sp00492	Self-Adaptive Parameters Reset	ECM (Engine Control Module)
sp00493	Reset Gear Configuration	ABS (Anti-Lock Braking System)
sp00494	Longitudinal And Lateral Sensor Calibration	ABS (Anti-Lock Braking System)
sp00495	Pressure Sensor Calibration	ABS (Anti-Lock Braking System)
sp00496	Steering Angle Sensor	EPS (Electric Power Steering)
sp00497	Reset Odometer	IC (Instrument Cluster)
sp00498	Reset Service Information	IC (Instrument Cluster)
sp00499	Disable Seat Belts Reminder	IC (Instrument Cluster)
sp00500	Enable Seat Belts Reminder	IC (Instrument Cluster)
sp00501	Last Service Date	IC (Instrument Cluster)
sp00502	Power Down	ETM (Entertainment Telematic Module)
sp00503	Power On And Disable User Inputs	ETM (Entertainment Telematic Module)
sp00504	Audio Video Signal Detection	ETM (Entertainment Telematic Module)
sp00505	Trailer Hook Presence Disabling	PAM (Parking Aid Module)
sp00506	Trailer Hook Presence Enabling	PAM (Parking Aid Module)
sp00507	Clear TPM Warnings	TPMS (Tire Pressure Monitoring System)
sp00508	Clear TPM Sensor Rolls Test Results	TPMS (Tire Pressure Monitoring System)
sp00509	TPM FGA Proxi Configuration	TPMS (Tire Pressure Monitoring System)
sp00510	Update Front And Rear Axle Nominal Tire Pressure Values	TPMS (Tire Pressure Monitoring System)
sp00511	Program Left Front Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp00512	Program Left Rear Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp00513	Program Right Front Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp00514	Program Right Rear Tire Sensor ID	TPMS (Tire Pressure Monitoring System)



sp00515	TPM Sensor Rolls Test	TPMS (Tire Pressure Monitoring System)
sp00516	Deactivation Of The Power Limitation Function	ECM (Engine Control Module)
sp00517	Motorised Throttle Replacement	ECM (Engine Control Module)
sp00518	Supercharging System Components Replacement	ECM (Engine Control Module)
sp00519	Intake Manifold Replacement	ECM (Engine Control Module)
sp00520	Clutch Group And/Or Clutch Potentiometer Replacement	ECM (Engine Control Module)
sp00521	Self-Learnt Functions Reset	ECM (Engine Control Module)
sp00522	Phonic Wheel Replacement	ECM (Engine Control Module)
sp00523	Intelligent Alternator (IAM) Replacement	ECM (Engine Control Module)
sp00524	Neutral Signal Learn	ECM (Engine Control Module)
sp00525	Self-Adaptive Parameters Reset	ECM (Engine Control Module)
sp00526	Reset Gear Configuration	ABS (Anti-Lock Braking System)
sp00527	Longitudinal And Lateral Sensor Calibration	ABS (Anti-Lock Braking System)
sp00528	Pressure Sensor Calibration	ABS (Anti-Lock Braking System)
sp00529	Steering Angle Sensor	EPS (Electric Power Steering)
sp00530	Reset Odometer	IC (Instrument Cluster)
sp00531	Reset Service Information	IC (Instrument Cluster)
sp00532	Disable Seat Belts Reminder	IC (Instrument Cluster)
sp00533	Enable Seat Belts Reminder	IC (Instrument Cluster)
sp00534	Last Service Date	IC (Instrument Cluster)
sp00535	Power Down	ETM (Entertainment Telematic Module)
sp00536	Power On And Disable User Inputs	ETM (Entertainment Telematic Module)
sp00537	Audio Video Signal Detection	ETM (Entertainment Telematic Module)
sp00538	Trailer Hook Presence Disabling	PAM (Parking Aid Module)
sp00539	Trailer Hook Presence Enabling	PAM (Parking Aid Module)
sp00540	Clear TPM Warnings	TPMS (Tire Pressure Monitoring System)
sp00541	Clear TPM Sensor Rolls Test Results	TPMS (Tire Pressure Monitoring System)
sp00542	TPM FGA Proxi Configuration	TPMS (Tire Pressure Monitoring System)
sp00543	Update Front And Rear Axle Nominal Tire Pressure Values	TPMS (Tire Pressure Monitoring System)
sp00544	Program Left Front Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp00545	Program Left Rear Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp00546	Program Right Front Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp00547	Program Right Rear Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp00548	TPM Sensor Rolls Test	TPMS (Tire Pressure Monitoring System)
sp00549	Air-Conditioning Self Learning	ECM (Engine Control Module)
sp00550	Brake Switch Learn	ECM (Engine Control Module)
sp00551	Check PCM Odometer	ECM (Engine Control Module)
sp00552	Clear Misfire TLC	ECM (Engine Control Module)
sp00553	Reset Accelerator Pedal Adaptives	ECM (Engine Control Module)
sp00554	Reset Memory	ECM (Engine Control Module)
sp00555	Throttle Body Self Learning	ECM (Engine Control Module)
sp00556	Reset Gear Configuration	ABS (Anti-Lock Braking System)
sp00557	Longitudinal And Lateral Sensor Calibration	ABS (Anti-Lock Braking System)
sp00558	Pressure Sensor Calibration	ABS (Anti-Lock Braking System)
sp00559	Clear TPM Warnings	TPMS (Tire Pressure Monitoring System)
sp00560	Clear TPM Sensor Rolls Test Results	TPMS (Tire Pressure Monitoring System)
sp00561	TPM FGA Proxi Configuration	TPMS (Tire Pressure Monitoring System)
sp00562	Update Front And Rear Axle Nominal Tire Pressure Values	TPMS (Tire Pressure Monitoring System)
sp00563	Program Left Front Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp00564	Program Left Rear Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp00565	Program Right Front Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp00566	Program Right Rear Tire Sensor ID	TPMS (Tire Pressure Monitoring System)



sp00567	TPM Sensor Rolls Test	TPMS (Tire Pressure Monitoring System)
sp00568	Trailer Hook Presence Disabling	PAM (Parking Assistant Module)
sp00569	Trailer Hook Presence Enabling	PAM (Parking Assistant Module)
sp00570	Reset Odometer	IC (Instrument Cluster)
sp00571	Reset Service Information	IC (Instrument Cluster)
sp00572	Disable Seat Belts Reminder	IC (Instrument Cluster)
sp00573	Enable Seat Belts Reminder	IC (Instrument Cluster)
sp00574	Last Service Date	IC (Instrument Cluster)
sp00575	Power Down	ETM (Entertainment Telematic Module)
sp00576	Power On And Disable User Inputs	ETM (Entertainment Telematic Module)
sp00577	Audio Video Signal Detection	ETM (Entertainment Telematic Module)
sp00578	Steering Angle Sensor	EPS (Electric Power Steering)
sp00579	Deactivation Of The Power Limitation Function	ECM (Engine Control Module)
sp00580	Motorised Throttle Replacement	ECM (Engine Control Module)
sp00581	Supercharging System Components Replacement	ECM (Engine Control Module)
sp00582	Intake Manifold Replacement	ECM (Engine Control Module)
sp00583	Clutch Group And/Or Clutch Potentiometer Replacement	ECM (Engine Control Module)
sp00584	Self-Learnt Functions Reset	ECM (Engine Control Module)
sp00585	Phonic Wheel Replacement	ECM (Engine Control Module)
sp00586	Intelligent Alternator (IAM) Replacement	ECM (Engine Control Module)
sp00587	Neutral Signal Learn	ECM (Engine Control Module)
sp00588	Self-Adaptive Parameters Reset	ECM (Engine Control Module)
sp00589	Reset Gear Configuration	ABS (Anti-Lock Braking System)
sp00590	Longitudinal And Lateral Sensor Calibration	ABS (Anti-Lock Braking System)
sp00591	Pressure Sensor Calibration	ABS (Anti-Lock Braking System)
sp00592	Steering Angle Sensor	EPS (Electric Power Steering)
sp00593	Reset Odometer	IC (Instrument Cluster)
sp00594	Reset Service Information	IC (Instrument Cluster)
sp00595	Disable Seat Belts Reminder	IC (Instrument Cluster)
sp00596	Enable Seat Belts Reminder	IC (Instrument Cluster)
sp00597	Last Service Date	IC (Instrument Cluster)
sp00598	Power Down	ETM (Entertainment Telematic Module)
sp00599	Power On And Disable User Inputs	ETM (Entertainment Telematic Module)
sp00600	Audio Video Signal Detection	ETM (Entertainment Telematic Module)
sp00601	Trailer Hook Presence Disabling	PAM (Parking Aid Module)
sp00602	Trailer Hook Presence Enabling	PAM (Parking Aid Module)
sp00603	Clear TPM Warnings	TPMS (Tire Pressure Monitoring System)
sp00604	Clear TPM Sensor Rolls Test Results	TPMS (Tire Pressure Monitoring System)
sp00605	TPM FGA Proxi Configuration	TPMS (Tire Pressure Monitoring System)
sp00606	Update Front And Rear Axle Nominal Tire Pressure Values	TPMS (Tire Pressure Monitoring System)
sp00607	Program Left Front Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp00608	Program Left Rear Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp00609	Program Right Front Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp00610	Program Right Rear Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp00611	TPM Sensor Rolls Test	TPMS (Tire Pressure Monitoring System)
sp00612	Deactivation Of The Power Limitation Function	ECM (Engine Control Module)
sp00613	Motorised Throttle Replacement	ECM (Engine Control Module)
sp00614	Supercharging System Components Replacement	ECM (Engine Control Module)
sp00615	Intake Manifold Replacement	ECM (Engine Control Module)
sp00616	Clutch Group And/Or Clutch Potentiometer Replacement	ECM (Engine Control Module)
sp00617	Self-Learnt Functions Reset	ECM (Engine Control Module)
sp00618	Phonic Wheel Replacement	ECM (Engine Control Module)

sp00619	Intelligent Alternator (IAM) Replacement	ECM (Engine Control Module)
sp00620	Neutral Signal Learn	ECM (Engine Control Module)
sp00621	Self-Adaptive Parameters Reset	ECM (Engine Control Module)
sp00622	Reset Gear Configuration	ABS (Anti-Lock Braking System)
sp00623	Longitudinal And Lateral Sensor Calibration	ABS (Anti-Lock Braking System)
sp00624	Pressure Sensor Calibration	ABS (Anti-Lock Braking System)
sp00625	Steering Angle Sensor	EPS (Electric Power Steering)
sp00626	Reset Odometer	IC (Instrument Cluster)
sp00627	Reset Service Information	IC (Instrument Cluster)
sp00628	Disable Seat Belts Reminder	IC (Instrument Cluster)
sp00629	Enable Seat Belts Reminder	IC (Instrument Cluster)
sp00630	Last Service Date	IC (Instrument Cluster)
sp00631	Power Down	ETM (Entertainment Telematic Module)
sp00632	Power On And Disable User Inputs	ETM (Entertainment Telematic Module)
sp00633	Audio Video Signal Detection	ETM (Entertainment Telematic Module)
sp00634	Trailer Hook Presence Disabling	PAM (Parking Aid Module)
sp00635	Trailer Hook Presence Enabling	PAM (Parking Aid Module)
sp00636	Clear TPM Warnings	TPMS (Tire Pressure Monitoring System)
sp00637	Clear TPM Sensor Rolls Test Results	TPMS (Tire Pressure Monitoring System)
sp00638	TPM FGA Proxi Configuration	TPMS (Tire Pressure Monitoring System)
sp00639	Update Front And Rear Axle Nominal Tire Pressure Values	TPMS (Tire Pressure Monitoring System)
sp00640	Program Left Front Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp00641	Program Left Rear Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp00642	Program Right Front Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp00643	Program Right Rear Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp00644	TPM Sensor Rolls Test	TPMS (Tire Pressure Monitoring System)
sp00645	Air-Conditioning Self Learning	ECM (Engine Control Module)
sp00646	Brake Switch Learn	ECM (Engine Control Module)
sp00647	Check PCM Odometer	ECM (Engine Control Module)
sp00648	Clear Misfire TLC	ECM (Engine Control Module)
sp00649	Reset Accelerator Pedal Adaptives	ECM (Engine Control Module)
sp00650	Reset Memory	ECM (Engine Control Module)
sp00651	Throttle Body Self Learning	ECM (Engine Control Module)
sp00652	Reset Gear Configuration	ABS (Anti-Lock Braking System)
sp00653	Longitudinal And Lateral Sensor Calibration	ABS (Anti-Lock Braking System)
sp00654	Pressure Sensor Calibration	ABS (Anti-Lock Braking System)
sp00655	Clear TPM Warnings	TPMS (Tire Pressure Monitoring System)
sp00656	Clear TPM Sensor Rolls Test Results	TPMS (Tire Pressure Monitoring System)
sp00657	TPM FGA Proxi Configuration	TPMS (Tire Pressure Monitoring System)
sp00658	Update Front And Rear Axle Nominal Tire Pressure Values	TPMS (Tire Pressure Monitoring System)
sp00659	Program Left Front Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp00660	Program Left Rear Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp00661	Program Right Front Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp00662	Program Right Rear Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp00663	TPM Sensor Rolls Test	TPMS (Tire Pressure Monitoring System)
sp00664	Trailer Hook Presence Disabling	PAM (Parking Assistant Module)
sp00665	Trailer Hook Presence Enabling	PAM (Parking Assistant Module)
sp00666	Reset Odometer	IC (Instrument Cluster)
sp00667	Reset Service Information	IC (Instrument Cluster)
sp00668	Disable Seat Belts Reminder	IC (Instrument Cluster)
sp00669	Enable Seat Belts Reminder	IC (Instrument Cluster)
sp00670	Last Service Date	IC (Instrument Cluster)

sp00671	Power Down	ETM (Entertainment Telematic Module)
sp00672	Power On And Disable User Inputs	ETM (Entertainment Telematic Module)
sp00673	Audio Video Signal Detection	ETM (Entertainment Telematic Module)
sp00674	Steering Angle Sensor	EPS (Electric Power Steering)
sp00675	Reset Gear Configuration	ABS (Anti-Lock Braking System)
sp00676	Longitudinal And Lateral Sensor Calibration	ABS (Anti-Lock Braking System)
sp00677	Pressure Sensor Calibration	ABS (Anti-Lock Braking System)
sp00678	Clear TPM Warnings	TPMS (Tire Pressure Monitoring System)
sp00679	Clear TPM Sensor Rolls Test Results	TPMS (Tire Pressure Monitoring System)
sp00680	TPM FGA Proxi Configuration	TPMS (Tire Pressure Monitoring System)
sp00681	Update Front And Rear Axle Nominal Tire Pressure Values	TPMS (Tire Pressure Monitoring System)
sp00682	Program Left Front Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp00683	Program Left Rear Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp00684	Program Right Front Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp00685	Program Right Rear Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp00686	TPM Sensor Rolls Test	TPMS (Tire Pressure Monitoring System)
sp00687	Trailer Hook Presence Disabling	PAM (Parking Aid Module)
sp00688	Trailer Hook Presence Enabling	PAM (Parking Aid Module)
sp00689	Reset Odometer	IC (Instrument Cluster)
sp00690	Reset Service Information	IC (Instrument Cluster)
sp00691	Disable Seat Belts Reminder	IC (Instrument Cluster)
sp00692	Enable Seat Belts Reminder	IC (Instrument Cluster)
sp00693	Last Service Date	IC (Instrument Cluster)
sp00694	Power Down	ETM (Entertainment Telematic Module)
sp00695	Power On And Disable User Inputs	ETM (Entertainment Telematic Module)
sp00696	Audio Video Signal Detection	ETM (Entertainment Telematic Module)
sp00697	Steering Angle Sensor	EPS (Electric Power Steering)
sp00698	Deactivation Of The Power Limitation Function	ECM (Engine Control Module)
sp00699	Phonic Wheel Replacement	ECM (Engine Control Module)
sp00700	Motorised Throttle Replacement	ECM (Engine Control Module)
sp00701	Supercharging System Components Replacement	ECM (Engine Control Module)
sp00702	Neutral Signal Learn	ECM (Engine Control Module)
sp00703	Intake Manifold Replacement	ECM (Engine Control Module)
sp00704	Clutch Group And/Or Clutch Potentiometer Replacement	ECM (Engine Control Module)
sp00705	Clutch Pedal Learning	ECM (Engine Control Module)
sp00706	Neutral Signal Learn	ECM (Engine Control Module)
sp00707	Self-Learnt Functions Reset	ECM (Engine Control Module)
sp00708	Self-Adaptive Parameters Reset	ECM (Engine Control Module)
sp00709	Tunnel Lever Replacement	TCM (Transmission Control Module)
sp00710	Levers At Wheel Replacement	TCM (Transmission Control Module)
sp00711	Pump Relay Replacement	TCM (Transmission Control Module)
sp00712	Self-Learnt Functions Reset	TCM (Transmission Control Module)
sp00713	Reset Gear Configuration	ABS (Anti-Lock Braking System)
sp00714	Longitudinal And Lateral Sensor Calibration	ABS (Anti-Lock Braking System)
sp00715	Pressure Sensor Calibration	ABS (Anti-Lock Braking System)
sp00716	Clear TPM Warnings	TPMS (Tire Pressure Monitoring System)
sp00717	Clear TPM Sensor Rolls Test Results	TPMS (Tire Pressure Monitoring System)
sp00718	TPM FGA Proxi Configuration	TPMS (Tire Pressure Monitoring System)
sp00719	Update Front And Rear Axle Nominal Tire Pressure Values	TPMS (Tire Pressure Monitoring System)
sp00720	Program Left Front Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp00721	Program Left Rear Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp00722	Program Right Front Tire Sensor ID	TPMS (Tire Pressure Monitoring System)

sp00723	Program Right Rear Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp00724	TPM Sensor Rolls Test	TPMS (Tire Pressure Monitoring System)
sp00725	Trailer Hook Presence Disabling	PAM (Parking Assistant Module)
sp00726	Trailer Hook Presence Enabling	PAM (Parking Assistant Module)
sp00727	Reset Odometer	IC (Instrument Cluster)
sp00728	Reset Service Information	IC (Instrument Cluster)
sp00729	Disable Seat Belts Reminder	IC (Instrument Cluster)
sp00730	Enable Seat Belts Reminder	IC (Instrument Cluster)
sp00731	Last Service Date	IC (Instrument Cluster)
sp00732	Power Down	ETM (Entertainment Telematic Module)
sp00733	Power On And Disable User Inputs	ETM (Entertainment Telematic Module)
sp00734	Audio Video Signal Detection	ETM (Entertainment Telematic Module)
sp00735	Steering Angle Sensor	EPS (Electric Power Steering)
sp00736	Intake Manifold Replacement	ECM (Engine Control Module)
sp00737	Clutch Group And/Or Clutch Potentiometer Replacement	ECM (Engine Control Module)
sp00738	Phonic Wheel Replacement	ECM (Engine Control Module)
sp00739	Intelligent Alternator (IAM) Replacement	ECM (Engine Control Module)
sp00740	Neutral Signal Learn	ECM (Engine Control Module)
sp00741	Fuel Supply System Components Replacement	ECM (Engine Control Module)
sp00742	Motorized Throttle Replacement	ECM (Engine Control Module)
sp00743	Factory VIN code lock	ECM (Engine Control Module)
sp00744	Control Unit Reprogramming	ECM (Engine Control Module)
sp00745	Self-Adaptive Parameters Reset	ECM (Engine Control Module)
sp00746	Proxi Alignment Procedure	ECM (Engine Control Module)
sp00747	Injector/S Replacement	ECM (Engine Control Module)
sp00748	Self-Adaptive Parameters Reset	ECM (Engine Control Module)
sp00749	Self-Learnt Functions Reset	ECM (Engine Control Module)
sp00750	Motorized Throttle Self Learning Command	ECM (Engine Control Module)
sp00751	Proxi Alignment Procedure	TCM (Transmission Control Module)
sp00752	ECU Substitution	ABS (Anti-Lock Braking System)
sp00753	Longitudinal And Lateral Sensor Calibration	ABS (Anti-Lock Braking System)
sp00754	Pressure Sensor Calibration	ABS (Anti-Lock Braking System)
sp00755	TPMS Reset Calibration	ABS (Anti-Lock Braking System)
sp00756	Fire Protection System Activate	BCM (Body Control Module )
sp00757	LIN Line Request Check	BCM (Body Control Module )
sp00758	Ultrasonic Sensors Check	BCM (Body Control Module )
sp00759	Power Down	RRM (Radio Receiver Module)
sp00760	Power On And Disable User Inputs	RRM (Radio Receiver Module)
sp00761	Reset Parameters To Default	RRM (Radio Receiver Module)
sp00762	Clear TPM Sensor Audit	RFH (Radio Frequency Hub)
sp00763	Clear TPM Sensor Warnings	RFH (Radio Frequency Hub)
sp00764	Factory VIN code lock	DTCM (Drive Train Control Module)
sp00765	Proxi Alignment Procedure	DTCM (Drive Train Control Module)
sp00766	Reset Odometer	IC (Instrument Cluster)
sp00767	Reset Service Information	IC (Instrument Cluster)
sp00768	Last Service Date	IC (Instrument Cluster)
sp00769	Self Learning Motors Test	HVAC (Heating Ventilation Air-Conditioning And Cooling)
sp00770	Steering Angle Sensor	EPS (Electric Power Steering)
sp00771	Proxi Alignment Procedure	ESM (Electronic Shifter Module)
sp00772	Factory VIN code lock	ESM (Electronic Shifter Module)
sp00773	Trailer Hook Presence Disabling	PAM (Parking Aid Module)
sp00774	Trailer Hook Presence Enabling	PAM (Parking Aid Module)
sp00775	Service Single Pole Calibration	HALF (Haptical Lane Feedback)

sp00776	Factory VIN code lock	CSWM (Comfort Seat Wheel Module)
sp00777	Intake Manifold Replacement	ECM (Engine Control Module)
sp00778	Clutch Group And/Or Clutch Potentiometer Replacement	ECM (Engine Control Module)
sp00779	Phonic Wheel Replacement	ECM (Engine Control Module)
sp00780	Intelligent Alternator (IAM) Replacement	ECM (Engine Control Module)
sp00781	Neutral Signal Learn	ECM (Engine Control Module)
sp00782	Fuel Supply System Components Replacement	ECM (Engine Control Module)
sp00783	Motorized Throttle Replacement	ECM (Engine Control Module)
sp00784	Factory VIN code lock	ECM (Engine Control Module)
sp00785	Control Unit Reprogramming	ECM (Engine Control Module)
sp00786	Self-Adaptive Parameters Reset	ECM (Engine Control Module)
sp00787	Proxi Alignment Procedure	ECM (Engine Control Module)
sp00788	Injector/S Replacement	ECM (Engine Control Module)
sp00789	Self-Adaptive Parameters Reset	ECM (Engine Control Module)
sp00790	Self-Learnt Functions Reset	ECM (Engine Control Module)
sp00791	Motorized Throttle Self Learning Command	ECM (Engine Control Module)
sp00792	Proxi Alignment Procedure	TCM (Transmission Control Module)
sp00793	ECU Substitution	ABS (Anti-Lock Braking System)
sp00794	Longitudinal And Lateral Sensor Calibration	ABS (Anti-Lock Braking System)
sp00795	Pressure Sensor Calibration	ABS (Anti-Lock Braking System)
sp00796	TPMS Reset Calibration	ABS (Anti-Lock Braking System)
sp00797	Fire Protection System Activate	BCM (Body Control Module )
sp00798	LIN Line Request Check	BCM (Body Control Module )
sp00799	Ultrasonic Sensors Check	BCM (Body Control Module )
sp00800	Power Down	RRM (Radio Receiver Module)
sp00801	Power On And Disable User Inputs	RRM (Radio Receiver Module)
sp00802	Reset Parameters To Default	RRM (Radio Receiver Module)
sp00803	Clear TPM Sensor Audit	RFH (Radio Frequency Hub)
sp00804	Clear TPM Sensor Warnings	RFH (Radio Frequency Hub)
sp00805	Factory VIN code lock	DTCM (Drive Train Control Module)
sp00806	Proxi Alignment Procedure	DTCM (Drive Train Control Module)
sp00807	Reset Odometer	IC (Instrument Cluster)
sp00808	Reset Service Information	IC (Instrument Cluster)
sp00809	Last Service Date	IC (Instrument Cluster)
sp00810	Self Learning Motors Test	HVAC (Heating Ventilation Air-Conditioning And Cooling)
sp00811	Steering Angle Sensor	EPS (Electric Power Steering)
sp00812	Proxi Alignment Procedure	ESM (Electronic Shifter Module)
sp00813	Factory VIN code lock	ESM (Electronic Shifter Module)
sp00814	Trailer Hook Presence Disabling	PAM (Parking Aid Module)
sp00815	Trailer Hook Presence Enabling	PAM (Parking Aid Module)
sp00816	Service Single Pole Calibration	HALF (Haptical Lane Feedback)
sp00817	Factory VIN code lock	CSWM (Comfort Seat Wheel Module)
sp00818	Intake Manifold Replacement	ECM (Engine Control Module)
sp00819	Clutch Group And/Or Clutch Potentiometer Replacement	ECM (Engine Control Module)
sp00820	Phonic Wheel Replacement	ECM (Engine Control Module)
sp00821	Intelligent Alternator (IAM) Replacement	ECM (Engine Control Module)
sp00822	Neutral Signal Learn	ECM (Engine Control Module)
sp00823	Fuel Supply System Components Replacement	ECM (Engine Control Module)
sp00824	Motorized Throttle Replacement	ECM (Engine Control Module)
sp00825	Factory VIN code lock	ECM (Engine Control Module)
sp00826	Control Unit Reprogramming	ECM (Engine Control Module)
sp00827	Self-Adaptive Parameters Reset	ECM (Engine Control Module)
sp00828	Proxi Alignment Procedure	ECM (Engine Control Module)
sp00829	Injector/S Replacement	ECM (Engine Control Module)
sp00830	Self-Adaptive Parameters Reset	ECM (Engine Control Module)

sp00831	Self-Learnt Functions Reset	ECM (Engine Control Module)
sp00832	Motorized Throttle Self Learning Command	ECM (Engine Control Module)
sp00833	Proxi Alignment Procedure	TCM (Transmission Control Module)
sp00834	ECU Substitution	ABS (Anti-Lock Braking System)
sp00835	Longitudinal And Lateral Sensor Calibration	ABS (Anti-Lock Braking System)
sp00836	Pressure Sensor Calibration	ABS (Anti-Lock Braking System)
sp00837	TPMS Reset Calibration	ABS (Anti-Lock Braking System)
sp00838	Fire Protection System Activate	BCM (Body Control Module )
sp00839	LIN Line Request Check	BCM (Body Control Module )
sp00840	Ultrasonic Sensors Check	BCM (Body Control Module )
sp00841	Power Down	RRM (Radio Receiver Module)
sp00842	Power On And Disable User Inputs	RRM (Radio Receiver Module)
sp00843	Reset Parameters To Default	RRM (Radio Receiver Module)
sp00844	Clear TPM Sensor Audit	RFH (Radio Frequency Hub)
sp00845	Clear TPM Sensor Warnings	RFH (Radio Frequency Hub)
sp00846	Trailer Hook Presence Disabling	PAM (Parking Aid Module)
sp00847	Trailer Hook Presence Enabling	PAM (Parking Aid Module)
sp00848	Reset Odometer	IC (Instrument Cluster)
sp00849	Reset Service Information	IC (Instrument Cluster)
sp00850	Last Service Date	IC (Instrument Cluster)
sp00851	Self Learning Motors Test	HVAC (Heating Ventilation Air-Conditioning And Cooling)
sp00852	Service Single Pole Calibration	HALF (Haptical Lane Feedback)
sp00853	Proxi Alignment Procedure	ESM (Electronic Shifter Module)
sp00854	Factory VIN code lock	ESM (Electronic Shifter Module)
sp00855	Steering Angle Sensor	EPS (Electric Power Steering)
sp00856	Factory VIN code lock	DTCM (Drive Train Control Module)
sp00857	Proxi Alignment Procedure	DTCM (Drive Train Control Module)
sp00858	Factory VIN code lock	CSWM (Comfort Seat Wheel Module)
sp00859	Intake Manifold Replacement	ECM (Engine Control Module)
sp00860	Clutch Group And/Or Clutch Potentiometer Replacement	ECM (Engine Control Module)
sp00861	Phonic Wheel Replacement	ECM (Engine Control Module)
sp00862	Intelligent Alternator (IAM) Replacement	ECM (Engine Control Module)
sp00863	Neutral Signal Learn	ECM (Engine Control Module)
sp00864	Fuel Supply System Components Replacement	ECM (Engine Control Module)
sp00865	Motorized Throttle Replacement	ECM (Engine Control Module)
sp00866	Factory VIN code lock	ECM (Engine Control Module)
sp00867	Control Unit Reprogramming	ECM (Engine Control Module)
sp00868	Self-Adaptive Parameters Reset	ECM (Engine Control Module)
sp00869	Proxi Alignment Procedure	ECM (Engine Control Module)
sp00870	Injector/S Replacement	ECM (Engine Control Module)
sp00871	Self-Adaptive Parameters Reset	ECM (Engine Control Module)
sp00872	Self-Learnt Functions Reset	ECM (Engine Control Module)
sp00873	Motorized Throttle Self Learning Command	ECM (Engine Control Module)
sp00874	Proxi Alignment Procedure	TCM (Transmission Control Module)
sp00875	ECU Substitution	ABS (Anti-Lock Braking System)
sp00876	Longitudinal And Lateral Sensor Calibration	ABS (Anti-Lock Braking System)
sp00877	Pressure Sensor Calibration	ABS (Anti-Lock Braking System)
sp00878	TPMS Reset Calibration	ABS (Anti-Lock Braking System)
sp00879	Fire Protection System Activate	BCM (Body Control Module )
sp00880	LIN Line Request Check	BCM (Body Control Module )
sp00881	Ultrasonic Sensors Check	BCM (Body Control Module )
sp00882	Power Down	RRM (Radio Receiver Module)
sp00883	Power On And Disable User Inputs	RRM (Radio Receiver Module)
sp00884	Reset Parameters To Default	RRM (Radio Receiver Module)
sp00885	Clear TPM Sensor Audit	RFH (Radio Frequency Hub)

sp00886	Clear TPM Sensor Warnings	RFH (Radio Frequency Hub)
sp00887	Factory VIN code lock	DTCM (Drive Train Control Module)
sp00888	Proxi Alignment Procedure	DTCM (Drive Train Control Module)
sp00889	Reset Odometer	IC (Instrument Cluster)
sp00890	Reset Service Information	IC (Instrument Cluster)
sp00891	Last Service Date	IC (Instrument Cluster)
sp00892	Self Learning Motors Test	HVAC (Heating Ventilation Air-Conditioning And Cooling)
sp00893	Steering Angle Sensor	EPS (Electric Power Steering)
sp00894	Proxi Alignment Procedure	ESM (Electronic Shifter Module)
sp00895	Factory VIN code lock	ESM (Electronic Shifter Module)
sp00896	Trailer Hook Presence Disabling	PAM (Parking Aid Module)
sp00897	Trailer Hook Presence Enabling	PAM (Parking Aid Module)
sp00898	Service Single Pole Calibration	HALF (Haptical Lane Feedback)
sp00899	Factory VIN code lock	CSWM (Comfort Seat Wheel Module)
sp00900	Intake Manifold Replacement	ECM (Engine Control Module)
sp00901	Clutch Group And/Or Clutch Potentiometer Replacement	ECM (Engine Control Module)
sp00902	Phonic Wheel Replacement	ECM (Engine Control Module)
sp00903	Intelligent Alternator (IAM) Replacement	ECM (Engine Control Module)
sp00904	Neutral Signal Learn	ECM (Engine Control Module)
sp00905	Fuel Supply System Components Replacement	ECM (Engine Control Module)
sp00906	Motorized Throttle Replacement	ECM (Engine Control Module)
sp00907	Factory VIN code lock	ECM (Engine Control Module)
sp00908	Control Unit Reprogramming	ECM (Engine Control Module)
sp00909	Self-Adaptive Parameters Reset	ECM (Engine Control Module)
sp00910	Proxi Alignment Procedure	ECM (Engine Control Module)
sp00911	Injector/S Replacement	ECM (Engine Control Module)
sp00912	Self-Adaptive Parameters Reset	ECM (Engine Control Module)
sp00913	Self-Learnt Functions Reset	ECM (Engine Control Module)
sp00914	Motorized Throttle Self Learning Command	ECM (Engine Control Module)
sp00915	Proxi Alignment Procedure	TCM (Transmission Control Module)
sp00916	ECU Substitution	ABS (Anti-Lock Braking System)
sp00917	Longitudinal And Lateral Sensor Calibration	ABS (Anti-Lock Braking System)
sp00918	Pressure Sensor Calibration	ABS (Anti-Lock Braking System)
sp00919	TPMS Reset Calibration	ABS (Anti-Lock Braking System)
sp00920	Fire Protection System Activate	BCM (Body Control Module )
sp00921	LIN Line Request Check	BCM (Body Control Module )
sp00922	Ultrasonic Sensors Check	BCM (Body Control Module )
sp00923	Power Down	RRM (Radio Receiver Module)
sp00924	Power On And Disable User Inputs	RRM (Radio Receiver Module)
sp00925	Reset Parameters To Default	RRM (Radio Receiver Module)
sp00926	Clear TPM Sensor Audit	RFH (Radio Frequency Hub)
sp00927	Clear TPM Sensor Warnings	RFH (Radio Frequency Hub)
sp00928	Trailer Hook Presence Disabling	PAM (Parking Aid Module)
sp00929	Trailer Hook Presence Enabling	PAM (Parking Aid Module)
sp00930	Reset Odometer	IC (Instrument Cluster)
sp00931	Reset Service Information	IC (Instrument Cluster)
sp00932	Last Service Date	IC (Instrument Cluster)
sp00933	Self Learning Motors Test	HVAC (Heating Ventilation Air-Conditioning And Cooling)
sp00934	Service Single Pole Calibration	HALF (Haptical Lane Feedback)
sp00935	Proxi Alignment Procedure	ESM (Electronic Shifter Module)
sp00936	Factory VIN code lock	ESM (Electronic Shifter Module)
sp00937	Steering Angle Sensor	EPS (Electric Power Steering)
sp00938	Factory VIN code lock	DTCM (Drive Train Control Module)
sp00939	Proxi Alignment Procedure	DTCM (Drive Train Control Module)
sp00940	Factory VIN code lock	CSWM (Comfort Seat Wheel Module)



sp00941	Intake Manifold Replacement	ECM (Engine Control Module)
sp00942	Clutch Group And/Or Clutch Potentiometer Replacement	ECM (Engine Control Module)
sp00943	Phonic Wheel Replacement	ECM (Engine Control Module)
sp00944	Intelligent Alternator (IAM) Replacement	ECM (Engine Control Module)
sp00945	Neutral Signal Learn	ECM (Engine Control Module)
sp00946	Fuel Supply System Components Replacement	ECM (Engine Control Module)
sp00947	Motorized Throttle Replacement	ECM (Engine Control Module)
sp00948	Factory VIN code lock	ECM (Engine Control Module)
sp00949	Control Unit Reprogramming	ECM (Engine Control Module)
sp00950	Self-Adaptive Parameters Reset	ECM (Engine Control Module)
sp00951	Proxi Alignment Procedure	ECM (Engine Control Module)
sp00952	Injector/S Replacement	ECM (Engine Control Module)
sp00953	Self-Adaptive Parameters Reset	ECM (Engine Control Module)
sp00954	Self-Learnt Functions Reset	ECM (Engine Control Module)
sp00955	Motorized Throttle Self Learning Command	ECM (Engine Control Module)
sp00956	Proxi Alignment Procedure	TCM (Transmission Control Module)
sp00957	ECU Substitution	ABS (Anti-Lock Braking System)
sp00958	Longitudinal And Lateral Sensor Calibration	ABS (Anti-Lock Braking System)
sp00959	Pressure Sensor Calibration	ABS (Anti-Lock Braking System)
sp00960	TPMS Reset Calibration	ABS (Anti-Lock Braking System)
sp00961	Fire Protection System Activate	BCM (Body Control Module )
sp00962	LIN Line Request Check	BCM (Body Control Module )
sp00963	Ultrasonic Sensors Check	BCM (Body Control Module )
sp00964	Power Down	RRM (Radio Receiver Module)
sp00965	Power On And Disable User Inputs	RRM (Radio Receiver Module)
sp00966	Reset Parameters To Default	RRM (Radio Receiver Module)
sp00967	Clear TPM Sensor Audit	RFH (Radio Frequency Hub)
sp00968	Clear TPM Sensor Warnings	RFH (Radio Frequency Hub)
sp00969	Trailer Hook Presence Disabling	PAM (Parking Aid Module)
sp00970	Trailer Hook Presence Enabling	PAM (Parking Aid Module)
sp00971	Reset Odometer	IC (Instrument Cluster)
sp00972	Reset Service Information	IC (Instrument Cluster)
sp00973	Last Service Date	IC (Instrument Cluster)
sp00974	Self Learning Motors Test	HVAC (Heating Ventilation Air-Conditioning And Cooling)
sp00975	Service Single Pole Calibration	HALF (Haptical Lane Feedback)
sp00976	Proxi Alignment Procedure	ESM (Electronic Shifter Module)
sp00977	Factory VIN code lock	ESM (Electronic Shifter Module)
sp00978	Steering Angle Sensor	EPS (Electric Power Steering)
sp00979	Factory VIN code lock	DTCM (Drive Train Control Module)
sp00980	Proxi Alignment Procedure	DTCM (Drive Train Control Module)
sp00981	Factory VIN code lock	CSWM (Comfort Seat Wheel Module)
sp00982	Intake Manifold Replacement	ECM (Engine Control Module)
sp00983	Clutch Group And/Or Clutch Potentiometer Replacement	ECM (Engine Control Module)
sp00984	Phonic Wheel Replacement	ECM (Engine Control Module)
sp00985	Intelligent Alternator (IAM) Replacement	ECM (Engine Control Module)
sp00986	Neutral Signal Learn	ECM (Engine Control Module)
sp00987	Fuel Supply System Components Replacement	ECM (Engine Control Module)
sp00988	Motorized Throttle Replacement	ECM (Engine Control Module)
sp00989	Factory VIN code lock	ECM (Engine Control Module)
sp00990	Control Unit Reprogramming	ECM (Engine Control Module)
sp00991	Self-Adaptive Parameters Reset	ECM (Engine Control Module)
sp00992	Proxi Alignment Procedure	ECM (Engine Control Module)



sp00993	Injector/S Replacement	ECM (Engine Control Module)
sp00994	Self-Adaptive Parameters Reset	ECM (Engine Control Module)
sp00995	Self-Learnt Functions Reset	ECM (Engine Control Module)
sp00996	Motorized Throttle Self Learning Command	ECM (Engine Control Module)
sp00997	Proxi Alignment Procedure	TCM (Transmission Control Module)
sp00998	ECU Substitution	ABS (Anti-Lock Braking System)
sp00999	Longitudinal And Lateral Sensor Calibration	ABS (Anti-Lock Braking System)
sp01000	Pressure Sensor Calibration	ABS (Anti-Lock Braking System)
sp01001	TPMS Reset Calibration	ABS (Anti-Lock Braking System)
sp01002	Fire Protection System Activate	BCM (Body Control Module )
sp01003	LIN Line Request Check	BCM (Body Control Module )
sp01004	Ultrasonic Sensors Check	BCM (Body Control Module )
sp01005	Power Down	RRM (Radio Receiver Module)
sp01006	Power On And Disable User Inputs	RRM (Radio Receiver Module)
sp01007	Reset Parameters To Default	RRM (Radio Receiver Module)
sp01008	Clear TPM Sensor Audit	RFH (Radio Frequency Hub)
sp01009	Clear TPM Sensor Warnings	RFH (Radio Frequency Hub)
sp01010	Trailer Hook Presence Disabling	PAM (Parking Aid Module)
sp01011	Trailer Hook Presence Enabling	PAM (Parking Aid Module)
sp01012	Reset Odometer	IC (Instrument Cluster)
sp01013	Reset Service Information	IC (Instrument Cluster)
sp01014	Last Service Date	IC (Instrument Cluster)
sp01015	Self Learning Motors Test	HVAC (Heating Ventilation Air-Conditioning And Cooling)
sp01016	Service Single Pole Calibration	HALF (Haptical Lane Feedback)
sp01017	Proxi Alignment Procedure	ESM (Electronic Shifter Module)
sp01018	Factory VIN code lock	ESM (Electronic Shifter Module)
sp01019	Steering Angle Sensor	EPS (Electric Power Steering)
sp01020	Factory VIN code lock	DTCM (Drive Train Control Module)
sp01021	Proxi Alignment Procedure	DTCM (Drive Train Control Module)
sp01022	Factory VIN code lock	CSWM (Comfort Seat Wheel Module)
sp01023	Deactivation Of The Power Limitation Function	ECM (Engine Control Module)
sp01024	Motorised Throttle Replacement	ECM (Engine Control Module)
sp01025	Supercharging System Components Replacement	ECM (Engine Control Module)
sp01026	Intake Manifold Replacement	ECM (Engine Control Module)
sp01027	Clutch Group And/Or Clutch Potentiometer Replacement	ECM (Engine Control Module)
sp01028	Phonic Wheel Replacement	ECM (Engine Control Module)
sp01029	Intelligent Alternator (IAM) Replacement	ECM (Engine Control Module)
sp01030	Neutral Signal Learn	ECM (Engine Control Module)
sp01031	Self-Learnt Functions Reset	ECM (Engine Control Module)
sp01032	Self-Adaptive Parameters Reset	ECM (Engine Control Module)
sp01033	Tunnel Lever Replacement	TCM (Transmission Control Module)
sp01034	Levers At Wheel Replacement	TCM (Transmission Control Module)
sp01035	Pump Relay Replacement	TCM (Transmission Control Module)
sp01036	Self-Learnt Functions Reset	TCM (Transmission Control Module)
sp01037	Static Test	ABS (Anti-Lock Braking System)
sp01038	Trailer Hook Presence Disabling	PAM (Parking Assistant Module)
sp01039	Trailer Hook Presence Enabling	PAM (Parking Assistant Module)
sp01040	Reset Odometer	IC (Instrument Cluster)
sp01041	Reset Service Information	IC (Instrument Cluster)
sp01042	Disable Seat Belts Reminder	IC (Instrument Cluster)
sp01043	Enable Seat Belts Reminder	IC (Instrument Cluster)
sp01044	Last Service Date	IC (Instrument Cluster)
sp01045	Flap Actuators Learning Test	HVAC (Heating Ventilation Air-Conditioning And Cooling)
sp01046	Audio Video Signal Detection	ETM (Entertainment Telematic Module)
sp01047	Steering Angle Calibration	EPS (Electric Power Steering)

sp01048	ECU Restart Routine	CTM (Convergence Telematic Module)
sp01049	Fire Protection System Activate	BCM (Body Control Module )
sp01050	Clutch Group And/Or Clutch Potentiometer Replacement	ECM (Engine Control Module)
sp01051	Intelligent Alternator (IAM) Replacement	ECM (Engine Control Module)
sp01052	Differential Pressure Sensor Replac.	ECM (Engine Control Module)
sp01053	Oil Change	ECM (Engine Control Module)
sp01054	Injector Replacement (Per Bank)	ECM (Engine Control Module)
sp01055	Injector Codes Read	ECM (Engine Control Module)
sp01056	Rail Pressure Sensor Replacement	ECM (Engine Control Module)
sp01057	Cylinder 3 Injector Replacement	ECM (Engine Control Module)
sp01058	Cylinder 2 Injector Replacement	ECM (Engine Control Module)
sp01059	Cylinder 1 Injector Replacement	ECM (Engine Control Module)
sp01060	Neutral Signal Learn	ECM (Engine Control Module)
sp01061	Phonic Wheel Replacement	ECM (Engine Control Module)
sp01062	Replacement Lambda Sensor	ECM (Engine Control Module)
sp01063	Speed Limit Setting	ECM (Engine Control Module)
sp01064	Speed Limit Setting	ECM (Engine Control Module)
sp01065	EGR Valve Test	ECM (Engine Control Module)
sp01066	Glow Plug Preheating Circuit Test	ECM (Engine Control Module)
sp01067	Resetting Distance Travelled With Water In Diesel W.Lamp ON	ECM (Engine Control Module)
sp01068	Throttle Valve Test	ECM (Engine Control Module)
sp01069	Resetting Distance Travelled With Water Temperature Warning Lamp ON	ECM (Engine Control Module)
sp01070	Self-Learnt Functions Reset	ECM (Engine Control Module)
sp01071	Fan Cooling Activation	ECM (Engine Control Module)
sp01072	Tunnel Lever Replacement	TCM (Transmission Control Module)
sp01073	Pump Relay Replacement	TCM (Transmission Control Module)
sp01074	Self-Learnt Functions Reset	TCM (Transmission Control Module)
sp01075	Longitudinal And Lateral Sensor Calibration	ABS (Anti-Lock Braking System)
sp01076	Pressure Sensor Calibration	ABS (Anti-Lock Braking System)
sp01077	Steering Angle Sensor Calibration	ABS (Anti-Lock Braking System)
sp01078	Write Front And Rear Nominal Tire Pressure Values	TPMS (Tire Pressure Monitoring System)
sp01079	Clear TPM Warnings	TPMS (Tire Pressure Monitoring System)
sp01080	Clear TPM Sensor Rolls Test Results	TPMS (Tire Pressure Monitoring System)
sp01081	ECU SERIAL NUMBER Management	TPMS (Tire Pressure Monitoring System)
sp01082	TPM Sensor Rolls Test	TPMS (Tire Pressure Monitoring System)
sp01083	Program Left Front Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp01084	Program Left Rear Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp01085	Program Right Front Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp01086	Program Right Rear Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp01087	Power Down	RADIO (RADIO)
sp01088	Power On And Disable User Inputs	RADIO (RADIO)
sp01089	Reset Parameters To Default	RADIO (RADIO)
sp01090	Trailer Hook Presence Disabling	PAM (Parking Assistant Module)
sp01091	Trailer Hook Presence Enabling	PAM (Parking Assistant Module)
sp01092	Disable Seat Belts Reminder	IPC (Instrument Panel Cluster)
sp01093	Reset Odometer	IPC (Instrument Panel Cluster)
sp01094	Reset Service Information	IPC (Instrument Panel Cluster)
sp01095	Last Service Date	IPC (Instrument Panel Cluster)
sp01096	Enable Seat Belts Reminder	IPC (Instrument Panel Cluster)
sp01097	Flap Actuators Learning Test	HVAC (Heating Ventilation Air-Conditioning And Cooling)
sp01098	Power Down	ETM (Entertainment Telematic Module)
sp01099	Power On And Disable User Inputs	ETM (Entertainment Telematic Module)

sp01100	Reset Parameters To Default	ETM (Entertainment Telematic Module)
sp01101	Audio Video Signal Detection	ETM (Entertainment Telematic Module)
sp01102	ECU Restart Routine	CTM (Convergence Telematic Module)
sp01103	Fire Protection System Activate	BCM (Body Control Module )
sp01104	Speed Limit Setting	ECM (Engine Control Module)
sp01105	Vehicle Configuration Reset	ECM (Engine Control Module)
sp01106	Reset Adaptative Parameter	ECM (Engine Control Module)
sp01107	Tunnel Lever Replacement	TCM (Transmission Control Module)
sp01108	Pump Relay Replacement	TCM (Transmission Control Module)
sp01109	Self-Learnt Functions Reset	TCM (Transmission Control Module)
sp01110	Inlet Valve Calibration	ABS (Anti-Lock Braking System)
sp01111	Longitudinal And Lateral Sensor Calibration	ABS (Anti-Lock Braking System)
sp01112	Pilot Valve Calibration	ABS (Anti-Lock Braking System)
sp01113	Brake Pressure Sensor Calibration	ABS (Anti-Lock Braking System)
sp01114	Steering Angle Sensor Calibration	ABS (Anti-Lock Braking System)
sp01115	Write Front And Rear Nominal Tire Pressure Values	TPMS (Tire Pressure Monitoring System)
sp01116	Clear TPM Warnings	TPMS (Tire Pressure Monitoring System)
sp01117	Clear TPM Sensor Rolls Test Results	TPMS (Tire Pressure Monitoring System)
sp01118	ECU SERIAL NUMBER Management	TPMS (Tire Pressure Monitoring System)
sp01119	TPM Sensor Rolls Test	TPMS (Tire Pressure Monitoring System)
sp01120	Program Left Front Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp01121	Program Left Rear Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp01122	Program Right Front Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp01123	Program Right Rear Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp01124	Trailer Hook Presence Disabling	PAM (Parking Assistant Module)
sp01125	Trailer Hook Presence Enabling	PAM (Parking Assistant Module)
sp01126	Reset Odometer	IC (Instrument Cluster)
sp01127	Reset Service Information	IC (Instrument Cluster)
sp01128	Disable Seat Belts Reminder	IC (Instrument Cluster)
sp01129	Enable Seat Belts Reminder	IC (Instrument Cluster)
sp01130	Last Service Date	IC (Instrument Cluster)
sp01131	Flap Actuators Learning Test	HVAC (Heating Ventilation Air-Conditioning And Cooling)
sp01132	Fire Protection System Activate	BCM (Body Control Module )
sp01133	Clutch Group And/Or Clutch Potentiometer Replacement	ECM (Engine Control Module)
sp01134	Differential Pressure Sensor Replac.	ECM (Engine Control Module)
sp01135	Oil Change	ECM (Engine Control Module)
sp01136	Rail Pressure Sensor Replacement	ECM (Engine Control Module)
sp01137	Phonic Wheel Replacement	ECM (Engine Control Module)
sp01138	Replacement Lambda Sensor	ECM (Engine Control Module)
sp01139	Injector Replacement (Per Bank)	ECM (Engine Control Module)
sp01140	Injector Codes Read	ECM (Engine Control Module)
sp01141	Cylinder 3 Injector Replacement	ECM (Engine Control Module)
sp01142	Cylinder 2 Injector Replacement	ECM (Engine Control Module)
sp01143	Cylinder 1 Injector Replacement	ECM (Engine Control Module)
sp01144	Speed Limit Setting	ECM (Engine Control Module)
sp01145	Self-Learnt Functions Reset	ECM (Engine Control Module)
sp01146	Fan Cooling Activation	ECM (Engine Control Module)
sp01147	EGR Valve Test	ECM (Engine Control Module)
sp01148	Resetting Distance Travelled With Water In Diesel W.Lamp ON	ECM (Engine Control Module)
sp01149	Throttle Valve Test	ECM (Engine Control Module)
sp01150	Resetting Distance Travelled With Water Temperature Warning Lamp ON	ECM (Engine Control Module)
sp01151	Longitudinal And Lateral Sensor Decalibration	ABS (Anti-Lock Braking System)
sp01152	Longitudinal And Lateral Sensor Calibration	ABS (Anti-Lock Braking System)
sp01153	Static Test	ABS (Anti-Lock Braking System)

sp01154	Steering Angle Sensor Calibration	ABS (Anti-Lock Braking System)
sp01155	Clear TPM Warnings	TPMS (Tire Pressure Monitoring System)
sp01156	Clear TPM Sensor Rolls Test Results	TPMS (Tire Pressure Monitoring System)
sp01157	Program Left Rear Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp01158	Program Right Rear Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp01159	ECU SERIAL NUMBER Management	TPMS (Tire Pressure Monitoring System)
sp01160	TPM Sensor Rolls Test	TPMS (Tire Pressure Monitoring System)
sp01161	Write Front And Rear Axle Nominal Tire Pressure	TPMS (Tire Pressure Monitoring System)
sp01162	Program Left Front Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp01163	Program Left Rear Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp01164	Program Right Front Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp01165	Program Right Rear Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp01166	Power Down	RADIO (RADIO)
sp01167	Power On And Disable User Inputs	RADIO (RADIO)
sp01168	Reset Parameters To Default	RADIO (RADIO)
sp01169	Trailer Hook Presence Disabling	PAM (Parking Aid Module)
sp01170	Trailer Hook Presence Enabling	PAM (Parking Aid Module)
sp01171	Reset Odometer	IC (Instrument Cluster)
sp01172	Reset Service Information	IC (Instrument Cluster)
sp01173	Disable Seat Belts Reminder	IC (Instrument Cluster)
sp01174	Enable Seat Belts Reminder	IC (Instrument Cluster)
sp01175	Last Service Date	IC (Instrument Cluster)
sp01176	Self Learning Motors Test	HVAC (Heating Ventilation Air-Conditioning And Cooling)
sp01177	Power Down	ETM (Entertainment Telematic Module)
sp01178	Power On And Disable User Inputs	ETM (Entertainment Telematic Module)
sp01179	Reset Parameters To Default	ETM (Entertainment Telematic Module)
sp01180	Audio Video Signal Detection	ETM (Entertainment Telematic Module)
sp01181	Service Single Pole Calibration	HALF (Haptical Lane Feedback)
sp01182	Clutch Group And/Or Clutch Potentiometer Replacement	ECM (Engine Control Module)
sp01183	Differential Pressure Sensor Replac.	ECM (Engine Control Module)
sp01184	Oil Change	ECM (Engine Control Module)
sp01185	Rail Pressure Sensor Replacement	ECM (Engine Control Module)
sp01186	Phonic Wheel Replacement	ECM (Engine Control Module)
sp01187	Replacement Lambda Sensor	ECM (Engine Control Module)
sp01188	Injector Replacement (Per Bank)	ECM (Engine Control Module)
sp01189	Injector Codes Read	ECM (Engine Control Module)
sp01190	Cylinder 3 Injector Replacement	ECM (Engine Control Module)
sp01191	Cylinder 2 Injector Replacement	ECM (Engine Control Module)
sp01192	Cylinder 1 Injector Replacement	ECM (Engine Control Module)
sp01193	Speed Limit Setting	ECM (Engine Control Module)
sp01194	Self-Learnt Functions Reset	ECM (Engine Control Module)
sp01195	Fan Cooling Activation	ECM (Engine Control Module)
sp01196	EGR Valve Test	ECM (Engine Control Module)
sp01197	Resetting Distance Travelled With Water In Diesel W.Lamp ON	ECM (Engine Control Module)
sp01198	Throttle Valve Test	ECM (Engine Control Module)
sp01199	Resetting Distance Travelled With Water Temperature Warning Lamp ON	ECM (Engine Control Module)
sp01200	Longitudinal And Lateral Sensor Decalibration	ABS (Anti-Lock Braking System)
sp01201	Longitudinal And Lateral Sensor Calibration	ABS (Anti-Lock Braking System)
sp01202	Static Test	ABS (Anti-Lock Braking System)
sp01203	Steering Angle Sensor Calibration	ABS (Anti-Lock Braking System)
sp01204	Clear TPM Warnings	TPMS (Tire Pressure Monitoring System)
sp01205	Clear TPM Sensor Rolls Test Results	TPMS (Tire Pressure Monitoring System)
sp01206	Program Left Rear Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp01207	Program Right Rear Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp01208	ECU SERIAL NUMBER Management	TPMS (Tire Pressure Monitoring System)

sp01209	TPM Sensor Rolls Test	TPMS (Tire Pressure Monitoring System)
sp01210	Write Front And Rear Axle Nominal Tire Pressure	TPMS (Tire Pressure Monitoring System)
sp01211	Program Left Front Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp01212	Program Left Rear Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp01213	Program Right Front Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp01214	Program Right Rear Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp01215	Power Down	RADIO (RADIO)
sp01216	Power On And Disable User Inputs	RADIO (RADIO)
sp01217	Reset Parameters To Default	RADIO (RADIO)
sp01218	Trailer Hook Presence Disabling	PAM (Parking Aid Module)
sp01219	Trailer Hook Presence Enabling	PAM (Parking Aid Module)
sp01220	Reset Odometer	IC (Instrument Cluster)
sp01221	Reset Service Information	IC (Instrument Cluster)
sp01222	Disable Seat Belts Reminder	IC (Instrument Cluster)
sp01223	Enable Seat Belts Reminder	IC (Instrument Cluster)
sp01224	Last Service Date	IC (Instrument Cluster)
sp01225	Self Learning Motors Test	HVAC (Heating Ventilation Air-Conditioning And Cooling)
sp01226	Service Single Pole Calibration	HALF (Haptical Lane Feedback)
sp01227	Power Down	ETM (Entertainment Telematic Module)
sp01228	Power On And Disable User Inputs	ETM (Entertainment Telematic Module)
sp01229	Reset Parameters To Default	ETM (Entertainment Telematic Module)
sp01230	Audio Video Signal Detection	ETM (Entertainment Telematic Module)
sp01231	Resetting Distance Travelled With Water In Diesel W.Lamp ON	ECM (Engine Control Module)
sp01232	Resetting Distance Travelled With Water Temperature Warning Lamp ON	ECM (Engine Control Module)
sp01233	Fan Cooling Activation	ECM (Engine Control Module)
sp01234	Neutral Signal Learn	ECM (Engine Control Module)
sp01235	Injector Codes Read	ECM (Engine Control Module)
sp01236	Nox Replacement	ECM (Engine Control Module)
sp01237	Factory VIN code lock	ECM (Engine Control Module)
sp01238	Intelligent Alternator (IAM) Replacement	ECM (Engine Control Module)
sp01239	Clutch Group And/Or Clutch Potentiometer Replacement	ECM (Engine Control Module)
sp01240	Injector Replacement (Per Bank)	ECM (Engine Control Module)
sp01241	Cylinder 1 Injector Replacement	ECM (Engine Control Module)
sp01242	Cylinder 2 Injector Replacement	ECM (Engine Control Module)
sp01243	Cylinder 3 Injector Replacement	ECM (Engine Control Module)
sp01244	Replacement Lambda Sensor	ECM (Engine Control Module)
sp01245	Oil Change	ECM (Engine Control Module)
sp01246	Differential Pressure Sensor Replac.	ECM (Engine Control Module)
sp01247	Rail Pressure Sensor Replacement	ECM (Engine Control Module)
sp01248	Replacement Of EGR Valve	ECM (Engine Control Module)
sp01249	EGR Low Pressure Valve Replacement	ECM (Engine Control Module)
sp01250	Glow Plug Preheating Circuit Test	ECM (Engine Control Module)
sp01251	EGR Valve Test	ECM (Engine Control Module)
sp01252	EGR Low Pressure Valve Test	ECM (Engine Control Module)
sp01253	Throttle Valve Test	ECM (Engine Control Module)
sp01254	Proxi Alignment Procedure	ECM (Engine Control Module)
sp01255	Neutral Position Self Learning.	TCM (Transmission Control Module)
sp01256	Clear Self-Learning Data	TCM (Transmission Control Module)
sp01257	Gearbox Replacement	TCM (Transmission Control Module)
sp01258	Static Test	ABS (Anti-Lock Braking System)
sp01259	Power Down	RRM (Radio Receiver Module)
sp01260	Power On And Disable User Inputs	RRM (Radio Receiver Module)
sp01261	Reset Parameters To Default	RRM (Radio Receiver Module)
sp01262	Trailer Hook Presence Disabling	PAM (Parking Assistant Module)

sp01263	Trailer Hook Presence Enabling	PAM (Parking Assistant Module)
sp01264	Reset Service Information	IC (Instrument Cluster)
sp01265	Reset Odometer	IC (Instrument Cluster)
sp01266	Last Service Date	IC (Instrument Cluster)
sp01267	Self Learning Motors Test	HVAC (Heating Ventilation Air-Conditioning And Cooling)
sp01268	Proxi Alignment Procedure	ESM (Electronic Shifter Module)
sp01269	Factory VIN code lock	ESM (Electronic Shifter Module)
sp01270	Resetting Distance Travelled With Water In Diesel W.Lamp ON	ECM (Engine Control Module)
sp01271	Resetting Distance Travelled With Water Temperature Warning Lamp ON	ECM (Engine Control Module)
sp01272	Fan Cooling Activation	ECM (Engine Control Module)
sp01273	Neutral Signal Learn	ECM (Engine Control Module)
sp01274	Injector Codes Read	ECM (Engine Control Module)
sp01275	Nox Replacement	ECM (Engine Control Module)
sp01276	Factory VIN code lock	ECM (Engine Control Module)
sp01277	Intelligent Alternator (IAM) Replacement	ECM (Engine Control Module)
sp01278	Clutch Group And/Or Clutch Potentiometer Replacement	ECM (Engine Control Module)
sp01279	Injector Replacement (Per Bank)	ECM (Engine Control Module)
sp01280	Cylinder 1 Injector Replacement	ECM (Engine Control Module)
sp01281	Cylinder 2 Injector Replacement	ECM (Engine Control Module)
sp01282	Cylinder 3 Injector Replacement	ECM (Engine Control Module)
sp01283	Replacement Lambda Sensor	ECM (Engine Control Module)
sp01284	Oil Change	ECM (Engine Control Module)
sp01285	Differential Pressure Sensor Replac.	ECM (Engine Control Module)
sp01286	Rail Pressure Sensor Replacement	ECM (Engine Control Module)
sp01287	Replacement Of EGR Valve	ECM (Engine Control Module)
sp01288	EGR Low Pressure Valve Replacement	ECM (Engine Control Module)
sp01289	Glow Plug Preheating Circuit Test	ECM (Engine Control Module)
sp01290	EGR Valve Test	ECM (Engine Control Module)
sp01291	EGR Low Pressure Valve Test	ECM (Engine Control Module)
sp01292	Throttle Valve Test	ECM (Engine Control Module)
sp01293	Proxi Alignment Procedure	ECM (Engine Control Module)
sp01294	Neutral Position Self Learning.	TCM (Transmission Control Module)
sp01295	Clear Self-Learning Data	TCM (Transmission Control Module)
sp01296	Gearbox Replacement	TCM (Transmission Control Module)
sp01297	Static Test	ABS (Anti-Lock Braking System)
sp01298	Power Down	RRM (Radio Receiver Module)
sp01299	Power On And Disable User Inputs	RRM (Radio Receiver Module)
sp01300	Reset Parameters To Default	RRM (Radio Receiver Module)
sp01301	Trailer Hook Presence Disabling	PAM (Parking Assistant Module)
sp01302	Trailer Hook Presence Enabling	PAM (Parking Assistant Module)
sp01303	Reset Service Information	IC (Instrument Cluster)
sp01304	Reset Odometer	IC (Instrument Cluster)
sp01305	Last Service Date	IC (Instrument Cluster)
sp01306	Self Learning Motors Test	HVAC (Heating Ventilation Air-Conditioning And Cooling)
sp01307	Proxi Alignment Procedure	ESM (Electronic Shifter Module)
sp01308	Factory VIN code lock	ESM (Electronic Shifter Module)
sp01309	Resetting Distance Travelled With Water In Diesel W.Lamp ON	ECM (Engine Control Module)
sp01310	Resetting Distance Travelled With Water Temperature Warning Lamp ON	ECM (Engine Control Module)
sp01311	Fan Cooling Activation	ECM (Engine Control Module)
sp01312	Neutral Signal Learn	ECM (Engine Control Module)
sp01313	Injector Codes Read	ECM (Engine Control Module)
sp01314	Nox Replacement	ECM (Engine Control Module)
sp01315	Factory VIN code lock	ECM (Engine Control Module)

sp01316	Intelligent Alternator (IAM) Replacement	ECM (Engine Control Module)
sp01317	Clutch Group And/Or Clutch Potentiometer Replacement	ECM (Engine Control Module)
sp01318	Injector Replacement (Per Bank)	ECM (Engine Control Module)
sp01319	Cylinder 1 Injector Replacement	ECM (Engine Control Module)
sp01320	Cylinder 2 Injector Replacement	ECM (Engine Control Module)
sp01321	Cylinder 3 Injector Replacement	ECM (Engine Control Module)
sp01322	Replacement Lambda Sensor	ECM (Engine Control Module)
sp01323	Oil Change	ECM (Engine Control Module)
sp01324	Differential Pressure Sensor Replac.	ECM (Engine Control Module)
sp01325	Rail Pressure Sensor Replacement	ECM (Engine Control Module)
sp01326	Replacement Of EGR Valve	ECM (Engine Control Module)
sp01327	EGR Low Pressure Valve Replacement	ECM (Engine Control Module)
sp01328	Glow Plug Preheating Circuit Test	ECM (Engine Control Module)
sp01329	EGR Valve Test	ECM (Engine Control Module)
sp01330	EGR Low Pressure Valve Test	ECM (Engine Control Module)
sp01331	Throttle Valve Test	ECM (Engine Control Module)
sp01332	Proxi Alignment Procedure	ECM (Engine Control Module)
sp01333	Neutral Position Self Learning.	TCM (Transmission Control Module)
sp01334	Clear Self-Learning Data	TCM (Transmission Control Module)
sp01335	Gearbox Replacement	TCM (Transmission Control Module)
sp01336	Static Test	ABS (Anti-Lock Braking System)
sp01337	Power Down	RRM (Radio Receiver Module)
sp01338	Power On And Disable User Inputs	RRM (Radio Receiver Module)
sp01339	Reset Parameters To Default	RRM (Radio Receiver Module)
sp01340	Trailer Hook Presence Disabling	PAM (Parking Assistant Module)
sp01341	Trailer Hook Presence Enabling	PAM (Parking Assistant Module)
sp01342	Reset Service Information	IC (Instrument Cluster)
sp01343	Reset Odometer	IC (Instrument Cluster)
sp01344	Last Service Date	IC (Instrument Cluster)
sp01345	Self Learning Motors Test	HVAC (Heating Ventilation Air-Conditioning And Cooling)
sp01346	Proxi Alignment Procedure	ESM (Electronic Shifter Module)
sp01347	Factory VIN code lock	ESM (Electronic Shifter Module)
sp01348	Differential Pressure Sensor Replac.	ECM (Engine Control Module)
sp01349	Oil Change	ECM (Engine Control Module)
sp01350	Injector Replacement (Per Bank)	ECM (Engine Control Module)
sp01351	Injector Codes Read	ECM (Engine Control Module)
sp01352	Rail Pressure Sensor Replacement	ECM (Engine Control Module)
sp01353	Cylinder 3 Injector Replacement	ECM (Engine Control Module)
sp01354	Cylinder 2 Injector Replacement	ECM (Engine Control Module)
sp01355	Cylinder 1 Injector Replacement	ECM (Engine Control Module)
sp01356	Phonic Wheel Replacement	ECM (Engine Control Module)
sp01357	Replacement Lambda Sensor	ECM (Engine Control Module)
sp01358	Neutral Signal Learn	ECM (Engine Control Module)
sp01359	EGR Valve Test	ECM (Engine Control Module)
sp01360	Glow Plug Preheating Circuit Test	ECM (Engine Control Module)
sp01361	Self-Learnt Functions Reset	ECM (Engine Control Module)
sp01362	Resetting Distance Travelled With Water In Diesel W. Lamp ON	ECM (Engine Control Module)
sp01363	Throttle Valve Test	ECM (Engine Control Module)
sp01364	Resetting Distance Travelled With Water Temperature Warning Lamp ON	ECM (Engine Control Module)
sp01365	Fan Cooling Activation	ECM (Engine Control Module)
sp01366	Speed Limit Setting	ECM (Engine Control Module)
sp01367	Tunnel Lever Replacement	TCM (Transmission Control Module)
sp01368	Pump Relay Replacement	TCM (Transmission Control Module)
sp01369	Self-Learnt Functions Reset	TCM (Transmission Control Module)
sp01370	Longitudinal And Lateral Sensor Decalibration	ABS (Anti-Lock Braking System)



sp01371	Longitudinal And Lateral Sensor Calibration	ABS (Anti-Lock Braking System)
sp01372	Static Test	ABS (Anti-Lock Braking System)
sp01373	Trailer Hook Presence Disabling	PAM (Parking Aid Module)
sp01374	Trailer Hook Presence Enabling	PAM (Parking Aid Module)
sp01375	Reset Odometer	IC (Instrument Cluster)
sp01376	Enable Seat Belts Reminder	IC (Instrument Cluster)
sp01377	Disable Seat Belts Reminder	IC (Instrument Cluster)
sp01378	ECU Restart Routine	CTM (Convergence Telematic Module)
sp01379	Differential Pressure Sensor Replac.	ECM (Engine Control Module)
sp01380	Oil Change	ECM (Engine Control Module)
sp01381	Injector Replacement (Per Bank)	ECM (Engine Control Module)
sp01382	Injector Codes Read	ECM (Engine Control Module)
sp01383	Rail Pressure Sensor Replacement	ECM (Engine Control Module)
sp01384	Cylinder 3 Injector Replacement	ECM (Engine Control Module)
sp01385	Cylinder 2 Injector Replacement	ECM (Engine Control Module)
sp01386	Cylinder 1 Injector Replacement	ECM (Engine Control Module)
sp01387	Phonic Wheel Replacement	ECM (Engine Control Module)
sp01388	Replacement Lambda Sensor	ECM (Engine Control Module)
sp01389	Neutral Signal Learn	ECM (Engine Control Module)
sp01390	EGR Valve Test	ECM (Engine Control Module)
sp01391	Glow Plug Preheating Circuit Test	ECM (Engine Control Module)
sp01392	Self-Learnt Functions Reset	ECM (Engine Control Module)
sp01393	Resetting Distance Travelled With Water In Diesel W. Lamp ON	ECM (Engine Control Module)
sp01394	Throttle Valve Test	ECM (Engine Control Module)
sp01395	Resetting Distance Travelled With Water Temperature Warning Lamp ON	ECM (Engine Control Module)
sp01396	Fan Cooling Activation	ECM (Engine Control Module)
sp01397	Speed Limit Setting	ECM (Engine Control Module)
sp01398	Tunnel Lever Replacement	TCM (Transmission Control Module)
sp01399	Pump Relay Replacement	TCM (Transmission Control Module)
sp01400	Self-Learnt Functions Reset	TCM (Transmission Control Module)
sp01401	Longitudinal And Lateral Sensor Decalibration	ABS (Anti-Lock Braking System)
sp01402	Longitudinal And Lateral Sensor Calibration	ABS (Anti-Lock Braking System)
sp01403	Static Test	ABS (Anti-Lock Braking System)
sp01404	Trailer Hook Presence Disabling	PAM (Parking Aid Module)
sp01405	Trailer Hook Presence Enabling	PAM (Parking Aid Module)
sp01406	Reset Odometer	IC (Instrument Cluster)
sp01407	Enable Seat Belts Reminder	IC (Instrument Cluster)
sp01408	Disable Seat Belts Reminder	IC (Instrument Cluster)
sp01409	ECU Restart Routine	CTM (Convergence Telematic Module)
sp01410	Air Flow Meter Replacement	PCM (Powertrain Control Module)
sp01411	DPF Reset Option	PCM (Powertrain Control Module)
sp01412	Lambda Sensor Replace	PCM (Powertrain Control Module)
sp01413	Reset Of Lambda Values	PCM (Powertrain Control Module)
sp01414	Reset Oil Change Indicator	PCM (Powertrain Control Module)
sp01415	Reset Zero Fuel Quantity Calibration	PCM (Powertrain Control Module)
sp01416	Service Diesel Particulate Filter Regeneration	PCM (Powertrain Control Module)
sp01417	Throttle Valve Learn	PCM (Powertrain Control Module)
sp01418	ABS Bleed Brakes	ABS (Anti-Lock Braking System)
sp01419	Brake Pedal Calibration	ABS (Anti-Lock Braking System)
sp01420	Initialize ORC	SRS (Supplemental Inflatable Restraint System, ORC)
sp01421	Rollover Detection	SRS (Supplemental Inflatable Restraint System, ORC)
sp01422	Activate Driver And Passenger Head Restraint	SRS (Supplemental Inflatable Restraint System, ORC)
sp01423	Program Tire Sensor ID With TPM Tool	TPMS (Tire Pressure Monitoring System)
sp01424	Actuator Calibration Test	HVAC (Heating Ventilation Air-Conditioning And Cooling)
sp01425	Initialize EPPM	EPPM (Electronic Pedestrian Protection Module)



sp01426	Configure License Plate Size	EPB (Electrical Parking Brake)
sp01427	System Wiring Test	EPB (Electrical Parking Brake)
sp01428	Auto Door Lock	BCM (Body Control Module)
sp01429	Program Tire Size	BCM (Body Control Module)
sp01430	Exit Shipping Mode	BCM (Body Control Module)
sp01431	Air Flow Meter Replacement	PCM (Powertrain Control Module)
sp01432	DPF Reset Option	PCM (Powertrain Control Module)
sp01433	Lambda Sensor Replace	PCM (Powertrain Control Module)
sp01434	Reset Of Lambda Values	PCM (Powertrain Control Module)
sp01435	Reset Oil Change Indicator	PCM (Powertrain Control Module)
sp01436	Reset Zero Fuel Quantity Calibration	PCM (Powertrain Control Module)
sp01437	Service Diesel Particulate Filter Regeneration	PCM (Powertrain Control Module)
sp01438	Throttle Valve Learn	PCM (Powertrain Control Module)
sp01439	ABS Bleed Brakes	ABS (Anti-Lock Braking System)
sp01440	Brake Pedal Calibration	ABS (Anti-Lock Braking System)
sp01441	Initialize ORC	SRS (Supplemental Inflatable Restraint System, ORC)
sp01442	Rollover Detection	SRS (Supplemental Inflatable Restraint System, ORC)
sp01443	Activate Driver And Passenger Head Restraint	SRS (Supplemental Inflatable Restraint System, ORC)
sp01444	Program Left Front Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp01445	Program Left Rear Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp01446	Program Right Front Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp01447	Program Right Rear Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp01448	Program Tire Sensor ID With TPM Tool	TPMS (Tire Pressure Monitoring System)
sp01449	Activate TPM High Gain Mode	TPMS (Tire Pressure Monitoring System)
sp01450	TPM Sensor Position Parameter Update	TPMS (Tire Pressure Monitoring System)
sp01451	Sensor Rolls Test	TPMS (Tire Pressure Monitoring System)
sp01452	Actuator Calibration Test	HVAC (Heating Ventilation Air-Conditioning And Cooling)
sp01453	Initialize EPPM	EPPM (Electronic Pedestrian Protection Module)
sp01454	Configure License Plate Size	EPB (Electrical Parking Brake)
sp01455	System Wiring Test	EPB (Electrical Parking Brake)
sp01456	Auto Door Lock	BCM (Body Control Module )
sp01457	Program Tire Size	BCM (Body Control Module )
sp01458	Exit Shipping Mode	BCM (Body Control Module )
sp01459	Cam Crank Relearn	PCM (Powertrain Control Module)
sp01460	Check PCM Odometer	PCM (Powertrain Control Module)
sp01461	Quicklearn (62TE)	PCM (Powertrain Control Module)
sp01462	Quicklearn (Non-RFE)	PCM (Powertrain Control Module)
sp01463	Reset Memory	PCM (Powertrain Control Module)
sp01464	Write Pinion Factor	PCM (Powertrain Control Module)
sp01465	EGR System Test	PCM (Powertrain Control Module)
sp01466	ETC Throttle Follower Test	PCM (Powertrain Control Module)
sp01467	Set Engine RPM	PCM (Powertrain Control Module)
sp01468	Shift Lever Position Test (62TE)	PCM (Powertrain Control Module)
sp01469	Shift Lever Position Test (Non-RFE)	PCM (Powertrain Control Module)
sp01470	ABS Bleed Brakes	ABS (Anti-Lock Braking System)
sp01471	Brake Pedal Calibration	ABS (Anti-Lock Braking System)
sp01472	Initialize ORC	SRS (Supplemental Inflatable Restraint System, ORC)
sp01473	Rollover Detection	SRS (Supplemental Inflatable Restraint System, ORC)
sp01474	Activate Driver And Passenger Head Restraint	SRS (Supplemental Inflatable Restraint System, ORC)
sp01475	Program Left Front Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp01476	Program Left Rear Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp01477	Program Right Front Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp01478	Program Right Rear Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp01479	Program Tire Sensor ID With TPM Tool	TPMS (Tire Pressure Monitoring System)
sp01480	Sensor Rolls Test	TPMS (Tire Pressure Monitoring System)

sp01481	Actuator Calibration Test	HVAC (Heating Ventilation Air-Conditioning And Cooling)
sp01482	Initialize EPPM	EPPM (Electronic Pedestrian Protection Module)
sp01483	Configure License Plate Size	EPB (Electrical Parking Brake)
sp01484	System Wiring Test	EPB (Electrical Parking Brake)
sp01485	Auto Door Lock	BCM (Body Control Module )
sp01486	Program Tire Size	BCM (Body Control Module )
sp01487	Exit Shipping Mode	BCM (Body Control Module )
sp01488	Air Flow Meter Replacement	PCM (Powertrain Control Module)
sp01489	DPF Reset Option	PCM (Powertrain Control Module)
sp01490	Lambda Sensor Replace	PCM (Powertrain Control Module)
sp01491	Reset Of Lambda Values	PCM (Powertrain Control Module)
sp01492	Reset Oil Change Indicator	PCM (Powertrain Control Module)
sp01493	Reset Zero Fuel Quantity Calibration	PCM (Powertrain Control Module)
sp01494	Service Diesel Particulate Filter Regeneration	PCM (Powertrain Control Module)
sp01495	Throttle Valve Learn	PCM (Powertrain Control Module)
sp01496	ABS Bleed Brakes	ABS (Anti-Lock Braking System)
sp01497	Brake Pedal Calibration	ABS (Anti-Lock Braking System)
sp01498	Initialize ORC	SRS (Supplemental Inflatable Restraint System, ORC)
sp01499	Rollover Detection	SRS (Supplemental Inflatable Restraint System, ORC)
sp01500	Activate Driver And Passenger Head Restraint	SRS (Supplemental Inflatable Restraint System, ORC)
sp01501	Program Left Front Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp01502	Program Left Rear Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp01503	Program Right Front Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp01504	Program Right Rear Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp01505	Program Tire Sensor ID With TPM Tool	TPMS (Tire Pressure Monitoring System)
sp01506	Sensor Rolls Test	TPMS (Tire Pressure Monitoring System)
sp01507	Actuator Calibration Test	HVAC (Heating Ventilation Air-Conditioning And Cooling)
sp01508	Initialize EPPM	EPPM (Electronic Pedestrian Protection Module)
sp01509	Configure License Plate Size	EPB (Electrical Parking Brake)
sp01510	System Wiring Test	EPB (Electrical Parking Brake)
sp01511	Auto Door Lock	BCM (Body Control Module )
sp01512	Program Tire Size	BCM (Body Control Module )
sp01513	Exit Shipping Mode	BCM (Body Control Module )
sp01514	Air Flow Meter Replacement	PCM (Powertrain Control Module)
sp01515	DPF Reset Option	PCM (Powertrain Control Module)
sp01516	Lambda Sensor Replace	PCM (Powertrain Control Module)
sp01517	Reset Of Lambda Values	PCM (Powertrain Control Module)
sp01518	Reset Oil Change Indicator	PCM (Powertrain Control Module)
sp01519	Reset Zero Fuel Quantity Calibration	PCM (Powertrain Control Module)
sp01520	Service Diesel Particulate Filter Regeneration	PCM (Powertrain Control Module)
sp01521	Throttle Valve Learn	PCM (Powertrain Control Module)
sp01522	ABS Bleed Brakes	ABS (Anti-Lock Braking System)
sp01523	Brake Pedal Calibration	ABS (Anti-Lock Braking System)
sp01524	Initialize ORC	SRS (Supplemental Inflatable Restraint System, ORC)
sp01525	Rollover Detection	SRS (Supplemental Inflatable Restraint System, ORC)
sp01526	Activate Driver And Passenger Head Restraint	SRS (Supplemental Inflatable Restraint System, ORC)
sp01527	Program Left Front Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp01528	Program Left Rear Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp01529	Program Right Front Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp01530	Program Right Rear Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp01531	Program Tire Sensor ID With TPM Tool	TPMS (Tire Pressure Monitoring System)
sp01532	Sensor Rolls Test	TPMS (Tire Pressure Monitoring System)
sp01533	Actuator Calibration Test	HVAC (Heating Ventilation Air-Conditioning And Cooling)
sp01534	Initialize EPPM	EPPM (Electronic Pedestrian Protection Module)
sp01535	Configure License Plate Size	EPB (Electrical Parking Brake)

sp01536	System Wiring Test	EPB (Electrical Parking Brake)
sp01537	Auto Door Lock	BCM (Body Control Module )
sp01538	Program Tire Size	BCM (Body Control Module )
sp01539	Exit Shipping Mode	BCM (Body Control Module )
sp01540	Air Flow Meter Replacement	PCM (Powertrain Control Module)
sp01541	DPF Reset Option	PCM (Powertrain Control Module)
sp01542	Lambda Sensor Replace	PCM (Powertrain Control Module)
sp01543	Reset Of Lambda Values	PCM (Powertrain Control Module)
sp01544	Reset Oil Change Indicator	PCM (Powertrain Control Module)
sp01545	Reset Zero Fuel Quantity Calibration	PCM (Powertrain Control Module)
sp01546	Service Diesel Particulate Filter Regeneration	PCM (Powertrain Control Module)
sp01547	Throttle Valve Learn	PCM (Powertrain Control Module)
sp01548	ABS Bleed Brakes	ABS (Anti-Lock Braking System)
sp01549	Brake Pedal Calibration	ABS (Anti-Lock Braking System)
sp01550	Initialize ORC	SRS (Supplemental Inflatable Restraint System, ORC)
sp01551	Rollover Detection	SRS (Supplemental Inflatable Restraint System, ORC)
sp01552	Activate Driver And Passenger Head Restraint	SRS (Supplemental Inflatable Restraint System, ORC)
sp01553	Auto Door Lock	BCM (Body Control Module )
sp01554	Program Tire Size	BCM (Body Control Module )
sp01555	Exit Shipping Mode	BCM (Body Control Module )
sp01556	Program Left Front Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp01557	Program Left Rear Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp01558	Program Right Front Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp01559	Program Right Rear Tire Sensor ID	TPMS (Tire Pressure Monitoring System)
sp01560	Program Tire Sensor ID With TPM Tool	TPMS (Tire Pressure Monitoring System)
sp01561	Sensor Rolls Test	TPMS (Tire Pressure Monitoring System)
sp01562	Actuator Calibration Test	HVAC (Heating Ventilation Air-Conditioning And Cooling)
sp01563	Configure License Plate Size	EPB (Electrical Parking Brake)
sp01564	System Wiring Test	EPB (Electrical Parking Brake)
sp01565	Air Flow Meter Replacement	PCM (Powertrain Control Module)
sp01566	DPF Reset Option	PCM (Powertrain Control Module)
sp01567	Lambda Sensor Replace	PCM (Powertrain Control Module)
sp01568	Reset Of Lambda Values	PCM (Powertrain Control Module)
sp01569	Reset Oil Change Indicator	PCM (Powertrain Control Module)
sp01570	Reset Zero Fuel Quantity Calibration	PCM (Powertrain Control Module)
sp01571	Service Diesel Particulate Filter Regeneration	PCM (Powertrain Control Module)
sp01572	Throttle Valve Learn	PCM (Powertrain Control Module)
sp01573	ABS Bleed Brakes	ABS (Anti-Lock Braking System)
sp01574	Brake Pedal Calibration	ABS (Anti-Lock Braking System)
sp01575	Initialize ORC	SRS (Supplemental Inflatable Restraint System, ORC)
sp01576	Rollover Detection	SRS (Supplemental Inflatable Restraint System, ORC)
sp01577	Activate Driver And Passenger Head Restraint	SRS (Supplemental Inflatable Restraint System, ORC)
sp01578	Auto Door Lock	BCM (Body Control Module)
sp01579	Program Tire Size	BCM (Body Control Module)
sp01580	Exit Shipping Mode	BCM (Body Control Module)
sp01581	Initialize EPPM	EPPM (Electronic Pedestrian Protection Module)
sp01582	Program Tire Sensor ID With TPM Tool	TPMS (Tire Pressure Monitoring System)
sp01583	Actuator Calibration Test	HVAC (Heating Ventilation Air-Conditioning And Cooling)
sp01584	Configure License Plate Size	Electronic Parking(EPB)
sp01585	System Wiring Test	Electronic Parking(EPB)
sp01586	Air Flow Meter Replacement	PCM (Powertrain Control Module)
sp01587	DPF Reset Option	PCM (Powertrain Control Module)
sp01588	Lambda Sensor Replace	PCM (Powertrain Control Module)
sp01589	Reset Of Lambda Values	PCM (Powertrain Control Module)

sp01590	Reset Oil Change Indicator	PCM (Powertrain Control Module)
sp01591	Reset Zero Fuel Quantity Calibration	PCM (Powertrain Control Module)
sp01592	Service Diesel Particulate Filter Regeneration	PCM (Powertrain Control Module)
sp01593	Throttle Valve Learn	PCM (Powertrain Control Module)
sp01594	ABS Bleed Brakes	ABS (Anti-Lock Braking System)
sp01595	Brake Pedal Calibration	ABS (Anti-Lock Braking System)
sp01596	Initialize ORC	SRS (Supplemental Inflatable Restraint System, ORC)
sp01597	Rollover Detection	SRS (Supplemental Inflatable Restraint System, ORC)
sp01598	Activate Driver And Passenger Head Restraint	SRS (Supplemental Inflatable Restraint System, ORC)
sp01599	ECM Proxi Alignment	ECM (Engine Control Module)
sp01600	Reset Adaptative Parameter	ECM (Engine Control Module)
sp01601	Vehicle Configuration Reset	ECM (Engine Control Module)
sp01602	Self Learning Throttle Body Activation	ECM (Engine Control Module)
sp01603	General Stop Actuator	ECM (Engine Control Module)
sp01604	Reset Functions Self Learned	TCM (Transmission Control Module)
sp01605	Disabling All Actuators	TCM (Transmission Control Module)
sp01606	Shutdown Actuators	TCM (Transmission Control Module)
sp01607	Learn Clutches Contact Point	TCM (Transmission Control Module)
sp01608	Quick Learn	TCM (Transmission Control Module)
sp01609	Hydraulic Circuit Depressurization	TCM (Transmission Control Module)
sp01610	Bleed Hydraulic Circuit	TCM (Transmission Control Module)
sp01611	MTA Proxi Configuration	TCM (Transmission Control Module)
sp01612	ECU Replacement With Value Transfer	TCM (Transmission Control Module)
sp01613	New Actuators	TCM (Transmission Control Module)
sp01614	Reset TPMS Calibration	ABS (Anti Lock Brakes)
sp01615	ORC Proxi Alignment	ORC (Occupant Restraint)
sp01616	Reset Parameter.	LTM (Low Telematic Module)
sp01617	Reset Parameter.	ETM (Entertainment Telematic Module)
sp01618	Reset Parameter	ETM (Entertainment Telematic Module)
sp01619	Reset Functions Self Learned	DMM (Doors Management Module)
sp01620	Disabling All Actuators	DMM (Doors Management Module)
sp01621	Shutdown Actuators	DMM (Doors Management Module)
sp01622	Learn Clutches Contact Point	DMM (Doors Management Module)
sp01623	Quick Learn	DMM (Doors Management Module)
sp01624	Hydraulic Circuit Depressurization	DMM (Doors Management Module)
sp01625	Bleed Hydraulic Circuit	DMM (Doors Management Module)
sp01626	MTA Proxi Configuration	DMM (Doors Management Module)
sp01627	ECU Replacement With Value Transfer	DMM (Doors Management Module)
sp01628	New Actuators	DMM (Doors Management Module)
sp01629	Lock Doors Command	BCM (Body Control Module)
sp01630	Wind Shield Wiper	BCM (Body Control Module)
sp01631	Rear Window Washer Command	BCM (Body Control Module)
sp01632	Unlock Doors Command	BCM (Body Control Module)
sp01633	Rear Window Wiper Command	BCM (Body Control Module)
sp01634	Siren Command	BCM (Body Control Module)
sp01635	ECM Proxi Alignment	ECM (Engine Control Module)
sp01636	Reset Adaptative Parameter	ECM (Engine Control Module)
sp01637	Vehicle Configuration Reset	ECM (Engine Control Module)
sp01638	Self Learning Throttle Body Activation	ECM (Engine Control Module)
sp01639	General Stop Actuator	ECM (Engine Control Module)
sp01640	Reset Functions Self Learned	TCM (Transmission Control Module)
sp01641	Disabling All Actuators	TCM (Transmission Control Module)
sp01642	Shutdown Actuators	TCM (Transmission Control Module)
sp01643	Learn Clutches Contact Point	TCM (Transmission Control Module)
sp01644	Quick Learn	TCM (Transmission Control Module)

sp01645	Hydraulic Circuit Depressurization	TCM (Transmission Control Module)
sp01646	Bleed Hydraulic Circuit	TCM (Transmission Control Module)
sp01647	MTA Proxi Configuration	TCM (Transmission Control Module)
sp01648	ECU Replacement With Value Transfer	TCM (Transmission Control Module)
sp01649	New Actuators	TCM (Transmission Control Module)
sp01650	Reset TPMS Calibration	ABS (Anti Lock Brakes)
sp01651	ORC Proxi Alignment	ORC (Occupant Restraint)
sp01652	Reset Parameter.	LTM (Low Telematic Module)
sp01653	Reset Parameter.	ETM (Entertainment Telematic Module)
sp01654	Reset Parameter	ETM (Entertainment Telematic Module)
sp01655	Reset Functions Self Learned	DMM (Doors Management Module)
sp01656	Disabling All Actuators	DMM (Doors Management Module)
sp01657	Shutdown Actuators	DMM (Doors Management Module)
sp01658	Learn Clutches Contact Point	DMM (Doors Management Module)
sp01659	Quick Learn	DMM (Doors Management Module)
sp01660	Hydraulic Circuit Depressurization	DMM (Doors Management Module)
sp01661	Bleed Hydraulic Circuit	DMM (Doors Management Module)
sp01662	MTA Proxi Configuration	DMM (Doors Management Module)
sp01663	ECU Replacement With Value Transfer	DMM (Doors Management Module)
sp01664	New Actuators	DMM (Doors Management Module)
sp01665	Lock Doors Command	BCM (Body Control Module)
sp01666	Wind Shield Wiper	BCM (Body Control Module)
sp01667	Rear Window Washer Command	BCM (Body Control Module)
sp01668	Unlock Doors Command	BCM (Body Control Module)
sp01669	Rear Window Wiper Command	BCM (Body Control Module)
sp01670	Siren Command	BCM (Body Control Module)
sp01671	ECM Proxi Alignment	ECM (Engine Control Module)
sp01672	Reset Adaptative Parameter	ECM (Engine Control Module)
sp01673	Vehicle Configuration Reset	ECM (Engine Control Module)
sp01674	Self Learning Throttle Body Activation	ECM (Engine Control Module)
sp01675	General Stop Actuator	ECM (Engine Control Module)
sp01676	Reset Functions Self Learned	TCM (Transmission Control Module)
sp01677	Disabling All Actuators	TCM (Transmission Control Module)
sp01678	Shutdown Actuators	TCM (Transmission Control Module)
sp01679	Learn Clutches Contact Point	TCM (Transmission Control Module)
sp01680	Quick Learn	TCM (Transmission Control Module)
sp01681	Hydraulic Circuit Depressurization	TCM (Transmission Control Module)
sp01682	Bleed Hydraulic Circuit	TCM (Transmission Control Module)
sp01683	MTA Proxi Configuration	TCM (Transmission Control Module)
sp01684	ECU Replacement With Value Transfer	TCM (Transmission Control Module)
sp01685	New Actuators	TCM (Transmission Control Module)
sp01686	Reset TPMS Calibration	ABS (Anti Lock Brakes)
sp01687	ORC Proxi Alignment	ORC (Occupant Restraint)
sp01688	Reset Parameter.	LTM (Low Telematic Module)
sp01689	Reset Parameter.	ETM (Entertainment Telematic Module)
sp01690	Reset Parameter	ETM (Entertainment Telematic Module)
sp01691	Reset Functions Self Learned	DMM (Doors Management Module)
sp01692	Disabling All Actuators	DMM (Doors Management Module)
sp01693	Shutdown Actuators	DMM (Doors Management Module)
sp01694	Learn Clutches Contact Point	DMM (Doors Management Module)
sp01695	Quick Learn	DMM (Doors Management Module)
sp01696	Hydraulic Circuit Depressurization	DMM (Doors Management Module)
sp01697	Bleed Hydraulic Circuit	DMM (Doors Management Module)
sp01698	MTA Proxi Configuration	DMM (Doors Management Module)
sp01699	ECU Replacement With Value Transfer	DMM (Doors Management Module)

sp01700	New Actuators	DMM (Doors Management Module)
sp01701	Lock Doors Command	BCM (Body Control Module)
sp01702	Wind Shield Wiper	BCM (Body Control Module)
sp01703	Rear Window Washer Command	BCM (Body Control Module)
sp01704	Unlock Doors Command	BCM (Body Control Module)
sp01705	Rear Window Wiper Command	BCM (Body Control Module)
sp01706	Siren Command	BCM (Body Control Module)
sp01707	ECM Proxi Alignment	ECM (Engine Control Module)
sp01708	Reset Adaptative Parameter	ECM (Engine Control Module)
sp01709	Vehicle Configuration Reset	ECM (Engine Control Module)
sp01710	Self Learning Throttle Body Activation	ECM (Engine Control Module)
sp01711	General Stop Actuator	ECM (Engine Control Module)
sp01712	Reset Functions Self Learned	TCM (Transmission Control Module)
sp01713	Disabling All Actuators	TCM (Transmission Control Module)
sp01714	Shutdown Actuators	TCM (Transmission Control Module)
sp01715	Learn Clutches Contact Point	TCM (Transmission Control Module)
sp01716	Quick Learn	TCM (Transmission Control Module)
sp01717	Hydraulic Circuit Depressurization	TCM (Transmission Control Module)
sp01718	Bleed Hydraulic Circuit	TCM (Transmission Control Module)
sp01719	MTA Proxi Configuration	TCM (Transmission Control Module)
sp01720	ECU Replacement With Value Transfer	TCM (Transmission Control Module)
sp01721	New Actuators	TCM (Transmission Control Module)
sp01722	Reset TPMS Calibration	ABS (Anti Lock Brakes)
sp01723	ORC Proxi Alignment	ORC (Occupant Restraint)
sp01724	Reset Parameter.	LTM (Low Telematic Module)
sp01725	Reset Parameter.	ETM (Entertainment Telematic Module)
sp01726	Reset Parameter	ETM (Entertainment Telematic Module)
sp01727	Reset Functions Self Learned	DMM (Doors Management Module)
sp01728	Disabling All Actuators	DMM (Doors Management Module)
sp01729	Shutdown Actuators	DMM (Doors Management Module)
sp01730	Learn Clutches Contact Point	DMM (Doors Management Module)
sp01731	Quick Learn	DMM (Doors Management Module)
sp01732	Hydraulic Circuit Depressurization	DMM (Doors Management Module)
sp01733	Bleed Hydraulic Circuit	DMM (Doors Management Module)
sp01734	MTA Proxi Configuration	DMM (Doors Management Module)
sp01735	ECU Replacement With Value Transfer	DMM (Doors Management Module)
sp01736	New Actuators	DMM (Doors Management Module)
sp01737	Lock Doors Command	BCM (Body Control Module)
sp01738	Wind Shield Wiper	BCM (Body Control Module)
sp01739	Rear Window Washer Command	BCM (Body Control Module)
sp01740	Unlock Doors Command	BCM (Body Control Module)
sp01741	Rear Window Wiper Command	BCM (Body Control Module)
sp01742	Siren Command	BCM (Body Control Module)
sp01743	ECM Proxi Alignment	ECM (Engine Control Module)
sp01744	Reset Adaptative Parameter	ECM (Engine Control Module)
sp01745	Vehicle Configuration Reset	ECM (Engine Control Module)
sp01746	Self Learning Throttle Body Activation	ECM (Engine Control Module)
sp01747	General Stop Actuator	ECM (Engine Control Module)
sp01748	Reset Functions Self Learned	TCM (Transmission Control Module)
sp01749	Disabling All Actuators	TCM (Transmission Control Module)
sp01750	Shutdown Actuators	TCM (Transmission Control Module)
sp01751	Learn Clutches Contact Point	TCM (Transmission Control Module)
sp01752	Quick Learn	TCM (Transmission Control Module)
sp01753	Hydraulic Circuit Depressurization	TCM (Transmission Control Module)
sp01754	Bleed Hydraulic Circuit	TCM (Transmission Control Module)

sp01755	MTA Proxi Configuration	TCM (Transmission Control Module)
sp01756	ECU Replacement With Value Transfer	TCM (Transmission Control Module)
sp01757	New Actuators	TCM (Transmission Control Module)
sp01758	Reset TPMS Calibration	ABS (Anti Lock Brakes)
sp01759	ORC Proxi Alignment	ORC (Occupant Restraint)
sp01760	Reset Parameter.	LTM (Low Telematic Module)
sp01761	Reset Parameter.	ETM (Entertainment Telematic Module)
sp01762	Reset Parameter	ETM (Entertainment Telematic Module)
sp01763	Reset Functions Self Learned	DMM (Doors Management Module)
sp01764	Disabling All Actuators	DMM (Doors Management Module)
sp01765	Shutdown Actuators	DMM (Doors Management Module)
sp01766	Learn Clutches Contact Point	DMM (Doors Management Module)
sp01767	Quick Learn	DMM (Doors Management Module)
sp01768	Hydraulic Circuit Depressurization	DMM (Doors Management Module)
sp01769	Bleed Hydraulic Circuit	DMM (Doors Management Module)
sp01770	MTA Proxi Configuration	DMM (Doors Management Module)
sp01771	ECU Replacement With Value Transfer	DMM (Doors Management Module)
sp01772	New Actuators	DMM (Doors Management Module)
sp01773	Lock Doors Command	BCM (Body Control Module)
sp01774	Wind Shield Wiper	BCM (Body Control Module)
sp01775	Rear Window Washer Command	BCM (Body Control Module)
sp01776	Unlock Doors Command	BCM (Body Control Module)
sp01777	Rear Window Wiper Command	BCM (Body Control Module)
sp01778	Siren Command	BCM (Body Control Module)
sp01779	ECM Proxi Alignment	ECM (Engine Control Module)
sp01780	Reset Adaptative Parameter	ECM (Engine Control Module)
sp01781	Vehicle Configuration Reset	ECM (Engine Control Module)
sp01782	Self Learning Throttle Body Activation	ECM (Engine Control Module)
sp01783	General Stop Actuator	ECM (Engine Control Module)
sp01784	Reset Functions Self Learned	TCM (Transmission Control Module)
sp01785	Disabling All Actuators	TCM (Transmission Control Module)
sp01786	Shutdown Actuators	TCM (Transmission Control Module)
sp01787	Learn Clutches Contact Point	TCM (Transmission Control Module)
sp01788	Quick Learn	TCM (Transmission Control Module)
sp01789	Hydraulic Circuit Depressurization	TCM (Transmission Control Module)
sp01790	Bleed Hydraulic Circuit	TCM (Transmission Control Module)
sp01791	MTA Proxi Configuration	TCM (Transmission Control Module)
sp01792	ECU Replacement With Value Transfer	TCM (Transmission Control Module)
sp01793	New Actuators	TCM (Transmission Control Module)
sp01794	Reset TPMS Calibration	ABS (Anti Lock Brakes)
sp01795	ORC Proxi Alignment	ORC (Occupant Restraint)
sp01796	Reset Parameter.	LTM (Low Telematic Module)
sp01797	Reset Parameter.	ETM (Entertainment Telematic Module)
sp01798	Reset Parameter	ETM (Entertainment Telematic Module)
sp01799	Reset Functions Self Learned	DMM (Doors Management Module)
sp01800	Disabling All Actuators	DMM (Doors Management Module)
sp01801	Shutdown Actuators	DMM (Doors Management Module)
sp01802	Learn Clutches Contact Point	DMM (Doors Management Module)
sp01803	Quick Learn	DMM (Doors Management Module)
sp01804	Hydraulic Circuit Depressurization	DMM (Doors Management Module)
sp01805	Bleed Hydraulic Circuit	DMM (Doors Management Module)
sp01806	MTA Proxi Configuration	DMM (Doors Management Module)
sp01807	ECU Replacement With Value Transfer	DMM (Doors Management Module)



sp01808	New Actuators	DMM (Doors Management Module)
sp01809	Lock Doors Command	BCM (Body Control Module)
sp01810	Wind Shield Wiper	BCM (Body Control Module)
sp01811	Rear Window Washer Command	BCM (Body Control Module)
sp01812	Unlock Doors Command	BCM (Body Control Module)
sp01813	Rear Window Wiper Command	BCM (Body Control Module)
sp01814	Siren Command	BCM (Body Control Module)
sp01815	Impone AF Gasoline	ECM (Engine Control Module)
sp01816	Impone AF Learning	ECM (Engine Control Module)
sp01817	ECM Proxi Alignment	ECM (Engine Control Module)
sp01818	Vehicle Configuration Reset	ECM (Engine Control Module)
sp01819	Self Learning Throttle Body Activation	ECM (Engine Control Module)
sp01820	General Stop Actuator	ECM (Engine Control Module)
sp01821	Impone AF Alcool	ECM (Engine Control Module)
sp01822	Fuel Circuit Purge	ECM (Engine Control Module)
sp01823	Purge Fuel Circuit Reset	ECM (Engine Control Module)
sp01824	Clutch Pedal Learning	ECM (Engine Control Module)
sp01825	Reset Adaptative Parameter	ECM (Engine Control Module)
sp01826	Reset Functions Self Learned	TCM (Transmission Control Module)
sp01827	Disabling All Actuators	TCM (Transmission Control Module)
sp01828	Shutdown Actuators	TCM (Transmission Control Module)
sp01829	Learn Clutches Contact Point	TCM (Transmission Control Module)
sp01830	Quick Learn	TCM (Transmission Control Module)
sp01831	Hydraulic Circuit Depressurization	TCM (Transmission Control Module)
sp01832	Bleed Hydraulic Circuit	TCM (Transmission Control Module)
sp01833	MTA Proxi Configuration	TCM (Transmission Control Module)
sp01834	ECU Replacement With Value Transfer	TCM (Transmission Control Module)
sp01835	New Actuators	TCM (Transmission Control Module)
sp01836	Reset TPMS Calibration	ABS (Anti-Lock Braking System)
sp01837	ORC Proxi Alignment	SRS (Supplemental Inflatable Restraint System, ORC)
sp01838	Lock Doors Command	BCM (Body Control Module)
sp01839	Wind Shield Wiper	BCM (Body Control Module)
sp01840	Rear Window Washer Command	BCM (Body Control Module)
sp01841	Unlock Doors Command	BCM (Body Control Module)
sp01842	Rear Window Wiper Command	BCM (Body Control Module)
sp01843	Siren Command	BCM (Body Control Module)
sp01844	Reset Functions Self Learned	DMM (Doors Management Module)
sp01845	Disabling All Actuators	DMM (Doors Management Module)
sp01846	Shutdown Actuators	DMM (Doors Management Module)
sp01847	Learn Clutches Contact Point	DMM (Doors Management Module)
sp01848	Quick Learn	DMM (Doors Management Module)
sp01849	Hydraulic Circuit Depressurization	DMM (Doors Management Module)
sp01850	Bleed Hydraulic Circuit	DMM (Doors Management Module)
sp01851	MTA Proxi Configuration	DMM (Doors Management Module)
sp01852	ECU Replacement With Value Transfer	DMM (Doors Management Module)
sp01853	New Actuators	DMM (Doors Management Module)
sp01854	Impone AF Gasoline	ECM (Engine Control Module)
sp01855	Impone AF Learning	ECM (Engine Control Module)
sp01856	ECM Proxi Alignment	ECM (Engine Control Module)
sp01857	Vehicle Configuration Reset	ECM (Engine Control Module)
sp01858	Self Learning Throttle Body Activation	ECM (Engine Control Module)
sp01859	General Stop Actuator	ECM (Engine Control Module)
sp01860	Impone AF Alcool	ECM (Engine Control Module)
sp01861	Fuel Circuit Purge	ECM (Engine Control Module)



sp01862	Purge Fuel Circuit Reset	ECM (Engine Control Module)
sp01863	Clutch Pedal Learning	ECM (Engine Control Module)
sp01864	Reset Adaptative Parameter	ECM (Engine Control Module)
sp01865	Reset Functions Self Learned	TCM (Transmission Control Module)
sp01866	Disabling All Actuators	TCM (Transmission Control Module)
sp01867	Shutdown Actuators	TCM (Transmission Control Module)
sp01868	Learn Clutches Contact Point	TCM (Transmission Control Module)
sp01869	Quick Learn	TCM (Transmission Control Module)
sp01870	Hydraulic Circuit Depressurization	TCM (Transmission Control Module)
sp01871	Bleed Hydraulic Circuit	TCM (Transmission Control Module)
sp01872	MTA Proxi Configuration	TCM (Transmission Control Module)
sp01873	ECU Replacement With Value Transfer	TCM (Transmission Control Module)
sp01874	New Actuators	TCM (Transmission Control Module)
sp01875	Reset TPMS Calibration	ABS (Anti-Lock Braking System)
sp01876	ORC Proxi Alignment	SRS (Supplemental Inflatable Restraint System, ORC)
sp01877	Lock Doors Command	BCM (Body Control Module)
sp01878	Wind Shield Wiper	BCM (Body Control Module)
sp01879	Rear Window Washer Command	BCM (Body Control Module)
sp01880	Unlock Doors Command	BCM (Body Control Module)
sp01881	Rear Window Wiper Command	BCM (Body Control Module)
sp01882	Siren Command	BCM (Body Control Module)
sp01883	Reset Functions Self Learned	DMM (Doors Management Module)
sp01884	Disabling All Actuators	DMM (Doors Management Module)
sp01885	Shutdown Actuators	DMM (Doors Management Module)
sp01886	Learn Clutches Contact Point	DMM (Doors Management Module)
sp01887	Quick Learn	DMM (Doors Management Module)
sp01888	Hydraulic Circuit Depressurization	DMM (Doors Management Module)
sp01889	Bleed Hydraulic Circuit	DMM (Doors Management Module)
sp01890	MTA Proxi Configuration	DMM (Doors Management Module)
sp01891	ECU Replacement With Value Transfer	DMM (Doors Management Module)
sp01892	New Actuators	DMM (Doors Management Module)
sp01893	Impone AF Gasoline	ECM (Engine Control Module)
sp01894	Impone AF Learning	ECM (Engine Control Module)
sp01895	ECM Proxi Alignment	ECM (Engine Control Module)
sp01896	Vehicle Configuration Reset	ECM (Engine Control Module)
sp01897	Self Learning Throttle Body Activation	ECM (Engine Control Module)
sp01898	General Stop Actuator	ECM (Engine Control Module)
sp01899	Impone AF Alcool	ECM (Engine Control Module)
sp01900	Fuel Circuit Purge	ECM (Engine Control Module)
sp01901	Purge Fuel Circuit Reset	ECM (Engine Control Module)
sp01902	Clutch Pedal Learning	ECM (Engine Control Module)
sp01903	Reset Adaptative Parameter	ECM (Engine Control Module)
sp01904	Reset Functions Self Learned	TCM (Transmission Control Module)
sp01905	Disabling All Actuators	TCM (Transmission Control Module)
sp01906	Shutdown Actuators	TCM (Transmission Control Module)
sp01907	Learn Clutches Contact Point	TCM (Transmission Control Module)
sp01908	Quick Learn	TCM (Transmission Control Module)
sp01909	Hydraulic Circuit Depressurization	TCM (Transmission Control Module)
sp01910	Bleed Hydraulic Circuit	TCM (Transmission Control Module)
sp01911	MTA Proxi Configuration	TCM (Transmission Control Module)
sp01912	ECU Replacement With Value Transfer	TCM (Transmission Control Module)
sp01913	New Actuators	TCM (Transmission Control Module)
sp01914	Reset TPMS Calibration	ABS (Anti-Lock Braking System)

sp01915	ORC Proxi Alignment	SRS (Supplemental Inflatable Restraint System, ORC)
sp01916	Lock Doors Command	BCM (Body Control Module)
sp01917	Wind Shield Wiper	BCM (Body Control Module)
sp01918	Rear Window Washer Command	BCM (Body Control Module)
sp01919	Unlock Doors Command	BCM (Body Control Module)
sp01920	Rear Window Wiper Command	BCM (Body Control Module)
sp01921	Siren Command	BCM (Body Control Module)
sp01922	Reset Functions Self Learned	DMM (Doors Management Module)
sp01923	Disabling All Actuators	DMM (Doors Management Module)
sp01924	Shutdown Actuators	DMM (Doors Management Module)
sp01925	Learn Clutches Contact Point	DMM (Doors Management Module)
sp01926	Quick Learn	DMM (Doors Management Module)
sp01927	Hydraulic Circuit Depressurization	DMM (Doors Management Module)
sp01928	Bleed Hydraulic Circuit	DMM (Doors Management Module)
sp01929	MTA Proxi Configuration	DMM (Doors Management Module)
sp01930	ECU Replacement With Value Transfer	DMM (Doors Management Module)
sp01931	New Actuators	DMM (Doors Management Module)
sp01932	Impone AF Gasoline	ECM (Engine Control Module)
sp01933	Impone AF Learning	ECM (Engine Control Module)
sp01934	ECM Proxi Alignment	ECM (Engine Control Module)
sp01935	Vehicle Configuration Reset	ECM (Engine Control Module)
sp01936	Self Learning Throttle Body Activation	ECM (Engine Control Module)
sp01937	General Stop Actuator	ECM (Engine Control Module)
sp01938	Impone AF Alcool	ECM (Engine Control Module)
sp01939	Fuel Circuit Purge	ECM (Engine Control Module)
sp01940	Purge Fuel Circuit Reset	ECM (Engine Control Module)
sp01941	Clutch Pedal Learning	ECM (Engine Control Module)
sp01942	Reset Adaptative Parameter	ECM (Engine Control Module)
sp01943	Reset Functions Self Learned	TCM (Transmission Control Module)
sp01944	Disabling All Actuators	TCM (Transmission Control Module)
sp01945	Shutdown Actuators	TCM (Transmission Control Module)
sp01946	Learn Clutches Contact Point	TCM (Transmission Control Module)
sp01947	Quick Learn	TCM (Transmission Control Module)
sp01948	Hydraulic Circuit Depressurization	TCM (Transmission Control Module)
sp01949	Bleed Hydraulic Circuit	TCM (Transmission Control Module)
sp01950	MTA Proxi Configuration	TCM (Transmission Control Module)
sp01951	ECU Replacement With Value Transfer	TCM (Transmission Control Module)
sp01952	New Actuators	TCM (Transmission Control Module)
sp01953	Reset TPMS Calibration	ABS (Anti-Lock Braking System)
sp01954	ORC Proxi Alignment	SRS (Supplemental Inflatable Restraint System, ORC)
sp01955	Lock Doors Command	BCM (Body Control Module)
sp01956	Wind Shield Wiper	BCM (Body Control Module)
sp01957	Rear Window Washer Command	BCM (Body Control Module)
sp01958	Unlock Doors Command	BCM (Body Control Module)
sp01959	Rear Window Wiper Command	BCM (Body Control Module)
sp01960	Siren Command	BCM (Body Control Module)
sp01961	Reset Functions Self Learned	DMM (Doors Management Module)
sp01962	Disabling All Actuators	DMM (Doors Management Module)
sp01963	Shutdown Actuators	DMM (Doors Management Module)
sp01964	Learn Clutches Contact Point	DMM (Doors Management Module)
sp01965	Quick Learn	DMM (Doors Management Module)
sp01966	Hydraulic Circuit Depressurization	DMM (Doors Management Module)
sp01967	Bleed Hydraulic Circuit	DMM (Doors Management Module)
sp01968	MTA Proxi Configuration	DMM (Doors Management Module)
sp01969	ECU Replacement With Value Transfer	DMM (Doors Management Module)

sp01970	New Actuators	DMM (Doors Management Module)
sp01971	Impone AF Gasoline	ECM (Engine Control Module)
sp01972	Impone AF Learning	ECM (Engine Control Module)
sp01973	ECM Proxi Alignment	ECM (Engine Control Module)
sp01974	Vehicle Configuration Reset	ECM (Engine Control Module)
sp01975	Self Learning Throttle Body Activation	ECM (Engine Control Module)
sp01976	General Stop Actuator	ECM (Engine Control Module)
sp01977	Impone AF Alcool	ECM (Engine Control Module)
sp01978	Fuel Circuit Purge	ECM (Engine Control Module)
sp01979	Purge Fuel Circuit Reset	ECM (Engine Control Module)
sp01980	Clutch Pedal Learning	ECM (Engine Control Module)
sp01981	Reset Adaptative Parameter	ECM (Engine Control Module)
sp01982	Reset Functions Self Learned	TCM (Transmission Control Module)
sp01983	Disabling All Actuators	TCM (Transmission Control Module)
sp01984	Shutdown Actuators	TCM (Transmission Control Module)
sp01985	Learn Clutches Contact Point	TCM (Transmission Control Module)
sp01986	Quick Learn	TCM (Transmission Control Module)
sp01987	Hydraulic Circuit Depressurization	TCM (Transmission Control Module)
sp01988	Bleed Hydraulic Circuit	TCM (Transmission Control Module)
sp01989	MTA Proxi Configuration	TCM (Transmission Control Module)
sp01990	ECU Replacement With Value Transfer	TCM (Transmission Control Module)
sp01991	New Actuators	TCM (Transmission Control Module)
sp01992	Reset TPMS Calibration	ABS (Anti Lock Brakes)
sp01993	ORC Proxi Alignment	ORC (Occupant Restraint)
sp01994	Reset Functions Self Learned	DMM (Doors Management Module)
sp01995	Disabling All Actuators	DMM (Doors Management Module)
sp01996	Shutdown Actuators	DMM (Doors Management Module)
sp01997	Learn Clutches Contact Point	DMM (Doors Management Module)
sp01998	Quick Learn	DMM (Doors Management Module)
sp01999	Hydraulic Circuit Depressurization	DMM (Doors Management Module)
sp02000	Bleed Hydraulic Circuit	DMM (Doors Management Module)
sp02001	MTA Proxi Configuration	DMM (Doors Management Module)
sp02002	ECU Replacement With Value Transfer	DMM (Doors Management Module)
sp02003	New Actuators	DMM (Doors Management Module)
sp02004	Lock Doors Command	BCM (Body Control Module)
sp02005	Wind Shield Wiper	BCM (Body Control Module)
sp02006	Rear Window Washer Command	BCM (Body Control Module)
sp02007	Unlock Doors Command	BCM (Body Control Module)
sp02008	Rear Window Wiper Command	BCM (Body Control Module)
sp02009	Siren Command	BCM (Body Control Module)
sp02010	Deactivation Of The Power Limitation Function	ECM (Engine Control Module)
sp02011	Fan Cooling Activation	ECM (Engine Control Module)
sp02012	Self-Adaptive Parameters Reset	ECM (Engine Control Module)
sp02013	Self-Learnt Functions Reset	ECM (Engine Control Module)
sp02014	Gearbox Replacement	TCM (Transmission Control Module)
sp02015	Lever Release Solenoid Command	TCM (Transmission Control Module)
sp02016	Static Test	ABS (Anti-Lock Braking System)
sp02017	Trailer Hook Presence Disabling	PAM (Parking Aid Module)
sp02018	Trailer Hook Presence Enabling	PAM (Parking Aid Module)
sp02019	Reset Odometer	IC (Instrument Cluster)
sp02020	Reset Service Information	IC (Instrument Cluster)
sp02021	Disable Seat Belts Reminder	IC (Instrument Cluster)
sp02022	Enable Seat Belts Reminder	IC (Instrument Cluster)
sp02023	Last Service Date	IC (Instrument Cluster)

sp02024	Actuator Calibration Test	HVAC (Heating Ventilation Air-Conditioning And Cooling)
sp02025	Fire Protection System Activate	BCM (Body Control Module )
sp02026	Deactivation Of The Power Limitation Function	ECM (Engine Control Module)
sp02027	Fan Cooling Activation	ECM (Engine Control Module)
sp02028	Self-Adaptive Parameters Reset	ECM (Engine Control Module)
sp02029	Self-Learnt Functions Reset	ECM (Engine Control Module)
sp02030	Gearbox Replacement	TCM (Transmission Control Module)
sp02031	Lever Release Solenoid Command	TCM (Transmission Control Module)
sp02032	Static Test	ABS (Anti-Lock Braking System)
sp02033	Trailer Hook Presence Disabling	PAM (Parking Aid Module)
sp02034	Trailer Hook Presence Enabling	PAM (Parking Aid Module)
sp02035	Reset Odometer	IC (Instrument Cluster)
sp02036	Reset Service Information	IC (Instrument Cluster)
sp02037	Disable Seat Belts Reminder	IC (Instrument Cluster)
sp02038	Enable Seat Belts Reminder	IC (Instrument Cluster)
sp02039	Last Service Date	IC (Instrument Cluster)
sp02040	Actuator Calibration Test	HVAC (Heating Ventilation Air-Conditioning And Cooling)
sp02041	Fire Protection System Activate	BCM (Body Control Module )
sp02042	Fire Protection System Activate	BCM (Body Control Module)
sp02043	Reset Adaptive Parameters	PCM (Powertrain Control Module)
sp02044	Reset Phases Front	PCM (Powertrain Control Module)
sp02045	Self Learning Throttle Body	PCM (Powertrain Control Module)
sp02046	Tunnel Lever Replacement	TCM (Transmission Control Module)
sp02047	Pump Relay Replacement	TCM (Transmission Control Module)
sp02048	Self-Learnt Functions Reset	TCM (Transmission Control Module)
sp02049	Static Test	ABS (Anti-Lock Braking System)
sp02050	Enable Tow Hook Presence	PTS (Parktronics)
sp02051	Disable Tow Hook Presence	PTS (Parktronics)
sp02052	Reset Odometer	IC (Instrument Cluster)
sp02053	Reset Service Information	IC (Instrument Cluster)
sp02054	Disable Seat Belts Reminder	IC (Instrument Cluster)
sp02055	Last Service Date	IC (Instrument Cluster)
sp02056	Enable Seat Belts Reminder	IC (Instrument Cluster)
sp02057	Flap Actuators Learning Test	HVAC (Heating Ventilation Air-Conditioning And Cooling)
sp02058	Injector Codes Read	ECM (Engine Control Module)
sp02059	Rail Pressure Sensor Replacement	ECM (Engine Control Module)
sp02060	Phonic Wheel Replacement	ECM (Engine Control Module)
sp02061	Replacement Lambda Sensor	ECM (Engine Control Module)
sp02062	Cylinder 1 Injector Replacement	ECM (Engine Control Module)
sp02063	Cylinder 2 Injector Replacement	ECM (Engine Control Module)
sp02064	Cylinder 3 Injector Replacement	ECM (Engine Control Module)
sp02065	Injector Replacement (Per Bank)	ECM (Engine Control Module)
sp02066	Rail Pressure Sensor And Injector/S Replacement	ECM (Engine Control Module)
sp02067	Self-Learnt Functions Reset	ECM (Engine Control Module)
sp02068	Tunnel Lever Replacement	TCM (Transmission Control Module)
sp02069	Levers At Wheel Replacement	TCM (Transmission Control Module)
sp02070	Pump Relay Replacement	TCM (Transmission Control Module)
sp02071	Self-Learnt Functions Reset	TCM (Transmission Control Module)
sp02072	Longitudinal And Lateral Sensor Decalibration	ABS (Anti-Lock Braking System)
sp02073	Longitudinal And Lateral Sensor Calibration	ABS (Anti-Lock Braking System)
sp02074	Static Test	ABS (Anti-Lock Braking System)
sp02075	Alarms Deletion	TPMS (Tire Pressure Monitoring System)
sp02076	Antenna Replacement	TPMS (Tire Pressure Monitoring System)
sp02077	Control Unit Activation	TPMS (Tire Pressure Monitoring System)

sp02078	Control Unit Deactivation	TPMS (Tire Pressure Monitoring System)
sp02079	Manual System Configuration	TPMS (Tire Pressure Monitoring System)
sp02080	Automatic Configuration Read	TPMS (Tire Pressure Monitoring System)
sp02081	Wheel Transmitters Learning	TPMS (Tire Pressure Monitoring System)
sp02082	Automatic Configuration Write	TPMS (Tire Pressure Monitoring System)
sp02083	Trailer Hook Presence Disabling	PAM (Parking Aid Module)
sp02084	Trailer Hook Presence Enabling	PAM (Parking Aid Module)
sp02085	Enable Seat Belts Reminder	IC (Instrument Cluster)
sp02086	Disable Seat Belts Reminder	IC (Instrument Cluster)
sp02087	Reset Odometer	IC (Instrument Cluster)
sp02088	Reset Service Information	IC (Instrument Cluster)
sp02089	Last Service Date	IC (Instrument Cluster)
sp02090	Self Learning Motor Test	HVAC (Heating Ventilation Air-Conditioning And Cooling)
sp02091	ECU Restart Routine	CTM (Convergence Telematic Module)
sp02092	Fire Protection System Activate	BCM (Body Control Module )
sp02093	Differential Pressure Sensor Replac.	ECM (Engine Control Module)
sp02094	Oil Change	ECM (Engine Control Module)
sp02095	Injector Replacement (Per Bank)	ECM (Engine Control Module)
sp02096	Injector Codes Read	ECM (Engine Control Module)
sp02097	Rail Pressure Sensor Replacement	ECM (Engine Control Module)
sp02098	Cylinder 3 Injector Replacement	ECM (Engine Control Module)
sp02099	Cylinder 2 Injector Replacement	ECM (Engine Control Module)
sp02100	Cylinder 1 Injector Replacement	ECM (Engine Control Module)
sp02101	Phonic Wheel Replacement	ECM (Engine Control Module)
sp02102	Replacement Lambda Sensor	ECM (Engine Control Module)
sp02103	Neutral Signal Learn	ECM (Engine Control Module)
sp02104	EGR Valve Test	ECM (Engine Control Module)
sp02105	Glow Plug Preheating Circuit Test	ECM (Engine Control Module)
sp02106	Self-Learnt Functions Reset	ECM (Engine Control Module)
sp02107	Resetting Distance Travelled With Water In Diesel W.Lamp ON	ECM (Engine Control Module)
sp02108	Throttle Valve Test	ECM (Engine Control Module)
sp02109	Resetting Distance Travelled With Water Temperature Warning Lamp ON	ECM (Engine Control Module)
sp02110	Fan Cooling Activation	ECM (Engine Control Module)
sp02111	Speed Limit Setting	ECM (Engine Control Module)
sp02112	Tunnel Lever Replacement	TCM (Transmission Control Module)
sp02113	Pump Relay Replacement	TCM (Transmission Control Module)
sp02114	Self-Learnt Functions Reset	TCM (Transmission Control Module)
sp02115	Longitudinal And Lateral Sensor Decalibration	ABS (Anti-Lock Braking System)
sp02116	Longitudinal And Lateral Sensor Calibration	ABS (Anti-Lock Braking System)
sp02117	Static Test	ABS (Anti-Lock Braking System)
sp02118	Reset Odometer	IC (Instrument Cluster)
sp02119	Enable Seat Belts Reminder	IC (Instrument Cluster)
sp02120	Disable Seat Belts Reminder	IC (Instrument Cluster)
sp02121	ECU Restart Routine	CTM (Convergence Telematic Module)
sp02122	Trailer Hook Presence Disabling	AHM (Additional Heater Module)
sp02123	Trailer Hook Presence Enabling	AHM (Additional Heater Module)
sp02124	Fuel Circuit Purge	ECM (Engine Control Module)
sp02125	General Stop Actuator	ECM (Engine Control Module)
sp02126	Reset Adaptive Parameter	ECM (Engine Control Module)
sp02127	Reset Purge Fuel Circuit	ECM (Engine Control Module)
sp02128	Reset Phonic Wheel Tooth Learn	ECM (Engine Control Module)
sp02129	Reset Camshaft Adaptive	ECM (Engine Control Module)
sp02130	Steering Angle Sensor	EPS (Electric Power Steering)
sp02131	Clear TPM Sensor Audit	RFH (Radio Frequency Hub)
sp02132	Clear TPM Sensor Warnings	RFH (Radio Frequency Hub)

sp02133	Trailer Hook Presence Disabling	PAM (Parking Aid Module)
sp02134	Trailer Hook Presence Enabling	PAM (Parking Aid Module)
sp02135	Reset Odometer	IPC (Instrument Panel Cluster)
sp02136	Self Learning Motors Test	HVAC (Heat, Ventilation And A/C)
sp02137	Service Single Pole Calibration	HALF (Haptical Lane Feedback)
sp02138	Proxi Alignment Procedure	ESM (Electronic Shifter Module)
sp02139	Factory VIN code lock	ESM (Electronic Shifter Module)
sp02140	Driver Mirror Axis X Command	DMM (Doors Management Module)
sp02141	Driver Mirror Axis Y Command	DMM (Doors Management Module)
sp02142	Fire Protection System Activate	BCM (Body Control Module)
sp02143	Lock Doors Command	BCM (Body Control Module)
sp02144	Unlock Doors Command	BCM (Body Control Module)
sp02145	Check Siren	BCM (Body Control Module)
sp02146	Siren Command	BCM (Body Control Module)
sp02147	Cargo Unlock Relay	BCM (Body Control Module)
sp02148	Cargo Lock Relay	BCM (Body Control Module)
sp02149	Fuel Circuit Purge	ECM (Engine Control Module)
sp02150	General Stop Actuator	ECM (Engine Control Module)
sp02151	Reset Adaptative Parameter	ECM (Engine Control Module)
sp02152	Reset Purge Fuel Circuit	ECM (Engine Control Module)
sp02153	Reset Phonic Wheel Tooth Learn	ECM (Engine Control Module)
sp02154	Reset Camshaft Adaptative	ECM (Engine Control Module)
sp02155	Steering Angle Sensor	EPS (Electric Power Steering)
sp02156	Clear TPM Sensor Audit	RFH (Radio Frequency Hub)
sp02157	Clear TPM Sensor Warnings	RFH (Radio Frequency Hub)
sp02158	Trailer Hook Presence Disabling	PAM (Parking Aid Module)
sp02159	Trailer Hook Presence Enabling	PAM (Parking Aid Module)
sp02160	Reset Odometer	IPC (Instrument Panel Cluster)
sp02161	Self Learning Motors Test	HVAC (Heat, Ventilation And A/C)
sp02162	Service Single Pole Calibration	HALF (Haptical Lane Feedback)
sp02163	Proxi Alignment Procedure	ESM (Electronic Shifter Module)
sp02164	Factory VIN code lock	ESM (Electronic Shifter Module)
sp02165	Driver Mirror Axis X Command	DMM (Doors Management Module)
sp02166	Driver Mirror Axis Y Command	DMM (Doors Management Module)
sp02167	Fire Protection System Activate	BCM (Body Control Module)
sp02168	Lock Doors Command	BCM (Body Control Module)
sp02169	Unlock Doors Command	BCM (Body Control Module)
sp02170	Check Siren	BCM (Body Control Module)
sp02171	Siren Command	BCM (Body Control Module)
sp02172	Cargo Unlock Relay	BCM (Body Control Module)
sp02173	Cargo Lock Relay	BCM (Body Control Module)
sp02174	Fuel Circuit Purge	ECM (Engine Control Module)
sp02175	General Stop Actuator	ECM (Engine Control Module)
sp02176	Reset Adaptative Parameter	ECM (Engine Control Module)
sp02177	Reset Purge Fuel Circuit	ECM (Engine Control Module)
sp02178	Reset Phonic Wheel Tooth Learn	ECM (Engine Control Module)
sp02179	Reset Camshaft Adaptative	ECM (Engine Control Module)
sp02180	Steering Angle Sensor	EPS (Electric Power Steering)
sp02181	Clear TPM Sensor Audit	RFH (Radio Frequency Hub)
sp02182	Clear TPM Sensor Warnings	RFH (Radio Frequency Hub)
sp02183	Trailer Hook Presence Disabling	PAM (Parking Aid Module)
sp02184	Trailer Hook Presence Enabling	PAM (Parking Aid Module)
sp02185	Reset Odometer	IPC (Instrument Panel Cluster)
sp02186	Self Learning Motors Test	HVAC (Heat, Ventilation And A/C)
sp02187	Service Single Pole Calibration	HALF (Haptical Lane Feedback)

sp02188	Proxi Alignment Procedure	ESM (Electronic Shifter Module)
sp02189	Factory VIN code lock	ESM (Electronic Shifter Module)
sp02190	Driver Mirror Axis X Command	DMM (Doors Management Module)
sp02191	Driver Mirror Axis Y Command	DMM (Doors Management Module)
sp02192	Fire Protection System Activate	BCM (Body Control Module)
sp02193	Lock Doors Command	BCM (Body Control Module)
sp02194	Unlock Doors Command	BCM (Body Control Module)
sp02195	Check Siren	BCM (Body Control Module)
sp02196	Siren Command	BCM (Body Control Module)
sp02197	Cargo Unlock Relay	BCM (Body Control Module)
sp02198	Cargo Lock Relay	BCM (Body Control Module)
sp02199	Fuel Circuit Purge	ECM (Engine Control Module)
sp02200	General Stop Actuator	ECM (Engine Control Module)
sp02201	Reset Adaptative Parameter	ECM (Engine Control Module)
sp02202	Reset Purge Fuel Circuit	ECM (Engine Control Module)
sp02203	Reset Phonic Wheel Tooth Learn	ECM (Engine Control Module)
sp02204	Reset Camshaft Adaptative	ECM (Engine Control Module)
sp02205	Steering Angle Sensor	EPS (Electric Power Steering)
sp02206	Clear TPM Sensor Audit	RFH (Radio Frequency Hub)
sp02207	Clear TPM Sensor Warnings	RFH (Radio Frequency Hub)
sp02208	Trailer Hook Presence Disabling	PAM (Parking Aid Module)
sp02209	Trailer Hook Presence Enabling	PAM (Parking Aid Module)
sp02210	Reset Odometer	IPC (Instrument Panel Cluster)
sp02211	Self Learning Motors Test	HVAC (Heat, Ventilation And A/C)
sp02212	Service Single Pole Calibration	HALF (Haptical Lane Feedback)
sp02213	Proxi Alignment Procedure	ESM (Electronic Shifter Module)
sp02214	Factory VIN code lock	ESM (Electronic Shifter Module)
sp02215	Driver Mirror Axis X Command	DMM (Doors Management Module)
sp02216	Driver Mirror Axis Y Command	DMM (Doors Management Module)
sp02217	Fire Protection System Activate	BCM (Body Control Module)
sp02218	Lock Doors Command	BCM (Body Control Module)
sp02219	Unlock Doors Command	BCM (Body Control Module)
sp02220	Check Siren	BCM (Body Control Module)
sp02221	Siren Command	BCM (Body Control Module)
sp02222	Cargo Unlock Relay	BCM (Body Control Module)
sp02223	Cargo Lock Relay	BCM (Body Control Module)
sp02224	Fuel Circuit Purge	ECM (Engine Control Module)
sp02225	General Stop Actuator	ECM (Engine Control Module)
sp02226	Reset Adaptative Parameter	ECM (Engine Control Module)
sp02227	Reset Purge Fuel Circuit	ECM (Engine Control Module)
sp02228	Reset Phonic Wheel Tooth Learn	ECM (Engine Control Module)
sp02229	Reset Camshaft Adaptative	ECM (Engine Control Module)
sp02230	Steering Angle Sensor	EPS (Electric Power Steering)
sp02231	Clear TPM Sensor Audit	RFH (Radio Frequency Hub)
sp02232	Clear TPM Sensor Warnings	RFH (Radio Frequency Hub)
sp02233	Trailer Hook Presence Disabling	PAM (Parking Aid Module)
sp02234	Trailer Hook Presence Enabling	PAM (Parking Aid Module)
sp02235	Reset Odometer	IPC (Instrument Panel Cluster)
sp02236	Self Learning Motors Test	HVAC (Heat, Ventilation And A/C)
sp02237	Service Single Pole Calibration	HALF (Haptical Lane Feedback)
sp02238	Proxi Alignment Procedure	ESM (Electronic Shifter Module)
sp02239	Factory VIN code lock	ESM (Electronic Shifter Module)
sp02240	Driver Mirror Axis X Command	DMM (Doors Management Module)
sp02241	Driver Mirror Axis Y Command	DMM (Doors Management Module)
sp02242	Fire Protection System Activate	BCM (Body Control Module)



sp02243	Lock Doors Command	BCM (Body Control Module)
sp02244	Unlock Doors Command	BCM (Body Control Module)
sp02245	Check Siren	BCM (Body Control Module)
sp02246	Siren Command	BCM (Body Control Module)
sp02247	Cargo Unlock Relay	BCM (Body Control Module)
sp02248	Cargo Lock Relay	BCM (Body Control Module)
sp02249	Fuel Circuit Purge	ECM (Engine Control Module)
sp02250	General Stop Actuator	ECM (Engine Control Module)
sp02251	Reset Adaptive Parameter	ECM (Engine Control Module)
sp02252	Reset Purge Fuel Circuit	ECM (Engine Control Module)
sp02253	Reset Phonic Wheel Tooth Learn	ECM (Engine Control Module)
sp02254	Reset Camshaft Adaptive	ECM (Engine Control Module)
sp02255	Clear Self Learning Data	TCM (Transmission Control Module)
sp02256	Neutral Position Self-Learning	TCM (Transmission Control Module)
sp02257	Exit Shipping Mode	BCM (Body Control Module)
sp02258	Lock Doors Command	BCM (Body Control Module)
sp02259	Unlock Doors Command	BCM (Body Control Module)
sp02260	Siren Command	BCM (Body Control Module)
sp02261	Fire Protection System Activate	BCM (Body Control Module)
sp02262	Reset Service Information	IC (Instrument Cluster)
sp02263	Clear TPM Sensor Audit	RFH (Radio Frequency Hub)
sp02264	Clear TPM Sensor Warnings	RFH (Radio Frequency Hub)
sp02265	Service Single Pole Calibration	HALF (Haptical Lane Feedback)
sp02266	Driver Mirror Axis X Command	DMM (Doors Management Module)
sp02267	Driver Mirror Axis Y Command	DMM (Doors Management Module)
sp02268	Steering Angle Sensor	EPS (Electric Power Steering)
sp02269	Trailer Hook Presence Disabling	PAM (Parking Assistant Module)
sp02270	Trailer Hook Presence Enabling	PAM (Parking Assistant Module)
sp02271	Self Learning Motors Test	HVAC (Heating Ventilation Air-Conditioning And Cooling)
sp02272	Proxi Alignment Procedure	ESM (Electronic Shifter Module)
sp02273	Factory VIN code lock	ESM (Electronic Shifter Module)
sp02274	Deactivation Of The Power Limitation Function	ECM (Engine Control Module)
sp02275	Fan Cooling Activation	ECM (Engine Control Module)
sp02276	Self-Adaptive Parameters Reset	ECM (Engine Control Module)
sp02277	Self-Learnt Functions Reset	ECM (Engine Control Module)
sp02278	Gearbox Replacement	TCM (Transmission Control Module)
sp02279	Lever Release Solenoid Command	TCM (Transmission Control Module)
sp02280	Static Test	ABS (Anti-Lock Braking System)
sp02281	Trailer Hook Presence Disabling	PAM (Parking Aid Module)
sp02282	Trailer Hook Presence Enabling	PAM (Parking Aid Module)
sp02283	Reset Odometer	IC (Instrument Cluster)
sp02284	Reset Service Information	IC (Instrument Cluster)
sp02285	Disable Seat Belts Reminder	IC (Instrument Cluster)
sp02286	Enable Seat Belts Reminder	IC (Instrument Cluster)
sp02287	Last Service Date	IC (Instrument Cluster)
sp02288	Actuator Calibration Test	HVAC (Heating Ventilation Air-Conditioning And Cooling)
sp02289	Fire Protection System Activate	BCM (Body Control Module)
sp02290	Cam Crank Relearn	PCM (Powertrain Control Module)
sp02291	Check PCM Odometer	PCM (Powertrain Control Module)
sp02292	Quicklearn (62TE)	PCM (Powertrain Control Module)
sp02293	Quicklearn (Non-RFE)	PCM (Powertrain Control Module)
sp02294	Reset Memory	PCM (Powertrain Control Module)
sp02295	EGR System Test	PCM (Powertrain Control Module)
sp02296	ETC Throttle Follower Test	PCM (Powertrain Control Module)
sp02297	Set Engine RPM	PCM (Powertrain Control Module)



sp02298	Shift Lever Position Test (62TE)	PCM (Powertrain Control Module)
sp02299	Shift Lever Position Test (Non-RFE)	PCM (Powertrain Control Module)
sp02300	ABS Initialization	ABS (Anti Lock Brakes)
sp02301	Bleed Brakes	ABS (Anti Lock Brakes)
sp02302	Activate Driver And Passenger Head Restraint	ORC (Occupant Restraint)
sp02303	Program Tire Sensor ID With TPM Tool	WCM (Wireless Control)
sp02304	Reset Odometer	PDM (Passenger Door Module)
sp02305	Reset Service Information	PDM (Passenger Door Module)
sp02306	Disable Seat Belts Reminder	PDM (Passenger Door Module)
sp02307	Enable Seat Belts Reminder	PDM (Passenger Door Module)
sp02308	Actuator Calibration Test	HVAC (Heat, Ventilation And A/C)
sp02309	Auto Door Lock	CCN (Instrument Cluster/Cabin Compartment Node)
sp02310	Auto Door Unlock	CCN (Instrument Cluster/Cabin Compartment Node)
sp02311	Seatbelt Alert Minder	CCN (Instrument Cluster/Cabin Compartment Node)
sp02312	Update Measurement Unit	CCN (Instrument Cluster/Cabin Compartment Node)
sp02313	Seatbelt Alert Minder	CCN (Instrument Cluster/Cabin Compartment Node)
sp02314	Self Test	CCN (Instrument Cluster/Cabin Compartment Node)
sp02315	Cam Crank Relearn	PCM (Powertrain Control Module)
sp02316	Check PCM Odometer	PCM (Powertrain Control Module)
sp02317	Quicklearn (62TE)	PCM (Powertrain Control Module)
sp02318	Quicklearn (Non-RFE)	PCM (Powertrain Control Module)
sp02319	Reset Memory	PCM (Powertrain Control Module)
sp02320	EGR System Test	PCM (Powertrain Control Module)
sp02321	ETC Throttle Follower Test	PCM (Powertrain Control Module)
sp02322	Set Engine RPM	PCM (Powertrain Control Module)
sp02323	Shift Lever Position Test (62TE)	PCM (Powertrain Control Module)
sp02324	Shift Lever Position Test (Non-RFE)	PCM (Powertrain Control Module)
sp02325	ABS Initialization	ABS (Anti Lock Brakes)
sp02326	Bleed Brakes	ABS (Anti Lock Brakes)
sp02327	Activate Driver And Passenger Head Restraint	ORC (Occupant Restraint)
sp02328	Program Tire Sensor ID With TPM Tool	WCM (Wireless Control)
sp02329	Reset Odometer	PDM (Passenger Door Module)
sp02330	Reset Service Information	PDM (Passenger Door Module)
sp02331	Disable Seat Belts Reminder	PDM (Passenger Door Module)
sp02332	Enable Seat Belts Reminder	PDM (Passenger Door Module)
sp02333	Actuator Calibration Test	HVAC (Heat, Ventilation And A/C)
sp02334	Auto Door Lock	CCN (Instrument Cluster/Cabin Compartment Node)
sp02335	Auto Door Unlock	CCN (Instrument Cluster/Cabin Compartment Node)
sp02336	Seatbelt Alert Minder	CCN (Instrument Cluster/Cabin Compartment Node)
sp02337	Update Measurement Unit	CCN (Instrument Cluster/Cabin Compartment Node)
sp02338	Seatbelt Alert Minder	CCN (Instrument Cluster/Cabin Compartment Node)
sp02339	Self Test	CCN (Instrument Cluster/Cabin Compartment Node)
sp02340	Resetting Distance Travelled With Water In Diesel W.Lamp ON	ECM (Engine Control Module)
sp02341	Resetting Distance Travelled With Water Temperature Warning Lamp ON	ECM (Engine Control Module)
sp02342	Fan Cooling Activation	ECM (Engine Control Module)
sp02343	Neutral Signal Learn	ECM (Engine Control Module)
sp02344	Injector Codes Read	ECM (Engine Control Module)
sp02345	Nox Replacement	ECM (Engine Control Module)
sp02346	Factory VIN code lock	ECM (Engine Control Module)
sp02347	Intelligent Alternator (IAM) Replacement	ECM (Engine Control Module)
sp02348	Clutch Group And/Or Clutch Potentiometer Replacement	ECM (Engine Control Module)
sp02349	Injector Replacement (Per Bank)	ECM (Engine Control Module)
sp02350	Cylinder 1 Injector Replacement	ECM (Engine Control Module)
sp02351	Cylinder 2 Injector Replacement	ECM (Engine Control Module)
sp02352	Cylinder 3 Injector Replacement	ECM (Engine Control Module)

sp02353	Replacement Lambda Sensor	ECM (Engine Control Module)
sp02354	Oil Change	ECM (Engine Control Module)
sp02355	Differential Pressure Sensor Replac.	ECM (Engine Control Module)
sp02356	Rail Pressure Sensor Replacement	ECM (Engine Control Module)
sp02357	Replacement Of EGR Valve	ECM (Engine Control Module)
sp02358	EGR Low Pressure Valve Replacement	ECM (Engine Control Module)
sp02359	Glow Plug Preheating Circuit Test	ECM (Engine Control Module)
sp02360	EGR Valve Test	ECM (Engine Control Module)
sp02361	EGR Low Pressure Valve Test	ECM (Engine Control Module)
sp02362	Throttle Valve Test	ECM (Engine Control Module)
sp02363	Proxi Alignment Procedure	ECM (Engine Control Module)
sp02364	Proxi Alignment Procedure	TCM (Transmission Control Module)
sp02365	ECU Substitution	ABS (Anti Lock Brakes)
sp02366	Longitudinal And Lateral Sensor Calibration	ABS (Anti Lock Brakes)
sp02367	Pressure Sensor Calibration	ABS (Anti Lock Brakes)
sp02368	Power Down	RRM (Radio Receiver Module)
sp02369	Power On And Disable User Inputs	RRM (Radio Receiver Module)
sp02370	Reset Parameters To Default	RRM (Radio Receiver Module)
sp02371	Clear TPM Sensor Audit	RFH (Radio Frequency Hub)
sp02372	Clear TPM Sensor Warnings	RFH (Radio Frequency Hub)
sp02373	Cam Crank Relearn	PCM (Powertrain Control Module)
sp02374	Check PCM Odometer	PCM (Powertrain Control Module)
sp02375	Cooled EGR H-Bridge Valve System Test	PCM (Powertrain Control Module)
sp02376	Reset Enhanced Automatic Oil Change Indicator	PCM (Powertrain Control Module)
sp02377	Write Pinion Factor	PCM (Powertrain Control Module)
sp02378	Reset Learn Flag Wheel Tooth	PCM (Powertrain Control Module)
sp02379	EGR System Test	PCM (Powertrain Control Module)
sp02380	ETC Throttle Follower Test	PCM (Powertrain Control Module)
sp02381	Set Engine RPM	PCM (Powertrain Control Module)
sp02382	Shift Lever Position Test (62TE)	PCM (Powertrain Control Module)
sp02383	Trailer Hook Presence Disabling	PAM (Parking Aid Module)
sp02384	Trailer Hook Presence Enabling	PAM (Parking Aid Module)
sp02385	Reset Service Information	IPC (Instrument Panel Cluster)
sp02386	Reset Odometer	IPC (Instrument Panel Cluster)
sp02387	Disable Seat Belts Reminder	IPC (Instrument Panel Cluster)
sp02388	Enable Seat Belts Reminder	IPC (Instrument Panel Cluster)
sp02389	Last Service Date	IPC (Instrument Panel Cluster)
sp02390	Self Learning Motors Test	HVAC (Heat, Ventilation And A/C)
sp02391	Service Single Pole Calibration	HALF (Haptical Lane Feedback)
sp02392	Proxi Alignment Procedure	ESM (Electronic Shifter Module)
sp02393	Factory VIN code lock	ESM (Electronic Shifter Module)
sp02394	Steering Angle Sensor	EPS (Electric Power Steering)
sp02395	Factory VIN code lock	DTCM (Drive Train Control Module)
sp02396	Proxi Alignment Procedure	DTCM (Drive Train Control Module)
sp02397	Factory VIN code lock	CSWM (Comfort Seat Wheel Module)
sp02398	Cam Crank Relearn	PCM (Powertrain Control Module)
sp02399	Check PCM Odometer	PCM (Powertrain Control Module)
sp02400	Cooled EGR H-Bridge Valve System Test	PCM (Powertrain Control Module)
sp02401	Reset Enhanced Automatic Oil Change Indicator	PCM (Powertrain Control Module)
sp02402	Write Pinion Factor	PCM (Powertrain Control Module)
sp02403	Reset Learn Flag Wheel Tooth	PCM (Powertrain Control Module)
sp02404	Enable Engine Idle Shutdown Feature	PCM (Powertrain Control Module)
sp02405	EGR System Test	PCM (Powertrain Control Module)
sp02406	ETC Throttle Follower Test	PCM (Powertrain Control Module)
sp02407	Set Engine RPM	PCM (Powertrain Control Module)

sp02408	Shift Lever Position Test (62TE)	PCM (Powertrain Control Module)
sp02409	Reset Learned Adaptives	TCM (Transmission Control Module)
sp02410	Store Learned Adaptives	TCM (Transmission Control Module)
sp02411	ABS Bleed Brakes	ABS (Anti-Lock Braking System)
sp02412	Brake Pedal Calibration	ABS (Anti-Lock Braking System)
sp02413	Initialize ORC	SRS (Supplemental Inflatable Restraint System, ORC)
sp02414	Program Left Front Tire Sensor ID	ESM (Electronic Shifter Module)
sp02415	Program Left Rear Tire Sensor ID	ESM (Electronic Shifter Module)
sp02416	Program Right Front Tire Sensor ID	ESM (Electronic Shifter Module)
sp02417	Program Right Rear Tire Sensor ID	ESM (Electronic Shifter Module)
sp02418	Sensor Rolls Test	ESM (Electronic Shifter Module)
sp02419	System Wiring Test	Parking Electronic Module (PTS)
sp02420	Program Tire Sensor ID With TPM Tool	TPM (Tire Pressure Monitor)
sp02421	FFCM Calibration	FFCM (Forward Facing Camera Module)
sp02422	Enable/Disable Seatbelt Minder	IPC (Instrument Panel Cluster)
sp02423	AFLS Calibration	AFLS (Adaptive Front Lighting System)
sp02424	Cam Crank Relearn	PCM (Powertrain Control Module)
sp02425	Check PCM Odometer	PCM (Powertrain Control Module)
sp02426	Cooled EGR H-Bridge Valve System Test	PCM (Powertrain Control Module)
sp02427	Reset Enhanced Automatic Oil Change Indicator	PCM (Powertrain Control Module)
sp02428	Write Pinion Factor	PCM (Powertrain Control Module)
sp02429	Reset Learn Flag Wheel Tooth	PCM (Powertrain Control Module)
sp02430	Enable Engine Idle Shutdown Feature	PCM (Powertrain Control Module)
sp02431	EGR System Test	PCM (Powertrain Control Module)
sp02432	ETC Throttle Follower Test	PCM (Powertrain Control Module)
sp02433	Set Engine RPM	PCM (Powertrain Control Module)
sp02434	Shift Lever Position Test (62TE)	PCM (Powertrain Control Module)
sp02435	Reset Learned Adaptives	TCM (Transmission Control Module)
sp02436	Store Learned Adaptives	TCM (Transmission Control Module)
sp02437	ABS Bleed Brakes	ABS (Anti-Lock Braking System)
sp02438	Brake Pedal Calibration	ABS (Anti-Lock Braking System)
sp02439	Initialize ORC	SRS (Supplemental Inflatable Restraint System, ORC)
sp02440	Program Left Front Tire Sensor ID	ESM (Electronic Shifter Module)
sp02441	Program Left Rear Tire Sensor ID	ESM (Electronic Shifter Module)
sp02442	Program Right Front Tire Sensor ID	ESM (Electronic Shifter Module)
sp02443	Program Right Rear Tire Sensor ID	ESM (Electronic Shifter Module)
sp02444	Sensor Rolls Test	ESM (Electronic Shifter Module)
sp02445	System Wiring Test	Parking Electronic Module (PTS)
sp02446	Program Tire Sensor ID With TPM Tool	TPM (Tire Pressure Monitor)
sp02447	FFCM Calibration	FFCM (Forward Facing Camera Module)
sp02448	Enable/Disable Seatbelt Minder	IPC (Instrument Panel Cluster)
sp02449	AFLS Calibration	AFLS (Adaptive Front Lighting System)
sp02450	Cam Crank Relearn	PCM (Powertrain Control Module)
sp02451	Check PCM Odometer	PCM (Powertrain Control Module)
sp02452	Cooled EGR H-Bridge Valve System Test	PCM (Powertrain Control Module)
sp02453	Reset Enhanced Automatic Oil Change Indicator	PCM (Powertrain Control Module)
sp02454	Write Pinion Factor	PCM (Powertrain Control Module)
sp02455	Reset Learn Flag Wheel Tooth	PCM (Powertrain Control Module)
sp02456	Enable Engine Idle Shutdown Feature	PCM (Powertrain Control Module)
sp02457	EGR System Test	PCM (Powertrain Control Module)
sp02458	ETC Throttle Follower Test	PCM (Powertrain Control Module)
sp02459	Set Engine RPM	PCM (Powertrain Control Module)
sp02460	Shift Lever Position Test (62TE)	PCM (Powertrain Control Module)
sp02461	Reset Learned Adaptives	TCM (Transmission Control Module)
sp02462	Store Learned Adaptives	TCM (Transmission Control Module)

sp02463	ABS Bleed Brakes	ABS (Anti-Lock Braking System)
sp02464	Brake Pedal Calibration	ABS (Anti-Lock Braking System)
sp02465	Initialize ORC	SRS (Supplemental Inflatable Restraint System, ORC)
sp02466	Program Left Front Tire Sensor ID	ESM (Electronic Shifter Module)
sp02467	Program Left Rear Tire Sensor ID	ESM (Electronic Shifter Module)
sp02468	Program Right Front Tire Sensor ID	ESM (Electronic Shifter Module)
sp02469	Program Right Rear Tire Sensor ID	ESM (Electronic Shifter Module)
sp02470	Sensor Rolls Test	ESM (Electronic Shifter Module)
sp02471	System Wiring Test	Parking Electronic Module(PTS)
sp02472	Program Tire Sensor ID With TPM Tool	TPM (Tire Pressure Monitor)
sp02473	FFCM Calibration	FFCM (Forward Facing Camera Module)
sp02474	Enable/Disable Seatbelt Minder	IPC (Instrument Panel Cluster)
sp02475	AFLS Calibration	AFLS (Adaptive Front Lighting System)
sp02476	Cam Crank Relearn	PCM (Powertrain Control Module)
sp02477	Check PCM Odometer	PCM (Powertrain Control Module)
sp02478	Cooled EGR H-Bridge Valve System Test	PCM (Powertrain Control Module)
sp02479	Reset Enhanced Automatic Oil Change Indicator	PCM (Powertrain Control Module)
sp02480	Write Pinion Factor	PCM (Powertrain Control Module)
sp02481	Reset Learn Flag Wheel Tooth	PCM (Powertrain Control Module)
sp02482	Enable Engine Idle Shutdown Feature	PCM (Powertrain Control Module)
sp02483	EGR System Test	PCM (Powertrain Control Module)
sp02484	ETC Throttle Follower Test	PCM (Powertrain Control Module)
sp02485	Set Engine RPM	PCM (Powertrain Control Module)
sp02486	Shift Lever Position Test (62TE)	PCM (Powertrain Control Module)
sp02487	Reset Learned Adaptives	TCM (Transmission Control Module)
sp02488	Store Learned Adaptives	TCM (Transmission Control Module)
sp02489	ABS Bleed Brakes	ABS (Anti-Lock Braking System)
sp02490	Brake Pedal Calibration	ABS (Anti-Lock Braking System)
sp02491	Initialize ORC	SRS (Supplemental Inflatable Restraint System, ORC)
sp02492	Program Left Front Tire Sensor ID	ESM (Electronic Shifter Module)
sp02493	Program Left Rear Tire Sensor ID	ESM (Electronic Shifter Module)
sp02494	Program Right Front Tire Sensor ID	ESM (Electronic Shifter Module)
sp02495	Program Right Rear Tire Sensor ID	ESM (Electronic Shifter Module)
sp02496	Sensor Rolls Test	ESM (Electronic Shifter Module)
sp02497	System Wiring Test	Parking Electronic Module(PTS)
sp02498	Program Tire Sensor ID With TPM Tool	TPM (Tire Pressure Monitor)
sp02499	FFCM Calibration	FFCM (Forward Facing Camera Module)
sp02500	Enable/Disable Seatbelt Minder	IPC (Instrument Panel Cluster)
sp02501	AFLS Calibration	AFLS (Adaptive Front Lighting System)
sp02502	Cam Crank Relearn	PCM (Powertrain Control Module)
sp02503	Check PCM Odometer	PCM (Powertrain Control Module)
sp02504	Cooled EGR H-Bridge Valve System Test	PCM (Powertrain Control Module)
sp02505	Reset Enhanced Automatic Oil Change Indicator	PCM (Powertrain Control Module)
sp02506	Write Pinion Factor	PCM (Powertrain Control Module)
sp02507	Reset Learn Flag Wheel Tooth	PCM (Powertrain Control Module)
sp02508	Enable Engine Idle Shutdown Feature	PCM (Powertrain Control Module)
sp02509	EGR System Test	PCM (Powertrain Control Module)
sp02510	ETC Throttle Follower Test	PCM (Powertrain Control Module)
sp02511	Set Engine RPM	PCM (Powertrain Control Module)
sp02512	Shift Lever Position Test (62TE)	PCM (Powertrain Control Module)
sp02513	Reset Learned Adaptives	TCM (Transmission Control Module)
sp02514	Store Learned Adaptives	TCM (Transmission Control Module)
sp02515	ABS Bleed Brakes	ABS (Anti-Lock Braking System)
sp02516	Brake Pedal Calibration	ABS (Anti-Lock Braking System)
sp02517	Initialize ORC	SRS (Supplemental Inflatable Restraint System, ORC)

sp02518	Program Left Front Tire Sensor ID	ESM (Electronic Shifter Module)
sp02519	Program Left Rear Tire Sensor ID	ESM (Electronic Shifter Module)
sp02520	Program Right Front Tire Sensor ID	ESM (Electronic Shifter Module)
sp02521	Program Right Rear Tire Sensor ID	ESM (Electronic Shifter Module)
sp02522	Sensor Rolls Test	ESM (Electronic Shifter Module)
sp02523	System Wiring Test	Parking Electronic Module (PTS)
sp02524	Program Tire Sensor ID With TPM Tool	TPM (Tire Pressure Monitor)
sp02525	FFCM Calibration	FFCM (Forward Facing Camera Module)
sp02526	Enable/Disable Seatbelt Minder	IPC (Instrument Panel Cluster)
sp02527	AFLS Calibration	AFLS (Adaptive Front Lighting System)
sp02528	Cam Crank Relearn	PCM (Powertrain Control Module)
sp02529	Check PCM Odometer	PCM (Powertrain Control Module)
sp02530	Cooled EGR H-Bridge Valve System Test	PCM (Powertrain Control Module)
sp02531	Reset Enhanced Automatic Oil Change Indicator	PCM (Powertrain Control Module)
sp02532	Write Pinion Factor	PCM (Powertrain Control Module)
sp02533	Reset Learn Flag Wheel Tooth	PCM (Powertrain Control Module)
sp02534	Enable Engine Idle Shutdown Feature	PCM (Powertrain Control Module)
sp02535	EGR System Test	PCM (Powertrain Control Module)
sp02536	ETC Throttle Follower Test	PCM (Powertrain Control Module)
sp02537	Set Engine RPM	PCM (Powertrain Control Module)
sp02538	Shift Lever Position Test (62TE)	PCM (Powertrain Control Module)
sp02539	Reset Learned Adaptives	TCM (Transmission Control Module)
sp02540	Store Learned Adaptives	TCM (Transmission Control Module)
sp02541	ABS Bleed Brakes	ABS (Anti Lock Brakes)
sp02542	Brake Pedal Calibration	ABS (Anti Lock Brakes)
sp02543	Initialize ORC	ORC (Occupant Restraint)
sp02544	Program Tire Sensor ID With TPM Tool	TPM (Tire Pressure Monitor)
sp02545	System Wiring Test	PTS (Parktronics)
sp02546	Enable/Disable Seatbelt Minder	IPC (Instrument Panel Cluster)
sp02547	FFCM Calibration	FFCM (Forward Facing Camera Module)
sp02548	Program Left Front Tire Sensor ID	ESM (Electronic Shifter Module)
sp02549	Program Left Rear Tire Sensor ID	ESM (Electronic Shifter Module)
sp02550	Program Right Front Tire Sensor ID	ESM (Electronic Shifter Module)
sp02551	Program Right Rear Tire Sensor ID	ESM (Electronic Shifter Module)
sp02552	Sensor Rolls Test	ESM (Electronic Shifter Module)
sp02553	AFLS Calibration	AFLS (Adaptive Front Lighting System)
sp02554	Cam Crank Relearn	PCM (Powertrain Control Module)
sp02555	Check PCM Odometer	PCM (Powertrain Control Module)
sp02556	Quicklearn (62TE)	PCM (Powertrain Control Module)
sp02557	Reset Memory	PCM (Powertrain Control Module)
sp02558	Clear Engine Auto Restart Crank Counter	PCM (Powertrain Control Module)
sp02559	Cooled EGR H-Bridge Valve System Test	PCM (Powertrain Control Module)
sp02560	Reset Enhanced Automatic Oil Change Indicator	PCM (Powertrain Control Module)
sp02561	EGR System Test	PCM (Powertrain Control Module)
sp02562	ETC Throttle Follower Test	PCM (Powertrain Control Module)
sp02563	Set Engine RPM	PCM (Powertrain Control Module)
sp02564	Shift Lever Position Test (62TE)	PCM (Powertrain Control Module)
sp02565	ABS Bleed Brakes	ABS (Anti Lock Brakes)
sp02566	Brake Pedal Calibration	ABS (Anti Lock Brakes)
sp02567	Initialize ORC	ORC (Occupant Restraint)
sp02568	Program Left Front Tire Sensor ID	TPM (Tire Pressure Monitor)
sp02569	Program Left Rear Tire Sensor ID	TPM (Tire Pressure Monitor)
sp02570	Program Right Front Tire Sensor ID	TPM (Tire Pressure Monitor)
sp02571	Program Right Rear Tire Sensor ID	TPM (Tire Pressure Monitor)
sp02572	Program Tire Sensor ID With TPM Tool	TPM (Tire Pressure Monitor)

sp02573	Activate TPM High Gain Mode	TPM (Tire Pressure Monitor)
sp02574	TPM Sensor Position Parameter Update	TPM (Tire Pressure Monitor)
sp02575	Sensor Rolls Test	TPM (Tire Pressure Monitor)
sp02576	System Wiring Test	PTS (Parktronics)
sp02577	Enable/Disable Seatbelt Minder	IPC (Instrument Panel Cluster)
sp02578	FFCM Calibration	FFCM (Forward Facing Camera Module)
sp02579	Program Left Front Tire Sensor ID	ESM (Electronic Shifter Module)
sp02580	Program Left Rear Tire Sensor ID	ESM (Electronic Shifter Module)
sp02581	Program Right Front Tire Sensor ID	ESM (Electronic Shifter Module)
sp02582	Program Right Rear Tire Sensor ID	ESM (Electronic Shifter Module)
sp02583	Sensor Rolls Test	ESM (Electronic Shifter Module)
sp02584	AFLS Calibration	AFLS (Adaptive Front Lighting System)
sp02585	Cam Crank Relearn	PCM (Powertrain Control Module)
sp02586	Check PCM Odometer	PCM (Powertrain Control Module)
sp02587	Quicklearn (62TE)	PCM (Powertrain Control Module)
sp02588	Quicklearn (Non-RFE)	PCM (Powertrain Control Module)
sp02589	Reset Memory	PCM (Powertrain Control Module)
sp02590	Cooled EGR H-Bridge Valve System Test	PCM (Powertrain Control Module)
sp02591	Reset Enhanced Automatic Oil Change Indicator	PCM (Powertrain Control Module)
sp02592	Write Pinion Factor	PCM (Powertrain Control Module)
sp02593	EGR System Test	PCM (Powertrain Control Module)
sp02594	ETC Throttle Follower Test	PCM (Powertrain Control Module)
sp02595	Set Engine RPM	PCM (Powertrain Control Module)
sp02596	Shift Lever Position Test (62TE)	PCM (Powertrain Control Module)
sp02597	Shift Lever Position Test (Non-RFE)	PCM (Powertrain Control Module)
sp02598	Reset Adaptive Values	TCM (Transmission Control Module)
sp02599	ABS Bleed Brakes	ABS (Anti Lock Brakes)
sp02600	Brake Pedal Calibration	ABS (Anti Lock Brakes)
sp02601	Initialize ORC	ORC (Occupant Restraint)
sp02602	Program Left Front Tire Sensor ID	TPM (Tire Pressure Monitor)
sp02603	Program Left Rear Tire Sensor ID	TPM (Tire Pressure Monitor)
sp02604	Program Right Front Tire Sensor ID	TPM (Tire Pressure Monitor)
sp02605	Program Right Rear Tire Sensor ID	TPM (Tire Pressure Monitor)
sp02606	Program Tire Sensor ID With TPM Tool	TPM (Tire Pressure Monitor)
sp02607	Sensor Rolls Test	TPM (Tire Pressure Monitor)
sp02608	Configure License Plate Size	PTS (Parktronics)
sp02609	System Wiring Test	PTS (Parktronics)
sp02610	Disable/Enable Seatbelt Minder Chime	IPC (Instrument Panel Cluster)
sp02611	Auto Door Lock	BCM (Body Control Module)
sp02612	Program Tire Size	BCM (Body Control Module)
sp02613	Exit Shipping Mode	BCM (Body Control Module)
sp02614	AFLS Calibration	AFLS (Adaptive Front Lighting System)
sp02615	Air Flow Meter Replacement	PCM (Powertrain Control Module)
sp02616	DPF Reset Option	PCM (Powertrain Control Module)
sp02617	Lambda Sensor Replace	PCM (Powertrain Control Module)
sp02618	Reset Of Lambda Values	PCM (Powertrain Control Module)
sp02619	Reset Oil Change Indicator	PCM (Powertrain Control Module)
sp02620	Reset Zero Fuel Quantity Calibration	PCM (Powertrain Control Module)
sp02621	Service Diesel Particulate Filter Regeneration	PCM (Powertrain Control Module)
sp02622	Throttle Valve Learn	PCM (Powertrain Control Module)
sp02623	Reset Adaptive Values	TCM (Transmission Control Module)
sp02624	ABS Bleed Brakes	ABS (Anti Lock Brakes)
sp02625	Brake Pedal Calibration	ABS (Anti Lock Brakes)
sp02626	Initialize ORC	ORC (Occupant Restraint)

sp02627	Program Left Front Tire Sensor ID	TPM (Tire Pressure Monitor)
sp02628	Program Left Rear Tire Sensor ID	TPM (Tire Pressure Monitor)
sp02629	Program Right Front Tire Sensor ID	TPM (Tire Pressure Monitor)
sp02630	Program Right Rear Tire Sensor ID	TPM (Tire Pressure Monitor)
sp02631	Program Tire Sensor ID With TPM Tool	TPM (Tire Pressure Monitor)
sp02632	Sensor Rolls Test	TPM (Tire Pressure Monitor)
sp02633	Configure License Plate Size	PTS (Parktronics)
sp02634	System Wiring Test	PTS (Parktronics)
sp02635	Disable/Enable Seatbelt Minder Chime	IPC (Instrument Panel Cluster)
sp02636	Auto Door Lock	BCM (Body Control Module)
sp02637	Program Tire Size	BCM (Body Control Module)
sp02638	Exit Shipping Mode	BCM (Body Control Module)
sp02639	AFLS Calibration	AFLS (Adaptive Front Lighting System)
sp02640	Air Flow Meter Replacement	PCM (Powertrain Control Module)
sp02641	DPF Reset Option	PCM (Powertrain Control Module)
sp02642	Lambda Sensor Replace	PCM (Powertrain Control Module)
sp02643	Reset Of Lambda Values	PCM (Powertrain Control Module)
sp02644	Reset Oil Change Indicator	PCM (Powertrain Control Module)
sp02645	Reset Zero Fuel Quantity Calibration	PCM (Powertrain Control Module)
sp02646	Service Diesel Particulate Filter Regeneration	PCM (Powertrain Control Module)
sp02647	Throttle Valve Learn	PCM (Powertrain Control Module)
sp02648	Reset Adaptive Values	TCM (Transmission Control Module)
sp02649	ABS Bleed Brakes	ABS (Anti Lock Brakes)
sp02650	Brake Pedal Calibration	ABS (Anti Lock Brakes)
sp02651	Initialize ORC	ORC (Occupant Restraint)
sp02652	Program Left Front Tire Sensor ID	TPM (Tire Pressure Monitor)
sp02653	Program Left Rear Tire Sensor ID	TPM (Tire Pressure Monitor)
sp02654	Program Right Front Tire Sensor ID	TPM (Tire Pressure Monitor)
sp02655	Program Right Rear Tire Sensor ID	TPM (Tire Pressure Monitor)
sp02656	Program Tire Sensor ID With TPM Tool	TPM (Tire Pressure Monitor)
sp02657	Sensor Rolls Test	TPM (Tire Pressure Monitor)
sp02658	Configure License Plate Size	PTS (Parktronics)
sp02659	System Wiring Test	PTS (Parktronics)
sp02660	Disable/Enable Seatbelt Minder Chime	IPC (Instrument Panel Cluster)
sp02661	Auto Door Lock	BCM (Body Control Module)
sp02662	Program Tire Size	BCM (Body Control Module)
sp02663	Exit Shipping Mode	BCM (Body Control Module)
sp02664	AFLS Calibration	AFLS (Adaptive Front Lighting System)
sp02665	Lambda Sensor 1 Initialization	PCM (Powertrain Control Module)
sp02666	Service Diesel Particulate Filter Regeneration	PCM (Powertrain Control Module)
sp02667	Rail Pressure Control Switchover	PCM (Powertrain Control Module)
sp02668	Diesel Particulate Filter Replacement	PCM (Powertrain Control Module)
sp02669	Request Anti-Slugging For Air Condition Compressor	PCM (Powertrain Control Module)
sp02670	Lambda Sensor 1 Initialization	PCM (Powertrain Control Module)
sp02671	Service Diesel Particulate Filter Regeneration	PCM (Powertrain Control Module)
sp02672	Rail Pressure Control Switchover	PCM (Powertrain Control Module)
sp02673	Diesel Particulate Filter Replacement	PCM (Powertrain Control Module)
sp02674	Request Anti-Slugging For Air Condition Compressor	PCM (Powertrain Control Module)
sp02675	ABS Bleed Brakes	ABS (Anti Lock Brakes)
sp02676	Initialize ORC	ORC (Occupant Restraint)
sp02677	Activate Driver And Passenger Head Restraint	ORC (Occupant Restraint)
sp02678	Reset WIN Configuration	WCM (Wireless Control)
sp02679	Program Tire Sensor ID With TPM Tool	WCM (Wireless Control)



sp02680	Program Left Front Tire Sensor ID	TPM (Tire Pressure Monitor)
sp02681	Program Left Rear Tire Sensor ID	TPM (Tire Pressure Monitor)
sp02682	Program Right Front Tire Sensor ID	TPM (Tire Pressure Monitor)
sp02683	Program Right Rear Tire Sensor ID	TPM (Tire Pressure Monitor)
sp02684	Turn Off Gain Mode Override	TPM (Tire Pressure Monitor)
sp02685	Program Tire Sensor ID With TPM Tool	TPM (Tire Pressure Monitor)
sp02686	TPM Sensor Rolls Test	TPM (Tire Pressure Monitor)
sp02687	Auto Wipers	TIPMCGW (Central Gateway)
sp02688	Auto Door Lock	TIPMCGW (Central Gateway)
sp02689	Auto Door Unlock	TIPMCGW (Central Gateway)
sp02690	Configure License Plate Size	PTS (Parktronics)
sp02691	System Wiring Test	PTS (Parktronics)
sp02692	Actuate Drive Clutch Engage	PSDMR (Power Sliding Doors (Right))
sp02693	Sliding Door Close Test	PSDMR (Power Sliding Doors (Right))
sp02694	Sliding Door Open Test	PSDMR (Power Sliding Doors (Right))
sp02695	Actuate Drive Clutch Engage	PSDML (Power Sliding Doors (Left))
sp02696	Sliding Door Close Test	PSDML (Power Sliding Doors (Left))
sp02697	Sliding Door Open Test	PSDML (Power Sliding Doors (Left))
sp02698	ITM Initialize Siren	ITM (Intrusion)
sp02699	Actuator Calibration Test	HVAC (Heat, Ventilation And A/C)
sp02700	Heated Steering Wheel Configuration	HSM (Heated Seat Module)
sp02701	Update Measurement Unit	CCN (Instrument Cluster/Cabin Compartment Node)
sp02702	Seatbelt Alert Minder	CCN (Instrument Cluster/Cabin Compartment Node)
sp02703	Self Test	CCN (Instrument Cluster/Cabin Compartment Node)
sp02704	Lambda Sensor 1 Initialization	PCM (Powertrain Control Module)
sp02705	Service Diesel Particulate Filter Regeneration	PCM (Powertrain Control Module)
sp02706	Rail Pressure Control Switchover	PCM (Powertrain Control Module)
sp02707	Diesel Particulate Filter Replacement	PCM (Powertrain Control Module)
sp02708	Request Anti-Slugging For Air Condition Compressor	PCM (Powertrain Control Module)
sp02709	ABS Bleed Brakes	ABS (Anti Lock Brakes)
sp02710	Initialize ORC	ORC (Occupant Restraint)
sp02711	Activate Driver And Passenger Head Restraint	ORC (Occupant Restraint)
sp02712	Reset WIN Configuration	WCM (Wireless Control)
sp02713	Program Tire Sensor ID With TPM Tool	WCM (Wireless Control)
sp02714	Program Left Front Tire Sensor ID	TPM (Tire Pressure Monitor)
sp02715	Program Left Rear Tire Sensor ID	TPM (Tire Pressure Monitor)
sp02716	Program Right Front Tire Sensor ID	TPM (Tire Pressure Monitor)
sp02717	Program Right Rear Tire Sensor ID	TPM (Tire Pressure Monitor)
sp02718	TPM Sensor Position Parameter Update	TPM (Tire Pressure Monitor)
sp02719	Program Tire Sensor ID With TPM Tool	TPM (Tire Pressure Monitor)
sp02720	TPM Sensor Rolls Test	TPM (Tire Pressure Monitor)
sp02721	Auto Wipers	TIPMCGW (Central Gateway)
sp02722	Auto Door Lock	TIPMCGW (Central Gateway)
sp02723	Auto Door Unlock	TIPMCGW (Central Gateway)
sp02724	Configure License Plate Size	PTS (Parktronics)
sp02725	System Wiring Test	PTS (Parktronics)
sp02726	Actuate Drive Clutch Engage	PSDMR (Power Sliding Doors (Right))
sp02727	Sliding Door Close Test	PSDMR (Power Sliding Doors (Right))
sp02728	Sliding Door Open Test	PSDMR (Power Sliding Doors (Right))
sp02729	Actuate Drive Clutch Engage	PSDML (Power Sliding Doors (Left))
sp02730	Sliding Door Close Test	PSDML (Power Sliding Doors (Left))
sp02731	Sliding Door Open Test	PSDML (Power Sliding Doors (Left))
sp02732	ITM Initialize Siren	ITM (Intrusion)
sp02733	Actuator Calibration Test	HVAC (Heat, Ventilation And A/C)



sp02734	Heated Steering Wheel Configuration	HSM (Heated Seat Module)
sp02735	Update Measurement Unit	CCN (Instrument Cluster/Cabin Compartment Node)
sp02736	Seatbelt Alert Minder	CCN (Instrument Cluster/Cabin Compartment Node)
sp02737	Self Test	CCN (Instrument Cluster/Cabin Compartment Node)
sp02738	Cam Crank Relearn	PCM (Powertrain Control Module)
sp02739	Check PCM Odometer	PCM (Powertrain Control Module)
sp02740	Quicklearn (62TE)	PCM (Powertrain Control Module)
sp02741	Quicklearn (Non-RFE)	PCM (Powertrain Control Module)
sp02742	Reset Memory	PCM (Powertrain Control Module)
sp02743	EGR System Test	PCM (Powertrain Control Module)
sp02744	ETC Throttle Follower Test	PCM (Powertrain Control Module)
sp02745	Set Engine RPM	PCM (Powertrain Control Module)
sp02746	Shift Lever Position Test (62TE)	PCM (Powertrain Control Module)
sp02747	Shift Lever Position Test (Non-RFE)	PCM (Powertrain Control Module)
sp02748	ABS Initialization	ABS (Anti Lock Brakes)
sp02749	Bleed Brakes	ABS (Anti Lock Brakes)
sp02750	Initialize ORC	ORC (Occupant Restraint)
sp02751	Activate Driver And Passenger Head Restraint	ORC (Occupant Restraint)
sp02752	Reset WIN Configuration	WCM (Wireless Control)
sp02753	Program Tire Sensor ID With TPM Tool	WCM (Wireless Control)
sp02754	Program Left Front Tire Sensor ID	TPM (Tire Pressure Monitor)
sp02755	Program Left Rear Tire Sensor ID	TPM (Tire Pressure Monitor)
sp02756	Program Right Front Tire Sensor ID	TPM (Tire Pressure Monitor)
sp02757	Program Right Rear Tire Sensor ID	TPM (Tire Pressure Monitor)
sp02758	TPM Sensor Position Parameter Update	TPM (Tire Pressure Monitor)
sp02759	Program Tire Sensor ID With TPM Tool	TPM (Tire Pressure Monitor)
sp02760	TPM Sensor Rolls Test	TPM (Tire Pressure Monitor)
sp02761	Auto Wipers	TIPMCGW (Central Gateway)
sp02762	Auto Door Lock	TIPMCGW (Central Gateway)
sp02763	Auto Door Unlock	TIPMCGW (Central Gateway)
sp02764	Configure License Plate Size	PTS (Parktronics)
sp02765	System Wiring Test	PTS (Parktronics)
sp02766	Actuate Drive Clutch Engage	PSDMR (Power Sliding Doors (Right))
sp02767	Sliding Door Close Test	PSDMR (Power Sliding Doors (Right))
sp02768	Sliding Door Open Test	PSDMR (Power Sliding Doors (Right))
sp02769	Actuate Drive Clutch Engage	PSDML (Power Sliding Doors (Left))
sp02770	Sliding Door Close Test	PSDML (Power Sliding Doors (Left))
sp02771	Sliding Door Open Test	PSDML (Power Sliding Doors (Left))
sp02772	ITM Initialize Siren	ITM (Intrusion)
sp02773	Heated Steering Wheel Configuration	HSM (Heated Seat Module)
sp02774	Update Measurement Unit	CCN (Instrument Cluster/Cabin Compartment Node)
sp02775	Seatbelt Alert Minder	CCN (Instrument Cluster/Cabin Compartment Node)
sp02776	Self Test	CCN (Instrument Cluster/Cabin Compartment Node)
sp02777	Cam Crank Relearn	PCM (Powertrain Control Module)
sp02778	Check PCM Odometer	PCM (Powertrain Control Module)
sp02779	Quicklearn (62TE)	PCM (Powertrain Control Module)
sp02780	Quicklearn (Non-RFE)	PCM (Powertrain Control Module)
sp02781	Reset Memory	PCM (Powertrain Control Module)
sp02782	EGR System Test	PCM (Powertrain Control Module)
sp02783	ETC Throttle Follower Test	PCM (Powertrain Control Module)
sp02784	Set Engine RPM	PCM (Powertrain Control Module)
sp02785	Shift Lever Position Test (62TE)	PCM (Powertrain Control Module)
sp02786	Shift Lever Position Test (Non-RFE)	PCM (Powertrain Control Module)
sp02787	ABS Initialization	ABS (Anti Lock Brakes)
sp02788	Bleed Brakes	ABS (Anti Lock Brakes)

sp02789	Initialize ORC	ORC (Occupant Restraint)
sp02790	Rollover Detection	ORC (Occupant Restraint)
sp02791	Activate Driver And Passenger Head Restraint	ORC (Occupant Restraint)
sp02792	Reset WIN Configuration	WCM (Wireless Control)
sp02793	Program Tire Sensor ID With TPM Tool	WCM (Wireless Control)
sp02794	Program Left Front Tire Sensor ID	TPM (Tire Pressure Monitor)
sp02795	Program Left Rear Tire Sensor ID	TPM (Tire Pressure Monitor)
sp02796	Program Right Front Tire Sensor ID	TPM (Tire Pressure Monitor)
sp02797	Program Right Rear Tire Sensor ID	TPM (Tire Pressure Monitor)
sp02798	TPM Sensor Position Parameter Update	TPM (Tire Pressure Monitor)
sp02799	Program Tire Sensor ID With TPM Tool	TPM (Tire Pressure Monitor)
sp02800	TPM Sensor Rolls Test	TPM (Tire Pressure Monitor)
sp02801	Auto Wipers	TIPMCGW (Central Gateway)
sp02802	Auto Door Lock	TIPMCGW (Central Gateway)
sp02803	Auto Door Unlock	TIPMCGW (Central Gateway)
sp02804	Configure License Plate Size	PTS (Parktronics)
sp02805	System Wiring Test	PTS (Parktronics)
sp02806	Actuate Drive Clutch Engage	PSDMR (Power Sliding Doors (Right))
sp02807	Sliding Door Close Test	PSDMR (Power Sliding Doors (Right))
sp02808	Sliding Door Open Test	PSDMR (Power Sliding Doors (Right))
sp02809	Actuate Drive Clutch Engage	PSDML (Power Sliding Doors (Left))
sp02810	Sliding Door Close Test	PSDML (Power Sliding Doors (Left))
sp02811	Sliding Door Open Test	PSDML (Power Sliding Doors (Left))
sp02812	ITM Initialize Siren	ITM (Intrusion)
sp02813	Heated Steering Wheel Configuration	HSM (Heated Seat Module)
sp02814	Update Measurement Unit	CCN (Instrument Cluster/Cabin Compartment Node)
sp02815	Seatbelt Alert Minder	CCN (Instrument Cluster/Cabin Compartment Node)
sp02816	Self Test	CCN (Instrument Cluster/Cabin Compartment Node)
sp02817	Intelligent Alternator (IAM) Replacement	ECM (Engine Control Module)
sp02818	Differential Pressure Sensor Replac.	ECM (Engine Control Module)
sp02819	Oil Change	ECM (Engine Control Module)
sp02820	Injector Replacement (Per Bank)	ECM (Engine Control Module)
sp02821	Injector Codes Read	ECM (Engine Control Module)
sp02822	Rail Pressure Sensor Replacement	ECM (Engine Control Module)
sp02823	Cylinder 3 Injector Replacement	ECM (Engine Control Module)
sp02824	Cylinder 2 Injector Replacement	ECM (Engine Control Module)
sp02825	Cylinder 1 Injector Replacement	ECM (Engine Control Module)
sp02826	Phonic Wheel Replacement	ECM (Engine Control Module)
sp02827	Replacement Lambda Sensor	ECM (Engine Control Module)
sp02828	Neutral Signal Learn	ECM (Engine Control Module)
sp02829	Rail Overpressure Waste Gate Valve Replacement	ECM (Engine Control Module)
sp02830	EGR Valve Test	ECM (Engine Control Module)
sp02831	Glow Plug Preheating Circuit Test	ECM (Engine Control Module)
sp02832	Self-Learnt Functions Reset	ECM (Engine Control Module)
sp02833	Resetting Distance Travelled With Water In Diesel W. Lamp ON	ECM (Engine Control Module)
sp02834	Throttle Valve Test	ECM (Engine Control Module)
sp02835	Resetting Distance Travelled With Water Temperature Warning Lamp ON	ECM (Engine Control Module)
sp02836	Fan Cooling Activation	ECM (Engine Control Module)
sp02837	Tunnel Lever Replacement	TCM (Transmission Control Module)
sp02838	Pump Relay Replacement	TCM (Transmission Control Module)
sp02839	Self-Learnt Functions Reset	TCM (Transmission Control Module)
sp02840	Longitudinal And Lateral Sensor Decalibration	ABS (Anti Lock Brakes)
sp02841	Longitudinal And Lateral Sensor Calibration	ABS (Anti Lock Brakes)
sp02842	Static Test	ABS (Anti Lock Brakes)

sp02843	Wheel Speed Sensor Type Test	ABS (Anti Lock Brakes)
sp02844	Flap Actuators Learning Test	HVAC (Heat, Ventilation And A/C)
sp02845	Steering Angle Calibration	EPS (Electric Power Steering)
sp02846	ECU Restart Routine	CTM (Convergence Telematic Module)
sp02847	Fire Protection System Activate	BCM (Body Control Module)
sp02848	Deactivation Of The Power Limitation Function	ECM (Engine Control Module)
sp02849	Motorised Throttle Replacement	ECM (Engine Control Module)
sp02850	Supercharging System Components Replacement	ECM (Engine Control Module)
sp02851	Intake Manifold Replacement	ECM (Engine Control Module)
sp02852	Clutch Group And/Or Clutch Potentiometer Replacement	ECM (Engine Control Module)
sp02853	Phonic Wheel Replacement	ECM (Engine Control Module)
sp02854	Intelligent Alternator (IAM) Replacement	ECM (Engine Control Module)
sp02855	Neutral Signal Learn	ECM (Engine Control Module)
sp02856	Self-Learnt Functions Reset	ECM (Engine Control Module)
sp02857	Self-Adaptive Parameters Reset	ECM (Engine Control Module)
sp02858	Tunnel Lever Replacement	TCM (Transmission Control Module)
sp02859	Levers At Wheel Replacement	TCM (Transmission Control Module)
sp02860	Pump Relay Replacement	TCM (Transmission Control Module)
sp02861	Self-Learnt Functions Reset	TCM (Transmission Control Module)
sp02862	Static Test	ABS (Anti-Lock Braking System)
sp02863	Trailer Hook Presence Disabling	PAM (Parking Assistant Module)
sp02864	Trailer Hook Presence Enabling	PAM (Parking Assistant Module)
sp02865	Reset Odometer	IC (Instrument Cluster)
sp02866	Reset Service Information	IC (Instrument Cluster)
sp02867	Disable Seat Belts Reminder	IC (Instrument Cluster)
sp02868	Enable Seat Belts Reminder	IC (Instrument Cluster)
sp02869	Last Service Date	IC (Instrument Cluster)
sp02870	Flap Actuators Learning Test	HVAC (Heating Ventilation Air-Conditioning And Cooling)
sp02871	Audio Video Signal Detection	ETM (Entertainment Telematic Module)
sp02872	Steering Angle Calibration	EPS (Electric Power Steering)
sp02873	ECU Restart Routine	CTM (Convergence Telematic Module)
sp02874	Fire Protection System Activate	BCM (Body Control Module )
sp02875	Deactivation Of The Power Limitation Function	ECM (Engine Control Module)
sp02876	Supercharging System Components Replacement	ECM (Engine Control Module)
sp02877	Engine Replacement	ECM (Engine Control Module)
sp02878	Oil Change	ECM (Engine Control Module)
sp02879	Fan Cooling Activation	ECM (Engine Control Module)
sp02880	Self-Adaptive Parameters Reset	ECM (Engine Control Module)
sp02881	Self-Learnt Functions Reset	ECM (Engine Control Module)
sp02882	Longitudinal And Lateral Sensor Decalibration	ABS (Anti Lock Brakes)
sp02883	Longitudinal And Lateral Sensor Calibration	ABS (Anti Lock Brakes)
sp02884	Static Test	ABS (Anti Lock Brakes)
sp02885	Steering Angle Sensor Calibration	ABS (Anti Lock Brakes)
sp02886	Write Front And Rear Nominal Tire Pressure Values	TPM (Tire Pressure Monitor)
sp02887	Clear TPM Warnings	TPM (Tire Pressure Monitor)
sp02888	Clear TPM Sensor Rolls Test Results	TPM (Tire Pressure Monitor)
sp02889	ECU SERIAL NUMBER Management	TPM (Tire Pressure Monitor)
sp02890	TPM Sensor Rolls Test	TPM (Tire Pressure Monitor)
sp02891	Program Left Front Tire Sensor ID	TPM (Tire Pressure Monitor)
sp02892	Program Left Rear Tire Sensor ID	TPM (Tire Pressure Monitor)
sp02893	Program Right Front Tire Sensor ID	TPM (Tire Pressure Monitor)
sp02894	Program Right Rear Tire Sensor ID	TPM (Tire Pressure Monitor)
sp02895	Tow Hook Exclusion	PAM (Parking Aid Module)
sp02896	Reset Odometer	IPC (Instrument Panel)

sp02897	Reset Service Information	IPC (Instrument Panel)
sp02898	Disable Seat Belts Reminder	IPC (Instrument Panel)
sp02899	Enable Seat Belts Reminder	IPC (Instrument Panel)
sp02900	Fire Protection System Activate	BCM (Body Control Module)
sp02901	Differential Pressure Sensor Replac.	ECM (Engine Control Module)
sp02902	Oil Change	ECM (Engine Control Module)
sp02903	Injector Replacement (Per Bank)	ECM (Engine Control Module)
sp02904	Injector Codes Read	ECM (Engine Control Module)
sp02905	Rail Pressure Sensor Replacement	ECM (Engine Control Module)
sp02906	Replacement Lambda Sensor	ECM (Engine Control Module)
sp02907	Replacement Of EGR Valve	ECM (Engine Control Module)
sp02908	Neutral Signal Learn	ECM (Engine Control Module)
sp02909	Cylinder 3 Injector Replacement	ECM (Engine Control Module)
sp02910	Cylinder 2 Injector Replacement	ECM (Engine Control Module)
sp02911	Cylinder 1 Injector Replacement	ECM (Engine Control Module)
sp02912	EGR Valve Test	ECM (Engine Control Module)
sp02913	Glow Plug Preheating Circuit Test	ECM (Engine Control Module)
sp02914	Resetting Distance Travelled With Water In Diesel W.Lamp ON	ECM (Engine Control Module)
sp02915	Resetting Distance Travelled With Water Temperature Warning Lamp ON	ECM (Engine Control Module)
sp02916	Self-Learnt Functions Reset	ECM (Engine Control Module)
sp02917	Proxi Alignment Procedure	TCM (Transmission Control Module)
sp02918	Check Air Presence In ABS Unit	ABS (Anti-Lock Braking System)
sp02919	Brake Pads Substitution (Brembo)	ABS (Anti-Lock Braking System)
sp02920	Brake Pads Substitution EPB (Brembo)	ABS (Anti-Lock Braking System)
sp02921	Brake Pads Substitution (Continental)	ABS (Anti-Lock Braking System)
sp02922	Disks Management Brembo	ABS (Anti-Lock Braking System)
sp02923	Replacement Brake Discs	ABS (Anti-Lock Braking System)
sp02924	Control Unit Reprogramming	ABS (Anti-Lock Braking System)
sp02925	Electric Park Brake Management	ABS (Anti-Lock Braking System)
sp02926	Electric Park Brake Motors Substitution	ABS (Anti-Lock Braking System)
sp02927	Longitudinal And Lateral Sensor Calibration	ABS (Anti-Lock Braking System)
sp02928	Brake Pressure Sensor Calibration	ABS (Anti-Lock Braking System)
sp02929	Settling Group Caliper And Brake Pads	ABS (Anti-Lock Braking System)
sp02930	Production State	ABS (Anti-Lock Braking System)
sp02931	Reset Angle Offset	ABS (Anti-Lock Braking System)
sp02932	Bleeding Brake System	ABS (Anti-Lock Braking System)
sp02933	Enable/Disable The Roll Bench Mode	ABS (Anti-Lock Braking System)
sp02934	ABS Unit Bleed	ABS (Anti-Lock Braking System)
sp02935	Calibrate Tandem Master Cylinder Sensor	ABS (Anti-Lock Braking System)
sp02936	Checking Air In The Hydraulic Circuit Between The Control Unit And H	ABS (Anti-Lock Braking System)
sp02937	Enabling Brake Pedal	ABS (Anti-Lock Braking System)
sp02938	Oil Change Reset	TVM (Torque Vectoring Module)
sp02939	Gearbox Data Transfer	TVM (Torque Vectoring Module)
sp02940	Clutch Adjustment	TVM (Torque Vectoring Module)
sp02941	E-Motor Replacement	TVM (Torque Vectoring Module)
sp02942	Self Test	TBM (Telematic Box Module)
sp02943	Backup Battery Test	TBM (Telematic Box Module)
sp02944	Reset Service Information	IC (Instrument Cluster)
sp02945	Test Pattern Display	IC (Instrument Cluster)
sp02946	Clear TPM Sensor Audit	RFH (Radio Frequency Hub)
sp02947	Clear TPM Sensor Warnings	RFH (Radio Frequency Hub)
sp02948	Target Calibration	HALF (Haptical Lane Feedback)
sp02949	Audio Video Signal Detection	ETM (Entertainment Telematic Module)
sp02950	SDARS Module Sync Command	ETM (Entertainment Telematic Module)

sp02951	Upload Configuration	EMCM (Entertainment Multimedia Control Module)
sp02952	Read Touch Pad Configuration	EMCM (Entertainment Multimedia Control Module)
sp02953	Touch Pad Self Test	EMCM (Entertainment Multimedia Control Module)
sp02954	Touch Pad Self Calibration	EMCM (Entertainment Multimedia Control Module)
sp02955	Restore Default Configuration	EMCM (Entertainment Multimedia Control Module)
sp02956	Steering Angle Calibration	EPS (Electric Power Steering)
sp02957	Proxi Alignment Procedure	ESM (Electronic Shifter Module)
sp02958	Factory VIN code lock	ESM (Electronic Shifter Module)
sp02959	LED Light Control Command	ESM (Electronic Shifter Module)
sp02960	Proxi Alignment Procedure	DTCM (Drive Train Control Module)
sp02961	Transfer Case Reset	DTCM (Drive Train Control Module)
sp02962	First Calibration	DTCM (Drive Train Control Module)
sp02963	Calibration Reset	DTCM (Drive Train Control Module)
sp02964	Factory VIN code lock	CDCM (Chassis Domain Control Module)
sp02965	Calibration Accelerometers	CDCM (Chassis Domain Control Module)
sp02966	AFLS Calibration	AFLS (Adaptive Front Lighting System)
sp02967	Active alignment program: radar calibration	ACC (Adaptive Cruise Control)
sp02968	Self Learning - Sensors Calibration	AAMR (Active Aerodynamic Module Right)
sp02969	Differential Pressure Sensor Replac.	ECM (Engine Control Module)
sp02970	Oil Change	ECM (Engine Control Module)
sp02971	Injector Replacement (Per Bank)	ECM (Engine Control Module)
sp02972	Injector Codes Read	ECM (Engine Control Module)
sp02973	Rail Pressure Sensor Replacement	ECM (Engine Control Module)
sp02974	Replacement Lambda Sensor	ECM (Engine Control Module)
sp02975	Replacement Of EGR Valve	ECM (Engine Control Module)
sp02976	Neutral Signal Learn	ECM (Engine Control Module)
sp02977	Cylinder 3 Injector Replacement	ECM (Engine Control Module)
sp02978	Cylinder 2 Injector Replacement	ECM (Engine Control Module)
sp02979	Cylinder 1 Injector Replacement	ECM (Engine Control Module)
sp02980	EGR Valve Test	ECM (Engine Control Module)
sp02981	Glow Plug Preheating Circuit Test	ECM (Engine Control Module)
sp02982	Resetting Distance Travelled With Water In Diesel W.Lamp ON	ECM (Engine Control Module)
sp02983	Resetting Distance Travelled With Water Temperature Warning Lamp ON	ECM (Engine Control Module)
sp02984	Self-Learnt Functions Reset	ECM (Engine Control Module)
sp02985	Proxi Alignment Procedure	TCM (Transmission Control Module)
sp02986	Check Air Presence In ABS Unit	ABS (Anti-Lock Braking System)
sp02987	Brake Pads Substitution (Brembo)	ABS (Anti-Lock Braking System)
sp02988	Brake Pads Substitution EPB (Brembo)	ABS (Anti-Lock Braking System)
sp02989	Brake Pads Substitution (Continental)	ABS (Anti-Lock Braking System)
sp02990	Disks Management Brembo	ABS (Anti-Lock Braking System)
sp02991	Replacement Brake Discs	ABS (Anti-Lock Braking System)
sp02992	Control Unit Reprogramming	ABS (Anti-Lock Braking System)
sp02993	Electric Park Brake Management	ABS (Anti-Lock Braking System)
sp02994	Electric Park Brake Motors Substitution	ABS (Anti-Lock Braking System)
sp02995	Longitudinal And Lateral Sensor Calibration	ABS (Anti-Lock Braking System)
sp02996	Brake Pressure Sensor Calibration	ABS (Anti-Lock Braking System)
sp02997	Settling Group Caliper And Brake Pads	ABS (Anti-Lock Braking System)
sp02998	Production State	ABS (Anti-Lock Braking System)
sp02999	Reset Angle Offset	ABS (Anti-Lock Braking System)
sp03000	Bleeding Brake System	ABS (Anti-Lock Braking System)
sp03001	Enable/Disable The Roll Bench Mode	ABS (Anti-Lock Braking System)
sp03002	ABS Unit Bleed	ABS (Anti-Lock Braking System)
sp03003	Calibrate Tandem Master Cylinder Sensor	ABS (Anti-Lock Braking System)
sp03004	Checking Air In The Hydraulic Circuit Between The Control Unit And	ABS (Anti-Lock Braking System)

sp03005	Enabling Brake Pedal	ABS (Anti-Lock Braking System)
sp03006	Oil Change Reset	TVM (Torque Vectoring Module)
sp03007	Gearbox Data Transfer	TVM (Torque Vectoring Module)
sp03008	Clutch Adjustment	TVM (Torque Vectoring Module)
sp03009	E-Motor Replacement	TVM (Torque Vectoring Module)
sp03010	Self Test	TBM (Telematic Box Module)
sp03011	Backup Battery Test	TBM (Telematic Box Module)
sp03012	Reset Service Information	IC (Instrument Cluster)
sp03013	Test Pattern Display	IC (Instrument Cluster)
sp03014	Clear TPM Sensor Audit	RFH (Radio Frequency Hub)
sp03015	Clear TPM Sensor Warnings	RFH (Radio Frequency Hub)
sp03016	Target Calibration	HALF (Haptical Lane Feedback)
sp03017	Audio Video Signal Detection	ETM (Entertainment Telematic Module)
sp03018	SDARS Module Sync Command	ETM (Entertainment Telematic Module)
sp03019	Upload Configuration	EMCM (Entertainment Multimedia Control Module)
sp03020	Read Touch Pad Configuration	EMCM (Entertainment Multimedia Control Module)
sp03021	Touch Pad Self Test	EMCM (Entertainment Multimedia Control Module)
sp03022	Touch Pad Self Calibration	EMCM (Entertainment Multimedia Control Module)
sp03023	Restore Default Configuration	EMCM (Entertainment Multimedia Control Module)
sp03024	Steering Angle Calibration	EPS (Electric Power Steering)
sp03025	Proxi Alignment Procedure	ESM (Electronic Shifter Module)
sp03026	Factory VIN code lock	ESM (Electronic Shifter Module)
sp03027	LED Light Control Command	ESM (Electronic Shifter Module)
sp03028	Proxi Alignment Procedure	DTCM (Drive Train Control Module)
sp03029	Transfer Case Reset	DTCM (Drive Train Control Module)
sp03030	First Calibration	DTCM (Drive Train Control Module)
sp03031	Calibration Reset	DTCM (Drive Train Control Module)
sp03032	Factory VIN code lock	CDCM (Chassis Domain Control Module)
sp03033	Calibration Accelerometers	CDCM (Chassis Domain Control Module)
sp03034	AFLS Calibration	AFLS (Adaptive Front Lighting System)
sp03035	Active alignment program: radar calibration	ACC (Adaptive Cruise Control)
sp03036	Self Learning - Sensors Calibration	AAMR (Active Aerodynamic Module Right)
sp03037	Differential Pressure Sensor Replac.	ECM (Engine Control Module)
sp03038	Oil Change	ECM (Engine Control Module)
sp03039	Injector Replacement (Per Bank)	ECM (Engine Control Module)
sp03040	Injector Codes Read	ECM (Engine Control Module)
sp03041	Rail Pressure Sensor Replacement	ECM (Engine Control Module)
sp03042	Replacement Lambda Sensor	ECM (Engine Control Module)
sp03043	Replacement Of EGR Valve	ECM (Engine Control Module)
sp03044	Neutral Signal Learn	ECM (Engine Control Module)
sp03045	Cylinder 3 Injector Replacement	ECM (Engine Control Module)
sp03046	Cylinder 2 Injector Replacement	ECM (Engine Control Module)
sp03047	Cylinder 1 Injector Replacement	ECM (Engine Control Module)
sp03048	EGR Valve Test	ECM (Engine Control Module)
sp03049	Glow Plug Preheating Circuit Test	ECM (Engine Control Module)
sp03050	Resetting Distance Travelled With Water In Diesel W. Lamp ON	ECM (Engine Control Module)
sp03051	Resetting Distance Travelled With Water Temperature Warning Lamp ON	ECM (Engine Control Module)
sp03052	Self-Learnt Functions Reset	ECM (Engine Control Module)
sp03053	Proxi Alignment Procedure	TCM (Transmission Control Module)
sp03054	Check Air Presence In ABS Unit	ABS (Anti-Lock Braking System)
sp03055	Brake Pads Substitution (Brembo)	ABS (Anti-Lock Braking System)
sp03056	Brake Pads Substitution EPB (Brembo)	ABS (Anti-Lock Braking System)
sp03057	Brake Pads Substitution (Continental)	ABS (Anti-Lock Braking System)
sp03058	Disks Management Brembo	ABS (Anti-Lock Braking System)

sp03059	Replacement Brake Discs	ABS (Anti-Lock Braking System)
sp03060	Control Unit Reprogramming	ABS (Anti-Lock Braking System)
sp03061	Electric Park Brake Management	ABS (Anti-Lock Braking System)
sp03062	Electric Park Brake Motors Substitution	ABS (Anti-Lock Braking System)
sp03063	Longitudinal And Lateral Sensor Calibration	ABS (Anti-Lock Braking System)
sp03064	Brake Pressure Sensor Calibration	ABS (Anti-Lock Braking System)
sp03065	Settling Group Caliper And Brake Pads	ABS (Anti-Lock Braking System)
sp03066	Production State	ABS (Anti-Lock Braking System)
sp03067	Reset Angle Offset	ABS (Anti-Lock Braking System)
sp03068	Bleeding Brake System	ABS (Anti-Lock Braking System)
sp03069	Enable/Disable The Roll Bench Mode	ABS (Anti-Lock Braking System)
sp03070	ABS Unit Bleed	ABS (Anti-Lock Braking System)
sp03071	Calibrate Tandem Master Cylinder Sensor	ABS (Anti-Lock Braking System)
sp03072	Checking Air In The Hydraulic Circuit Between The Control Unit And	ABS (Anti-Lock Braking System)
sp03073	Enabling Brake Pedal	ABS (Anti-Lock Braking System)
sp03074	Oil Change Reset	TVM (Torque Vectoring Module)
sp03075	Gearbox Data Transfer	TVM (Torque Vectoring Module)
sp03076	Clutch Adjustment	TVM (Torque Vectoring Module)
sp03077	E-Motor Replacement	TVM (Torque Vectoring Module)
sp03078	Self Test	TBM (Telematic Box Module)
sp03079	Backup Battery Test	TBM (Telematic Box Module)
sp03080	Reset Service Information	IC (Instrument Cluster)
sp03081	Test Pattern Display	IC (Instrument Cluster)
sp03082	Clear TPM Sensor Audit	RFH (Radio Frequency Hub)
sp03083	Clear TPM Sensor Warnings	RFH (Radio Frequency Hub)
sp03084	Target Calibration	HALF (Haptical Lane Feedback)
sp03085	Audio Video Signal Detection	ETM (Entertainment Telematic Module)
sp03086	SDARS Module Sync Command	ETM (Entertainment Telematic Module)
sp03087	Upload Configuration	EMCM (Entertainment Multimedia Control Module)
sp03088	Read Touch Pad Configuration	EMCM (Entertainment Multimedia Control Module)
sp03089	Touch Pad Self Test	EMCM (Entertainment Multimedia Control Module)
sp03090	Touch Pad Self Calibration	EMCM (Entertainment Multimedia Control Module)
sp03091	Restore Default Configuration	EMCM (Entertainment Multimedia Control Module)
sp03092	Steering Angle Calibration	EPS (Electric Power Steering)
sp03093	Proxi Alignment Procedure	ESM (Electronic Shifter Module)
sp03094	Factory VIN code lock	ESM (Electronic Shifter Module)
sp03095	LED Light Control Command	ESM (Electronic Shifter Module)
sp03096	Proxi Alignment Procedure	DTCM (Drive Train Control Module)
sp03097	Transfer Case Reset	DTCM (Drive Train Control Module)
sp03098	First Calibration	DTCM (Drive Train Control Module)
sp03099	Calibration Reset	DTCM (Drive Train Control Module)
sp03100	Factory VIN code lock	CDCM (Chassis Domain Control Module)
sp03101	Calibration Accelerometers	CDCM (Chassis Domain Control Module)
sp03102	AFLS Calibration	AFLS (Adaptive Front Lighting System)
sp03103	Active alignment program: radar calibration	ACC (Adaptive Cruise Control)
sp03104	Self Learning - Sensors Calibration	AAMR (Active Aerodynamic Module Right)
sp03105	Differential Pressure Sensor Replac.	ECM (Engine Control Module)
sp03106	Oil Change	ECM (Engine Control Module)
sp03107	Injector Replacement (Per Bank)	ECM (Engine Control Module)
sp03108	Injector Codes Read	ECM (Engine Control Module)
sp03109	Rail Pressure Sensor Replacement	ECM (Engine Control Module)
sp03110	Replacement Lambda Sensor	ECM (Engine Control Module)
sp03111	Replacement Of EGR Valve	ECM (Engine Control Module)
sp03112	Neutral Signal Learn	ECM (Engine Control Module)
sp03113	Cylinder 3 Injector Replacement	ECM (Engine Control Module)



sp03114	Cylinder 2 Injector Replacement	ECM (Engine Control Module)
sp03115	Cylinder 1 Injector Replacement	ECM (Engine Control Module)
sp03116	EGR Valve Test	ECM (Engine Control Module)
sp03117	Glow Plug Preheating Circuit Test	ECM (Engine Control Module)
sp03118	Resetting Distance Travelled With Water In Diesel W.Lamp ON	ECM (Engine Control Module)
sp03119	Resetting Distance Travelled With Water Temperature Warning Lamp ON	ECM (Engine Control Module)
sp03120	Self-Learnt Functions Reset	ECM (Engine Control Module)
sp03121	Proxi Alignment Procedure	TCM (Transmission Control Module)
sp03122	Check Air Presence In ABS Unit	ABS (Anti-Lock Braking System)
sp03123	Brake Pads Substitution (Brembo)	ABS (Anti-Lock Braking System)
sp03124	Brake Pads Substitution EPB (Brembo)	ABS (Anti-Lock Braking System)
sp03125	Brake Pads Substitution (Continental)	ABS (Anti-Lock Braking System)
sp03126	Disks Management Brembo	ABS (Anti-Lock Braking System)
sp03127	Replacement Brake Discs	ABS (Anti-Lock Braking System)
sp03128	Control Unit Reprogramming	ABS (Anti-Lock Braking System)
sp03129	Electric Park Brake Management	ABS (Anti-Lock Braking System)
sp03130	Electric Park Brake Motors Substitution	ABS (Anti-Lock Braking System)
sp03131	Longitudinal And Lateral Sensor Calibration	ABS (Anti-Lock Braking System)
sp03132	Brake Pressure Sensor Calibration	ABS (Anti-Lock Braking System)
sp03133	Settling Group Caliper And Brake Pads	ABS (Anti-Lock Braking System)
sp03134	Production State	ABS (Anti-Lock Braking System)
sp03135	Reset Angle Offset	ABS (Anti-Lock Braking System)
sp03136	Bleeding Brake System	ABS (Anti-Lock Braking System)
sp03137	Enable/Disable The Roll Bench Mode	ABS (Anti-Lock Braking System)
sp03138	ABS Unit Bleed	ABS (Anti-Lock Braking System)
sp03139	Calibrate Tandem Master Cylinder Sensor	ABS (Anti-Lock Braking System)
sp03140	Checking Air In The Hydraulic Circuit Between The Control Unit And	ABS (Anti-Lock Braking System)
sp03141	Enabling Brake Pedal	ABS (Anti-Lock Braking System)
sp03142	Oil Change Reset	TVM (Torque Vectoring Module)
sp03143	Gearbox Data Transfer	TVM (Torque Vectoring Module)
sp03144	Clutch Adjustment	TVM (Torque Vectoring Module)
sp03145	E-Motor Replacement	TVM (Torque Vectoring Module)
sp03146	Self Test	TBM (Telematic Box Module)
sp03147	Backup Battery Test	TBM (Telematic Box Module)
sp03148	Clear TPM Sensor Audit	RFH (Radio Frequency Hub)
sp03149	Clear TPM Sensor Warnings	RFH (Radio Frequency Hub)
sp03150	Reset Service Information	IC (Instrument Cluster)
sp03151	Test Pattern Display	IC (Instrument Cluster)
sp03152	Target Calibration	HALF (Haptical Lane Feedback)
sp03153	Audio Video Signal Detection	ETM (Entertainment Telematic Module)
sp03154	SDARS Module Sync Command	ETM (Entertainment Telematic Module)
sp03155	Proxi Alignment Procedure	ESM (Electronic Shifter Module)
sp03156	Factory VIN code lock	ESM (Electronic Shifter Module)
sp03157	LED Light Control Command	ESM (Electronic Shifter Module)
sp03158	Steering Angle Calibration	EPS (Electric Power Steering)
sp03159	Upload Configuration	EMCM (Entertainment Multimedia Control Module)
sp03160	Read Touch Pad Configuration	EMCM (Entertainment Multimedia Control Module)
sp03161	Touch Pad Self Test	EMCM (Entertainment Multimedia Control Module)
sp03162	Touch Pad Self Calibration	EMCM (Entertainment Multimedia Control Module)
sp03163	Restore Default Configuration	EMCM (Entertainment Multimedia Control Module)
sp03164	Proxi Alignment Procedure	DTCM (Drive Train Control Module)
sp03165	Transfer Case Reset	DTCM (Drive Train Control Module)
sp03166	First Calibration	DTCM (Drive Train Control Module)
sp03167	Calibration Reset	DTCM (Drive Train Control Module)



sp03168	Factory VIN code lock	CDCM (Chassis Domain Control Module)
sp03169	Calibration Accelerometers	CDCM (Chassis Domain Control Module)
sp03170	AFLS Calibration	AFLS (Adaptive Front Lighting System)
sp03171	Active alignment program: radar calibration	ACC (Adaptive Cruise Control)
sp03172	Self Learning - Sensors Calibration	AAMR (Active Aerodynamic Module Right)
sp03173	Differential Pressure Sensor Replac.	ECM (Engine Control Module)
sp03174	Oil Change	ECM (Engine Control Module)
sp03175	Injector Replacement (Per Bank)	ECM (Engine Control Module)
sp03176	Injector Codes Read	ECM (Engine Control Module)
sp03177	Rail Pressure Sensor Replacement	ECM (Engine Control Module)
sp03178	Replacement Lambda Sensor	ECM (Engine Control Module)
sp03179	Replacement Of EGR Valve	ECM (Engine Control Module)
sp03180	Neutral Signal Learn	ECM (Engine Control Module)
sp03181	Cylinder 3 Injector Replacement	ECM (Engine Control Module)
sp03182	Cylinder 2 Injector Replacement	ECM (Engine Control Module)
sp03183	Cylinder 1 Injector Replacement	ECM (Engine Control Module)
sp03184	EGR Valve Test	ECM (Engine Control Module)
sp03185	Glow Plug Preheating Circuit Test	ECM (Engine Control Module)
sp03186	Resetting Distance Travelled With Water In Diesel W.Lamp ON	ECM (Engine Control Module)
sp03187	Resetting Distance Travelled With Water Temperature Warning Lamp ON	ECM (Engine Control Module)
sp03188	Self-Learnt Functions Reset	ECM (Engine Control Module)
sp03189	Proxi Alignment Procedure	TCM (Transmission Control Module)
sp03190	Check Air Presence In ABS Unit	ABS (Anti-Lock Braking System)
sp03191	Brake Pads Substitution (Brembo)	ABS (Anti-Lock Braking System)
sp03192	Brake Pads Substitution EPB (Brembo)	ABS (Anti-Lock Braking System)
sp03193	Brake Pads Substitution (Continental)	ABS (Anti-Lock Braking System)
sp03194	Disks Management Brembo	ABS (Anti-Lock Braking System)
sp03195	Replacement Brake Discs	ABS (Anti-Lock Braking System)
sp03196	Control Unit Reprogramming	ABS (Anti-Lock Braking System)
sp03197	Electric Park Brake Management	ABS (Anti-Lock Braking System)
sp03198	Electric Park Brake Motors Substitution	ABS (Anti-Lock Braking System)
sp03199	Longitudinal And Lateral Sensor Calibration	ABS (Anti-Lock Braking System)
sp03200	Brake Pressure Sensor Calibration	ABS (Anti-Lock Braking System)
sp03201	Settling Group Caliper And Brake Pads	ABS (Anti-Lock Braking System)
sp03202	Production State	ABS (Anti-Lock Braking System)
sp03203	Reset Angle Offset	ABS (Anti-Lock Braking System)
sp03204	Bleeding Brake System	ABS (Anti-Lock Braking System)
sp03205	Enable/Disable The Roll Bench Mode	ABS (Anti-Lock Braking System)
sp03206	ABS Unit Bleed	ABS (Anti-Lock Braking System)
sp03207	Calibrate Tandem Master Cylinder Sensor	ABS (Anti-Lock Braking System)
sp03208	Checking Air In The Hydraulic Circuit Between The Control Unit And H	ABS (Anti-Lock Braking System)
sp03209	Enabling Brake Pedal	ABS (Anti-Lock Braking System)
sp03210	Oil Change Reset	TVM (Torque Vectoring Module)
sp03211	Gearbox Data Transfer	TVM (Torque Vectoring Module)
sp03212	Clutch Adjustment	TVM (Torque Vectoring Module)
sp03213	E-Motor Replacement	TVM (Torque Vectoring Module)
sp03214	Self Test	TBM (Telematic Box Module)
sp03215	Backup Battery Test	TBM (Telematic Box Module)
sp03216	Clear TPM Sensor Audit	RFH (Radio Frequency Hub)
sp03217	Clear TPM Sensor Warnings	RFH (Radio Frequency Hub)
sp03218	Reset Service Information	IC (Instrument Cluster)
sp03219	Test Pattern Display	IC (Instrument Cluster)
sp03220	Target Calibration	HALF (Haptical Lane Feedback)
sp03221	Audio Video Signal Detection	ETM (Entertainment Telematic Module)

sp03222	SDARS Module Sync Command	ETM (Entertainment Telematic Module)
sp03223	Proxi Alignment Procedure	ESM (Electronic Shifter Module)
sp03224	Factory VIN code lock	ESM (Electronic Shifter Module)
sp03225	LED Light Control Command	ESM (Electronic Shifter Module)
sp03226	Steering Angle Calibration	EPS (Electric Power Steering)
sp03227	Upload Configuration	EMCM (Entertainment Multimedia Control Module)
sp03228	Read Touch Pad Configuration	EMCM (Entertainment Multimedia Control Module)
sp03229	Touch Pad Self Test	EMCM (Entertainment Multimedia Control Module)
sp03230	Touch Pad Self Calibration	EMCM (Entertainment Multimedia Control Module)
sp03231	Restore Default Configuration	EMCM (Entertainment Multimedia Control Module)
sp03232	Proxi Alignment Procedure	DTCM (Drive Train Control Module)
sp03233	Transfer Case Reset	DTCM (Drive Train Control Module)
sp03234	First Calibration	DTCM (Drive Train Control Module)
sp03235	Calibration Reset	DTCM (Drive Train Control Module)
sp03236	Factory VIN code lock	CDCM (Chassis Domain Control Module)
sp03237	Calibration Accelerometers	CDCM (Chassis Domain Control Module)
sp03238	AFLS Calibration	AFLS (Adaptive Front Lighting System)
sp03239	Active alignment program: radar calibration	ACC (Adaptive Cruise Control)
sp03240	Self Learning - Sensors Calibration	AAMR (Active Aerodynamic Module Right)
sp03241	Differential Pressure Sensor Replac.	ECM (Engine Control Module)
sp03242	Oil Change	ECM (Engine Control Module)
sp03243	Injector Replacement (Per Bank)	ECM (Engine Control Module)
sp03244	Injector Codes Read	ECM (Engine Control Module)
sp03245	Rail Pressure Sensor Replacement	ECM (Engine Control Module)
sp03246	Replacement Lambda Sensor	ECM (Engine Control Module)
sp03247	Replacement Of EGR Valve	ECM (Engine Control Module)
sp03248	Neutral Signal Learn	ECM (Engine Control Module)
sp03249	Cylinder 3 Injector Replacement	ECM (Engine Control Module)
sp03250	Cylinder 2 Injector Replacement	ECM (Engine Control Module)
sp03251	Cylinder 1 Injector Replacement	ECM (Engine Control Module)
sp03252	EGR Valve Test	ECM (Engine Control Module)
sp03253	Glow Plug Preheating Circuit Test	ECM (Engine Control Module)
sp03254	Resetting Distance Travelled With Water In Diesel W.Lamp ON	ECM (Engine Control Module)
sp03255	Resetting Distance Travelled With Water Temperature Warning Lamp ON	ECM (Engine Control Module)
sp03256	Self-Learnt Functions Reset	ECM (Engine Control Module)
sp03257	Proxi Alignment Procedure	TCM (Transmission Control Module)
sp03258	Check Air Presence In ABS Unit	ABS (Anti-Lock Braking System)
sp03259	Brake Pads Substitution (Brembo)	ABS (Anti-Lock Braking System)
sp03260	Brake Pads Substitution EPB (Brembo)	ABS (Anti-Lock Braking System)
sp03261	Brake Pads Substitution (Continental)	ABS (Anti-Lock Braking System)
sp03262	Disks Management Brembo	ABS (Anti-Lock Braking System)
sp03263	Replacement Brake Discs	ABS (Anti-Lock Braking System)
sp03264	Control Unit Reprogramming	ABS (Anti-Lock Braking System)
sp03265	Electric Park Brake Management	ABS (Anti-Lock Braking System)
sp03266	Electric Park Brake Motors Substitution	ABS (Anti-Lock Braking System)
sp03267	Longitudinal And Lateral Sensor Calibration	ABS (Anti-Lock Braking System)
sp03268	Brake Pressure Sensor Calibration	ABS (Anti-Lock Braking System)
sp03269	Settling Group Caliper And Brake Pads	ABS (Anti-Lock Braking System)
sp03270	Production State	ABS (Anti-Lock Braking System)
sp03271	Reset Angle Offset	ABS (Anti-Lock Braking System)
sp03272	Bleeding Brake System	ABS (Anti-Lock Braking System)
sp03273	Enable/Disable The Roll Bench Mode	ABS (Anti-Lock Braking System)
sp03274	ABS Unit Bleed	ABS (Anti-Lock Braking System)

sp03275	Calibrate Tandem Master Cylinder Sensor	ABS (Anti-Lock Braking System)
sp03276	Checking Air In The Hydraulic Circuit Between The Control Unit And H	ABS (Anti-Lock Braking System)
sp03277	Enabling Brake Pedal	ABS (Anti-Lock Braking System)
sp03278	Oil Change Reset	TVM (Torque Vectoring Module)
sp03279	Gearbox Data Transfer	TVM (Torque Vectoring Module)
sp03280	Clutch Adjustment	TVM (Torque Vectoring Module)
sp03281	E-Motor Replacement	TVM (Torque Vectoring Module)
sp03282	Self Test	TBM (Telematic Box Module)
sp03283	Backup Battery Test	TBM (Telematic Box Module)
sp03284	Clear TPM Sensor Audit	RFH (Radio Frequency Hub)
sp03285	Clear TPM Sensor Warnings	RFH (Radio Frequency Hub)
sp03286	Reset Service Information	IC (Instrument Cluster)
sp03287	Test Pattern Display	IC (Instrument Cluster)
sp03288	Target Calibration	HALF (Haptical Lane Feedback)
sp03289	Audio Video Signal Detection	ETM (Entertainment Telematic Module)
sp03290	SDARS Module Sync Command	ETM (Entertainment Telematic Module)
sp03291	Proxi Alignment Procedure	ESM (Electronic Shifter Module)
sp03292	Factory VIN code lock	ESM (Electronic Shifter Module)
sp03293	LED Light Control Command	ESM (Electronic Shifter Module)
sp03294	Steering Angle Calibration	EPS (Electric Power Steering)
sp03295	Upload Configuration	EMCM (Entertainment Multimedia Control Module)
sp03296	Read Touch Pad Configuration	EMCM (Entertainment Multimedia Control Module)
sp03297	Touch Pad Self Test	EMCM (Entertainment Multimedia Control Module)
sp03298	Touch Pad Self Calibration	EMCM (Entertainment Multimedia Control Module)
sp03299	Restore Default Configuration	EMCM (Entertainment Multimedia Control Module)
sp03300	Proxi Alignment Procedure	DTCM (Drive Train Control Module)
sp03301	Transfer Case Reset	DTCM (Drive Train Control Module)
sp03302	First Calibration	DTCM (Drive Train Control Module)
sp03303	Calibration Reset	DTCM (Drive Train Control Module)
sp03304	Factory VIN code lock	CDCM (Chassis Domain Control Module)
sp03305	Calibration Accelerometers	CDCM (Chassis Domain Control Module)
sp03306	AFLS Calibration	AFLS (Adaptive Front Lighting System)
sp03307	Active alignment program: radar calibration	ACC (Adaptive Cruise Control)
sp03308	Self Learning - Sensors Calibration	AAMR (Active Aerodynamic Module Right)
sp03309	Differential Pressure Sensor Replac.	ECM (Engine Control Module)
sp03310	Oil Change	ECM (Engine Control Module)
sp03311	Injector Replacement (Per Bank)	ECM (Engine Control Module)
sp03312	Injector Codes Read	ECM (Engine Control Module)
sp03313	Rail Pressure Sensor Replacement	ECM (Engine Control Module)
sp03314	Replacement Lambda Sensor	ECM (Engine Control Module)
sp03315	Replacement Of EGR Valve	ECM (Engine Control Module)
sp03316	Neutral Signal Learn	ECM (Engine Control Module)
sp03317	Cylinder 3 Injector Replacement	ECM (Engine Control Module)
sp03318	Cylinder 2 Injector Replacement	ECM (Engine Control Module)
sp03319	Cylinder 1 Injector Replacement	ECM (Engine Control Module)
sp03320	EGR Valve Test	ECM (Engine Control Module)
sp03321	Glow Plug Preheating Circuit Test	ECM (Engine Control Module)
sp03322	Resetting Distance Travelled With Water In Diesel W.Lamp ON	ECM (Engine Control Module)
sp03323	Resetting Distance Travelled With Water Temperature Warning Lamp ON	ECM (Engine Control Module)
sp03324	Self-Learnt Functions Reset	ECM (Engine Control Module)
sp03325	Proxi Alignment Procedure	TCM (Transmission Control Module)
sp03326	Check Air Presence In ABS Unit	ABS (Anti-Lock Braking System)
sp03327	Brake Pads Substitution (Brembo)	ABS (Anti-Lock Braking System)
sp03328	Brake Pads Substitution EPB (Brembo)	ABS (Anti-Lock Braking System)

sp03329	Brake Pads Substitution (Continental)	ABS (Anti-Lock Braking System)
sp03330	Disks Management Brembo	ABS (Anti-Lock Braking System)
sp03331	Replacement Brake Discs	ABS (Anti-Lock Braking System)
sp03332	Control Unit Reprogramming	ABS (Anti-Lock Braking System)
sp03333	Electric Park Brake Management	ABS (Anti-Lock Braking System)
sp03334	Electric Park Brake Motors Substitution	ABS (Anti-Lock Braking System)
sp03335	Longitudinal And Lateral Sensor Calibration	ABS (Anti-Lock Braking System)
sp03336	Brake Pressure Sensor Calibration	ABS (Anti-Lock Braking System)
sp03337	Settling Group Caliper And Brake Pads	ABS (Anti-Lock Braking System)
sp03338	Production State	ABS (Anti-Lock Braking System)
sp03339	Reset Angle Offset	ABS (Anti-Lock Braking System)
sp03340	Bleeding Brake System	ABS (Anti-Lock Braking System)
sp03341	Enable/Disable The Roll Bench Mode	ABS (Anti-Lock Braking System)
sp03342	ABS Unit Bleed	ABS (Anti-Lock Braking System)
sp03343	Calibrate Tandem Master Cylinder Sensor	ABS (Anti-Lock Braking System)
sp03344	Checking Air In The Hydraulic Circuit Between The Control Unit And H	ABS (Anti-Lock Braking System)
sp03345	Enabling Brake Pedal	ABS (Anti-Lock Braking System)
sp03346	Oil Change Reset	TVM (Torque Vectoring Module)
sp03347	Gearbox Data Transfer	TVM (Torque Vectoring Module)
sp03348	Clutch Adjustment	TVM (Torque Vectoring Module)
sp03349	E-Motor Replacement	TVM (Torque Vectoring Module)
sp03350	Self Test	TBM (Telematic Box Module)
sp03351	Backup Battery Test	TBM (Telematic Box Module)
sp03352	Clear TPM Sensor Audit	RFH (Radio Frequency Hub)
sp03353	Clear TPM Sensor Warnings	RFH (Radio Frequency Hub)
sp03354	Reset Service Information	IC (Instrument Cluster)
sp03355	Test Pattern Display	IC (Instrument Cluster)
sp03356	Target Calibration	HALF (Haptical Lane Feedback)
sp03357	Audio Video Signal Detection	ETM (Entertainment Telematic Module)
sp03358	SDARS Module Sync Command	ETM (Entertainment Telematic Module)
sp03359	Proxi Alignment Procedure	ESM (Electronic Shifter Module)
sp03360	Factory VIN code lock	ESM (Electronic Shifter Module)
sp03361	LED Light Control Command	ESM (Electronic Shifter Module)
sp03362	Steering Angle Calibration	EPS (Electric Power Steering)
sp03363	Upload Configuration	EMCM (Entertainment Multimedia Control Module)
sp03364	Read Touch Pad Configuration	EMCM (Entertainment Multimedia Control Module)
sp03365	Touch Pad Self Test	EMCM (Entertainment Multimedia Control Module)
sp03366	Touch Pad Self Calibration	EMCM (Entertainment Multimedia Control Module)
sp03367	Restore Default Configuration	EMCM (Entertainment Multimedia Control Module)
sp03368	Proxi Alignment Procedure	DTCM (Drive Train Control Module)
sp03369	Transfer Case Reset	DTCM (Drive Train Control Module)
sp03370	First Calibration	DTCM (Drive Train Control Module)
sp03371	Calibration Reset	DTCM (Drive Train Control Module)
sp03372	Factory VIN code lock	CDCM (Chassis Domain Control Module)
sp03373	Calibration Accelerometers	CDCM (Chassis Domain Control Module)
sp03374	AFLS Calibration	AFLS (Adaptive Front Lighting System)
sp03375	Active alignment program: radar calibration	ACC (Adaptive Cruise Control)
sp03376	Self Learning - Sensors Calibration	AAMR (Active Aerodynamic Module Right)
sp03377	Deactivation Of The Power Limitation Function	ECM (Engine Control Module)
sp03378	Motorised Throttle Replacement	ECM (Engine Control Module)
sp03379	Supercharging System Components Replacement	ECM (Engine Control Module)
sp03380	Phonic Wheel Replacement	ECM (Engine Control Module)
sp03381	Intelligent Alternator (IAM) Replacement	ECM (Engine Control Module)
sp03382	Self-Adaptive Parameters Reset	ECM (Engine Control Module)

sp03383	Self-Learnt Functions Reset	ECM (Engine Control Module)
sp03384	Hydraulic Circuit Depressurization	TCM (Transmission Control Module)
sp03385	Gearbox Replacement	TCM (Transmission Control Module)
sp03386	Lever Release Solenoid Command	TCM (Transmission Control Module)
sp03387	Control Unit Reprogramming	TCM (Transmission Control Module)
sp03388	Inlet Valve Calibration	ABS (Anti Lock Brakes)
sp03389	Longitudinal And Lateral Sensor Calibration	ABS (Anti Lock Brakes)
sp03390	Pilot Valve Calibration	ABS (Anti Lock Brakes)
sp03391	Brake Pressure Sensor Calibration	ABS (Anti Lock Brakes)
sp03392	Steering Wheel Angle Sensor Offset Calibration	ABS (Anti Lock Brakes)
sp03393	Audio Video Signal Detection	ETM (Entertainment Telematic Module)
sp03394	SDARS Module Sync Command	ETM (Entertainment Telematic Module)
sp03395	Steering Angle Calibration	EPS (Electric Power Steering)
sp03396	Reset Service Information	IPC (Instrument Panel Cluster)
sp03397	Test Pattern Display	IPC (Instrument Panel Cluster)
sp03398	Target Calibration	HALF (Haptical Lane Feedback)
sp03399	Proxi Alignment Procedure	ESM (Electronic Shifter Module)
sp03400	Factory VIN code lock	ESM (Electronic Shifter Module)
sp03401	LED Light Control Command	ESM (Electronic Shifter Module)
sp03402	Active alignment program: radar calibration	ACC (Adaptive Cruise Control)
sp03403	Clear TPM Sensor Audit	RFH (Radio Frequency Hub)
sp03404	Clear TPM Sensor Warnings	RFH (Radio Frequency Hub)
sp03405	Factory VIN code lock	CDCM (Chassis Domain Control Module)
sp03406	Calibration Accelerometers	CDCM (Chassis Domain Control Module)
sp03407	Proxi Alignment Procedure	DTCM (Drive Train Control Module)
sp03408	Transfer Case Reset	DTCM (Drive Train Control Module)
sp03409	First Calibration	DTCM (Drive Train Control Module)
sp03410	Calibration Reset	DTCM (Drive Train Control Module)
sp03411	Upload Configuration	EMCM (Entertainment Multimedia Control Module)
sp03412	Read Touch Pad Configuration	EMCM (Entertainment Multimedia Control Module)
sp03413	Touch Pad Self Test	EMCM (Entertainment Multimedia Control Module)
sp03414	Touch Pad Self Calibration	EMCM (Entertainment Multimedia Control Module)
sp03415	Restore Default Configuration	EMCM (Entertainment Multimedia Control Module)
sp03416	Self Test	TBM (Telematic Box Module)
sp03417	Backup Battery Test	TBM (Telematic Box Module)
sp03418	Oil Change Reset	TVM (Torque Vectoring Module)
sp03419	Gearbox Data Transfer	TVM (Torque Vectoring Module)
sp03420	Clutch Adjustment	TVM (Torque Vectoring Module)
sp03421	E-Motor Replacement	TVM (Torque Vectoring Module)
sp03422	Deactivation Of The Power Limitation Function	ECM (Engine Control Module)
sp03423	Motorised Throttle Replacement	ECM (Engine Control Module)
sp03424	Supercharging System Components Replacement	ECM (Engine Control Module)
sp03425	Phonic Wheel Replacement	ECM (Engine Control Module)
sp03426	Intelligent Alternator (IAM) Replacement	ECM (Engine Control Module)
sp03427	Self-Adaptive Parameters Reset	ECM (Engine Control Module)
sp03428	Self-Learnt Functions Reset	ECM (Engine Control Module)
sp03429	Hydraulic Circuit Depressurization	TCM (Transmission Control Module)
sp03430	Gearbox Replacement	TCM (Transmission Control Module)
sp03431	Lever Release Solenoid Command	TCM (Transmission Control Module)
sp03432	Control Unit Reprogramming	TCM (Transmission Control Module)
sp03433	Inlet Valve Calibration	ABS (Anti Lock Brakes)
sp03434	Longitudinal And Lateral Sensor Calibration	ABS (Anti Lock Brakes)
sp03435	Pilot Valve Calibration	ABS (Anti Lock Brakes)
sp03436	Brake Pressure Sensor Calibration	ABS (Anti Lock Brakes)

sp03437	Steering Wheel Angle Sensor Offset Calibration	ABS (Anti Lock Brakes)
sp03438	Audio Video Signal Detection	ETM (Entertainment Telematic Module)
sp03439	SDARS Module Sync Command	ETM (Entertainment Telematic Module)
sp03440	Steering Angle Calibration	EPS (Electric Power Steering)
sp03441	Reset Service Information	IPC (Instrument Panel Cluster)
sp03442	Test Pattern Display	IPC (Instrument Panel Cluster)
sp03443	Target Calibration	HALF (Haptical Lane Feedback)
sp03444	Proxi Alignment Procedure	ESM (Electronic Shifter Module)
sp03445	Factory VIN code lock	ESM (Electronic Shifter Module)
sp03446	LED Light Control Command	ESM (Electronic Shifter Module)
sp03447	Active alignment program: radar calibration	ACC (Adaptive Cruise Control)
sp03448	Clear TPM Sensor Audit	RFH (Radio Frequency Hub)
sp03449	Clear TPM Sensor Warnings	RFH (Radio Frequency Hub)
sp03450	Factory VIN code lock	CDCM (Chassis Domain Control Module)
sp03451	Calibration Accelerometers	CDCM (Chassis Domain Control Module)
sp03452	Proxi Alignment Procedure	DTCM (Drive Train Control Module)
sp03453	Transfer Case Reset	DTCM (Drive Train Control Module)
sp03454	First Calibration	DTCM (Drive Train Control Module)
sp03455	Calibration Reset	DTCM (Drive Train Control Module)
sp03456	Upload Configuration	EMCM (Entertainment Multimedia Control Module)
sp03457	Read Touch Pad Configuration	EMCM (Entertainment Multimedia Control Module)
sp03458	Touch Pad Self Test	EMCM (Entertainment Multimedia Control Module)
sp03459	Touch Pad Self Calibration	EMCM (Entertainment Multimedia Control Module)
sp03460	Restore Default Configuration	EMCM (Entertainment Multimedia Control Module)
sp03461	Self Test	TBM (Telematic Box Module)
sp03462	Backup Battery Test	TBM (Telematic Box Module)
sp03463	Oil Change Reset	TVM (Torque Vectoring Module)
sp03464	Gearbox Data Transfer	TVM (Torque Vectoring Module)
sp03465	Clutch Adjustment	TVM (Torque Vectoring Module)
sp03466	E-Motor Replacement	TVM (Torque Vectoring Module)
sp03467	Deactivation Of The Power Limitation Function	ECM (Engine Control Module)
sp03468	Motorised Throttle Replacement	ECM (Engine Control Module)
sp03469	Supercharging System Components Replacement	ECM (Engine Control Module)
sp03470	Phonic Wheel Replacement	ECM (Engine Control Module)
sp03471	Intelligent Alternator (IAM) Replacement	ECM (Engine Control Module)
sp03472	Self-Adaptive Parameters Reset	ECM (Engine Control Module)
sp03473	Self-Learnt Functions Reset	ECM (Engine Control Module)
sp03474	Hydraulic Circuit Depressurization	TCM (Transmission Control Module)
sp03475	Gearbox Replacement	TCM (Transmission Control Module)
sp03476	Lever Release Solenoid Command	TCM (Transmission Control Module)
sp03477	Control Unit Reprogramming	TCM (Transmission Control Module)
sp03478	Inlet Valve Calibration	ABS (Anti Lock Brakes)
sp03479	Longitudinal And Lateral Sensor Calibration	ABS (Anti Lock Brakes)
sp03480	Pilot Valve Calibration	ABS (Anti Lock Brakes)
sp03481	Brake Pressure Sensor Calibration	ABS (Anti Lock Brakes)
sp03482	Steering Wheel Angle Sensor Offset Calibration	ABS (Anti Lock Brakes)
sp03483	Audio Video Signal Detection	ETM (Entertainment Telematic Module)
sp03484	SDARS Module Sync Command	ETM (Entertainment Telematic Module)
sp03485	Steering Angle Calibration	EPS (Electric Power Steering)
sp03486	Reset Service Information	IPC (Instrument Panel Cluster)
sp03487	Test Pattern Display	IPC (Instrument Panel Cluster)
sp03488	Target Calibration	HALF (Haptical Lane Feedback)
sp03489	Proxi Alignment Procedure	ESM (Electronic Shifter Module)

sp03490	Factory VIN code lock	ESM (Electronic Shifter Module)
sp03491	LED Light Control Command	ESM (Electronic Shifter Module)
sp03492	Active alignment program: radar calibration	ACC (Adaptive Cruise Control)
sp03493	Clear TPM Sensor Audit	RFH (Radio Frequency Hub)
sp03494	Clear TPM Sensor Warnings	RFH (Radio Frequency Hub)
sp03495	Factory VIN code lock	CDCM (Chassis Domain Control Module)
sp03496	Calibration Accelerometers	CDCM (Chassis Domain Control Module)
sp03497	Proxi Alignment Procedure	DTCM (Drive Train Control Module)
sp03498	Transfer Case Reset	DTCM (Drive Train Control Module)
sp03499	First Calibration	DTCM (Drive Train Control Module)
sp03500	Calibration Reset	DTCM (Drive Train Control Module)
sp03501	Upload Configuration	EMCM (Entertainment Multimedia Control Module)
sp03502	Read Touch Pad Configuration	EMCM (Entertainment Multimedia Control Module)
sp03503	Touch Pad Self Test	EMCM (Entertainment Multimedia Control Module)
sp03504	Touch Pad Self Calibration	EMCM (Entertainment Multimedia Control Module)
sp03505	Restore Default Configuration	EMCM (Entertainment Multimedia Control Module)
sp03506	Self Test	TBM (Telematic Box Module)
sp03507	Backup Battery Test	TBM (Telematic Box Module)
sp03508	Oil Change Reset	TVM (Torque Vectoring Module)
sp03509	Gearbox Data Transfer	TVM (Torque Vectoring Module)
sp03510	Clutch Adjustment	TVM (Torque Vectoring Module)
sp03511	E-Motor Replacement	TVM (Torque Vectoring Module)
sp03512	Deactivation Of The Power Limitation Function	ECM (Engine Control Module)
sp03513	Motorised Throttle Replacement	ECM (Engine Control Module)
sp03514	Supercharging System Components Replacement	ECM (Engine Control Module)
sp03515	Phonic Wheel Replacement	ECM (Engine Control Module)
sp03516	Intelligent Alternator (IAM) Replacement	ECM (Engine Control Module)
sp03517	Self-Adaptive Parameters Reset	ECM (Engine Control Module)
sp03518	Self-Learnt Functions Reset	ECM (Engine Control Module)
sp03519	Hydraulic Circuit Depressurization	TCM (Transmission Control Module)
sp03520	Gearbox Replacement	TCM (Transmission Control Module)
sp03521	Lever Release Solenoid Command	TCM (Transmission Control Module)
sp03522	Control Unit Reprogramming	TCM (Transmission Control Module)
sp03523	Inlet Valve Calibration	ABS (Anti Lock Brakes)
sp03524	Longitudinal And Lateral Sensor Calibration	ABS (Anti Lock Brakes)
sp03525	Pilot Valve Calibration	ABS (Anti Lock Brakes)
sp03526	Brake Pressure Sensor Calibration	ABS (Anti Lock Brakes)
sp03527	Steering Wheel Angle Sensor Offset Calibration	ABS (Anti Lock Brakes)
sp03528	Audio Video Signal Detection	ETM (Entertainment Telematic Module)
sp03529	SDARS Module Sync Command	ETM (Entertainment Telematic Module)
sp03530	Steering Angle Calibration	EPS (Electric Power Steering)
sp03531	Reset Service Information	IPC (Instrument Panel Cluster)
sp03532	Test Pattern Display	IPC (Instrument Panel Cluster)
sp03533	Target Calibration	HALF (Haptical Lane Feedback)
sp03534	Proxi Alignment Procedure	ESM (Electronic Shifter Module)
sp03535	Factory VIN code lock	ESM (Electronic Shifter Module)
sp03536	LED Light Control Command	ESM (Electronic Shifter Module)
sp03537	Active alignment program: radar calibration	ACC (Adaptive Cruise Control)
sp03538	Clear TPM Sensor Audit	RFH (Radio Frequency Hub)
sp03539	Clear TPM Sensor Warnings	RFH (Radio Frequency Hub)
sp03540	Factory VIN code lock	CDCM (Chassis Domain Control Module)
sp03541	Calibration Accelerometers	CDCM (Chassis Domain Control Module)
sp03542	Proxi Alignment Procedure	DTCM (Drive Train Control Module)



sp03543	Transfer Case Reset	DTCM (Drive Train Control Module)
sp03544	First Calibration	DTCM (Drive Train Control Module)
sp03545	Calibration Reset	DTCM (Drive Train Control Module)
sp03546	Upload Configuration	EMCM (Entertainment Multimedia Control Module)
sp03547	Read Touch Pad Configuration	EMCM (Entertainment Multimedia Control Module)
sp03548	Touch Pad Self Test	EMCM (Entertainment Multimedia Control Module)
sp03549	Touch Pad Self Calibration	EMCM (Entertainment Multimedia Control Module)
sp03550	Restore Default Configuration	EMCM (Entertainment Multimedia Control Module)
sp03551	Self Test	TBM (Telematic Box Module)
sp03552	Backup Battery Test	TBM (Telematic Box Module)
sp03553	Oil Change Reset	TVM (Torque Vectoring Module)
sp03554	Gearbox Data Transfer	TVM (Torque Vectoring Module)
sp03555	Clutch Adjustment	TVM (Torque Vectoring Module)
sp03556	E-Motor Replacement	TVM (Torque Vectoring Module)
sp03557	Deactivation Of The Power Limitation Function	ECM (Engine Control Module)
sp03558	Motorised Throttle Replacement	ECM (Engine Control Module)
sp03559	Supercharging System Components Replacement	ECM (Engine Control Module)
sp03560	Phonic Wheel Replacement	ECM (Engine Control Module)
sp03561	Intelligent Alternator (IAM) Replacement	ECM (Engine Control Module)
sp03562	Self-Adaptive Parameters Reset	ECM (Engine Control Module)
sp03563	Self-Learnt Functions Reset	ECM (Engine Control Module)
sp03564	Hydraulic Circuit Depressurization	TCM (Transmission Control Module)
sp03565	Gearbox Replacement	TCM (Transmission Control Module)
sp03566	Lever Release Solenoid Command	TCM (Transmission Control Module)
sp03567	Control Unit Reprogramming	TCM (Transmission Control Module)
sp03568	Inlet Valve Calibration	ABS (Anti Lock Brakes)
sp03569	Longitudinal And Lateral Sensor Calibration	ABS (Anti Lock Brakes)
sp03570	Pilot Valve Calibration	ABS (Anti Lock Brakes)
sp03571	Brake Pressure Sensor Calibration	ABS (Anti Lock Brakes)
sp03572	Steering Wheel Angle Sensor Offset Calibration	ABS (Anti Lock Brakes)
sp03573	Audio Video Signal Detection	ETM (Entertainment Telematic Module)
sp03574	SDARS Module Sync Command	ETM (Entertainment Telematic Module)
sp03575	Steering Angle Calibration	EPS (Electric Power Steering)
sp03576	Reset Service Information	IPC (Instrument Panel Cluster)
sp03577	Test Pattern Display	IPC (Instrument Panel Cluster)
sp03578	Target Calibration	HALF (Haptical Lane Feedback)
sp03579	Proxi Alignment Procedure	ESM (Electronic Shifter Module)
sp03580	Factory VIN code lock	ESM (Electronic Shifter Module)
sp03581	LED Light Control Command	ESM (Electronic Shifter Module)
sp03582	Active alignment program: radar calibration	ACC (Adaptive Cruise Control)
sp03583	Clear TPM Sensor Audit	RFH (Radio Frequency Hub)
sp03584	Clear TPM Sensor Warnings	RFH (Radio Frequency Hub)
sp03585	Factory VIN code lock	CDCM (Chassis Domain Control Module)
sp03586	Calibration Accelerometers	CDCM (Chassis Domain Control Module)
sp03587	Proxi Alignment Procedure	DTCM (Drive Train Control Module)
sp03588	Transfer Case Reset	DTCM (Drive Train Control Module)
sp03589	First Calibration	DTCM (Drive Train Control Module)
sp03590	Calibration Reset	DTCM (Drive Train Control Module)
sp03591	Upload Configuration	EMCM (Entertainment Multimedia Control Module)
sp03592	Read Touch Pad Configuration	EMCM (Entertainment Multimedia Control Module)
sp03593	Touch Pad Self Test	EMCM (Entertainment Multimedia Control Module)
sp03594	Touch Pad Self Calibration	EMCM (Entertainment Multimedia Control Module)
sp03595	Restore Default Configuration	EMCM (Entertainment Multimedia Control Module)
sp03596	Self Test	TBM (Telematic Box Module)



sp03597	Backup Battery Test	TBM (Telematic Box Module)
sp03598	Oil Change Reset	TVM (Torque Vectoring Module)
sp03599	Gearbox Data Transfer	TVM (Torque Vectoring Module)
sp03600	Clutch Adjustment	TVM (Torque Vectoring Module)
sp03601	E-Motor Replacement	TVM (Torque Vectoring Module)
sp03602	Deactivation Of The Power Limitation Function	ECM (Engine Control Module)
sp03603	Motorised Throttle Replacement	ECM (Engine Control Module)
sp03604	Supercharging System Components Replacement	ECM (Engine Control Module)
sp03605	Phonic Wheel Replacement	ECM (Engine Control Module)
sp03606	Intelligent Alternator (IAM) Replacement	ECM (Engine Control Module)
sp03607	Self-Adaptive Parameters Reset	ECM (Engine Control Module)
sp03608	Self-Learnt Functions Reset	ECM (Engine Control Module)
sp03609	Hydraulic Circuit Depressurization	TCM (Transmission Control Module)
sp03610	Gearbox Replacement	TCM (Transmission Control Module)
sp03611	Lever Release Solenoid Command	TCM (Transmission Control Module)
sp03612	Control Unit Reprogramming	TCM (Transmission Control Module)
sp03613	Inlet Valve Calibration	ABS (Anti Lock Brakes)
sp03614	Longitudinal And Lateral Sensor Calibration	ABS (Anti Lock Brakes)
sp03615	Pilot Valve Calibration	ABS (Anti Lock Brakes)
sp03616	Brake Pressure Sensor Calibration	ABS (Anti Lock Brakes)
sp03617	Steering Wheel Angle Sensor Offset Calibration	ABS (Anti Lock Brakes)
sp03618	Trailer Hook Presence Disabling	PAM (Parking Aid Module)
sp03619	Trailer Hook Presence Enabling	PAM (Parking Aid Module)
sp03620	Reset Odometer	IPC (Instrument Panel)
sp03621	Reset Service Information	IPC (Instrument Panel)
sp03622	Disable Seat Belts Reminder	IPC (Instrument Panel)
sp03623	Enable Seat Belts Reminder	IPC (Instrument Panel)
sp03624	Last Service Date	IPC (Instrument Panel)
sp03625	Self Learning Motor Test	HVAC (Heat, Ventilation And A/C)
sp03626	Power Down	ETM (Entertainment Telematic Module)
sp03627	Power On And Disable User Inputs	ETM (Entertainment Telematic Module)
sp03628	Audio Video Signal Detection	ETM (Entertainment Telematic Module)
sp03629	Steering Angle Calibration	EPS (Electric Power Steering)
sp03630	ECU Restart Routine	CTM (Convergence Telematic Module)
sp03631	Fire Protection System Activate	BCM (Body Control Module)
sp03632	LIN Line Request Check	BCM (Body Control Module)
sp03633	Siren Check	BCM (Body Control Module)
sp03634	Ultrasonic Sensors Check	BCM (Body Control Module)
sp03635	AFLS Calibration	AFLS (Adaptive Front Lighting System)
sp03636	Deactivation Of The Power Limitation Function	ECM (Engine Control Module)
sp03637	Motorised Throttle Replacement	ECM (Engine Control Module)
sp03638	Supercharging System Components Replacement	ECM (Engine Control Module)
sp03639	Intake Manifold Replacement	ECM (Engine Control Module)
sp03640	Phonic Wheel Replacement	ECM (Engine Control Module)
sp03641	Intelligent Alternator (IAM) Replacement	ECM (Engine Control Module)
sp03642	Self-Adaptive Parameters Reset	ECM (Engine Control Module)
sp03643	Self-Learnt Functions Reset	ECM (Engine Control Module)
sp03644	Hydraulic Circuit Depressurization	TCM (Transmission Control Module)
sp03645	Gearbox Replacement	TCM (Transmission Control Module)
sp03646	Lever Release Solenoid Command	TCM (Transmission Control Module)
sp03647	Control Unit Reprogramming	TCM (Transmission Control Module)
sp03648	Static Test	ABS (Anti Lock Brakes)
sp03649	Longitudinal G-Sensor Calibration Test	ABS (Anti Lock Brakes)
sp03650	Clear TPM Warnings	TPM (Tire Pressure Monitor)

sp03651	Clear TPM Sensor Rolls Test Results	TPM (Tire Pressure Monitor)
sp03652	Update Front And Rear Axle Nominal Tire Pressure Values	TPM (Tire Pressure Monitor)
sp03653	Program Left Front Tire Sensor ID	TPM (Tire Pressure Monitor)
sp03654	Program Left Rear Tire Sensor ID	TPM (Tire Pressure Monitor)
sp03655	Program Right Front Tire Sensor ID	TPM (Tire Pressure Monitor)
sp03656	Program Right Rear Tire Sensor ID	TPM (Tire Pressure Monitor)
sp03657	TPM Sensor Rolls Test	TPM (Tire Pressure Monitor)
sp03658	Trailer Hook Presence Disabling	PAM (Parking Aid Module)
sp03659	Trailer Hook Presence Enabling	PAM (Parking Aid Module)
sp03660	Reset Odometer	IPC (Instrument Panel)
sp03661	Reset Service Information	IPC (Instrument Panel)
sp03662	Disable Seat Belts Reminder	IPC (Instrument Panel)
sp03663	Enable Seat Belts Reminder	IPC (Instrument Panel)
sp03664	Last Service Date	IPC (Instrument Panel)
sp03665	Flap Actuators Learning Test	HVAC (Heat, Ventilation And A/C)
sp03666	ECU Restart Routine	CTM (Convergence Telematic Module)
sp03667	Fire Protection System Activate	BCM (Body Control Module)
sp03668	LIN Line Request Check	BCM (Body Control Module)
sp03669	LIN Ultrasonic Sensors Check	BCM (Body Control Module)
sp03670	Deactivation Of The Power Limitation Function	ECM (Engine Control Module)
sp03671	Fan Cooling Activation	ECM (Engine Control Module)
sp03672	Self-Adaptive Parameters Reset	ECM (Engine Control Module)
sp03673	Self-Learnt Functions Reset	ECM (Engine Control Module)
sp03674	Gearbox Replacement	TCM (Transmission Control Module)
sp03675	Lever Release Solenoid Command	TCM (Transmission Control Module)
sp03676	Static Test	ABS (Anti-Lock Braking System)
sp03677	Trailer Hook Presence Disabling	PAM (Parking Aid Module)
sp03678	Trailer Hook Presence Enabling	PAM (Parking Aid Module)
sp03679	Reset Odometer	IC (Instrument Cluster)
sp03680	Reset Service Information	IC (Instrument Cluster)
sp03681	Disable Seat Belts Reminder	IC (Instrument Cluster)
sp03682	Enable Seat Belts Reminder	IC (Instrument Cluster)
sp03683	Last Service Date	IC (Instrument Cluster)
sp03684	Actuator Calibration Test	HVAC (Heating Ventilation Air-Conditioning And Cooling)
sp03685	Fire Protection System Activate	BCM (Body Control Module )
sp03686	Deactivation Of The Power Limitation Function	ECM (Engine Control Module)
sp03687	Fan Cooling Activation	ECM (Engine Control Module)
sp03688	Self-Adaptive Parameters Reset	ECM (Engine Control Module)
sp03689	Self-Learnt Functions Reset	ECM (Engine Control Module)
sp03690	Gearbox Replacement	TCM (Transmission Control Module)
sp03691	Lever Release Solenoid Command	TCM (Transmission Control Module)
sp03692	Static Test	ABS (Anti-Lock Braking System)
sp03693	Trailer Hook Presence Disabling	PAM (Parking Aid Module)
sp03694	Trailer Hook Presence Enabling	PAM (Parking Aid Module)
sp03695	Reset Odometer	IC (Instrument Cluster)
sp03696	Reset Service Information	IC (Instrument Cluster)
sp03697	Disable Seat Belts Reminder	IC (Instrument Cluster)
sp03698	Enable Seat Belts Reminder	IC (Instrument Cluster)
sp03699	Last Service Date	IC (Instrument Cluster)
sp03700	Actuator Calibration Test	HVAC (Heating Ventilation Air-Conditioning And Cooling)
sp03701	Fire Protection System Activate	BCM (Body Control Module )