



FORCE Function List V5.10

Tips and Instructions:

The programming function only supports H6PRO, H6PRO Master Edition products.

* This feature is new.

✓ This feature is supported.

This feature is not supported.

※ This feature is partially supported.

Vehicle Classification	Vehicle Name	Vehicle Type	Read ECU Information	Read Trouble Code	Clear Trouble Code	Live Data	Actuation Test	Special function
SUV	Force One - 4*2	TD2200 BS IV (IOBD-I)	✓	✓	✓	✓		SP0016,SP0017,SP0018,SP0019,SP0020
SUV	Force One - 4*2	TD2200 BS IV (IOBD-II)	✓	✓	✓	✓		SP0016,SP0017,SP0018,SP0019,SP0020
SUV	Force One - 4*4	TD2200 BS IV (IOBD-II)	✓	✓	✓	✓		SP0016,SP0017,SP0018,SP0019,SP0020
SUV	Force One - Base	TD2650FTI BS III	✓	✓	✓	✓		SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007
SUV	Force One - Base	TD2650CR CD BS IV (IOBD-II)	✓	✓	✓	✓		SP0021,SP0022,SP0023,SP0024,SP0025,SP0026,SP0027
MPV	Traveller	TD2200 BS IV (IOBD-II)	✓	✓	✓	✓		SP0016,SP0017,SP0018,SP0019,SP0020
UV	Trax	TD2650FTI BS III	✓	✓	✓	✓		SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007
UV	Trax	TD2200 BS III (EDC15)	✓	✓	✓	✓		SP0008,SP0009,SP0010,SP0011,SP0012,SP0013,SP0014,SP0015
UV	Trax	TD2200 BS IV (IOBD-II)	✓	✓	✓	✓		SP0016,SP0017,SP0018,SP0019,SP0020
UV	Trax Pickup	TD2650FTI BS III	✓	✓	✓	✓		SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007
UV	Trax Pickup	TD2200 BS IV (IOBD-II)	✓	✓	✓	✓		SP0016,SP0017,SP0018,SP0019,SP0020
UV	Gurkha RL 4*4	TD2650FTI BS III	✓	✓	✓	✓		SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007
UV	Gurkha RL 4*4	TD2200 BS IV (IOBD-II)	✓	✓	✓	✓		SP0016,SP0017,SP0018,SP0019,SP0020
UV	Gurkha RL 4*4	TD2650CR CD BS IV (IOBD-II)	✓	✓	✓	✓		SP0021,SP0022,SP0023,SP0024,SP0025,SP0026,SP0027
LCV	Traveller	TD2650FTI BS III	✓	✓	✓	✓		SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007
LCV	Traveller	TD2200 BS III (EDC15)	✓	✓	✓	✓		SP0008,SP0009,SP0010,SP0011,SP0012,SP0013,SP0014,SP0015
LCV	Traveller	TD2200 BS III (EDC17)	✓	✓	✓	✓		SP0016,SP0017,SP0018,SP0019,SP0020
LCV	Traveller	TD2200 BS IV (IOBD-I)	✓	✓	✓	✓		SP0016,SP0017,SP0018,SP0019,SP0020
LCV	Traveller	TD2200 BS IV (IOBD-II)	✓	✓	✓	✓		SP0016,SP0017,SP0018,SP0019,SP0020
LCV	Traveller	TD3250/2650CR ED BS IV (IOBD-II)	✓	✓	✓	✓		SP0021,SP0022,SP0023,SP0024,SP0025,SP0026,SP0027
LCV	Shaktiman	TD2650FTI BS III	✓	✓	✓	✓		SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007
LCV	Shaktiman	TD2200 BS III (EDC15)	✓	✓	✓	✓		SP0008,SP0009,SP0010,SP0011,SP0012,SP0013,SP0014,SP0015
LCV	Shaktiman	TD3250/2650CR ED BS IV (IOBD-II)	✓	✓	✓	✓		SP0021,SP0022,SP0023,SP0024,SP0025,SP0026,SP0027
LCV	Citiline	TD2650FTI BS III	✓	✓	✓	✓		SP0001,SP0002,SP0003,SP0004,SP0005,SP0006,SP0007
LCV	Traveller26	TD2200 BS III (EDC15)	✓	✓	✓	✓		SP0008,SP0009,SP0010,SP0011,SP0012,SP0013,SP0014,SP0015
LCV	Traveller26	TD2200 BS III (EDC17)	✓	✓	✓	✓		SP0016,SP0017,SP0018,SP0019,SP0020
LCV	Traveller26	TD2200 BS IV (IOBD-II)	✓	✓	✓	✓		SP0016,SP0017,SP0018,SP0019,SP0020

LCV	Traveller26	TD3250/2650CR ED BS IV (IOBD-II)	✓	✓	✓	✓		SP0021,SP0022,SP0023,SP0024,SP0025,SP0026,SP0027
BS6	BOSCH BSVI	ENGINE	✓	✓	✓	✓		
BS6	DELPHI BSVI	ENGINE	✓	✓	✓	✓		

XTOOL

Special Functions List

No.	Functions Name	System Name
SP0001	Adjust Begin Of Injection	Engine
SP0002	Adjust Idle Engine Speed Set Point	Engine
SP0003	Adjust Starting Quantity Correction	Engine
SP0004	Adjust Limiting Quantity (Multiplicative)	Engine
SP0005	Adjust Value For EGR	Engine
SP0006	Write Vehicle Identification Number	Engine
SP0007	Write Service Date	Engine
SP0008	Adjustment Value Of Starting Quantity	Engine
SP0009	Adjustment Value Of Limited Quantity	Engine
SP0010	Adjustment Of Low Idle Engine Speed	Engine
SP0011	Adjustment Value Of Exhaust Gas Recirculation	Engine
SP0012	Adjustment Value Of Boost Pressure Set Point	Engine
SP0013	Vehicle Identification Number	Engine
SP0014	Software Calibration Number	Engine
SP0015	Adjustment Of Injector Classification	Engine
SP0016	Vehicle Identification Number	Engine
SP0017	Low Idle Engine Speed Adjustment Range	Engine
SP0018	Trimming Value For Air Mass	Engine
SP0019	Starting Torque	Engine
SP0020	Shop Code and Programming Date	Engine
SP0021	Pressure Relief Valve (PRV) count	Engine
SP0022	Pressure Relief Valve (PRV) Time	Engine
SP0023	Shop Code and Programming Date	Engine
SP0024	Starting Torque	Engine
SP0025	Trimming Value For Air Mass	Engine
SP0026	Low Idle Engine Speed Adjustment Range	Engine
SP0027	Vehicle Identification Number	Engine