



Shenzhen Xtooltech Co., Ltd

Holden Function List V13.20

Tips and Instructions:

The programming function only supports H6PRO, H6PRO Master Edition products.

* This feature is new.

√ This feature is supported.

 This feature is not supported.

※ This feature is partially supported.

Year	Make	Model Series	System Name	Read ECU Information	Read Trouble Code	Clear Trouble Code	Live Data	Actuation Test	Special Functions
2020	Holden	Acadia	Video Processing Control Module	√	√	√	√	√	
2020	Holden	Acadia	Liftgate Control Module	√	√	√	√	√	0146 0169
2020	Holden	Acadia	Active Safety Control Module	√	√	√	√		
2020	Holden	Acadia	Frontview Camera - Windshield	√	√	√	√		0196
2020	Holden	Acadia	Forward Range Radar Sensor - Long Range	√	√	√	√		0260
2020	Holden	Acadia	Transmission Control Module	√	√	√	√	√	0017
2020	Holden	Acadia	Serial Data Gateway Module - Processor 1	√	√	√			
2020	Holden	Acadia	Serial Data Gateway Module - Processor 2	√	√	√			
2020	Holden	Acadia	Side Object Sensor Module - Left	√	√	√		√	
2020	Holden	Acadia	Side Object Sensor Module - Right	√	√	√		√	
2020	Holden	Acadia	Steering Column Lock Control Module	√	√	√	√		
2020	Holden	Acadia	Parking Assist Control Module	√	√	√	√	√	0247
2020	Holden	Acadia	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0134 0111 0758
2020	Holden	Acadia	Keyless Entry Control Module	√	√	√	√	√	0759
2020	Holden	Acadia	Passenger Presence Module	√	√	√	√	√	0057
2020	Holden	Acadia	Instrument Cluster	√	√	√	√	√	0247
2020	Holden	Acadia	Electronic Brake Control Module	√	√	√	√	√	0225 0090 0111 0277
2020	Holden	Acadia	Power Steering Control Module	√	√	√	√		0089 0084
2020	Holden	Acadia	Suspension Control Module	√	√	√	√	√	
2020	Holden	Acadia	Seat Memory Control Module - Driver	√	√	√	√	√	
2020	Holden	Acadia	Engine Control Module	√	√	√	√	√	0263 0156 0209 0006 0115 0756 0086 0085 0154 0217 0258 0236
2020	Holden	Acadia	Body Control Module	√	√	√	√	√	0199 0239 0161 0162 0163 0164 0165 0166 0167 0168 0242 0263 0203 0201 0208 0206 0083 0267 0160 0233 0150
2020	Holden	Acadia	Radio	√	√	√	√	√	0226 0267 0269

2020	Holden	Acadia	HVAC Controls	√	√	√	√	√	
2020	Holden	Acadia	Amplifier	√	√	√	√	√	
2020	Holden	Acadia	HVAC Control Module	√	√	√	√	√	0007 0129
2020	Holden	Acadia	Rear Drive Control Module	√	√	√	√	√	0003
2020	Holden	Astra	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0111
2020	Holden	Astra	Keyless Entry Control Module	√	√	√	√	√	
2020	Holden	Astra	Transmission Control Module	√	√	√	√	√	0017 0036
2020	Holden	Astra	Frontview Camera - Windshield	√	√	√	√	√	0196
2020	Holden	Astra	Instrument Cluster	√	√	√	√	√	0247
2020	Holden	Astra	Parking Assist Control Module	√	√	√	√	√	0247 0271
2020	Holden	Astra	Serial Data Gateway Module - Processor 1	√	√	√	√	√	
2020	Holden	Astra	Serial Data Gateway Module - Processor 2	√	√	√	√	√	
2020	Holden	Astra	Steering Column Lock Control Module	√	√	√	√	√	
2020	Holden	Astra	Body Control Module	√	√	√	√	√	0199 0239 0161 0162 0163 0164 0165 0166 0167 0168 0242 0263 0203 0201 0208 0206 0083 0267 0160 0233 0150
2020	Holden	Astra	Engine Control Module	√	√	√	√	√	0263 0156 0209 0020 0132 0067 0115 0086 0085 0154 0213 0221 0212 0214 0217 0006 0144 0258 0139 0076 0147 0236
2020	Holden	Astra	Power Supply Transformer	√	√	√	√	√	
2020	Holden	Astra	HVAC Controls	√	√	√	√	√	
2020	Holden	Astra	Radio	√	√	√	√	√	0150 0226 0269
2020	Holden	Astra	HVAC Control Module	√	√	√	√	√	0007 0247 0129
2020	Holden	Astra	Trailer Lighting Control Module	√	√	√	√	√	0247
2020	Holden	Astra	Electronic Brake Control Module	√	√	√	√	√	0090 0278
2020	Holden	Astra	Power Steering Control Module	√	√	√	√	√	0089
2020	Holden	Astra	Active Safety Control Module	√	√	√	√	√	
2020	Holden	Astra	Forward Range Radar Sensor - Long Range	√	√	√	√	√	0260
2020	Holden	Colorado	Transmission Control Module	√	√	√	√	√	0016
2020	Holden	Colorado	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0134 0111 0758
2020	Holden	Colorado	Instrument Cluster	√	√	√	√	√	0247
2020	Holden	Colorado	Parking Assist Control Module	√	√	√	√	√	0247 0271
2020	Holden	Colorado	Serial Data Gateway Module	√	√	√	√	√	
2020	Holden	Colorado	Body Control Module	√	√	√	√	√	0199 0239 0161 0162 0163 0164 0165 0166 0167 0168 0242 0263 0203 0201 0208 0206 0083 0267 0160 0233 0150

2020	Holden	Colorado	HVAC Control Module	√	√	√	√	√	0007 0129
2020	Holden	Colorado	Trailer Lighting Control Module	√	√	√	√	√	0247
2020	Holden	Colorado	Human Machine Interface Control Module	√	√	√	√	√	0150
2020	Holden	Colorado	HVAC Controls	√	√	√	√	√	
2020	Holden	Colorado	Radio	√	√	√	√	√	0226 0150
2020	Holden	Colorado	Radio Controls	√	√	√	√	√	0241
2020	Holden	Colorado	Digital Radio Receiver Control Module	√	√	√	√	√	0247
2020	Holden	Colorado	Frontview Camera - Windshield	√	√	√	√	√	0196
2020	Holden	Colorado	Engine Control Module	√	√	√	√	√	0263 0210 0224 0130 0222 0066 0147 0060 0044 0045 0086 0217 0109 0068 0084 0070 0071 0074 0075 0043 0173 0179 0181 0183 0185 0222
2020	Holden	Colorado	Electronic Brake Control Module	√	√	√	√	√	0090 0112
2020	Holden	Colorado	Power Steering Control Module	√	√	√	√	√	0089
2020	Holden	Colorado	Side Object Sensor Module - Right	√	√	√		√	
2020	Holden	Colorado	Side Object Sensor Module - Left	√	√	√		√	
2020	Holden	Colorado	Transfer Case Control Module	√	√	√	√	√	0037
2020	Holden	Colorado	Steering Wheel Angle Sensor Module	√	√	√			0093 0090
2020	Holden	Commodore	Video Processing Control Module	√	√	√	√	√	
2020	Holden	Commodore	Trailer Lighting Control Module	√	√	√	√	√	0247
2020	Holden	Commodore	Headlamp Control Module	√	√	√	√	√	0195
2020	Holden	Commodore	Liftgate Control Module	√	√	√	√	√	0146 0169
2020	Holden	Commodore	Side Object Sensor Module - Left	√	√	√		√	
2020	Holden	Commodore	Transmission Control Module	√	√	√	√	√	0020 0084 0017
2020	Holden	Commodore	Active Safety Control Module	√	√	√	√	√	
2020	Holden	Commodore	Frontview Camera - Windshield	√	√	√	√	√	0196
2020	Holden	Commodore	Forward Range Radar Sensor - Long Range	√	√	√	√	√	0260
2020	Holden	Commodore	Instrument Cluster	√	√	√	√	√	0247 0145
2020	Holden	Commodore	Steering Column Lock Control Module	√	√	√	√	√	
2020	Holden	Commodore	Serial Data Gateway Module	√	√	√			
2020	Holden	Commodore	Electronic Brake Control Module	√	√	√	√	√	0090 0278
2020	Holden	Commodore	Power Steering Control Module	√	√	√	√	√	0089
2020	Holden	Commodore	Suspension Control Module	√	√	√	√	√	
2020	Holden	Commodore	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0111
2020	Holden	Commodore	Keyless Entry Control Module	√	√	√	√	√	
2020	Holden	Commodore	Seat Memory Control Module - Driver	√	√	√	√	√	
2020	Holden	Commodore	Seat Memory Control Module - Passenger	√	√	√	√	√	

2020	Holden	Commodore	Body Control Module	√	√	√	√	√	0199 0239 0161 0162 0163 0164 0165 0166 0167 0168 0242 0263 0203 0201 0208 0206 0083 0267 0160 0233 0150
2020	Holden	Commodore	Amplifier	√	√	√	√		
2020	Holden	Commodore	HVAC Controls	√	√	√	√	√	
2020	Holden	Commodore	Radio Controls	√	√	√	√		0241
2020	Holden	Commodore	Radio	√	√	√	√	√	0150 0226 0269
2020	Holden	Commodore	Engine Control Module	√	√	√	√	√	0263 0156 0209 0076 0132 0067 0147 0115 0086 0154 0212 0214 0217 0006 0144 0258 0236 0139 0756 0085 0222 076D 079A 0044 0045 0171 0219 0792 0109 0074 0075 0072 0073 0070 0071 0119 0117 077E 0178 0180
2020	Holden	Commodore	Power Supply Transformer	√	√	√	√		
2020	Holden	Commodore	Parking Assist Control Module	√	√	√	√	√	
2020	Holden	Commodore	Differential Control Module	√	√	√	√	√	0003
2020	Holden	Commodore	HVAC Control Module	√	√	√	√	√	0007 0129
2020	Holden	Equinox	Electronic Brake Control Module	√	√	√	√	√	0225 0090 0229 0771
2020	Holden	Equinox	Power Steering Control Module	√	√	√	√		0089
2020	Holden	Equinox	Serial Data Gateway Module	√	√	√			
2020	Holden	Equinox	Trailer Lighting Control Module	√	√	√	√	√	0247
2020	Holden	Equinox	Video Processing Control Module	√	√	√	√	√	
2020	Holden	Equinox	Instrument Cluster	√	√	√	√	√	0247
2020	Holden	Equinox	Parking Assist Control Module	√	√	√	√	√	0247 0271
2020	Holden	Equinox	Steering Column Lock Control Module	√	√	√	√		
2020	Holden	Equinox	Transmission Control Module	√	√	√	√	√	0017 0036
2020	Holden	Equinox	Headlamp Control Module	√	√	√	√	√	0195
2020	Holden	Equinox	Liftgate Control Module	√	√	√	√	√	0146 0169
2020	Holden	Equinox	Telematics Communication Interface Control Module	√	√	√			
2020	Holden	Equinox	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0134 0111 0758
2020	Holden	Equinox	Keyless Entry Control Module	√	√	√	√	√	
2020	Holden	Equinox	Body Control Module	√	√	√	√	√	0199 0239 0161 0162 0163 0164 0165 0166 0167 0168 0242 0263 0203 0201 0208 0206 0083 0267 0160 0233 0150
2020	Holden	Equinox	Side Object Sensor Module - Left	√	√	√		√	

2020	Holden	Equinox	Frontview Camera - Windshield	√	√	√	√		0196 0084
2020	Holden	Equinox	HVAC Control Module	√	√	√	√	√	0007 0129
2020	Holden	Equinox	Seat Memory Control Module - Driver	√	√	√	√	√	
2020	Holden	Equinox	Amplifier	√	√	√	√		
2020	Holden	Equinox	HVAC Controls	√	√	√	√	√	
2020	Holden	Equinox	Radio Controls	√	√	√	√		0241
2020	Holden	Equinox	Radio	√	√	√	√	√	0150 0226 0269
2020	Holden	Equinox	Engine Control Module	√	√	√	√	√	0263 0156 0209 0020 0132 0067 0115 0086 0085 0154 0213 0221 0212 0214 0217 0006 0144 0258 0139 0076 0147 0236 0222 076D 079A 0764 0171 0219 0792 0109 0074 0075 0072 0073 0070 0071 0119 0117 07AF 077E
2020	Holden	Equinox	Rear Drive Control Module	√	√	√	√	√	0003
2020	Holden	Spark	Transmission Control Module	√	√	√	√	√	0017
2020	Holden	Spark	Keyless Entry Control Module	√	√	√	√	√	
2020	Holden	Spark	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0111
2020	Holden	Spark	Parking Assist Control Module	√	√	√	√	√	0247 0271
2020	Holden	Spark	Instrument Cluster	√	√	√	√	√	0247
2020	Holden	Spark	Steering Column Lock Control Module	√	√	√	√		
2020	Holden	Spark	Body Control Module	√	√	√	√	√	0199 0239 0161 0162 0163 0164 0165 0166 0167 0168 0242 0263 0203 0201 0208 0206 0083 0267 0160 0233 0150
2020	Holden	Spark	Frontview Camera - Windshield	√	√	√	√	√	0205 0196 075A
2020	Holden	Spark	Electronic Brake Control Module	√	√	√	√	√	0090 0111 0229 0225
2020	Holden	Spark	Power Steering Control Module	√	√	√	√		0089
2020	Holden	Spark	Radio	√	√	√	√	√	0150 0226 0269
2020	Holden	Spark	Serial Data Gateway Module - Processor 1	√	√	√			
2020	Holden	Spark	Serial Data Gateway Module - Processor 2	√	√	√			
2020	Holden	Spark	Engine Control Module	√	√	√	√	√	0156 0209 0132 0067 0263 0086 0217 0115
2020	Holden	Trailblazer	Transmission Control Module	√	√	√	√	√	0016
2020	Holden	Trailblazer	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0134 0111 0758
2020	Holden	Trailblazer	Instrument Cluster	√	√	√	√	√	0247
2020	Holden	Trailblazer	Serial Data Gateway Module	√	√	√			
2020	Holden	Trailblazer	Parking Assist Control Module	√	√	√	√	√	0247 0271

2020	Holden	Trailblazer	Body Control Module	√	√	√	√	√	0199 0239 0161 0162 0163 0164 0165 0166 0167 0168 0242 0263 0203 0201 0208 0206 0083 0267 0160 0233 0150
2020	Holden	Trailblazer	Trailer Lighting Control Module	√	√	√	√	√	0247
2020	Holden	Trailblazer	Human Machine Interface Control Module	√	√	√	√	√	0150
2020	Holden	Trailblazer	HVAC Controls	√	√	√	√	√	
2020	Holden	Trailblazer	Radio	√	√	√	√	√	0226 0150
2020	Holden	Trailblazer	Radio Controls	√	√	√	√	√	0241
2020	Holden	Trailblazer	Digital Radio Receiver Control Module	√	√	√	√	√	0247
2020	Holden	Trailblazer	Frontview Camera - Windshield	√	√	√	√	√	0196
2020	Holden	Trailblazer	Engine Control Module	√	√	√	√	√	0263 0210 0224 0130 0222 0066 0147 0060 0044 0045 0086 0217 0109 0068 0084 0070 0071 0074 0075 0043 0173 0179 0181 0183 0185 0232
2020	Holden	Trailblazer	Electronic Brake Control Module	√	√	√	√	√	0090 0112
2020	Holden	Trailblazer	Power Steering Control Module	√	√	√	√	√	0089
2020	Holden	Trailblazer	Transfer Case Control Module	√	√	√	√	√	0037
2020	Holden	Trailblazer	HVAC Control Module	√	√	√	√	√	0007 0129
2020	Holden	Trailblazer	Side Object Sensor Module - Left	√	√	√	√	√	
2020	Holden	Trailblazer	Side Object Sensor Module - Right	√	√	√	√	√	
2020	Holden	Trailblazer	Steering Wheel Angle Sensor Module	√	√	√	√	√	0093 0090
2020	Holden	Trax	Trailer Lighting Control Module	√	√	√	√	√	0247
2020	Holden	Trax	Electronic Brake Control Module	√	√	√	√	√	0090
2020	Holden	Trax	Power Steering Control Module	√	√	√	√	√	0207
2020	Holden	Trax	Steering Wheel Angle Sensor Module	√	√	√	√	√	0093 0090
2020	Holden	Trax	Headlamp Control Module	√	√	√	√	√	0195
2020	Holden	Trax	Headlamp High Beam Control Module	√	√	√	√	√	0247
2020	Holden	Trax	Body Control Module	√	√	√	√	√	0263 0203 0083 0159
2020	Holden	Trax	Instrument Cluster	√	√	√	√	√	0247
2020	Holden	Trax	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0134 0111 0758
2020	Holden	Trax	Keyless Entry Control Module	√	√	√	√	√	
2020	Holden	Trax	Parking Assist Control Module	√	√	√	√	√	0247 0271
2020	Holden	Trax	Serial Data Gateway Module	√	√	√	√	√	
2020	Holden	Trax	Steering Column Lock Control Module	√	√	√	√	√	
2020	Holden	Trax	Side Object Sensor Module - Left	√	√	√	√	√	
2020	Holden	Trax	Frontview Camera - Windshield	√	√	√	√	√	0205 0196 075A

2020	Holden	Trax	Engine Control Module	√	√	√	√	√	0263 0156 0209 0020 0132 0067 0066 076D 0086 0213 0217 0006
2020	Holden	Trax	Transmission Control Module	√	√	√	√	√	0017 0036
2020	Holden	Trax	Power Supply Transformer	√	√	√	√	√	
2020	Holden	Trax	HVAC Control Module	√	√	√	√	√	
2020	Holden	Trax	Front Seat Heating Control Module	√	√	√	√	√	
2020	Holden	Trax	Radio	√	√	√	√	√	
2020	Holden	Trax	Chassis Control Module	√	√	√	√	√	0217
2019	Holden	Acadia	Liftgate Control Module	√	√	√	√	√	0146 0169
2019	Holden	Acadia	Video Processing Control Module	√	√	√	√	√	
2019	Holden	Acadia	Engine Control Module	√	√	√	√	√	0263 0156 0209 0006 0115 0756 0086 0085 0154 0217 0258 0236
2019	Holden	Acadia	Transmission Control Module	√	√	√	√	√	0017
2019	Holden	Acadia	Instrument Cluster	√	√	√	√	√	0247
2019	Holden	Acadia	Left Side Object Detection Control Module	√	√	√	√	√	
2019	Holden	Acadia	Parking Assist Control Module	√	√	√	√	√	0247
2019	Holden	Acadia	Keyless Entry Control Module	√	√	√	√	√	
2019	Holden	Acadia	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0134 0111 0758
2019	Holden	Acadia	HVAC Control Module	√	√	√	√	√	0007 0129
2019	Holden	Acadia	Body Control Module	√	√	√	√	√	0199 0239 0161 0162 0163 0164 0165 0166 0167 0168 0242 0263 0203 0201 0208 0206 0083 0267 0160 0233 0150
2019	Holden	Acadia	Amplifier	√	√	√	√	√	
2019	Holden	Acadia	HVAC Controls	√	√	√	√	√	
2019	Holden	Acadia	Radio	√	√	√	√	√	0226 0267 0269
2019	Holden	Acadia	Active Safety Control Module	√	√	√	√	√	
2019	Holden	Acadia	Frontview Camera - Windshield	√	√	√	√	√	0196
2019	Holden	Acadia	Long Range Radar Sensor Module	√	√	√	√	√	0260
2019	Holden	Acadia	Electronic Brake Control Module	√	√	√	√	√	0225 0090 0111 0277
2019	Holden	Acadia	Power Steering Control Module	√	√	√	√	√	0089 0084
2019	Holden	Acadia	Suspension Control Module	√	√	√	√	√	
2019	Holden	Acadia	Right Side Object Detection Control Module	√	√	√	√	√	
2019	Holden	Acadia	Seat Memory Control Module - Driver	√	√	√	√	√	
2019	Holden	Acadia	Rear Differential Clutch Control Module	√	√	√	√	√	0003
2019	Holden	Acadia	Serial Data Gateway Module - Processor 1	√	√	√	√	√	
2019	Holden	Acadia	Serial Data Gateway Module - Processor 2	√	√	√	√	√	
2019	Holden	Acadia	Steering Column Lock Control Module	√	√	√	√	√	
2019	Holden	Astra Sedan NB4	Steering Column Lock Control Module	√	√	√	√	√	

2019	Holden	Astra Sedan NB4	Engine Control Module	√	√	√	√	√	0263 0156 0209 0020 0132 0067 0115 0086 0085 0154 0213 0221 0212 0214 0217 0006 0144 0258 0130
2019	Holden	Astra Sedan NB4	Transmission Control Module	√	√	√	√	√	0017 0036
2019	Holden	Astra Sedan NB4	Trailer Lighting Control Module	√	√	√	√	√	0247
2019	Holden	Astra Sedan NB4	Body Control Module	√	√	√	√	√	0242 0263 0203 0208 0201 0206 0083 0160
2019	Holden	Astra Sedan NB4	HVAC Control Module	√	√	√	√	√	0007 0129
2019	Holden	Astra Sedan NB4	Power Supply Transformer	√	√	√	√	√	
2019	Holden	Astra Sedan NB4	Keyless Entry Control Module	√	√	√	√	√	
2019	Holden	Astra Sedan NB4	Radio	√	√	√	√	√	0226 0150
2019	Holden	Astra Sedan NB4	HVAC Controls	√	√	√	√	√	
2019	Holden	Astra Sedan NB4	Amplifier	√	√	√	√	√	
2019	Holden	Astra Sedan NB4	Human Machine Interface Control Module	√	√	√	√	√	0150
2019	Holden	Astra Sedan NB4	Radio Controls	√	√	√	√	√	0241
2019	Holden	Astra Sedan NB4	Parking Assist Control Module	√	√	√	√	√	0271 0247
2019	Holden	Astra Sedan NB4	Instrument Cluster	√	√	√	√	√	0247
2019	Holden	Astra Sedan NB4	Frontview Camera - Windshield	√	√	√	√	√	0205 0196 075A
2019	Holden	Astra Sedan NB4	Electronic Brake Control Module	√	√	√	√	√	0090 0278
2019	Holden	Astra Sedan NB4	Power Steering Control Module	√	√	√	√	√	0089
2019	Holden	Astra Sedan NB4	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0111
2019	Holden	Astra-K	Liftgate Control Module	√	√	√	√	√	0146 0169
2019	Holden	Astra-K	Trailer Lighting Control Module	√	√	√	√	√	0247
2019	Holden	Astra-K	Frontview Camera - Windshield	√	√	√	√	√	0205 0196 075A
2019	Holden	Astra-K	Long Range Radar Sensor Module	√	√	√	√	√	0260
2019	Holden	Astra-K	Active Safety Control Module	√	√	√	√	√	
2019	Holden	Astra-K	HVAC Control Module	√	√	√	√	√	0007 0247 0129
2019	Holden	Astra-K	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0111
2019	Holden	Astra-K	Instrument Cluster	√	√	√	√	√	0247
2019	Holden	Astra-K	Parking Assist Control Module	√	√	√	√	√	0247 0271
2019	Holden	Astra-K	Serial Data Gateway Module	√	√	√	√	√	
2019	Holden	Astra-K	Body Control Module	√	√	√	√	√	0242 0263 0203 0208 0201 0206 0083 0160
2019	Holden	Astra-K	Power Supply Transformer	√	√	√	√	√	
2019	Holden	Astra-K	Human Machine Interface Control Module	√	√	√	√	√	0150
2019	Holden	Astra-K	HVAC Controls	√	√	√	√	√	
2019	Holden	Astra-K	Radio	√	√	√	√	√	0226 0150
2019	Holden	Astra-K	Radio Controls	√	√	√	√	√	0241
2019	Holden	Astra-K	Headlamp Control Module	√	√	√	√	√	0195
2019	Holden	Astra-K	Multi-Axis Acceleration Sensor Module	√	√	√	√	√	0112 0111
2019	Holden	Astra-K	Electronic Brake Control Module	√	√	√	√	√	0090 0278

2019	Holden	Astra-K	Power Steering Control Module	√	√	√	√		0089
2019	Holden	Astra-K	Transmission Control Module	√	√	√	√	√	0017 0036
2019	Holden	Astra-K	Engine Control Module	√	√	√	√	√	0263 0156 0209 0020 0132 0067 0115 0086 0085 0154 0213 0221 0212 0214 0217 0006 0144 0258 0130
2019	Holden	Barina	Electronic Brake Control Module	√	√	√	√	√	0090
2019	Holden	Barina	Power Steering Control Module	√	√	√	√		0207
2019	Holden	Barina	Steering Wheel Angle Sensor Module	√	√	√			0093 0090
2019	Holden	Barina	HVAC Control Module	√	√	√	√	√	
2019	Holden	Barina	Keyless Entry Control Module	√	√	√	√	√	
2019	Holden	Barina	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0111
2019	Holden	Barina	Instrument Cluster	√	√	√	√	√	
2019	Holden	Barina	Parking Assist Control Module	√	√	√	√	√	0247 0271
2019	Holden	Barina	Serial Data Gateway Module	√	√	√			
2019	Holden	Barina	Body Control Module	√	√	√	√	√	0263 0203 0083 0159
2019	Holden	Barina	Front Seat Heating Control Module	√	√	√	√	√	
2019	Holden	Barina	Radio	√	√	√	√	√	
2019	Holden	Barina	Transmission Control Module	√	√	√	√	√	0017 0036
2019	Holden	Barina	Engine Control Module	√	√	√	√	√	0156 0209 0132 0067 0263 0086 0217 0139
2019	Holden	Barina	Chassis Control Module	√	√	√	√	√	0217
2019	Holden	Barina	Steering Column Lock Control Module	√	√	√	√		
2019	Holden	Colorado	Transmission Control Module	√	√	√	√	√	0016
2019	Holden	Colorado	Electronic Brake Control Module	√	√	√	√	√	0090 0112
2019	Holden	Colorado	Power Steering Control Module	√	√	√	√		0089
2019	Holden	Colorado	Instrument Cluster	√	√	√	√	√	0247
2019	Holden	Colorado	Parking Assist Control Module	√	√	√	√	√	0247 0271
2019	Holden	Colorado	Serial Data Gateway Module	√	√	√			
2019	Holden	Colorado	Trailer Lighting Control Module	√	√	√	√	√	0247
2019	Holden	Colorado	HVAC Control Module	√	√	√	√	√	0007 0129
2019	Holden	Colorado	Frontview Camera - Windshield	√	√	√	√	√	0196
2019	Holden	Colorado	Transfer Case Control Module	√	√	√	√	√	0037
2019	Holden	Colorado	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0134 0111 0758
2019	Holden	Colorado	Body Control Module	√	√	√	√	√	0199 0239 0161 0162 0163 0164 0165 0166 0167 0168 0242 0263 0203 0201 0208 0206 0083 0267 0160 0233 0159
2019	Holden	Colorado	Radio	√	√	√	√	√	0226 0150
2019	Holden	Colorado	Human Machine Interface Control Module	√	√	√	√	√	0150
2019	Holden	Colorado	HVAC Controls	√	√	√	√	√	

2019	Holden	Colorado	Radio Controls	√	√	√	√		0241
2019	Holden	Colorado	Engine Control Module	√	√	√	√	√	0263 0210 0224 0130 0222 0066 0147 0060 0044 0045 0086 0217 0109 0068 0084 0070 0071 0074 0075 0043 0173 0179 0181 0183 0185 0232
2019	Holden	Colorado	Steering Wheel Angle Sensor Module	√	√	√			0093 0090
2019	Holden	Commodore	Headlamp Control Module	√	√	√	√	√	0195
2019	Holden	Commodore	Liftgate Control Module	√	√	√	√	√	0146 0169
2019	Holden	Commodore	Trailer Lighting Control Module	√	√	√	√	√	0247
2019	Holden	Commodore	Steering Column Lock Control Module	√	√	√	√		
2019	Holden	Commodore	Video Processing Control Module	√	√	√	√	√	
2019	Holden	Commodore	HVAC Control Module	√	√	√	√	√	0007 0129
2019	Holden	Commodore	Seat Memory Control Module - Driver	√	√	√	√	√	
2019	Holden	Commodore	Engine Control Module	√	√	√	√	√	0156 0210 0066 0147 0060 0044 0045 0086 0097 0068 0084 0073 0070 0071 0117 0119 0131 0179 0181 0183 0185 0232 0043 0173 0128 0263 0209 0076 0132 0067 0115 0154 0212 0214 0217 0006 0144 0258 0236 0139
2019	Holden	Commodore	Instrument Cluster	√	√	√	√	√	0247 0145
2019	Holden	Commodore	Serial Data Gateway Module	√	√	√			
2019	Holden	Commodore	Left Side Object Detection Control Module	√	√	√		√	
2019	Holden	Commodore	Parking Assist Control Module	√	√	√	√	√	
2019	Holden	Commodore	Transmission Control Module	√	√	√	√	√	0020 0084 0017
2019	Holden	Commodore	Keyless Entry Control Module	√	√	√	√	√	0759
2019	Holden	Commodore	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0111
2019	Holden	Commodore	Rear Differential Clutch Control Module	√	√	√	√	√	0003
2019	Holden	Commodore	Body Control Module	√	√	√	√	√	0199 0239 0161 0162 0163 0164 0165 0166 0167 0168 0242 0263 0203 0201 0208 0206 0083 0267 0160 0233 0150
2019	Holden	Commodore	Seat Memory Control Module - Passenger	√	√	√	√	√	
2019	Holden	Commodore	Power Supply Transformer	√	√	√	√		
2019	Holden	Commodore	Radio	√	√	√	√	√	0150 0226 0269 0267
2019	Holden	Commodore	Amplifier	√	√	√	√		
2019	Holden	Commodore	HVAC Controls	√	√	√	√	√	

2019	Holden	Commodore	Radio Controls	√	√	√	√		0241
2019	Holden	Commodore	Active Safety Control Module	√	√	√	√		
2019	Holden	Commodore	Long Range Radar Sensor Module	√	√	√	√		0260
2019	Holden	Commodore	Frontview Camera - Windshield	√	√	√	√		0196
2019	Holden	Commodore	Electronic Brake Control Module	√	√	√	√	√	0090 0278
2019	Holden	Commodore	Power Steering Control Module	√	√	√	√		0089
2019	Holden	Commodore	Suspension Control Module	√	√	√	√	√	
2019	Holden	Equinox	Engine Control Module	√	√	√	√	√	0263 0156 0209 0020 0132 0067 0115 0086 0085 0154 0213 0221 0212 0214 0217 0006 0144 0258 0139 0210 0224 0130 0222 0066 0147 0060 079A 0044 0045 0097 0792 0109 0068 0084 0070 0071 0074 0075 0117 0043 0173 0179 0181 0183
2019	Holden	Equinox	Rear Differential Clutch Control Module	√	√	√	√	√	0003
2019	Holden	Equinox	Steering Column Lock Control Module	√	√	√	√		
2019	Holden	Equinox	Transmission Control Module	√	√	√	√	√	0017 0036
2019	Holden	Equinox	Electronic Brake Control Module	√	√	√	√	√	0225 0090 0229 0771
2019	Holden	Equinox	Power Steering Control Module	√	√	√	√		0089
2019	Holden	Equinox	Frontview Camera Module	√	√	√	√	√	0247
2019	Holden	Equinox	Headlamp Control Module	√	√	√	√	√	0195
2019	Holden	Equinox	Liftgate Control Module	√	√	√	√	√	0146 0169
2019	Holden	Equinox	HVAC Control Module	√	√	√	√	√	0007 0129
2019	Holden	Equinox	Seat Memory Control Module - Driver	√	√	√	√	√	
2019	Holden	Equinox	Frontview Camera - Windshield	√	√	√	√		0196 0084
2019	Holden	Equinox	Long Range Radar Sensor Module	√	√	√	√		0260
2019	Holden	Equinox	Video Processing Control Module	√	√	√	√	√	
2019	Holden	Equinox	Parking Assist Control Module	√	√	√	√	√	0247 0271
2019	Holden	Equinox	Left Side Object Detection Control Module	√	√	√	√	√	
2019	Holden	Equinox	Serial Data Gateway Module	√	√	√	√		
2019	Holden	Equinox	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0134 0111 0758
2019	Holden	Equinox	Keyless Entry Control Module	√	√	√	√	√	0759
2019	Holden	Equinox	Instrument Cluster	√	√	√	√	√	0247
2019	Holden	Equinox	Body Control Module	√	√	√	√	√	0199 0239 0161 0162 0163 0164 0165 0166 0167 0168 0242 0263 0203 0201 0208 0206 0083 0267 0160 0233 0150
2019	Holden	Equinox	Amplifier	√	√	√	√		

2019	Holden	Equinox	Radio	√	√	√	√	√	0150 0226 0269 0267
2019	Holden	Equinox	HVAC Controls	√	√	√	√	√	
2019	Holden	Equinox	Radio Controls	√	√	√	√	√	0241
2019	Holden	Equinox	Trailer Interface Control Module	√	√	√	√	√	0247
2019	Holden	Spark	Steering Column Lock Control Module	√	√	√	√	√	
2019	Holden	Spark	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0111
2019	Holden	Spark	Keyless Entry Control Module	√	√	√	√	√	
2019	Holden	Spark	Transmission Control Module	√	√	√	√	√	0017
2019	Holden	Spark	Serial Data Gateway Module	√	√	√			
2019	Holden	Spark	Parking Assist Control Module	√	√	√	√	√	0247 0271
2019	Holden	Spark	Instrument Cluster	√	√	√	√	√	0247
2019	Holden	Spark	Engine Control Module	√	√	√	√	√	0263 0156 0132 0067 0147 0209 0086 0217
2019	Holden	Spark	HVAC Controls	√	√	√	√	√	
2019	Holden	Spark	Radio	√	√	√	√	√	0150 0226 0269
2019	Holden	Spark	Body Control Module	√	√	√	√	√	0199 0239 0161 0162 0163 0164 0165 0166 0167 0168 0242 0263 0203 0201 0208 0206 0083 0267 0160 0233 0150
2019	Holden	Spark	Electronic Brake Control Module	√	√	√	√	√	0090 0111 0229 0225
2019	Holden	Spark	Power Steering Control Module	√	√	√	√		0089
2019	Holden	Spark	Frontview Camera - Windshield	√	√	√	√	√	0205 0196 075A
2019	Holden	Trailblazer	Transmission Control Module	√	√	√	√	√	0016
2019	Holden	Trailblazer	Electronic Brake Control Module	√	√	√	√	√	0090 0112
2019	Holden	Trailblazer	Power Steering Control Module	√	√	√	√		0089
2019	Holden	Trailblazer	HVAC Control Module	√	√	√	√	√	0007 0129
2019	Holden	Trailblazer	Frontview Camera - Windshield	√	√	√	√	√	0196
2019	Holden	Trailblazer	Instrument Cluster	√	√	√	√	√	0247
2019	Holden	Trailblazer	Left Side Object Detection Control Module	√	√	√		√	
2019	Holden	Trailblazer	Right Side Object Detection Control Module	√	√	√		√	
2019	Holden	Trailblazer	Serial Data Gateway Module	√	√	√			
2019	Holden	Trailblazer	Trailer Lighting Control Module	√	√	√	√	√	0247
2019	Holden	Trailblazer	Parking Assist Control Module	√	√	√	√	√	0247 0271
2019	Holden	Trailblazer	Transfer Case Control Module	√	√	√	√	√	0037
2019	Holden	Trailblazer	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0134 0111 0758
2019	Holden	Trailblazer	Body Control Module	√	√	√	√	√	0199 0239 0161 0162 0163 0164 0165 0166 0167 0168 0242 0263 0203 0201 0208 0206 0083 0267 0160 0233 0150
2019	Holden	Trailblazer	Human Machine Interface Control Module	√	√	√	√	√	0150

2019	Holden	Trailblazer	HVAC Controls	√	√	√	√	√	
2019	Holden	Trailblazer	Radio Controls	√	√	√	√	√	0241
2019	Holden	Trailblazer	Radio	√	√	√	√	√	0226 0150
2019	Holden	Trailblazer	Engine Control Module	√	√	√	√	√	0263 0210 0224 0130 0222 0066 0147 0060 0044 0045 0086 0217 0109 0068 0084 0070 0071 0074 0075 0043 0173 0179 0181 0183 0185 0232
2019	Holden	Trailblazer	Steering Wheel Angle Sensor Module	√	√	√			0093 0090
2019	Holden	Trax	Engine Control Module	√	√	√	√	√	0263 0156 0209 0020 0132 0067 0066 076D 0086 0213 0217 0006
2019	Holden	Trax	Steering Column Lock Control Module	√	√	√	√		
2019	Holden	Trax	Rear Differential Clutch Control Module	√	√	√	√		0003 075B
2019	Holden	Trax	Headlamp Control Module	√	√	√	√	√	0195
2019	Holden	Trax	Chassis Control Module	√	√	√	√	√	0217
2019	Holden	Trax	Trailer Lighting Control Module	√	√	√	√	√	0247
2019	Holden	Trax	Frontview Camera - Windshield	√	√	√	√	√	0205 0196 075A
2019	Holden	Trax	HVAC Control Module	√	√	√	√	√	
2019	Holden	Trax	Keyless Entry Control Module	√	√	√	√	√	
2019	Holden	Trax	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0134 0111 0758
2019	Holden	Trax	Instrument Cluster	√	√	√	√	√	0247
2019	Holden	Trax	Parking Assist Control Module	√	√	√	√	√	0247 0271
2019	Holden	Trax	Serial Data Gateway Module	√	√	√			
2019	Holden	Trax	Left Side Object Detection Control Module	√	√	√		√	
2019	Holden	Trax	Transmission Control Module	√	√	√	√	√	0017 0036
2019	Holden	Trax	Body Control Module	√	√	√	√	√	0263 0203 0083 0159
2019	Holden	Trax	Front Seat Heating Control Module	√	√	√	√	√	
2019	Holden	Trax	Radio	√	√	√	√	√	
2019	Holden	Trax	Power Supply Transformer	√	√	√	√		
2019	Holden	Trax	Headlamp High Beam Control Module	√	√	√	√	√	0247
2019	Holden	Trax	Electronic Brake Control Module	√	√	√	√	√	0090
2019	Holden	Trax	Power Steering Control Module	√	√	√	√		0207
2019	Holden	Trax	Steering Wheel Angle Sensor Module	√	√	√			0093 0090
2018	Holden	Astra Sedan NB4	Power Supply Transformer	√	√	√	√	√	
2018	Holden	Astra Sedan NB4	Body Control Module	√	√	√	√	√	0263 0242 0203 0201 0208 0206 0083 0160
2018	Holden	Astra Sedan NB4	Electronic Brake Control Module	√	√	√	√	√	0090 0278
2018	Holden	Astra Sedan NB4	Power Steering Control Module	√	√	√	√		0089
2018	Holden	Astra Sedan NB4	Radio	√	√	√	√	√	0226
2018	Holden	Astra Sedan NB4	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0111

2018	Holden	Astra Sedan NB4	Engine Control Module	√	√	√	√	√	0263 0156 0209 0020 0132 0067 0115 0086 0085 0154 0213 0221 0212 0214 0217 0006 0144 0250 0130
2018	Holden	Astra Sedan NB4	Parking Assist Control Module	√	√	√	√	√	0271 0247
2018	Holden	Astra Sedan NB4	HVAC Control Module	√	√	√	√	√	0007 0129
2018	Holden	Astra Sedan NB4	Instrument Cluster	√	√	√	√	√	0247 0145
2018	Holden	Astra Sedan NB4	HVAC Controls	√	√	√			
2018	Holden	Astra Sedan NB4	Radio Controls	√	√	√			
2018	Holden	Astra Sedan NB4	Trailer Lighting Control Module	√	√	√	√	√	0247
2018	Holden	Astra Sedan NB4	Frontview Camera Module	√	√	√	√	√	0205 0196 075A
2018	Holden	Astra Sedan NB4	Transmission Control Module	√	√	√	√	√	0017 0036
2018	Holden	Astra Sedan NB4	Amplifier	√	√	√	√	√	
2018	Holden	Astra Sedan NB4	Human Machine Interface Control Module	√	√	√	√	√	0150
2018	Holden	Astra Sedan NB4	Keyless Entry Control Module	√	√	√	√	√	
2018	Holden	Astra Sedan NB4	Steering Column Lock Control Module	√	√	√	√	√	
2018	Holden	Astra-J	Body Control Module	√	√	√	√	√	0242 0263 0203 0208 0201 0206 0083 0160
2018	Holden	Astra-J	Instrument Cluster	√	√	√	√	√	0247
2018	Holden	Astra-J	Digital Radio Receiver Control Module	√	√	√	√	√	0247
2018	Holden	Astra-J	Parking Assist Control Module	√	√	√	√	√	0247
2018	Holden	Astra-J	Trailer Lighting Control Module	√	√	√	√	√	0247
2018	Holden	Astra-J	Headlamp Control Module	√	√	√	√	√	0195
2018	Holden	Astra-J	HVAC Control Module	√	√	√	√	√	0007 0247 0129
2018	Holden	Astra-J	Suspension Control Module	√	√	√	√	√	
2018	Holden	Astra-J	Electronic Brake Control Module	√	√	√	√	√	0090 0225 0111
2018	Holden	Astra-J	Parking Brake Control Module	√	√	√	√	√	0229
2018	Holden	Astra-J	Power Steering Control Module	√	√	√	√	√	0081 0080 0089
2018	Holden	Astra-J	Radio	√	√	√	√	√	
2018	Holden	Astra-J	Front Seat Heating Control Module	√	√	√	√	√	
2018	Holden	Astra-J	Chassis Control Module	√	√	√	√	√	0217 0095 0194
2018	Holden	Astra-J	Transmission Control Module	√	√	√	√	√	0019
2018	Holden	Astra-J	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172
2018	Holden	Astra-J	Engine Control Module	√	√	√	√	√	0263 0156 0209 0216 0132 0067 0147 0066 0115 0086 0154 0214 0215 0217 0006 0144 0130 0250
2018	Holden	Astra-J	Multi-Axis Acceleration Sensor Module	√	√	√			0112 0111
2018	Holden	Astra-J	Steering Wheel Angle Sensor Module	√	√	√			0093 0090
2018	Holden	Astra-J	Frontview Camera Module	√	√	√	√	√	0205 0196 0247
2018	Holden	Astra-K	Body Control Module	√	√	√	√	√	0242 0263 0203 0208 0201 0206 0083 0160

2018	Holden	Astra-K	Instrument Cluster	√	√	√	√	√	0247 0145
2018	Holden	Astra-K	Radio Controls	√	√	√			
2018	Holden	Astra-K	HVAC Controls	√	√	√			
2018	Holden	Astra-K	Trailer Lighting Control Module	√	√	√	√	√	0247
2018	Holden	Astra-K	Parking Assist Control Module	√	√	√	√	√	0271 0247
2018	Holden	Astra-K	Liftgate Control Module	√	√	√	√		0146 0169
2018	Holden	Astra-K	Serial Data Gateway Module	√	√	√			
2018	Holden	Astra-K	Human Machine Interface Control Module	√	√	√	√	√	0150
2018	Holden	Astra-K	Headlamp Control Module	√	√	√	√	√	0195
2018	Holden	Astra-K	HVAC Control Module	√	√	√	√	√	0007 0247 0129
2018	Holden	Astra-K	Power Supply Transformer	√	√	√	√		
2018	Holden	Astra-K	Steering Column Lock Control Module	√	√	√	√		
2018	Holden	Astra-K	Electronic Brake Control Module	√	√	√	√	√	0090 0278
2018	Holden	Astra-K	Power Steering Control Module	√	√	√	√		0089
2018	Holden	Astra-K	Radio	√	√	√	√	√	0226
2018	Holden	Astra-K	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0111
2018	Holden	Astra-K	Engine Control Module	√	√	√	√	√	0263 0156 0209 0216 0132 0067 0147 0066 0115 0086 0154 0214 0215 0217 0006 0144
2018	Holden	Astra-K	Transmission Control Module	√	√	√	√	√	0019
2018	Holden	Astra-K	Frontview Camera Module	√	√	√	√		0205 0196 075A
2018	Holden	Astra-K	Active Safety Control Module	√	√	√	√	√	
2018	Holden	Astra-K	Long Range Radar Sensor Module	√	√	√	√		0260
2018	Holden	Astra-K	Multi-Axis Acceleration Sensor Module	√	√	√			0112 0111
2018	Holden	Astra-K	Keyless Entry Control Module	√	√	√	√	√	
2018	Holden	Barina	Body Control Module	√	√	√	√	√	0263 0203 0083 0159
2018	Holden	Barina	Instrument Cluster	√	√	√	√	√	
2018	Holden	Barina	Parking Assist Control Module	√	√	√	√	√	0247
2018	Holden	Barina	Steering Wheel Angle Sensor Module	√	√	√			0093 0090
2018	Holden	Barina	Electronic Brake Control Module	√	√	√	√	√	0090
2018	Holden	Barina	Power Steering Control Module	√	√	√	√		0207
2018	Holden	Barina	Radio	√	√	√	√	√	
2018	Holden	Barina	Front Seat Heating Control Module	√	√	√	√	√	
2018	Holden	Barina	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0111
2018	Holden	Barina	Engine Control Module	√	√	√	√	√	0156 0209 0132 0067 0263 0086 0217 0139
2018	Holden	Barina	HVAC Control Module	√	√	√	√	√	
2018	Holden	Barina	Serial Data Gateway Module	√	√	√			
2018	Holden	Barina	Steering Column Lock Control Module	√	√	√	√		
2018	Holden	Barina	Chassis Control Module	√	√	√	√	√	0217 0095 0194
2018	Holden	Barina	Transmission Control Module	√	√	√	√	√	0019

2018	Holden	Barina	Keyless Entry Control Module	√	√	√	√	√	
2018	Holden	Captiva	Headlamp Control Module	√	√	√	√	√	0195 0065
2018	Holden	Captiva	HVAC Control Module	√	√	√	√	√	
2018	Holden	Captiva	Electronic Brake Control Module	√	√	√	√	√	0090
2018	Holden	Captiva	Variable Power Steering Control Module	√				√	
2018	Holden	Captiva	Radio	√	√	√	√	√	
2018	Holden	Captiva	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0261
2018	Holden	Captiva	Left Side Object Detection Control Module	√	√	√		√	
2018	Holden	Captiva	Right Side Object Detection Control Module	√	√	√		√	
2018	Holden	Captiva	Parking Brake Control Module	√	√	√	√	√	0229
2018	Holden	Captiva	Body Control Module	√	√	√	√	√	0242 0263 0261
2018	Holden	Captiva	Remote Control Door Lock Receiver	√	√	√	√	√	0110 0160 0159 079B
2018	Holden	Captiva	Auxiliary Body Control Module	√	√	√	√	√	0050
2018	Holden	Captiva	Chassis Control Module	√	√	√	√	√	0217 0095 0194
2018	Holden	Captiva	Transmission Control Module	√	√	√	√	√	0019
2018	Holden	Captiva	Engine Control Module	√	√	√	√	√	0263 0156 0209 0132 0067 0086 0217 0213 0098 0216 0224 0449 0130 0143 0450 0265 0147 0108 0452 0237 0044 0045 0043 0135 0453 0454 0455 0456
2018	Holden	Captiva	Rear Differential Clutch Control Module	√	√	√	√	√	0155
2018	Holden	Captiva	Instrument Cluster	√	√	√	√	√	
2018	Holden	Cascada	Body Control Module	√	√	√	√	√	0242 0263 0203 0208 0201 0206 0083 0160
2018	Holden	Cascada	Folding Top Control Module	√	√	√	√	√	0247 0004 0005
2018	Holden	Cascada	Instrument Cluster	√	√	√	√	√	0247
2018	Holden	Cascada	Digital Radio Receiver Control Module	√	√	√	√	√	0247
2018	Holden	Cascada	Headlamp Control Module	√	√	√	√	√	0195
2018	Holden	Cascada	HVAC Control Module	√	√	√	√	√	0007 0247 0129
2018	Holden	Cascada	Parking Assist Control Module	√	√	√	√	√	0247
2018	Holden	Cascada	Suspension Control Module	√	√	√	√	√	
2018	Holden	Cascada	Multi-Axis Acceleration Sensor Module	√	√	√			0112 0111
2018	Holden	Cascada	Steering Wheel Angle Sensor Module	√	√	√			0093 0090
2018	Holden	Cascada	Frontview Camera Module	√	√	√	√	√	0205 0196 075A 0247
2018	Holden	Cascada	Transmission Control Module	√	√	√	√	√	0019
2018	Holden	Cascada	Chassis Control Module	√	√	√	√	√	0217 0095 0194
2018	Holden	Cascada	Electronic Brake Control Module	√	√	√	√	√	0090 0225 0111
2018	Holden	Cascada	Front Seat Heating Control Module	√	√	√	√	√	
2018	Holden	Cascada	Power Steering Control Module	√	√	√	√	√	0081 0080 0089
2018	Holden	Cascada	Radio	√	√	√	√	√	
2018	Holden	Cascada	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0111

2018	Holden	Cascada	Parking Brake Control Module	√	√	√	√	√	0229
2018	Holden	Cascada	Engine Control Module	√	√	√	√	√	0263 0156 0209 0216 0132 0067 0147 0066 0115 0086 0154 0214 0215 0217 0006 0144 0138
2018	Holden	Colorado	Body Control Module	√	√	√	√	√	0199 0239 0161 0162 0163 0164 0165 0166 0167 0168 0242 0263 0203 0201 0208 0206 0083 0267 0160 0233 0150
2018	Holden	Colorado	Trailer Lighting Control Module	√	√	√	√	√	0247
2018	Holden	Colorado	Instrument Cluster	√	√	√	√	√	0247
2018	Holden	Colorado	Radio Controls	√	√	√	√	√	
2018	Holden	Colorado	HVAC Controls	√	√	√	√	√	
2018	Holden	Colorado	HVAC Control Module	√	√	√	√	√	0007 0129
2018	Holden	Colorado	Engine Control Module	√	√	√	√	√	0263 0210 0224 0130 0222 0066 0147 0060 0044 0045 0086 0217 0109 0068 0084 0070 0071 0074 0075 0043 0173 0179 0181 0183 0185 0232
2018	Holden	Colorado	Electronic Brake Control Module	√	√	√	√	√	0090 0112
2018	Holden	Colorado	Parking Assist Control Module	√	√	√	√	√	0247
2018	Holden	Colorado	Power Steering Control Module	√	√	√	√	√	0089
2018	Holden	Colorado	Radio	√	√	√	√	√	0226
2018	Holden	Colorado	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0111
2018	Holden	Colorado	Human Machine Interface Control Module	√	√	√	√	√	0150
2018	Holden	Colorado	Serial Data Gateway Module	√	√	√			
2018	Holden	Colorado	Transfer Case Control Module	√	√	√	√	√	0037
2018	Holden	Colorado	Transmission Control Module	√	√	√	√	√	0016
2018	Holden	Colorado	Frontview Camera Module	√	√	√	√	√	0205 0196
2018	Holden	Commodore	Instrument Cluster	√	√	√	√	√	0247 0145
2018	Holden	Commodore	Trailer Lighting Control Module	√	√	√	√	√	0247
2018	Holden	Commodore	Serial Data Gateway Module	√	√	√			
2018	Holden	Commodore	HVAC Controls	√	√	√			
2018	Holden	Commodore	Radio Controls	√	√	√			
2018	Holden	Commodore	Human Machine Interface Control Module	√	√	√	√	√	0150

2018	Holden	Commodore	Engine Control Module	√	√	√	√	√	0263 0156 0209 0006 0115 0756 0086 0085 0154 0217 0258 0236 0139 0076 0132 0067 0147 0212 0214 0144 0210 0066 0060 0044 0045 0097 0068 0084 0073 0070 0071 0117 0119 0131 0179 0181 0183 0185 0232 0043
2018	Holden	Commodore	Headlamp Control Module	√	√	√	√	√	0195
2018	Holden	Commodore	HVAC Control Module	√	√	√	√	√	0129
2018	Holden	Commodore	Parking Assist Control Module	√	√	√	√	√	
2018	Holden	Commodore	Electronic Brake Control Module	√	√	√	√	√	0090 0278
2018	Holden	Commodore	Power Steering Control Module	√	√	√	√	√	0089
2018	Holden	Commodore	Radio	√	√	√	√	√	0226
2018	Holden	Commodore	Seat Memory Control Module - Driver	√	√	√	√	√	0310
2018	Holden	Commodore	Seat Memory Control Module - Passenger	√	√	√	√	√	
2018	Holden	Commodore	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0111
2018	Holden	Commodore	Suspension Control Module	√	√	√	√	√	
2018	Holden	Commodore	Rear Differential Clutch Control Module	√	√	√	√	√	0003
2018	Holden	Commodore	Transmission Control Module	√	√	√	√	√	0017 0020 0084
2018	Holden	Commodore	Liftgate Control Module	√	√	√	√	√	0146 0169
2018	Holden	Commodore	Steering Column Lock Control Module	√	√	√	√	√	
2018	Holden	Commodore	Body Control Module	√	√	√	√	√	0199 0239 0161 0162 0163 0164 0165 0166 0167 0168 0242 0263 0203 0201 0208 0206 0083 0267 0160 0233 0158
2018	Holden	Commodore	Frontview Camera Module	√	√	√	√	√	0196
2018	Holden	Commodore	Active Safety Control Module	√	√	√	√	√	
2018	Holden	Commodore	Long Range Radar Sensor Module	√	√	√	√	√	0260
2018	Holden	Commodore	Video Processing Control Module	√	√	√	√	√	
2018	Holden	Commodore	Power Supply Transformer	√	√	√	√	√	
2018	Holden	Commodore	Left Side Object Detection Control Module	√	√	√	√	√	
2018	Holden	Commodore	Keyless Entry Control Module	√	√	√	√	√	0759
2018	Holden	Commodore	Amplifier	√	√	√	√	√	
2018	Holden	Equinox	Steering Column Lock Control Module	√	√	√	√	√	
2018	Holden	Equinox	Liftgate Control Module	√	√	√	√	√	0146 0169
2018	Holden	Equinox	Electronic Brake Control Module	√	√	√	√	√	0225 0090 0229 0771
2018	Holden	Equinox	Parking Assist Control Module	√	√	√	√	√	0271 0247
2018	Holden	Equinox	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0111
2018	Holden	Equinox	Power Steering Control Module	√	√	√	√	√	0089

2018	Holden	Equinox	Radio	√	√	√	√	√	0226
2018	Holden	Equinox	Seat Memory Control Module - Driver	√	√	√	√	√	
2018	Holden	Equinox	Engine Control Module	√	√	√	√	√	0263 0156 0209 0020 0132 0067 0115 0086 0085 0154 0213 0221 0212 0214 0217 0006 0144 0258 0139 0210 0224 0130 0222 0066 0147 0060 079A 0044 0045 0097 0792 0109 0068 0084 0070 0071 0074 0075 0117 0043 0173 0179 0181 0183
2018	Holden	Equinox	Audio Amplifier	√	√	√	√		
2018	Holden	Equinox	Instrument Cluster	√	√	√	√	√	0247 0145
2018	Holden	Equinox	HVAC Controls	√	√	√			
2018	Holden	Equinox	Radio Controls	√	√	√			
2018	Holden	Equinox	HVAC Control Module	√	√	√	√	√	0007 0129
2018	Holden	Equinox	Frontview Camera Module	√	√	√	√		0205 0196 075A
2018	Holden	Equinox	Transmission Control Module	√	√	√	√	√	0017 0036
2018	Holden	Equinox	Body Control Module	√	√	√	√	√	0199 0239 0161 0162 0163 0164 0165 0166 0167 0168 0242 0263 0203 0201 0208 0206 0083 0267 0160 0233 0150
2018	Holden	Equinox	Headlamp Control Module	√	√	√	√	√	0195
2018	Holden	Equinox	Left Side Object Detection Control Module	√	√	√		√	
2018	Holden	Equinox	Serial Data Gateway Module	√	√	√			
2018	Holden	Equinox	Rear Differential Clutch Control Module	√	√	√	√	√	0003
2018	Holden	Equinox	Human Machine Interface Control Module	√	√	√	√	√	0150
2018	Holden	Equinox	Keyless Entry Control Module	√	√	√	√	√	
2018	Holden	Equinox	Trailer Lighting Control Module	√	√	√	√	√	0247
2018	Holden	Spark	Body Control Module	√	√	√	√	√	0263 0203 0083 0159
2018	Holden	Spark	Instrument Cluster	√	√	√	√	√	0247
2018	Holden	Spark	Engine Control Module	√	√	√	√	√	0263 0156 0209 0066 0086 0217 0141 0139
2018	Holden	Spark	Radio	√	√	√	√	√	
2018	Holden	Spark	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0111
2018	Holden	Spark	Power Steering Control Module	√	√	√	√		0089
2018	Holden	Spark	Electronic Brake Control Module	√	√	√	√	√	0090
2018	Holden	Spark	Steering Column Lock Control Module	√	√	√	√		
2018	Holden	Spark	Transmission Control Module	√	√	√	√	√	0017
2018	Holden	Spark	Serial Data Gateway Module	√	√	√			

2018	Holden	Spark	Parking Assist Control Module	√	√	√	√	√	0271 0247
2018	Holden	Spark	Keyless Entry Control Module	√	√	√	√	√	
2018	Holden	Trailblazer	Trailer Lighting Control Module	√	√	√	√	√	0247
2018	Holden	Trailblazer	Instrument Cluster	√	√	√	√	√	0247
2018	Holden	Trailblazer	HVAC Controls	√	√	√	√	√	
2018	Holden	Trailblazer	Radio Controls	√	√	√	√	√	
2018	Holden	Trailblazer	HVAC Control Module	√	√	√	√	√	0007 0129
2018	Holden	Trailblazer	Engine Control Module	√	√	√	√	√	0263 0210 0224 0130 0222 0060 0044 0045 0086 0097 0084 0043
2018	Holden	Trailblazer	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0111
2018	Holden	Trailblazer	Electronic Brake Control Module	√	√	√	√	√	0090 0112
2018	Holden	Trailblazer	Parking Assist Control Module	√	√	√	√	√	0247
2018	Holden	Trailblazer	Power Steering Control Module	√	√	√	√	√	0089
2018	Holden	Trailblazer	Radio	√	√	√	√	√	0226
2018	Holden	Trailblazer	Human Machine Interface Control Module	√	√	√	√	√	0150
2018	Holden	Trailblazer	Body Control Module	√	√	√	√	√	0199 0239 0161 0162 0163 0164 0165 0166 0167 0168 0242 0263 0203 0201 0208 0206 0083 0267 0160 0233 0150
2018	Holden	Trailblazer	Serial Data Gateway Module	√	√	√			
2018	Holden	Trailblazer	Transfer Case Control Module	√	√	√	√	√	0037
2018	Holden	Trailblazer	Transmission Control Module	√	√	√	√	√	0016
2018	Holden	Trailblazer	Frontview Camera Module	√	√	√	√	√	0205 0196
2018	Holden	Trailblazer	Left Side Object Detection Control Module	√	√	√		√	
2018	Holden	Trailblazer	Right Side Object Detection Control Module	√	√	√		√	
2018	Holden	Trax	Body Control Module	√	√	√	√	√	0263 0203 0083 0159
2018	Holden	Trax	Instrument Cluster	√	√	√	√	√	0247
2018	Holden	Trax	Radio Controls	√	√	√			
2018	Holden	Trax	Trailer Lighting Control Module	√	√	√	√	√	0247
2018	Holden	Trax	Engine Control Module	√	√	√	√	√	0263 0156 0209 0020 0132 0067 0066 076D 0086 0213 0217 0006
2018	Holden	Trax	HVAC Control Module	√	√	√	√	√	
2018	Holden	Trax	Power Supply Transformer	√	√	√	√		
2018	Holden	Trax	Steering Wheel Angle Sensor Module	√	√	√			0093 0090
2018	Holden	Trax	Left Side Object Detection Control Module	√	√	√		√	
2018	Holden	Trax	Steering Column Lock Control Module	√	√	√	√		
2018	Holden	Trax	Rear Differential Clutch Control Module	√	√	√	√		0003 075B
2018	Holden	Trax	Electronic Brake Control Module	√	√	√	√	√	0090
2018	Holden	Trax	Power Steering Control Module	√	√	√	√	√	0207

2018	Holden	Trax	Radio	√	√	√	√	√	
2018	Holden	Trax	Front Seat Heating Control Module	√	√	√	√	√	
2018	Holden	Trax	Parking Assist Control Module	√	√	√	√	√	0247
2018	Holden	Trax	Frontview Camera Module	√	√	√	√	√	0205 0196 075A 0247
2018	Holden	Trax	Transmission Control Module	√	√	√	√	√	0017 0036
2018	Holden	Trax	Headlamp Control Module	√	√	√	√	√	0195
2018	Holden	Trax	Serial Data Gateway Module	√	√	√			
2018	Holden	Trax	Amplifier	√	√	√	√		
2018	Holden	Trax	Human Machine Interface Control Module	√	√	√	√	√	0150
2018	Holden	Trax	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0111
2018	Holden	Trax	Keyless Entry Control Module	√	√	√	√	√	
2018	Holden	Trax	Chassis Control Module	√	√	√	√	√	0217
2017	Holden	Astra Sedan NB4	Engine Control Module	√	√	√	√	√	0263 0156 0209 0216 0132 0067 0147 0066 0115 0086 0154 0214 0215 0217 0006 0144 0128
2017	Holden	Astra Sedan NB4	Keyless Entry Control Module	√	√	√	√	√	
2017	Holden	Astra Sedan NB4	Body Control Module	√	√	√	√	√	0263 0242 0203 0201 0208 0206 0083 0160
2017	Holden	Astra Sedan NB4	Instrument Cluster	√	√	√	√	√	0247 0145
2017	Holden	Astra Sedan NB4	Human Machine Interface Control Module	√	√	√	√	√	0150
2017	Holden	Astra Sedan NB4	HVAC Control Module	√	√	√	√	√	0007 0129
2017	Holden	Astra Sedan NB4	Serial Data Gateway Module	√	√	√			
2017	Holden	Astra Sedan NB4	Electronic Brake Control Module	√	√	√	√	√	0090 0278
2017	Holden	Astra Sedan NB4	Power Steering Control Module	√	√	√	√		0089
2017	Holden	Astra Sedan NB4	Radio	√	√	√	√	√	0226
2017	Holden	Astra Sedan NB4	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0111
2017	Holden	Astra Sedan NB4	Parking Assist Control Module	√	√	√	√	√	0271 0247
2017	Holden	Astra Sedan NB4	Transmission Control Module	√	√	√	√	√	0019
2017	Holden	Astra Sedan NB4	Steering Column Lock Control Module	√	√	√	√		
2017	Holden	Astra Sedan NB4	Power Supply Transformer	√	√	√	√		
2017	Holden	Astra Sedan NB4	Frontview Camera Module	√	√	√	√		0205 0196 075A
2017	Holden	Astra Sedan NB4	HVAC Controls	√	√	√			
2017	Holden	Astra Sedan NB4	Radio Controls	√	√	√			
2017	Holden	Astra Sedan NB4	Trailer Lighting Control Module	√	√	√	√	√	0247
2017	Holden	Astra-J	Body Control Module	√	√	√	√	√	0242 0263 0203 0208 0201 0206 0083 0160
2017	Holden	Astra-J	Headlamp Control Module	√	√	√	√	√	0195
2017	Holden	Astra-J	HVAC Control Module	√	√	√	√	√	0007 0247 0129

2017	Holden	Astra-J	Engine Control Module	√	√	√	√	√	0263 0156 0209 0216 0132 0067 0147 0066 0115 0086 0154 0214 0215 0217 0006 0144 0128 0258
2017	Holden	Astra-J	Instrument Cluster	√	√	√	√	√	0247
2017	Holden	Astra-J	Trailer Interface Control Module	√	√	√	√	√	0247
2017	Holden	Astra-J	Suspension Control Module	√	√	√	√	√	
2017	Holden	Astra-J	Electronic Brake Control Module	√	√	√	√	√	0090 0225 0111
2017	Holden	Astra-J	Front Seat Heating Control Module	√	√	√	√	√	
2017	Holden	Astra-J	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172
2017	Holden	Astra-J	Parking Brake Control Module	√	√	√	√	√	0229
2017	Holden	Astra-J	Power Steering Control Module	√	√	√	√	√	0081 0080 0089
2017	Holden	Astra-J	Radio	√	√	√	√	√	
2017	Holden	Astra-J	Digital Radio Receiver Control Module	√	√	√	√	√	0247
2017	Holden	Astra-J	Parking Assist Control Module	√	√	√	√	√	0247
2017	Holden	Astra-J	Chassis Control Module	√	√	√	√	√	0217 0095 0194
2017	Holden	Astra-J	Transmission Control Module	√	√	√	√	√	0019
2017	Holden	Astra-J	Multi-Axis Acceleration Sensor Module	√	√	√			0112 0111
2017	Holden	Astra-J	Steering Wheel Angle Sensor Module	√	√	√			0093 0090
2017	Holden	Astra-J	Frontview Camera Module	√	√	√	√	√	0205 0196 0247
2017	Holden	Astra-K	Body Control Module	√	√	√	√	√	0242 0263 0203 0208 0201 0206 0083 0160
2017	Holden	Astra-K	HVAC Controls	√	√	√	√	√	
2017	Holden	Astra-K	Radio Controls	√	√	√	√	√	0150
2017	Holden	Astra-K	Instrument Cluster	√	√	√	√	√	0247
2017	Holden	Astra-K	Trailer Interface Control Module	√	√	√	√	√	0247
2017	Holden	Astra-K	Serial Data Gateway Module	√	√	√			
2017	Holden	Astra-K	Human Machine Interface Control Module	√	√	√	√	√	0150
2017	Holden	Astra-K	Frontview Camera Module	√	√	√	√	√	0205 0196 075A
2017	Holden	Astra-K	Headlamp Control Module	√	√	√	√	√	0195
2017	Holden	Astra-K	HVAC Control Module	√	√	√	√	√	0007 0247 0129
2017	Holden	Astra-K	Engine Control Module	√	√	√	√	√	0263 0156 0209 0216 0132 0067 0147 0066 0115 0086 0154 0214 0215 0217 0006 0144 0128 0258
2017	Holden	Astra-K	Keyless Entry Control Module	√	√	√	√	√	
2017	Holden	Astra-K	Steering Column Lock Control Module	√	√	√	√	√	
2017	Holden	Astra-K	Transmission Control Module	√	√	√	√	√	0019
2017	Holden	Astra-K	Parking Assist Control Module	√	√	√	√	√	0271 0247
2017	Holden	Astra-K	Power Supply Transformer	√	√	√	√	√	
2017	Holden	Astra-K	Electronic Brake Control Module	√	√	√	√	√	0090 0278
2017	Holden	Astra-K	Power Steering Control Module	√	√	√	√	√	0089

2017	Holden	Astra-K	Radio	√	√	√	√	√	0226
2017	Holden	Astra-K	Active Safety Control Module	√	√	√	√	√	
2017	Holden	Astra-K	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0111
2017	Holden	Astra-K	Long Range Radar Sensor Module	√	√	√	√		0260
2017	Holden	Astra-K	Multi-Axis Acceleration Sensor Module	√	√	√			0112 0111
2017	Holden	Barina	Body Control Module	√	√	√	√	√	0263 0203 0083 0159
2017	Holden	Barina	Engine Control Module	√	√	√	√	√	0156 0209 0132 0067 0263 0086 0217 0139
2017	Holden	Barina	HVAC Control Module	√	√	√	√	√	
2017	Holden	Barina	Parking Assist Control Module	√	√	√	√	√	0247
2017	Holden	Barina	Steering Wheel Angle Sensor Module	√	√	√			0093 0090
2017	Holden	Barina	Instrument Cluster	√	√	√	√	√	0247
2017	Holden	Barina	Transmission Control Module	√	√	√	√	√	0019
2017	Holden	Barina	Electronic Brake Control Module	√	√	√	√	√	0090
2017	Holden	Barina	Front Seat Heating Control Module	√	√	√	√	√	
2017	Holden	Barina	Power Steering Control Module	√	√	√	√		0207
2017	Holden	Barina	Radio	√	√	√	√	√	
2017	Holden	Barina	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0111
2017	Holden	Barina	Chassis Control Module	√	√	√	√	√	0217 0095 0194
2017	Holden	Barina	Serial Data Gateway Module	√	√	√			
2017	Holden	Barina	Steering Column Lock Control Module	√	√	√	√		
2017	Holden	Barina	Keyless Entry Control Module	√	√	√	√	√	
2017	Holden	Caprice	Body Control Module	√	√	√	√	√	0263 0203 0201 0208 0206 0083 0160 0159
2017	Holden	Caprice	Headlamp Control Module	√	√	√	√	√	0195
2017	Holden	Caprice	HVAC Control Module	√	√	√	√	√	0007 0129
2017	Holden	Caprice	Instrument Cluster	√	√	√	√	√	0247 0145
2017	Holden	Caprice	Trailer Interface Control Module	√	√	√	√	√	0247
2017	Holden	Caprice	Radio Controls	√	√	√	√	√	0241 0247
2017	Holden	Caprice	HVAC Controls	√	√	√	√	√	
2017	Holden	Caprice	Parking Assist Control Module	√	√	√	√	√	0247
2017	Holden	Caprice	Head-Up Display Module	√	√	√	√	√	
2017	Holden	Caprice	Transmission Control Module	√	√	√	√	√	0016
2017	Holden	Caprice	Engine Control Module	√	√	√	√	√	0156 0209 0132 0067 0263 0086 0217 0258
2017	Holden	Caprice	Suspension Control Module	√	√	√	√	√	0245
2017	Holden	Caprice	Steering Wheel Angle Sensor Module	√	√	√			0093 0090
2017	Holden	Caprice	Right Side Object Detection Control Module	√	√	√		√	
2017	Holden	Caprice	Left Side Object Detection Control Module	√	√	√		√	
2017	Holden	Caprice	Frontview Camera Module	√	√	√	√	√	0205 0049
2017	Holden	Caprice	Electronic Brake Control Module	√	√	√	√	√	0225 0090 0111
2017	Holden	Caprice	Power Steering Control Module	√	√	√	√		0081

2017	Holden	Caprice	Radio	√	√	√	√	√	
2017	Holden	Caprice	Seat Memory Control Module - Driver	√	√	√	√	√	
2017	Holden	Caprice	Parking Brake Control Module	√	√	√	√	√	0229
2017	Holden	Caprice	Steering Column Lock Control Module	√	√	√	√	√	
2017	Holden	Caprice	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0111
2017	Holden	Caprice	Liftgate Control Module	√	√	√	√	√	
2017	Holden	Caprice	Keyless Entry Control Module	√	√	√	√	√	
2017	Holden	Caprice	Chassis Control Module	√	√	√	√	√	0217 0095 0194 0245
2017	Holden	Captiva	Headlamp Control Module	√	√	√	√	√	0195 0065
2017	Holden	Captiva	HVAC Control Module	√	√	√	√	√	
2017	Holden	Captiva	Rear Differential Clutch Control Module	√	√	√	√	√	0155
2017	Holden	Captiva	Body Control Module	√	√	√	√	√	0242 0263 0261
2017	Holden	Captiva	Remote Control Door Lock Receiver	√	√	√	√	√	0110 0160 0159 079B
2017	Holden	Captiva	Auxiliary Body Control Module	√	√	√	√	√	0050
2017	Holden	Captiva	Parking Brake Control Module	√	√	√	√	√	0229
2017	Holden	Captiva	Left Side Object Detection Control Module	√	√	√	√	√	
2017	Holden	Captiva	Right Side Object Detection Control Module	√	√	√	√	√	
2017	Holden	Captiva	Engine Control Module	√	√	√	√	√	0156 0209 0098 0216 0224 0449 0130 0143 0450 0265 0147 0108 0452 0237 0044 0045 0086 0043 0135 0453 0454 0455 0456 0263 0132 0067 0217 0212
2017	Holden	Captiva	Instrument Cluster	√	√	√	√	√	
2017	Holden	Captiva	Transmission Control Module	√	√	√	√	√	0019
2017	Holden	Captiva	Radio	√	√	√	√	√	
2017	Holden	Captiva	Electronic Brake Control Module	√	√	√	√	√	0090
2017	Holden	Captiva	Variable Power Steering Control Module	√	√	√	√	√	
2017	Holden	Captiva	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0261
2017	Holden	Captiva	Chassis Control Module	√	√	√	√	√	0217 0095 0194
2017	Holden	Cascada	Body Control Module	√	√	√	√	√	0242 0263 0203 0208 0201 0206 0083 0160
2017	Holden	Cascada	Folding Top Control Module	√	√	√	√	√	0247 0004 0005
2017	Holden	Cascada	Headlamp Control Module	√	√	√	√	√	0195
2017	Holden	Cascada	HVAC Control Module	√	√	√	√	√	0007 0247 0129
2017	Holden	Cascada	Instrument Cluster	√	√	√	√	√	0247
2017	Holden	Cascada	Parking Assist Control Module	√	√	√	√	√	0247
2017	Holden	Cascada	Frontview Camera Module	√	√	√	√	√	0247
2017	Holden	Cascada	Multi-Axis Acceleration Sensor Module	√	√	√	√	√	0112 0111
2017	Holden	Cascada	Steering Wheel Angle Sensor Module	√	√	√	√	√	0093 0090
2017	Holden	Cascada	Digital Radio Receiver Control Module	√	√	√	√	√	0247
2017	Holden	Cascada	Transmission Control Module	√	√	√	√	√	0019

2017	Holden	Cascada	Engine Control Module	√	√	√	√	√	0263 0156 0209 0216 0132 0067 0147 0066 0115 0086 0154 0214 0215 0217 0006 0144 0128
2017	Holden	Cascada	Chassis Control Module	√	√	√	√	√	0217 0095 0194
2017	Holden	Cascada	Electronic Brake Control Module	√	√	√	√	√	0090 0225 0111
2017	Holden	Cascada	Front Seat Heating Control Module	√	√	√	√	√	
2017	Holden	Cascada	Parking Brake Control Module	√	√	√	√	√	0229
2017	Holden	Cascada	Power Steering Control Module	√	√	√	√	√	0081 0080 0089
2017	Holden	Cascada	Radio	√	√	√	√	√	
2017	Holden	Cascada	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0111
2017	Holden	Cascada	Suspension Control Module	√	√	√	√	√	
2017	Holden	Colorado	Body Control Module	√	√	√	√	√	0199 0239 0161 0162 0163 0164 0165 0166 0167 0168 0242 0263 0203 0201 0208 0206 0083 0267 0160 0233 0150
2017	Holden	Colorado	Instrument Cluster	√	√	√	√	√	0247
2017	Holden	Colorado	Trailer Interface Control Module	√	√	√	√	√	0247
2017	Holden	Colorado	Serial Data Gateway Module	√	√	√	√	√	
2017	Holden	Colorado	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0111
2017	Holden	Colorado	Parking Assist Control Module	√	√	√	√	√	0247
2017	Holden	Colorado	Electronic Brake Control Module	√	√	√	√	√	0090 0112
2017	Holden	Colorado	Radio	√	√	√	√	√	0226
2017	Holden	Colorado	Engine Control Module	√	√	√	√	√	0263 0210 0224 0130 0222 0060 0044 0045 0086 0097 0084 0043
2017	Holden	Colorado	Transmission Control Module	√	√	√	√	√	0016
2017	Holden	Colorado	Transfer Case Control Module	√	√	√	√	√	0037
2017	Holden	Colorado	Power Steering Control Module	√	√	√	√	√	0089
2017	Holden	Colorado	Frontview Camera Module	√	√	√	√	√	0205 0196
2017	Holden	Colorado	Human Machine Interface Control Module	√	√	√	√	√	0150
2017	Holden	Colorado	Radio Controls	√	√	√	√	√	
2017	Holden	Colorado	HVAC Controls	√	√	√	√	√	
2017	Holden	Colorado	HVAC Control Module	√	√	√	√	√	0007 0129
2017	Holden	Commodore	Body Control Module	√	√	√	√	√	0263 0203 0201 0208 0206 0083 0160 0159
2017	Holden	Commodore	Liftgate Control Module	√	√	√	√	√	
2017	Holden	Commodore	HVAC Control Module	√	√	√	√	√	0007 0129
2017	Holden	Commodore	Headlamp Control Module	√	√	√	√	√	0195
2017	Holden	Commodore	Instrument Cluster	√	√	√	√	√	0247 0145
2017	Holden	Commodore	Trailer Interface Control Module	√	√	√	√	√	0247

2017	Holden	Commodore	HVAC Controls	√	√	√	√	√	
2017	Holden	Commodore	Radio Controls	√	√	√	√	√	0241 0247
2017	Holden	Commodore	Parking Assist Control Module	√	√	√	√	√	0247
2017	Holden	Commodore	Head-Up Display Module	√	√	√	√	√	
2017	Holden	Commodore	Transmission Control Module	√	√	√	√	√	0016
2017	Holden	Commodore	Engine Control Module	√	√	√	√	√	0263 0156 0209 0132 0067 0086 0217 0258
2017	Holden	Commodore	Suspension Control Module	√	√	√	√	√	0245
2017	Holden	Commodore	Steering Column Lock Control Module	√	√	√	√	√	
2017	Holden	Commodore	Electronic Brake Control Module	√	√	√	√	√	0225 0090 0111
2017	Holden	Commodore	Parking Brake Control Module	√	√	√	√	√	0229
2017	Holden	Commodore	Power Steering Control Module	√	√	√	√	√	0081
2017	Holden	Commodore	Radio	√	√	√	√	√	
2017	Holden	Commodore	Seat Memory Control Module - Driver	√	√	√	√	√	
2017	Holden	Commodore	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0111
2017	Holden	Commodore	Keyless Entry Control Module	√	√	√	√	√	
2017	Holden	Commodore	Chassis Control Module	√	√	√	√	√	0217 0095 0194 0245
2017	Holden	Commodore	Steering Wheel Angle Sensor Module	√	√	√	√	√	0093 0090
2017	Holden	Commodore	Right Side Object Detection Control Module	√	√	√	√	√	
2017	Holden	Commodore	Left Side Object Detection Control Module	√	√	√	√	√	
2017	Holden	Commodore	Frontview Camera Module	√	√	√	√	√	0205 0049
2017	Holden	Insignia	Body Control Module	√	√	√	√	√	0242 0263 0203 0208 0201 0206 0083 0160
2017	Holden	Insignia	Steering Column Lock Control Module	√	√	√	√	√	
2017	Holden	Insignia	Keyless Entry Control Module	√	√	√	√	√	
2017	Holden	Insignia	Human Machine Interface Control Module	√	√	√	√	√	0150
2017	Holden	Insignia	Engine Control Module	√	√	√	√	√	0156 0067 0086 0217
2017	Holden	Insignia	HVAC Control Module	√	√	√	√	√	0007 0247 0129
2017	Holden	Insignia	Headlamp Control Module	√	√	√	√	√	0195
2017	Holden	Insignia	Amplifier	√	√	√	√	√	
2017	Holden	Insignia	Instrument Cluster	√	√	√	√	√	0247
2017	Holden	Insignia	HVAC Controls	√	√	√	√	√	
2017	Holden	Insignia	Radio Controls	√	√	√	√	√	0150
2017	Holden	Insignia	Trailer Interface Control Module	√	√	√	√	√	0247
2017	Holden	Insignia	Suspension Control Module	√	√	√	√	√	
2017	Holden	Insignia	Rear Differential Clutch Control Module	√	√	√	√	√	
2017	Holden	Insignia	Parking Assist Control Module	√	√	√	√	√	0247
2017	Holden	Insignia	Electronic Brake Control Module	√	√	√	√	√	0225 0090 0111 0277
2017	Holden	Insignia	Radio	√	√	√	√	√	0226
2017	Holden	Insignia	Front Seat Heating/Venting/Cooling/Memory Control Module	√	√	√	√	√	
2017	Holden	Insignia	Power Steering Control Module	√	√	√	√	√	

2017	Holden	Insignia	Parking Brake Control Module	√	√	√	√	√	0229
2017	Holden	Insignia	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0111
2017	Holden	Insignia	Frontview Camera Module	√	√	√	√	√	0205 0196
2017	Holden	Insignia	Distance Sensing Cruise Control Module	√	√	√	√		0047
2017	Holden	Insignia	Left Side Object Detection Control Module	√	√	√		√	
2017	Holden	Insignia	Steering Wheel Angle Sensor Module	√	√	√			0093 0090
2017	Holden	Insignia	Transmission Control Module	√	√	√	√	√	0020 0084
2017	Holden	Insignia	Chassis Control Module	√	√	√	√	√	0217 0095 0194
2017	Holden	Spark	Body Control Module	√	√	√	√	√	0263 0203 0083 0159
2017	Holden	Spark	Engine Control Module	√	√	√	√	√	0263 0156 0209 0066 0086 0217 0141 0139
2017	Holden	Spark	Serial Data Gateway Module	√	√	√			
2017	Holden	Spark	Electronic Brake Control Module	√	√	√	√	√	0090
2017	Holden	Spark	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0111
2017	Holden	Spark	Power Steering Control Module	√	√	√	√		0089
2017	Holden	Spark	Radio	√	√	√	√	√	
2017	Holden	Spark	Instrument Cluster	√	√	√	√	√	0247
2017	Holden	Spark	Keyless Entry Control Module	√	√	√	√	√	
2017	Holden	Spark	Parking Assist Control Module	√	√	√	√	√	0271 0247
2017	Holden	Spark	Transmission Control Module	√	√	√	√	√	0017
2017	Holden	Spark	Steering Column Lock Control Module	√	√	√	√		
2017	Holden	Trailblazer	Body Control Module	√	√	√	√	√	0199 0239 0161 0162 0163 0164 0165 0166 0167 0168 0242 0263 0203 0201 0208 0206 0083 0267 0160 0233 0159
2017	Holden	Trailblazer	Instrument Cluster	√	√	√	√	√	0247
2017	Holden	Trailblazer	Trailer Interface Control Module	√	√	√	√	√	0247
2017	Holden	Trailblazer	Parking Assist Control Module	√	√	√	√	√	0247
2017	Holden	Trailblazer	Engine Control Module	√	√	√	√	√	0263 0210 0224 0130 0222 0060 0044 0045 0086 0097 0084 0043
2017	Holden	Trailblazer	Transfer Case Control Module	√	√	√	√	√	0037
2017	Holden	Trailblazer	Transmission Control Module	√	√	√	√	√	0016
2017	Holden	Trailblazer	Left Side Object Detection Control Module	√	√	√		√	
2017	Holden	Trailblazer	Right Side Object Detection Control Module	√	√	√		√	
2017	Holden	Trailblazer	Power Steering Control Module	√	√	√	√		0089
2017	Holden	Trailblazer	Electronic Brake Control Module	√	√	√	√	√	0090 0112
2017	Holden	Trailblazer	Radio	√	√	√	√	√	0226
2017	Holden	Trailblazer	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0111
2017	Holden	Trailblazer	Frontview Camera Module	√	√	√	√	√	0205 0196
2017	Holden	Trailblazer	Serial Data Gateway Module	√	√	√			

2017	Holden	Trailblazer	Human Machine Interface Control Module	√	√	√	√	√	0150
2017	Holden	Trailblazer	Radio Controls	√	√	√	√	√	
2017	Holden	Trailblazer	HVAC Controls	√	√	√	√	√	
2017	Holden	Trailblazer	HVAC Control Module	√	√	√	√	√	0007 0129
2017	Holden	Trax	Body Control Module	√	√	√	√	√	0263 0203 0083 0159
2017	Holden	Trax	Engine Control Module	√	√	√	√	√	0263 0156 0209 0132 0067 0066 0217 0086
2017	Holden	Trax	HVAC Control Module	√	√	√	√	√	
2017	Holden	Trax	Instrument Cluster	√	√	√	√	√	0247
2017	Holden	Trax	Trailer Interface Control Module	√	√	√	√	√	0247
2017	Holden	Trax	Parking Assist Control Module	√	√	√	√	√	0247
2017	Holden	Trax	Rear Differential Clutch Control Module	√	√	√	√		0003 075B
2017	Holden	Trax	Steering Wheel Angle Sensor Module	√	√	√			0093 0090
2017	Holden	Trax	Keyless Entry Control Module	√	√	√	√	√	
2017	Holden	Trax	Radio Controls	√	√	√	√	√	
2017	Holden	Trax	Transmission Control Module	√	√	√	√	√	0019
2017	Holden	Trax	Electronic Brake Control Module	√	√	√	√	√	0090
2017	Holden	Trax	Front Seat Heating Control Module	√	√	√	√	√	
2017	Holden	Trax	Power Steering Control Module	√	√	√	√		0207
2017	Holden	Trax	Radio	√	√	√	√	√	
2017	Holden	Trax	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0111
2017	Holden	Trax	Serial Data Gateway Module	√	√	√			
2017	Holden	Trax	Steering Column Lock Control Module	√	√	√	√		
2017	Holden	Trax	Power Supply Transformer	√	√	√	√		
2017	Holden	Trax	Left Side Object Detection Control Module	√	√	√		√	
2017	Holden	Trax	Chassis Control Module	√	√	√	√	√	0217
2016	Holden	Astra-J	Parking Assist Control Module	√	√	√	√	√	0247
2016	Holden	Astra-J	Front Seat Heating Control Module	√	√	√	√	√	
2016	Holden	Astra-J	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172
2016	Holden	Astra-J	Instrument Cluster	√	√	√	√	√	0247
2016	Holden	Astra-J	Radio	√	√	√	√	√	
2016	Holden	Astra-J	Headlamp Control Module	√	√	√	√	√	0195
2016	Holden	Astra-J	HVAC Control Module	√	√	√	√	√	0007 0247 0129
2016	Holden	Astra-J	Trailer Interface Control Module	√	√	√	√	√	0247
2016	Holden	Astra-J	Multi-Axis Acceleration Sensor Module	√	√	√			0112 0111
2016	Holden	Astra-J	Steering Wheel Angle Sensor Module	√	√	√			0093 0090
2016	Holden	Astra-J	Frontview Camera Module	√	√	√	√	√	0205 0196 0247
2016	Holden	Astra-J	Digital Radio Receiver Control Module	√	√	√	√	√	0247
2016	Holden	Astra-J	Electronic Brake Control Module	√	√	√	√	√	0090 0225 0111
2016	Holden	Astra-J	Power Steering Control Module	√	√	√	√	√	0081 0080 0089
2016	Holden	Astra-J	Parking Brake Control Module	√	√	√	√	√	0229

2016	Holden	Astra-J	Body Control Module	√	√	√	√	√	0242 0263 0203 0208 0201 0206 0083 0160
2016	Holden	Astra-J	Engine Control Module	√	√	√	√	√	0263 0156 0209 0132 0067 0216 0086 0217 0258 0128 0147 0066 0115 0154 0214 0215 0005 0144
2016	Holden	Astra-J	Suspension Control Module	√	√	√	√	√	
2016	Holden	Astra-J	Transmission Control Module	√	√	√	√	√	0019
2016	Holden	Astra-J	Chassis Control Module	√	√	√	√	√	0217 0095 0194
2016	Holden	Barina	Instrument Cluster	√	√	√	√	√	0247
2016	Holden	Barina	Engine Control Module	√	√	√	√	√	0263 0156 0209 0132 0067 0066 0217 0086 0238 0128 0139
2016	Holden	Barina	Front Seat Heating Control Module	√	√	√	√	√	
2016	Holden	Barina	Electronic Brake Control Module	√	√	√	√	√	0090
2016	Holden	Barina	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0111
2016	Holden	Barina	HVAC Control Module	√	√	√	√	√	
2016	Holden	Barina	Power Steering Control Module	√	√	√	√	√	0207
2016	Holden	Barina	Parking Assist Control Module	√	√	√	√	√	0247
2016	Holden	Barina	Body Control Module	√	√	√	√	√	0263 0203 0083 0159
2016	Holden	Barina	Transmission Control Module	√	√	√	√	√	0019
2016	Holden	Barina	Steering Wheel Angle Sensor Module	√	√	√	√	√	0093 0090
2016	Holden	Barina	Radio	√	√	√	√	√	
2016	Holden	Barina	Chassis Control Module	√	√	√	√	√	0217 0095 0194
2016	Holden	Caprice	Transmission Control Module	√	√	√	√	√	0016
2016	Holden	Caprice	Engine Control Module	√	√	√	√	√	0156 0209 0132 0067 0263 0086 0217 0258
2016	Holden	Caprice	Seat Memory Control Module - Driver	√	√	√	√	√	
2016	Holden	Caprice	Parking Assist Control Module	√	√	√	√	√	0247
2016	Holden	Caprice	Body Control Module	√	√	√	√	√	0263 0203 0201 0208 0206 0083 0160 0159
2016	Holden	Caprice	Keyless Entry Control Module	√	√	√	√	√	
2016	Holden	Caprice	Instrument Cluster	√	√	√	√	√	0247 0145
2016	Holden	Caprice	Radio Controls	√	√	√	√	√	0241 0247
2016	Holden	Caprice	HVAC Controls	√	√	√	√	√	
2016	Holden	Caprice	Trailer Interface Control Module	√	√	√	√	√	0247
2016	Holden	Caprice	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0111
2016	Holden	Caprice	Electronic Brake Control Module	√	√	√	√	√	0225 0090 0111
2016	Holden	Caprice	Parking Brake Control Module	√	√	√	√	√	0229
2016	Holden	Caprice	Power Steering Control Module	√	√	√	√	√	0081
2016	Holden	Caprice	Suspension Control Module	√	√	√	√	√	0245
2016	Holden	Caprice	Head-Up Display Module	√	√	√	√	√	

2016	Holden	Caprice	Radio	√	√	√	√	√	
2016	Holden	Caprice	Steering Column Lock Control Module	√	√	√	√		
2016	Holden	Caprice	Frontview Camera Module	√	√	√	√	√	0205 0049
2016	Holden	Caprice	Steering Wheel Angle Sensor Module	√	√	√			0093 0090
2016	Holden	Caprice	Left Side Object Detection Control Module	√	√	√		√	
2016	Holden	Caprice	HVAC Control Module	√	√	√	√	√	0007 0129
2016	Holden	Caprice	Headlamp Control Module	√	√	√	√	√	0195
2016	Holden	Caprice	Chassis Control Module	√	√	√	√	√	0217 0095 0194 0245
2016	Holden	Caprice	Right Side Object Detection Control Module	√	√	√		√	
2016	Holden	Captiva	Engine Control Module	√	√	√	√	√	0156 0209 0098 0216 0224 0449 0130 0143 0450 0265 0147 0108 0452 0237 0044 0045 0086 0043 0135 0453 0454 0455 0456 0263 0132 0067 0217 0213
2016	Holden	Captiva	Rear Differential Clutch Control Module	√	√	√	√	√	0155
2016	Holden	Captiva	Transmission Control Module	√	√	√	√	√	0019
2016	Holden	Captiva	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0261
2016	Holden	Captiva	Radio	√	√	√	√	√	
2016	Holden	Captiva	Electronic Brake Control Module	√	√	√	√	√	0090
2016	Holden	Captiva	Variable Power Steering Control Module	√				√	
2016	Holden	Captiva	Parking Brake Control Module	√	√	√	√	√	0229
2016	Holden	Captiva	Instrument Cluster	√	√	√	√	√	
2016	Holden	Captiva	Auxiliary Body Control Module	√	√	√	√	√	0050
2016	Holden	Captiva	Remote Control Door Lock Receiver	√	√	√	√	√	0110 0160 0159 079B
2016	Holden	Captiva	Body Control Module	√	√	√	√	√	0242 0263 0261
2016	Holden	Captiva	Left Side Object Detection Control Module	√	√	√		√	
2016	Holden	Captiva	Right Side Object Detection Control Module	√	√	√		√	
2016	Holden	Captiva	Chassis Control Module	√	√	√	√	√	0217 0095 0194
2016	Holden	Captiva	Headlamp Control Module	√	√	√	√	√	0195 0065
2016	Holden	Captiva	HVAC Control Module	√	√	√		√	
2016	Holden	Cascada	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0111
2016	Holden	Cascada	Parking Assist Control Module	√	√	√	√	√	0247
2016	Holden	Cascada	Front Seat Heating Control Module	√	√	√	√	√	
2016	Holden	Cascada	Instrument Cluster	√	√	√	√	√	0247
2016	Holden	Cascada	Radio	√	√	√	√	√	
2016	Holden	Cascada	Headlamp Control Module	√	√	√	√	√	0195
2016	Holden	Cascada	HVAC Control Module	√	√	√	√	√	0007 0247 0129
2016	Holden	Cascada	Multi-Axis Acceleration Sensor Module	√	√	√			0112 0111
2016	Holden	Cascada	Steering Wheel Angle Sensor Module	√	√	√			0093 0090
2016	Holden	Cascada	Frontview Camera Module	√	√	√	√	√	0205 0196 0247
2016	Holden	Cascada	Digital Radio Receiver Control Module	√	√	√	√	√	0247

2016	Holden	Cascada	Parking Brake Control Module	√	√	√	√	√	0229
2016	Holden	Cascada	Electronic Brake Control Module	√	√	√	√	√	0090 0225 0111
2016	Holden	Cascada	Power Steering Control Module	√	√	√	√	√	0081 0080 0089
2016	Holden	Cascada	Body Control Module	√	√	√	√	√	0242 0263 0203 0208 0201 0206 0083 0160
2016	Holden	Cascada	Folding Top Control Module	√	√	√	√	√	0247 0004 0005
2016	Holden	Cascada	Engine Control Module	√	√	√	√	√	0263 0156 0209 0216 0132 0067 0147 0066 0115 0086 0154 0214 0215 0217 0006 0144
2016	Holden	Cascada	Transmission Control Module	√	√	√	√	√	0019
2016	Holden	Cascada	Chassis Control Module	√	√	√	√	√	0217 0095 0194
2016	Holden	Cascada	Suspension Control Module	√	√	√	√	√	
2016	Holden	Colorado	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172
2016	Holden	Colorado	Engine Control Module	√	√	√	√	√	0263 0210 0224 0130 0222 0060 0044 0045 0086 0097 0084 0043
2016	Holden	Colorado	Electronic Brake Control Module	√	√	√	√	√	0090 0112
2016	Holden	Colorado	Parking Assist Control Module	√	√	√	√	√	0247
2016	Holden	Colorado	Body Control Module	√	√	√	√	√	0263 0203 0201 0208 0206 0083 0160 0159
2016	Holden	Colorado	Transmission Control Module	√	√	√	√	√	0016
2016	Holden	Colorado	Multi-Axis Acceleration Sensor Module	√	√	√			0112 0111
2016	Holden	Colorado	Steering Wheel Angle Sensor Module	√	√	√			0093 0090
2016	Holden	Colorado	Instrument Cluster	√	√	√	√	√	0247
2016	Holden	Colorado	Trailer Interface Control Module	√	√	√	√	√	0247
2016	Holden	Colorado	Radio	√	√	√	√	√	
2016	Holden	Colorado	Transfer Case Control Module	√	√	√	√	√	0037
2016	Holden	Colorado 7	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172
2016	Holden	Colorado 7	Engine Control Module	√	√	√	√	√	0263 0210 0224 0130 0222 0060 0044 0045 0086 0097 0084 0043
2016	Holden	Colorado 7	Electronic Brake Control Module	√	√	√	√	√	0090 0112
2016	Holden	Colorado 7	Parking Assist Control Module	√	√	√	√	√	0247
2016	Holden	Colorado 7	Body Control Module	√	√	√	√	√	0263 0203 0201 0208 0206 0083 0160 0159
2016	Holden	Colorado 7	Transmission Control Module	√	√	√	√	√	0016
2016	Holden	Colorado 7	Steering Wheel Angle Sensor Module	√	√	√			0093 0090
2016	Holden	Colorado 7	Multi-Axis Acceleration Sensor Module	√	√	√			0112 0111
2016	Holden	Colorado 7	Instrument Cluster	√	√	√	√	√	0247
2016	Holden	Colorado 7	Trailer Interface Control Module	√	√	√	√	√	0247
2016	Holden	Colorado 7	Radio	√	√	√	√	√	

2016	Holden	Colorado 7	Transfer Case Control Module	√	√	√	√	√	0037
2016	Holden	Commodore	Steering Column Lock Control Module	√	√	√	√		
2016	Holden	Commodore	Liftgate Control Module	√	√	√	√	√	
2016	Holden	Commodore	Transmission Control Module	√	√	√	√	√	0016
2016	Holden	Commodore	Engine Control Module	√	√	√	√	√	0263 0156 0209 0132 0067 0086 0217 0258
2016	Holden	Commodore	Seat Memory Control Module - Driver	√	√	√	√	√	
2016	Holden	Commodore	Parking Assist Control Module	√	√	√	√	√	0247
2016	Holden	Commodore	Body Control Module	√	√	√	√	√	0263 0203 0201 0208 0206 0083 0160 0159
2016	Holden	Commodore	Keyless Entry Control Module	√	√	√	√	√	
2016	Holden	Commodore	Instrument Cluster	√	√	√	√	√	0247 0145
2016	Holden	Commodore	HVAC Controls	√	√	√	√	√	
2016	Holden	Commodore	Radio Controls	√	√	√	√	√	0241 0247
2016	Holden	Commodore	Trailer Interface Control Module	√	√	√	√	√	0247
2016	Holden	Commodore	Electronic Brake Control Module	√	√	√	√	√	0225 0090 0111
2016	Holden	Commodore	Power Steering Control Module	√	√	√	√		0081
2016	Holden	Commodore	Suspension Control Module	√	√	√	√	√	0245
2016	Holden	Commodore	Head-Up Display Module	√	√	√	√	√	
2016	Holden	Commodore	Parking Brake Control Module	√	√	√	√	√	0229
2016	Holden	Commodore	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0111
2016	Holden	Commodore	Steering Wheel Angle Sensor Module	√	√	√			0093 0090
2016	Holden	Commodore	Left Side Object Detection Control Module	√	√	√		√	
2016	Holden	Commodore	Frontview Camera Module	√	√	√	√	√	0205 0049
2016	Holden	Commodore	Radio	√	√	√	√	√	
2016	Holden	Commodore	HVAC Control Module	√	√	√	√	√	0007 0129
2016	Holden	Commodore	Headlamp Control Module	√	√	√	√	√	0195
2016	Holden	Commodore	Chassis Control Module	√	√	√	√	√	0217 0095 0194 0245
2016	Holden	Commodore	Right Side Object Detection Control Module	√	√	√		√	
2016	Holden	Cruze	Electronic Brake Control Module	√	√	√	√	√	0225 0090 0111
2016	Holden	Cruze	Power Steering Control Module	√	√	√	√		0081 0080 0089
2016	Holden	Cruze	Engine Control Module	√	√	√	√	√	0263 0209 0132 0067 0066 0086 0217 0156
2016	Holden	Cruze	Instrument Cluster	√	√	√	√	√	0247
2016	Holden	Cruze	Trailer Interface Control Module	√	√	√	√	√	0247
2016	Holden	Cruze	Multi-Axis Acceleration Sensor Module	√	√	√			0112 0111
2016	Holden	Cruze	Steering Wheel Angle Sensor Module	√	√	√			0093 0090
2016	Holden	Cruze	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172
2016	Holden	Cruze	Front Seat Heating Control Module	√	√	√	√	√	
2016	Holden	Cruze	Radio	√	√	√	√	√	
2016	Holden	Cruze	Parking Assist Control Module	√	√	√	√	√	0247

2016	Holden	Cruze	Body Control Module	√	√	√	√	√	0263 0203 0201 0208 0206 0083 0160 0159
2016	Holden	Cruze	Transmission Control Module	√	√	√	√	√	0019
2016	Holden	Cruze	HVAC Control Module	√	√	√	√	√	0007 0129
2016	Holden	Cruze	Steering Column Lock Control Module	√	√	√	√	√	
2016	Holden	Cruze	Keyless Entry Control Module	√	√	√	√	√	
2016	Holden	Insignia	Front Seat Heating/Venting/Cooling/Memory Control Module	√	√	√	√	√	
2016	Holden	Insignia	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0111
2016	Holden	Insignia	Parking Assist Control Module	√	√	√	√	√	0247
2016	Holden	Insignia	Human Machine Interface Control Module	√	√	√	√	√	0150
2016	Holden	Insignia	Headlamp Control Module	√	√	√	√	√	0195
2016	Holden	Insignia	HVAC Control Module	√	√	√	√	√	0007 0247 0129
2016	Holden	Insignia	Radio	√	√	√	√	√	0226
2016	Holden	Insignia	Instrument Cluster	√	√	√	√	√	0247
2016	Holden	Insignia	Trailer Interface Control Module	√	√	√	√	√	0247
2016	Holden	Insignia	Left Side Object Detection Control Module	√	√	√	√	√	
2016	Holden	Insignia	Distance Sensing Cruise Control Module	√	√	√	√	√	0047
2016	Holden	Insignia	Multi-Axis Acceleration Sensor Module	√	√	√	√	√	0112 0111
2016	Holden	Insignia	Steering Wheel Angle Sensor Module	√	√	√	√	√	0093 0090
2016	Holden	Insignia	Frontview Camera Module	√	√	√	√	√	0205 0196
2016	Holden	Insignia	Amplifier	√	√	√	√	√	
2016	Holden	Insignia	Electronic Brake Control Module	√	√	√	√	√	0225 0090 0111 0277
2016	Holden	Insignia	Engine Control Module	√	√	√	√	√	0156 0067 0086 0217
2016	Holden	Insignia	Power Steering Control Module	√	√	√	√	√	
2016	Holden	Insignia	Parking Brake Control Module	√	√	√	√	√	0229
2016	Holden	Insignia	Body Control Module	√	√	√	√	√	0242 0263 0203 0208 0201 0206 0083 0160
2016	Holden	Insignia	Steering Column Lock Control Module	√	√	√	√	√	
2016	Holden	Insignia	Keyless Entry Control Module	√	√	√	√	√	
2016	Holden	Insignia	HVAC Controls	√	√	√	√	√	
2016	Holden	Insignia	Radio Controls	√	√	√	√	√	0150
2016	Holden	Insignia	Chassis Control Module	√	√	√	√	√	0217 0095 0194
2016	Holden	Insignia	Rear Differential Clutch Control Module	√	√	√	√	√	
2016	Holden	Insignia	Suspension Control Module	√	√	√	√	√	
2016	Holden	Insignia	Transmission Control Module	√	√	√	√	√	0020 0084
2016	Holden	Spark	Transmission Control Module	√	√	√	√	√	0017
2016	Holden	Spark	Engine Control Module	√	√	√	√	√	0263 0156 0209 0066 0086 0217 0141 0139
2016	Holden	Spark	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0111
2016	Holden	Spark	Parking Assist Control Module	√	√	√	√	√	0271 0247
2016	Holden	Spark	Electronic Brake Control Module	√	√	√	√	√	0090

2016	Holden	Spark	Power Steering Control Module	√	√	√	√		0089
2016	Holden	Spark	Body Control Module	√	√	√	√	√	0263 0203 0083 0159
2016	Holden	Spark	Radio	√	√	√	√	√	
2016	Holden	Spark	Instrument Cluster	√	√	√	√	√	0247
2016	Holden	Spark	Keyless Entry Control Module	√	√	√	√	√	
2016	Holden	Spark	Steering Column Lock Control Module	√	√	√	√		
2016	Holden	Trax	Instrument Cluster	√	√	√	√	√	0247
2016	Holden	Trax	Electronic Brake Control Module	√	√	√	√	√	0090
2016	Holden	Trax	Power Steering Control Module	√	√	√	√		0207
2016	Holden	Trax	Parking Assist Control Module	√	√	√	√	√	0247
2016	Holden	Trax	Body Control Module	√	√	√	√	√	0263 0203 0083 0159
2016	Holden	Trax	Transmission Control Module	√	√	√	√	√	0019
2016	Holden	Trax	Engine Control Module	√	√	√	√	√	0263 0156 0209 0132 0067 0066 0217 0086
2016	Holden	Trax	Steering Wheel Angle Sensor Module	√	√	√			0093 0090
2016	Holden	Trax	Front Seat Heating Control Module	√	√	√	√	√	
2016	Holden	Trax	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0111
2016	Holden	Trax	Radio	√	√	√	√	√	
2016	Holden	Trax	HVAC Control Module	√	√	√	√	√	
2016	Holden	Trax	Rear Differential Clutch Control Module	√	√	√	√		0003 075B
2016	Holden	Trax	Trailer Interface Control Module	√	√	√	√	√	0247
2016	Holden	Trax	Chassis Control Module	√	√	√	√	√	0217
2015	Holden	Astra-J	Instrument Cluster	√	√	√	√	√	0247
2015	Holden	Astra-J	Trailer Interface Control Module	√	√	√	√	√	0247
2015	Holden	Astra-J	Electronic Brake Control Module	√	√	√	√	√	0090 0225 0111
2015	Holden	Astra-J	Parking Brake Control Module	√	√	√	√	√	0229
2015	Holden	Astra-J	Power Steering Control Module	√	√	√	√		0081 0080 0089
2015	Holden	Astra-J	Body Control Module	√	√	√	√	√	0242 0263 0203 0208 0201 0206 0083 0160
2015	Holden	Astra-J	Multi-Axis Acceleration Sensor Module	√	√	√			0112 0111
2015	Holden	Astra-J	Steering Wheel Angle Sensor Module	√	√	√			0093 0090
2015	Holden	Astra-J	Frontview Camera Module	√	√	√	√	√	0247
2015	Holden	Astra-J	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172
2015	Holden	Astra-J	Front Seat Heating Control Module	√	√	√	√	√	
2015	Holden	Astra-J	Parking Assist Control Module	√	√	√	√	√	0247
2015	Holden	Astra-J	Radio	√	√	√	√	√	
2015	Holden	Astra-J	Suspension Control Module	√	√	√	√	√	
2015	Holden	Astra-J	HVAC Control Module	√	√	√	√	√	0007 0247 0129
2015	Holden	Astra-J	Transmission Control Module	√	√	√	√	√	0019
2015	Holden	Astra-J	Chassis Control Module	√	√	√	√	√	0217 0095 0194
2015	Holden	Astra-J	Headlamp Control Module	√	√	√	√	√	0195

2015	Holden	Astra-J	Engine Control Module	√	√	√	√	√	0263 0156 0209 0216 0132 0067 0147 0066 0115 0086 0154 0214 0215 0217 0006 0144 0128 0258
2015	Holden	Astra-J	Digital Radio Receiver Control Module	√	√	√	√	√	0247
2015	Holden	Barina	Chassis Control Module	√	√	√	√	√	0217 0095 0194 0245
2015	Holden	Barina	Engine Control Module	√	√	√	√	√	0133 0156 0210 0383 0098 0096 0094 0216 0130 0143 0265 0147 0237 0045 0086 0393 0043 0135 0128 0173 0263 0209 0020 0132 0067 0066 076D 0213 0217 0006 0144 0258
2015	Holden	Barina	Transmission Control Module	√	√	√	√	√	0017 0036
2015	Holden	Barina	Front Seat Heating Control Module	√	√	√	√	√	
2015	Holden	Barina	Instrument Cluster	√	√	√	√	√	0247
2015	Holden	Barina	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0134 0111
2015	Holden	Barina	Radio	√	√	√	√	√	
2015	Holden	Barina	Electronic Brake Control Module	√	√	√	√	√	0090
2015	Holden	Barina	HVAC Control Module	√	√	√	√	√	
2015	Holden	Barina	Parking Assist Control Module	√	√	√	√	√	0247
2015	Holden	Barina	Power Steering Control Module	√	√	√	√	√	0207
2015	Holden	Barina	Steering Wheel Angle Sensor Module	√	√	√	√	√	0093 0090
2015	Holden	Barina	Body Control Module	√	√	√	√	√	0242 0263 0203 0201 0208 0206 0083 0160
2015	Holden	Barina Spark	Engine Control Module	√	√	√	√	√	0156 0209 0132 0067 0263 0086 0217 0139
2015	Holden	Barina Spark	Keyless Entry Control Module				√		
2015	Holden	Barina Spark	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0134
2015	Holden	Barina Spark	Radio	√	√	√	√	√	
2015	Holden	Barina Spark	Instrument Cluster	√	√	√	√	√	0247
2015	Holden	Barina Spark	Multi-Axis Acceleration Sensor Module	√	√	√	√	√	0112 0111
2015	Holden	Barina Spark	Electronic Brake Control Module	√	√	√	√	√	0090
2015	Holden	Barina Spark	Power Steering Control Module	√	√	√	√	√	0089
2015	Holden	Barina Spark	Body Control Module	√	√	√	√	√	0242 0263 0203 0201 0208 0206 0083 0160
2015	Holden	Barina Spark	Transmission Control Module	√	√	√	√	√	0016
2015	Holden	Caprice	Steering Column Lock Control Module	√	√	√	√	√	
2015	Holden	Caprice	Transmission Control Module	√	√	√	√	√	0016
2015	Holden	Caprice	Engine Control Module	√	√	√	√	√	0263 0156 0209 0132 0067 0086 0217 0258 0212 0006 0131

2015	Holden	Caprice	Head-Up Display Module	√	√	√	√	√	
2015	Holden	Caprice	Instrument Cluster	√	√	√	√	√	0247 0145
2015	Holden	Caprice	Left Side Object Detection Control Module	√	√	√		√	
2015	Holden	Caprice	Right Side Object Detection Control Module	√	√	√		√	
2015	Holden	Caprice	Seat Memory Control Module - Driver	√	√	√	√	√	
2015	Holden	Caprice	Headlamp Control Module	√	√	√	√	√	0195
2015	Holden	Caprice	Suspension Control Module	√	√	√	√	√	0245
2015	Holden	Caprice	Trailer Interface Control Module	√	√	√	√	√	0247
2015	Holden	Caprice	Fuel Injector Control Module	√			√	√	
2015	Holden	Caprice	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0134 0111
2015	Holden	Caprice	Keyless Entry Control Module	√	√	√	√	√	
2015	Holden	Caprice	Electronic Brake Control Module	√	√	√	√	√	0225 0090 0111
2015	Holden	Caprice	Power Steering Control Module	√	√	√	√		0081
2015	Holden	Caprice	Parking Assist Control Module	√	√	√	√	√	0247
2015	Holden	Caprice	Body Control Module	√	√	√	√	√	0199 0239 0161 0162 0163 0164 0165 0166 0167 0168 0242 0263 0203 0201 0208 0206 0000 0150 0000 0150
2015	Holden	Caprice	Steering Wheel Angle Sensor Module	√	√	√			0093 0090
2015	Holden	Caprice	Frontview Camera Module	√	√	√	√	√	0205 0049
2015	Holden	Caprice	Parking Brake Control Module	√	√	√	√	√	0229
2015	Holden	Caprice	HVAC Control Module	√	√	√	√	√	0007 0129
2015	Holden	Caprice	Chassis Control Module	√	√	√	√	√	0217 0095 0194 0245
2015	Holden	Caprice	Radio Controls	√	√	√	√	√	0247
2015	Holden	Caprice	HVAC Controls	√	√	√	√	√	
2015	Holden	Caprice	Radio	√	√	√	√	√	
2015	Holden	Captiva 5	Transmission Control Module	√	√	√	√	√	0017 0036
2015	Holden	Captiva 5	Engine Control Module	√	√	√	√	√	0263 0209 0132 0067 0156 0086 0217 0213 0098 0216 0224 0449 0130 0143 0450 0265 0147 0108 0452 0237 0044 0045 0043 0135 0452 0454 0455 0456
2015	Holden	Captiva 5	Mobile Telephone Control Module	√	√	√		√	0247 0065 0249 0246
2015	Holden	Captiva 5	Rear Differential Clutch Control Module	√	√	√	√	√	0155
2015	Holden	Captiva 5	HVAC Control Module	√	√	√		√	
2015	Holden	Captiva 5	Headlamp Control Module	√	√	√	√	√	0195 0065
2015	Holden	Captiva 5	Electronic Brake Control Module	√	√	√	√	√	0090
2015	Holden	Captiva 5	Variable Power Steering Control Module	√				√	
2015	Holden	Captiva 5	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0261
2015	Holden	Captiva 5	Info Display Module	√	√	√	√	√	0170 0467 0468 0247 0246 0065 0249 07B3

2015	Holden	Captiva 5	Parking Brake Control Module	√	√	√	√	√	0229
2015	Holden	Captiva 5	Parking Assist Control Module	√	√	√	√	√	
2015	Holden	Captiva 5	Auxiliary Body Control Module	√	√	√	√	√	0050
2015	Holden	Captiva 5	Remote Control Door Lock Receiver	√	√	√	√	√	0204 0239 0161 0162 0163 0164 0159 0160
2015	Holden	Captiva 5	Theft Deterrent Module	√	√	√	√	√	
2015	Holden	Captiva 5	Body Control Module	√	√	√	√	√	0242 0263 0261
2015	Holden	Captiva 5	Instrument Cluster	√	√	√	√	√	
2015	Holden	Captiva 5	Radio	√	√	√	√	√	0170 07B4 0247 0246 0065 0470 07B5
2015	Holden	Captiva 5	Chassis Control Module	√	√	√	√	√	0217 0095 0194
2015	Holden	Captiva 7	Mobile Telephone Control Module	√	√	√	√	√	
2015	Holden	Captiva 7	Transmission Control Module	√	√	√	√	√	0017 0036
2015	Holden	Captiva 7	Engine Control Module	√	√	√	√	√	0156 0209 0098 0216 0224 0449 0130 0143 0450 0265 0147 0108 0452 0237 0044 0045 0086 0043 0135 0453 0454 0455 0456 0263 0132 0067 0217 0213 0006 0131 0258
2015	Holden	Captiva 7	HVAC Control Module	√	√	√	√	√	
2015	Holden	Captiva 7	Electronic Brake Control Module	√	√	√	√	√	0090 0111
2015	Holden	Captiva 7	Variable Power Steering Control Module					√	
2015	Holden	Captiva 7	Instrument Cluster	√	√	√	√	√	
2015	Holden	Captiva 7	Theft Deterrent Module	√	√	√	√	√	
2015	Holden	Captiva 7	Rear Differential Clutch Control Module	√	√	√	√	√	0155
2015	Holden	Captiva 7	Headlamp Control Module	√	√	√	√	√	0195 0065
2015	Holden	Captiva 7	Body Control Module	√	√	√	√	√	0242 0263 0261
2015	Holden	Captiva 7	Remote Control Door Lock Receiver	√	√	√	√	√	0110 0160 0159 079B
2015	Holden	Captiva 7	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0261
2015	Holden	Captiva 7	Chassis Control Module	√	√	√	√	√	0217
2015	Holden	Captiva 7	Parking Brake Control Module	√	√	√	√	√	0229
2015	Holden	Captiva 7	Auxiliary Body Control Module	√	√	√	√	√	0050
2015	Holden	Cascada	Instrument Cluster	√	√	√	√	√	0247
2015	Holden	Cascada	Body Control Module	√	√	√	√	√	0242 0263 0203 0208 0201 0206 0083 0160
2015	Holden	Cascada	Folding Top Control Module	√	√	√	√	√	0247 0004 0005
2015	Holden	Cascada	Multi-Axis Acceleration Sensor Module	√	√	√	√	√	0112 0111
2015	Holden	Cascada	Steering Wheel Angle Sensor Module	√	√	√	√	√	0093 0090
2015	Holden	Cascada	Frontview Camera Module	√	√	√	√	√	0247
2015	Holden	Cascada	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0111
2015	Holden	Cascada	Front Seat Heating Control Module	√	√	√	√	√	

2015	Holden	Cascada	Parking Assist Control Module	√	√	√	√	√	0247
2015	Holden	Cascada	Parking Brake Control Module	√	√	√	√	√	0229
2015	Holden	Cascada	Power Steering Control Module	√	√	√	√	√	0081 0080 0089
2015	Holden	Cascada	Electronic Brake Control Module	√	√	√	√	√	0090 0225 0111
2015	Holden	Cascada	Radio	√	√	√	√	√	
2015	Holden	Cascada	Engine Control Module	√	√	√	√	√	0263 0156 0209 0216 0132 0067 0147 0066 0115 0086 0154 0214 0215 0217 0006 0144
2015	Holden	Cascada	Chassis Control Module	√	√	√	√	√	0217 0095 0194
2015	Holden	Cascada	Transmission Control Module	√	√	√	√	√	0019
2015	Holden	Cascada	Headlamp Control Module	√	√	√	√	√	0195
2015	Holden	Cascada	HVAC Control Module	√	√	√	√	√	0007 0247 0129
2015	Holden	Cascada	Digital Radio Receiver Control Module	√	√	√	√	√	0247
2015	Holden	Colorado	Transmission Control Module	√	√	√	√	√	0016
2015	Holden	Colorado	Parking Assist Control Module	√	√	√	√	√	0247
2015	Holden	Colorado	Instrument Cluster	√	√	√	√	√	0247
2015	Holden	Colorado	Trailer Interface Control Module	√	√	√	√	√	0247
2015	Holden	Colorado	Engine Control Module	√	√	√	√	√	0263 0210 0224 0130 0222 0060 0044 0045 0086 0097 0084 0043
2015	Holden	Colorado	Electronic Brake Control Module	√	√	√	√	√	0090 0112
2015	Holden	Colorado	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0134
2015	Holden	Colorado	Transfer Case Control Module	√	√	√	√	√	0037
2015	Holden	Colorado	Multi-Axis Acceleration Sensor Module	√	√	√			0112 0111
2015	Holden	Colorado	Steering Wheel Angle Sensor Module	√	√	√			0093 0090
2015	Holden	Colorado	Body Control Module	√	√	√	√	√	0199 0239 0161 0162 0163 0164 0165 0166 0167 0168 0242 0263 0203 0201 0208 0206
2015	Holden	Colorado	Radio	√	√	√	√	√	
2015	Holden	Colorado 7	Transmission Control Module	√	√	√	√	√	0016
2015	Holden	Colorado 7	Parking Assist Control Module	√	√	√	√	√	0247
2015	Holden	Colorado 7	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0134
2015	Holden	Colorado 7	Instrument Cluster	√	√	√	√	√	0247
2015	Holden	Colorado 7	Trailer Interface Control Module	√	√	√	√	√	0247
2015	Holden	Colorado 7	Engine Control Module	√	√	√	√	√	0263 0210 0224 0130 0222 0060 0044 0045 0086 0097 0084 0043
2015	Holden	Colorado 7	Electronic Brake Control Module	√	√	√	√	√	0090 0112
2015	Holden	Colorado 7	Frontview Camera Module	√	√	√	√	√	0205 0196 075A
2015	Holden	Colorado 7	Transfer Case Control Module	√	√	√	√	√	0037

2015	Holden	Colorado 7	Steering Wheel Angle Sensor Module	√	√	√			0093 0090
2015	Holden	Colorado 7	Multi-Axis Acceleration Sensor Module	√	√	√			0112 0111
2015	Holden	Colorado 7	Body Control Module	√	√	√	√	√	0199 0239 0161 0162 0163 0164 0165 0166 0167 0168 0242 0263 0203 0201 0208 0206 0002 0150 0232 0150
2015	Holden	Colorado 7	Radio	√	√	√	√	√	
2015	Holden	Commodore	Liftgate Control Module	√	√	√	√	√	
2015	Holden	Commodore	Steering Column Lock Control Module	√	√	√	√		
2015	Holden	Commodore	Transmission Control Module	√	√	√	√	√	0016
2015	Holden	Commodore	Engine Control Module	√	√	√	√	√	0263 0156 0209 0132 0067 0086 0217 0258 0212 0006 0131
2015	Holden	Commodore	Head-Up Display Module	√	√	√	√	√	
2015	Holden	Commodore	Instrument Cluster	√	√	√	√	√	0247 0145
2015	Holden	Commodore	Left Side Object Detection Control Module	√	√	√		√	
2015	Holden	Commodore	Right Side Object Detection Control Module	√	√	√		√	
2015	Holden	Commodore	Seat Memory Control Module - Driver	√	√	√	√	√	
2015	Holden	Commodore	Headlamp Control Module	√	√	√	√	√	0195
2015	Holden	Commodore	Suspension Control Module	√	√	√	√	√	0245
2015	Holden	Commodore	Trailer Interface Control Module	√	√	√	√	√	0247
2015	Holden	Commodore	Fuel Injector Control Module	√			√	√	
2015	Holden	Commodore	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0134 0111
2015	Holden	Commodore	Keyless Entry Control Module	√	√	√	√	√	
2015	Holden	Commodore	Power Steering Control Module	√	√	√	√		0081
2015	Holden	Commodore	Electronic Brake Control Module	√	√	√	√	√	0225 0090 0111
2015	Holden	Commodore	Parking Assist Control Module	√	√	√	√	√	0247
2015	Holden	Commodore	Body Control Module	√	√	√	√	√	0199 0239 0161 0162 0163 0164 0165 0166 0167 0168 0242 0263 0203 0201 0208 0206 0002 0150 0232 0150
2015	Holden	Commodore	Frontview Camera Module	√	√	√	√	√	0205 0049
2015	Holden	Commodore	Steering Wheel Angle Sensor Module	√	√	√			0093 0090
2015	Holden	Commodore	Parking Brake Control Module	√	√	√	√	√	0229
2015	Holden	Commodore	HVAC Control Module	√	√	√	√	√	0007 0129
2015	Holden	Commodore	Chassis Control Module	√	√	√	√	√	0217 0095 0194 0245
2015	Holden	Commodore	Radio Controls	√	√	√	√	√	0247
2015	Holden	Commodore	HVAC Controls	√	√	√	√	√	
2015	Holden	Commodore	Radio	√	√	√	√	√	
2015	Holden	Cruze	Transmission Control Module	√	√	√	√	√	0017 0036
2015	Holden	Cruze	HVAC Control Module	√	√	√	√	√	0007 0129

2015	Holden	Cruze	Engine Control Module	√	√	√	√	√	0156 0209 0132 0067 0263 0086 0217 0139 0020 0066 076D 0213 0006 0144 0258 0098 0216 0224 0449 0130 0143 0450 0265 0147 0108 0452 0237 0044 0045 0043 0135 0453
2015	Holden	Cruze	Front Seat Heating Control Module	√	√	√	√	√	
2015	Holden	Cruze	Left Side Object Detection Control Module	√	√	√		√	
2015	Holden	Cruze	Parking Assist Control Module	√	√	√	√	√	0247
2015	Holden	Cruze	Right Side Object Detection Control Module	√	√	√		√	
2015	Holden	Cruze	Instrument Cluster	√	√	√	√	√	0247
2015	Holden	Cruze	Electronic Brake Control Module	√	√	√	√	√	0225 0090 0111
2015	Holden	Cruze	Power Steering Control Module	√	√	√	√		0081 0080 0089
2015	Holden	Cruze	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0134
2015	Holden	Cruze	Keyless Entry Control Module	√	√	√	√	√	
2015	Holden	Cruze	Body Control Module	√	√	√	√	√	0242 0263 0203 0201 0208 0206 0083 0160
2015	Holden	Cruze	Mobile Telephone Control Module	√	√	√	√	√	0247
2015	Holden	Cruze	Multi-Axis Acceleration Sensor Module	√	√	√			0112 0111
2015	Holden	Cruze	Steering Wheel Angle Sensor Module	√	√	√			0093 0090
2015	Holden	Cruze	Fuel Injector Control Module	√			√	√	
2015	Holden	Cruze	Chassis Control Module	√	√	√	√	√	0217
2015	Holden	Cruze	Radio	√	√	√	√	√	
2015	Holden	Cruze	Trailer Interface Control Module	√	√	√	√	√	0247
2015	Holden	Cruze	Multimedia Player Interface Module	√	√	√	√		0247
2015	Holden	Cruze	Steering Column Lock Control Module	√	√	√	√		
2015	Holden	Insignia	Instrument Cluster	√	√	√	√	√	0247
2015	Holden	Insignia	Trailer Interface Control Module	√	√	√	√	√	0247
2015	Holden	Insignia	Body Control Module	√	√	√	√	√	0242 0263 0203 0208 0201 0206 0083 0160
2015	Holden	Insignia	Keyless Entry Control Module	√	√	√	√	√	
2015	Holden	Insignia	Steering Column Lock Control Module	√	√	√	√		
2015	Holden	Insignia	Steering Wheel Angle Sensor Module	√	√	√			0093 0090
2015	Holden	Insignia	Frontview Camera Module	√	√	√	√	√	0205 0196
2015	Holden	Insignia	Electronic Brake Control Module	√	√	√	√	√	0225 0090 0111 0277
2015	Holden	Insignia	Parking Brake Control Module	√	√	√	√	√	0229
2015	Holden	Insignia	Power Steering Control Module	√	√	√	√	√	
2015	Holden	Insignia	Radio	√	√	√	√	√	0226
2015	Holden	Insignia	Amplifier	√	√	√	√		
2015	Holden	Insignia	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0111

2015	Holden	Insignia	Front Seat Heating/Venting/Cooling/Memory Control Module	√	√	√	√	√	
2015	Holden	Insignia	Parking Assist Control Module	√	√	√	√	√	0247
2015	Holden	Insignia	Engine Control Module	√	√	√	√	√	0156 0067 0086 0217
2015	Holden	Insignia	Distance Sensing Cruise Control Module	√	√	√	√		0047
2015	Holden	Insignia	Left Side Object Detection Control Module	√	√	√		√	
2015	Holden	Insignia	Rear Differential Clutch Control Module	√	√	√	√	√	
2015	Holden	Insignia	Suspension Control Module	√	√	√	√	√	
2015	Holden	Insignia	Human Machine Interface Control Module	√	√	√	√	√	0150
2015	Holden	Insignia	HVAC Controls	√	√	√	√	√	
2015	Holden	Insignia	Radio Controls	√	√	√	√	√	0150
2015	Holden	Insignia	Transmission Control Module	√	√	√	√	√	0020 0084
2015	Holden	Insignia	Chassis Control Module	√	√	√	√	√	0217 0095 0194
2015	Holden	Insignia	HVAC Control Module	√	√	√	√	√	0007 0247 0129
2015	Holden	Insignia	Headlamp Control Module	√	√	√	√	√	0195
2015	Holden	Malibu	Steering Column Lock Control Module	√	√	√	√		
2015	Holden	Malibu	Parking Brake Control Module	√	√	√	√	√	0229
2015	Holden	Malibu	Transmission Control Module	√	√	√	√	√	0017 0036 0020 0084
2015	Holden	Malibu	Engine Control Module	√	√	√	√	√	0263 0156 0209 0020 0132 0067 0066 076D 0086 0213 0217 0006 0144 0258 0139 0133 0210 0383 0098 0096 0094 0216 0130 0143 0265 0147 0237 0045 0393 0043 0135 0128
2015	Holden	Malibu	HVAC Control Module	√	√	√	√	√	0007 0129
2015	Holden	Malibu	Headlamp Control Module	√	√	√	√	√	0195
2015	Holden	Malibu	Rear Differential Clutch Control Module	√	√	√	√	√	
2015	Holden	Malibu	Instrument Cluster	√	√	√	√	√	0247
2015	Holden	Malibu	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0134 0111
2015	Holden	Malibu	Keyless Entry Control Module	√	√	√	√	√	
2015	Holden	Malibu	Parking Assist Control Module	√	√	√	√	√	0247
2015	Holden	Malibu	Body Control Module	√	√	√	√	√	0199 0239 0161 0162 0163 0164 0165 0166 0167 0168 0242 0263 0203 0201 0208 0206 0002 0150 0032 0150
2015	Holden	Malibu	Electronic Brake Control Module	√	√	√	√	√	0225 0090 0111
2015	Holden	Malibu	Power Steering Control Module	√	√	√	√	√	0081 0080 0089
2015	Holden	Malibu	Mobile Telephone Control Module	√	√	√	√	√	0247
2015	Holden	Malibu	Frontview Camera Module	√	√	√	√	√	0205 0049
2015	Holden	Malibu	Steering Wheel Angle Sensor Module	√	√	√			0093 0090
2015	Holden	Malibu	Front Seat Heating Control Module	√	√	√	√	√	

2015	Holden	Malibu	Left Side Object Detection Control Module	√	√	√	√	√	
2015	Holden	Malibu	Rear Seat Heating Control Module	√	√	√	√	√	
2015	Holden	Malibu	Seat Memory Control Module	√	√	√	√	√	0310
2015	Holden	Malibu	Radio	√	√	√	√	√	
2015	Holden	Malibu	Multimedia Player Interface Module	√	√	√	√	√	0247
2015	Holden	Malibu	Trailer Interface Control Module	√	√	√	√	√	0247
2015	Holden	Trax	Transmission Control Module	√	√	√	√	√	0017 0036
2015	Holden	Trax	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0134 0111
2015	Holden	Trax	Instrument Cluster	√	√	√	√	√	0247
2015	Holden	Trax	HVAC Control Module	√	√	√	√	√	
2015	Holden	Trax	Electronic Brake Control Module	√	√	√	√	√	0090
2015	Holden	Trax	Body Control Module	√	√	√	√	√	0199 0239 0161 0162 0163 0164 0165 0166 0167 0168 0242 0263 0203 0201 0208 0206 0202 0156 0232 0158
2015	Holden	Trax	Rear Differential Clutch Control Module	√	√	√	√	√	0003 075B
2015	Holden	Trax	Steering Wheel Angle Sensor Module	√	√	√	√	√	0093 0090
2015	Holden	Trax	Engine Control Module	√	√	√	√	√	0263 0156 0209 0020 0132 0067 0066 076D 0086 0213 0217 0006
2015	Holden	Trax	Power Steering Control Module	√	√	√	√	√	0207
2015	Holden	Trax	Parking Assist Control Module	√	√	√	√	√	0247
2015	Holden	Trax	Front Seat Heating Control Module	√	√	√	√	√	
2015	Holden	Trax	Seat Memory Control Module	√	√	√	√	√	0310
2015	Holden	Trax	Radio	√	√	√	√	√	
2015	Holden	Trax	Trailer Interface Control Module	√	√	√	√	√	0247
2015	Holden	Volt	Electric A/C Compressor Control Module	√					
2015	Holden	Volt	Battery Energy Control Module	√			√		
2015	Holden	Volt	Coolant Heater Control Module	√	√	√			
2015	Holden	Volt	Battery Charger Control Module	√			√		
2015	Holden	Volt	Hybrid Powertrain Control Module	√	√	√	√	√	
2015	Holden	Volt	Drive Motor Control Module 1	√	√	√	√	√	
2015	Holden	Volt	Drive Motor Control Module 2	√	√	√	√	√	
2015	Holden	Volt	Auxiliary Transmission Fluid Pump	√	√	√	√	√	
2015	Holden	Volt	Hybrid Powertrain Control Module 2	√	√	√	√	√	0124 0125 0056 0218 0122 0123 0127
2015	Holden	Volt	Telematics Communication Interface Control Module	√	√	√	√	√	
2015	Holden	Volt	Steering Column Lock Control Module	√	√	√	√	√	
2015	Holden	Volt	Chassis Control Module	√	√	√	√	√	0217
2015	Holden	Volt	Instrument Cluster	√	√	√	√	√	0247
2015	Holden	Volt	Front Seat Heating Control Module	√	√	√	√	√	
2015	Holden	Volt	Parking Assist Control Module	√	√	√	√	√	0247

2015	Holden	Volt	Transmission Control Module	√	√	√	√	√	
2015	Holden	Volt	Engine Control Module	√	√	√	√	√	0209 0132 0067 0086 0217 0176
2015	Holden	Volt	HVAC Control Module	√	√	√	√	√	0007 0129
2015	Holden	Volt	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0134 0111 0758
2015	Holden	Volt	Keyless Entry Control Module	√	√	√	√	√	
2015	Holden	Volt	Radio	√	√	√	√	√	
2015	Holden	Volt	Electronic Brake Control Module	√	√	√	√	√	0263 0371 0111
2015	Holden	Volt	Parking Brake Control Module	√	√	√	√	√	0229
2015	Holden	Volt	Body Control Module	√	√	√	√	√	0199 0239 0161 0162 0163 0164 0165 0166 0167 0168 0242 0263 0203 0201 0208 0206 0083 0160 0233 0150
2015	Holden	Volt	Power Steering Control Module	√	√	√	√	√	0081 0080 0089
2015	Holden	Volt	Steering Wheel Angle Sensor Module	√	√	√			0093 0090
2015	Holden	Volt	Frontview Camera Module	√	√	√	√	√	0205 0049
2014	Holden	Barina	Transmission Control Module	√	√	√	√	√	0017 0036
2014	Holden	Barina	Chassis Control Module	√	√	√	√	√	0217 0095 0194
2014	Holden	Barina	Instrument Cluster	√	√	√	√	√	0247
2014	Holden	Barina	Engine Control Module	√	√	√	√	√	0263 0156 0209 0020 0132 0067 0066 076D 0086 0213 0217 0006
2014	Holden	Barina	Body Control Module	√	√	√	√	√	0242 0263 0203 0201 0208 0206 0083 0160
2014	Holden	Barina	Parking Assist Control Module	√	√	√	√	√	0247
2014	Holden	Barina	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0134
2014	Holden	Barina	Front Seat Heating Control Module	√	√	√	√	√	
2014	Holden	Barina	HVAC Control Module	√	√	√	√	√	
2014	Holden	Barina	Steering Wheel Angle Sensor Module	√	√	√			0093 0090
2014	Holden	Barina	Multi-Axis Acceleration Sensor Module	√	√	√			0112 0111
2014	Holden	Barina	Electronic Brake Control Module	√	√	√	√	√	0090
2014	Holden	Barina	Power Steering Control Module	√	√	√	√	√	0207
2014	Holden	Barina	Radio	√	√	√	√	√	
2014	Holden	Barina Spark	Engine Control Module	√	√	√	√	√	0156 0209 0132 0067 0263 0086 0217 0139
2014	Holden	Barina Spark	Transmission Control Module	√	√	√	√	√	0016
2014	Holden	Barina Spark	Instrument Cluster	√	√	√	√	√	0247
2014	Holden	Barina Spark	Body Control Module	√	√	√	√	√	0242 0263 0203 0201 0208 0206 0083 0160
2014	Holden	Barina Spark	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0134
2014	Holden	Barina Spark	Keyless Entry Control Module				√		
2014	Holden	Barina Spark	Steering Wheel Angle Sensor Module	√	√	√			0093 0090

2014	Holden	Barina Spark	Multi-Axis Acceleration Sensor Module	√	√	√			0112 0111
2014	Holden	Barina Spark	Electronic Brake Control Module	√	√	√	√	√	0090
2014	Holden	Barina Spark	Power Steering Control Module	√	√	√	√	√	0089
2014	Holden	Barina Spark	Radio	√	√	√	√	√	
2014	Holden	Caprice	Transmission Control Module	√	√	√	√	√	0016
2014	Holden	Caprice	Chassis Control Module	√	√	√	√	√	0217 0095 0194
2014	Holden	Caprice	Steering Column Lock Control Module	√	√	√	√	√	
2014	Holden	Caprice	Parking Assist Control Module	√	√	√	√	√	0247
2014	Holden	Caprice	Engine Control Module	√	√	√	√	√	0263 0156 0209 0132 0067 0086 0217 0006
2014	Holden	Caprice	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0134 0111
2014	Holden	Caprice	Keyless Entry Control Module	√	√	√	√	√	
2014	Holden	Caprice	Instrument Cluster	√	√	√	√	√	0247 0145
2014	Holden	Caprice	Left Side Object Detection Control Module	√	√	√		√	
2014	Holden	Caprice	Right Side Object Detection Control Module	√	√	√		√	
2014	Holden	Caprice	Seat Memory Control Module - Driver	√	√	√	√	√	
2014	Holden	Caprice	Radio	√	√	√	√	√	
2014	Holden	Caprice	Radio Controls	√	√	√	√	√	0247
2014	Holden	Caprice	Head-Up Display Module	√	√	√	√	√	
2014	Holden	Caprice	HVAC Controls	√	√	√	√	√	
2014	Holden	Caprice	Body Control Module	√	√	√	√	√	0199 0239 0161 0162 0163 0164 0165 0166 0167 0168 0242 0263 0203 0201 0208 0206 0002 0150 0222 0150
2014	Holden	Caprice	HVAC Control Module	√	√	√	√	√	0007 0129
2014	Holden	Caprice	Headlamp Control Module	√	√	√	√	√	0195
2014	Holden	Caprice	Suspension Control Module	√	√	√	√	√	0245
2014	Holden	Caprice	Frontview Camera Module	√	√	√	√	√	0205 0049
2014	Holden	Caprice	Steering Wheel Angle Sensor Module	√	√	√			0093 0090
2014	Holden	Caprice	Trailer Interface Control Module	√	√	√	√	√	0247
2014	Holden	Caprice	Fuel Injector Control Module	√			√	√	
2014	Holden	Caprice	Electronic Brake Control Module	√	√	√	√	√	0225 0090 0111
2014	Holden	Caprice	Power Steering Control Module	√	√	√	√	√	0081
2014	Holden	Caprice	Parking Brake Control Module	√	√	√	√	√	0229
2014	Holden	Captiva 5	Body Control Module	√	√	√	√	√	0242 0263 0261
2014	Holden	Captiva 5	Engine Control Module	√	√	√	√	√	0263 0209 0132 0067 0156 0086 0217 0213 0258 0212 0098 0216 0224 0449 0130 0143 0450 0265 0147 0108 0452 0237 0044 0045 0043 0135 0453 0454
2014	Holden	Captiva 5	Transmission Control Module	√	√	√	√	√	0017 0036

2014	Holden	Captiva 5	Chassis Control Module	√	√	√	√	√	0217 0095 0194
2014	Holden	Captiva 5	Rear Differential Clutch Control Module	√	√	√	√	√	0155
2014	Holden	Captiva 5	Mobile Telephone Control Module	√	√	√	√	√	0247 0065 0249 0246
2014	Holden	Captiva 5	Radio	√	√	√	√	√	0170 07B4 0247 0246 0065 0470 07B5
2014	Holden	Captiva 5	HVAC Control Module	√	√	√	√	√	
2014	Holden	Captiva 5	Headlamp Control Module	√	√	√	√	√	0195 0065
2014	Holden	Captiva 5	Auxiliary Body Control Module	√	√	√	√	√	0050
2014	Holden	Captiva 5	Remote Control Door Lock Receiver	√	√	√	√	√	0204 0239 0161 0162 0163 0164 0159 0160
2014	Holden	Captiva 5	Theft Deterrent Module	√	√	√	√	√	
2014	Holden	Captiva 5	Instrument Cluster	√	√	√	√	√	
2014	Holden	Captiva 5	Parking Brake Control Module	√	√	√	√	√	0229
2014	Holden	Captiva 5	Parking Assist Control Module	√	√	√	√	√	
2014	Holden	Captiva 5	Electronic Brake Control Module	√	√	√	√	√	0090
2014	Holden	Captiva 5	Variable Power Steering Control Module	√	√	√	√	√	
2014	Holden	Captiva 5	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0261
2014	Holden	Captiva 5	Info Display Module	√	√	√	√	√	0170 0467 0468 0247 0246 0065 0249 07B3
2014	Holden	Captiva 7	Engine Control Module	√	√	√	√	√	0156 0209 0098 0216 0224 0449 0130 0143 0450 0265 0147 0108 0452 0237 0044 0045 0086 0043 0135 0453 0454 0455 0456 0263 0132 0067 0217 0213 0006 0131 0258
2014	Holden	Captiva 7	Transmission Control Module	√	√	√	√	√	0017 0036
2014	Holden	Captiva 7	Chassis Control Module	√	√	√	√	√	0217 0095 0194
2014	Holden	Captiva 7	HVAC Control Module	√	√	√	√	√	
2014	Holden	Captiva 7	Auxiliary Body Control Module	√	√	√	√	√	0050
2014	Holden	Captiva 7	Rear Differential Clutch Control Module	√	√	√	√	√	0155
2014	Holden	Captiva 7	Body Control Module	√	√	√	√	√	0242 0263 0261
2014	Holden	Captiva 7	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0261
2014	Holden	Captiva 7	Remote Control Door Lock Receiver	√	√	√	√	√	0110 0160 0159 079B 0233 0204 0239 0161 0162 0163 0164
2014	Holden	Captiva 7	Theft Deterrent Module	√	√	√	√	√	
2014	Holden	Captiva 7	Headlamp Control Module	√	√	√	√	√	0195 0065
2014	Holden	Captiva 7	Instrument Cluster	√	√	√	√	√	
2014	Holden	Captiva 7	Electronic Brake Control Module	√	√	√	√	√	0090 0111
2014	Holden	Captiva 7	Variable Power Steering Control Module	√	√	√	√	√	
2014	Holden	Captiva 7	Parking Brake Control Module	√	√	√	√	√	0229

2014	Holden	Colorado	Transmission Control Module	√	√	√	√	√	0016
2014	Holden	Colorado	Transfer Case Control Module	√	√	√	√	√	0037
2014	Holden	Colorado	Instrument Cluster	√	√	√	√	√	0247
2014	Holden	Colorado	Trailer Interface Control Module	√	√	√	√	√	0247
2014	Holden	Colorado	Engine Control Module	√	√	√	√	√	0263 0210 0224 0130 0222 0060 0044 0045 0086 0097 0084 0043
2014	Holden	Colorado	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0134
2014	Holden	Colorado	Multi-Axis Acceleration Sensor Module	√	√	√			0112 0111
2014	Holden	Colorado	Steering Wheel Angle Sensor Module	√	√	√			0093 0090
2014	Holden	Colorado	Body Control Module	√	√	√	√	√	0199 0239 0161 0162 0163 0164 0165 0166 0167 0168 0242 0263 0203 0201 0208 0206 0093 0160 0222 0150
2014	Holden	Colorado	Electronic Brake Control Module	√	√	√	√	√	0090 0112
2014	Holden	Colorado	Radio	√	√	√	√	√	
2014	Holden	Colorado	Parking Assist Control Module	√	√	√	√	√	0247
2014	Holden	Colorado 7	Transfer Case Control Module	√	√	√	√	√	0037
2014	Holden	Colorado 7	Instrument Cluster	√	√	√	√	√	0247
2014	Holden	Colorado 7	Trailer Interface Control Module	√	√	√	√	√	0247
2014	Holden	Colorado 7	Engine Control Module	√	√	√	√	√	0263 0210 0224 0130 0222 0060 0044 0045 0086 0097 0084 0043
2014	Holden	Colorado 7	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0134
2014	Holden	Colorado 7	Multi-Axis Acceleration Sensor Module	√	√	√			0112 0111
2014	Holden	Colorado 7	Steering Wheel Angle Sensor Module	√	√	√			0093 0090
2014	Holden	Colorado 7	Body Control Module	√	√	√	√	√	0199 0239 0161 0162 0163 0164 0165 0166 0167 0168 0242 0263 0203 0201 0208 0206 0093 0160 0222 0150
2014	Holden	Colorado 7	Parking Assist Control Module	√	√	√	√	√	0247
2014	Holden	Colorado 7	Electronic Brake Control Module	√	√	√	√	√	0090 0112
2014	Holden	Colorado 7	Transmission Control Module	√	√	√	√	√	0016
2014	Holden	Colorado 7	Radio	√	√	√	√	√	
2014	Holden	Commodore	Transmission Control Module	√	√	√	√	√	0016
2014	Holden	Commodore	Chassis Control Module	√	√	√	√	√	0217 0095 0194
2014	Holden	Commodore	Steering Column Lock Control Module	√	√	√	√	√	
2014	Holden	Commodore	Parking Assist Control Module	√	√	√	√	√	0247
2014	Holden	Commodore	Trailer Interface Control Module	√	√	√	√	√	0247
2014	Holden	Commodore	Power Steering Control Module	√	√	√	√	√	0081
2014	Holden	Commodore	Electronic Brake Control Module	√	√	√	√	√	0225 0090 0111
2014	Holden	Commodore	Headlamp Control Module	√	√	√	√	√	0195

2014	Holden	Commodore	Fuel Injector Control Module	√			√	√	
2014	Holden	Commodore	Engine Control Module	√	√	√	√	√	0263 0156 0209 0132 0067 0086 0217 0258 0212 0006 0131
2014	Holden	Commodore	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0134 0111
2014	Holden	Commodore	Keyless Entry Control Module	√	√	√	√	√	
2014	Holden	Commodore	Instrument Cluster	√	√	√	√	√	0247 0145
2014	Holden	Commodore	Left Side Object Detection Control Module	√	√	√		√	
2014	Holden	Commodore	Right Side Object Detection Control Module	√	√	√		√	
2014	Holden	Commodore	Seat Memory Control Module - Driver	√	√	√	√	√	
2014	Holden	Commodore	HVAC Control Module	√	√	√	√	√	0007 0129
2014	Holden	Commodore	Radio	√	√	√	√	√	
2014	Holden	Commodore	Head-Up Display Module	√	√	√	√	√	
2014	Holden	Commodore	Liftgate Control Module	√	√	√	√	√	
2014	Holden	Commodore	Radio Controls	√	√	√	√	√	0247
2014	Holden	Commodore	Body Control Module	√	√	√	√	√	0199 0239 0161 0162 0163 0164 0165 0166 0167 0168 0242 0263 0203 0201 0208 0206 0000 0150 0000 0150
2014	Holden	Commodore	HVAC Controls	√	√	√	√	√	
2014	Holden	Commodore	Frontview Camera Module	√	√	√	√	√	0205 0049
2014	Holden	Commodore	Steering Wheel Angle Sensor Module	√	√	√			0093 0090
2014	Holden	Commodore	Suspension Control Module	√	√	√	√	√	0245
2014	Holden	Commodore	Parking Brake Control Module	√	√	√	√	√	0229
2014	Holden	Cruze	Chassis Control Module	√	√	√	√	√	0217 0095 0194
2014	Holden	Cruze	Front Seat Heating Control Module	√	√	√	√	√	
2014	Holden	Cruze	Parking Assist Control Module	√	√	√	√	√	0247
2014	Holden	Cruze	Body Control Module	√	√	√	√	√	0242 0263 0203 0201 0208 0206 0083 0160
2014	Holden	Cruze	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0134
2014	Holden	Cruze	Keyless Entry Control Module	√	√	√	√	√	
2014	Holden	Cruze	Transmission Control Module	√	√	√	√	√	0017 0036
2014	Holden	Cruze	Engine Control Module	√	√	√	√	√	0156 0209 0132 0067 0263 0086 0217 0139 0020 0066 076D 0213 0006 0144 0258 0098 0216 0224 0449 0130 0143 0450 0265 0147 0108 0452 0237 0044 0045 0043 0135 0453
2014	Holden	Cruze	Instrument Cluster	√	√	√	√	√	0247
2014	Holden	Cruze	Steering Column Lock Control Module	√	√	√	√	√	
2014	Holden	Cruze	Electronic Brake Control Module	√	√	√	√	√	0225 0090 0111

2014	Holden	Cruze	Power Steering Control Module	√	√	√	√		0081 0080 0089
2014	Holden	Cruze	Steering Wheel Angle Sensor Module	√	√	√			0093 0090
2014	Holden	Cruze	Multi-Axis Acceleration Sensor Module	√	√	√			0112 0111
2014	Holden	Cruze	Mobile Telephone Control Module	√	√	√	√	√	0247
2014	Holden	Cruze	Trailer Interface Control Module	√	√	√	√	√	0247
2014	Holden	Cruze	HVAC Control Module	√	√	√	√	√	0007 0129
2014	Holden	Cruze	Radio	√	√	√	√	√	
2014	Holden	Cruze	Multimedia Player Interface Module	√	√	√	√		0247
2014	Holden	Malibu	Suspension Control Module	√	√	√	√	√	
2014	Holden	Malibu	Engine Control Module	√	√	√	√	√	0263 0156 0209 0020 0132 0067 0066 076D 0086 0213 0217 0006 0144 0258 0139 0133 0210 0383 0098 0096 0094 0216 0130 0143 0265 0147 0237 0045 0393 0043 0135 0128
2014	Holden	Malibu	Electronic Brake Control Module	√	√	√	√	√	0225 0090 0111
2014	Holden	Malibu	Power Steering Control Module	√	√	√	√	√	0081 0080 0089
2014	Holden	Malibu	Transmission Control Module	√	√	√	√	√	0017 0036 0020 0084
2014	Holden	Malibu	Steering Column Lock Control Module	√	√	√	√		
2014	Holden	Malibu	Headlamp Control Module	√	√	√	√	√	0195
2014	Holden	Malibu	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0134
2014	Holden	Malibu	Keyless Entry Control Module	√	√	√	√	√	
2014	Holden	Malibu	Body Control Module	√	√	√	√	√	0199 0239 0161 0162 0163 0164 0165 0166 0167 0168 0242 0263 0203 0201 0208 0206 0202 0150 0232 0150
2014	Holden	Malibu	Instrument Cluster	√	√	√	√	√	0247
2014	Holden	Malibu	HVAC Control Module	√	√	√	√	√	0007 0129
2014	Holden	Malibu	Radio	√	√	√	√	√	
2014	Holden	Malibu	Multimedia Player Interface Module	√	√	√	√		0247
2014	Holden	Malibu	Parking Brake Control Module	√	√	√	√	√	0229
2014	Holden	Malibu	Front Seat Heating Control Module	√	√	√	√	√	
2014	Holden	Malibu	Parking Assist Control Module	√	√	√	√	√	0247
2014	Holden	Malibu	Rear Seat Heating Control Module	√	√	√	√	√	
2014	Holden	Malibu	Seat Memory Control Module	√	√	√	√	√	0310
2014	Holden	Malibu	Left Side Object Detection Control Module	√	√	√		√	
2014	Holden	Malibu	Mobile Telephone Control Module	√	√	√	√	√	0247
2014	Holden	Malibu	Multi-Axis Acceleration Sensor Module	√	√	√			0112 0111
2014	Holden	Malibu	Steering Wheel Angle Sensor Module	√	√	√			0093 0090
2014	Holden	Malibu	Frontview Camera Module	√	√	√	√	√	0205 0049
2014	Holden	Malibu	Trailer Interface Control Module	√	√	√	√	√	0247

2014	Holden	Trax	Transmission Control Module	√	√	√	√	√	0017 0036
2014	Holden	Trax	Instrument Cluster	√	√	√	√	√	0247
2014	Holden	Trax	Engine Control Module	√	√	√	√	√	0263 0156 0209 0020 0132 0067 0066 076D 0086 0213 0217 0006
2014	Holden	Trax	Body Control Module	√	√	√	√	√	0242 0263 0203 0201 0208 0206 0083 0160
2014	Holden	Trax	Steering Wheel Angle Sensor Module	√	√	√			0093 0090
2014	Holden	Trax	Rear Differential Clutch Control Module	√	√	√	√		0003 075B
2014	Holden	Trax	Electronic Brake Control Module	√	√	√	√	√	0090
2014	Holden	Trax	Power Steering Control Module	√	√	√	√		0207
2014	Holden	Trax	Radio	√	√	√	√	√	
2014	Holden	Trax	HVAC Control Module	√	√	√	√	√	
2014	Holden	Trax	Front Seat Heating Control Module	√	√	√	√	√	
2014	Holden	Trax	Parking Assist Control Module	√	√	√	√	√	0247
2014	Holden	Trax	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0134 0111
2014	Holden	Trax	Trailer Interface Control Module	√	√	√	√	√	0247
2014	Holden	Volt	Electric A/C Compressor Control Module	√					
2014	Holden	Volt	Battery Charger Control Module	√			√		
2014	Holden	Volt	Battery Energy Control Module	√			√		
2014	Holden	Volt	Coolant Heater Control Module	√	√	√			
2014	Holden	Volt	Hybrid Powertrain Control Module 2	√	√	√	√	√	0124 0125 0056 0218 0122 0123 0127
2014	Holden	Volt	Hybrid Powertrain Control Module	√	√	√	√	√	
2014	Holden	Volt	Drive Motor Control Module 1	√	√	√	√		
2014	Holden	Volt	Drive Motor Control Module 2	√	√	√	√		
2014	Holden	Volt	Auxiliary Transmission Fluid Pump	√	√	√	√		
2014	Holden	Volt	Transmission Control Module	√	√	√	√	√	
2014	Holden	Volt	Instrument Cluster	√	√	√	√	√	0247
2014	Holden	Volt	Telematics Communication Interface Control Module	√	√	√	√		
2014	Holden	Volt	Chassis Control Module	√	√	√	√	√	0217 0095 0194
2014	Holden	Volt	Engine Control Module	√	√	√	√	√	0209 0132 0067 0086 0217 0176
2014	Holden	Volt	Steering Column Lock Control Module	√	√	√	√		
2014	Holden	Volt	Body Control Module	√	√	√	√	√	0199 0239 0161 0162 0163 0164 0165 0166 0167 0168 0242 0263 0203 0201 0208 0206 0003 0156 0003 0156
2014	Holden	Volt	Keyless Entry Control Module	√	√	√	√	√	
2014	Holden	Volt	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0134 0111 0758
2014	Holden	Volt	Steering Wheel Angle Sensor Module	√	√	√			0093 0090
2014	Holden	Volt	Frontview Camera Module	√	√	√	√	√	0205 0049

2014	Holden	Volt	Power Steering Control Module	√	√	√	√		0081 0080 0089
2014	Holden	Volt	HVAC Control Module	√	√	√	√	√	0007 0129
2014	Holden	Volt	Radio	√	√	√	√	√	
2014	Holden	Volt	Front Seat Heating Control Module	√	√	√	√	√	
2014	Holden	Volt	Parking Assist Control Module	√	√	√	√	√	0247
2014	Holden	Volt	Electronic Brake Control Module	√	√	√	√	√	0263 0371 0111
2014	Holden	Volt	Parking Brake Control Module	√	√	√	√	√	0229
2013	Holden	Barina	Engine Control Module	√	√	√	√	√	0323 0305 0306 0067 0263 0308 0217
2013	Holden	Barina	Fuel Pump Control Module	√	√	√	√	√	0217
2013	Holden	Barina	Transmission Control Module	√	√	√	√	√	0017
2013	Holden	Barina	Electronic Brake Control Module	√	√	√	√	√	0090
2013	Holden	Barina	Instrument Cluster	√	√	√	√	√	0301
2013	Holden	Barina	Parking Assist Control Module	√	√	√	√	√	0301
2013	Holden	Barina	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172
2013	Holden	Barina	Body Control Module	√	√	√	√	√	0243 0263 0203 0201 0208 0206 0297 0298
2013	Holden	Barina	Power Steering Control Module	√	√	√	√		
2013	Holden	Barina	Steering Wheel Angle Sensor Module	√	√	√			
2013	Holden	Barina	Multi-Axis Acceleration Sensor Module	√	√	√			0111 0111
2013	Holden	Barina	Radio	√	√	√	√	√	
2013	Holden	Barina	HVAC Control Module	√	√	√	√	√	
2013	Holden	Barina	Front Seat Heating Control Module	√	√	√	√	√	
2013	Holden	Barina ark	Electronic Brake Control Module	√	√	√	√	√	0090
2013	Holden	Barina ark	Instrument Cluster	√	√	√	√	√	
2013	Holden	Barina ark	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172
2013	Holden	Barina ark	Body Control Module	√	√	√	√	√	0243 0263 0203 0201 0208 0206 0297 0298
2013	Holden	Barina ark	Multi-Axis Acceleration Sensor Module	√	√	√			0111 0111
2013	Holden	Barina ark	Engine Control Module	√	√	√	√	√	0323 0305 0306 0067 0263 0308 0217
2013	Holden	Barina ark	Transmission Control Module	√	√	√	√	√	0016
2013	Holden	Barina ark	Power Steering Control Module	√	√	√	√		
2013	Holden	Barina ark	Steering Wheel Angle Sensor Module	√	√	√			
2013	Holden	Barina ark	Radio	√	√	√	√	√	
2013	Holden	Captiva 5	Transmission Control Module	√	√	√	√	√	0017
2013	Holden	Captiva 5	Rear Differential Clutch Control Module	√	√	√	√	√	0155
2013	Holden	Captiva 5	Instrument Cluster	√	√	√	√	√	
2013	Holden	Captiva 5	HVAC Control Module	√	√	√			
2013	Holden	Captiva 5	Engine Control Module	√	√	√	√	√	0263 0323 0305 0306 0067 0308 0217 0309
2013	Holden	Captiva 5	Electronic Brake Control Module	√	√	√	√	√	0090

2013	Holden	Captiva 5	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0332
2013	Holden	Captiva 5	Info Dilay Module	√	√	√	√	√	0170 0170 0170 0170 0467 0468 0301 0301 0246 0246 0246 0246
2013	Holden	Captiva 5	Radio	√	√	√	√	√	0170 0170 0170 0170 0065 0065 0065 0065
2013	Holden	Captiva 5	Body Control Module	√	√	√	√	√	0243 0263
2013	Holden	Captiva 5	Mobile Telephone Control Module	√	√	√	√	√	
2013	Holden	Captiva 5	Headlamp Control Module	√	√	√	√	√	0195 0065
2013	Holden	Captiva 5	Auxiliary Body Control Module	√	√	√	√	√	0050
2013	Holden	Captiva 5	Remote Control Door Lock Receiver	√	√	√	√	√	0204 0239 0161 0162 0163 0164 0159 0298
2013	Holden	Captiva 5	Theft Deterrent Module	√	√	√	√	√	
2013	Holden	Captiva 5	Parking Brake Control Module	√	√	√	√	√	0316
2013	Holden	Captiva 5	Parking Assist Control Module	√	√	√	√	√	
2013	Holden	Captiva 5	Fuel Pump Control Module	√	√	√	√	√	0217
2013	Holden	Captiva 7	Transmission Control Module	√	√	√	√	√	0017
2013	Holden	Captiva 7	Rear Differential Clutch Control Module	√	√	√	√	√	0155
2013	Holden	Captiva 7	Instrument Cluster	√	√	√	√	√	
2013	Holden	Captiva 7	Auxiliary Body Control Module	√	√	√	√	√	0050
2013	Holden	Captiva 7	Remote Control Door Lock Receiver	√	√	√	√	√	0204 0239 0161 0162 0163 0164 0159 0298
2013	Holden	Captiva 7	Body Control Module	√	√	√	√	√	0243 0263 0332
2013	Holden	Captiva 7	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0172 0332
2013	Holden	Captiva 7	Theft Deterrent Module	√	√	√	√	√	
2013	Holden	Captiva 7	Engine Control Module	√	√	√	√	√	0323 0305 0098 0387 0224 0449 0130 0143 0450 0265 0147 0108 0452 0391 0401 0392 0308 0394 0135 0453 0454 0455 0456
2013	Holden	Captiva 7	Electronic Brake Control Module	√	√	√	√	√	0090 0111
2013	Holden	Captiva 7	HVAC Control Module	√	√	√	√	√	
2013	Holden	Captiva 7	Mobile Telephone Control Module	√	√	√	√	√	0301
2013	Holden	Captiva 7	Fuel Pump Control Module	√	√	√	√	√	0217
2013	Holden	Captiva 7	Headlamp Control Module	√	√	√	√	√	0195 0065
2013	Holden	Captiva 7	Parking Brake Control Module	√	√	√	√	√	0316
2013	Holden	Colorado	Engine Control Module	√	√	√	√	√	0305 0306 0067 0323 0263 0308 0217 0309
2013	Holden	Colorado	Transmission Control Module	√	√	√	√	√	0016
2013	Holden	Colorado	Transfer Case Control Module	√	√	√	√	√	0037
2013	Holden	Colorado	Electronic Brake Control Module	√	√	√	√	√	0090 0112
2013	Holden	Colorado	Multi-Axis Acceleration Sensor Module	√	√	√	√	√	0111 0111

2013	Holden	Colorado	Steering Wheel Angle Sensor Module	√	√	√			
2013	Holden	Colorado	Body Control Module	√	√	√	√	√	0243 0263 0203 0201 0208 0206 0297 0298
2013	Holden	Colorado	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0172
2013	Holden	Colorado	Instrument Cluster	√	√	√	√	√	0301
2013	Holden	Colorado	Trailer Interface Control Module	√	√	√	√	√	0301
2013	Holden	Colorado	Telematic Vehicle Localization and Immobilization Control Module	√	√	√	√	√	
2013	Holden	Colorado 7	Transmission Control Module	√	√	√	√	√	0016
2013	Holden	Colorado 7	Transfer Case Control Module	√	√	√	√	√	0037
2013	Holden	Colorado 7	Body Control Module	√	√	√	√	√	0243 0263 0203 0201 0208 0206 0297 0298
2013	Holden	Colorado 7	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0172
2013	Holden	Colorado 7	Electronic Brake Control Module	√	√	√	√	√	0090 0112
2013	Holden	Colorado 7	Engine Control Module	√	√	√	√	√	0484 0387
2013	Holden	Colorado 7	Multi-Axis Acceleration Sensor Module	√	√	√			0111 0111
2013	Holden	Colorado 7	Steering Wheel Angle Sensor Module	√	√	√			
2013	Holden	Colorado 7	Instrument Cluster	√	√	√	√	√	0301
2013	Holden	Colorado 7	Trailer Interface Control Module	√	√	√	√	√	0301
2013	Holden	Colorado 7	Parking Assist Control Module	√	√	√	√	√	0301
2013	Holden	Cruze	Engine Control Module	√	√	√	√	√	0263 0323 0305 0020 0306 0067 0217 0337
2013	Holden	Cruze	Transmission Control Module	√	√	√	√	√	0017
2013	Holden	Cruze	Electronic Brake Control Module	√	√	√	√	√	0225 0090 0111
2013	Holden	Cruze	Multi-Axis Acceleration Sensor Module	√	√	√			0111 0111
2013	Holden	Cruze	Power Steering Control Module	√	√	√	√		0081 0081 0080 0080
2013	Holden	Cruze	Steering Wheel Angle Sensor Module	√	√	√			
2013	Holden	Cruze	Body Control Module	√	√	√	√	√	0243 0263 0203 0201 0208 0206 0297 0298
2013	Holden	Cruze	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0172
2013	Holden	Cruze	Instrument Cluster	√	√	√	√	√	0301
2013	Holden	Cruze	Trailer Interface Control Module	√	√	√	√	√	0301
2013	Holden	Cruze	Radio	√	√	√	√	√	
2013	Holden	Cruze	Multimedia Player Interface Module	√	√	√	√		
2013	Holden	Cruze	Mobile Telephone Control Module	√	√	√	√	√	0301 0301
2013	Holden	Cruze	HVAC Control Module	√	√	√	√	√	0311 0129
2013	Holden	Cruze	Front Seat Heating Control Module	√	√	√	√	√	
2013	Holden	Cruze	Keyless Entry Control Module	√	√	√	√	√	
2013	Holden	Cruze	Parking Assist Control Module	√	√	√	√	√	
2013	Holden	Cruze	Steering Column Lock Control Module	√	√	√	√		
2013	Holden	Cruze	Telematic Vehicle Localization and Immobilization Control Module	√	√	√	√	√	

2013	Holden	Malibu	Transmission Control Module	√	√	√	√	√	0017
2013	Holden	Malibu	Body Control Module	√	√	√	√	√	0243 0263 0203 0201 0208 0206 0297 0298
2013	Holden	Malibu	Instrument Cluster	√	√	√	√	√	0301
2013	Holden	Malibu	Seat Memory Control Module	√	√	√	√	√	0310
2013	Holden	Malibu	Front Seat Heating Control Module	√	√	√	√	√	
2013	Holden	Malibu	Rear Seat Heating Control Module	√	√	√	√	√	
2013	Holden	Malibu	Parking Assist Control Module	√	√	√	√	√	0301
2013	Holden	Malibu	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0172
2013	Holden	Malibu	Keyless Entry Control Module	√	√	√	√	√	
2013	Holden	Malibu	HVAC Control Module	√	√	√	√	√	0311 0129
2013	Holden	Malibu	Engine Control Module	√	√	√	√	√	0133 0133 0323 0382 0382 0383 0098 0098 0096 0096 0094 0094 0387 0387 0130 0143 0265 0265 0147 0147 0391 0391 0392 0308 0393 0393 0394 0135 0128 0173 0173
2013	Holden	Malibu	Telematic Vehicle Localization and Immobilization Control Module	√	√	√	√	√	
2013	Holden	Malibu	Steering Column Lock Control Module	√	√	√	√		
2013	Holden	Malibu	Electronic Brake Control Module	√	√	√	√	√	0225 0090 0111 0111
2013	Holden	Malibu	Power Steering Control Module	√	√	√	√		0081 0081 0080 0080
2013	Holden	Malibu	Steering Wheel Angle Sensor Module	√	√	√			
2013	Holden	Malibu	Frontview Camera Module	√	√	√	√	√	0205 0447
2013	Holden	Malibu	Multi-Axis Acceleration Sensor Module	√	√	√			0111 0111
2013	Holden	Malibu	Headlamp Control Module	√	√	√	√	√	0195
2013	Holden	Malibu	Mobile Telephone Control Module	√	√	√	√	√	0301 0301
2013	Holden	Malibu	Suension Control Module	√	√	√	√	√	
2013	Holden	Volt	Engine Control Module	√	√	√	√	√	0305 0306 0067 0308 0217 0176
2013	Holden	Volt	Fuel Pump Control Module	√	√	√	√	√	0217
2013	Holden	Volt	Hybrid Powertrain Control Module	√	√	√	√	√	
2013	Holden	Volt	Transmission Control Module	√	√	√	√	√	
2013	Holden	Volt	Drive Motor Control Module 1	√	√	√	√		
2013	Holden	Volt	Drive Motor Control Module 2	√	√	√	√		
2013	Holden	Volt	Auxiliary Transmission Fluid Pump	√	√	√	√		
2013	Holden	Volt	Multi-Axis Acceleration Sensor Module	√	√	√			
2013	Holden	Volt	Power Steering Control Module	√	√	√	√		0081 0081 0080 0080
2013	Holden	Volt	Steering Wheel Angle Sensor Module	√	√	√			
2013	Holden	Volt	Instrument Cluster	√	√	√	√	√	0301
2013	Holden	Volt	Telematics Communication Interface Control Module	√	√	√	√		

2013	Holden	Volt	Mobile Telephone Control Module	√	√	√	√	√	0301 0301
2013	Holden	Volt	Electric A/C Compressor Control Module	√					
2013	Holden	Volt	Coolant Heater Control Module	√	√	√			
2013	Holden	Volt	Steering Column Lock Control Module	√	√	√	√		
2013	Holden	Volt	Battery Charger Control Module	√			√		
2013	Holden	Volt	Hybrid Powertrain Control Module 2	√	√	√	√	√	0362 0363 0364 0365 0366 0367 0368
2013	Holden	Volt	Battery Energy Control Module	√			√		
2013	Holden	Volt	Keyless Entry Control Module	√	√	√	√	√	
2013	Holden	Volt	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0172
2013	Holden	Volt	HVAC Control Module	√	√	√	√	√	0311 0129
2013	Holden	Volt	Body Control Module	√	√	√	√	√	0243 0263 0203 0201 0208 0206 0297 0298
2013	Holden	Volt	Parking Assist Control Module	√	√	√	√	√	0301
2013	Holden	Volt	Front Seat Heating Control Module	√	√	√	√	√	
2013	Holden	Volt	Radio	√	√	√	√	√	
2013	Holden	Volt	Frontview Camera Module	√	√	√	√	√	0205 0196
2013	Holden	Volt	Electronic Brake Control Module	√	√	√	√	√	0371 0111 0111 0111
2012	Holden	Barina	Engine Control Module	√	√	√	√	√	0323 0305
2012	Holden	Barina	Fuel Injector Control Module	√			√	√	
2012	Holden	Barina	Fuel Pump Control Module	√	√	√	√	√	0217
2012	Holden	Barina	Transmission Control Module	√	√	√	√	√	0017
2012	Holden	Barina	Electronic Brake Control Module	√	√	√	√	√	0090
2012	Holden	Barina	Multi-Axis Acceleration Sensor Module	√	√	√			0111 0111
2012	Holden	Barina	Electric Power Steering Control Module	√	√	√	√		
2012	Holden	Barina	Steering Wheel Angle Sensor Module	√	√	√			
2012	Holden	Barina	Body Control Module	√	√	√	√	√	0243 0263 0203 0201 0208 0206 0297 0298
2012	Holden	Barina	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172
2012	Holden	Barina	Passenger Presence Module	√	√	√	√		0322
2012	Holden	Barina	Instrument Cluster	√	√	√	√	√	0301
2012	Holden	Barina	Radio	√	√	√	√	√	
2012	Holden	Barina	Telematic Vehicle Localization and Immobilization Control Module	√	√	√	√	√	
2012	Holden	Barina	Telematics Communication Interface Control Module	√	√	√	√	√	0465 0259
2012	Holden	Barina	Front Seat Heating Control Module	√	√	√	√	√	
2012	Holden	Barina	Parking Assist Control Module	√	√	√	√	√	0301

2012	Holden	Barina ark	Engine Control Module	√	√	√	√	√	0133 0133 0323 0383 0096 0096 0130 0143 0265 0265 0147 0147 0098 0098 0387 0387 0382 0382 0391 0391 0094 0094 0392 0308 0393 0393 0394 0394 0135 0128 0173 0173
2012	Holden	Barina ark	Fuel Injector Control Module	√	√	√	√	√	
2012	Holden	Barina ark	Transmission Control Module	√	√	√	√	√	
2012	Holden	Barina ark	Electronic Brake Control Module	√	√	√	√	√	0090
2012	Holden	Barina ark	Multi-Axis Acceleration Sensor Module	√	√	√			0111 0111
2012	Holden	Barina ark	Electric Power Steering Control Module	√	√	√	√		
2012	Holden	Barina ark	Steering Wheel Angle Sensor Module	√	√	√			0093 0093 0090 0090
2012	Holden	Barina ark	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	
2012	Holden	Barina ark	Passenger Presence Module	√	√	√	√	√	0322
2012	Holden	Barina ark	Instrument Cluster	√	√	√	√	√	
2012	Holden	Captiva 5	Engine Control Module	√	√	√	√	√	0263 0323 0305 0306 0067 0308 0217 0309
2012	Holden	Captiva 5	Fuel Pump Control Module	√	√	√	√	√	0217
2012	Holden	Captiva 5	Transmission Control Module	√	√	√	√	√	0248
2012	Holden	Captiva 5	Rear Differential Clutch Control Module	√	√	√	√	√	0155
2012	Holden	Captiva 5	Electronic Brake Control Module	√	√	√	√	√	0090
2012	Holden	Captiva 5	Parking Brake Control Module	√	√	√	√	√	0316
2012	Holden	Captiva 5	Body Control Module	√	√	√	√	√	0243 0263
2012	Holden	Captiva 5	Auxiliary Body Control Module	√	√	√	√	√	0050
2012	Holden	Captiva 5	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0332
2012	Holden	Captiva 5	Headlamp Control Module	√	√	√	√	√	0195 0065
2012	Holden	Captiva 5	Radio	√	√	√	√	√	0170 0170 0170 0170 0065 0065 0065 0065
2012	Holden	Captiva 5	Mobile Telephone Control Module	√	√	√		√	
2012	Holden	Captiva 5	HVAC Control Module	√	√	√		√	
2012	Holden	Captiva 5	Info Dilay Module	√	√	√	√	√	0170 0170 0170 0170 0467 0468 0301 0301 0246 0246 0246 0246
2012	Holden	Captiva 5	Remote Control Door Lock Receiver	√	√	√	√	√	0204 0239 0161 0162 0163 0164 0159 0298
2012	Holden	Captiva 5	Parking Assist Control Module	√	√	√	√	√	
2012	Holden	Captiva 5	Theft Deterrent Module	√	√	√	√	√	
2012	Holden	Captiva 5	Instrument Cluster	√	√	√	√	√	
2012	Holden	Captiva 7	Engine Control Module	√	√	√	√	√	0263 0305 0306 0067 0323 0308 0217 0337
2012	Holden	Captiva 7	Fuel Pump Control Module	√	√	√	√	√	0217

2012	Holden	Captiva 7	Transmission Control Module	√	√	√	√	√	0017
2012	Holden	Captiva 7	Rear Differential Clutch Control Module	√	√	√	√	√	0155
2012	Holden	Captiva 7	Electronic Brake Control Module	√	√	√	√	√	0090 0111
2012	Holden	Captiva 7	Parking Brake Control Module	√	√	√	√	√	0316
2012	Holden	Captiva 7	Body Control Module	√	√	√	√	√	0243 0263 0332
2012	Holden	Captiva 7	Auxiliary Body Control Module	√	√	√	√	√	0050
2012	Holden	Captiva 7	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0172 0332
2012	Holden	Captiva 7	Instrument Cluster	√	√	√	√	√	
2012	Holden	Captiva 7	Headlamp Control Module	√	√	√	√	√	0195 0065
2012	Holden	Captiva 7	Radio	√	√	√	√	√	0170 0492 0468 0467
2012	Holden	Captiva 7	Mobile Telephone Control Module	√	√	√	√	√	0301
2012	Holden	Captiva 7	HVAC Control Module	√	√	√		√	
2012	Holden	Captiva 7	Info Dilay Module	√	√	√			
2012	Holden	Captiva 7	Remote Control Door Lock Receiver	√	√	√	√	√	0204 0239 0161 0162 0163 0164 0159 0298
2012	Holden	Captiva 7	Parking Assist Control Module	√	√	√	√	√	
2012	Holden	Captiva 7	Theft Deterrent Module	√	√	√	√		
2012	Holden	Colorado	Engine Control Module	√	√	√	√	√	0484 0387
2012	Holden	Colorado	Transmission Control Module	√	√	√	√	√	0016
2012	Holden	Colorado	Transfer Case Control Module	√	√	√	√	√	0037
2012	Holden	Colorado	Electronic Brake Control Module	√	√	√	√	√	0090
2012	Holden	Colorado	Multi-Axis Acceleration Sensor Module	√	√	√			0112 0112 0111 0111
2012	Holden	Colorado	Steering Wheel Angle Sensor Module	√	√	√			
2012	Holden	Colorado	Body Control Module	√	√	√	√	√	0243 0263 0203 0201 0208 0206 0297 0298
2012	Holden	Colorado	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0172
2012	Holden	Colorado	Instrument Cluster	√	√	√	√	√	
2012	Holden	Colorado	Trailer Interface Control Module	√	√	√	√	√	
2012	Holden	Colorado	Telematic Vehicle Localization and Immobilization Control Module	√	√	√	√	√	
2012	Holden	Cruze	Engine Control Module	√	√	√	√	√	0308 0217
2012	Holden	Cruze	Fuel Pump Control Module	√	√	√	√	√	0217
2012	Holden	Cruze	Transmission Control Module	√	√	√	√	√	0017
2012	Holden	Cruze	Electronic Brake Control Module	√	√	√	√	√	0225 0090 0111
2012	Holden	Cruze	Multi-Axis Acceleration Sensor Module	√	√	√			0111 0111
2012	Holden	Cruze	Power Steering Control Module	√	√	√	√		0081 0081 0080 0080
2012	Holden	Cruze	Steering Wheel Angle Sensor Module	√	√	√			0093 0093 0090 0090
2012	Holden	Cruze	Body Control Module	√	√	√	√	√	0263 0203 0201 0208 0206 0297 0298 0159
2012	Holden	Cruze	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0172
2012	Holden	Cruze	Passenger Presence Module	√	√	√	√		0322
2012	Holden	Cruze	Instrument Cluster	√	√	√	√	√	0301

2012	Holden	Cruze	Trailer Interface Control Module	√	√	√	√	√	0301
2012	Holden	Cruze	Radio	√	√	√	√	√	
2012	Holden	Cruze	Multimedia Player Interface Module	√	√	√	√	√	
2012	Holden	Cruze	Mobile Telephone Control Module	√	√	√	√	√	0301 0301
2012	Holden	Cruze	Telematics Communication Interface Control Module	√	√	√	√	√	0465 0259
2012	Holden	Cruze	Remote Heater and Air Conditioning Control Module	√	√	√	√	√	0311 0129
2012	Holden	Cruze	Front Seat Heating Control Module	√	√	√	√	√	
2012	Holden	Cruze	Keyless Entry Control Module	√	√	√	√	√	
2012	Holden	Cruze	Parking Assist Control Module	√	√	√	√	√	
2012	Holden	Cruze	Steering Column Lock Control Module	√	√	√	√	√	
2012	Holden	Others	Supplemental inflatable restraint	√	√	√	√	√	
2012	Holden	Others	Immobilizer						0508
2012	Holden	Others	Electronic Brake Control Module	√	√	√	√	√	0506
2012	Holden	Others	Power steering control module	√	√	√	√	√	
2012	Holden	Others	Tire pressure monitor	√	√	√	√	√	0510 0511
2012	Holden	Others	Engine Control Module		√	√	√	√	0493
2012	Holden	Others	Transmission control module	√	√	√	√	√	
2011	Holden	Barina ark	Engine Control Module	√	√	√	√	√	0133 0133 0323 0383 0096 0096 0130 0143 0265 0265 0147 0147 0098 0098 0387 0387 0382 0382 0391 0391 0094 0094 0392 0308 0393 0393 0394 0394 0135 0128 0173 0173
2011	Holden	Barina ark	Fuel Injector Control Module	√	√	√	√	√	
2011	Holden	Barina ark	Transmission Control Module	√	√	√	√	√	
2011	Holden	Barina ark	Electronic Brake Control Module	√	√	√	√	√	0090
2011	Holden	Barina ark	Multi-Axis Acceleration Sensor Module	√	√	√			0111 0111
2011	Holden	Barina ark	Electric Power Steering Control Module	√	√	√	√		
2011	Holden	Barina ark	Steering Wheel Angle Sensor Module	√	√	√			0093 0093 0090 0090
2011	Holden	Barina ark	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	
2011	Holden	Barina ark	Passenger Presence Module	√	√	√	√	√	0322
2011	Holden	Barina ark	Instrument Cluster	√	√	√	√	√	
2011	Holden	Captiva 5	Engine Control Module	√	√	√	√	√	0263 0305 0306 0067 0323 0308 0217 0337
2011	Holden	Captiva 5	Fuel Pump Control Module	√	√	√	√	√	0217
2011	Holden	Captiva 5	Transmission Control Module	√	√	√	√	√	0017
2011	Holden	Captiva 5	Rear Differential Clutch Control Module	√	√	√	√	√	0155
2011	Holden	Captiva 5	Electronic Brake Control Module	√	√	√	√	√	0090 0111
2011	Holden	Captiva 5	Parking Brake Control Module	√	√	√	√	√	0316
2011	Holden	Captiva 5	Body Control Module	√	√	√	√	√	0243 0263 0332
2011	Holden	Captiva 5	Auxiliary Body Control Module	√	√	√	√	√	0050

2011	Holden	Captiva 5	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0172 0332
2011	Holden	Captiva 5	Instrument Cluster	√	√	√	√	√	
2011	Holden	Captiva 5	Headlamp Control Module	√	√	√	√	√	0195 0065
2011	Holden	Captiva 5	Radio	√	√	√	√	√	0170 0492 0468 0467
2011	Holden	Captiva 5	Mobile Telephone Control Module	√	√	√	√	√	0301
2011	Holden	Captiva 5	HVAC Control Module	√	√	√		√	
2011	Holden	Captiva 5	Info Dilay Module	√	√	√			
2011	Holden	Captiva 5	Remote Control Door Lock Receiver	√	√	√	√	√	0204 0239 0161 0162 0163 0164 0159 0298
2011	Holden	Captiva 5	Parking Assist Control Module	√	√	√	√	√	
2011	Holden	Captiva 5	Theft Deterrent Module	√	√	√	√		
2011	Holden	Captiva 7	Engine Control Module	√	√	√	√	√	0263 0305 0306 0067 0323 0308 0217 0337
2011	Holden	Captiva 7	Fuel Pump Control Module	√	√	√	√	√	0217
2011	Holden	Captiva 7	Transmission Control Module	√	√	√	√	√	0017
2011	Holden	Captiva 7	Rear Differential Clutch Control Module	√	√	√	√	√	0155
2011	Holden	Captiva 7	Electronic Brake Control Module	√	√	√	√	√	0090 0111
2011	Holden	Captiva 7	Parking Brake Control Module	√	√	√	√	√	0316
2011	Holden	Captiva 7	Body Control Module	√	√	√	√	√	0243 0263 0332
2011	Holden	Captiva 7	Auxiliary Body Control Module	√	√	√	√	√	0050
2011	Holden	Captiva 7	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0172 0332
2011	Holden	Captiva 7	Instrument Cluster	√	√	√	√	√	
2011	Holden	Captiva 7	Headlamp Control Module	√	√	√	√	√	0195 0065
2011	Holden	Captiva 7	Radio	√	√	√	√	√	0170 0492 0468 0467
2011	Holden	Captiva 7	Mobile Telephone Control Module	√	√	√	√	√	0301
2011	Holden	Captiva 7	HVAC Control Module	√	√	√		√	
2011	Holden	Captiva 7	Info Dilay Module	√	√	√			
2011	Holden	Captiva 7	Remote Control Door Lock Receiver	√	√	√	√	√	0204 0239 0161 0162 0163 0164 0159 0298
2011	Holden	Captiva 7	Parking Assist Control Module	√	√	√	√	√	
2011	Holden	Captiva 7	Theft Deterrent Module	√	√	√	√		
2011	Holden	Cruze	Engine Control Module	√	√	√	√	√	0308 0217
2011	Holden	Cruze	Fuel Pump Control Module	√	√	√	√	√	0217
2011	Holden	Cruze	Transmission Control Module	√	√	√	√	√	0017
2011	Holden	Cruze	Electronic Brake Control Module	√	√	√	√	√	0225 0090 0111
2011	Holden	Cruze	Multi-Axis Acceleration Sensor Module	√	√	√			0111 0111
2011	Holden	Cruze	Power Steering Control Module	√	√	√	√		0081 0081 0080 0080
2011	Holden	Cruze	Steering Wheel Angle Sensor Module	√	√	√			0093 0093 0090 0090
2011	Holden	Cruze	Body Control Module	√	√	√	√	√	0263 0203 0201 0208 0206 0297 0298 0159
2011	Holden	Cruze	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0172
2011	Holden	Cruze	Passenger Presence Module	√	√	√	√		0322

2011	Holden	Cruze	Instrument Cluster	√	√	√	√	√	0301
2011	Holden	Cruze	Trailer Interface Control Module	√	√	√	√	√	0301
2011	Holden	Cruze	Radio	√	√	√	√	√	
2011	Holden	Cruze	Multimedia Player Interface Module	√	√	√	√	√	
2011	Holden	Cruze	Mobile Telephone Control Module	√	√	√	√	√	0301 0301
2011	Holden	Cruze	Telematics Communication Interface Control Module	√	√	√	√	√	0465 0259
2011	Holden	Cruze	Remote Heater and Air Conditioning Control Module	√	√	√	√	√	0311 0129
2011	Holden	Cruze	Front Seat Heating Control Module	√	√	√	√	√	
2011	Holden	Cruze	Keyless Entry Control Module	√	√	√	√	√	
2011	Holden	Cruze	Parking Assist Control Module	√	√	√	√	√	
2011	Holden	Cruze	Steering Column Lock Control Module	√	√	√	√	√	
2011	Holden	Others	Engine Control Module	√	√	√	√	√	
2011	Holden	Others	Transmission control module	√	√	√	√	√	0493
2011	Holden	Others	Supplemental inflatable restraint	√	√	√	√	√	
2011	Holden	Others	ISU	√	√	√	√	√	0493
2011	Holden	Others	Immobilizer	√	√	√	√	√	0508
2011	Holden	Others	Electronic Brake Control Module	√	√	√	√	√	0493
2011	Holden	Others	Tire pressure monitor	√	√	√	√	√	0510 0511
2010	Holden	Barina ark	Engine Control Module	√	√	√	√	√	0133 0133 0323 0383 0096 0096 0130 0143 0265 0265 0147 0147 0098 0098 0387 0387 0382 0382 0391 0391 0094 0094 0392 0308 0393 0393 0394 0394 0135 0128 0173 0173
2010	Holden	Barina ark	Fuel Injector Control Module	√	√	√	√	√	
2010	Holden	Barina ark	Transmission Control Module	√	√	√	√	√	
2010	Holden	Barina ark	Electronic Brake Control Module	√	√	√	√	√	0090
2010	Holden	Barina ark	Multi-Axis Acceleration Sensor Module	√	√	√	√	√	0111 0111
2010	Holden	Barina ark	Electric Power Steering Control Module	√	√	√	√	√	
2010	Holden	Barina ark	Steering Wheel Angle Sensor Module	√	√	√	√	√	0093 0093 0090 0090
2010	Holden	Barina ark	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	
2010	Holden	Barina ark	Passenger Presence Module	√	√	√	√	√	0322
2010	Holden	Barina ark	Instrument Cluster	√	√	√	√	√	
2010	Holden	Cruze	Engine Control Module	√	√	√	√	√	0308 0217
2010	Holden	Cruze	Fuel Pump Control Module	√	√	√	√	√	0217
2010	Holden	Cruze	Transmission Control Module	√	√	√	√	√	0017
2010	Holden	Cruze	Electronic Brake Control Module	√	√	√	√	√	0225 0090 0111
2010	Holden	Cruze	Multi-Axis Acceleration Sensor Module	√	√	√	√	√	0111 0111
2010	Holden	Cruze	Power Steering Control Module	√	√	√	√	√	0081 0081 0080 0080
2010	Holden	Cruze	Steering Wheel Angle Sensor Module	√	√	√	√	√	0093 0093 0090 0090

2010	Holden	Cruze	Body Control Module	√	√	√	√	√	0263 0203 0201 0208 0206 0297 0298 0159
2010	Holden	Cruze	Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	0172 0172
2010	Holden	Cruze	Passenger Presence Module	√	√	√	√	√	0322
2010	Holden	Cruze	Instrument Cluster	√	√	√	√	√	0301
2010	Holden	Cruze	Trailer Interface Control Module	√	√	√	√	√	0301
2010	Holden	Cruze	Radio	√	√	√	√	√	
2010	Holden	Cruze	Multimedia Player Interface Module	√	√	√	√	√	
2010	Holden	Cruze	Mobile Telephone Control Module	√	√	√	√	√	0301 0301
2010	Holden	Cruze	Telematics Communication Interface Control Module	√	√	√	√	√	0465 0259
2010	Holden	Cruze	Remote Heater and Air Conditioning Control Module	√	√	√	√	√	0311 0129
2010	Holden	Cruze	Front Seat Heating Control Module	√	√	√	√	√	
2010	Holden	Cruze	Keyless Entry Control Module	√	√	√	√	√	
2010	Holden	Cruze	Parking Assist Control Module	√	√	√	√	√	
2010	Holden	Cruze	Steering Column Lock Control Module	√	√	√	√	√	
2010	Holden	Others	Engine Control Module	√	√	√	√	√	0509
2010	Holden	Others	Transmission control module	√	√	√	√	√	0509
2010	Holden	Others	Supplemental inflatable restraint	√	√	√	√	√	
2010	Holden	Others	ISU	√	√	√	√	√	
2010	Holden	Others	Electronic Brake Control Module	√	√	√	√	√	0493
2010	Holden	Others	Immobilizer						0508
2010	Holden	Others	Tire pressure monitor	√	√	√	√	√	0510 0511
2010	Holden	Captiva	Engine Control Module	√	√	√	√	√	0509
2010	Holden	Captiva	Transmission control module	√	√	√	√	√	0509
2010	Holden	Captiva	Rear drive system	√	√	√	√	√	0530
2010	Holden	Captiva	Remote control door lock receiver	√	√	√	√	√	0513 0159
2010	Holden	Captiva	Body Control Module	√	√	√	√	√	0497
2010	Holden	Captiva	Body Control Module	√	√	√	√	√	
2010	Holden	Captiva	Theft Deterrent Module	√	√	√	√	√	
2010	Holden	Captiva	Instrument panel cluster	√	√	√	√	√	
2010	Holden	Captiva	Supplemental inflatable restraint	√	√	√	√	√	0497
2010	Holden	Captiva	HVAC Control Module	√	√	√	√	√	
2010	Holden	Captiva	Electronic Brake Control Module	√	√	√	√	√	
2010	Holden	Captiva Maxx	Engine Control Module	√	√	√	√	√	0509
2010	Holden	Captiva Maxx	Rear drive system	√	√	√	√	√	0530
2010	Holden	Captiva Maxx	Transmission control module	√	√	√	√	√	0530
2010	Holden	Captiva Maxx	Park assist module	√	√	√	√	√	
2010	Holden	Captiva Maxx	Supplemental inflatable restraint	√	√	√	√	√	0497
2010	Holden	Captiva Maxx	Remote control door lock receiver	√	√	√	√	√	0513 0159
2010	Holden	Captiva Maxx	Body Control Module	√	√	√	√	√	0497
2010	Holden	Captiva Maxx	Body Control Module	√	√	√	√	√	

2010	Holden	Captiva Maxx	Headlamp Control Module	√	√	√	√	√	
2010	Holden	Captiva Maxx	Instrument panel cluster	√	√	√	√	√	
2010	Holden	Captiva Maxx	Front dilay interface module	√	√	√			
2010	Holden	Captiva Maxx	Radio	√	√	√	√	√	
2010	Holden	Captiva Maxx	HVAC Control Module	√	√	√		√	
2010	Holden	Captiva Maxx	Theft Deterrent Module	√	√	√	√	√	0497
2010	Holden	Captiva Maxx	Electronic Brake Control Module	√	√	√	√	√	
2009	Holden	Captiva	Engine Control Module	√	√	√	√	√	0562
2009	Holden	Captiva	Transmission control module	√	√	√	√	√	0562
2009	Holden	Captiva	Rear drive system	√	√	√	√	√	0530
2009	Holden	Captiva	HVAC Control Module	√	√	√		√	
2009	Holden	Captiva	Instrument panel cluster	√	√	√	√	√	
2009	Holden	Captiva	Body Control Module	√	√	√	√	√	0497
2009	Holden	Captiva	Body Control Module	√	√	√	√	√	
2009	Holden	Captiva	Remote control door lock receiver	√	√	√	√	√	0513 0159
2009	Holden	Captiva	Supplemental inflatable restraint	√	√	√	√	√	0497
2009	Holden	Captiva	Theft Deterrent Module	√	√	√	√	√	0497
2009	Holden	Captiva	Electronic Brake Control Module	√	√	√	√	√	
2009	Holden	Captiva Maxx	Transmission control module	√	√	√	√	√	
2009	Holden	Captiva Maxx	Engine Control Module	√	√	√	√	√	
2009	Holden	Captiva Maxx	Rear drive system	√	√	√	√	√	0530
2009	Holden	Captiva Maxx	Instrument panel cluster	√	√	√	√	√	
2009	Holden	Captiva Maxx	Front dilay interface module	√	√	√			
2009	Holden	Captiva Maxx	HVAC Control Module	√	√	√		√	
2009	Holden	Captiva Maxx	Radio	√	√	√	√	√	
2009	Holden	Captiva Maxx	Body Control Module	√	√	√	√	√	
2009	Holden	Captiva Maxx	Body Control Module	√	√	√	√	√	0497
2009	Holden	Captiva Maxx	Supplemental inflatable restraint	√	√	√	√	√	0497
2009	Holden	Captiva Maxx	Headlamp Control Module	√	√	√	√	√	
2009	Holden	Captiva Maxx	Park assist module	√	√	√	√		
2009	Holden	Captiva Maxx	Remote control door lock receiver	√	√	√	√	√	0513 0159
2009	Holden	Captiva Maxx	Theft Deterrent Module	√	√	√	√	√	0497
2009	Holden	Captiva Maxx	Electronic Brake Control Module	√	√	√	√	√	
2008	Holden	Captiva	Engine Control Module	√	√	√	√	√	
2008	Holden	Captiva	Transmission control module	√	√	√	√	√	
2008	Holden	Captiva	Rear drive system	√	√	√	√	√	0530
2008	Holden	Captiva	Remote control door lock receiver	√	√	√	√	√	0513 0159
2008	Holden	Captiva	Theft Deterrent Module	√	√	√	√		
2008	Holden	Captiva	HVAC Control Module	√	√	√		√	
2008	Holden	Captiva	Body Control Module	√	√	√	√	√	0497
2008	Holden	Captiva	Body Control Module	√	√	√	√	√	

2008	Holden	Captiva	Instrument panel cluster	√	√	√	√	√	
2008	Holden	Captiva	Supplemental inflatable restraint	√	√	√	√	√	0497
2008	Holden	Captiva	Electronic Brake Control Module	√	√	√	√	√	
2008	Holden	Captiva Maxx	Engine Control Module	√	√	√	√	√	
2008	Holden	Captiva Maxx	Transmission control module	√	√	√	√	√	
2008	Holden	Captiva Maxx	Rear drive system	√	√	√	√	√	0530
2008	Holden	Captiva Maxx	Instrument panel cluster	√	√	√	√	√	
2008	Holden	Captiva Maxx	Body Control Module	√	√	√	√	√	0497
2008	Holden	Captiva Maxx	Body Control Module	√	√	√	√	√	
2008	Holden	Captiva Maxx	Supplemental inflatable restraint	√	√	√	√	√	0497
2008	Holden	Captiva Maxx	Headlamp Control Module	√	√	√	√	√	
2008	Holden	Captiva Maxx	Park assist module	√	√	√	√	√	
2008	Holden	Captiva Maxx	Remote control door lock receiver	√	√	√	√	√	0513 0159
2008	Holden	Captiva Maxx	Theft Deterrent Module	√	√	√	√	√	
2008	Holden	Captiva Maxx	HVAC Control Module	√	√	√	√	√	
2008	Holden	Captiva Maxx	Radio	√	√	√	√	√	
2008	Holden	Captiva Maxx	Front dilay interface module	√	√	√	√	√	0497
2008	Holden	Captiva Maxx	Electronic Brake Control Module	√	√	√	√	√	
2007	Holden	Captiva	HVAC Control Module	√	√	√	√	√	
2007	Holden	Captiva	Instrument panel cluster	√	√	√	√	√	
2007	Holden	Captiva	Body Control Module	√	√	√	√	√	0497
2007	Holden	Captiva	Body Control Module	√	√	√	√	√	
2007	Holden	Captiva	Supplemental inflatable restraint	√	√	√	√	√	0497
2007	Holden	Captiva	Remote control door lock receiver	√	√	√	√	√	0513 0159
2007	Holden	Captiva	Theft Deterrent Module	√	√	√	√	√	0497
2007	Holden	Captiva Maxx	HVAC Control Module	√	√	√	√	√	
2007	Holden	Captiva Maxx	Remote control door lock receiver	√	√	√	√	√	0513 0159
2007	Holden	Captiva Maxx	Theft Deterrent Module	√	√	√	√	√	
2007	Holden	Captiva Maxx	Front dilay interface module	√	√	√	√	√	
2007	Holden	Captiva Maxx	Instrument panel cluster	√	√	√	√	√	
2007	Holden	Captiva Maxx	Headlamp Control Module	√	√	√	√	√	
2007	Holden	Captiva Maxx	Park assist module	√	√	√	√	√	
2007	Holden	Captiva Maxx	Body Control Module	√	√	√	√	√	0497
2007	Holden	Captiva Maxx	Body Control Module	√	√	√	√	√	
2007	Holden	Captiva Maxx	Supplemental inflatable restraint	√	√	√	√	√	0497
2007	Holden	Captiva Maxx	Radio	√	√	√	√	√	0513 0159
2007	Holden	Captiva Maxx	Electronic Brake Control Module	√	√	√	√	√	
2007	Holden	Captiva Maxx	Engine Control Module	√	√	√	√	√	
2007	Holden	Captiva Maxx	Transmission control module	√	√	√	√	√	
2007	Holden	Captiva Maxx	Rear drive system	√	√	√	√	√	0530

Special Functions List

No.	Functions Name
SP0000	1-2 Shift Adapt Data
SP0001	14V Power Module
SP0002	ABS Motor
SP0003	AWD Disabled-by-Malfunction Counter Reset
SP0004	B237D Easy Entry Seat Position Sensor - Driver Learn
SP0005	B237P Easy Entry Seat Position Sensor - Passenger Learn
SP0006	HO2S Heater Resistance Learned Values Reset
SP0007	HVAC Actuators Learn
SP0008	MOST Bus Diagnostic Starting Point
SP0009	PTO Operation Mode
SP0010	WLAN Service Set Identifier (SSID) Reset
SP0011	WLAN Password Reset
SP0012	Backup Battery Test
SP0013	Backup Park Lock Actuator Disarming
SP0014	Transmission Range Control Module Range Motor Position Learn
SP0015	Transmission Learn Data
SP0016	Transmission Adaptive Pressure Reset
SP0017	Transmission Service Fast Learn
SP0018	Transmission Adaptive Torque Reset
SP0019	Transmission Adaptive Values Learn
SP0020	Gear Selector -N- Position Learn
SP0021	Transmission Solenoid Valves Calibration Preset
SP0022	Shift Transmission Gear
SP0023	Transmission Clutch 1 Return Spring Learn
SP0024	Transmission Clutch 1 Volume Learn
SP0025	Transmission Clutch 2 Return Spring Learn
SP0026	Transmission Clutch 2 Volume Learn
SP0027	Transmission Clutch 3 Return Spring Learn

SP0028	Transmission Clutch 3 Volume Learn
SP0029	Transmission Clutch 4 Return Spring Learn
SP0030	Transmission Clutch 4 Volume Learn
SP0031	Transmission Clutch 5 Return Spring Learn
SP0032	Transmission Clutch 5 Volume Learn
SP0033	Transmission Clutch Learn Status
SP0034	Transmission Adaptive Pressure Reset
SP0035	Transmission Learn
SP0036	Transmission Oil Life Reset
SP0037	Range Actuator Learn
SP0038	Manual Door Locks (-AU3)(-AU4) Without Seat Belt Pretensioner (-A70)
SP0039	Electric Door Locks (AU3) Without Seat Belt Pretensioner (-A70)
SP0040	Automatic Electric Door Locks (AU4) Without Seat Belt Pretensioner (-A70)
SP0041	Retained Accessory Power
SP0042	DPF/Catalyst 2 Reset
SP0043	DPF Service Regeneration
SP0044	DPF Pressure Sensor Reset
SP0045	DPF Reset
SP0046	Lane Departure Warning Indicator
SP0047	Distance Sensing Cruise Control Module
SP0048	Vehicle Health Data Upload
SP0049	Vehicle Direction Camera Learn
SP0050	Vehicle Inclination Sensor
SP0051	VIN Digits 10-17 Right Headlamp High Beam Control Module
SP0052	VIN Digits 10-17 Left Headlamp High Beam Control Module
SP0053	Vehicle Model
SP0054	Content Theft - Exterior Lamp Flash
SP0055	Content Theft - Horn Chirp / Door Key Cylinder Disarming
SP0056	Passenger Compartment Heater Coolant Control Solenoid Valve Learn
SP0057	Passenger Presence Sensor Learn
SP0058	Catalyst 1 Reset
SP0059	Catalyst Test

SP0060	Catalyst Reset
SP0061	BARO Sensor Reset
SP0062	Manual Door Locks (-AU3)(-AU4) With Seat Belt Pretensioner (A70)
SP0063	Electric Door Locks (AU3) With Seat Belt Pretensioner (A70)
SP0064	Automatic Electric Door Locks (AU4) With Seat Belt Pretensioner (A70)
SP0065	Code Index
SP0066	Idle Speed Adjustment
SP0067	Idle Learn
SP0068	Idle Air Control Reset
SP0069	Idle Speed Control Reset
SP0070	NOx Sensor 1 Reset
SP0071	NOx Sensor 2 Reset
SP0072	NOx Catalyst Reductant Loading Reset
SP0073	NOx Catalyst Reset
SP0074	NOx Adsorber Catalyst Data Reset
SP0075	NOx Adsorber Catalyst Reset
SP0076	Gear Position Sensor Learn
SP0077	Gear Selector -N- Position Learn
SP0078	Backup Park Lock Actuator Arming
SP0079	EV Range Reset
SP0080	Power Steering Softstops Learn
SP0081	Power Steering Softstops Reset
SP0082	Power Steering Pressure Sensor Learn
SP0083	Read LIN Bus Device ID Information
SP0084	Learned Values Reset
SP0085	Engine Oil Type Setup
SP0086	Engine Oil Life Reset
SP0087	ECM Reset
SP0088	Engine Serial Number
SP0089	Steering Wheel Angle Sensor Centering
SP0090	Steering Wheel Angle Sensor Learn
SP0091	Steering Wheel Angle Sensor Learn

SP0092	Steering Wheel Angle Sensor Centering
SP0093	Steering Wheel Angle Sensor Reset
SP0094	Flywheel Learn
SP0095	Exhaust Flow Control Valve Learn
SP0096	Exhaust Gas Temperature Sensor Learn
SP0097	Exhaust Gas Temperature Sensor Reset
SP0098	EGR Valve Learn
SP0099	Transfer Case Clutch Identifier
SP0100	Transfer Case Clutch Overtemperature Counter Reset
SP0101	Assist Step Motor Learn
SP0102	Reset PTO Inhibit and Disengage History
SP0103	Power Steering Softstops Reset
SP0104	Steering Wheel Angle Sensor Reset
SP0105	Reset Functions
SP0106	Learned Values Reset
SP0107	Copy and Restore Tire Pressure Monitoring Information
SP0108	High Pressure Fuel Pump Learn
SP0109	High Pressure Fuel Correction Reset
SP0110	Personalization
SP0111	Yaw Rate Sensor Learn
SP0112	Yaw Rate Sensor Reset
SP0113	Rear Differential Clutch Service Calibration Setup
SP0114	Rear Suspension Position Sensor Trim Height
SP0115	Ambient Air Temperature Calculation Reset
SP0116	Ambient Air Temperature Instant Update
SP0117	Reductant Fluid Tank Level Reset
SP0118	Reductant Injector Reset
SP0119	Reductant System Data Reset
SP0120	Reductant System Reset
SP0121	Restore Factory Settings
SP0122	Hybrid/EV Battery Contactor Open Reasons Reset
SP0123	Hybrid/EV Battery Pack Charging Adaptive Learn Reset

SP0124	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn
SP0125	Hybrid/EV Battery Pack Capacity Learn
SP0126	Hybrid/EV Battery Pack Capacity Reset
SP0127	Hybrid/EV Battery Pack Data Reset
SP0128	Calculated Fuel Economy Setup
SP0129	HVAC Afterblow Configuration
SP0130	HO2S Learn
SP0131	HO2S Learned Values Reset
SP0132	HO2S Heater Learn
SP0133	APP Learn
SP0134	Reset High Voltage Disable Request After Crash Event Detected
SP0135	Inspection/Maintenance Data
SP0136	Depressurize System
SP0137	Copy Injector Flow Identifiers from ECM to Glow Plug Control Module
SP0138	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM
SP0139	Throttle Body Idle Air Flow Compensation Reset
SP0140	Throttle Position Learn
SP0141	Throttle Actuator Reset
SP0142	Panic Alarm
SP0143	Intake Air Flow Valve Learn
SP0144	Intake System Learned Values Reset
SP0145	Speedometer Calibration
SP0146	Liftgate Maximum Open Position Learn
SP0147	Neutral Position Sensor Learn
SP0148	A/C Compressor Speed
SP0149	A/C Indicator
SP0150	Control Module Reset
SP0151	Control Module Self-Test
SP0152	Control Module Self-Test
SP0153	Clutch Purge
SP0154	Excessive Clutch Slip Data Reset
SP0155	Clutch Control Module/Rear Drive System Matching Identification Setup

SP0156	Clutch Pedal Position Learn
SP0157	Clutch Position Learn
SP0158	Odometer Setup
SP0159	Tire Type/Pressure Selection
SP0160	Tire Pressure Sensors Learn
SP0161	Key Fob 1
SP0162	Key Fob 2
SP0163	Key Fob 3
SP0164	Key Fob 4
SP0165	Key Fob 5
SP0166	Key Fob 6
SP0167	Key Fob 7
SP0168	Key Fob 8
SP0169	Hands-Free Liftgate Sensor Control Module Calibration
SP0170	Module Setup
SP0171	Exhaust Aftertreatment Fuel Injector Reset
SP0172	Configure New Module
SP0173	Injector Flow Rate Programming
SP0174	Yaw Rate Sensor Reset
SP0175	Yaw Rate Sensor Learn
SP0176	Average Fuel Age Reset
SP0177	Enable Deployment Loops
SP0178	Cylinder 1 Injector Flow Identifier
SP0179	Cylinder 1 Fuel Injector Correction Value Reset
SP0180	Cylinder 2 Injector Flow Identifier
SP0181	Cylinder 2 Fuel Injector Correction Value Reset
SP0182	Cylinder 3 Injector Flow Identifier
SP0183	Cylinder 3 Fuel Injector Correction Value Reset
SP0184	Cylinder 4 Injector Flow Identifier
SP0185	Cylinder 4 Fuel Injector Correction Value Reset
SP0186	Cylinder 5 Injector Flow Identifier
SP0187	Cylinder 5 Fuel Injector Correction Value Reset

SP0188	Cylinder 6 Injector Flow Identifier
SP0189	Cylinder 6 Fuel Injector Correction Value Reset
SP0190	Cylinder 7 Injector Flow Identifier
SP0191	Cylinder 7 Fuel Injector Correction Value Reset
SP0192	Cylinder 8 Injector Flow Identifier
SP0193	Cylinder 8 Fuel Injector Correction Value Reset
SP0194	Cylinder Deactivation Exhaust Flow Control Valve Learn
SP0195	Headlamp Leveling Sensor Learn
SP0196	Frontview Camera Learn
SP0197	Frontview Camera Learn
SP0198	Front Suspension Position Sensor Trim Height
SP0199	Erase/Program All Key Fobs
SP0200	Clear Transmission Counters
SP0201	Clear Passenger Window Learned Values
SP0202	Clear Secured High Voltage DTCs
SP0203	Clear Driver Window Learned Values
SP0204	Erase All Key Fobs
SP0205	Clear Disable History Data
SP0206	Clear Right Rear Window Learned Values
SP0207	Clear Active Pull Compensation Learned Limits
SP0208	Clear Left Rear Window Learned Values
SP0209	Crankshaft Position Variation Learn
SP0210	Crankshaft Position Reluctor Ring Learn
SP0211	Cancel Camera Learn
SP0212	Fuel Pump Trim Reset
SP0213	Fuel Composition Reset
SP0214	Fuel Rail Pressure Relief Valve Learned Values Reset
SP0215	Fuel Rail Pressure Sensor Reset
SP0216	Fuel Rail Pressure Sensor or Fuel Rail Learn
SP0217	Fuel Trim Reset
SP0218	Fuel Economy Reset
SP0219	Fuel Filter Life Reset

SP0220	Fuel Injector Correction Value Preset
SP0221	Fuel Injection Small Quantity Data Reset
SP0222	Fuel Injection Small Quantity Learn
SP0223	Fuel Trim Reset
SP0224	Fuel Pressure Regulator Learn
SP0225	Brake Pressure Sensor Calibration
SP0226	Erase Valet Mode Code
SP0227	Manual Door Locks (-AU3) (-AU4)
SP0228	Manual Service Disconnect Fuse Life Reset
SP0229	Park Brake Calibration
SP0230	Data Display
SP0231	Digital Radio Receiver Control Module
SP0232	All Cylinders Fuel Injector Correction Value Reset
SP0233	Tire Pressure Sensor Signal Reset
SP0234	Tire Pressure Selection
SP0235	Add/Replace Key Fobs
SP0236	Stop/Start Capacitor State of Health Reset
SP0237	Turbocharger Learn
SP0238	Turbocharger Learned Values Reset
SP0239	Next Available Slot
SP0240	Display ECM and Glow Plug Control Module Injector Flow Identifiers
SP0241	Info Display/Infotainment Faceplate Reset
SP0242	Battery Sensor Module Learn
SP0243	Battery Sensor Module Learn
SP0244	Energy Storage Capacitor Learn
SP0245	Suspension Position Sensor Trim Height
SP0246	Option Configuration
SP0247	CAN Bus Configuration Learn
SP0248	Transmission Adaptive Values Learn
SP0249	VIN Learn
SP0250	Power Steering Softstops Learn
SP0251	Learn Functions

SP0252	Throttle Position Learn
SP0253	Inlet Solenoid Valves Learn
SP0254	Liftgate Maximum Open Position Learn
SP0255	CO Adjust
SP0256	Calculated Fuel Economy Setup
SP0257	Glow Plug Learn
SP0258	Remote Vehicle Start Disable History Reset
SP0259	Remote Vehicle Speed Limiting Reset
SP0260	Long Range Radar Sensor Module Learn
SP0261	Setup SDM Part Number in BCM
SP0262	DC Charging Disabled Reset
SP0263	Brake Pedal Position Sensor Learn
SP0264	Brake Hydraulics Sensors Learn
SP0265	MAF Sensor Learn
SP0266	Reset History Buffer
SP0267	Reset Teen Driver Key PIN
SP0268	Reset Event Records
SP0269	Reset Manufacturer Enable Counter
SP0270	Proactive Alerts
SP0271	Parking Assist Sensor Learn
SP0272	Park Brake Reset
SP0273	Steering Gear Learned Values Reset
SP0274	Steering Gear Replacement Procedure
SP0275	Assembly Plant Mode
SP0276	Automatic Braking Active Signal
SP0277	Adaptive Pressure Control Learn
SP0278	Longitudinal Acceleration Sensor Reset
SP0279	Assembly Plant Emission and Fuel Economy Test
SP0280	Brake Pedal Position Sensor Learn
SP0281	Headlamp Leveling Sensor Learn
SP0282	Erase/Program All Key Fobs
SP0283	Next Available Slot

SP0284	Key Fob 1
SP0285	Key Fob 2
SP0286	Key Fob 3
SP0287	Key Fob 4
SP0288	Key Fob 5
SP0289	Key Fob 6
SP0290	Key Fob 7
SP0291	Key Fob 8
SP0292	Battery Sensor Module Learn
SP0293	Clear Driver Window Learned Values
SP0294	Clear Passenger Window Learned Values
SP0295	Clear Left Rear Window Learned Values
SP0296	Clear Right Rear Window Learned Values
SP0297	Read LIN Bus Device ID Information
SP0298	Tire Pressure Sensors Learn
SP0299	Tire Pressure Sensor Signal Reset
SP0300	Tire Type/Pressure Selection
SP0301	CAN Bus Configuration Learn
SP0302	Transmission Service Fast Learn
SP0303	Configure New Module
SP0304	Fuel Trim Reset
SP0305	Crankshaft Position Variation Learn
SP0306	HO2S Heater Learn
SP0307	Idle Learn
SP0308	Engine Oil Life Reset
SP0309	Remote Vehicle Start Disable History Reset
SP0310	Adjustable Pedals Softstops Learn
SP0311	HVAC Actuators Learn
SP0312	HVAC Afterblow Configuration
SP0313	Brake Pressure Sensor Calibration
SP0314	Steering Wheel Angle Sensor Learn
SP0315	Yaw Rate Sensor Learn

SP0316	Park Brake Calibration
SP0317	Suspension Position Sensor Trim Height
SP0318	Remote Vehicle Speed Limiting Reset
SP0319	Vehicle Health Data Upload
SP0320	WLAN Password Reset
SP0321	WLAN Service Set Identifier (SSID) Reset
SP0322	Passenger Presence Sensor Learn
SP0323	Clutch Pedal Position Learn
SP0324	Neutral Position Sensor Learn
SP0325	Fuel Pump Trim Reset
SP0326	Steering Wheel Angle Sensor Centering
SP0327	Transmission Adaptive Pressure Reset
SP0328	Liftgate Maximum Open Position Learn
SP0329	Clear Disable History Data
SP0330	Frontview Camera Learn
SP0331	Ambient Air Temperature Instant Update
SP0332	Setup SDM Part Number in BCM
SP0333	Erase All Key Fobs
SP0334	Clutch Control Module/Rear Drive System Matching Identification Setup
SP0335	Digital Radio Receiver Control Module
SP0336	Gear Selector -N- Position Learn
SP0337	Fuel Composition Reset
SP0338	Stop/Start Capacitor State of Health Reset
SP0339	AWD Disabled-by-Malfunction Counter Reset
SP0340	Long Range Radar Sensor Module Learn
SP0341	Hands-Free Liftgate Sensor Control Module Calibration
SP0342	Erase Valet Mode Code
SP0343	Control Module Reset
SP0344	Info Display/Infotainment Faceplate Reset
SP0345	Exhaust Flow Control Valve Learn
SP0346	Cylinder Deactivation Exhaust Flow Control Valve Learn
SP0347	Distance Sensing Cruise Control Module

SP0348	Adaptive Pressure Control Learn
SP0349	Yaw Rate Sensor Reset
SP0350	Gear Position Sensor Learn
SP0351	Transfer Case Clutch Identifier
SP0352	Transfer Case Clutch Overtemperature Counter Reset
SP0353	Vehicle Model
SP0354	Power Steering Softstops Learn
SP0355	Rear Suspension Position Sensor Trim Height
SP0356	Front Suspension Position Sensor Trim Height
SP0357	Reset History Buffer
SP0358	Rear Differential Clutch Service Calibration Setup
SP0359	Range Actuator Learn
SP0360	Parking Assist Sensor Learn
SP0361	Learned Values Reset
SP0362	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn
SP0363	Hybrid/EV Battery Pack Capacity Learn
SP0364	Passenger Compartment Heater Coolant Control Solenoid Valve Learn
SP0365	Fuel Economy Reset
SP0366	Hybrid/EV Battery Contactor Open Reasons Reset
SP0367	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
SP0368	Hybrid/EV Battery Pack Data Reset
SP0369	Manual Service Disconnect Fuse Life Reset
SP0370	Average Fuel Age Reset
SP0371	Electronic Brake Control Module Learn
SP0372	Steering Wheel Angle Sensor Reset
SP0373	Fuel Rail Pressure Relief Valve Learned Values Reset
SP0374	Idle Speed Control Reset
SP0375	ECM Reset
SP0376	Speedometer Calibration
SP0377	Retained Accessory Power
SP0378	Throttle Position Learn
SP0379	Automatic Braking Active Signal

SP0380	Transmission Oil Life Reset
SP0381	APP Learn
SP0382	Crankshaft Position Reluctor Ring Learn
SP0383	DPF Pressure Sensor Learn
SP0384	EGR Valve Learn
SP0385	Exhaust Gas Temperature Sensor Learn
SP0386	Flywheel Learn
SP0387	Fuel Rail Pressure Sensor or Fuel Rail Learn
SP0388	HO2S Learn
SP0389	Intake Air Flow Valve Learn
SP0390	MAF Sensor Learn
SP0391	Turbocharger Learn
SP0392	DPF Reset
SP0393	Glow Plug Control Module Reset
SP0394	DPF Service Regeneration
SP0395	Inspection/Maintenance Data
SP0396	Calculated Fuel Economy Setup
SP0397	Injector Flow Rate Programming
SP0398	Ambient Air Temperature Calculation Reset
SP0399	Catalyst 1 Reset
SP0400	DPF/Catalyst 2 Reset
SP0401	DPF Pressure Sensor Reset
SP0402	Engine Serial Number
SP0403	Fuel Filter Life Reset
SP0404	NOx Catalyst Reset
SP0405	NOx Catalyst Reductant Loading Reset
SP0406	NOx Sensor 1 Reset
SP0407	NOx Sensor 2 Reset
SP0408	Reductant Fluid Tank Level Reset
SP0409	Reductant Injector Reset
SP0410	Reductant System Data Reset
SP0411	Reductant System Reset

SP0412	Display ECM and Glow Plug Control Module Injector Flow Identifiers
SP0413	Cylinder 1 Injector Flow Identifier
SP0414	Cylinder 2 Injector Flow Identifier
SP0415	Cylinder 3 Injector Flow Identifier
SP0416	Cylinder 4 Injector Flow Identifier
SP0417	Cylinder 5 Injector Flow Identifier
SP0418	Cylinder 6 Injector Flow Identifier
SP0419	Cylinder 7 Injector Flow Identifier
SP0420	Cylinder 8 Injector Flow Identifier
SP0421	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM
SP0422	Copy Injector Flow Identifiers from ECM to Glow Plug Control Module
SP0423	Cylinder 1 Fuel Injector Correction Value Reset
SP0424	Cylinder 2 Fuel Injector Correction Value Reset
SP0425	Cylinder 3 Fuel Injector Correction Value Reset
SP0426	Cylinder 4 Fuel Injector Correction Value Reset
SP0427	Cylinder 5 Fuel Injector Correction Value Reset
SP0428	Cylinder 6 Fuel Injector Correction Value Reset
SP0429	Cylinder 7 Fuel Injector Correction Value Reset
SP0430	Cylinder 8 Fuel Injector Correction Value Reset
SP0431	All Cylinders Fuel Injector Correction Value Reset
SP0432	Fuel Injector Correction Value Preset
SP0433	Glow Plug Learn
SP0434	CO Adjust
SP0435	Clear Secured High Voltage DTCs
SP0436	On-Board Jump Assist Counter Reset
SP0437	Reset PTO Inhibit and Disengage History
SP0438	Restore Factory Settings
SP0439	DC Charging Disabled Reset
SP0440	EV Range Reset
SP0441	Idle Speed Adjustment
SP0442	Transmission Adaptive Torque Reset
SP0443	Fuel Rail Pressure Sensor Reset

SP0444	Power Steering Softstops Reset
SP0445	Transmission Adaptive Values Learn
SP0446	Turbocharger Learned Values Reset
SP0447	Vehicle Direction Camera Learn
SP0448	Fuel Pressure Regulator Learn
SP0449	Fuel Pressure Regulator Fast Learn
SP0450	Intake Manifold Runner Control Valve Learn
SP0451	High Pressure Fuel Pump Learn
SP0452	Boost Pressure Sensor Learn
SP0453	Cylinder 1 Injector
SP0454	Cylinder 2 Injector
SP0455	Cylinder 3 Injector
SP0456	Cylinder 4 Injector
SP0457	Vehicle Inclination Sensor
SP0458	Code Index
SP0459	Fuel Injection Small Quantity Data Reset
SP0460	Fuel Injection Small Quantity Learn
SP0461	Catalyst Reset
SP0462	Exhaust Gas Temperature Sensor Reset
SP0463	Idle Air Control Reset
SP0464	Throttle Actuator Reset
SP0465	Preferred Roaming List Update
SP0466	Module Setup
SP0467	Not Linked
SP0468	Linked
SP0469	Option Configuration
SP0470	Audio Code Index
SP0471	Personalization
SP0472	Total Fuel Consumed Reset
SP0473	Automatic Electric Door Locks (AU4) With Seat Belt Pretensioner (A70)
SP0474	Automatic Electric Door Locks (AU4) Without Seat Belt Pretensioner (-A70)
SP0475	Electric Door Locks (AU3) With Seat Belt Pretensioner (A70)

SP0476	Electric Door Locks (AU3) Without Seat Belt Pretensioner (-A70)
SP0477	Manual Door Locks (-AU3) (-AU4)
SP0478	Enable Deployment Loops
SP0479	Clear Transmission Counters
SP0480	Clutch Position Learn
SP0481	Clutch Purge
SP0482	Depressurize System
SP0483	Transmission Learn
SP0484	Fuel Injector Learn
SP0485	Low Speed Target Pressure
SP0486	High Speed Target Pressure
SP0487	Minimum Telltale Pressure
SP0488	Safe Telltale Pressure
SP0489	Low Speed Threshold
SP0490	High Speed Threshold
SP0491	Setup Module DTCs
SP0492	Reset
SP0493	Crankshaft pos. variation learn
SP0494	PRL update
SP0495	Set language
SP0496	Stolen vehicle slowdown clear
SP0497	Setup SDM primary key in BCM
SP0498	Inclination sensor enable
SP0499	BPP sensor calibration
SP0500	Afterblow option
SP0501	Data recorder
SP0502	Audiopilot test
SP0503	Eject
SP0504	TV region lockout
SP0505	TV region select
SP0506	Automated bleed
SP0507	CO adjust (leaded fuel only)

SP0508	Change to neutral mode
SP0509	DPF reset replace ECM
SP0510	Learn sensor location
SP0511	Learn sen loc with tire press tool
SP0512	Re-zero passenger presence system
SP0513	Copy and paste TPM information
SP0514	Tire type/pressure selection
SP0515	Setup SDM part number in BCM
SP0516	DRR setup
SP0517	Passenger presence sensor learn
SP0518	Auto. door unlock
SP0519	Key fob in veh. warning
SP0520	Passive door lock
SP0521	Setup new RCCLR
SP0522	Column calibration
SP0523	Setup new HVAC
SP0524	Radio setup
SP0525	VIN relearn
SP0526	HVAC ambient temp. disp.
SP0527	Power window motor programming
SP0528	Digital radio receiver
SP0529	Radio RPO selection
SP0530	CCM RDS matching ID
SP0531	Clear manufacturer enable counter
SP0532	Bump stop
SP0533	Acceleration sensor reset
SP0534	BMC prim. piston pos. relearn
SP0535	EBCM relearn
SP0536	Steering pos./torque sensor cal.
SP0537	Preload passenger presence system
SP0538	Engine serial number
SP0539	Capture & restore data

SP0540	Injector flow rate programming
SP0541	Setup new ROS
SP0542	PTO options
SP0543	ECM PTO options
SP0544	Reset ECM
SP0545	Reset immobilizer
SP0546	Reset vehicle build settings
SP0547	Middle east speed bias (UC2)
SP0548	Brazil units (CV2)
SP0549	Module setup
SP0550	Setup SDM serial number in BCM
SP0551	Program VIN
SP0552	Tuner calibration
SP0553	Navigation option
SP0554	Transmission type
SP0555	Disable/enable secure car
SP0556	Auto. door unlock trigger
SP0557	Delayed locking
SP0558	Passive door unlock
SP0559	Setup SDM part number in IPM
SP0560	Disable dtc(s)
SP0561	Bluetooth
SP0562	System configuration
SP0563	PSCM calibration procedure
SP0564	New actuator setup procedure
SP0565	Program phone number
SP0566	Hybrid batt. charge hrs.
SP0567	Hybrid batt. discharge amp hrs.
SP0568	Erase transponder-keys
SP0569	Seat belt chime
SP0570	Learn tire pressure sensors
SP0571	Engine shutdown

SP0572	Country code
SP0573	Chime level
SP0574	Loud chime volume
SP0575	Loud amp chime volume
SP0576	Normal chime volume
SP0577	Normal amp chime volume
SP0578	AM pass A stopping
SP0579	FM pass A stopping
SP0580	IPC setup
SP0581	U85
SP0582	UZ6
SP0583	Driver info. display option
SP0584	Calibrate module
SP0585	VCIM setup
SP0586	Optional modules
SP0587	Region code options
SP0588	New tire/wheel base/booster info.
SP0589	Setup SDM part number in IPC
SP0590	Setup SDM serial number in IPC
SP0591	Acquisition setting
SP0592	Step 1
SP0593	Step 2
SP0594	North america
SP0595	Middle east
SP0596	Steering tuning selection
SP0597	Yaw rate sensor recalibration
SP0598	BCM copy and flash
SP0599	Reduction of pressure drive
SP0600	IPC recalibration
SP0601	Injector flow rates
SP0602	Vehicle speed limit
SP0603	Navigation voice

SP0604	Setup SDM serial number in DIM
SP0605	Setup SDM part number in DIM
SP0606	LONG WAVE
SP0607	Traffic seek
SP0608	Vehicle type
SP0609	Door zone module VIN relearn
SP0610	Intrusion sensor step 1
SP0611	Inclination sensor step 1
SP0612	Alarm siren module step 1
SP0613	Tap shift
SP0614	Point of sale
SP0615	Miscellaneous options 2
SP0616	Variable effort steering
SP0617	Right hand drive
SP0618	Personalization option
SP0619	Universal theft deterrent
SP0620	Intrusion sensor step 2
SP0621	Inclination sensor step 2
SP0622	Alarm siren module step 2
SP0623	Twilight sentinel
SP0624	Front fog lamp type
SP0625	DRL option
SP0626	Perimeter lighting
SP0627	TPM option enable
SP0628	New VIN
SP0629	Tire rotation procedure
SP0630	Afterblow
SP0631	Recalibration
SP0632	Accessory wheel size setup
SP0633	Clear memory and program all fobs
SP0634	CTD operation
SP0635	Fob feedback

SP0636	Theftlock LED
SP0637	Option configuration
SP0638	Fuel injector balance
SP0639	Buckle up reminder
SP0640	Pre-alarm option
SP0641	Solenoid test
SP0642	Cruise control options
SP0643	Exhaust brake options
SP0644	Gear down protection options
SP0645	Oil capacity options
SP0646	DPM setup
SP0647	Preferred system setting
SP0648	ALC trimset
SP0649	Dimming delay
SP0650	Export ID
SP0651	Language
SP0652	AM distant
SP0653	AM local
SP0654	FM distant
SP0655	FM local
SP0656	Fob button hold time
SP0657	Electronic suspension control
SP0658	Nav. radio theft
SP0659	Oil life monitor
SP0660	Axle ratio
SP0661	Fast learn adapt. process
SP0662	BCM reprogramming
SP0663	Setup IPC
SP0664	Miscellaneous options 1
SP0665	Automatic/manual HVAC options
SP0666	Magna steer option
SP0667	Temperature offset

SP0668	Load management option
SP0669	Disable belt tower dtc's
SP0670	Navigation radio present
SP0671	Military or standard time
SP0672	Tire pressure warning
SP0673	Tire pressure monitor
SP0674	Performance shift
SP0675	Key fob personalization
SP0676	SCLM setup
SP0677	DTC mask
SP0678	Accessory inflator
SP0679	Middle east region mode
SP0680	Tire rotation/sensor replacement
SP0681	Setup RFA
SP0682	Synchronize IPC and SIR
SP0683	Setup new onstar
SP0684	Electronic serial number
SP0685	Update HVAC calcs. in DIM
SP0686	LH drvr. personalization
SP0687	RH drvr. personalization
SP0688	BCM RPO reprogram
SP0689	Twilight sentinel reprogram
SP0690	Seed and key relearn
SP0691	Setup new VTD module
SP0692	Export option
SP0693	Valet lockout
SP0694	Compact disc
SP0695	Cellular telephone
SP0696	A/C compressor calibration
SP0697	Option A
SP0698	Option B
SP0699	Option C

SP0700	Option D
SP0701	Option E
SP0702	VIN information
SP0703	Bass frequency response
SP0704	Steering angle sensor centering
SP0705	Heater recalibration
SP0706	Door lock
SP0707	Door unlock
SP0708	Door jamb switch
SP0709	Brake pedal
SP0710	Ignition switch
SP0711	Option no. 0
SP0712	HVAC recal. download
SP0713	TV present
SP0714	Bose display
SP0715	Isolation valve test
SP0716	Option no. 1
SP0717	Fob 1 option 2
SP0718	Fob 1 option 3
SP0719	Fob 2 option 1
SP0720	Fob 2 option 2
SP0721	Fob 2 option 3
SP0722	Option no. 2
SP0723	Service spark retard reset
SP0724	Odometer reset
SP0725	Gauge setup
SP0726	Synchronize TTM and MSM
SP0727	Synchronize MSM and TTM
SP0728	Remove/reset module
SP0729	Vehicle dynamic sensor offset calibration
SP0730	Clear Proximity Detection Disable Reason
SP0731	Engine air filter monitor settings

SP0732	Transmission overtemperature counter reset
SP0733	Reset buffer history instruction
SP0734	Transmission clutch read in
SP0735	Vehicle dynamic sensor 1 and 2 offset calibration
SP0736	Read the starting point of the brake system piston pressure rise
SP0737	Reading of brake system plunger motor position sensor
SP0738	Read brake pedal stroke sensor
SP0739	Front axle brake pad life monitoring reset
SP0740	Rear axle brake pad life monitoring reset
SP0741	Configuration/reset function
SP0742	Trailer tire pressure sensor read in manually
SP0743	Steering wheel angle sensor offset calibration
SP0744	Read in longitudinal acceleration sensor
SP0745	Regeneration of diesel particulate filters
SP0746	Injector correction reset
SP0747	Capture information
SP0748	Copy and restore data
SP0749	Gear actuator correction read
SP0750	4WD high-low gear low-speed actuator clutch read-in
SP0751	Distance sensing constant speed control module
SP0752	Engine speed/throttle
SP0753	Rear Gate Driver Information Center Message Reset
SP0754	Headlamp Leveling System Suspension Trim Position Learn
SP0755	Backup Battery Timer Reset
SP0756	Engine Air Filter Life Reset
SP0757	Fuel Pump Driver Control Module Configuration
SP0758	Vehicle Dynamic Sensor Offset Calibration
SP0759	Clear Approach Detection Disabled Reasons
SP075A	All Cameras Alignment Learn
SP075B	Rear Drive Clutch Service Calibration Setup
SP075C	Transmission Overtemperature Counter Reset
SP075D	Engine Block Coolant Valve Position Learn

SP075E	Engine Coolant Control Valve Learn
SP075F	Engine Coolant Flow Control Valve Learn
SP0760	Turbocharger Wastegate Learn
SP0761	Engine Coolant Pump Data Reset
SP0762	Heater Core Coolant Temperature Sensor Reset
SP0763	Particulate Filter Reset
SP0764	Particulate Filter Pressure Sensor Reset
SP0765	Engine Air Filter Monitor Setup
SP0766	Steering Wheel Angle Sensor Offset Calibration
SP0767	Brake System Plunger Motor Position Sensor Learn
SP0768	Brake System Plunger Pressure Rise Starting Point Learn
SP0769	License Compliance Materials Download Error Counter Reset
SP076A	Transmission Control Module Reset
SP076B	Exhaust Control Valve Learn
SP076C	Air Cleaner Monitor Setup
SP076D	Barometric Pressure Sensor Reset
SP076E	Fuel Pump Power Control Module Configuration
SP076F	Correction Angle Reset
SP0770	Cylinder Deactivation Exhaust Control Valve Learn
SP0771	Longitudinal Acceleration Sensor Learn
SP0772	Clear Short Range Radar Sensor Vehicle Position
SP0773	Variable Exhaust Flow Control Valve Learn
SP0774	Vehicle Longitudinal Accelerometer Sensor Learn
SP0775	Heated Oxygen Sensor Heater Resistance Learned Values Reset
SP0776	Range Actuator Correlation Learn
SP0777	Engine Block Coolant Control Valve Position Learn
SP0778	Turbocharger/Supercharger Boost Control Initial Position Learn
SP0779	Catalytic Converter Reset
SP077A	High Pressure Fuel Variable Reset
SP077B	Nitrogen Oxides Catalytic Converter Reductant Loading Reset
SP077C	Nitrogen Oxides Catalytic Converter Reset
SP077D	Nitrogen Oxides Sensor Reset

SP077E	Display ECM Injector Flow Identifiers
SP077F	Cylinder 1 Fuel Injector Flow Identifier
SP0780	Cylinder 2 Fuel Injector Flow Identifier
SP0781	Cylinder 3 Fuel Injector Flow Identifier
SP0782	Cylinder 4 Fuel Injector Flow Identifier
SP0783	Cylinder 5 Fuel Injector Flow Identifier
SP0784	Cylinder 6 Fuel Injector Flow Identifier
SP0785	Left Front Air Spring Inflate
SP0786	Right Front Air Spring Inflate
SP0787	Left Rear Air Spring Inflate
SP0788	Right Rear Air Spring Inflate
SP0789	Left Front Suspension Position Sensor Trim Height
SP078A	Right Front Suspension Position Sensor Trim Height
SP078B	Left Rear Suspension Position Sensor Trim Height
SP078C	Right Rear Suspension Position Sensor Trim Height
SP078D	Level Vehicle to Target Height
SP078E	Brake Pedal Travel Sensor Learn
SP078F	Front Axle Brake Pad Life Monitoring Reset
SP0790	Rear Axle Brake Pad Life Monitoring Reset
SP0791	Turbocharger Vane Position Learn
SP0792	Fuel Injection Small Quantity Learning Odometer Reset
SP0793	Theft Deterrent Relearn
SP0794	Vehicle Dynamic Sensors 1 and 2 Offset Calibration
SP0795	Transmission Clutch 6 Volume Learn
SP0796	Transmission Clutch 6 Return Spring Learn
SP0797	Service Cleaning Procedure
SP0798	Hydraulic System Leak Test
SP0799	Park Brake Pad Life Monitoring Reset
SP079A	Crankshaft Position Reluctor Ring Learned Values Reset
SP079B	Copy Tire Pressure Monitoring Information
SP079C	CO Adjustment
SP079D	Tire Pressure Sensors Manual Learn

SP079E	Flexible Fuel Reset
SP079F	Steering Performance Calibration
SP07A0	Powertrain Compartment Cover Full Open Height Reset
SP07A1	Powertrain Compartment Cover Cycle Counts Reset
SP07A2	Powertrain Compartment Cover Hold Open Counter Reset
SP07A3	Powertrain Compartment Cover Obstacle Counter Reset
SP07A4	Powertrain Compartment Cover Zone Counter Reset
SP07A5	Powertrain Compartment Cover Drive Unit Learn
SP07A6	4WD Low Range Actuator Clutch Learn
SP07A7	Theft Deterrent Relearn VIN Reset
SP07A8	Radio Favorites Reset
SP07A9	Turbocharger Boost Control Initial Position Learn
SP07AA	Fuel System Adaptation Reset
SP07AB	Power Take-Off Operation Mode Settings
SP07AC	Copy and Restore Data
SP07AD	Trailer Tire Pressure Sensor Manual Learn
SP07AE	Clear All Vehicle DTCs
SP07AF	Stop/Start Capacitor Control Module State of Health Reset
SP07B0	Vehicle Variant
SP07B1	Hydraulic Clutch Bleed
SP07B2	Engine Coolant Bypass Valve Position Learn
SP07B3	Set Time and Date
SP07B4	Remove/Reset Module
SP07B5	Temperature Code Index
SP07B6	EGR Cooler Run Time Counter Reset