



深圳市朗仁科 Shenzhen Xtool

Borgward V26.0

Description: ○: All support by OBD △: Partially support by C
●: All support by OBD(Need accessories) ▲: Partially support by C
×: Not support /:Unnecessary

Make	Area	Model	Year	Key Type	Read PIN	Add Keys
Borgward		BX5		smart key	/	○
Borgward		BX6		smart key	/	○
Borgward		BX7		smart key	/	○
Borgward		BXi7		smart key	/	○

技有限公司 tech Co., Ltd

08

)BD : All support (Disassembly)
)BD(Need accessories) : Partially support (Disassembly)
: Conditional support

All Keys Lost	Programme Remote	Other Functions
○	/	1. Matching smart computer 2. Matching engine computer 3. Match the new system 4. Match the steering column lock
○	/	1. Matching smart computer 2. Matching engine computer 3. Match the new system 4. Match the steering column lock
○	/	1. Matching smart computer 2. Matching engine computer 3. Match the new system 4. Match the steering column lock
○	/	1. Match the smart key 2. Matching engine computer 3. Match the new system 4. Match the steering column lock

