



# Shenzhen Xtooltech Co., Ltd

## BRILLIANCE V26.62

Description: ○: All support by OBD      △: Partially support by OBD      □: All support (Disassembly)  
 ●: All support by OBD(Need accessories)      ▲: Partially support by OBD(Need accessories)      ■: Partially support (Disassembly)  
 ×: Not support      /:Unnecessary      ◎: Conditional support

Make	Model	Year	Key Type	Read PIN	Add Keys	All Keys Lost	Programme Remote	Other Functions
Brilliance	Old Zhonghua		Mitsubishi Immobiliser	×	○	○	/	Fault codes Erase DTC Live data Program keys Reset immobiliser
Brilliance	Zunchi		Delphi Immobiliser	×	○	○	/	ECU identification Fault codes Erase DTC Live data Program function Program new system Replace immobiliser ECU Replace engine ECU Program keys Program engine VIN Program immobiliser VIN Reset engine ECU Reset immobiliser Erase keys
Brilliance	Zunchi		Mitsubishi Immobiliser	×	○	○	/	Fault codes Erase DTC Live data Program keys Reset immobiliser

Brilliance	Zunchi		Siemens Immobiliser	×	○	○	/	ECU identification Fault codes Erase DTC Live data Program function Program new system Program keys Replace immobiliser ECU Replace engine ECU Program mechanical key number Program engine VIN Program WSC Reset engine ECU Reset immobiliser
Brilliance	Junjie		Delphi Immobiliser	×	○	○	/	ECU identification Fault codes Erase DTC Live data Program function Program new system Replace immobiliser ECU Replace engine ECU Program keys Program engine VIN Program immobiliser VIN Reset engine ECU Reset immobiliser Erase keys
Brilliance	Junjie		Mitsubishi Immobiliser	×	○	○	/	Fault codes Erase DTC Live data Program keys Reset immobiliser

Brilliance	Junjie		Siemens Immobiliser	×	○	○	/	ECU identification Fault codes Erase DTC Live data Program function Program new system Program keys Replace immobiliser ECU Replace engine ECU Program mechanical key number Program engine VIN Program WSC Reset engine ECU Reset immobiliser
Brilliance	Kubao		Delphi Immobiliser	×	○	○	/	ECU identification Fault codes Erase DTC Live data Program function Program new system Replace immobiliser ECU Replace engine ECU Program keys Program engine VIN Program immobiliser VIN Reset engine ECU Reset immobiliser Erase keys
Brilliance	Kubao		Mitsubishi Immobiliser	×	○	○	/	Fault codes Erase DTC Live data Program keys Reset immobiliser

Brilliance	Kubao		Siemens Immobiliser	×	○	○	/	ECU identification Fault codes Erase DTC Live data Program function Program new system Program keys Replace immobiliser ECU Replace engine ECU Program mechanical key number Program engine VIN Program WSC Reset engine ECU Reset immobiliser
Brilliance	Junjie FRV		Mitsubishi Immobiliser	×	○	○	/	Fault codes Erase DTC Live data Program keys Reset immobiliser
Brilliance	Junjie FRV		Siemens Immobiliser	×	○	○	/	ECU identification Fault codes Erase DTC Live data Program function Program new system Program keys Replace immobiliser ECU Replace engine ECU Program mechanical key number Program engine VIN Program WSC Reset engine ECU Reset immobiliser
Brilliance	Junjie FSV		Mitsubishi Immobiliser	×	○	○	/	Fault codes Erase DTC Live data Program keys Reset immobiliser

Brilliance	Junjie FSV		Siemens Immobiliser	×	○	○	/	ECU identification Fault codes Erase DTC Live data Program function Program new system Program keys Replace immobiliser ECU Replace engine ECU Program mechanical key number Program engine VIN Program WSC Reset engine ECU Reset immobiliser
Brilliance	Immobiliser		Junjie CROSS	×	○	○	/	ECU identification Fault codes Erase DTC Live data Program function Program new system Program keys Replace immobiliser ECU Replace engine ECU Program mechanical key number Program engine VIN Program WSC Reset engine ECU Reset immobiliser

Brilliance	Immobiliser		Junjie WAGON	×	○	○	/	ECU identification Fault codes Erase DTC Live data Program function Program new system Program keys Replace immobiliser ECU Replace engine ECU Program mechanical key number Program engine VIN Program WSC Reset engine ECU Reset immobiliser
Brilliance	Immobiliser		H220	×	○	○	/	ECU identification Fault codes Erase DTC Live data Program function Program new system Program keys Replace immobiliser ECU Replace engine ECU Program mechanical key number Program engine VIN Program WSC Reset engine ECU Reset immobiliser

Brilliance	Immobiliser		H230	×	○	○	/	ECU identification Fault codes Erase DTC Live data Program function Program new system Program keys Replace immobiliser ECU Replace engine ECU Program mechanical key number Program engine VIN Program WSC Reset engine ECU Reset immobiliser
Brilliance	Immobiliser		H3	×	○	○	/	ECU identification Fault codes Erase DTC Live data Program function Program new system Program keys Replace immobiliser ECU Replace engine ECU Program mechanical key number Program engine VIN Program WSC Reset engine ECU Reset immobiliser

Brilliance	Immobiliser		H320	×	○	○	/	ECU identification Fault codes Erase DTC Live data Program function Program new system Program keys Replace immobiliser ECU Replace engine ECU Program mechanical key number Program engine VIN Program WSC Reset engine ECU Reset immobiliser
Brilliance	H330		Mitsubishi Immobiliser	×	○	○	/	Fault codes Erase DTC Live data Program keys Reset immobiliser
Brilliance	H330		Siemens Immobiliser	×	○	○	/	ECU identification Fault codes Erase DTC Live data Program function Program new system Program keys Replace immobiliser ECU Replace engine ECU Program mechanical key number Program engine VIN Program WSC Reset engine ECU Reset immobiliser



Brilliance	H530		Immobiliser	×	○	○	/	ECU identification Fault codes Erase DTC Live data Program function Program new system Program keys Replace immobiliser ECU Replace engine ECU Program mechanical key number Program engine VIN Program WSC Reset engine ECU Reset immobiliser
Brilliance	V3		Immobiliser	×	○	○	/	ECU identification Fault codes Erase DTC Live data Program function Program new system Program keys Replace immobiliser ECU Replace engine ECU Program mechanical key number Program engine VIN Program WSC Reset engine ECU Reset immobiliser

Brilliance	V3 (G3)		Immobiliser	×	○	○	/	ECU identification Fault codes Erase DTC Live data Program function Program new system Program keys Replace immobiliser ECU Replace engine ECU Program mechanical key number Program engine VIN Program WSC Reset engine ECU Reset immobiliser
Brilliance	V5		Immobiliser	×	○	○	/	ECU identification Fault codes Erase DTC Live data Program function Program new system Program keys Replace immobiliser ECU Replace engine ECU Program mechanical key number Program engine VIN Program WSC Reset engine ECU Reset immobiliser
Brilliance	V6		Immobiliser	×	○	○	○	Program Key Program remote control Program EMS Program IMMO Reset EMS Program EMS and IMMO
Brilliance	FSV	Type 1	With Smart (Old)	×	○	○	/	Program smart keys
Brilliance	FSV	Type 2	With Smart (Old)	×	○	○	/	Program smart keys

Brilliance	FSV		With Smart (New)	×	○	○	/	Fault codes Erase DTC Program function Program smart keys Program new system Reset engine ECU Reset immobiliser
Brilliance	H3	2016	With Smart	×	○	○	/	Program new PEPS Program key Program new ESCL Program new EMS Reset PEPS Reset FOB Reset EMS read FOB status Program new system
Brilliance	H330		With Smart	×	○	○	/	Fault codes Erase DTC Program function Program smart keys Program new system Reset engine ECU Reset immobiliser
Brilliance	H530		With Smart (diag)	/	/	/	/	ECU identification 1 ECU identification 2 Fault codes Erase DTC Live data General information 1 普通信息2 Automatic test Write VIN
Brilliance	H530		With Smart (program)	×	○	○	/	Program new system Program smart keys Program PEPS Reset PEPS Program ESCL

Brilliance	V3		With Smart	×	○	○	/	Program new PEPS Program key Program new ESCL Program new EMS Reset PEPS Reset FOB Reset EMS read FOB status Program new system
Brilliance	V3(G3)		With Smart	×	○	○	/	Program new PEPS Program key Program new ESCL Program new EMS Reset PEPS Reset FOB Reset EMS read FOB status Program new system
Brilliance	V5		With Smart(diag)	/	/	/	/	ECU identification 1 ECU identification 2 Fault codes Erase DTC Live data General information 1 普通信息2 Automatic test Write VIN
Brilliance	V5		With Smart(program)	×	○	○	/	Program new system Program smart keys Program PEPS Reset PEPS Program ESCL
Brilliance	V6		With Smart	×	○	○	/	Program smart key Reset smart key Reset PEPS Reset EMS Program EMS Program ESCL Program PEPS Program EMS and PEPS

Brilliance	V7		With Smart	×	○	○	/	Smart key matching
Brilliance	Jinbei		Delphi Immobiliser	×	○	○	/	ECU identification Fault codes Erase DTC Live data Program function Program new system Replace immobiliser ECU Replace engine ECU Program keys Program engine VIN Program immobiliser VIN Reset engine ECU Reset immobiliser Erase keys
Brilliance	Jinbei		H2	×	○	○	/	ECU identification Fault codes Erase DTC Live data Program function Program new system Program keys Replace immobiliser ECU Replace engine ECU Program mechanical key number Program engine VIN Program WSC Reset engine ECU Reset immobiliser
Brilliance	F50		CAN protocol	×	○	○	/	Match Key Clear Key Match IMMO Match EMS Reset IMMO Reset EMS

Brilliance	F50		KWP protocol	×	○	○	/	ECU identification Fault codes Erase DTC Live data Program function Program new system Program keys Replace immobiliser ECU Replace engine ECU Program mechanical key number Program engine VIN Program WSC Reset engine ECU Reset immobiliser
Brilliance	Zhishang S30		With Smart	×	○	○	/	Program Key Program PEPS Program ESCL Program EMS
Brilliance	Zhishang S30		Immobiliser system	×	○	○	/	ECU identification Fault codes Erase DTC Live data Program function Program new system Program keys Replace immobiliser ECU Replace engine ECU Program mechanical key number Program engine VIN Program WSC Reset engine ECU Reset immobiliser
Brilliance	Zhishang S35		With Smart	×	○	○	/	Program Key Program PEPS Program ESCL Program EMS

Brilliance	Zhishang S35		Immobiliser system	×	○	○	/	ECU identification Fault codes Erase DTC Live data Program function Program new system Program keys Replace immobiliser ECU Replace engine ECU Program mechanical key number Program engine VIN Program WSC Reset engine ECU Reset immobiliser
Brilliance	S70		With Smart	×	○	○	/	Program Key Program PEPS Program ESCL Program EMS
Brilliance	MS3		With Smart	×	○	○	/	Program Key Program PEPS Program ESCL Program EMS
Brilliance	HuaSong 7		Immobiliser system	×	○	○	/	Program keys Erase keys and add keys Program engine
Brilliance	HuaSong 7		Without Smart	/	○	○	○	All lost remote Program remote
Brilliance	GuanJing		With Smart	×	○	○	/	Program key Program new PEPS Program new EMS Program new system Reset PEPS Reset EMS



# Shenzhen Xto

BAOJUN V26.4

Description: ○: All support by OBD      △: Partially support by OBD  
●: All support by OBD(Need accessories)      ▲: Partially support by OBD  
×: Not support      /:Unnecessary

Make	Model	Year	Key Type	Read PIN	Add Keys
Baojun	310	-2021	Immobiliser	/	○
Baojun	310 Wagon	-2021	Immobiliser	/	○
Baojun	330	-2021	Immobiliser	/	○
Baojun	360	-2021	Immobiliser	/	○
Baojun	510	-2021	Immobiliser	/	○
Baojun	560	-2021	Immobiliser	/	○
Baojun	610	-2021	Immobiliser	/	○
Baojun	630	-2021	Immobiliser	/	○
Baojun	730	-2021	Immobiliser	/	○
Baojun	310 Wagon	-2021	Smart key	/	○



Baojun	510	-2020	smart key	/	○
Baojun	510	2020-	smart key	/	○
Baojun	530	-2020	smart key	/	○
Baojun	530	2020-	smart key	/	○
Baojun	560	2021-	smart key	/	○
Baojun	730	2021-	smart key	/	○
Baojun	E100	2021-	smart key	/	○
Baojun	E200	-2018	smart key	/	○
Baojun	E200	2018-	smart key	/	○
Baojun	E100	2021-	Immobiliser	/	/
Baojun	E200	2021-	Immobiliser	/	/

New Baojun	RC-5	-2021	Immobiliser	/	○
New Baojun	RC-5W	-2021	Immobiliser	/	○
New Baojun	RC-6	-2021	Immobiliser	/	○
New Baojun	RM-5	-2021	Immobiliser	/	○
New Baojun	RS-3	-2021	Immobiliser	/	○
New Baojun	RS-5	-2021	Immobiliser	/	○
New Baojun	RS-7	-2021	Immobiliser	/	○
New Baojun	E300 LV2/LV3	-2021	Immobiliser	/	○
New Baojun	E300Plus LV2/LV3	-2021	Immobiliser	/	○
New Baojun	RC-5 N15A	-2021	smart key	/	○
New Baojun	RC-5 N15T	-2021	smart key	/	○

New Baojun	RC-5W N15A	-2021	smart key	/	○
New Baojun	RC-5W N15T	-2021	smart key	/	○
New Baojun	RC-6	-2021	smart key	/	○
New Baojun	RM-5	-2021	smart key	/	○
New Baojun	RS-3	-2021	smart key	/	○
New Baojun	RS-5	-2021	smart key	/	○
New Baojun	RS-7	-2021	smart key	/	○
New Baojun	Valli	-2021	smart key	/	○
New Baojun	E300 LV1	-2021	Immobiliser	/	/
New Baojun	E300Plus LV1	-2021	Immobiliser	/	/

# oltech Co., Ltd

56

by OBD : All support (Disassembly)  
 by OBD(Need accessories) : Partially support (Disassembly)  
: Conditional support

All Keys Lost	Programme Remote	Other Functions
○	/	1. Read the number of keys 2. Read the body state 3. ECM engine reset 4. BCM body matching 5. ECM engine matching
○	/	1. Read the number of keys 2. Read the body state 3. ECM engine reset 4. BCM body matching 5. ECM engine matching
○	/	1. Read the number of keys 2. New system matching
○	○	1. Read the number of keys 2. Read the body state 3. ECM engine reset 4. BCM body matching 5. ECM engine matching
○	/	1. Read the number of keys 2. Read the body state 3. ECM engine reset 4. BCM body matching 5. ECM engine matching
○	/	1. Read the number of keys 2. Read the body state 3. ECM engine reset 4. BCM body matching 5. ECM engine matching
○	○	1. Read the number of keys
○	○	1. Read the number of keys
○	/	1. Read the number of keys 2. Read the body state 3. ECM engine reset 4. BCM body matching 5. ECM engine matching
○	/	1. Read version information 2. Reset PEPS 3. Reset ESCL 4. Match PEPS 5. Match ESCL

○	/	1. Read version information 2. Reset PEPS 3. Reset ESCL 4. Match PEPS 5. Match ESCL
○	/	1. Read version information 2. Reset PEPS 3. Reset ESCL 4. Match PEPS 5. Match ESCL
○	/	1. Read version information 2. Reset PEPS 3. Reset ESCL 4. Match PEPS 5. Match ESCL
○	/	1. Read version information 2. Reset PEPS 3. Reset ESCL 4. Match PEPS 5. Match ESCL
○	/	1. Read version information 2. Reset PEPS 3. Reset ESCL 4. Match PEPS 5. Match ESCL
○	/	1. Read version information 2. Reset PEPS 3. Reset ESCL 4. Match PEPS 5. Match ESCL
○	/	1. Read version information 2. Reset PEPS 3. Reset ESCL 4. Match PEPS 5. Match ESCL
○	/	1. Read version information 2. Reset PEPS 3. Reset ESCL 4. Match PEPS 5. Match ESCL
○	/	1. Read version information 2. Reset PEPS 3. Reset ESCL 4. Match PEPS 5. Match ESCL
○	/	1. Read version information 2. Reset PEPS 3. Reset ESCL 4. Match PEPS 5. Match ESCL
	○	
/	○	

○	/	<ol style="list-style-type: none"> <li>1. Read the number of keys</li> <li>2. Read the body state</li> <li>3. ECM engine reset</li> <li>4. BCM body matching</li> <li>5. ECM engine matching</li> </ol>
○	/	<ol style="list-style-type: none"> <li>1. Read the number of keys</li> <li>2. Read the body state</li> <li>3. ECM engine reset</li> <li>4. BCM body matching</li> <li>5. ECM engine matching</li> </ol>
○	/	<ol style="list-style-type: none"> <li>1. Read the number of keys</li> <li>2. Read the body state</li> <li>3. ECM engine reset</li> <li>4. BCM body matching</li> <li>5. ECM engine matching</li> </ol>
○	/	<ol style="list-style-type: none"> <li>1. Read the number of keys</li> <li>2. Read the body state</li> <li>3. ECM engine reset</li> <li>4. BCM body matching</li> <li>5. ECM engine matching</li> </ol>
○	/	<ol style="list-style-type: none"> <li>1. Read the number of keys</li> <li>2. Read the body state</li> <li>3. ECM engine reset</li> <li>4. BCM body matching</li> <li>5. ECM engine matching</li> </ol>
○	/	<ol style="list-style-type: none"> <li>1. Read the number of keys</li> <li>2. Read the body state</li> <li>3. ECM engine reset</li> <li>4. BCM body matching</li> <li>5. ECM engine matching</li> </ol>
○	/	<ol style="list-style-type: none"> <li>1. Read the number of keys</li> <li>2. Read the body state</li> <li>3. ECM engine reset</li> <li>4. BCM body matching</li> <li>5. ECM engine matching</li> </ol>
○	/	<ol style="list-style-type: none"> <li>1. Read the number of keys</li> <li>2. Read the body state</li> <li>3. ECM engine reset</li> <li>4. BCM body matching</li> <li>5. ECM engine matching</li> </ol>
○	/	<ol style="list-style-type: none"> <li>1. Read the number of keys</li> <li>2. Module matching</li> </ol>
○	/	<ol style="list-style-type: none"> <li>1. Read the number of keys</li> <li>2. Module matching</li> </ol>
○	/	<ol style="list-style-type: none"> <li>1. Read version information</li> <li>2. Reset PEPS</li> <li>3. Reset ESCL</li> <li>4. Match PEPS</li> <li>5. Match ESCL</li> </ol>
○	/	<ol style="list-style-type: none"> <li>1. Read version information</li> <li>2. Reset PEPS</li> <li>3. Reset ESCL</li> <li>4. Match PEPS</li> <li>5. Match ESCL</li> </ol>

○	/	1. Read version information 2. Reset PEPS 3. Reset ESCL 4. Match PEPS 5. Match ESCL
○	/	1. Read version information 2. Reset PEPS 3. Reset ESCL 4. Match PEPS 5. Match ESCL
○	/	1. Read version information 2. Reset PEPS 3. Reset ESCL 4. Match PEPS 5. Match ESCL
○	/	1. Read version information 2. Reset PEPS 3. Reset ESCL 4. Match PEPS 5. Match ESCL
○	/	1. Read version information 2. Reset PEPS 3. Reset ESCL 4. Match PEPS 5. Match ESCL
○	/	1. Read version information 2. Reset PEPS 3. Reset ESCL 4. Match PEPS 5. Match ESCL
○	/	1. Read version information 2. Reset PEPS 3. Reset ESCL 4. Match PEPS 5. Match ESCL
○	/	1. Read version information 2. Reset PEPS 3. Reset ESCL 4. Match PEPS 5. Match ESCL
○	/	1. Read version information 2. Reset PEPS 3. Reset ESCL 4. Match PEPS 5. Match ESCL
/	○	
/	○	