

Brand	Model	Key Type	Read PIN	Add Keys	All Keys Lost	Program Remote	Other Functions
Dongfeng Liuqi	B11	Blade key	×	○	○	/	1. New system matching 2. Anti-theft device ECU matching 3. Engine ECU matching 4. Immobilizer ECU reset 5. Engine ECU reset 6. Read VIN code 7. Key detection 8. Engine ECU detection 9. Programming engine VIN 10. Programming immobilizer VIN 11. Locking the immobilizer 12. LED status indicator
Dongfeng Liuqi	B12	Blade key	○	○	○	/	1. New system matching 2. Anti-theft device ECU matching 3. Engine ECU matching 4. Immobilizer ECU reset 5. Engine ECU reset 6. Read VIN code 7. Key detection 8. Engine ECU detection 9. Programming engine VIN 10. Programming immobilizer VIN 11. Locking the immobilizer 12. LED status indicator
Dongfeng Liuqi	BH5/Bh5 LV/BH5A	Blade key	○	○	○	/	1. New system matching 2. Anti-theft device ECU matching 3. Engine ECU matching 4. Immobilizer ECU reset 5. Engine ECU reset 6. Read VIN code 7. Key detection 8. Engine ECU detection 9. Programming engine VIN 10. Programming immobilizer VIN 11. Locking the immobilizer 12. LED status indicator
Dongfeng Liuqi	BX3	Blade key	○	○	○	/	1. New system matching 2. Anti-theft device ECU matching 3. Engine ECU matching 4. Immobilizer ECU reset 5. Engine ECU reset 6. Read VIN code 7. Key detection 8. Engine ECU detection 9. Programming engine VIN 10. Programming immobilizer VIN 11. Locking the immobilizer 12. LED status indicator
Dongfeng Liuqi	BX5/BX5A	Blade key	○	○	○	/	1. New system matching 2. Anti-theft device ECU matching 3. Engine ECU matching 4. Immobilizer ECU reset 5. Engine ECU reset 6. Read VIN code 7. Key detection 8. Engine ECU detection 9. Programming engine VIN 10. Programming immobilizer VIN 11. Locking the immobilizer 12. LED status indicator
Dongfeng Liuqi	BX5/BX5A	Blade key	×	○	○	/	1. Number of keys 2. Match the entire system 3. BCM matching 4. Engine ECU matching 5. Engine ECU reset
Dongfeng Liuqi	BX5/BX5A	Smart key	○	○	○	/	1. Number of keys 2. Read PEPS (IMMO) match information 3. Match the entire system 4. Anti-theft ECU matching 5. Engine ECU matching 6. ESCL match 7. Reset EMS
Dongfeng Liuqi	BX5/BX5A	Blade key	×	○	○	○	

Dongfeng Liuqi	XV	Blade key	○	○	○	/	1.New system matching 2. Anti-theft device ECU matching 3. Engine ECU matching 4. Immobilizer ECU reset 5. Engine ECU reset 6. Read VIN code 7. Key detection 8. Engine ECU detection 9. Programming engine VIN 10. Programming immobilizer VIN 11. Locking the immobilizer 12. LED status indicator
Dongfeng Liuqi	XV	Blade key	×	○	○	/	1. Number of keys 2. Match the entire system 3. BCM matching 4. Engine ECU matching 5. Engine ECU reset
Dongfeng Liuqi	XV	Smart key	○	○	○	/	1. Number of keys 2. Read PEPS (IMMO) match information 3. Match the entire system 4. Anti-theft ECU matching 5. Engine ECU matching 6. ESCL match 7. Reset EMS
Dongfeng Liuqi	XV	Blade key	×	○	○	○	
Dongfeng Liuqi	S50	Blade key	○	○	○	/	1. New system matching 2. Anti-theft device ECU matching 3. Engine ECU matching 4. Immobilizer ECU reset 5. Engine ECU reset 6. Read VIN code 7. Key detection 8. Engine ECU detection 9. Programming engine VIN 10. Programming immobilizer VIN 11. Locking the immobilizer 12. LED status indicator
Dongfeng Liuqi	S50	Blade key	×	○	○	/	1. Number of keys 2. Match the entire system 3. BCM matching 4. Engine ECU matching 5. Engine ECU reset
Dongfeng Liuqi	S50	Smart key	○	○	○	/	1. Number of keys 2. Read PEPS (IMMO) match information 3. Match the entire system 4. Anti-theft ECU matching 5. Engine ECU matching 6. ESCL match 7. Reset EMS
Dongfeng Liuqi	S50	Blade key	×	○	○	○	
Dongfeng Liuqi	SX3	Blade key	○	○	○	/	1. New system matching 2. Anti-theft device ECU matching 3. Engine ECU matching 4. Immobilizer ECU reset 5. Engine ECU reset 6. Read VIN code 7. Key detection 8. Engine ECU detection 9. Programming engine VIN 10. Programming immobilizer VIN 11. Locking the immobilizer 12. LED status indicator
Dongfeng Liuqi	SX3	Blade key	×	○	○	/	1. Number of keys 2. Match the entire system 3. BCM matching 4. Engine ECU matching 5. Engine ECU reset
Dongfeng Liuqi	SX3	Smart key	○	○	○	/	1. Number of keys 2. Read PEPS (IMMO) match information 3. Match the entire system 4. Anti-theft ECU matching 5. Engine ECU matching 6. ESCL match 7. Reset EMS

Dongfeng Liuqi	SX3	Blade key	×	○	○	○	
Dongfeng Liuqi	SX5/X5	Blade key	○	○	○	/	1. New system matching 2. Anti-theft device ECU matching 3. Engine ECU matching 4. Immobilizer ECU reset 5. Engine ECU reset 6. Read VIN code 7. Key detection 8. Engine ECU detection 9. Programming engine VIN 10. Programming immobilizer VIN 11. Locking the immobilizer 12. LED status indicator
Dongfeng Liuqi	SX5/X5	Blade key	×	○	○	/	1. Number of keys 2. Match the entire system 3. BCM matching 4. Engine ECU matching 5. Engine ECU reset
Dongfeng Liuqi	SX5/X5	Smart key	○	○	○	/	1. Number of keys 2. Read PEPS (IMMO) match information 3. Match the entire system 4. Anti-theft ECU matching 5. Engine ECU matching 6. ESCL match 7. Reset EMS
Dongfeng Liuqi	SX5/X5	Blade key	×	○	○	○	
Dongfeng Liuqi	SX6	Blade key	○	○	○	/	1. New system matching 2. Anti-theft device ECU matching 3. Engine ECU matching 4. Immobilizer ECU reset 5. Engine ECU reset 6. Read VIN code 7. Key detection 8. Engine ECU detection 9. Programming engine VIN 10. Programming immobilizer VIN 11. Locking the immobilizer 12. LED status indicator
Dongfeng Liuqi	SX6	Blade key	×	○	○	/	1. Number of keys 2. Match the entire system 3. BCM matching 4. Engine ECU matching 5. Engine ECU reset
Dongfeng Liuqi	SX6	Smart key	○	○	○	/	1. Number of keys 2. Read PEPS (IMMO) match information 3. Match the entire system 4. Anti-theft ECU matching 5. Engine ECU matching 6. ESCL match 7. Reset EMS
Dongfeng Liuqi	SX6	Blade key	×	○	○	○	
Dongfeng Liuqi	T5/T5L	Blade key	×	○	○	/	1. Number of keys 2. Match the entire system 3. BCM matching 4. Engine ECU matching 5. Engine ECU reset
Dongfeng Liuqi	T5/T5L	Smart key	○	○	○	/	1. Number of keys 2. Read PEPS (IMMO) match information 3. Match the entire system 4. Anti-theft ECU matching 5. Engine ECU matching 6. ESCL match 7. Reset EMS
Dongfeng Liuqi	T5/T5L	Blade key	×	○	○	○	
Dongfeng Liuqi	T5 EVO	Blade key	×	○	○	/	1. Number of keys
Dongfeng Liuqi	T5 EVO	Smart key	○	○	○	/	1. Number of keys
Dongfeng Liuqi	T5 EVO	Blade key	×	○	○	○	

Dongfeng Liuqi	CM7/CV7/CM7A	Blade key	○	○	○	/	1.New system matching 2. Anti-theft device ECU matching 3. Engine ECU matching 4. Immobilizer ECU reset 5. Engine ECU reset 6. Read VIN code 7. Key detection 8. Engine ECU detection 9. Programming engine VIN 10. Programming immobilizer VIN 11. Locking the immobilizer 12. LED status indicator
Dongfeng Liuqi	CM7/CV7/CM7A	Smart key	○	○	○	/	1. Number of keys 2. Read PEPS (IMMO) match information 3. Match the entire system 4. Anti-theft ECU matching 5. Engine ECU matching 6. ESCL match 7. Reset EMS
Dongfeng Liuqi	M5/M51/V5	Blade key	×	○	○	○	
Dongfeng Liuqi	CM7	Blade key	○	○	○	/	1. New system matching 2. Anti-theft device ECU matching 3. Engine ECU matching 4. Immobilizer ECU reset 5. Engine ECU reset 6. Read VIN code 7. Key detection 8. Engine ECU detection 9. Programming engine VIN 10. Programming immobilizer VIN 11. Locking the immobilizer 12. LED status indicator
Dongfeng Liuqi	CM7	Blade key	×	○	○	/	1. Number of keys 2. Match the entire system 3. BCM matching 4. Engine ECU matching 5. Engine ECU reset
Dongfeng Liuqi	CM7	Smart key	○	○	○	/	1. Number of keys 2. Read PEPS (IMMO) match information 3. Match the entire system 4. Anti-theft ECU matching 5. Engine ECU matching 6. ESCL match 7. Reset EMS
Dongfeng Liuqi	CM7	Blade key	×	○	○	○	
Dongfeng Liuqi	S500	Blade key	○	○	○	/	1. New system matching 2. Anti-theft device ECU matching 3. Engine ECU matching 4. Immobilizer ECU reset 5. Engine ECU reset 6. Read VIN code 7. Key detection 8. Engine ECU detection 9. Programming engine VIN 10. Programming immobilizer VIN 11. Locking the immobilizer 12. LED status indicator
Dongfeng Liuqi	S500	Blade key	×	○	○	/	1. Number of keys 2. Match the entire system 3. BCM matching 4. Engine ECU matching 5. Engine ECU reset
Dongfeng Liuqi	S500	Smart key	○	○	○	/	1. Number of keys 2. Read PEPS (IMMO) match information 3. Match the entire system 4. Anti-theft ECU matching 5. Engine ECU matching 6. ESCL match 7. Reset EMS
Dongfeng Liuqi	S500	Blade key	×	○	○	○	

Dongfeng Liuqi	F600 / L series	Blade key	○	○	○	/	1.New system matching 2. Anti-theft device ECU matching 3. Engine ECU matching 4. Immobilizer ECU reset 5. Engine ECU reset 6. Read VIN code 7. Key detection 8. Engine ECU detection 9. Programming engine VIN 10. Programming immobilizer VIN 11. Locking the immobilizer 12. LED status indicator
Dongfeng Liuqi	F600 / L series	Blade key	×	○	○	/	1. Number of keys 2. Match the entire system 3. BCM matching 4. Engine ECU matching 5. Engine ECU reset
Dongfeng Liuqi	F600 / L series	Smart key	○	○	○	/	1. Number of keys 2. Read PEPS (IMMO) match information 3. Match the entire system 4. Anti-theft ECU matching 5. Engine ECU matching 6. ESCL match 7. Reset EMS
Dongfeng Liuqi	F600 / L series	Blade key	×	○	○	○	
Dongfeng Liuqi	S50EV/S500EV (2017)	Blade key	×	○	○	/	1. Number of keys 2. Match the entire system 3. BCM matching 4. Engine ECU matching 5. Engine ECU reset
Dongfeng Liuqi	S50EV/S500EV (2017)	Smart key	○	○	○	/	1. Number of keys 2. Read PEPS (IMMO) match information 3. Match the entire system 4. Anti-theft ECU matching 5. Engine ECU matching 6. ESCL match 7. Reset EMS
Dongfeng Liuqi	S50EV/S500EV (2017)	Blade key	×	○	○	○	
Dongfeng Liuqi	S50EVD (2018)	Smart key	○	○	○	/	1. Number of keys 2. Read PEPS (IMMO) match information 3. Match the entire system 4. Anti-theft ECU matching 5. Engine ECU matching 6. ESCL match 7. Reset EMS
Dongfeng Liuqi	S50EVD (2018)	Blade key	×	○	○	○	
Dongfeng Liuqi	S50EVB (2018-2020)	Smart key	○	○	○	/	1. Number of keys 2. Read PEPS (IMMO) match information 3. Match the entire system 4. Anti-theft ECU matching 5. Engine ECU matching 6. ESCL match 7. Reset EMS
Dongfeng Liuqi	S50EVB (2018-2020)	Blade key	×	○	○	○	
Dongfeng Liuqi	S50EVC (2018)	Blade key	×	○	○	○	
Dongfeng Liuqi	S50EVC (2020)	Smart key	○	○	○	/	1. Number of keys 2. Read PEPS (IMMO) match information 3. Match the entire system 4. Anti-theft ECU matching 5. Engine ECU matching 6. ESCL match 7. Reset EMS
Dongfeng Liuqi	S50EVC (2020)	Blade key	×	○	○	○	
Dongfeng Liuqi	CM5EV (2017)	Blade key	×	○	○	○	
Dongfeng Liuqi	CM5EVA (2018)	Blade key	×	○	○	○	
Dongfeng Liuqi	CM5EVB (2019-2020)	Blade key	×	○	○	○	
Dongfeng Liuqi	SX1EV (EX1)	Blade key	×	○	○	○	