

Brand	Model	Key Type	Read PIN	Add Keys	All Keys Lost	Program Remote	Other Functions
FAWJB	V80/V80L/T80	Blade key	×	○	○	/	1. Replace engine ECU 2. Program Immo ECU 3. Reset immobiliser ECU 4. Reset EMS

XTOOL