

Brand	Model	Year	Key Type	Read PIN	Add Keys	All Keys Lost	Program Remote	Other Functions
Roewe	350	-2012	Blade key	×	○	×	/	1.Key increase 2.Key clear 3.Remaining unlock time
Roewe	350	2013-	Blade key	×	○	×	/	1.Add a smart key 2.Erase smart keys 3.Remaining unlock time 4.Body computer matching 5.Engine computer matching 6.New system matching
Roewe	360	2017	Smart key	○	○	×	/	1.Add smart keys 2.Erase smart keys
Roewe	360		Blade key	×	○	×	○	1.Add a smart key 2.Erase smart keys 3.Remaining unlock time 4.Body computer matching 5.Engine computer matching 6.New system matching
Roewe	550	-2012	Blade key	×	○	×	/	1.Add a key 2.Erase keys
Roewe	550	2013-	Blade key	×	○	×	/	1.Add a key 2.Erase keys 3.Unlock time remaning 4.Read Pin Code 5.BCM programming 6.ECM programming 7.BCM and ECM programming
Roewe	750 (New)		Blade key	×	○	×	○	1.Add a key 2.Erase keys
Roewe	950		Smart key	×	○	○	/	1.Clear Trouble Code 2.Read number of key 3.Program keys(Blade key) 3.1.All keys lost 3.2.Add keys 4.Program keys(Smart key) 4.1.All keys lost 4.2.Add keys

Roewe	950		Blade key	×	○	○	/	1. Clear Trouble Code 2. Read number of key 3. Program keys (Blade key) 3.1. All keys lost 3.2. Add keys 4. Program keys (Smart key) 4.1. All keys lost 4.2. Add keys
Roewe	E50	-2012	Blade key	×	○	×	/	1. Key increase 2. Key clear 3. Remaining unlock time
Roewe	E50	2013-	Blade key	×	○	×	/	1. Add a smart key 2. Erase smart keys 3. Remaining unlock time 4. Body computer matching 5. Engine computer matching 6. New system matching
Roewe	i5		Smart key	×	○	×	/	1. Add keys 2. Erase key 3. The number keys
Roewe	Ei5		Smart key	○	○	×	/	1. Add a smart key 2. Erase smart keys 3. The number keys
Roewe	i6		Smart key (Type 1)	×	○	×	/	1. Add a smart key 2. Erase smart keys 3. The number keys
Roewe	i6		Smart key (Type 2)	×	○	×	/	1. Add a smart key 2. Erase smart keys 3. The number keys
Roewe	i6		Blade key	×	○	×	/	1. Add a key 2. Erase keys 3. Num. of keys in mem.
Roewe	Ei6		Smart key	×	○	×	/	1. Add a smart key 2. Erase smart keys 3. The number keys
Roewe	Marvel X		Smart key	×	○	×	/	1. Add a smart key 2. Erase smart keys 3. The number keys

Roewe	RX3		Smart key	×	○	×	/	1. Add keys 2. Erase key 3. The number keys
Roewe	RX3		Blade key	×	○	×	/	1. Add a key 2. Erase keys 3. Num. of keys in mem.
Roewe	RX5		Smart key	○	○	×	/	1. Add a smart key 2. Erase smart keys 3. The number keys
Roewe	RX5		Blade key	×	○	×	/	1. Add a key 2. Erase keys 3. Num. of keys in mem.
Roewe	RX5 MAX		Smart key	○	○	×	/	1. Add a smart key 2. Erase smart keys 3. The number keys
Roewe	RX5 MAX		Blade key	×	○	×	/	1. Add a key 2. Erase keys 3. Num. of keys in mem.
Roewe	ERX5		Smart key	○	○	×	/	1. Add a smart key 2. Erase smart keys 3. The number keys
Roewe	ERX5		Blade key	×	○	×	/	1. Add a key 2. Erase keys 3. Num. of keys in mem.
Roewe	RX8		Smart key	○	○	×	/	1. Add a smart key 2. Erase smart keys 3. The number keys
Roewe	RX8		Blade key	×	○	×	/	1. Add a key 2. Erase keys 3. Num. of keys in mem.
Roewe	W5	-2012	Blade key	×	○	×	○	1. Key increase 2. Key clear 3. Remaining unlock time

Roewe	W5	2013-	Blade key	×	○	×	○	1.Add a smart key 2.Erase smart keys 3.Remaining unlock time 4.Body computer matching 5.Engine computer matching 6.New system matching
Roewe	IMAX8		Smart key	×	○	×	/	1.Add a smart key 2.Erase smart keys 3.The number keys
Roewe	CLEVER		Smart key	×	○	×	/	1.Add a smart key 2.Erase smart keys 3.The number keys
Roewe	R ER6		Smart key	×	○	×	/	1.Add a smart key 2.Erase smart keys 3.The number keys

*XT*TOOL