



Shenzhen Xtooltech Co., Ltd

SKODA V28.18

Description: ○: All support by OBD △: Partially support by OBD □: All support (Disassembly)
 ●: All support by OBD(Need accessories) ▲: Partially support by OBD(Need accessories) ■: Partially support (Disassembly)
 ×: Not support /:Unnecessary ◎: Conditional support

Make	Area	Model	Year	Read PIN	Add Keys	All Keys Lost	Programme Remote	Other Functions
SAIC VOLKSWAGEN SKODA	China	Fabia (0F) 2015	2015-	△	△	△	△	1. Read dashboard information 2. IMMO status 3. Reset the dashboard
SAIC VOLKSWAGEN SKODA	China	Fabia (55) 2008	2008-2013	○	●	●	○	1. Read dashboard information 2. IMMO status 3. Reset the dashboard
SAIC VOLKSWAGEN SKODA	China	Fabia (55) 2008	2013-2015	○	●	●	○	1. Read dashboard information 2. IMMO status 3. Reset the dashboard
SAIC VOLKSWAGEN SKODA	China	Kamiq	2018-	/	●	×	/	1. Read dashboard information 2. IMMO status 3. Reset the dashboard
SAIC VOLKSWAGEN SKODA	China	Karoq (0X) 2018	2018-	/	●	×	/	1. Read dashboard information 2. IMMO status 3. Reset the dashboard
SAIC VOLKSWAGEN SKODA	China	Kodiaq (0Z) 2017	2017	/	●	×	/	1. Read dashboard information 2. IMMO status 3. Reset the dashboard
SAIC VOLKSWAGEN SKODA	China	Octavia (1Z) 2007	2007-2010	○	●	●	○	1. Read dashboard information 2. IMMO status 3. Reset the dashboard
SAIC VOLKSWAGEN SKODA	China	Octavia (1Z) 2007	2010-2012	○	●	●	○	1. Read dashboard information 2. IMMO status 3. Reset the dashboard
SAIC VOLKSWAGEN SKODA	China	Octavia (1Z) 2007	2012-2013	○	●	●	○	1. Read dashboard information 2. IMMO status 3. Reset the dashboard
SAIC VOLKSWAGEN SKODA	China	Octavia (5E) 2014	2014-	/	●	×	/	1. Read dashboard information 2. IMMO status 3. Reset the dashboard

SAIC VOLKSWAGEN	China	Rapid/Spacebake (0G/NG) 2013	2013-	○	●	●	○	1. Read dashboard information 2. IMMO status 3. Reset the dashboard
SAIC VOLKSWAGEN SKODA	China	Superb (3T) 2009	2009-2011	○	●	●	○	1. Read dashboard information 2. IMMO status 3. Reset the dashboard
SAIC VOLKSWAGEN SKODA	China	Superb (3T) 2009	2012-2016	○	●	●	○	1. Read dashboard information 2. IMMO status 3. Reset the dashboard
SAIC VOLKSWAGEN SKODA	China	Superb (NP) 2016	2016-	/	●	×	/	1. Read dashboard information 2. IMMO status 3. Reset the dashboard
SAIC VOLKSWAGEN SKODA	China	Yeti (5L) 2012	2012-2014/6	○	●	●	○	1. Read dashboard information 2. IMMO status 3. Reset the dashboard
SAIC VOLKSWAGEN SKODA	China	Yeti (5L) 2012	2014/6-	○	●	●	○	1. Read dashboard information 2. IMMO status 3. Reset the dashboard
Skoda	Europe	Citigo (AA)	2012-	○	●	●	○	1. Read dashboard information 2. IMMO status 3. Reset the dashboard
Skoda	Europe	Fabia IND (5J) 2009	2009-2015	△	△	△	△	
Skoda	Europe	Fabia (5J) 2007	2007-2010	△	△	△	△	
Skoda	Europe	Fabia (5J) 2007	2011-2012	○	●	●	○	1. Read dashboard information 2. IMMO status 3. Reset the dashboard
Skoda	Europe	Fabia (5J) 2007	2013-2015	○	●	●	○	1. Read dashboard information 2. IMMO status 3. Reset the dashboard
Skoda	Europe	Fabia (6Y) 1999	1999-2008	○	○	○	○	
Skoda	Europe	Fabia (NJ) 2015	2015-	/	●	×	/	1. Read dashboard information 2. IMMO status 3. Reset the dashboard
Skoda	Europe	Kamiq	2019-	/	●	×	/	1. Read dashboard information 2. IMMO status 3. Reset the dashboard
Skoda	Europe	Karoq 2018	2018-	/	●	×	/	1. Read dashboard information 2. IMMO status 3. Reset the dashboard
Skoda	Europe	Kodiaq (NS) 2017	2017-	/	●	×	/	1. Read dashboard information 2. IMMO status 3. Reset the dashboard

Skoda	Europe	Octavia (1U) 1997	1997-2011	△	△	△	△	
Skoda	Europe	Octavia (1Z) 2004	2004-2008	○	●	●	○	1. Read dashboard information 2. IMMO status 3. Reset the dashboard
Skoda	Europe	Octavia (1Z) 2004	2009-2011	○	●	●	○	1. Read dashboard information 2. IMMO status 3. Reset the dashboard
Skoda	Europe	Octavia (1Z) 2004	2011-2013	○	●	●	○	1. Read dashboard information 2. IMMO status 3. Reset the dashboard
Skoda	Europe	Octavia (NE) 2013	2013-	/	●	×	/	1. Read dashboard information 2. IMMO status 3. Reset the dashboard
Skoda	Europe	Rapid IND (NA) 2012	2012-2014/8	○	●	●	○	1. Read dashboard information 2. IMMO status 3. Reset the dashboard
Skoda	Europe	Rapid IND (NA) 2012	2014/8-2015/8	○	●	●	○	1. Read dashboard information 2. IMMO status 3. Reset the dashboard
Skoda	Europe	Rapid (NH) 2012	2012-2013/5	○	●	●	○	1. Read dashboard information 2. IMMO status 3. Reset the dashboard
Skoda	Europe	Rapid (NH) 2012	2013/5- 2014/11	○	●	●	○	1. Read dashboard information 2. IMMO status 3. Reset the dashboard
Skoda	Europe	Rapid (NH) 2012	2014/11-2015	○	●	●	○	1. Read dashboard information 2. IMMO status 3. Reset the dashboard
Skoda	Europe	Rapid (NH) 2012	2016-	/	●	×	/	1. Read dashboard information 2. IMMO status 3. Reset the dashboard
Skoda	Europe	Roomster (5J) 2006	2006-2010	△	△	△	△	
Skoda	Europe	Roomster (5J) 2006	2011-2012	○	●	●	○	1. Read dashboard information 2. IMMO status 3. Reset the dashboard
Skoda	Europe	Roomster (5J) 2006	2012-2015	○	●	●	○	1. Read dashboard information 2. IMMO status 3. Reset the dashboard
Skoda	Europe	Superb (3T) 2008	2008-2010	○	●	●	○	1. Read dashboard information 2. IMMO status 3. Reset the dashboard

Skoda	Europe	Superb (3T) 2008	2011	○	●	●	○	1. Read dashboard information 2. IMMO status 3. Reset the dashboard
Skoda	Europe	Superb (3T) 2008	2012-2015/5	○	●	●	○	1. Read dashboard information 2. IMMO status 3. Reset the dashboard
Skoda	Europe	Superb (3U) 2001	2001-2008	△	△	△	△	
Skoda	Europe	Superb (NP) 2015	2015-	/	●	×	/	1. Read dashboard information 2. IMMO status 3. Reset the dashboard
Skoda	Europe	Yeti (5L) 2010	2010	○	●	●	○	1. Read dashboard information 2. IMMO status 3. Reset the dashboard
Skoda	Europe	Yeti (5L) 2010	2011-2012	○	●	●	○	1. Read dashboard information 2. IMMO status 3. Reset the dashboard
Skoda	Europe	Yeti (5L) 2010	2012-2014/6	○	●	●	○	1. Read dashboard information 2. IMMO status 3. Reset the dashboard
Skoda	Europe	Yeti (5L) 2010	2014/6-	○	●	●	○	1. Read dashboard information 2. IMMO status 3. Reset the dashboard