



Shenzhen Xtooltech Co., Ltd

Jaguar Function List V11.95

Tips and Instructions:

The programming function only supports H6PRO, H6PRO Master Edition products.

* This feature is new.

✓ This feature is supported.

This feature is not supported.

※ This feature is partially supported.

Model	Year	System Name	Read ECU Information	Read Trouble Code	Clear Trouble Code	Live Data	Actuation Test
Jaguar F-type	2014	ABS control module	✓	✓	✓		✓
Jaguar F-type	2014	All terrain control module	✓	✓	✓		✓
Jaguar F-type	2014	Body control module	✓	✓	✓		✓
Jaguar F-type	2014	Chassis control module	✓	✓	✓		✓
Jaguar F-type	2014	Folding top control module	✓	✓	✓		
Jaguar F-type	2014	Folding top control module B	✓	✓	✓		
Jaguar F-type	2014	Gear shift module	✓	✓	✓		
Jaguar F-type	2014	Gateway module	✓	✓	✓		
Jaguar F-type	2014	Headlamp control module	✓	✓	✓		
Jaguar F-type	2014	Instrument cluster control module.	✓	✓	✓		✓
Jaguar F-type	2014	Restraints occupant classification system module	✓	✓	✓		
Jaguar F-type	2014	Parking assist control module	✓	✓	✓		
Jaguar F-type	2014	Parking brake control module	✓	✓	✓		
Jaguar F-type	2014	Powertrain control module	✓	✓	✓		✓
Jaguar F-type	2014	Powertrain control module	✓	✓	✓		✓
Jaguar F-type	2014	Restraints control module	✓	✓	✓		
Jaguar F-type	2014	Rear differential control module	✓	✓	✓		
Jaguar F-type	2014	Transmission control module	✓	✓	✓		
Jaguar F-type	2014	Vehicle immobilizer control module	✓	✓	✓		
Jaguar F-type	2014	Driver's door module	✓	✓	✓		✓
Jaguar F-type	2014	Driver's seat module	✓	✓	✓		✓
Jaguar F-type	2014	Front control/display interface module (high level display front)	✓	✓	✓		
Jaguar F-type	2014	Integrated control panel	✓	✓	✓		
Jaguar F-type	2014	Headlamp control module 'B'	✓	✓	✓		✓
Jaguar F-type	2014	Heating ventilation and air conditioning control module	✓	✓	✓		
Jaguar F-type	2014	Image processing module 'B'	✓	✓	✓		
Jaguar F-type	2014	Keyless vehicle module	✓	✓	✓		
Jaguar F-type	2014	Passenger's door module	✓	✓	✓		✓
Jaguar F-type	2014	Passenger's seat module	✓	✓	✓		✓
Jaguar F-type	2014	Side object detection control module - Left	✓	✓	✓		✓
Jaguar F-type	2014	Side object detection control module - Right	✓	✓	✓		✓
Jaguar F-type	2014	Audio amplifier module	✓	✓	✓		
Jaguar F-type	2014	Audio front control module	✓	✓	✓		
Jaguar F-type	2014	Digital audio broadcast module	✓	✓	✓		
Jaguar F-type	2014	Navigation control module	✓	✓	✓		
Jaguar F-type	2014	Satellite audio unit module.	✓	✓	✓		
Jaguar F-type	2014	Television module	✓	✓	✓		

Jaguar XF	2013-2015	ABS control module	✓	✓	✓		✓
Jaguar XF	2013-2015	Adaptive damping control module	✓	✓	✓		✓
Jaguar XF	2013-2015	Speed control module	✓	✓	✓		
Jaguar XF	2013-2015	Chassis control module	✓	✓	✓		✓
Jaguar XF	2013-2015	Gear shift module	✓	✓	✓		
Jaguar XF	2013-2015	Gateway module	✓	✓	✓		
Jaguar XF	2013-2015	Headlamp control module	✓	✓	✓		
Jaguar XF	2013-2015	Instrument cluster control module.	✓	✓	✓		✓
Jaguar XF	2013-2015	Restraints occupant classification system module	✓	✓	✓		
Jaguar XF	2013-2015	Parking brake control module	✓	✓	✓		
Jaguar XF	2013-2015	Powertrain control module	✓	✓	✓		✓
Jaguar XF	2013-2015	Powertrain control module	✓	✓	✓		✓
Jaguar XF	2013-2015	Powertrain control module	✓	✓	✓		✓
Jaguar XF	2013-2015	Powertrain control module	✓	✓	✓		✓
Jaguar XF	2013-2015	Restraints control module	✓	✓	✓		
Jaguar XF	2013-2015	Rear differential control module	✓	✓	✓		
Jaguar XF	2013-2015	Safety belt pretensioner control module A - drivers side	✓	✓	✓		
Jaguar XF	2013-2015	Safety belt pretensioner control module B - passengers side	✓	✓	✓		
Jaguar XF	2013-2015	Transfer case control module	✓	✓	✓		
Jaguar XF	2013-2015	Transmission control module	✓	✓	✓		
Jaguar XF	2013-2015	Vehicle immobilizer control module	✓	✓	✓		
Jaguar XF	2013-2015	Driver's climate seat module	✓	✓	✓		
Jaguar XF	2013-2015	Driver's door module	✓	✓	✓		
Jaguar XF	2013-2015	Driver's seat module	✓	✓	✓		✓
Jaguar XF	2013-2015	Front control/display interface module (high level display front)	✓	✓	✓		
Jaguar XF	2013-2015	Front controls interface module 'B' (front audio control panel)	✓	✓	✓		
Jaguar XF	2013-2015	Central junction box (body control module)	✓	✓	✓		✓
Jaguar XF	2013-2015	Headlamp control module 'B'	✓	✓	✓		✓
Jaguar XF	2013-2015	Heating ventilation and air conditioning control module	✓	✓	✓		✓
Jaguar XF	2013-2015	Keyless vehicle module	✓	✓	✓		
Jaguar XF	2013-2015	Parking assist control module	✓	✓	✓		
Jaguar XF	2013-2015	Passenger's door module	✓	✓	✓		
Jaguar XF	2013-2015	Passenger's seat module	✓	✓	✓		✓
Jaguar XF	2013-2015	Rear gate / trunk module	✓	✓	✓		
Jaguar XF	2013-2015	Auxiliary junction box (body control module B)	✓	✓	✓		
Jaguar XF	2013-2015	Side object detection control module - Left	✓	✓	✓		✓
Jaguar XF	2013-2015	Side object detection control module - Right	✓	✓	✓		✓
Jaguar XF	2013-2015	Tire pressure monitor module	✓	✓	✓		
Jaguar XF	2013-2015	Audio amplifier module	✓	✓	✓		
Jaguar XF	2013-2015	Audio front control module	✓	✓	✓		
Jaguar XF	2013-2015	Digital audio broadcast module	✓	✓	✓		
Jaguar XF	2013-2015	Navigation control module	✓	✓	✓		
Jaguar XF	2013-2015	Satellite audio unit module.	✓	✓	✓		
Jaguar XF	2013-2015	Television module	✓	✓	✓		
Jaguar XF	2010-2011	ABS control module	✓	✓	✓		✓
Jaguar XF	2010-2011	Adaptive damping control module	✓	✓	✓		✓
Jaguar XF	2010-2011	Speed control module	✓	✓	✓		
Jaguar XF	2010-2011	Gear shift module	✓	✓	✓		
Jaguar XF	2010-2011	Headlamp control module	✓	✓	✓		
Jaguar XF	2010-2011	Impact classification system	✓	✓	✓		
Jaguar XF	2010-2011	Instrument cluster control module.	✓	✓	✓		✓

Jaguar XF	2010-2011	Instrument cluster control module.	✓	✓	✓		✓
Jaguar XF	2010-2011	Instrument cluster control module.	✓	✓	✓		✓
Jaguar XF	2010-2011	Instrument cluster control module.	✓	✓	✓		✓
Jaguar XF	2010-2011	Instrument cluster control module.	✓	✓	✓		✓
Jaguar XF	2010-2011	Restraints occupant classification system module	✓	✓	✓		
Jaguar XF	2010-2011	Parking brake control module	✓	✓	✓		
Jaguar XF	2010-2011	Parking brake control module	✓	✓	✓		
Jaguar XF	2010-2011	Parking brake control module	✓	✓	✓		
Jaguar XF	2010-2011	Parking brake control module	✓	✓	✓		
Jaguar XF	2010-2011	Powertrain control module	✓	✓	✓		✓
Jaguar XF	2010-2011	Powertrain control module	✓	✓	✓		✓
Jaguar XF	2010-2011	Powertrain control module	✓	✓	✓		✓
Jaguar XF	2010-2011	Powertrain control module	✓	✓	✓		✓
Jaguar XF	2010-2011	Powertrain control module	✓	✓	✓		✓
Jaguar XF	2010-2011	Restraints control module	✓	✓	✓		
Jaguar XF	2010-2011	Rear differential control module	✓	✓	✓		
Jaguar XF	2010-2011	Transmission control module	✓	✓	✓		
Jaguar XF	2010-2011	Transmission control module	✓	✓	✓		
Jaguar XF	2010-2011	Transmission control module	✓	✓	✓		
Jaguar XF	2010-2011	Transmission control module	✓	✓	✓		
Jaguar XF	2010-2011	Transmission control module	✓	✓	✓		
Jaguar XF	2010-2011	Vehicle immobilizer control module	✓	✓	✓		
Jaguar XF	2010-2011	Driver's climate seat module	✓	✓	✓		
Jaguar XF	2010-2011	Driver's door module	✓	✓	✓		✓
Jaguar XF	2010-2011	Driver's seat module	✓	✓	✓		
Jaguar XF	2010-2011	Central junction box (body control module)	✓	✓	✓		✓
Jaguar XF	2010-2011	Heating ventilation and air conditioning control module	✓	✓	✓		✓
Jaguar XF	2010-2011	Infotainment control module.	✓	✓	✓		
Jaguar XF	2010-2011	Integrated control panel	✓	✓	✓		✓
Jaguar XF	2010-2011	Keyless vehicle module	✓	✓	✓		
Jaguar XF	2010-2011	Parking assist control module	✓	✓	✓		
Jaguar XF	2010-2011	Passenger's door module	✓	✓	✓		✓
Jaguar XF	2010-2011	Auxiliary junction box (body control module B)	✓	✓	✓		
Jaguar XF	2010-2011	Side object detection control module - Left	✓	✓	✓		✓
Jaguar XF	2010-2011	Side object detection control module - Right	✓	✓	✓		✓
Jaguar XF	2010-2011	Tire pressure monitor module	✓	✓	✓		
Jaguar XF	2010-2011	Forward looking radar	✓	✓			
Jaguar XF	2010-2011	Audio amplifier module	✓	✓	✓		
Jaguar XF	2010-2011	Audio front control module	✓	✓	✓		
Jaguar XF	2010-2011	Accessory protocol interface module	✓	✓	✓		
Jaguar XF	2010-2011	Digital audio control module C	✓	✓	✓		
Jaguar XF	2010-2011	Front control/display interface module (high level display front)	✓	✓	✓		
Jaguar XF	2010-2011	Navigation control module	✓	✓	✓		
Jaguar XF	2010-2011	Satellite audio unit module.	✓	✓	✓		
Jaguar XF	2010-2011	Cellular telephone control module	✓	✓	✓		
Jaguar XF	2010-2011	Television module	✓	✓	✓		
Jaguar XF	2010-2011	Digital audio broadcast module	✓	✓	✓		
Jaguar XF	2008-2009	ABS control module	✓	✓	✓		✓
Jaguar XF	2008-2009	Adaptive damping control module	✓	✓	✓		
Jaguar XF	2008-2009	Speed control module	✓	✓	✓		

Jaguar XF	2008-2009	Gear shift module	✓	✓	✓		
Jaguar XF	2008-2009	Headlamp control module	✓	✓	✓		
Jaguar XF	2008-2009	Impact classification system	✓	✓	✓		✓
Jaguar XF	2008-2009	Instrument cluster control module.	✓	✓	✓		✓
Jaguar XF	2008-2009	Restraints occupant classification system module	✓	✓	✓		
Jaguar XF	2008-2009	Parking brake control module	✓	✓	✓		
Jaguar XF	2008-2009	Powertrain control module	✓	✓	✓		✓
Jaguar XF	2008-2009	Powertrain control module	✓	✓	✓		✓
Jaguar XF	2008-2009	Powertrain control module	✓	✓	✓		✓
Jaguar XF	2008-2009	Powertrain control module	✓	✓	✓		✓
Jaguar XF	2008-2009	Restraints control module	✓	✓	✓		
Jaguar XF	2008-2009	Transmission control module	✓	✓	✓		
Jaguar XF	2008-2009	Vehicle immobilizer control module	✓	✓	✓		
Jaguar XF	2008-2009	Driver's climate seat module	✓	✓	✓		
Jaguar XF	2008-2009	Driver's door module	✓	✓	✓		✓
Jaguar XF	2008-2009	Driver's seat module	✓	✓	✓		✓
Jaguar XF	2008-2009	Central junction box (body control module)	✓	✓	✓		✓
Jaguar XF	2008-2009	Heating ventilation and air conditioning control module	✓	✓	✓		✓
Jaguar XF	2008-2009	Infotainment control module.	✓	✓	✓		
Jaguar XF	2008-2009	Integrated control panel	✓	✓	✓		
Jaguar XF	2008-2009	Keyless vehicle module	✓	✓	✓		
Jaguar XF	2008-2009	Parking assist control module	✓	✓	✓		
Jaguar XF	2008-2009	Passenger's door module	✓	✓	✓		✓
Jaguar XF	2008-2009	Auxiliary junction box (body control module B)	✓	✓	✓		
Jaguar XF	2008-2009	Side object detection control module - Left	✓	✓	✓		✓
Jaguar XF	2008-2009	Side object detection control module - Right	✓	✓	✓		✓
Jaguar XF	2008-2009	Tire pressure monitor module	✓	✓	✓		
Jaguar XF	2008-2009	Forward looking radar	✓	✓	✓		
Jaguar XF	2008-2009	Audio amplifier module	✓	✓	✓		
Jaguar XF	2008-2009	Audio front control module	✓	✓	✓		
Jaguar XF	2008-2009	Accessory protocol interface module	✓	✓	✓		
Jaguar XF	2008-2009	Front control/display interface module (high level display front)	✓	✓	✓		
Jaguar XF	2008-2009	Navigation control module	✓	✓	✓		
Jaguar XF	2008-2009	Satellite audio unit module.	✓	✓	✓		
Jaguar XF	2008-2009	Cellular telephone control module	✓	✓	✓		
Jaguar XF	2008-2009	Television module	✓	✓	✓		
Jaguar XF	2008-2009	Digital audio broadcast module	✓	✓	✓		
Jaguar XF	2012	ABS control module	✓	✓	✓		
Jaguar XF	2012	Adaptive damping control module	✓	✓	✓		✓
Jaguar XF	2012	Speed control module	✓	✓	✓		
Jaguar XF	2012	Gear shift module	✓	✓	✓		
Jaguar XF	2012	Gateway module	✓	✓	✓		
Jaguar XF	2012	Headlamp control module	✓	✓	✓		
Jaguar XF	2012	Instrument cluster control module.	✓	✓	✓		✓
Jaguar XF	2012	Restraints occupant classification system module	✓	✓	✓		
Jaguar XF	2012	Parking brake control module	✓	✓	✓		
Jaguar XF	2012	Powertrain control module	✓	✓	✓		✓
Jaguar XF	2012	Powertrain control module	✓	✓	✓		
Jaguar XF	2012	Powertrain control module	✓	✓	✓		
Jaguar XF	2012	Powertrain control module	✓	✓	✓		
Jaguar XF	2012	Powertrain control module	✓	✓	✓		
Jaguar XF	2012	Restraints control module	✓	✓	✓		

Jaguar XF	2012	Rear differential control module	✓	✓	✓		
Jaguar XF	2012	Safety belt pretensioner control module A - drivers side	✓	✓	✓		
Jaguar XF	2012	Safety belt pretensioner control module B - passengers side	✓	✓	✓		
Jaguar XF	2012	Transmission control module	✓	✓	✓		
Jaguar XF	2012	Transmission control module	✓	✓	✓		
Jaguar XF	2012	Transmission control module	✓	✓	✓		
Jaguar XF	2012	Transmission control module	✓	✓	✓		
Jaguar XF	2012	Vehicle immobilizer control module	✓	✓	✓		
Jaguar XF	2012	Driver's climate seat module	✓	✓	✓		
Jaguar XF	2012	Driver's door module	✓	✓	✓		
Jaguar XF	2012	Driver's seat module	✓	✓	✓		✓
Jaguar XF	2012	Front control/display interface module (high level display front)	✓	✓	✓		
Jaguar XF	2012	Front controls interface module 'B' (front audio control panel)	✓	✓	✓		
Jaguar XF	2012	Central junction box (body control module)	✓	✓	✓		✓
Jaguar XF	2012	Headlamp control module 'B'	✓	✓	✓		✓
Jaguar XF	2012	Heating ventilation and air conditioning control module	✓	✓	✓		✓
Jaguar XF	2012	Keyless vehicle module	✓	✓	✓		
Jaguar XF	2012	Parking assist control module	✓	✓	✓		
Jaguar XF	2012	Passenger's door module	✓	✓	✓		
Jaguar XF	2012	Passenger's seat module	✓	✓	✓		✓
Jaguar XF	2012	Auxiliary junction box (body control module B)	✓	✓	✓		
Jaguar XF	2012	Side object detection control module - Left	✓	✓	✓		✓
Jaguar XF	2012	Side object detection control module - Right	✓	✓	✓		✓
Jaguar XF	2012	Tire pressure monitor module	✓	✓	✓		
Jaguar XF	2012	Audio amplifier module	✓	✓	✓		
Jaguar XF	2012	Audio front control module	✓	✓	✓		
Jaguar XF	2012	Digital audio broadcast module	✓	✓	✓		
Jaguar XF	2012	Navigation control module	✓	✓	✓		
Jaguar XF	2012	Satellite audio unit module.	✓	✓	✓		
Jaguar XF	2012	Television module	✓	✓	✓		
New XK	2010-2014	ABS control module	✓	✓	✓		✓
New XK	2010-2014	Speed control module	✓	✓	✓		
New XK	2010-2014	Adaptive damping control module	✓	✓	✓		✓
New XK	2010-2014	Headlamp control module	✓	✓	✓		
New XK	2010-2014	Powertrain control module	✓	✓	✓		✓
New XK	2010-2014	Powertrain control module	✓	✓	✓		✓
New XK	2010-2014	Parking brake control module	✓	✓	✓		
New XK	2010-2014	Vehicle immobilizer control module	✓	✓	✓		
New XK	2010-2014	Gear shift module	✓	✓	✓		
New XK	2010-2014	Instrument cluster control module.	✓	✓	✓		✓
New XK	2010-2014	Impact classification system	✓	✓	✓		
New XK	2010-2014	Restraints occupant classification system module	✓	✓	✓		
New XK	2010-2014	Restraints control module	✓	✓	✓		
New XK	2010-2014	Rear differential control module	✓	✓	✓		
New XK	2010-2014	Transmission control module	✓	✓	✓		
New XK	2010-2014	Driver's climate seat module	✓	✓	✓		
New XK	2010-2014	Driver's door module	✓	✓	✓		✓
New XK	2010-2014	Driver's seat module	✓	✓	✓		✓
New XK	2010-2014	Central junction box (body control module)	✓	✓	✓		✓
New XK	2010-2014	Folding top control module	✓	✓	✓		✓
New XK	2010-2014	Infotainment control module.	✓	✓	✓		

New XK	2010-2014	Integrated control panel	✓	✓			✓
New XK	2010-2014	Keyless vehicle module	✓	✓	✓		
New XK	2010-2014	Parking assist control module	✓	✓	✓		
New XK	2010-2014	Passenger's door module	✓	✓	✓		✓
New XK	2010-2014	Passenger's seat module	✓	✓	✓		✓
New XK	2010-2014	Heating ventilation and air conditioning control module	✓	✓	✓		✓
New XK	2010-2014	Auxiliary junction box (body control module B)	✓	✓	✓		✓
New XK	2010-2014	Tire pressure monitor module	✓	✓	✓		
New XK	2010-2014	Forward looking radar	✓	✓			
New XK	2010-2014	Front control/display interface module (high level display front)	✓	✓	✓		
New XK	2010-2014	Audio front control module	✓	✓	✓		
New XK	2010-2014	Audio amplifier module	✓	✓	✓		
New XK	2010-2014	Accessory protocol interface module	✓	✓	✓		
New XK	2010-2014	Digital audio broadcast module	✓	✓	✓		
New XK	2010-2014	Digital audio control module C	✓	✓	✓		
New XK	2010-2014	Navigation control module	✓	✓	✓		
New XK	2010-2014	Satellite audio unit module.	✓	✓	✓		
New XK	2010-2014	Cellular telephone control module	✓	✓	✓		
New XK	2006.5-2009	ABS control module	✓	✓	✓		
New XK	2006.5-2009	Speed control module	✓	✓	✓		
New XK	2006.5-2009	Adaptive damping control module	✓	✓	✓		
New XK	2006.5-2009	Headlamp control module	✓	✓	✓		
New XK	2006.5-2009	Powertrain control module	✓	✓	✓		✓
New XK	2006.5-2009	Powertrain control module	✓	✓	✓		✓
New XK	2006.5-2009	Parking brake control module	✓	✓	✓		
New XK	2006.5-2009	Vehicle immobilizer control module	✓	✓	✓		
New XK	2006.5-2009	Gear shift module					
New XK	2006.5-2009	Instrument cluster control module.	✓	✓	✓		
New XK	2006.5-2009	Impact classification system	✓	✓	✓		
New XK	2006.5-2009	Restraints control module	✓	✓	✓		
New XK	2006.5-2009	Transmission control module	✓	✓	✓		
New XK	2006.5-2009	Driver's door module	✓	✓	✓		✓
New XK	2006.5-2009	Driver's seat module	✓	✓	✓		✓
New XK	2006.5-2009	Central junction box (body control module)	✓	✓	✓		✓
New XK	2006.5-2009	Folding top control module	✓	✓	✓		✓
New XK	2006.5-2009	Infotainment control module.	✓	✓	✓		
New XK	2006.5-2009	Integrated control panel	✓	✓			
New XK	2006.5-2009	Keyless vehicle module	✓	✓	✓		
New XK	2006.5-2009	Parking assist control module	✓	✓	✓		
New XK	2006.5-2009	Passenger's door module	✓	✓	✓		✓
New XK	2006.5-2009	Passenger's seat module	✓	✓	✓		✓
New XK	2006.5-2009	Heating ventilation and air conditioning control module	✓	✓	✓		✓
New XK	2006.5-2009	Auxiliary junction box (body control module B)	✓	✓	✓		✓
New XK	2006.5-2009	Tire pressure monitor module	✓	✓	✓		
New XK	2006.5-2009	Forward looking radar	✓	✓			
New XK	2006.5-2009	Front control/display interface module (high level display front)	✓	✓	✓		
New XK	2006.5-2009	Audio front control module	✓	✓	✓		
New XK	2006.5-2009	Audio amplifier module	✓	✓	✓		
New XK	2006.5-2009	Navigation control module	✓	✓	✓		
New XK	2006.5-2009	Satellite audio unit module.	✓	✓	✓		
New XK	2006.5-2009	Cellular telephone control module (bluetooth telephone module)	✓	✓	✓		
S-Type	2001	Anti-lock braking system	✓	✓	✓		

S-Type	2001	Climate control module	✓	✓	✓		
S-Type	2001	Driver's door module	✓	✓	✓		
S-Type	2001	General electronics control module.	✓	✓	✓		
S-Type	2001	Audio unit.	✓	✓	✓		
S-Type	2001	Instrument pack	✓	✓	✓		
S-Type	2001	Message center control module	✓	✓	✓		
S-Type	2001	Powertrain control module	✓	✓	✓		
S-Type	2001	Restraints control module	✓	✓	✓		
S-Type	2001	Rear electronic control module.	✓	✓	✓		
S-Type	2001	Vehicle emergency control module	✓	✓	✓		
S-Type	2001	Throttle control unit.	✓	✓			
S-Type	2001	Adaptive damping system.	✓	✓	✓		
S-Type	2001	Driver's seat module	✓	✓	✓		
S-Type	2001	Navigation control module	✓	✓			
S-Type	2001	Voice activation control module.	✓	✓	✓		
S-Type	2001	Cellular telephone control module	✓	✓	✓		
S-Type	2001	Parking aid control module.	✓	✓	✓		
S-Type	2001	Steering column lock module	✓	✓			
S-Type	2000	Anti-lock braking system	✓	✓	✓		
S-Type	2000	Climate control module	✓	✓	✓		
S-Type	2000	Driver's door module	✓	✓	✓		
S-Type	2000	General electronics control module.	✓	✓	✓		
S-Type	2000	Audio unit.	✓	✓	✓		
S-Type	2000	Instrument pack	✓	✓	✓		
S-Type	2000	Message center control module	✓	✓	✓		
S-Type	2000	Powertrain control module	✓	✓	✓		
S-Type	2000	Restraints control module	✓	✓	✓		
S-Type	2000	Rear electronic control module.	✓	✓	✓		
S-Type	2000	Vehicle emergency control module	✓	✓	✓		
S-Type	2000	Throttle control unit.	✓	✓			
S-Type	2000	Adaptive damping system.	✓	✓	✓		
S-Type	2000	Driver's seat module	✓	✓	✓		
S-Type	2000	Navigation control module	✓	✓			
S-Type	2000	Voice activation control module.	✓	✓	✓		
S-Type	2000	Cellular telephone control module	✓	✓	✓		
S-Type	2000	Parking aid control module.	✓	✓	✓		
S-Type	2000	Steering column lock module	✓	✓			
S-Type	1999.25	Anti-lock braking system	✓	✓	✓		
S-Type	1999.25	Climate control module	✓	✓	✓		
S-Type	1999.25	Driver's door module	✓	✓	✓		
S-Type	1999.25	General electronics control module.	✓	✓	✓		
S-Type	1999.25	Audio unit.	✓	✓	✓		
S-Type	1999.25	Instrument pack	✓	✓	✓		
S-Type	1999.25	Message center control module	✓	✓	✓		
S-Type	1999.25	Powertrain control module	✓	✓	✓		
S-Type	1999.25	Restraints control module	✓	✓	✓		
S-Type	1999.25	Rear electronic control module.	✓	✓	✓		
S-Type	1999.25	Vehicle emergency control module	✓	✓	✓		
S-Type	1999.25	Throttle control unit.	✓	✓			
S-Type	1999.25	Adaptive damping system.	✓	✓	✓		
S-Type	1999.25	Driver's seat module	✓	✓	✓		
S-Type	1999.25	Navigation control module	✓	✓			

S-Type	1999.25	Voice activation control module.	✓	✓	✓		
S-Type	1999.25	Cellular telephone control module	✓	✓	✓		
S-Type	1999.25	Parking aid control module.	✓	✓	✓		
S-Type	1999.25	Steering column lock module	✓	✓			
S-Type 2002 model year onwards	2006-2008	Anti-lock braking system	✓	✓	✓		
S-Type 2002 model year onwards	2006-2008	Adaptive speed control control module.	✓	✓	✓		
S-Type 2002 model year onwards	2006-2008	Headlamp levelling system.	✓	✓	✓		
S-Type 2002 model year onwards	2006-2008	Adaptive damping ride control.	✓	✓	✓		
S-Type 2002 model year onwards	2006-2008	Auxiliary heater control module	✓	✓	✓		
S-Type 2002 model year onwards	2006-2008	Amplifier	✓	✓	✓		
S-Type 2002 model year onwards	2006-2008	Restraints control module	✓	✓	✓		
S-Type 2002 model year onwards	2006-2008	Climate control module	✓	✓	✓		
S-Type 2002 model year onwards	2006-2008	Cellular telephone control module	✓	✓	✓		
S-Type 2002 model year onwards	2006-2008	Driver's door module	✓	✓	✓		
S-Type 2002 model year onwards	2006-2008	Driver's seat module	✓	✓	✓		
S-Type 2002 model year onwards	2006-2008	Audio unit.	✓	✓	✓		
S-Type 2002 model year onwards	2006-2008	General electronics control module.	✓	✓	✓		
S-Type 2002 model year onwards	2006-2008	Instrument pack	✓	✓	✓		
S-Type 2002 model year onwards	2006-2008	Intrusion sensor module	✓	✓	✓		
S-Type 2002 model year onwards	2006-2008	Navigation control module	✓	✓	✓		
S-Type 2002 model year onwards	2006-2008	Parking aid control module.	✓	✓	✓		
S-Type 2002 model year onwards	2006-2008	Parking brake control module	✓	✓	✓		
S-Type 2002 model year onwards	2006-2008	Powertrain control module	✓	✓	✓		✓
S-Type 2002 model year onwards	2006-2008	Rear electronic control module.	✓	✓	✓		
S-Type 2002 model year onwards	2006-2008	Steering column lock module	✓	✓	✓		
S-Type 2002 model year onwards	2006-2008	Transmission control module	✓	✓	✓		
S-Type 2002 model year onwards	2006-2008	Tire pressure monitor module	✓	✓	✓		
S-Type 2002 model year onwards	2006-2008	Voice activation control module.	✓	✓	✓		
S-Type 2002 model year onwards	2004-2005	Anti-lock braking system	✓	✓	✓		

S-Type 2002 model year onwards	2004-2005	Adaptive speed control control module.	✓	✓	✓		
S-Type 2002 model year onwards	2004-2005	Headlamp levelling system.	✓	✓	✓		
S-Type 2002 model year onwards	2004-2005	Adaptive damping ride control.	✓	✓	✓		
S-Type 2002 model year onwards	2004-2005	Amplifier	✓	✓	✓		
S-Type 2002 model year onwards	2004-2005	Restraints control module	✓	✓	✓		
S-Type 2002 model year onwards	2004-2005	Climate control module	✓	✓	✓		
S-Type 2002 model year onwards	2004-2005	Cellular telephone control module	✓	✓	✓		
S-Type 2002 model year onwards	2004-2005	Driver's door module	✓	✓	✓		
S-Type 2002 model year onwards	2004-2005	Driver's seat module	✓	✓	✓		
S-Type 2002 model year onwards	2004-2005	Engine control module	✓	✓	✓		
S-Type 2002 model year onwards	2004-2005	Audio unit.	✓	✓	✓		
S-Type 2002 model year onwards	2004-2005	General electronics control module.	✓	✓	✓		
S-Type 2002 model year onwards	2004-2005	Instrument pack	✓	✓	✓		
S-Type 2002 model year onwards	2004-2005	Intrusion sensor module	✓	✓	✓		
S-Type 2002 model year onwards	2004-2005	Navigation control module	✓	✓	✓		
S-Type 2002 model year onwards	2004-2005	Parking aid control module.	✓	✓	✓		
S-Type 2002 model year onwards	2004-2005	Rear electronic control module.	✓	✓	✓		
S-Type 2002 model year onwards	2004-2005	Steering column lock module	✓	✓	✓		
S-Type 2002 model year onwards	2004-2005	Transmission control module	✓	✓	✓		
S-Type 2002 model year onwards	2004-2005	Parking brake control module	✓	✓	✓		
S-Type 2002 model year onwards	2004-2005	Powertrain control module	✓	✓	✓		
S-Type 2002 model year onwards	2004-2005	Auxiliary heater control module	✓	✓	✓		
S-Type 2002 model year onwards	2004-2005	Voice activation control module.	✓	✓	✓		
S-Type 2002 model year onwards	2002.5-2003	Anti-lock braking system	✓	✓	✓		
S-Type 2002 model year onwards	2002.5-2003	Adaptive speed control control module.	✓	✓	✓		
S-Type 2002 model year onwards	2002.5-2003	Headlamp levelling system.	✓	✓	✓		
S-Type 2002 model year onwards	2002.5-2003	Adaptive damping ride control.	✓	✓	✓		

S-Type 2002 model year onwards	2002.5-2003	Amplifier	√	√	√		
S-Type 2002 model year onwards	2002.5-2003	Restraints control module	√	√	√		
S-Type 2002 model year onwards	2002.5-2003	Climate control module	√	√	√		
S-Type 2002 model year onwards	2002.5-2003	Cellular telephone control module	√	√	√		
S-Type 2002 model year onwards	2002.5-2003	Driver's door module	√	√	√		
S-Type 2002 model year onwards	2002.5-2003	Driver's seat module	√	√	√		
S-Type 2002 model year onwards	2002.5-2003	Engine control module	√	√	√		
S-Type 2002 model year onwards	2002.5-2003	Electronic parking brake	√	√	√		
S-Type 2002 model year onwards	2002.5-2003	Audio unit.	√	√	√		
S-Type 2002 model year onwards	2002.5-2003	General electronics control module.	√	√	√		
S-Type 2002 model year onwards	2002.5-2003	Instrument pack	√	√	√		
S-Type 2002 model year onwards	2002.5-2003	Intrusion sensor module	√	√	√		
S-Type 2002 model year onwards	2002.5-2003	Navigation control module	√	√	√		
S-Type 2002 model year onwards	2002.5-2003	Parking aid control module.	√	√	√		
S-Type 2002 model year onwards	2002.5-2003	Rear electronic control module.	√	√	√		
S-Type 2002 model year onwards	2002.5-2003	Steering column lock module	√	√	√		
S-Type 2002 model year onwards	2002.5-2003	Transmission control module	√	√	√		
S-Type 2002 model year onwards	2002.5-2003	Voice activation control module.	√	√	√		
XJ range(X350)	2008-2009	Anti-lock braking system	√	√	√		
XJ range(X350)	2008-2009	Adaptive speed control control module.	√	√	√		
XJ range(X350)	2008-2009	Left lighting control module	√	√			
XJ range(X350)	2008-2009	Right lighting control module	√	√			
XJ range(X350)	2008-2009	Auxiliary heater control module	√	√	√		
XJ range(X350)	2008-2009	Amplifier	√	√	√		
XJ range(X350)	2008-2009	Restraints control module	√	√	√		
XJ range(X350)	2008-2009	Air suspension module	√	√	√		
XJ range(X350)	2008-2009	Climate control module	√	√	√		
XJ range(X350)	2008-2009	Cellular telephone control module	√	√	√		
XJ range(X350)	2008-2009	Driver's climate seat module	√	√	√		
XJ range(X350)	2008-2009	Driver's door module	√	√	√		
XJ range(X350)	2008-2009	Driver's seat module	√	√	√		
XJ range(X350)	2008-2009	Audio unit.	√	√	√		
XJ range(X350)	2008-2009	General electronics control module.	√	√	√		
XJ range(X350)	2008-2009	Gateway module	√	√	√		
XJ range(X350)	2008-2009	Instrument pack	√	√	√		
XJ range(X350)	2008-2009	Intrusion sensor module	√	√	√		

XJ range(X350)	2008-2009	Navigation control module	✓	✓	✓		
XJ range(X350)	2008-2009	Parking aid control module.	✓	✓	✓		
XJ range(X350)	2008-2009	Parking brake control module	✓	✓	✓		
XJ range(X350)	2008-2009	Powertrain control module	✓	✓	✓		✓
XJ range(X350)	2008-2009	Powertrain control module	✓	✓	✓		✓
XJ range(X350)	2008-2009	Powertrain control module	✓	✓	✓		✓
XJ range(X350)	2008-2009	Powertrain control module	✓	✓	✓		✓
XJ range(X350)	2008-2009	Rear climate control module	✓	✓	✓		
XJ range(X350)	2008-2009	Rear electronic control module.	✓	✓	✓		
XJ range(X350)	2008-2009	Rear entertainment control module	✓	✓	✓		
XJ range(X350)	2008-2009	Rear seat control module.	✓	✓	✓		
XJ range(X350)	2008-2009	Steering column lock module	✓	✓	✓		
XJ range(X350)	2008-2009	Transmission control module	✓	✓	✓		
XJ range(X350)	2008-2009	Tire pressure monitor module	✓	✓	✓		
XJ range(X350)	2008-2009	Voice activation control module.	✓	✓	✓		
XJ range(X350)	2006	Anti-lock braking system	✓	✓	✓		
XJ range(X350)	2006	Adaptive speed control control module.	✓	✓	✓		
XJ range(X350)	2006	Left lighting control module	✓	✓			
XJ range(X350)	2006	Right lighting control module	✓	✓			
XJ range(X350)	2006	Auxiliary heater control module	✓	✓	✓		✓
XJ range(X350)	2006	Amplifier	✓	✓	✓		
XJ range(X350)	2006	Restraints control module	✓	✓	✓		
XJ range(X350)	2006	Air suspension module	✓	✓	✓		
XJ range(X350)	2006	Climate control module	✓	✓	✓		
XJ range(X350)	2006	Cellular telephone control module	✓	✓	✓		
XJ range(X350)	2006	Driver's door module	✓	✓	✓		
XJ range(X350)	2006	Driver's seat module	✓	✓	✓		
XJ range(X350)	2006	Audio unit.	✓	✓	✓		
XJ range(X350)	2006	General electronics control module.	✓	✓	✓		
XJ range(X350)	2006	Instrument pack	✓	✓	✓		
XJ range(X350)	2006	Intrusion sensor module	✓	✓	✓		
XJ range(X350)	2006	Navigation control module	✓	✓	✓		
XJ range(X350)	2006	Parking aid control module.	✓	✓	✓		
XJ range(X350)	2006	Parking brake control module	✓	✓	✓		✓
XJ range(X350)	2006	Powertrain control module	✓	✓	✓		
XJ range(X350)	2006	Rear climate control module	✓	✓	✓		
XJ range(X350)	2006	Rear electronic control module.	✓	✓	✓		
XJ range(X350)	2006	Rear entertainment control module	✓	✓	✓		
XJ range(X350)	2006	Rear seat control module.	✓	✓	✓		
XJ range(X350)	2006	Steering column lock module	✓	✓	✓		
XJ range(X350)	2006	Transmission control module	✓	✓	✓		
XJ range(X350)	2006	Tire pressure monitor module	✓	✓	✓		
XJ range(X350)	2006	Voice activation control module.	✓	✓	✓		
XJ range(X350)	2002.5	Anti-lock braking system	✓	✓	✓		
XJ range(X350)	2002.5	Adaptive speed control control module.	✓	✓	✓		
XJ range(X350)	2002.5	Left lighting control module	✓	✓	✓		
XJ range(X350)	2002.5	Right lighting control module	✓	✓	✓		
XJ range(X350)	2002.5	Amplifier	✓	✓	✓		
XJ range(X350)	2002.5	Restraints control module	✓	✓	✓		
XJ range(X350)	2002.5	Air suspension module	✓	✓	✓		
XJ range(X350)	2002.5	Climate control module	✓	✓	✓		
XJ range(X350)	2002.5	Cellular telephone control module	✓	✓	✓		

XJ range(X350)	2002.5	Driver's door module	✓	✓	✓		
XJ range(X350)	2002.5	Driver's seat module	✓	✓	✓		
XJ range(X350)	2002.5	Engine control module	✓	✓	✓		
XJ range(X350)	2002.5	Electronic parking brake	✓	✓	✓		
XJ range(X350)	2002.5	Audio unit.	✓	✓	✓		
XJ range(X350)	2002.5	General electronics control module.	✓	✓	✓		
XJ range(X350)	2002.5	Instrument pack	✓	✓	✓		
XJ range(X350)	2002.5	Intrusion sensor module	✓	✓	✓		
XJ range(X350)	2002.5	Navigation control module	✓	✓	✓		
XJ range(X350)	2002.5	Parking aid control module.	✓	✓	✓		
XJ range(X350)	2002.5	Rear climate control module	✓	✓	✓		
XJ range(X350)	2002.5	Rear electronic control module.	✓	✓	✓		
XJ range(X350)	2002.5	Rear entertainment control module	✓	✓	✓		
XJ range(X350)	2002.5	Rear seat control module.	✓	✓	✓		
XJ range(X350)	2002.5	Steering column lock module	✓	✓	✓		
XJ range(X350)	2002.5	Transmission control module	✓	✓	✓		
XJ range(X350)	2002.5	Voice activation control module.	✓	✓	✓		
XJ range(X351)	2013-2015	ABS control module	✓	✓	✓		✓
XJ range(X351)	2013-2015	Body control module	✓	✓	✓		✓
XJ range(X351)	2013-2015	Speed control module	✓	✓	✓		
XJ range(X351)	2013-2015	Chassis control module	✓	✓	✓		✓
XJ range(X351)	2013-2015	Gear shift module	✓	✓	✓		
XJ range(X351)	2013-2015	Gateway module	✓	✓	✓		
XJ range(X351)	2013-2015	Headlamp control module	✓	✓	✓		
XJ range(X351)	2013-2015	Instrument cluster control module.	✓	✓	✓		✓
XJ range(X351)	2013-2015	Restraints occupant classification system module	✓	✓	✓		
XJ range(X351)	2013-2015	Parking brake control module	✓	✓	✓		
XJ range(X351)	2013-2015	Powertrain control module	✓	✓	✓		✓
XJ range(X351)	2013-2015	Powertrain control module	✓	✓	✓		✓
XJ range(X351)	2013-2015	Powertrain control module	✓	✓	✓		✓
XJ range(X351)	2013-2015	Powertrain control module	✓	✓	✓		✓
XJ range(X351)	2013-2015	Powertrain control module	✓	✓	✓		✓
XJ range(X351)	2013-2015	Restraints control module	✓	✓	✓		
XJ range(X351)	2013-2015	Rear differential control module	✓	✓	✓		
XJ range(X351)	2013-2015	Safety belt pretensioner control module A - drivers side	✓	✓	✓		
XJ range(X351)	2013-2015	Safety belt pretensioner control module B - passengers side	✓	✓	✓		
XJ range(X351)	2013-2015	Transmission control module	✓	✓	✓		
XJ range(X351)	2013-2015	Vehicle immobilizer control module	✓	✓	✓		
XJ range(X351)	2013-2015	Vehicle immobilizer control module	✓	✓	✓		
XJ range(X351)	2013-2015	Driver's climate seat module	✓	✓	✓		
XJ range(X351)	2013-2015	Driver's door module	✓	✓	✓		
XJ range(X351)	2013-2015	Driver's seat module	✓	✓	✓		✓
XJ range(X351)	2013-2015	Front control/display interface module (high level display front)	✓	✓	✓		
XJ range(X351)	2013-2015	Front controls interface module 'B' (front audio control panel)	✓	✓	✓		
XJ range(X351)	2013-2015	Headlamp control module 'B'	✓	✓	✓		✓
XJ range(X351)	2013-2015	Heating ventilation and air conditioning control module	✓	✓	✓		
XJ range(X351)	2013-2015	Keyless vehicle module	✓	✓	✓		
XJ range(X351)	2013-2015	Parking assist control module	✓	✓	✓		
XJ range(X351)	2013-2015	Passenger's door module	✓	✓	✓		
XJ range(X351)	2013-2015	Passenger's seat module	✓	✓	✓		✓
XJ range(X351)	2013-2015	Rear climate seat module	✓	✓	✓		
XJ range(X351)	2013-2015	Rear gate / trunk module	✓	✓	✓		

XJ range(X351)	2013-2015	Rear Heating ventilation and air conditioning control module	✓	✓	✓		✓
XJ range(X351)	2013-2015	Rear seat - Control module - Right	✓	✓	✓		
XJ range(X351)	2013-2015	Rear seat - Control module - Left	✓	✓	✓		
XJ range(X351)	2013-2015	Side object detection control module - Left	✓	✓	✓		✓
XJ range(X351)	2013-2015	Side object detection control module - Right	✓	✓	✓		✓
XJ range(X351)	2013-2015	Audio amplifier module	✓	✓	✓		
XJ range(X351)	2013-2015	Audio front control module	✓	✓	✓		
XJ range(X351)	2013-2015	Digital audio broadcast module	✓	✓	✓		
XJ range(X351)	2013-2015	Navigation control module	✓	✓	✓		
XJ range(X351)	2013-2015	Rear entertainment control module	✓	✓	✓		
XJ range(X351)	2013-2015	Satellite audio unit module.	✓	✓	✓		
XJ range(X351)	2013-2015	Television module	✓	✓	✓		
XJ range(X351)	2010-2012	ABS control module	✓	✓	✓		✓
XJ range(X351)	2010-2012	Adaptive damping control module	✓	✓	✓		✓
XJ range(X351)	2010-2012	Body control module	✓	✓	✓		✓
XJ range(X351)	2010-2012	Speed control module	✓	✓	✓		
XJ range(X351)	2010-2012	Gear shift module	✓	✓	✓		
XJ range(X351)	2010-2012	Headlamp control module	✓	✓	✓		
XJ range(X351)	2010-2012	Instrument cluster control module.	✓	✓	✓		✓
XJ range(X351)	2010-2012	Restraints occupant classification system module	✓	✓	✓		
XJ range(X351)	2010-2012	Parking brake control module	✓	✓	✓		
XJ range(X351)	2010-2012	Powertrain control module	✓	✓	✓		✓
XJ range(X351)	2010-2012	Powertrain control module	✓	✓	✓		✓
XJ range(X351)	2010-2012	Powertrain control module	✓	✓	✓		✓
XJ range(X351)	2010-2012	Powertrain control module	✓	✓	✓		✓
XJ range(X351)	2010-2012	Restraints control module	✓	✓	✓		
XJ range(X351)	2010-2012	Rear differential control module	✓	✓	✓		
XJ range(X351)	2010-2012	Ride level control module	✓	✓	✓		✓
XJ range(X351)	2010-2012	Safety belt pretensioner control module A - drivers side	✓	✓	✓		
XJ range(X351)	2010-2012	Safety belt pretensioner control module B - passengers side	✓	✓	✓		
XJ range(X351)	2010-2012	Transmission control module	✓	✓	✓		
XJ range(X351)	2010-2012	Vehicle immobilizer control module	✓	✓	✓		
XJ range(X351)	2010-2012	Driver's climate seat module	✓	✓	✓		
XJ range(X351)	2010-2012	Driver's door module	✓	✓	✓		✓
XJ range(X351)	2010-2012	Driver's seat module	✓	✓	✓		
XJ range(X351)	2010-2012	Front control/display interface module (high level display front)	✓	✓	✓		
XJ range(X351)	2010-2012	Front controls interface module 'B' (front audio control panel)	✓	✓	✓		
XJ range(X351)	2010-2012	Headlamp control module 'B'	✓	✓	✓		✓
XJ range(X351)	2010-2012	Heating ventilation and air conditioning control module	✓	✓	✓		
XJ range(X351)	2010-2012	Keyless vehicle module	✓	✓	✓		
XJ range(X351)	2010-2012	Parking assist control module	✓	✓	✓		
XJ range(X351)	2010-2012	Passenger's door module	✓	✓	✓		✓
XJ range(X351)	2010-2012	Passenger's seat module	✓	✓	✓		
XJ range(X351)	2010-2012	Rear climate seat module	✓	✓	✓		
XJ range(X351)	2010-2012	Rear gate / trunk module	✓	✓	✓		
XJ range(X351)	2010-2012	Rear Heating ventilation and air conditioning control module	✓	✓	✓		✓
XJ range(X351)	2010-2012	Side object detection control module - Left	✓	✓	✓		✓
XJ range(X351)	2010-2012	Side object detection control module - Right	✓	✓	✓		✓
XJ range(X351)	2010-2012	Audio amplifier module	✓	✓	✓		
XJ range(X351)	2010-2012	Audio front control module	✓	✓	✓		
XJ range(X351)	2010-2012	Digital audio broadcast module	✓	✓	✓		
XJ range(X351)	2010-2012	Rear entertainment control module	✓	✓	✓		

XJ range(X351)	2010-2012	Satellite audio unit module.	✓	✓	✓		
XJ range(X351)	2010-2012	Television module	✓	✓	✓		
XJ8(X300)	2001	Anti-lock braking system	✓	✓	✓		
XJ8(X300)	2001	Engine control module	✓	✓	✓		
XJ8(X300)	2001	Instrument pack	✓	✓	✓		
XJ8(X300)	2001	Transmission control module	✓	✓	✓		
XJ8(X300)	2001	Driver's seat module	✓	✓	✓		
XJ8(X300)	2001	Passenger's seat module	✓	✓	✓		
XJ8(X300)	2001	Security locking module.	✓	✓	✓		
XJ8(X300)	2001	Passenger's door module	✓	✓	✓		
XJ8(X300)	2001	Passenger's (side) rear door module.	✓	✓	✓		
XJ8(X300)	2001	Driver's door module	✓	✓	✓		
XJ8(X300)	2001	Driver's (side) rear door module.	✓	✓	✓		
XJ8(X300)	2001	Body processor module	✓	✓	✓		
XJ8(X300)	2001	Climate control module	✓	✓	✓		
XJ8(X300)	2001	Restraints control module	✓	✓	✓		
XJ8(X300)	2001	Adaptive damping system.	✓	✓	✓		
XJ8(X300)	2001	Key transponder module.	✓	✓			
XJ8(X300)	2000	Anti-lock braking system	✓	✓	✓		
XJ8(X300)	2000	Engine control module	✓	✓	✓		
XJ8(X300)	2000	Instrument pack	✓	✓	✓		
XJ8(X300)	2000	Transmission control module	✓	✓	✓		
XJ8(X300)	2000	Driver's seat module	✓	✓	✓		
XJ8(X300)	2000	Passenger's seat module	✓	✓	✓		
XJ8(X300)	2000	Security locking module.	✓	✓	✓		
XJ8(X300)	2000	Passenger's door module	✓	✓	✓		
XJ8(X300)	2000	Passenger's (side) rear door module.	✓	✓	✓		
XJ8(X300)	2000	Driver's door module	✓	✓	✓		
XJ8(X300)	2000	Driver's (side) rear door module.	✓	✓	✓		
XJ8(X300)	2000	Body processor module	✓	✓	✓		
XJ8(X300)	2000	Climate control module	✓	✓	✓		
XJ8(X300)	2000	Restraints control module	✓	✓	✓		
XJ8(X300)	2000	Adaptive damping system.	✓	✓	✓		
XJ8(X300)	2000	Key transponder module.	✓	✓			
XJ8(X300)	1999	Anti-lock braking system	✓	✓	✓		
XJ8(X300)	1999	Engine control module	✓	✓	✓		
XJ8(X300)	1999	Instrument pack	✓	✓	✓		
XJ8(X300)	1999	Transmission control module	✓	✓	✓		
XJ8(X300)	1999	Driver's seat module	✓	✓	✓		
XJ8(X300)	1999	Passenger's seat module	✓	✓	✓		
XJ8(X300)	1999	Security locking module.	✓	✓	✓		
XJ8(X300)	1999	Passenger's door module	✓	✓	✓		
XJ8(X300)	1999	Passenger's (side) rear door module.	✓	✓	✓		
XJ8(X300)	1999	Driver's door module	✓	✓	✓		
XJ8(X300)	1999	Driver's (side) rear door module.	✓	✓	✓		
XJ8(X300)	1999	Body processor module	✓	✓	✓		
XJ8(X300)	1999	Climate control module	✓	✓	✓		
XJ8(X300)	1999	Restraints control module	✓	✓	✓		
XJ8(X300)	1999	Adaptive damping system.	✓	✓	✓		
XJ8(X300)	1999	Key transponder module.	✓	✓			
XJ8(X300)	1998.25	Anti-lock braking system	✓	✓	✓		
XJ8(X300)	1998.25	Engine control module	✓	✓	✓		

XJ8(X300)	1998.25	Instrument pack	✓	✓	✓		
XJ8(X300)	1998.25	Transmission control module	✓	✓	✓		
XJ8(X300)	1998.25	Driver's seat module	✓	✓	✓		
XJ8(X300)	1998.25	Passenger's seat module	✓	✓	✓		
XJ8(X300)	1998.25	Security locking module.	✓	✓	✓		
XJ8(X300)	1998.25	Passenger's door module	✓	✓	✓		
XJ8(X300)	1998.25	Passenger's (side) rear door module.	✓	✓	✓		
XJ8(X300)	1998.25	Driver's door module	✓	✓	✓		
XJ8(X300)	1998.25	Driver's (side) rear door module.	✓	✓	✓		
XJ8(X300)	1998.25	Body processor module	✓	✓	✓		
XJ8(X300)	1998.25	Climate control module	✓	✓	✓		
XJ8(X300)	1998.25	Restraints control module	✓	✓	✓		
XJ8(X300)	1998.25	Adaptive damping system.	✓	✓	✓		
XJ8(X300)	1998.25	Key transponder module.	✓	✓			
XJ8(X300)	1998	Anti-lock braking system	✓	✓	✓		
XJ8(X300)	1998	Engine control module	✓	✓	✓		
XJ8(X300)	1998	Instrument pack	✓	✓	✓		
XJ8(X300)	1998	Transmission control module	✓	✓	✓		
XJ8(X300)	1998	Transmission control module	✓	✓	✓		
XJ8(X300)	1998	Driver's seat module	✓	✓	✓		
XJ8(X300)	1998	Passenger's seat module	✓	✓	✓		
XJ8(X300)	1998	Security locking module.	✓	✓	✓		
XJ8(X300)	1998	Passenger's door module	✓	✓	✓		
XJ8(X300)	1998	Passenger's (side) rear door module.	✓	✓	✓		
XJ8(X300)	1998	Driver's door module	✓	✓	✓		
XJ8(X300)	1998	Driver's (side) rear door module.	✓	✓	✓		
XJ8(X300)	1998	Body processor module	✓	✓	✓		
XJ8(X300)	1998	Climate control module	✓	✓	✓		
XJ8(X300)	1998	Restraints control module	✓	✓	✓		
XJ8(X300)	1998	Adaptive damping system.	✓	✓	✓		
XJ8(X300)	1998	Key transponder module.	✓	✓			
XJ8(X300)	1997	Anti-lock braking system	✓	✓	✓		
XJ8(X300)	1997	Engine control module	✓	✓	✓		
XJ8(X300)	1997	Engine control module	✓	✓	✓		
XJ8(X300)	1997	Instrument pack	✓	✓	✓		
XJ8(X300)	1997	Transmission control module	✓	✓	✓		
XJ8(X300)	1997	Driver's seat module	✓	✓	✓		
XJ8(X300)	1997	Passenger's seat module	✓	✓	✓		
XJ8(X300)	1997	Body processor module	✓	✓	✓		
XJ8(X300)	1997	Climate control module	✓	✓	✓		
XJ8(X300)	1997	Column/mirror memory control module	✓	✓	✓		
XJ8(X300)	1997	Security system control module	✓	✓	✓		
XJ8(X300)	1996	Anti-lock braking system	✓	✓	✓		
XJ8(X300)	1996	Engine control module	✓	✓	✓		
XJ8(X300)	1996	Instrument pack	✓	✓	✓		
XJ8(X300)	1996	Transmission control module	✓	✓	✓		
XJ8(X300)	1996	Driver's seat module	✓	✓	✓		
XJ8(X300)	1996	Passenger's seat module	✓	✓	✓		
XJ8(X300)	1996	Body processor module	✓	✓	✓		
XJ8(X300)	1996	Climate control module	✓	✓	✓		
XJ8(X300)	1996	Column/mirror memory control module	✓	✓	✓		
XJ8(X300)	1996	Security system control module	✓	✓	✓		

XJ8(X300)	1995.75	Anti-lock braking system	✓	✓	✓		
XJ8(X300)	1995.75	Engine control module	✓	✓	✓		
XJ8(X300)	1995.75	Instrument pack	✓	✓	✓		
XJ8(X300)	1995.75	Transmission control module	✓	✓	✓		
XJ8(X300)	1995.75	Driver's seat module	✓	✓	✓		
XJ8(X300)	1995.75	Passenger's seat module	✓	✓	✓		
XJ8(X300)	1995.75	Body processor module	✓	✓	✓		
XJ8(X300)	1995.75	Climate control module	✓	✓	✓		
XJ8(X300)	1995.75	Column/mirror memory control module	✓	✓	✓		
XJ8(X300)	1995.75	Security system control module	✓	✓	✓		
XJ8(X300)	1995.5	Anti-lock braking system	✓	✓	✓		
XJ8(X300)	1995.5	Engine control module	✓	✓	✓		
XJ8(X300)	1995.5	Instrument pack	✓	✓	✓		
XJ8(X300)	1995.5	Transmission control module	✓	✓	✓		
XJ8(X300)	1995.5	Driver's seat module	✓	✓	✓		
XJ8(X300)	1995.5	Passenger's seat module	✓	✓	✓		
XJ8(X300)	1995.5	Body processor module	✓	✓	✓		
XJ8(X300)	1995.5	Climate control module	✓	✓	✓		
XJ8(X300)	1995.5	Column/mirror memory control module	✓	✓	✓		
XJ8(X300)	1995.5	Security system control module	✓	✓	✓		
XJ8(X300)	1995	Anti-lock braking system	✓	✓	✓		
XJ8(X300)	1995	Engine control module	✓	✓	✓		
XJ8(X300)	1995	Instrument pack	✓	✓	✓		
XJ8(X300)	1995	Transmission control module	✓	✓	✓		
XJ8(X300)	1995	Driver's seat module	✓	✓	✓		
XJ8(X300)	1995	Passenger's seat module	✓	✓	✓		
XJ8(X300)	1995	Body processor module	✓	✓	✓		
XJ8(X300)	1995	Climate control module	✓	✓	✓		
XJ8(X300)	1995	Column/mirror memory control module	✓	✓	✓		
XJ8(X300)	1995	Security system control module	✓	✓	✓		
XJ8(X300H)	1996.5	Anti-lock braking system	✓	✓	✓		
XJ8(X300H)	1996.5	Engine control module	✓	✓	✓		
XJ8(X300H)	1996.5	Instrument pack	✓	✓	✓		
XJ8(X300H)	1996.5	Transmission control module	✓	✓	✓		
XJ8(X300H)	1996.5	Driver's seat module	✓	✓	✓		
XJ8(X300H)	1996.5	Passenger's seat module	✓	✓	✓		
XJ8(X300H)	1996.5	Body processor module	✓	✓	✓		
XJ8(X300H)	1996.5	Climate control module	✓	✓	✓		
XJ8(X300H)	1996.5	Column/mirror memory control module	✓	✓	✓		
XJ8(X300H)	1996.5	Security system control module	✓	✓	✓		
XJS	1996	Anti-lock braking system	✓	✓	✓		
XJS	1996	Engine control module	✓	✓	✓		
XJS	1996	Transmission control module	✓	✓	✓		
XJS	1996	Driver's seat module	✓	✓	✓		
XJS	1996	Climate control module	✓	✓	✓		
XJS	1996	Security system control module	✓	✓	✓		
XJS	1995	Anti-lock braking system	✓	✓	✓		
XJS	1995	Engine control module	✓	✓	✓		
XJS	1995	Transmission control module	✓	✓	✓		
XJS	1995	Driver's seat module	✓	✓	✓		
XJS	1995	Climate control module	✓	✓	✓		
XJS	1995	Security system control module	✓	✓	✓		

XJS	1994	Anti-lock braking system	✓	✓	✓		
XJS	1994	Engine control module	✓	✓	✓		
XJS	1994	Transmission control module	✓	✓	✓		
XJS	1994	Driver's seat module	✓	✓	✓		
XJS	1994	Climate control module	✓	✓	✓		
XJS	1994	Security system control module	✓	✓	✓		
XK8	2003	ABS control module	✓	✓	✓		
XK8	2003	Adaptive speed control control module.	✓	✓	✓		
XK8	2003	Left lighting control module	✓	✓	✓		
XK8	2003	Right lighting control module	✓	✓	✓		
XK8	2003	Adaptive damping ride control.	✓	✓	✓		
XK8	2003	Restraints control module	✓	✓	✓		
XK8	2003	Climate control module	✓	✓	✓		
XK8	2003	Driver's door module	✓	✓	✓		
XK8	2003	Driver's seat module	✓	✓	✓		
XK8	2003	Engine control module	✓	✓	✓		
XK8	2003	Instrument pack	✓	✓	✓		
XK8	2003	Parking aid control module.	✓	✓	✓		
XK8	2003	Transmission control module	✓	✓	✓		
XK8	2003	Body processor module	✓	✓	✓		
XK8	2003	Passenger's door module	✓	✓	✓		
XK8	2003	Security locking module.	✓	✓	✓		
XK8	2003	Passenger's seat module	✓	✓	✓		
XK8	2003	Passenger's head restraint module	✓	✓	✓		
XK8	2003	Driver's head restraint module	✓	✓	✓		
XK8	2003	Key transponder module.	✓	✓	✓		
XK8	2001	ABS control module	✓	✓	✓		
XK8	2001	Engine control module	✓	✓	✓		
XK8	2001	Instrument pack	✓	✓	✓		
XK8	2001	Transmission control module	✓	✓	✓		
XK8	2001	Adaptive speed control control module.	✓	✓			
XK8	2001	Adaptive speed control booster control module	✓	✓			
XK8	2001	Driver's seat module	✓	✓	✓		
XK8	2001	Passenger's seat module	✓	✓	✓		
XK8	2001	Security locking module.	✓	✓	✓		
XK8	2001	Passenger's door module	✓	✓	✓		
XK8	2001	Driver's door module	✓	✓	✓		
XK8	2001	Body processor module	✓	✓	✓		
XK8	2001	Driver's head restraint module	✓	✓	✓		
XK8	2001	Passenger's head restraint module	✓	✓	✓		
XK8	2001	Climate control module	✓	✓	✓		
XK8	2001	Restraints control module	✓	✓	✓		
XK8	2001	Adaptive damping system.	✓	✓	✓		
XK8	2001	Key transponder module.	✓	✓	✓		
XK8	2000	ABS control module	✓	✓	✓		
XK8	2000	Engine control module	✓	✓	✓		
XK8	2000	Instrument pack	✓	✓	✓		
XK8	2000	Transmission control module	✓	✓	✓		
XK8	2000	Adaptive speed control control module.	✓	✓			
XK8	2000	Adaptive speed control booster control module	✓	✓			
XK8	2000	Driver's seat module	✓	✓	✓		
XK8	2000	Passenger's seat module	✓	✓	✓		

XK8	2000	Security locking module.	✓	✓	✓		
XK8	2000	Passenger's door module	✓	✓	✓		
XK8	2000	Driver's door module	✓	✓	✓		
XK8	2000	Body processor module	✓	✓	✓		
XK8	2000	Climate control module	✓	✓	✓		
XK8	2000	Restraints control module	✓	✓	✓		
XK8	2000	Adaptive damping system.	✓	✓	✓		
XK8	2000	Key transponder module.	✓	✓	✓		
XK8	1999	ABS control module	✓	✓	✓		
XK8	1999	Engine control module	✓	✓	✓		
XK8	1999	Instrument pack	✓	✓	✓		
XK8	1999	Transmission control module	✓	✓	✓		
XK8	1999	Driver's seat module	✓	✓	✓		
XK8	1999	Passenger's seat module	✓	✓	✓		
XK8	1999	Security locking module.	✓	✓	✓		
XK8	1999	Passenger's door module	✓	✓	✓		
XK8	1999	Driver's door module	✓	✓	✓		
XK8	1999	Body processor module	✓	✓	✓		
XK8	1999	Climate control module	✓	✓	✓		
XK8	1999	Restraints control module	✓	✓	✓		
XK8	1999	Adaptive damping system.	✓	✓	✓		
XK8	1999	Key transponder module.	✓	✓	✓		
XK8	1998.75	ABS control module	✓	✓	✓		
XK8	1998.75	Engine control module	✓	✓	✓		
XK8	1998.75	Instrument pack	✓	✓	✓		
XK8	1998.75	Transmission control module	✓	✓	✓		
XK8	1998.75	Driver's seat module	✓	✓	✓		
XK8	1998.75	Passenger's seat module	✓	✓	✓		
XK8	1998.75	Security locking module.	✓	✓	✓		
XK8	1998.75	Passenger's door module	✓	✓	✓		
XK8	1998.75	Driver's door module	✓	✓	✓		
XK8	1998.75	Body processor module	✓	✓	✓		
XK8	1998.75	Climate control module	✓	✓	✓		
XK8	1998.75	Restraints control module	✓	✓	✓		
XK8	1998.75	Adaptive damping system.	✓	✓	✓		
XK8	1998.75	Key transponder module.	✓	✓	✓		
XK8	1998	ABS control module	✓	✓	✓		
XK8	1998	Engine control module	✓	✓	✓		
XK8	1998	Instrument pack	✓	✓	✓		
XK8	1998	Transmission control module	✓	✓	✓		
XK8	1998	Driver's seat module	✓	✓	✓		
XK8	1998	Passenger's seat module	✓	✓	✓		
XK8	1998	Security locking module.	✓	✓	✓		
XK8	1998	Passenger's door module	✓	✓	✓		
XK8	1998	Driver's door module	✓	✓	✓		
XK8	1998	Body processor module	✓	✓	✓		
XK8	1998	Climate control module	✓	✓	✓		
XK8	1998	Restraints control module	✓	✓	✓		
XK8	1998	Adaptive damping system.	✓	✓	✓		
XK8	1998	Key transponder module.	✓	✓	✓		
XK8	1997.25	ABS control module	✓	✓	✓		
XK8	1997.25	Engine control module	✓	✓	✓		

X-Type	2004-2009	Transmission control module	✓	✓	✓		
X-Type	2004-2009	Tire pressure monitor	✓	✓	✓		
X-Type	2004-2009	Voice activation control module.	✓	✓	✓		
X-Type	2004-2009	Engine control module	✓	✓	✓		
X-Type	2001-2003	Anti-lock braking system	✓	✓	✓		
X-Type	2001-2003	Climate control module	✓	✓	✓		
X-Type	2001-2003	Engine control module	✓	✓	✓		
X-Type	2001-2003	Instrument pack	✓	✓	✓		
X-Type	2001-2003	Transmission control module	✓	✓	✓		
X-Type	2001-2003	Restraints control module	✓	✓	✓		
X-Type	2001-2003	Audio unit.	✓	✓	✓		
X-Type	2001-2003	General electronics control module.	✓	✓	✓		
X-Type	2001-2003	Headlamp levelling system.	✓	✓	✓		
X-Type	2001-2003	Intrusion sensor module	✓	✓			
X-Type	2001-2003	Navigation control module	✓	✓	✓		
X-Type	2001-2003	Parking aid control module.	✓	✓	✓		
X-Type	2001-2003	Cellular telephone control module	✓	✓	✓		
X-Type	2001-2003	Voice activation control module.	✓	✓	✓		
XE	2016	ABS control module	✓	✓	✓		✓
XE	2016	Body control module	✓	✓	✓		✓
XE	2016	Speed control module	✓	✓	✓		
XE	2016	Gear shift module	✓	✓	✓		
XE	2016	Gateway module	✓	✓	✓		
XE	2016	Instrument cluster control module.	✓	✓	✓		✓
XE	2016	Restraints occupant classification system module	✓	✓	✓		
XE	2016	Powertrain control module	✓	✓	✓		✓
XE	2016	Powertrain control module	✓	✓	✓		✓
XE	2016	Powertrain control module	✓	✓	✓		✓
XE	2016	Restraints control module	✓	✓	✓		
XE	2016	Transmission control module	✓	✓	✓		
XE	2016	Throttle control unit.	✓	✓	✓		
XE	2016	Tire pressure monitor module	✓	✓	✓		
XE	2016	Vehicle immobilizer control module	✓	✓	✓		
XE	2016	All terrain control module	✓	✓	✓		
XE	2016	Chassis control module	✓	✓	✓		
XE	2016	Image processing control module A	✓	✓			
XE	2016	Parking assist control module	✓	✓	✓		
XE	2016	Power steering control module	✓	✓	✓		
XE	2016	Steering angle sensor module	✓	✓	✓		
XE	2016	Driver's door module	✓	✓	✓		✓
XE	2016	Driver's (side) rear door module.	✓	✓	✓		✓
XE	2016	Driver's seat module	✓	✓	✓		✓
XE	2016	Keyless vehicle module	✓	✓	✓		
XE	2016	Passenger's door module	✓	✓	✓		✓
XE	2016	Passenger's (side) rear door module.	✓	✓	✓		✓
XE	2016	Rear gate / trunk module	✓	✓	✓		
XE	2016	Deployable towbar control module	✓	✓	✓		
XE	2016	Audio head unit - Low line	✓	✓			
XE	2016	Head-up display cooling fan module	✓	✓	✓		
XE	2016	Connect and view module	✓	✓	✓		
XE	2016	Front control/display interface module (high level display front)	✓	✓	✓		

XE	2016	Front controls interface module (heating ventilation air conditioning controls)	✓	✓	✓		
XE	2016	Head up display	✓	✓			
XE	2016	Heating ventilation and air conditioning control module	✓	✓	✓		✓
XE	2016	Image processing module 'B'	✓	✓			
XE	2016	Navigation control module	✓	✓			
XE	2016	Side object detection control module - Left	✓	✓	✓		✓
XE	2016	Side object detection control module - Right	✓	✓	✓		✓
XE	2016	Audio amplifier module	✓	✓	✓		
XE	2016	Audio front control module	✓	✓	✓		
XE	2016	Digital audio broadcast module	✓	✓	✓		
XE	2016	Navigation control module	✓	✓	✓		
XE	2016	Satellite audio unit module.	✓	✓	✓		
XE	2016	Television module	✓	✓	✓		
XE	2017	ABS control module	✓	✓			✓
XE	2017	Body control module	✓	✓			✓
XE	2017	Speed control module	✓	✓			
XE	2017	Gear shift module	✓	✓			
XE	2017	Gateway module	✓	✓			
XE	2017	Instrument cluster control module.	✓	✓			✓
XE	2017	Restraints occupant classification system module	✓	✓			
XE	2017	Powertrain control module	✓	✓			✓
XE	2017	Powertrain control module	✓	✓			✓
XE	2017	Powertrain control module	✓	✓			
XE	2017	Restraints control module	✓	✓			
XE	2017	Transmission control module	✓	✓			
XE	2017	Throttle control unit.	✓	✓			
XE	2017	Tire pressure monitor module	✓	✓			
XE	2017	Vehicle immobilizer control module	✓	✓			✓
XE	2017	All terrain control module	✓	✓			✓
XE	2017	Chassis control module	✓	✓			
XE	2017	Image processing control module A	✓	✓			
XE	2017	Parking assist control module	✓	✓			
XE	2017	Power steering control module	✓	✓			
XE	2017	Steering angle sensor module	✓	✓			
XE	2017	Audio head unit - Low line	✓	✓			
XE	2017	Head-up display cooling fan module	✓	✓			
XE	2017	Front controls interface module (heating ventilation air conditioning controls)	✓	✓			
XE	2017	Head up display	✓	✓			✓
XE	2017	Heating ventilation and air conditioning control module	✓	✓			
XE	2017	InControl Touch Pro infotainment master controller	✓	✓			
XE	2017	Image processing module 'B'	✓	✓			
XE	2017	Side object detection control module - Left	✓	✓			
XE	2017	Side object detection control module - Right	✓	✓			✓
XE	2017	Driver's door module	✓	✓			✓
XE	2017	Driver's (side) rear door module.	✓	✓			✓
XE	2017	Driver's seat module	✓	✓			
XE	2017	Keyless vehicle module	✓	✓			✓
XE	2017	Passenger's door module	✓	✓			✓
XE	2017	Passenger's (side) rear door module.	✓	✓			

XE	2017	Rear gate / trunk module	✓	✓			
XE	2017	Deployable towbar control module	✓	✓			
XE	2017	Audio amplifier module	✓	✓			
XE	2018-	Body control module	✓	✓	✓	✓	
XE	2018-	Gateway module	✓	✓	✓	✓	
XE	2018-	Instrument cluster control module.	✓	✓	✓	✓	
XE	2018-	Powertrain control module	✓	✓	✓	✓	
NEW XF	2016-2017	ABS control module	✓	✓	✓		✓
NEW XF	2016-2017	Body control module	✓	✓	✓		✓
NEW XF	2016-2017	Speed control module	✓	✓	✓		
NEW XF	2016-2017	Gear shift module	✓	✓	✓		
NEW XF	2016-2017	Gateway module	✓	✓	✓		
NEW XF	2016-2017	Instrument cluster control module.	✓	✓			✓
NEW XF	2016-2017	Restraints occupant classification system module	✓	✓	✓		
NEW XF	2016-2017	Powertrain control module	✓	✓	✓		✓
NEW XF	2016-2017	Powertrain control module	✓	✓	✓		
NEW XF	2016-2017	Powertrain control module	✓	✓	✓		
NEW XF	2016-2017	Powertrain control module	✓	✓	✓		
NEW XF	2016-2017	Restraints control module	✓	✓	✓		
NEW XF	2016-2017	Transfer case control module	✓	✓	✓		
NEW XF	2016-2017	Transmission control module	✓	✓	✓		
NEW XF	2016-2017	Throttle control unit.	✓	✓	✓		
NEW XF	2016-2017	Tire pressure monitor module	✓	✓	✓		
NEW XF	2016-2017	Vehicle immobilizer control module	✓	✓	✓		
NEW XF	2016-2017	Audio head unit - Low line	✓	✓			
NEW XF	2016-2017	Head-up display cooling fan module	✓	✓	✓		✓
NEW XF	2016-2017	Front controls interface module (heating ventilation air conditioning controls)	✓	✓	✓		
NEW XF	2016-2017	Head up display	✓	✓			
NEW XF	2016-2017	Heating ventilation and air conditioning control module	✓	✓	✓		
NEW XF	2016-2017	InControl Touch Pro infotainment master controller	✓	✓	✓		
NEW XF	2016-2017	Image processing control module A	✓	✓			✓
NEW XF	2016-2017	Image processing module 'B'	✓	✓			✓
NEW XF	2016-2017	Rear Heating ventilation and air conditioning control module	✓	✓	✓		✓
NEW XF	2016-2017	Side object detection control module - Left	✓	✓	✓		✓
NEW XF	2016-2017	Side object detection control module - Right	✓	✓	✓		
NEW XF	2016-2017	All terrain control module	✓	✓	✓		
NEW XF	2016-2017	Chassis control module	✓	✓	✓		
NEW XF	2016-2017	Parking assist control module	✓	✓	✓		✓
NEW XF	2016-2017	Power steering control module	✓	✓	✓		✓
NEW XF	2016-2017	Steering angle sensor module	✓	✓	✓		✓
NEW XF	2016-2017	Driver's door module	✓	✓	✓		
NEW XF	2016-2017	Driver's (side) rear door module.	✓	✓	✓		✓
NEW XF	2016-2017	Driver's seat module	✓	✓	✓		✓
NEW XF	2016-2017	Keyless vehicle module	✓	✓	✓		✓
NEW XF	2016-2017	Passenger's door module	✓	✓	✓		
NEW XF	2016-2017	Passenger's (side) rear door module.	✓	✓	✓		
NEW XF	2016-2017	Passenger's seat module	✓	✓	✓		
NEW XF	2016-2017	Rear gate / trunk module	✓	✓	✓		
NEW XF	2016-2017	Deployable towbar control module	✓	✓	✓		
NEW XF	2016-2017	Audio amplifier module	✓	✓	✓		
NEW XF	2018-	Body control module	✓	✓	✓	✓	

NEW XF	2018-	Gateway module	✓	✓	✓	✓	
NEW XF	2018-	Instrument cluster control module.	✓	✓	✓	✓	
NEW XF	2018-	Powertrain control module	✓	✓	✓	✓	
F-PACE	2017	ABS control module	✓	✓			✓
F-PACE	2017	Body control module	✓	✓			✓
F-PACE	2017	Speed control module	✓	✓			
F-PACE	2017	Gear shift module	✓	✓			
F-PACE	2017	Gateway module	✓	✓			
F-PACE	2017	Instrument cluster control module.	✓	✓			✓
F-PACE	2017	Restraints occupant classification system module	✓	✓			
F-PACE	2017	Powertrain control module	✓	✓			✓
F-PACE	2017	Powertrain control module	✓	✓			
F-PACE	2017	Powertrain control module	✓	✓			
F-PACE	2017	Powertrain control module	✓	✓			
F-PACE	2017	Restraints control module	✓	✓			
F-PACE	2017	Transfer case control module	✓	✓			
F-PACE	2017	Transmission control module	✓	✓			
F-PACE	2017	Throttle control unit.	✓	✓			
F-PACE	2017	Tire pressure monitor module	✓	✓			
F-PACE	2017	Vehicle immobilizer control module	✓	✓			
F-PACE	2017	Audio head unit - Low line	✓	✓			
F-PACE	2017	Head-up display cooling fan module	✓	✓			✓
F-PACE	2017	Front controls interface module (heating ventilation air conditioning controls)	✓	✓			
F-PACE	2017	Head up display	✓	✓			
F-PACE	2017	Heating ventilation and air conditioning control module	✓	✓			
F-PACE	2017	InControl Touch Pro infotainment master controller	✓	✓			
F-PACE	2017	Image processing control module A	✓	✓			
F-PACE	2017	Image processing module 'B'	✓	✓			
F-PACE	2017	Rear Heating ventilation and air conditioning control module	✓	✓			✓
F-PACE	2017	Side object detection control module - Left	✓	✓			✓
F-PACE	2017	Side object detection control module - Right	✓	✓			
F-PACE	2017	All terrain control module	✓	✓			
F-PACE	2017	Chassis control module	✓	✓			
F-PACE	2017	Parking assist control module	✓	✓			✓
F-PACE	2017	Power steering control module	✓	✓			✓
F-PACE	2017	Steering angle sensor module	✓	✓			✓
F-PACE	2017	Driver's door module	✓	✓			
F-PACE	2017	Driver's (side) rear door module.	✓	✓			✓
F-PACE	2017	Driver's seat module	✓	✓			✓
F-PACE	2017	Keyless vehicle module	✓	✓			✓
F-PACE	2017	Passenger's door module	✓	✓			
F-PACE	2017	Passenger's (side) rear door module.	✓	✓			
F-PACE	2017	Passenger's seat module	✓	✓			
F-PACE	2017	Rear gate / trunk module	✓	✓			
F-PACE	2017	Deployable towbar control module	✓	✓			
F-PACE	2017	Audio amplifier module	✓	✓			
F-PACE	2018-	Body control module	✓	✓	✓		
F-PACE	2018-	Gateway module	✓	✓	✓		
F-PACE	2018-	Instrument cluster control module.	✓	✓	✓		
F-PACE	2018-	Powertrain control module	✓	✓	✓		

F-Type	2016-2017	Body control module	✓	✓	✓		✓
F-Type	2016-2017	Gear shift module	✓	✓	✓		
F-Type	2016-2017	Gateway module	✓	✓	✓		
F-Type	2016-2017	Headlamp control module	✓	✓	✓		
F-Type	2016-2017	Instrument cluster control module.	✓	✓	✓		✓
F-Type	2016-2017	Powertrain control module	✓	✓	✓		✓
F-Type	2016-2017	Powertrain control module	✓	✓	✓		✓
F-Type	2016-2017	Rear differential control module	✓	✓	✓		
F-Type	2016-2017	Transfer case control module	✓	✓	✓		
F-Type	2016-2017	Transmission control module	✓	✓	✓		
F-Type	2016-2017	Throttle control unit.	✓	✓	✓		
F-Type	2016-2017	Tire pressure monitor module	✓	✓	✓		
F-Type	2016-2017	Vehicle immobilizer control module	✓	✓	✓		
F-Type	2016-2017	ABS control module	✓	✓	✓		✓
F-Type	2016-2017	All terrain control module	✓	✓	✓		✓
F-Type	2016-2017	Chassis control module	✓	✓	✓		✓
F-Type	2016-2017	Folding top control module	✓	✓	✓		
F-Type	2016-2017	Folding top control module B	✓	✓	✓		
F-Type	2016-2017	Image processing control module A	✓	✓			
F-Type	2016-2017	Restraints occupant classification system module	✓	✓	✓		
F-Type	2016-2017	Parking assist control module	✓	✓	✓		
F-Type	2016-2017	Parking brake control module	✓	✓	✓		
F-Type	2016-2017	Power steering control module	✓	✓	✓		
F-Type	2016-2017	Restraints control module	✓	✓	✓		
F-Type	2016-2017	Steering angle sensor module	✓	✓	✓		
F-Type	2016-2017	Driver's door module	✓	✓	✓		
F-Type	2016-2017	Driver's seat module	✓	✓	✓		✓
F-Type	2016-2017	Keyless vehicle module	✓	✓	✓		
F-Type	2016-2017	Passenger's door module	✓	✓	✓		
F-Type	2016-2017	Passenger's seat module	✓	✓	✓		✓
F-Type	2016-2017	Rear gate / trunk module	✓	✓	✓		
F-Type	2016-2017	Audio head unit - Low line	✓	✓			
F-Type	2016-2017	Connect and view module	✓	✓	✓		
F-Type	2016-2017	Front control/display interface module (high level display front)	✓	✓	✓		
F-Type	2016-2017	Front controls interface module (heating ventilation air conditioning controls)	✓	✓	✓		
F-Type	2016-2017	Heating ventilation and air conditioning control module	✓	✓	✓		✓
F-Type	2016-2017	Image processing module 'B'	✓	✓			
F-Type	2016-2017	Navigation control module	✓	✓			
F-Type	2016-2017	Side object detection control module - Left	✓	✓	✓		✓
F-Type	2016-2017	Side object detection control module - Right	✓	✓	✓		✓
F-Type	2016-2017	Audio amplifier module	✓	✓	✓		
F-Type	2016-2017	Audio front control module	✓	✓	✓		
F-Type	2016-2017	Digital audio broadcast module	✓	✓	✓		
F-Type	2016-2017	Navigation control module	✓	✓	✓		
F-Type	2016-2017	Satellite audio unit module.	✓	✓	✓		
F-Type	2016-2017	Television module	✓	✓			
F-Type	2018-	Audio amplifier module	✓	✓	✓	✓	
F-Type	2018-	ABS control module	✓	✓	✓	✓	
F-Type	2018-	Audio front control module	✓	✓	✓	✓	
F-Type	2018-	All terrain control module	✓	✓	✓	✓	
F-Type	2018-	Body control module	✓	✓	✓	✓	

F-Type	2018-	Chassis control module	✓	✓	✓	✓	
F-Type	2018-	Driver's door module	✓	✓	✓	✓	
F-Type	2018-	Driver's seat module	✓	✓	✓	✓	
F-Type	2018-	Front control/display interface module (high level display front)	✓	✓	✓	✓	
F-Type	2018-	Front controls interface module (heating ventilation air conditioning controls)	✓	✓	✓	✓	
F-Type	2018-	Folding top control module B	✓	✓	✓	✓	
F-Type	2018-	Interior Sensing Module	✓	✓	✓	✓	
F-Type	2018-	Gear shift module	✓	✓	✓	✓	
F-Type	2018-	Gateway module	✓	✓	✓	✓	
F-Type	2018-	Headlamp Control Module 'A'	✓	✓	✓	✓	
F-Type	2018-	Headlamp Control Module 'B'	✓	✓	✓	✓	
F-Type	2018-	Heating ventilation and air conditioning control module	✓	✓	✓	✓	
F-Type	2018-	Infotainment master controller	✓	✓	✓	✓	
F-Type	2018-	Instrument cluster control module.	✓	✓	✓	✓	
F-Type	2018-	Image processing control module A	✓	✓	✓	✓	
F-Type	2018-	Image processing module 'B'	✓	✓	✓	✓	
F-Type	2018-	Navigation control module	✓	✓	✓	✓	
F-Type	2018-	Restraints occupant classification system module	✓	✓	✓	✓	
F-Type	2018-	Parking assist control module	✓	✓	✓	✓	
F-Type	2018-	Parking brake control module	✓	✓	✓	✓	
F-Type	2018-	Powertrain control module	✓	✓	✓	✓	
F-Type	2018-	Passenger's door module	✓	✓	✓	✓	
F-Type	2018-	Power steering control module	✓	✓	✓	✓	
F-Type	2018-	Passenger's seat module	✓	✓	✓	✓	
F-Type	2018-	Restraints control module	✓	✓	✓	✓	
F-Type	2018-	Rear differential control module	✓	✓	✓	✓	
F-Type	2018-	Remote function actuator	✓	✓	✓	✓	
F-Type	2018-	Rear gate / trunk module	✓	✓	✓	✓	
F-Type	2018-	Satellite Radio Module [SARM]	✓	✓	✓	✓	
F-Type	2018-	Steering angle sensor module	✓	✓	✓	✓	
F-Type	2018-	Side object detection control module - Left	✓	✓	✓	✓	
F-Type	2018-	Side object detection control module - Right	✓	✓	✓	✓	
F-Type	2018-	Transfer case control module	✓	✓	✓	✓	
F-Type	2018-	Transmission control module	✓	✓	✓	✓	
F-Type	2018-	Throttle control unit.	✓	✓	✓	✓	
F-Type	2018-	Telephone Control Module [TEL]	✓	✓	✓	✓	
F-Type	2018-	Tire pressure monitor module	✓	✓	✓	✓	
F-Type	2018-	Television module	✓	✓	✓	✓	
F-Type	2018-	Vehicle immobilizer control module	✓	✓	✓	✓	
XJ	2016	ABS control module	✓	✓	✓		✓
XJ	2016	Body control module	✓	✓	✓		✓
XJ	2016	Speed control module	✓	✓	✓		
XJ	2016	Gear shift module	✓	✓	✓		
XJ	2016	Gateway module	✓	✓	✓		
XJ	2016	Headlamp control module	✓	✓	✓		
XJ	2016	Restraints occupant classification system module	✓	✓	✓		
XJ	2016	Parking brake control module	✓	✓	✓		
XJ	2016	Powertrain control module	✓	✓	✓		✓
XJ	2016	Powertrain control module	✓	✓	✓		✓
XJ	2016	Powertrain control module	✓	✓	✓		✓
XJ	2016	Powertrain control module	✓	✓	✓		✓

XJ	2016	Restraints control module	✓	✓	✓		
XJ	2016	Rear differential control module	✓	✓	✓		
XJ	2016	Transfer case control module	✓	✓	✓		
XJ	2016	Transmission control module	✓	✓	✓		
XJ	2016	Throttle control unit.	✓	✓	✓		
XJ	2016	Tire pressure monitor module	✓	✓	✓		
XJ	2016	Vehicle immobilizer control module	✓	✓	✓		
XJ	2016	InControl Touch Pro infotainment master controller	✓	✓	✓		
XJ	2016	Front controls interface module (heating ventilation air conditioning controls)	✓	✓	✓		
XJ	2016	Heating ventilation and air conditioning control module	✓	✓	✓		✓
XJ	2016	Instrument cluster control module.	✓	✓	✓		✓
XJ	2016	Image processing module 'B'	✓	✓	✓		
XJ	2016	Rear Heating ventilation and air conditioning control module	✓	✓	✓		
XJ	2016	Side object detection control module - Left	✓	✓	✓		✓
XJ	2016	Side object detection control module - Right	✓	✓	✓		✓
XJ	2016	Chassis control module	✓	✓	✓		
XJ	2016	Image processing control module A	✓	✓	✓		
XJ	2016	Parking assist control module	✓	✓	✓		
XJ	2016	Power steering control module	✓	✓	✓		
XJ	2016	Steering angle sensor module	✓	✓	✓		
XJ	2016	Vehicle dynamics control module	✓	✓	✓		
XJ	2016	Driver's door module	✓	✓	✓		
XJ	2016	Driver's seat module	✓	✓	✓		✓
XJ	2016	Keyless vehicle module	✓	✓	✓		
XJ	2016	Passenger's door module	✓	✓	✓		
XJ	2016	Passenger's seat module	✓	✓	✓		✓
XJ	2016	Rear gate / trunk module	✓	✓	✓		
XJ	2016	Rear seat - Control module - Left	✓	✓	✓		
XJ	2016	Rear seat - Control module - Right	✓	✓	✓		
XJ	2016	Audio amplifier module	✓	✓	✓		
E-Pace	2018-	Audio amplifier module	✓	✓	✓	✓	
E-Pace	2018-	ABS control module	✓	✓	✓	✓	
E-Pace	2018-	All terrain control module	✓	✓	✓	✓	
E-Pace	2018-	All Wheel Drive Module	✓	✓	✓	✓	
E-Pace	2018-	Body control module	✓	✓	✓	✓	
E-Pace	2018-	Speed control module	✓	✓	✓	✓	
E-Pace	2018-	Chassis control module	✓	✓	✓	✓	
E-Pace	2018-	Driver's door module	✓	✓	✓	✓	
E-Pace	2018-	Driver's (side) rear door module.	✓	✓	✓	✓	
E-Pace	2018-	Driver's seat module	✓	✓	✓	✓	
E-Pace	2018-	Gear shift module	✓	✓	✓	✓	
E-Pace	2018-	Gateway module	✓	✓	✓	✓	
E-Pace	2018-	Headlamp Control Module 'A'	✓	✓	✓	✓	
E-Pace	2018-	Headlamp Control Module 'B'	✓	✓	✓	✓	
E-Pace	2018-	Head up display	✓	✓	✓	✓	
E-Pace	2018-	Heating ventilation and air conditioning control module	✓	✓	✓	✓	
E-Pace	2018-	Infotainment master controller	✓	✓	✓	✓	
E-Pace	2018-	Instrument cluster control module.	✓	✓	✓	✓	
E-Pace	2018-	Image processing control module A	✓	✓	✓	✓	
E-Pace	2018-	Image processing module 'B'	✓	✓	✓	✓	

E-Pace	2018-	Restraints occupant classification system module	✓	✓	✓	✓	
E-Pace	2018-	Occupant Monitoring Module	✓	✓	✓	✓	
E-Pace	2018-	Parking assist control module	✓	✓	✓	✓	
E-Pace	2018-	Powertrain control module	✓	✓	✓	✓	
E-Pace	2018-	Passenger's door module	✓	✓	✓	✓	
E-Pace	2018-	Passenger's (side) rear door module.	✓	✓	✓	✓	
E-Pace	2018-	Power steering control module	✓	✓	✓	✓	
E-Pace	2018-	Passenger's seat module	✓	✓	✓	✓	
E-Pace	2018-	Restraints control module	✓	✓	✓	✓	
E-Pace	2018-	Remote function actuator	✓	✓	✓	✓	
E-Pace	2018-	Rear gate / trunk module	✓	✓	✓	✓	
E-Pace	2018-	Rear Heating ventilation and air conditioning control module	✓	✓	✓	✓	
E-Pace	2018-	Steering angle sensor module	✓	✓	✓	✓	
E-Pace	2018-	Side object detection control module - Left	✓	✓	✓	✓	
E-Pace	2018-	Side object detection control module - Right	✓	✓	✓	✓	
E-Pace	2018-	Tow Bar Control Module	✓	✓	✓	✓	
E-Pace	2018-	Transmission control module	✓	✓	✓	✓	
E-Pace	2018-	Throttle control unit.	✓	✓	✓	✓	
E-Pace	2018-	Tire pressure monitor module	✓	✓	✓	✓	
E-Pace	2018-	Vehicle immobilizer control module	✓	✓	✓	✓	
I-Pace	2019-	Body control module	✓	✓	✓	✓	
I-Pace	2019-	Gateway module	✓	✓	✓	✓	
I-Pace	2019-	Instrument cluster control module.	✓	✓	✓	✓	
I-Pace	2019-	Powertrain control module	✓	✓	✓	✓	

Special Functions List

Model	Year	Functions Name
New XK	2006. 5-2009	Seat cushion replacement
New XK	2006. 5-2009	Driver's memory seat calibration.
New XK	2006. 5-2009	Tire pressure monitor confirmation application.
New XK	2006. 5-2009	Powertrain control module adaption clear.
New XK	2006. 5-2009	Yaw rate sensor calibration.
New XK	2006. 5-2009	Driver's side - Door glass window calibration
New XK	2006. 5-2009	Passenger's side - Door glass window calibration
New XK	2006. 5-2009	Lateral accelerometer calibration.
New XK	2006. 5-2009	Pressure sensor calibration.
New XK	2006. 5-2009	Transmission Control Module Adaptive Clearance
New XK	2006. 5-2009	Vehicle reset
New XK	2006. 5-2009	Parking brake release to the service position
New XK	2006. 5-2009	Tire pressure sensor replacement
New XK	2006. 5-2009	Tire pressure monitor receiver calibration
New XK	2006. 5-2009	Tire pressure monitoring tire pressure sensor test
New XK	2006. 5-2009	Configure the new module. -Tire pressure monitor module
New XK	2006. 5-2009	Software enhancement program-rearview mirror personalization function

New XK	2006.5-2009	Powertrain-Self-check of purge valve.
New XK	2006.5-2009	Driveline-drive shaft balance
New XK	2006.5-2009	Add/remove accessories. -Rearview mirror personalization function
New XK	2010-2014	Seat cushion replacement
New XK	2010-2014	Driver's memory seat calibration.
New XK	2010-2014	Brake bleed
New XK	2010-2014	Tire pressure monitor confirmation application.
New XK	2010-2014	Tire pressure monitoring sensor identification display
New XK	2010-2014	Transmission Control Module Adaptive Clearance
New XK	2010-2014	Powertrain Control Module Adaptive Clearance
New XK	2010-2014	Check engine oil level
New XK	2010-2014	Oil maintenance counter reset
New XK	2010-2014	Let the oil level reset
New XK	2010-2014	The parking brake is released to the service position
New XK	2010-2014	Battery replacement
New XK	2010-2014	Vehicle reset
New XK	2010-2014	Customer side door glass window calibration
New XK	2010-2014	Driver side door glazing calibration
New XK	2010-2014	Parking brake release to the service position
New XK	2010-2014	Tire pressure sensor replacement
New XK	2010-2014	Tire pressure monitor receiver calibration
New XK	2010-2014	Tire pressure monitoring tire pressure sensor test
New XK	2010-2014	Height sensor-calibration
New XK	2010-2014	Adaptive damping control module
New XK	2010-2014	Configure the new module. -Audio amplifier module.
New XK	2010-2014	Configure the new module. -ABS control module
New XK	2010-2014	Configure the new module. -Auxiliary protocol interface module
New XK	2010-2014	Configure the new module. -Digital Audio Broadcasting Module
New XK	2010-2014	Configure the new module. -Digital Audio Control Module C
New XK	2010-2014	Configure the new module. -Front control/display interface module (high-level display front)
New XK	2010-2014	Configure the new module. -Foldable roof control module
New XK	2010-2014	Configure the new module. -Shift module
New XK	2010-2014	Configure the new module. -Headlight control module
New XK	2010-2014	Configure the new module. -Heating air conditioning control module
New XK	2010-2014	Configure the new module. -Integrated control panel
New XK	2010-2014	Configure the new module. -Navigation control module
New XK	2010-2014	Configure the new module. -Parking aid control module
New XK	2010-2014	Configure the new module. -Parking brake control module
New XK	2010-2014	Configure the new module. -Restricted occupant classification system module
New XK	2010-2014	Configure the new module. -Satellite audio unit module.
New XK	2010-2014	Configure the new module. -Speed ??control module
New XK	2010-2014	Seat-replacement seat cover
New XK	2010-2014	Heating and ventilation-stepper motor initialization
New XK	2010-2014	Rear differential control module. -Control module calibration
New XK	2010-2014	Active damping control module-establishment mode
New XK	2010-2014	Active vibration reduction control module-calibration acquisition
New XK	2010-2014	Powertrain-Self-check of purge valve.
New XK	2010-2014	Powertrain-Evaporation System Diagnostic Test
New XK	2010-2014	Powertrain-fuel preparation routine
New XK	2010-2014	Powertrain-Fuel Lift Pump
New XK	2010-2014	Power Train-Engine Control Module VIN Reading Application
New XK	2010-2014	Add/remove accessories. -Rearview mirror personalization function

New XK	2010-2014	Add/remove accessories. -Combination instrument-Russian option
New XK	2010-2014	Drive train-repair history data
XJ	2006	Reset the oil service counter
XJ	2006	Tire pressure monitor receiver calibration.
XJ	2008-2009	Yaw rate sensor calibration.
XJ	2008-2009	Reset the oil service counter
XJ	2008-2009	Tire pressure monitor receiver calibration.
XJ	2008-2009	Parking brake release to service position
XJ	2008-2009	Lateral accelerometer calibration.
XJ	2008-2009	Pressure sensor calibration.
NEW XJ	2010-2012	Driver's memory seat calibration.
NEW XJ	2010-2012	Brake bleed
NEW XJ	2010-2012	Diesel particulate filter replacement
NEW XJ	2010-2012	Powertrain control module adaption clear.
NEW XJ	2010-2012	Oil service counter reset
NEW XJ	2010-2012	Reset water in fuel detection
NEW XJ	2010-2012	Turbine shut-off valve
NEW XJ	2010-2012	Throttle valve actuator
NEW XJ	2010-2012	Exhaust gas recirculation valve
NEW XJ	2010-2012	Oxygen sensor
NEW XJ	2010-2012	Oxidation catalyst
NEW XJ	2010-2012	Tire pressure monitoring sensor identification display
NEW XJ	2010-2012	Transmission Control Module Adaptive Clearance
NEW XJ	2010-2012	Diesel particulate filter dynamic regeneration
NEW XJ	2010-2012	Powertrain Control Module Adaptive Clearance
NEW XJ	2010-2012	Show injector correction factor
NEW XJ	2010-2012	Anti-theft locker antenna unit function check
NEW XJ	2010-2012	Check all antennas
NEW XJ	2010-2012	The parking brake is released to the service position
NEW XJ	2010-2012	Replace the seat cover
NEW XJ	2010-2012	Battery replacement
NEW XJ	2010-2012	Vehicle reset
NEW XJ	2010-2012	Check before departure
NEW XJ	2010-2012	Other countries and regions of the world - Maintenance interval options
NEW XJ	2010-2012	Maintenance interval reset
NEW XJ	2010-2012	Constraint build mode
NEW XJ	2010-2012	Side Object Detection Module History
NEW XJ	2010-2012	Customer side door glass window calibration
NEW XJ	2010-2012	Driver side door glazing calibration
NEW XJ	2010-2012	Phase 1 - Preparation - Important Notes
NEW XJ	2010-2012	Phase 4 - Front Control / Display Interface Module Update Part A
NEW XJ	2010-2012	Altitude Calibration
NEW XJ	2010-2012	Air suspension deflation
NEW XJ	2010-2012	Air suspension inflation
NEW XJ	2010-2012	Set/Cancel Air Suspension Geometry Settings
NEW XJ	2010-2012	Set/Cancel Air Suspension Precision Tolerance Mode (Headlight Setting)
NEW XJ	2010-2012	Ride level control module diagnostic interface
NEW XJ	2010-2012	Ride level control module inflation (showroom)
NEW XJ	2010-2012	Display injector correction factors
NEW XJ	2010-2012	Parking brake release to the service position
NEW XJ	2010-2012	Tire pressure monitoring tire pressure sensor test
NEW XJ	2010-2012	Sunroof calibration

NEW XJ	2010-2012	Tailgate/trunk calibration
NEW XJ	2010-2012	Special application-Dashboard virtual display diagnostic application
NEW XJ	2010-2012	Tire pressure monitoring system-tire pressure sensor replacement
NEW XJ	2010-2012	Configure the new module. -ABS control module
NEW XJ	2010-2012	Configure the new module. -Adaptive damping control module
NEW XJ	2010-2012	Configure the new module. -Digital Audio Broadcasting Module
NEW XJ	2010-2012	Configure the new module. -Front control/display interface module (high-level display front)
NEW XJ	2010-2012	Configure the new module. -Shift module
NEW XJ	2010-2012	Configure the new module. -Headlamp control module'B'
NEW XJ	2010-2012	Configure the new module. -Rear climate control module
NEW XJ	2010-2012	Configure the new module. -Front control interface module 'B' (front audio control panel)
NEW XJ	2010-2012	Configure the new module. -Navigation control module
NEW XJ	2010-2012	Configure the new module. -Parking aid control module
NEW XJ	2010-2012	Configure the new module. -Parking brake control module
NEW XJ	2010-2012	Configure the new module. -Restricted occupant classification system module
NEW XJ	2010-2012	Configure the new module. -Satellite audio unit module.
NEW XJ	2010-2012	Configure the new module. -Side object detection control module-left
NEW XJ	2010-2012	Configure the new module. -Speed ??control module
NEW XJ	2010-2012	Configure the new module. -Rear climate seat module
NEW XJ	2010-2012	Body system-valet parking mode reset
NEW XJ	2010-2012	Powertrain settings-fuel water detection reset
NEW XJ	2010-2012	Drivetrain settings-throttle actuator
NEW XJ	2010-2012	Drive train settings-turbine shut-off valve
NEW XJ	2010-2012	Drive train settings-oxygen sensor
NEW XJ	2010-2012	Drivetrain settings-oxidation catalyst
NEW XJ	2010-2012	Rear differential control module. -Control module calibration
NEW XJ	2010-2012	Suspension system-set/cancel air suspension manufacturing/freeze mode
NEW XJ	2010-2012	Active damping control module-establishment mode
NEW XJ	2010-2012	Active vibration reduction control module-calibration acquisition
NEW XJ	2010-2012	Audio system. -Calibration dynamic quantity control
NEW XJ	2010-2012	Special application-transmission mode
NEW XJ	2010-2012	Powertrain-Self-check of purge valve.
NEW XJ	2010-2012	Powertrain-Evaporation System Diagnostic Test
NEW XJ	2010-2012	Powertrain-fuel preparation routine
NEW XJ	2010-2012	Powertrain-Fuel Lift Pump
NEW XJ	2010-2012	Powertrain-diesel particulate filter replacement
NEW XJ	2010-2012	Drive train-oil service counter reset
NEW XJ	2010-2012	Power Train-Engine Control Module VIN Reading Application
NEW XJ	2010-2012	Entertainment system-reset navigation
NEW XJ	2010-2012	Entertainment system-DVD zone counter reset
NEW XJ	2010-2012	Configure the new module. -Electric tailgate
NEW XJ	2010-2012	Configure the new module. -Right seat belt pretensioner
NEW XJ	2010-2012	Configure the new module. -Left seat belt pretensioner
NEW XJ	2010-2012	Body System-Tailgate/Luggage Compartment Calibration
NEW XJ	2010-2012	Body system-variable assist power steering curve path programming.
NEW XJ	2010-2012	Heating and ventilation-vent actuator test
NEW XJ	2010-2012	Heating and ventilation-stepper motor initialization
NEW XJ	2010-2012	Heating and ventilation-evaporator and heater testing
NEW XJ	2010-2012	Side Object Detection-History of Side Object Detection Module
NEW XJ	2010-2012	Drive train-repair history data
NEW XJ	2010-2012	Seat belt pretensioner system-seat belt dynamic retraction and release
NEW XJ	2010-2012	Seat belt pretensioner system-clear module learning data

NEW XJ	2013-2015	Brake bleed
NEW XJ	2013-2015	Diesel particulate filter replacement
NEW XJ	2013-2015	Powertrain control module adaption clear.
NEW XJ	2013-2015	Yaw rate sensor calibration.
NEW XJ	2013-2015	Reset water in fuel detection
NEW XJ	2013-2015	Turbine shut-off valve
NEW XJ	2013-2015	Throttle valve actuator
NEW XJ	2013-2015	Exhaust gas recirculation valve
NEW XJ	2013-2015	Oxygen sensor
NEW XJ	2013-2015	Oxidation catalyst
NEW XJ	2013-2015	Throttle valve actuator replacement
NEW XJ	2013-2015	Tire pressure monitoring sensor identification display
NEW XJ	2013-2015	Transmission Control Module Adaptive Clearance
NEW XJ	2013-2015	Diesel particulate filter dynamic regeneration
NEW XJ	2013-2015	Powertrain Control Module Adaptive Clearance
NEW XJ	2013-2015	Engine Control Module Unlocking Application
NEW XJ	2013-2015	Throttle Valve Brake Replacement
NEW XJ	2013-2015	Injector valve test
NEW XJ	2013-2015	Fuel preparation routine
NEW XJ	2013-2015	Show injector correction factor
NEW XJ	2013-2015	Oil maintenance counter reset
NEW XJ	2013-2015	Anti-theft locker antenna unit function check
NEW XJ	2013-2015	Check all antennas
NEW XJ	2013-2015	The parking brake is released to the service position
NEW XJ	2013-2015	Replace the seat cover
NEW XJ	2013-2015	Starting TV Test Picture
NEW XJ	2013-2015	Applications for Information and Entertainment Systems
NEW XJ	2013-2015	Testing Dual Battery Systems
NEW XJ	2013-2015	Battery replacement
NEW XJ	2013-2015	Static current control module internal inspection
NEW XJ	2013-2015	Verify auxiliary battery charging
NEW XJ	2013-2015	Set/Cancel Air Suspension Precision Tolerance Mode (Headlight Setting)
NEW XJ	2013-2015	Set/Cancel Air Suspension Geometry Settings
NEW XJ	2013-2015	Vehicle reset
NEW XJ	2013-2015	Check before departure
NEW XJ	2013-2015	Other countries and regions of the world - Maintenance interval options
NEW XJ	2013-2015	Maintenance interval reset
NEW XJ	2013-2015	Constraint build mode
NEW XJ	2013-2015	Customer side door glass window calibration
NEW XJ	2013-2015	Personal side rear door sunshade initialization
NEW XJ	2013-2015	Driver side door glazing calibration
NEW XJ	2013-2015	Driver side rear door sunshade initialization
NEW XJ	2013-2015	Altitude Calibration
NEW XJ	2013-2015	Air suspension deflation
NEW XJ	2013-2015	Air suspension inflation
NEW XJ	2013-2015	Ride level control module diagnostic interface
NEW XJ	2013-2015	Ride level control module inflation (showroom)
NEW XJ	2013-2015	Display injector correction factors
NEW XJ	2013-2015	Parking brake release to the service position
NEW XJ	2013-2015	Tire pressure monitoring tire pressure sensor test
NEW XJ	2013-2015	Sunroof calibration
NEW XJ	2013-2015	Tailgate/trunk calibration

NEW XJ	2013-2015	Special application-Dashboard virtual display diagnostic application
NEW XJ	2013-2015	Tire pressure monitoring system-tire pressure sensor replacement
NEW XJ	2013-2015	Configure the new module. -ABS control module
NEW XJ	2013-2015	Configure the new module. -Digital Audio Broadcasting Module
NEW XJ	2013-2015	Configure the new module. -Front control/display interface module (high-level display front)
NEW XJ	2013-2015	Configure the new module. -Shift module
NEW XJ	2013-2015	Configure the new module. -Headlamp control module'B'
NEW XJ	2013-2015	Configure the new module. -Rear climate control module
NEW XJ	2013-2015	Configure the new module. -Front control interface module 'B' (front audio control panel)
NEW XJ	2013-2015	Configure the new module. -Navigation control module
NEW XJ	2013-2015	Configure the new module. -Parking aid control module
NEW XJ	2013-2015	Configure the new module. -Restricted occupant classification system module
NEW XJ	2013-2015	Configure the new module. -Satellite audio unit module.
NEW XJ	2013-2015	Configure the new module. -Side object detection control module-left
NEW XJ	2013-2015	Configure the new module. -Speed ??control module
NEW XJ	2013-2015	Configure the new module. -Rear climate seat module
NEW XJ	2013-2015	Braking system-yaw rate sensor calibration.
NEW XJ	2013-2015	Body system-valet parking mode reset
NEW XJ	2013-2015	Powertrain settings-fuel water detection reset
NEW XJ	2013-2015	Drivetrain settings-throttle actuator
NEW XJ	2013-2015	Drive train settings-turbine shut-off valve
NEW XJ	2013-2015	Drive train settings-oxygen sensor
NEW XJ	2013-2015	Drivetrain settings-oxidation catalyst
NEW XJ	2013-2015	Rear differential control module. -Control module calibration
NEW XJ	2013-2015	Suspension system-set/cancel air suspension manufacturing/freeze mode
NEW XJ	2013-2015	Audio system. -Calibration dynamic quantity control
NEW XJ	2013-2015	Transfer case-calibration clutch.
NEW XJ	2013-2015	Transfer case-oil replacement reset
NEW XJ	2013-2015	Special application-transmission mode
NEW XJ	2013-2015	Powertrain-Fuel Lift Pump
NEW XJ	2013-2015	Powertrain-diesel particulate filter replacement
NEW XJ	2013-2015	Power Train-Fuel Pump Supply Pipe-Enable/Disable
NEW XJ	2013-2015	Entertainment system-reset navigation
NEW XJ	2013-2015	Entertainment system-DVD zone counter reset
NEW XJ	2013-2015	Configure the new module. -Electric tailgate
NEW XJ	2013-2015	Body System-Tailgate/Luggage Compartment Calibration
NEW XJ	2013-2015	Body system-variable assist power steering curve path programming.
NEW XJ	2013-2015	Heating and ventilation-vent actuator test
NEW XJ	2013-2015	Heating and ventilation-stepper motor initialization
NEW XJ	2013-2015	Heating and ventilation-evaporator and heater testing
NEW XJ	2013-2015	Powertrain-Engine Control Module Unlock Application
NEW XJ	2013-2015	Entertainment system-dedicated applications for information and entertainment systems
NEW XJ	2016	Brake bleed
NEW XJ	2016	Steering column calibration
NEW XJ	2016	Oil change reset
NEW XJ	2016	Throttle valve actuator replacement
NEW XJ	2016	Auto oil reset
NEW XJ	2016	Service interval reset
NEW XJ	2016	Replace brake pads -operating guide
NEW XJ	2016	Oil service counter reset
NEW XJ	2016	Front left wheel sensor
NEW XJ	2016	Front right wheel sensor

NEW XJ	2016	Rear right wheel sensor
NEW XJ	2016	Rear left wheel sensor
NEW XJ	2016	Spare wheel
NEW XJ	2016	Power steering soft-lock end stops reset routine
NEW XJ	2016	Lock steering tune to vehicle
NEW XJ	2016	Yaw rate sensor calibration.
NEW XJ	2016	Tire pressure monitoring sensor identification display
NEW XJ	2016	Reset Selective Catalytic Reduction Start Prohibition
NEW XJ	2016	Resetting the Selective Catalytic Reduction Mass Monitor
NEW XJ	2016	Transmission Control Module Adaptive Clearance
NEW XJ	2016	Diesel exhaust gas oil infusion and pressure test
NEW XJ	2016	Diesel exhaust gas tank level sensor replacement
NEW XJ	2016	Diesel exhaust gas jet pump replacement
NEW XJ	2016	Diesel particulate filter dynamic regeneration
NEW XJ	2016	This routine will reset flight recorder data
NEW XJ	2016	Powertrain Control Module Adaptive Clearance
NEW XJ	2016	Engine Control Module Low Pressure EGR Adaptive Value Clearance
NEW XJ	2016	Engine Control Module Resets Crankcase Pressure Sensor
NEW XJ	2016	Engine Control Module Unlocking Application
NEW XJ	2016	Engine Control Module Mass Air Flow Adaptive Value Clearance
NEW XJ	2016	Throttle Valve Brake Replacement
NEW XJ	2016	Exhaust valve adaptation
NEW XJ	2016	Injector valve test
NEW XJ	2016	Enable/Disable Glow Plug
NEW XJ	2016	Fuel preparation routine
NEW XJ	2016	Show injector correction factor
NEW XJ	2016	Check all antennas
NEW XJ	2016	Parking Brake Start
NEW XJ	2016	Remote Information Processing SIM Card Type
NEW XJ	2016	Battery replacement
NEW XJ	2016	Static current control module internal inspection
NEW XJ	2016	Set/Cancel Air Suspension Precision Tolerance Mode (Headlight Setting)
NEW XJ	2016	Set/Cancel Air Suspension Geometry Settings
NEW XJ	2016	IPMA AEB Data Reading
NEW XJ	2016	Vehicle reset
NEW XJ	2016	Check before departure
NEW XJ	2016	Customer side door glass window calibration
NEW XJ	2016	Personal side rear door sunshade initialization
NEW XJ	2016	Driver side door glazing calibration
NEW XJ	2016	Driver side rear door sunshade initialization
NEW XJ	2016	Altitude Calibration
NEW XJ	2016	Air suspension deflation
NEW XJ	2016	Air suspension inflation
NEW XJ	2016	Ride level control module diagnostic interface
NEW XJ	2016	Ride level control module inflation (showroom)
NEW XJ	2016	Display injector correction factors
NEW XJ	2016	Longitudinal accelerometer calibration.
NEW XJ	2016	Brake caliper replacement assembly test
NEW XJ	2016	Parking brake pad replacement - Release to service position
NEW XJ	2016	Parking brake pad replacement - Exit maintenance mode application
NEW XJ	2016	Parking brake activation
NEW XJ	2016	Sunroof calibration

NEW XJ	2016	Tailgate/trunk calibration
NEW XJ	2016	Power Train-Diesel Exhaust Oil Level Check
NEW XJ	2016	Special application-Dashboard virtual display diagnostic application
NEW XJ	2016	Tire pressure monitoring system-tire pressure sensor replacement
NEW XJ	2016	Configure the new module. -ABS control module
NEW XJ	2016	Configure the new module. -Shift module
NEW XJ	2016	Configure the new module. -Rear climate control module
NEW XJ	2016	Configure the new module. -Front control interface module (heating, ventilation and air conditioning control)
NEW XJ	2016	Configure the new module. -Speed ??control module
NEW XJ	2016	Configure the new module. -Image processing control module
NEW XJ	2016	Configure the new module. -Steering angle sensor module.
NEW XJ	2016	Configure the new module. -Vehicle dynamic control module.
NEW XJ	2016	Remote communication control module-remote communication server communication check
NEW XJ	2016	Remote communication control module-pre-activated remote communication control module
NEW XJ	2016	Remote communication control module-network registration status
NEW XJ	2016	Remote communication control module-remote communication-operation mode
NEW XJ	2016	Remote communication control module-remote communication control module battery replacement reset
NEW XJ	2016	Security-Passive entry/passive start enabled
NEW XJ	2016	Seat-calibration of the driver's seat.
NEW XJ	2016	Seat-calibration of the passenger side seat.
NEW XJ	2016	Seat-Rear Seat-Calibration-Right
NEW XJ	2016	Seat-Rear Seat-Calibration-Left
NEW XJ	2016	Seat-driver's seat massage on-demand self-check
NEW XJ	2016	Seat-Passenger seat massage on-demand self-check
NEW XJ	2016	Seat-right rear seat massage on-demand self-check
NEW XJ	2016	Seat-left rear seat massage on-demand self-check
NEW XJ	2016	Braking system-yaw rate sensor calibration.
NEW XJ	2016	Body system-valet parking mode reset
NEW XJ	2016	Body system-variable assist power steering curve path programming.
NEW XJ	2016	Body system-power steering soft lock stop position reset routine
NEW XJ	2016	Body system-ignition cycle counter reset
NEW XJ	2016	Body system-tuning and locking the steering wheel to the vehicle
NEW XJ	2016	Body system-rain sensor calibration
NEW XJ	2016	Heating and ventilation-seat climate control module calibration
NEW XJ	2016	Powertrain settings-fuel water detection reset
NEW XJ	2016	Drivetrain settings-throttle actuator
NEW XJ	2016	Drive train settings-turbine shut-off valve
NEW XJ	2016	Drive train settings-oxygen sensor
NEW XJ	2016	Drivetrain settings-oxidation catalyst
NEW XJ	2016	Drivetrain settings-diesel particulate filter differential pressure sensor replacement
NEW XJ	2016	Drive train settings-reinitialize diesel fuel filling adaptation value
NEW XJ	2016	Rear differential control module. -Control module calibration
NEW XJ	2016	Suspension system-set/cancel air suspension manufacturing/freeze mode
NEW XJ	2016	Transfer case-calibration clutch.
NEW XJ	2016	Transfer case-oil replacement reset
NEW XJ	2016	Special application-transmission mode
NEW XJ	2016	Remote communication control module-test internal backup battery
NEW XJ	2016	Remote communication control module-emergency call and fault call switch lighting test
NEW XJ	2016	Powertrain-Fuel Lift Pump
NEW XJ	2016	Powertrain-diesel particulate filter replacement
NEW XJ	2016	Power Train-Fuel Pump Supply Pipe-Enable/Disable
NEW XJ	2016	Powertrain-Clear the stored carbon particle filter value

NEW XJ	2016	Entertainment system-InControl Touch Pro wireless headset system self-check
NEW XJ	2016	Entertainment system-InControl Touch Pro auxiliary electric cooling fan test
NEW XJ	2016	Entertainment system-InControl Touch Pro engineering interface enabled
NEW XJ	2016	Entertainment System-InControl Touch Pro SiriusXM? Logo Display
NEW XJ	2016	Entertainment System-InControl Smart Control, Exclusive Touch Customer PIN Reset
NEW XJ	2016	Configure the new module. -Restricted occupant classification system module
NEW XJ	2016	Configure the new module. -Electric tailgate
NEW XJ	2016	Remote communication control module-activate the remote communication control module
NEW XJ	2016	Body System-Tailgate/Luggage Compartment Calibration
NEW XJ	2016	Heating and ventilation-vent actuator test
NEW XJ	2016	Heating and ventilation-stepper motor initialization
NEW XJ	2016	Heating and ventilation-evaporator and heater testing
NEW XJ	2016	Powertrain-Engine Control Module Unlock Application
NEW XJ	2016	Powertrain-Selective Catalytic Reduction-Quantitative Distribution Module Test
XE	2016	Diesel particulate filter replacement
XE	2016	Throttle valve actuator
XE	2016	Diesel particulate filter differential pressure sensor replacement
XE	2016	Throttle valve actuator replacement
XE	2016	Parking brake pad replacement - Release to service position
XE	2016	Parking brake pad replacement - Exit maintenance mode application
XE	2016	Auto oil reset
XE	2016	Service interval reset
XE	2016	Oil service counter reset
XE	2016	Replace brake pads -operating guide
XE	2016	Front left wheel sensor
XE	2016	Front right wheel sensor
XE	2016	Rear right wheel sensor
XE	2016	Rear left wheel sensor
XE	2016	Spare wheel
XE	2016	Power steering soft-lock end stops reset routine
XE	2016	Lock steering tune to vehicle
XE	2016	roof blind calibration
XE	2016	Driver's seat massage on demand self test
XE	2016	Tire pressure monitoring sensor identification display
XE	2016	Reset Selective Catalytic Reduction Start Prohibition
XE	2016	Transmission Control Module Adaptive Clearance
XE	2016	Diesel exhaust gas oil infusion and pressure test
XE	2016	Diesel exhaust gas tank level sensor replacement
XE	2016	Diesel exhaust gas jet pump replacement
XE	2016	Diesel particulate filter dynamic regeneration
XE	2016	This routine will reset flight recorder data
XE	2016	Powertrain Control Module Adaptive Clearance
XE	2016	Engine Control Module Low Pressure EGR Adaptive Value Clearance
XE	2016	Engine Control Module Resets Crankcase Pressure Sensor
XE	2016	Engine Control Module Vortex Valve Adaptive Value Clearance
XE	2016	Engine Control Module Mass Air Flow Adaptive Value Clearance
XE	2016	Engine Control Module Resets Fuel Pump Adaptive Value
XE	2016	Glow Plug Control Module
XE	2016	Throttle Valve Brake Replacement
XE	2016	Injector valve test
XE	2016	Enable/Disable Glow Plug
XE	2016	Fuel preparation routine

XE	2016	Show injector correction factor
XE	2016	Anti-theft locker antenna unit function check
XE	2016	Check all antennas
XE	2016	Parking Brake Start
XE	2016	Activate test picture
XE	2016	Head-view display control module reset
XE	2016	Activate Telematics Control Module
XE	2016	Remote Information Processing SIM Card Type
XE	2016	Applications for Information and Entertainment Systems
XE	2016	Battery replacement
XE	2016	Static current control module internal inspection
XE	2016	IPMA AEB Data Reading
XE	2016	Vehicle reset
XE	2016	Check before departure
XE	2016	Constraint build mode
XE	2016	door and window calibration
XE	2016	Altitude Calibration
XE	2016	Display injector correction factors
XE	2016	Sunroof calibration
XE	2016	Tailgate/trunk calibration
XE	2016	Power Train-Diesel Exhaust Oil Level Check
XE	2016	Tire pressure monitoring system-tire pressure sensor replacement
XE	2016	Brake bleed
XE	2016	Configure the new module. -Audio amplifier module.
XE	2016	Configure the new module. -Digital Audio Broadcasting Module
XE	2016	Configure the new module. -Front control/display interface module (high-level display front)
XE	2016	Configure the new module. -Shift module
XE	2016	Configure the new module. -Front control interface module (heating, ventilation and air conditioning control)
XE	2016	Configure the new module. -Navigation control module
XE	2016	Configure the new module. -Satellite audio unit module.
XE	2016	Configure the new module. -Speed ??control module
XE	2016	Configure the new module. -All terrain control modules.
XE	2016	Configure the new module. -Image processing control module
XE	2016	Configure the new module. -Steering angle sensor module.
XE	2016	Configure the new module. -Head-up display cooling fan module
XE	2016	Configure the new module. -Expandable traction rod control module
XE	2016	Configure the new module. -Interactive display module
XE	2016	Remote communication control module-remote communication server communication check
XE	2016	Remote communication control module-pre-activated remote communication control module
XE	2016	Remote communication control module-reset/clear WiFi hotspot
XE	2016	Remote communication control module-network registration status
XE	2016	Remote communication control module-remote communication-operation mode
XE	2016	Remote communication control module-remote communication control module battery replacement reset
XE	2016	Seat-calibration of the driver's seat.
XE	2016	Seat-driver's seat massage on-demand self-check
XE	2016	Parking brake-brake caliper replacement assembly test
XE	2016	Parking brake-parking brake pad replacement-release to service position
XE	2016	Parking brake-parking brake pad replacement-exit the maintenance mode application
XE	2016	Parking brake-apply and release the electric parking brake
XE	2016	Body system-roof shade-calibration
XE	2016	Body system-valet parking mode reset
XE	2016	Body system-power steering soft lock stop position reset routine

XE	2016	Body system-ignition cycle counter reset
XE	2016	Body system-tuning and locking the steering wheel to the vehicle
XE	2016	Body system-rain sensor calibration
XE	2016	Auxiliary heater-auxiliary heater fuel delivery test
XE	2016	Powertrain settings-fuel water detection reset
XE	2016	Drivetrain settings-throttle actuator
XE	2016	Drive train settings-turbine shut-off valve
XE	2016	Drive train settings-exhaust gas recirculation valve.
XE	2016	Drive train settings-oxygen sensor
XE	2016	Drivetrain settings-oxidation catalyst
XE	2016	Drivetrain settings-diesel particulate filter differential pressure sensor replacement
XE	2016	Drive train settings-reinitialize diesel fuel filling adaptation value
XE	2016	Suspension system-set/cancel air suspension manufacturing/freeze mode
XE	2016	Audio system. -Calibration dynamic quantity control
XE	2016	Special application-transmission mode
XE	2016	Remote communication control module-test internal backup battery
XE	2016	Remote communication control module-emergency call and fault call switch lighting test
XE	2016	Powertrain-Fuel Lift Pump
XE	2016	Powertrain-diesel particulate filter replacement
XE	2016	Power Train-Fuel Pump Supply Pipe-Enable/Disable
XE	2016	Powertrain-Air Channel Setting Program
XE	2016	Unlock the deployable towbar
XE	2016	Deployable towbar recovery
XE	2016	Retractable towbar
XE	2016	Deploy towbar
XE	2016	Deployable towbar speaker test
XE	2016	Configure the new module. -Restricted occupant classification system module
XE	2016	Configure the new module. -Electric tailgate
XE	2016	Body System-Tailgate/Luggage Compartment Calibration
XE	2016	Heating and ventilation-stepper motor initialization
XE	2016	Heating and ventilation-actuator end stop detection
XE	2016	Heating and ventilation-reset compressor protection counter
XE	2016	Auxiliary heater-The auxiliary heater is routinely prepared.
XE	2016	Auxiliary heater-auxiliary heater startup test
XE	2016	Powertrain-Selective Catalytic Reduction-Quantitative Distribution Module Test
XE	2017	Brake bleed
XE	2017	Reset Selective Catalytic Reduction Start Prohibition
XE	2017	Transmission Control Module Adaptive Clearance
XE	2017	Diesel exhaust gas oil infusion and pressure test
XE	2017	Diesel exhaust gas tank level sensor replacement
XE	2017	Diesel exhaust gas jet pump replacement
XE	2017	Diesel particulate filter dynamic regeneration
XE	2017	This routine will reset flight recorder data
XE	2017	Powertrain Control Module Adaptive Clearance
XE	2017	Engine Control Module Low Pressure EGR Adaptive Value Clearance
XE	2017	Engine Control Module Resets Crankcase Pressure Sensor
XE	2017	Engine Control Module Vortex Valve Adaptive Value Clearance
XE	2017	Engine Control Module Mass Air Flow Adaptive Value Clearance
XE	2017	Engine Control Module Resets Fuel Pump Adaptive Value
XE	2017	Glow Plug Control Module
XE	2017	Throttle Valve Brake Replacement
XE	2017	Injector valve test

XE	2017	Enable/Disable Glow Plug
XE	2017	Fuel preparation routine
XE	2017	Show injector correction factor
XE	2017	Anti-theft locker antenna unit function check
XE	2017	Check all antennas
XE	2017	Transfer box control module - locking central differential
XE	2017	Parking Brake Start
XE	2017	Activate test picture
XE	2017	Head-view display control module reset
XE	2017	Activate Telematics Control Module
XE	2017	Remote Information Processing SIM Card Type
XE	2017	Pump ventilation
XE	2017	Reset - Clear specified features
XE	2017	Battery replacement
XE	2017	Static current control module internal inspection
XE	2017	IPMA AEB Data Reading
XE	2017	Vehicle reset
XE	2017	Check before departure
XE	2017	Constraint build mode
XE	2017	door and window calibration
XE	2017	Altitude Calibration
XE	2017	Sunroof calibration
XE	2017	Tailgate/trunk calibration
XE	2017	Power Train-Diesel Exhaust Oil Level Check
XE	2017	Tire pressure monitoring system-tire pressure sensor replacement
XE	2017	Configure the new module. -Audio amplifier module.
XE	2017	Configure the new module. -Shift module
XE	2017	Configure the new module. -Front control interface module (heating, ventilation and air conditioning control)
XE	2017	Configure the new module. -Speed ??control module
XE	2017	Configure the new module. -All terrain control modules.
XE	2017	Configure the new module. -Image processing control module
XE	2017	Configure the new module. -Steering angle sensor module.
XE	2017	Configure the new module. -Head-up display cooling fan module
XE	2017	Configure the new module. -Expandable traction rod control module
XE	2017	Configure the new module. -Interactive display module
XE	2017	Remote communication control module-remote communication server communication check
XE	2017	Remote communication control module-pre-activated remote communication control module
XE	2017	Remote communication control module-reset/clear WiFi hotspot
XE	2017	Remote communication control module-network registration status
XE	2017	Remote communication control module-remote communication-operation mode
XE	2017	Remote communication control module-remote communication control module battery replacement reset
XE	2017	Security-Passive entry/passive start enabled
XE	2017	Seat-calibration of the driver's seat.
XE	2017	Seat-driver's seat massage on-demand self-check
XE	2017	Parking brake-brake caliper replacement assembly test
XE	2017	Parking brake-parking brake pad replacement-release to service position
XE	2017	Parking brake-parking brake pad replacement-exit the maintenance mode application
XE	2017	Parking brake-apply and release the electric parking brake
XE	2017	Body system-roof shade-calibration
XE	2017	Body system-valet parking mode reset
XE	2017	Body system-power steering soft lock stop position reset routine
XE	2017	Body system-ignition cycle counter reset

XE	2017	Body system-tuning and locking the steering wheel to the vehicle
XE	2017	Body system-rain sensor calibration
XE	2017	Auxiliary heater-auxiliary heater fuel delivery test
XE	2017	Powertrain settings-fuel water detection reset
XE	2017	Drivetrain settings-throttle actuator
XE	2017	Drive train settings-turbine shut-off valve
XE	2017	Drive train settings-exhaust gas recirculation valve.
XE	2017	Drive train settings-oxygen sensor
XE	2017	Drivetrain settings-oxidation catalyst
XE	2017	Drivetrain settings-diesel particulate filter differential pressure sensor replacement
XE	2017	Drive train settings-reinitialize diesel fuel filling adaptation value
XE	2017	Suspension system-set/cancel air suspension manufacturing/freeze mode
XE	2017	Special application-transmission mode
XE	2017	Remote communication control module-test internal backup battery
XE	2017	Remote communication control module-emergency call and fault call switch lighting test
XE	2017	Powertrain-Fuel Lift Pump
XE	2017	Powertrain-diesel particulate filter replacement
XE	2017	Power Train-Fuel Pump Supply Pipe-Enable/Disable
XE	2017	Powertrain-Air Channel Setting Program
XE	2017	Entertainment system-InControl Touch Pro wireless headset system self-check
XE	2017	Entertainment system-InControl Touch Pro auxiliary electric cooling fan test
XE	2017	Entertainment system-InControl Touch Pro engineering interface enabled
XE	2017	Entertainment System-InControl Touch Pro SiriusXM? Logo Display
XE	2017	Entertainment System-InControl Smart Control, Exclusive Touch Customer PIN Reset
XE	2017	Unlock the deployable towbar
XE	2017	Deployable towbar recovery
XE	2017	Retractable towbar
XE	2017	Deploy towbar
XE	2017	Deployable towbar speaker test
XE	2017	Configure the new module. -Restricted occupant classification system module
XE	2017	Configure the new module. -Electric tailgate
XE	2017	Remote communication control module-activate the remote communication control module
XE	2017	Body System-Tailgate/Luggage Compartment Calibration
XE	2017	Heating and ventilation-stepper motor initialization
XE	2017	Heating and ventilation-actuator end stop detection
XE	2017	Heating and ventilation-reset compressor protection counter
XE	2017	Auxiliary heater-The auxiliary heater is routinely prepared.
XE	2017	Auxiliary heater-auxiliary heater startup test
XE	2017	Powertrain-Selective Catalytic Reduction-Quantitative Distribution Module Test
XF	2008-2009	Brake bleed
XF	2008-2009	Tire pressure monitor confirmation application.
XF	2008-2009	Powertrain control module adaption clear.
XF	2008-2009	Transmission Control Module Adaptive Clearance
XF	2008-2009	Diesel particulate filter dynamic regeneration
XF	2008-2009	Diesel particulate filter replacement
XF	2008-2009	Diesel particulate filter fuel related parts replacement
XF	2008-2009	Diesel particulate filter conditions (stored value)
XF	2008-2009	High Pressure Jet Pump Replacement
XF	2008-2009	Air conditioning system adaptive reset
XF	2008-2009	Oil maintenance counter reset
XF	2008-2009	The parking brake is released to the service position
XF	2008-2009	Stepper motor initialization

XF	2008-2009	Ventilator Actuator Test
XF	2008-2009	Speed control internal state
XF	2008-2009	Replace the seat cover
XF	2008-2009	Battery replacement
XF	2008-2009	Constraint build mode
XF	2008-2009	Side Object Detection Module History
XF	2008-2009	Right - Radar Signal - Reverse Correction
XF	2008-2009	Customer side door glass window calibration
XF	2008-2009	Driver side door glazing calibration
XF	2008-2009	Pedestrian collision state reset
XF	2008-2009	Tire pressure sensor replacement
XF	2008-2009	Tire pressure monitor receiver calibration
XF	2008-2009	Tire pressure monitoring tire pressure sensor test
XF	2008-2009	Configure the new module. -ABS control module
XF	2008-2009	Configure the new module. -Adaptive damping control module
XF	2008-2009	Configure the new module. -Central junction box configuration update
XF	2008-2009	Configure the new module. -Digital Audio Broadcasting Module
XF	2008-2009	Configure the new module. -Front control/display interface module (high-level display front)
XF	2008-2009	Configure the new module. -Shift module
XF	2008-2009	Configure the new module. -Collision classification system
XF	2008-2009	Configure the new module. -Navigation control module
XF	2008-2009	Configure the new module. -Parking aid control module
XF	2008-2009	Configure the new module. -Parking brake control module
XF	2008-2009	Configure the new module. -Restricted occupant classification system module
XF	2008-2009	Configure the new module. -Satellite audio unit module.
XF	2008-2009	Configure the new module. -Side object detection control module-left
XF	2008-2009	Configure the new module. -Speed control module
XF	2008-2009	XF--Pre-sales update-Central junction box configuration update
XF	2008-2009	Active vibration reduction control module-calibration acquisition
XF	2008-2009	Powertrain-Self-check of purge valve.
XF	2008-2009	Powertrain-The powertrain control module is adaptively cleared.
XF	2008-2009	Add/remove accessories. -Rearview mirror personalization function
XF	2008-2009	Add/remove accessories. -Passenger restraint disable switch
XF	2008-2009	Side Object Detection-History of Side Object Detection Module
XF	2010-2011	Driver's memory seat calibration.
XF	2010-2011	Brake bleed
XF	2010-2011	Tire pressure monitor confirmation application.
XF	2010-2011	Diesel particulate filter replacement
XF	2010-2011	Powertrain control module adaption clear.
XF	2010-2011	Reset water in fuel detection
XF	2010-2011	Turbine shut-off valve
XF	2010-2011	Throttle valve actuator
XF	2010-2011	Exhaust gas recirculation valve
XF	2010-2011	Injector replacement
XF	2010-2011	Oxygen sensor
XF	2010-2011	Oxidation catalyst
XF	2010-2011	Transmission Control Module Adaptive Clearance
XF	2010-2011	Diesel particulate filter dynamic regeneration
XF	2010-2011	Check engine oil level
XF	2010-2011	Show injector correction factor
XF	2010-2011	Oil maintenance counter reset
XF	2010-2011	Let the oil level reset

XF	2010-2011	The parking brake is released to the service position
XF	2010-2011	Stepper motor initialization
XF	2010-2011	Ventilator Actuator Test
XF	2010-2011	Replace the seat cover
XF	2010-2011	Battery replacement
XF	2010-2011	Other countries and regions of the world - Maintenance interval options
XF	2010-2011	Constraint build mode
XF	2010-2011	Side Object Detection Module History
XF	2010-2011	Right - Radar Signal - Reverse Correction
XF	2010-2011	Customer side door glass window calibration
XF	2010-2011	Driver side door glazing calibration
XF	2010-2011	Pedestrian collision state reset
XF	2010-2011	Tire pressure sensor replacement
XF	2010-2011	Tire pressure monitor receiver calibration
XF	2010-2011	Tire pressure monitoring tire pressure sensor test
XF	2010-2011	Height sensor-calibration
XF	2010-2011	Adaptive damping control module
XF	2010-2011	Configure the new module. -ABS control module
XF	2010-2011	Configure the new module. -Auxiliary protocol interface module
XF	2010-2011	Configure the new module. -Digital Audio Broadcasting Module
XF	2010-2011	Configure the new module. -Digital Audio Control Module C
XF	2010-2011	Configure the new module. -Front control/display interface module (high-level display front)
XF	2010-2011	Configure the new module. -Shift module
XF	2010-2011	Configure the new module. -Integrated control panel
XF	2010-2011	Configure the new module. -Navigation control module
XF	2010-2011	Configure the new module. -Parking aid control module
XF	2010-2011	Configure the new module. -Parking brake control module
XF	2010-2011	Configure the new module. -Restricted occupant classification system module
XF	2010-2011	Configure the new module. -Satellite audio unit module.
XF	2010-2011	Configure the new module. -Side object detection control module-left
XF	2010-2011	Configure the new module. -Speed ??control module
XF	2010-2011	Powertrain settings-fuel water detection reset
XF	2010-2011	Drivetrain settings-throttle actuator
XF	2010-2011	Drive train settings-turbine shut-off valve
XF	2010-2011	Drive train settings-oxygen sensor
XF	2010-2011	Drivetrain settings-oxidation catalyst
XF	2010-2011	Rear differential control module. -Control module calibration
XF	2010-2011	Active damping control module-establishment mode
XF	2010-2011	Active vibration reduction control module-calibration acquisition
XF	2010-2011	Powertrain-fuel preparation routine
XF	2010-2011	Powertrain-Fuel Lift Pump
XF	2010-2011	Powertrain-The powertrain control module is adaptively cleared.
XF	2010-2011	Powertrain-diesel particulate filter replacement
XF	2010-2011	Power Train-Engine Control Module VIN Reading Application
XF	2010-2011	Add/remove accessories. -Rearview mirror personalization function
XF	2010-2011	Add/remove accessories. -Passenger restraint disable switch
XF	2010-2011	Side Object Detection-History of Side Object Detection Module
XF	2010-2011	Drive train-repair history data
XF	2012	Brake bleed
XF	2012	Diesel particulate filter replacement
XF	2012	Powertrain control module adaption clear.
XF	2012	Yaw rate sensor calibration.

XF	2012	Reset water in fuel detection
XF	2012	Turbine shut-off valve
XF	2012	Throttle valve actuator
XF	2012	Exhaust gas recirculation valve
XF	2012	Oxygen sensor
XF	2012	Oxidation catalyst
XF	2012	Diesel particulate filter differential pressure sensor replacement
XF	2012	Diesel fueling adaption re-initialization
XF	2012	Transmission Control Module Adaptive Clearance
XF	2012	Diesel particulate filter dynamic regeneration
XF	2012	Check engine oil level
XF	2012	Show injector correction factor
XF	2012	Oil maintenance counter reset
XF	2012	Let the oil level reset
XF	2012	The parking brake is released to the service position
XF	2012	Stepper motor initialization
XF	2012	Ventilator Actuator Test
XF	2012	Replace the seat cover
XF	2012	Applications for Information and Entertainment Systems
XF	2012	Battery replacement
XF	2012	Other countries and regions of the world - Maintenance interval options
XF	2012	Constraint build mode
XF	2012	Side Object Detection Module History
XF	2012	Right - Radar Signal - Reverse Correction
XF	2012	Customer side door glass window calibration
XF	2012	Driver side door glazing calibration
XF	2012	Display injector correction factors
XF	2012	Parking brake release to the service position
XF	2012	Tire pressure sensor replacement
XF	2012	Tire pressure monitor receiver calibration
XF	2012	Tire pressure monitoring tire pressure sensor test
XF	2012	Height sensor-calibration
XF	2012	Adaptive damping control module
XF	2012	Configure the new module. -ABS control module
XF	2012	Configure the new module. -Digital Audio Broadcasting Module
XF	2012	Configure the new module. -Front control/display interface module (high-level display front)
XF	2012	Configure the new module. -Shift module
XF	2012	Configure the new module. -Headlamp control module 'B'
XF	2012	Configure the new module. -Front control interface module 'B' (front audio control panel)
XF	2012	Configure the new module. -Navigation control module
XF	2012	Configure the new module. -Parking aid control module
XF	2012	Configure the new module. -Parking brake control module
XF	2012	Configure the new module. -Restricted occupant classification system module
XF	2012	Configure the new module. -Satellite audio unit module.
XF	2012	Configure the new module. -Side object detection control module-left
XF	2012	Configure the new module. -Speed ??control module
XF	2012	Configure the new module. -Gateway module
XF	2012	Braking system-yaw rate sensor calibration.
XF	2012	Powertrain settings-fuel water detection reset
XF	2012	Drivetrain settings-throttle actuator
XF	2012	Drive train settings-turbine shut-off valve
XF	2012	Drive train settings-exhaust gas recirculation valve.

XF	2012	Drive train settings-oxygen sensor
XF	2012	Drivetrain settings-oxidation catalyst
XF	2012	Drivetrain settings-diesel particulate filter differential pressure sensor replacement
XF	2012	Drive train settings-reinitialize diesel fuel filling adaptation value
XF	2012	Rear differential control module. -Control module calibration
XF	2012	Active damping control module-establishment mode
XF	2012	Active vibration reduction control module-calibration acquisition
XF	2012	Audio system. -Calibration dynamic quantity control
XF	2012	Powertrain-Evaporation System Diagnostic Test
XF	2012	Powertrain-fuel preparation routine
XF	2012	Powertrain-Fuel Lift Pump
XF	2012	Powertrain-The powertrain control module is adaptively cleared.
XF	2012	Powertrain-diesel particulate filter replacement
XF	2012	Entertainment system-reset navigation
XF	2012	Entertainment system-DVD zone counter reset
XF	2012	Configure the new module. -Right seat belt pretensioner
XF	2012	Configure the new module. -Left seat belt pretensioner
XF	2012	Side Object Detection-History of Side Object Detection Module
XF	2012	Drive train-repair history data
XF	2012	Seat belt pretensioner system-seat belt dynamic retraction and release
XF	2012	Seat belt pretensioner system-clear module learning data
XF	2013-2015	Brake bleed
XF	2013-2015	Diesel particulate filter replacement
XF	2013-2015	Powertrain control module adaption clear.
XF	2013-2015	Yaw rate sensor calibration.
XF	2013-2015	Reset water in fuel detection
XF	2013-2015	Turbine shut-off valve
XF	2013-2015	Throttle valve actuator
XF	2013-2015	Exhaust gas recirculation valve
XF	2013-2015	Oxygen sensor
XF	2013-2015	Oxidation catalyst
XF	2013-2015	Battery replacement
XF	2013-2015	Diesel fueling adaption re-initialization
XF	2013-2015	Throttle valve actuator replacement
XF	2013-2015	Transmission Control Module Adaptive Clearance
XF	2013-2015	Diesel particulate filter dynamic regeneration
XF	2013-2015	Powertrain Control Module Adaptive Clearance
XF	2013-2015	Engine Control Module Unlocking Application
XF	2013-2015	Throttle Valve Brake Replacement
XF	2013-2015	Injector valve test
XF	2013-2015	Fuel preparation routine
XF	2013-2015	Show injector correction factor
XF	2013-2015	Oil maintenance counter reset
XF	2013-2015	Anti-theft locker antenna unit function check
XF	2013-2015	Check all antennas
XF	2013-2015	The parking brake is released to the service position
XF	2013-2015	Stepper motor initialization
XF	2013-2015	Ventilator Actuator Test
XF	2013-2015	Replace the seat cover
XF	2013-2015	Starting TV Test Picture
XF	2013-2015	Applications for Information and Entertainment Systems
XF	2013-2015	Testing Dual Battery Systems

XF	2013-2015	Static current control module internal inspection
XF	2013-2015	Verify auxiliary battery charging
XF	2013-2015	Set/Cancel Air Suspension Precision Tolerance Mode (Headlight Setting)
XF	2013-2015	Set/Cancel Air Suspension Geometry Settings
XF	2013-2015	Check before departure
XF	2013-2015	Other countries and regions of the world - Maintenance interval options
XF	2013-2015	Maintenance interval reset
XF	2013-2015	Constraint build mode
XF	2013-2015	Right - Radar Signal - Reverse Correction
XF	2013-2015	Customer side door glass window calibration
XF	2013-2015	Driver side door glazing calibration
XF	2013-2015	Altitude Calibration
XF	2013-2015	Air suspension deflation
XF	2013-2015	Air suspension inflation
XF	2013-2015	Ride level control module diagnostic interface
XF	2013-2015	Ride level control module inflation (showroom)
XF	2013-2015	Display injector correction factors
XF	2013-2015	Parking brake release to the service position
XF	2013-2015	Tire pressure sensor replacement
XF	2013-2015	Tire pressure monitor receiver calibration
XF	2013-2015	Tire pressure monitoring tire pressure sensor test
XF	2013-2015	Tailgate/trunk calibration
XF	2013-2015	Height sensor-calibration
XF	2013-2015	Adaptive damping control module
XF	2013-2015	Configure the new module. -ABS control module
XF	2013-2015	Configure the new module. -Digital Audio Broadcasting Module
XF	2013-2015	Configure the new module. -Front control/display interface module (high-level display front)
XF	2013-2015	Configure the new module. -Shift module
XF	2013-2015	Configure the new module. -Headlamp control module 'B'
XF	2013-2015	Configure the new module. -Heating air conditioning control module
XF	2013-2015	Configure the new module. -Front control interface module 'B' (front audio control panel)
XF	2013-2015	Configure the new module. -Navigation control module
XF	2013-2015	Configure the new module. -Parking aid control module
XF	2013-2015	Configure the new module. -Parking brake control module
XF	2013-2015	Configure the new module. -Restricted occupant classification system module
XF	2013-2015	Configure the new module. -Satellite audio unit module.
XF	2013-2015	Configure the new module. -Side object detection control module-left
XF	2013-2015	Configure the new module. -Speed ??control module
XF	2013-2015	Configure the new module. -Gateway module
XF	2013-2015	Braking system-yaw rate sensor calibration.
XF	2013-2015	Powertrain settings-fuel water detection reset
XF	2013-2015	Drivetrain settings-throttle actuator
XF	2013-2015	Drive train settings-turbine shut-off valve
XF	2013-2015	Drive train settings-exhaust gas recirculation valve.
XF	2013-2015	Drive train settings-oxygen sensor
XF	2013-2015	Drivetrain settings-oxidation catalyst
XF	2013-2015	Drivetrain settings-diesel particulate filter differential pressure sensor replacement
XF	2013-2015	Drive train settings-reinitialize diesel fuel filling adaptation value
XF	2013-2015	Rear differential control module. -Control module calibration
XF	2013-2015	Suspension system-set/cancel air suspension manufacturing/freeze mode
XF	2013-2015	Active damping control module-establishment mode
XF	2013-2015	Active vibration reduction control module-calibration acquisition

XF	2013-2015	Audio system. -Calibration dynamic quantity control
XF	2013-2015	Transfer case-calibration clutch.
XF	2013-2015	Transfer case-oil replacement reset
XF	2013-2015	Special application-transmission mode
XF	2013-2015	Powertrain-Fuel Lift Pump
XF	2013-2015	Powertrain-diesel particulate filter replacement
XF	2013-2015	Power Train-Fuel Pump Supply Pipe-Enable/Disable
XF	2013-2015	Entertainment system-reset navigation
XF	2013-2015	Entertainment system-DVD zone counter reset
XF	2013-2015	Configure the new module. -Electric tailgate
XF	2013-2015	Configure the new module. -Right seat belt pretensioner
XF	2013-2015	Configure the new module. -Left seat belt pretensioner
XF	2013-2015	Body System-Tailgate/Luggage Compartment Calibration
XF	2013-2015	Auxiliary heater-The auxiliary heater is routinely prepared.
XF	2013-2015	Auxiliary heater-auxiliary heater startup test
XF	2013-2015	Powertrain-Engine Control Module Unlock Application
XF	2013-2015	Seat belt pretensioner system-seat belt dynamic retraction and release
XF	2013-2015	Seat belt pretensioner system-clear module learning data
NEW XF	2016-2017	Brake bleed
NEW XF	2016-2017	Steering column calibration
NEW XF	2016-2017	Throttle valve actuator replacement
NEW XF	2016-2017	Auto oil reset
NEW XF	2016-2017	Service interval reset
NEW XF	2016-2017	Oil service counter reset
NEW XF	2016-2017	Replace brake pads -operating guide
NEW XF	2016-2017	Front left wheel sensor
NEW XF	2016-2017	Front right wheel sensor
NEW XF	2016-2017	Rear right wheel sensor
NEW XF	2016-2017	Rear left wheel sensor
NEW XF	2016-2017	Spare wheel
NEW XF	2016-2017	Power steering soft-lock end stops reset routine
NEW XF	2016-2017	Lock steering tune to vehicle
NEW XF	2016-2017	Tire pressure monitoring sensor identification display
NEW XF	2016-2017	Resetting the Selective Catalytic Reduction Mass Monitor
NEW XF	2016-2017	Transmission Control Module Adaptive Clearance
NEW XF	2016-2017	Diesel exhaust gas oil infusion and pressure test
NEW XF	2016-2017	Diesel exhaust gas tank level sensor replacement
NEW XF	2016-2017	Diesel exhaust gas jet pump replacement
NEW XF	2016-2017	Diesel particulate filter dynamic regeneration
NEW XF	2016-2017	This routine will reset flight recorder data
NEW XF	2016-2017	Powertrain Control Module Adaptive Clearance
NEW XF	2016-2017	Engine Control Module Low Pressure EGR Adaptive Value Clearance
NEW XF	2016-2017	Engine Control Module Resets Crankcase Pressure Sensor
NEW XF	2016-2017	Engine Control Module Vortex Valve Adaptive Value Clearance
NEW XF	2016-2017	Engine Control Module Mass Air Flow Adaptive Value Clearance
NEW XF	2016-2017	Engine Control Module Resets Fuel Pump Adaptive Value
NEW XF	2016-2017	Glow Plug Control Module
NEW XF	2016-2017	Throttle Valve Brake Replacement
NEW XF	2016-2017	Exhaust valve adaptation
NEW XF	2016-2017	Injector valve test
NEW XF	2016-2017	Enable/Disable Glow Plug
NEW XF	2016-2017	Fuel preparation routine

NEW XF	2016-2017	Show injector correction factor
NEW XF	2016-2017	Check all antennas
NEW XF	2016-2017	Transfer box control module - locking central differential
NEW XF	2016-2017	Parking Brake Start
NEW XF	2016-2017	Activate test picture
NEW XF	2016-2017	Head-view display control module reset
NEW XF	2016-2017	Activate Telematics Control Module
NEW XF	2016-2017	Remote Information Processing SIM Card Type
NEW XF	2016-2017	Pump ventilation
NEW XF	2016-2017	Reset - Clear specified features
NEW XF	2016-2017	Battery replacement
NEW XF	2016-2017	Static current control module internal inspection
NEW XF	2016-2017	IPMA AEB Data Reading
NEW XF	2016-2017	Vehicle reset
NEW XF	2016-2017	Check before departure
NEW XF	2016-2017	Constraint build mode
NEW XF	2016-2017	door and window calibration
NEW XF	2016-2017	Altitude Calibration
NEW XF	2016-2017	Display injector correction factors
NEW XF	2016-2017	Brake caliper replacement assembly test
NEW XF	2016-2017	Parking brake pad replacement - Release to service position
NEW XF	2016-2017	Parking brake pad replacement - Exit maintenance mode application
NEW XF	2016-2017	Parking brake activation
NEW XF	2016-2017	Apply and release electric park brake
NEW XF	2016-2017	Sunroof calibration
NEW XF	2016-2017	Tailgate/trunk calibration
NEW XF	2016-2017	Power Train-Diesel Exhaust Oil Level Check
NEW XF	2016-2017	Tire pressure monitoring system-tire pressure sensor replacement
NEW XF	2016-2017	Configure the new module. -Audio amplifier module.
NEW XF	2016-2017	Configure the new module. -Shift module
NEW XF	2016-2017	Configure the new module. -Rear climate control module
NEW XF	2016-2017	Configure the new module. -Front control interface module (heating, ventilation and air conditioning control)
NEW XF	2016-2017	Configure the new module. -Speed ??control module
NEW XF	2016-2017	Configure the new module. -All terrain control modules.
NEW XF	2016-2017	Configure the new module. -Steering angle sensor module.
NEW XF	2016-2017	Configure the new module. -Head-up display cooling fan module
NEW XF	2016-2017	Configure the new module. -Expandable traction rod control module
NEW XF	2016-2017	Configure the new module. -Interactive display module
NEW XF	2016-2017	Remote communication control module-remote communication server communication check
NEW XF	2016-2017	Remote communication control module-pre-activated remote communication control module
NEW XF	2016-2017	Remote communication control module-reset/clear WiFi hotspot
NEW XF	2016-2017	Remote communication control module-network registration status
NEW XF	2016-2017	Remote communication control module-remote communication-operation mode
NEW XF	2016-2017	Remote communication control module-remote communication control module battery replacement reset
NEW XF	2016-2017	Security-Passive entry/passive start enabled
NEW XF	2016-2017	Seat-calibration of the driver's seat.
NEW XF	2016-2017	Seat-calibration of the passenger side seat.
NEW XF	2016-2017	Seat-driver's seat massage on-demand self-check
NEW XF	2016-2017	Seat-Passenger seat massage on-demand self-check
NEW XF	2016-2017	Body system-roof shade-calibration
NEW XF	2016-2017	Body system-valet parking mode reset
NEW XF	2016-2017	Body system-power steering soft lock stop position reset routine

NEW XF	2016-2017	Body system-ignition cycle counter reset
NEW XF	2016-2017	Body system-tuning and locking the steering wheel to the vehicle
NEW XF	2016-2017	Body system-rain sensor calibration
NEW XF	2016-2017	Auxiliary heater-auxiliary heater fuel delivery test
NEW XF	2016-2017	Powertrain settings-fuel water detection reset
NEW XF	2016-2017	Drivetrain settings-throttle actuator
NEW XF	2016-2017	Drive train settings-turbine shut-off valve
NEW XF	2016-2017	Drive train settings-exhaust gas recirculation valve.
NEW XF	2016-2017	Drive train settings-oxygen sensor
NEW XF	2016-2017	Drivetrain settings-oxidation catalyst
NEW XF	2016-2017	Drivetrain settings-diesel particulate filter differential pressure sensor replacement
NEW XF	2016-2017	Drive train settings-reinitialize diesel fuel filling adaptation value
NEW XF	2016-2017	Suspension system-set/cancel air suspension manufacturing/freeze mode
NEW XF	2016-2017	Special application-transmission mode
NEW XF	2016-2017	Remote communication control module-test internal backup battery
NEW XF	2016-2017	Powertrain-Fuel Lift Pump
NEW XF	2016-2017	Powertrain-diesel particulate filter replacement
NEW XF	2016-2017	Power Train-Fuel Pump Supply Pipe-Enable/Disable
NEW XF	2016-2017	Entertainment system-InControl Touch Pro wireless headset system self-check
NEW XF	2016-2017	Entertainment system-InControl Touch Pro auxiliary electric cooling fan test
NEW XF	2016-2017	Entertainment system-InControl Touch Pro engineering interface enabled
NEW XF	2016-2017	Entertainment System-InControl Touch Pro SiriusXM? Logo Display
NEW XF	2016-2017	Entertainment System-InControl Smart Control, Exclusive Touch Customer PIN Reset
NEW XF	2016-2017	Unlock the deployable towbar
NEW XF	2016-2017	Deployable towbar recovery
NEW XF	2016-2017	Retractable towbar
NEW XF	2016-2017	Deploy towbar
NEW XF	2016-2017	Deployable towbar speaker test
NEW XF	2016-2017	Configure the new module. -Restricted occupant classification system module
NEW XF	2016-2017	Configure the new module. -Electric tailgate
NEW XF	2016-2017	Remote communication control module-activate the remote communication control module
NEW XF	2016-2017	Body System-Tailgate/Luggage Compartment Calibration
NEW XF	2016-2017	Heating and ventilation-stepper motor initialization
NEW XF	2016-2017	Heating and ventilation-actuator end stop detection
NEW XF	2016-2017	Heating and ventilation-reset compressor protection counter
NEW XF	2016-2017	Auxiliary heater-The auxiliary heater is routinely prepared.
NEW XF	2016-2017	Auxiliary heater-auxiliary heater startup test
NEW XF	2016-2017	Powertrain-Selective Catalytic Reduction-Quantitative Distribution Module Test
F-PACE	2017	Brake bleed
F-PACE	2017	Tire pressure monitoring sensor identification display
F-PACE	2017	Resetting the Selective Catalytic Reduction Mass Monitor
F-PACE	2017	Transmission Control Module Adaptive Clearance
F-PACE	2017	Diesel exhaust gas oil infusion and pressure test
F-PACE	2017	Diesel exhaust gas tank level sensor replacement
F-PACE	2017	Diesel exhaust gas jet pump replacement
F-PACE	2017	Diesel particulate filter dynamic regeneration
F-PACE	2017	This routine will reset flight recorder data
F-PACE	2017	Powertrain Control Module Adaptive Clearance
F-PACE	2017	Engine Control Module Low Pressure EGR Adaptive Value Clearance
F-PACE	2017	Engine Control Module Resets Crankcase Pressure Sensor
F-PACE	2017	Engine Control Module Vortex Valve Adaptive Value Clearance
F-PACE	2017	Engine Control Module Mass Air Flow Adaptive Value Clearance

F-PACE	2017	Engine Control Module Resets Fuel Pump Adaptive Value
F-PACE	2017	Glow Plug Control Module
F-PACE	2017	Throttle Valve Brake Replacement
F-PACE	2017	Exhaust valve adaptation
F-PACE	2017	Injector valve test
F-PACE	2017	Enable/Disable Glow Plug
F-PACE	2017	Fuel preparation routine
F-PACE	2017	Show injector correction factor
F-PACE	2017	Check all antennas
F-PACE	2017	Transfer box control module - locking central differential
F-PACE	2017	Parking Brake Start
F-PACE	2017	Activate test picture
F-PACE	2017	Head-view display control module reset
F-PACE	2017	Activate Telematics Control Module
F-PACE	2017	Remote Information Processing SIM Card Type
F-PACE	2017	Pump ventilation
F-PACE	2017	Reset - Clear specified features
F-PACE	2017	Battery replacement
F-PACE	2017	Static current control module internal inspection
F-PACE	2017	IPMA AEB Data Reading
F-PACE	2017	Vehicle reset
F-PACE	2017	Check before departure
F-PACE	2017	Constraint build mode
F-PACE	2017	door and window calibration
F-PACE	2017	Altitude Calibration
F-PACE	2017	Display injector correction factors
F-PACE	2017	Brake caliper replacement assembly test
F-PACE	2017	Parking brake pad replacement - Release to service position
F-PACE	2017	Parking brake pad replacement - Exit maintenance mode application
F-PACE	2017	Parking brake activation
F-PACE	2017	Apply and release electric park brake
F-PACE	2017	Sunroof calibration
F-PACE	2017	Tailgate/trunk calibration
F-PACE	2017	Power Train-Diesel Exhaust Oil Level Check
F-PACE	2017	Tire pressure monitoring system-tire pressure sensor replacement
F-PACE	2017	Configure the new module. -Audio amplifier module.
F-PACE	2017	Configure the new module. -Shift module
F-PACE	2017	Configure the new module. -Rear climate control module
F-PACE	2017	Configure the new module. -Front control interface module (heating, ventilation and air conditioning control)
F-PACE	2017	Configure the new module. -Speed ??control module
F-PACE	2017	Configure the new module. -All terrain control modules.
F-PACE	2017	Configure the new module. -Image processing control module
F-PACE	2017	Configure the new module. -Steering angle sensor module.
F-PACE	2017	Configure the new module. -Head-up display cooling fan module
F-PACE	2017	Configure the new module. -Expandable traction rod control module
F-PACE	2017	Configure the new module. -Interactive display module
F-PACE	2017	Remote communication control module-remote communication server communication check
F-PACE	2017	Remote communication control module-pre-activated remote communication control module
F-PACE	2017	Remote communication control module-reset/clear WiFi hotspot
F-PACE	2017	Remote communication control module-network registration status
F-PACE	2017	Remote communication control module-remote communication-operation mode
F-PACE	2017	Remote communication control module-remote communication control module battery replacement reset

F-PACE	2017	Security-Passive entry/passive start enabled
F-PACE	2017	Seat-calibration of the driver's seat.
F-PACE	2017	Seat-calibration of the passenger side seat.
F-PACE	2017	Seat-driver's seat massage on-demand self-check
F-PACE	2017	Seat-Passenger seat massage on-demand self-check
F-PACE	2017	Body system-roof shade-calibration
F-PACE	2017	Body system-valet parking mode reset
F-PACE	2017	Body system-power steering soft lock stop position reset routine
F-PACE	2017	Body system-ignition cycle counter reset
F-PACE	2017	Body system-tuning and locking the steering wheel to the vehicle
F-PACE	2017	Body system-rain sensor calibration
F-PACE	2017	Auxiliary heater-auxiliary heater fuel delivery test
F-PACE	2017	Powertrain settings-fuel water detection reset
F-PACE	2017	Drivetrain settings-throttle actuator
F-PACE	2017	Drive train settings-turbine shut-off valve
F-PACE	2017	Drive train settings-exhaust gas recirculation valve.
F-PACE	2017	Drive train settings-oxygen sensor
F-PACE	2017	Drivetrain settings-oxidation catalyst
F-PACE	2017	Drivetrain settings-diesel particulate filter differential pressure sensor replacement
F-PACE	2017	Drive train settings-reinitialize diesel fuel filling adaptation value
F-PACE	2017	Suspension system-set/cancel air suspension manufacturing/freeze mode
F-PACE	2017	Special application-transmission mode
F-PACE	2017	Remote communication control module-test internal backup battery
F-PACE	2017	Powertrain-Fuel Lift Pump
F-PACE	2017	Powertrain-diesel particulate filter replacement
F-PACE	2017	Power Train-Fuel Pump Supply Pipe-Enable/Disable
F-PACE	2017	Entertainment system-InControl Touch Pro wireless headset system self-check
F-PACE	2017	Entertainment system-InControl Touch Pro auxiliary electric cooling fan test
F-PACE	2017	Entertainment system-InControl Touch Pro engineering interface enabled
F-PACE	2017	Entertainment System-InControl Touch Pro SiriusXM? Logo Display
F-PACE	2017	Entertainment System-InControl Smart Control, Exclusive Touch Customer PIN Reset
F-PACE	2017	Expandable side pedal-Operate the left side expandable side pedal
F-PACE	2017	Expandable side pedal-operate the right side expandable side pedal
F-PACE	2017	Unlock the deployable towbar
F-PACE	2017	Deployable towbar recovery
F-PACE	2017	Retractable towbar
F-PACE	2017	Deploy towbar
F-PACE	2017	Deployable towbar speaker test
F-PACE	2017	Configure the new module. -Restricted occupant classification system module
F-PACE	2017	Configure the new module. -Electric tailgate
F-PACE	2017	Remote communication control module-activate the remote communication control module
F-PACE	2017	Body System-Tailgate/Luggage Compartment Calibration
F-PACE	2017	Heating and ventilation-stepper motor initialization
F-PACE	2017	Heating and ventilation-actuator end stop detection
F-PACE	2017	Heating and ventilation-reset compressor protection counter
F-PACE	2017	Auxiliary heater-The auxiliary heater is routinely prepared.
F-PACE	2017	Auxiliary heater-auxiliary heater startup test
F-PACE	2017	Tire pressure monitoring system-tire pressure monitoring sensor identification display
F-PACE	2017	Powertrain-Selective Catalytic Reduction-Quantitative Distribution Module Test
X-Type	2004-2009	Transmission control module adaptation clear.
F-Type	2014-2015	Seat cushion replacement
F-Type	2014-2015	Driver's memory seat calibration.

F-Type	2014-2015	Brake bleed
F-Type	2014-2015	Steering angle sensor calibration
F-Type	2014-2015	Tire pressure monitoring sensor identification display
F-Type	2014-2015	Transmission Control Module Adaptive Clearance
F-Type	2014-2015	Powertrain Control Module Adaptive Clearance
F-Type	2014-2015	Engine Control Module Unlocking Application
F-Type	2014-2015	Throttle Valve Brake Replacement
F-Type	2014-2015	Injector valve test
F-Type	2014-2015	Fuel preparation routine
F-Type	2014-2015	Oil maintenance counter reset
F-Type	2014-2015	Anti-theft locker antenna unit function check
F-Type	2014-2015	Check all antennas
F-Type	2014-2015	Parking Brake Start
F-Type	2014-2015	Starting TV Test Picture
F-Type	2014-2015	Applications for Information and Entertainment Systems
F-Type	2014-2015	Testing Dual Battery Systems
F-Type	2014-2015	Battery replacement
F-Type	2014-2015	Static current control module internal inspection
F-Type	2014-2015	Verify auxiliary battery charging
F-Type	2014-2015	Vehicle reset
F-Type	2014-2015	Check before departure
F-Type	2014-2015	Maintenance interval reset
F-Type	2014-2015	Constraint build mode
F-Type	2014-2015	Customer side door glass window calibration
F-Type	2014-2015	Driver side door glazing calibration
F-Type	2014-2015	Altitude Calibration
F-Type	2014-2015	Longitudinal accelerometer calibration.
F-Type	2014-2015	Brake caliper replacement assembly test
F-Type	2014-2015	Parking brake pad replacement - Release to service position
F-Type	2014-2015	Parking brake pad replacement - Exit maintenance mode application
F-Type	2014-2015	Parking brake activation
F-Type	2014-2015	Tire pressure monitoring tire pressure sensor test
F-Type	2014-2015	Tailgate/trunk calibration
F-Type	2014-2015	Tire pressure monitoring system-tire pressure sensor replacement
F-Type	2014-2015	Configure the new module. -Digital Audio Broadcasting Module
F-Type	2014-2015	Configure the new module. -Front control/display interface module (high-level display front)
F-Type	2014-2015	Configure the new module. -Shift module
F-Type	2014-2015	Configure the new module. -Headlamp control module'B'
F-Type	2014-2015	Configure the new module. -Front control interface module (heating, ventilation and air conditioning control)
F-Type	2014-2015	Configure the new module. -Navigation control module
F-Type	2014-2015	Configure the new module. -Parking aid control module
F-Type	2014-2015	Configure the new module. -Parking brake control module
F-Type	2014-2015	Configure the new module. -Satellite audio unit module.
F-Type	2014-2015	Configure the new module. -All terrain control modules.
F-Type	2014-2015	Configure the new module. -Image processing control module
F-Type	2014-2015	Seat-calibration of the driver's seat.
F-Type	2014-2015	Seat-calibration of the passenger side seat.
F-Type	2014-2015	Braking system-steering angle sensor calibration
F-Type	2014-2015	Brake system-brake disc wear protection reset
F-Type	2014-2015	Body system-valet parking mode reset
F-Type	2014-2015	Rear differential control module. -Control module calibration
F-Type	2014-2015	Suspension system-set/cancel air suspension manufacturing/freeze mode

F-Type	2014-2015	Audio system. -Calibration dynamic quantity control
F-Type	2014-2015	Special application-transmission mode
F-Type	2014-2015	Power Train-Fuel Pump Supply Pipe-Enable/Disable
F-Type	2014-2015	Entertainment system-DVD zone counter reset
F-Type	2014-2015	Configure the new module. -Restricted occupant classification system module
F-Type	2014-2015	Configure the new module. -Electric tailgate
F-Type	2014-2015	Body System-Tailgate/Luggage Compartment Calibration
F-Type	2014-2015	Body system-variable assist power steering curve path programming.
F-Type	2014-2015	Heating and ventilation-vent actuator test
F-Type	2014-2015	Heating and ventilation-stepper motor initialization
F-Type	2014-2015	Powertrain-Engine Control Module Unlock Application
F-Type	2016-2017	Seat cushion replacement
F-Type	2016-2017	Steering column calibration
F-Type	2016-2017	Throttle valve actuator replacement
F-Type	2016-2017	Auto oil reset
F-Type	2016-2017	Service interval reset
F-Type	2016-2017	Replace brake pads -operating guide
F-Type	2016-2017	Oil service counter reset
F-Type	2016-2017	Front left wheel sensor
F-Type	2016-2017	Front right wheel sensor
F-Type	2016-2017	Rear right wheel sensor
F-Type	2016-2017	Rear left wheel sensor
F-Type	2016-2017	Spare wheel
F-Type	2016-2017	Power steering soft-lock end stops reset routine
F-Type	2016-2017	Lock steering tune to vehicle
F-Type	2016-2017	Tire pressure monitoring sensor identification display
F-Type	2016-2017	Transmission Control Module Adaptive Clearance
F-Type	2016-2017	Powertrain Control Module Adaptive Clearance
F-Type	2016-2017	Engine Control Module Unlocking Application
F-Type	2016-2017	Throttle Valve Brake Replacement
F-Type	2016-2017	Injector valve test
F-Type	2016-2017	Fuel preparation routine
F-Type	2016-2017	Anti-theft locker antenna unit function check
F-Type	2016-2017	Check all antennas
F-Type	2016-2017	Parking Brake Start
F-Type	2016-2017	Remote Information Processing SIM Card Type
F-Type	2016-2017	Starting TV Test Picture
F-Type	2016-2017	Applications for Information and Entertainment Systems
F-Type	2016-2017	Battery replacement
F-Type	2016-2017	Static current control module internal inspection
F-Type	2016-2017	Vehicle reset
F-Type	2016-2017	Check before departure
F-Type	2016-2017	Constraint build mode
F-Type	2016-2017	Customer side door glass window calibration
F-Type	2016-2017	Driver side door glazing calibration
F-Type	2016-2017	Altitude Calibration
F-Type	2016-2017	Longitudinal accelerometer calibration.
F-Type	2016-2017	Brake caliper replacement assembly test
F-Type	2016-2017	Parking brake pad replacement - Release to service position
F-Type	2016-2017	Parking brake pad replacement - Exit maintenance mode application
F-Type	2016-2017	Parking brake activation
F-Type	2016-2017	Tailgate/trunk calibration

F-Type	2016-2017	Tire pressure monitoring system-tire pressure sensor replacement
F-Type	2016-2017	Brake bleed
F-Type	2016-2017	Configure the new module. -Digital Audio Broadcasting Module
F-Type	2016-2017	Configure the new module. -Front control/display interface module (high-level display front)
F-Type	2016-2017	Configure the new module. -Foldable roof control module
F-Type	2016-2017	Configure the new module. -Shift module
F-Type	2016-2017	Configure the new module. -Front control interface module (heating, ventilation and air conditioning control)
F-Type	2016-2017	Configure the new module. -Navigation control module
F-Type	2016-2017	Configure the new module. -Satellite audio unit module.
F-Type	2016-2017	Configure the new module. -All terrain control modules.
F-Type	2016-2017	Configure the new module. -Image processing control module
F-Type	2016-2017	Configure the new module. -Steering angle sensor module.
F-Type	2016-2017	Configure the new module. -Folding top control module B
F-Type	2016-2017	Configure the new module. -Image processing control module A
F-Type	2016-2017	Configure the new module. -Interactive display module
F-Type	2016-2017	Remote communication control module-remote communication server communication check
F-Type	2016-2017	Remote communication control module-pre-activated remote communication control module
F-Type	2016-2017	Remote communication control module-activate the remote communication control module
F-Type	2016-2017	Remote communication control module-network registration status
F-Type	2016-2017	Remote communication control module-remote communication-operation mode
F-Type	2016-2017	Remote communication control module-remote communication control module battery replacement reset
F-Type	2016-2017	Security-Passive entry/passive start enabled
F-Type	2016-2017	Seat-calibration of the driver's seat.
F-Type	2016-2017	Seat-calibration of the passenger side seat.
F-Type	2016-2017	Brake system-brake disc wear protection reset
F-Type	2016-2017	Body system-valet parking mode reset
F-Type	2016-2017	Body system-power steering soft lock stop position reset routine
F-Type	2016-2017	Body system-ignition cycle counter reset
F-Type	2016-2017	Body system-tuning and locking the steering wheel to the vehicle
F-Type	2016-2017	Body system-rain sensor calibration
F-Type	2016-2017	Rear differential control module. -Control module calibration
F-Type	2016-2017	Suspension system-set/cancel air suspension manufacturing/freeze mode
F-Type	2016-2017	Audio system. -Calibration dynamic quantity control
F-Type	2016-2017	Transfer case-calibration clutch.
F-Type	2016-2017	Transfer case-oil replacement reset
F-Type	2016-2017	Special application-transmission mode
F-Type	2016-2017	Special application-parking assist control module reset
F-Type	2016-2017	Special application-The parking assist control module resets the configuration state.
F-Type	2016-2017	Remote communication control module-test internal backup battery
F-Type	2016-2017	Remote communication control module-emergency call and fault call switch lighting test
F-Type	2016-2017	Power Train-Fuel Pump Supply Pipe-Enable/Disable
F-Type	2016-2017	Configure the new module. -Restricted occupant classification system module
F-Type	2016-2017	Configure the new module. -Electric tailgate
F-Type	2016-2017	Body System-Tailgate/Luggage Compartment Calibration
F-Type	2016-2017	Heating and ventilation-vent actuator test
F-Type	2016-2017	Heating and ventilation-stepper motor initialization
F-Type	2016-2017	Heating and ventilation-reset compressor protection counter
F-Type	2016-2017	Powertrain-Engine Control Module Unlock Application
S-Type	2006-2008	Yaw rate sensor calibration.
S-Type	2006-2008	Reset the oil service counter

XTOOL

New XK	2006. 5- 2009	Seat cushion replacement
New XK	2006. 5- 2009	Driver's memory seat calibration.
New XK	2006. 5- 2009	Tire pressure monitor confirmation application.
New XK	2006. 5- 2009	Powertrain control module adaption clear.
New XK	2006. 5- 2009	Yaw rate sensor calibration.
New XK	2006. 5- 2009	Driver's side - Door glass window calibration
New XK	2006. 5- 2009	Passenger's side - Door glass window calibration
New XK	2006. 5- 2009	Lateral accelerometer calibration.
New XK	2006. 5- 2009	Pressure sensor calibration.
New XK	2006. 5- 2009	Transmission Control Module Adaptive Clearance
New XK	2006. 5- 2009	Vehicle reset
New XK	2006. 5- 2009	Parking brake release to the service position
New XK	2006. 5- 2009	Tire pressure sensor replacement
New XK	2006. 5- 2009	Tire pressure monitor receiver calibration
New XK	2006. 5- 2009	Tire pressure monitoring tire pressure sensor test
New XK	2006. 5- 2009	Configure the new module. -Tire pressure monitor module
New XK	2006. 5- 2009	Software enhancement program-rearview mirror personalization function
New XK	2006. 5- 2009	Powertrain-Self-check of purge valve.
New XK	2006. 5- 2009	Driveline-drive shaft balance
New XK	2006. 5- 2009	Add/remove accessories. -Rearview mirror personalization function
New XK	2010- 2014	Seat cushion replacement
New XK	2010- 2014	Driver's memory seat calibration.
New XK	2010- 2014	Brake bleed
New XK	2010- 2014	Tire pressure monitor confirmation application.
New XK	2010- 2014	Tire pressure monitoring sensor identification display
New XK	2010- 2014	Transmission Control Module Adaptive Clearance
New XK	2010- 2014	Powertrain Control Module Adaptive Clearance

New XK	2010-2014	Check engine oil level
New XK	2010-2014	Oil maintenance counter reset
New XK	2010-2014	Let the oil level reset
New XK	2010-2014	The parking brake is released to the service position
New XK	2010-2014	Battery replacement
New XK	2010-2014	Vehicle reset
New XK	2010-2014	Customer side door glass window calibration
New XK	2010-2014	Driver side door glazing calibration
New XK	2010-2014	Parking brake release to the service position
New XK	2010-2014	Tire pressure sensor replacement
New XK	2010-2014	Tire pressure monitor receiver calibration
New XK	2010-2014	Tire pressure monitoring tire pressure sensor test
New XK	2010-2014	Height sensor-calibration
New XK	2010-2014	Adaptive damping control module
New XK	2010-2014	Configure the new module. -Audio amplifier module.
New XK	2010-2014	Configure the new module. -ABS control module
New XK	2010-2014	Configure the new module. -Auxiliary protocol interface module
New XK	2010-2014	Configure the new module. -Digital Audio Broadcasting Module
New XK	2010-2014	Configure the new module. -Digital Audio Control Module C
New XK	2010-2014	Configure the new module. -Front control/display interface module (high-level
New XK	2010-2014	Configure the new module. -Foldable roof control module
New XK	2010-2014	Configure the new module. -Shift module
New XK	2010-2014	Configure the new module. -Headlight control module
New XK	2010-2014	Configure the new module. -Heating air conditioning control module
New XK	2010-2014	Configure the new module. -Integrated control panel
New XK	2010-2014	Configure the new module. -Navigation control module
New XK	2010-2014	Configure the new module. -Parking aid control module

New XK	2010-2014	Configure the new module. -Parking brake control module
New XK	2010-2014	Configure the new module. -Restricted occupant classification system module
New XK	2010-2014	Configure the new module. -Satellite audio unit module.
New XK	2010-2014	Configure the new module. -Speed ??control module
New XK	2010-2014	Seat-replacement seat cover
New XK	2010-2014	Heating and ventilation-stepper motor initialization
New XK	2010-2014	Rear differential control module. -Control module calibration
New XK	2010-2014	Active damping control module-establishment mode
New XK	2010-2014	Active vibration reduction control module-calibration acquisition
New XK	2010-2014	Powertrain-Self-check of purge valve.
New XK	2010-2014	Powertrain-Evaporation System Diagnostic Test
New XK	2010-2014	Powertrain-fuel preparation routine
New XK	2010-2014	Powertrain-Fuel Lift Pump
New XK	2010-2014	Power Train-Engine Control Module VIN Reading Application
New XK	2010-2014	Add/remove accessories. -Rearview mirror personalization function
New XK	2010-2014	Add/remove accessories. -Combination instrument-Russian option
XJ	2006	Reset the oil service counter
XJ	2006	Tire pressure monitor receiver calibration.
XJ	2008-2009	Yaw rate sensor calibration.
XJ	2008-2009	Reset the oil service counter
XJ	2008-2009	Tire pressure monitor receiver calibration.
XJ	2008-2009	Parking brake release to service position
XJ	2008-2009	Lateral accelerometer calibration.
XJ	2008-2009	Pressure sensor calibration.
NEW XJ	2010-2012	Driver's memory seat calibration.
NEW XJ	2010-2012	Brake bleed
NEW XJ	2010-2012	Diesel particulate filter replacement
NEW XJ	2010-2012	Powertrain control module adaption clear.

NEW XJ	2010-2012	Oil service counter reset
NEW XJ	2010-2012	Reset water in fuel detection
NEW XJ	2010-2012	Turbine shut-off valve
NEW XJ	2010-2012	Throttle valve actuator
NEW XJ	2010-2012	Exhaust gas recirculation valve
NEW XJ	2010-2012	Oxygen sensor
NEW XJ	2010-2012	Oxidation catalyst
NEW XJ	2010-2012	Tire pressure monitoring sensor identification display
NEW XJ	2010-2012	Transmission Control Module Adaptive Clearance
NEW XJ	2010-2012	Diesel particulate filter dynamic regeneration
NEW XJ	2010-2012	Powertrain Control Module Adaptive Clearance
NEW XJ	2010-2012	Show injector correction factor
NEW XJ	2010-2012	Anti-theft locker antenna unit function check
NEW XJ	2010-2012	Check all antennas
NEW XJ	2010-2012	The parking brake is released to the service position
NEW XJ	2010-2012	Replace the seat cover
NEW XJ	2010-2012	Battery replacement
NEW XJ	2010-2012	Vehicle reset
NEW XJ	2010-2012	Check before departure
NEW XJ	2010-2012	Other countries and regions of the world - Maintenance interval options
NEW XJ	2010-2012	Maintenance interval reset
NEW XJ	2010-2012	Constraint build mode
NEW XJ	2010-2012	Side Object Detection Module History
NEW XJ	2010-2012	Customer side door glass window calibration
NEW XJ	2010-2012	Driver side door glazing calibration
NEW XJ	2010-2012	Phase 1 - Preparation - Important Notes
NEW XJ	2010-2012	Phase 4 - Front Control / Display Interface Module Update Part A

NEW XJ	2010-2012	Altitude Calibration
NEW XJ	2010-2012	Air suspension deflation
NEW XJ	2010-2012	Air suspension inflation
NEW XJ	2010-2012	Set/Cancel Air Suspension Geometry Settings
NEW XJ	2010-2012	Set/Cancel Air Suspension Precision Tolerance Mode (Headlight Setting)
NEW XJ	2010-2012	Ride level control module diagnostic interface
NEW XJ	2010-2012	Ride level control module inflation (showroom)
NEW XJ	2010-2012	Display injector correction factors
NEW XJ	2010-2012	Parking brake release to the service position
NEW XJ	2010-2012	Tire pressure monitoring tire pressure sensor test
NEW XJ	2010-2012	Sunroof calibration
NEW XJ	2010-2012	Tailgate/trunk calibration
NEW XJ	2010-2012	Special application-Dashboard virtual display diagnostic application
NEW XJ	2010-2012	Tire pressure monitoring system-tire pressure sensor replacement
NEW XJ	2010-2012	Configure the new module. -ABS control module
NEW XJ	2010-2012	Configure the new module. -Adaptive damping control module
NEW XJ	2010-2012	Configure the new module. -Digital Audio Broadcasting Module
NEW XJ	2010-2012	Configure the new module. -Front control/display interface module (high-level
NEW XJ	2010-2012	Configure the new module. -Shift module
NEW XJ	2010-2012	Configure the new module. -Headlamp control module 'B'
NEW XJ	2010-2012	Configure the new module. -Rear climate control module
NEW XJ	2010-2012	Configure the new module. -Front control interface module 'B' (front audio control
NEW XJ	2010-2012	Configure the new module. -Navigation control module
NEW XJ	2010-2012	Configure the new module. -Parking aid control module
NEW XJ	2010-2012	Configure the new module. -Parking brake control module
NEW XJ	2010-2012	Configure the new module. -Restricted occupant classification system module
NEW XJ	2010-2012	Configure the new module. -Satellite audio unit module.

NEW XJ	2010-2012	Configure the new module. -Side object detection control module-left
NEW XJ	2010-2012	Configure the new module. -Speed ??control module
NEW XJ	2010-2012	Configure the new module. -Rear climate seat module
NEW XJ	2010-2012	Body system-valet parking mode reset
NEW XJ	2010-2012	Powertrain settings-fuel water detection reset
NEW XJ	2010-2012	Drivetrain settings-throttle actuator
NEW XJ	2010-2012	Drive train settings-turbine shut-off valve
NEW XJ	2010-2012	Drive train settings-oxygen sensor
NEW XJ	2010-2012	Drivetrain settings-oxidation catalyst
NEW XJ	2010-2012	Rear differential control module. -Control module calibration
NEW XJ	2010-2012	Suspension system-set/cancel air suspension manufacturing/freeze mode
NEW XJ	2010-2012	Active damping control module-establishment mode
NEW XJ	2010-2012	Active vibration reduction control module-calibration acquisition
NEW XJ	2010-2012	Audio system. -Calibration dynamic quantity control
NEW XJ	2010-2012	Special application-transmission mode
NEW XJ	2010-2012	Powertrain-Self-check of purge valve.
NEW XJ	2010-2012	Powertrain-Evaporation System Diagnostic Test
NEW XJ	2010-2012	Powertrain-fuel preparation routine
NEW XJ	2010-2012	Powertrain-Fuel Lift Pump
NEW XJ	2010-2012	Powertrain-diesel particulate filter replacement
NEW XJ	2010-2012	Drive train-oil service counter reset
NEW XJ	2010-2012	Power Train-Engine Control Module VIN Reading Application
NEW XJ	2010-2012	Entertainment system-reset navigation
NEW XJ	2010-2012	Entertainment system-DVD zone counter reset
NEW XJ	2013-2015	Brake bleed
NEW XJ	2013-2015	Diesel particulate filter replacement
NEW XJ	2013-2015	Powertrain control module adaption clear.

NEW XJ	2013-2015	Yaw rate sensor calibration.
NEW XJ	2013-2015	Reset water in fuel detection
NEW XJ	2013-2015	Turbine shut-off valve
NEW XJ	2013-2015	Throttle valve actuator
NEW XJ	2013-2015	Exhaust gas recirculation valve
NEW XJ	2013-2015	Oxygen sensor
NEW XJ	2013-2015	Oxidation catalyst
NEW XJ	2013-2015	Throttle valve actuator replacement
NEW XJ	2013-2015	Tire pressure monitoring sensor identification display
NEW XJ	2013-2015	Transmission Control Module Adaptive Clearance
NEW XJ	2013-2015	Diesel particulate filter dynamic regeneration
NEW XJ	2013-2015	Powertrain Control Module Adaptive Clearance
NEW XJ	2013-2015	Engine Control Module Unlocking Application
NEW XJ	2013-2015	Throttle Valve Brake Replacement
NEW XJ	2013-2015	Injector valve test
NEW XJ	2013-2015	Fuel preparation routine
NEW XJ	2013-2015	Show injector correction factor
NEW XJ	2013-2015	Oil maintenance counter reset
NEW XJ	2013-2015	Anti-theft locker antenna unit function check
NEW XJ	2013-2015	Check all antennas
NEW XJ	2013-2015	The parking brake is released to the service position
NEW XJ	2013-2015	Replace the seat cover
NEW XJ	2013-2015	Starting TV Test Picture
NEW XJ	2013-2015	Applications for Information and Entertainment Systems
NEW XJ	2013-2015	Testing Dual Battery Systems
NEW XJ	2013-2015	Battery replacement
NEW XJ	2013-2015	Static current control module internal inspection

NEW XJ	2013-2015	Verify auxiliary battery charging
NEW XJ	2013-2015	Set/Cancel Air Suspension Precision Tolerance Mode (Headlight Setting)
NEW XJ	2013-2015	Set/Cancel Air Suspension Geometry Settings
NEW XJ	2013-2015	Vehicle reset
NEW XJ	2013-2015	Check before departure
NEW XJ	2013-2015	Other countries and regions of the world - Maintenance interval options
NEW XJ	2013-2015	Maintenance interval reset
NEW XJ	2013-2015	Constraint build mode
NEW XJ	2013-2015	Customer side door glass window calibration
NEW XJ	2013-2015	Personal side rear door sunshade initialization
NEW XJ	2013-2015	Driver side door glazing calibration
NEW XJ	2013-2015	Driver side rear door sunshade initialization
NEW XJ	2013-2015	Altitude Calibration
NEW XJ	2013-2015	Air suspension deflation
NEW XJ	2013-2015	Air suspension inflation
NEW XJ	2013-2015	Ride level control module diagnostic interface
NEW XJ	2013-2015	Ride level control module inflation (showroom)
NEW XJ	2013-2015	Display injector correction factors
NEW XJ	2013-2015	Parking brake release to the service position
NEW XJ	2013-2015	Tire pressure monitoring tire pressure sensor test
NEW XJ	2013-2015	Sunroof calibration
NEW XJ	2013-2015	Tailgate/trunk calibration
NEW XJ	2013-2015	Special application-Dashboard virtual display diagnostic application
NEW XJ	2013-2015	Tire pressure monitoring system-tire pressure sensor replacement
NEW XJ	2013-2015	Configure the new module. -ABS control module
NEW XJ	2013-2015	Configure the new module. -Digital Audio Broadcasting Module
NEW XJ	2013-2015	Configure the new module. -Front control/display interface module (high-level

NEW XJ	2013-2015	Configure the new module. -Shift module
NEW XJ	2013-2015	Configure the new module. -Headlamp control module'B'
NEW XJ	2013-2015	Configure the new module. -Rear climate control module
NEW XJ	2013-2015	Configure the new module. -Front control interface module 'B' (front audio control
NEW XJ	2013-2015	Configure the new module. -Navigation control module
NEW XJ	2013-2015	Configure the new module. -Parking aid control module
NEW XJ	2013-2015	Configure the new module. -Restricted occupant classification system module
NEW XJ	2013-2015	Configure the new module. -Satellite audio unit module.
NEW XJ	2013-2015	Configure the new module. -Side object detection control module-left
NEW XJ	2013-2015	Configure the new module. -Speed ??control module
NEW XJ	2013-2015	Configure the new module. -Rear climate seat module
NEW XJ	2013-2015	Braking system-yaw rate sensor calibration.
NEW XJ	2013-2015	Body system-valet parking mode reset
NEW XJ	2013-2015	Powertrain settings-fuel water detection reset
NEW XJ	2013-2015	Drivetrain settings-throttle actuator
NEW XJ	2013-2015	Drive train settings-turbine shut-off valve
NEW XJ	2013-2015	Drive train settings-oxygen sensor
NEW XJ	2013-2015	Drivetrain settings-oxidation catalyst
NEW XJ	2013-2015	Rear differential control module. -Control module calibration
NEW XJ	2013-2015	Suspension system-set/cancel air suspension manufacturing/freeze mode
NEW XJ	2013-2015	Audio system. -Calibration dynamic quantity control
NEW XJ	2013-2015	Transfer case-calibration clutch.
NEW XJ	2013-2015	Transfer case-oil replacement reset
NEW XJ	2013-2015	Special application-transmission mode
NEW XJ	2013-2015	Powertrain-Fuel Lift Pump
NEW XJ	2013-2015	Powertrain-diesel particulate filter replacement
NEW XJ	2013-2015	Power Train-Fuel Pump Supply Pipe-Enable/Disable

NEW XJ	2013-2015	Entertainment system-reset navigation
NEW XJ	2013-2015	Entertainment system-DVD zone counter reset
NEW XJ	2016	Brake bleed
NEW XJ	2016	Steering column calibration
NEW XJ	2016	Oil change reset
NEW XJ	2016	Throttle valve actuator replacement
NEW XJ	2016	Auto oil reset
NEW XJ	2016	Service interval reset
NEW XJ	2016	Replace brake pads -operating guide
NEW XJ	2016	Oil service counter reset
NEW XJ	2016	Front left wheel sensor
NEW XJ	2016	Front right wheel sensor
NEW XJ	2016	Rear right wheel sensor
NEW XJ	2016	Rear left wheel sensor
NEW XJ	2016	Spare wheel
NEW XJ	2016	Power steering soft-lock end stops reset
NEW XJ	2016	Lock steering tune to vehicle
NEW XJ	2016	Yaw rate sensor calibration.
NEW XJ	2016	Tire pressure monitoring sensor
NEW XJ	2016	Reset Selective Catalytic Reduction Start
NEW XJ	2016	Resetting the Selective Catalytic Reduction
NEW XJ	2016	Transmission Control Module Adaptive
NEW XJ	2016	Diesel exhaust gas oil infusion and pressure
NEW XJ	2016	Diesel exhaust gas tank level sensor
NEW XJ	2016	Diesel exhaust gas jet pump replacement
NEW XJ	2016	Diesel particulate filter dynamic
NEW XJ	2016	This routine will reset flight recorder data
NEW XJ	2016	Powertrain Control Module Adaptive Clearance
NEW XJ	2016	Engine Control Module Low Pressure EGR
NEW XJ	2016	Engine Control Module Resets Crankcase
NEW XJ	2016	Engine Control Module Unlocking Application
NEW XJ	2016	Engine Control Module Mass Air Flow Adaptive
NEW XJ	2016	Throttle Valve Brake Replacement
NEW XJ	2016	Exhaust valve adaptation
NEW XJ	2016	Injector valve test
NEW XJ	2016	Enable/Disable Glow Plug
NEW XJ	2016	Fuel preparation routine
NEW XJ	2016	Show injector correction factor
NEW XJ	2016	Check all antennas
NEW XJ	2016	Parking Brake Start
NEW XJ	2016	Remote Information Processing SIM Card Type
NEW XJ	2016	Battery replacement
NEW XJ	2016	Static current control module internal
NEW XJ	2016	Set/Cancel Air Suspension Precision
NEW XJ	2016	Set/Cancel Air Suspension Geometry Settings
NEW XJ	2016	IPMA AEB Data Reading
NEW XJ	2016	Vehicle reset
NEW XJ	2016	Check before departure
NEW XJ	2016	Customer side door glass window calibration
NEW XJ	2016	Personal side rear door sunshade
NEW XJ	2016	Driver side door glazing calibration
NEW XJ	2016	Driver side rear door sunshade

NEW XJ	2016	Altitude Calibration
NEW XJ	2016	Air suspension deflation
NEW XJ	2016	Air suspension inflation
NEW XJ	2016	Ride level control module diagnostic
NEW XJ	2016	Ride level control module inflation
NEW XJ	2016	Display injector correction factors
NEW XJ	2016	Longitudinal accelerometer calibration.
NEW XJ	2016	Brake caliper replacement assembly test
NEW XJ	2016	Parking brake pad replacement - Release to
NEW XJ	2016	Parking brake pad replacement - Exit
NEW XJ	2016	Parking brake activation
NEW XJ	2016	Sunroof calibration
NEW XJ	2016	Tailgate/trunk calibration
NEW XJ	2016	Power Train-Diesel Exhaust Oil Level Check
NEW XJ	2016	Special application-Dashboard virtual
NEW XJ	2016	Tire pressure monitoring system-tire
NEW XJ	2016	Configure the new module. -ABS control
NEW XJ	2016	Configure the new module. -Shift module
NEW XJ	2016	Configure the new module. -Rear climate
NEW XJ	2016	Configure the new module. -Front control
NEW XJ	2016	Configure the new module. -Speed ??control
NEW XJ	2016	Configure the new module. -Image processing
NEW XJ	2016	Configure the new module. -Steering angle
NEW XJ	2016	Configure the new module. -Vehicle dynamic
NEW XJ	2016	Remote communication control module-remote
NEW XJ	2016	Remote communication control module-pre-
NEW XJ	2016	Remote communication control module-network
NEW XJ	2016	Remote communication control module-remote
NEW XJ	2016	Remote communication control module-remote
NEW XJ	2016	Security-Passive entry/passive start enabled
NEW XJ	2016	Seat-calibration of the driver's seat.
NEW XJ	2016	Seat-calibration of the passenger side seat.
NEW XJ	2016	Seat-Rear Seat-Calibration-Right
NEW XJ	2016	Seat-Rear Seat-Calibration-Left
NEW XJ	2016	Seat-driver's seat massage on-demand self-
NEW XJ	2016	Seat-Passenger seat massage on-demand self-
NEW XJ	2016	Seat-right rear seat massage on-demand self-
NEW XJ	2016	Seat-left rear seat massage on-demand self-
NEW XJ	2016	Braking system-yaw rate sensor calibration.
NEW XJ	2016	Body system-valet parking mode reset
NEW XJ	2016	Body system-variable assist power steering
NEW XJ	2016	Body system-power steering soft lock stop
NEW XJ	2016	Body system-ignition cycle counter reset
NEW XJ	2016	Body system-tuning and locking the steering
NEW XJ	2016	Body system-rain sensor calibration
NEW XJ	2016	Heating and ventilation-seat climate control
NEW XJ	2016	Powertrain settings-fuel water detection
NEW XJ	2016	Drivetrain settings-throttle actuator
NEW XJ	2016	Drive train settings-turbine shut-off valve
NEW XJ	2016	Drive train settings-oxygen sensor
NEW XJ	2016	Drivetrain settings-oxidation catalyst
NEW XJ	2016	Drivetrain settings-diesel particulate
NEW XJ	2016	Drive train settings-reinitialize diesel
NEW XJ	2016	Rear differential control module. -Control

NEW XJ	2016	Suspension system-set/cancel air suspension
NEW XJ	2016	Transfer case-calibration clutch.
NEW XJ	2016	Transfer case-oil replacement reset
NEW XJ	2016	Special application-transmission mode
NEW XJ	2016	Remote communication control module-test
NEW XJ	2016	Remote communication control module-
NEW XJ	2016	Powertrain-Fuel Lift Pump
NEW XJ	2016	Powertrain-diesel particulate filter
NEW XJ	2016	Power Train-Fuel Pump Supply Pipe-
NEW XJ	2016	Powertrain-Clear the stored carbon particle
NEW XJ	2016	Entertainment system-InControl Touch Pro
NEW XJ	2016	Entertainment system-InControl Touch Pro
NEW XJ	2016	Entertainment system-InControl Touch Pro
NEW XJ	2016	Entertainment System-InControl Touch Pro
NEW XJ	2016	Entertainment System-InControl Smart
XE	2016	Diesel particulate filter replacement
XE	2016	Throttle valve actuator
XE	2016	Diesel particulate filter differential
XE	2016	Throttle valve actuator replacement
XE	2016	Parking brake pad replacement - Release to
XE	2016	Parking brake pad replacement - Exit
XE	2016	Auto oil reset
XE	2016	Service interval reset
XE	2016	Oil service counter reset
XE	2016	Replace brake pads -operating guide
XE	2016	Front left wheel sensor
XE	2016	Front right wheel sensor
XE	2016	Rear right wheel sensor
XE	2016	Rear left wheel sensor
XE	2016	Spare wheel
XE	2016	Power steering soft-lock end stops reset
XE	2016	Lock steering tune to vehicle
XE	2016	roof blind calibration
XE	2016	Driver's seat massage on demand self test
XE	2016	Tire pressure monitoring sensor
XE	2016	Reset Selective Catalytic Reduction Start
XE	2016	Transmission Control Module Adaptive
XE	2016	Diesel exhaust gas oil infusion and pressure
XE	2016	Diesel exhaust gas tank level sensor
XE	2016	Diesel exhaust gas jet pump replacement
XE	2016	Diesel particulate filter dynamic
XE	2016	This routine will reset flight recorder data
XE	2016	Powertrain Control Module Adaptive Clearance
XE	2016	Engine Control Module Low Pressure EGR
XE	2016	Engine Control Module Resets Crankcase
XE	2016	Engine Control Module Vortex Valve Adaptive
XE	2016	Engine Control Module Mass Air Flow Adaptive
XE	2016	Engine Control Module Resets Fuel Pump
XE	2016	Glow Plug Control Module
XE	2016	Throttle Valve Brake Replacement
XE	2016	Injector valve test
XE	2016	Enable/Disable Glow Plug
XE	2016	Fuel preparation routine
XE	2016	Show injector correction factor

XE	2016	Anti-theft locker antenna unit function
XE	2016	Check all antennas
XE	2016	Parking Brake Start
XE	2016	Activate test picture
XE	2016	Head-view display control module reset
XE	2016	Activate Telematics Control Module
XE	2016	Remote Information Processing SIM Card Type
XE	2016	Applications for Information and
XE	2016	Battery replacement
XE	2016	Static current control module internal
XE	2016	IPMA AEB Data Reading
XE	2016	Vehicle reset
XE	2016	Check before departure
XE	2016	Constraint build mode
XE	2016	door and window calibration
XE	2016	Headlight level adjustment height sensor
XE	2016	Altitude Calibration
XE	2016	Display injector correction factors
XE	2016	Sunroof calibration
XE	2016	Tailgate/trunk calibration
XE	2016	Power Train-Diesel Exhaust Oil Level Check
XE	2016	Tire pressure monitoring system-tire
XE	2016	Brake bleed
XE	2016	Configure the new module. -Audio amplifier
XE	2016	Configure the new module. -Digital Audio
XE	2016	Configure the new module. -Front
XE	2016	Configure the new module. -Shift module
XE	2016	Configure the new module. -Front control
XE	2016	Configure the new module. -Navigation
XE	2016	Configure the new module. -Satellite audio
XE	2016	Configure the new module. -Speed ??control
XE	2016	Configure the new module. -All terrain
XE	2016	Configure the new module. -Image processing
XE	2016	Configure the new module. -Steering angle
XE	2016	Configure the new module. -Head-up display
XE	2016	Configure the new module. -Expandable
XE	2016	Configure the new module. -Interactive
XE	2016	Remote communication control module-remote
XE	2016	Remote communication control module-pre-
XE	2016	Remote communication control module-
XE	2016	Remote communication control module-network
XE	2016	Remote communication control module-remote
XE	2016	Remote communication control module-remote
XE	2016	Seat-calibration of the driver's seat.
XE	2016	Seat-driver's seat massage on-demand self-
XE	2016	Parking brake-brake caliper replacement
XE	2016	Parking brake-parking brake pad replacement-
XE	2016	Parking brake-parking brake pad replacement-
XE	2016	Parking brake-apply and release the electric
XE	2016	Body system-roof shade-calibration
XE	2016	Body system-valet parking mode reset
XE	2016	Body system-power steering soft lock stop
XE	2016	Body system-ignition cycle counter reset
XE	2016	Body system-tuning and locking the steering

XE	2016	Body system-rain sensor calibration
XE	2016	Auxiliary heater-auxiliary heater fuel
XE	2016	Powertrain settings-fuel water detection
XE	2016	Drivetrain settings-throttle actuator
XE	2016	Drive train settings-turbine shut-off valve
XE	2016	Drive train settings-exhaust gas
XE	2016	Drive train settings-oxygen sensor
XE	2016	Drivetrain settings-oxidation catalyst
XE	2016	Drivetrain settings-diesel particulate
XE	2016	Drive train settings-reinitialize diesel
XE	2016	Suspension system-set/cancel air suspension
XE	2016	Audio system. -Calibration dynamic quantity
XE	2016	Special application-transmission mode
XE	2016	Remote communication control module-test
XE	2016	Remote communication control module-
XE	2016	Powertrain-Fuel Lift Pump
XE	2016	Powertrain-diesel particulate filter
XE	2016	Power Train-Fuel Pump Supply Pipe-
XE	2016	Powertrain-Air Channel Setting Program
XE	2016	Unlock the deployable towbar
XE	2016	Deployable towbar recovery
XE	2016	Retractable towbar
XE	2016	Deploy towbar
XE	2016	Deployable towbar speaker test
XE	2017	Brake bleed
XE	2017	Reset Selective Catalytic Reduction Start
XE	2017	Transmission Control Module Adaptive
XE	2017	Diesel exhaust gas oil infusion and pressure
XE	2017	Diesel exhaust gas tank level sensor
XE	2017	Diesel exhaust gas jet pump replacement
XE	2017	Diesel particulate filter dynamic
XE	2017	This routine will reset flight recorder data
XE	2017	Powertrain Control Module Adaptive Clearance
XE	2017	Engine Control Module Low Pressure EGR
XE	2017	Engine Control Module Resets Crankcase
XE	2017	Engine Control Module Vortex Valve Adaptive
XE	2017	Engine Control Module Mass Air Flow Adaptive
XE	2017	Engine Control Module Resets Fuel Pump
XE	2017	Glow Plug Control Module
XE	2017	Throttle Valve Brake Replacement
XE	2017	Injector valve test
XE	2017	Enable/Disable Glow Plug
XE	2017	Fuel preparation routine
XE	2017	Show injector correction factor
XE	2017	Anti-theft locker antenna unit function
XE	2017	Check all antennas
XE	2017	Transfer box control module - locking
XE	2017	Parking Brake Start
XE	2017	Activate test picture
XE	2017	Head-view display control module reset
XE	2017	Activate Telematics Control Module
XE	2017	Remote Information Processing SIM Card Type
XE	2017	Pump ventilation
XE	2017	Reset - Clear specified features

XE	2017	Battery replacement
XE	2017	Static current control module internal
XE	2017	IPMA AEB Data Reading
XE	2017	Vehicle reset
XE	2017	Check before departure
XE	2017	Constraint build mode
XE	2017	door and window calibration
XE	2017	Headlight level adjustment height sensor
XE	2017	Altitude Calibration
XE	2017	Sunroof calibration
XE	2017	Tailgate/trunk calibration
XE	2017	Power Train-Diesel Exhaust Oil Level Check
XE	2017	Tire pressure monitoring system-tire
XE	2017	Configure the new module. -Audio amplifier
XE	2017	Configure the new module. -Shift module
XE	2017	Configure the new module. -Front control
XE	2017	Configure the new module. -Speed ??control
XE	2017	Configure the new module. -All terrain
XE	2017	Configure the new module. -Image processing
XE	2017	Configure the new module. -Steering angle
XE	2017	Configure the new module. -Head-up display
XE	2017	Configure the new module. -Expandable
XE	2017	Configure the new module. -Interactive
XE	2017	Remote communication control module-remote
XE	2017	Remote communication control module-pre-
XE	2017	Remote communication control module-
XE	2017	Remote communication control module-network
XE	2017	Remote communication control module-remote
XE	2017	Remote communication control module-remote
XE	2017	Security-Passive entry/passive start enabled
XE	2017	Seat-calibration of the driver's seat.
XE	2017	Seat-driver's seat massage on-demand self-
XE	2017	Parking brake-brake caliper replacement
XE	2017	Parking brake-parking brake pad replacement-
XE	2017	Parking brake-parking brake pad replacement-
XE	2017	Parking brake-apply and release the electric
XE	2017	Body system-roof shade-calibration
XE	2017	Body system-valet parking mode reset
XE	2017	Body system-power steering soft lock stop
XE	2017	Body system-ignition cycle counter reset
XE	2017	Body system-tuning and locking the steering
XE	2017	Body system-rain sensor calibration
XE	2017	Auxiliary heater-auxiliary heater fuel
XE	2017	Powertrain settings-fuel water detection
XE	2017	Drivetrain settings-throttle actuator
XE	2017	Drive train settings-turbine shut-off valve
XE	2017	Drive train settings-exhaust gas
XE	2017	Drive train settings-oxygen sensor
XE	2017	Drivetrain settings-oxidation catalyst
XE	2017	Drivetrain settings-diesel particulate
XE	2017	Drive train settings-reinitialize diesel
XE	2017	Suspension system-set/cancel air suspension
XE	2017	Special application-transmission mode
XE	2017	Remote communication control module-test

XE	2017	Remote communication control module-
XE	2017	Powertrain-Fuel Lift Pump
XE	2017	Powertrain-diesel particulate filter
XE	2017	Power Train-Fuel Pump Supply Pipe-
XE	2017	Powertrain-Air Channel Setting Program
XE	2017	Entertainment system-InControl Touch Pro
XE	2017	Entertainment system-InControl Touch Pro
XE	2017	Entertainment system-InControl Touch Pro
XE	2017	Entertainment System-InControl Touch Pro
XE	2017	Entertainment System-InControl Smart
XE	2017	Unlock the deployable towbar
XE	2017	Deployable towbar recovery
XE	2017	Retractable towbar
XE	2017	Deploy towbar
XE	2017	Deployable towbar speaker test
XF	2008- 2009	Brake bleed
XF	2008- 2009	Tire pressure monitor confirmation application.
XF	2008- 2009	Powertrain control module adaption clear.
XF	2008- 2009	Transmission Control Module Adaptive Clearance
XF	2008- 2009	Diesel particulate filter dynamic regeneration
XF	2008- 2009	Diesel particulate filter replacement
XF	2008- 2009	Diesel particulate filter fuel related parts replacement
XF	2008- 2009	Diesel particulate filter conditions (stored value)
XF	2008- 2009	High Pressure Jet Pump Replacement
XF	2008- 2009	Air conditioning system adaptive reset
XF	2008- 2009	Oil maintenance counter reset
XF	2008- 2009	The parking brake is released to the service position
XF	2008- 2009	Stepper motor initialization
XF	2008- 2009	Ventilator Actuator Test
XF	2008- 2009	Speed control internal state
XF	2008- 2009	Replace the seat cover
XF	2008- 2009	Battery replacement
XF	2008- 2009	Constraint build mode
XF	2008- 2009	Side Object Detection Module History

XF	2008-2009	Right - Radar Signal - Reverse Correction
XF	2008-2009	Customer side door glass window calibration
XF	2008-2009	Driver side door glazing calibration
XF	2008-2009	Pedestrian collision state reset
XF	2008-2009	Tire pressure sensor replacement
XF	2008-2009	Tire pressure monitor receiver calibration
XF	2008-2009	Tire pressure monitoring tire pressure sensor test
XF	2008-2009	Configure the new module. -ABS control module
XF	2008-2009	Configure the new module. -Adaptive damping control module
XF	2008-2009	Configure the new module. -Central junction box configuration update
XF	2008-2009	Configure the new module. -Digital Audio Broadcasting Module
XF	2008-2009	Configure the new module. -Front control/display interface module (high-level
XF	2008-2009	Configure the new module. -Shift module
XF	2008-2009	Configure the new module. -Collision classification system
XF	2008-2009	Configure the new module. -Navigation control module
XF	2008-2009	Configure the new module. -Parking aid control module
XF	2008-2009	Configure the new module. -Parking brake control module
XF	2008-2009	Configure the new module. -Restricted occupant classification system module
XF	2008-2009	Configure the new module. -Satellite audio unit module.
XF	2008-2009	Configure the new module. -Side object detection control module-left
XF	2008-2009	Configure the new module. -Speed control module
XF	2008-2009	XF--Pre-sales update-Central junction box configuration update
XF	2008-2009	Active vibration reduction control module-calibration acquisition
XF	2008-2009	Powertrain-Self-check of purge valve.
XF	2008-2009	Powertrain-The powertrain control module is adaptively cleared.
XF	2008-2009	Add/remove accessories. -Rearview mirror personalization function
XF	2008-2009	Add/remove accessories. -Passenger restraint disable switch

XF	2010-2011	Driver's memory seat calibration.
XF	2010-2011	Brake bleed
XF	2010-2011	Tire pressure monitor confirmation application.
XF	2010-2011	Diesel particulate filter replacement
XF	2010-2011	Powertrain control module adaption clear.
XF	2010-2011	Reset water in fuel detection
XF	2010-2011	Turbine shut-off valve
XF	2010-2011	Throttle valve actuator
XF	2010-2011	Exhaust gas recirculation valve
XF	2010-2011	Injector replacement
XF	2010-2011	Oxygen sensor
XF	2010-2011	Oxidation catalyst
XF	2010-2011	Transmission Control Module Adaptive Clearance
XF	2010-2011	Diesel particulate filter dynamic regeneration
XF	2010-2011	Check engine oil level
XF	2010-2011	Show injector correction factor
XF	2010-2011	Oil maintenance counter reset
XF	2010-2011	Let the oil level reset
XF	2010-2011	The parking brake is released to the service position
XF	2010-2011	Stepper motor initialization
XF	2010-2011	Ventilator Actuator Test
XF	2010-2011	Replace the seat cover
XF	2010-2011	Battery replacement
XF	2010-2011	Other countries and regions of the world - Maintenance interval options
XF	2010-2011	Constraint build mode
XF	2010-2011	Side Object Detection Module History
XF	2010-2011	Right - Radar Signal - Reverse Correction

XF	2010-2011	Customer side door glass window calibration
XF	2010-2011	Driver side door glazing calibration
XF	2010-2011	Pedestrian collision state reset
XF	2010-2011	Tire pressure sensor replacement
XF	2010-2011	Tire pressure monitor receiver calibration
XF	2010-2011	Tire pressure monitoring tire pressure sensor test
XF	2010-2011	Height sensor-calibration
XF	2010-2011	Adaptive damping control module
XF	2010-2011	Configure the new module. -ABS control module
XF	2010-2011	Configure the new module. -Auxiliary protocol interface module
XF	2010-2011	Configure the new module. -Digital Audio Broadcasting Module
XF	2010-2011	Configure the new module. -Digital Audio Control Module C
XF	2010-2011	Configure the new module. -Front control/display interface module (high-level
XF	2010-2011	Configure the new module. -Shift module
XF	2010-2011	Configure the new module. -Integrated control panel
XF	2010-2011	Configure the new module. -Navigation control module
XF	2010-2011	Configure the new module. -Parking aid control module
XF	2010-2011	Configure the new module. -Parking brake control module
XF	2010-2011	Configure the new module. -Restricted occupant classification system module
XF	2010-2011	Configure the new module. -Satellite audio unit module.
XF	2010-2011	Configure the new module. -Side object detection control module-left
XF	2010-2011	Configure the new module. -Speed ??control module
XF	2010-2011	Powertrain settings-fuel water detection reset
XF	2010-2011	Drivetrain settings-throttle actuator
XF	2010-2011	Drive train settings-turbine shut-off valve
XF	2010-2011	Drive train settings-oxygen sensor
XF	2010-2011	Drivetrain settings-oxidation catalyst

XF	2010-2011	Rear differential control module. -Control module calibration
XF	2010-2011	Active damping control module-establishment mode
XF	2010-2011	Active vibration reduction control module-calibration acquisition
XF	2010-2011	Powertrain-fuel preparation routine
XF	2010-2011	Powertrain-Fuel Lift Pump
XF	2010-2011	Powertrain-The powertrain control module is adaptively cleared.
XF	2010-2011	Powertrain-diesel particulate filter replacement
XF	2010-2011	Power Train-Engine Control Module VIN Reading Application
XF	2010-2011	Add/remove accessories. -Rearview mirror personalization function
XF	2010-2011	Add/remove accessories. -Passenger restraint disable switch
XF	2012	Brake bleed
XF	2012	Diesel particulate filter replacement
XF	2012	Powertrain control module adaption clear.
XF	2012	Yaw rate sensor calibration.
XF	2012	Reset water in fuel detection
XF	2012	Turbine shut-off valve
XF	2012	Throttle valve actuator
XF	2012	Exhaust gas recirculation valve
XF	2012	Oxygen sensor
XF	2012	Oxidation catalyst
XF	2012	Diesel particulate filter differential
XF	2012	Diesel fueling adaption re-initialization
XF	2012	Transmission Control Module Adaptive
XF	2012	Diesel particulate filter dynamic
XF	2012	Check engine oil level
XF	2012	Show injector correction factor
XF	2012	Oil maintenance counter reset
XF	2012	Let the oil level reset
XF	2012	The parking brake is released to the service
XF	2012	Stepper motor initialization
XF	2012	Ventilator Actuator Test
XF	2012	Replace the seat cover
XF	2012	Applications for Information and
XF	2012	Battery replacement
XF	2012	Other countries and regions of the world -
XF	2012	Constraint build mode
XF	2012	Side Object Detection Module History
XF	2012	Right - Radar Signal - Reverse Correction
XF	2012	Customer side door glass window calibration
XF	2012	Driver side door glazing calibration
XF	2012	Display injector correction factors
XF	2012	Parking brake release to the service
XF	2012	Tire pressure sensor replacement
XF	2012	Tire pressure monitor receiver calibration

XF	2012	Tire pressure monitoring tire pressure
XF	2012	Height sensor-calibration
XF	2012	Adaptive damping control module
XF	2012	Configure the new module. -ABS control
XF	2012	Configure the new module. -Digital Audio
XF	2012	Configure the new module. -Front
XF	2012	Configure the new module. -Shift module
XF	2012	Configure the new module. -Headlamp control
XF	2012	Configure the new module. -Front control
XF	2012	Configure the new module. -Navigation
XF	2012	Configure the new module. -Parking aid
XF	2012	Configure the new module. -Parking brake
XF	2012	Configure the new module. -Restricted
XF	2012	Configure the new module. -Satellite audio
XF	2012	Configure the new module. -Side object
XF	2012	Configure the new module. -Speed ??control
XF	2012	Configure the new module. -Gateway module
XF	2012	Braking system-yaw rate sensor calibration.
XF	2012	Powertrain settings-fuel water detection
XF	2012	Drivetrain settings-throttle actuator
XF	2012	Drive train settings-turbine shut-off valve
XF	2012	Drive train settings-exhaust gas
XF	2012	Drive train settings-oxygen sensor
XF	2012	Drivetrain settings-oxidation catalyst
XF	2012	Drivetrain settings-diesel particulate
XF	2012	Drive train settings-reinitialize diesel
XF	2012	Rear differential control module. -Control
XF	2012	Active damping control module-establishment
XF	2012	Active vibration reduction control module-
XF	2012	Audio system. -Calibration dynamic quantity
XF	2012	Powertrain-Evaporation System Diagnostic
XF	2012	Powertrain-fuel preparation routine
XF	2012	Powertrain-Fuel Lift Pump
XF	2012	Powertrain-The powertrain control module is
XF	2012	Powertrain-diesel particulate filter
XF	2012	Entertainment system-reset navigation
XF	2012	Entertainment system-DVD zone counter reset
XF	2013-2015	Brake bleed
XF	2013-2015	Diesel particulate filter replacement
XF	2013-2015	Powertrain control module adaption clear.
XF	2013-2015	Yaw rate sensor calibration.
XF	2013-2015	Reset water in fuel detection
XF	2013-2015	Turbine shut-off valve
XF	2013-2015	Throttle valve actuator
XF	2013-2015	Exhaust gas recirculation valve

XF	2013-2015	Oxygen sensor
XF	2013-2015	Oxidation catalyst
XF	2013-2015	Battery replacement
XF	2013-2015	Diesel fueling adaption re-initialization
XF	2013-2015	Throttle valve actuator replacement
XF	2013-2015	Transmission Control Module Adaptive Clearance
XF	2013-2015	Diesel particulate filter dynamic regeneration
XF	2013-2015	Powertrain Control Module Adaptive Clearance
XF	2013-2015	Engine Control Module Unlocking Application
XF	2013-2015	Throttle Valve Brake Replacement
XF	2013-2015	Injector valve test
XF	2013-2015	Fuel preparation routine
XF	2013-2015	Show injector correction factor
XF	2013-2015	Oil maintenance counter reset
XF	2013-2015	Anti-theft locker antenna unit function check
XF	2013-2015	Check all antennas
XF	2013-2015	The parking brake is released to the service position
XF	2013-2015	Stepper motor initialization
XF	2013-2015	Ventilator Actuator Test
XF	2013-2015	Replace the seat cover
XF	2013-2015	Starting TV Test Picture
XF	2013-2015	Applications for Information and Entertainment Systems
XF	2013-2015	Testing Dual Battery Systems
XF	2013-2015	Static current control module internal inspection
XF	2013-2015	Verify auxiliary battery charging
XF	2013-2015	Set/Cancel Air Suspension Precision Tolerance Mode (Headlight Setting)
XF	2013-2015	Set/Cancel Air Suspension Geometry Settings

XF	2013-2015	Check before departure
XF	2013-2015	Other countries and regions of the world - Maintenance interval options
XF	2013-2015	Maintenance interval reset
XF	2013-2015	Constraint build mode
XF	2013-2015	Right - Radar Signal - Reverse Correction
XF	2013-2015	Customer side door glass window calibration
XF	2013-2015	Driver side door glazing calibration
XF	2013-2015	Altitude Calibration
XF	2013-2015	Air suspension deflation
XF	2013-2015	Air suspension inflation
XF	2013-2015	Ride level control module diagnostic interface
XF	2013-2015	Ride level control module inflation (showroom)
XF	2013-2015	Display injector correction factors
XF	2013-2015	Parking brake release to the service position
XF	2013-2015	Tire pressure sensor replacement
XF	2013-2015	Tire pressure monitor receiver calibration
XF	2013-2015	Tire pressure monitoring tire pressure sensor test
XF	2013-2015	Tailgate/trunk calibration
XF	2013-2015	Height sensor-calibration
XF	2013-2015	Adaptive damping control module
XF	2013-2015	Configure the new module. -ABS control module
XF	2013-2015	Configure the new module. -Digital Audio Broadcasting Module
XF	2013-2015	Configure the new module. -Front control/display interface module (high-level
XF	2013-2015	Configure the new module. -Shift module
XF	2013-2015	Configure the new module. -Headlamp control module 'B'
XF	2013-2015	Configure the new module. -Heating air conditioning control module
XF	2013-2015	Configure the new module. -Front control interface module 'B' (front audio control

XF	2013-2015	Configure the new module. -Navigation control module
XF	2013-2015	Configure the new module. -Parking aid control module
XF	2013-2015	Configure the new module. -Parking brake control module
XF	2013-2015	Configure the new module. -Restricted occupant classification system module
XF	2013-2015	Configure the new module. -Satellite audio unit module.
XF	2013-2015	Configure the new module. -Side object detection control module-left
XF	2013-2015	Configure the new module. -Speed ??control module
XF	2013-2015	Configure the new module. -Gateway module
XF	2013-2015	Braking system-yaw rate sensor calibration.
XF	2013-2015	Powertrain settings-fuel water detection reset
XF	2013-2015	Drivetrain settings-throttle actuator
XF	2013-2015	Drive train settings-turbine shut-off valve
XF	2013-2015	Drive train settings-exhaust gas recirculation valve.
XF	2013-2015	Drive train settings-oxygen sensor
XF	2013-2015	Drivetrain settings-oxidation catalyst
XF	2013-2015	Drivetrain settings-diesel particulate filter differential pressure sensor
XF	2013-2015	Drive train settings-reinitialize diesel fuel filling adaptation value
XF	2013-2015	Rear differential control module. -Control module calibration
XF	2013-2015	Suspension system-set/cancel air suspension manufacturing/freeze mode
XF	2013-2015	Active damping control module-establishment mode
XF	2013-2015	Active vibration reduction control module-calibration acquisition
XF	2013-2015	Audio system. -Calibration dynamic quantity control
XF	2013-2015	Transfer case-calibration clutch.
XF	2013-2015	Transfer case-oil replacement reset
XF	2013-2015	Special application-transmission mode
XF	2013-2015	Powertrain-Fuel Lift Pump
XF	2013-2015	Powertrain-diesel particulate filter replacement

XF	2013-2015	Power Train-Fuel Pump Supply Pipe-Enable/Disable
XF	2013-2015	Entertainment system-reset navigation
XF	2013-2015	Entertainment system-DVD zone counter reset
NEW XF	2016-2017	Brake bleed
NEW XF	2016-2017	Steering column calibration
NEW XF	2016-2017	Throttle valve actuator replacement
NEW XF	2016-2017	Auto oil reset
NEW XF	2016-2017	Service interval reset
NEW XF	2016-2017	Oil service counter reset
NEW XF	2016-2017	Replace brake pads -operating guide
NEW XF	2016-2017	Front left wheel sensor
NEW XF	2016-2017	Front right wheel sensor
NEW XF	2016-2017	Rear right wheel sensor
NEW XF	2016-2017	Rear left wheel sensor
NEW XF	2016-2017	Spare wheel
NEW XF	2016-2017	Power steering soft-lock end stops reset routine
NEW XF	2016-2017	Lock steering tune to vehicle
NEW XF	2016-2017	Tire pressure monitoring sensor identification display
NEW XF	2016-2017	Resetting the Selective Catalytic Reduction Mass Monitor
NEW XF	2016-2017	Transmission Control Module Adaptive Clearance
NEW XF	2016-2017	Diesel exhaust gas oil infusion and pressure test
NEW XF	2016-2017	Diesel exhaust gas tank level sensor replacement
NEW XF	2016-2017	Diesel exhaust gas jet pump replacement
NEW XF	2016-2017	Diesel particulate filter dynamic regeneration
NEW XF	2016-2017	This routine will reset flight recorder data
NEW XF	2016-2017	Powertrain Control Module Adaptive Clearance
NEW XF	2016-2017	Engine Control Module Low Pressure EGR Adaptive Value Clearance

NEW XF	2016-2017	Engine Control Module Resets Crankcase Pressure Sensor
NEW XF	2016-2017	Engine Control Module Vortex Valve Adaptive Value Clearance
NEW XF	2016-2017	Engine Control Module Mass Air Flow Adaptive Value Clearance
NEW XF	2016-2017	Engine Control Module Resets Fuel Pump Adaptive Value
NEW XF	2016-2017	Glow Plug Control Module
NEW XF	2016-2017	Throttle Valve Brake Replacement
NEW XF	2016-2017	Exhaust valve adaptation
NEW XF	2016-2017	Injector valve test
NEW XF	2016-2017	Enable/Disable Glow Plug
NEW XF	2016-2017	Fuel preparation routine
NEW XF	2016-2017	Show injector correction factor
NEW XF	2016-2017	Check all antennas
NEW XF	2016-2017	Transfer box control module - locking central differential
NEW XF	2016-2017	Parking Brake Start
NEW XF	2016-2017	Activate test picture
NEW XF	2016-2017	Head-view display control module reset
NEW XF	2016-2017	Activate Telematics Control Module
NEW XF	2016-2017	Remote Information Processing SIM Card Type
NEW XF	2016-2017	Pump ventilation
NEW XF	2016-2017	Reset - Clear specified features
NEW XF	2016-2017	Battery replacement
NEW XF	2016-2017	Static current control module internal inspection
NEW XF	2016-2017	IPMA AEB Data Reading
NEW XF	2016-2017	Vehicle reset
NEW XF	2016-2017	Check before departure
NEW XF	2016-2017	Constraint build mode
NEW XF	2016-2017	door and window calibration

NEW XF	2016-2017	Headlight level adjustment height sensor calibration
NEW XF	2016-2017	Altitude Calibration
NEW XF	2016-2017	Display injector correction factors
NEW XF	2016-2017	Brake caliper replacement assembly test
NEW XF	2016-2017	Parking brake pad replacement - Release to service position
NEW XF	2016-2017	Parking brake pad replacement - Exit maintenance mode application
NEW XF	2016-2017	Parking brake activation
NEW XF	2016-2017	Apply and release electric park brake
NEW XF	2016-2017	Sunroof calibration
NEW XF	2016-2017	Tailgate/trunk calibration
NEW XF	2016-2017	Power Train-Diesel Exhaust Oil Level Check
NEW XF	2016-2017	Tire pressure monitoring system-tire pressure sensor replacement
NEW XF	2016-2017	Configure the new module. -Audio amplifier module.
NEW XF	2016-2017	Configure the new module. -Shift module
NEW XF	2016-2017	Configure the new module. -Rear climate control module
NEW XF	2016-2017	Configure the new module. -Front control interface module (heating, ventilation and
NEW XF	2016-2017	Configure the new module. -Speed ??control module
NEW XF	2016-2017	Configure the new module. -All terrain control modules.
NEW XF	2016-2017	Configure the new module. -Steering angle sensor module.
NEW XF	2016-2017	Configure the new module. -Head-up display cooling fan module
NEW XF	2016-2017	Configure the new module. -Expandable traction rod control module
NEW XF	2016-2017	Configure the new module. -Interactive display module
NEW XF	2016-2017	Remote communication control module-remote communication server communication check
NEW XF	2016-2017	Remote communication control module-pre-activated remote communication control
NEW XF	2016-2017	Remote communication control module-reset/clear WiFi hotspot
NEW XF	2016-2017	Remote communication control module-network registration status
NEW XF	2016-2017	Remote communication control module-remote communication-operation mode

NEW XF	2016-2017	Remote communication control module-remote communication control module battery
NEW XF	2016-2017	Security-Passive entry/passive start enabled
NEW XF	2016-2017	Seat-calibration of the driver's seat.
NEW XF	2016-2017	Seat-calibration of the passenger side seat.
NEW XF	2016-2017	Seat-driver's seat massage on-demand self-check
NEW XF	2016-2017	Seat-Passenger seat massage on-demand self-check
NEW XF	2016-2017	Body system-roof shade-calibration
NEW XF	2016-2017	Body system-valet parking mode reset
NEW XF	2016-2017	Body system-power steering soft lock stop position reset routine
NEW XF	2016-2017	Body system-ignition cycle counter reset
NEW XF	2016-2017	Body system-tuning and locking the steering wheel to the vehicle
NEW XF	2016-2017	Body system-rain sensor calibration
NEW XF	2016-2017	Auxiliary heater-auxiliary heater fuel delivery test
NEW XF	2016-2017	Powertrain settings-fuel water detection reset
NEW XF	2016-2017	Drivetrain settings-throttle actuator
NEW XF	2016-2017	Drive train settings-turbine shut-off valve
NEW XF	2016-2017	Drive train settings-exhaust gas recirculation valve.
NEW XF	2016-2017	Drive train settings-oxygen sensor
NEW XF	2016-2017	Drivetrain settings-oxidation catalyst
NEW XF	2016-2017	Drivetrain settings-diesel particulate filter differential pressure sensor
NEW XF	2016-2017	Drive train settings-reinitialize diesel fuel filling adaptation value
NEW XF	2016-2017	Suspension system-set/cancel air suspension manufacturing/freeze mode
NEW XF	2016-2017	Special application-transmission mode
NEW XF	2016-2017	Remote communication control module-test internal backup battery
NEW XF	2016-2017	Powertrain-Fuel Lift Pump
NEW XF	2016-2017	Powertrain-diesel particulate filter replacement
NEW XF	2016-2017	Power Train-Fuel Pump Supply Pipe-Enable/Disable

NEW XF	2016-2017	Entertainment system-InControl Touch Pro wireless headset system self-check
NEW XF	2016-2017	Entertainment system-InControl Touch Pro auxiliary electric cooling fan test
NEW XF	2016-2017	Entertainment system-InControl Touch Pro engineering interface enabled
NEW XF	2016-2017	Entertainment System-InControl Touch Pro SiriusXM? Logo Display
NEW XF	2016-2017	Entertainment System-InControl Smart Control, Exclusive Touch Customer PIN Reset
NEW XF	2016-2017	Unlock the deployable towbar
NEW XF	2016-2017	Deployable towbar recovery
NEW XF	2016-2017	Retractable towbar
NEW XF	2016-2017	Deploy towbar
NEW XF	2016-2017	Deployable towbar speaker test
F-PACE	2017	Brake bleed
F-PACE	2017	Tire pressure monitoring sensor
F-PACE	2017	Resetting the Selective Catalytic Reduction
F-PACE	2017	Transmission Control Module Adaptive
F-PACE	2017	Diesel exhaust gas oil infusion and pressure
F-PACE	2017	Diesel exhaust gas tank level sensor
F-PACE	2017	Diesel exhaust gas jet pump replacement
F-PACE	2017	Diesel particulate filter dynamic
F-PACE	2017	This routine will reset flight recorder data
F-PACE	2017	Powertrain Control Module Adaptive Clearance
F-PACE	2017	Engine Control Module Low Pressure EGR
F-PACE	2017	Engine Control Module Resets Crankcase
F-PACE	2017	Engine Control Module Vortex Valve Adaptive
F-PACE	2017	Engine Control Module Mass Air Flow Adaptive
F-PACE	2017	Engine Control Module Resets Fuel Pump
F-PACE	2017	Glow Plug Control Module
F-PACE	2017	Throttle Valve Brake Replacement
F-PACE	2017	Exhaust valve adaptation
F-PACE	2017	Injector valve test
F-PACE	2017	Enable/Disable Glow Plug
F-PACE	2017	Fuel preparation routine
F-PACE	2017	Show injector correction factor
F-PACE	2017	Check all antennas
F-PACE	2017	Transfer box control module - locking
F-PACE	2017	Parking Brake Start
F-PACE	2017	Activate test picture
F-PACE	2017	Head-view display control module reset
F-PACE	2017	Activate Telematics Control Module
F-PACE	2017	Remote Information Processing SIM Card Type
F-PACE	2017	Pump ventilation
F-PACE	2017	Reset - Clear specified features
F-PACE	2017	Battery replacement
F-PACE	2017	Static current control module internal
F-PACE	2017	IPMA AEB Data Reading

F-PACE	2017	Vehicle reset
F-PACE	2017	Check before departure
F-PACE	2017	Constraint build mode
F-PACE	2017	door and window calibration
F-PACE	2017	Headlight level adjustment height sensor
F-PACE	2017	Altitude Calibration
F-PACE	2017	Display injector correction factors
F-PACE	2017	Brake caliper replacement assembly test
F-PACE	2017	Parking brake pad replacement - Release to
F-PACE	2017	Parking brake pad replacement - Exit
F-PACE	2017	Parking brake activation
F-PACE	2017	Apply and release electric park brake
F-PACE	2017	Sunroof calibration
F-PACE	2017	Tailgate/trunk calibration
F-PACE	2017	Power Train-Diesel Exhaust Oil Level Check
F-PACE	2017	Tire pressure monitoring system-tire
F-PACE	2017	Configure the new module. -Audio amplifier
F-PACE	2017	Configure the new module. -Shift module
F-PACE	2017	Configure the new module. -Rear climate
F-PACE	2017	Configure the new module. -Front control
F-PACE	2017	Configure the new module. -Speed ??control
F-PACE	2017	Configure the new module. -All terrain
F-PACE	2017	Configure the new module. -Image processing
F-PACE	2017	Configure the new module. -Steering angle
F-PACE	2017	Configure the new module. -Head-up display
F-PACE	2017	Configure the new module. -Expandable
F-PACE	2017	Configure the new module. -Interactive
F-PACE	2017	Remote communication control module-remote
F-PACE	2017	Remote communication control module-pre-
F-PACE	2017	Remote communication control module-
F-PACE	2017	Remote communication control module-network
F-PACE	2017	Remote communication control module-remote
F-PACE	2017	Remote communication control module-remote
F-PACE	2017	Security-Passive entry/passive start enabled
F-PACE	2017	Seat-calibration of the driver's seat.
F-PACE	2017	Seat-calibration of the passenger side seat.
F-PACE	2017	Seat-driver's seat massage on-demand self-
F-PACE	2017	Seat-Passenger seat massage on-demand self-
F-PACE	2017	Body system-roof shade-calibration
F-PACE	2017	Body system-valet parking mode reset
F-PACE	2017	Body system-power steering soft lock stop
F-PACE	2017	Body system-ignition cycle counter reset
F-PACE	2017	Body system-tuning and locking the steering
F-PACE	2017	Body system-rain sensor calibration
F-PACE	2017	Auxiliary heater-auxiliary heater fuel
F-PACE	2017	Powertrain settings-fuel water detection
F-PACE	2017	Drivetrain settings-throttle actuator
F-PACE	2017	Drive train settings-turbine shut-off valve
F-PACE	2017	Drive train settings-exhaust gas
F-PACE	2017	Drive train settings-oxygen sensor
F-PACE	2017	Drivetrain settings-oxidation catalyst
F-PACE	2017	Drivetrain settings-diesel particulate
F-PACE	2017	Drive train settings-reinitialize diesel
F-PACE	2017	Suspension system-set/cancel air suspension

F-PACE	2017	Special application-transmission mode
F-PACE	2017	Remote communication control module-test
F-PACE	2017	Powertrain-Fuel Lift Pump
F-PACE	2017	Powertrain-diesel particulate filter
F-PACE	2017	Power Train-Fuel Pump Supply Pipe-
F-PACE	2017	Entertainment system-InControl Touch Pro
F-PACE	2017	Entertainment system-InControl Touch Pro
F-PACE	2017	Entertainment system-InControl Touch Pro
F-PACE	2017	Entertainment System-InControl Touch Pro
F-PACE	2017	Entertainment System-InControl Smart
F-PACE	2017	Expandable side pedal-Operate the left side
F-PACE	2017	Expandable side pedal-operate the right side
F-PACE	2017	Unlock the deployable towbar
F-PACE	2017	Deployable towbar recovery
F-PACE	2017	Retractable towbar
F-PACE	2017	Deploy towbar
F-PACE	2017	Deployable towbar speaker test
X-Type	2004- 2009	Transmission control module adaptation clear.
F-Type	2014- 2015	Seat cushion replacement
F-Type	2014- 2015	Driver's memory seat calibration.
F-Type	2014- 2015	Brake bleed
F-Type	2014- 2015	Steering angle sensor calibration
F-Type	2014- 2015	Tire pressure monitoring sensor identification display
F-Type	2014- 2015	Transmission Control Module Adaptive Clearance
F-Type	2014- 2015	Powertrain Control Module Adaptive Clearance
F-Type	2014- 2015	Engine Control Module Unlocking Application
F-Type	2014- 2015	Throttle Valve Brake Replacement
F-Type	2014- 2015	Injector valve test
F-Type	2014- 2015	Fuel preparation routine
F-Type	2014- 2015	Oil maintenance counter reset
F-Type	2014- 2015	Anti-theft locker antenna unit function check
F-Type	2014- 2015	Check all antennas
F-Type	2014- 2015	Parking Brake Start
F-Type	2014- 2015	Starting TV Test Picture
F-Type	2014- 2015	Applications for Information and Entertainment Systems

F-Type	2014-2015	Testing Dual Battery Systems
F-Type	2014-2015	Battery replacement
F-Type	2014-2015	Static current control module internal inspection
F-Type	2014-2015	Verify auxiliary battery charging
F-Type	2014-2015	Vehicle reset
F-Type	2014-2015	Check before departure
F-Type	2014-2015	Maintenance interval reset
F-Type	2014-2015	Constraint build mode
F-Type	2014-2015	Customer side door glass window calibration
F-Type	2014-2015	Driver side door glazing calibration
F-Type	2014-2015	Altitude Calibration
F-Type	2014-2015	Longitudinal accelerometer calibration.
F-Type	2014-2015	Brake caliper replacement assembly test
F-Type	2014-2015	Parking brake pad replacement - Release to service position
F-Type	2014-2015	Parking brake pad replacement - Exit maintenance mode application
F-Type	2014-2015	Parking brake activation
F-Type	2014-2015	Tire pressure monitoring tire pressure sensor test
F-Type	2014-2015	Tailgate/trunk calibration
F-Type	2014-2015	Tire pressure monitoring system-tire pressure sensor replacement
F-Type	2014-2015	Configure the new module. -Digital Audio Broadcasting Module
F-Type	2014-2015	Configure the new module. -Front control/display interface module (high-level
F-Type	2014-2015	Configure the new module. -Shift module
F-Type	2014-2015	Configure the new module. -Headlamp control module' B'
F-Type	2014-2015	Configure the new module. -Front control interface module (heating, ventilation and
F-Type	2014-2015	Configure the new module. -Navigation control module
F-Type	2014-2015	Configure the new module. -Parking aid control module
F-Type	2014-2015	Configure the new module. -Parking brake control module

F-Type	2014-2015	Configure the new module. -Satellite audio unit module.
F-Type	2014-2015	Configure the new module. -All terrain control modules.
F-Type	2014-2015	Configure the new module. -Image processing control module
F-Type	2014-2015	Seat-calibration of the driver's seat.
F-Type	2014-2015	Seat-calibration of the passenger side seat.
F-Type	2014-2015	Braking system-steering angle sensor calibration
F-Type	2014-2015	Brake system-brake disc wear protection reset
F-Type	2014-2015	Body system-valet parking mode reset
F-Type	2014-2015	Rear differential control module. -Control module calibration
F-Type	2014-2015	Suspension system-set/cancel air suspension manufacturing/freeze mode
F-Type	2014-2015	Audio system. -Calibration dynamic quantity control
F-Type	2014-2015	Special application-transmission mode
F-Type	2014-2015	Power Train-Fuel Pump Supply Pipe-Enable/Disable
F-Type	2014-2015	Entertainment system-DVD zone counter reset
F-Type	2016-2017	Seat cushion replacement
F-Type	2016-2017	Steering column calibration
F-Type	2016-2017	Throttle valve actuator replacement
F-Type	2016-2017	Auto oil reset
F-Type	2016-2017	Service interval reset
F-Type	2016-2017	Replace brake pads -operating guide
F-Type	2016-2017	Oil service counter reset
F-Type	2016-2017	Front left wheel sensor
F-Type	2016-2017	Front right wheel sensor
F-Type	2016-2017	Rear right wheel sensor
F-Type	2016-2017	Rear left wheel sensor
F-Type	2016-2017	Spare wheel
F-Type	2016-2017	Power steering soft-lock end stops reset routine

F-Type	2016-2017	Lock steering tune to vehicle
F-Type	2016-2017	Tire pressure monitoring sensor identification display
F-Type	2016-2017	Transmission Control Module Adaptive Clearance
F-Type	2016-2017	Powertrain Control Module Adaptive Clearance
F-Type	2016-2017	Engine Control Module Unlocking Application
F-Type	2016-2017	Throttle Valve Brake Replacement
F-Type	2016-2017	Injector valve test
F-Type	2016-2017	Fuel preparation routine
F-Type	2016-2017	Anti-theft locker antenna unit function check
F-Type	2016-2017	Check all antennas
F-Type	2016-2017	Parking Brake Start
F-Type	2016-2017	Remote Information Processing SIM Card Type
F-Type	2016-2017	Starting TV Test Picture
F-Type	2016-2017	Applications for Information and Entertainment Systems
F-Type	2016-2017	Battery replacement
F-Type	2016-2017	Static current control module internal inspection
F-Type	2016-2017	Vehicle reset
F-Type	2016-2017	Check before departure
F-Type	2016-2017	Constraint build mode
F-Type	2016-2017	Customer side door glass window calibration
F-Type	2016-2017	Driver side door glazing calibration
F-Type	2016-2017	Altitude Calibration
F-Type	2016-2017	Longitudinal accelerometer calibration.
F-Type	2016-2017	Brake caliper replacement assembly test
F-Type	2016-2017	Parking brake pad replacement - Release to service position
F-Type	2016-2017	Parking brake pad replacement - Exit maintenance mode application
F-Type	2016-2017	Parking brake activation

F-Type	2016-2017	Tailgate/trunk calibration
F-Type	2016-2017	Tire pressure monitoring system-tire pressure sensor replacement
F-Type	2016-2017	Brake bleed
F-Type	2016-2017	Configure the new module. -Audio amplifier module.
F-Type	2016-2017	Configure the new module. -Digital Audio Broadcasting Module
F-Type	2016-2017	Configure the new module. -Front control/display interface module (high-level
F-Type	2016-2017	Configure the new module. -Foldable roof control module
F-Type	2016-2017	Configure the new module. -Shift module
F-Type	2016-2017	Configure the new module. -Front control interface module (heating, ventilation and
F-Type	2016-2017	Configure the new module. -Navigation control module
F-Type	2016-2017	Configure the new module. -Satellite audio unit module.
F-Type	2016-2017	Configure the new module. -All terrain control modules.
F-Type	2016-2017	Configure the new module. -Image processing control module
F-Type	2016-2017	Configure the new module. -Steering angle sensor module.
F-Type	2016-2017	Configure the new module. -Folding top control module B
F-Type	2016-2017	Configure the new module. -Image processing control module A
F-Type	2016-2017	Configure the new module. -Interactive display module
F-Type	2016-2017	Remote communication control module-remote communication server communication check
F-Type	2016-2017	Remote communication control module-pre-activated remote communication control
F-Type	2016-2017	Remote communication control module-activate the remote communication control module
F-Type	2016-2017	Remote communication control module-network registration status
F-Type	2016-2017	Remote communication control module-remote communication-operation mode
F-Type	2016-2017	Remote communication control module-remote communication control module battery
F-Type	2016-2017	Security-Passive entry/passive start enabled
F-Type	2016-2017	Seat-calibration of the driver's seat.
F-Type	2016-2017	Seat-calibration of the passenger side seat.
F-Type	2016-2017	Brake system-brake disc wear protection reset

F-Type	2016-2017	Body system-valet parking mode reset
F-Type	2016-2017	Body system-power steering soft lock stop position reset routine
F-Type	2016-2017	Body system-ignition cycle counter reset
F-Type	2016-2017	Body system-tuning and locking the steering wheel to the vehicle
F-Type	2016-2017	Body system-rain sensor calibration
F-Type	2016-2017	Rear differential control module. -Control module calibration
F-Type	2016-2017	Suspension system-set/cancel air suspension manufacturing/freeze mode
F-Type	2016-2017	Audio system. -Calibration dynamic quantity control
F-Type	2016-2017	Transfer case-calibration clutch.
F-Type	2016-2017	Transfer case-oil replacement reset
F-Type	2016-2017	Special application-transmission mode
F-Type	2016-2017	Special application-parking assist control module reset
F-Type	2016-2017	Special application-The parking assist control module resets the configuration
F-Type	2016-2017	Remote communication control module-test internal backup battery
F-Type	2016-2017	Remote communication control module-emergency call and fault call switch
F-Type	2016-2017	Power Train-Fuel Pump Supply Pipe-Enable/Disable
S-Type	2006-2008	Yaw rate sensor calibration.
S-Type	2006-2008	Reset the oil service counter