



Shenzhen Xtooltech Co., Ltd

Peugeot Function List V11.60

Tips and Instructions:

- * This feature is new.
- ✓ This feature is supported.
- This feature is not supported.
- ※ This feature is partially supported.

Model	System Name	ECU	Read ECU Information	Read Trouble Code	Clear Trouble Code	Live Data	Actuation Test	Special Functions
1007 VAN	Engine	NFU ME744	✓	✓	✓	✓	✓	S0034
1007 VAN	Engine	BOSCH ME7.4.5	✓	✓	✓	✓	✓	S0034
1007 VAN	Engine	KFV S2000PM2	✓	✓	✓	✓	✓	S0034
1007 VAN	Engine	KFU MM6LP	✓	✓	✓	✓	✓	
1007 VAN	Engine	KFV J34P	✓	✓	✓	✓	✓	
1007 VAN	Engine	SIEMENS SID 804	✓	✓	✓	✓	✓	
1007 VAN	Gearbox ECU		✓	✓	✓	✓	✓	
1007 VAN	ABS or ESP ECU	ABS MK70	✓	✓	✓	✓	✓	S0039
1007 VAN	ABS or ESP ECU	ESP MK60	✓	✓	✓	✓	✓	S0035
1007 VAN	Airbag ECU		✓	✓	✓	✓		
1007 VAN	Instrument panel		✓	✓	✓	✓	✓	
1007 VAN	Air Conditioning		✓			✓		
1007 VAN	Sliding side doors module		✓	✓	✓	✓		
1007 VAN	Switch module at the steering wheel		✓	✓	✓	✓		
1007 VAN	Alarm		✓	✓	✓			
1007 VAN	Radio		✓	✓	✓	✓		
1007 VAN	CD Player		✓	✓	✓	✓		
1007 VAN	Parking aid		✓	✓	✓	✓		

1007 VAN	Rain/brightness sensor		✓	✓	✓			
1007 VAN	Display/Telematics		✓	✓	✓	✓		
1007 CAN	Engine	NFU BOSCH ME745	✓	✓	✓	✓	✓	S0034
1007 CAN	Engine	KFV J34P	✓	✓	✓	✓	✓	S0034
1007 CAN	Engine	KFU MM6LPC	✓	✓	✓	✓	✓	S0034
1007 CAN	Engine	ME749	✓	✓	✓	✓	✓	
1007 CAN	Engine	SID 806 DV4	✓	✓	✓	✓	✓	
1007 CAN	Engine	BOSCH EDC16C3	✓	✓	✓	✓	✓	S0037
1007 CAN	Gearbox ECU		✓	✓	✓	✓	✓	
1007 CAN	ABS or ESP ECU	ABS MK70.1	✓	✓	✓	✓	✓	S0039
1007 CAN	ABS or ESP ECU	ESP MK60 0	✓	✓	✓	✓		
1007 CAN	Airbag ECU		✓	✓	✓	✓		
1007 CAN	Power Steering		✓	✓	✓	✓		
1007 CAN	Instrument Panel		✓	✓	✓	✓	✓	
1007 CAN	Sliding side doors module		✓	✓	✓	✓		
1007 CAN	ALARM		✓	✓	✓	✓		
1007 CAN	Multiplexed Additive Adding Pump (POMPE MUX MGI)		✓	✓	✓	✓		
1007 CAN	Air Conditioning		✓	✓	✓	✓	✓	
1007 CAN	Under inflation detection		✓	✓	✓	✓		
1007 CAN	Parking Aid (AAS)		✓	✓	✓	✓	✓	
1007 CAN	Telematics		✓	✓	✓	✓	✓	
1007 CAN	Switch module at the steering wheel		✓	✓	✓	✓		
1007 CAN	Multifunction Display		✓	✓	✓	✓		
1007 CAN	High frequency receiver		✓	✓	✓	✓		
1007 CAN	Rain/sunlight sensor		✓	✓	✓			
1007 CAN	RADIO		✓	✓	✓	✓		
1007 CAN	Cd player		✓	✓	✓			
1007 CAN	Engine relay unit		✓	✓	✓	✓		
1007 CAN	Trailer Relay Unit		✓	✓	✓	✓		

106	Additional Heating		✓	✓	✓	✓		
206	Engine	DCN2	✓	✓	✓	✓		
206	Engine	EDC15C2	✓	✓	✓	✓	✓	
206	Engine	EDC16C3DV4	✓	✓	✓	✓	✓	S0036
206	Engine	EDC16C3	✓	✓	✓	✓	✓	S0036
206	Engine	EDC17C10 BR2	✓	✓	✓	✓	✓	S0037 S0036
206	Engine	J34P	✓	✓	✓	✓	✓	S0034
206	Engine	ME745	✓	✓	✓	✓	✓	S0034
206	Engine	N6A ME749 BIO FLEX	✓	✓	✓	✓	✓	S0034
206	Engine	NFU OR N6A ME749	✓	✓	✓	✓	✓	S0034
206	Engine	V343	✓	✓	✓	✓	✓	
206	Engine	V34 3	✓	✓	✓	✓	✓	
206	Engine	ME744	✓	✓	✓	✓	✓	S0034
206	Gearbox ECU		✓	✓	✓	✓	✓	
206	ABS or ESP ECU	ABS MK70	✓	✓	✓	✓	✓	S0039
206	ABS or ESP ECU	ESP MK60	✓	✓	✓	✓	✓	
206	ABS or ESP ECU	ABS TEVES	✓	✓	✓	✓		
206	Airbag ECU		✓	✓	✓			
206	Power steering		✓	✓	✓	✓		
206	Alarm		✓	✓	✓	✓		
206	Instrument panel		✓	✓	✓	✓	✓	
206	Air Conditioning		✓	✓	✓	✓		
206	Switch module at the steering wheel		✓			✓		
206	On board navigation system		✓	✓	✓	✓		
206	Driving school mode		✓			✓		
206	Rain/brightness sensor		✓	✓	✓			
206	Diesel fuel additive control unit		✓	✓	✓	✓		
206	Display/Telematics	AMF	✓	✓	✓	✓	✓	
206	Display/Telematics	RT3	✓	✓	✓	✓	✓	
206	Radio		✓	✓	✓	✓		
206 MUX	Engine	DCN2	✓	✓	✓	✓		
206 MUX	Engine	EDC15C2	✓	✓	✓	✓	✓	

206 MUX	Engine	EDC16C3DV4	✓	✓	✓	✓	✓	S0036
206 MUX	Engine	EDC16C3	✓	✓	✓	✓	✓	S0036
206 MUX	Engine	EDC17C10 BR2	✓	✓	✓	✓	✓	S0037 S0036
206 MUX	Engine	J34P	✓	✓	✓	✓	✓	S0034
206 MUX	Engine	ME745	✓	✓	✓	✓	✓	S0034
206 MUX	Engine	N6A ME749 BIO FLEX	✓	✓	✓	✓	✓	S0034
206 MUX	Engine	NFU OR N6A ME749	✓	✓	✓	✓	✓	S0034
206 MUX	Engine	V343	✓	✓	✓	✓	✓	
206 MUX	Engine	V34 3	✓	✓	✓	✓	✓	
206 MUX	Engine	ME744	✓	✓	✓	✓	✓	S0034
206 MUX	Gearbox ECU		✓	✓	✓	✓		
206 MUX	ABS or ESP ECU	ESP MK60	✓	✓	✓	✓	✓	S0039 S0035
206 MUX	ABS or ESP ECU	ABS MK70	✓	✓	✓	✓	✓	S0039
206 MUX	ABS or ESP ECU	ABS TEVES	✓	✓	✓	✓		
206 MUX	Airbag ECU	SAC CENT AUTOLIV 2	✓	✓	✓			
206 MUX	Airbag ECU	Airbag and seatbelts	✓	✓	✓			
206 MUX	Airbag ECU	Left side airbag	✓	✓	✓			
206 MUX	Airbag ECU	Right side airbag	✓	✓	✓			
206 MUX	Power steering		✓	✓	✓	✓		
206 MUX	Instrument panel		✓	✓	✓	✓	✓	
206 MUX	Air Conditioning		✓	✓	✓	✓		
206 MUX	BSI		✓	✓	✓			S0033
206 MUX	Diesel fuel additive control unit		✓	✓	✓	✓		
206 MUX	Display/Telematics	AMF	✓	✓	✓	✓	✓	
206 MUX	Display/Telematics	RT3	✓	✓	✓	✓	✓	
206 MUX	Radio		✓	✓	✓	✓		
206 MUX	Alarm		✓	✓	✓	✓		
206 MUX	On board navigation system		✓	✓	✓	✓		
206 MUX	Driving school mode		✓			✓		
206 MUX	Rain/brightness sensor		✓	✓	✓			
306R	Engine	EDC16C3		✓	✓		✓	S0037 S0036
306R	Engine	HDI SID803		✓	✓		✓	S0037
306R	Engine	ME745		✓	✓		✓	S0034

306R	Engine	MM6LP		✓	✓			
306R	Gearbox ECU		✓	✓	✓	✓		
306R	ABS/ESP		✓	✓	✓	✓		
306R	Airbag ECU	Airbag and seatbelts	✓	✓	✓			
306R	Airbag ECU	Left side airbag	✓	✓	✓			
306R	Airbag ECU	Right side airbag	✓	✓	✓			
307 VAN	Engine	EDC16C3		✓	✓		✓	S0037 S0036
307 VAN	Engine	HDI SID803		✓	✓		✓	S0037
307 VAN	Engine	ME745		✓	✓		✓	S0034
307 VAN	Engine	MM6LP		✓	✓			
307 VAN	Engine	ME744	✓	✓	✓	✓	✓	S0034
307 VAN	Gearbox ECU		✓	✓	✓	✓	✓	
307 VAN	ABS/ESP	ABS BOSCH8	✓	✓	✓	✓	✓	
307 VAN	ABS/ESP	ESP BOSCH8	✓	✓	✓	✓	✓	S0035 S0039
307 VAN	ABS/ESP	ESP BOSCH57	✓	✓	✓	✓	✓	S0035 S0039
307 VAN	ABS/ESP	ABS BOSCH53	✓	✓	✓	✓		
307 VAN	Air bags		✓	✓	✓			
307 VAN	Power Steering		✓	✓	✓	✓		
307 VAN	Instrument panel		✓	✓	✓	✓	✓	
307 VAN	Air Conditioning		✓	✓	✓	✓		
307 VAN	Diesel fuel additive control unit		✓	✓	✓	✓		
307 VAN	Alarm		✓	✓	✓	✓		
307 VAN	Switch module at the steering wheel		✓			✓		
307 VAN	Multi function display		✓	✓	✓	✓	✓	
307 VAN	Parking aid		✓	✓	✓	✓		
307 VAN	Radio		✓	✓	✓	✓	✓	
307 VAN	CD Player		✓	✓	✓	✓		
307 VAN	Driving school mode		✓			✓		
307 VAN	Roll over ECU		✓	✓	✓	✓		
307 VAN	Sun roof	TO WEBASTO	✓	✓	✓	✓		
307 VAN	Sun roof	TOUV TEXTON	✓	✓	✓	✓		
405	Engine		✓	✓	✓	✓	✓	S0034
405	AT BVA AL		✓	✓	✓	✓		

406	Engine	EDC15C2	✓	✓	✓	✓	✓	
406	Engine	HDI SID803	✓	✓	✓	✓	✓	
406	Engine	ME744	✓	✓	✓	✓	✓	S0034
406	Engine	HDI SID803		✓	✓		✓	S0037
406	Gearbox ECU		✓	✓	✓	✓		
406	ABS/ESP		✓	✓	✓	✓		
406	Airbag ECU	Airbag and seatbelts	✓	✓	✓			
406	Airbag ECU	Left side airbag	✓	✓	✓			
406	Airbag ECU	Right side airbag	✓	✓	✓			
406R	Engine	6FZ SAGEM S2000	✓	✓	✓	✓		
406R	Engine	LFX MM1AP	✓	✓	✓	✓		
406R	Engine	LFY BOSCH MP7.3	✓	✓	✓	✓		
406R	Engine	LFY SAGEM SL96	✓	✓	✓	✓		
406R	Engine	R6F MM4.8P	✓	✓	✓	✓		
406R	Engine	XFZ BOSCH MP7.0	✓	✓	✓	✓		
406R	Gearbox ECU	Auto Gearbox ZF4HP20	✓	✓	✓	✓	✓	
406R	Gearbox ECU	BVA ZF	✓	✓	✓	✓	✓	
406R	Gearbox ECU	BVA AL4	✓	✓	✓	✓	✓	
406R	ABS/ESP		✓	✓	✓	✓		
406R	Airbag ECU	SAC CENT AUTOLIV 2	✓	✓	✓			
406R	Airbag ECU	Airbag and seatbelts	✓	✓	✓			
406R	Power Steering		✓			✓		
406R	Instrument panel		✓	✓	✓	✓	✓	
406R	Air Conditioning		✓	✓	✓	✓		
406R	Multi function display		✓	✓	✓	✓	✓	
406R	Radio		✓	✓	✓	✓	✓	
406R	Seat and mirrors with memory		✓	✓	✓	✓		
406R	Diesel fuel additive control unit		✓	✓	✓	✓		
406R	system		✓	✓	✓	✓		
406R	Rain/brightness sensor		✓	✓	✓			
406R	CD Player		✓	✓	✓	✓	✓	
406R Coupe	Engine	EDC15C2	✓	✓	✓	✓	✓	
406R Coupe	Engine	HDI SID803	✓	✓	✓	✓	✓	

406R Coupe	Engine	ME744	✓	✓	✓	✓	✓	S0034
406R Coupe	Engine	HDI SID803		✓	✓		✓	S0037
406R Coupe	Gearbox ECU	Auto Gearbox ZF4HP20	✓	✓	✓	✓	✓	
406R Coupe	Gearbox ECU	Auto Gearbox AL4	✓	✓	✓	✓	✓	
406R Coupe	Gearbox ECU	BVA ZF	✓	✓	✓	✓	✓	
406R Coupe	Gearbox ECU	BVA AL4	✓	✓	✓	✓	✓	
406R Coupe	ABS/ESP		✓	✓	✓	✓		
406R Coupe	Airbag ECU	SAC CENT AUTOLIV 2	✓	✓	✓			
406R Coupe	Airbag ECU	Airbag and seatbelts	✓	✓	✓			
406R Coupe	Power Steering		✓			✓		
406R Coupe	Instrument panel		✓	✓	✓	✓	✓	
406R Coupe	Air Conditioning		✓	✓	✓	✓		
406R Coupe	Multi function display		✓	✓	✓	✓	✓	
406R Coupe	Radio		✓	✓	✓	✓	✓	
406R Coupe	Alarm		✓	✓	✓	✓		
406R Coupe	Diesel fuel additive control unit		✓	✓	✓	✓		
406R Coupe	On board navigation system		✓	✓	✓	✓		
406R Coupe	Rain/brightness sensor		✓	✓	✓			
406R Coupe	CD Player		✓	✓	✓	✓	✓	
607	Engine	EDC15C2	✓	✓	✓	✓	✓	
607	Engine	HDI SID803	✓	✓	✓	✓	✓	
607	Gearbox ECU		✓	✓	✓	✓	✓	
607	ABS/ESP		✓	✓	✓	✓		
607	Airbag ECU		✓	✓	✓			
607	Air Conditioning		✓	✓	✓	✓		
806	Engine	EDC15C2	✓	✓	✓	✓	✓	
806	Engine	HDI SID803	✓	✓	✓	✓	✓	
806	Engine	9HY BOSCH EDC16C3 EURO4	✓	✓	✓	✓	✓	
806	ABS/ESP		✓	✓	✓	✓		
806	Airbag ECU		✓	✓	✓			
807 VAN	Engine	EDC15C2	✓	✓	✓	✓	✓	
807 VAN	Engine	HDI SID803	✓	✓	✓	✓	✓	
807 VAN	Engine	9HY BOSCH EDC16C3 EURO4	✓	✓	✓	✓	✓	

807 VAN	Gearbox ECU	BVA AL4	✓	✓	✓	✓		
807 VAN	Gearbox ECU	Auto Gearbox ZF4HP20	✓	✓	✓	✓	✓	
807 VAN	ABS/ESP		✓	✓	✓	✓	✓	S0035 S0039
807 VAN	Airbag ECU		✓	✓	✓			
807 VAN	Instrument panel		✓	✓	✓	✓	✓	
807 VAN	Air Conditioning		✓	✓	✓	✓		
807 VAN	Multi function display		✓	✓	✓	✓	✓	
807 VAN	Radio		✓	✓	✓	✓		
807 VAN	Alarm		✓	✓	✓	✓		
807 VAN	Driver's door module		✓	✓	✓	✓		
807 VAN	Passenger door module		✓	✓	✓	✓		
807 VAN	control unit		✓	✓	✓	✓		
807 VAN	CD Player		✓	✓	✓	✓		
807 VAN	steering wheel		✓	✓	✓	✓		
Boxer	Engine	DCU102	✓	✓	✓	✓		
Boxer	Engine	TUB EDC16C39	✓	✓	✓	✓		
Boxer	Engine	EDC17CP52	✓	✓	✓	✓		S0037
Boxer	ABS/ESP		✓	✓	✓	✓		
Expert	Engine	DCN2	✓	✓	✓	✓		
Expert	Engine	EDC15C2	✓	✓	✓	✓	✓	
Expert	AT		✓	✓	✓	✓		
Expert	ABS or ESP ECU	BOSCH ABS5.3	✓	✓	✓	✓		
Expert	ABS or ESP ECU	BENDIX	✓	✓	✓	✓	✓	
Expert	Airbag ECU		✓	✓	✓			
Expert 2	Engine	RFH MM6KP	✓	✓	✓	✓	✓	S0034
Expert 2	Engine	9HU EDC16C3	✓	✓	✓	✓	✓	
Expert 2	Engine	SID803	✓	✓	✓	✓	✓	S0037
Expert 2	Engine	RHH DCM3.5	✓	✓	✓	✓	✓	S0037 S0036
Expert 2	Engine	DCM3.5 BR2	✓	✓	✓	✓	✓	S0037 S0036
Expert 2	Engine	EDC17C10 BR2	✓	✓	✓	✓		
Expert 2	AT		✓	✓	✓	✓	✓	
Expert 2	ABS	ABS 8.1	✓	✓	✓	✓	✓	S0035 S0039
Expert 2	ABS	ABS8	✓	✓	✓	✓	✓	S0035 S0039
Expert 2	ABS	ESP 8.1	✓	✓	✓	✓	✓	S0035 S0039

Expert 2	ABS	ESP8	✓	✓	✓	✓	✓	S0035 S0039
Expert 2	SRS		✓	✓	✓	✓		
Expert 2	Instrument Panel		✓	✓	✓	✓		
Expert 2	Additional Heating		✓	✓	✓	✓	✓	
Expert 2	RADIO		✓	✓	✓	✓		
Partner	Engine	EDC16C3	✓	✓	✓	✓	✓	S0036
Partner	Engine	BOSCH ME749	✓	✓	✓	✓	✓	S0034
Partner	Engine	ME 7.4.5 [NFR]	✓	✓	✓	✓	✓	S0034
Partner	Engine	9HT BOSCH EDC16C3	✓	✓	✓	✓	✓	
Partner	ABS/ESP	ESP BOSCH57	✓	✓	✓	✓	✓	S0035 S0039
Partner	ABS/ESP	ABS BOSCH 8 KwpEcu	✓	✓	✓	✓	✓	
Partner	ABS/ESP	ESP BOSCH8 KwpECU	✓	✓	✓	✓	✓	S0035 S0039
Partner	ABS/ESP	ABS 81 KwpECU	✓	✓	✓	✓	✓	
Partner	ABS/ESP	ABS BOSCH53	✓	✓	✓	✓		
Partner	Airbag ECU	SAC CENT AUTOLIV	✓	✓	✓			
Partner	Airbag ECU	Airbag and seatbelts	✓	✓	✓			
Partner	Instrument panel		✓	✓	✓	✓	✓	
Partner	Additional Heating		✓	✓	✓	✓		
Partner	Switch module at the steering wheel		✓			✓		
Partner	Alarm		✓	✓	✓	✓		
Partner	Display/Telematics		✓	✓	✓	✓	✓	
Partner	CD Player		✓	✓	✓	✓		
Partner	Radio		✓	✓	✓	✓	✓	
Partner	Rain/brightness sensor		✓	✓	✓			
Partner 2	Engine	1.6 16v BOSCH Motronic ME 7.4.5 [NFR]	✓	✓	✓	✓	✓	
Partner 2	Engine	1.6 BOSCH HDI EDC16C34 [9HW]	✓	✓	✓	✓	✓	
Partner 2	ABS		✓	✓	✓	✓	✓	S0035 S0039
Partner 2	SRS		✓	✓	✓	✓		
106R	Engine	CDY BOSCH MA3.1	✓	✓	✓			
106R	Engine	CDZ BOSCH MA3.1	✓	✓	✓			
106R	Engine	HDY BOSCH MA3.1	✓	✓	✓			
106R	Engine	HDZ BOSCH MA3.1	✓	✓	✓			

106R	Engine	KFX BOSCH MP7.3	✓	✓	✓	✓		
106R	Engine	KFX MM1AP	✓	✓	✓	✓		
106R	Engine	NFX MM1AP	✓	✓	✓	✓		
106R	Engine	NFX MM48P	✓	✓	✓	✓		
106R	Engine	NFZ BOSCH MP5.2		✓	✓	✓		
106R	Additional heating		✓	✓	✓	✓		
605	Engine	R6E BOSCH MP5.2		✓	✓	✓		
605	Engine	RFV BOSCH MP5.2		✓	✓	✓		
605	Engine	RGX BOSCH MP3.2		✓	✓			
605	Engine	XFZ BOSCH MP7.0	✓	✓	✓	✓		
iON	Electric machine management ECU	MCU	✓	✓	✓	✓		
iON	electric vehicle ECU	EV ECU	✓	✓	✓	✓		
iON	traction battery ECU	BMU	✓	✓	✓	✓	✓	
iON	Traction battery cells management ECU (module 1)	CMU 01	✓			✓		
iON	Traction battery cells management ECU (module 2)	CMU 02	✓			✓		
iON	Traction battery cells management ECU (module 3)	CMU 03	✓			✓		
iON	management ECU (module 4)	CMU 04	✓			✓		
iON	Traction battery cells management ECU (module 5)	CMU 05	✓			✓		
iON	management ECU (module 7)	CMU 07	✓			✓		
iON	Traction battery cells management ECU (module 8)	CMU 08	✓			✓		
iON	Traction battery cells management ECU (module 9)	CMU 09	✓			✓		

iON	management ECU (CMU 10	✓			✓		
iON	management ECU (CMU 11	✓			✓		
iON	System (ABS) or	ASC	✓	✓	✓	✓		
iON	pretensioners ECU	SRS	✓	✓	✓	✓		
iON	pretensioners ECU	ORC	✓	✓	✓	✓		
iON	interface	ETACS	✓	✓	✓	✓		
iON	power steering	EPS	✓	✓	✓	✓		
iON	instrument panel	METER	✓	✓	✓	✓		S0033
iON	air conditioning	HVAC	✓	✓	✓	✓		
iON	passenger compartment	COMP HTR	✓	✓	✓			
iON	direct voltage	OBC DCDC	✓	✓	✓	✓		
iON	sensor	SAS	✓	✓	✓	✓		S0035
iON	Gateway wiring housing	BSP	✓	✓	✓	✓		
iON	Independent telematic	BTA	✓	✓	✓	✓		
iON	Independent telematic	BTA 2	✓	✓	✓	✓		
iON	radio	RDE	✓	✓	✓	✓		
iON	thermal programming	REMOTE EV	✓	✓	✓	✓		
107	engine management ECU	HDI SID805	✓	✓	✓	✓	✓	
107	engine management ECU	ME795	✓			✓		
107	manual gearbox	MMT	✓			✓		
107	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS90 T	✓			✓		
107	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 8 0 C1	✓			✓		
107	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP 8 0 C1	✓			✓		
107	airbags and pretensioners ECU	SAC TRW	✓			✓		
107	power steering	DAE	✓			✓		S0035

107	coded immobiliser / Hands-free unit	ADC	✓			✓		
107	radio	RDE	✓	✓	✓	✓	✓	
108	engine management ECU	V46	✓	✓	✓	✓		
108	engine management ECU (Engine 1KR)	ME17 9 52	✓	✓	✓	✓		
108	automatic or piloted manual gearbox	MMT T	✓	✓	✓	✓		
108	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	RBV	✓	✓	✓	✓		
108	airbags and pretensioners ECU	ABG	✓	✓	✓	✓		
108	power steering	EPS T	✓	✓	✓	✓		
108	instrument panel	MET	✓	✓	✓	✓		
108	Stop and Start ECU	ECO	✓	✓	✓	✓		
108	coded immobiliser / Hands-free unit	IMMO	✓	✓	✓	✓		
108	Hands-free unit (Entry and start) : starting monitoring	PMN SC	✓	✓	✓	✓		
108	Hands-free unit (Entry and start) : starting authorised	PMN PS	✓	✓	✓	✓		
108	Hands-free unit (Entry and start) : Access and starting	IDT	✓	✓	✓	✓		
108	air conditioning	ACN HVAC	✓	✓	✓	✓		
108	multifunction screen	AVN	✓	✓	✓	✓		
108	Multifunction video camera and remote detection by laser assembly	CSP	✓	✓	✓	✓		
206+	engine management ECU	EDC15C2	✓	✓	✓	✓	✓	

206+	engine management ECU	EDC15C2	✓	✓	✓	✓		
206+	engine management ECU	ME745	✓	✓	✓	✓	✓	S0034
206+	engine management ECU	ME749	✓	✓	✓	✓	✓	S0034
206+	engine management ECU	J34P	✓	✓	✓	✓	✓	S0034
206+	engine management ECU	DCN2	✓	✓	✓	✓		
206+	engine management ECU	EDC16C3DV4	✓	✓	✓	✓	✓	S0036
206+	engine management ECU	EDC17C10 BR2	✓	✓	✓	✓	✓	S0037 S0036
206+	engine management ECU	V343	✓	✓	✓	✓	✓	
206+	automatic or piloted manual gearbox	BVA AL4	✓	✓	✓	✓	✓	
206+	automatic or piloted manual gearbox	BVA AL4	✓	✓	✓	✓	✓	
206+	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABSMK70 1	✓	✓	✓	✓	✓	S0039
206+	System (ABS) or	ESPMK60 0	✓	✓	✓	✓	✓	
206+	airbags and pretensioners ECU	SAC AUTOLIV	✓	✓	✓			
206+	built-in systems interface	BSI	✓			✓		
206+	power steering	GEP	✓	✓	✓	✓		
206+	anti-theft alarm	ALARME	✓			✓		
206+	instrument panel	COMBINE	✓			✓	✓	
206+	air conditioning	CLIM REGULEE	✓			✓		
206+	multifunction screen	RT3	✓			✓	✓	
206+	multifunction screen	AMF	✓			✓	✓	
206+	radio	AUTORADIO	✓	✓	✓	✓		
206+	radio	RDE	✓	✓	✓	✓		
206+	CD changer / external CD player	CHANGEUR CD	✓	✓	✓	✓		
206+	rain and sunlight sensor	PLUIE LUMINOSITE	✓					
206+	controls under the steering wheel	COM2000	✓			✓		

	Service module / Independent telematic unit							
206+		BLVV	✓	✓	✓	✓	✓	
207 VAN	engine management ECU	EDC15C2	✓	✓	✓	✓	✓	
207 VAN	engine management ECU	EDC15C2	✓	✓	✓	✓		
207 VAN	engine management ECU	ME745	✓	✓	✓	✓	✓	S0034
207 VAN	engine management ECU	ME749	✓	✓	✓	✓	✓	S0034
207 VAN	engine management ECU	J34P	✓	✓	✓	✓	✓	S0034
207 VAN	engine management ECU	DCN2	✓	✓	✓	✓		
207 VAN	engine management ECU	EDC16C3DV4	✓	✓	✓	✓	✓	S0036
207 VAN	engine management ECU	EDC17C10 BR2	✓	✓	✓	✓	✓	S0037 S0036
207 VAN	engine management ECU	V343	✓	✓	✓	✓	✓	
207 VAN	manual gearbox	BVA AL4	✓	✓	✓	✓	✓	
207 VAN	manual gearbox	BVA AL4	✓	✓	✓	✓	✓	
207 VAN	System (ABS) or	ABSMK70 1	✓	✓	✓	✓	✓	S0039
207 VAN	System (ABS) or	ESPMK60 0	✓	✓	✓	✓	✓	
207 VAN	airbags and pretensioners ECU	SAC AUTOLIV	✓	✓	✓			
207 VAN	built-in systems interface	BSI	✓			✓		
207 VAN	power steering	GEP	✓	✓	✓	✓		
207 VAN	anti-theft alarm	ALARME	✓			✓		
207 VAN	instrument panel	COMBINE	✓			✓	✓	
207 VAN	air conditioning	CLIM REGULEE	✓			✓		
207 VAN	multifunction screen	RT3	✓			✓	✓	
207 VAN	multifunction screen	AMF	✓			✓	✓	
207 VAN	radio	AUTORADIO	✓	✓	✓	✓		
207 VAN	radio	RDE	✓	✓	✓	✓		
207 VAN	CD changer / external CD player	CHANGEUR CD	✓	✓	✓	✓		
207 VAN	rain and sunlight sensor	PLUIE LUMINOSITE	✓					
207 VAN	controls under the steering wheel	COM2000	✓			✓		
207 VAN	Independent telematic	BLVV	✓	✓	✓	✓	✓	

207 CAN	engine management ECU	EDC16C3	✓	✓	✓	✓		
207 CAN	engine management ECU	EDC16C3DV4	✓	✓	✓			
207 CAN	engine management ECU	ME745	✓	✓	✓	✓	✓	
207 CAN	engine management ECU	MM6LPC	✓	✓	✓	✓	✓	S0034
207 CAN	engine management ECU	MED17 4 EURO4	✓	✓	✓		✓	S0034
207 CAN	engine management ECU	MEV17 4 EURO4	✓	✓	✓	✓	✓	S0034
207 CAN	engine management ECU	J34P	✓	✓	✓	✓	✓	S0034
207 CAN	engine management ECU	MEV17 4 EURO5	✓	✓	✓	✓	✓	S0034
207 CAN	engine management ECU	HDI SID807	✓	✓	✓	✓		
207 CAN	engine management ECU	V341	✓	✓	✓	✓	✓	S0034
207 CAN	engine management ECU	EDC17C10	✓	✓	✓	✓		
207 CAN	engine management ECU	EDC17C10 BR2	✓	✓	✓	✓		
207 CAN	engine management ECU	MEV17 4 2	✓	✓	✓	✓	✓	S0034
207 CAN	engine management ECU	HDI SID807 BR2	✓	✓	✓	✓		
207 CAN	automatic or piloted manual gearbox	BVA AL4	✓	✓	✓	✓		
207 CAN	automatic or piloted manual gearbox	BVMP	✓	✓	✓	✓	✓	
207 CAN	System (ABS) or	ABSMK70 1	✓	✓	✓	✓	✓	S0039
207 CAN	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESPMK60 0	✓	✓	✓	✓	✓	S0039 S0035
207 CAN	airbags and pretensioners ECU	SAC AUTOLIV	✓	✓	✓	✓		
207 CAN	built-in systems interface	BSI	✓	✓	✓	✓		
207 CAN	power steering	DAE	✓	✓	✓	✓		
207 CAN	anti-theft alarm	ALARME	✓	✓	✓	✓	✓	
207 CAN	instrument panel	COMBINE	✓	✓	✓	✓	✓	
207 CAN	air conditioning	CLIM REGULEE	✓	✓	✓	✓	✓	
207 CAN	UNDER-INFLATION DETECTION	DSG	✓	✓	✓	✓		
207 CAN	DETECTION	DSG UDS	✓	✓	✓	✓		
207 CAN	parking assistance	AAS	✓	✓	✓	✓		

207 CAN	diesel fuel additive pump	PADDGO	✓	✓	✓	✓		
207 CAN	battery charge status control unit	BECB	✓	✓	✓	✓		S003A
207 CAN	battery charge status control unit	BECB GEN2	✓	✓	✓	✓		
207 CAN	Dynamic headlamp height adjuster	AFS	✓	✓	✓	✓	✓	
207 CAN	engine wiring housing	BSM	✓	✓	✓	✓		
207 CAN	Trailer relay unit	BSR	✓	✓	✓	✓		
207 CAN	steering wheel	HDC	✓	✓	✓	✓	✓	
207 CAN	multifunction screen	EMF A	✓	✓	✓	✓		
207 CAN	multifunction screen	EMF C	✓	✓	✓	✓		
207 CAN	radio	AUTORADIO	✓	✓	✓	✓		
207 CAN	radio	RD45	✓	✓	✓	✓	✓	
207 CAN	Telematic unit (RTx) or audio-navigation	RADIONAV RNEG	✓	✓	✓	✓		
207 CAN	Telematic unit (RTx) or audio-navigation	BOITIER TELEMATIQUE	✓	✓	✓	✓	✓	
207 CAN	CD changer / external CD player	CHANGEUR CD	✓	✓	✓			
207 CAN	Hands-free Kit / Portable Unit	KML	✓	✓	✓	✓	✓	
207 CAN	Portable Unit	BOITIER NOMADE	✓	✓	✓	✓	✓	
207 CAN	Retractable roof	BTE	✓	✓	✓	✓	✓	
207 CAN	driving school module	MAE	✓	✓	✓			
207 CAN	high frequency receiver	RHF	✓	✓	✓	✓		
207 CAN	seat belt not fastened warning lights unit	TNB	✓					
207 CAN	Service module / Independent telematic unit	BTA	✓	✓	✓	✓		
207 CAN	rain and sunlight sensor	PLUIE LUMINOSITE	✓	✓	✓			

207i	engine management ECU	EDC15C2	✓	✓	✓	✓	✓	
207i	engine management ECU	EDC15C2	✓	✓	✓	✓		
207i	engine management ECU	ME745	✓	✓	✓	✓	✓	S0034
207i	engine management ECU	ME749	✓	✓	✓	✓	✓	S0034
207i	engine management ECU	J34P	✓	✓	✓	✓	✓	S0034
207i	engine management ECU	DCN2	✓	✓	✓	✓		
207i	engine management ECU	EDC16C3DV4	✓	✓	✓	✓	✓	S0036
207i	engine management ECU	EDC17C10 BR2	✓	✓	✓	✓	✓	S0037 S0036
207i	engine management ECU	V343	✓	✓	✓	✓	✓	
207i	manual gearbox	BVA AL4	✓	✓	✓	✓	✓	
207i	manual gearbox	BVA AL4	✓	✓	✓	✓	✓	
207i	System (ABS) or	ABSMK70 1	✓	✓	✓	✓	✓	S0039
207i	System (ABS) or	ESPMK60 0	✓	✓	✓	✓	✓	
207i	airbags and pretensioners ECU	SAC AUTOLIV	✓	✓	✓			
207i	built-in systems interface	BSI	✓			✓		
207i	power steering	GEP	✓	✓	✓	✓		
207i	anti-theft alarm	ALARME	✓			✓		
207i	instrument panel	COMBINE	✓			✓	✓	
207i	air conditioning	CLIM REGULEE	✓			✓		
207i	multifunction screen	RT3	✓			✓	✓	
207i	multifunction screen	AMF	✓			✓	✓	
207i	radio	AUTORADIO	✓	✓	✓	✓		
207i	radio	RDE	✓	✓	✓	✓		
207i	CD changer / external CD player	CHANGEUR CD	✓	✓	✓	✓		
207i	rain and sunlight sensor	PLUIE LUMINOSITE	✓					
207i	controls under the steering wheel	COM2000	✓			✓		
207i	Service module / Independent telematic unit	BLVV	✓	✓	✓	✓	✓	
207+	engine management ECU	EDC16C3	✓	✓	✓	✓		

207+	engine management ECU	EDC16C3DV4	✓	✓	✓			
207+	engine management ECU	ME745	✓	✓	✓	✓	✓	
207+	engine management ECU	MM6LPC	✓	✓	✓	✓	✓	S0034
207+	engine management ECU	MED17 4 EURO4	✓	✓	✓		✓	S0034
207+	engine management ECU	MEV17 4 EURO4	✓	✓	✓	✓	✓	S0034
207+	engine management ECU	J34P	✓	✓	✓	✓	✓	S0034
207+	engine management ECU	MEV17 4 EURO5	✓	✓	✓	✓	✓	S0034
207+	engine management ECU	HDI SID807	✓	✓	✓	✓		
207+	engine management ECU	V341	✓	✓	✓	✓	✓	S0034
207+	engine management ECU	EDC17C10	✓	✓	✓	✓		
207+	engine management ECU	EDC17C10 BR2	✓	✓	✓	✓		
207+	engine management ECU	MEV17 4 2	✓	✓	✓	✓	✓	S0034
207+	engine management ECU	HDI SID807 BR2	✓	✓	✓	✓		
207+	manual gearbox	BVA AL4	✓	✓	✓	✓		
207+	automatic or piloted manual gearbox	BVMP	✓	✓	✓	✓	✓	
207+	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABSMK70 1	✓	✓	✓	✓	✓	S0039
207+	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESPMK60 0	✓	✓	✓	✓	✓	S0039 S0035
207+	pretensioners ECU	SAC AUTOLIV	✓	✓	✓	✓		
207+	built-in systems interface	BSI	✓	✓	✓	✓		
207+	power steering	DAE	✓	✓	✓	✓		
207+	anti-theft alarm	ALARME	✓	✓	✓	✓	✓	
207+	instrument panel	COMBINE	✓	✓	✓	✓	✓	
207+	air conditioning	CLIM REGULEE	✓	✓	✓	✓	✓	
207+	DETECTION	DSG	✓	✓	✓	✓		
207+	DETECTION	DSG UDS	✓	✓	✓	✓		
207+	parking assistance	AAS	✓	✓	✓	✓		
207+	pump	PADDGO	✓	✓	✓	✓		

207+	control unit	BECB	✓	✓	✓	✓		S003A
207+	control unit	BECB GEN2	✓	✓	✓	✓		
207+	height adjuster	AFS	✓	✓	✓	✓	✓	
207+	engine wiring housing	BSM	✓	✓	✓	✓		
207+	Trailer relay unit	BSR	✓	✓	✓	✓		
207+	steering wheel	HDC	✓	✓	✓	✓	✓	
207+	multifunction screen	EMF A	✓	✓	✓	✓		
207+	multifunction screen	EMF C	✓	✓	✓	✓		
207+	radio	AUTORADIO	✓	✓	✓	✓		
207+	radio	RD45	✓	✓	✓	✓	✓	
207+	or audio-navigation	RADIONAV RNEG	✓	✓	✓	✓		
207+	or audio-navigation	BOITIER TELEMATIQUE	✓	✓	✓	✓	✓	
207+	CD player	CHANGEUR CD	✓	✓	✓			
207+	Portable Unit	KML	✓	✓	✓	✓	✓	
207+	Portable Unit	BOITIER NOMADE	✓	✓	✓	✓	✓	
207+	Retractable roof	BTE	✓	✓	✓	✓	✓	
207+	driving school module	MAE	✓	✓	✓			
207+	high frequency receiver	RHF	✓	✓	✓	✓		
207+	seat belt not fastened warning lights unit	TNB	✓					
207+	Service module / Independent telematic unit	BTA	✓	✓	✓	✓		
207+	rain and sunlight sensor	PLUIE LUMINOSITE	✓	✓	✓			
208	engine management ECU	ME749 EC5	✓	✓	✓	✓		
208	engine management ECU	EDC17C10 BR2	✓	✓	✓	✓	✓	S0037
208	engine management ECU	MEV17 4 2	✓	✓	✓	✓		S0034
208	engine management ECU	HDI SID807 BR2	✓	✓	✓	✓	✓	S0037
208	engine management ECU	V46	✓	✓	✓	✓		
208	engine management ECU	MED17 4 2	✓	✓	✓	✓		S0034
208	engine management ECU	MEVD17 4 2	✓	✓	✓	✓		
208	engine management ECU	V344	✓	✓	✓	✓		
208	engine management ECU	V345	✓	✓	✓	✓		

208	engine management ECU	ME745 EC5	✓	✓	✓	✓		
208	engine management ECU	VD46	✓	✓	✓	✓		
208	engine management ECU	EDC17C60	✓	✓	✓	✓		
208	engine management ECU	MEVD17 4 4	✓	✓	✓	✓		
208	engine management ECU	MED17 4 4	✓	✓	✓	✓		
208	engine management ECU	V46 21	✓	✓	✓	✓		
208	engine management ECU	V46 52	✓	✓	✓	✓		
208	engine management ECU	V46 6	✓	✓	✓	✓		
208	engine management ECU	CMM V56	✓	✓	✓	✓		
208	engine management ECU	CMM MD1CS003	✓	✓	✓	✓		
208	engine management ECU	CMM VD56	✓	✓	✓	✓		
208	automatic or piloted manual gearbox	BVA AL4	✓	✓	✓	✓	✓	
208	automatic or piloted manual gearbox	BVMP	✓	✓	✓	✓		
208	automatic or piloted manual gearbox	CFC300P	✓	✓	✓	✓	✓	
208	manual gearbox	MAPS UDS	✓	✓	✓	✓		
208	automatic or piloted manual gearbox	BVA AM6 AT6 UDS	✓	✓	✓	✓		
208	automatic or piloted manual gearbox	BVMP MCP UDS	✓	✓	✓	✓		
208	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABSMK100	✓	✓	✓	✓	✓	S0039
208	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESPMK100	✓	✓	✓	✓	✓	S0039
208	airbags and pretensioners ECU	RBG UDS	✓	✓	✓	✓		
208	built-in systems interface	BSI2010	✓	✓	✓	✓		
208	power steering	DAE	✓	✓	✓	✓		

208	power steering	DAE A515	✓	✓	✓	✓		
208	power steering	DAE UDS	✓	✓	✓	✓		
208	anti-theft alarm	MUS	✓	✓	✓	✓	✓	
208	Intrusion alarm siren	SIR	✓	✓	✓	✓		
208	instrument panel	COMBINE UDS	✓	✓	✓	✓	✓	
208	Control panel dot matrix display	MATT C 2010	✓	✓	✓			
208	Control panel dot matrix display	MATT M 2010	✓	✓	✓			
208	Control panel dot matrix display	MATT P 2010	✓	✓	✓			
208	air conditioning	TDC CH MUX	✓	✓	✓	✓		
208	air conditioning	TDC RF MUX	✓	✓	✓	✓		
208	air conditioning	TDC RFTA MUX	✓	✓	✓	✓		
208	parking assistance	AAS UDS	✓	✓	✓	✓		
208	diesel fuel additive pump	PADDGO	✓	✓	✓	✓		
208	diesel fuel additive pump	PADDGO TI E6	✓	✓	✓	✓		
208	Voltage maintaining device	DMTC	✓					
208	Voltage maintaining device	DMTR	✓	✓	✓			
208	device	DMTR DTC3B	✓	✓	✓			
208	Trailer relay unit	BSG 2010 RQ	✓	✓	✓	✓		
208	battery charge status control unit	BECB GEN2	✓	✓	✓	✓		S003A
208	controls under the steering wheel	COM2008P	✓	✓	✓	✓	✓	
208	Controls on the steering wheel / Integral controls steering wheel	VCI	✓	✓	✓	✓		

208	Controls on the steering wheel / Integral controls steering wheel	VCI	✓	✓	✓	✓		
208	Multifunction control panel	FMUX	✓	✓	✓	✓		
208	driving school module	MAE	✓	✓	✓			
208	rain and sunlight sensor	PLUIE LUMINOSITE UDS	✓	✓	✓	✓		
208	Vehicle Distance Assistance	LIDAR	✓	✓	✓	✓		
208	touch screen	EMF DGT LVDS BD	✓	✓	✓	✓		
208	Telematic unit (RTx) or audio-navigation	SMEG	✓	✓	✓	✓		
208	Telematic unit (RTx) or audio-navigation	SMEG PLUS	✓	✓	✓	✓		
208	or audio-navigation	NAC	✓	✓	✓	✓		
208	or audio-navigation	RCC	✓	✓	✓	✓		
208	or audio-navigation	AIO	✓	✓	✓	✓		
208	radio	RDE	✓	✓	✓	✓	✓	
208	radio	RD6	✓	✓	✓	✓		
208	Independent telematic	BTA	✓	✓	✓	✓		
208	Independent telematic	BTA 2	✓	✓	✓	✓		
208	Independent telematic	BTA 3R	✓	✓	✓	✓		
208	Independent telematic	BTA 3S	✓	✓	✓	✓		
208	external CD player	CDE	✓	✓	✓	✓	✓	
208	audio amplifier	AMPLI AUDIO	✓	✓	✓			
208	Lighting fuse box	BSG E	✓	✓	✓	✓		
208 (P21)	engine management ECU	CMM MD1CS003	✓	✓	✓	✓		
208 (P21)	engine management ECU	V46 21	✓	✓	✓	✓		
208 (P21)	manual gearbox	BVA AM6 AT6 UDS	✓	✓	✓	✓		
208 (P21)	manual gearbox	BVA AXN8	✓	✓	✓	✓		
208 (P21)	System (ABS) or	ESPMK100 UDS	✓	✓	✓	✓		
208 (P21)	System (ABS) or	ABSMK100 UDS	✓	✓	✓	✓		
208 (P21)	pretensioners ECU	RBG SPEED UDS	✓	✓	✓	✓		

208 (P21)	interface	BSI2010 EV	✓	✓	✓	✓		
208 (P21)	power steering	DAE UDS	✓	✓	✓	✓		
208 (P21)	Electric steering lock	AVE	✓	✓	✓	✓		
208 (P21)	anti-theft alarm	MUS2	✓	✓	✓	✓		
208 (P21)	Intrusion alarm siren	SIR	✓	✓	✓	✓		
208 (P21)	instrument panel	COMBINE UDS EV	✓	✓	✓	✓		
208 (P21)	Hands-free unit	SDCM	✓	✓	✓	✓		
208 (P21)	air conditioning	BCC	✓	✓	✓	✓		
208 (P21)	parking assistance	AAS UDS G6	✓	✓	✓	✓		
208 (P21)	Sequential gear lever	ESM	✓	✓	✓	✓		
208 (P21)	Multifunction control panel	FMUX 2	✓	✓	✓	✓		
208 (P21)	Dynamic headlamp height adjuster	BEMP UDS	✓	✓	✓	✓		
208 (P21)	Trailer relay unit	BSG 2010 RQ	✓	✓	✓	✓		
208 (P21)	battery charge status control unit	BECB GEN2	✓	✓	✓	✓		
208 (P21)	controls under the steering wheel	COM2008P	✓	✓	✓	✓		
208 (P21)	Controls on the steering wheel / Integral controls steering wheel	VCI	✓	✓	✓	✓		
208 (P21)	seat belt not fastened warning lights unit	TNB 2010	✓					
208 (P21)	rain and sunlight sensor	CDPL UDS HELLA	✓	✓	✓	✓		
208 (P21)	Multifunction video camera (CMF)	CVM 3	✓	✓	✓	✓		
208 (P21)	Vehicle Distance Assistance	RADAR AV 4	✓	✓	✓	✓		
208 (P21)	touch screen	EMF DGT UDS GP	✓	✓	✓	✓		
208 (P21)	touch screen	EMF DGT LVDS BD	✓	✓	✓	✓		
208 (P21)	Telematic unit (RTx) or audio-navigation	NAC	✓	✓	✓	✓		

208 (P21)	Telematic unit (RTx) or audio-navigation	RCC	✓	✓	✓	✓		
208 (P21)	Telematic unit (RTx) or audio-navigation	RCE	✓	✓	✓	✓		
208 (P21)	Telematic unit (RTx) or audio-navigation	AIO	✓	✓	✓	✓		
208 (P21)	Service module / Independent telematic unit	BTA 3R	✓	✓	✓	✓		
208 (P21)	Service module / Independent telematic unit	BTA 3S	✓	✓	✓	✓		
208 (P21)	driver's door module	PDPC UDS	✓	✓	✓	✓		
208 (P21)	Front left seat heated pads and ventilation regulation ECU	BRNC AVG	✓			✓		
208 (P21)	Front right seat heated pads and ventilation regulation ECU	BRNC AVD	✓			✓		
208 (P21)	LEDs management ECU	PLMB	✓	✓	✓			
208 (Ai91)	engine management ECU	ME749 EC5	✓	✓	✓	✓		
208 (Ai91)	engine management ECU	EDC17C10 BR2	✓	✓	✓	✓	✓	S0037
208 (Ai91)	engine management ECU	MEV17 4 2	✓	✓	✓	✓		S0034
208 (Ai91)	engine management ECU	HDI SID807 BR2	✓	✓	✓	✓	✓	S0037
208 (Ai91)	engine management ECU	V46	✓	✓	✓	✓		
208 (Ai91)	engine management ECU	MED17 4 2	✓	✓	✓	✓		S0034
208 (Ai91)	engine management ECU	MEVD17 4 2	✓	✓	✓	✓		
208 (Ai91)	engine management ECU	V344	✓	✓	✓	✓		
208 (Ai91)	engine management ECU	V345	✓	✓	✓	✓		
208 (Ai91)	engine management ECU	ME745 EC5	✓	✓	✓	✓		
208 (Ai91)	engine management ECU	VD46	✓	✓	✓	✓		
208 (Ai91)	engine management ECU	EDC17C60	✓	✓	✓	✓		
208 (Ai91)	engine management ECU	MEVD17 4 4	✓	✓	✓	✓		
208 (Ai91)	engine management ECU	MED17 4 4	✓	✓	✓	✓		

208 (Ai91)	engine management ECU	V46 21	✓	✓	✓	✓		
208 (Ai91)	engine management ECU	V46 52	✓	✓	✓	✓		
208 (Ai91)	engine management ECU	V46 6	✓	✓	✓	✓		
208 (Ai91)	engine management ECU	CMM V56	✓	✓	✓	✓		
208 (Ai91)	engine management ECU	CMM MD1CS003	✓	✓	✓	✓		
208 (Ai91)	engine management ECU	CMM VD56	✓	✓	✓	✓		
208 (Ai91)	automatic or piloted manual gearbox	BVA AL4	✓	✓	✓	✓	✓	
208 (Ai91)	automatic or piloted manual gearbox	BVMP	✓	✓	✓	✓		
208 (Ai91)	automatic or piloted manual gearbox	CFC300P	✓	✓	✓	✓	✓	
208 (Ai91)	automatic or piloted manual gearbox	MAPS UDS	✓	✓	✓	✓		
208 (Ai91)	automatic or piloted manual gearbox	BVA AM6 AT6 UDS	✓	✓	✓	✓		
208 (Ai91)	automatic or piloted manual gearbox	BVMP MCP UDS	✓	✓	✓	✓		
208 (Ai91)	System (ABS) or	ABSMK100	✓	✓	✓	✓	✓	S0039
208 (Ai91)	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESPMK100	✓	✓	✓	✓	✓	S0039
208 (Ai91)	airbags and pretensioners ECU	RBG UDS	✓	✓	✓	✓		
208 (Ai91)	interface	BSI2010	✓	✓	✓	✓		
208 (Ai91)	power steering	DAE	✓	✓	✓	✓		
208 (Ai91)	power steering	DAE A515	✓	✓	✓	✓		
208 (Ai91)	power steering	DAE UDS	✓	✓	✓	✓		
208 (Ai91)	anti-theft alarm	MUS	✓	✓	✓	✓	✓	
208 (Ai91)	Intrusion alarm siren	SIR	✓	✓	✓	✓		
208 (Ai91)	instrument panel	COMBINE UDS	✓	✓	✓	✓	✓	
208 (Ai91)	matrix display	MATT C 2010	✓	✓	✓			
208 (Ai91)	matrix display	MATT M 2010	✓	✓	✓			
208 (Ai91)	matrix display	MATT P 2010	✓	✓	✓			

208 (Ai91)	air conditioning	TDC CH MUX	✓	✓	✓	✓		
208 (Ai91)	air conditioning	TDC RF MUX	✓	✓	✓	✓		
208 (Ai91)	air conditioning	TDC RFTA MUX	✓	✓	✓	✓		
208 (Ai91)	parking assistance	AAS UDS	✓	✓	✓	✓		
208 (Ai91)	steering wheel	COM2008P	✓	✓	✓	✓	✓	
208 (Ai91)	steering wheel /	VCI	✓	✓	✓	✓		
208 (Ai91)	steering wheel /	VCI	✓	✓	✓	✓		
208 (Ai91)	Multifunction control panel	FMUX	✓	✓	✓	✓		
208 (Ai91)	rain and sunlight sensor	PLUIE LUMINOSITE UDS	✓	✓	✓	✓		
208 (Ai91)	Telematic unit (RTx) or audio-navigation	SMEG	✓	✓	✓	✓		
208 (Ai91)	Telematic unit (RTx) or audio-navigation	SMEG PLUS	✓	✓	✓	✓		
208 (Ai91)	Telematic unit (RTx) or audio-navigation	NAC	✓	✓	✓	✓		
208 (Ai91)	Telematic unit (RTx) or audio-navigation	RCC	✓	✓	✓	✓		
208 (Ai91)	Telematic unit (RTx) or audio-navigation	AIO	✓	✓	✓	✓		
208 (Ai91)	radio	RDE	✓	✓	✓	✓	✓	
208 (Ai91)	radio	RD6	✓	✓	✓	✓		
208 (Ai91)	Service module / Independent telematic unit	BTA	✓	✓	✓	✓		
208 (Ai91)	Service module / Independent telematic unit	BTA 2	✓	✓	✓	✓		
208 (Ai91)	Service module / Independent telematic unit	BTA 3R	✓	✓	✓	✓		
208 (Ai91)	Service module / Independent telematic unit	BTA 3S	✓	✓	✓	✓		

208 (Ai91)	external CD player	CDE	✓	✓	✓	✓	✓	
301	engine management ECU	V46 21	✓	✓	✓	✓	✓	
301	engine management ECU	EDC17C10 BR2	✓	✓	✓	✓	✓	S0037 S0036
301	engine management ECU	V46	✓	✓	✓	✓		
301	engine management ECU	ME745 EC5	✓	✓	✓	✓	✓	S0034
301	engine management ECU	MED17 4 4	✓	✓	✓	✓		
301	engine management ECU	EDC17C60	✓	✓	✓	✓		
301	engine management ECU	V46 52	✓	✓	✓	✓		
301	engine management ECU	VD46	✓	✓	✓	✓	✓	
301	engine management ECU	CMM V56	✓	✓	✓	✓		
301	engine management ECU	CMM MD1CS003	✓	✓	✓	✓		
301	automatic or piloted manual gearbox	BVA AL4	✓	✓	✓	✓	✓	
301	automatic or piloted manual gearbox	MAPS UDS	✓	✓	✓	✓		
301	manual gearbox	BVA AM6 AT6 UDS	✓	✓	✓	✓		
301	automatic or piloted manual gearbox	DCT 6DCT200	✓	✓	✓	✓		
301	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABSMK100	✓	✓	✓	✓	✓	S0039
301	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESPMK100	✓	✓	✓	✓	✓	S0039
301	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90	✓	✓	✓			
301	airbags and pretensioners ECU	RBG UDS	✓	✓	✓	✓		
301	built-in systems interface	BSI2010	✓	✓	✓	✓		S0033
301	power steering	DAE	✓	✓	✓	✓		

301	power steering	DAE A515	✓	✓	✓	✓		
301	power steering	GEP	✓	✓	✓			
301	power steering	DAE UDS	✓	✓	✓	✓		
301	Intrusion alarm siren	SIR	✓	✓	✓	✓		
301	instrument panel	COMBINE UDS	✓	✓	✓	✓	✓	
301	parking assistance	AAS UDS	✓	✓	✓	✓		
301	diesel fuel additive pump	PADDGO	✓	✓	✓	✓		
301	diesel fuel additive pump	PADDGO TI E6	✓	✓	✓	✓		
301	Trailer relay unit	BSG 2010 RQ	✓	✓	✓	✓		
301	battery charge status control unit	BECB GEN2	✓	✓	✓	✓		
301	controls under the steering wheel	HDC	✓	✓	✓	✓		
301	controls under the steering wheel	COM2008P	✓	✓	✓	✓		
301	multifunction screen	EMF A UDS	✓	✓	✓	✓		
301	multifunction screen	EMF C UDS	✓	✓	✓	✓		
301	touch screen	EMF DGT LVDS BD	✓	✓	✓	✓		
301	Telematic unit (RTx) or audio-navigation	MRN	✓	✓	✓	✓		
301	Telematic unit (RTx) or audio-navigation	RCC	✓	✓	✓	✓		
301	Telematic unit (RTx) or audio-navigation	NAC	✓	✓	✓	✓		
301	radio	RDE	✓	✓	✓	✓	✓	
301	radio	RD45	✓	✓	✓	✓	✓	
HOGGAR	engine management ECU	EDC15C2	✓	✓	✓	✓	✓	
HOGGAR	engine management ECU	EDC15C2	✓	✓	✓	✓		
HOGGAR	engine management ECU	ME745	✓	✓	✓	✓	✓	S0034
HOGGAR	engine management ECU	ME749	✓	✓	✓	✓	✓	S0034
HOGGAR	engine management ECU	J34P	✓	✓	✓	✓	✓	S0034
HOGGAR	engine management ECU	DCN2	✓	✓	✓	✓		

HOGGAR	engine management ECU	EDC16C3DV4	✓	✓	✓	✓	✓	S0036
HOGGAR	engine management ECU	EDC17C10 BR2	✓	✓	✓	✓	✓	S0037 S0036
HOGGAR	engine management ECU	V343	✓	✓	✓	✓	✓	
HOGGAR	manual gearbox	BVA AL4	✓	✓	✓	✓	✓	
HOGGAR	manual gearbox	BVA AL4	✓	✓	✓	✓	✓	
HOGGAR	System (ABS) or	ABSMK70 1	✓	✓	✓	✓	✓	S0039
HOGGAR	System (ABS) or	ESPMK60 0	✓	✓	✓	✓	✓	
HOGGAR	pretensioners ECU	SAC AUTOLIV	✓	✓	✓			
HOGGAR	interface	BSI	✓			✓		
HOGGAR	power steering	GEP	✓	✓	✓	✓		
HOGGAR	anti-theft alarm	ALARME	✓			✓		
HOGGAR	instrument panel	COMBINE	✓			✓	✓	
HOGGAR	air conditioning	CLIM REGULEE	✓			✓		
HOGGAR	multifunction screen	RT3	✓			✓	✓	
HOGGAR	multifunction screen	AMF	✓			✓	✓	
HOGGAR	radio	AUTORADIO	✓	✓	✓	✓		
HOGGAR	radio	RDE	✓	✓	✓	✓		
HOGGAR	CD changer / external CD player	CHANGEUR CD	✓	✓	✓	✓		
HOGGAR	rain and sunlight sensor	PLUIE LUMINOSITE	✓					
HOGGAR	controls under the steering wheel	COM2000	✓			✓		
HOGGAR	Service module / Independent telematic unit	BLVV	✓	✓	✓	✓	✓	
307 CAN	engine management ECU	DCM34	✓	✓	✓	✓	✓	S0037 S0036
307 CAN	engine management ECU	EDC16C3	✓	✓	✓	✓	✓	S0036
307 CAN	engine management ECU	MM6LPB	✓	✓	✓	✓	✓	S0034
307 CAN	engine management ECU	ME745	✓	✓	✓	✓	✓	S0034 S0040 S0041 S004 2
307 CAN	engine management ECU	ME749	✓	✓	✓	✓	✓	S0034
307 CAN	engine management ECU	MM6KP	✓	✓	✓	✓	✓	S0034
307 CAN	engine management ECU	EDC15C2	✓	✓	✓	✓	✓	

307 CAN	engine management ECU	MM6LP	✓	✓	✓	✓	✓	S0034
307 CAN	engine management ECU	HDI SID803	✓	✓	✓	✓	✓	
307 CAN	engine management ECU	HDI SID803A	✓	✓	✓	✓	✓	
307 CAN	engine management ECU	MM6LPC	✓	✓	✓	✓	✓	S0034
307 CAN	engine management ECU	ME745 EC5	✓	✓	✓	✓	✓	
307 CAN	automatic or piloted manual gearbox	BVA AL4	✓	✓	✓	✓		
307 CAN	automatic or piloted manual gearbox	BVA AM6	✓	✓	✓	✓	✓	
307 CAN	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS81	✓	✓	✓	✓	✓	S0039
307 CAN	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81	✓	✓	✓	✓	✓	S0039 S0035
307 CAN	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS8 BOSCH	✓	✓	✓	✓	✓	S0039
307 CAN	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP8 BOSCH	✓	✓	✓	✓	✓	S0039
307 CAN	airbags and pretensioners ECU	SAC AUTOLIV	✓	✓	✓	✓		
307 CAN	built-in systems interface	BSI	✓	✓	✓	✓		S0033
307 CAN	power steering	GEP	✓	✓	✓	✓	✓	
307 CAN	anti-theft alarm	ALARME	✓	✓	✓	✓	✓	
307 CAN	instrument panel	COMBINE	✓	✓	✓	✓	✓	
307 CAN	air conditioning	CLIM REGULEE	✓	✓	✓	✓	✓	
307 CAN	UNDER-INFLATION DETECTION	DSG	✓	✓	✓	✓		

307 CAN	parking assistance	AAS	✓	✓	✓	✓	✓	
307 CAN	diesel additive	ADDGO3	✓	✓	✓	✓		
307 CAN	diesel fuel additive pump	PADDGO	✓	✓	✓	✓		
307 CAN	Right-hand dynamic headlamp height adjuster	PROJECTEURD	✓	✓	✓	✓		
307 CAN	Left-hand dynamic headlamp height adjuster	PROJECTEURG	✓	✓	✓	✓		
307 CAN	engine wiring housing	BSM	✓	✓	✓	✓		
307 CAN	Trailer relay unit	BSR	✓	✓	✓	✓		
307 CAN	multifunction screen	EMF A	✓	✓	✓	✓		
307 CAN	multifunction screen	EMF C	✓	✓	✓	✓		
307 CAN	controls under the steering wheel	HDC	✓	✓	✓	✓	✓	
307 CAN	CD player	CHANGEUR CD	✓	✓	✓			
307 CAN	Hands-free Kit / Portable Unit	KML	✓	✓	✓	✓	✓	
307 CAN	Hands-free Kit / Portable Unit	BOITIER NOMADE	✓	✓	✓	✓		
307 CAN	radio	AUTORADIO	✓	✓	✓	✓	✓	
307 CAN	Telematic unit (RTx) or audio-navigation	BOITIER TELEMATIQUE	✓	✓	✓			
307 CAN	passenger door module	EDPP	✓	✓	✓	✓	✓	
307 CAN	driver's door module	EDPC	✓	✓	✓	✓	✓	
307 CAN	sunroof	TOUV	✓	✓	✓	✓		
307 CAN	Retractable roof	BTE	✓	✓	✓	✓		
307 CAN	driving school module	MAE	✓	✓	✓			
307 CAN	sensor	PLUIE LUMINOSITE	✓	✓	✓			
307 CAN	receiver	RHF	✓	✓	✓	✓		
307 CAN	Independent telematic	BLVV	✓	✓	✓	✓		
308	engine management ECU	DCM35 BR2	✓	✓	✓	✓	✓	S0037 S0036
308	engine management ECU	DCM34	✓	✓	✓	✓	✓	S0037 S0036
308	engine management ECU	DCM35	✓	✓	✓	✓	✓	S0037 S0036

308	engine management ECU	EDC16C3	✓	✓	✓	✓	✓	
308	engine management ECU	MED17 4 EURO4	✓	✓	✓	✓	✓	S0034
308	engine management ECU	MEV17 4 EURO4	✓	✓	✓	✓	✓	S0034
308	engine management ECU	MM6LPB	✓	✓	✓	✓	✓	
308	engine management ECU	ME745	✓	✓	✓	✓	✓	
308	engine management ECU	ME749	✓	✓	✓	✓	✓	
308	engine management ECU	ME749 EC5	✓	✓	✓	✓	✓	S0034
308	engine management ECU	MM6KP	✓	✓	✓	✓	✓	S0034
308	engine management ECU	MEV17 4 EURO5	✓	✓	✓	✓	✓	S0034
308	engine management ECU	MED17 4 EURO5	✓	✓	✓	✓	✓	S0034
308	engine management ECU	HDI SID807	✓	✓	✓	✓		
308	engine management ECU	EDC17C10	✓	✓	✓	✓	✓	S0037 S0036
308	engine management ECU	EDC17C10 BR2	✓	✓	✓	✓	✓	S0037 S0036
308	engine management ECU	MEV17 4 2	✓	✓	✓	✓	✓	S0034
308	engine management ECU	HDI SID807 BR2	✓	✓	✓	✓	✓	S0037
308	engine management ECU	MEVD17 4 2	✓	✓	✓	✓	✓	S0034
308	engine management ECU	MED17 4 2	✓	✓	✓	✓	✓	
308	engine management ECU	ME745 EC5	✓	✓	✓	✓		
308	engine management ECU	V46 21	✓	✓	✓	✓		
308	engine management ECU	MED17 4 4	✓	✓	✓	✓		
308	automatic or piloted manual gearbox	BVA AM6 AT6 EURO5	✓	✓	✓	✓	✓	
308	automatic or piloted manual gearbox	BVA AL4	✓	✓	✓	✓	✓	
308	automatic or piloted manual gearbox	BVA AM6	✓	✓	✓	✓	✓	
308	automatic or piloted manual gearbox	CFC300P	✓	✓	✓	✓	✓	
308	automatic or piloted manual gearbox	BVA AM6 AT6 UDS	✓	✓	✓	✓		
308	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS81	✓	✓	✓	✓	✓	S0039

308	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81	✓	✓	✓	✓	✓	S0039 S0035
308	System (ABS) or	ESP90	✓	✓	✓	✓		
308	airbags and pretensioners ECU	SAC AUTOLIV	✓	✓	✓	✓		
308	built-in systems interface	BSI	✓	✓	✓			
308	power steering	GEP	✓	✓	✓	✓	✓	
308	anti-theft alarm	ALARME	✓	✓	✓	✓	✓	
308	anti-theft alarm	ALARME LIN	✓	✓	✓	✓	✓	
308	instrument panel	COMBINE	✓	✓	✓	✓	✓	
308	Control panel dot matrix display	MATT	✓	✓	✓	✓	✓	
308	air conditioning	CLIM REGULEE	✓	✓	✓	✓	✓	
308	UNDER-INFLATION DETECTION	DSG	✓	✓	✓	✓		
308	UNDER-INFLATION DETECTION	DSG UDS	✓	✓	✓	✓		
308	parking assistance	AAS	✓	✓	✓	✓		
308	parking assistance	AAS UDS	✓	✓	✓			
308	diesel fuel additive pump	PADDGO	✓	✓	✓	✓	✓	
308	diesel fuel additive pump	PADDGO E5	✓	✓	✓	✓		
308	diesel fuel additive pump	PADDGO TI E6	✓	✓	✓	✓		
308	Dynamic headlamp height adjuster	LADCT	✓	✓	✓	✓	✓	
308	battery charge status control unit	BECB	✓	✓	✓	✓		S003A
308	battery charge status control unit	BECB GEN2	✓	✓	✓	✓		S003A
308	lane wandering alert	AFIL	✓	✓	✓	✓	✓	

308	engine wiring housing	BSM	✓	✓	✓	✓	✓	
308	Trailer relay unit	BSR	✓	✓	✓	✓	✓	
308	multifunction screen	EMF A	✓	✓	✓	✓	✓	
308	multifunction screen	EMF C	✓	✓	✓	✓	✓	
308	windscreen wiper	MOTEV	✓	✓	✓	✓		
308	controls under the steering wheel	HDC	✓	✓	✓	✓	✓	
308	CD changer / external CD player	CHANGEUR CD	✓	✓	✓			
308	Telematic unit (RTx) or audio-navigation	RADIONAV RNEGC	✓	✓	✓	✓		
308	or audio-navigation	RADIONAV RNEG	✓	✓	✓	✓		
308	or audio-navigation	RADIONAV NG4	✓	✓	✓	✓		
308	or audio-navigation	BOITIER TELEMATIQUE	✓	✓	✓			
308	or audio-navigation	RADIONAV RNEG ECO	✓	✓	✓	✓		
308	or audio-navigation	RNEG2010	✓	✓	✓	✓		
308	or audio-navigation	SMEG PLUS	✓	✓	✓	✓		
308	audio amplifier	AMPLI AUDIO	✓	✓	✓	✓		
308	Portable Unit	KML	✓	✓	✓	✓	✓	
308	Portable Unit	BOITIER NOMADE	✓	✓	✓	✓	✓	
308	radio	RD43	✓	✓	✓	✓		
308	radio	AUTORADIO	✓	✓	✓	✓	✓	
308	radio	RD45	✓	✓	✓	✓	✓	
308	memory module.	BDMC	✓	✓	✓	✓	✓	
308	position memory	BDMP	✓	✓	✓	✓	✓	
308	driver's door module	PDPC	✓	✓	✓	✓	✓	
308	sunroof	TOUV	✓	✓	✓	✓		
308	Moving panel deflector	DEFL PAN MOBIL	✓	✓	✓	✓		
308	Retractable roof	BTE	✓	✓	✓	✓		
308	Service module / Independent telematic unit	MD SERV	✓	✓	✓	✓		
308	Service module / Independent telematic unit	BTA	✓	✓	✓	✓		

308	Service module / Independent telematic unit	BLVV	✓	✓	✓	✓		
308	Service module / Independent telematic unit	BTA 3R	✓	✓	✓	✓		
308	Service module / Independent telematic unit	BTA 3S	✓	✓	✓	✓		
308	driving school module	MAE	✓	✓	✓			
308	rain and sunlight sensor	PLUIE LUMINOSITE	✓	✓	✓			
308	seat belt not fastened warning lights unit	TNB	✓					
308	high frequency receiver	RHF	✓	✓	✓	✓		
308	Voltage maintaining device	DMTC	✓					
308	Voltage maintaining device	DMTR DTC3B	✓	✓	✓			
308 4 portes	engine management ECU	DCM35 BR2	✓	✓	✓	✓	✓	S0037 S0036
308 4 portes	engine management ECU	DCM34	✓	✓	✓	✓	✓	S0037 S0036
308 4 portes	engine management ECU	DCM35	✓	✓	✓	✓	✓	S0037 S0036
308 4 portes	engine management ECU	EDC16C3	✓	✓	✓	✓	✓	
308 4 portes	engine management ECU	MED17 4 EURO4	✓	✓	✓	✓	✓	S0034
308 4 portes	engine management ECU	MEV17 4 EURO4	✓	✓	✓	✓	✓	S0034
308 4 portes	engine management ECU	MM6LPB	✓	✓	✓	✓	✓	
308 4 portes	engine management ECU	ME745	✓	✓	✓	✓	✓	
308 4 portes	engine management ECU	ME749	✓	✓	✓	✓	✓	
308 4 portes	engine management ECU	ME749 EC5	✓	✓	✓	✓	✓	S0034
308 4 portes	engine management ECU	MM6KP	✓	✓	✓	✓	✓	S0034
308 4 portes	engine management ECU	MEV17 4 EURO5	✓	✓	✓	✓	✓	S0034
308 4 portes	engine management ECU	MED17 4 EURO5	✓	✓	✓	✓	✓	S0034
308 4 portes	engine management ECU	HDI SID807	✓	✓	✓	✓		
308 4 portes	engine management ECU	EDC17C10	✓	✓	✓	✓	✓	S0037 S0036

308 4 portes	engine management ECU	EDC17C10 BR2	✓	✓	✓	✓	✓	S0037 S0036
308 4 portes	engine management ECU	MEV17 4 2	✓	✓	✓	✓	✓	S0034
308 4 portes	engine management ECU	HDI SID807 BR2	✓	✓	✓	✓	✓	S0037
308 4 portes	engine management ECU	MEVD17 4 2	✓	✓	✓	✓	✓	S0034
308 4 portes	engine management ECU	MED17 4 2	✓	✓	✓	✓	✓	
308 4 portes	engine management ECU	ME745 EC5	✓	✓	✓	✓		
308 4 portes	engine management ECU	V46 21	✓	✓	✓	✓		
308 4 portes	engine management ECU	MED17 4 4	✓	✓	✓	✓		
308 4 portes	automatic or piloted manual gearbox	BVA AM6 AT6 EURO5	✓	✓	✓	✓	✓	
308 4 portes	automatic or piloted manual gearbox	BVA AL4	✓	✓	✓	✓	✓	
308 4 portes	automatic or piloted manual gearbox	BVA AM6	✓	✓	✓	✓	✓	
308 4 portes	automatic or piloted manual gearbox	CFC300P	✓	✓	✓	✓	✓	
308 4 portes	automatic or piloted manual gearbox	BVA AM6 AT6 UDS	✓	✓	✓	✓		
308 4 portes	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS81	✓	✓	✓	✓	✓	S0039
308 4 portes	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81	✓	✓	✓	✓	✓	S0039 S0035
308 4 portes	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90	✓	✓	✓	✓		
308 4 portes	airbags and pretensioners ECU	SAC AUTOLIV	✓	✓	✓	✓		
308 4 portes	built-in systems interface	BSI	✓	✓	✓			
308 4 portes	power steering	GEP	✓	✓	✓	✓	✓	

308 4 portes	anti-theft alarm	ALARME	✓	✓	✓	✓	✓	
308 4 portes	anti-theft alarm	ALARME LIN	✓	✓	✓	✓	✓	
308 4 portes	instrument panel	COMBINE	✓	✓	✓	✓	✓	
308 4 portes	Control panel dot matrix display	MATT	✓	✓	✓	✓	✓	
308 4 portes	air conditioning	CLIM REGULEE	✓	✓	✓	✓	✓	
308 4 portes	UNDER-INFLATION DETECTION	DSG	✓	✓	✓	✓		
308 4 portes	UNDER-INFLATION DETECTION	DSG UDS	✓	✓	✓	✓		
308 4 portes	parking assistance	AAS	✓	✓	✓	✓		
308 4 portes	parking assistance	AAS UDS	✓	✓	✓			
308 4 portes	diesel fuel additive pump	PADDGO	✓	✓	✓	✓	✓	
308 4 portes	diesel fuel additive pump	PADDGO E5	✓	✓	✓	✓		
308 4 portes	diesel fuel additive pump	PADDGO TI E6	✓	✓	✓	✓		
308 4 portes	Dynamic headlamp height adjuster	LADCT	✓	✓	✓	✓	✓	
308 4 portes	battery charge status control unit	BECB	✓	✓	✓	✓		S003A
308 4 portes	battery charge status control unit	BECB GEN2	✓	✓	✓	✓		S003A
308 4 portes	lane wandering alert	AFIL	✓	✓	✓	✓	✓	
308 4 portes	engine wiring housing	BSM	✓	✓	✓	✓	✓	
308 4 portes	multifunction screen	EMF A	✓	✓	✓	✓	✓	
308 4 portes	multifunction screen	EMF C	✓	✓	✓	✓	✓	
308 4 portes	windscreen wiper	MOTEV	✓	✓	✓	✓		
308 4 portes	controls under the steering wheel	HDC	✓	✓	✓	✓	✓	
308 4 portes	CD changer / external CD player	CHANGEUR CD	✓	✓	✓			

308 4 portes	Telematic unit (RTx) or audio-navigation	RADIONAV RNEGC	✓	✓	✓	✓		
308 4 portes	Telematic unit (RTx) or audio-navigation	RADIONAV RNEG	✓	✓	✓	✓		
308 4 portes	Telematic unit (RTx) or audio-navigation	RADIONAV NG4	✓	✓	✓	✓		
308 4 portes	Telematic unit (RTx) or audio-navigation	BOITIER TELEMATIQUE	✓	✓	✓			
308 4 portes	Telematic unit (RTx) or audio-navigation	RADIONAV RNEG ECO	✓	✓	✓	✓		
308 4 portes	Telematic unit (RTx) or audio-navigation	RNEG2010	✓	✓	✓	✓		
308 4 portes	Telematic unit (RTx) or audio-navigation	SMEG PLUS	✓	✓	✓	✓		
308 4 portes	audio amplifier	AMPLI AUDIO	✓	✓	✓	✓		
308 4 portes	Hands-free Kit / Portable Unit	KML	✓	✓	✓	✓	✓	
308 4 portes	Hands-free Kit / Portable Unit	BOITIER NOMADE	✓	✓	✓	✓	✓	
308 4 portes	Seat driver position memory module.	BDMC	✓	✓	✓	✓	✓	
308 4 portes	Seat passenger position memory module.	BDMP	✓	✓	✓	✓	✓	
308 4 portes	driver's door module	PDPC	✓	✓	✓	✓	✓	
308 4 portes	sunroof	TOUV	✓	✓	✓	✓		
308 4 portes	Moving panel deflector	DEFL PAN MOBIL	✓	✓	✓	✓		
308 4 portes	Retractable roof	BTE	✓	✓	✓	✓		
308 4 portes	Service module / Independent telematic unit	MD SERV	✓	✓	✓	✓		
308 4 portes	Service module / Independent telematic unit	BTA	✓	✓	✓	✓		
308 4 portes	Independent telematic	BLVV	✓	✓	✓	✓		

308 4 portes	Service module / Independent telematic unit	BTA 3R	✓	✓	✓	✓		
308 4 portes	Service module / Independent telematic unit	BTA 3S	✓	✓	✓	✓		
308 4 portes	driving school module	MAE	✓	✓	✓			
308 4 portes	rain and sunlight sensor	PLUIE LUMINOSITE	✓	✓	✓			
308 4 portes	seat belt not fastened warning lights unit	TNB	✓					
308 (T9)	engine management ECU	HDI SID807 BR2	✓	✓	✓	✓	✓	
308 (T9)	engine management ECU	EDC17C10 BR2	✓	✓	✓	✓	✓	
308 (T9)	engine management ECU	MED17 4 2	✓	✓	✓	✓	✓	
308 (T9)	engine management ECU	V46	✓	✓	✓	✓		
308 (T9)	engine management ECU	V46 21	✓	✓	✓	✓		
308 (T9)	engine management ECU	EDC17C60	✓	✓	✓	✓		
308 (T9)	engine management ECU	VD46	✓	✓	✓	✓		
308 (T9)	engine management ECU	DCM62	✓	✓	✓	✓	✓	
308 (T9)	engine management ECU	V46 32	✓	✓	✓	✓		
308 (T9)	engine management ECU	MED17 4 4	✓	✓	✓	✓		
308 (T9)	engine management ECU	MEVD17 4 4	✓	✓	✓	✓		
308 (T9)	engine management ECU	V46 52	✓	✓	✓	✓		
308 (T9)	engine management ECU	CMM DCM71	✓	✓	✓	✓		
308 (T9)	engine management ECU	CMM MD1CS003	✓	✓	✓	✓		
308 (T9)	engine management ECU	CMM VD56	✓	✓	✓	✓		
308 (T9)	engine management ECU	CMM MG1CS042	✓	✓	✓	✓		
308 (T9)	automatic or piloted manual gearbox	BVA AM6 AT6 UDS	✓	✓	✓	✓		
308 (T9)	manual gearbox	BVA AXN8	✓	✓	✓	✓		
308 (T9)	manual gearbox	DCT 6DCT200	✓	✓	✓	✓		
308 (T9)	System (ABS) or	ESP90	✓	✓	✓	✓		S0039
308 (T9)	pretensioners ECU	RBG UDS	✓	✓	✓	✓		
308 (T9)	interface	BSI2010	✓	✓	✓	✓		
308 (T9)	interface	BSI2010 EV	✓	✓	✓			

308 (T9)	power steering	DAE BVH2	✓	✓	✓	✓		
308 (T9)	Electric steering lock	AVE	✓	✓	✓	✓		
308 (T9)	anti-theft alarm	MUS	✓	✓	✓	✓		
308 (T9)	Intrusion alarm siren	SIR	✓	✓	✓	✓		
308 (T9)	instrument panel	COMBINE UDS	✓	✓	✓	✓		
308 (T9)	matrix display	MATT C 2010	✓	✓	✓			
308 (T9)	matrix display	MATT M 2010	✓	✓	✓			
308 (T9)	Hands-free unit	BML	✓	✓	✓	✓		
308 (T9)	air conditioning	BCC	✓	✓	✓	✓		
308 (T9)	parking assistance	AAS UDS	✓	✓	✓	✓		
308 (T9)	diesel fuel additive pump	PADDGO INERGY	✓	✓	✓	✓		
308 (T9)	Voltage maintaining device	DMTC	✓					
308 (T9)	Voltage maintaining device	DMTR	✓	✓	✓			
308 (T9)	Voltage maintaining device	DMTR DTC3B	✓	✓	✓			
308 (T9)	Sequential gear lever	ESM	✓	✓	✓	✓		
308 (T9)	Dynamic headlamp height adjuster	LADCT	✓	✓	✓	✓	✓	
308 (T9)	engine wiring housing	BSM 2010	✓	✓	✓	✓		
308 (T9)	Trailer relay unit	BSG 2010 RQ	✓	✓	✓	✓		
308 (T9)	battery charge status control unit	BECB GEN2	✓	✓	✓	✓		
308 (T9)	supplies protection and management unit	BPGA2010	✓	✓	✓	✓		
308 (T9)	Electronic key reader	LCE	✓	✓	✓	✓		
308 (T9)	controls under the steering wheel	COM2008P	✓	✓	✓	✓		
308 (T9)	controls under the steering wheel	HDC	✓	✓	✓	✓	✓	

308 (T9)	Controls on the steering wheel / Integral controls steering wheel	VCI	✓	✓	✓	✓		
308 (T9)	Controls on the steering wheel / Integral controls steering wheel	VCI	✓	✓	✓	✓		
308 (T9)	Multifunction control panel	FMUX	✓	✓	✓	✓		
308 (T9)	seat belt not fastened warning lights unit	TNB 2010	✓					
308 (T9)	rain and sunlight sensor	CDPL UDS HELLA	✓	✓	✓	✓		
308 (T9)	Multifunction video camera (CMF)	CVM 2	✓	✓	✓	✓		
308 (T9)	Vehicle Distance Assistance	ARTIV UDS	✓	✓	✓	✓		
308 (T9)	multifunction screen	EMF A UDS	✓	✓	✓	✓		
308 (T9)	multifunction screen	EMF C UDS	✓	✓	✓	✓		
308 (T9)	touch screen	EMF DGT UDS	✓	✓	✓	✓		
308 (T9)	touch screen	EMF DGT UDS GP	✓	✓	✓	✓		
308 (T9)	or audio-navigation	SMEG PLUS	✓	✓	✓	✓	✓	
308 (T9)	Telematic unit (RTx) or audio-navigation	MRN	✓	✓	✓	✓		
308 (T9)	Telematic unit (RTx) or audio-navigation	NAC	✓	✓	✓	✓		
308 (T9)	Telematic unit (RTx) or audio-navigation	RCC	✓	✓	✓	✓		
308 (T9)	radio	RD45	✓	✓	✓	✓		
308 (T9)	radio	RD6	✓	✓	✓	✓		
308 (T9)	radio	RD6 CN	✓	✓	✓	✓		
308 (T9)	Control of the telematic unit	CRT UDS KOSTAL	✓	✓	✓	✓		

308 (T9)	Service module / Independent telematic unit	BTA	✓	✓	✓	✓		
308 (T9)	Service module / Independent telematic unit	BTA CN	✓	✓	✓	✓		
308 (T9)	Service module / Independent telematic unit	BTA 2	✓	✓	✓	✓		
308 (T9)	Service module / Independent telematic unit	BTA 3S	✓	✓	✓	✓		
308 (T9)	Service module / Independent telematic unit	BTA 3R	✓	✓	✓	✓		
308 (T9)	external CD player	CDE	✓	✓	✓	✓	✓	
308 (T9)	audio amplifier	AMPLI AUDIO	✓	✓	✓			
308 (T9)	driver's door module	PDPC	✓	✓	✓	✓		
308 (T9)	driver's door module	PDPC UDS	✓	✓	✓	✓		
308 (T9)	additional heating	CHAUFF ADD	✓	✓	✓	✓		
308 (T9)	memory module.	BDMC	✓	✓	✓	✓		
308S	engine management ECU	HDI SID807 BR2	✓	✓	✓	✓	✓	
308S	engine management ECU	EDC17C10 BR2	✓	✓	✓	✓	✓	
308S	engine management ECU	MED17 4 2	✓	✓	✓	✓	✓	
308S	engine management ECU	V46	✓	✓	✓	✓		
308S	engine management ECU	V46 21	✓	✓	✓	✓		
308S	engine management ECU	EDC17C60	✓	✓	✓	✓		
308S	engine management ECU	VD46	✓	✓	✓	✓		
308S	engine management ECU	DCM62	✓	✓	✓	✓	✓	
308S	engine management ECU	V46 32	✓	✓	✓	✓		
308S	engine management ECU	MED17 4 4	✓	✓	✓	✓		
308S	engine management ECU	MEVD17 4 4	✓	✓	✓	✓		
308S	engine management ECU	V46 52	✓	✓	✓	✓		
308S	engine management ECU	CMM DCM71	✓	✓	✓	✓		
308S	engine management ECU	CMM MD1CS003	✓	✓	✓	✓		

308S	engine management ECU	CMM VD56	✓	✓	✓	✓		
308S	engine management ECU	CMM MG1CS042	✓	✓	✓	✓		
308S	manual gearbox	BVA AM6 AT6 UDS	✓	✓	✓	✓		
308S	manual gearbox	BVA AXN8	✓	✓	✓	✓		
308S	manual gearbox	DCT 6DCT200	✓	✓	✓	✓		
308S	System (ABS) or	ESP90	✓	✓	✓	✓		S0039
308S	pretensioners ECU	RBG UDS	✓	✓	✓	✓		
308S	interface	BSI2010	✓	✓	✓	✓		
308S	built-in systems interface	BSI2010 EV	✓	✓	✓			
308S	power steering	DAE BVH2	✓	✓	✓	✓		
308S	Electric steering lock	AVE	✓	✓	✓	✓		
308S	anti-theft alarm	ALARME	✓	✓	✓	✓	✓	
308S	instrument panel	COMBINE UDS	✓	✓	✓	✓		
308S	Control panel dot matrix display	MATT C 2010	✓	✓	✓			
308S	Control panel dot matrix display	MATT M 2010	✓	✓	✓			
308S	Hands-free unit	BML	✓	✓	✓	✓		
308S	air conditioning	BCC	✓	✓	✓	✓		
308S	parking assistance	AAS UDS	✓	✓	✓	✓		
308S	Voltage maintaining device	DMTC	✓					
308S	Voltage maintaining device	DMTR	✓	✓	✓			
308S	Voltage maintaining device	DMTR DTC3B	✓	✓	✓			
308S	Dynamic headlamp height adjuster	LADCT	✓	✓	✓	✓	✓	
308S	engine wiring housing	BSM 2010	✓	✓	✓	✓		
308S	battery charge status control unit	BECB GEN2	✓	✓	✓	✓		
308S	supplies protection and management unit	BPGA2010	✓	✓	✓	✓		
308S	Electronic key reader	LCE	✓	✓	✓	✓		

308S	controls under the steering wheel	COM2008P	✓	✓	✓	✓		
308S	controls under the steering wheel	HDC	✓	✓	✓	✓	✓	
308S	Controls on the steering wheel / Integral controls steering wheel	VCI	✓	✓	✓	✓		
308S	Controls on the steering wheel / Integral controls steering wheel	VCI	✓	✓	✓	✓		
308S	Multifunction control panel	FMUX	✓	✓	✓	✓		
308S	rain and sunlight sensor	CDPL UDS HELLA	✓	✓	✓	✓		
308S	multifunction screen	EMF A UDS	✓	✓	✓	✓		
308S	multifunction screen	EMF C UDS	✓	✓	✓	✓		
308S	touch screen	EMF DGT UDS	✓	✓	✓	✓		
308S	touch screen	EMF DGT UDS GP	✓	✓	✓	✓		
308S	Telematic unit (RTx) or audio-navigation	SMEG PLUS	✓	✓	✓	✓	✓	
308S	Telematic unit (RTx) or audio-navigation	MRN	✓	✓	✓	✓		
308S	Telematic unit (RTx) or audio-navigation	NAC	✓	✓	✓	✓		
308S	Telematic unit (RTx) or audio-navigation	RCC	✓	✓	✓	✓		
308S	radio	RD45	✓	✓	✓	✓		
308S	radio	RD6	✓	✓	✓	✓		
308S	radio	RD6 CN	✓	✓	✓	✓		
308S	Control of the telematic unit	CRT UDS KOSTAL	✓	✓	✓	✓		

308S	Service module / Independent telematic unit	BTA	✓	✓	✓	✓		
308S	Service module / Independent telematic unit	BTA CN	✓	✓	✓	✓		
308S	Service module / Independent telematic unit	BTA 2	✓	✓	✓	✓		
308S	Service module / Independent telematic unit	BTA 3S	✓	✓	✓	✓		
308S	Service module / Independent telematic unit	BTA 3R	✓	✓	✓	✓		
308S	Seat driver position memory module.	BDMC	✓	✓	✓	✓		
???308 (TX9)	engine management ECU	VD46	✓	✓	✓	✓		
???308 (TX9)	engine management ECU	V46 52	✓	✓	✓	✓		
???308 (TX9)	engine management ECU	MED17 4 4	✓	✓	✓	✓		S0034
???308 (TX9)	engine management ECU	CMM VD56	✓	✓	✓	✓		
???308 (TX9)	automatic or piloted manual gearbox	BVA AM6 AT6 UDS	✓	✓	✓	✓		
???308 (TX9)	automatic or piloted manual gearbox	DCT 6DCT200	✓	✓	✓	✓		
???308 (TX9)	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90	✓	✓	✓	✓		S0035 S0039 S0038
???308 (TX9)	airbags and pretensioners ECU	RBG UDS	✓	✓	✓	✓		
???308 (TX9)	interface	BSI2010 EV	✓	✓	✓	✓		
???308 (TX9)	Electric steering lock	AVE	✓	✓	✓	✓		
???308 (TX9)	power steering	DAE BVH2	✓	✓	✓	✓		
???308 (TX9)	instrument panel	COMBINE UDS	✓	✓	✓	✓		

????308 (TX9)	Control panel dot matrix display	MATT C 2010	✓	✓	✓			
????308 (TX9)	air conditioning	BCC	✓	✓	✓	✓		
????308 (TX9)	parking assistance	AAS UDS	✓	✓	✓	✓		
????308 (TX9)	rain and sunlight sensor	CDPL UDS HELLA	✓	✓	✓	✓		
????308 (TX9)	navigation/telematic unit/connected audio	NAC	✓	✓	✓	✓		
????308 (TX9)	Service module / Independent telematic unit	BTA CN	✓	✓	✓	✓		
????308 (TX9)	panel	FMUX	✓	✓	✓	✓		
????308 (TX9)	steering wheel	COM2008P	✓	✓	✓	✓	✓	
????308 (TX9)	multifunction screen	EMF C UDS	✓	✓	✓	✓		
????308 (TX9)	control unit	BECB GEN2	✓	✓	✓	✓		S003A
????308 (TX9)	steering wheel /	VCI	✓	✓	✓	✓		
????308 (TX9)	radio	RD45	✓	✓	✓	✓	✓	
????308 (TX9)	device	DMTR DTC3B	✓	✓	✓			
????308 (TX9)	touch screen	EMF DGT UDS GP	✓	✓	✓	✓		
RCZ	engine management ECU	DCM35 BR2	✓	✓	✓	✓	✓	S0037 S0036
RCZ	engine management ECU	DCM34	✓	✓	✓	✓	✓	S0037 S0036
RCZ	engine management ECU	DCM35	✓	✓	✓	✓	✓	S0037 S0036
RCZ	engine management ECU	EDC16C3	✓	✓	✓	✓	✓	
RCZ	engine management ECU	MED17 4 EURO4	✓	✓	✓	✓	✓	S0034
RCZ	engine management ECU	MEV17 4 EURO4	✓	✓	✓	✓	✓	S0034
RCZ	engine management ECU	MM6LPB	✓	✓	✓	✓	✓	
RCZ	engine management ECU	ME745	✓	✓	✓	✓	✓	
RCZ	engine management ECU	ME749	✓	✓	✓	✓	✓	
RCZ	engine management ECU	ME749 EC5	✓	✓	✓	✓	✓	S0034
RCZ	engine management ECU	MM6KP	✓	✓	✓	✓	✓	S0034
RCZ	engine management ECU	MEV17 4 EURO5	✓	✓	✓	✓	✓	S0034
RCZ	engine management ECU	MED17 4 EURO5	✓	✓	✓	✓	✓	S0034
RCZ	engine management ECU	HDI SID807	✓	✓	✓	✓		
RCZ	engine management ECU	EDC17C10	✓	✓	✓	✓	✓	S0037 S0036
RCZ	engine management ECU	EDC17C10 BR2	✓	✓	✓	✓	✓	S0037 S0036

RCZ	engine management ECU	MEV17 4 2	✓	✓	✓	✓	✓	S0034
RCZ	engine management ECU	HDI SID807 BR2	✓	✓	✓	✓	✓	S0037
RCZ	engine management ECU	MEVD17 4 2	✓	✓	✓	✓	✓	S0034
RCZ	engine management ECU	MED17 4 2	✓	✓	✓	✓	✓	
RCZ	engine management ECU	ME745 EC5	✓	✓	✓	✓		
RCZ	engine management ECU	V46 21	✓	✓	✓	✓		
RCZ	engine management ECU	MED17 4 4	✓	✓	✓	✓		
RCZ	automatic or piloted manual gearbox	BVA AM6 AT6 EURO5	✓	✓	✓	✓	✓	
RCZ	automatic or piloted manual gearbox	BVA AL4	✓	✓	✓	✓	✓	
RCZ	automatic or piloted manual gearbox	BVA AM6	✓	✓	✓	✓	✓	
RCZ	automatic or piloted manual gearbox	CFC300P	✓	✓	✓	✓	✓	
RCZ	automatic or piloted manual gearbox	BVA AM6 AT6 UDS	✓	✓	✓	✓		
RCZ	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS81	✓	✓	✓	✓	✓	S0039
RCZ	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81	✓	✓	✓	✓	✓	S0039 S0035
RCZ	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90	✓	✓	✓	✓		
RCZ	pretensioners ECU	SAC AUTOLIV	✓	✓	✓	✓		
RCZ	built-in systems interface	BSI	✓	✓	✓			
RCZ	power steering	GEP	✓	✓	✓	✓	✓	
RCZ	anti-theft alarm	ALARME	✓	✓	✓	✓	✓	
RCZ	instrument panel	COMBINE	✓	✓	✓	✓	✓	

RCZ	Control panel dot matrix display	MATT	✓	✓	✓	✓	✓	
RCZ	air conditioning	CLIM REGULEE	✓	✓	✓	✓	✓	
RCZ	UNDER-INFLATION DETECTION	DSG	✓	✓	✓	✓		
RCZ	UNDER-INFLATION DETECTION	DSG UDS	✓	✓	✓	✓		
RCZ	parking assistance	AAS	✓	✓	✓	✓		
RCZ	parking assistance	AAS UDS	✓	✓	✓			
RCZ	Hands-free Kit / Portable Unit	KML	✓	✓	✓	✓	✓	
RCZ	Hands-free Kit / Portable Unit	BOITIER NOMADE	✓	✓	✓	✓	✓	
RCZ	Dynamic headlamp height adjuster	LADCT	✓	✓	✓	✓	✓	
RCZ	battery charge status control unit	BECB	✓	✓	✓	✓		S003A
RCZ	battery charge status control unit	BECB GEN2	✓	✓	✓	✓		S003A
RCZ	lane wandering alert	AFIL	✓	✓	✓	✓	✓	
RCZ	engine wiring housing	BSM	✓	✓	✓	✓	✓	
RCZ	Trailer relay unit	BSR	✓	✓	✓	✓	✓	
RCZ	multifunction screen	EMF A	✓	✓	✓	✓	✓	
RCZ	multifunction screen	EMF C	✓	✓	✓	✓	✓	
RCZ	windscreen wiper	MOTEV	✓	✓	✓	✓		
RCZ	controls under the steering wheel	HDC	✓	✓	✓	✓	✓	
RCZ	CD changer / external CD player	CHANGEUR CD	✓	✓	✓			
RCZ	Telematic unit (RTx) or audio-navigation	RADIONAV RNEGC	✓	✓	✓	✓		
RCZ	Telematic unit (RTx) or audio-navigation	RADIONAV RNEG	✓	✓	✓	✓		

RCZ	Telematic unit (RTx) or audio-navigation	RADIONAV NG4	✓	✓	✓	✓		
RCZ	Telematic unit (RTx) or audio-navigation	BOITIER TELEMATIQUE	✓	✓	✓			
RCZ	or audio-navigation	RADIONAV RNEG ECO	✓	✓	✓	✓		
RCZ	Telematic unit (RTx) or audio-navigation	RNEG2010	✓	✓	✓	✓		
RCZ	Telematic unit (RTx) or audio-navigation	SMEG PLUS	✓	✓	✓	✓		
RCZ	audio amplifier	AMPLI AUDIO	✓	✓	✓	✓		
RCZ	radio	RD43	✓	✓	✓	✓		
RCZ	radio	AUTORADIO	✓	✓	✓	✓	✓	
RCZ	radio	RD45	✓	✓	✓	✓	✓	
RCZ	Seat driver position memory module.	BDMC	✓	✓	✓	✓	✓	
RCZ	position memory	BDMP	✓	✓	✓	✓	✓	
RCZ	driver's door module	PDPC	✓	✓	✓	✓	✓	
RCZ	sunroof	TOUV	✓	✓	✓	✓		
RCZ	Moving panel deflector	DEFL PAN MOBIL	✓	✓	✓	✓		
RCZ	Retractable roof	BTE	✓	✓	✓	✓		
RCZ	Independent telematic	MD SERV	✓	✓	✓	✓		
RCZ	Independent telematic	BTA	✓	✓	✓	✓		
RCZ	Independent telematic	BLVV	✓	✓	✓	✓		
RCZ	Independent telematic	BTA 3R	✓	✓	✓	✓		
RCZ	Independent telematic	BTA 3S	✓	✓	✓	✓		
RCZ	sensor	PLUIE LUMINOSITE	✓	✓	✓			
RCZ	Detection Unit	DETECT CHOC PIETON	✓	✓	✓	✓		
RCZ	seat belt not fastened warning lights unit	TNB	✓					
RCZ	diesel fuel additive pump	PADDGO	✓	✓	✓	✓	✓	
RCZ	diesel fuel additive pump	PADDGO E5	✓	✓	✓	✓		
RCZ	diesel fuel additive pump	PADDGO TI E6	✓	✓	✓	✓		

RCZ	high frequency receiver	RHF	✓	✓	✓	✓		
RCZ	Voltage maintaining device	DMTC	✓					
RCZ	Voltage maintaining device	DMTR DTC3B	✓	✓	✓			
407	engine management ECU	ME747	✓	✓	✓	✓	✓	
407	engine management ECU	EDC16C3	✓	✓	✓	✓	✓	
407	engine management ECU	MM6LP	✓	✓	✓	✓	✓	
407	engine management ECU	S2000PM2	✓	✓	✓	✓	✓	
407	engine management ECU	SID201	✓	✓	✓	✓	✓	S0037
407	engine management ECU	HDI SID803	✓	✓	✓	✓	✓	
407	engine management ECU	HDI SID803A	✓	✓	✓	✓	✓	S0037
407	engine management ECU	MM6LPB	✓	✓	✓	✓	✓	
407	engine management ECU	DCM34	✓	✓	✓	✓	✓	S0037 S0036
407	engine management ECU	DCM35	✓	✓	✓	✓	✓	S0037 S0036
407	engine management ECU	EDC16CP39	✓	✓	✓	✓	✓	S0037
407	engine management ECU	MM6KP	✓	✓	✓	✓	✓	
407	engine management ECU	EDC17CP11	✓	✓	✓	✓	✓	S0037 S0036
407	engine management ECU	DCM35 BR2	✓	✓	✓	✓		
407	automatic or piloted manual gearbox	BVA AM6 AT6 EURO5	✓	✓	✓	✓	✓	
407	automatic or piloted manual gearbox	BVA AM6	✓	✓	✓	✓	✓	
407	automatic or piloted manual gearbox	BVA ZF	✓	✓	✓	✓	✓	
407	automatic or piloted manual gearbox	BVA AL4	✓	✓	✓	✓	✓	
407	automatic or piloted manual gearbox	BVA AL4	✓	✓	✓	✓		
407	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP EBC 440 CAN	✓	✓	✓	✓	✓	

407	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP EBC 440 K	✓	✓	✓	✓	✓	
407	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81	✓	✓	✓	✓	✓	S0035 S0039
407	airbags and pretensioners ECU	SAC AUTOLIV	✓	✓	✓	✓		
407	interface	BSI	✓	✓	✓	✓		S0033
407	power steering	GEP	✓	✓	✓	✓	✓	
407	anti-theft alarm	ALARME	✓	✓	✓	✓	✓	
407	instrument panel	COMBINE	✓	✓	✓	✓	✓	
407	air conditioning	CLIM REGULEE	✓	✓	✓	✓	✓	
407	UNDER-INFLATION DETECTION	DSG	✓	✓	✓	✓		
407	parking assistance	AAS	✓	✓	✓	✓	✓	
407	electronically managed suspension	CSS	✓	✓	✓	✓		
407	additional heating	CHAUFF ADD	✓	✓	✓	✓	✓	
407	diesel additive	ADDG03	✓	✓	✓	✓	✓	
407	Right-hand dynamic headlamp height adjuster	PROJECTEURD	✓	✓	✓	✓		
407	Left-hand dynamic headlamp height adjuster	PROJECTEURG	✓	✓	✓	✓		
407	Dynamic headlamp height adjuster	LAD	✓	✓	✓	✓		
407	Dynamic headlamp height adjuster	LADAFS	✓	✓	✓	✓		
407	battery charge status control unit	BECB	✓	✓	✓	✓		S003A

407	battery charge status control unit	BECB GEN2	✓	✓	✓	✓		S003A
407	Trailer relay unit	BSR	✓	✓	✓	✓		
407	engine wiring housing	BSM	✓	✓	✓	✓		
407	windscreen wiper	MOTEV	✓	✓	✓			
407	controls under the steering wheel	HDC	✓	✓	✓	✓	✓	
407	multifunction screen	EMF C	✓	✓	✓	✓		
407	radio	AUTORADIO	✓	✓	✓	✓	✓	
407	Hands-free Kit / Portable Unit	KML	✓	✓	✓	✓	✓	
407	Portable Unit	BOITIER NOMADE	✓	✓	✓	✓	✓	
407	CD player	CHANGEUR CD	✓	✓	✓			
407	Telematic unit (RTx) or audio-navigation	RADIONAV RNEG	✓	✓	✓	✓		
407	Telematic unit (RTx) or audio-navigation	BOITIER TELEMATIQUE	✓	✓	✓	✓	✓	
407	Seat passenger position memory module.	BDMP	✓	✓	✓	✓	✓	
407	Seat driver position memory module.	BDMC	✓	✓	✓	✓	✓	
407	driver's door module	EDPC	✓	✓	✓	✓	✓	
407	passenger door module	EDPP	✓	✓	✓	✓	✓	
407	sunroof	TOUV	✓	✓	✓	✓		
407	receiver	RHF	✓	✓	✓	✓		
407	sensor	PLUIE LUMINOSITE	✓	✓	✓			
407	Boot relay unit	BSC	✓	✓	✓	✓		
408 (T73)	engine management ECU	DCM35 BR2	✓	✓	✓	✓	✓	S0037 S0036
408 (T73)	engine management ECU	DCM34	✓	✓	✓	✓	✓	S0037 S0036
408 (T73)	engine management ECU	DCM35	✓	✓	✓	✓	✓	S0037 S0036
408 (T73)	engine management ECU	EDC16C3	✓	✓	✓	✓	✓	
408 (T73)	engine management ECU	MED17 4 EURO4	✓	✓	✓	✓	✓	S0034

408 (T73)	engine management ECU	MEV17 4 EURO4	✓	✓	✓	✓	✓	S0034
408 (T73)	engine management ECU	MM6LPB	✓	✓	✓	✓	✓	
408 (T73)	engine management ECU	ME745	✓	✓	✓	✓	✓	
408 (T73)	engine management ECU	ME749	✓	✓	✓	✓	✓	
408 (T73)	engine management ECU	ME749 EC5	✓	✓	✓	✓	✓	S0034
408 (T73)	engine management ECU	MM6KP	✓	✓	✓	✓	✓	S0034
408 (T73)	engine management ECU	MEV17 4 EURO5	✓	✓	✓	✓	✓	S0034
408 (T73)	engine management ECU	MED17 4 EURO5	✓	✓	✓	✓	✓	S0034
408 (T73)	engine management ECU	HDI SID807	✓	✓	✓	✓		
408 (T73)	engine management ECU	EDC17C10	✓	✓	✓	✓	✓	S0037 S0036
408 (T73)	engine management ECU	EDC17C10 BR2	✓	✓	✓	✓	✓	S0037 S0036
408 (T73)	engine management ECU	MEV17 4 2	✓	✓	✓	✓	✓	S0034
408 (T73)	engine management ECU	HDI SID807 BR2	✓	✓	✓	✓	✓	S0037
408 (T73)	engine management ECU	MEVD17 4 2	✓	✓	✓	✓	✓	S0034
408 (T73)	engine management ECU	MED17 4 2	✓	✓	✓	✓	✓	
408 (T73)	engine management ECU	ME745 EC5	✓	✓	✓	✓		
408 (T73)	engine management ECU	V46 21	✓	✓	✓	✓		
408 (T73)	engine management ECU	MED17 4 4	✓	✓	✓	✓		
408 (T73)	automatic or piloted manual gearbox	BVA AM6 AT6 EURO5	✓	✓	✓	✓	✓	
408 (T73)	automatic or piloted manual gearbox	BVA AL4	✓	✓	✓	✓	✓	
408 (T73)	manual gearbox	BVA AM6	✓	✓	✓	✓	✓	
408 (T73)	automatic or piloted manual gearbox	CFC300P	✓	✓	✓	✓	✓	
408 (T73)	automatic or piloted manual gearbox	BVA AM6 AT6 UDS	✓	✓	✓	✓		
408 (T73)	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS81	✓	✓	✓	✓	✓	S0039
408 (T73)	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81	✓	✓	✓	✓	✓	S0039 S0035

408 (T73)	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90	✓	✓	✓	✓		
408 (T73)	airbags and pretensioners ECU	SAC AUTOLIV	✓	✓	✓	✓		
408 (T73)	built-in systems interface	BSI	✓	✓	✓			
408 (T73)	power steering	GEP	✓	✓	✓	✓	✓	
408 (T73)	anti-theft alarm	ALARME	✓	✓	✓	✓	✓	
408 (T73)	anti-theft alarm	ALARME LIN	✓	✓	✓	✓	✓	
408 (T73)	instrument panel	COMBINE	✓	✓	✓	✓	✓	
408 (T73)	air conditioning	CLIM REGULEE	✓	✓	✓	✓	✓	
408 (T73)	UNDER-INFLATION DETECTION	DSG	✓	✓	✓	✓		
408 (T73)	UNDER-INFLATION DETECTION	DSG UDS	✓	✓	✓	✓		
408 (T73)	parking assistance	AAS	✓	✓	✓	✓		
408 (T73)	parking assistance	AAS UDS	✓	✓	✓			
408 (T73)	diesel fuel additive pump	PADDGO	✓	✓	✓	✓	✓	
408 (T73)	diesel fuel additive pump	PADDGO E5	✓	✓	✓	✓		
408 (T73)	diesel fuel additive pump	PADDGO TI E6	✓	✓	✓	✓		
408 (T73)	Dynamic headlamp height adjuster	LADCT	✓	✓	✓	✓	✓	
408 (T73)	battery charge status control unit	BECEB	✓	✓	✓	✓		S003A
408 (T73)	control unit	BECEB GEN2	✓	✓	✓	✓		S003A
408 (T73)	lane wandering alert	AFIL	✓	✓	✓	✓	✓	
408 (T73)	engine wiring housing	BSM	✓	✓	✓	✓	✓	
408 (T73)	Trailer relay unit	BSR	✓	✓	✓	✓	✓	
408 (T73)	multifunction screen	EMF A	✓	✓	✓	✓	✓	

408 (T73)	multifunction screen	EMF C	✓	✓	✓	✓	✓	
408 (T73)	windscreen wiper	MOTEV	✓	✓	✓	✓		
408 (T73)	controls under the steering wheel	HDC	✓	✓	✓	✓	✓	
408 (T73)	CD changer / external CD player	CHANGEUR CD	✓	✓	✓			
408 (T73)	Telematic unit (RTx) or audio-navigation	RADIONAV RNEGC	✓	✓	✓	✓		
408 (T73)	Telematic unit (RTx) or audio-navigation	RADIONAV RNEG	✓	✓	✓	✓		
408 (T73)	Telematic unit (RTx) or audio-navigation	RADIONAV NG4	✓	✓	✓	✓		
408 (T73)	Telematic unit (RTx) or audio-navigation	BOITIER TELEMATIQUE	✓	✓	✓			
408 (T73)	Telematic unit (RTx) or audio-navigation	RADIONAV RNEG ECO	✓	✓	✓	✓		
408 (T73)	Telematic unit (RTx) or audio-navigation	RNEG2010	✓	✓	✓	✓		
408 (T73)	or audio-navigation	SMEG PLUS	✓	✓	✓	✓		
408 (T73)	audio amplifier	AMPLI AUDIO	✓	✓	✓	✓		
408 (T73)	Hands-free Kit / Portable Unit	KML	✓	✓	✓	✓	✓	
408 (T73)	Portable Unit	BOITIER NOMADE	✓	✓	✓	✓	✓	
408 (T73)	radio	RD43	✓	✓	✓	✓		
408 (T73)	radio	AUTORADIO	✓	✓	✓	✓	✓	
408 (T73)	radio	RD45	✓	✓	✓	✓	✓	
408 (T73)	memory module.	BDMC	✓	✓	✓	✓	✓	
408 (T73)	position memory	BDMP	✓	✓	✓	✓	✓	
408 (T73)	driver's door module	PDPC	✓	✓	✓	✓	✓	
408 (T73)	sunroof	TOUV	✓	✓	✓	✓		
408 (T73)	Moving panel deflector	DEFL PAN MOBIL	✓	✓	✓	✓		
408 (T73)	Retractable roof	BTE	✓	✓	✓	✓		
408 (T73)	Independent telematic	MD SERV	✓	✓	✓	✓		
408 (T73)	Independent telematic	BTA	✓	✓	✓	✓		

408 (T73)	Service module / Independent telematic unit	BLVV	✓	✓	✓	✓		
408 (T73)	Service module / Independent telematic unit	BTA 3R	✓	✓	✓	✓		
408 (T73)	Service module / Independent telematic unit	BTA 3S	✓	✓	✓	✓		
408 (T73)	rain and sunlight sensor	PLUIE LUMINOSITE	✓	✓	✓			
408 (T73)	seat belt not fastened warning lights unit	TNB	✓					
408 (T73)	high frequency receiver	RHF	✓	✓	✓	✓		
408 (T93)	engine management ECU	HDI SID807 BR2	✓	✓	✓	✓	✓	
408 (T93)	engine management ECU	EDC17C10 BR2	✓	✓	✓	✓	✓	
408 (T93)	engine management ECU	MED17 4 2	✓	✓	✓	✓	✓	
408 (T93)	engine management ECU	V46	✓	✓	✓	✓		
408 (T93)	engine management ECU	V46 21	✓	✓	✓	✓		
408 (T93)	engine management ECU	EDC17C60	✓	✓	✓	✓		
408 (T93)	engine management ECU	VD46	✓	✓	✓	✓		
408 (T93)	engine management ECU	DCM62	✓	✓	✓	✓	✓	
408 (T93)	engine management ECU	V46 32	✓	✓	✓	✓		
408 (T93)	engine management ECU	MED17 4 4	✓	✓	✓	✓		
408 (T93)	engine management ECU	MEVD17 4 4	✓	✓	✓	✓		
408 (T93)	engine management ECU	V46 52	✓	✓	✓	✓		
408 (T93)	engine management ECU	CMM DCM71	✓	✓	✓	✓		
408 (T93)	engine management ECU	CMM MD1CS003	✓	✓	✓	✓		
408 (T93)	engine management ECU	CMM VD56	✓	✓	✓	✓		
408 (T93)	engine management ECU	CMM MG1CS042	✓	✓	✓	✓		
408 (T93)	automatic or piloted manual gearbox	BVA AM6 AT6 UDS	✓	✓	✓	✓		
408 (T93)	automatic or piloted manual gearbox	BVA AXN8	✓	✓	✓	✓		

408 (T93)	automatic or piloted manual gearbox	DCT 6DCT200	✓	✓	✓	✓		
408 (T93)	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90	✓	✓	✓	✓		S0035 S0038 S0039
408 (T93)	airbags and pretensioners ECU	RBG UDS	✓	✓	✓	✓		
408 (T93)	built-in systems interface	BSI2010	✓	✓	✓	✓		
408 (T93)	built-in systems interface	BSI2010 EV	✓	✓	✓			
408 (T93)	power steering	DAE BVH2	✓	✓	✓	✓		
408 (T93)	Electric steering lock	AVE	✓	✓	✓	✓		
408 (T93)	anti-theft alarm	ALARME	✓	✓	✓	✓	✓	
408 (T93)	instrument panel	COMBINE UDS	✓	✓	✓	✓		
408 (T93)	Control panel dot matrix display	MATT C 2010	✓	✓	✓			
408 (T93)	Control panel dot matrix display	MATT M 2010	✓	✓	✓			
408 (T93)	Hands-free unit	BML	✓	✓	✓	✓		
408 (T93)	air conditioning	BCC	✓	✓	✓	✓		
408 (T93)	parking assistance	AAS UDS	✓	✓	✓	✓		
408 (T93)	device	DMTC	✓					
408 (T93)	Voltage maintaining device	DMTR	✓	✓	✓			
408 (T93)	Voltage maintaining device	DMTR DTC3B	✓	✓	✓			
408 (T93)	Dynamic headlamp height adjuster	LADCT	✓	✓	✓	✓	✓	
408 (T93)	engine wiring housing	BSM 2010	✓	✓	✓	✓		
408 (T93)	battery charge status control unit	BECB GEN2	✓	✓	✓	✓		
408 (T93)	supplies protection and management unit	BPGA2010	✓	✓	✓	✓		

408 (T93)	Electronic key reader	LCE	✓	✓	✓	✓		
408 (T93)	controls under the steering wheel	COM2008P	✓	✓	✓	✓		
408 (T93)	controls under the steering wheel	HDC	✓	✓	✓	✓	✓	
408 (T93)	Controls on the steering wheel / Integral controls steering wheel	VCI	✓	✓	✓	✓		
408 (T93)	steering wheel / Integral controls	VCI	✓	✓	✓	✓		
408 (T93)	Multifunction control panel	FMUX	✓	✓	✓	✓		
408 (T93)	rain and sunlight sensor	CDPL UDS HELLA	✓	✓	✓	✓		
408 (T93)	Panoramic visual assistance ECU	AVP	✓	✓	✓	✓		
408 (T93)	multifunction screen	EMF A UDS	✓	✓	✓	✓		
408 (T93)	multifunction screen	EMF C UDS	✓	✓	✓	✓		
408 (T93)	touch screen	EMF DGT UDS	✓	✓	✓	✓		
408 (T93)	touch screen	EMF DGT UDS GP	✓	✓	✓	✓		
408 (T93)	Telematic unit (RTx) or audio-navigation	SMEG PLUS	✓	✓	✓	✓	✓	
408 (T93)	Telematic unit (RTx) or audio-navigation	MRN	✓	✓	✓	✓		
408 (T93)	Telematic unit (RTx) or audio-navigation	NAC	✓	✓	✓	✓		
408 (T93)	Telematic unit (RTx) or audio-navigation	RCC	✓	✓	✓	✓		
408 (T93)	radio	RD45	✓	✓	✓	✓		
408 (T93)	radio	RD6	✓	✓	✓	✓		
408 (T93)	radio	RD6 CN	✓	✓	✓	✓		
408 (T93)	Control of the telematic unit	CRT UDS KOSTAL	✓	✓	✓	✓		

408 (T93)	Service module / Independent telematic unit	BTA	✓	✓	✓	✓		
408 (T93)	Service module / Independent telematic unit	BTA CN	✓	✓	✓	✓		
408 (T93)	Service module / Independent telematic unit	BTA 2	✓	✓	✓	✓		
408 (T93)	Independent telematic	BTA 3S	✓	✓	✓	✓		
408 (T93)	Independent telematic	BTA 3R	✓	✓	✓	✓		
408 (T93)	driver's door module	PDPC	✓	✓	✓	✓		
408 (T93)	driver's door module	PDPC UDS	✓	✓	✓	✓		
408 (T93)	memory module.	BDMC	✓	✓	✓	✓		
508	engine management ECU	DCM35 BR2	✓	✓	✓	✓	✓	
508	engine management ECU	DCM34 P	✓	✓	✓	✓	✓	S0037 S0036
508	engine management ECU	HDI SID807 BR2	✓	✓	✓	✓	✓	S0037
508	engine management ECU	MED17 4 2	✓	✓	✓	✓	✓	S0034
508	engine management ECU	MEV17 4 2	✓	✓	✓	✓	✓	S0034
508	engine management ECU	EDC17CP42	✓	✓	✓	✓	✓	S0037
508	engine management ECU	MM6KP	✓	✓	✓	✓	✓	S0034
508	engine management ECU	DCM35 HY	✓	✓	✓	✓	✓	S0037 S0036
508	engine management ECU	DCM62	✓	✓	✓	✓		
508	engine management ECU	MED17 4 4	✓	✓	✓	✓		S0034
508	engine management ECU	MED17 4 4 EP8	✓	✓	✓	✓		
508	engine management ECU	EDC17C60	✓	✓	✓	✓		
508	automatic or piloted manual gearbox	BVA AM6 AT6 EURO5	✓	✓	✓	✓	✓	
508	automatic or piloted manual gearbox	CFC300P HY	✓	✓	✓	✓		
508	automatic or piloted manual gearbox	BVA AM6 AT6 UDS	✓	✓	✓	✓		
508	automatic or piloted manual gearbox	CFC300P	✓	✓	✓	✓	✓	
508	System (ABS) or	ABS81	✓	✓	✓	✓	✓	S0039 S0035

508	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81	✓	✓	✓	✓	✓	S0039 S0035 S0038
508	airbags and pretensioners ECU	RBG UDS	✓	✓	✓	✓		
508	built-in systems interface	BSI2010	✓	✓	✓			S0033
508	power steering	GEP	✓	✓	✓	✓	✓	
508	Electric steering lock	AVE	✓	✓	✓	✓		
508	anti-theft alarm	ALARME	✓	✓	✓	✓	✓	
508	instrument panel	COMBINE UDS	✓	✓	✓	✓	✓	
508	Control panel dot matrix display	MATT C 2010	✓	✓	✓			
508	Control panel dot matrix display	MATT M 2010	✓	✓	✓			
508	Control panel dot matrix display	MATT P 2010	✓	✓	✓			
508	Hands-free unit	BML	✓	✓	✓	✓		
508	air conditioning	CLIM REGULEE UDS	✓	✓	✓	✓	✓	
508	rear air conditioning	CLIM AR	✓			✓		
508	UNDER-INFLATION DETECTION	DSG	✓	✓	✓	✓		
508	UNDER-INFLATION DETECTION	DSG UDS	✓	✓	✓	✓		
508	parking assistance	AAS UDS	✓	✓	✓	✓		
508	active damper electronic unit	BEBA	✓	✓	✓	✓		
508	battery charge status control unit	BECB GEN2	✓	✓	✓	✓		
508	Electric secondary brake	FSE	✓	✓	✓	✓		S0038
508	Dynamic headlamp height adjuster	LADCT	✓	✓	✓	✓	✓	
508	height adjuster	BEMP	✓	✓	✓			

508	additional heating	CHAUFF ADD	✓	✓	✓	✓		
508	engine wiring housing	BSM 2010	✓	✓	✓	✓		
508	Trailer relay unit	BSG 2010 RQ	✓	✓	✓	✓		
508	multifunction screen	EMF A UDS	✓	✓	✓	✓		
508	multifunction screen	EMF C UDS	✓	✓	✓	✓		
508	touch screen	EMF DGT LVDS BD	✓	✓	✓	✓		
508	or audio-navigation	RNEG2010	✓	✓	✓	✓	✓	
508	Telematic unit (RTx) or audio-navigation	MRN	✓	✓	✓	✓		
508	Telematic unit (RTx) or audio-navigation	SMEG PLUS	✓	✓	✓	✓		
508	Telematic unit (RTx) or audio-navigation	NAC	✓	✓	✓	✓		
508	Independent telematic	BTA	✓	✓	✓	✓		
508	Service module / Independent telematic unit	BTA 2	✓	✓	✓	✓		
508	Service module / Independent telematic unit	BTA 3R	✓	✓	✓	✓		
508	Service module / Independent telematic unit	BTA 3S	✓	✓	✓	✓		
508	panel	FMUX	✓	✓	✓	✓		
508	radio	RD5	✓	✓	✓	✓	✓	
508	separate control pad	CRT UDS	✓			✓		
508	audio amplifier	AMPLI AUDIO	✓	✓	✓	✓		
508	steering wheel	COM2008P	✓	✓	✓	✓	✓	
508	warning lights unit	TNB 2010	✓					
508	supplies protection and management unit	BPGA2010	✓	✓	✓	✓		
508	Controls on the steering wheel / Integral controls steering wheel	VCI	✓	✓	✓	✓		

508	rain and sunlight sensor	PLUIE LUMINOSITE UDS	✓	✓	✓	✓		
508	Motorised Boot Unit	COFFRE MOTORISE	✓	✓	✓	✓		
508	Seat driver position memory module.	BDMC	✓	✓	✓	✓		
508	driver's door module	PDPC	✓	✓	✓	✓	✓	
508	Voltage maintaining device	DMTC	✓					
508	Voltage maintaining device	DMTR	✓	✓	✓			
508	Voltage maintaining device	DMTR DTC3B	✓	✓	✓			
508	Electronic key reader	LCE	✓	✓	✓	✓		
508	Head Up Display	VTH UDS	✓	✓	✓	✓		
508	Main beams assistant ECU	RETRO INT	✓	✓	✓	✓		
508	front left wiper motor	MOTEV UDS	✓	✓	✓	✓		
508	front left wiper motor	ESV G	✓	✓	✓	✓		
508	front right wiper motor	MOTED UDS	✓	✓	✓	✓		
508	front right wiper motor	ESV D	✓	✓	✓	✓		
508	external CD player	CDE	✓	✓	✓	✓		
508 HYbrid4	engine management ECU	DCM35 BR2	✓	✓	✓	✓	✓	
508 HYbrid4	engine management ECU	DCM34 P	✓	✓	✓	✓	✓	S0037 S0036
508 HYbrid4	engine management ECU	HDI SID807 BR2	✓	✓	✓	✓	✓	S0037
508 HYbrid4	engine management ECU	MED17 4 2	✓	✓	✓	✓	✓	S0034
508 HYbrid4	engine management ECU	MEV17 4 2	✓	✓	✓	✓	✓	S0034
508 HYbrid4	engine management ECU	EDC17CP42	✓	✓	✓	✓	✓	S0037
508 HYbrid4	engine management ECU	MM6KP	✓	✓	✓	✓	✓	S0034
508 HYbrid4	engine management ECU	DCM35 HY	✓	✓	✓	✓	✓	S0037 S0036
508 HYbrid4	engine management ECU	DCM62	✓	✓	✓	✓		
508 HYbrid4	engine management ECU	MED17 4 4	✓	✓	✓	✓		S0034
508 HYbrid4	engine management ECU	MED17 4 4 EP8	✓	✓	✓	✓		
508 HYbrid4	engine management ECU	EDC17C60	✓	✓	✓	✓		

508 HYbrid4	hybrid control ECU 1	HCU1	✓	✓	✓	✓		
508 HYbrid4	hybrid control ECU 2	HCU2	✓	✓	✓	✓		
508 HYbrid4	traction battery ECU	TBMU	✓	✓	✓	✓		
508 HYbrid4	automatic or piloted manual gearbox	BVA AM6 AT6 EURO5	✓	✓	✓	✓	✓	
508 HYbrid4	automatic or piloted manual gearbox	CFC300P HY	✓	✓	✓	✓		
508 HYbrid4	automatic or piloted manual gearbox	BVA AM6 AT6 UDS	✓	✓	✓	✓		
508 HYbrid4	automatic or piloted manual gearbox	CFC300P	✓	✓	✓	✓	✓	
508 HYbrid4	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS81	✓	✓	✓	✓	✓	S0039 S0035
508 HYbrid4	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81	✓	✓	✓	✓	✓	S0039 S0035 S0038
508 HYbrid4	airbags and pretensioners ECU	RBG UDS	✓	✓	✓	✓		
508 HYbrid4	built-in systems interface	BSI2010	✓	✓	✓			S0033
508 HYbrid4	power steering	GEP	✓	✓	✓	✓	✓	
508 HYbrid4	Electric steering lock	AVE	✓	✓	✓	✓		
508 HYbrid4	anti-theft alarm	ALARME	✓	✓	✓	✓	✓	
508 HYbrid4	instrument panel	COMBINE UDS	✓	✓	✓	✓	✓	
508 HYbrid4	Control panel dot matrix display	MATT C 2010	✓	✓	✓			
508 HYbrid4	Control panel dot matrix display	MATT M 2010	✓	✓	✓			
508 HYbrid4	Control panel dot matrix display	MATT P 2010	✓	✓	✓			
508 HYbrid4	Hands-free unit	BML	✓	✓	✓	✓		
508 HYbrid4	air conditioning	CLIM REGULEE UDS	✓	✓	✓	✓	✓	

508 HYbrid4	rear air conditioning	CLIM AR	✓			✓		
508 HYbrid4	UNDER-INFLATION DETECTION	DSG	✓	✓	✓	✓		
508 HYbrid4	UNDER-INFLATION DETECTION	DSG UDS	✓	✓	✓	✓		
508 HYbrid4	parking assistance	AAS UDS	✓	✓	✓	✓		
508 HYbrid4	Hybrid mode selector	MCM	✓			✓		
508 HYbrid4	Electric secondary brake	FSE	✓	✓	✓	✓		S0038
508 HYbrid4	battery charge status control unit	BECB GEN2	✓	✓	✓	✓		
508 HYbrid4	Dynamic headlamp height adjuster	LADCT	✓	✓	✓	✓	✓	
508 HYbrid4	Dynamic headlamp height adjuster	BEMP	✓	✓	✓			
508 HYbrid4	additional heating	CHAUFF ADD	✓	✓	✓	✓		
508 HYbrid4	engine wiring housing	BSM 2010	✓	✓	✓	✓		
508 HYbrid4	Trailer relay unit	BSG 2010 RQ	✓	✓	✓	✓		
508 HYbrid4	multifunction screen	EMF A UDS	✓	✓	✓	✓		
508 HYbrid4	multifunction screen	EMF C UDS	✓	✓	✓	✓		
508 HYbrid4	Service module / Independent telematic unit	BTA	✓	✓	✓	✓		
508 HYbrid4	Service module / Independent telematic unit	BTA 2	✓	✓	✓	✓		
508 HYbrid4	Service module / Independent telematic unit	BTA 3R	✓	✓	✓	✓		
508 HYbrid4	Independent telematic	BTA 3S	✓	✓	✓	✓		
508 HYbrid4	Electronic key reader	LCE	✓	✓	✓	✓		
508 HYbrid4	memory module.	BDMC	✓	✓	✓	✓		
508 HYbrid4	or audio-navigation	RNEG2010	✓	✓	✓	✓	✓	
508 HYbrid4	Telematic unit (RTx) or audio-navigation	MRN	✓	✓	✓	✓		

508 HYbrid4	Telematic unit (RTx) or audio-navigation	SMEG PLUS	✓	✓	✓	✓		
508 HYbrid4	Telematic unit (RTx) or audio-navigation	NAC	✓	✓	✓	✓		
508 HYbrid4	Multifunction control panel	FMUX	✓	✓	✓	✓		
508 HYbrid4	radio	RD5	✓	✓	✓	✓	✓	
508 HYbrid4	Telematic navigator / separate control pad	CRT UDS	✓			✓		
508 HYbrid4	audio amplifier	AMPLI AUDIO	✓	✓	✓	✓		
508 HYbrid4	seat belt not fastened warning lights unit	TNB 2010	✓					
508 HYbrid4	rain and sunlight sensor	PLUIE LUMINOSITE UDS	✓	✓	✓	✓		
508 HYbrid4	supplies protection and management unit	BPGA2010	✓	✓	✓	✓		
508 HYbrid4	front right wiper motor	MOTED UDS	✓	✓	✓	✓		
508 HYbrid4	front right wiper motor	ESV D	✓	✓	✓	✓		
508 HYbrid4	front left wiper motor	MOTEV UDS	✓	✓	✓	✓		
508 HYbrid4	front left wiper motor	ESV G	✓	✓	✓	✓		
508 HYbrid4	Controls on the steering wheel / Integral controls steering wheel	VCI	✓	✓	✓	✓		
508 HYbrid4	Main beams assistant ECU	RETRO INT	✓	✓	✓	✓		
508 HYbrid4	Head Up Display	VTH UDS	✓	✓	✓	✓		
508 HYbrid4	driver's door module	PDPC	✓	✓	✓	✓	✓	
508 HYbrid4	controls under the steering wheel	COM2008P	✓	✓	✓	✓	✓	
508 HYbrid4	external CD player	CDE	✓	✓	✓	✓		
508 RXH	engine management ECU	DCM35 BR2	✓	✓	✓	✓	✓	
508 RXH	engine management ECU	DCM34 P	✓	✓	✓	✓	✓	S0037 S0036

508 RXH	engine management ECU	HDI SID807 BR2	✓	✓	✓	✓	✓	S0037
508 RXH	engine management ECU	MED17 4 2	✓	✓	✓	✓	✓	S0034
508 RXH	engine management ECU	MEV17 4 2	✓	✓	✓	✓	✓	S0034
508 RXH	engine management ECU	EDC17CP42	✓	✓	✓	✓	✓	S0037
508 RXH	engine management ECU	MM6KP	✓	✓	✓	✓	✓	S0034
508 RXH	engine management ECU	DCM35 HY	✓	✓	✓	✓	✓	S0037 S0036
508 RXH	engine management ECU	DCM62	✓	✓	✓	✓		
508 RXH	engine management ECU	MED17 4 4	✓	✓	✓	✓		S0034
508 RXH	engine management ECU	MED17 4 4 EP8	✓	✓	✓	✓		
508 RXH	engine management ECU	EDC17C60	✓	✓	✓	✓		
508 RXH	automatic or piloted manual gearbox	BVA AM6 AT6 EURO5	✓	✓	✓	✓	✓	
508 RXH	automatic or piloted manual gearbox	CFC300P HY	✓	✓	✓	✓		
508 RXH	automatic or piloted manual gearbox	BVA AM6 AT6 UDS	✓	✓	✓	✓		
508 RXH	automatic or piloted manual gearbox	CFC300P	✓	✓	✓	✓	✓	
508 RXH	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS81	✓	✓	✓	✓	✓	S0039 S0035
508 RXH	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81	✓	✓	✓	✓	✓	S0039 S0035 S0038
508 RXH	airbags and pretensioners ECU	RBG UDS	✓	✓	✓	✓		
508 RXH	built-in systems interface	BSI2010	✓	✓	✓			S0033
508 RXH	Electric steering lock	AVE	✓	✓	✓	✓		
508 RXH	power steering	GEP	✓	✓	✓	✓	✓	
508 RXH	anti-theft alarm	ALARME	✓	✓	✓	✓	✓	
508 RXH	instrument panel	COMBINE UDS	✓	✓	✓	✓	✓	
508 RXH	matrix display	MATT C 2010	✓	✓	✓			

508 RXH	Control panel dot matrix display	MATT M 2010	✓	✓	✓			
508 RXH	Control panel dot matrix display	MATT P 2010	✓	✓	✓			
508 RXH	Hands-free unit	BML	✓	✓	✓	✓		
508 RXH	air conditioning	CLIM REGULEE UDS	✓	✓	✓	✓	✓	
508 RXH	rear air conditioning	CLIM AR	✓			✓		
508 RXH	UNDER-INFLATION DETECTION	DSG	✓	✓	✓	✓		
508 RXH	UNDER-INFLATION DETECTION	DSG UDS	✓	✓	✓	✓		
508 RXH	parking assistance	AAS UDS	✓	✓	✓	✓		
508 RXH	Telematic unit (RTx) or audio-navigation	RNEG2010	✓	✓	✓	✓	✓	
508 RXH	Telematic unit (RTx) or audio-navigation	MRN	✓	✓	✓	✓		
508 RXH	Telematic unit (RTx) or audio-navigation	SMEG PLUS	✓	✓	✓	✓		
508 RXH	Telematic unit (RTx) or audio-navigation	NAC	✓	✓	✓	✓		
508 RXH	Dynamic headlamp height adjuster	LADCT	✓	✓	✓	✓	✓	
508 RXH	Dynamic headlamp height adjuster	BEMP	✓	✓	✓			
508 RXH	additional heating	CHAUFF ADD	✓	✓	✓	✓		
508 RXH	panel	FMUX	✓	✓	✓	✓		
508 RXH	device	DMTC	✓					
508 RXH	Voltage maintaining device	DMTR	✓	✓	✓			
508 RXH	Voltage maintaining device	DMTR DTC3B	✓	✓	✓			
508 RXH	Electronic key reader	LCE	✓	✓	✓	✓		
508 RXH	driver's door module	PDPC	✓	✓	✓	✓	✓	
508 RXH	Motorised Boot Unit	COFFRE MOTORISE	✓	✓	✓	✓		

508 RXH	supplies protection and management unit	BPGA2010	✓	✓	✓	✓		
508 RXH	Trailer relay unit	BSG 2010 RQ	✓	✓	✓	✓		
508 RXH	rain and sunlight sensor	PLUIE LUMINOSITE UDS	✓	✓	✓	✓		
508 RXH	controls under the steering wheel	COM2008P	✓	✓	✓	✓	✓	
508 RXH	front left wiper motor	MOTEV UDS	✓	✓	✓	✓		
508 RXH	front left wiper motor	ESV G	✓	✓	✓	✓		
508 RXH	front right wiper motor	MOTED UDS	✓	✓	✓	✓		
508 RXH	front right wiper motor	ESV D	✓	✓	✓	✓		
508 RXH	Main beams assistant ECU	RETRO INT	✓	✓	✓	✓		
508 RXH	seat belt not fastened warning lights unit	TNB 2010	✓					
508 RXH	Controls on the steering wheel / Integral controls steering wheel	VCI	✓	✓	✓	✓		
508 RXH	Head Up Display	VTH UDS	✓	✓	✓	✓		
508 RXH	audio amplifier	AMPLI AUDIO	✓	✓	✓	✓		
508 RXH	Seat driver position memory module.	BDMC	✓	✓	✓	✓		
508 RXH	Electric secondary brake	FSE	✓	✓	✓	✓		S0038
508 RXH	Service module / Independent telematic unit	BTA	✓	✓	✓	✓		
508 RXH	Service module / Independent telematic unit	BTA 2	✓	✓	✓	✓		

	Service module / Independent telematic unit							
508 RXH		BTA 3R	✓	✓	✓	✓		
508 RXH	Independent telematic	BTA 3S	✓	✓	✓	✓		
508 RXH	engine wiring housing	BSM 2010	✓	✓	✓	✓		
508 RXH	battery charge status control unit	BECB GEN2	✓	✓	✓	✓		
508 RXH	external CD player	CDE	✓	✓	✓	✓		
508 RXH HYbrid4	engine management ECU	DCM35 BR2	✓	✓	✓	✓	✓	
508 RXH HYbrid4	engine management ECU	DCM34 P	✓	✓	✓	✓	✓	S0037 S0036
508 RXH HYbrid4	engine management ECU	HDI SID807 BR2	✓	✓	✓	✓	✓	S0037
508 RXH HYbrid4	engine management ECU	MED17 4 2	✓	✓	✓	✓	✓	S0034
508 RXH HYbrid4	engine management ECU	MEV17 4 2	✓	✓	✓	✓	✓	S0034
508 RXH HYbrid4	engine management ECU	EDC17CP42	✓	✓	✓	✓	✓	S0037
508 RXH HYbrid4	engine management ECU	MM6KP	✓	✓	✓	✓	✓	S0034
508 RXH HYbrid4	engine management ECU	DCM35 HY	✓	✓	✓	✓	✓	S0037 S0036
508 RXH HYbrid4	engine management ECU	DCM62	✓	✓	✓	✓		
508 RXH HYbrid4	engine management ECU	MED17 4 4	✓	✓	✓	✓		S0034
508 RXH HYbrid4	engine management ECU	MED17 4 4 EP8	✓	✓	✓	✓		
508 RXH HYbrid4	engine management ECU	EDC17C60	✓	✓	✓	✓		
508 RXH HYbrid4	hybrid control ECU 1	HCU1	✓	✓	✓	✓		
508 RXH HYbrid4	hybrid control ECU 2	HCU2	✓	✓	✓	✓		
508 RXH HYbrid4	traction battery ECU	TBMU	✓	✓	✓	✓		
508 RXH HYbrid4	manual gearbox	BVA AM6 AT6 EURO5	✓	✓	✓	✓	✓	
508 RXH HYbrid4	manual gearbox	CFC300P HY	✓	✓	✓	✓		
508 RXH HYbrid4	automatic or piloted manual gearbox	BVA AM6 AT6 UDS	✓	✓	✓	✓		
508 RXH HYbrid4	automatic or piloted manual gearbox	CFC300P	✓	✓	✓	✓	✓	
508 RXH HYbrid4	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS81	✓	✓	✓	✓	✓	S0039 S0035

508 RXH HYbrid4	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81	✓	✓	✓	✓	✓	S0039 S0035 S0038
508 RXH HYbrid4	airbags and pretensioners ECU	RBG UDS	✓	✓	✓	✓		
508 RXH HYbrid4	built-in systems interface	BSI2010	✓	✓	✓			S0033
508 RXH HYbrid4	power steering	GEP	✓	✓	✓	✓	✓	
508 RXH HYbrid4	Electric steering lock	AVE	✓	✓	✓	✓		
508 RXH HYbrid4	anti-theft alarm	ALARME	✓	✓	✓	✓	✓	
508 RXH HYbrid4	instrument panel	COMBINE UDS	✓	✓	✓	✓	✓	
508 RXH HYbrid4	Control panel dot matrix display	MATT C 2010	✓	✓	✓			
508 RXH HYbrid4	Control panel dot matrix display	MATT M 2010	✓	✓	✓			
508 RXH HYbrid4	Control panel dot matrix display	MATT P 2010	✓	✓	✓			
508 RXH HYbrid4	Hands-free unit	BML	✓	✓	✓	✓		
508 RXH HYbrid4	air conditioning	CLIM REGULEE UDS	✓	✓	✓	✓	✓	
508 RXH HYbrid4	rear air conditioning	CLIM AR	✓			✓		
508 RXH HYbrid4	UNDER-INFLATION DETECTION	DSG	✓	✓	✓	✓		
508 RXH HYbrid4	UNDER-INFLATION DETECTION	DSG UDS	✓	✓	✓	✓		
508 RXH HYbrid4	parking assistance	AAS UDS	✓	✓	✓	✓		
508 RXH HYbrid4	Hybrid mode selector	MCM	✓			✓		
508 RXH HYbrid4	control unit	BECB GEN2	✓	✓	✓	✓		
508 RXH HYbrid4	brake	FSE	✓	✓	✓	✓		S0038
508 RXH HYbrid4	height adjuster	LADCT	✓	✓	✓	✓	✓	
508 RXH HYbrid4	height adjuster	BEMP	✓	✓	✓			
508 RXH HYbrid4	additional heating	CHAUFF ADD	✓	✓	✓	✓		
508 RXH HYbrid4	engine wiring housing	BSM 2010	✓	✓	✓	✓		
508 RXH HYbrid4	Trailer relay unit	BSG 2010 RQ	✓	✓	✓	✓		
508 RXH HYbrid4	multifunction screen	EMF A UDS	✓	✓	✓	✓		

508 RXH HYbrid4	multifunction screen	EMF C UDS	✓	✓	✓	✓		
508 RXH HYbrid4	Independent telematic	BTA	✓	✓	✓	✓		
508 RXH HYbrid4	Independent telematic	BTA 2	✓	✓	✓	✓		
508 RXH HYbrid4	Independent telematic	BTA 3R	✓	✓	✓	✓		
508 RXH HYbrid4	Independent telematic	BTA 3S	✓	✓	✓	✓		
508 RXH HYbrid4	Electronic key reader	LCE	✓	✓	✓	✓		
508 RXH HYbrid4	memory module.	BDMC	✓	✓	✓	✓		
508 RXH HYbrid4	Motorised Boot Unit	COFFRE MOTORISE	✓	✓	✓	✓		
508 RXH HYbrid4	or audio-navigation	RNEG2010	✓	✓	✓	✓	✓	
508 RXH HYbrid4	or audio-navigation	MRN	✓	✓	✓	✓		
508 RXH HYbrid4	or audio-navigation	SMEG PLUS	✓	✓	✓	✓		
508 RXH HYbrid4	or audio-navigation	NAC	✓	✓	✓	✓		
508 RXH HYbrid4	panel	FMUX	✓	✓	✓	✓		
508 RXH HYbrid4	radio	RD5	✓	✓	✓	✓	✓	
508 RXH HYbrid4	Telematic navigator / separate control pad	CRT UDS	✓			✓		
508 RXH HYbrid4	audio amplifier	AMPLI AUDIO	✓	✓	✓	✓		
508 RXH HYbrid4	seat belt not fastened warning lights unit	TNB 2010	✓					
508 RXH HYbrid4	rain and sunlight sensor	PLUIE LUMINOSITE UDS	✓	✓	✓	✓		
508 RXH HYbrid4	supplies protection and management unit	BPGA2010	✓	✓	✓	✓		
508 RXH HYbrid4	front right wiper motor	MOTED UDS	✓	✓	✓	✓		
508 RXH HYbrid4	front right wiper motor	ESV D	✓	✓	✓	✓		
508 RXH HYbrid4	front left wiper motor	MOTEV UDS	✓	✓	✓	✓		
508 RXH HYbrid4	front left wiper motor	ESV G	✓	✓	✓	✓		
508 RXH HYbrid4	Controls on the steering wheel / Integral controls steering wheel	VCI	✓	✓	✓	✓		
508 RXH HYbrid4	Main beams assistant ECU	RETRO INT	✓	✓	✓	✓		

508 RXH HYbrid4	Head Up Display	VTH UDS	✓	✓	✓	✓		
508 RXH HYbrid4	driver's door module	PDPC	✓	✓	✓	✓	✓	
508 RXH HYbrid4	controls under the steering wheel	COM2008P	✓	✓	✓	✓	✓	
508 RXH HYbrid4	external CD player	CDE	✓	✓	✓	✓		
508 (R8)	engine management ECU	MED17 4 4	✓	✓	✓	✓		
508 (R8)	engine management ECU	CMM DCM71	✓	✓	✓	✓		
508 (R8)	engine management ECU	CMM MD1CS003	✓	✓	✓	✓		
508 (R8)	engine management ECU	CMM MG1CS042	✓	✓	✓	✓		
508 (R8)	automatic or piloted manual gearbox	BVA AM6 AT6 UDS	✓	✓	✓	✓		
508 (R8)	automatic or piloted manual gearbox	BVA AXN8	✓	✓	✓	✓		
508 (R8)	automatic gearbox electric control ECU	COMELEC2	✓	✓	✓	✓		
508 (R8)	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90	✓	✓	✓	✓		
508 (R8)	airbags and pretensioners ECU	RBG SPEED UDS	✓	✓	✓	✓		
508 (R8)	interface	BSI2010 EV	✓	✓	✓	✓		
508 (R8)	power steering	DAE BVH2	✓	✓	✓	✓		
508 (R8)	Electric steering lock	AVE	✓	✓	✓			
508 (R8)	anti-theft alarm	MUS2	✓	✓	✓	✓		
508 (R8)	Intrusion alarm siren	SIR	✓	✓	✓	✓		
508 (R8)	instrument panel	CIROCCO	✓	✓	✓	✓		
508 (R8)	Hands full access ECU, right-hand side or rear	BAAST	✓					
508 (R8)	air conditioning	BCC	✓	✓	✓	✓		
508 (R8)	rear air conditioning ECU	BCC ADD	✓	✓	✓	✓		
508 (R8)	parking assistance	AAS UDS G6	✓	✓	✓	✓		

508 (R8)	diesel fuel additive pump	PADDGO TI UDS	✓	✓	✓	✓		
508 (R8)	Voltage maintaining device	DMTC	✓					
508 (R8)	Voltage maintaining device	DMTR DTC3B	✓	✓	✓			
508 (R8)	Sequential gear lever	ESM	✓	✓	✓	✓		
508 (R8)	Variable damping ECU	CSS UDS	✓	✓	✓	✓		
508 (R8)	Dynamic headlamp height adjuster	LADCT	✓	✓	✓	✓		
508 (R8)	Trailer relay unit	BSG 2010 RQ	✓	✓	✓	✓		
508 (R8)	battery charge status control unit	BECB GEN2	✓	✓	✓	✓		
508 (R8)	controls under the steering wheel	COM2008P	✓	✓	✓	✓		
508 (R8)	Controls on the steering wheel / Integral controls steering wheel	VCi	✓	✓	✓	✓		
508 (R8)	Multifunction control panel	FMUX	✓	✓	✓	✓		
508 (R8)	seat belt not fastened warning lights unit	TNB 2010	✓					
508 (R8)	windscreen wiper	ESV	✓	✓	✓	✓		
508 (R8)	rain and sunlight sensor	CDPL UDS HELLA	✓	✓	✓	✓		
508 (R8)	Panoramic visual assistance ECU	AVP	✓	✓	✓	✓		
508 (R8)	Multifunction video camera (CMF)	CVM 3	✓	✓	✓	✓		
508 (R8)	Vehicle Distance Assistance	RADAR AV 4	✓	✓	✓	✓		
508 (R8)	night vision ECU	BVN	✓	✓	✓	✓		
508 (R8)	touch screen	EMF DGT LVDS BD	✓	✓	✓	✓		

508 (R8)	Telematic unit (RTx) or audio-navigation	NAC	✓	✓	✓	✓		
508 (R8)	Telematic unit (RTx) or audio-navigation	RCC	✓	✓	✓	✓		
508 (R8)	Independent telematic unit	BTA 3R	✓	✓	✓	✓		
508 (R8)	Service module / Independent telematic unit	BTA 3S	✓	✓	✓			
508 (R8)	Service module / Independent telematic unit	BTA CN	✓	✓	✓			
508 (R8)	audio amplifier	AMPLI AUDIO	✓	✓	✓			
508 (R8)	driver's door module	PDPC	✓	✓	✓			
508 (R8)	driver's door module	PDPC UDS	✓	✓	✓	✓		
508 (R8)	Motorised Boot Unit	VERINS MOTORISES	✓	✓	✓	✓		
508 (R8)	sunroof	TO	✓			✓		
508 (R8)	sunroof	TO DTC	✓	✓	✓			
508 (R8)	additional heating	BECH	✓			✓		
508 (R8)	Front left seat heated pads and ventilation regulation ECU	BRNC AVG	✓			✓		
508 (R8)	heated pads and	BRNC AVD	✓			✓		
508 (R8)	Driver's seat comfort ECU	SCB D	✓	✓	✓	✓		
508 (R8)	pneumatic functions	SPB D	✓			✓		
508 (R8)	Passenger's seat pneumatic functions ECU	SPB P	✓			✓		
508L (R83)	engine management ECU	MED17 4 4	✓	✓	✓	✓		
508L (R83)	engine management ECU	CMM DCM71	✓	✓	✓	✓		
508L (R83)	engine management ECU	CMM MD1CS003	✓	✓	✓	✓		
508L (R83)	engine management ECU	CMM MG1CS042	✓	✓	✓	✓		
508L (R83)	automatic or piloted manual gearbox	BVA AM6 AT6 UDS	✓	✓	✓	✓		

508L (R83)	automatic or piloted manual gearbox	BVA AXN8	✓	✓	✓	✓		
508L (R83)	automatic gearbox electric control ECU	COMELEC2	✓	✓	✓	✓		
508L (R83)	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90	✓	✓	✓	✓		
508L (R83)	airbags and pretensioners ECU	RBG SPEED UDS	✓	✓	✓	✓		
508L (R83)	built-in systems interface	BSI2010 EV	✓	✓	✓	✓		
508L (R83)	power steering	DAE BVH2	✓	✓	✓	✓		
508L (R83)	Electric steering lock	AVE	✓	✓	✓			
508L (R83)	instrument panel	CIROCCO	✓	✓	✓	✓		
508L (R83)	right-hand side or	BAAST	✓					
508L (R83)	air conditioning	BCC	✓	✓	✓	✓		
508L (R83)	DETECTION	DSG UDS	✓	✓	✓	✓		
508L (R83)	parking assistance	AAS UDS G6	✓	✓	✓	✓		
508L (R83)	device	DMTC	✓					
508L (R83)	device	DMTR DTC3B	✓	✓	✓			
508L (R83)	Sequential gear lever	ESM	✓	✓	✓	✓		
508L (R83)	Variable damping ECU	CSS UDS	✓	✓	✓	✓		
508L (R83)	height adjuster	LADCT	✓	✓	✓	✓		
508L (R83)	control unit	BECB GEN2	✓	✓	✓	✓		
508L (R83)	steering wheel	COM2008P	✓	✓	✓	✓		
508L (R83)	Controls on the steering wheel / Integral controls steering wheel	VCI	✓	✓	✓	✓		
508L (R83)	Multifunction control panel	FMUX	✓	✓	✓	✓		
508L (R83)	windscreen wiper	ESV	✓	✓	✓	✓		
508L (R83)	rain and sunlight sensor	CDPL UDS HELLA	✓	✓	✓	✓		

508L (R83)	Multifunction video camera (CMF)	CVM 3	✓	✓	✓	✓		
508L (R83)	Vehicle Distance Assistance	RADAR AV 4	✓	✓	✓	✓		
508L (R83)	night vision ECU	BVN	✓	✓	✓	✓		
508L (R83)	touch screen	EMF DGT LVDS BD	✓	✓	✓	✓		
508L (R83)	Telematic unit (RTx) or audio-navigation	NAC	✓	✓	✓	✓		
508L (R83)	Telematic unit (RTx) or audio-navigation	RCC	✓	✓	✓	✓		
508L (R83)	Service module / Independent telematic unit	BTA 3R	✓	✓	✓	✓		
508L (R83)	Service module / Independent telematic unit	BTA 3S	✓	✓	✓			
508L (R83)	Service module / Independent telematic unit	BTA CN	✓	✓	✓			
508L (R83)	audio amplifier	AMPLI AUDIO	✓	✓	✓			
508L (R83)	driver's door module	PDPC	✓	✓	✓			
508L (R83)	driver's door module	PDPC UDS	✓	✓	✓	✓		
508L (R83)	sunroof	TO	✓			✓		
508L (R83)	sunroof	TO DTC	✓	✓	✓			
508L (R83)	rear air conditioning control panel	IHM AR CENTRAL	✓			✓		
508L (R83)	Front left seat heated pads and ventilation regulation ECU	BRNC AVG	✓			✓		
508L (R83)	Front right seat heated pads and ventilation regulation ECU	BRNC AVD	✓			✓		
508L (R83)	ECU	SCB D	✓	✓	✓	✓		

508L (R83)	Driver's seat pneumatic functions ECU	SPB D	✓			✓		
607R	engine management ECU	ME747	✓	✓	✓	✓	✓	S0034
607R	engine management ECU	EDC15C2	✓	✓	✓	✓		
607R	engine management ECU	EDC15C2	✓	✓	✓	✓		
607R	engine management ECU	SID201	✓	✓	✓	✓	✓	S0037
607R	engine management ECU	HDI SID803A	✓	✓	✓	✓	✓	
607R	engine management ECU	MM6LP	✓	✓	✓	✓	✓	S0034
607R	engine management ECU	MM6LPB	✓	✓	✓	✓	✓	
607R	engine management ECU	EDC16CP39	✓	✓	✓	✓	✓	S0037
607R	automatic or piloted manual gearbox	BVA AM6	✓	✓	✓	✓	✓	
607R	automatic or piloted manual gearbox	BVA ZF	✓	✓	✓	✓	✓	
607R	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP8 BOSCH	✓	✓	✓	✓	✓	
607R	airbags and pretensioners ECU	SAC AUTOLIV	✓	✓	✓	✓		
607R	built-in systems interface	BSI	✓	✓	✓	✓		
607R	power steering	GEP	✓	✓	✓	✓		
607R	anti-theft alarm	ALARME	✓	✓	✓	✓	✓	
607R	instrument panel	COMBINE	✓	✓	✓	✓	✓	
607R	air conditioning	CLIM REGULEE	✓	✓	✓	✓	✓	
607R	UNDER-INFLATION DETECTION	DSG	✓	✓	✓	✓		
607R	parking assistance	AAS	✓	✓	✓	✓	✓	
607R	electronically managed suspension	CSS	✓	✓	✓	✓		
607R	diesel additive	ADDG03	✓	✓	✓	✓	✓	
607R	engine wiring housing	BSM	✓	✓	✓	✓		
607R	Trailer relay unit	BSR	✓	✓	✓	✓		

607R	steering wheel	HDC	✓	✓	✓	✓	✓	
607R	multifunction screen	EMF A	✓	✓	✓	✓	✓	
607R	multifunction screen	EMF C	✓	✓	✓	✓	✓	
607R	radio	AUTORADIO	✓	✓	✓	✓	✓	
607R	Portable Unit	KML	✓	✓	✓	✓	✓	
607R	CD player	CHANGEUR CD	✓	✓	✓			
607R	or audio-navigation	BOITIER TELEMATIQUE	✓	✓	✓	✓	✓	
607R	memory module.	BDMC	✓	✓	✓	✓	✓	
607R	driver's door module	EDPC	✓	✓	✓	✓	✓	
607R	passenger door module	EDPP	✓	✓	✓	✓	✓	
607R	sensor	PLUIE LUMINOSITE	✓	✓	✓	✓		
607R	Motorised Boot Unit	COFFRE MOTORISE	✓			✓		
807 CAN	engine management ECU	EDC15C2	✓	✓	✓	✓	✓	
807 CAN	engine management ECU	MM6LPB	✓	✓	✓	✓	✓	
807 CAN	engine management ECU	HDI SID803A	✓	✓	✓	✓	✓	
807 CAN	engine management ECU	EDC16CP39	✓	✓	✓	✓	✓	S0037
807 CAN	engine management ECU	DCM35	✓	✓	✓	✓	✓	S0037 S0036
807 CAN	engine management ECU	DCM35 BR2	✓	✓	✓	✓		
807 CAN	manual gearbox	BVA AM6 AT6 EURO5	✓	✓	✓	✓	✓	
807 CAN	automatic or piloted manual gearbox	BVA AM6	✓	✓	✓	✓	✓	
807 CAN	automatic or piloted manual gearbox	BVA AL4	✓	✓	✓	✓	✓	
807 CAN	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP8 BOSCH	✓	✓	✓	✓	✓	S0039 S0035
807 CAN	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81	✓	✓	✓	✓	✓	S0039 S0035
807 CAN	airbags and pretensioners ECU	SAC AUTOLIV	✓	✓	✓	✓		
807 CAN	built-in systems interface	BSI	✓	✓	✓	✓		S0033

807 CAN	power steering	GEP	✓	✓	✓	✓		
807 CAN	anti-theft alarm	ALARME	✓	✓	✓	✓	✓	
807 CAN	instrument panel	COMBINE	✓	✓	✓	✓	✓	
807 CAN	air conditioning	CLIM REGULEE	✓	✓	✓	✓	✓	
807 CAN	UNDER-INFLATION DETECTION	DSG	✓	✓	✓	✓		
807 CAN	parking assistance	AAS	✓	✓	✓	✓	✓	
807 CAN	diesel additive	ADDG03	✓	✓	✓	✓	✓	
807 CAN	additional heating	CHAUFF ADD	✓	✓	✓	✓		
807 CAN	headlamp height	PROJECTEURG	✓			✓		
807 CAN	Right-hand dynamic headlamp height adjuster	PROJECTEURD	✓			✓		
807 CAN	Trailer relay unit	BSR	✓	✓	✓	✓		
807 CAN	engine wiring housing	BSM	✓	✓	✓	✓		
807 CAN	multifunction screen	EMF A	✓	✓	✓	✓	✓	
807 CAN	multifunction screen	EMF C	✓	✓	✓	✓	✓	
807 CAN	controls under the steering wheel	HDC	✓	✓	✓	✓	✓	
807 CAN	CD changer / external CD player	CHANGEUR CD	✓	✓	✓			
807 CAN	radio	AUTORADIO	✓	✓	✓	✓	✓	
807 CAN	radio	RD45	✓	✓	✓	✓	✓	
807 CAN	Hands-free Kit / Portable Unit	KML	✓	✓	✓	✓	✓	
807 CAN	Hands-free Kit / Portable Unit	BOITIER NOMADE	✓	✓	✓	✓	✓	
807 CAN	Telematic unit (RTx) or audio-navigation	BOITIER TELEMATIQUE	✓	✓	✓			
807 CAN	Telematic unit (RTx) or audio-navigation	RADIONAV RNEG	✓	✓	✓	✓		
807 CAN	Telematic unit (RTx) or audio-navigation	RNEG2010	✓	✓	✓	✓		
807 CAN	Seat driver position memory module.	BDMC	✓	✓	✓	✓	✓	

807 CAN	passenger door module	EDPP	✓	✓	✓	✓	✓	
807 CAN	sliding side doors module	PLCM	✓	✓	✓	✓		
807 CAN	driver's door module	EDPC	✓	✓	✓	✓	✓	
807 CAN	rear sunroof	TO INALFA	✓	✓	✓	✓		
807 CAN	front sunroof	TO INALFA	✓	✓	✓	✓		
807 CAN	central sunroof	TO INALFA	✓	✓	✓	✓		
807 CAN	Odometer LED unit	BTO	✓	✓	✓	✓		
807 CAN	rain and sunlight sensor	PLUIE LUMINOSITE	✓	✓	✓			
807 CAN	Control of the telematic unit	CRT	✓			✓		
2008	engine management ECU	ME749 EC5	✓	✓	✓	✓		
2008	engine management ECU	EDC17C10 BR2	✓	✓	✓	✓	✓	S0037
2008	engine management ECU	MEV17 4 2	✓	✓	✓	✓		S0034
2008	engine management ECU	HDI SID807 BR2	✓	✓	✓	✓	✓	S0037
2008	engine management ECU	V46	✓	✓	✓	✓		
2008	engine management ECU	MED17 4 2	✓	✓	✓	✓		S0034
2008	engine management ECU	MEVD17 4 2	✓	✓	✓	✓		
2008	engine management ECU	V344	✓	✓	✓	✓		
2008	engine management ECU	V345	✓	✓	✓	✓		
2008	engine management ECU	ME745 EC5	✓	✓	✓	✓		
2008	engine management ECU	VD46	✓	✓	✓	✓		
2008	engine management ECU	EDC17C60	✓	✓	✓	✓		
2008	engine management ECU	MEVD17 4 4	✓	✓	✓	✓		
2008	engine management ECU	MED17 4 4	✓	✓	✓	✓		
2008	engine management ECU	V46 21	✓	✓	✓	✓		
2008	engine management ECU	V46 52	✓	✓	✓	✓		
2008	engine management ECU	V46 6	✓	✓	✓	✓		
2008	engine management ECU	CMM V56	✓	✓	✓	✓		
2008	engine management ECU	CMM MD1CS003	✓	✓	✓	✓		
2008	engine management ECU	CMM VD56	✓	✓	✓	✓		
2008	manual gearbox	BVA AL4	✓	✓	✓	✓	✓	
2008	manual gearbox	BVMP	✓	✓	✓	✓		
2008	manual gearbox	CFC300P	✓	✓	✓	✓	✓	

2008	manual gearbox	MAPS UDS	✓	✓	✓	✓		
2008	manual gearbox	BVA AM6 AT6 UDS	✓	✓	✓	✓		
2008	manual gearbox	BVMP MCP UDS	✓	✓	✓	✓		
2008	System (ABS) or	ABSMK100	✓	✓	✓	✓	✓	S0039
2008	System (ABS) or	ESPMK100	✓	✓	✓	✓	✓	S0039
2008	airbags and pretensioners ECU	RBG UDS	✓	✓	✓	✓		
2008	built-in systems interface	BSI2010	✓	✓	✓	✓		
2008	power steering	DAE	✓	✓	✓	✓		
2008	power steering	DAE A515	✓	✓	✓	✓		
2008	power steering	DAE UDS	✓	✓	✓	✓		
2008	anti-theft alarm	MUS	✓	✓	✓	✓	✓	
2008	Intrusion alarm siren	SIR	✓	✓	✓	✓		
2008	instrument panel	COMBINE UDS	✓	✓	✓	✓	✓	
2008	matrix display	MATT C 2010	✓	✓	✓			
2008	Control panel dot matrix display	MATT M 2010	✓	✓	✓			
2008	Control panel dot matrix display	MATT P 2010	✓	✓	✓			
2008	air conditioning	TDC CH MUX	✓	✓	✓	✓		
2008	air conditioning	TDC RF MUX	✓	✓	✓	✓		
2008	air conditioning	TDC RFTA MUX	✓	✓	✓	✓		
2008	parking assistance	AAS UDS	✓	✓	✓	✓		
2008	diesel fuel additive pump	PADDGO	✓	✓	✓	✓		
2008	diesel fuel additive pump	PADDGO TI E6	✓	✓	✓	✓		
2008	Voltage maintaining device	DMTC	✓					
2008	Voltage maintaining device	DMTR	✓	✓	✓			
2008	Voltage maintaining device	DMTR DTC3B	✓	✓	✓			
2008	Trailer relay unit	BSG 2010 RQ	✓	✓	✓	✓		

2008	battery charge status control unit	BECB GEN2	✓	✓	✓	✓		S003A
2008	controls under the steering wheel	COM2008P	✓	✓	✓	✓	✓	
2008	steering wheel /	VCI	✓	✓	✓	✓		
2008	Controls on the steering wheel / Integral controls steering wheel	VCI	✓	✓	✓	✓		
2008	Traction control mode selector	ASR	✓			✓		
2008	Multifunction control panel	FMUX	✓	✓	✓	✓		
2008	rain and sunlight sensor	PLUIE LUMINOSITE UDS	✓	✓	✓	✓		
2008	Vehicle Distance Assistance	LIDAR	✓	✓	✓	✓		
2008	touch screen	EMF DGT LVDS BD	✓	✓	✓	✓		
2008	Telematic unit (RTx) or audio-navigation	SMEG	✓	✓	✓	✓		
2008	Telematic unit (RTx) or audio-navigation	SMEG PLUS	✓	✓	✓	✓		
2008	Telematic unit (RTx) or audio-navigation	NAC	✓	✓	✓	✓		
2008	Telematic unit (RTx) or audio-navigation	RCC	✓	✓	✓	✓		
2008	Telematic unit (RTx) or audio-navigation	AIO	✓	✓	✓	✓		
2008	radio	RDE	✓	✓	✓	✓	✓	
2008	radio	RD6	✓	✓	✓	✓		
2008	Service module / Independent telematic unit	BTA	✓	✓	✓	✓		

2008	Service module / Independent telematic unit	BTA 2	✓	✓	✓	✓		
2008	Service module / Independent telematic unit	BTA 3R	✓	✓	✓	✓		
2008	Service module / Independent telematic unit	BTA 3S	✓	✓	✓	✓		
2008	external CD player	CDE	✓	✓	✓	✓	✓	
2008	audio amplifier	AMPLI AUDIO	✓	✓	✓			
3008	engine management ECU	DCM35 BR2	✓	✓	✓	✓	✓	S0037 S0036
3008	engine management ECU	EDC16C3	✓	✓	✓	✓	✓	S0037 S0036
3008	engine management ECU	MEV17 4 EURO4	✓	✓	✓	✓	✓	S0034
3008	engine management ECU	MED17 4 EURO4	✓	✓	✓	✓	✓	S0034
3008	engine management ECU	MEV17 4 EURO5	✓	✓	✓	✓	✓	S0034
3008	engine management ECU	MED17 4 EURO5	✓	✓	✓	✓	✓	S0034
3008	engine management ECU	DCM35	✓	✓	✓	✓	✓	S0036 S0037
3008	engine management ECU	HDI SID807	✓	✓	✓	✓	✓	S0037
3008	engine management ECU	MEV17 4 2	✓	✓	✓	✓	✓	
3008	engine management ECU	HDI SID807 BR2	✓	✓	✓	✓	✓	S0037
3008	engine management ECU	MED17 4 2	✓	✓	✓	✓	✓	S0034
3008	engine management ECU	DCM35 HY	✓	✓	✓	✓	✓	S0037 S0036
3008	engine management ECU	MM6KP	✓	✓	✓	✓	✓	S0034
3008	engine management ECU	DCM62	✓	✓	✓	✓		
3008	engine management ECU	EDC17C60	✓	✓	✓	✓		
3008	engine management ECU	MED17 4 4	✓	✓	✓	✓		
3008	engine management ECU	VD46	✓	✓	✓	✓		
3008	manual gearbox	BVA AM6 AT6 EURO5	✓	✓	✓	✓	✓	
3008	manual gearbox	CFC300P HY	✓	✓	✓	✓	✓	
3008	manual gearbox	CFC300P	✓	✓	✓	✓	✓	
3008	manual gearbox	BVA AM6 AT6 UDS	✓	✓	✓	✓		

3008	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81	✓	✓	✓	✓	✓	S0039 S0035 S0038
3008	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90	✓	✓	✓	✓		
3008	airbags and pretensioners ECU	SAC AUTOLIV	✓	✓	✓	✓		
3008	built-in systems interface	BSI	✓	✓	✓	✓		
3008	power steering	GEP	✓	✓	✓	✓	✓	
3008	anti-theft alarm	ALARME	✓	✓	✓	✓	✓	
3008	instrument panel	COMBINE	✓	✓	✓	✓		
3008	Control panel dot matrix display	MATT	✓	✓	✓	✓	✓	
3008	air conditioning	CLIM REGULEE	✓	✓	✓	✓	✓	
3008	UNDER-INFLATION DETECTION	DSG	✓	✓	✓	✓		
3008	DETECTION	DSG UDS	✓	✓	✓	✓		
3008	parking assistance	AAS	✓	✓	✓	✓		
3008	parking assistance	AAS UDS	✓	✓	✓	✓		
3008	diesel fuel additive pump	PADDGO	✓	✓	✓	✓		
3008	diesel fuel additive pump	PADDGO E5	✓	✓	✓	✓		
3008	diesel fuel additive pump	PADDGO TI E6	✓	✓	✓	✓		
3008	Dynamic headlamp height adjuster	LADCT	✓	✓	✓	✓	✓	
3008	battery charge status control unit	BECEB	✓	✓	✓	✓		
3008	battery charge status control unit	BECEB GEN2	✓	✓	✓	✓		

3008	Vehicle Distance Assistance	ARTIV	✓	✓	✓	✓		
3008	Electric secondary brake	FSE	✓	✓	✓	✓		
3008	Trailer relay unit	BSR	✓	✓	✓	✓		
3008	engine wiring housing	BSM	✓	✓	✓	✓		
3008	steering wheel	HDC	✓	✓	✓	✓		
3008	controls under the steering wheel	COM2008P	✓	✓	✓	✓		
3008	multifunction screen	EMF A	✓	✓	✓	✓	✓	
3008	multifunction screen	EMF C	✓	✓	✓	✓	✓	
3008	windscreen wiper	MOTEV	✓	✓	✓			
3008	radio	AUTORADIO	✓	✓	✓	✓	✓	
3008	radio	RD45	✓	✓	✓	✓		
3008	radio	RD43	✓	✓	✓	✓		
3008	Telematic unit (RTx) or audio-navigation	RADIONAV RNEG	✓	✓	✓	✓		
3008	Telematic unit (RTx) or audio-navigation	RADIONAV NG4	✓	✓	✓	✓	✓	
3008	Telematic unit (RTx) or audio-navigation	RNEG2010	✓	✓	✓	✓		
3008	Telematic unit (RTx) or audio-navigation	RADIONAV RNEGC	✓	✓	✓	✓		
3008	Telematic unit (RTx) or audio-navigation	MRN	✓	✓	✓	✓		
3008	audio amplifier	AMPLI AUDIO	✓	✓	✓		✓	
3008	CD changer / external CD player	CHANGEUR CD	✓	✓	✓			
3008	Hands-free Kit / Portable Unit	BOITIER NOMADE	✓	✓	✓	✓	✓	
3008	Traction control mode selector	ASR	✓			✓	✓	
3008	driver's door module	PDPC	✓	✓	✓	✓	✓	

3008	Service module / Independent telematic unit	MD SERV	✓	✓	✓	✓	✓	
3008	Service module / Independent telematic unit	BTA	✓	✓	✓	✓	✓	
3008	Service module / Independent telematic unit	BLVV	✓	✓	✓	✓		
3008	rain and sunlight sensor	PLUIE LUMINOSITE	✓	✓	✓			
3008	Voltage maintaining device	DMTC	✓					
3008	Voltage maintaining device	DMTR	✓	✓	✓			
3008	Voltage maintaining device	DMTR DTC3B	✓	✓	✓			
3008	Head Up Display	VTH	✓	✓	✓	✓		
3008	Head Up Display	VTH UDS	✓	✓	✓	✓		
3008	high frequency receiver	RHF	✓	✓	✓	✓		
3008	seat belt not fastened warning lights unit	TNB	✓					
3008 HYbrid4	engine management ECU	DCM35 BR2	✓	✓	✓	✓	✓	S0037 S0036
3008 HYbrid4	engine management ECU	EDC16C3	✓	✓	✓	✓	✓	S0037 S0036
3008 HYbrid4	engine management ECU	MEV17 4 EURO4	✓	✓	✓	✓	✓	S0034
3008 HYbrid4	engine management ECU	MED17 4 EURO4	✓	✓	✓	✓	✓	S0034
3008 HYbrid4	engine management ECU	MEV17 4 EURO5	✓	✓	✓	✓	✓	S0034
3008 HYbrid4	engine management ECU	MED17 4 EURO5	✓	✓	✓	✓	✓	S0034
3008 HYbrid4	engine management ECU	DCM35	✓	✓	✓	✓	✓	S0036 S0037
3008 HYbrid4	engine management ECU	HDI SID807	✓	✓	✓	✓	✓	S0037
3008 HYbrid4	engine management ECU	MEV17 4 2	✓	✓	✓	✓	✓	
3008 HYbrid4	engine management ECU	HDI SID807 BR2	✓	✓	✓	✓	✓	S0037
3008 HYbrid4	engine management ECU	MED17 4 2	✓	✓	✓	✓	✓	S0034
3008 HYbrid4	engine management ECU	DCM35 HY	✓	✓	✓	✓	✓	S0037 S0036

3008 HYbrid4	engine management ECU	MM6KP	✓	✓	✓	✓	✓	S0034
3008 HYbrid4	engine management ECU	DCM62	✓	✓	✓	✓		
3008 HYbrid4	engine management ECU	EDC17C60	✓	✓	✓	✓		
3008 HYbrid4	engine management ECU	MED17 4 4	✓	✓	✓	✓		
3008 HYbrid4	engine management ECU	VD46	✓	✓	✓	✓		
3008 HYbrid4	traction battery ECU	TBMU	✓	✓	✓	✓		
3008 HYbrid4	hybrid control ECU 1	HCU1	✓	✓	✓	✓		
3008 HYbrid4	hybrid control ECU 2	HCU2	✓	✓	✓	✓		
3008 HYbrid4	manual gearbox	BVA AM6 AT6 EURO5	✓	✓	✓	✓	✓	
3008 HYbrid4	manual gearbox	CFC300P HY	✓	✓	✓	✓	✓	
3008 HYbrid4	manual gearbox	CFC300P	✓	✓	✓	✓	✓	
3008 HYbrid4	manual gearbox	BVA AM6 AT6 UDS	✓	✓	✓	✓		
3008 HYbrid4	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81	✓	✓	✓	✓	✓	S0039 S0035 S0038
3008 HYbrid4	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90	✓	✓	✓	✓		
3008 HYbrid4	airbags and pretensioners ECU	SAC AUTOLIV	✓	✓	✓	✓		
3008 HYbrid4	built-in systems interface	BSI	✓	✓	✓	✓		
3008 HYbrid4	power steering	GEP	✓	✓	✓	✓	✓	
3008 HYbrid4	anti-theft alarm	ALARME	✓	✓	✓	✓	✓	
3008 HYbrid4	Control panel dot matrix display	MATT	✓	✓	✓	✓	✓	
3008 HYbrid4	instrument panel	COMBINE	✓	✓	✓	✓		
3008 HYbrid4	air conditioning	CLIM REGULEE	✓	✓	✓	✓	✓	
3008 HYbrid4	UNDER-INFLATION DETECTION	DSG	✓	✓	✓	✓		
3008 HYbrid4	UNDER-INFLATION DETECTION	DSG UDS	✓	✓	✓	✓		
3008 HYbrid4	parking assistance	AAS	✓	✓	✓	✓		

3008 HYbrid4	parking assistance	AAS UDS	✓	✓	✓	✓		
3008 HYbrid4	Hybrid mode selector	MCM	✓			✓		
3008 HYbrid4	Telematic unit (RTx) or audio-navigation	RADIONAV RNEG	✓	✓	✓	✓		
3008 HYbrid4	Telematic unit (RTx) or audio-navigation	RADIONAV NG4	✓	✓	✓	✓	✓	
3008 HYbrid4	Telematic unit (RTx) or audio-navigation	RNEG2010	✓	✓	✓	✓		
3008 HYbrid4	Telematic unit (RTx) or audio-navigation	RADIONAV RNEGC	✓	✓	✓	✓		
3008 HYbrid4	Telematic unit (RTx) or audio-navigation	MRN	✓	✓	✓	✓		
3008 HYbrid4	rain and sunlight sensor	PLUIE LUMINOSITE	✓	✓	✓			
3008 HYbrid4	control unit	BECB	✓	✓	✓	✓		
3008 HYbrid4	battery charge status control unit	BECB GEN2	✓	✓	✓	✓		
3008 HYbrid4	diesel fuel additive pump	PADDGO	✓	✓	✓	✓		
3008 HYbrid4	pump	PADDGO E5	✓	✓	✓	✓		
3008 HYbrid4	diesel fuel additive pump	PADDGO TI E6	✓	✓	✓	✓		
3008 HYbrid4	controls under the steering wheel	HDC	✓	✓	✓	✓		
3008 HYbrid4	controls under the steering wheel	COM2008P	✓	✓	✓	✓		
3008 HYbrid4	Electric secondary brake	FSE	✓	✓	✓	✓		
3008 HYbrid4	radio	AUTORADIO	✓	✓	✓	✓	✓	
3008 HYbrid4	radio	RD45	✓	✓	✓	✓		
3008 HYbrid4	radio	RD43	✓	✓	✓	✓		
3008 HYbrid4	Service module / Independent telematic unit	MD SERV	✓	✓	✓	✓	✓	

3008 HYbrid4	Service module / Independent telematic unit	BTA	✓	✓	✓	✓	✓	
3008 HYbrid4	Service module / Independent telematic unit	BLVV	✓	✓	✓	✓		
3008 HYbrid4	multifunction screen	EMF A	✓	✓	✓	✓	✓	
3008 HYbrid4	multifunction screen	EMF C	✓	✓	✓	✓	✓	
3008 HYbrid4	engine wiring housing	BSM	✓	✓	✓	✓		
3008 HYbrid4	Head Up Display	VTH	✓	✓	✓	✓		
3008 HYbrid4	Head Up Display	VTH UDS	✓	✓	✓	✓		
3008 HYbrid4	Trailer relay unit	BSR	✓	✓	✓	✓		
3008 HYbrid4	Hands-free Kit / Portable Unit	BOITIER NOMADE	✓	✓	✓	✓	✓	
3008 HYbrid4	windscreen wiper	MOTEV	✓	✓	✓			
3008 HYbrid4	audio amplifier	AMPLI AUDIO	✓	✓	✓		✓	
3008 HYbrid4	driver's door module	PDPC	✓	✓	✓	✓	✓	
3008 HYbrid4	CD changer / external CD player	CHANGEUR CD	✓	✓	✓			
3008 Chine	engine management ECU	DCM35 BR2	✓	✓	✓	✓	✓	S0037 S0036
3008 Chine	engine management ECU	EDC16C3	✓	✓	✓	✓	✓	S0037 S0036
3008 Chine	engine management ECU	MEV17 4 EURO4	✓	✓	✓	✓	✓	S0034
3008 Chine	engine management ECU	MED17 4 EURO4	✓	✓	✓	✓	✓	S0034
3008 Chine	engine management ECU	MEV17 4 EURO5	✓	✓	✓	✓	✓	S0034
3008 Chine	engine management ECU	MED17 4 EURO5	✓	✓	✓	✓	✓	S0034
3008 Chine	engine management ECU	DCM35	✓	✓	✓	✓	✓	S0036 S0037
3008 Chine	engine management ECU	HDI SID807	✓	✓	✓	✓	✓	S0037
3008 Chine	engine management ECU	MEV17 4 2	✓	✓	✓	✓	✓	
3008 Chine	engine management ECU	HDI SID807 BR2	✓	✓	✓	✓	✓	S0037
3008 Chine	engine management ECU	MED17 4 2	✓	✓	✓	✓	✓	S0034
3008 Chine	engine management ECU	DCM35 HY	✓	✓	✓	✓	✓	S0037 S0036
3008 Chine	engine management ECU	MM6KP	✓	✓	✓	✓	✓	S0034
3008 Chine	engine management ECU	DCM62	✓	✓	✓	✓		
3008 Chine	engine management ECU	EDC17C60	✓	✓	✓	✓		
3008 Chine	engine management ECU	MED17 4 4	✓	✓	✓	✓		

3008 Chine	engine management ECU	VD46	✓	✓	✓	✓		
3008 Chine	automatic or piloted manual gearbox	BVA AM6 AT6 EURO5	✓	✓	✓	✓	✓	
3008 Chine	automatic or piloted manual gearbox	CFC300P HY	✓	✓	✓	✓	✓	
3008 Chine	automatic or piloted manual gearbox	CFC300P	✓	✓	✓	✓	✓	
3008 Chine	automatic or piloted manual gearbox	BVA AM6 AT6 UDS	✓	✓	✓	✓		
3008 Chine	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81	✓	✓	✓	✓	✓	S0039 S0035 S0038
3008 Chine	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90	✓	✓	✓	✓		
3008 Chine	airbags and pretensioners ECU	SAC AUTOLIV	✓	✓	✓	✓		
3008 Chine	interface	BSI	✓	✓	✓	✓		
3008 Chine	power steering	GEP	✓	✓	✓	✓	✓	
3008 Chine	anti-theft alarm	ALARME	✓	✓	✓	✓	✓	
3008 Chine	instrument panel	COMBINE	✓	✓	✓	✓		
3008 Chine	Control panel dot matrix display	MATT	✓	✓	✓	✓	✓	
3008 Chine	air conditioning	CLIM REGULEE	✓	✓	✓	✓	✓	
3008 Chine	UNDER-INFLATION DETECTION	DSG	✓	✓	✓	✓		
3008 Chine	UNDER-INFLATION DETECTION	DSG UDS	✓	✓	✓	✓		
3008 Chine	parking assistance	AAS	✓	✓	✓	✓		
3008 Chine	parking assistance	AAS UDS	✓	✓	✓	✓		
3008 Chine	engine wiring housing	BSM	✓	✓	✓	✓		
3008 Chine	controls under the steering wheel	HDC	✓	✓	✓	✓		

3008 Chine	steering wheel	COM2008P	✓	✓	✓	✓		
3008 Chine	Telematic unit (RTx) or audio-navigation	RADIONAV RNEG	✓	✓	✓	✓		
3008 Chine	Telematic unit (RTx) or audio-navigation	RADIONAV NG4	✓	✓	✓	✓	✓	
3008 Chine	Telematic unit (RTx) or audio-navigation	RNEG2010	✓	✓	✓	✓		
3008 Chine	Telematic unit (RTx) or audio-navigation	RADIONAV RNEGC	✓	✓	✓	✓		
3008 Chine	Telematic unit (RTx) or audio-navigation	MRN	✓	✓	✓	✓		
3008 Chine	windscreen wiper	MOTEV	✓	✓	✓			
3008 Chine	radio	AUTORADIO	✓	✓	✓	✓	✓	
3008 Chine	radio	RD45	✓	✓	✓	✓		
3008 Chine	radio	RD43	✓	✓	✓	✓		
3008 Chine	Head Up Display	VTH	✓	✓	✓	✓		
3008 Chine	Head Up Display	VTH UDS	✓	✓	✓	✓		
3008 Chine	driver's door module	PDPC	✓	✓	✓	✓	✓	
3008 Chine	rain and sunlight sensor	PLUIE LUMINOSITE	✓	✓	✓			
3008 Chine	multifunction screen	EMF A	✓	✓	✓	✓	✓	
3008 Chine	multifunction screen	EMF C	✓	✓	✓	✓	✓	
3008 Chine	Electric secondary brake	FSE	✓	✓	✓	✓		
3008 Chine	Traction control mode selector	ASR	✓			✓	✓	
3008 Chine	Voltage maintaining device	DMTC	✓					
3008 Chine	Voltage maintaining device	DMTR	✓	✓	✓			
3008 Chine	Voltage maintaining device	DMTR DTC3B	✓	✓	✓			
3008 Chine	battery charge status control unit	BECB	✓	✓	✓	✓		

3008 Chine	battery charge status control unit	BECEB GEN2	✓	✓	✓	✓		
3008 Chine	Controls on the steering wheel / Integral controls steering wheel	VCI	✓	✓	✓	✓		
3008 Chine	Multifunction video recording camera	IDVR	✓	✓	✓	✓		
3008 Chine	Panoramic visual assistance ECU	AVP	✓	✓	✓	✓		
3008 (P84)	engine management ECU	VD46	✓	✓	✓	✓		
3008 (P84)	engine management ECU	MED17 4 4	✓	✓	✓	✓		
3008 (P84)	engine management ECU	DCM62	✓	✓	✓	✓		
3008 (P84)	engine management ECU	EDC17C60	✓	✓	✓	✓		
3008 (P84)	engine management ECU	MED17 4 4 EP8	✓	✓	✓	✓		
3008 (P84)	engine management ECU	CMM DCM71	✓	✓	✓	✓		
3008 (P84)	engine management ECU	MEVD17 4 4	✓	✓	✓	✓		
3008 (P84)	engine management ECU	CMM MD1CS003	✓	✓	✓	✓		
3008 (P84)	engine management ECU	CMM VD56	✓	✓	✓	✓		
3008 (P84)	engine management ECU	CMM MG1CS042	✓	✓	✓	✓		
3008 (P84)	manual gearbox	BVA AM6 AT6 UDS	✓	✓	✓	✓		
3008 (P84)	manual gearbox	BVA AXN8	✓	✓	✓			
3008 (P84)	electric control ECU	COMELEC2	✓	✓	✓	✓		
3008 (P84)	System (ABS) or	ESP90	✓	✓	✓	✓		S0038
3008 (P84)	pretensioners ECU	RBG SPEED UDS	✓	✓	✓	✓		
3008 (P84)	airbags and pretensioners ECU	RBG UDS	✓	✓	✓	✓		
3008 (P84)	built-in systems interface	BSI2010 EV	✓	✓	✓	✓		
3008 (P84)	power steering	DAE BVH2	✓	✓	✓	✓		
3008 (P84)	Electric steering lock	AVE	✓	✓	✓			
3008 (P84)	anti-theft alarm	MUS2	✓	✓	✓	✓		
3008 (P84)	Intrusion alarm siren	SIR	✓	✓	✓	✓		

3008 (P84)	instrument panel	CIROCCO	✓	✓	✓	✓		
3008 (P84)	instrument panel	COMBINE UDS	✓	✓	✓	✓	✓	
3008 (P84)	right-hand side or	BAAST	✓					
3008 (P84)	air conditioning	BCC	✓	✓	✓	✓		
3008 (P84)	rear air conditioning ECU	BCC ADD	✓	✓	✓	✓		
3008 (P84)	diesel fuel additive pump	PADDGO TI UDS	✓	✓	✓	✓		
3008 (P84)	Voltage maintaining device	DMTC	✓					
3008 (P84)	Sequential gear lever	ESM	✓	✓	✓	✓		
3008 (P84)	Dynamic headlamp height adjuster	LADCT	✓	✓	✓	✓		
3008 (P84)	engine wiring housing	BSM 2010	✓	✓	✓	✓		
3008 (P84)	Trailer relay unit	BSG 2010 RQ	✓	✓	✓	✓		
3008 (P84)	battery charge status control unit	BECB GEN2	✓	✓	✓	✓		
3008 (P84)	supplies protection and management unit	BPGA2010	✓	✓	✓	✓		
3008 (P84)	controls under the steering wheel	COM2008P	✓	✓	✓	✓	✓	
3008 (P84)	Controls on the steering wheel / Integral controls steering wheel	VCI	✓	✓	✓	✓		
3008 (P84)	Traction control mode selector	ASR	✓			✓		
3008 (P84)	Multifunction control panel	FMUX	✓	✓	✓	✓		
3008 (P84)	seat belt not fastened warning lights unit	TNB 2010	✓					
3008 (P84)	windscreen wiper	ESV	✓	✓	✓	✓		
3008 (P84)	rain and sunlight sensor	CDPL UDS HELLA	✓	✓	✓	✓		

3008 (P84)	Panoramic visual assistance ECU	AVP	✓	✓	✓	✓		
3008 (P84)	Multifunction video camera (CMF)	CVM 2	✓	✓	✓	✓		
3008 (P84)	Vehicle Distance Assistance	ARTIV UDS	✓	✓	✓	✓		
3008 (P84)	multifunction screen	EMF C UDS	✓	✓	✓			
3008 (P84)	touch screen	EMF DGT LVDS BD	✓	✓	✓	✓		
3008 (P84)	radio	RD6	✓	✓	✓	✓		
3008 (P84)	Service module / Independent telematic unit	BTA 2	✓	✓	✓	✓		
3008 (P84)	Service module / Independent telematic unit	BTA CN	✓	✓	✓			
3008 (P84)	Service module / Independent telematic unit	BTA 3R	✓	✓	✓	✓		
3008 (P84)	Service module / Independent telematic unit	BTA 3S	✓	✓	✓	✓		
3008 (P84)	external CD player	CDE	✓	✓	✓	✓	✓	
3008 (P84)	audio amplifier	AMPLI AUDIO	✓	✓	✓			
3008 (P84)	driver's door module	PDPC UDS	✓	✓	✓	✓		
3008 (P84)	driver's door module	PDPC	✓	✓	✓	✓	✓	
3008 (P84)	Motorised Boot Unit	VERINS MOTORISES	✓	✓	✓	✓		
3008 (P84)	pads and ventilation	BRNC AVG	✓			✓		
3008 (P84)	heated pads and	BRNC AVD	✓			✓		
3008 (P84)	ECU	SCB D	✓	✓	✓	✓		
3008 (P84)	pneumatic functions	SPB D	✓			✓		
3008 (P84)	pneumatic functions	SPB P	✓			✓		
4007	engine management ECU	EDC16CP39	✓	✓	✓	✓	✓	S0037
4007	engine management ECU	MIVEC	✓	✓	✓	✓	✓	

4007	engine management ECU	EDC16CP39 E5	✓	✓	✓	✓	✓	S0037
4007	manual gearbox	BV CVT	✓	✓	✓	✓		
4007	manual gearbox	BOITE GETRAG	✓	✓	✓	✓		
4007	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS	✓	✓	✓	✓		
4007	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP	✓	✓	✓	✓		S0035
4007	airbags and pretensioners ECU	SAC TRW	✓	✓	✓	✓		
4007	built-in systems interface	ETACS SUV	✓	✓	✓	✓		
4007	instrument panel	COMBINE	✓	✓	✓	✓	✓	S0033
4007	coded immobiliser / Hands-free unit	WCM	✓	✓	✓	✓		
4007	air conditioning	CLIM REGULEE	✓	✓	✓	✓		
4007	parking assistance	AAS MMC	✓	✓	✓	✓		
4007	gear lever	LEVIER DCT	✓	✓	✓	✓		
4007	rear final drive controlled clutch ECU	TRANSMISSION	✓	✓	✓	✓		
4007	Portable Unit	KML	✓	✓	✓	✓		
4007	aid to navigation	NAVIGATION	✓	✓	✓			
4007	radio	AUTORADIO 3	✓	✓	✓	✓	✓	
4007	rear left door control pad	PDPARG	✓			✓		
4007	driver's door module	PDPC	✓			✓		
4007	passenger door module	PDPP	✓			✓		
4007	rear right door control pad	PDPARD	✓			✓		
4007	sunroof	TO WEBASTO	✓			✓		
4007	sensor	CAV	✓	✓	✓			S0035

4007	rain and sunlight sensor	CDPL	✓			✓		
4007	height adjuster	CORPRO	✓	✓	✓	✓		
4008 (J3)	engine management ECU	MIVEC	✓	✓	✓	✓	✓	
4008 (J3)	engine management ECU	CMM 4A92	✓	✓	✓	✓	✓	
4008 (J3)	engine management ECU	HDI 4N13	✓	✓	✓	✓	✓	
4008 (J3)	engine management ECU	HDI SID807 J3J4	✓	✓	✓	✓	✓	
4008 (J3)	automatic or piloted manual gearbox	BV CVT	✓	✓	✓	✓		
4008 (J3)	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS 4x4	✓	✓	✓	✓		
4008 (J3)	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP 4x4	✓	✓	✓	✓	✓	
4008 (J3)	airbags and pretensioners ECU	SAC TRW	✓	✓	✓	✓	✓	
4008 (J3)	built-in systems interface	ETACS SUV	✓	✓	✓	✓	✓	
4008 (J3)	power steering	EPS	✓	✓	✓	✓		
4008 (J3)	power steering (Recent vehicle)	EPS M	✓	✓	✓	✓		
4008 (J3)	anti-theft alarm	ALARME MMC	✓	✓	✓	✓		
4008 (J3)	instrument panel	COMBINE	✓	✓	✓	✓	✓	S0033
4008 (J3)	coded immobiliser / Hands-free unit	WCM	✓	✓	✓	✓		
4008 (J3)	coded immobiliser / Hands-free unit	KOS	✓	✓	✓	✓	✓	
4008 (J3)	Starting authorisation ECU	OSS	✓	✓	✓	✓		
4008 (J3)	Stop and Start ECU	STT MMC	✓	✓	✓	✓		
4008 (J3)	air conditioning	CLIM REGULEE	✓	✓	✓	✓	✓	
4008 (J3)	parking assistance	AAS MMC	✓	✓	✓	✓		

4008 (J3)	rear final drive controlled clutch ECU	TRANSMISSION	✓	✓	✓	✓		
4008 (J3)	driver's door module	PDPC	✓			✓		
4008 (J3)	steering wheel angle sensor	CAV	✓	✓	✓			S0035
4008 (J3)	rain and sunlight sensor	CDPL	✓			✓		
4008 (J3)	Dynamic headlamp height adjuster	CORPRO	✓	✓	✓	✓	✓	
4008 (J3)	radio	AUTORADIO 3	✓	✓	✓	✓		
4008 (J3)	aid to navigation	NAVIGATION	✓	✓	✓			
4008 (P84)	engine management ECU	VD46	✓	✓	✓	✓		
4008 (P84)	engine management ECU	MED17 4 4	✓	✓	✓	✓		
4008 (P84)	engine management ECU	DCM62	✓	✓	✓	✓		
4008 (P84)	engine management ECU	EDC17C60	✓	✓	✓	✓		
4008 (P84)	engine management ECU	MED17 4 4 EP8	✓	✓	✓	✓		
4008 (P84)	engine management ECU	CMM DCM71	✓	✓	✓	✓		
4008 (P84)	engine management ECU	MEVD17 4 4	✓	✓	✓	✓		
4008 (P84)	engine management ECU	CMM MD1CS003	✓	✓	✓	✓		
4008 (P84)	engine management ECU	CMM VD56	✓	✓	✓	✓		
4008 (P84)	engine management ECU	CMM MG1CS042	✓	✓	✓	✓		
4008 (P84)	automatic or piloted manual gearbox	BVA AM6 AT6 UDS	✓	✓	✓	✓		
4008 (P84)	automatic or piloted manual gearbox	BVA AXN8	✓	✓	✓			
4008 (P84)	automatic gearbox electric control ECU	COMELEC2	✓	✓	✓	✓		
4008 (P84)	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90	✓	✓	✓	✓		S0035 S0039 S0038
4008 (P84)	airbags and pretensioners ECU	RBG SPEED UDS	✓	✓	✓	✓		

4008 (P84)	pretensioners ECU	RBG UDS	✓	✓	✓	✓		
4008 (P84)	built-in systems interface	BSI2010 EV	✓	✓	✓	✓		
4008 (P84)	power steering	DAE BVH2	✓	✓	✓	✓		
4008 (P84)	Electric steering lock	AVE	✓	✓	✓			
4008 (P84)	instrument panel	CIROCCO	✓	✓	✓	✓		
4008 (P84)	instrument panel	COMBINE UDS	✓	✓	✓	✓	✓	
4008 (P84)	Hands full access ECU, right-hand side or rear	BAAST	✓					
4008 (P84)	air conditioning	BCC	✓	✓	✓	✓		
4008 (P84)	ECU	BCC ADD	✓	✓	✓	✓		
4008 (P84)	device	DMTC	✓					
4008 (P84)	Sequential gear lever	ESM	✓	✓	✓	✓		
4008 (P84)	height adjuster	LADCT	✓	✓	✓	✓		
4008 (P84)	battery charge status control unit	BECB GEN2	✓	✓	✓	✓		
4008 (P84)	controls under the steering wheel	COM2008P	✓	✓	✓	✓	✓	
4008 (P84)	steering wheel / selector	VCI	✓	✓	✓	✓		
4008 (P84)	panel	ASR	✓			✓		
4008 (P84)	panel	FMUX	✓	✓	✓	✓		
4008 (P84)	windscreen wiper	ESV	✓	✓	✓	✓		
4008 (P84)	rain and sunlight sensor	CDPL UDS HELLA	✓	✓	✓	✓		
4008 (P84)	Panoramic visual assistance ECU	AVP	✓	✓	✓	✓		
4008 (P84)	camera (CMF)	CVM 2	✓	✓	✓	✓		
4008 (P84)	Vehicle Distance Assistance	ARTIV UDS	✓	✓	✓	✓		
4008 (P84)	touch screen	EMF DGT LVDS BD	✓	✓	✓	✓		
4008 (P84)	Service module / Independent telematic unit	BTA 2	✓	✓	✓	✓		
4008 (P84)	Independent telematic	BTA CN	✓	✓	✓			

4008 (P84)	Independent telematic	BTA 3R	✓	✓	✓	✓		
4008 (P84)	Service module / Independent telematic unit	BTA 3S	✓	✓	✓	✓		
4008 (P84)	audio amplifier	AMPLI AUDIO	✓	✓	✓			
4008 (P84)	driver's door module	PDPC UDS	✓	✓	✓	✓		
4008 (P84)	driver's door module	PDPC	✓	✓	✓	✓	✓	
4008 (P84)	Motorised Boot Unit	VERINS MOTORISES	✓	✓	✓	✓		
4008 (P84)	pads and ventilation	BRNC AVG	✓			✓		
4008 (P84)	heated pads and	BRNC AVD	✓			✓		
4008 (P84)	Driver's seat comfort ECU	SCB D	✓	✓	✓	✓		
4008 (P84)	pneumatic functions	SPB D	✓			✓		
4008 (P84)	pneumatic functions	SPB P	✓			✓		
5008	engine management ECU	DCM35 BR2	✓	✓	✓	✓	✓	S0037 S0036
5008	engine management ECU	EDC16C3	✓	✓	✓	✓	✓	S0037 S0036
5008	engine management ECU	MEV17 4 EURO4	✓	✓	✓	✓	✓	S0034
5008	engine management ECU	MED17 4 EURO4	✓	✓	✓	✓	✓	S0034
5008	engine management ECU	MEV17 4 EURO5	✓	✓	✓	✓	✓	S0034
5008	engine management ECU	MED17 4 EURO5	✓	✓	✓	✓	✓	S0034
5008	engine management ECU	DCM35	✓	✓	✓	✓	✓	S0036 S0037
5008	engine management ECU	HDI SID807	✓	✓	✓	✓	✓	S0037
5008	engine management ECU	MEV17 4 2	✓	✓	✓	✓	✓	
5008	engine management ECU	HDI SID807 BR2	✓	✓	✓	✓	✓	S0037
5008	engine management ECU	MED17 4 2	✓	✓	✓	✓	✓	S0034
5008	engine management ECU	DCM35 HY	✓	✓	✓	✓	✓	S0037 S0036
5008	engine management ECU	MM6KP	✓	✓	✓	✓	✓	S0034
5008	engine management ECU	DCM62	✓	✓	✓	✓		
5008	engine management ECU	EDC17C60	✓	✓	✓	✓		
5008	engine management ECU	MED17 4 4	✓	✓	✓	✓		
5008	engine management ECU	VD46	✓	✓	✓	✓		
5008	automatic or piloted manual gearbox	BVA AM6 AT6 EURO5	✓	✓	✓	✓	✓	
5008	automatic or piloted manual gearbox	CFC300P HY	✓	✓	✓	✓	✓	

5008	automatic or piloted manual gearbox	CFC300P	✓	✓	✓	✓	✓	
5008	automatic or piloted manual gearbox	BVA AM6 AT6 UDS	✓	✓	✓	✓		
5008	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81	✓	✓	✓	✓	✓	S0039 S0035 S0038
5008	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90	✓	✓	✓	✓		
5008	airbags and pretensioners ECU	SAC AUTOLIV	✓	✓	✓	✓		
5008	built-in systems interface	BSI	✓	✓	✓	✓		
5008	power steering	GEP	✓	✓	✓	✓	✓	
5008	anti-theft alarm	ALARME	✓	✓	✓	✓	✓	
5008	instrument panel	COMBINE	✓	✓	✓	✓		
5008	Control panel dot matrix display	MATT	✓	✓	✓	✓	✓	
5008	air conditioning	CLIM REGULEE	✓	✓	✓	✓	✓	
5008	UNDER-INFLATION DETECTION	DSG	✓	✓	✓	✓		
5008	UNDER-INFLATION DETECTION	DSG UDS	✓	✓	✓	✓		
5008	parking assistance	AAS	✓	✓	✓	✓		
5008	parking assistance	AAS UDS	✓	✓	✓	✓		
5008	pump	PADDGO	✓	✓	✓	✓		
5008	pump	PADDGO E5	✓	✓	✓	✓		
5008	pump	PADDGO TI E6	✓	✓	✓	✓		
5008	height adjuster	LADCT	✓	✓	✓	✓	✓	
5008	battery charge status control unit	BECB	✓	✓	✓	✓		

5008	battery charge status control unit	BECB GEN2	✓	✓	✓	✓		
5008	Vehicle Distance Assistance	ARTIV	✓	✓	✓	✓		
5008	Electric secondary brake	FSE	✓	✓	✓	✓		
5008	Trailer relay unit	BSR	✓	✓	✓	✓		
5008	engine wiring housing	BSM	✓	✓	✓	✓		
5008	controls under the steering wheel	HDC	✓	✓	✓	✓		
5008	steering wheel	COM2008P	✓	✓	✓	✓		
5008	multifunction screen	EMF A	✓	✓	✓	✓	✓	
5008	multifunction screen	EMF C	✓	✓	✓	✓	✓	
5008	windscreen wiper	MOTEV	✓	✓	✓			
5008	radio	AUTORADIO	✓	✓	✓	✓	✓	
5008	radio	RD45	✓	✓	✓	✓		
5008	radio	RD43	✓	✓	✓	✓		
5008	Telematic unit (RTx) or audio-navigation	RADIONAV RNEG	✓	✓	✓	✓		
5008	or audio-navigation	RADIONAV NG4	✓	✓	✓	✓	✓	
5008	Telematic unit (RTx) or audio-navigation	RNEG2010	✓	✓	✓	✓		
5008	Telematic unit (RTx) or audio-navigation	RADIONAV RNEGC	✓	✓	✓	✓		
5008	Telematic unit (RTx) or audio-navigation	MRN	✓	✓	✓	✓		
5008	audio amplifier	AMPLI AUDIO	✓	✓	✓		✓	
5008	CD changer / external CD player	CHANGEUR CD	✓	✓	✓			
5008	Hands-free Kit / Portable Unit	BOITIER NOMADE	✓	✓	✓	✓	✓	
5008	driver's door module	PDPC	✓	✓	✓	✓	✓	
5008	Service module / Independent telematic unit	MD SERV	✓	✓	✓	✓	✓	

5008	Independent telematic unit	BTA	✓	✓	✓	✓	✓	
5008	Service module / Independent telematic unit	BLVV	✓	✓	✓	✓		
5008	rain and sunlight sensor	PLUIE LUMINOSITE	✓	✓	✓			
5008	Voltage maintaining device	DMTC	✓					
5008	Voltage maintaining device	DMTR	✓	✓	✓			
5008	Voltage maintaining device	DMTR DTC3B	✓	✓	✓			
5008	Head Up Display	VTH	✓	✓	✓	✓		
5008	Head Up Display	VTH UDS	✓	✓	✓	✓		
5008	high frequency receiver	RHF	✓	✓	✓	✓		
5008	seat belt not fastened warning lights unit	TNB	✓					
5008 (P87)	engine management ECU	VD46	✓	✓	✓	✓		
5008 (P87)	engine management ECU	MED17 4 4	✓	✓	✓	✓		
5008 (P87)	engine management ECU	DCM62	✓	✓	✓	✓		
5008 (P87)	engine management ECU	EDC17C60	✓	✓	✓	✓		
5008 (P87)	engine management ECU	MED17 4 4 EP8	✓	✓	✓	✓		
5008 (P87)	engine management ECU	CMM DCM71	✓	✓	✓	✓		
5008 (P87)	engine management ECU	MEVD17 4 4	✓	✓	✓	✓		
5008 (P87)	engine management ECU	CMM MD1CS003	✓	✓	✓	✓		
5008 (P87)	engine management ECU	CMM VD56	✓	✓	✓	✓		
5008 (P87)	engine management ECU	CMM MG1CS042	✓	✓	✓	✓		
5008 (P87)	manual gearbox	BVA AM6 AT6 UDS	✓	✓	✓	✓		
5008 (P87)	manual gearbox	BVA AXN8	✓	✓	✓			
5008 (P87)	electric control ECU	COMELEC2	✓	✓	✓	✓		

5008 (P87)	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90	✓	✓	✓	✓		S0035 S0039 S0038
5008 (P87)	airbags and pretensioners ECU	RBG SPEED UDS	✓	✓	✓	✓		
5008 (P87)	airbags and pretensioners ECU	RBG UDS	✓	✓	✓	✓		
5008 (P87)	built-in systems interface	BSI2010 EV	✓	✓	✓	✓		
5008 (P87)	power steering	DAE BVH2	✓	✓	✓	✓		
5008 (P87)	Electric steering lock	AVE	✓	✓	✓			
5008 (P87)	anti-theft alarm	MUS2	✓	✓	✓	✓		
5008 (P87)	Intrusion alarm siren	SIR	✓	✓	✓	✓		
5008 (P87)	instrument panel	CIROCCO	✓	✓	✓	✓		
5008 (P87)	instrument panel	COMBINE UDS	✓	✓	✓	✓	✓	
5008 (P87)	Hands full access ECU, right-hand side or rear	BAAST	✓					
5008 (P87)	air conditioning	BCC	✓	✓	✓	✓		
5008 (P87)	rear air conditioning ECU	BCC ADD	✓	✓	✓	✓		
5008 (P87)	diesel fuel additive pump	PADDGO TI UDS	✓	✓	✓	✓		
5008 (P87)	Voltage maintaining device	DMTC	✓					
5008 (P87)	Sequential gear lever	ESM	✓	✓	✓	✓		
5008 (P87)	Dynamic headlamp height adjuster	LADCT	✓	✓	✓	✓		
5008 (P87)	engine wiring housing	BSM 2010	✓	✓	✓	✓		
5008 (P87)	Trailer relay unit	BSG 2010 RQ	✓	✓	✓	✓		
5008 (P87)	battery charge status control unit	BECEB GEN2	✓	✓	✓	✓		
5008 (P87)	supplies protection and management unit	BPGA2010	✓	✓	✓	✓		

5008 (P87)	controls under the steering wheel	COM2008P	✓	✓	✓	✓	✓	
5008 (P87)	Controls on the steering wheel / Integral controls steering wheel	VCI	✓	✓	✓	✓		
5008 (P87)	Traction control mode selector	ASR	✓			✓		
5008 (P87)	Multifunction control panel	FMUX	✓	✓	✓	✓		
5008 (P87)	seat belt not fastened warning lights unit	TNB 2010	✓					
5008 (P87)	windscreen wiper	ESV	✓	✓	✓	✓		
5008 (P87)	rain and sunlight sensor	CDPL UDS HELLA	✓	✓	✓	✓		
5008 (P87)	Panoramic visual assistance ECU	AVP	✓	✓	✓	✓		
5008 (P87)	Multifunction video camera (CMF)	CVM 2	✓	✓	✓	✓		
5008 (P87)	Vehicle Distance Assistance	ARTIV UDS	✓	✓	✓	✓		
5008 (P87)	multifunction screen	EMF C UDS	✓	✓	✓			
5008 (P87)	touch screen	EMF DGT LVDS BD	✓	✓	✓	✓		
5008 (P87)	radio	RD6	✓	✓	✓	✓		
5008 (P87)	Service module / Independent telematic unit	BTA 2	✓	✓	✓	✓		
5008 (P87)	Independent telematic	BTA CN	✓	✓	✓			
5008 (P87)	Independent telematic	BTA 3R	✓	✓	✓	✓		
5008 (P87)	Independent telematic	BTA 3S	✓	✓	✓	✓		
5008 (P87)	external CD player	CDE	✓	✓	✓	✓	✓	
5008 (P87)	audio amplifier	AMPLI AUDIO	✓	✓	✓			
5008 (P87)	driver's door module	PDPC UDS	✓	✓	✓	✓		
5008 (P87)	driver's door module	PDPC	✓	✓	✓	✓	✓	

5008 (P87)	Motorised Boot Unit	VERINS MOTORISES	✓	✓	✓	✓		
5008 (P87)	Front left seat heated pads and ventilation regulation ECU	BRNC AVG	✓			✓		
5008 (P87)	Front right seat heated pads and ventilation regulation ECU	BRNC AVD	✓			✓		
5008 (P87)	Driver's seat comfort ECU	SCB D	✓	✓	✓	✓		
5008 (P87)	Driver's seat pneumatic functions ECU	SPB D	✓			✓		
5008 (P87)	pneumatic functions	SPB P	✓			✓		
BIPPER	engine management ECU	EDC16C34	✓	✓	✓	✓		
BIPPER	engine management ECU	V34P	✓	✓	✓	✓		
BIPPER	engine management ECU	V342	✓	✓	✓	✓	✓	
BIPPER	engine management ECU	HDI 8DF2	✓	✓	✓	✓		
BIPPER	engine management ECU	HDI 8DF3	✓	✓	✓	✓		
BIPPER	engine management ECU	HDI 9DF	✓	✓	✓	✓		
BIPPER	automatic or piloted manual gearbox	BVMP MTA	✓	✓	✓	✓		
BIPPER	manual gearbox	BVMP	✓	✓	✓	✓		
BIPPER	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS81	✓	✓	✓	✓	✓	
BIPPER	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81	✓	✓	✓	✓		S0035
BIPPER	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90 F	✓	✓	✓	✓		

BIPPER	airbags and pretensioners ECU	SAC AUTOLIV	✓	✓	✓	✓		
BIPPER	built-in systems interface	BCM	✓	✓	✓	✓		
BIPPER	instrument panel	COMBINE	✓	✓	✓	✓	✓	
BIPPER	parking assistance	AAS	✓	✓	✓	✓		
BIPPER	Telematic unit (RTx) or audio-navigation	CTM	✓	✓	✓	✓		
Partner 2 Iran-AMLAT	engine management ECU	ME745	✓	✓	✓	✓		
Partner 2 Iran-AMLAT	engine management ECU	ME749	✓	✓	✓	✓		
Partner 2 Iran-AMLAT	engine management ECU	EDC17C10 BR2	✓	✓	✓	✓		
Partner 2 Iran-AMLAT	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS81	✓	✓	✓	✓		
Partner 2 Iran-AMLAT	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81	✓	✓	✓	✓		
Partner 2 Iran-AMLAT	airbags and pretensioners ECU	SAC AUTOLIV	✓	✓	✓			
Partner 2 Iran-AMLAT	built-in systems interface	BSI	✓			✓		
Partner 2 Iran-AMLAT	instrument panel	COMBINE	✓			✓		
Partner 2 Iran-AMLAT	multifunction screen	AMF	✓			✓		
Partner 2 Iran-AMLAT	controls under the steering wheel	COM2000	✓			✓		
Partner 2 Iran-AMLAT	radio	AUTORADIO	✓	✓	✓	✓		
Partner 2 Iran-AMLAT	radio	RDE	✓	✓	✓	✓		
Partner 2 Iran-AMLAT	Service module / Independent telematic unit	BLVV	✓	✓	✓	✓		
PARTNER 2 (M69)	engine management ECU	EDC17C10 BR2	✓	✓	✓	✓	✓	S0037
PARTNER 2 (M69)	engine management ECU	ME749 EC5	✓	✓	✓	✓	✓	S0034

PARTNER 2 (M69)	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABSMK70 1	✓	✓	✓	✓	✓	S0039
PARTNER 2 (M69)	airbags and pretensioners ECU	SAC AUTOLIV	✓	✓	✓	✓		
PARTNER 2 (M69)	interface	BSI	✓	✓	✓	✓		S0033
PARTNER 2 (M69)	instrument panel	COMBINE	✓	✓	✓	✓	✓	
PARTNER 2 (M69)	controls under the steering wheel	HDC	✓	✓	✓	✓	✓	
PARTNER 2 (M69)	Telematic unit (RTx) or audio-navigation	AIO	✓	✓	✓	✓		
PARTNER 2 (M69)	radio	RD6	✓	✓	✓	✓		
PARTNER (B9)	engine management ECU	ME745	✓	✓	✓	✓		
PARTNER (B9)	engine management ECU	EDC16C3	✓	✓	✓	✓	✓	S0037 S0036
PARTNER (B9)	engine management ECU	MEV17 4 EURO5	✓	✓	✓	✓		
PARTNER (B9)	engine management ECU	EDC17C10 BR2	✓	✓	✓	✓	✓	S0037 S0036
PARTNER (B9)	engine management ECU	MEV17 4 2	✓	✓	✓	✓	✓	
PARTNER (B9)	engine management ECU	HDI SID807 BR2	✓	✓	✓	✓	✓	S0037
PARTNER (B9)	engine management ECU	HDI SID807	✓	✓	✓	✓	✓	S0037
PARTNER (B9)	engine management ECU	EDC17C60	✓	✓	✓	✓		S0037
PARTNER (B9)	engine management ECU	VD46	✓	✓	✓	✓		
PARTNER (B9)	automatic or piloted manual gearbox	CFC300P	✓	✓	✓	✓	✓	
PARTNER (B9)	automatic or piloted manual gearbox	BVMP MCP UDS	✓	✓	✓	✓		
PARTNER (B9)	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS81	✓	✓	✓	✓	✓	S0035 S0039
PARTNER (B9)	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81	✓	✓	✓	✓	✓	S0035 S0039

PARTNER (B9)	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90	✓	✓	✓	✓		S0035 S0039 S0038
PARTNER (B9)	airbags and pretensioners ECU	SAC AUTOLIV	✓	✓	✓	✓		
PARTNER (B9)	built-in systems interface	BSI	✓	✓	✓			S0033
PARTNER (B9)	power steering	GEP	✓	✓	✓	✓	✓	
PARTNER (B9)	anti-theft alarm	ALARME	✓	✓	✓	✓		
PARTNER (B9)	instrument panel	COMBINE	✓	✓	✓	✓	✓	
PARTNER (B9)	air conditioning	CLIM REGULEE	✓	✓	✓	✓	✓	
PARTNER (B9)	air conditioning	CLIM	✓	✓	✓	✓	✓	
PARTNER (B9)	UNDER-INFLATION DETECTION	DSG	✓	✓	✓	✓		
PARTNER (B9)	UNDER-INFLATION DETECTION	DSG UDS	✓	✓	✓	✓		
PARTNER (B9)	parking assistance	AAS	✓	✓	✓	✓		
PARTNER (B9)	parking assistance	AAS UDS	✓	✓	✓	✓		
PARTNER (B9)	diesel fuel additive pump	PADDGO	✓	✓	✓	✓		
PARTNER (B9)	diesel fuel additive pump	PADDGO E5	✓	✓	✓	✓		
PARTNER (B9)	diesel fuel additive pump	PADDGO TI E6	✓	✓	✓	✓		
PARTNER (B9)	battery charge status control unit	BECEB	✓	✓	✓	✓		
PARTNER (B9)	battery charge status control unit	BECEB GEN2	✓	✓	✓	✓		
PARTNER (B9)	engine wiring housing	BSM	✓	✓	✓	✓		
PARTNER (B9)	bodywork conversion unit	BTC	✓	✓	✓	✓		

PARTNER (B9)	Trailer relay unit	BSR	✓	✓	✓	✓		
PARTNER (B9)	multifunction screen	EMF A	✓	✓	✓	✓	✓	
PARTNER (B9)	multifunction screen	EMF C	✓	✓	✓	✓	✓	
PARTNER (B9)	controls under the steering wheel	HDC	✓	✓	✓	✓	✓	
PARTNER (B9)	Hands-free Kit / Portable Unit	KML	✓	✓	✓	✓		
PARTNER (B9)	Hands-free Kit / Portable Unit	BOITIER NOMADE	✓	✓	✓	✓		
PARTNER (B9)	radio	AUTORADIO	✓	✓	✓	✓		
PARTNER (B9)	radio	RD45	✓	✓	✓	✓	✓	
PARTNER (B9)	Telematic unit (RTx) or audio-navigation	RADIONAV RNEG	✓	✓	✓	✓	✓	
PARTNER (B9)	Telematic unit (RTx) or audio-navigation	RNEG2010	✓	✓	✓	✓		
PARTNER (B9)	Telematic unit (RTx) or audio-navigation	SMEG PLUS	✓	✓	✓	✓		
PARTNER (B9)	CD changer / external CD player	CHANGEUR CD	✓	✓	✓			
PARTNER (B9)	Traction control mode selector	ASR	✓			✓		
PARTNER (B9)	Service module / Independent telematic unit	BTA	✓	✓	✓	✓	✓	
PARTNER (B9)	Service module / Independent telematic unit	BTA 3R	✓	✓	✓			
PARTNER (B9)	Service module / Independent telematic unit	BTA 3S	✓	✓	✓	✓		
PARTNER (B9)	rain and sunlight sensor	PLUIE LUMINOSITE	✓	✓	✓			

PARTNER (B9)	high frequency receiver	RHF	✓	✓	✓	✓		
PARTNER (B9)	Voltage maintaining device	DMTC	✓					
PARTNER (B9)	Voltage maintaining device	DMTR	✓	✓	✓			
PARTNER (B9)	Voltage maintaining device	DMTR DTC3B	✓	✓	✓			
PARTNER (B9)	Vehicle Distance Assistance	LIDAR	✓	✓	✓	✓		
PARTNER Electric (B9e)	traction battery ECU	BMU	✓	✓	✓	✓		
PARTNER Electric (B9e)	Traction battery cells management ECU (module 1)	CMU 01	✓			✓		
PARTNER Electric (B9e)	Traction battery cells management ECU (module 2)	CMU 02	✓			✓		
PARTNER Electric (B9e)	Traction battery cells management ECU (module 3)	CMU 03	✓			✓		
PARTNER Electric (B9e)	Traction battery cells management ECU (module 4)	CMU 04	✓			✓		
(B9e)	management ECU (CMU 05	✓			✓		
(B9e)	management ECU (CMU 06	✓			✓		
(B9e)	management ECU (CMU 07	✓			✓		
(B9e)	management ECU (CMU 08	✓			✓		
(B9e)	management ECU (CMU 09	✓			✓		
(B9e)	management ECU (CMU 10	✓			✓		
(B9e)	electric vehicle ECU	EV ECU	✓	✓	✓	✓		
(B9e)	management ECU	MCU	✓	✓	✓	✓		
(B9e)	System (ABS) or	ABS81	✓	✓	✓	✓	✓	S0035 S0039
(B9e)	System (ABS) or	ESP81	✓	✓	✓	✓	✓	S0035 S0039
(B9e)	System (ABS) or	ESP90	✓	✓	✓	✓		S0038

(B9e)	pretensioners ECU	SAC AUTOLIV	✓	✓	✓	✓		
(B9e)	interface	BSI	✓	✓	✓			S0033
(B9e)	power steering	GEP	✓	✓	✓	✓	✓	
(B9e)	anti-theft alarm	ALARME	✓	✓	✓	✓		
(B9e)	instrument panel	COMBINE	✓	✓	✓	✓	✓	
(B9e)	air conditioning	CLIM REGULEE	✓	✓	✓	✓	✓	
(B9e)	air conditioning	CLIM	✓	✓	✓	✓	✓	
(B9e)	DETECTION	DSG	✓	✓	✓	✓		
(B9e)	DETECTION	DSG UDS	✓	✓	✓	✓		
PARTNER Electric (B9e)	parking assistance	AAS	✓	✓	✓	✓		
PARTNER Electric (B9e)	parking assistance	AAS UDS	✓	✓	✓	✓		
PARTNER Electric (B9e)	radio	AUTORADIO	✓	✓	✓	✓		
PARTNER Electric (B9e)	radio	RD45	✓	✓	✓	✓	✓	
PARTNER Electric (B9e)	On-board charger / direct voltage transformer assembly	OBC DCDC	✓	✓	✓	✓		
PARTNER Electric (B9e)	passenger compartment air heating resistor	CTPA	✓	✓	✓	✓		
PARTNER Electric (B9e)	air con compressor	CCE	✓	✓	✓	✓		
PARTNER Electric (B9e)	Service module / Independent telematic unit	BTA	✓	✓	✓	✓	✓	
PARTNER Electric (B9e)	Service module / Independent telematic unit	BTA 3R	✓	✓	✓			
PARTNER Electric (B9e)	Service module / Independent telematic unit	BTA 3S	✓	✓	✓	✓		
PARTNER Electric (B9e)	multifunction screen	EMF A	✓	✓	✓	✓	✓	

PARTNER Electric (B9e)	multifunction screen	EMF C	✓	✓	✓	✓	✓	
PARTNER Electric (B9e)	Drive train interface ECU	PIU	✓	✓	✓	✓	✓	
PARTNER Electric (B9e)	rain and sunlight sensor	PLUIE LUMINOSITE	✓	✓	✓			
(B9e)	or audio-navigation	RADIONAV RNEG	✓	✓	✓	✓	✓	
PARTNER Electric (B9e)	Telematic unit (RTx) or audio-navigation	RNEG2010	✓	✓	✓	✓		
PARTNER Electric (B9e)	Telematic unit (RTx) or audio-navigation	SMEG PLUS	✓	✓	✓	✓		
PARTNER Electric (B9e)	engine wiring housing	BSM	✓	✓	✓	✓		
PARTNER Electric (B9e)	Gateway wiring housing	BSP	✓	✓	✓	✓		
PARTNER Electric (B9e)	controls under the steering wheel	HDC	✓	✓	✓	✓	✓	
RIFTER (K9) : PARTNER (K9)	engine management ECU	EDC17C60	✓	✓	✓	✓		
RIFTER (K9) : PARTNER (K9)	engine management ECU	CMM MD1CS003	✓	✓	✓	✓		
RIFTER (K9) : PARTNER (K9)	engine management ECU	EDC17C10 BR2	✓	✓	✓	✓		
RIFTER (K9) : PARTNER (K9)	engine management ECU	V46 21	✓	✓	✓	✓		
RIFTER (K9) : PARTNER (K9)	engine management ECU	CMM VD56	✓	✓	✓	✓		
RIFTER (K9) : PARTNER (K9)	automatic or piloted manual gearbox	BVA AXN8	✓	✓	✓	✓		
RIFTER (K9) : PARTNER (K9)	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90	✓	✓	✓	✓		
RIFTER (K9) : PARTNER (K9)	airbags and pretensioners ECU	RBG SPEED UDS	✓	✓	✓	✓		

RIFTER (K9) : PARTNER (K9)	built-in systems interface	BSI2010 EV	✓	✓	✓	✓		
RIFTER (K9) : PARTNER (K9)	power steering	DAE BVH2	✓	✓	✓	✓		
RIFTER (K9) : PARTNER (K9)	Electric steering lock	AVE	✓	✓	✓			
RIFTER (K9) : PARTNER (K9)	anti-theft alarm	MUS2	✓	✓	✓	✓		
RIFTER (K9) : PARTNER (K9)	Intrusion alarm siren	SIR	✓	✓	✓	✓		
RIFTER (K9) : PARTNER (K9)	instrument panel	COMBINE UDS	✓	✓	✓	✓		
RIFTER (K9) : PARTNER (K9)	air conditioning	BCC	✓	✓	✓	✓		
RIFTER (K9) : PARTNER (K9)	parking assistance	AAS UDS G6	✓	✓	✓	✓		
RIFTER (K9) : PARTNER (K9)	diesel fuel additive pump	PADDGO TI UDS	✓	✓	✓	✓		
RIFTER (K9) : PARTNER (K9)	overload indicator ECU	OLVI	✓	✓	✓	✓		
RIFTER (K9) : PARTNER (K9)	Trailer relay unit	BSG 2010 RQ	✓	✓	✓	✓		
RIFTER (K9) : PARTNER (K9)	bodywork conversion unit	BSG 2010 TC	✓	✓	✓	✓		
RIFTER (K9) : PARTNER (K9)	battery charge status control unit	BECB GEN2	✓	✓	✓	✓		
RIFTER (K9) : PARTNER (K9)	Head Up Display	VTH UDS	✓	✓	✓	✓		
RIFTER (K9) : PARTNER (K9)	controls under the steering wheel	COM2008P	✓	✓	✓	✓		
RIFTER (K9) : PARTNER (K9)	Controls on the steering wheel / Integral controls steering wheel	VCI	✓	✓	✓	✓		

RIFTER (K9) : PARTNER (K9)	Traction control mode selector	ASR	✓			✓		
RIFTER (K9) : PARTNER (K9)	Multifunction control panel	FMUX	✓	✓	✓	✓		
RIFTER (K9) : PARTNER (K9)	seat belt not fastened warning lights unit	TNB 2010	✓					
RIFTER (K9) : PARTNER (K9)	rain and sunlight sensor	CDPL UDS HELLA	✓	✓	✓	✓		
RIFTER (K9) : PARTNER (K9)	Interior mirror with screen	SVSB	✓			✓		
RIFTER (K9) : PARTNER (K9)	Multifunction video camera (CMF)	CVM 3	✓	✓	✓	✓		
RIFTER (K9) : PARTNER (K9)	multifunction screen	EMF C UDS	✓	✓	✓	✓		
RIFTER (K9) : PARTNER (K9)	touch screen	EMF DGT LVDS BD	✓	✓	✓	✓		
RIFTER (K9) : PARTNER (K9)	Audio- navigation/telematic unit/connected audio system	NAC	✓	✓	✓	✓		
RIFTER (K9) : PARTNER (K9)	Audio- navigation/telematic unit/connected audio system	RCC	✓	✓	✓	✓		
(K9)	radio	RD6	✓	✓	✓	✓		
(K9)	telematic unit	CRT UDS KOSTAL	✓					
RIFTER (K9) : PARTNER (K9)	Service module / Independent telematic unit	BTA 3S	✓	✓	✓	✓		
RIFTER (K9) : PARTNER (K9)	external CD player	CDE	✓	✓	✓	✓		
RIFTER (K9) : PARTNER (K9)	driver's door module	PDPC UDS	✓	✓	✓	✓		
RIFTER (K9) : PARTNER (K9)	additional heating	BECH	✓			✓		

EXPERT 3	engine management ECU	DCM35 BR2	✓	✓	✓	✓		
EXPERT 3	engine management ECU	EDC16C3	✓	✓	✓	✓	✓	S0036
EXPERT 3	engine management ECU	HDI SID803A	✓	✓	✓	✓		S0037
EXPERT 3	engine management ECU	MM6KP	✓	✓	✓	✓	✓	S0034
EXPERT 3	engine management ECU	DCM35	✓	✓	✓	✓	✓	S0036 S0037
EXPERT 3	engine management ECU	EDC17C10 BR2	✓	✓	✓	✓	✓	S0036 S0037
EXPERT 3	automatic or piloted manual gearbox	BVA AM6 AT6 EURO5	✓	✓	✓	✓	✓	
EXPERT 3	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS81	✓	✓	✓	✓	✓	S0035 S0039
EXPERT 3	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP81	✓	✓	✓	✓	✓	S0035 S0039
EXPERT 3	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS8 BOSCH	✓	✓	✓	✓	✓	S0035 S0039
EXPERT 3	System (ABS) or	ESP8 BOSCH	✓	✓	✓	✓	✓	S0035 S0039
EXPERT 3	airbags and pretensioners ECU	SAC AUTOLIV	✓	✓	✓	✓		
EXPERT 3	built-in systems interface	BSI	✓	✓	✓	✓		S0033
EXPERT 3	power steering	GEP	✓	✓	✓	✓		
EXPERT 3	anti-theft alarm	ALARME	✓	✓	✓	✓		
EXPERT 3	instrument panel	COMBINE	✓	✓	✓	✓	✓	
EXPERT 3	air conditioning	CLIM REGULEE	✓	✓	✓	✓	✓	
EXPERT 3	UNDER-INFLATION DETECTION	DSG	✓	✓	✓	✓		
EXPERT 3	UNDER-INFLATION DETECTION	DSG UDS	✓	✓	✓	✓		
EXPERT 3	parking assistance	AAS	✓	✓	✓	✓	✓	
EXPERT 3	pneumatic suspension	SUSPENSION	✓	✓	✓	✓	✓	

EXPERT 3	additional heating	CHAUFF_ADD	✓	✓	✓	✓		
EXPERT 3	Trailer relay unit	BSR	✓	✓	✓	✓		
EXPERT 3	bodywork conversion unit	BTC	✓	✓	✓	✓		
EXPERT 3	engine wiring housing	BSM	✓	✓	✓	✓		
EXPERT 3	controls under the steering wheel	HDC	✓	✓	✓	✓	✓	
EXPERT 3	multifunction screen	EMF_A	✓	✓	✓	✓	✓	
EXPERT 3	multifunction screen	EMF_C	✓	✓	✓	✓	✓	
EXPERT 3	CD changer / external CD player	CHANGEUR_CD	✓	✓	✓			
EXPERT 3	Hands-free Kit / Portable Unit	KML	✓	✓	✓	✓	✓	
EXPERT 3	Hands-free Kit / Portable Unit	BOITIER_NOMADE	✓	✓	✓	✓	✓	
EXPERT 3	radio	AUTORADIO	✓	✓	✓	✓		
EXPERT 3	radio	RD45	✓	✓	✓	✓		
EXPERT 3	or audio-navigation	BOITIER_TELEMATIQUE	✓	✓	✓	✓	✓	
EXPERT 3	or audio-navigation	RADIONAV_RNEG	✓	✓	✓	✓		
EXPERT 3	or audio-navigation	RNEG2010	✓	✓	✓	✓		
EXPERT 3	selector	ASR	✓			✓		
EXPERT 3	rear air conditioning control panel	TAB_CLIM_AR	✓	✓	✓	✓		
EXPERT 3	rain and sunlight sensor	PLUIE_LUMINOSITE	✓	✓	✓			
EXPERT 3	high frequency receiver	RHF	✓	✓	✓	✓		
EXPERT 3	battery charge status control unit	BECB_GEN2	✓	✓	✓	✓		S003A
EXPERT (K0)	engine management ECU	EDC17C10_BR2	✓	✓	✓	✓		
EXPERT (K0)	engine management ECU	DCM62	✓	✓	✓	✓		
EXPERT (K0)	engine management ECU	EDC17C60	✓	✓	✓	✓		
EXPERT (K0)	engine management ECU	CMM_DCM71	✓	✓	✓	✓		

EXPERT (K0)	engine management ECU	CMM MD1CS003	✓	✓	✓	✓		
EXPERT (K0)	manual gearbox	BVA AM6 AT6 UDS	✓	✓	✓	✓		
EXPERT (K0)	automatic or piloted manual gearbox	BVMP MCP UDS	✓	✓	✓	✓		
EXPERT (K0)	automatic or piloted manual gearbox	BVA AXN8	✓	✓	✓	✓		
EXPERT (K0)	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90	✓	✓	✓	✓		S0035 S0039 S0038
EXPERT (K0)	airbags and pretensioners ECU	RBG UDS	✓	✓	✓	✓		
EXPERT (K0)	built-in systems interface	BSI2010 EV	✓	✓	✓	✓		
EXPERT (K0)	power steering	GEP UDS	✓	✓	✓	✓		
EXPERT (K0)	Electric steering lock	AVE	✓	✓	✓	✓		
EXPERT (K0)	instrument panel	COMBINE UDS	✓	✓	✓	✓		
EXPERT (K0)	left-hand side	BAASL	✓					
EXPERT (K0)	Hands full access ECU, right-hand side or rear	BAAST	✓					
EXPERT (K0)	air conditioning	BCC	✓	✓	✓	✓		
EXPERT (K0)	rear air conditioning ECU	BCC ADD	✓	✓	✓	✓		
EXPERT (K0)	parking assistance	AAS UDS	✓	✓	✓	✓		
EXPERT (K0)	diesel fuel additive pump	PADDGO TI UDS	✓	✓	✓	✓		
EXPERT (K0)	engine wiring housing	BSM 2010	✓	✓	✓	✓		
EXPERT (K0)	Trailer relay unit	BSG 2010 RQ	✓	✓	✓	✓		
EXPERT (K0)	bodywork conversion unit	BSG 2010 TC	✓	✓	✓	✓		
EXPERT (K0)	battery charge status control unit	BECEB GEN2	✓	✓	✓	✓		
EXPERT (K0)	supplies protection and management unit	BPGA2010	✓	✓	✓	✓		

EXPERT (K0)	Head Up Display	VTH UDS	✓	✓	✓	✓		
EXPERT (K0)	controls under the steering wheel	COM2008P	✓	✓	✓	✓	✓	
EXPERT (K0)	Controls on the steering wheel / Integral controls steering wheel	VCI	✓	✓	✓	✓		
EXPERT (K0)	Multifunction control panel	FMUX	✓	✓	✓	✓		
EXPERT (K0)	seat belt not fastened warning lights unit	TNB 2010	✓					
EXPERT (K0)	rain and sunlight sensor	CDPL UDS HELLA	✓	✓	✓	✓		
EXPERT (K0)	Multifunction video camera (CMF)	CVM 2	✓	✓	✓	✓		
EXPERT (K0)	Vehicle Distance Assistance	ARTIV UDS	✓	✓	✓	✓		
EXPERT (K0)	multifunction screen	EMF A UDS	✓	✓	✓			
EXPERT (K0)	multifunction screen	EMF C UDS	✓	✓	✓	✓		
EXPERT (K0)	touch screen	EMF DGT LVDS BD	✓	✓	✓	✓		
EXPERT (K0)	Telematic unit (RTx) or audio-navigation	NAC	✓	✓	✓	✓		
EXPERT (K0)	Telematic unit (RTx) or audio-navigation	RCC	✓	✓	✓	✓		
EXPERT (K0)	radio	RD6	✓	✓	✓	✓		
EXPERT (K0)	Control of the telematic unit	CRT UDS KOSTAL	✓			✓		
EXPERT (K0)	Service module / Independent telematic unit	BTA 2	✓	✓	✓	✓		
EXPERT (K0)	Service module / Independent telematic unit	BTA 3R	✓	✓	✓	✓		

EXPERT (K0)	Service module / Independent telematic unit	BTA 3S	✓	✓	✓	✓		
EXPERT (K0)	Left-hand sliding side door ECU	MDPLC G	✓	✓	✓	✓		
EXPERT (K0)	Right-hand sliding side door ECU	MDPLC D	✓	✓	✓	✓		
EXPERT (K0)	rear air conditioning control panel	IHM AR CENTRAL	✓					
TRAVELLER	engine management ECU	EDC17C10 BR2	✓	✓	✓	✓		
TRAVELLER	engine management ECU	DCM62	✓	✓	✓	✓		
TRAVELLER	engine management ECU	EDC17C60	✓	✓	✓	✓		
TRAVELLER	engine management ECU	CMM DCM71	✓	✓	✓	✓		
TRAVELLER	engine management ECU	CMM MD1CS003	✓	✓	✓	✓		
TRAVELLER	automatic or piloted manual gearbox	BVA AM6 AT6 UDS	✓	✓	✓	✓		
TRAVELLER	automatic or piloted manual gearbox	BVMP MCP UDS	✓	✓	✓	✓		
TRAVELLER	automatic or piloted manual gearbox	BVA AXN8	✓	✓	✓	✓		
TRAVELLER	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90	✓	✓	✓	✓		S0035 S0039 S0038
TRAVELLER	airbags and pretensioners ECU	RBG UDS	✓	✓	✓	✓		
TRAVELLER	built-in systems interface	BSI2010 EV	✓	✓	✓	✓		
TRAVELLER	power steering	GEP UDS	✓	✓	✓	✓		
TRAVELLER	Electric steering lock	AVE	✓	✓	✓	✓		
TRAVELLER	instrument panel	COMBINE UDS	✓	✓	✓	✓		
TRAVELLER	Hands full access ECU, left-hand side	BAASL	✓					

TRAVELLER	Hands full access ECU, right-hand side or rear	BAAST	✓					
TRAVELLER	air conditioning	BCC	✓	✓	✓	✓		
TRAVELLER	rear air conditioning ECU	BCC ADD	✓	✓	✓	✓		
TRAVELLER	parking assistance	AAS UDS	✓	✓	✓	✓		
TRAVELLER	diesel fuel additive pump	PADDGO TI UDS	✓	✓	✓	✓		
TRAVELLER	engine wiring housing	BSM 2010	✓	✓	✓	✓		
TRAVELLER	Trailer relay unit	BSG 2010 RQ	✓	✓	✓	✓		
TRAVELLER	bodywork conversion unit	BSG 2010 TC	✓	✓	✓	✓		
TRAVELLER	battery charge status control unit	BECB GEN2	✓	✓	✓	✓		
TRAVELLER	supplies protection and management unit	BPGA2010	✓	✓	✓	✓		
TRAVELLER	Head Up Display	VTH UDS	✓	✓	✓	✓		
TRAVELLER	controls under the steering wheel	COM2008P	✓	✓	✓	✓	✓	
TRAVELLER	Controls on the steering wheel / Integral controls steering wheel	VCI	✓	✓	✓	✓		
TRAVELLER	Multifunction control panel	FMUX	✓	✓	✓	✓		
TRAVELLER	seat belt not fastened warning lights unit	TNB 2010	✓					
TRAVELLER	rain and sunlight sensor	CDPL UDS HELLA	✓	✓	✓	✓		
TRAVELLER	Multifunction video camera (CMF)	CVM 2	✓	✓	✓	✓		
TRAVELLER	Vehicle Distance Assistance	ARTIV UDS	✓	✓	✓	✓		
TRAVELLER	multifunction screen	EMF A UDS	✓	✓	✓			

TRAVELLER	multifunction screen	EMF C UDS	✓	✓	✓	✓		
TRAVELLER	touch screen	EMF DGT LVDS BD	✓	✓	✓	✓		
TRAVELLER	Telematic unit (RTx) or audio-navigation	NAC	✓	✓	✓	✓		
TRAVELLER	Telematic unit (RTx) or audio-navigation	RCC	✓	✓	✓	✓		
TRAVELLER	radio	RD6	✓	✓	✓	✓		
TRAVELLER	Control of the telematic unit	CRT UDS KOSTAL	✓			✓		
TRAVELLER	Service module / Independent telematic unit	BTA 2	✓	✓	✓	✓		
TRAVELLER	Service module / Independent telematic unit	BTA 3R	✓	✓	✓	✓		
TRAVELLER	Service module / Independent telematic unit	BTA 3S	✓	✓	✓	✓		
TRAVELLER	Left-hand sliding side door ECU	MDPLC G	✓	✓	✓	✓		
TRAVELLER	Right-hand sliding side door ECU	MDPLC D	✓	✓	✓	✓		
TRAVELLER	rear air conditioning control panel	IHM AR CENTRAL	✓					
BOXER 3	engine management ECU	PUMA	✓	✓	✓	✓		
BOXER 3	engine management ECU	EDC16C39	✓	✓	✓	✓		
BOXER 3	engine management ECU	EDC17CP52	✓	✓	✓	✓		
BOXER 3	System (ABS) or	ABS80	✓	✓	✓	✓	✓	S0039
BOXER 3	System (ABS) or	ESP80	✓	✓	✓	✓	✓	S0039 S0035
BOXER 3	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ASR80	✓	✓	✓	✓	✓	S0039

BOXER 3	airbags and pretensioners ECU	SAC TRW	✓	✓	✓	✓		
BOXER 3	airbags and pretensioners ECU	SDM	✓	✓	✓	✓		
BOXER 3	built-in systems interface	NBC	✓	✓	✓	✓		
BOXER 3	power steering	SSCU	✓	✓	✓	✓		
BOXER 3	instrument panel	COMBINE	✓	✓	✓	✓		
BOXER 3	air conditioning	CLIM REGULEE	✓	✓	✓	✓		
BOXER 3	parking assistance	AAS	✓	✓	✓	✓		
BOXER 3	suspension	SUSPENSION	✓	✓	✓	✓		
BOXER 3	additional heating	CHAUFF ADD	✓	✓	✓	✓	✓	
BOXER 3	Telematic unit (RTx) or audio-navigation	BOITIER TELEMATIQUE	✓	✓	✓	✓		
BOXER 3	tachograph	CHRONOTACHYGRAPHE	✓	✓	✓	✓		
BOXER 3 minibus	engine management ECU	PUMA	✓	✓	✓	✓		
BOXER 3 minibus	engine management ECU	EDC16C39	✓	✓	✓	✓		
BOXER 3 minibus	engine management ECU	EDC17CP52	✓	✓	✓	✓		
BOXER 3 minibus	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS80	✓	✓	✓	✓	✓	S0039
BOXER 3 minibus	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP80	✓	✓	✓	✓	✓	S0039
BOXER 3 minibus	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ASR80	✓	✓	✓	✓	✓	S0039 S0035
BOXER 3 minibus	airbags and pretensioners ECU	SAC TRW	✓	✓	✓	✓		
BOXER 3 minibus	airbags and pretensioners ECU	SDM	✓	✓	✓	✓		

BOXER 3 minibus	built-in systems interface	NBC	✓	✓	✓	✓		
BOXER 3 minibus	power steering	SSCU	✓	✓	✓	✓		
BOXER 3 minibus	instrument panel	COMBINE	✓	✓	✓	✓		
BOXER 3 minibus	air conditioning	CLIM REGULEE	✓	✓	✓	✓		
BOXER 3 minibus	parking assistance	AAS	✓	✓	✓	✓		
BOXER 3 minibus	electronically managed suspension	SUSPENSION	✓	✓	✓	✓		
BOXER 3 minibus	additional heating	CHAUFF ADD	✓	✓	✓	✓	✓	
BOXER 3 minibus	Telematic unit (RTx) or audio-navigation	BOITIER TELEMATIQUE	✓	✓	✓	✓		
BOXER 3 minibus	tachograph	CHRONOTACHYGRAPHE	✓	✓	✓	✓		
BOXER 3 Euro 5 / Euro 6	engine management ECU	EDC17CP52 UDS	✓	✓	✓	✓	✓	S0037
BOXER 3 Euro 5 / Euro 6	engine management ECU	SID208	✓	✓	✓	✓		
BOXER 3 Euro 5 / Euro 6	engine management ECU	DCM62 F	✓	✓	✓	✓		
BOXER 3 Euro 5 / Euro 6	engine management ECU	CMM DCM71 F	✓	✓	✓	✓		
BOXER 3 Euro 5 / Euro 6	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ABS90 F	✓	✓	✓	✓		
BOXER 3 Euro 5 / Euro 6	Anti-lock Braking System (ABS) or Electronic Stability Program (ESP)	ESP90 F	✓	✓	✓	✓		
BOXER 3 Euro 5 / Euro 6	airbags and pretensioners ECU	SDM	✓	✓	✓	✓		
BOXER 3 Euro 5 / Euro 6	built-in systems interface	BCM	✓	✓	✓	✓		
BOXER 3 Euro 5 / Euro 6	power steering	SSCU	✓	✓	✓	✓		

BOXER 3 Euro 5 / Euro 6	instrument panel	IPC	✓	✓	✓	✓	✓	S0033
BOXER 3 Euro 5 / Euro 6	air conditioning	ACM	✓	✓	✓	✓	✓	
BOXER 3 Euro 5 / Euro 6	UNDER-INFLATION DETECTION	TPMS	✓	✓	✓	✓		
BOXER 3 Euro 5 / Euro 6	parking assistance	AAS	✓	✓	✓	✓		
BOXER 3 Euro 5 / Euro 6	Trailer relay unit	TTM	✓	✓	✓	✓		
BOXER 3 Euro 5 / Euro 6	additional heating	CHAUFF ADD	✓	✓	✓	✓	✓	
BOXER 3 Euro 5 / Euro 6	Telematic unit (RTx) or audio-navigation	CTM	✓	✓	✓	✓		
BOXER 3 Euro 5 / Euro 6	Audio-navigation system LTM	LTM	✓	✓	✓	✓		
BOXER 3 Euro 5 / Euro 6	tachograph	CHRONOTACHYGRAPHE	✓	✓	✓	✓		
BOXER 3 Euro 5 / Euro 6	electronically managed suspension	SUSPENSION	✓	✓	✓	✓		
BOXER 3 Euro 5 / Euro 6	radio	RRM	✓	✓	✓	✓		
BOXER 3 Euro 5 / Euro 6	lane wandering alert	HALF	✓	✓	✓	✓		

Special Functions List

No.	Functions Name	System Name
S0033	Maintenance and return to zero	BSI
S0033	Maintenance and return to zero	BSI-BSI 2010
S0033	Maintenance and return to zero	Instrument Panel
S0034	Throttle matching	Engine-1.6 16v BOSCH Motronic ME
S0034	Throttle matching	Engine-BOSCH ME7.4.5

S0034	Throttle matching	Engine-BOSCH ME749
S0034	Throttle matching	Engine-EMV17 4 2
S0034	Throttle matching	Engine-J34P
S0034	Throttle matching	Engine-KFU MM6LP
S0034	Throttle matching	Engine-KFU MM6LPC
S0034	Throttle matching	Engine-KFV J34P
S0034	Throttle matching	Engine-KFV S2000PM2
S0034	Throttle matching	Engine-ME744
S0034	Throttle matching	Engine-ME745
S0034	Throttle matching	Engine-ME745 EC5
S0034	Throttle matching	Engine-ME747
S0034	Throttle matching	Engine-ME749
S0034	Throttle matching	Engine-ME749 BIO FLEX
S0034	Throttle matching	Engine-ME749 EC5
S0034	Throttle matching	Engine-MED17 4 2
S0034	Throttle matching	Engine-MED17 4 EURO4
S0034	Throttle matching	Engine-MED17 4 EURO5
S0034	Throttle matching	Engine-MED17 4 4
S0034	Throttle matching	Engine-MEV17 4 2
S0034	Throttle matching	Engine-MEV17 4 EURO4
S0034	Throttle matching	Engine-MEV17 4 EURO5
S0034	Throttle matching	Engine-MEV17.4
S0034	Throttle matching	Engine-MEVD17 4 2
S0034	Throttle matching	Engine-MM6KP
S0034	Throttle matching	Engine-MM6KP bio
S0034	Throttle matching	Engine-MM6KP Bio Flex1
S0034	Throttle matching	Engine-MM6KP Bio Flex2
S0034	Throttle matching	Engine-MM6KP BioFlex
S0034	Throttle matching	Engine-MM6LP
S0034	Throttle matching	Engine-MM6LPC
S0034	Throttle matching	Engine-N6A ME749 BIO FLEX
S0034	Throttle matching	Engine-NFU BOSCH ME745
S0034	Throttle matching	Engine-NFU ME744
S0034	Throttle matching	Engine-NFU OR N6A ME749

S0034	Throttle matching	Engine-RFH MM6KP
S0034	Throttle matching	Engine-RFJ MM6LPB
S0034	Throttle matching	Engine-RFK MM6LP
S0034	Throttle matching	Engine-RFN MM6LP
S0034	Throttle matching	Engine-V341
S0034	Throttle matching	Service Module (RASTREADOR)
S0035	Steering angle reset	ABS or ESP ECU-ABS 81
S0035	Steering angle reset	ABS or ESP ECU-ABS8 BOSCH
S0035	Steering angle reset	ABS or ESP ECU-ESP
S0035	Steering angle reset	ABS or ESP ECU-ESP 90
S0035	Steering angle reset	ABS or ESP ECU-ESP MK60
S0035	Steering angle reset	ABS or ESP ECU-ESP8 BOSCH
S0035	Steering angle reset	ABS or ESP ECU-ESP81
S0035	Steering angle reset	ABS or ESP ECU-ESPMK60 0
S0035	Steering angle reset	ABS-81 ESP
S0035	Steering angle reset	ABS-ABS 8.1
S0035	Steering angle reset	ABS-ABS ESP8 0
S0035	Steering angle reset	ABS-ABS8
S0035	Steering angle reset	ABS-ABS81
S0035	Steering angle reset	ABS-BOSCH ABS 8.1
S0035	Steering angle reset	ABS-ESP 8.1
S0035	Steering angle reset	ABS-ESP 81
S0035	Steering angle reset	ABS-ESP8
S0035	Steering angle reset	ABS-ESP8 BOSCH
S0035	Steering angle reset	ABS-ESP81
S0035	Steering angle reset	ABS-ESP81 BOSCH
S0035	Steering angle reset	ABS/ESP
S0035	Steering angle reset	ABS/ESP-ESP BOSCH57
S0035	Steering angle reset	ABS/ESP-ESP BOSCH8 KwpECU
S0035	Steering angle reset	ABS/ESP-ESP MK60 0
S0035	Steering angle reset	ABS/ESP-ESP8.1
S0035	Steering angle reset	Flywheel Angle Sensor
S0035	Steering angle reset	Power steering

S0035	Steering angle reset	Steering wheel angle sensor
S0036	Injector code	Engine-9HU EDC16C3
S0036	Injector code	Engine-9HV BOSCH EDC16C3
S0036	Injector code	Engine-DCM3.4
S0036	Injector code	Engine-DCM3.5 BR2
S0036	Injector code	Engine-DCM3.5 RHE/RHH
S0036	Injector code	Engine-DCM34
S0036	Injector code	Engine-DCM35
S0036	Injector code	Engine-DCM35 BR2
S0036	Injector code	Engine-DCM35 HY
S0036	Injector code	Engine-EDC16C3
S0036	Injector code	Engine-EDC16C3 (CAN)
S0036	Injector code	Engine-EDC16C3DV4
S0036	Injector code	Engine-EDC17C10
S0036	Injector code	Engine-EDC17C10 BR2
S0036	Injector code	Engine-EDC17C10 BR2
S0036	Injector code	Engine-EDC17CP11
S0036	Injector code	Engine-RHH DCM3.5
S0036	Injector code	Engine-RHH DW10CTED4-163CV
S0037	DPF regeneration	Engine-4HK EDC16CP39
S0037	DPF regeneration	Engine-4HN EDC16CP39
S0037	DPF regeneration	Engine-BOSCH EDC16C3
S0037	DPF regeneration	Engine-DCM3.4
S0037	DPF regeneration	Engine-DCM3.5 BR2
S0037	DPF regeneration	Engine-DCM3.5 RHE/RHH
S0037	DPF regeneration	Engine-DCM34
S0037	DPF regeneration	Engine-DCM35
S0037	DPF regeneration	Engine-DCM35 BR2
S0037	DPF regeneration	Engine-DCM35 HY
S0037	DPF regeneration	Engine-EDC16C3
S0037	DPF regeneration	Engine-EDC16C3 (CAN)
S0037	DPF regeneration	Engine-EDC16CP39
S0037	DPF regeneration	Engine-EDC17C10
S0037	DPF regeneration	Engine-EDC17C10 BR2

S0037	DPF regeneration	Engine-EDC17C10 BR2
S0037	DPF regeneration	Engine-EDC17C60
S0037	DPF regeneration	Engine-EDC17CP11
S0037	DPF regeneration	Engine-EDC17CP42
S0037	DPF regeneration	Engine-EDC17CP52
S0037	DPF regeneration	Engine-EDC17CP52 UDS
S0037	DPF regeneration	Engine-HDI SID803A
S0037	DPF regeneration	Engine-HDI SID807
S0037	DPF regeneration	Engine-HDI SID807 BR2
S0037	DPF regeneration	Engine-HDI SID803
S0037	DPF regeneration	Engine-RHH DCM3.5
S0037	DPF regeneration	Engine-RHH DW10CTED4-163CV
S0037	DPF regeneration	Engine-SID201
S0037	DPF regeneration	Engine-SID803
S0037	DPF regeneration	Engine-SID807
S0037	DPF regeneration	Engine-SID807 BR2
S0038	Brake pad reset	ABS or ESP ECU-ESP 90
S0038	Brake pad reset	ABS or ESP ECU-ESP81
S0038	Brake pad reset	ABS-ESP81
S0038	Brake pad reset	Electric parking brake
S0038	Brake pad reset	Electric secondary brake
S0039	Exhaust	ABS or ESP ECU
S0039	Exhaust	ABS or ESP ECU-ABS 81
S0039	Exhaust	ABS or ESP ECU-ABS MK100
S0039	Exhaust	ABS or ESP ECU-ABS MK70
S0039	Exhaust	ABS or ESP ECU-ABS MK70.1
S0039	Exhaust	ABS or ESP ECU-ABS8 BOSCH
S0039	Exhaust	ABS or ESP ECU-ABS81
S0039	Exhaust	ABS or ESP ECU-ABSMK70 1
S0039	Exhaust	ABS or ESP ECU-ESP 90
S0039	Exhaust	ABS or ESP ECU-ESP MK60
S0039	Exhaust	ABS or ESP ECU-ESP8 BOSCH
S0039	Exhaust	ABS or ESP ECU-ESP81
S0039	Exhaust	ABS or ESP ECU-ESPMK100

S0039	Exhaust	ABS or ESP ECU-ESPMK60 0
S0039	Exhaust	ABS-81 ESP
S0039	Exhaust	ABS-ABS 8. 1
S0039	Exhaust	ABS-ABS ABS8 0
S0039	Exhaust	ABS-ABS ASR8 0
S0039	Exhaust	ABS-ABS ESP8 0
S0039	Exhaust	ABS-ABS MK100
S0039	Exhaust	ABS-ABS8
S0039	Exhaust	ABS-ABS81
S0039	Exhaust	ABS-BOSCH ABS 8. 1
S0039	Exhaust	ABS-ESP 8. 1
S0039	Exhaust	ABS-ESP8
S0039	Exhaust	ABS-ESP8 BOSCH
S0039	Exhaust	ABS-ESP81
S0039	Exhaust	ABS-ESP81 BOSCH
S0039	Exhaust	ABS-ESPMK100
S0039	Exhaust	ABS/ESP
S0039	Exhaust	ABS/ESP-ABS8 BOSCH
S0039	Exhaust	ABS/ESP-ABS8. 1
S0039	Exhaust	ABS/ESP-ESP BOC8H8
S0039	Exhaust	ABS/ESP-ESP BOSCH57
S0039	Exhaust	ABS/ESP-ESP BOSCH8
S0039	Exhaust	ABS/ESP-ESP BOSCH8 KwpECU
S0039	Exhaust	ABS/ESP-ESP MK60 0
S0039	Exhaust	ABS/ESP-ESP8. 1
S0039	Exhaust	ABS/ESP-MK70. 1
S003A	Battery matching	Battery change status unit-BECB
S003A	Battery matching	Battery change status unit-BECB GEN2
S003A	Battery matching	Battery charge status unit
S003A	Battery matching	Battery charge status unit-BECB
S003A	Battery matching	Battery charge status unit-BECB GEN2
S003A	Battery matching	Battery charge status unit-BECB GEN2
S0040	Adaptive initialization	Engine-ME745
S0041	Replace the throttle body , Accelerator pedal sensor , Ejector ,	Engine-ME745

S0042	Replace ECU	Engine-ME745
-------	-------------	--------------

XTOOL