



# Shenzhen Xtooltech Co., Ltd

## SQDTZY Function List V5.60

### Tips and Instructions:

The programming function only supports H6PRO, H6PRO Master Edition products.

- \* This feature is new
- √ This feature is supported.
- This feature is not supported.
- ※ This feature is partially supported.

Model	Model Series	System Name	Read ECU Information	Read Trouble Code	Clear Trouble Code	Live Data	Read Freeze Frame	Actuation Test	Special Functions
SQDTZY	T60	Engine Management System (EMS)/Engine Management System (EDC17C81 D19t EU5)	√	√	√	√		√	SP0000-SP0036
SQDTZY	T60	Engine Management System (EMS)/Engine Management System (EDC17C81 D19t EU4)	√	√	√	√		√	SP0037-SP0076
SQDTZY	T60	Engine Management System (EMS)/Engine Management System (MT221 4G69)	√	√	√	√		√	SP0077-SP0079
SQDTZY	T60	Engine Management System (EMS)/Engine Management System (NLE)	√	√	√	√		√	SP0080-SP0084
SQDTZY	T60	Engine Management System (EMS)/Engine Management System (D20)	√	√	√	√		√	SP0085-SP0100
SQDTZY	T60	Transmission Control System (TCU)	√	√	√	√		√	SP0101-SP0103
SQDTZY	T60	Anti-lock brake/electronic stability system (ABS/ESP)	√	√	√	√		√	SP0104-SP0110
SQDTZY	T60	Airbag System (SRS)	√	√	√	√		√	SP0111-SP0119
SQDTZY	T60	Body Control System (BCM)/Body Control System (NLE 2.0)	√	√	√	√		√	SP0120-SP0129
SQDTZY	T60	Body Control System (BCM)/Body Control System	√	√	√	√		√	SP0130-SP0139
SQDTZY	T60	Electronic Power Steering System (EPS)	√	√	√	√			SP0140-SP0146
SQDTZY	T60	Instrument Control System (IPK)/Instrument System	√	√	√	√		√	SP0147-SP0159
SQDTZY	T60	Instrument control system (IPK)/instrument system (NLE 2.0 or MT221 4G69)	√	√	√	√			
SQDTZY	T60	Keyless Entry System (PEPS)	√	√	√	√		√	SP0160-SP0165
SQDTZY	T60	Air Conditioning System (AC)	√	√	√	√		√	SP0166-SP0167
SQDTZY	T60	Tire Pressure Control System (TPMS)	√	√	√	√		√	SP0168-SP0195
SQDTZY	T60	Gateway Control System (GW)	√	√	√	√			SP0196-SP0197
SQDTZY	T60	Headlight Control System (AFS)	√	√	√	√		√	SP0198-SP0204
SQDTZY	T60	Blind Spot Monitoring System (BSD)	√	√	√	√		√	SP0205-SP0206
SQDTZY	T60	Voltage stabilization module system (DCDC)	√	√	√	√			SP0207-SP0208
SQDTZY	T60	Front Infotainment Control System (FICM)/Front Infotainment Control System	√	√	√	√		√	SP0209-SP0210
SQDTZY	T60	Front Infotainment Control System (FICM)/Front Infotainment Control System (CR)	√	√	√	√		√	SP0211-SP0220
SQDTZY	T60	Lane Departure Warning System (LDW)	√	√	√	√		√	SP0221-SP0225
SQDTZY	T60	Trailer Module System (LSM)	√	√	√	√		√	SP0226-SP0227
SQDTZY	T60	Transfer case control unit system (TCCU)	√	√	√	√		√	SP0228-SP0230
SQDTZY	T60	Telematics control terminal system (TBOX)	√	√	√	√			SP0231-SP0236
SQDTZY	D90	Engine Management System (EMS)	√	√	√	√		√	SP0237-SP0241
SQDTZY	D90	Transmission Control System (TCU)	√	√	√	√		√	SP0242-SP0244
SQDTZY	D90	Anti-lock brake/electronic stability system (ABS/ESP)	√	√	√	√		√	SP0245-SP0251
SQDTZY	D90	Airbag System (SRS)	√	√	√	√		√	SP0252-SP0262
SQDTZY	D90	Body Control System (BCM)	√	√	√	√		√	SP0263-SP0273
SQDTZY	D90	Electronic Power Steering System (EPS)	√	√	√	√			SP0274-SP0280
SQDTZY	D90	Instrument Control System (IPK)	√	√	√	√		√	SP0281-SP0286
SQDTZY	D90	Keyless Entry System (PEPS)	√	√	√	√		√	SP0287-SP0292
SQDTZY	D90	Air Conditioning System (AC)	√	√	√	√		√	SP0293-SP0295
SQDTZY	D90	Tire Pressure Control System (TPMS)	√	√	√	√		√	SP0296-SP0302
SQDTZY	D90	Electronic parking brake system (EPB)	√	√	√	√		√	SP0303-SP0314
SQDTZY	D90	Gateway Control System (GW)	√	√	√	√		√	SP0315-SP0316
SQDTZY	D90	Headlight Control System (AFS)	√	√	√	√		√	SP0317-SP0322
SQDTZY	D90	Transfer case control unit system (TCCU)/ATS intelligent four-wheel drive models and timely four-wheel drive	√	√	√	√		√	SP0323-SP0327
SQDTZY	D90	Transfer case control unit system (TCCU)/transfer case control unit	√	√	√	√		√	SP0328-SP0330
SQDTZY	D90	Ambient Light Control System (ALC)	√	√	√	√			SP0331-SP0332
SQDTZY	D90	Parking Assist System (APA)	√	√	√	√		√	SP0333-SP0336
SQDTZY	D90	Voltage stabilization module system (DCDC)	√	√	√	√			SP0337-SP0338
SQDTZY	D90	Seat Memory Module System (DSM)	√	√	√	√		√	SP0339-SP0350
SQDTZY	D90	Electronic Differential Lock Module System (EDL)	√	√	√	√		√	SP0351-SP0353
SQDTZY	D90	Front Infotainment Control System (FICM)/Front Infotainment Control System	√	√	√	√		√	SP0354-SP0356
SQDTZY	D90	Front Infotainment Control System (FICM)/Front Infotainment Control System (CR)	√	√	√	√		√	SP0357-SP0358
SQDTZY	D90	Lane Departure Warning System (LDW)	√	√	√	√		√	SP0359-SP0366



SQDTZY	G20	Keyless Start System (PEPS)			✓	✓					
SQDTZY	G20	Air Conditioning System (AC)			✓	✓					
SQDTZY	G20	Tire Pressure Monitoring System (TPMS)			✓	✓					
SQDTZY	G20	Gateway system (GW)			✓	✓					
SQDTZY	G20	Automatic Parking Assist System (APA)			✓	✓					
SQDTZY	G20	Ambient Light Controller System (ALC)			✓	✓					
SQDTZY	G20	Electronic gear lever controller system (GSM)			✓	✓					
SQDTZY	G20	360 panoramic camera controller system (BVS)			✓	✓					
SQDTZY	G20	Voltage stabilization module system (DCDC)			✓	✓					
SQDTZY	G20	Driver Assistance System (DAS)			✓	✓					
SQDTZY	G20	Tailgate Control Unit System (TGC)/Tailgate Control Unit (TGC) UMC			✓	✓					
SQDTZY	G20	Tailgate Control Unit System (TGC)/Power Tailgate (PLG) Mingfang			✓	✓					
SQDTZY	G20	Lane Change Alert Controller System (LCA)			✓	✓					
SQDTZY	G20	Front Infotainment Control System (FICM)/Front Infotainment Control System			✓	✓					
SQDTZY	G20	Front Infotainment Control System (FICM)/Front Infotainment Control System (CR)			✓	✓					
SQDTZY	G20	Telematics control terminal system (TBOX)			✓	✓					
SQDTZY	G50	Engine System (EMS)	✓		✓	✓	✓			✓	
SQDTZY	G50	Automatic Transmission System (TCU)			✓	✓					
SQDTZY	G50	Electronic Stability System (ESP)	✓		✓	✓	✓			✓	
SQDTZY	G50	Airbag System (SRS)	✓		✓	✓	✓	✓		✓	
SQDTZY	G50	Body Control System (BCM)	✓		✓	✓	✓	✓		✓	
SQDTZY	G50	Electronic Power Steering (EPS)/Electric Power Steering-Bosch	✓		✓	✓	✓	✓			SP0722
SQDTZY	G50	Electronic Power Steering System (EPS)/Electric Power Steering-Donghua	✓		✓	✓	✓	✓		✓	SP0723
SQDTZY	G50	Instrument Control System (ICM)/Combination Instrument-Wichl			✓	✓					SP0724-SP0725
SQDTZY	G50	Instrument Control System (ICM)/Combination Instrument-Visteon			✓	✓					SP0726-SP0727
SQDTZY	G50	Keyless Start System (PEPS)	✓		✓	✓	✓	✓		✓	
SQDTZY	G50	Air Conditioning System (AC)	✓		✓	✓	✓	✓		✓	
SQDTZY	G50	Gateway system (GW)	✓		✓	✓	✓	✓		✓	
SQDTZY	G50	Intelligent Assisted Autonomous Driving System (ADAS)			✓	✓					
SQDTZY	G50	Tailgate Control Unit System (TGC)			✓	✓					
SQDTZY	G50	Parking sensor system (PDC)	✓		✓	✓	✓	✓			
SQDTZY	G50	Front Infotainment Control System (FICM)/Front Infotainment Control System	✓		✓	✓	✓	✓			
SQDTZY	G50	Front Infotainment Control System (FICM)/Front Infotainment Control System (CR)	✓		✓	✓	✓	✓			
SQDTZY	G50	Head-up display system (HUD)	✓		✓	✓	✓	✓		✓	
SQDTZY	G50	Radio Frequency System (RF)	✓		✓	✓	✓	✓			
SQDTZY	G50	Telematics control terminal system (TBOX)	✓		✓	✓	✓	✓			
SQDTZY	V90	Engine System (EMS)	✓		✓	✓	✓	✓		✓	SP0728-SP0743
SQDTZY	V90	Automatic Transmission System (AT)/Transmission Control Unit-AMT	✓		✓	✓	✓	✓			
SQDTZY	V90	Automatic Transmission System (AT)/Transmission Control Unit-AT			✓	✓					
SQDTZY	V90	Anti-lock brake/electronic stability system (ABS/ESP)/electronic stability system (ESP)			✓	✓					
SQDTZY	V90	Anti-lock brake/electronic stability system (ABS/ESP)/anti-lock brake system (ABS)			✓	✓					
SQDTZY	V90	Airbag System (SRS)			✓	✓					
SQDTZY	V90	Body Control System (BCM)			✓	✓					
SQDTZY	V90	Electronic Power Steering System (EPS)			✓	✓					
SQDTZY	V90	Instrument Control System (ICM)			✓	✓					SP0744-SP0745
SQDTZY	V90	Keyless Start System (PEPS)			✓	✓					
SQDTZY	V90	Air Conditioning System (AC)			✓	✓					
SQDTZY	V90	Gateway system (GW)			✓	✓					
SQDTZY	V90	Driver Assistance System (DAS)			✓	✓					
SQDTZY	V90	Voltage stabilization module system (DCDC)			✓	✓					
SQDTZY	V90	Parking sensor system (PDC)			✓	✓					
SQDTZY	V90	Driving Recorder Module System (DRM)			✓	✓					
SQDTZY	V90	Front Infotainment Control System (FICM)			✓	✓					
SQDTZY	V90	Lane Change Alert Controller System (LCA)			✓	✓					
SQDTZY	V90	Radio Frequency System (RF)			✓	✓					
SQDTZY	V90	Telematics control terminal system (TBOX)			✓	✓					
SQDTZY	T70	Engine System (EMS)	✓		✓	✓	✓	✓		✓	SP0746-SP0761
SQDTZY	T70	Automatic Transmission System (TCU)	✓		✓	✓	✓	✓		✓	
SQDTZY	T70	Anti-lock brake system (ABS)	✓		✓	✓	✓	✓		✓	
SQDTZY	T70	Airbag System (SRS)	✓		✓	✓	✓	✓		✓	SP0762-SP0763
SQDTZY	T70	Body Control System (BCM)	✓		✓	✓	✓	✓		✓	
SQDTZY	T70	Electronic Power Steering System (EPS)	✓		✓	✓	✓	✓			
SQDTZY	T70	Instrument Control System (ICM)	✓		✓	✓	✓	✓		✓	SP0764-SP0765
SQDTZY	T70	Keyless Start System (PEPS)	✓		✓	✓	✓	✓		✓	

SQDTZY	T70	Air Conditioning System (AC)	✓	✓	✓	✓	✓	✓	
SQDTZY	T70	Tire Pressure Monitoring System (TPMS)	✓	✓	✓	✓	✓	✓	
SQDTZY	T70	Gateway system (GW)	✓	✓	✓	✓	✓	✓	
SQDTZY	T70	Adaptive headlight system (AFS)	✓	✓	✓	✓	✓	✓	
SQDTZY	T70	Transfer case control unit system (TCCU)	✓	✓	✓	✓	✓	✓	
SQDTZY	T70	Front Infotainment Control System (FICM)/Front Infotainment Control System	✓	✓	✓	✓	✓	✓	
SQDTZY	T70	Front Infotainment Control System (FICM)/Front Infotainment Control System (CR)	✓	✓	✓	✓	✓	✓	
SQDTZY	T70	Lane Departure Warning System (LDW)	✓	✓	✓	✓	✓	✓	
SQDTZY	T70	Trailer Module System (LSM)	✓	✓	✓	✓	✓	✓	
SQDTZY	T70	Telematics control terminal system (TBOX)/Telematics control terminal-Huihan	✓	✓	✓	✓	✓	✓	
SQDTZY	T70	Telematics control terminal system (TBOX)/Telematics control terminal-Sangde	✓	✓	✓	✓	✓	✓	
SQDTZY	D60	Engine System (EMS)	✓	✓	✓	✓	✓	✓	
SQDTZY	D60	Automatic Transmission System (TCU)/Transmission Control Unit-Autonomous	✓	✓	✓	✓	✓	✓	
SQDTZY	D60	Automatic Transmission System (TCU)/Transmission Control Unit-Hitachi	✓	✓	✓	✓	✓	✓	
SQDTZY	D60	Electronic Stability System (ESP)	✓	✓	✓	✓	✓	✓	
SQDTZY	D60	Airbag System (SRS)	✓	✓	✓	✓	✓	✓	
SQDTZY	D60	Body Control System (BCM)	✓	✓	✓	✓	✓	✓	
SQDTZY	D60	Electronic Power Steering (EPS)/Electric Power Steering-Bosch	✓	✓	✓	✓	✓	✓	SP0766
SQDTZY	D60	Electronic Power Steering System (EPS)/Electric Power Steering-Donghua	✓	✓	✓	✓	✓	✓	SP0767
SQDTZY	D60	Instrument Control System (ICM)/Combination Instrument-Wichl	✓	✓	✓	✓	✓	✓	SP0768-SP0769
SQDTZY	D60	Instrument Control System (ICM)/Combination Instrument-Visteon	✓	✓	✓	✓	✓	✓	SP0770-SP0771
SQDTZY	D60	Keyless Start System (PEPS)	✓	✓	✓	✓	✓	✓	
SQDTZY	D60	Air Conditioning System (AC)	✓	✓	✓	✓	✓	✓	
SQDTZY	D60	Gateway system (GW)	✓	✓	✓	✓	✓	✓	
SQDTZY	D60	Intelligent Assisted Autonomous Driving System (ADAS)	✓	✓	✓	✓	✓	✓	
SQDTZY	D60	Tailgate Control Unit System (TGC)	✓	✓	✓	✓	✓	✓	
SQDTZY	D60	Parking sensor system (PDC)	✓	✓	✓	✓	✓	✓	
SQDTZY	D60	Front Infotainment Control System (FICM)/Front Infotainment Control System	✓	✓	✓	✓	✓	✓	
SQDTZY	D60	Front Infotainment Control System (FICM)/Front Infotainment Control System (CR)	✓	✓	✓	✓	✓	✓	
SQDTZY	D60	Head-up display system (HUD)	✓	✓	✓	✓	✓	✓	
SQDTZY	D60	Radio Frequency System (RF)	✓	✓	✓	✓	✓	✓	
SQDTZY	D60	Automatic Parking Assist System (APA)	✓	✓	✓	✓	✓	✓	
SQDTZY	D60	Lane Change Alert Controller System (LCA)/Lane Change Assist System-Main	✓	✓	✓	✓	✓	✓	
SQDTZY	D60	Lane Change Alert Controller System (LCA)/Lane Change Assist System-Slave	✓	✓	✓	✓	✓	✓	
SQDTZY	D60	360 panoramic camera controller system (AVM)	✓	✓	✓	✓	✓	✓	
SQDTZY	D60	Shift control module system (SCU)	✓	✓	✓	✓	✓	✓	
SQDTZY	D60	Electronic gear lever controller system (GSM)	✓	✓	✓	✓	✓	✓	
SQDTZY	D60	Telematics control terminal system (TBOX)	✓	✓	✓	✓	✓	✓	
SQDTZY	EXTENDER	Engine System (EMS)	✓	✓	✓	✓	✓	✓	SP0772-SP0787
SQDTZY	EXTENDER	Automatic Transmission System (TCU)	✓	✓	✓	✓	✓	✓	
SQDTZY	EXTENDER	Anti-lock brake system (ABS)	✓	✓	✓	✓	✓	✓	
SQDTZY	EXTENDER	Airbag System (SRS)	✓	✓	✓	✓	✓	✓	SP0788-SP0789
SQDTZY	EXTENDER	Body Control System (BCM)	✓	✓	✓	✓	✓	✓	
SQDTZY	EXTENDER	Instrument Control System (ICM)/Instrument Control System	✓	✓	✓	✓	✓	✓	SP0790-SP0791
SQDTZY	EXTENDER	Instrumentation control system (ICM)/instrumentation control system-high configuration	✓	✓	✓	✓	✓	✓	SP0792-SP0793
SQDTZY	EXTENDER	Keyless Start System (PEPS)	✓	✓	✓	✓	✓	✓	
SQDTZY	EXTENDER	Air Conditioning System (AC)	✓	✓	✓	✓	✓	✓	
SQDTZY	EXTENDER	Tire Pressure Monitoring System (TPMS)	✓	✓	✓	✓	✓	✓	
SQDTZY	EXTENDER	Gateway system (GW)	✓	✓	✓	✓	✓	✓	
SQDTZY	EXTENDER	Adaptive headlight system (AFS)	✓	✓	✓	✓	✓	✓	
SQDTZY	EXTENDER	Transfer case control unit system (TCCU)	✓	✓	✓	✓	✓	✓	
SQDTZY	EXTENDER	Lane Departure Warning System (LDW)	✓	✓	✓	✓	✓	✓	
SQDTZY	EXTENDER	Trailer Module System (LSM)	✓	✓	✓	✓	✓	✓	
SQDTZY	EXTENDER	Voltage stabilization module system (DCDC)	✓	✓	✓	✓	✓	✓	
SQDTZY	EXTENDER	Front Infotainment Control System (FICM)	✓	✓	✓	✓	✓	✓	
SQDTZY	EXTENDER	Blind Spot Detection System (BSD)	✓	✓	✓	✓	✓	✓	
SQDTZY	EXTENDER	Telematics control terminal system (TBOX)	✓	✓	✓	✓	✓	✓	
SQDTZY	EV80	Vehicle Controller System (VMS)/Vehicle Management System	✓	✓	✓	✓	✓	✓	SP0794-SP0797
SQDTZY	EV80	Vehicle Controller System (VMS)/Vehicle Management System (2018)	✓	✓	✓	✓	✓	✓	SP0798-SP0800
SQDTZY	EV80	Power Control Unit System (PCU)	✓	✓	✓	✓	✓	✓	SP0801-SP0802
SQDTZY	EV80	Battery Management System (BMS)/Battery Management System	✓	✓	✓	✓	✓	✓	SP0803-SP0805
SQDTZY	EV80	Battery Management System (BMS)/Battery Management System (Autonomous)	✓	✓	✓	✓	✓	✓	SP0806-SP0808
SQDTZY	EV80	Battery Management System (BMS)/Battery Management System (CATL)	✓	✓	✓	✓	✓	✓	
SQDTZY	EV80	Battery Pack Data (BPD)/Battery Pack Type 1	✓	✓	✓	✓	✓	✓	

SQDTZY	EV80	Battery Pack Data (BPD)/Battery Pack Type 2	✓	✓	✓	✓			
SQDTZY	EV80	Anti-lock brake system (ABS)	✓	✓	✓	✓	✓	SP0809-SP0812	
SQDTZY	EV80	Airbag System (SRS)	✓	✓	✓	✓	✓	SP0813-SP0816	
SQDTZY	EV80	Body Control System (BCM)/Body Control Module	✓	✓	✓	✓	✓	SP0817-SP0832	
SQDTZY	EV80	Body Control System (BCM)/Body Control Module (2018)	✓	✓	✓	✓	✓	SP0833-SP0845	
SQDTZY	EV80	Electro-hydraulic power steering system (EHPS)	✓	✓	✓	✓	✓	SP0846-SP0847	
SQDTZY	EV80	Instrument Control System (IPK)/Instrument System	✓	✓	✓	✓	✓	SP0848-SP0851	
SQDTZY	EV80	Instrument Control System (IPK)/Instrument System (2018)	✓	✓	✓	✓	✓	SP0852-SP0855	
SQDTZY	EV80	Air Conditioning System (AC)	✓	✓	✓	✓	✓	SP0856-SP0857	
SQDTZY	EV80	Tire Pressure Control System (TPMS)/Tire Pressure Monitoring System	✓	✓	✓	✓	✓	SP0858-SP0879	
SQDTZY	EV80	Tire Pressure Control System (TPMS)/Tire Pressure Monitoring System (2018)	✓	✓	✓	✓	✓	SP0880-SP0901	
SQDTZY	EV80	Electronic parking brake system (EPB)/electronic parking brake system	✓	✓	✓	✓	✓	SP0902-SP0906	
SQDTZY	EV80	Electronic parking brake system (EPB)/electronic parking system	✓	✓	✓	✓	✓	SP0907-SP0908	
SQDTZY	EV80	Gateway Control System (GW)	✓	✓	✓	✓	✓	SP0909-SP0911	
SQDTZY	EV80	Charger Communication Control Module System (EVCC)	✓	✓	✓	✓	✓	SP0912-SP0913	
SQDTZY	EV80	Front Infotainment Control System (FICM)	✓	✓	✓	✓	✓	SP0914-SP0931	
SQDTZY	EV80	Lane Change Alert Controller System (LCA)	✓	✓	✓	✓	✓	SP0932-SP0934	
SQDTZY	EV80	Voltage stabilization module system (DCDC)	✓	✓	✓	✓	✓	SP0935-SP0936	
SQDTZY	EV80	Telematics control terminal system (TBOX)	✓	✓	✓	✓	✓	SP0937-SP0939	
SQDTZY	EG10	Vehicle Controller System (VMS)	✓	✓	✓	✓	✓	SP0940-SP0942	
SQDTZY	EG10	Motor Controller System (MCU)	✓	✓	✓	✓	✓	SP0943-SP0944	
SQDTZY	EG10	Battery Management System (BMS)	✓	✓	✓	✓	✓	SP0945-SP0946	
SQDTZY	EG10	Anti-lock brake/electronic stability system (ABS/ESP)	✓	✓	✓	✓	✓	SP0947-SP0952	
SQDTZY	EG10	Airbag System (SRS)	✓	✓	✓	✓	✓	SP0953-SP0957	
SQDTZY	EG10	Body Control System (BCM)	✓	✓	✓	✓	✓	SP0958-SP0964	
SQDTZY	EG10	Electro-hydraulic power steering system (EHPS)	✓	✓	✓	✓	✓	SP0965-SP0966	
SQDTZY	EG10	Instrument Control System (IPK)	✓	✓	✓	✓	✓	SP0967-SP0987	
SQDTZY	EG10	Keyless Entry System (PEPS)	✓	✓	✓	✓	✓	SP0988-SP0998	
SQDTZY	EG10	Air Conditioning System (AC)	✓	✓	✓	✓	✓	SP0999-SP1001	
SQDTZY	EG10	Tire Pressure Control System (TPMS)	✓	✓	✓	✓	✓	SP1002-SP1023	
SQDTZY	EG10	Gateway Control System (GW)	✓	✓	✓	✓	✓	SP1024-SP1027	
SQDTZY	EG10	Headlight Control System (AFS)	✓	✓	✓	✓	✓	SP1028-SP1031	
SQDTZY	EG10	360 panoramic camera controller system (BVS)	✓	✓	✓	✓	✓	SP1032-SP1033	
SQDTZY	EG10	Voltage stabilization module system (DCDC)	✓	✓	✓	✓	✓	SP1034-SP1035	
SQDTZY	EG10	Lane Change Alert Controller System (LCA)	✓	✓	✓	✓	✓	SP1036-SP1038	
SQDTZY	EG10	Electric tailgate controller system (PTG)	✓	✓	✓	✓	✓	SP1039-SP1041	
SQDTZY	EG10	Telematics control terminal system (TBOX)	✓	✓	✓	✓	✓	SP1042-SP1044	
SQDTZY	FCV80	Vehicle Controller System (VMS)	✓	✓	✓	✓	✓	SP1045-SP1048	
SQDTZY	FCV80	Motor Controller System (MCU)	✓	✓	✓	✓	✓	SP1049-SP1050	
SQDTZY	FCV80	Battery Management System (BMS)	✓	✓	✓	✓	✓	SP1051-SP1053	
SQDTZY	FCV80	Anti-lock brake system (ABS)	✓	✓	✓	✓	✓	SP1054-SP1057	
SQDTZY	FCV80	Airbag System (SRS)	✓	✓	✓	✓	✓	SP1058-SP1063	
SQDTZY	FCV80	Body Control System (BCM)	✓	✓	✓	✓	✓	SP1064-SP1079	
SQDTZY	FCV80	Electro-hydraulic power steering system (EHPS)	✓	✓	✓	✓	✓	SP1080-SP1081	
SQDTZY	FCV80	Instrument Control System (IPK)	✓	✓	✓	✓	✓	SP1082-SP1084	
SQDTZY	FCV80	Air Conditioning System (AC)	✓	✓	✓	✓	✓	SP1085-SP1086	
SQDTZY	FCV80	Tire Pressure Control System (TPMS)	✓	✓	✓	✓	✓	SP1087-SP1108	
SQDTZY	FCV80	Electronic parking brake system (EPB)	✓	✓	✓	✓	✓	SP1109-SP1113	
SQDTZY	FCV80	Fuel cell system (FCS)	✓	✓	✓	✓	✓	SP1114-SP1116	
SQDTZY	FCV80	Telematics control terminal system (TBOX)	✓	✓	✓	✓	✓	SP1117-SP1123	
SQDTZY	EG50/EUNIQ5	Battery Management System (BMS)	✓	✓	✓	✓	✓		
SQDTZY	EG50/EUNIQ5	Motor Controller System (MCU)	✓	✓	✓	✓	✓		
SQDTZY	EG50/EUNIQ5	Vehicle Controller System (VCI)	✓	✓	✓	✓	✓		
SQDTZY	EG50/EUNIQ5	Electronic Stability System (ESP)	✓	✓	✓	✓	✓		
SQDTZY	EG50/EUNIQ5	Airbag System (SRS)	✓	✓	✓	✓	✓		
SQDTZY	EG50/EUNIQ5	Body Control System (BCM)	✓	✓	✓	✓	✓		
SQDTZY	EG50/EUNIQ5	Electronic Power Steering (EPS)/Electric Power Steering-Bosch	✓	✓	✓	✓	✓	SP1124	
SQDTZY	EG50/EUNIQ5	Electronic Power Steering System (EPS)/Electric Power Steering-Donghua	✓	✓	✓	✓	✓	SP1125	
SQDTZY	EG50/EUNIQ5	Instrument Control System (ICM)	✓	✓	✓	✓	✓	SP1126-SP1127	
SQDTZY	EG50/EUNIQ5	Keyless Start System (PEPS)	✓	✓	✓	✓	✓		
SQDTZY	EG50/EUNIQ5	Air Conditioning System (AC)	✓	✓	✓	✓	✓		
SQDTZY	EG50/EUNIQ5	Gateway system (GW)	✓	✓	✓	✓	✓		
SQDTZY	EG50/EUNIQ5	Parking sensor system (PDC)	✓	✓	✓	✓	✓		
SQDTZY	EG50/EUNIQ5	Front Infotainment Control System (FICM)/Front Infotainment Control System	✓	✓	✓	✓	✓		

SQDTZY	EG50/EUNIQ5	Front Infotainment Control System (FICM)/Front Infotainment Control System (CR)	✓	✓	✓	✓			
SQDTZY	EG50/EUNIQ5	Head-up display system (HUD)	✓	✓	✓	✓		✓	
SQDTZY	EG50/EUNIQ5	Radio Frequency System (RF)	✓	✓	✓	✓			
SQDTZY	EG50/EUNIQ5	Voltage stabilization module system (DCDC)	✓	✓	✓	✓			
SQDTZY	EG50/EUNIQ5	Vehicle Acoustic Alert System (AVAS)	✓	✓	✓				
SQDTZY	EG50/EUNIQ5	Telematics control terminal system (TBOX)	✓	✓	✓	✓			
SQDTZY	EV30	Battery Management System (BMS)	✓	✓	✓	✓			
SQDTZY	EV30	Battery Pack Data (BPD)				✓			
SQDTZY	EV30	Motor Controller System (MCU)	✓	✓	✓	✓			
SQDTZY	EV30	Vehicle Controller System (VCI)	✓	✓	✓	✓		✓	
SQDTZY	EV30	Electronic Stability System (ESP)	✓	✓	✓	✓		✓	
SQDTZY	EV30	Airbag System (SRS)	✓	✓	✓	✓		✓	
SQDTZY	EV30	Body Control System (BCM)	✓	✓	✓	✓		✓	
SQDTZY	EV30	Electronic Power Steering System (EPS)	✓	✓	✓	✓		✓	
SQDTZY	EV30	Instrument Control System (ICM)	✓	✓	✓	✓		✓	SP1128-SP1129
SQDTZY	EV30	Air Conditioning System (AC)	✓	✓	✓	✓		✓	
SQDTZY	EV30	Voltage stabilization module system (DCDC)	✓	✓	✓	✓			
SQDTZY	EV30	Front Infotainment Control System (FICM)	✓	✓	✓	✓			
SQDTZY	EV30	Vehicle Acoustic Alert System (AVAS)	✓	✓	✓				
SQDTZY	EV30	Telematics control terminal system (TBOX)	✓	✓	✓	✓			

## Special Functions List

No.	Functions Name	System Name
SP0000	Configuration	Engine Management System (EDC17C81 D19t EU5)
SP0001	Write vehicle identification code	Engine Management System (EDC17C81 D19t EU5)
SP0002	The zero fuel volume calibration correction value reset for the fuel injection volume of the fuel injector	Engine Management System (EDC17C81 D19t EU5)
SP0003	Write engine running time	Engine Management System (EDC17C81 D19t EU5)
SP0004	Write the distance traveled by the engine	Engine Management System (EDC17C81 D19t EU5)
SP0005	Air flow meter drift correction value	Engine Management System (EDC17C81 D19t EU5)
SP0006	Write the maximum speed limit value	Engine Management System (EDC17C81 D19t EU5)
SP0007	FMO reset (replace lambda oxygen sensor)	Engine Management System (EDC17C81 D19t EU5)
SP0008	FMO reset (replace rail pressure sensor)	Engine Management System (EDC17C81 D19t EU5)
SP0009	FMO reset (replace air flow meter)	Engine Management System (EDC17C81 D19t EU5)
SP0010	FMO reset (replace the injector)	Engine Management System (EDC17C81 D19t EU5)
SP0011	Lambda oxygen sensor dew point detection reset	Engine Management System (EDC17C81 D19t EU5)
SP0012	Lambda oxygen sensor correction value reset	Engine Management System (EDC17C81 D19t EU5)
SP0013	Air flow meter drift correction value reset	Engine Management System (EDC17C81 D19t EU5)
SP0014	Write engine code	Engine Management System (EDC17C81 D19t EU5)
SP0015	Write calibration identification number	Engine Management System (EDC17C81 D19t EU5)
SP0016	EGR (exhaust gas recirculation) valve correction value learning	Engine Management System (EDC17C81 D19t EU5)
SP0017	TVA valve fully closed position correction value self-learning	Engine Management System (EDC17C81 D19t EU5)
SP0018	Read the injector code	Engine Management System (EDC17C81 D19t EU5)
SP0019	Write injector code	Engine Management System (EDC17C81 D19t EU5)
SP0020	DPF regeneration lock canceled	Engine Management System (EDC17C81 D19t EU5)
SP0021	DPF regeneration lock reset	Engine Management System (EDC17C81 D19t EU5)
SP0022	DPF regeneration function activated	Engine Management System (EDC17C81 D19t EU5)
SP0023	DPF regeneration function terminated	Engine Management System (EDC17C81 D19t EU5)
SP0024	Diesel particulate filter value	Engine Management System (EDC17C81 D19t EU5)
SP0025	Diesel particulate filter value write	Engine Management System (EDC17C81 D19t EU5)
SP0026	Diesel particulate filter value reset	Engine Management System (EDC17C81 D19t EU5)
SP0027	Clutch pedal self-learning	Engine Management System (EDC17C81 D19t EU5)
SP0028	Engine speed when each cylinder is doing work	Engine Management System (EDC17C81 D19t EU5)
SP0029	Injector closed test cylinder 1	Engine Management System (EDC17C81 D19t EU5)
SP0030	Injector closed test cylinder 2	Engine Management System (EDC17C81 D19t EU5)
SP0031	Injector closed test cylinder 3	Engine Management System (EDC17C81 D19t EU5)
SP0032	Injector closed test cylinder 4	Engine Management System (EDC17C81 D19t EU5)
SP0033	Compression test	Engine Management System (EDC17C81 D19t EU5)
SP0034	high-pressure test	Engine Management System (EDC17C81 D19t EU5)
SP0035	Accelerated testing	Engine Management System (EDC17C81 D19t EU5)
SP0036	Start failure information	Engine Management System (EDC17C81 D19t EU5)
SP0037	Configuration	Engine Management System (EDC17C81 D19t EU4)
SP0038	Write vehicle identification code	Engine Management System (EDC17C81 D19t EU4)
SP0039	The zero fuel volume calibration correction value reset for the fuel injection volume of the fuel injector	Engine Management System (EDC17C81 D19t EU4)
SP0040	Write the zero fuel volume calibration correction value for the fuel injection volume of the fuel injector	Engine Management System (EDC17C81 D19t EU4)
SP0041	Write engine running time	Engine Management System (EDC17C81 D19t EU4)
SP0042	Write the distance traveled by the engine	Engine Management System (EDC17C81 D19t EU4)
SP0043	Air flow meter drift correction value	Engine Management System (EDC17C81 D19t EU4)
SP0044	Write the maximum speed limit value	Engine Management System (EDC17C81 D19t EU4)
SP0045	FMO reset (replace lambda oxygen sensor)	Engine Management System (EDC17C81 D19t EU4)
SP0046	FMO reset (replace rail pressure sensor)	Engine Management System (EDC17C81 D19t EU4)
SP0047	FMO reset (replace air flow meter)	Engine Management System (EDC17C81 D19t EU4)
SP0048	FMO reset (replace the injector)	Engine Management System (EDC17C81 D19t EU4)
SP0049	Lambda oxygen sensor dew point detection reset	Engine Management System (EDC17C81 D19t EU4)
SP0050	Lambda oxygen sensor correction value reset	Engine Management System (EDC17C81 D19t EU4)
SP0051	Air flow meter drift correction value reset	Engine Management System (EDC17C81 D19t EU4)
SP0052	Write engine code	Engine Management System (EDC17C81 D19t EU4)
SP0053	Write calibration identification number	Engine Management System (EDC17C81 D19t EU4)
SP0054	EGR (exhaust gas recirculation) valve correction value learning	Engine Management System (EDC17C81 D19t EU4)
SP0055	TVA valve fully closed position correction value self-learning	Engine Management System (EDC17C81 D19t EU4)
SP0056	Read the injector code	Engine Management System (EDC17C81 D19t EU4)
SP0057	Write injector code	Engine Management System (EDC17C81 D19t EU4)
SP0058	DPF manual regeneration	Engine Management System (EDC17C81 D19t EU4)

SP0059	DPF (Particle Filter) reset	Engine Management System (EDC17C81 D19t EU4)
SP0060	DPF regeneration lock canceled	Engine Management System (EDC17C81 D19t EU4)
SP0061	DPF regeneration lock reset	Engine Management System (EDC17C81 D19t EU4)
SP0062	DPF regeneration function activated	Engine Management System (EDC17C81 D19t EU4)
SP0063	DPF regeneration function terminated	Engine Management System (EDC17C81 D19t EU4)
SP0064	Diesel particulate filter value	Engine Management System (EDC17C81 D19t EU4)
SP0065	Diesel particulate filter value write	Engine Management System (EDC17C81 D19t EU4)
SP0066	Diesel particulate filter value reset	Engine Management System (EDC17C81 D19t EU4)
SP0067	Clutch pedal self-learning	Engine Management System (EDC17C81 D19t EU4)
SP0068	Injector closed test cylinder 1	Engine Management System (EDC17C81 D19t EU4)
SP0069	Injector closed test cylinder 2	Engine Management System (EDC17C81 D19t EU4)
SP0070	Injector closed test cylinder 3	Engine Management System (EDC17C81 D19t EU4)
SP0071	Injector closed test cylinder 4	Engine Management System (EDC17C81 D19t EU4)
SP0072	Compression test	Engine Management System (EDC17C81 D19t EU4)
SP0073	high-pressure test	Engine Management System (EDC17C81 D19t EU4)
SP0074	Accelerated testing	Engine Management System (EDC17C81 D19t EU4)
SP0075	Engine speed when each cylinder is doing work	Engine Management System (EDC17C81 D19t EU4)
SP0076	Start failure information	Engine Management System (EDC17C81 D19t EU4)
SP0077	Write VIN code	Engine Management System (MT221 4G69)
SP0078	Write vehicle characteristic information	Engine Management System (MT221 4G69)
SP0079	Clutch learning	Engine Management System (MT221 4G69)
SP0080	Write VIN code	Engine Management System (NLE)
SP0081	Write vehicle characteristic information	Engine Management System (NLE)
SP0082	Brake pedal self-learning	Engine Management System (NLE)
SP0083	Clutch pedal self-learning	Engine Management System (NLE)
SP0084	Write EMS configuration	Engine Management System (NLE)
SP0085	Speed limit write	Engine Management System (D20)
SP0086	Vehicle speed sensor source selection write	Engine Management System (D20)
SP0087	Throttle replacement	Engine Management System (D20)
SP0088	Diesel Particulate Filter (DPF) Differential Pressure Sensor	Engine Management System (D20)
SP0089	Injector replacement	Engine Management System (D20)
SP0090	Write fuel injection correction (IQA) code	Engine Management System (D20)
SP0091	Fuel quality correction reset (replace injector)	Engine Management System (D20)
SP0092	After-treatment catalyst NH3 load reset	Engine Management System (D20)
SP0093	Diesel particulate filter related value reset	Engine Management System (D20)
SP0094	Reset regeneration lock and increase soot quality	Engine Management System (D20)
SP0095	Cancel regeneration lock	Engine Management System (D20)
SP0096	Activate regeneration service	Engine Management System (D20)
SP0097	Stop regeneration service	Engine Management System (D20)
SP0098	Exhaust gas recirculation (EGR) valve correction value self-learning	Engine Management System (D20)
SP0099	Low pressure exhaust gas recirculation (EGR) valve reset	Engine Management System (D20)
SP0100	Self-learning of correction value of throttle valve fully closed position	Engine Management System (D20)
SP0101	Write VIN code	Transmission Control System (TCU)
SP0102	Write vehicle characteristic information	Transmission Control System (TCU)
SP0103	Write network configuration	Transmission Control System (TCU)
SP0104	Write VIN code	Electronic Stability System (ABS/ESP)
SP0105	Write vehicle characteristic information	Electronic Stability System (ABS/ESP)
SP0106	Write down the line detection status	Electronic Stability System (ABS/ESP)
SP0107	Write annotated status	Electronic Stability System (ABS/ESP)
SP0108	Calibration of external yaw rate sensor (only for ESP)	Electronic Stability System (ABS/ESP)
SP0109	Maintenance exhaust	Electronic Stability System (ABS/ESP)
SP0110	Variable data	Electronic Stability System (ABS/ESP)
SP0111	Write VIN code	Airbag System (SRS)
SP0112	Write vehicle characteristic information	Airbag System (SRS)
SP0113	Electric control unit installation date	Airbag System (SRS)
SP0114	Safety belt buckle electric control unit configuration	Airbag System (SRS)
SP0115	Electric control unit configuration of seat belt tensioner	Airbag System (SRS)
SP0116	Airbag sensor electronic control unit configuration	Airbag System (SRS)
SP0117	Write client model	Airbag System (SRS)
SP0118	Write airbag ECU configuration	Airbag System (SRS)
SP0119	Collision output (via hard wire)	Airbag System (SRS)
SP0120	Write VIN code	Body Control System (NLE 2.0)
SP0121	Write vehicle characteristic information	Body Control System (NLE 2.0)
SP0122	Initialize the sun and rain sensor	Body Control System (NLE 2.0)

SP0123	Brake pedal learning	Body Control System (NLE 2.0)
SP0124	Write wiper configuration information	Body Control System (NLE 2.0)
SP0125	Write auxiliary configuration	Body Control System (NLE 2.0)
SP0126	Write other independent configurations	Body Control System (NLE 2.0)
SP0127	Write TBOX calibration configuration	Body Control System (NLE 2.0)
SP0128	Write light configuration information	Body Control System (NLE 2.0)
SP0129	Write BCM configuration information	Body Control System (NLE 2.0)
SP0130	Write VIN code	Body control system
SP0131	Write vehicle characteristic information	Body control system
SP0132	Initialize the sun and rain sensor	Body control system
SP0133	Brake pedal learning	Body control system
SP0134	Write wiper configuration information	Body control system
SP0135	Write auxiliary configuration	Body control system
SP0136	Write other independent configurations	Body control system
SP0137	Write TBOX calibration configuration	Body control system
SP0138	Write light configuration information	Body control system
SP0139	Write BCM configuration information	Body control system
SP0140	Write VIN code	Electronic Power Steering System (EPS)
SP0141	Write vehicle characteristic information	Electronic Power Steering System (EPS)
SP0142	Write down the line configuration	Electronic Power Steering System (EPS)
SP0143	RES configuration	Electronic Power Steering System (EPS)
SP0144	PDC (reversing radar) configuration	Electronic Power Steering System (EPS)
SP0145	CCP configuration	Electronic Power Steering System (EPS)
SP0146	PDC initial torque value	Electronic Power Steering System (EPS)
SP0147	Write VIN code	Instrument system
SP0148	Write vehicle characteristic information	Instrument system
SP0149	Maintenance interval mileage	Instrument system
SP0150	Vehicle system information configuration	Instrument system
SP0151	Instrument self-check: all	Instrument system
SP0152	Meter self-check: speedometer	Instrument system
SP0153	Instrument self-check: tachometer	Instrument system
SP0154	Instrument self-check: fuel	Instrument system
SP0155	Meter self-check: temperature	Instrument system
SP0156	Meter self-check: screen	Instrument system
SP0157	Meter self-check: indicator	Instrument system
SP0158	Instrument self-check: tick sound	Instrument system
SP0159	Perform SIA (maintenance light) reset	Instrument system
SP0160	Write VIN code	Keyless Entry System (PEPS)
SP0161	Write vehicle characteristic information	Keyless Entry System (PEPS)
SP0162	Maximum number of matching keys supported	Keyless Entry System (PEPS)
SP0163	Engine crank timeout value	Keyless Entry System (PEPS)
SP0164	Electronic control unit configuration	Keyless Entry System (PEPS)
SP0165	Write the installation date of the electronic control unit	Keyless Entry System (PEPS)
SP0166	Write VIN code	Air Conditioning System (AC)
SP0167	Write vehicle characteristic information	Air Conditioning System (AC)
SP0168	Write vehicle identification number (VIN)	Tire Pressure Control System (TPMS)
SP0169	Write vehicle characteristic information	Tire Pressure Control System (TPMS)
SP0170	TPMS standard settings	Tire Pressure Control System (TPMS)
SP0171	Winter pattern matching	Tire Pressure Control System (TPMS)
SP0172	Write left front tire status	Tire Pressure Control System (TPMS)
SP0173	Write right front tire status	Tire Pressure Control System (TPMS)
SP0174	Write right rear tire status	Tire Pressure Control System (TPMS)
SP0175	Write left rear tire status	Tire Pressure Control System (TPMS)
SP0176	Left front tire pressure value	Tire Pressure Control System (TPMS)
SP0177	Right front tire pressure value	Tire Pressure Control System (TPMS)
SP0178	Right rear tire pressure value	Tire Pressure Control System (TPMS)
SP0179	Tire pressure value of left rear tire	Tire Pressure Control System (TPMS)
SP0180	Left front tire temperature value	Tire Pressure Control System (TPMS)
SP0181	Right front tire temperature value	Tire Pressure Control System (TPMS)
SP0182	Right rear tire temperature value	Tire Pressure Control System (TPMS)
SP0183	Left rear tire temperature value	Tire Pressure Control System (TPMS)
SP0184	Left front tire matching status	Tire Pressure Control System (TPMS)
SP0185	Right front tire matching status	Tire Pressure Control System (TPMS)
SP0186	Right rear tire matching status	Tire Pressure Control System (TPMS)

SP0187	Left rear tire matching status	Tire Pressure Control System (TPMS)
SP0188	Left front tire sensor ID	Tire Pressure Control System (TPMS)
SP0189	Right front tire sensor ID	Tire Pressure Control System (TPMS)
SP0190	Right rear tire sensor ID	Tire Pressure Control System (TPMS)
SP0191	Rear left tire sensor ID	Tire Pressure Control System (TPMS)
SP0192	Front axle standard pressure setting	Tire Pressure Control System (TPMS)
SP0193	Rear axle standard pressure setting	Tire Pressure Control System (TPMS)
SP0194	High voltage alarm setting	Tire Pressure Control System (TPMS)
SP0195	High pressure alarm limit	Tire Pressure Control System (TPMS)
SP0196	Write vehicle identification number (VIN)	Gateway Control System (GW)
SP0197	Write vehicle characteristic information	Gateway Control System (GW)
SP0198	AFS calibration parameters	Headlight Control System (AFS)
SP0199	Horizontal calibration	Headlight Control System (AFS)
SP0200	Write vehicle identification number (VIN)	Headlight Control System (AFS)
SP0201	Write vehicle characteristic information	Headlight Control System (AFS)
SP0202	Height calibration setting	Headlight Control System (AFS)
SP0203	Write node timeout control settings	Headlight Control System (AFS)
SP0204	AFS system mode settings	Headlight Control System (AFS)
SP0205	Write vehicle identification number (VIN)	Blind Spot Monitoring System (BSD)
SP0206	Write vehicle characteristic information	Blind Spot Monitoring System (BSD)
SP0207	Write vehicle identification number (VIN)	Voltage stabilization module system (DCDC)
SP0208	Write vehicle characteristic information	Voltage stabilization module system (DCDC)
SP0209	Write vehicle identification number (VIN)	Front Infotainment Control System
SP0210	Write vehicle characteristic information	Front Infotainment Control System
SP0211	Write vehicle identification number (VIN)	Front Infotainment Control System (CR)
SP0212	Write vehicle characteristic information	Front Infotainment Control System (CR)
SP0213	Steering wheel custom configuration	Front Infotainment Control System (CR)
SP0214	Language configuration	Front Infotainment Control System (CR)
SP0215	Door type configuration	Front Infotainment Control System (CR)
SP0216	Write personalized settings (assisted driving 1)	Front Infotainment Control System (CR)
SP0217	Write personalized settings (assisted driving 2)	Front Infotainment Control System (CR)
SP0218	Write personalized settings (comfort and convenience)	Front Infotainment Control System (CR)
SP0219	Vehicle configuration 1 (air conditioning/seat/tire pressure)	Front Infotainment Control System (CR)
SP0220	Vehicle configuration 2 (LDW/emergency braking/360 type/car display)	Front Infotainment Control System (CR)
SP0221	DAS service verification	Lane Departure Warning System (LDW)
SP0222	Write vehicle identification number (VIN)	Lane Departure Warning System (LDW)
SP0223	Write vehicle characteristic information	Lane Departure Warning System (LDW)
SP0224	LDW on	Lane Departure Warning System (LDW)
SP0225	Driver's choice of LDW sensitivity	Lane Departure Warning System (LDW)
SP0226	Write vehicle identification number (VIN)	Trailer Module System (LSM)
SP0227	Write vehicle characteristic information	Trailer Module System (LSM)
SP0228	Write vehicle identification number (VIN)	Transfer case control unit system (TCCU)
SP0229	Write vehicle characteristic information	Transfer case control unit system (TCCU)
SP0230	Write vehicle network configuration	Transfer case control unit system (TCCU)
SP0231	MPU upgrade configuration	Telematics control terminal system (TBOX)
SP0232	Replace BCM	Telematics control terminal system (TBOX)
SP0233	Replace TBOX	Telematics control terminal system (TBOX)
SP0234	Write vehicle identification number (VIN)	Telematics control terminal system (TBOX)
SP0235	Write vehicle characteristic information	Telematics control terminal system (TBOX)
SP0236	Cloud authentication	Telematics control terminal system (TBOX)
SP0237	Clutch pedal self-learning	Engine Management System (EMS)
SP0238	Brake pedal self-learning	Engine Management System (EMS)
SP0239	Write vehicle identification number (VIN)	Engine Management System (EMS)
SP0240	Write vehicle characteristic information	Engine Management System (EMS)
SP0241	Write EMS configuration	Engine Management System (EMS)
SP0242	Write vehicle identification number (VIN)	Transmission Control System (TCU)
SP0243	Write vehicle characteristic information	Transmission Control System (TCU)
SP0244	Write network configuration	Transmission Control System (TCU)
SP0245	Write down the line status	Electronic Stability System (ABS/ESP)
SP0246	Write annotated status	Electronic Stability System (ABS/ESP)
SP0247	Maintenance exhaust	Electronic Stability System (ABS/ESP)
SP0248	Calibration of external yaw rate sensor (only for ESP)	Electronic Stability System (ABS/ESP)
SP0249	Write vehicle identification number (VIN)	Electronic Stability System (ABS/ESP)
SP0250	Write vehicle characteristic information	Electronic Stability System (ABS/ESP)

SP0251	Write variable data (long axis/short axis)	Electronic Stability System (ABS/ESP)
SP0252	Write vehicle identification number (VIN)	Airbag System (SRS)
SP0253	Write vehicle characteristic information	Airbag System (SRS)
SP0254	Write the part number of the electronic control unit	Airbag System (SRS)
SP0255	Safety belt buckle electric control unit configuration	Airbag System (SRS)
SP0256	Electric control unit configuration of seat belt tensioner	Airbag System (SRS)
SP0257	Write client model	Airbag System (SRS)
SP0258	Write airbag ECU configuration	Airbag System (SRS)
SP0259	Collision output (via hard wire)	Airbag System (SRS)
SP0260	Air curtain	Airbag System (SRS)
SP0261	Passenger airbag	Airbag System (SRS)
SP0262	Driving sensor	Airbag System (SRS)
SP0263	Initialize the sun and rain sensor	Body Control System (BCM)
SP0264	Brake pedal self-learning	Body Control System (BCM)
SP0265	Write vehicle identification number (VIN)	Body Control System (BCM)
SP0266	Write vehicle characteristic information	Body Control System (BCM)
SP0267	Write wiper configuration information	Body Control System (BCM)
SP0268	Write auxiliary configuration	Body Control System (BCM)
SP0269	Write other independent configurations	Body Control System (BCM)
SP0270	Write TBOX calibration configuration	Body Control System (BCM)
SP0271	Write light configuration information	Body Control System (BCM)
SP0272	Write BCM configuration information	Body Control System (BCM)
SP0273	Write personalized factory settings	Body Control System (BCM)
SP0274	Write vehicle identification number (VIN)	Electronic Power Steering System (EPS)
SP0275	Write vehicle characteristic information	Electronic Power Steering System (EPS)
SP0276	Write down the line configuration	Electronic Power Steering System (EPS)
SP0277	RES configuration	Electronic Power Steering System (EPS)
SP0278	PDC (reversing radar) configuration	Electronic Power Steering System (EPS)
SP0279	CCP configuration	Electronic Power Steering System (EPS)
SP0280	PDC initial torque value	Electronic Power Steering System (EPS)
SP0281	Perform SIA (maintenance light) reset	Instrument Control System (IPK)
SP0282	Write vehicle identification number (VIN)	Instrument Control System (IPK)
SP0283	Write vehicle characteristic information	Instrument Control System (IPK)
SP0284	Vehicle system information configuration	Instrument Control System (IPK)
SP0285	Instrument self-check: all	Instrument Control System (IPK)
SP0286	Instrument self-check: reserved	Instrument Control System (IPK)
SP0287	Write vehicle identification VIN code	Keyless Entry System (PEPS)
SP0288	Write vehicle characteristic information	Keyless Entry System (PEPS)
SP0289	Write the installation date of the electronic control unit	Keyless Entry System (PEPS)
SP0290	Electronic control unit configuration	Keyless Entry System (PEPS)
SP0291	Maximum number of matching keys supported	Keyless Entry System (PEPS)
SP0292	Engine crank timeout value	Keyless Entry System (PEPS)
SP0293	Write vehicle identification VIN code	Air Conditioning System (AC)
SP0294	Write vehicle characteristic information	Air Conditioning System (AC)
SP0295	Configure steering wheel position	Air Conditioning System (AC)
SP0296	TPMS standard settings	Tire Pressure Control System (TPMS)
SP0297	Write vehicle identification number (VIN)	Tire Pressure Control System (TPMS)
SP0298	Write vehicle characteristic information	Tire Pressure Control System (TPMS)
SP0299	Winter mode configuration	Tire Pressure Control System (TPMS)
SP0300	Front axle standard pressure setting	Tire Pressure Control System (TPMS)
SP0301	Rear axle standard pressure setting	Tire Pressure Control System (TPMS)
SP0302	High voltage alarm setting	Tire Pressure Control System (TPMS)
SP0303	Write configuration information	Electronic parking brake system (EPB)
SP0304	Service mode is on	Electronic parking brake system (EPB)
SP0305	EPB clamping on both sides	Electronic parking brake system (EPB)
SP0306	EPB release on both sides	Electronic parking brake system (EPB)
SP0307	EPB clamping on the left	Electronic parking brake system (EPB)
SP0308	Right EPB clamping	Electronic parking brake system (EPB)
SP0309	EPB release on the left	Electronic parking brake system (EPB)
SP0310	Right EPB release	Electronic parking brake system (EPB)
SP0311	Service mode is off	Electronic parking brake system (EPB)
SP0312	Assembly inspection	Electronic parking brake system (EPB)
SP0313	Write vehicle identification number (VIN)	Electronic parking brake system (EPB)
SP0314	Write vehicle characteristic information	Electronic parking brake system (EPB)

SP0315	Write vehicle identification number (VIN)	Gateway Control System (GW)
SP0316	Write vehicle characteristic information	Gateway Control System (GW)
SP0317	AFS calibration parameters	Headlight Control System (AFS)
SP0318	Horizontal calibration position	Headlight Control System (AFS)
SP0319	Write vehicle identification number (VIN)	Headlight Control System (AFS)
SP0320	Write vehicle characteristic information	Headlight Control System (AFS)
SP0321	Height calibration setting	Headlight Control System (AFS)
SP0322	Write node timeout control settings	Headlight Control System (AFS)
SP0323	Write vehicle identification number (VIN)	ATS intelligent four-wheel drive models and timely four-wheel drive models
SP0324	Write vehicle characteristic information	ATS intelligent four-wheel drive models and timely four-wheel drive models
SP0325	Select ATS (All Terrain System) type-ATS (All Terrain System)	ATS intelligent four-wheel drive models and timely four-wheel drive models
SP0326	Select EPB (Electronic Hand Brake) Type-Automatic	ATS intelligent four-wheel drive models and timely four-wheel drive models
SP0327	Transmission control unit type	ATS intelligent four-wheel drive models and timely four-wheel drive models
SP0328	Write vehicle identification number (VIN)	Transfer case control unit
SP0329	Write vehicle characteristic information	Transfer case control unit
SP0330	Write vehicle network configuration	Transfer case control unit
SP0331	Write vehicle identification number (VIN)	Ambient Light Control System (ALC)
SP0332	Write vehicle characteristic information	Ambient Light Control System (ALC)
SP0333	Write vehicle identification number (VIN)	Parking Assist System (APA)
SP0334	Write vehicle characteristic information	Parking Assist System (APA)
SP0335	Write configuration information	Parking Assist System (APA)
SP0336	UPA mode	Parking Assist System (APA)
SP0337	Write vehicle identification number (VIN)	Voltage stabilization module system (DCDC)
SP0338	Write vehicle characteristic information	Voltage stabilization module system (DCDC)
SP0339	Write vehicle identification number (VIN)	Seat Memory Module System (DSM)
SP0340	Write vehicle characteristic information	Seat Memory Module System (DSM)
SP0341	Position error range of lifter motor	Seat Memory Module System (DSM)
SP0342	Recliner motor position error range	Seat Memory Module System (DSM)
SP0343	Write function configuration	Seat Memory Module System (DSM)
SP0344	Slow write mode	Seat Memory Module System (DSM)
SP0345	Error range of slider motor position	Seat Memory Module System (DSM)
SP0346	Threshold of currently locked recliner motor (mA)	Seat Memory Module System (DSM)
SP0347	Threshold of currently locked recliner motor (mA)	Seat Memory Module System (DSM)
SP0348	Threshold of currently locked slider motor (mA)	Seat Memory Module System (DSM)
SP0349	Threshold of locked motor overcurrent (mA)	Seat Memory Module System (DSM)
SP0350	Position error range of the turning machine motor	Seat Memory Module System (DSM)
SP0351	Write vehicle identification number (VIN)	Electronic Differential Lock Module System (EDL)
SP0352	Write vehicle characteristic information	Electronic Differential Lock Module System (EDL)
SP0353	Write vehicle configuration information	Electronic Differential Lock Module System (EDL)
SP0354	Write FICM offline configuration version	Front Infotainment Control System
SP0355	Write vehicle identification number (VIN)	Front Infotainment Control System
SP0356	Write vehicle characteristic information	Front Infotainment Control System
SP0357	Write vehicle identification number (VIN)	Front Infotainment Control System (CR)
SP0358	Write vehicle characteristic information	Front Infotainment Control System (CR)
SP0359	DAS service verification	Lane Departure Warning System (LDW)
SP0360	Write vehicle identification number (VIN)	Lane Departure Warning System (LDW)
SP0361	Write vehicle characteristic information	Lane Departure Warning System (LDW)
SP0362	Write DAS function configuration	Lane Departure Warning System (LDW)
SP0363	Write the default value of the configuration selected by the driver	Lane Departure Warning System (LDW)
SP0364	Write function switch configuration	Lane Departure Warning System (LDW)
SP0365	Vehicle area code	Lane Departure Warning System (LDW)
SP0366	Speed configuration	Lane Departure Warning System (LDW)
SP0367	Self-learning	Electric tailgate controller system (PTG)
SP0368	Write vehicle identification number (VIN)	Electric tailgate controller system (PTG)
SP0369	Write vehicle characteristic information	Electric tailgate controller system (PTG)
SP0370	Electronic control unit configuration 1	Electric tailgate controller system (PTG)
SP0371	Electronic control unit configuration 2	Electric tailgate controller system (PTG)
SP0372	MPU upgrade configuration	Telematics control terminal system (TBOX)
SP0373	Write vehicle identification number (VIN)	Telematics control terminal system (TBOX)
SP0374	Write vehicle characteristic information	Telematics control terminal system (TBOX)
SP0375	Replace BCM	Telematics control terminal system (TBOX)
SP0376	Replace TBOX	Telematics control terminal system (TBOX)
SP0377	Clutch pedal self-learning	Engine Management System (EDC17C53 EU4)
SP0378	Read the IAQ code of the injector	Engine Management System (EDC17C53 EU4)

SP0379	Write the injector IQA code	Engine Management System (EDC17C53 EU4)
SP0380	Write the maximum speed limit value	Engine Management System (EDC17C53 EU4)
SP0381	Read VIN code	Engine Management System (EDC17C53 EU4)
SP0382	Write repair station code and programming date	Engine Management System (EDC17C53 EU4)
SP0383	Write the zero fuel volume calibration correction value for the fuel injection volume of the fuel injector	Engine Management System (EDC17C53 EU4)
SP0384	Write vehicle identification number (VIN)	Engine Management System (EDC17C53 EU6)
SP0385	FMO reset (replace lambda oxygen sensor)	Engine Management System (EDC17C53 EU6)
SP0386	FMO reset (replace rail pressure sensor)	Engine Management System (EDC17C53 EU6)
SP0387	FMO reset (replace the injector)	Engine Management System (EDC17C53 EU6)
SP0388	SCR catalyst load reset	Engine Management System (EDC17C53 EU6)
SP0389	ZFC reset	Engine Management System (EDC17C53 EU6)
SP0390	The total time of the metering valve overheating reset	Engine Management System (EDC17C53 EU6)
SP0391	Air flow meter drift correction value reset	Engine Management System (EDC17C53 EU6)
SP0392	The status is reset when the first filling is completed	Engine Management System (EDC17C53 EU6)
SP0393	Read the IQA code of the injector	Engine Management System (EDC17C53 EU6)
SP0394	Write the injector IQA code	Engine Management System (EDC17C53 EU6)
SP0395	Write the zero fuel volume calibration correction value for the fuel injection volume of the fuel injector	Engine Management System (EDC17C53 EU6)
SP0396	Write engine running time	Engine Management System (EDC17C53 EU6)
SP0397	Write the distance traveled by the engine	Engine Management System (EDC17C53 EU6)
SP0398	Air flow meter drift correction value	Engine Management System (EDC17C53 EU6)
SP0399	Write DEF lifetime consumption	Engine Management System (EDC17C53 EU6)
SP0400	Write SCR catalyst loading	Engine Management System (EDC17C53 EU6)
SP0401	Write the total time for the metering valve to overheat	Engine Management System (EDC17C53 EU6)
SP0402	Write remaining mileage	Engine Management System (EDC17C53 EU6)
SP0403	Write the completion status of the first refill	Engine Management System (EDC17C53 EU6)
SP0404	Write the maximum speed limit value	Engine Management System (EDC17C53 EU6)
SP0405	Write engine code	Engine Management System (EDC17C53 EU6)
SP0406	Cure detection (SCR mechanical or electronic failure)	Engine Management System (EDC17C53 EU6)
SP0407	Cure test (empty urea tank)	Engine Management System (EDC17C53 EU6)
SP0408	Configuration	Engine Management System (EDC17C53 EU6)
SP0409	Write identifier configuration	Engine Management System (EDC17C53 EU6)
SP0410	Write speed sensor selection	Engine Management System (EDC17C53 EU6)
SP0411	Read the injector IQA code	Engine Management System (EDC17C53 EU6)
SP0412	Write the injector IQA code	Engine Management System (EDC17C53 EU6)
SP0413	DPF manual regeneration	Engine Management System (EDC17C53 EU6)
SP0414	Diesel particulate filter value	Engine Management System (EDC17C53 EU6)
SP0415	Diesel particulate filter value write	Engine Management System (EDC17C53 EU6)
SP0416	Diesel particulate filter value reset	Engine Management System (EDC17C53 EU6)
SP0417	Clutch pedal self-learning	Engine Management System (EDC17C53 EU6)
SP0418	Injector closed test cylinder 1	Engine Management System (EDC17C53 EU6)
SP0419	Injector closed test cylinder 2	Engine Management System (EDC17C53 EU6)
SP0420	Injector closed test cylinder 3	Engine Management System (EDC17C53 EU6)
SP0421	Injector closed test cylinder 4	Engine Management System (EDC17C53 EU6)
SP0422	Compression test	Engine Management System (EDC17C53 EU6)
SP0423	high-pressure test	Engine Management System (EDC17C53 EU6)
SP0424	Accelerated testing	Engine Management System (EDC17C53 EU6)
SP0425	Engine speed when each cylinder is doing work	Engine Management System (EDC17C53 EU6)
SP0426	Start failure information	Engine Management System (EDC17C53 EU6)
SP0427	Reflux pump test	Engine Management System (EDC17C53 EU6)
SP0428	Urea injection volume test	Engine Management System (EDC17C53 EU6)
SP0429	Dry action test of urea injection unit	Engine Management System (EDC17C53 EU6)
SP0430	EOL test	Engine Management System (EDC17C53 EU6)
SP0431	First activation test	Engine Management System (EDC17C53 EU6)
SP0432	Leak detection test	Engine Management System (EDC17C53 EU6)
SP0433	System empty test	Engine Management System (EDC17C53 EU6)
SP0434	FMO reset (replace lambda oxygen sensor)	Engine Management System (EDC17C53 EU5)
SP0435	FMO reset (replace rail pressure sensor)	Engine Management System (EDC17C53 EU5)
SP0436	FMO reset (replace air flow meter)	Engine Management System (EDC17C53 EU5)
SP0437	FMO reset (replace the injector)	Engine Management System (EDC17C53 EU5)
SP0438	Lambda oxygen sensor dew point detection reset	Engine Management System (EDC17C53 EU5)
SP0439	Air flow meter drift correction value reset	Engine Management System (EDC17C53 EU5)
SP0440	Read the IQA code of the injector	Engine Management System (EDC17C53 EU5)
SP0441	Write the injector IQA code	Engine Management System (EDC17C53 EU5)
SP0442	Write vehicle identification number (VIN)	Engine Management System (EDC17C53 EU5)

SP0443	Write the maximum speed limit value	Engine Management System (EDC17C53 EU5)
SP0444	Write calibration identification number	Engine Management System (EDC17C53 EU5)
SP0445	EGR (exhaust gas recirculation) valve self-learning	Engine Management System (EDC17C53 EU5)
SP0446	Write repair station code	Engine Management System (EDC17C53 EU5)
SP0447	TVA valve fully closed position correction value self-learning	Engine Management System (EDC17C53 EU5)
SP0448	DPF manual regeneration	Engine Management System (EDC17C53 EU5)
SP0449	Diesel particulate filter value	Engine Management System (EDC17C53 EU5)
SP0450	Diesel particulate filter value write	Engine Management System (EDC17C53 EU5)
SP0451	Diesel particulate filter value reset	Engine Management System (EDC17C53 EU5)
SP0452	Vehicle speed selection source	Engine Management System (EDC17C53 EU5)
SP0453	Write engine running time	Engine Management System (EDC17C53 EU5)
SP0454	Repair date	Engine Management System (EDC17C53 EU5)
SP0455	Air flow meter drift correction value	Engine Management System (EDC17C53 EU5)
SP0456	Write the zero fuel volume calibration correction value for the fuel injection volume of the fuel injector	Engine Management System (EDC17C53 EU5)
SP0457	Clutch pedal self-learning	Engine Management System (EDC17C53 EU5)
SP0458	Oil uniformity test (FBC)	Engine Management System (EDC17C53 EU5)
SP0459	Reflux pump test	Engine Management System (EDC17C53 EU5)
SP0460	Pressure relief of hydraulic accumulator	Automatic Transmission Control System (TCU)
SP0461	Clutch exhaust	Automatic Transmission Control System (TCU)
SP0462	Gearbox gear learning	Automatic Transmission Control System (TCU)
SP0463	Clutch engagement point self-learning	Automatic Transmission Control System (TCU)
SP0464	Accelerometer offset self-learning	Automatic Transmission Control System (TCU)
SP0465	Clutch replacement	Automatic Transmission Control System (TCU)
SP0466	Actuator replacement	Automatic Transmission Control System (TCU)
SP0467	Gearbox replacement	Automatic Transmission Control System (TCU)
SP0468	Shift lever replacement	Automatic Transmission Control System (TCU)
SP0469	Actuator hydraulic pump replacement	Automatic Transmission Control System (TCU)
SP0470	Storage tank replacement	Automatic Transmission Control System (TCU)
SP0471	Actuator hydraulic pump relay replacement	Automatic Transmission Control System (TCU)
SP0472	Mode switch replacement	Automatic Transmission Control System (TCU)
SP0473	The vehicle uses static data reset	Automatic Transmission Control System (TCU)
SP0474	Write vehicle identification number (VIN)	Automatic Transmission Control System (TCU)
SP0475	Write vehicle characteristic information	Automatic Transmission Control System (TCU)
SP0476	Maintenance exhaust	Anti-lock brake system (ABS)
SP0477	Raising status	Anti-lock brake system (ABS)
SP0478	Offline test status	Anti-lock brake system (ABS)
SP0479	Variable data (long axis and short axis)	Anti-lock brake system (ABS)
SP0480	Write vehicle identification number (VIN)	Airbag System (SRS)
SP0481	Write ECU configuration information: system fault light	Airbag System (SRS)
SP0482	Write ECU configuration information: collision output	Airbag System (SRS)
SP0483	Write ECU configuration information: the occupant seat belt pretensioner exists	Airbag System (SRS)
SP0484	Write ECU configuration information: the driver's seat belt pretensioner exists	Airbag System (SRS)
SP0485	Write ECU configuration information: the presence of front airbags	Airbag System (SRS)
SP0486	Write ECU configuration information: the presence of the driver's front airbag	Airbag System (SRS)
SP0487	Does the airbag controller have an ignition function?	Airbag System (SRS)
SP0488	Write vehicle identification number (VIN)	Body control system
SP0489	Body side door configuration	Body control system
SP0490	Defrost heating configuration	Body control system
SP0491	Front fog lamp configuration	Body control system
SP0492	Remote control key function configuration	Body control system
SP0493	IMMO function configuration	Body control system
SP0494	Body controller status	Body control system
SP0495	Emergency lights (school bus)	Body control system
SP0496	Daytime running lights configuration (export)	Body control system
SP0497	Tailgate open alarm configuration (school bus)	Body control system
SP0498	Number of matching remote control keys (school bus)	Body control system
SP0499	Rear ceiling reading light configuration	Body control system
SP0500	Tailgate configuration	Body control system
SP0501	Number of buttons on the remote control key	Body control system
SP0502	Enable sliding door open warning configuration	Body control system
SP0503	Enable the vehicle to automatically release the lock configuration	Body control system
SP0504	Rear fog lamp configuration	Body control system
SP0505	Write vehicle identification number (VIN)	Body Control System (2018)
SP0506	Write vehicle characteristic information	Body Control System (2018)

SP0507	BCM allows the number of authentication failures	Body Control System (2018)
SP0508	Maximum time to wait for TBOX response	Body Control System (2018)
SP0509	Brake pad calibration threshold setting	Body Control System (2018)
SP0510	Write fatigue driving detection calibration configuration	Body Control System (2018)
SP0511	Write wiper configuration information	Body Control System (2018)
SP0512	Write auxiliary configuration	Body Control System (2018)
SP0513	Write other independent configurations	Body Control System (2018)
SP0514	Write TBOX calibration configuration	Body Control System (2018)
SP0515	Write light configuration information	Body Control System (2018)
SP0516	Write personalized factory settings	Body Control System (2018)
SP0517	Write BCM configuration information	Body Control System (2018)
SP0518	Perform SIA (maintenance light) reset	Instrumentation System (2018)
SP0519	Write vehicle identification number (VIN)	Instrumentation System (2018)
SP0520	Write vehicle characteristic information	Instrumentation System (2018)
SP0521	Maintenance configuration	Instrumentation System (2018)
SP0522	IPK configuration	Instrumentation System (2018)
SP0523	Speeding alarm	Instrument system
SP0524	IPK configuration	Instrument system
SP0525	Write vehicle identification number (VIN)	Instrument system
SP0526	Write vehicle characteristic information	Instrument system
SP0527	Meter self-check: speedometer	Instrument system
SP0528	Instrument self-check: tachometer	Instrument system
SP0529	Instrument self-check: fuel	Instrument system
SP0530	Meter self-check: temperature	Instrument system
SP0531	Meter self-check: screen	Instrument system
SP0532	Meter self-check: indicator	Instrument system
SP0533	Instrument self-check: tick sound	Instrument system
SP0534	ESP internal sensor calibration	Electronic Stability System (ESC)
SP0535	Maintenance exhaust	Electronic Stability System (ESC)
SP0536	Write vehicle identification number (VIN)	Electronic Stability System (ESC)
SP0537	Write vehicle characteristic information	Electronic Stability System (ESC)
SP0538	Write variable data (long axis/short axis)	Electronic Stability System (ESC)
SP0539	Write down the line status	Electronic Stability System (ESC)
SP0540	Write annotated status	Electronic Stability System (ESC)
SP0541	Write vehicle identification number (VIN)	Tire Pressure Control System (TPMS)
SP0542	Write vehicle characteristic information	Tire Pressure Control System (TPMS)
SP0543	Write left front tire status	Tire Pressure Control System (TPMS)
SP0544	Write right front tire status	Tire Pressure Control System (TPMS)
SP0545	Write right rear tire status	Tire Pressure Control System (TPMS)
SP0546	Write left rear tire status	Tire Pressure Control System (TPMS)
SP0547	Left front tire pressure value	Tire Pressure Control System (TPMS)
SP0548	Right front tire pressure value	Tire Pressure Control System (TPMS)
SP0549	Right rear tire pressure value	Tire Pressure Control System (TPMS)
SP0550	Tire pressure value of left rear tire	Tire Pressure Control System (TPMS)
SP0551	Left front tire temperature value	Tire Pressure Control System (TPMS)
SP0552	Right front tire temperature value	Tire Pressure Control System (TPMS)
SP0553	Right rear tire temperature value	Tire Pressure Control System (TPMS)
SP0554	Left rear tire temperature value	Tire Pressure Control System (TPMS)
SP0555	Left front tire matching status	Tire Pressure Control System (TPMS)
SP0556	Right front tire matching status	Tire Pressure Control System (TPMS)
SP0557	Right rear tire matching status	Tire Pressure Control System (TPMS)
SP0558	Left rear tire matching status	Tire Pressure Control System (TPMS)
SP0559	Left front tire sensor ID	Tire Pressure Control System (TPMS)
SP0560	Right front tire sensor ID	Tire Pressure Control System (TPMS)
SP0561	Right rear tire sensor ID	Tire Pressure Control System (TPMS)
SP0562	Rear left tire sensor ID	Tire Pressure Control System (TPMS)
SP0563	EPB initialization calibration	Electronic parking brake system (EPB)
SP0564	Write vehicle identification number (VIN)	Electronic parking brake system (EPB)
SP0565	Write vehicle characteristic information	Electronic parking brake system (EPB)
SP0566	Write system configuration	Electronic parking brake system (EPB)
SP0567	Write vehicle mode configuration	Electronic parking brake system (EPB)
SP0568	Write vehicle identification number (VIN)	Gateway Control System (GW)
SP0569	Write vehicle characteristic information	Gateway Control System (GW)
SP0570	Write fault code settings	Gateway Control System (GW)

SP0571	Write vehicle identification number (VIN)	Front Infotainment Control Systems (FICMs)
SP0572	Write vehicle characteristic information	Front Infotainment Control Systems (FICMs)
SP0573	Vehicle configuration 1 (air conditioning/seat/tire pressure)	Front Infotainment Control Systems (FICMs)
SP0574	Vehicle configuration 2 (lane departure/automatic braking/blind spot monitoring/forward collision/360° panoramic type/vehicle display)	Front Infotainment Control Systems (FICMs)
SP0575	Write side air curtain setting	Front Infotainment Control Systems (FICMs)
SP0576	Vehicle configuration 3 (power windows/navigation/hands-free)	Front Infotainment Control Systems (FICMs)
SP0577	Vehicle configuration 4 (entertainment display/digital broadcasting/parking assist/rear view camera/360° panoramic display)	Front Infotainment Control Systems (FICMs)
SP0578	Vehicle configuration 5 (steering wheel/audio/AUX port/video input)	Front Infotainment Control Systems (FICMs)
SP0579	Vehicle configuration 6 (USB port/radio frequency)	Front Infotainment Control Systems (FICMs)
SP0580	Vehicle configuration 7 (IPOD/model year/model series)	Front Infotainment Control Systems (FICMs)
SP0581	Vehicle configuration 8 (brand/country/driving direction/engine type)	Front Infotainment Control Systems (FICMs)
SP0582	Vehicle configuration 9 (gearbox/tailgate/pedestrian warning)	Front Infotainment Control Systems (FICMs)
SP0583	Vehicle configuration A (vehicle speed alarm/emergency call/sunroof/hybrid)	Front Infotainment Control Systems (FICMs)
SP0584	Vehicle configuration B (main driving economy mode/light sensor)	Front Infotainment Control Systems (FICMs)
SP0585	Vehicle configuration C (air purification system/model configuration/GPS chip)	Front Infotainment Control Systems (FICMs)
SP0586	Vehicle configuration D (voice recognition/ESP/ABS node/steering angle sensor/PEPS configuration)	Front Infotainment Control Systems (FICMs)
SP0587	Vehicle configuration E (WIFI/chassis height/drive type/speed limit)	Front Infotainment Control Systems (FICMs)
SP0588	Vehicle configuration 20 (Internet of Vehicles/Welcome Light and Ambient Light/Seat Memory)	Front Infotainment Control Systems (FICMs)
SP0589	Write vehicle identification number (VIN)	Lane Change Alert Controller System (LCA)
SP0590	Write vehicle characteristic information	Lane Change Alert Controller System (LCA)
SP0591	Wheelbase type	Lane Change Alert Controller System (LCA)
SP0592	Write vehicle identification number (VIN)	Telematics control terminal system (TBOX)
SP0593	Write vehicle characteristic information	Telematics control terminal system (TBOX)
SP0594	Enter sleep mode time (min)	Telematics control terminal system (TBOX)
SP0595	Allow periodic wake-up time (day)	Telematics control terminal system (TBOX)
SP0596	Write data acquisition configuration	Telematics control terminal system (TBOX)
SP0597	Write data collection event configuration	Telematics control terminal system (TBOX)
SP0598	Replace BCM	Telematics control terminal system (TBOX)
SP0599	Replace TBOX	Telematics control terminal system (TBOX)
SP0600	Cloud authentication	Telematics control terminal system (TBOX)
SP0601	Maintenance exhaust	Anti-lock brake system (ABS)
SP0602	Raising status	Anti-lock brake system (ABS)
SP0603	Offline test status	Anti-lock brake system (ABS)
SP0604	Variable data (long axis and short axis)	Anti-lock brake system (ABS)
SP0605	Write vehicle identification number (VIN)	Airbag System (SRS)
SP0606	Write ECU configuration information: system fault light	Airbag System (SRS)
SP0607	Write ECU configuration information: collision output	Airbag System (SRS)
SP0608	Write ECU configuration information: the occupant seat belt pretensioner exists	Airbag System (SRS)
SP0609	Write ECU configuration information: the driver's seat belt pretensioner exists	Airbag System (SRS)
SP0610	Write ECU configuration information: the presence of front airbags	Airbag System (SRS)
SP0611	Write ECU configuration information: the presence of the driver's front airbag	Airbag System (SRS)
SP0612	Does the airbag controller have an ignition function?	Airbag System (SRS)
SP0613	Replace the gasoline particulate filter (GPF)	Engine Management System (NLE)
SP0614	Replace the gasoline particulate filter (GPF) differential pressure sensor	Engine Management System (NLE)
SP0615	Replace gasoline particulate filter (GPF) regeneration	Engine Management System (NLE)
SP0616	Replace the gasoline particulate filter (GPF)	Engine Management System (NLE)
SP0617	Replace the gasoline particulate filter (GPF) differential pressure sensor	Engine Management System (NLE)
SP0618	Replace gasoline particulate filter (GPF) regeneration	Engine Management System (NLE)
SP0619	Speed limit write	Engine Management System (D20)
SP0620	Vehicle speed sensor source selection write	Engine Management System (D20)
SP0621	Throttle replacement	Engine Management System (D20)
SP0622	Diesel Particulate Filter (DPF) Differential Pressure Sensor	Engine Management System (D20)
SP0623	Injector replacement	Engine Management System (D20)
SP0624	Write fuel injection correction (IQA) code	Engine Management System (D20)
SP0625	Fuel quality correction reset (replace injector)	Engine Management System (D20)
SP0626	After-treatment catalyst NH3 load reset	Engine Management System (D20)
SP0627	Diesel particulate filter related value reset	Engine Management System (D20)
SP0628	Reset regeneration lock and increase soot quality	Engine Management System (D20)
SP0629	Cancel regeneration lock	Engine Management System (D20)
SP0630	Activate regeneration service	Engine Management System (D20)
SP0631	Stop regeneration service	Engine Management System (D20)
SP0632	Exhaust gas recirculation (EGR) valve correction value self-learning	Engine Management System (D20)
SP0633	Low pressure exhaust gas recirculation (EGR) valve reset	Engine Management System (D20)

SP0634	Self-learning of correction value of throttle valve fully closed position	Engine Management System (D20)
SP0635	Read the fuel injection correction (IQA) code	Engine Management System (EDC17C81 D19t EU5)
SP0636	Write fuel injection correction (IQA) code	Engine Management System (EDC17C81 D19t EU5)
SP0637	Write the zero fuel volume calibration correction value for the fuel injection volume of the fuel injector	Engine Management System (EDC17C81 D19t EU5)
SP0638	Reset the zero fuel volume calibration correction value written into the fuel injection volume of the fuel injector	Engine Management System (EDC17C81 D19t EU5)
SP0639	Write the maximum speed limit value	Engine Management System (EDC17C81 D19t EU5)
SP0640	DPF regeneration lock canceled	Engine Management System (EDC17C81 D19t EU5)
SP0641	DPF regeneration lock reset	Engine Management System (EDC17C81 D19t EU5)
SP0642	DPF regeneration function activated	Engine Management System (EDC17C81 D19t EU5)
SP0643	DPF regeneration function terminated	Engine Management System (EDC17C81 D19t EU5)
SP0644	Diesel particulate filter value	Engine Management System (EDC17C81 D19t EU5)
SP0645	Diesel particulate filter value write	Engine Management System (EDC17C81 D19t EU5)
SP0646	Diesel particulate filter value reset	Engine Management System (EDC17C81 D19t EU5)
SP0647	Read the fuel injection correction (IQA) code	Engine Management System (EDC17C81 D19t EU4)
SP0648	Write fuel injection correction (IQA) code	Engine Management System (EDC17C81 D19t EU4)
SP0649	Write the zero fuel volume calibration correction value for the fuel injection volume of the fuel injector	Engine Management System (EDC17C81 D19t EU4)
SP0650	Reset the zero fuel volume calibration correction value written into the fuel injection volume of the fuel injector	Engine Management System (EDC17C81 D19t EU4)
SP0651	Write the maximum speed limit value	Engine Management System (EDC17C81 D19t EU4)
SP0652	Write the frame number	Engine Management System
SP0653	Vehicle speed limit information writing	Engine Management System
SP0654	Speed and mileage write	Engine Management System
SP0655	EGR (exhaust gas recirculation) valve correction value self-learning	Engine Management System
SP0656	TVA valve fully closed position correction value self-learning	Engine Management System
SP0657	Diesel particulate filter reset value	Engine Management System
SP0658	DPF regeneration	Engine Management System
SP0659	DPF regeneration lock canceled	Engine Management System
SP0660	DPF regeneration lock reset	Engine Management System
SP0661	Fuel accumulation detection system FMO setting	Engine Management System
SP0662	Air flow meter sensor reset	Engine Management System
SP0663	Oxygen sensor LSU reset	Engine Management System
SP0664	Configuration	Engine Management System
SP0665	Clutch pedal self-learning	Engine Management System
SP0666	Fuel injection closed test 1 cylinder	Engine Management System
SP0667	Fuel injection closed test 2 cylinders	Engine Management System
SP0668	Fuel injection closed test 3-cylinder	Engine Management System
SP0669	Fuel injection closed test 4-cylinder	Engine Management System
SP0670	Engine speed when each cylinder is doing work	Engine Management System
SP0671	Start failure information	Engine Management System
SP0672	Compression test	Engine Management System
SP0673	Maintenance exhaust	Anti-lock brake system (ABS)
SP0674	Write airbag ECU configuration	Airbag System (SRS)
SP0675	Write client mode	Airbag System (SRS)
SP0676	ECU (Electronic Controller) reset	Airbag System (SRS)
SP0677	Write airbag ECU configuration	Airbag System (SRS) 2018 Plus
SP0678	Write client mode	Airbag System (SRS) 2018 Plus
SP0679	ECU (Electronic Controller) reset	Airbag System (SRS) 2018 Plus
SP0680	Steering wheel angle sensor calibration	Electronic Power Steering System (EPS)
SP0681	Manual setting of maintenance light	Instrument Control System (ICM)
SP0682	Maintenance light resets automatically	Instrument Control System (ICM)
SP0683	Write left front tire status	Tire Pressure Monitoring System (TPMS)
SP0684	Write right front tire status	Tire Pressure Monitoring System (TPMS)
SP0685	Write right rear tire status	Tire Pressure Monitoring System (TPMS)
SP0686	Write left rear tire status	Tire Pressure Monitoring System (TPMS)
SP0687	Left front tire pressure value	Tire Pressure Monitoring System (TPMS)
SP0688	Right front tire pressure value	Tire Pressure Monitoring System (TPMS)
SP0689	Right rear tire pressure value	Tire Pressure Monitoring System (TPMS)
SP0690	Tire pressure value of left rear tire	Tire Pressure Monitoring System (TPMS)
SP0691	Left front tire temperature value	Tire Pressure Monitoring System (TPMS)
SP0692	Right front tire temperature value	Tire Pressure Monitoring System (TPMS)
SP0693	Right rear tire temperature value	Tire Pressure Monitoring System (TPMS)
SP0694	Left rear tire temperature value	Tire Pressure Monitoring System (TPMS)
SP0695	Left front tire matching status	Tire Pressure Monitoring System (TPMS)
SP0696	Right front tire matching status	Tire Pressure Monitoring System (TPMS)
SP0697	Right rear tire matching status	Tire Pressure Monitoring System (TPMS)

SP0698	Left rear tire matching status	Tire Pressure Monitoring System (TPMS)
SP0699	Left front tire sensor ID	Tire Pressure Monitoring System (TPMS)
SP0700	Right front tire sensor ID	Tire Pressure Monitoring System (TPMS)
SP0701	Right rear tire sensor ID	Tire Pressure Monitoring System (TPMS)
SP0702	Rear left tire sensor ID	Tire Pressure Monitoring System (TPMS)
SP0703	Speed limit write	Engine Management System (D20)
SP0704	Vehicle speed sensor source selection write	Engine Management System (D20)
SP0705	Throttle replacement	Engine Management System (D20)
SP0706	Diesel Particulate Filter (DPF) Differential Pressure Sensor	Engine Management System (D20)
SP0707	Injector replacement	Engine Management System (D20)
SP0708	Write fuel injection correction (IQA) code	Engine Management System (D20)
SP0709	Fuel quality correction reset (replace injector)	Engine Management System (D20)
SP0710	After-treatment catalyst NH3 load reset	Engine Management System (D20)
SP0711	Diesel particulate filter related value reset	Engine Management System (D20)
SP0712	Reset regeneration lock and increase soot quality	Engine Management System (D20)
SP0713	Cancel regeneration lock	Engine Management System (D20)
SP0714	Activate regeneration service	Engine Management System (D20)
SP0715	Stop regeneration service	Engine Management System (D20)
SP0716	Exhaust gas recirculation (EGR) valve correction value self-learning	Engine Management System (D20)
SP0717	Low pressure exhaust gas recirculation (EGR) valve reset	Engine Management System (D20)
SP0718	Self-learning of correction value of throttle valve fully closed position	Engine Management System (D20)
SP0719	Steering wheel angle sensor calibration	Electronic Power Steering System (EPS)
SP0720	Write maintenance mileage	Instrument Control System (ICM)
SP0721	Perform maintenance cycle display (SIA) maintenance light reset	Instrument Control System (ICM)
SP0722	Steering wheel angle sensor calibration	Electric power steering-Bosch
SP0723	Steering wheel angle sensor calibration	Electric power steering-donghua
SP0724	Maintenance interval mileage	Combination Instrument-Wichill
SP0725	Perform maintenance cycle display (SIA) maintenance light reset	Combination Instrument-Wichill
SP0726	Maintenance interval mileage	Combination Instrument-Visteon
SP0727	Perform maintenance cycle display (SIA) maintenance light reset	Combination Instrument-Visteon
SP0728	Speed limit write	Engine System (EMS)
SP0729	Vehicle speed sensor source selection write	Engine System (EMS)
SP0730	Throttle replacement	Engine System (EMS)
SP0731	Diesel Particulate Filter (DPF) Differential Pressure Sensor	Engine System (EMS)
SP0732	Injector replacement	Engine System (EMS)
SP0733	Write fuel injection correction (IQA) code	Engine System (EMS)
SP0734	Fuel quality correction reset (replace injector)	Engine System (EMS)
SP0735	After-treatment catalyst NH3 load reset	Engine System (EMS)
SP0736	Diesel particulate filter related value reset	Engine System (EMS)
SP0737	Reset regeneration lock and increase soot quality	Engine System (EMS)
SP0738	Cancel regeneration lock	Engine System (EMS)
SP0739	Activate regeneration service	Engine System (EMS)
SP0740	Stop regeneration service	Engine System (EMS)
SP0741	Exhaust gas recirculation (EGR) valve correction value self-learning	Engine System (EMS)
SP0742	Low pressure exhaust gas recirculation (EGR) valve reset	Engine System (EMS)
SP0743	Self-learning of correction value of throttle valve fully closed position	Engine System (EMS)
SP0744	Write mileage value	Instrument Control System (ICM)
SP0745	Perform maintenance cycle display (SIA) maintenance light reset	Instrument Control System (ICM)
SP0746	Speed limit write	Engine System (EMS)
SP0747	Vehicle speed sensor source selection write	Engine System (EMS)
SP0748	Throttle replacement	Engine System (EMS)
SP0749	Diesel Particulate Filter (DPF) Differential Pressure Sensor	Engine System (EMS)
SP0750	Injector replacement	Engine System (EMS)
SP0751	Write fuel injection correction (IQA) code	Engine System (EMS)
SP0752	Fuel quality correction reset (replace injector)	Engine System (EMS)
SP0753	After-treatment catalyst NH3 load reset	Engine System (EMS)
SP0754	Diesel particulate filter related value reset	Engine System (EMS)
SP0755	Reset regeneration lock and increase soot quality	Engine System (EMS)
SP0756	Cancel regeneration lock	Engine System (EMS)
SP0757	Activate regeneration service	Engine System (EMS)
SP0758	Stop regeneration service	Engine System (EMS)
SP0759	Exhaust gas recirculation (EGR) valve correction value self-learning	Engine System (EMS)
SP0760	Low pressure exhaust gas recirculation (EGR) valve reset	Engine System (EMS)
SP0761	Self-learning of correction value of throttle valve fully closed position	Engine System (EMS)

SP0762	Write airbag ECU configuration	Airbag System (SRS)
SP0763	Write client mode	Airbag System (SRS)
SP0764	Maintenance interval mileage	Instrument Control System (ICM)
SP0765	Perform maintenance cycle display (SIA) maintenance light reset	Instrument Control System (ICM)
SP0766	Steering wheel angle sensor calibration	Electric power steering-Bosch
SP0767	Steering wheel angle sensor calibration	Electric power steering-donghua
SP0768	Maintenance interval mileage	Combination Instrument-Wichill
SP0769	Perform maintenance cycle display (SIA) maintenance light reset	Combination Instrument-Wichill
SP0770	Maintenance interval mileage	Combination Instrument-Visteon
SP0771	Perform maintenance cycle display (SIA) maintenance light reset	Combination Instrument-Visteon
SP0772	Speed limit write	Engine System (EMS)
SP0773	Vehicle speed sensor source selection write	Engine System (EMS)
SP0774	Throttle replacement	Engine System (EMS)
SP0775	Diesel Particulate Filter (DPF) Differential Pressure Sensor	Engine System (EMS)
SP0776	Injector replacement	Engine System (EMS)
SP0777	Write fuel injection correction (IQA) code	Engine System (EMS)
SP0778	Fuel quality correction reset (replace injector)	Engine System (EMS)
SP0779	After-treatment catalyst NH3 load reset	Engine System (EMS)
SP0780	Diesel particulate filter related value reset	Engine System (EMS)
SP0781	Reset regeneration lock and increase soot quality	Engine System (EMS)
SP0782	Cancel regeneration lock	Engine System (EMS)
SP0783	Activate regeneration service	Engine System (EMS)
SP0784	Stop regeneration service	Engine System (EMS)
SP0785	Exhaust gas recirculation (EGR) valve correction value self-learning	Engine System (EMS)
SP0786	Low pressure exhaust gas recirculation (EGR) valve reset	Engine System (EMS)
SP0787	Self-learning of correction value of throttle valve fully closed position	Engine System (EMS)
SP0788	Write airbag ECU configuration	Airbag System (SRS)
SP0789	Write client mode	Airbag System (SRS)
SP0790	Maintenance interval mileage	Instrument Control System
SP0791	Perform maintenance cycle display (SIA) maintenance light reset	Instrument Control System
SP0792	Maintenance interval mileage	Instrument control system-high configuration
SP0793	Perform maintenance cycle display (SIA) maintenance light reset	Instrument control system-high configuration
SP0794	Write vehicle identification number (VIN)	Vehicle management system
SP0795	Write vehicle characteristic information	Vehicle management system
SP0796	Write the part number of the electronic control unit	Vehicle management system
SP0797	Write vehicle configuration	Vehicle management system
SP0798	Write vehicle identification number (VIN)	Vehicle Management System (2018)
SP0799	Write vehicle characteristic information	Vehicle Management System (2018)
SP0800	Write vehicle configuration	Vehicle Management System (2018)
SP0801	Write vehicle identification number (VIN)	Power Control Unit System (PCU)
SP0802	Write vehicle characteristic information	Power Control Unit System (PCU)
SP0803	Write vehicle identification number (VIN)	Battery Management System
SP0804	Write vehicle characteristic information	Battery Management System
SP0805	Battery Type	Battery Management System
SP0806	Write vehicle identification number (VIN)	Battery management system (autonomous)
SP0807	Write vehicle characteristic information	Battery management system (autonomous)
SP0808	Battery energy storage system code	Battery management system (autonomous)
SP0809	Raising status	Anti-lock brake system (ABS)
SP0810	Offline detection status	Anti-lock brake system (ABS)
SP0811	Variable data (long axis and short axis)	Anti-lock brake system (ABS)
SP0812	Maintenance exhaust	Anti-lock brake system (ABS)
SP0813	Write vehicle identification number (VIN)	Airbag System (SRS)
SP0814	Write vehicle characteristic information	Airbag System (SRS)
SP0815	Write client model	Airbag System (SRS)
SP0816	Write airbag ECU configuration	Airbag System (SRS)
SP0817	Body side door configuration	Body control module
SP0818	Defrost heating configuration	Body control module
SP0819	Front fog lamp configuration	Body control module
SP0820	Remote control key function configuration	Body control module
SP0821	IMMO function configuration	Body control module
SP0822	Body controller status	Body control module
SP0823	Emergency lights (school bus)	Body control module
SP0824	Daytime running lights configuration (export)	Body control module
SP0825	Tailgate open alarm configuration (school bus)	Body control module

SP0826	Number of matching remote control keys (school bus)	Body control module
SP0827	Rear ceiling reading light configuration	Body control module
SP0828	Tailgate configuration	Body control module
SP0829	Number of buttons on the remote control key	Body control module
SP0830	Enable sliding door open warning configuration	Body control module
SP0831	Enable the vehicle to automatically release the lock configuration	Body control module
SP0832	Rear fog lamp configuration	Body control module
SP0833	Write vehicle identification number (VIN)	Body Control Module (2018)
SP0834	Write vehicle characteristic information	Body Control Module (2018)
SP0835	BCM allows the number of authentication failures	Body Control Module (2018)
SP0836	Maximum time to wait for TBOX response	Body Control Module (2018)
SP0837	Brake pad calibration threshold setting	Body Control Module (2018)
SP0838	Write fatigue driving detection calibration configuration	Body Control Module (2018)
SP0839	Write wiper configuration information	Body Control Module (2018)
SP0840	Write auxiliary configuration	Body Control Module (2018)
SP0841	Write other independent configurations	Body Control Module (2018)
SP0842	Write TBOX calibration configuration	Body Control Module (2018)
SP0843	Write light configuration information	Body Control Module (2018)
SP0844	Write personalized factory settings	Body Control Module (2018)
SP0845	Write BCM configuration information	Body Control Module (2018)
SP0846	Write vehicle identification number (VIN)	Electro-hydraulic power steering system (EHPS)
SP0847	Write vehicle characteristic information	Electro-hydraulic power steering system (EHPS)
SP0848	Write vehicle identification number (VIN)	Instrument system
SP0849	Write vehicle characteristic information	Instrument system
SP0850	Write IPK configuration	Instrument system
SP0851	Write the initial offset value of the rotary encoder	Instrument system
SP0852	Write vehicle identification number (VIN)	Instrumentation System (2018)
SP0853	Write vehicle characteristic information	Instrumentation System (2018)
SP0854	IPK configuration	Instrumentation System (2018)
SP0855	Speeding alarm	Instrumentation System (2018)
SP0856	Write VIN code	Air Conditioning System (AC)
SP0857	Write vehicle characteristic information	Air Conditioning System (AC)
SP0858	Write left front tire status	Tire pressure monitoring system
SP0859	Write right front tire status	Tire pressure monitoring system
SP0860	Write right rear tire status	Tire pressure monitoring system
SP0861	Write left rear tire status	Tire pressure monitoring system
SP0862	Left front tire pressure value	Tire pressure monitoring system
SP0863	Right front tire pressure value	Tire pressure monitoring system
SP0864	Right rear tire pressure value	Tire pressure monitoring system
SP0865	Tire pressure value of left rear tire	Tire pressure monitoring system
SP0866	Left front tire temperature value	Tire pressure monitoring system
SP0867	Right front tire temperature value	Tire pressure monitoring system
SP0868	Right rear tire temperature value	Tire pressure monitoring system
SP0869	Left rear tire temperature value	Tire pressure monitoring system
SP0870	Left front tire matching status	Tire pressure monitoring system
SP0871	Right front tire matching status	Tire pressure monitoring system
SP0872	Right rear tire matching status	Tire pressure monitoring system
SP0873	Left rear tire matching status	Tire pressure monitoring system
SP0874	Left front tire sensor ID	Tire pressure monitoring system
SP0875	Right front tire sensor ID	Tire pressure monitoring system
SP0876	Right rear tire sensor ID	Tire pressure monitoring system
SP0877	Rear left tire sensor ID	Tire pressure monitoring system
SP0878	Write vehicle identification number (VIN)	Tire pressure monitoring system
SP0879	Write vehicle characteristic information	Tire pressure monitoring system
SP0880	Write left front tire status	Tire Pressure Monitoring System (2018)
SP0881	Write right front tire status	Tire Pressure Monitoring System (2018)
SP0882	Write right rear tire status	Tire Pressure Monitoring System (2018)
SP0883	Write left rear tire status	Tire Pressure Monitoring System (2018)
SP0884	Left front tire pressure value	Tire Pressure Monitoring System (2018)
SP0885	Right front tire pressure value	Tire Pressure Monitoring System (2018)
SP0886	Right rear tire pressure value	Tire Pressure Monitoring System (2018)
SP0887	Tire pressure value of left rear tire	Tire Pressure Monitoring System (2018)
SP0888	Left front tire temperature value	Tire Pressure Monitoring System (2018)
SP0889	Right front tire temperature value	Tire Pressure Monitoring System (2018)

SP0890	Right rear tire temperature value	Tire Pressure Monitoring System (2018)
SP0891	Left rear tire temperature value	Tire Pressure Monitoring System (2018)
SP0892	Left front tire matching status	Tire Pressure Monitoring System (2018)
SP0893	Right front tire matching status	Tire Pressure Monitoring System (2018)
SP0894	Right rear tire matching status	Tire Pressure Monitoring System (2018)
SP0895	Left rear tire matching status	Tire Pressure Monitoring System (2018)
SP0896	Left front tire sensor ID	Tire Pressure Monitoring System (2018)
SP0897	Right front tire sensor ID	Tire Pressure Monitoring System (2018)
SP0898	Right rear tire sensor ID	Tire Pressure Monitoring System (2018)
SP0899	Rear left tire sensor ID	Tire Pressure Monitoring System (2018)
SP0900	Write vehicle identification number (VIN)	Tire Pressure Monitoring System (2018)
SP0901	Write vehicle characteristic information	Tire Pressure Monitoring System (2018)
SP0902	EPB initialization calibration	Electronic parking brake system
SP0903	Write vehicle identification number (VIN)	Electronic parking brake system
SP0904	Write vehicle characteristic information	Electronic parking brake system
SP0905	Write system configuration	Electronic parking brake system
SP0906	Write vehicle mode configuration	Electronic parking brake system
SP0907	Write vehicle identification number (VIN)	Electronic parking system
SP0908	Write vehicle characteristic information	Electronic parking system
SP0909	Write vehicle identification number (VIN)	Gateway Control System (GW)
SP0910	Write vehicle characteristic information	Gateway Control System (GW)
SP0911	Write fault code settings	Gateway Control System (GW)
SP0912	Write vehicle identification number (VIN)	Charger Communication Control Module System (EVCC)
SP0913	Write vehicle characteristic information	Charger Communication Control Module System (EVCC)
SP0914	Write vehicle identification number (VIN)	Front Infotainment Control System (FICM)
SP0915	Write vehicle characteristic information	Front Infotainment Control System (FICM)
SP0916	Vehicle configuration 1 (air conditioning/seat/tire pressure)	Front Infotainment Control System (FICM)
SP0917	Vehicle configuration 2 (lane departure/automatic braking/blind spot monitoring/forward collision/360° panoramic type/vehicle display)	Front Infotainment Control System (FICM)
SP0918	Write side air curtain setting	Front Infotainment Control System (FICM)
SP0919	Vehicle configuration 3 (power windows/navigation/hands-free)	Front Infotainment Control System (FICM)
SP0920	Vehicle configuration 4 (entertainment display/digital broadcasting/parking assist/rear view camera/360° panoramic display)	Front Infotainment Control System (FICM)
SP0921	Vehicle configuration 5 (steering wheel/audio/AUX port/video input)	Front Infotainment Control System (FICM)
SP0922	Vehicle configuration 6 (USB port/radio frequency)	Front Infotainment Control System (FICM)
SP0923	Vehicle configuration 7 (IPOD/model year/model series)	Front Infotainment Control System (FICM)
SP0924	Vehicle configuration 8 (brand/country/driving direction/engine type)	Front Infotainment Control System (FICM)
SP0925	Vehicle configuration 9 (gearbox/tailgate/pedestrian warning)	Front Infotainment Control System (FICM)
SP0926	Vehicle configuration A (vehicle speed alarm/emergency call/sunroof/hybrid)	Front Infotainment Control System (FICM)
SP0927	Vehicle configuration B (main driving economy mode/light sensor)	Front Infotainment Control System (FICM)
SP0928	Vehicle configuration C (air purification system/model configuration/GPS chip)	Front Infotainment Control System (FICM)
SP0929	Vehicle configuration D (voice recognition/ESP/ABS node/steering angle sensor/PEPS configuration)	Front Infotainment Control System (FICM)
SP0930	Vehicle configuration E (WIFI/chassis height/drive type/speed limit)	Front Infotainment Control System (FICM)
SP0931	Vehicle configuration 20 (Internet of Vehicles/Welcome Light and Ambient Light/Seat Memory)	Front Infotainment Control System (FICM)
SP0932	Wheelbase type	Lane Change Alert Controller System (LCA)
SP0933	Write vehicle identification number (VIN)	Lane Change Alert Controller System (LCA)
SP0934	Write vehicle characteristic information	Lane Change Alert Controller System (LCA)
SP0935	Write vehicle identification number (VIN)	Voltage stabilization module system (DCDC)
SP0936	Write vehicle characteristic information	Voltage stabilization module system (DCDC)
SP0937	Write vehicle identification number (VIN)	Telematics control terminal system (TBOX)
SP0938	Write vehicle characteristic information	Telematics control terminal system (TBOX)
SP0939	Motor type configuration	Telematics control terminal system (TBOX)
SP0940	Write vehicle identification number (VIN)	Vehicle Controller System (VMS)
SP0941	Write vehicle characteristic information	Vehicle Controller System (VMS)
SP0942	Write the part number of the electronic control unit	Vehicle Controller System (VMS)
SP0943	Write vehicle identification number (VIN)	Motor Controller System (MCU)
SP0944	Write vehicle characteristic information	Motor Controller System (MCU)
SP0945	Write vehicle identification number (VIN)	Battery Management System (BMS)
SP0946	Write vehicle characteristic information	Battery Management System (BMS)
SP0947	Calibration of external yaw rate sensor	Electronic Stability System (ABS/ESP)
SP0948	Maintenance exhaust	Electronic Stability System (ABS/ESP)
SP0949	Write vehicle identification number (VIN)	Electronic Stability System (ABS/ESP)
SP0950	Write vehicle characteristic information	Electronic Stability System (ABS/ESP)
SP0951	Write down the line status	Electronic Stability System (ABS/ESP)
SP0952	Write annotated status	Electronic Stability System (ABS/ESP)

SP0953	Write vehicle identification number (VIN)	Airbag System (SRS)
SP0954	Write vehicle characteristic information	Airbag System (SRS)
SP0955	Write the part number of the electronic control unit	Airbag System (SRS)
SP0956	Write airbag ECU configuration	Airbag System (SRS)
SP0957	Write CAN node configuration	Airbag System (SRS)
SP0958	Write vehicle identification number (VIN)	Body Control System (BCM)
SP0959	Write vehicle characteristic information	Body Control System (BCM)
SP0960	Write wiper configuration information	Body Control System (BCM)
SP0961	Write auxiliary configuration	Body Control System (BCM)
SP0962	Write other independent configurations	Body Control System (BCM)
SP0963	Write light configuration information	Body Control System (BCM)
SP0964	Write BCM configuration information	Body Control System (BCM)
SP0965	Write vehicle identification number (VIN)	Electro-hydraulic power steering system (EHPS)
SP0966	Write vehicle characteristic information	Electro-hydraulic power steering system (EHPS)
SP0967	Manual maintenance lamp reset	Instrument Control System (IPK)
SP0968	Perform SIA (maintenance light) reset	Instrument Control System (IPK)
SP0969	Maintenance mileage interval	Instrument Control System (IPK)
SP0970	Write vehicle identification number (VIN)	Instrument Control System (IPK)
SP0971	Write vehicle characteristic information	Instrument Control System (IPK)
SP0972	Write the part number of the electronic control unit	Instrument Control System (IPK)
SP0973	AFS warning light configuration	Instrument Control System (IPK)
SP0974	Front fog lamp warning configuration	Instrument Control System (IPK)
SP0975	Cruise warning light configuration	Instrument Control System (IPK)
SP0976	ESP warning light configuration	Instrument Control System (IPK)
SP0977	ESP OFF warning light configuration	Instrument Control System (IPK)
SP0978	TPMS warning light configuration	Instrument Control System (IPK)
SP0979	LCD gear display configuration	Instrument Control System (IPK)
SP0980	LCD RLS display configuration	Instrument Control System (IPK)
SP0981	Write common configuration	Instrument Control System (IPK)
SP0982	Driver's steering wheel position setting	Instrument Control System (IPK)
SP0983	PEPS configuration	Instrument Control System (IPK)
SP0984	Overspeed alarm function configuration-user adjustable	Instrument Control System (IPK)
SP0985	SRS airbag warning light configuration	Instrument Control System (IPK)
SP0986	LCA configuration	Instrument Control System (IPK)
SP0987	ECO lamp configuration	Instrument Control System (IPK)
SP0988	Write vehicle identification number (VIN)	Keyless Entry System (PEPS)
SP0989	Write vehicle characteristic information	Keyless Entry System (PEPS)
SP0990	Programming date	Keyless Entry System (PEPS)
SP0991	Write the installation date of the electronic control unit	Keyless Entry System (PEPS)
SP0992	Write the date of manufacture of the electronic control unit	Keyless Entry System (PEPS)
SP0993	Write the serial number of the electronic control unit	Keyless Entry System (PEPS)
SP0994	Maximum number of matching keys supported	Keyless Entry System (PEPS)
SP0995	Engine crank timeout value	Keyless Entry System (PEPS)
SP0996	Electronic control unit configuration	Keyless Entry System (PEPS)
SP0997	System supplier's electronic control unit hardware number	Keyless Entry System (PEPS)
SP0998	System supplier's electronic control unit hardware version number	Keyless Entry System (PEPS)
SP0999	Write VIN code	Air Conditioning System (AC)
SP1000	Write vehicle characteristic information	Air Conditioning System (AC)
SP1001	Write the part number of the electronic control unit	Air Conditioning System (AC)
SP1002	Write left front tire status	Tire Pressure Control System (TPMS)
SP1003	Write right front tire status	Tire Pressure Control System (TPMS)
SP1004	Write right rear tire status	Tire Pressure Control System (TPMS)
SP1005	Write left rear tire status	Tire Pressure Control System (TPMS)
SP1006	Left front tire pressure value	Tire Pressure Control System (TPMS)
SP1007	Right front tire pressure value	Tire Pressure Control System (TPMS)
SP1008	Right rear tire pressure value	Tire Pressure Control System (TPMS)
SP1009	Tire pressure value of left rear tire	Tire Pressure Control System (TPMS)
SP1010	Left front tire temperature value	Tire Pressure Control System (TPMS)
SP1011	Right front tire temperature value	Tire Pressure Control System (TPMS)
SP1012	Right rear tire temperature value	Tire Pressure Control System (TPMS)
SP1013	Left rear tire temperature value	Tire Pressure Control System (TPMS)
SP1014	Left front tire matching status	Tire Pressure Control System (TPMS)
SP1015	Right front tire matching status	Tire Pressure Control System (TPMS)
SP1016	Right rear tire matching status	Tire Pressure Control System (TPMS)

SP1017	Left rear tire matching status	Tire Pressure Control System (TPMS)
SP1018	Left front tire sensor ID	Tire Pressure Control System (TPMS)
SP1019	Right front tire sensor ID	Tire Pressure Control System (TPMS)
SP1020	Right rear tire sensor ID	Tire Pressure Control System (TPMS)
SP1021	Rear left tire sensor ID	Tire Pressure Control System (TPMS)
SP1022	Write vehicle identification number (VIN)	Tire Pressure Control System (TPMS)
SP1023	Write vehicle characteristic information	Tire Pressure Control System (TPMS)
SP1024	Write vehicle identification number (VIN)	Gateway Control System (GW)
SP1025	Write vehicle characteristic information	Gateway Control System (GW)
SP1026	Write the part number of the electronic control unit	Gateway Control System (GW)
SP1027	Write diagnostic CAN	Gateway Control System (GW)
SP1028	Horizontal calibration position	Headlight Control System (AFS)
SP1029	Write vehicle identification number (VIN)	Headlight Control System (AFS)
SP1030	Write vehicle characteristic information	Headlight Control System (AFS)
SP1031	Write calibration file type	Headlight Control System (AFS)
SP1032	Write vehicle identification number (VIN)	360 panoramic camera controller system (BVS)
SP1033	Write vehicle characteristic information	360 panoramic camera controller system (BVS)
SP1034	Write vehicle identification number (VIN)	Voltage stabilization module system (DCDC)
SP1035	Write vehicle characteristic information	Voltage stabilization module system (DCDC)
SP1036	Write vehicle identification number (VIN)	Lane Change Alert Controller System (LCA)
SP1037	Write vehicle characteristic information	Lane Change Alert Controller System (LCA)
SP1038	Write the part number of the electronic control unit	Lane Change Alert Controller System (LCA)
SP1039	Write vehicle identification number (VIN)	Electric tailgate controller system (PTG)
SP1040	Write vehicle characteristic information	Electric tailgate controller system (PTG)
SP1041	Write the part number of the electronic control unit	Electric tailgate controller system (PTG)
SP1042	Write vehicle identification number (VIN)	Telematics control terminal system (TBOX)
SP1043	Write vehicle characteristic information	Telematics control terminal system (TBOX)
SP1044	Motor type configuration	Telematics control terminal system (TBOX)
SP1045	Write vehicle identification number (VIN)	Vehicle Controller System (VMS)
SP1046	Write vehicle characteristic information	Vehicle Controller System (VMS)
SP1047	Write vehicle configuration	Vehicle Controller System (VMS)
SP1048	Hydrogen mode switch	Vehicle Controller System (VMS)
SP1049	Write vehicle identification number (VIN)	Motor Controller System (MCU)
SP1050	Write vehicle characteristic information	Motor Controller System (MCU)
SP1051	Write vehicle identification number (VIN)	Battery Management System (BMS)
SP1052	Write vehicle characteristic information	Battery Management System (BMS)
SP1053	Battery Type	Battery Management System (BMS)
SP1054	Raising status	Anti-lock brake system (ABS)
SP1055	Offline detection status	Anti-lock brake system (ABS)
SP1056	Variable data (long axis and short axis)	Anti-lock brake system (ABS)
SP1057	Maintenance exhaust	Anti-lock brake system (ABS)
SP1058	Write vehicle identification number (VIN)	Airbag System (SRS)
SP1059	Write vehicle characteristic information	Airbag System (SRS)
SP1060	Write client model	Airbag System (SRS)
SP1061	Write airbag ECU configuration	Airbag System (SRS)
SP1062	Write the last maintenance date	Airbag System (SRS)
SP1063	Write vehicle production date	Airbag System (SRS)
SP1064	Body side door configuration	Body Control System (BCM)
SP1065	Defrost heating configuration	Body Control System (BCM)
SP1066	Front fog lamp configuration	Body Control System (BCM)
SP1067	Remote control key function configuration	Body Control System (BCM)
SP1068	IMMO function configuration	Body Control System (BCM)
SP1069	Body controller status	Body Control System (BCM)
SP1070	Emergency lights (school bus)	Body Control System (BCM)
SP1071	Daytime running lights configuration (export)	Body Control System (BCM)
SP1072	Tailgate open alarm configuration (school bus)	Body Control System (BCM)
SP1073	Number of matching remote control keys (school bus)	Body Control System (BCM)
SP1074	Rear ceiling reading light configuration	Body Control System (BCM)
SP1075	Tailgate configuration	Body Control System (BCM)
SP1076	Number of buttons on the remote control key	Body Control System (BCM)
SP1077	Enable sliding door open warning configuration	Body Control System (BCM)
SP1078	Enable the vehicle to automatically release the lock configuration	Body Control System (BCM)
SP1079	Rear fog lamp configuration	Body Control System (BCM)
SP1080	Write vehicle identification number (VIN)	Electro-hydraulic power steering system (EHPS)

SP1081	Write vehicle characteristic information	Electro-hydraulic power steering system (EHPS)
SP1082	Write vehicle identification number (VIN)	Instrument Control System (IPK)
SP1083	Write vehicle characteristic information	Instrument Control System (IPK)
SP1084	Write IPK configuration	Instrument Control System (IPK)
SP1085	Write VIN code	Air Conditioning System (AC)
SP1086	Write vehicle characteristic information	Air Conditioning System (AC)
SP1087	Write left front tire status	Tire Pressure Control System (TPMS)
SP1088	Write right front tire status	Tire Pressure Control System (TPMS)
SP1089	Write right rear tire status	Tire Pressure Control System (TPMS)
SP1090	Write left rear tire status	Tire Pressure Control System (TPMS)
SP1091	Left front tire pressure value	Tire Pressure Control System (TPMS)
SP1092	Right front tire pressure value	Tire Pressure Control System (TPMS)
SP1093	Right rear tire pressure value	Tire Pressure Control System (TPMS)
SP1094	Tire pressure value of left rear tire	Tire Pressure Control System (TPMS)
SP1095	Left front tire temperature value	Tire Pressure Control System (TPMS)
SP1096	Right front tire temperature value	Tire Pressure Control System (TPMS)
SP1097	Right rear tire temperature value	Tire Pressure Control System (TPMS)
SP1098	Left rear tire temperature value	Tire Pressure Control System (TPMS)
SP1099	Left front tire matching status	Tire Pressure Control System (TPMS)
SP1100	Right front tire matching status	Tire Pressure Control System (TPMS)
SP1101	Right rear tire matching status	Tire Pressure Control System (TPMS)
SP1102	Left rear tire matching status	Tire Pressure Control System (TPMS)
SP1103	Left front tire sensor ID	Tire Pressure Control System (TPMS)
SP1104	Right front tire sensor ID	Tire Pressure Control System (TPMS)
SP1105	Right rear tire sensor ID	Tire Pressure Control System (TPMS)
SP1106	Rear left tire sensor ID	Tire Pressure Control System (TPMS)
SP1107	Write vehicle identification number (VIN)	Tire Pressure Control System (TPMS)
SP1108	Write vehicle characteristic information	Tire Pressure Control System (TPMS)
SP1109	EPB initialization calibration	Electronic parking brake system (EPB)
SP1110	Write vehicle identification number (VIN)	Electronic parking brake system (EPB)
SP1111	Write vehicle characteristic information	Electronic parking brake system (EPB)
SP1112	Write system configuration	Electronic parking brake system (EPB)
SP1113	Write vehicle mode configuration	Electronic parking brake system (EPB)
SP1114	Write vehicle identification number (VIN)	Fuel cell system (FCS)
SP1115	Write vehicle characteristic information	Fuel cell system (FCS)
SP1116	Write vehicle configuration	Fuel cell system (FCS)
SP1117	Write vehicle identification number (VIN)	Telematics control terminal system (TBOX)
SP1118	Write vehicle characteristic information	Telematics control terminal system (TBOX)
SP1119	Motor type configuration	Telematics control terminal system (TBOX)
SP1120	Allow periodic wake-up time (day)	Telematics control terminal system (TBOX)
SP1121	Enter sleep mode time (day)	Telematics control terminal system (TBOX)
SP1122	Allow periodic wake-up time (min)	Telematics control terminal system (TBOX)
SP1123	Cloud authentication	Telematics control terminal system (TBOX)
SP1124	Steering wheel angle sensor calibration	Electric power steering-Bosch
SP1125	Steering wheel angle sensor calibration	Electric power steering-donghua
SP1126	Maintenance interval mileage	Instrument Control System (ICM)
SP1127	Perform maintenance cycle display (SIA) maintenance light reset	Instrument Control System (ICM)
SP1128	Write service mileage	Instrument Control System (ICM)
SP1129	Perform maintenance cycle display (SIA) maintenance light reset	Instrument Control System (ICM)