



# Shenzhen Xtooltech Co., Ltd.

## Transporter Function List V18.70

**NOTES:**

√ This function is supported.

\* This function is new added.

Model	Model Series	Control Unit Groups	System Name	Read ECU Informati	Read Trouble Code	Clear Troubl e Code	Live Data	Actuation Test	Special Functions
V/Vito/Metris-Class	447	Body	EZS-Electronic ignition switch	√	√	√	√	×	×
V/Vito/Metris-Class	447	Information and communication	KI-dash board	√	√	√	×	×	×
V/Vito/Metris-Class	447	Information and communication	KOMO-Telematics module	√	√	√	√	×	×
V/Vito/Metris-Class	447	Information and communication	HERMES-Telematics module	√	√	√	×	×	×
V/Vito/Metris-Class	447	Information and communication	E-Call-RU-eCall, Russia (GLONASS)	√	√	√	×	×	×
V/Vito/Metris-Class	447	Seats and Doors	SIH/SIB-HL 2-Rear left row of second seat air conditioning seat	√	√	√	√	×	×
V/Vito/Metris-Class	447	Body	MRM-Steering column module	√	√	√	√	×	×
V/Vito/Metris-Class	447	Seats and Doors	SIH/SIB-HR 2-Rear row of second-row seat air-conditioned seats on the right	√	√	√	√	×	×
V/Vito/Metris-Class	447	Chassis	ESP-Electronic stability program	√	√	√	×	×	×
V/Vito/Metris-Class	447	Chassis	ESP-Electronic stability program	√	√	√	√	×	×
V/Vito/Metris-Class	447	Information and communication	NAV-Navigation System	√	√	√	√	×	×
V/Vito/Metris-Class	447	Information and communication	TPAD-Touch pad	√	√	√	√	×	×
V/Vito/Metris-Class	447	Information and communication	TPAD-Touchpad	√	√	√	√	×	×

V/Vito/Metris-Class	447	Information and communication	RD-Radio (Audio / Cab Management and Data Systems)	√	√	√	√	×	×
V/Vito/Metris-Class	447	Information and communication	Audio-Audio or COMAND	√	√	√	√	×	×
V/Vito/Metris-Class	447	Information and communication	A26/17 - MBUX multimedia system (host, code: E2Y, E2Z) (HU6)	√	√	√	×	×	×
V/Vito/Metris-Class	447	Information and communication	ZBE-Audio / Cab Management and Data System (COMAND) operating unit	√	√	√	×	×	×
V/Vito/Metris-Class	447	Information and communication	ZAN-Audio/COMAND display	√	√	√	√	×	×
V/Vito/Metris-Class	447	Information and communication	ZAN-Audio / Cab Management and Data System (COMAND) display	√	√	√	√	×	×
V/Vito/Metris-Class	447	Information and communication	UHI-Cellular telephone (fixed installation or portable) (D2B)	√	√	√	√	×	×
V/Vito/Metris-Class	447	Information and communication	KI-dash board	√	√	√	√	×	×
V/Vito/Metris-Class	447	Chassis	RDK-Tire pressure monitor	√	√	√	√	×	×
V/Vito/Metris-Class	447	Body	EDW-Burglar alarm system	√	√	√	√	×	×
V/Vito/Metris-Class	447	Driver assistance system	RFK-Backup camera	√	√	√	√	×	×
V/Vito/Metris-Class	447	Information and communication	RFK-Reversing camera	√	√	√	√	×	×
V/Vito/Metris-Class	447	Information and communication	CAMERA-Control unit '360 ?camera'	√	√	√	√	×	×
V/Vito/Metris-Class	447	Body	SRS-Supplemental restraint system	√	√	√	√	×	×
V/Vito/Metris-Class	447	Body	SRS-Supplemental restraint system	√	√	√	×	×	×
V/Vito/Metris-Class	447	Body	SOGESTAR2-Sound generator for electric vehicle	√	√	√	×	×	×
V/Vito/Metris-Class	447	Information and communication	RD-radio	√	√	√	×	×	×
V/Vito/Metris-Class	447	Information and communication	Audio-Audio or COMAND	√	√	√	×	×	×
V/Vito/Metris-Class	447	Information and communication	SG-AWF-Control unit 'crash-aid system'	√	√	√	√	×	×
V/Vito/Metris-Class	447	Driver assistance system	SG AWF-COLLISION PREVENTION ASSIST	√	√	√	×	×	×

V/Vito/Metris-Class	447	Body	DC Charging Connection Unit (DCCU)	√	√	√	√	×	×
V/Vito/Metris-Class	447	Drive	SG EM-Power electronics	√	√	√	√	×	×
V/Vito/Metris-Class	447	Body	SG LG-Charger	√	√	√	√	×	×
V/Vito/Metris-Class	447	Body	SG LG-Charger	√	√	√	×	×	×
V/Vito/Metris-Class	447	Body	DC/DC-DC/DC converter	√	√	√	√	×	×
V/Vito/Metris-Class	447	Body	SG BMS-Battery management system control unit	√	√	√	×	×	×
V/Vito/Metris-Class	447	Information and communication	IRS-HRA-Right rear external intelligent radar range sensor	√	√	√	√	×	×
V/Vito/Metris-Class	447	Driver assistance system	AB-Airbag	√	√	√	×	×	×
V/Vito/Metris-Class	447	Body	MF-HL-Rear row of the first row of seats on the left massage function control	√	√	√	√	×	×
V/Vito/Metris-Class	447	Information and communication	IRS-HLA-Left rear external smart radar range sensor	√	√	√	√	×	×
V/Vito/Metris-Class	447	Driver assistance system	ACS-Automatic clutch system	√	√	√	×	×	×
V/Vito/Metris-Class	447	Body	MF-HR-Rear row of massage function on the right side of the first row seat control	√	√	√	√	×	×
V/Vito/Metris-Class	447	Body	PSM-Parameterizable Special Module	√	√	√	×	×	×
V/Vito/Metris-Class	447	Chassis	ADS-Adaptive damping system(N51/5)	√	√	√	×	×	×
V/Vito/Metris-Class	447	Information and communication	MFK-Multi-function camera (monocular)	√	√	√	√	×	×
V/Vito/Metris-Class	447	Air conditioning	KLA-air conditioning	√	√	√	√	×	×
V/Vito/Metris-Class	447	Seats and Doors	S47/2 (driver's door switch module)	√	√	√	×	×	×
V/Vito/Metris-Class	447	Seats and Doors	S22 (driver's side door seat adjustment switch)	√	√	√	×	×	×
V/Vito/Metris-Class	447	Seats and Doors	Intelligent climate control switch group for driver's seat (S51/1)	√	√	√	×	×	×
V/Vito/Metris-Class	447	Seats and Doors	S47/3 (door switch module on front passenger side)	√	√	√	×	×	×

V/Vito/Meris-Class	447	Seats and Doors	S23 (door seat adjustment switch on front passenger side)	√	√	√	×	×	×
V/Vito/Meris-Class	447	Seats and Doors	S51/2 (Front passenger side door seat heater switch)	√	√	√	×	×	×
V/Vito/Meris-Class	447	Body	SOGESTAR2-Sound generator for electric vehicle	√	√	√	×	×	×
V/Vito/Meris-Class	447	Chassis	ES-Electric power steering	√	√	√	√	×	×
V/Vito/Meris-Class	447	Body	SD-'Panoramic sliding sunroof' control module	√	√	√	√	×	×
V/Vito/Meris-Class	447	Air conditioning	STH-Stationary heater	√	√	√	×	×	×
V/Vito/Meris-Class	447	Body	RevGUS-VL-Left front adaptive belt tensioner	√	√	√	√	×	×
V/Vito/Meris-Class	447	Body	RevGUS-VR-Right front adaptive seat belt tensioner	√	√	√	√	×	×
V/Vito/Meris-Class	447	Seats and Doors	ESE-Driver's seat adjustment	√	√	√	√	×	×
V/Vito/Meris-Class	447	Seats and Doors	ESE-'Front passenger' electric seat adjustment	√	√	√	√	×	×
V/Vito/Meris-Class	447	Body	N175/1 - Expansion Module 3 for Mercedes-Benz Advanced Controller (EM-1-MBAC)	√	√	√	×	×	×
V/Vito/Meris-Class	447	Drive	ISM-Intelligent servo module	√	√	√	√	×	×
V/Vito/Meris-Class	447	Body	AAG-Trailer identification device	√	√	√	√	×	×
V/Vito/Meris-Class	447	Body	SAM-Signal acquisition and actuation control module	√	√	√	×	×	×
V/Vito/Meris-Class	447	Body	DBE-Roof control panel	√	√	√	×	×	×
V/Vito/Meris-Class	447	Information and communication	DTR-Limit control system	√	√	√	×	×	×
V/Vito/Meris-Class	447	Seats and Doors	DCM-FL-Door control module front left	√	√	√	√	×	×
V/Vito/Meris-Class	447	Seats and Doors	DCM-FR-Door control module front right	√	√	√	√	×	×
V/Vito/Meris-Class	447	Information and communication	TV-TV tuner	√	√	√	√	×	×
V/Vito/Meris-Class	447	Information and communication	CDI60-Common Rail Diesel Injection(OM642 EPA13)	√	√	√	×	×	×

V/Vito/Metris-Class	447	Information and communication	SOUND-sound system	√	√	√	√	×	×
V/Vito/Metris-Class	447	Information and communication	SOUND-Sound system	√	√	√	√	×	×
V/Vito/Metris-Class	447	Seats and Doors	STL-Left electric sliding door	√	√	√	√	×	×
V/Vito/Metris-Class	447	Information and communication	DAB-Digital Audio Broadcasting	√	√	√	√	×	×
V/Vito/Metris-Class	447	Seats and Doors	STR-Right electric sliding door	√	√	√	√	×	×
V/Vito/Metris-Class	447	Body	SK-HR-Rear row of seats on the right side of the seat cushion control	√	√	√	×	×	×
V/Vito/Metris-Class	447	Chassis	EFB-Electric parking activator	√	√	√	√	×	×
V/Vito/Metris-Class	447	Driver assistance system	RFK-Backup camera	√	√	√	×	×	×
V/Vito/Metris-Class	447	Information and communication	RFK-Reversing camera	√	√	√	×	×	×
V/Vito/Metris-Class	447	Body	HMI-GW-Human Interface Gateway	√	√	√	√	×	×
V/Vito/Metris-Class	447	Body	SG-SW-L-Left headlight	√	√	√	√	×	×
V/Vito/Metris-Class	447	Body	SG-SW-R-Right headlight	√	√	√	×	×	×
V/Vito/Metris-Class	447	Body	SG BMS-Battery management system control unit	√	√	√	×	×	×
V/Vito/Metris-Class	447	Body	RGLS-Rain/light sensor	√	√	√	×	×	×
V/Vito/Metris-Class	447	Information and communication	PTS-Parktronic system	√	√	√	√	×	×
V/Vito/Metris-Class	447	Body	SG BMS-Battery management system control unit	√	√	√	×	×	×
V/Vito/Metris-Class	447	Information and communication	DTCO-Digital tachograph	√	√	√	×	×	×
V/Vito/Metris-Class	447	Information and communication	DTCO-Digital tachograph	√	√	√	×	×	×
V/Vito/Metris-Class	447	Information and communication	DTCO-Digital tachograph	√	√	√	×	×	×
V/Vito/Metris-Class	447	Body	SK-HL-Rear row of seats on the left air cushion control	√	√	√	×	×	×

V/Vito/Meris-Class	447	Body	N175/2 - Expansion Module 3 for Mercedes-Benz Advanced Controller (EM-2-MBAC)	√	√	√	×	×	×
V/Vito/Meris-Class	447	Seats and Doors	SIH/SIB-HL 1-Rear left row of first seat air conditioning seat	√	√	√	√	×	×
V/Vito/Meris-Class	447	Body	N175/3 - Expansion Module 3 for Mercedes-Benz Advanced Controller (EM-3-MBAC)	√	√	√	×	×	×
V/Vito/Meris-Class	447	Body	ATA-ATA[EDW]/tow-away protection/interior protection	√	√	√	×	×	×
V/Vito/Meris-Class	447	Body	ATA-ATA[EDW]/tow-away protection/interior protection	√	√	√	×	×	×
V/Vito/Meris-Class	447	Seats and Doors	SIH/SIB-HR 1-Rear row of seats on the right hand side seat air conditioning	√	√	√	√	×	×
V/Vito/Meris-Class	447	Information and communication	KAB-Control unit 'camera guard'	√	√	√	√	×	×
V/Vito/Meris-Class	447	Drive	CDI-Engine electronics 'CR41' for internal combustion engine 'OM651'	√	√	√	√	×	SP0000
V/Vito/Meris-Class	447	Drive	CDI-Engine electronics 'CR41R' for internal combustion engine 'OM622'	√	√	√	√	×	SP0001, SP0002, SP0003, SP0000
V/Vito/Meris-Class	447	Drive	CDI-Motor electronics	√	√	√	×	×	×
V/Vito/Meris-Class	447	Drive	ME-Engine electronics 'ME40' for internal combustion engine 'M274'	√	√	√	√	×	×
V/Vito/Meris-Class	447	Drive	CDI-Motor electronics	√	√	√	×	×	×
V/Vito/Meris-Class	447	Drive	CDI-Motor electronics	√	√	√	×	×	×
V/Vito/Meris-Class	447	Drive	VGS-Start clutch oil pressure sensor	√	√	√	√	×	×
V/Vito/Meris-Class	447	Drive	Transmission control	√	√	√	×	×	×
V/Vito/Meris-Class	447	Drive	Transmission control	√	√	√	×	×	×
V/Vito/Meris-Class	447	Drive	FSCU-Fuel system control unit	√	√	√	√	×	×
V/Vito/Meris-Class	447	Drive	FSCU01-Control unit Fuel pump	√	√	√	√	×	×
V/Vito/Meris-Class	447	Drive	SCR-Selective Catalytic Reduction	√	√	√	√	×	×
V/Vito/Meris-Class	447	Drive	SCR-Selective catalytic reduction	√	√	√	√	×	×

V/Vito/Meris-Class	447	Drive	SCR-Selective catalytic reduction	√	√	√	×	×	×
V/Vito/Meris-Class	447	Drive	N127 (Drivetrain control unit)	√	√	√	√	×	×
V/Vito/Meris-Class	447	Drive	N127 (Drivetrain control unit)	√	√	√	√	×	×
V/Vito/Meris-Class	447	Drive	N127 (Drivetrain control unit)	√	√	√	×	×	×
V/Vito/Meris-Class	447	Body	BMS-Battery management system	√	√	√	×	×	×
V/Vito/Meris-Class	447	Body	SG BMS-Battery management system control unit	√	√	√	×	×	×
V/Vito/Meris-Class	447	Body	SG BMS-Battery management system control unit	√	√	√	×	×	×
V/Vito/Meris-Class	447	Body	N175 - Expansion module 3 for Mercedes-Benz Advanced Controller (MBAC)	√	√	√	×	×	×
V/Vito/Meris-Class	447	Body	N26/25 - On-board logic unit (OLU)	√	√	√	×	×	×
V/Vito-Class	448	Body	EZS-Electronic ignition switch	√	√	√	√	×	×
V/Vito-Class	448	Drive	CDI-Engine electronics 'CR41' for internal combustion engine 'OM651'	√	√	√	√	×	SP0000
V/Vito-Class	448	Drive	CDI-Engine electronics 'CR41R' for internal combustion engine 'OM622'	√	√	√	√	×	SP0001, SP0002, SP0003, SP0000
V/Vito-Class	448	Drive	ME-Engine electronics 'ME40' for internal combustion engine 'M274'	√	√	√	√	×	×
V/Vito-Class	448	Drive	VGS-Start clutch oil pressure sensor	√	√	√	√	×	×
V/Vito-Class	448	Chassis	ESP-Electronic stability program	√	√	√	√	×	×
V/Vito-Class	448	Body	SRS-Supplemental restraint system	√	√	√	√	×	×
V/Vito-Class	448	Chassis	ES-Electric power steering	√	√	√	√	×	×
V/Vito-Class	448	Drive	ISM-Intelligent servo module	√	√	√	√	×	×
V/Vito-Class	448	Drive	FSCU-Fuel system control unit	√	√	√	√	×	×
V/Vito-Class	448	Drive	SCR-Selective Catalytic Reduction	√	√	√	√	×	×

V/Vito-Class	448	Chassis	RDK-Tire pressure monitor	√	√	√	√	×	×
V/Vito-Class	448	Body	SAM-Signal acquisition and actuation control module	√	√	√	×	×	×
V/Vito-Class	448	Body	SG-SW-L-Left headlight	√	√	√	√	×	×
V/Vito-Class	448	Body	SG-SW-R-Right headlight	√	√	√	×	×	×
V/Vito-Class	448	Body	PSM-Parameterizable Special Module	√	√	√	×	×	×
V/Vito-Class	448	Body	DBE-Roof control panel	√	√	√	×	×	×
V/Vito-Class	448	Body	RevGUS-VL-Left front adaptive belt tensioner	√	√	√	√	×	×
V/Vito-Class	448	Body	RevGUS-VR-Right front adaptive seat belt tensioner	√	√	√	√	×	×
V/Vito-Class	448	Body	MRM-Steering column module	√	√	√	√	×	×
V/Vito-Class	448	Body	EDW-Burglar alarm system	√	√	√	√	×	×
V/Vito-Class	448	Body	MF-HR-Rear row of massage function on the right side of the first row seat control	√	√	√	√	×	×
V/Vito-Class	448	Body	SK-HR-Rear row of seats on the right side of the seat cushion control	√	√	√	×	×	×
V/Vito-Class	448	Body	MF-HL-Rear row of the first row of seats on the left massage function control	√	√	√	√	×	×
V/Vito-Class	448	Body	SK-HL-Rear row of seats on the left air cushion control	√	√	√	×	×	×
V/Vito-Class	448	Body	SD-'Panoramic sliding sunroof' control module	√	√	√	√	×	×
V/Vito-Class	448	Information and communication	KOMO-Telematics module	√	√	√	√	×	×
V/Vito-Class	448	Information and communication	HERMES-Telematics module	√	√	√	×	×	×
V/Vito-Class	448	Information and communication	RD-radio	√	√	√	×	×	×
V/Vito-Class	448	Information and communication	KAB-Control unit 'camera guard'	√	√	√	√	×	×
V/Vito-Class	448	Information and communication	SG-AWF-Control unit 'crash-aid system'	√	√	√	√	×	×



V/Vito-Class	448	Information and communication	IRS-HRA-Right rear external intelligent radar range sensor	√	√	√	√	×	×
V/Vito-Class	448	Information and communication	IRS-HLA-Left rear external smart radar range sensor	√	√	√	√	×	×
V/Vito-Class	448	Information and communication	KI-dash board	√	√	√	×	×	×
V/Vito-Class	448	Information and communication	KI-dash board	√	√	√	√	×	×
V/Vito-Class	448	Information and communication	NAV-Navigation System	√	√	√	√	×	×
V/Vito-Class	448	Information and communication	PTS-Parktronic system	√	√	√	√	×	×
V/Vito-Class	448	Information and communication	RFK-Reversing camera	√	√	√	×	×	×
V/Vito-Class	448	Information and communication	MFK-Multi-function camera (monocular)	√	√	√	√	×	×
V/Vito-Class	448	Seats and Doors	DCM-FL-Door control module front left	√	√	√	√	×	×
V/Vito-Class	448	Seats and Doors	DCM-FR-Door control module front right	√	√	√	√	×	×
V/Vito-Class	448	Seats and Doors	STL-Left electric sliding door	√	√	√	√	×	×
V/Vito-Class	448	Seats and Doors	STR-Right electric sliding door	√	√	√	√	×	×
V/Vito-Class	448	Seats and Doors	ESE-Driver's seat adjustment	√	√	√	√	×	×
V/Vito-Class	448	Seats and Doors	ESE-'Front passenger' electric seat adjustment	√	√	√	√	×	×
V/Vito-Class	448	Seats and Doors	SIH/SIB-HL 1-Rear left row of first seat air conditioning seat	√	√	√	√	×	×
V/Vito-Class	448	Seats and Doors	SIH/SIB-HR 1-Rear row of seats on the right hand side seat air conditioning	√	√	√	√	×	×
V/Vito-Class	448	Air conditioning	KLA-air conditioning	√	√	√	√	×	×
V/Vito-Class	448	Chassis	EFB-Electric parking activator	√	√	√	√	×	×
V/Vito-Class	448	Body	HMI-GW-Human Interface Gateway	√	√	√	√	×	×
V/Vito-Class	448	Information and communication	ZBE-Audio / Cab Management and Data System (COMAND) operating unit	√	√	√	×	×	×

V/Vito-Class	448	Information and communication	ZAN-Audio / Cab Management and Data System (COMAND) display	√	√	√	√	×	×
V/Vito-Class	448	Information and communication	DTR-Limit control system	√	√	√	×	×	×
V/Vito-Class	448	Information and communication	RD-Radio (Audio / Cab Management and Data Systems)	√	√	√	√	×	×
V/Vito-Class	448	Information and communication	CAMERA-Control unit '360 ?camera'	√	√	√	√	×	×
V/Vito-Class	448	Information and communication	RFK-Reversing camera	√	√	√	√	×	×
V/Vito-Class	448	Information and communication	SOUND-sound system	√	√	√	√	×	×
V/Vito-Class	448	Information and communication	DAB-Digital Audio Broadcasting	√	√	√	√	×	×
V/Vito-Class	448	Information and communication	TV-TV tuner	√	√	√	√	×	×
V/Vito-Class	448	Information and communication	TPAD-Touch pad	√	√	√	√	×	×
Citan-Class	415	Air conditioning	KLA-air conditioning	√	√	√	×	×	×
Citan-Class	415	Chassis	ESP-Electronic stability program	√	√	√	√	×	×
Citan-Class	415	Chassis	ES-Electric power steering	√	√	√	√	×	×
Citan-Class	415	Information and communication	KI-dash board	√	√	√	×	×	×
Citan-Class	415	Air conditioning	KLA-air conditioning	√	√	√	√	×	×
Citan-Class	415	Body	SAM-Signal acquisition and actuation control module	√	√	√	√	×	×
Citan-Class	415	Body	SRM-Fuses and relay modules	√	√	√	√	×	×
Citan-Class	415	Information and communication	PTS-Parktronic system	√	√	√	√	×	×
Citan-Class	415	Body	SRS-Supplemental restraint system	√	√	√	√	×	×

Citan-Class	415	Chassis	RDK-Tire pressure monitor	√	√	√	√	×	×
Citan-Class	415	Drive	CDI Engine Electronics 'Common Rail Injection System' (CDI)	√	√	√	√	×	×
Citan-Class	415	Drive	CDI Engine Electronics 'Common Rail Injection System' (CDI)	√	√	√	√	×	×
Citan-Class	415	Drive	ME - Engine Electronic Equipment 'ME (Engine Electronic Equipment)' (ME	√	√	√	√	×	×
Citan-Class	415	Drive	ME - Engine Electronic Equipment 'ME (Engine Electronic Equipment)' (ME	√	√	√	√	×	×
Citan-Class	415	Drive	CDI-Motor electronics	√	√	√	×	×	×
Citan-Class	415	Drive	CDI Engine Electronics 'Common Rail Injection System' (CDI)	√	√	√	√	×	×
Citan-Class	415	Drive	CDI Engine Electronics 'Common Rail Injection System' (CDI)	√	√	√	√	×	×
Citan-Class	415	Drive	DKG-Dual clutch gearbox	√	√	√	√	×	×
Citan-Class	415	Drive	SCR-Selective catalytic reduction	√	√	√	×	×	×
Sprinter III-Class	9061	Information and communication	E-Call-RU-eCall, Russia (GLONASS)	√	√	√	×	×	×
Sprinter III-Class	9061	Body	EZS-Electronic ignition switch	√	√	√	×	×	×
Sprinter III-Class	9061	Body	EZS-Electronic ignition switch	√	√	√	×	×	×
Sprinter III-Class	9061	Information and communication	AUDIO/APS-Auto pilot system	√	√	√	×	×	×
Sprinter III-Class	9061	Air conditioning	KLA-air conditioning	√	√	√	×	×	×
Sprinter III-Class	9061	Information and communication	NAV-Navigation System	√	√	√	√	×	×
Sprinter III-Class	9061	Driver assistance system	SG AWF-COLLISION PREVENTION ASSIST	√	√	√	×	×	×
Sprinter III-Class	9061	Body	SAM-Signal acquisition and actuation module	√	√	√	×	×	×

Sprinter III-Class	9061	Body	DBE-Overhead control panel	√	√	√	×	×	×
Sprinter III-Class	9061	Driver assistance system	MFK-Multifunction camera (mono)	√	√	√	×	×	×
Sprinter III-Class	9061	Body	KE-Keyless Entry	√	√	√	×	×	×
Sprinter III-Class	9061	Body	OBF2-Upper control panel	√	√	√	×	×	×
Sprinter III-Class	9061	Chassis	RDK Tire pressure monitor (As of model year 2011)	√	√	√	×	×	×
Sprinter III-Class	9061	Body	SRS-supplemental restraint system	√	√	√	×	×	×
Sprinter III-Class	9061	Body	SRS-supplemental restraint system	√	√	√	×	×	×
Sprinter III-Class	9061	Seats and Doors	TSG-Door control module front driver side	√	√	√	×	×	×
Sprinter III-Class	9061	Drive	FSCU01-Control unit Fuel pump	√	√	√	×	×	×
Sprinter III-Class	9061	LIN Bus	PSM-Parameterizable Special Module	√	√	√	×	×	×
Sprinter III-Class	9061	Air conditioning	PTC-Heater booster	√	√	√	×	×	×
Sprinter III-Class	9061	Body	AAG-Trailer connection unit	√	√	√	×	×	×
Sprinter III-Class	9061	Body	AAG-Trailer identification device	√	√	√	×	×	×
Sprinter III-Class	9061	Air conditioning	ZHE-Auxiliary heater	√	√	√	×	×	×
Sprinter III-Class	9061	Air conditioning	ZHZ-Heater booster	√	√	√	×	×	×
Sprinter III-Class	9061	Chassis	ENR-Electronic rear axle level control	√	√	√	×	×	×
Sprinter III-Class	9061	Seats and Doors	STL-Left electric sliding door	√	√	√	×	×	×

Sprinter III-Class	9061	Seats and Doors	STR-Right electric sliding door	√	√	√	×	×	×
Sprinter III-Class	9061	Drive	IRS HRA-Outer right rear intelligent radar sensor system	√	√	√	×	×	×
Sprinter III-Class	9061	Air conditioning	KLA-air conditioning	√	√	√	×	×	×
Sprinter III-Class	9061	Drive	IRS HRA-Outer right rear intelligent radar sensor system	√	√	√	×	×	×
Sprinter III-Class	9061	Drive	IRS HRA-Outer right rear intelligent radar sensor system	√	√	√	×	×	×
Sprinter III-Class	9061	Drive	IRS HRA-Outer right rear intelligent radar sensor system	√	√	√	×	×	×
Sprinter III-Class	9061	Air conditioning	KLA-air conditioning	√	√	√	×	×	×
Sprinter III-Class	9061	Drive	FSCU01-Control unit Fuel pump	√	√	√	×	×	×
Sprinter III-Class	9061	Chassis	ESP-Electronic stability program	√	√	√	×	×	×
Sprinter III-Class	9061	Drive	ESM-Electronic selector module	√	√	√	×	×	×
Sprinter III-Class	9061	Information and	PTS-Parktronic system	√	√	√	×	×	×
Sprinter III-Class	9061	Air conditioning	KLA-Automatic air conditioning	√	√	√	×	×	×
Sprinter III-Class	9061	Body	MRM-Steering column module	√	√	√	×	×	×
Sprinter III-Class	9061	Body	ALWR-Headlamp range adjustment	√	√	√	×	×	×
Sprinter III-Class	9061	Information and	KI-Instrument cluster	√	√	√	×	×	×
Sprinter III-Class	9061	Information and	DTCO-Digital tachograph	√	√	√	×	×	×
Sprinter III-Class	9061	Information and	DTCO-Digital tachograph	√	√	√	×	×	×
Sprinter III-Class	9061	Information and	MTCO-Modular tachograph	√	√	√	×	×	×
Sprinter III-Class	9061	Drive	ME SFI-CNG compressed natural gas	√	√	√	×	×	×
Sprinter III-Class	9061	Air conditioning	KLA-air conditioning	√	√	√	×	×	×
Sprinter III-Class	9061	Drive	CDI-Motor electronics	√	√	√	√	×	×
Sprinter III-Class	9061	Drive	CDI-Motor electronics	√	√	√	×	×	×

Sprinter III-Class	9061	Drive	CDI-Motor electronics	√	√	√	×	×	×
Sprinter III-Class	9061	Drive	CDI-Motor electronics	√	√	√	√	×	×
Sprinter III-Class	9061	Drive	CDI-Motor electronics	√	√	√	×	×	×
Sprinter III-Class	9061	Drive	CDI-Motor electronics	√	√	√	×	×	×
Sprinter III-Class	9061	Drive	ME-Motor electronics	√	√	√	×	×	×
Sprinter III-Class	9061	Drive	CDI-Motor electronics	√	√	√	×	×	×
Sprinter III-Class	9061	Chassis	TPM-Tire pressure monitor	√	√	√	×	×	×
Sprinter III-Class	9061	Drive	ME SFI-Motor electronics	√	√	√	×	×	×
Sprinter III-Class	9061	Drive	EGS electronic transmission control	√	√	√	×	×	×
Sprinter III-Class	9061	Drive	Transmission control	√	√	√	√	×	×
Sprinter III-Class	9061	Drive	SCR-Selective Catalytic Reduction	√	√	√	×	×	×
Sprinter III-Class	9061	Drive	SCR-Selective Catalytic Reduction	√	√	√	√	×	×
Sprinter 907-Class	907	Body	EZS-Electronic ignition switch	√	√	√	√	×	×
Sprinter 907-Class	907	Seats and Doors	DCU RF-Right front door	√	√	√	√	×	×
Sprinter 907-Class	907	Seats and Doors	STL-Left electric sliding door	√	√	√	×	×	×
Sprinter 907-Class	907	Seats and Doors	STR-Right electric sliding door	√	√	√	×	×	×
Sprinter 907-Class	907	Seats and Doors	Name Bauteil - (KEP) (Code:T40, T41) (SDD907)	√	√	√	×	×	×
Sprinter 907-Class	907	Seats and Doors	DCU LF-Left front door	√	√	√	√	×	×
Sprinter 907-Class	907	Seats and Doors	ESE-Driver's seat adjustment	√	√	√	√	×	×
Sprinter 907-Class	907	Body	SAM-Signal acquisition and actuation module	√	√	√	√	×	×
Sprinter 907-Class	907	Information and communication	HERMES-Telematics module	√	√	√	×	×	×
Sprinter 907-Class	907	Seats and Doors	ESE-'Front passenger' electric seat adjustment	√	√	√	√	×	×
Sprinter 907-Class	907	Air conditioning	C AAC-Convenience automatic air conditioning/AAC-Automatic air conditioning/HEAT-Automatic heater	√	√	√	√	×	×

Sprinter 907-Class	907	Body	ATA-Interior motion sensor	√	√	√	×	×	×
Sprinter 907-Class	907	Body	AAG-Trailer identification device	√	√	√	×	×	×
Sprinter 907-Class	907	Body	Multifunction control unit-Multifunction control unit	√	√	√	×	×	×
Sprinter 907-Class	907	Driver assistance system	AB-Airbag	√	√	√	√	×	×
Sprinter 907-Class	907	Driver assistance system	ACS-Automatic clutch system	√	√	√	√	×	×
Sprinter 907-Class	907	Body	CL-Central locking control unit	√	√	√	√	×	×
Sprinter 907-Class	907	Body	UCP-Upper control panel	√	√	√	×	×	×
Sprinter 907-Class	907	Information and communication	A26/17 - MBUX multimedia system (host, 1 row - 100%) (CONCEPT)	√	√	√	×	×	×
Sprinter 907-Class	907	Information and communication	A26/17 - MBUX multimedia system (host, 1 row - 100%) (type)	√	√	√	×	×	×
Sprinter 907-Class	907	Information and communication	ZAN-Audio/COMAND display	√	√	√	√	×	×
Sprinter 907-Class	907	Information and communication	UHI-Cellular telephone (fixed installation or portable) (D2B)	√	√	√	×	×	×
Sprinter 907-Class	907	Information and communication	UHI-Cellular telephone (fixed installation or portable) (D2B)	√	√	√	√	×	×
Sprinter 907-Class	907	Information and communication	IC-Instrument cluster	√	√	√	×	×	×
Sprinter 907-Class	907	Driver assistance system	RFK-Backup camera	√	√	√	√	×	×
Sprinter 907-Class	907	Body	SRS-Supplemental restraint system	√	√	√	√	×	×
Sprinter 907-Class	907	Body	SOGESTAR2-Sound generator for electric vehicle	√	√	√	×	×	×
Sprinter 907-Class	907	Body	SG SW L-Left headlamp	√	√	√	×	×	×
Sprinter 907-Class	907	Chassis	TPM-Tire pressure monitor	√	√	√	√	×	×
Sprinter 907-Class	907	Driver assistance system	MFK-Multifunction camera (mono)	√	√	√	√	×	×
Sprinter 907-Class	907	Body	SG SW R-Right headlamp	√	√	√	×	×	×

Sprinter 907-Class	907	Body	DC Charging Connection Unit (DCCU)	√	√	√	√	×	×
Sprinter 907-Class	907	Drive	ISM-Shift module	√	√	√	√	×	×
Sprinter 907-Class	907	Drive	SG EM-Power electronics	√	√	√	√	×	×
Sprinter 907-Class	907	Body	SG LG-Charger	√	√	√	√	×	×
Sprinter 907-Class	907	Body	DC/DC-DC/DC converter	√	√	√	√	×	×
Sprinter 907-Class	907	Body	SG BMS-Battery management system control unit	√	√	√	×	×	×
Sprinter 907-Class	907	Body	BSN-Battery sensor	√	√	√	×	×	×
Sprinter 907-Class	907	Body	RGLS-Rain/light sensor	√	√	√	√	×	×
Sprinter 907-Class	907	Body	ATA-Anti-theft alarm system	√	√	√	×	×	×
Sprinter 907-Class	907	Seats and Doors	S47/2 (driver's door switch module)	√	√	√	×	×	×
Sprinter 907-Class	907	Seats and Doors	S22 (driver's side door seat adjustment switch)	√	√	√	×	×	×
Sprinter 907-Class	907	Seats and Doors	Intelligent climate control switch group for driver's seat (S51/1)	√	√	√	×	×	×
Sprinter 907-Class	907	Seats and Doors	S47/3 (door switch module on front passenger side)	√	√	√	×	×	×
Sprinter 907-Class	907	Seats and Doors	S23 (door seat adjustment switch on front passenger side)	√	√	√	×	×	×
Sprinter 907-Class	907	Seats and Doors	S51/2 (intelligent climate control switch group for front passenger seat)	√	√	√	×	×	×
Sprinter 907-Class	907	Body	AS-Alarm siren	√	√	√	√	×	×
Sprinter 907-Class	907	Body	ATA-ATA[EDW]/tow-away protection/interior protection	√	√	√	×	×	×
Sprinter 907-Class	907	Air conditioning	STH-Stationary heater	√	√	√	×	×	×



Sprinter 907-Class	907	Air conditioning	STH-Stationary heater	√	√	√	√	×	×
Sprinter 907-Class	907	Air conditioning	C AAC-Convenience automatic air conditioning/AAC-Automatic air conditioning/HEAT-Automatic heater	√	√	√	×	×	×
Sprinter 907-Class	907	Body	N175/1 - Expansion Module 3 for Mercedes-Benz Advanced Controller (EM-1-MBAC)	√	√	√	×	×	×
Sprinter 907-Class	907	Driver assistance system	SG AWF-COLLISION PREVENTION ASSIST	√	√	√	√	×	×
Sprinter 907-Class	907	Driver assistance system	PTS-PARKTRONIC	√	√	√	√	×	×
Sprinter 907-Class	907	Chassis	ES-Electric power steering	√	√	√	√	×	×
Sprinter 907-Class	907	Body	MRM-Steering column module	√	√	√	√	×	×
Sprinter 907-Class	907	Drive	VG-Transfer case	√	√	√	√	×	×
Sprinter 907-Class	907	Drive	VG-Transfer case	√	√	√	×	×	×
Sprinter 907-Class	907	Body	SG BMS-Battery management system control unit	√	√	√	×	×	×
Sprinter 907-Class	907	Body	SG BMS-Battery management system control unit	√	√	√	×	×	×
Sprinter 907-Class	907	Information and communication	DTCO-Digital tachograph	√	√	√	×	×	×
Sprinter 907-Class	907	Information and communication	DTCO-Digital tachograph	√	√	√	×	×	×
Sprinter 907-Class	907	Information and communication	MTCO-Modular tachograph	√	√	√	×	×	×
Sprinter 907-Class	907	Body	N175/2 - Expansion Module 3 for Mercedes-Benz Advanced Controller (EM-2-MBAC)	√	√	√	×	×	×
Sprinter 907-Class	907	Body	N175/3 - Expansion Module 3 for Mercedes-Benz Advanced Controller (EM-3-MBAC)	√	√	√	×	×	×

Sprinter 907-Class	907	Body	SG BMS-Battery management system control unit	√	√	√	×	×	×
Sprinter 907-Class	907	Drive	CDI-Motor electronics	√	√	√	×	×	×
Sprinter 907-Class	907	Drive	CDI-Motor electronics	√	√	√	√	×	×
Sprinter 907-Class	907	Drive	CDI-Motor electronics	√	√	√	×	×	×
Sprinter 907-Class	907	Drive	CDI-Motor electronics	√	√	√	×	×	×
Sprinter 907-Class	907	Drive	CDI-Motor electronics	√	√	√	×	×	×
Sprinter 907-Class	907	Drive	ME-Engine electronics 'ME40' for internal combustion engine 'M274'	√	√	√	√	×	×
Sprinter 907-Class	907	Drive	CDI-Motor electronics	√	√	√	×	×	×
Sprinter 907-Class	907	Drive	CDI-Motor electronics	√	√	√	×	×	×
Sprinter 907-Class	907	Drive	FTC-Front transmission control	√	√	√	×	×	×
Sprinter 907-Class	907	Drive	VGS-Start clutch oil pressure sensor	√	√	√	√	×	×
Sprinter 907-Class	907	Drive	Transmission control	√	√	√	×	×	×
Sprinter 907-Class	907	Drive	Transmission control	√	√	√	×	×	×
Sprinter 907-Class	907	Chassis	ESP-Electronic stability program	√	√	√	×	×	×
Sprinter 907-Class	907	Drive	FSCU01-Control unit Fuel pump	√	√	√	√	×	×
Sprinter 907-Class	907	Drive	SCR-Selective catalytic reduction	√	√	√	√	×	×
Sprinter 907-Class	907	Drive	SCR-Selective catalytic reduction	√	√	√	×	×	×
Sprinter 907-Class	907	Drive	N127 (Drivetrain control unit)	√	√	√	√	×	×

Sprinter 907-Class	907	Drive	N127 (Drivetrain control unit)	√	√	√	√	×	×
Sprinter 907-Class	907	Drive	N127 (Drivetrain control unit)	√	√	√	×	×	×
Sprinter 907-Class	907	Body	BMS-Battery management system	√	√	√	×	×	×
Sprinter 907-Class	907	Body	N175 - Expansion module 3 for Mercedes-Benz Advanced Controller (MBAC)	√	√	√	×	×	×
Sprinter 907-Class	907	Body	N26/25 - On-board logic unit (OLU)	√	√	√	×	×	×
Sprinter 910-Class	910	Body	EZS-Electronic ignition switch	√	√	√	√	×	×
Sprinter 910-Class	910	Seats and Doors	DCU RF-Right front door	√	√	√	√	×	×
Sprinter 910-Class	910	Seats and Doors	STL-Left electric sliding door	√	√	√	×	×	×
Sprinter 910-Class	910	Seats and Doors	STR-Right electric sliding door	√	√	√	×	×	×
Sprinter 910-Class	910	Seats and Doors	Name Bauteil - (KEP) (Code:T40, T41) (SDD907)	√	√	√	×	×	×
Sprinter 910-Class	910	Seats and Doors	DCU LF-Left front door	√	√	√	√	×	×
Sprinter 910-Class	910	Seats and Doors	ESE-Driver's seat adjustment	√	√	√	√	×	×
Sprinter 910-Class	910	Body	SAM-Signal acquisition and actuation module	√	√	√	√	×	×
Sprinter 910-Class	910	Information and communication	HERMES-Telematics module	√	√	√	×	×	×
Sprinter 910-Class	910	Seats and Doors	ESE-'Front passenger' electric seat adjustment	√	√	√	√	×	×
Sprinter 910-Class	910	Air conditioning	C AAC-Convenience automatic air conditioning/AAC-Automatic air	√	√	√	√	×	×
Sprinter 910-Class	910	Body	ATA-Interior motion sensor	√	√	√	×	×	×
Sprinter 910-Class	910	Body	AAG-Trailer identification device	√	√	√	×	×	×

Sprinter 910-Class	910	Body	Multifunction control unit-Multifunction control unit	√	√	√	×	×	×
Sprinter 910-Class	910	Driver assistance system	AB-Airbag	√	√	√	√	×	×
Sprinter 910-Class	910	Driver assistance system	ACS-Automatic clutch system	√	√	√	√	×	×
Sprinter 910-Class	910	Body	CL-Central locking control unit	√	√	√	√	×	×
Sprinter 910-Class	910	Body	UCP-Upper control panel	√	√	√	×	×	×
Sprinter 910-Class	910	Information and communication	A26/17 - MBUX multimedia system (host, code: E2W, E2X) (CONNECT907)	√	√	√	×	×	×
Sprinter 910-Class	910	Information and communication	A26/17 - MBUX multimedia system (host, code: E2Y, E2Z) (HU6)	√	√	√	×	×	×
Sprinter 910-Class	910	Information and communication	ZAN-Audio/COMAND display	√	√	√	√	×	×
Sprinter 910-Class	910	Information and communication	UHI-Cellular telephone (fixed installation or portable)(D2B)	√	√	√	√	×	×
Sprinter 910-Class	910	Information and communication	IC-Instrument cluster	√	√	√	×	×	×
Sprinter 910-Class	910	Driver assistance system	RFK-Backup camera	√	√	√	√	×	×
Sprinter 910-Class	910	Body	SRS-Supplemental restraint system	√	√	√	√	×	×
Sprinter 910-Class	910	Body	SOGESTAR2-Sound generator for electric vehicle	√	√	√	×	×	×
Sprinter 910-Class	910	Body	SG SW L-Left headlamp	√	√	√	×	×	×
Sprinter 910-Class	910	Chassis	TPM-Tire pressure monitor	√	√	√	√	×	×
Sprinter 910-Class	910	Driver assistance system	MFK-Multifunction camera(mono)	√	√	√	√	×	×
Sprinter 910-Class	910	Body	SG SW R-Right headlamp	√	√	√	×	×	×
Sprinter 910-Class	910	Body	DC Charging Connection Unit (DCCU)	√	√	√	√	×	×

Sprinter 910-Class	910	Drive	ISM-Shift module	√	√	√	√	×	×
Sprinter 910-Class	910	Drive	SG EM-Power electronics	√	√	√	√	×	×
Sprinter 910-Class	910	Body	SG LG-Charger	√	√	√	√	×	×
Sprinter 910-Class	910	Body	DC/DC-DC/DC converter	√	√	√	√	×	×
Sprinter 910-Class	910	Body	SG BMS-Battery management system control unit	√	√	√	×	×	×
Sprinter 910-Class	910	Body	BSN-Battery sensor	√	√	√	×	×	×
Sprinter 910-Class	910	Body	RGLS-Rain/light sensor	√	√	√	√	×	×
Sprinter 910-Class	910	Body	ATA-Anti-theft alarm system	√	√	√	×	×	×
Sprinter 910-Class	910	Seats and Doors	S47/2 (driver's door switch module)	√	√	√	×	×	×
Sprinter 910-Class	910	Seats and Doors	S22 (driver's side door seat adjustment switch)	√	√	√	×	×	×
Sprinter 910-Class	910	Seats and Doors	Intelligent climate control switch group for driver's seat (S51/1)	√	√	√	×	×	×
Sprinter 910-Class	910	Seats and Doors	S47/3 (door switch module on front passenger side)	√	√	√	×	×	×
Sprinter 910-Class	910	Seats and Doors	S23 (door seat adjustment switch on front passenger side)	√	√	√	×	×	×
Sprinter 910-Class	910	Seats and Doors	S51/2 (intelligent climate control switch group for front passenger seat)	√	√	√	×	×	×
Sprinter 910-Class	910	Body	AS-Alarm siren	√	√	√	√	×	×
Sprinter 910-Class	910	Body	ATA-ATA[EDW]/tow-away protection/interior protection	√	√	√	×	×	×
Sprinter 910-Class	910	Air conditioning	STH-Stationary heater	√	√	√	×	×	×
Sprinter 910-Class	910	Air conditioning	STH-Stationary heater	√	√	√	√	×	×

Sprinter 910-Class	910	Air conditioning	C AAC-Convenience automatic air conditioning/AAC-Automatic air	√	√	√	×	×	×
Sprinter 910-Class	910	Body	N175/1 - Expansion Module 3 for Mercedes-Benz Advanced Controller (EM-1-MBAC)	√	√	√	×	×	×
Sprinter 910-Class	910	Driver assistance system	SG AWF-COLLISION PREVENTION ASSIST	√	√	√	√	×	×
Sprinter 910-Class	910	Driver assistance system	PTS-PARKTRONIC	√	√	√	√	×	×
Sprinter 910-Class	910	Chassis	ES-Electric power steering	√	√	√	√	×	×
Sprinter 910-Class	910	Body	MRM-Steering column module	√	√	√	√	×	×
Sprinter 910-Class	910	Drive	VG-Transfer case	√	√	√	×	×	×
Sprinter 910-Class	910	Body	SG BMS-Battery management system control unit	√	√	√	×	×	×
Sprinter 910-Class	910	Body	SG BMS-Battery management system control unit	√	√	√	×	×	×
Sprinter 910-Class	910	Information and communication	DTCO-Digital tachograph	√	√	√	×	×	×
Sprinter 910-Class	910	Information and communication	DTCO-Digital tachograph	√	√	√	×	×	×
Sprinter 910-Class	910	Information and communication	MTCO-Modular tachograph	√	√	√	×	×	×
Sprinter 910-Class	910	Body	N175/2 - Expansion Module 3 for Mercedes-Benz Advanced Controller (EM-2-MBAC)	√	√	√	×	×	×
Sprinter 910-Class	910	Body	N175/3 - Expansion Module 3 for Mercedes-Benz Advanced Controller (EM-3-MBAC)	√	√	√	×	×	×
Sprinter 910-Class	910	Body	SG BMS-Battery management system control unit	√	√	√	×	×	×
Sprinter 910-Class	910	Drive	CDI-Motor electronics	√	√	√	×	×	×
Sprinter 910-Class	910	Drive	CDI-Motor electronics	√	√	√	√	×	×
Sprinter 910-Class	910	Drive	CDI-Motor electronics	√	√	√	×	×	×

Sprinter 910-Class	910	Drive	CDI-Motor electronics	√	√	√	×	×	×
Sprinter 910-Class	910	Drive	CDI-Motor electronics	√	√	√	×	×	×
Sprinter 910-Class	910	Drive	ME-Engine electronics 'ME40' for internal combustion engine 'M274'	√	√	√	√	×	×
Sprinter 910-Class	910	Drive	CDI-Motor electronics	√	√	√	×	×	×
Sprinter 910-Class	910	Drive	CDI-Motor electronics	√	√	√	×	×	×
Sprinter 910-Class	910	Drive	FTC-Front transmission control	√	√	√	×	×	×
Sprinter 910-Class	910	Drive	VGS-Start clutch oil pressure sensor	√	√	√	√	×	×
Sprinter 910-Class	910	Drive	Transmission control	√	√	√	×	×	×
Sprinter 910-Class	910	Drive	Transmission control	√	√	√	×	×	×
Sprinter 910-Class	910	Chassis	ESP-Electronic stability program	√	√	√	×	×	×
Sprinter 910-Class	910	Drive	FSCU01-Control unit Fuel pump	√	√	√	√	×	×
Sprinter 910-Class	910	Drive	SCR-Selective catalytic reduction	√	√	√	√	×	×
Sprinter 910-Class	910	Drive	SCR-Selective catalytic reduction	√	√	√	×	×	×
Sprinter 910-Class	910	Drive	N127 (Drivetrain control unit)	√	√	√	√	×	×
Sprinter 910-Class	910	Drive	N127 (Drivetrain control unit)	√	√	√	√	×	×
Sprinter 910-Class	910	Drive	N127 (Drivetrain control unit)	√	√	√	×	×	×
Sprinter 910-Class	910	Body	BMS-Battery management system	√	√	√	×	×	×
Sprinter 910-Class	910	Body	N175 - Expansion module 3 for Mercedes-Benz Advanced Controller (MBAC)	√	√	√	×	×	×

Sprinter 910-Class	910	Body	N26/25 - On-board logic unit (OLU)	√	√	√	×	×	×
Ctian 420-Class	420	Drive	ME-Motor electronics	√	√	√	×	×	×
Ctian 420-Class	420	Drive	ETC-Electronic transmission control	√	√	√	×	×	×
Ctian 420-Class	420	Body	MRM-Steering column module	√	√	√	×	×	×
Ctian 420-Class	420	Chassis	ESP-Electronic stability program	√	√	√	×	×	×
Ctian 420-Class	420	Body	Name Bauteil - RCGW420	√	√	√	×	×	×
Ctian 420-Class	420	Air conditioning	KLA-air conditioning	√	√	√	×	×	×
Ctian 420-Class	420	Drive	ME-Motro electronics CNGCM246 for combustion engine 379CNG	√	√	√	×	×	×
Ctian 420-Class	420	Drive	ME-Motro electronics CNGCM246 for combustion engine 379CNG	√	√	√	×	×	×
Ctian 420-Class	420	Air conditioning	KLA-air conditioning	√	√	√	×	×	×
Ctian 420-Class	420	Drive	SCR-Selective catalytic reduction	√	√	√	×	×	×
Ctian 420-Class	420	Air conditioning	KLA-air conditioning	√	√	√	×	×	×
Ctian 420-Class	420	Information and communication	HERMES-Telematics module	√	√	√	×	×	×
Ctian 420-Class	420	Body	N135 (Steering wheel electronics) (LRE)	√	√	√	×	×	×
Ctian 420-Class	420	Body	UCP-Upper control panel	√	√	√	×	×	×
Ctian 420-Class	420	Information and communication	A26/17 - MBUX multimedia system (host, code: E2W, E2X) (CONNECT907)	√	√	√	×	×	×
Ctian 420-Class	420	Information and communication	A26/17 - MBUX multimedia system (host, code: E2Y, E2Z) (HU6)	√	√	√	×	×	×
Ctian 420-Class	420	Information and communication	ZAN-Audio/COMAND display	√	√	√	√	×	×



Ctian 420-Class	420	Information and communication	IC-Instrument cluster	√	√	√	×	×	×
Ctian 420-Class	420	Driver assistance system	RFK-Backup camera	√	√	√	√	×	×
Ctian 420-Class	420	Body	SG SW L-Left headlamp	√	√	√	×	×	×
Ctian 420-Class	420	Body	SG SW R-Right headlamp	√	√	√	×	×	×
Ctian 420-Class	420	Body	N75 (Driver Assistance System Control Unit) (SG-FAS)	√	√	√	×	×	×
Ctian 420-Class	420	Body	IRS-HLA-Left rear external smart radar range sensor	√	√	√	×	×	×
Ctian 420-Class	420	Seats and Doors	SOGESTAR2-Sound generator for electric vehicle	√	√	√	×	×	×
Ctian 420-Class	420	Chassis	ES-Electric power steering	√	√	√	×	×	×
Ctian 420-Class	420	Air conditioning	C AAC-Convenience automatic air conditioning/AAC-Automatic air	√	√	√	×	×	×
Ctian 420-Class	420	Air conditioning	C AAC-Convenience automatic air conditioning/AAC-Automatic air	√	√	√	×	×	×
Ctian 420-Class	420	Body	SAM-Signal acquisition and actuation control module	√	√	√	×	×	×
Ctian 420-Class	420	Air conditioning	KLA-air conditioning	√	√	√	×	×	×
Ctian 420-Class	420	Body	SRS-Supplemental restraint system	√	√	√	×	×	×
Ctian 420-Class	420	Air conditioning	KLA-air conditioning	√	√	√	×	×	×
Ctian 420-Class	420	Air conditioning	KLA-air conditioning	√	√	√	×	×	×
Ctian 420-Class	420	Drive	HFM-SFI-Hot film engine management	√	√	√	×	×	×
Ctian 420-Class	420	Body	Inductive Charging System (WCBS420)	√	√	√	×	×	×
Ctian 420-Class	420	Body	N75 (Driver Assistance System Control Unit) (SG-FAS)	√	√	√	×	×	×

Ctian 420-Class	420	Body	IRS-HRA-Right rear external intelligent radar range sensor	√	√	√	×	×	×
Ctian 420-Class	420	Drive	SG LML VR-LED matrix of right front lamp unit	√	√	√	×	×	×
Ctian 420-Class	420	Air conditioning	KLA-air conditioning	√	√	√	×	×	×
Ctian 420-Class	420	Information and communication	MFK-Multifunction camera	√	√	√	×	×	×
Ctian 420-Class	420	Drive	CDI-Motor electronics	√	√	√	×	×	×
Sprinter 909-Class	909	Information and communication	E-Call-RU-eCall, Russia (GLONASS)	√	√	√	×	×	×
Sprinter 909-Class	909	Body	SRS-Supplemental restraint system	√	√	√	×	×	×
Sprinter 909-Class	909	Chassis	ESP-Electronic stability program	√	√	√	×	×	×
Sprinter 909-Class	909	Body	ZV-Central locking system	√	√	√	×	×	×
Sprinter 909-Class	909	Body	WSP immobilizer	√	√	√	×	×	×
Sprinter 909-Class	909	Body	HZR-Heating control	√	√	√	×	×	×
Sprinter 909-Class	909	Body	KE-Keyless Entry	√	√	√	×	×	×
Sprinter 909-Class	909	Drive	CDI-Motor electronics	√	√	√	×	×	×
Sprinter 909-Class	909	Drive	CDI-Motor electronics	√	√	√	×	×	×
X 470-Class	470	Information and communication	HERMES-Telematics module	√	√	√	×	×	×
X 470-Class	470	Body	MRM-Steering column module	√	√	√	√	×	×
X 470-Class	470	Information and communication	TPAD-Touch pad	√	√	√	√	×	×
X 470-Class	470	Information and communication	RD-Radio (Audio / Cab Management and Data Systems)	√	√	√	√	×	×

X 470-Class	470	Information and communication	Audio-Audio or COMAND	√	√	√	√	×	×
X 470-Class	470	Information and communication	ZBE-Audio / Cab Management and Data System (COMAND) operating unit	√	√	√	×	×	×
X 470-Class	470	Information and communication	ZAN-Audio / Cab Management and Data System (COMAND) display	√	√	√	√	×	×
X 470-Class	470	Information and communication	IC-Instrument cluster	√	√	√	×	×	×
X 470-Class	470	Driver assistance	RFK-Backup camera	√	√	√	×	×	×
X 470-Class	470	Driver assistance	360 camera - 360 camera	√	√	√	×	×	×
X 470-Class	470	Information and communication	MFK-Multifunction camera	√	√	√	×	×	×
X 470-Class	470	Information and communication	DAB-Digital Audio Broadcasting	√	√	√	√	×	×
X 470-Class	470	Information and communication	SG AWF-Control unit 'COLLISION PREVENTION ASSIST'	√	√	√	×	×	×
X 470-Class	470	Body	CGW-Central gateway	√	√	√	×	×	×
X 470-Class	470	Chassis	ESP-Electronic stability program	√	√	√	×	×	×
X 470-Class	470	Body	WSS-Weight sensing system	√	√	√	×	×	×
X 470-Class	470	Air conditioning	C AAC-Convenience automatic air conditioning/AAC-Automatic air	√	√	√	×	×	×
X 470-Class	470	Body	SAM-Signal acquisition and actuation control	√	√	√	×	×	×
X 470-Class	470	Body	Headlight Range Regulation (LWR)	√	√	√	×	×	×
X 470-Class	470	Drive	AAC-Automatic air conditioning	√	√	√	×	×	×
X 470-Class	470	Information and communication	PTS-Parktronic system	√	√	√	×	×	×
X 470-Class	470	Body	BSN-Battery sensor	√	√	√	×	×	×
X 470-Class	470	Body	SRS-Supplemental restraint system	√	√	√	×	×	×
X 470-Class	470	Chassis	TPM-Tire pressure monitor	√	√	√	×	×	×
X 470-Class	470	Body	N75 (Driver Assistance System Control Unit) (SG-	√	√	√	×	×	×
X 470-Class	470	Information and communication	Vehicle power grid management system (ElectSysManage)	√	√	√	×	×	×
X 470-Class	470	Drive	VG-Transfer case	√	√	√	×	×	×
X 470-Class	470	Information and communication	DTCO-Digital tachograph	√	√	√	×	×	×

X 470-Class	470	Information and communication	DTCO-Digital tachograph	√	√	√	×	×	×
X 470-Class	470	Information and communication	DTCO-Digital tachograph	√	√	√	×	×	×
X 470-Class	470	Drive	HAQ-Interwheel differential lock at rear axle	√	√	√	×	×	×
X 470-Class	470	Drive	CDI-Motor electronics	√	√	√	×	×	×
X 470-Class	470	Drive	CDI-Motor electronics	√	√	√	×	×	×
X 470-Class	470	Drive	CDI-Motor electronics	√	√	√	×	×	×
X 470-Class	470	Drive	CDI-Motor electronics	√	√	√	×	×	×
X 470-Class	470	Drive	CDI-Motor electronics	√	√	√	×	×	×
X 470-Class	470	Drive	ETC-Electronic transmission control	√	√	√	×	×	×
X 470-Class	470	Drive	VGS-Start clutch oil pressure sensor	√	√	√	√	×	×
X 470-Class	470	Drive	Transmission control	√	√	√	×	×	×
X 470-Class	470	Drive	FSCU-Fuel system control unit	√	√	√	√	×	×
X 470-Class	470	Drive	SCR-Selective Catalytic Reduction	√	√	√	√	×	×
X 470-Class	470	Drive	N127 (Drivetrain control unit)	√	√	√	×	×	×
X 470-Class	470	Drive	SCR-Selective catalytic reduction	√	√	√	×	×	×
X 470-Class	470	Air conditioning	KLA-air conditioning	√	√	√	×	×	×
V/Vito-	638	Drive	ME-Motor electronics	√	√	√	√	×	×
V/Vito-	638	Drive	CR-Common rail	√	√	√	√	×	×
V/Vito-	638	Drive	CR-Common rail	√	√	√	√	×	×
V/Vito-Class	638	Information and communication	KI-Instrument cluster	√	√	√	√	×	×
V/Vito-	638	Body	WSP immobilizer	√	√	√	√	×	×
V/Vito-	638	Body	AB-Airbag	√	√	√	×	×	×
V/Vito-	638	Body	ABW-Airbag with window airbag	√	√	√	√	×	×
V/Vito-	638	Chassis	ABS-Anti lock braking system	√	√	√	√	×	×
V/Vito-Class	638	Information and communication	Radio (SOUND series)	√	√	√	√	×	×
V/Vito-Class	638	Information and communication	AUDIO/APS-Auto pilot system	√	√	√	√	×	×
V/Vito-Class	638	Information and communication	APS-Auto pilot system	√	√	√	√	×	×
V/Vito-	638	Body	ARS-All-wheel system	√	√	√	√	×	×
V/Vito-	638	Body	EDW2-Anti-theft alarm	√	√	√	√	×	×

V/Vito-	638	Drive	EGS electronic transmission control	√	√	√	√	×	×
V/Vito-	638	Drive	EWM-Electronic selector lever module	√	√	√	√	×	×
V/Vito-	638	Chassis	ESP-Electronic stability program	√	√	√	√	×	SP0004
V/Vito-	638	Body	HZR-Heating control	√	√	√	√	×	×
V/Vito-	638	Air conditioning	HB-Heater booster	√	√	√	√	×	×
V/Vito-	638	Body	RFH backup assist	√	√	√	√	×	×
V/Vito-	638	Body	ZV-Central locking system	√	√	√	√	×	×
V/Vito-	638	Body	LPG Liquefied Petroleum Gas	√	√	√	√	×	×
Viano/Vito- Class	639	Drive	ME-SFI 2.8-Motor electronics 2.8	√	√	√	√	×	×
Viano/Vito- Class	639	Drive	EGS electronic transmission control	√	√	√	√	×	×
Viano/Vito- Class	639	Drive	ESM-Electronic selector module	√	√	√	√	×	×
Viano/Vito- Class	639	Chassis	ESP-Electronic stability program	√	√	√	√	×	SP0004
Viano/Vito- Class	639	Chassis	ESP-Electronic stability program	√	√	√	√	×	SP0004,SP0005
Viano/Vito- Class	639	Body	CGW-Central gateway	√	√	√	×	×	×
Viano/Vito- Class	639	Body	EZS-Electronic ignition switch	√	√	√	√	×	×
Viano/Vito- Class	639	Information and communication	IC-Instrument cluster	√	√	√	√	×	×
Viano/Vito- Class	639	Information and communication	IC-Instrument cluster	√	√	√	√	×	×
Viano/Vito- Class	639	Body	SRS-supplemental restraint system	√	√	√	×	×	×
Viano/Vito- Class	639	Body	SRS-supplemental restraint system	√	√	√	√	×	×
Viano/Vito- Class	639	Body	SAM-Signal acquisition and actuation module	√	√	√	√	×	×
Viano/Vito- Class	639	Body	UCP-Upper control panel	√	√	√	√	×	×
Viano/Vito- Class	639	Seats and Doors	DCM-FL-Door control module front left	√	√	√	√	×	×

Viano/Vito-Class	639	Seats and Doors	DCM-FR-Door control module front right	√	√	√	√	×	×
Viano/Vito-Class	639	Body	OCP-Overhead control panel	√	√	√	√	ACT0000,ACT0001,ACT0002,ACT0003,ACT0004,ACT0005	SP0006,SP0007
Viano/Vito-Class	639	Body	SDE-H-Rear sliding roof unit	√	√	√	√	ACT0004,ACT0003	SP0006,SP0008,SP0009
Viano/Vito-Class	639	Air conditioning	REAR AC-Rear air conditioning	√	√	√	√	×	SP0010
Viano/Vito-Class	639	Air conditioning	AAC-Automatic air conditioning	√	√	√	√	×	SP0011
Viano/Vito-Class	639	Air conditioning	STH-Stationary heater	√	√	√	√	×	×
Viano/Vito-Class	639	Information and communication	PTS-Parktronic system	√	√	√	√	×	×
Viano/Vito-Class	639	Seats and Doors	STE-R-ESD [STE] Right electric sliding door	√	√	√	√	×	SP0012,SP0013,SP0014
Viano/Vito-Class	639	Seats and Doors	STE-L-ESD [STE] Left electric sliding door	√	√	√	√	×	SP0012,SP0013,SP0014
Viano/Vito-Class	639	Chassis	ENR-Electronic rear axle level control	√	√	√	√	ACT0006,ACT0007,ACT0008	SP0015
Viano/Vito-Class	639	Seats and Doors	ESA driver-Electric seat adjustment driver (with memory)	√	√	√	√	ACT0009,ACT0010,ACT0011,ACT0012,ACT0013	SP0016,SP0017,SP0018,SP0019,SP0020
Viano/Vito-Class	639	Seats and Doors	ESA passenger-Electric seat adjustment front passenger (with memory)	√	√	√	√	ACT0009,ACT0010,ACT0011,ACT0012,ACT0013	SP0016,SP0017,SP0018,SP0019,SP0020
Viano/Vito-Class	639	Chassis	TPC-Tire pressure monitor	√	√	√	√	×	×
Viano/Vito-Class	639	Body	AHE-Trailer recognition	√	√	√	√	×	×
Viano/Vito-Class	639	Body	AAG-Trailer connection unit	√	√	√	√	×	×
Viano/Vito-Class	639	LIN Bus	PSM-Parameterizable Special Module	√	√	√	×	×	×
Viano/Vito-Class	639	LIN Bus	PSM-Parameterizable Special Module	√	√	√	√	×	×

Viano/Vito-Class	639	Information and communication	RADIO Sound 5	√	√	√	×	×	×
Viano/Vito-Class	639	Information and communication	AUDIO/APS-Auto pilot system	√	√	√	√	×	×
Viano/Vito-Class	639	Information and communication	COMAND	√	√	√	√	×	×
Viano/Vito-Class	639	Information and communication	HRA-Headlamp range adjustment	√	√	√	√	×	×
Viano/Vito-Class	639	Information and communication	Radio (SOUND series)	√	√	√	√	×	×
Viano/Vito-Class	639	Information and communication	CDC-CD changer	√	√	√	×	×	×
Viano/Vito-Class	639	Information and communication	CTEL-Cellular telephone 1 (fixed installation or portable)(D2B)	√	√	√	×	×	×
Viano/Vito-Class	639	Information and communication	UHI-Cellular telephone (fixed installation or portable)(D2B)	√	√	√	√	×	×
Viano/Vito-Class	639	Information and communication	VCS-Voice control system	√	√	√	√	×	×
Viano/Vito-Class	639	Information and communication	TV-TV tuner	√	√	√	√	×	×
Viano/Vito-Class	639	Information and communication	NAVI-Navigation system (COMAND,SOUND 50)	√	√	√	√	×	×
Viano/Vito-Class	639	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	√	√	√	√	×	×
Viano/Vito-Class	639	Information and communication	RADIO Sound 20	√	√	√	√	×	×
Viano/Vito-Class	639	Information and communication	SOUND 5NG	√	√	√	√	×	×
Viano/Vito-Class	639	Information and communication	CDW-CD changer	√	√	√	√	×	×
Viano/Vito-Class	639	Information and communication	TEL-Telephone control unit	√	√	√	√	×	×
Viano/Vito-Class	639	Information and communication	AVN-Headlamp range adjustmen	√	√	√	√	×	×
Viano/Vito-Class	639	Drive	CDI-Common Rail Diesel Injection	√	√	√	×	×	×

Viano/Vito-Class	639	Drive	CDI-Common Rail Diesel Injection	√	√	√	×	×	×
Viano/Vito-Class	639	Drive	CDI4-Common Rail Diesel Injection	√	√	√	√	×	×
Viano/Vito-Class	639	Drive	CDI4-Common Rail Diesel Injection	√	√	√	×	×	×
Viano/Vito-Class	639	Body	SAM-Signal acquisition and actuation module	√	√	√	√	×	×
Viano/Vito-Class	639	Air conditioning	PTC-Heater booster	√	√	√	√	×	×
Viano/Vito-Class	639	Air conditioning	PTC-Heater booster	√	√	√	√	×	×
Viano/Vito-Class	639	Drive	EGS electronic transmission control	√	√	√	√	×	×
Viano/Vito-Class	639	Drive	ETC-Electronic transmission control	√	√	√	√	×	×
Viano/Vito-Class	639	Body	EZS-Electronic ignition switch	√	√	√	√	×	×
Viano/Vito-Class	639	Drive	ME 97-Motor electronics 9.7	√	√	√	√	ACT0014,ACT0015, ACT0016,ACT0017, ACT0018,ACT0019, ACT0020,ACT0021, ACT0022,ACT0023, ACT0024,ACT0025, ACT0026,ACT0027,	SP0021,SP0022, SP0023,SP0024
Viano/Vito-Class	639	Drive	CDID2-Common Rail Diesel Injection	√	√	√	√	ACT0029,ACT0030, ACT0031,ACT0032, ACT0033,ACT0034, ACT0035,ACT0036, ACT0037,ACT0038,	SP0025,SP0026, SP0027,SP0028, SP0021,SP0029, SP0030,SP0031, SP0032,SP0033,



Viano/Vito-Class	639	Drive	CDI6-Common Rail Diesel Injection	√	√	√	√	ACT0029,ACT0040,ACT0030,ACT0041,ACT0031,ACT0042,ACT0043,ACT0044,ACT0045,ACT0038,ACT0039	SP0025,SP0026,SP0035,SP0021,SP0036,SP0027,SP0037,SP0038,SP0028,SP0039,SP0040,SP0041,SP0030,SP0042,SP0043,SP0044,
Viano/Vito-Class	639	Body	OBF2-Upper control panel	√	√	√	√	×	×
Viano/Vito-Class	639	Body	SRS-supplemental restraint system	√	√	√	√	×	×
Viano/Vito-Class	639	Information and communication	DTCO-Digital tachograph	√	√	√	√	×	×
Viano/Vito-Class	639	Information and communication	FSE Hands-free system (Bluetooth)	√	√	√	√	×	×
Viano/Vito-Class	639	Drive	FSCU-Fuel pump	√	√	√	√	×	×
Viano/Vito-Class	639	Body	ALWR-Headlamp range adjustment	√	√	√	√	ACT0046	×
Viano/Vito-Class	639	Information and communication	COMAND or AUDIO	√	√	√	√	×	×
Viano/Vito-Class	639	Drive	CDI4-Common Rail Diesel Injection	√	√	√	√	ACT0047,ACT0048,ACT0049,ACT0050,ACT0051,ACT0052,ACT0053,ACT0054,ACT0055,ACT0056,ACT0057,ACT0058,ACT0052,ACT0059,	SP0046,SP0047,SP0048,SP0049,SP0050,SP0051,SP0052,SP0043,SP0044,SP0002
Sprinter III/Sprinter III up to 2013-Class	906	Drive	CR-Common rail	√	√	√	√	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Information and communication	KI-Instrument cluster	√	√	√	√	×	×

Sprinter III/Sprinter III up to 2013-Class	906	Body	WSP immobilizer	√	√	√	√	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Body	AB-Airbag	√	√	√	×	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Body	ABW-Airbag with window airbag	√	√	√	√	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Body	ARS-All-wheel system	√	√	√	√	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Drive	EGS electronic transmission control	√	√	√	√	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Chassis	ABS-Anti lock braking system	√	√	√	√	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Information and communication	Radio (SOUND series)	√	√	√	√	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Information and communication	AUDIO/APS-Auto pilot system	√	√	√	√	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Information and communication	APS-Auto pilot system	√	√	√	√	×	×

Sprinter III/Sprinter III up to 2013-Class	906	Body	EDW2-Anti-theft alarm	√	√	√	√	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Drive	EWM-Electronic selector lever module	√	√	√	√	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Chassis	ESP-Electronic stability program	√	√	√	√	×	SP0004
Sprinter III/Sprinter III up to 2013-Class	906	Body	HZR-Heating control	√	√	√	√	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Body	RFH backup assist	√	√	√	√	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Air conditioning	HB-Heater booster	√	√	√	√	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Body	ZV-Central locking system	√	√	√	√	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Drive	ME-Motor electronics	√	√	√	√	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Drive	CR-Common rail	√	√	√	√	×	×

Sprinter III/Sprinter III up to 2013-Class	906	Body	EZS-Electronic ignition switch	√	√	√	√	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Body	EZS-Electronic ignition switch	√	√	√	√	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Body	EZS-Electronic ignition switch	√	√	√	√	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Drive	CDI4-Common Rail Diesel Injection	√	√	√	√	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Drive	CDI3-Common Rail Diesel Injection	√	√	√	√	ACT0062,ACT0030,ACT0031,ACT0039	SP0046,SP0026,SP0053,SP0032
Sprinter III/Sprinter III up to 2013-Class	906	Drive	CDID2-Common Rail Diesel Injection	√	√	√	√	ACT0029,ACT0030,ACT0031,ACT0032,ACT0033,ACT0034,ACT0035,ACT0036,ACT0037,ACT0038,	SP0025,SP0026,SP0027,SP0028,SP0021,SP0029,SP0030,SP0031,SP0032,SP0033,
Sprinter III/Sprinter III up to 2013-Class	906	Drive	CDI6-Common Rail Diesel Injection	√	√	√	√	ACT0029,ACT0040,ACT0030,ACT0041,ACT0031,ACT0042,ACT0043,ACT0044,ACT0045,ACT0038,ACT0039	SP0025,SP0026,SP0035,SP0021,SP0036,SP0027,SP0037,SP0038,SP0028,SP0039,SP0040,SP0041,SP0030,SP0042,SP0043,SP0044,

Sprinter III/Sprinter III up to 2013-Class	906	Drive	CDI60-Common Rail Diesel Injection(OM642 EPA13)	√	√	√	√	ACT0063,ACT0064, ACT0065,ACT0066, ACT0039,ACT0067, ACT0068,ACT0069, ACT0070,ACT0028, ACT0071,ACT0072, ACT0073,ACT0074	SP0035,SP0002, SP0021,SP0036, SP0027,SP0037, SP0038,SP0028, SP0054,SP0030, SP0055,SP0056, SP0042,SP0057, SP0058,SP0059, SP0060,SP0043, SP0044,SP0061,
Sprinter III/Sprinter III up to 2013-Class	906	Drive	CDI4-Common Rail Diesel Injection	√	√	√	√	×	SP0064,SP0065, SP0066,SP0030, SP0060,SP0002, SP0035,SP0046, SP0059,SP0043,
Sprinter III/Sprinter III up to 2013-Class	906	Drive	ME 97-Motor electronics 9.7	√	√	√	√	ACT0014,ACT0015, ACT0016,ACT0017, ACT0018,ACT0019, ACT0020,ACT0021, ACT0022,ACT0023, ACT0024,ACT0025, ACT0026,ACT0027,	SP0021,SP0022, SP0023,SP0024
Sprinter III/Sprinter III up to 2013-Class	906	Drive	ME-SFI-Motor electronics	√	√	√	√	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Drive	CDI4-Common Rail Diesel Injection	√	√	√	√	ACT0047,ACT0048, ACT0049,ACT0050, ACT0051,ACT0052, ACT0053,ACT0054, ACT0055,ACT0056, ACT0057,ACT0058, ACT0052,ACT0059,	SP0046,SP0047, SP0048,SP0049, SP0050,SP0051, SP0052,SP0043, SP0044,SP0002
Sprinter III/Sprinter III up to 2013-Class	906	Information and communication	KI-Instrument cluster	√	√	√	√	×	×

Sprinter III/Sprinter III up to 2013-Class	906	Body	OBF-Upper control panel	√	√	√	√	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Body	OBF2-Upper control panel	√	√	√	√	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Body	SAM-Signal acquisition and actuation module	√	√	√	√	ACT0075,ACT0076,ACT0077,ACT0078,ACT0079,ACT0080,ACT0081,ACT0082,ACT0083,ACT0084,ACT0085,ACT0086,ACT0087,ACT0088,ACT0089,ACT0090,	×
Sprinter III/Sprinter III up to 2013-Class	906	Seats and Doors	TSG-Door control module front driver side	√	√	√	√	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Body	ALWR-Headlamp range adjustment	√	√	√	√	ACT0046	×
Sprinter III/Sprinter III up to 2013-Class	906	Body	AAG-Trailer connection unit	√	√	√	√	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Drive	NGT-Natural Gas Technology	√	×	×	√	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Body	DBE-Overhead control panel	√	√	√	√	ACT0084,ACT0093,ACT0094,ACT0095,ACT0096,ACT0097	SP0067,SP0068,SP0069,SP0070,SP0071,SP0072,SP0073,SP0074

Sprinter III/Sprinter III up to 2013-Class	906	Drive	EGS electronic transmission control	√	√	√	√	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Drive	EGS electronic transmission control	√	√	√	√	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Chassis	ESP-Electronic stability program	√	√	√	√	×	SP0075
Sprinter III/Sprinter III up to 2013-Class	906	Chassis	ESP9-Electronic stability program	√	√	√	√	×	SP0004,SP0076, SP0077
Sprinter III/Sprinter III up to 2013-Class	906	Drive	EWM-Electronic selector lever module	√	√	√	√	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Body	KE-Keyless Entry	√	√	√	√	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Air conditioning	KLA-Automatic air conditioning	√	√	√	√	×	SP0078
Sprinter III/Sprinter III up to 2013-Class	906	Body	MRM-Steering column module	√	√	√	√	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Information and communication	MTCO-Modular tachograph	√	√	√	√	×	×

Sprinter III/Sprinter III up to 2013-Class	906	Air conditioning	PTC-Heater booster	√	√	√	√	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Information and communication	PTS-Parktronic system	√	√	√	√	ACT0098,ACT0099	×
Sprinter III/Sprinter III up to 2013-Class	906	Chassis	RDK Tire pressure monitor(Up to model year 2010)	√	√	√	√	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Chassis	RDK Tire pressure monitor(As of model year 2011)	√	√	√	√	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Body	SRS-supplemental restraint system	√	√	√	√	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Air conditioning	ZHE-Auxiliary heater	√	√	√	√	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Seats and Doors	STL-Left electric sliding door	√	√	√	√	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Seats and Doors	STR-Right electric sliding door	√	√	√	√	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Drive	VG-Transfer case	√	√	√	√	×	SP0079



Sprinter III/Sprinter III up to 2013-Class	906	Air conditioning	ZHZ-Heater booster	√	√	√	√	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Chassis	ENR-Electronic rear axle level control	√	√	√	√	ACT0006	SP0080,SP0081
Sprinter III/Sprinter III up to 2013-Class	906	Drive	SCR-Selective Catalytic Reduction	√	√	√	√	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Information and communication	RADIO Sound 5	√	√	√	×	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	√	√	√	√	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Information and communication	RADIO Sound 20	√	√	√	√	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Information and communication	COMAND or AUDIO	√	√	√	√	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Information and communication	SOUND 5NG	√	√	√	√	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Information and communication	NAVI-Navigation system (COMAND,SOUND 50)	√	√	√	√	×	×

Sprinter III/Sprinter III up to 2013-Class	906	Information and communication	CDW-CD changer	√	√	√	√	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Information and communication	TEL-Telephone control unit	√	√	√	√	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Information and communication	FSE Hands-free system (Bluetooth)	√	√	√	√	×	×
Sprinter III/Sprinter III up to 2013-Class	906	LIN Bus	PSM-Parameterizable Special Module	√	√	√	√	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Body	SRS-Supplemental restraint system(LowLine)As of production month 12/2011	√	√	√	√	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Drive	FSCU-Fuel pump	√	√	√	√	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Drive	ASG-Automatic gearshift system	√	√	√	√	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Drive	CDI4-Common Rail Diesel Injection	√	√	√	×	×	SP0046,SP0049, SP0051,SP0052, SP0044,SP0043, SP0026,SP0082
Vaneo-Class	414	Drive	ECM-Engine control monolith	√	√	√	√	×	×
Vaneo-Class	414	Chassis	ESP-Electronic stability program	√	√	√	√	×	×
Vaneo-Class	414	Information and communication	IC-Instrument cluster	√	√	√	√	×	×
Vaneo-Class	414	Body	ABW-Airbag with window airbag	√	√	√	√	×	×

Vaneo-Class	414	Body	DAS-Drive authorization system	√	√	√	√	×	×
Vaneo-Class	414	Seats and Doors	CL-Central locking control unit	√	√	√	√	×	×
Vaneo-Class	414	Air conditioning	HEAT/TAC-Automatic temperature control	√	√	√	√	×	×
Vaneo-Class	414	Body	ATA-Anti-theft alarm system	√	√	√	√	×	×
Vaneo-Class	414	Information and communication	PTS-Parktronic system	√	√	√	√	×	×
Vaneo-Class	414	Information and communication	Radio (SOUND series)	√	√	√	√	×	×
Vaneo-Class	414	Information and communication	AUDIO/APS-Auto pilot system	√	√	√	√	×	×
Vaneo-Class	414	Information and communication	COMAND	√	√	√	√	×	×
Vaneo-Class	414	Information and communication	CDC-CD changer	√	√	√	×	×	×
Vaneo-Class	414	Information and communication	CTEL-Cellular telephone 1 (fixed installation or portable)(D2B)	√	√	√	×	×	×
Vaneo-Class	414	Information and communication	UHI-Cellular telephone (fixed installation or portable)(D2B)	√	√	√	√	×	×
Vaneo-Class	414	Drive	ACS-Automatic clutch system	√	√	√	√	×	×
Vaneo-Class	414	Drive	FTC-Front transmission control	√	√	√	√	×	×
Vaneo-Class	414	Drive	FTC-Front transmission control	√	√	√	√	×	×
Vaneo-Class	414	Drive	ESM-Electronic selector module	√	√	√	√	×	×
Vaneo-Class	414	Drive	CDI-Common Rail Diesel Injection	√	√	√	√	×	×

## Actions

No.	Model Series	System Name
ACT0000	Dome lamp	OCP-Overhead control panel
ACT0001	Left front reading lamp	OCP-Overhead control panel
ACT0002	Right front reading lamp	OCP-Overhead control panel
ACT0003	Switch illumination	OCP-Overhead control panel
ACT0004	Sliding or tilting roof motor	OCP-Overhead control panel
ACT0005	EDW anti-theft alarm	OCP-Overhead control panel
ACT0006	A9/1ml (Air compressor motor)-A9/1yl (Air compressor pressure relief valve)-Y36 (Level control valve unit)	ENR-Electronic rear axle level control
ACT0007	S77/1 (ELC lock button)	ENR-Electronic rear axle level control
ACT0008	S77 (ELC raise/lower button)	ENR-Electronic rear axle level control
ACT0009	Forward/back adjustment	ESA driver-Electric seat adjustment driver (with memory)
ACT0010	Height at front	ESA driver-Electric seat adjustment driver (with memory)
ACT0011	Height at rear	ESA driver-Electric seat adjustment driver (with memory)
ACT0012	Backrest	ESA driver-Electric seat adjustment driver (with memory)
ACT0013	Head restraint	ESA driver-Electric seat adjustment driver (with memory)
ACT0014	Y62 (Fuel injection valves)	ME 97-Motor electronics 9.7
ACT0015	M16/5 (Throttle valve actuator)	ME 97-Motor electronics 9.7
ACT0016	M33 (Electric air pump)	ME 97-Motor electronics 9.7
ACT0017	M3/3 (Fuel pump with fuel level sensor)	ME 97-Motor electronics 9.7
ACT0018	Mixture adaptation	ME 97-Motor electronics 9.7
ACT0019	Y22/10 (Intake manifold switchover valve)	ME 97-Motor electronics 9.7
ACT0020	Y49/4 (Left intake camshaft positioner)	ME 97-Motor electronics 9.7
ACT0021	Y49/5 (Right intake camshaft positioner)	ME 97-Motor electronics 9.7
ACT0022	Y49/6 (Left exhaust camshaft positioner)	ME 97-Motor electronics 9.7
ACT0023	Y49/7 (Right exhaust camshaft positioner)	ME 97-Motor electronics 9.7
ACT0024	Y22/9 (Intake manifold tumble flap switchover valve)	ME 97-Motor electronics 9.7
ACT0025	Y58/12 (Purge control valve)	ME 97-Motor electronics 9.7
ACT0026	R48/1 (Thermostat)	ME 97-Motor electronics 9.7
ACT0027	G2/6 (Alternator)	ME 97-Motor electronics 9.7
ACT0028	Compression test	ME 97-Motor electronics 9.7
ACT0029	A1e17 (EOBD indicator lamp)	CDID2-Common Rail Diesel Injection
ACT0030	G2/7 (Alternator with LIN bus)	CDID2-Common Rail Diesel Injection
ACT0031	M3/5 (Fuel pump with fuel level sensor)	CDID2-Common Rail Diesel Injection
ACT0032	M16/45 (Throttle valve actuator)	CDID2-Common Rail Diesel Injection
ACT0033	R39/3 (Vent line heater element)	CDID2-Common Rail Diesel Injection

ACT0034	R48/2 (Thermostat heating element)	CDID2-Common Rail Diesel Injection
ACT0035	Y27/15 (Exhaust gas recirculation positioner)	CDID2-Common Rail Diesel Injection
ACT0036	Y77/6 (Boost pressure regulator)	CDID2-Common Rail Diesel Injection
ACT0037	Y127/1 (Oil spray nozzle valve)	CDID2-Common Rail Diesel Injection
ACT0038	Perform diagnostic glowing.	CDID2-Common Rail Diesel Injection
ACT0039	Injector shutoff	CDID2-Common Rail Diesel Injection
ACT0040	A27/2 (Viscous fan)	CDI6-Common Rail Diesel Injection
ACT0041	B85/3 (Oxygen sensor)	CDI6-Common Rail Diesel Injection
ACT0042	M16/48 (Throttle valve actuator)	CDI6-Common Rail Diesel Injection
ACT0043	R39/4 (Vent line heater element)	CDI6-Common Rail Diesel Injection
ACT0044	Y27/17 (Exhaust gas recirculation positioner)	CDI6-Common Rail Diesel Injection
ACT0045	Y77/8 (Boost pressure regulator)	CDI6-Common Rail Diesel Injection
ACT0046	Function test Positioning motors	ALWR-Headlamp range adjustment
ACT0047	Test of compression	CDI4-Common Rail Diesel Injection
ACT0048	Test of smooth running control	CDI4-Common Rail Diesel Injection
ACT0049	Test of high pressure pump	CDI4-Common Rail Diesel Injection
ACT0050	Check fuel high pressure system for rail pressure variations.	CDI4-Common Rail Diesel Injection
ACT0051	B2/7 (Hot film mass air flow sensor)	CDI4-Common Rail Diesel Injection
ACT0052	Actuation	CDI4-Common Rail Diesel Injection
ACT0053	M3/3ml (Fuel pump)	CDI4-Common Rail Diesel Injection
ACT0054	M16/42 (Throttle valve actuator)	CDI4-Common Rail Diesel Injection
ACT0055	M72 (Intake port shutoff actuator motor)	CDI4-Common Rail Diesel Injection
ACT0056	Y27/1 (Exhaust gas recirculation positioner)	CDI4-Common Rail Diesel Injection
ACT0057	Hysteresis	CDI4-Common Rail Diesel Injection
ACT0058	Test values at idle speed	CDI4-Common Rail Diesel Injection
ACT0059	Dynamic test	CDI4-Common Rail Diesel Injection
ACT0060	Y94/1 (Quantity control valve)	CDI4-Common Rail Diesel Injection
ACT0061	Programming of performance tuning	CDI4-Common Rail Diesel Injection
ACT0062	Check boost pressure control.	CDI3-Common Rail Diesel Injection
ACT0063	Indicator lamp 'MIL'	CDI60-Common Rail Diesel Injection(OM642 EPA13)
ACT0064	Fuel pump	CDI60-Common Rail Diesel Injection(OM642 EPA13)
ACT0065	Fuel filter heater	CDI60-Common Rail Diesel Injection(OM642 EPA13)
ACT0066	Inlet port shutoff	CDI60-Common Rail Diesel Injection(OM642 EPA13)
ACT0067	Throttle valve positioner	CDI60-Common Rail Diesel Injection(OM642 EPA13)
ACT0068	Boost pressure control flap	CDI60-Common Rail Diesel Injection(OM642 EPA13)
ACT0069	Exhaust gas recirculation valve	CDI60-Common Rail Diesel Injection(OM642 EPA13)

ACT0070	Glow output stage	CDI60-Common Rail Diesel Injection(OM642 EPA13)
ACT0071	Generator	CDI60-Common Rail Diesel Injection(OM642 EPA13)
ACT0072	Fan	CDI60-Common Rail Diesel Injection(OM642 EPA13)
ACT0073	Bypass flap 'Exhaust gas recirculation cooler'	CDI60-Common Rail Diesel Injection(OM642 EPA13)
ACT0074	Heating element of vent line 'Crankcase'	CDI60-Common Rail Diesel Injection(OM642 EPA13)
ACT0075	Side lamp	SAM-Signal acquisition and actuation module
ACT0076	Low beam	SAM-Signal acquisition and actuation module
ACT0077	Main beam	SAM-Signal acquisition and actuation module
ACT0078	Fog light	SAM-Signal acquisition and actuation module
ACT0079	Turning lamps	SAM-Signal acquisition and actuation module
ACT0080	Rear lamps	SAM-Signal acquisition and actuation module
ACT0081	Body outline lights	SAM-Signal acquisition and actuation module
ACT0082	Side-marker lamps	SAM-Signal acquisition and actuation module
ACT0083	Turn signals	SAM-Signal acquisition and actuation module
ACT0084	Interior lamp	SAM-Signal acquisition and actuation module
ACT0085	Electric vent windows	SAM-Signal acquisition and actuation module
ACT0086	Audible warning device	SAM-Signal acquisition and actuation module
ACT0087	Windscreen wipers, wash systems	SAM-Signal acquisition and actuation module
ACT0088	Passenger door	SAM-Signal acquisition and actuation module
ACT0089	Rear-end doors	SAM-Signal acquisition and actuation module
ACT0090	Front passenger door power window	SAM-Signal acquisition and actuation module
ACT0091	Relay 'Circuits'	SAM-Signal acquisition and actuation module
ACT0092	M2/2x1 (Control module box blower motor connector)	SAM-Signal acquisition and actuation module
ACT0093	Switch on left front reading lamp.	DBE-Overhead control panel
ACT0094	Switch on right front reading lamp.	DBE-Overhead control panel
ACT0095	Switch on switch lighting.	DBE-Overhead control panel
ACT0096	Actuate tilting/sliding roof.	DBE-Overhead control panel
ACT0097	Arm anti-theft alarm system.	DBE-Overhead control panel
ACT0098	Warning elements	PTS-Parktronic system
ACT0099	Test function lighting of component N72/1s9 (PTS OFF button) by operating.	PTS-Parktronic system
ACT0100	A9/1m1 (空气压缩机马达) -A9/1y1 (空气压缩机减压阀) -Y36 (水平高度控制阀门单元)	电子后轴水平高度调节(ENR)

## Special Function

No.	Model Series	System Name
SP0000	Regeneration of the diesel particulate filter while driving	CDI-Engine electronics 'CR41' for internal combustion engine 'OM651'
SP0001	Teach in diesel particulate filter again.	CDI-Engine electronics 'CR41R' for internal combustion engine 'OM622'
SP0002	Teach in used diesel particulate filter.	CDI-Engine electronics 'CR41R' for internal combustion engine 'OM622'
SP0003	Resetting of learned values of component ''B28/8 (DPF differential pressure sensor)''	CDI-Engine electronics 'CR41R' for internal combustion engine 'OM622'
SP0004	Component B24/8 (Steering angle sensor):Perform calibration.	ESP-Electronic stability program
SP0005	Component B24/15 (Yaw rate, lateral and longitudinal acceleration sensor):Perform calibration.	ESP-Electronic stability program
SP0006	Normalizing routine/Learning process	OCP-Overhead control panel
SP0007	Initialization of system 'EDW anti-theft alarm'	OCP-Overhead control panel
SP0008	Adapt obstruction protection.	SDE-H-Rear sliding roof unit
SP0009	Coding of sliding/tilting roof function of 'automatic operation'	SDE-H-Rear sliding roof unit
SP0010	Perform normalizing of component A32/2m3 (Rear blending air flap actuator motor).	REAR AC-Rear air conditioning
SP0011	Normalizing of positioning motors	AAC-Automatic air conditioning
SP0012	Normalizing	STE-R-ESD [STE] Right electric sliding door
SP0013	Detection of sliding movement	STE-R-ESD [STE] Right electric sliding door
SP0014	Denormalization	STE-R-ESD [STE] Right electric sliding door
SP0015	Level calibration	ENR-Electronic rear axle level control
SP0016	Normalizing of forward/back adjustment	ESA driver-Electric seat adjustment driver (with memory)
SP0017	Normalizing of height adjustment at front	ESA driver-Electric seat adjustment driver (with memory)
SP0018	Normalizing of height adjustment at rear	ESA driver-Electric seat adjustment driver (with memory)
SP0019	Normalizing of head restraint adjustment	ESA driver-Electric seat adjustment driver (with memory)
SP0020	Normalizing of backrest adjustment	ESA driver-Electric seat adjustment driver (with memory)
SP0021	Learning of the throttle valve stop	ME 97-Motor electronics 9.7
SP0022	Drive authorization system	ME 97-Motor electronics 9.7
SP0023	Reset adaptation values.	ME 97-Motor electronics 9.7
SP0024	Learning processes	ME 97-Motor electronics 9.7

SP0025	Activate drive authorization system.	CDID2-Common Rail Diesel Injection
SP0026	Maximum vehicle speed limit	CDID2-Common Rail Diesel Injection
SP0027	Resetting the lambda values	CDID2-Common Rail Diesel Injection
SP0028	Activate fuel pump.	CDID2-Common Rail Diesel Injection
SP0029	Teach in component Charge pressure positioner.	CDID2-Common Rail Diesel Injection
SP0030	Reset fill factor of air filter.	CDID2-Common Rail Diesel Injection
SP0031	Teach in component Glow output stage.	CDID2-Common Rail Diesel Injection
SP0032	Write VIN.	CDID2-Common Rail Diesel Injection
SP0033	Quick teach-in of the zero quantity calibration values at idle	CDID2-Common Rail Diesel Injection
SP0034	Quick teach-in of the zero quantity calibration values while driving	CDID2-Common Rail Diesel Injection
SP0035	Teach in new diesel particulate filter.	CDI6-Common Rail Diesel Injection
SP0036	Teach in component Differential pressure sensor.	CDI6-Common Rail Diesel Injection
SP0037	Exhaust gas recirculation valve teach-in	CDI6-Common Rail Diesel Injection
SP0038	Teach in component Pressure control valve.	CDI6-Common Rail Diesel Injection
SP0039	Reset quantity mean value adaptation data.	CDI6-Common Rail Diesel Injection
SP0040	Reset values for HFM drift compensation.	CDI6-Common Rail Diesel Injection
SP0041	Resetting the adaptation values	CDI6-Common Rail Diesel Injection
SP0042	Teach in component Diesel oxidation catalytic converter.	CDI6-Common Rail Diesel Injection
SP0043	Regeneration of diesel particulate filter when driving	CDI6-Common Rail Diesel Injection
SP0044	Regeneration of diesel particulate filter	CDI6-Common Rail Diesel Injection
SP0045	Reset warning message 'SCR'.	CDI6-Common Rail Diesel Injection
SP0046	Drive authorization	CDI4-Common Rail Diesel Injection
SP0047	Initialization of system 'Air filter'	CDI4-Common Rail Diesel Injection
SP0048	Initialization of system 'Throttle valve positioner'	CDI4-Common Rail Diesel Injection
SP0049	Initialization of system 'Air intake, turbocharging'	CDI4-Common Rail Diesel Injection
SP0050	Initialization of system 'Common Rail'	CDI4-Common Rail Diesel Injection
SP0051	Initialization of system 'Catalytic converter'	CDI4-Common Rail Diesel Injection
SP0052	Initialization of system 'Diesel particulate filter'	CDI4-Common Rail Diesel Injection
SP0053	Limit valuesWorking speed control	CDI3-Common Rail Diesel Injection
SP0054	Resetting the wear values of component 'Hot film mass air flow sensor'	CDI60-Common Rail Diesel Injection(OM642 EPA13)
SP0055	Teach in component Y130 (AdBlue(R) injection valve).	CDI60-Common Rail Diesel Injection(OM642 EPA13)



SP0056	Initialize system 'SCR'.	CDI60-Common Rail Diesel Injection(OM642 EPA13)
SP0057	Teach in component SCR catalytic converter.	CDI60-Common Rail Diesel Injection(OM642 EPA13)
SP0058	Teach in component B16/12 (Temperature sensor upstream of SCR catalytic converter).	CDI60-Common Rail Diesel Injection(OM642 EPA13)
SP0059	Teach-in process after replacement of component Diesel particulate filter	CDI60-Common Rail Diesel Injection(OM642 EPA13)
SP0060	Teaching in the diesel particulate filter after replacing the engine control unit	CDI60-Common Rail Diesel Injection(OM642 EPA13)
SP0061	Detach transport protection.	CDI60-Common Rail Diesel Injection(OM642 EPA13)
SP0062	Personalizing	CDI60-Common Rail Diesel Injection(OM642 EPA13)
SP0063	Activate control module CDI.	CDI60-Common Rail Diesel Injection(OM642 EPA13)
SP0064	Initialize component Hot film mass air flow sensor.	CDI4-Common Rail Diesel Injection
SP0065	Teach in component Throttle valve.	CDI4-Common Rail Diesel Injection
SP0066	Initialize system 'Rail pressure regulation'.	CDI4-Common Rail Diesel Injection
SP0067	Perform normalizing of component Sliding/tilting roof.	DBE-Overhead control panel
SP0068	Perform denormalization of component Sliding/tilting roof.	DBE-Overhead control panel
SP0069	Delete denormalization causes.	DBE-Overhead control panel
SP0070	Inversion of rotation direction	DBE-Overhead control panel
SP0071	Reset alarm sources.	DBE-Overhead control panel
SP0072	Teach in component Battery-operated horn.	DBE-Overhead control panel
SP0073	Teach in component Rain/light sensor.	DBE-Overhead control panel
SP0074	Function 'Silent alarm'	DBE-Overhead control panel
SP0075	Calibration of component B24/15 (Yaw rate, lateral and longitudinal acceleration sensor)	ESP-Electronic stability program
SP0076	Component Sensor 'Yaw rate, lateral and longitudinal acceleration':Perform calibration.	ESP9-Electronic stability program
SP0077	Component B37 (Pedal travel sensor):Perform calibration.	ESP9-Electronic stability program
SP0078	Teach in actuator motors.	KLA-Automatic air conditioning
SP0079	Exchange transfer case.	VG-Transfer case
SP0080	Initialize component A9/1ml (Air compressor motor).	ENR-Electronic rear axle level control
SP0081	Initialize component Y36y2 (Right rear level control valve).	ENR-Electronic rear axle level control
SP0082	Idle speed adjustment(800 l/min)	CDI4-Common Rail Diesel Injection