



# Shenzhen Xtooltech Co., Ltd.

## Transporter Function List V18.80

NOTES:

√ This function is supported.

\* This function is new added.

Model	Model Series	Control Unit Groups	System Name	Read ECU Informati	Read Trouble Code	Clear Troubl e Code	Live Data	Read Freeze Frame	Actuation Test	Special Functions
V/Vito/Meris-Class	447	Body	EZS-Electronic ignition switch	√	√	√	√	×	×	×
V/Vito/Meris-Class	447	Information and communication	KI-dash board	√	√	√	√	×	×	×
V/Vito/Meris-Class	447	Information and communication	KOMO-Telematics module	√	√	√	√	×	×	×
V/Vito/Meris-Class	447	Information and communication	HERMES-Telematics module	√	√	√	√	×	×	×
V/Vito/Meris-Class	447	Information and communication	E-Call-RU-eCall, Russia (GLONASS)	√	√	√	√	×	×	×
V/Vito/Meris-Class	447	Seats and Doors	SIH/SIB-HL 2-Rear left row of second seat air conditioning seat	√	√	√	√	×	×	×
V/Vito/Meris-Class	447	Body	MRM-Steering column module	√	√	√	√	×	×	×
V/Vito/Meris-Class	447	Seats and Doors	SIH/SIB-HR 2-Rear row of second-row seat air-conditioned seats on the right	√	√	√	√	×	×	×
V/Vito/Meris-Class	447	Chassis	ESP-Electronic stability program	√	√	√	√	×	×	×
V/Vito/Meris-Class	447	Chassis	ESP-Electronic stability program	√	√	√	√	×	×	×
V/Vito/Meris-Class	447	Information and communication	NAV-Navigation System	√	√	√	√	×	×	×
V/Vito/Meris-Class	447	Information and communication	TPAD-Touch pad	√	√	√	√	×	×	×
V/Vito/Meris-Class	447	Information and communication	TPAD-Touchpad	√	√	√	√	×	×	×

V/Vito/Metris-Class	447	Information and communication	RD-Radio (Audio / Cab Management and Data Systems)	√	√	√	√	×	×	×
V/Vito/Metris-Class	447	Information and communication	Audio-Audio or COMAND	√	√	√	√	×	×	×
V/Vito/Metris-Class	447	Information and communication	A26/17 - MBUX multimedia system (host, code: E2Y, E2Z) (HU6)	√	√	√	×	×	×	×
V/Vito/Metris-Class	447	Information and communication	ZBE-Audio / Cab Management and Data System (COMAND) operating unit	√	√	√	√	×	×	×
V/Vito/Metris-Class	447	Information and communication	ZAN-Audio/COMAND display	√	√	√	√	×	×	×
V/Vito/Metris-Class	447	Information and communication	ZAN-Audio / Cab Management and Data System (COMAND) display	√	√	√	√	×	×	×
V/Vito/Metris-Class	447	Information and communication	UHI-Cellular telephone (fixed installation or portable) (D2B)	√	√	√	√	×	×	×
V/Vito/Metris-Class	447	Information and communication	KI-dash board	√	√	√	√	×	×	×
V/Vito/Metris-Class	447	Chassis	RDK-Tire pressure monitor	√	√	√	√	×	×	×
V/Vito/Metris-Class	447	Body	EDW-Burglar alarm system	√	√	√	√	×	×	×
V/Vito/Metris-Class	447	Driver assistance system	RFK-Backup camera	√	√	√	√	×	×	×
V/Vito/Metris-Class	447	Information and communication	RFK-Reversing camera	√	√	√	√	×	×	×
V/Vito/Metris-Class	447	Information and communication	CAMERA-Control unit '360 ?camera'	√	√	√	√	×	×	×
V/Vito/Metris-Class	447	Body	SRS-Supplemental restraint system	√	√	√	√	×	×	×
V/Vito/Metris-Class	447	Body	SRS-Supplemental restraint system	√	√	√	×	×	×	×
V/Vito/Metris-Class	447	Body	SOGESTAR2-Sound generator for electric vehicle	√	√	√	√	×	×	×
V/Vito/Metris-Class	447	Information and communication	RD-radio	√	√	√	√	×	×	×
V/Vito/Metris-Class	447	Information and communication	Audio-Audio or COMAND	√	√	√	×	×	×	×
V/Vito/Metris-Class	447	Information and communication	SG-AWF-Control unit 'crash-aid system'	√	√	√	√	×	×	×
V/Vito/Metris-Class	447	Driver assistance system	SG AWF-COLLISION PREVENTION ASSIST	√	√	√	×	×	×	×

V/Vito/Metris-Class	447	Body	DC Charging Connection Unit (DCCU)	√	√	√	√	×	×	×
V/Vito/Metris-Class	447	Drive	SG EM-Power electronics	√	√	√	√	×	×	×
V/Vito/Metris-Class	447	Body	SG LG-Charger	√	√	√	√	×	×	×
V/Vito/Metris-Class	447	Body	SG LG-Charger	√	√	√	×	×	×	×
V/Vito/Metris-Class	447	Body	DC/DC-DC/DC converter	√	√	√	√	×	×	×
V/Vito/Metris-Class	447	Body	SG BMS-Battery management system control unit	√	√	√	×	×	×	×
V/Vito/Metris-Class	447	Information and communication	IRS-HRA-Right rear external intelligent radar range sensor	√	√	√	√	×	×	×
V/Vito/Metris-Class	447	Driver assistance system	AB-Airbag	√	√	√	×	×	×	×
V/Vito/Metris-Class	447	Body	MF-HL-Rear row of the first row of seats on the left massage function control	√	√	√	√	×	×	×
V/Vito/Metris-Class	447	Information and communication	IRS-HLA-Left rear external smart radar range sensor	√	√	√	√	×	×	×
V/Vito/Metris-Class	447	Driver assistance system	ACS-Automatic clutch system	√	√	√	×	×	×	×
V/Vito/Metris-Class	447	Body	MF-HR-Rear row of massage function on the right side of the first row seat control	√	√	√	√	×	×	×
V/Vito/Metris-Class	447	Body	PSM-Parameterizable Special Module	√	√	√	√	×	×	×
V/Vito/Metris-Class	447	Chassis	ADS-Adaptive damping system(N51/5)	√	√	√	×	×	×	×
V/Vito/Metris-Class	447	Driver assistance system	N74 (operator panel control unit for driver assistance systems)	√	√	√	√	×	×	×
V/Vito/Metris-Class	447	Information and communication	MFK-Multi-function camera (monocular)	√	√	√	√	×	×	×
V/Vito/Metris-Class	447	Air conditioning	KLA-air conditioning	√	√	√	√	×	×	×
V/Vito/Metris-Class	447	Driver assistance system	N32/4 Right front seat heating	√	√	√	√	×	×	×
V/Vito/Metris-Class	447	Driver assistance system	N32/2 Heated front left seat	√	√	√	√	×	×	×
V/Vito/Metris-Class	447	Seats and Doors	S47/2 (driver's door switch module)	√	√	√	×	×	×	×

V/Vito/Meris-Class	447	Seats and Doors	S22 (driver's side door seat adjustment switch)	√	√	√	×	×	×	×
V/Vito/Meris-Class	447	Seats and Doors	Intelligent climate control switch group for driver's seat (S51/1)	√	√	√	×	×	×	×
V/Vito/Meris-Class	447	Seats and Doors	S47/3 (door switch module on front passenger side)	√	√	√	×	×	×	×
V/Vito/Meris-Class	447	Seats and Doors	S23 (door seat adjustment switch on front passenger side)	√	√	√	×	×	×	×
V/Vito/Meris-Class	447	Seats and Doors	S51/2 (Front passenger side door seat heater switch)	√	√	√	×	×	×	×
V/Vito/Meris-Class	447	Body	SOGESTAR2-Sound generator for electric vehicle	√	√	√	√	×	×	×
V/Vito/Meris-Class	447	Chassis	ES-Electric power steering	√	√	√	√	×	×	×
V/Vito/Meris-Class	447	Body	SD-'Panoramic sliding sunroof' control module	√	√	√	√	×	×	×
V/Vito/Meris-Class	447	Body	S98/2 (rear heater/air conditioner operating unit switch)	√	√	√	×	×	×	×
V/Vito/Meris-Class	447	Body	S98/1 (Front heater/air conditioner operating unit switch)	√	√	√	×	×	×	×
V/Vito/Meris-Class	447	Body	TSTH-Radio remote control of stationary heater	√	√	√	√	×	×	×
V/Vito/Meris-Class	447	Body	STH-Stationary heater	√	√	√	×	×	×	×
V/Vito/Meris-Class	447	Air conditioning	STH-Stationary heater	√	√	√	×	×	×	×
V/Vito/Meris-Class	447	Body	RevGUS-VL-Left front adaptive belt tensioner	√	√	√	√	×	×	×
V/Vito/Meris-Class	447	Body	OBF-Upper control panel	√	√	√	×	×	×	×
V/Vito/Meris-Class	447	Body	A40/1 (lower left control panel (UBFL) control unit)	√	√	√	×	×	×	×
V/Vito/Meris-Class	447	Body	A40/2 (right lower control panel (UBFR) control unit)	√	√	√	×	×	×	×
V/Vito/Meris-Class	447	Body	RevGUS-VR-Right front adaptive seat belt tensioner	√	√	√	√	×	×	×
V/Vito/Meris-Class	447	Seats and Doors	ESE-Driver's seat adjustment	√	√	√	√	×	×	×
V/Vito/Meris-Class	447	Seats and Doors	ESE-'Front passenger' electric seat adjustment	√	√	√	√	×	×	×

V/Vito/Meris-Class	447	Body	N175/1 - Expansion Module 3 for Mercedes-Benz Advanced Controller (EM-1-MBAC)	√	√	√	×	×	×	×
V/Vito/Meris-Class	447	Drive	ISM-Intelligent servo module	√	√	√	√	×	×	×
V/Vito/Meris-Class	447	Body	AAG-Trailer identification device	√	√	√	√	×	×	×
V/Vito/Meris-Class	447	Body	SAM-Signal acquisition and actuation control module	√	√	√	√	×	×	×
V/Vito/Meris-Class	447	Body	DBE-Roof control panel	√	√	√	√	×	×	×
V/Vito/Meris-Class	447	Information and communication	DTR-Limit control system	√	√	√	√	×	×	×
V/Vito/Meris-Class	447	Seats and Doors	DCM-FL-Door control module front left	√	√	√	√	×	×	×
V/Vito/Meris-Class	447	Seats and Doors	DCM-FR-Door control module front right	√	√	√	√	×	×	×
V/Vito/Meris-Class	447	Information and communication	TV-TV tuner	√	√	√	√	×	×	×
V/Vito/Meris-Class	447	Information and communication	CDI60-Common Rail Diesel Injection (OM642 EPA13)	√	√	√	×	×	×	×
V/Vito/Meris-Class	447	Information and communication	SOUND-sound system	√	√	√	√	×	×	×
V/Vito/Meris-Class	447	Information and communication	SOUND-Sound system	√	√	√	√	×	×	×
V/Vito/Meris-Class	447	Seats and Doors	STL-Left electric sliding door	√	√	√	√	×	×	×
V/Vito/Meris-Class	447	Information and communication	DAB-Digital Audio Broadcasting	√	√	√	√	×	×	×
V/Vito/Meris-Class	447	Seats and Doors	STR-Right electric sliding door	√	√	√	√	×	×	×
V/Vito/Meris-Class	447	Body	SK-HR-Rear row of seats on the right side of the seat cushion control	√	√	√	√	×	×	×
V/Vito/Meris-Class	447	Chassis	EFB-Electric parking activator	√	√	√	√	×	×	×
V/Vito/Meris-Class	447	Driver assistance system	RFK-Backup camera	√	√	√	×	×	×	×
V/Vito/Meris-Class	447	Information and communication	RFK-Reversing camera	√	√	√	√	×	×	×
V/Vito/Meris-Class	447	Body	HMI-GW-Human Interface Gateway	√	√	√	√	×	×	×

V/Vito/Meris-Class	447	Body	WSS-Weight sensing system	✓	✓	✓	✓	×	×	×
V/Vito/Meris-Class	447	Body	BSN-Battery sensor	✓	✓	✓	×	×	×	×
V/Vito/Meris-Class	447	Body	DBE-Roof control panel	✓	✓	✓	✓	×	×	×
V/Vito/Meris-Class	447	Body	SG-SW-L-Left headlight	✓	✓	✓	✓	×	×	×
V/Vito/Meris-Class	447	Body	SG-SW-R-Right headlight	✓	✓	✓	✓	×	×	×
V/Vito/Meris-Class	447	Body	SG BMS-Battery management system control unit	✓	✓	✓	×	×	×	×
V/Vito/Meris-Class	447	Body	OCP-Control unit 'Overhead control panel'	✓	✓	✓	×	×	×	×
V/Vito/Meris-Class	447	Body	RGLS-Rain/light sensor	✓	✓	✓	✓	×	×	×
V/Vito/Meris-Class	447	Body	RGLS-Rain/light sensor	✓	✓	✓	×	×	×	×
V/Vito/Meris-Class	447	Driver assistance system	AISP-Dimming inside rearview mirror	✓	✓	✓	✓	×	×	×
V/Vito/Meris-Class	447	Information and communication	PTS-Parktronic system	✓	✓	✓	✓	×	×	×
V/Vito/Meris-Class	447	Body	SG BMS-Battery management system control unit	✓	✓	✓	×	×	×	×
V/Vito/Meris-Class	447	Information and communication	DTCO-Digital tachograph	✓	✓	✓	✓	×	×	×
V/Vito/Meris-Class	447	Information and communication	DTCO-Digital tachograph	✓	✓	✓	×	×	×	×
V/Vito/Meris-Class	447	Information and communication	DTCO-Digital tachograph	✓	✓	✓	×	×	×	×
V/Vito/Meris-Class	447	Chassis	N135 (Steering wheel electronics) (LRE)	✓	✓	✓	×	×	×	×
V/Vito/Meris-Class	447	Body	SK-HL-Rear row of seats on the left air cushion control	✓	✓	✓	✓	×	×	×
V/Vito/Meris-Class	447	Body	N175/2 - Expansion Module 3 for Mercedes-Benz Advanced Controller (EM-2-MBAC)	✓	✓	✓	✓	×	×	×
V/Vito/Meris-Class	447	Seats and Doors	SIH/SIB-HL 1-Rear left row of first seat air conditioning seat	✓	✓	✓	✓	×	×	×
V/Vito/Meris-Class	447	Body	N175/3 - Expansion Module 3 for Mercedes-Benz Advanced Controller (EM-3-MBAC)	✓	✓	✓	✓	×	×	×

V/Vito/Meris-Class	447	Body	AS-Alarm siren	√	√	√	√	×	×	×
V/Vito/Meris-Class	447	Body	ATA-ATA[EDW]/tow-away protection/interior protection	√	√	√	×	×	×	×
V/Vito/Meris-Class	447	Body	ATA-ATA[EDW]/tow-away protection/interior protection	√	√	√	×	×	×	×
V/Vito/Meris-Class	447	Seats and Doors	SIH/SIB-HR 1-Rear row of seats on the right hand side seat air conditioning	√	√	√	√	×	×	×
V/Vito/Meris-Class	447	Information and communication	KAB-Control unit 'camera guard'	√	√	√	√	×	×	×
V/Vito/Meris-Class	447	Driver assistance system	E1/ln7 (Left front LED exterior lighting actuator module)	√	√	√	√	×	×	×
V/Vito/Meris-Class	447	Driver assistance system	E2/ln7 (right front LED exterior lighting actuator module)	√	√	√	√	×	×	×
V/Vito/Meris-Class	447	Drive	CDI-Engine electronics 'CR41' for internal combustion engine 'OM651'	√	√	√	√	×	×	SP0000
V/Vito/Meris-Class	447	Drive	CDI-Engine electronics 'CR41R' for internal combustion engine 'OM622'	√	√	√	√	×	×	SP0001, SP0002, SP0003, SP0000
V/Vito/Meris-Class	447	Drive	CDI-Motor electronics	√	√	√	×	×	×	×
V/Vito/Meris-Class	447	Drive	ME-Engine electronics 'ME40' for internal combustion engine 'M274'	√	√	√	√	×	×	×
V/Vito/Meris-Class	447	Drive	CDI-Motor electronics	√	√	√	×	×	×	×
V/Vito/Meris-Class	447	Drive	CDI-Motor electronics	√	√	√	×	×	×	×
V/Vito/Meris-Class	447	Drive	VGS-Start clutch oil pressure sensor	√	√	√	√	×	×	×
V/Vito/Meris-Class	447	Drive	Transmission control	√	√	√	×	×	×	×
V/Vito/Meris-Class	447	Drive	Transmission control	√	√	√	×	×	×	×
V/Vito/Meris-Class	447	Drive	FSCU-Fuel system control unit	√	√	√	√	×	×	×
V/Vito/Meris-Class	447	Drive	FSCU01-Control unit Fuel pump	√	√	√	√	×	×	×
V/Vito/Meris-Class	447	Drive	SCR-Selective Catalytic Reduction	√	√	√	√	×	×	×
V/Vito/Meris-Class	447	Drive	SCR-Selective catalytic reduction	√	√	√	√	×	×	×

V/Vito/Metris-Class	447	Drive	SCR-Selective catalytic reduction	√	√	√	×	×	×	×
V/Vito/Metris-Class	447	Drive	N127 (Drivetrain control unit)	√	√	√	√	×	×	×
V/Vito/Metris-Class	447	Drive	N127 (Drivetrain control unit)	√	√	√	√	×	×	×
V/Vito/Metris-Class	447	Drive	N127 (Drivetrain control unit)	√	√	√	×	×	×	×
V/Vito/Metris-Class	447	Body	BMS-Battery management system	√	√	√	×	×	×	×
V/Vito/Metris-Class	447	Body	SG BMS-Battery management system control unit	√	√	√	×	×	×	×
V/Vito/Metris-Class	447	Body	SG BMS-Battery management system control unit	√	√	√	×	×	×	×
V/Vito/Metris-Class	447	Body	N175 - Expansion module 3 for Mercedes-Benz Advanced Controller (MBAC)	√	√	√	√	×	×	×
V/Vito/Metris-Class	447	Body	N26/25 - On-board logic unit (OLU)	√	√	√	×	×	×	×
V/Vito-Class	448	Body	EZS-Electronic ignition switch	√	√	√	√	×	×	×
V/Vito-Class	448	Drive	CDI-Engine electronics 'CR41' for internal combustion engine 'OM651'	√	√	√	√	×	×	SP0000
V/Vito-Class	448	Drive	CDI-Engine electronics 'CR41R' for internal combustion engine 'OM622'	√	√	√	√	×	×	SP0001, SP0002, SP0003, SP0000
V/Vito-Class	448	Drive	ME-Engine electronics 'ME40' for internal combustion engine 'M274'	√	√	√	√	×	×	×
V/Vito-Class	448	Drive	VGS-Start clutch oil pressure sensor	√	√	√	√	×	×	×
V/Vito-Class	448	Chassis	ESP-Electronic stability program	√	√	√	√	×	×	×
V/Vito-Class	448	Body	SRS-Supplemental restraint system	√	√	√	√	×	×	×
V/Vito-Class	448	Chassis	ES-Electric power steering	√	√	√	√	×	×	×
V/Vito-Class	448	Drive	ISM-Intelligent servo module	√	√	√	√	×	×	×
V/Vito-Class	448	Drive	FSCU-Fuel system control unit	√	√	√	√	×	×	×
V/Vito-Class	448	Drive	SCR-Selective Catalytic Reduction	√	√	√	√	×	×	×

V/Vito-Class	448	Chassis	RDK-Tire pressure monitor	√	√	√	√	×	×	×
V/Vito-Class	448	Body	SAM-Signal acquisition and actuation control module	√	√	√	√	×	×	×
V/Vito-Class	448	Body	OCP-Control unit 'Overhead control panel'	√	√	√	×	×	×	×
V/Vito-Class	448	Body	BSN-Battery sensor	√	√	√	×	×	×	×
V/Vito-Class	448	Body	RGLS-Rain/light sensor	√	√	√	√	×	×	×
V/Vito-Class	448	Body	DBE-Roof control panel	√	√	√	√	×	×	×
V/Vito-Class	448	Driver assistance system	N74 (operator panel control unit for driver assistance systems)	√	√	√	√	×	×	×
V/Vito-Class	448	Driver assistance system	N32/2 Heated front left seat	√	√	√	√	×	×	×
V/Vito-Class	448	Driver assistance system	N32/4 Right front seat heating	√	√	√	√	×	×	×
V/Vito-Class	448	Driver assistance system	AISP-Dimming inside rearview mirror	√	√	√	√	×	×	×
V/Vito-Class	448	Body	SG-SW-L-Left headlight	√	√	√	√	×	×	×
V/Vito-Class	448	Driver assistance system	E1/1n7 (Left front LED exterior lighting actuator module)	√	√	√	√	×	×	×
V/Vito-Class	448	Body	SG-SW-R-Right headlight	√	√	√	√	×	×	×
V/Vito-Class	448	Driver assistance system	E2/1n7 (right front LED exterior lighting actuator module)	√	√	√	√	×	×	×
V/Vito-Class	448	Body	PSM-Parameterizable Special Module	√	√	√	√	×	×	×
V/Vito-Class	448	Body	DBE-Roof control panel	√	√	√	√	×	×	×
V/Vito-Class	448	Body	WSS-Weight sensing system	√	√	√	√	×	×	×
V/Vito-Class	448	Body	RevGUS-VL-Left front adaptive belt tensioner	√	√	√	√	×	×	×
V/Vito-Class	448	Body	RevGUS-VR-Right front adaptive seat belt tensioner	√	√	√	√	×	×	×
V/Vito-Class	448	Body	MRM-Steering column module	√	√	√	√	×	×	×

V/Vito-Class	448	Chassis	N135 (Steering wheel electronics) (LRE)	√	√	√	×	×	×	×
V/Vito-Class	448	Body	EDW-Burglar alarm system	√	√	√	√	×	×	×
V/Vito-Class	448	Body	AS-Alarm siren	√	√	√	√	×	×	×
V/Vito-Class	448	Body	MF-HR-Rear row of massage function on the right side of the first row seat control	√	√	√	√	×	×	×
V/Vito-Class	448	Body	SK-HR-Rear row of seats on the right side of the seat cushion control	√	√	√	√	×	×	×
V/Vito-Class	448	Body	MF-HL-Rear row of the first row of seats on the left massage function control	√	√	√	√	×	×	×
V/Vito-Class	448	Body	SK-HL-Rear row of seats on the left air cushion control	√	√	√	√	×	×	×
V/Vito-Class	448	Body	SD-'Panoramic sliding sunroof' control module	√	√	√	√	×	×	×
V/Vito-Class	448	Information and communication	KOMO-Telematics module	√	√	√	√	×	×	×
V/Vito-Class	448	Information and communication	HERMES-Telematics module	√	√	√	√	×	×	×
V/Vito-Class	448	Information and communication	RD-radio	√	√	√	√	×	×	×
V/Vito-Class	448	Information and communication	KAB-Control unit 'camera guard'	√	√	√	√	×	×	×
V/Vito-Class	448	Information and communication	SG-AWF-Control unit 'crash-aid system'	√	√	√	√	×	×	×
V/Vito-Class	448	Information and communication	IRS-HRA-Right rear external intelligent radar range sensor	√	√	√	√	×	×	×
V/Vito-Class	448	Information and communication	IRS-HLA-Left rear external smart radar range sensor	√	√	√	√	×	×	×
V/Vito-Class	448	Information and communication	KI-dash board	√	√	√	√	×	×	×
V/Vito-Class	448	Information and communication	KI-dash board	√	√	√	√	×	×	×
V/Vito-Class	448	Information and communication	NAV-Navigation System	√	√	√	√	×	×	×

V/Vito-Class	448	Information and communication	PTS-Parktronic system	√	√	√	√	×	×	×
V/Vito-Class	448	Information and communication	RFK-Reversing camera	√	√	√	√	×	×	×
V/Vito-Class	448	Information and communication	MFK-Multi-function camera (monocular)	√	√	√	√	×	×	×
V/Vito-Class	448	Seats and Doors	DCM-FL-Door control module front left	√	√	√	√	×	×	×
V/Vito-Class	448	Seats and Doors	DCM-FR-Door control module front right	√	√	√	√	×	×	×
V/Vito-Class	448	Seats and Doors	STL-Left electric sliding door	√	√	√	√	×	×	×
V/Vito-Class	448	Seats and Doors	STR-Right electric sliding door	√	√	√	√	×	×	×
V/Vito-Class	448	Seats and Doors	ESE-Driver's seat adjustment	√	√	√	√	×	×	×
V/Vito-Class	448	Seats and Doors	ESE-'Front passenger' electric seat adjustment	√	√	√	√	×	×	×
V/Vito-Class	448	Seats and Doors	SIH/SIB-HL 1-Rear left row of first seat air conditioning seat	√	√	√	√	×	×	×
V/Vito-Class	448	Seats and Doors	SIH/SIB-HR 1-Rear row of seats on the right hand side seat air conditioning	√	√	√	√	×	×	×
V/Vito-Class	448	Air conditioning	KLA-air conditioning	√	√	√	√	×	×	×
V/Vito-Class	448	Body	STH-Stationary heater	√	√	√	×	×	×	×
V/Vito-Class	448	Body	TSTH-Radio remote control of stationary heater	√	√	√	√	×	×	×
V/Vito-Class	448	Chassis	EFB-Electric parking activator	√	√	√	√	×	×	×
V/Vito-Class	448	Body	HMI-GW-Human Interface Gateway	√	√	√	√	×	×	×
V/Vito-Class	448	Information and communication	ZBE-Audio / Cab Management and Data System (COMAND) operating unit	√	√	√	√	×	×	×
V/Vito-Class	448	Body	OBF-Upper control panel	√	√	√	×	×	×	×

V/Vito-Class	448	Body	A40/1 (lower left control panel (UBFL) control unit)	√	√	√	×	×	×	×
V/Vito-Class	448	Body	A40/2 (right lower control panel (UBFR) control unit)	√	√	√	×	×	×	×
V/Vito-Class	448	Information and communication	ZAN-Audio / Cab Management and Data System (COMAND) display	√	√	√	√	×	×	×
V/Vito-Class	448	Information and communication	DTR-Limit control system	√	√	√	√	×	×	×
V/Vito-Class	448	Information and communication	RD-Radio (Audio / Cab Management and Data Systems)	√	√	√	√	×	×	×
V/Vito-Class	448	Information and communication	CAMERA-Control unit '360 ?camera'	√	√	√	√	×	×	×
V/Vito-Class	448	Information and communication	RFK-Reversing camera	√	√	√	√	×	×	×
V/Vito-Class	448	Information and communication	SOUND-sound system	√	√	√	√	×	×	×
V/Vito-Class	448	Information and communication	DAB-Digital Audio Broadcasting	√	√	√	√	×	×	×
V/Vito-Class	448	Information and communication	TV-TV tuner	√	√	√	√	×	×	×
V/Vito-Class	448	Information and communication	TPAD-Touch pad	√	√	√	√	×	×	×
V/Vito-Class	448	Body	S98/1 (Front heater/air conditioner operating unit switch)	√	√	√	×	×	×	×
V/Vito-Class	448	Body	S98/2 (rear heater/air conditioner operating unit switch)	√	√	√	×	×	×	×
Citan-Class	415		KLA-air conditioning	√	√	√	×	×	×	×
Citan-Class	415	Chassis	ESP-Electronic stability program	√	√	√	√	×	×	×
Citan-Class	415	Chassis	ES-Electric power steering	√	√	√	√	×	×	×
Citan-Class	415	Information and communication	KI-dash board	√	√	√	√	×	×	×

Citan-Class	415	Air conditioning	KLA-air conditioning	√	√	√	√	×	×	×
Citan-Class	415	Body	SAM-Signal acquisition and actuation control module	√	√	√	√	×	×	×
Citan-Class	415	Body	SRM-Fuses and relay modules	√	√	√	√	×	×	×
Citan-Class	415	Information and communication	PTS-Parktronic system	√	√	√	√	×	×	×
Citan-Class	415	Body	SRS-Supplemental restraint system	√	√	√	√	×	×	×
Citan-Class	415	Chassis	RDK-Tire pressure monitor	√	√	√	√	×	×	×
Citan-Class	415	Drive	CDI Engine Electronics 'Common Rail Injection System' (CDI)	√	√	√	√	×	×	×
Citan-Class	415	Drive	CDI Engine Electronics 'Common Rail Injection System' (CDI)	√	√	√	√	×	×	×
Citan-Class	415	Drive	ME - Engine Electronic Equipment 'ME (Engine Electronic Equipment)' (ME)	√	√	√	√	×	×	×
Citan-Class	415	Drive	ME - Engine Electronic Equipment 'ME (Engine Electronic Equipment)' (ME)	√	√	√	√	×	×	×
Citan-Class	415	Drive	CDI-Motor electronics	√	√	√	×	×	×	×
Citan-Class	415	Drive	CDI Engine Electronics 'Common Rail Injection System' (CDI)	√	√	√	√	×	×	×
Citan-Class	415	Drive	CDI Engine Electronics 'Common Rail Injection System' (CDI)	√	√	√	√	×	×	×
Citan-Class	415	Drive	CDI-Common Rail Diesel Injection	√	√	√	×	×	×	×
Citan-Class	415	Drive	DKG-Dual clutch gearbox	√	√	√	√	×	×	×
Citan-Class	415	Drive	SCR-Selective catalytic reduction	√	√	√	√	×	×	×
Sprinter III-CL	9061	Information and communication	E-Call-RU-eCall, Russia (GLONASS)	√	√	√	√	×	×	×
Sprinter III-CL	9061	Body	EZS-Electronic ignition switch	√	√	√	×	×	×	×
Sprinter III-CL	9061	Body	EZS-Electronic ignition switch	√	√	√	×	×	×	×
Sprinter III-CL	9061	Information and communication	AUDIO/APS-Auto pilot system	√	√	√	√	×	×	×
Sprinter III-CL	9061		KLA-air conditioning	√	√	√	×	×	×	×
Sprinter III-CL	9061	Information and communication	NAV-Navigation System	√	√	√	√	×	×	×

Sprinter III-Class	9061	Driver assistance	SG AWF-COLLISION PREVENTION ASSIST	√	√	√	×	×	×	×
Sprinter III-Class	9061	Body	SAM-Signal acquisition and actuation	√	√	√	×	×	×	×
Sprinter III-Class	9061	Body	DBE-Overhead control panel	√	√	√	√	×	×	×
Sprinter III-Class	9061	Driver assistance	MFK-Multifunction camera(mono)	√	√	√	×	×	×	×
Sprinter III-Class	9061	Body	KE-Keyless Entry	√	√	√	×	×	×	×
Sprinter III-Class	9061	Body	OBP2-Upper control panel	√	√	√	×	×	×	×
Sprinter III-Class	9061	Chassis	RDK Tire pressure monitor(As of model 9011)	√	√	√	×	×	×	×
Sprinter III-Class	9061	Body	SRS-supplemental restraint system	√	√	√	√	×	×	×
Sprinter III-Class	9061	Body	SRS-supplemental restraint system	√	√	√	√	×	×	×
Sprinter III-Class	9061	Seats and Doors	TSG-Door control module front driver side	√	√	√	×	×	×	×
Sprinter III-Class	9061	Drive	FSCU01-Control unit Fuel pump	√	√	√	×	×	×	×
Sprinter III-Class	9061	LIN Bus	PSM-Parameterizable Special Module	√	√	√	×	×	×	×
Sprinter III-Class	9061	Air conditioning	PTC-Heater booster	√	√	√	×	×	×	×
Sprinter III-Class	9061	Body	AAG-Trailer connection unit	√	√	√	√	×	×	×
Sprinter III-Class	9061	Body	AAG-Trailer identification device	√	√	√	×	×	×	×
Sprinter III-Class	9061	Air conditioning	ZHE-Auxiliary heater	√	√	√	×	×	×	×
Sprinter III-Class	9061	Air conditioning	ZHZ-Heater booster	√	√	√	×	×	×	×
Sprinter III-Class	9061	Chassis	ENR-Electronic rear axle level control	√	√	√	√	×	×	×
Sprinter III-Class	9061	Seats and Doors	STL-Left electric sliding door	√	√	√	×	×	×	×
Sprinter III-Class	9061	Seats and Doors	STR-Right electric sliding door	√	√	√	×	×	×	×
Sprinter III-Class	9061	Drive	IRS HRA-Outer right rear intelligent radar sensor system	√	√	√	×	×	×	×
Sprinter III-Class	9061		KLA-air conditioning	√	√	√	×	×	×	×
Sprinter III-Class	9061	Drive	IRS HRA-Outer right rear intelligent radar sensor system	√	√	√	×	×	×	×

Sprinter III-Class	9061	Drive	IRS HLA-Outer left rear intelligent radar sensor system	√	√	√	×	×	×	×
Sprinter III-Class	9061	Drive	IRS HLA-Outer left rear intelligent radar sensor system	√	√	√	×	×	×	×
Sprinter III-Class	9061		KLA-air conditioning	√	√	√	×	×	×	×
Sprinter III-Class	9061	Drive	FSCU01-Control unit Fuel pump	√	√	√	×	×	×	×
Sprinter III-Class	9061	Chassis	ESP-Electronic stability program	√	√	√	√	×	×	×
Sprinter III-Class	9061	Drive	ESM-Electronic selector module	√	√	√	×	×	×	×
Sprinter III-Class	9061	Information and communication	PTS-Parktronic system	√	√	√	×	×	×	×
Sprinter III-Class	9061	Air conditioning	KLA-Automatic air conditioning	√	√	√	×	×	×	×
Sprinter III-Class	9061	Body	MRM-Steering column module	√	√	√	×	×	×	×
Sprinter III-Class	9061	Body	ALWR-Headlamp range adjustment	√	√	√	√	×	×	×
Sprinter III-Class	9061	Information and communication	KI-Instrument cluster	√	√	√	×	×	×	×
Sprinter III-Class	9061	Information and communication	DTCO-Digital tachograph	√	√	√	√	×	×	×
Sprinter III-Class	9061	Information and communication	DTCO-Digital tachograph	√	√	√	×	×	×	×
Sprinter III-Class	9061	Information and communication	MTCO-Modular tachograph	√	√	√	×	×	×	×
Sprinter III-Class	9061	Drive	ME SFI-CNG compressed natural gas	√	×	√	×	×	×	×
Sprinter III-Class	9061		KLA-air conditioning	√	√	√	×	×	×	×
Sprinter III-Class	9061	Drive	CDI-Motor electronics	√	√	√	√	×	×	×
Sprinter III-Class	9061	Drive	CDI-Motor electronics	√	√	√	×	×	×	×
Sprinter III-Class	9061	Drive	CDI-Motor electronics	√	√	√	×	×	×	×
Sprinter III-Class	9061	Drive	CDI-Motor electronics	√	√	√	√	×	×	×

Sprinter III-Class	9061	Drive	CDI-Motor electronics	√	√	√	×	×	×	×
Sprinter III-Class	9061	Drive	CDI-Motor electronics	√	√	√	×	×	×	×
Sprinter III-Class	9061	Drive	ME-Motor electronics	√	√	√	×	×	×	×
Sprinter III-Class	9061	Drive	CDI-Motor electronics	√	√	√	×	×	×	×
Sprinter III-Class	9061	Chassis	TPM-Tire pressure monitor	√	√	√	×	×	×	×
Sprinter III-Class	9061	Drive	ME SFI-Motor electronics	√	√	√	×	×	×	×
Sprinter III-Class	9061	Drive	EGS electronic transmission control	√	√	√	√	×	×	×
Sprinter III-Class	9061	Drive	Transmission control	√	√	√	√	×	×	×
Sprinter III-Class	9061	Drive	SCR-Selective Catalytic Reduction	√	√	√	×	×	×	×
Sprinter III-Class	9061	Drive	SCR-Selective Catalytic Reduction	√	√	√	√	×	×	×
Sprinter 907-Class	907	Body	EZS-Electronic ignition switch	√	√	√	√	×	×	×
Sprinter 907-Class	907	Seats and Doors	DCU RF-Right front door	√	√	√	√	×	×	×
Sprinter 907-Class	907	Seats and Doors	STL-Left electric sliding door	√	√	√	×	×	×	×
Sprinter 907-Class	907	Seats and Doors	STR-Right electric sliding door	√	√	√	×	×	×	×
Sprinter 907-Class	907	Seats and Doors	Name Bauteil - (KEP) (Code:T40, T41) (SDD907)	√	√	√	×	×	×	×
Sprinter 907-Class	907	Seats and Doors	DCU LF-Left front door	√	√	√	√	×	×	×
Sprinter 907-Class	907	Seats and Doors	ESE-Driver's seat adjustment	√	√	√	√	×	×	×
Sprinter 907-Class	907	Body	SAM-Signal acquisition and actuation module	√	√	√	√	×	×	×
Sprinter 907-Class	907	Information and communication	HERMES-Telematics module	√	√	√	√	×	×	×
Sprinter 907-Class	907	Seats and Doors	ESE-'Front passenger' electric seat adjustment	√	√	√	√	×	×	×

Sprinter 907-Class	907	Air conditioning	C AAC-Convenience automatic air conditioning/AAC-Automatic air conditioning/HEAT-Automatic heater	√	√	√	√	×	×	×
Sprinter 907-Class	907	Body	ATA-Interior motion sensor	√	√	√	×	×	×	×
Sprinter 907-Class	907	Body	AAG-Trailer identification device	√	√	√	×	×	×	×
Sprinter 907-Class	907	Body	Multifunction control unit-Multifunction control unit	√	√	√	×	×	×	×
Sprinter 907-Class	907	Driver assistance system	AB-Airbag	√	√	√	√	×	×	×
Sprinter 907-Class	907	Driver assistance system	ACS-Automatic clutch system	√	√	√	√	×	×	×
Sprinter 907-Class	907	Body	CL-Central locking control unit	√	√	√	√	×	×	×
Sprinter 907-Class	907	Body	UCP-Upper control panel	√	√	√	√	×	×	×
Sprinter 907-Class	907	Information and communication	A26/17 - MBUX multimedia system (host, code: E2W, E2X) (CONNECT907)	√	√	√	×	×	×	×
Sprinter 907-Class	907	Information and communication	A26/17 - MBUX multimedia system (host, code: E2Y, E2Z) (HU6)	√	√	√	×	×	×	×
Sprinter 907-Class	907	Information and communication	ZAN-Audio/COMAND display	√	√	√	√	×	×	×
Sprinter 907-Class	907	Information and communication	UHI-Cellular telephone (fixed installation or portable) (D2B)	√	√	√	×	×	×	×
Sprinter 907-Class	907	Information and communication	UHI-Cellular telephone (fixed installation or portable) (D2B)	√	√	√	√	×	×	×
Sprinter 907-Class	907	Information and communication	IC-Instrument cluster	√	√	√	×	×	×	×
Sprinter 907-Class	907	Driver assistance system	RFK-Backup camera	√	√	√	√	×	×	×
Sprinter 907-Class	907	Body	SRS-Supplemental restraint system	√	√	√	√	×	×	×
Sprinter 907-Class	907	Body	SOGESTAR2-Sound generator for electric vehicle	√	√	√	√	×	×	×
Sprinter 907-Class	907	Body	SG SW L-Left headlamp	√	√	√	×	×	×	×
Sprinter 907-Class	907	Chassis	TPM-Tire pressure monitor	√	√	√	√	×	×	×

Sprinter 907-Class	907	Driver assistance system	MFK-Multifunction camera (mono)	√	√	√	√	×	×	×
Sprinter 907-Class	907	Body	SG SW R-Right headlamp	√	√	√	×	×	×	×
Sprinter 907-Class	907	Body	DC Charging Connection Unit (DCCU)	√	√	√	√	×	×	×
Sprinter 907-Class	907	Drive	ISM-Shift module	√	√	√	√	×	×	×
Sprinter 907-Class	907	Drive	SG EM-Power electronics	√	√	√	√	×	×	×
Sprinter 907-Class	907	Body	SG LG-Charger	√	√	√	√	×	×	×
Sprinter 907-Class	907	Body	DC/DC-DC/DC converter	√	√	√	√	×	×	×
Sprinter 907-Class	907	Body	SG BMS-Battery management system control unit	√	√	√	×	×	×	×
Sprinter 907-Class	907	Body	BSN-Battery sensor	√	√	√	×	×	×	×
Sprinter 907-Class	907	Body	RGLS-Rain/light sensor	√	√	√	√	×	×	×
Sprinter 907-Class	907	Body	ATA-Anti-theft alarm system	√	√	√	×	×	×	×
Sprinter 907-Class	907	Driver assistance system	N32/4 Right front seat heating	√	√	√	√	×	×	×
Sprinter 907-Class	907	Driver assistance system	N32/2 Heated front left seat	√	√	√	√	×	×	×
Sprinter 907-Class	907	Seats and Doors	S47/2 (driver's door switch module)	√	√	√	×	×	×	×
Sprinter 907-Class	907	Seats and Doors	S22 (driver's side door seat adjustment switch)	√	√	√	×	×	×	×
Sprinter 907-Class	907	Seats and Doors	Intelligent climate control switch group for driver's seat (S51/1)	√	√	√	×	×	×	×
Sprinter 907-Class	907	Seats and Doors	S47/3 (door switch module on front passenger side)	√	√	√	×	×	×	×
Sprinter 907-Class	907	Seats and Doors	S23 (door seat adjustment switch on front passenger side)	√	√	√	×	×	×	×
Sprinter 907-Class	907	Seats and Doors	S51/2 (intelligent climate control switch group for front passenger seat)	√	√	√	×	×	×	×
Sprinter 907-Class	907	Body	AS-Alarm siren	√	√	√	√	×	×	×

Sprinter 907-Class	907	Body	ATA-ATA[EDW]/tow-away protection/interior protection	√	√	√	×	×	×	×
Sprinter 907-Class	907	Air conditioning	STH-Stationary heater	√	√	√	×	×	×	×
Sprinter 907-Class	907	Air conditioning	STH-Stationary heater	√	√	√	√	×	×	×
Sprinter 907-Class	907	Air conditioning	C AAC-Convenience automatic air conditioning/AAC-Automatic air conditioning/HEAT-Automatic heater	√	√	√	×	×	×	×
Sprinter 907-Class	907	Body	TSTH-Radio remote control of stationary heater	√	√	√	√	×	×	×
Sprinter 907-Class	907	Body	N175/1 - Expansion Module 3 for Mercedes-Benz Advanced Controller (EM-1-MBAC)	√	√	√	×	×	×	×
Sprinter 907-Class	907	Driver assistance system	SG AWF-COLLISION PREVENTION ASSIST	√	√	√	√	×	×	×
Sprinter 907-Class	907	Driver assistance system	PTS-PARKTRONIC	√	√	√	√	×	×	×
Sprinter 907-Class	907	Chassis	ES-Electric power steering	√	√	√	√	×	×	×
Sprinter 907-Class	907	Body	MRM-Steering column module	√	√	√	√	×	×	×
Sprinter 907-Class	907	Drive	VG-Transfer case	√	√	√	√	×	×	×
Sprinter 907-Class	907	Drive	VG-Transfer case	√	√	√	×	×	×	×
Sprinter 907-Class	907	Body	SG BMS-Battery management system control unit	√	√	√	×	×	×	×
Sprinter 907-Class	907	Body	SG BMS-Battery management system control unit	√	√	√	×	×	×	×
Sprinter 907-Class	907	Information and communication	DTCO-Digital tachograph	√	√	√	√	×	×	×
Sprinter 907-Class	907	Information and communication	DTCO-Digital tachograph	√	√	√	×	×	×	×
Sprinter 907-Class	907	Information and communication	MTCO-Modular tachograph	√	√	√	×	×	×	×
Sprinter 907-Class	907	Body	N175/2 - Expansion Module 3 for Mercedes-Benz Advanced Controller (EM-2-MBAC)	√	√	√	√	×	×	×
Sprinter 907-Class	907	Body	N175/3 - Expansion Module 3 for Mercedes-Benz Advanced Controller (EM-3-MBAC)	√	√	√	√	×	×	×

Sprinter 907-Class	907	Body	SG BMS-Battery management system control unit	√	√	√	×	×	×	×
Sprinter 907-Class	907	Drive	CDI-Motor electronics	√	√	√	×	×	×	×
Sprinter 907-Class	907	Drive	CDI-Motor electronics	√	√	√	√	×	×	×
Sprinter 907-Class	907	Drive	CDI-Motor electronics	√	√	√	×	×	×	×
Sprinter 907-Class	907	Drive	CDI-Motor electronics	√	√	√	×	×	×	×
Sprinter 907-Class	907	Drive	CDI-Motor electronics	√	√	√	×	×	×	×
Sprinter 907-Class	907	Drive	ME-Engine electronics 'ME40' for internal combustion engine 'M274'	√	√	√	√	×	×	×
Sprinter 907-Class	907	Drive	CDI-Motor electronics	√	√	√	×	×	×	×
Sprinter 907-Class	907	Drive	CDI-Motor electronics	√	√	√	×	×	×	×
Sprinter 907-Class	907	Drive	FTC-Front transmission control	√	√	√	×	×	×	×
Sprinter 907-Class	907	Drive	VGS-Start clutch oil pressure sensor	√	√	√	√	×	×	×
Sprinter 907-Class	907	Drive	Transmission control	√	√	√	×	×	×	×
Sprinter 907-Class	907	Drive	Transmission control	√	√	√	×	×	×	×
Sprinter 907-Class	907	Chassis	ESP-Electronic stability program	√	√	√	√	×	×	×
Sprinter 907-Class	907	Drive	FSCU01-Control unit Fuel pump	√	√	√	√	×	×	×
Sprinter 907-Class	907	Drive	SCR-Selective catalytic reduction	√	√	√	√	×	×	×
Sprinter 907-Class	907	Drive	SCR-Selective catalytic reduction	√	√	√	×	×	×	×
Sprinter 907-Class	907	Drive	N127 (Drivetrain control unit)	√	√	√	√	×	×	×
Sprinter 907-Class	907	Drive	N127 (Drivetrain control unit)	√	√	√	√	×	×	×
Sprinter 907-Class	907	Drive	N127 (Drivetrain control unit)	√	√	√	×	×	×	×

Sprinter 907-Class	907	Body	BMS-Battery management system	√	√	√	×	×	×	×
Sprinter 907-Class	907	Body	N175 - Expansion module 3 for Mercedes-Benz Advanced Controller (MBAC)	√	√	√	√	×	×	×
Sprinter 907-Class	907	Body	N26/25 - On-board logic unit (OLU)	√	√	√	×	×	×	×
Sprinter 910-Class	910	Body	EZS-Electronic ignition switch	√	√	√	√	×	×	×
Sprinter 910-Class	910	Seats and Doors	DCU RF-Right front door	√	√	√	√	×	×	×
Sprinter 910-Class	910	Seats and Doors	STL-Left electric sliding door	√	√	√	×	×	×	×
Sprinter 910-Class	910	Seats and Doors	STR-Right electric sliding door	√	√	√	×	×	×	×
Sprinter 910-Class	910	Seats and Doors	Name Bauteil - (KEP) (Code:T40, T41) (SDD907)	√	√	√	×	×	×	×
Sprinter 910-Class	910	Seats and Doors	DCU LF-Left front door	√	√	√	√	×	×	×
Sprinter 910-Class	910	Seats and Doors	ESE-Driver's seat adjustment	√	√	√	√	×	×	×
Sprinter 910-Class	910	Body	SAM-Signal acquisition and actuation module	√	√	√	√	×	×	×
Sprinter 910-Class	910	Information and communication	HERMES-Telematics module	√	√	√	√	×	×	×
Sprinter 910-Class	910	Seats and Doors	ESE-'Front passenger' electric seat adjustment	√	√	√	√	×	×	×
Sprinter 910-Class	910	Air conditioning	C AAC-Convenience automatic air conditioning/AAC-Automatic air conditioning/HEAT-Automatic heater	√	√	√	√	×	×	×
Sprinter 910-Class	910	Body	ATA-Interior motion sensor	√	√	√	×	×	×	×
Sprinter 910-Class	910	Body	AAG-Trailer identification device	√	√	√	×	×	×	×
Sprinter 910-Class	910	Body	Multifunction control unit-Multifunction control unit	√	√	√	×	×	×	×
Sprinter 910-Class	910	Driver assistance system	AB-Airbag	√	√	√	√	×	×	×
Sprinter 910-Class	910	Driver assistance system	ACS-Automatic clutch system	√	√	√	√	×	×	×

Sprinter 910-Class	910	Body	CL-Central locking control unit	√	√	√	√	×	×	×
Sprinter 910-Class	910	Body	UCP-Upper control panel	√	√	√	√	×	×	×
Sprinter 910-Class	910	Information and communication	A26/17 - MBUX multimedia system (host, code: E2W, E2X) (CONNECT907)	√	√	√	×	×	×	×
Sprinter 910-Class	910	Information and communication	A26/17 - MBUX multimedia system (host, code: E2Y, E2Z) (HU6)	√	√	√	×	×	×	×
Sprinter 910-Class	910	Information and communication	ZAN-Audio/COMAND display	√	√	√	√	×	×	×
Sprinter 910-Class	910	Information and communication	UHI-Cellular telephone (fixed installation or portable) (D2B)	√	√	√	√	×	×	×
Sprinter 910-Class	910	Information and communication	IC-Instrument cluster	√	√	√	×	×	×	×
Sprinter 910-Class	910	Driver assistance system	RFK-Backup camera	√	√	√	√	×	×	×
Sprinter 910-Class	910	Body	SRS-Supplemental restraint system	√	√	√	√	×	×	×
Sprinter 910-Class	910	Body	SOGESTAR2-Sound generator for electric vehicle	√	√	√	√	×	×	×
Sprinter 910-Class	910	Body	SG SW L-Left headlamp	√	√	√	×	×	×	×
Sprinter 910-Class	910	Chassis	TPM-Tire pressure monitor	√	√	√	√	×	×	×
Sprinter 910-Class	910	Driver assistance system	MFK-Multifunction camera (mono)	√	√	√	√	×	×	×
Sprinter 910-Class	910	Body	SG SW R-Right headlamp	√	√	√	×	×	×	×
Sprinter 910-Class	910	Body	DC Charging Connection Unit (DCCU)	√	√	√	√	×	×	×
Sprinter 910-Class	910	Drive	ISM-Shift module	√	√	√	√	×	×	×
Sprinter 910-Class	910	Drive	SG EM-Power electronics	√	√	√	√	×	×	×
Sprinter 910-Class	910	Body	SG LG-Charger	√	√	√	√	×	×	×
Sprinter 910-Class	910	Body	DC/DC-DC/DC converter	√	√	√	√	×	×	×
Sprinter 910-Class	910	Body	SG BMS-Battery management system control unit	√	√	√	×	×	×	×

Sprinter 910-Class	910	Body	BSN-Battery sensor	√	√	√	×	×	×	×
Sprinter 910-Class	910	Body	RGLS-Rain/light sensor	√	√	√	√	×	×	×
Sprinter 910-Class	910	Body	ATA-Anti-theft alarm system	√	√	√	×	×	×	×
Sprinter 910-Class	910	Driver assistance system	N32/4 Right front seat heating	√	√	√	√	×	×	×
Sprinter 910-Class	910	Driver assistance system	N32/2 Heated front left seat	√	√	√	√	×	×	×
Sprinter 910-Class	910	Seats and Doors	S47/2 (driver's door switch module)	√	√	√	×	×	×	×
Sprinter 910-Class	910	Seats and Doors	S22 (driver's side door seat adjustment switch)	√	√	√	×	×	×	×
Sprinter 910-Class	910	Seats and Doors	Intelligent climate control switch group for driver's seat (S51/1)	√	√	√	×	×	×	×
Sprinter 910-Class	910	Seats and Doors	S47/3 (door switch module on front passenger side)	√	√	√	×	×	×	×
Sprinter 910-Class	910	Seats and Doors	S23 (door seat adjustment switch on front passenger side)	√	√	√	×	×	×	×
Sprinter 910-Class	910	Seats and Doors	S51/2 (intelligent climate control switch group for front passenger seat)	√	√	√	×	×	×	×
Sprinter 910-Class	910	Body	AS-Alarm siren	√	√	√	√	×	×	×
Sprinter 910-Class	910	Body	ATA-ATA[EDW]/tow-away protection/interior protection	√	√	√	×	×	×	×
Sprinter 910-Class	910	Air conditioning	STH-Stationary heater	√	√	√	×	×	×	×
Sprinter 910-Class	910	Air conditioning	STH-Stationary heater	√	√	√	√	×	×	×
Sprinter 910-Class	910	Air conditioning	C AAC-Convenience automatic air conditioning/AAC-Automatic air conditioning/HEAT-Automatic heater	√	√	√	×	×	×	×
Sprinter 910-Class	910	Body	TSTH-Radio remote control of stationary heater	√	√	√	√	×	×	×
Sprinter 910-Class	910	Body	N175/1 - Expansion Module 3 for Mercedes-Benz Advanced Controller (EM-1-MBAC)	√	√	√	×	×	×	×
Sprinter 910-Class	910	Driver assistance system	SG AWF-COLLISION PREVENTION ASSIST	√	√	√	√	×	×	×

Sprinter 910-Class	910	Driver assistance system	PTS-PARKTRONIC	√	√	√	√	×	×	×
Sprinter 910-Class	910	Chassis	ES-Electric power steering	√	√	√	√	×	×	×
Sprinter 910-Class	910	Body	MRM-Steering column module	√	√	√	√	×	×	×
Sprinter 910-Class	910	Drive	VG-Transfer case	√	√	√	×	×	×	×
Sprinter 910-Class	910	Body	SG BMS-Battery management system control unit	√	√	√	×	×	×	×
Sprinter 910-Class	910	Body	SG BMS-Battery management system control unit	√	√	√	×	×	×	×
Sprinter 910-Class	910	Information and communication	DTCO-Digital tachograph	√	√	√	√	×	×	×
Sprinter 910-Class	910	Information and communication	DTCO-Digital tachograph	√	√	√	×	×	×	×
Sprinter 910-Class	910	Information and communication	MTCO-Modular tachograph	√	√	√	×	×	×	×
Sprinter 910-Class	910	Body	N175/2 - Expansion Module 3 for Mercedes-Benz Advanced Controller (EM-2-MBAC)	√	√	√	√	×	×	×
Sprinter 910-Class	910	Body	N175/3 - Expansion Module 3 for Mercedes-Benz Advanced Controller (EM-3-MBAC)	√	√	√	√	×	×	×
Sprinter 910-Class	910	Body	SG BMS-Battery management system control unit	√	√	√	×	×	×	×
Sprinter 910-Class	910	Drive	CDI-Motor electronics	√	√	√	×	×	×	×
Sprinter 910-Class	910	Drive	CDI-Motor electronics	√	√	√	√	×	×	×
Sprinter 910-Class	910	Drive	CDI-Motor electronics	√	√	√	×	×	×	×
Sprinter 910-Class	910	Drive	CDI-Motor electronics	√	√	√	×	×	×	×
Sprinter 910-Class	910	Drive	CDI-Motor electronics	√	√	√	×	×	×	×
Sprinter 910-Class	910	Drive	ME-Engine electronics 'ME40' for internal combustion engine 'M274'	√	√	√	√	×	×	×
Sprinter 910-Class	910	Drive	CDI-Motor electronics	√	√	√	×	×	×	×
Sprinter 910-Class	910	Drive	CDI-Motor electronics	√	√	√	×	×	×	×

Sprinter 910-Class	910	Drive	FTC-Front transmission control	√	√	√	×	×	×	×
Sprinter 910-Class	910	Drive	VGS-Start clutch oil pressure sensor	√	√	√	√	×	×	×
Sprinter 910-Class	910	Drive	Transmission control	√	√	√	×	×	×	×
Sprinter 910-Class	910	Drive	Transmission control	√	√	√	×	×	×	×
Sprinter 910-Class	910	Chassis	ESP-Electronic stability program	√	√	√	√	×	×	×
Sprinter 910-Class	910	Drive	FSCU01-Control unit Fuel pump	√	√	√	√	×	×	×
Sprinter 910-Class	910	Drive	SCR-Selective catalytic reduction	√	√	√	√	×	×	×
Sprinter 910-Class	910	Drive	SCR-Selective catalytic reduction	√	√	√	×	×	×	×
Sprinter 910-Class	910	Drive	N127 (Drivetrain control unit)	√	√	√	√	×	×	×
Sprinter 910-Class	910	Drive	N127 (Drivetrain control unit)	√	√	√	√	×	×	×
Sprinter 910-Class	910	Drive	N127 (Drivetrain control unit)	√	√	√	×	×	×	×
Sprinter 910-Class	910	Body	BMS-Battery management system	√	√	√	×	×	×	×
Sprinter 910-Class	910	Body	N175 - Expansion module 3 for Mercedes-Benz Advanced Controller (MBAC)	√	√	√	√	×	×	×
Sprinter 910-Class	910	Body	N26/25 - On-board logic unit (OLU)	√	√	√	×	×	×	×
Ctian 420-Class	420	Drive	Engine control module	√	√	√	√	×	×	×
Ctian 420-Class	420	Drive	CDI-Common Rail Diesel Injection	√	√	√	×	×	×	×
Ctian 420-Class	420	Drive	ETC-Electronic transmission control	√	√	√	×	×	×	×
Ctian 420-Class	420	Body	MRM-Steering column module	√	√	√	×	×	×	×
Ctian 420-Class	420	Chassis	ESP-Electronic stability program	√	√	√	√	×	×	×
Ctian 420-Class	420	Body	Name Bauteil - RCGW420	√	√	√	×	×	×	×

Ctian 420- Class	420		KLA-air conditioning	√	√	√	×	×	×	×
Ctian 420- Class	420	Drive	ME-Motro electronics CNGCM246 for combustion engine 379CNG	√	√	√	×	×	×	×
Ctian 420- Class	420	Drive	ME-Motro electronics CNGCM246 for combustion engine 379CNG	√	√	√	×	×	×	×
Ctian 420- Class	420		KLA-air conditioning	√	√	√	×	×	×	×
Ctian 420- Class	420	Drive	SCR-Selective catalytic reduction	√	√	√	√	×	×	×
Ctian 420- Class	420		KLA-air conditioning	√	√	√	×	×	×	×
Ctian 420- Class	420	Information and communication	HERMES-Telematics module	√	√	√	√	×	×	×
Ctian 420- Class	420	Body	N135 (Steering wheel electronics) (LRE)	√	√	√	×	×	×	×
Ctian 420- Class	420	Body	UCP-Upper control panel	√	√	√	√	×	×	×
Ctian 420- Class	420	Information and communication	A26/17 - MBUX multimedia system (host, code: E2W, E2X) (CONNECT907)	√	√	√	×	×	×	×
Ctian 420- Class	420	Information and communication	A26/17 - MBUX multimedia system (host, code: E2Y, E2Z) (HU6)	√	√	√	×	×	×	×
Ctian 420- Class	420	Information and communication	ZAN-Audio/COMAND display	√	√	√	√	×	×	×
Ctian 420- Class	420	Information and communication	IC-Instrument cluster	√	√	√	×	×	×	×
Ctian 420- Class	420	Driver assistance system	RFK-Backup camera	√	√	√	√	×	×	×
Ctian 420- Class	420	Body	SG SW L-Left headlamp	√	√	√	×	×	×	×
Ctian 420- Class	420	Body	SG SW R-Right headlamp	√	√	√	×	×	×	×
Ctian 420- Class	420	Body	N75 (Driver Assistance System Control Unit) (SG-FAS)	√	√	√	×	×	×	×
Ctian 420- Class	420	Body	DTR-DISTRONIC	√	√	√	×	×	×	×
Ctian 420- Class	420	Body	IRS-HLA-Left rear external smart radar range sensor	√	√	√	×	×	×	×
Ctian 420- Class	420	Seats and Doors	SOGESTAR2-Sound generator for electric vehicle	√	√	√	×	×	×	×

Ctian 420- Class	420	Chassis	ES-Electric power steering	√	√	√	√	×	×	×
Ctian 420- Class	420	Air conditioning	C AAC-Convenience automatic air conditioning/AAC-Automatic air conditioning/HEAT-Automatic heater	√	√	√	×	×	×	×
Ctian 420- Class	420	Air conditioning	C AAC-Convenience automatic air conditioning/AAC-Automatic air conditioning/HEAT-Automatic heater	√	√	√	×	×	×	×
Ctian 420- Class	420	Body	SAM-Signal acquisition and actuation control module	√	√	√	√	×	×	×
Ctian 420- Class	420	Body	SRM-Fuses and relay modules	√	√	√	×	×	×	×
Ctian 420- Class	420		KLA-air conditioning	√	√	√	×	×	×	×
Ctian 420- Class	420	Body	SRS-Supplemental restraint system	√	√	√	×	×	×	×
Ctian 420- Class	420		KLA-air conditioning	√	√	√	×	×	×	×
Ctian 420- Class	420		KLA-air conditioning	√	√	√	×	×	×	×
Ctian 420- Class	420	Drive	HFM-SFI-Hot film engine management	√	√	√	×	×	×	×
Ctian 420- Class	420		KLA-air conditioning	√	√	√	×	×	×	×
Ctian 420- Class	420	Body	N75 (Driver Assistance System Control Unit) (SG-FAS)	√	√	√	√	×	×	×
Ctian 420- Class	420	Body	IRS-HRA-Right rear external intelligent radar range sensor	√	√	√	×	×	×	×
Ctian 420- Class	420	Body	SG LML VR-LED matrix of right front lamp unit	√	√	√	√	×	×	×
Ctian 420- Class	420		KLA-air conditioning	√	√	√	×	×	×	×
Ctian 420- Class	420	Information and communication	MFK-Multifunction camera	√	√	√	√	×	×	×
Ctian 420- Class	420	Drive	CDI-Motor electronics	√	√	√	×	×	×	×
Sprinter 909-Class	909	Information and communication	E-Call-RU-eCall, Russia (GLONASS)	√	√	√	√	×	×	×
Sprinter 909-Class	909	Body	SRS-Supplemental restraint system	√	√	√	√	×	×	×

Sprinter 909-Class	909	Chassis	ESP-Electronic stability program	√	√	√	√	×	×	×
Sprinter 909-Class	909	Body	ZV-Central locking system	√	√	√	√	×	×	×
Sprinter 909-Class	909	Body	WSP immobilizer	√	√	√	×	×	×	×
Sprinter 909-Class	909	Body	HZR-Heating control	√	√	√	×	×	×	×
Sprinter 909-Class	909	Body	KE-Keyless Entry	√	√	√	√	×	×	×
Sprinter 909-Class	909	Drive	CDI-Motor electronics	√	√	√	×	×	×	×
Sprinter 909-Class	909	Drive	CDI-Motor electronics	√	√	√	×	×	×	×
X 470-Class	470	Information and communication	HERMES-Telematics module	√	√	√	√	×	×	×
X 470-Class	470	Body	MRM-Steering column module	√	√	√	√	×	×	×
X 470-Class	470	Information and communication	TPAD-Touch pad	√	√	√	√	×	×	×
X 470-Class	470	Information and communication	RD-Radio (Audio / Cab Management and Data Systems)	√	√	√	√	×	×	×
X 470-Class	470	Information and communication	Audio-Audio or COMAND	√	√	√	√	×	×	×
X 470-Class	470	Information and communication	ZBE-Audio / Cab Management and Data System (COMAND) operating unit	√	√	√	√	×	×	×
X 470-Class	470	Information and communication	ZAN-Audio / Cab Management and Data System (COMAND) display	√	√	√	√	×	×	×
X 470-Class	470	Information and communication	IC-Instrument cluster	√	√	√	×	×	×	×
X 470-Class	470	Driver assistance system	RFK-Backup camera	√	√	√	×	×	×	×
X 470-Class	470	Driver assistance system	360 camera - 360 camera	√	√	√	×	×	×	×
X 470-Class	470	Body	OBF-Upper control panel	√	√	√	×	×	×	×
X 470-Class	470	Body	A40/1 (lower left control panel (UBFL) control unit)	√	√	√	×	×	×	×
X 470-Class	470	Body	A40/2 (right lower control panel (UBFR) control unit)	√	√	√	×	×	×	×

X 470- Class	470	Information and communication	MFK-Multifunction camera	√	√	√	√	×	×	×
X 470- Class	470	Information and communication	DAB-Digital Audio Broadcasting	√	√	√	√	×	×	×
X 470- Class	470	Information and communication	SG AWF-Control unit 'COLLISION PREVENTION ASSIST'	√	√	√	×	×	×	×
X 470- Class	470	Body	CGW-Central gateway	√	√	√	×	×	×	×
X 470- Class	470	Chassis	ESP-Electronic stability program	√	√	√	√	×	×	×
X 470- Class	470	Body	WSS-Weight sensing system	√	√	√	×	×	×	×
X 470- Class	470	Air conditioning	C AAC-Convenience automatic air conditioning/AAC-Automatic air conditioning/HEAT-Automatic heater	√	√	√	×	×	×	×
X 470- Class	470	Body	SAM-Signal acquisition and actuation control module	√	√	√	×	×	×	×
X 470- Class	470	Body	Headlight Range Regulation (LWR)	√	√	√	×	×	×	×
X 470- Class	470	Drive	VG-All-wheel drive	√	√	√	√	×	×	×
X 470- Class	470	Body	SRM-Fuses and relay modules	√	√	√	×	×	×	×
X 470- Class	470	Information and communication	PTS-Parktronic system	√	√	√	×	×	×	×
X 470- Class	470	Body	BSN-Battery sensor	√	√	√	×	×	×	×
X 470- Class	470	Body	SRS-Supplemental restraint system	√	√	√	×	×	×	×
X 470- Class	470	Chassis	TPM-Tire pressure monitor	√	√	√	×	×	×	×
X 470- Class	470	Body	N75 (Driver Assistance System Control Unit) (SG-FAS)	√	√	√	√	×	×	×
X 470- Class	470	Information and communication	Vehicle power grid management system (ElectSysManage)	√	√	√	√	×	×	×
X 470- Class	470	Drive	VG-Transfer case	√	√	√	×	×	×	×
X 470- Class	470	Information and communication	DTCO-Digital tachograph	√	√	√	×	×	×	×

X 470- Class	470	Information and communication	DTCO-Digital tachograph	√	√	√	√	×	×	×
X 470- Class	470	Information and communication	DTCO-Digital tachograph	√	√	√	×	×	×	×
X 470- Class	470	Chassis	N135 (Steering wheel electronics) (LRE)	√	√	√	×	×	×	×
X 470- Class	470	Drive	HAQ-Interwheel differential lock at rear axle	√	√	√	×	×	×	×
X 470- Class	470	Drive	CDI-Motor electronics	√	√	√	×	×	×	×
X 470- Class	470	Drive	CDI-Motor electronics	√	√	√	×	×	×	×
X 470- Class	470	Drive	CDI-Motor electronics	√	√	√	×	×	×	×
X 470- Class	470	Drive	CDI-Motor electronics	√	√	√	×	×	×	×
X 470- Class	470	Drive	ETC-Electronic transmission control	√	√	√	×	×	×	×
X 470- Class	470	Drive	VGS-Start clutch oil pressure sensor	√	√	√	√	×	×	×
X 470- Class	470	Drive	Transmission control	√	√	√	×	×	×	×
X 470- Class	470	Drive	FSCU-Fuel system control unit	√	√	√	√	×	×	×
X 470- Class	470	Drive	SCR-Selective Catalytic Reduction	√	√	√	√	×	×	×
X 470- Class	470	Drive	N127 (Drivetrain control unit)	√	√	√	×	×	×	×
X 470- Class	470	Drive	SCR-Selective catalytic reduction	√	√	√	√	×	×	×
X 470- Class	470		KLA-air conditioning	√	√	√	×	×	×	×
V/Vito- Class	638	Drive	ME-Motor electronics	√	√	√	√	×	×	×
V/Vito- Class	638	Drive	CR-Common rail	√	√	√	√	×	×	×
V/Vito- Class	638	Drive	CR-Common rail	√	√	√	√	×	×	×
V/Vito- Class	638	Information and communication	KI-Instrument cluster	√	√	√	√	×	×	×

V/Vito-	638	Body	WSP immobilizer	√	√	√	√	×	×	×
V/Vito-	638	Body	AB-Airbag	√	√	√	×	×	×	×
V/Vito-	638	Body	ABW-Airbag with window airbag	√	√	√	√	×	×	×
V/Vito-	638	Chassis	ABS-Anti lock braking system	√	√	√	√	×	×	×
V/Vito-Class	638	Information and communication	Radio (SOUND series)	√	√	√	√	×	×	×
V/Vito-Class	638	Information and communication	AUDIO/APS-Auto pilot system	√	√	√	√	×	×	×
V/Vito-Class	638	Information and communication	APS-Auto pilot system	√	√	√	√	×	×	×
V/Vito-	638	Body	ARS-All-wheel system	√	√	√	√	×	×	×
V/Vito-	638	Body	EDW2-Anti-theft alarm	√	√	√	√	×	×	×
V/Vito-	638	Drive	EGS electronic transmission control	√	√	√	√	×	×	×
V/Vito-	638	Drive	EWM-Electronic selector lever module	√	√	√	√	×	×	×
V/Vito-	638	Chassis	ESP-Electronic stability program	√	√	√	√	×	×	SP0004
V/Vito-Class	638	Body	HZR-Heating control	√	√	√	√	×	ACT0000,ACT0001, ACT0002,ACT0003, ACT0004,ACT0005,	×
V/Vito-	638	Air conditioning	HB-Heater booster	√	√	√	√	×	×	×
V/Vito-	638	Body	RFH backup assist	√	√	√	√	×	×	×
V/Vito-	638	Body	ZV-Central locking system	√	√	√	√	×	×	×
V/Vito-	638	Body	LPG Liquefied Petroleum Gas	√	√	√	√	×	×	×
Viano/Vito-Class	639	Drive	ME-SFI 2.8-Motor electronics 2.8	√	√	√	√	×	×	×
Viano/Vito-Class	639	Drive	EGS electronic transmission control	√	√	√	√	×	×	×
Viano/Vito-Class	639	Drive	ESM-Electronic selector module	√	√	√	√	×	×	×
Viano/Vito-Class	639	Chassis	ESP-Electronic stability program	√	√	√	√	×	×	SP0004
Viano/Vito-Class	639	Chassis	ESP-Electronic stability program	√	√	√	√	×	×	SP0004,SP0005
Viano/Vito-Class	639	Body	CGW-Central gateway	√	√	√	×	×	×	×

Viano/Vito-Class	639	Body	EZS-Electronic ignition switch	√	√	√	√	×	×	×
Viano/Vito-Class	639	Information and communication	IC-Instrument cluster	√	√	√	√	×	×	×
Viano/Vito-Class	639	Information and communication	IC-Instrument cluster	√	√	√	√	×	×	×
Viano/Vito-Class	639	Body	SRS-supplemental restraint system	√	√	√	√	×	×	×
Viano/Vito-Class	639	Body	SRS-supplemental restraint system	√	√	√	√	×	×	×
Viano/Vito-Class	639	Body	SAM-Signal acquisition and actuation module	√	√	√	√	×	ACT0007,ACT0008,ACT0009,ACT0010,ACT0011,ACT0012,ACT0013,ACT0014,ACT0015,ACT0016,ACT0017,ACT0018,ACT0019,ACT0020,ACT0021,ACT0022,ACT0023,ACT0024,ACT0025,ACT0026,ACT0027,ACT0028,ACT0029,ACT0030,ACT0031,ACT0032,ACT0033,ACT0034,ACT0035,ACT0036,ACT0037,ACT0038,ACT0039,ACT0040,ACT0041,ACT0042,	×
Viano/Vito-Class	639	Body	UCP-Upper control panel	√	√	√	√	×	×	×
Viano/Vito-Class	639	Seats and Doors	DCM-FL-Door control module front left	√	√	√	√	×	×	×
Viano/Vito-Class	639	Seats and Doors	DCM-FR-Door control module front right	√	√	√	√	×	ACT0047,ACT0048,ACT0049,ACT0050,ACT0051,ACT0038,	×

Viano/Vito-Class	639	Body	OCP-Overhead control panel	√	√	√	√	×	ACT0053,ACT0054, ACT0055,ACT0038, ACT0056,ACT0057	SP0006,SP0007
Viano/Vito-Class	639	Body	SDE-H-Rear sliding roof unit	√	√	√	√	×	ACT0056,ACT0038	SP0006,SP0008, SP0009
Viano/Vito-Class	639	Air conditioning	REAR AC-Rear air conditioning	√	√	√	√	×	×	SP0010
Viano/Vito-Class	639	Air conditioning	AAC-Automatic air conditioning	√	√	√	√	×	×	SP0011
Viano/Vito-Class	639	Air conditioning	STH-Stationary heater	√	√	√	√	×	ACT0058,ACT0059, ACT0060,ACT0061, ACT0062,ACT0063, ACT0064,ACT0065,	×
Viano/Vito-Class	639	Information and communication	PTS-Parktronic system	√	√	√	√	×	×	×
Viano/Vito-Class	639	Seats and Doors	STE-R-ESD [STE] Right electric sliding door	√	√	√	√	×	×	SP0012,SP0013, SP0014
Viano/Vito-Class	639	Seats and Doors	STE-L-ESD [STE] Left electric sliding door	√	√	√	√	×	×	SP0012,SP0013, SP0014
Viano/Vito-Class	639	Chassis	ENR-Electronic rear axle level control	√	√	√	√	×	ACT0067,ACT0068, ACT0069	SP0015
Viano/Vito-Class	639	Seats and Doors	ESA driver-Electric seat adjustment driver (with memory)	√	√	√	√	×	ACT0070,ACT0071, ACT0072,ACT0073, ACT0074	SP0016,SP0017, SP0018,SP0019, SP0020
Viano/Vito-Class	639	Seats and Doors	ESA passenger-Electric seat adjustment front passenger (with memory)	√	√	√	√	×	ACT0070,ACT0071, ACT0072,ACT0073, ACT0074	SP0016,SP0017, SP0018,SP0019, SP0020
Viano/Vito-Class	639	Chassis	TPC-Tire pressure monitor	√	√	√	√	×	×	×
Viano/Vito-Class	639	Body	AHE-Trailer recognition	√	√	√	√	×	×	×
Viano/Vito-Class	639	Body	AAG-Trailer connection unit	√	√	√	√	×	ACT0075,ACT0076, ACT0077,ACT0078, ACT0079,ACT0080,	×
Viano/Vito-Class	639	LIN Bus	PSM-Parameterizable Special Module	√	√	√	×	×	×	×

Viano/Vito-Class	639	LIN Bus	PSM-Parameterizable Special Module	√	√	√	√	×	×	×
Viano/Vito-Class	639	Information and communication	RADIO Sound 5	√	√	√	×	×	×	×
Viano/Vito-Class	639	Information and communication	AUDIO/APS-Auto pilot system	√	√	√	√	×	×	×
Viano/Vito-Class	639	Information and communication	COMAND	√	√	√	√	×	×	×
Viano/Vito-Class	639	Information and communication	HRA-Headlamp range adjustment	√	√	√	√	×	×	×
Viano/Vito-Class	639	Information and communication	Radio (SOUND series)	√	√	√	√	×	×	×
Viano/Vito-Class	639	Information and communication	CDC-CD changer	√	√	√	×	×	×	×
Viano/Vito-Class	639	Information and communication	CTEL-Cellular telephone 1 (fixed installation or portable)(D2B)	√	√	√	×	×	×	×
Viano/Vito-Class	639	Information and communication	UHI-Cellular telephone (fixed installation or portable)(D2B)	√	√	√	√	×	×	×
Viano/Vito-Class	639	Information and communication	VCS-Voice control system	√	√	√	√	×	×	×
Viano/Vito-Class	639	Information and communication	TV-TV tuner	√	√	√	√	×	×	×
Viano/Vito-Class	639	Information and communication	NAVI-Navigation system (COMAND,SOUND 50)	√	√	√	√	×	×	×
Viano/Vito-Class	639	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	√	√	√	√	×	×	×
Viano/Vito-Class	639	Information and communication	RADIO Sound 20	√	√	√	√	×	×	×
Viano/Vito-Class	639	Information and communication	SOUND 5NG	√	√	√	√	×	×	×
Viano/Vito-Class	639	Information and communication	CDW-CD changer	√	√	√	√	×	×	×
Viano/Vito-Class	639	Information and communication	TEL-Telephone control unit	√	√	√	√	×	×	×
Viano/Vito-Class	639	Information and communication	AVN-Headlamp range adjustmen	√	√	√	√	×	×	×

Viano/Vito-Class	639	Drive	CDI-Common Rail Diesel Injection	√	√	√	×	×	×	×
Viano/Vito-Class	639	Drive	CDI-Common Rail Diesel Injection	√	√	√	×	×	×	×
Viano/Vito-Class	639	Drive	CDI4-Common Rail Diesel Injection	√	√	√	√	×	×	×
Viano/Vito-Class	639	Drive	CDI4-Common Rail Diesel Injection	√	√	√	×	×	×	×
Viano/Vito-Class	639	Body	SAM-Signal acquisition and actuation module	√	√	√	√	×	ACT0007,ACT0008,ACT0009,ACT0010,ACT0011,ACT0082,ACT0083,ACT0084,ACT0085,ACT0086,ACT0087,ACT0088,ACT0012,ACT0013,ACT0014,ACT0015,ACT0016,ACT0089,ACT0090,ACT0091,ACT0092,ACT0093,ACT0094,ACT0095,ACT0017,ACT0018,ACT0019,ACT0020,ACT0021,ACT0022,ACT0023,ACT0024,ACT0025,ACT0026,ACT0027,ACT0028,ACT0029,ACT0030,ACT0096,ACT0097,ACT0098,ACT0099,ACT0100,ACT0031,ACT0032,ACT0033,ACT0034,ACT0035,ACT0101,ACT0036,ACT0037,ACT0038,ACT0039,ACT0040,	×
Viano/Vito-Class	639	Air conditioning	PTC-Heater booster	√	√	√	√	×	×	×

Viano/Vito-Class	639	Air conditioning	PTC-Heater booster	√	√	√	√	×	×	×
Viano/Vito-Class	639	Drive	EGS electronic transmission control	√	√	√	√	×	×	×
Viano/Vito-Class	639	Drive	ETC-Electronic transmission control	√	√	√	√	×	×	×
Viano/Vito-Class	639	Body	EZS-Electronic ignition switch	√	√	√	√	×	×	×
Viano/Vito-Class	639	Drive	ME 97-Motor electronics 9.7	√	√	√	√	×	ACT0103,ACT0104,ACT0105,ACT0106,ACT0107,ACT0108,ACT0109,ACT0110,ACT0111,ACT0112,ACT0113,ACT0114,ACT0115,ACT0116,	SP0021,SP0022,SP0023,SP0024
Viano/Vito-Class	639	Drive	CDID2-Common Rail Diesel Injection	√	√	√	√	×	ACT0118,ACT0119,ACT0120,ACT0121,ACT0122,ACT0123,ACT0124,ACT0125,ACT0126,ACT0127,	SP0025,SP0026,SP0027,SP0028,SP0021,SP0029,SP0030,SP0031,SP0032,SP0033,
Viano/Vito-Class	639	Drive	CDI6-Common Rail Diesel Injection	√	√	√	√	×	ACT0118,ACT0129,ACT0119,ACT0130,ACT0120,ACT0131,ACT0132,ACT0133,ACT0134,ACT0127,ACT0128	SP0025,SP0026,SP0035,SP0021,SP0036,SP0027,SP0037,SP0038,SP0028,SP0039,SP0040,SP0041,SP0030,SP0042,SP0043,SP0044,
Viano/Vito-Class	639	Body	OBF2-Upper control panel	√	√	√	√	×	×	×
Viano/Vito-Class	639	Body	SRS-supplemental restraint system	√	√	√	√	×	×	×
Viano/Vito-Class	639	Information and communication	DTCO-Digital tachograph	√	√	√	√	×	×	×
Viano/Vito-Class	639	Information and communication	FSE Hands-free system (Bluetooth)	√	√	√	√	×	×	×

Viano/Vito-Class	639	Drive	FSCU-Fuel pump	√	√	√	√	×	×	×
Viano/Vito-Class	639	Body	ALWR-Headlamp range adjustment	√	√	√	√	×	ACT0135	×
Viano/Vito-Class	639	Information and communication	COMAND or AUDIO	√	√	√	√	×	×	×
Viano/Vito-Class	639	Drive	CDI4-Common Rail Diesel Injection	√	√	√	√	×	ACT0136,ACT0137,ACT0138,ACT0139,ACT0140,ACT0141,ACT0142,ACT0143,ACT0144,ACT0145,ACT0146,ACT0147,ACT0141,ACT0148,	SP0046,SP0047,SP0048,SP0049,SP0050,SP0051,SP0052,SP0043,SP0044,SP0002
Sprinter III/Sprinter III up to 2013-Class	906	Drive	CR-Common rail	√	√	√	√	×	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Information and communication	KI-Instrument cluster	√	√	√	√	×	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Body	WSP immobilizer	√	√	√	√	×	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Body	AB-Airbag	√	√	√	×	×	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Body	ABW-Airbag with window airbag	√	√	√	√	×	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Body	ARS-All-wheel system	√	√	√	√	×	×	×

Sprinter III/Sprinter III up to 2013-Class	906	Drive	EGS electronic transmission control	√	√	√	√	×	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Chassis	ABS-Anti lock braking system	√	√	√	√	×	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Information and communication	Radio (SOUND series)	√	√	√	√	×	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Information and communication	AUDIO/APS-Auto pilot system	√	√	√	√	×	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Information and communication	APS-Auto pilot system	√	√	√	√	×	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Body	EDW2-Anti-theft alarm	√	√	√	√	×	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Drive	EWM-Electronic selector lever module	√	√	√	√	×	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Chassis	ESP-Electronic stability program	√	√	√	√	×	×	SP0004
Sprinter III/Sprinter III up to 2013-Class	906	Body	HZR-Heating control	√	√	√	√	×	ACT0000,ACT0001,ACT0002,ACT0003,ACT0004,ACT0005,ACT0006	×

Sprinter III/Sprinter III up to 2013-Class	906	Body	RFH backup assist	√	√	√	√	×	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Air conditioning	HB-Heater booster	√	√	√	√	×	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Body	ZV-Central locking system	√	√	√	√	×	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Drive	ME-Motor electronics	√	√	√	√	×	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Drive	CR-Common rail	√	√	√	√	×	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Body	EZS-Electronic ignition switch	√	√	√	√	×	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Body	EZS-Electronic ignition switch	√	√	√	√	×	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Body	EZS-Electronic ignition switch	√	√	√	√	×	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Drive	CDI4-Common Rail Diesel Injection	√	√	√	√	×	×	×

Sprinter III/Sprinter III up to 2013-Class	906	Drive	CDI3-Common Rail Diesel Injection	√	√	√	√	×	ACT0150,ACT0119,ACT0120,ACT0128	SP0046,SP0026,SP0053,SP0032
Sprinter III/Sprinter III up to 2013-Class	906	Drive	CDID2-Common Rail Diesel Injection	√	√	√	√	×	ACT0118,ACT0119,ACT0120,ACT0121,ACT0122,ACT0123,ACT0124,ACT0125,ACT0126,ACT0127,	SP0025,SP0026,SP0027,SP0028,SP0021,SP0029,SP0030,SP0031,SP0032,SP0033,
Sprinter III/Sprinter III up to 2013-Class	906	Drive	CDI6-Common Rail Diesel Injection	√	√	√	√	×	ACT0118,ACT0129,ACT0119,ACT0130,ACT0120,ACT0131,ACT0132,ACT0133,ACT0134,ACT0127,ACT0128	SP0025,SP0026,SP0035,SP0021,SP0036,SP0027,SP0037,SP0038,SP0028,SP0039,SP0040,SP0041,SP0030,SP0042,SP0043,SP0044,
Sprinter III/Sprinter III up to 2013-Class	906	Drive	CDI60-Common Rail Diesel Injection(OM642 EPA13)	√	√	√	√	×	ACT0151,ACT0152,ACT0153,ACT0154,ACT0128,ACT0155,ACT0156,ACT0157,ACT0158,ACT0117,ACT0159,ACT0160,ACT0161,ACT0162	SP0035,SP0002,SP0021,SP0036,SP0027,SP0037,SP0038,SP0028,SP0054,SP0030,SP0055,SP0056,SP0042,SP0057,SP0058,SP0059,SP0060,SP0043,SP0044,SP0061,
Sprinter III/Sprinter III up to 2013-Class	906	Drive	CDI4-Common Rail Diesel Injection	√	√	√	√	×	ACT0136,ACT0150,ACT0163,ACT0164,ACT0119,ACT0120,ACT0143,ACT0165,ACT0166,ACT0167,ACT0168,ACT0169	SP0064,SP0065,SP0066,SP0030,SP0002,SP0035,SP0046,SP0059,SP0060,SP0043,SP0044

Sprinter III/Sprinter III up to 2013-Class	906	Drive	ME 97-Motor electronics 9.7	√	√	√	√	×	ACT0103,ACT0104,ACT0105,ACT0106,ACT0107,ACT0108,ACT0109,ACT0110,ACT0111,ACT0112,ACT0113,ACT0114,ACT0115,ACT0116,	SP0021,SP0022,SP0023,SP0024
Sprinter III/Sprinter III up to 2013-Class	906	Drive	ME-SFI-Motor electronics	√	√	√	√	×	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Drive	CDI4-Common Rail Diesel Injection	√	√	√	√	×	ACT0136,ACT0137,ACT0138,ACT0139,ACT0140,ACT0141,ACT0142,ACT0143,ACT0144,ACT0145,ACT0146,ACT0147,ACT0141,ACT0148,	SP0046,SP0047,SP0048,SP0049,SP0050,SP0051,SP0052,SP0043,SP0044,SP0002
Sprinter III/Sprinter III up to 2013-Class	906	Information and communication	KI-Instrument cluster	√	√	√	√	×	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Body	OBF-Upper control panel	√	√	√	√	×	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Body	OBF2-Upper control panel	√	√	√	√	×	×	×

Sprinter III/Sprinter III up to 2013-Class	906	Body	SAM-Signal acquisition and actuation module	√	√	√	√	×	ACT0170,ACT0171,ACT0172,ACT0173,ACT0174,ACT0175,ACT0176,ACT0177,ACT0178,ACT0179,ACT0180,ACT0037,ACT0181,ACT0182,ACT0183,ACT0184,ACT0185,ACT0186,ACT0187,ACT0188,	×
Sprinter III/Sprinter III up to 2013-Class	906	Seats and Doors	TSG-Door control module front driver side	√	√	√	√	×	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Body	ALWR-Headlamp range adjustment	√	√	√	√	×	ACT0135	×
Sprinter III/Sprinter III up to 2013-Class	906	Body	AAG-Trailer connection unit	√	√	√	√	×	ACT0075,ACT0076,ACT0077,ACT0078,ACT0079,ACT0080,ACT0081	×
Sprinter III/Sprinter III up to 2013-Class	906	Drive	NGT-Natural Gas Technology	√	×	×	√	×	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Body	DBE-Overhead control panel	√	√	√	√	×	ACT0179,ACT0190,ACT0191,ACT0192,ACT0193,ACT0194	SP0067,SP0068,SP0069,SP0070,SP0071,SP0072,SP0073,SP0074
Sprinter III/Sprinter III up to 2013-Class	906	Drive	EGS electronic transmission control	√	√	√	√	×	×	×

Sprinter III/Sprinter III up to 2013-Class	906	Drive	EGS electronic transmission control	√	√	√	√	×	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Chassis	ESP-Electronic stability program	√	√	√	√	×	×	SP0075
Sprinter III/Sprinter III up to 2013-Class	906	Chassis	ESP9-Electronic stability program	√	√	√	√	×	×	SP0004,SP0076, SP0077
Sprinter III/Sprinter III up to 2013-Class	906	Drive	EWM-Electronic selector lever module	√	√	√	√	×	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Body	KE-Keyless Entry	√	√	√	√	×	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Air conditioning	KLA-Automatic air conditioning	√	√	√	√	×	×	SP0078
Sprinter III/Sprinter III up to 2013-Class	906	Body	MRM-Steering column module	√	√	√	√	×	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Information and communication	MTCO-Modular tachograph	√	√	√	√	×	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Air conditioning	PTC-Heater booster	√	√	√	√	×	×	×

Sprinter III/Sprinter III up to 2013-Class	906	Information and communication	PTS-Parktronic system	√	√	√	√	×	ACT0195,ACT0196	×
Sprinter III/Sprinter III up to 2013-Class	906	Chassis	RDK Tire pressure monitor(Up to model year 2010)	√	√	√	√	×	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Chassis	RDK Tire pressure monitor(As of model year 2011)	√	√	√	√	×	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Body	SRS-supplemental restraint system	√	√	√	√	×	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Air conditioning	ZHE-Auxiliary heater	√	√	√	√	×	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Seats and Doors	STL-Left electric sliding door	√	√	√	√	×	ACT0197,ACT0198,ACT0199,ACT0200,ACT0201,ACT0202	×
Sprinter III/Sprinter III up to 2013-Class	906	Seats and Doors	STR-Right electric sliding door	√	√	√	√	×	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Drive	VG-Transfer case	√	√	√	√	×	×	SP0079
Sprinter III/Sprinter III up to 2013-Class	906	Air conditioning	ZHZ-Heater booster	√	√	√	√	×	×	×

Sprinter III/Sprinter III up to 2013-Class	906	Chassis	ENR-Electronic rear axle level control	√	√	√	√	×	ACT0067	SP0080,SP0081
Sprinter III/Sprinter III up to 2013-Class	906	Drive	SCR-Selective Catalytic Reduction	√	√	√	√	×	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Information and communication	RADIO Sound 5	√	√	√	×	×	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	√	√	√	√	×	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Information and communication	RADIO Sound 20	√	√	√	√	×	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Information and communication	COMAND or AUDIO	√	√	√	√	×	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Information and communication	SOUND 5NG	√	√	√	√	×	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Information and communication	NAVI-Navigation system (COMAND,SOUND 50)	√	√	√	√	×	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Information and communication	CDW-CD changer	√	√	√	√	×	×	×

Sprinter III/Sprinter III up to 2013-Class	906	Information and communication	TEL-Telephone control unit	√	√	√	√	×	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Information and communication	FSE Hands-free system (Bluetooth)	√	√	√	√	×	×	×
Sprinter III/Sprinter III up to 2013-Class	906	LIN Bus	PSM-Parameterizable Special Module	√	√	√	√	×	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Body	SRS-Supplemental restraint system(LowLine)As of production month 12/2011	√	√	√	√	×	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Drive	FSCU-Fuel pump	√	√	√	√	×	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Drive	ASG-Automatic gearshift system	√	√	√	√	×	×	×
Sprinter III/Sprinter III up to 2013-Class	906	Drive	CDI4-Common Rail Diesel Injection	√	√	√	×	×	×	SP0046,SP0049, SP0051,SP0052, SP0044,SP0043, SP0026,SP0082
Vaneo-Class	414	Drive	ECM-Engine control monolith	√	√	√	√	×	×	×
Vaneo-Class	414	Chassis	ESP-Electronic stability program	√	√	√	√	×	×	×
Vaneo-Class	414	Information and communication	IC-Instrument cluster	√	√	√	√	×	×	SP0083,SP0084
Vaneo-Class	414	Body	ABW-Airbag with window airbag	√	√	√	√	×	×	×
Vaneo-Class	414	Body	DAS-Drive authorization system	√	√	√	√	×	×	×
Vaneo-Class	414	Seats and Doors	CL-Central locking control unit	√	√	√	√	×	×	×
Vaneo-Class	414	Air conditioning	HEAT/TAC-Automatic temperature control	√	√	√	√	×	×	×

Vaneo-Class	414	Body	ATA-Anti-theft alarm system	√	√	√	√	×	×	×
Vaneo-Class	414	Information and communication	PTS-Parktronic system	√	√	√	√	×	×	×
Vaneo-Class	414	Information and communication	Radio (SOUND series)	√	√	√	√	×	×	×
Vaneo-Class	414	Information and communication	AUDIO/APS-Auto pilot system	√	√	√	√	×	×	×
Vaneo-Class	414	Information and communication	COMAND	√	√	√	√	×	×	×
Vaneo-Class	414	Information and communication	CDC-CD changer	√	√	√	×	×	×	×
Vaneo-Class	414	Information and communication	CTEL-Cellular telephone 1 (fixed installation or portable)(D2B)	√	√	√	×	×	×	×
Vaneo-Class	414	Information and communication	UHI-Cellular telephone (fixed installation or portable)(D2B)	√	√	√	√	×	×	×
Vaneo-Class	414	Drive	ACS-Automatic clutch system	√	√	√	√	×	×	×
Vaneo-Class	414	Drive	FTC-Front transmission control	√	√	√	√	×	×	×
Vaneo-Class	414	Drive	FTC-Front transmission control	√	√	√	√	×	×	×
Vaneo-Class	414	Drive	ESM-Electronic selector module	√	√	√	√	×	×	×
Vaneo-Class	414	Drive	CDI-Common Rail Diesel Injection	√	√	√	√	×	×	×

## Actions

No.	Model Series	System Name
ACT0000	Heater booster	HZR-Heating control
ACT0001	Blower	HZR-Heating control
ACT0002	Compressor clutch	HZR-Heating control
ACT0003	Recirculated air' solenoid valve	HZR-Heating control
ACT0004	Circulation pump	HZR-Heating control
ACT0005	Auxiliary fan	HZR-Heating control
ACT0006	Water cycle valve	HZR-Heating control
ACT0007	E1e1 (High beam)	SAM-Signal acquisition and actuation module
ACT0008	E1e2 (Low beam)	SAM-Signal acquisition and actuation module
ACT0009	E1e3 (Standing and parking lamp)	SAM-Signal acquisition and actuation module
ACT0010	E1e4 (Fog lamp)	SAM-Signal acquisition and actuation module
ACT0011	E1e5 (Turn signal lamp)	SAM-Signal acquisition and actuation module
ACT0012	E2e1 (High beam)	SAM-Signal acquisition and actuation module
ACT0013	E2e2 (Low beam)	SAM-Signal acquisition and actuation module
ACT0014	E2e3 (Standing and parking lamp)	SAM-Signal acquisition and actuation module
ACT0015	E2e4 (Fog lamp)	SAM-Signal acquisition and actuation module
ACT0016	E2e5 (Turn signal lamp)	SAM-Signal acquisition and actuation module
ACT0017	E3e1 (Turn signal lamp)	SAM-Signal acquisition and actuation module
ACT0018	E3e2 (Taillamp and parking lamp)	SAM-Signal acquisition and actuation module
ACT0019	E3e3 (Backup lamp)	SAM-Signal acquisition and actuation module
ACT0020	E3e4 (Stop lamp)	SAM-Signal acquisition and actuation module
ACT0021	E3e5 (Rear fog lamp)	SAM-Signal acquisition and actuation module
ACT0022	E4e1 (Turn signal lamp)	SAM-Signal acquisition and actuation module
ACT0023	E4e2 (Taillamp and parking lamp)	SAM-Signal acquisition and actuation module
ACT0024	E4e3 (Backup lamp)	SAM-Signal acquisition and actuation module
ACT0025	E4e4 (Stop lamp)	SAM-Signal acquisition and actuation module
ACT0026	E4e5 (Rear fog lamp)	SAM-Signal acquisition and actuation module
ACT0027	Center high-mounted stop lamp	SAM-Signal acquisition and actuation module
ACT0028	License plate lights	SAM-Signal acquisition and actuation module
ACT0029	Blower motor in control module box	SAM-Signal acquisition and actuation module
ACT0030	Rear window defroster	SAM-Signal acquisition and actuation module
ACT0031	K40/9k1 (Horn relay)	SAM-Signal acquisition and actuation module
ACT0032	K40/9k2 (Wiper ON/OFF relay)	SAM-Signal acquisition and actuation module
ACT0033	K40/9k3 (Wiper stage 2 relay)	SAM-Signal acquisition and actuation module
ACT0034	K40/9k7 (Circuit 15R relay)	SAM-Signal acquisition and actuation module

ACT0035	K40/9k8 (Circuit 15 relay)	SAM-Signal acquisition and actuation module
ACT0036	K40/9k9 (Heated rear window relay)	SAM-Signal acquisition and actuation module
ACT0037	Audible warning device	SAM-Signal acquisition and actuation module
ACT0038	Switch illumination	SAM-Signal acquisition and actuation module
ACT0039	M5/1 (Windshield washer fluid pump)	SAM-Signal acquisition and actuation module
ACT0040	M6/1 (Windshield wiper motor)STAGE 1	SAM-Signal acquisition and actuation module
ACT0041	M6/1 (Windshield wiper motor)STAGE 2	SAM-Signal acquisition and actuation module
ACT0042	M5/3 (Windshield washer fluid pump)	SAM-Signal acquisition and actuation module
ACT0043	M6/10 (Left rear-end door wiper motor)	SAM-Signal acquisition and actuation module
ACT0044	M6/11 (Right rear-end door wiper motor)	SAM-Signal acquisition and actuation module
ACT0045	M6/12 (Tailgate wiper motor)	SAM-Signal acquisition and actuation module
ACT0046	M5/2 (Headlamp cleaning system pump)	SAM-Signal acquisition and actuation module
ACT0047	M10/2 (Right front power window motor)	DCM-FR-Door control module front right
ACT0048	Denormalize power windows.	DCM-FR-Door control module front right
ACT0049	Mirror adjustment motors	DCM-FR-Door control module front right
ACT0050	M21/7m3 (Mirror fold-in motor)	DCM-FR-Door control module front right
ACT0051	M21/7r1 (Mirror heater)	DCM-FR-Door control module front right
ACT0052	CL functions	DCM-FR-Door control module front right
ACT0053	Dome lamp	OCP-Overhead control panel
ACT0054	Left front reading lamp	OCP-Overhead control panel
ACT0055	Right front reading lamp	OCP-Overhead control panel
ACT0056	Sliding or tilting roof motor	OCP-Overhead control panel
ACT0057	EDW anti-theft alarm	OCP-Overhead control panel
ACT0058	Switch on stationary heater (normal mode).	STH-Stationary heater
ACT0059	Switch on stationary heater (test mode).	STH-Stationary heater
ACT0060	A6m1 (Combustion air blower)	STH-Stationary heater
ACT0061	A6r1 (Glow pin)	STH-Stationary heater
ACT0062	K23/1 (Blower motor relay)	STH-Stationary heater
ACT0063	M13/5 (Coolant circulation pump)	STH-Stationary heater
ACT0064	M46/1 (Stationary heater metering pump)	STH-Stationary heater
ACT0065	Switch on LEDs in the control switch.	STH-Stationary heater
ACT0066	Canceling the overheating, fault and crash interlock	STH-Stationary heater
ACT0067	A9/1m1 (Air compressor motor)-A9/1y1 (Air compressor pressure relief valve)-Y36 (Level control valve unit)	ENR-Electronic rear axle level control
ACT0068	S77/1 (ELC lock button)	ENR-Electronic rear axle level control
ACT0069	S77 (ELC raise/lower button)	ENR-Electronic rear axle level control
ACT0070	Forward/back adjustment	ESA driver-Electric seat adjustment driver (with memory)

ACT0071	Height at front	ESA driver-Electric seat adjustment driver (with memory)
ACT0072	Height at rear	ESA driver-Electric seat adjustment driver (with memory)
ACT0073	Backrest	ESA driver-Electric seat adjustment driver (with memory)
ACT0074	Head restraint	ESA driver-Electric seat adjustment driver (with memory)
ACT0075	Left turn signal	AAG-Trailer connection unit
ACT0076	Right turn signal	AAG-Trailer connection unit
ACT0077	Left tail light	AAG-Trailer connection unit
ACT0078	Right tail light	AAG-Trailer connection unit
ACT0079	Stop lamp	AAG-Trailer connection unit
ACT0080	Rear foglight	AAG-Trailer connection unit
ACT0081	Reversing lamp	AAG-Trailer connection unit
ACT0082	E1e7 (Left daytime running light)	SAM-Signal acquisition and actuation module
ACT0083	E1/6e1 (Left high beam)	SAM-Signal acquisition and actuation module
ACT0084	E1/6e2 (Left low beam)	SAM-Signal acquisition and actuation module
ACT0085	E1/6e3 (Left standing and parking lamp)	SAM-Signal acquisition and actuation module
ACT0086	E1/6e6 (Left curve and front fog light)	SAM-Signal acquisition and actuation module
ACT0087	E1/6e5 (Left turn signal lamp)	SAM-Signal acquisition and actuation module
ACT0088	E1/6e7 (Left daytime running light)	SAM-Signal acquisition and actuation module
ACT0089	E2e7 (Right daytime running light)	SAM-Signal acquisition and actuation module
ACT0090	E2/6e1 (Right high beam)	SAM-Signal acquisition and actuation module
ACT0091	E2/6e2 (Right low beam)	SAM-Signal acquisition and actuation module
ACT0092	E2/6e3 (Right standing and parking lamp)	SAM-Signal acquisition and actuation module
ACT0093	E2/6e6 (Right curve and front fog light)	SAM-Signal acquisition and actuation module
ACT0094	E2/6e5 (Right turn signal lamp)	SAM-Signal acquisition and actuation module
ACT0095	E2/6e7 (Right daytime running light)	SAM-Signal acquisition and actuation module
ACT0096	Front interior light	SAM-Signal acquisition and actuation module
ACT0097	Rear interior lamp	SAM-Signal acquisition and actuation module
ACT0098	Rear interior lampAmbiance lighting	SAM-Signal acquisition and actuation module
ACT0099	Front footwell lamps	SAM-Signal acquisition and actuation module
ACT0100	Rear footwell lamps	SAM-Signal acquisition and actuation module
ACT0101	K40/9k7 (Circuit 15R relay)K40/9k8 (Circuit 15 relay)K40/9k11 (Terminal 15 relief relay)	SAM-Signal acquisition and actuation module
ACT0102	Central locking	SAM-Signal acquisition and actuation module
ACT0103	Y62 (Fuel injection valves)	ME 97-Motor electronics 9.7
ACT0104	M16/5 (Throttle valve actuator)	ME 97-Motor electronics 9.7
ACT0105	M33 (Electric air pump)	ME 97-Motor electronics 9.7
ACT0106	M3/3 (Fuel pump with fuel level sensor)	ME 97-Motor electronics 9.7

ACT0107	Mixture adaptation	ME 97-Motor electronics 9.7
ACT0108	Y22/10 (Intake manifold switchover valve)	ME 97-Motor electronics 9.7
ACT0109	Y49/4 (Left intake camshaft positioner)	ME 97-Motor electronics 9.7
ACT0110	Y49/5 (Right intake camshaft positioner)	ME 97-Motor electronics 9.7
ACT0111	Y49/6 (Left exhaust camshaft positioner)	ME 97-Motor electronics 9.7
ACT0112	Y49/7 (Right exhaust camshaft positioner)	ME 97-Motor electronics 9.7
ACT0113	Y22/9 (Intake manifold tumble flap switchover valve)	ME 97-Motor electronics 9.7
ACT0114	Y58/12 (Purge control valve)	ME 97-Motor electronics 9.7
ACT0115	R48/1 (Thermostat)	ME 97-Motor electronics 9.7
ACT0116	G2/6 (Alternator)	ME 97-Motor electronics 9.7
ACT0117	Compression test	ME 97-Motor electronics 9.7
ACT0118	A1e17 (EOBD indicator lamp)	CDID2-Common Rail Diesel Injection
ACT0119	G2/7 (Alternator with LIN bus)	CDID2-Common Rail Diesel Injection
ACT0120	M3/5 (Fuel pump with fuel level sensor)	CDID2-Common Rail Diesel Injection
ACT0121	M16/45 (Throttle valve actuator)	CDID2-Common Rail Diesel Injection
ACT0122	R39/3 (Vent line heater element)	CDID2-Common Rail Diesel Injection
ACT0123	R48/2 (Thermostat heating element)	CDID2-Common Rail Diesel Injection
ACT0124	Y27/15 (Exhaust gas recirculation positioner)	CDID2-Common Rail Diesel Injection
ACT0125	Y77/6 (Boost pressure regulator)	CDID2-Common Rail Diesel Injection
ACT0126	Y127/1 (Oil spray nozzle valve)	CDID2-Common Rail Diesel Injection
ACT0127	Perform diagnostic glowing.	CDID2-Common Rail Diesel Injection
ACT0128	Injector shutoff	CDID2-Common Rail Diesel Injection
ACT0129	A27/2 (Viscous fan)	CDI6-Common Rail Diesel Injection
ACT0130	B85/3 (Oxygen sensor)	CDI6-Common Rail Diesel Injection
ACT0131	M16/48 (Throttle valve actuator)	CDI6-Common Rail Diesel Injection
ACT0132	R39/4 (Vent line heater element)	CDI6-Common Rail Diesel Injection
ACT0133	Y27/17 (Exhaust gas recirculation positioner)	CDI6-Common Rail Diesel Injection
ACT0134	Y77/8 (Boost pressure regulator)	CDI6-Common Rail Diesel Injection
ACT0135	Function test Positioning motors	ALWR-Headlamp range adjustment
ACT0136	Test of compression	CDI4-Common Rail Diesel Injection
ACT0137	Test of smooth running control	CDI4-Common Rail Diesel Injection
ACT0138	Test of high pressure pump	CDI4-Common Rail Diesel Injection
ACT0139	Check fuel high pressure system for rail pressure variations.	CDI4-Common Rail Diesel Injection
ACT0140	B2/7 (Hot film mass air flow sensor)	CDI4-Common Rail Diesel Injection
ACT0141	Actuation	CDI4-Common Rail Diesel Injection
ACT0142	M3/3ml (Fuel pump)	CDI4-Common Rail Diesel Injection

ACT0143	M16/42 (Throttle valve actuator)	CDI4-Common Rail Diesel Injection
ACT0144	M72 (Intake port shutoff actuator motor)	CDI4-Common Rail Diesel Injection
ACT0145	Y27/1 (Exhaust gas recirculation positioner)	CDI4-Common Rail Diesel Injection
ACT0146	Hysteresis	CDI4-Common Rail Diesel Injection
ACT0147	Test values at idle speed	CDI4-Common Rail Diesel Injection
ACT0148	Dynamic test	CDI4-Common Rail Diesel Injection
ACT0149	Y94/1 (Quantity control valve)	CDI4-Common Rail Diesel Injection
ACT0150	Check boost pressure control.	CDI3-Common Rail Diesel Injection
ACT0151	Indicator lamp 'MIL'	CDI60-Common Rail Diesel Injection(OM642 EPA13)
ACT0152	Fuel pump	CDI60-Common Rail Diesel Injection(OM642 EPA13)
ACT0153	Fuel filter heater	CDI60-Common Rail Diesel Injection(OM642 EPA13)
ACT0154	Inlet port shutoff	CDI60-Common Rail Diesel Injection(OM642 EPA13)
ACT0155	Throttle valve positioner	CDI60-Common Rail Diesel Injection(OM642 EPA13)
ACT0156	Boost pressure control flap	CDI60-Common Rail Diesel Injection(OM642 EPA13)
ACT0157	Exhaust gas recirculation valve	CDI60-Common Rail Diesel Injection(OM642 EPA13)
ACT0158	Glow output stage	CDI60-Common Rail Diesel Injection(OM642 EPA13)
ACT0159	Generator	CDI60-Common Rail Diesel Injection(OM642 EPA13)
ACT0160	Fan	CDI60-Common Rail Diesel Injection(OM642 EPA13)
ACT0161	Bypass flap 'Exhaust gas recirculation cooler'	CDI60-Common Rail Diesel Injection(OM642 EPA13)
ACT0162	Heating element of vent line 'Crankcase'	CDI60-Common Rail Diesel Injection(OM642 EPA13)
ACT0163	HFM-SFICheck charge air system.	CDI4-Common Rail Diesel Injection
ACT0164	Actuation of exhaust gas recirculation	CDI4-Common Rail Diesel Injection
ACT0165	M72 (Intake port shutoff actuator)	CDI4-Common Rail Diesel Injection
ACT0166	N14/3 (Glow output stage)	CDI4-Common Rail Diesel Injection
ACT0167	Y27/13 (Exhaust gas recirculation cooling solenoid valve)	CDI4-Common Rail Diesel Injection
ACT0168	Y31/14 (Boost pressure control pressure transducer)	CDI4-Common Rail Diesel Injection
ACT0169	Y77 (Waste gate pressure transducer)	CDI4-Common Rail Diesel Injection
ACT0170	Side lamp	SAM-Signal acquisition and actuation module
ACT0171	Low beam	SAM-Signal acquisition and actuation module
ACT0172	Main beam	SAM-Signal acquisition and actuation module
ACT0173	Fog light	SAM-Signal acquisition and actuation module
ACT0174	Turning lamps	SAM-Signal acquisition and actuation module
ACT0175	Rear lamps	SAM-Signal acquisition and actuation module
ACT0176	Body outline lights	SAM-Signal acquisition and actuation module
ACT0177	Side-marker lamps	SAM-Signal acquisition and actuation module
ACT0178	Turn signals	SAM-Signal acquisition and actuation module
ACT0179	Interior lamp	SAM-Signal acquisition and actuation module

ACT0180	Electric vent windows	SAM-Signal acquisition and actuation module
ACT0181	Windscreen wipers, wash systems	SAM-Signal acquisition and actuation module
ACT0182	K13/5 (Heated rear window relay 1)	SAM-Signal acquisition and actuation module
ACT0183	K13/6 (Left heated rear window with EDW relay)	SAM-Signal acquisition and actuation module
ACT0184	K13/7 (Heated windshield relay)	SAM-Signal acquisition and actuation module
ACT0185	Passenger door	SAM-Signal acquisition and actuation module
ACT0186	Rear-end doors	SAM-Signal acquisition and actuation module
ACT0187	Front passenger door power window	SAM-Signal acquisition and actuation module
ACT0188	Relay 'Circuits'	SAM-Signal acquisition and actuation module
ACT0189	M2/2x1 (Control module box blower motor connector)	SAM-Signal acquisition and actuation module
ACT0190	Switch on left front reading lamp.	DBE-Overhead control panel
ACT0191	Switch on right front reading lamp.	DBE-Overhead control panel
ACT0192	Switch on switch lighting.	DBE-Overhead control panel
ACT0193	Actuate tilting/sliding roof.	DBE-Overhead control panel
ACT0194	Arm anti-theft alarm system.	DBE-Overhead control panel
ACT0195	Warning elements	PTS-Parktronic system
ACT0196	Test function lighting of component N72/1s9 (PTS OFF button) by operating.	PTS-Parktronic system
ACT0197	Actuators	STL-Left electric sliding door
ACT0198	UCP Pushbutton	STL-Left electric sliding door
ACT0199	REAR Pushbutton	STL-Left electric sliding door
ACT0200	Gong	STL-Left electric sliding door
ACT0201	Electric sliding door	STL-Left electric sliding door
ACT0202	Anti-pinch protection	STL-Left electric sliding door
ACT0203	A9/1m1 (Air compressor motor)-A9/1y1 (Air compressor pressure relief valve)-Y36 (Level control valve unit)	ENR-Electronic rear axle level control

## Special Function

No.	Model Series	System Name
SP0000	Regeneration of the diesel particulate filter while driving	CDI-Engine electronics 'CR41' for internal combustion engine 'OM651'
SP0001	Teach in diesel particulate filter again.	CDI-Engine electronics 'CR41R' for internal combustion engine 'OM622'
SP0002	Teach in used diesel particulate filter.	CDI-Engine electronics 'CR41R' for internal combustion engine 'OM622'
SP0003	Resetting of learned values of component ''B28/8 (DPF differential pressure sensor)''	CDI-Engine electronics 'CR41R' for internal combustion engine 'OM622'
SP0004	Component B24/8 (Steering angle sensor):Perform calibration.	ESP-Electronic stability program
SP0005	Component B24/15 (Yaw rate, lateral and longitudinal acceleration sensor):Perform calibration.	ESP-Electronic stability program
SP0006	Normalizing routine/Learning process	OCP-Overhead control panel
SP0007	Initialization of system 'EDW anti-theft alarm'	OCP-Overhead control panel
SP0008	Adapt obstruction protection.	SDE-H-Rear sliding roof unit
SP0009	Coding of sliding/tilting roof function of 'automatic operation'	SDE-H-Rear sliding roof unit
SP0010	Perform normalizing of component A32/2m3 (Rear blending air flap actuator motor).	REAR AC-Rear air conditioning
SP0011	Normalizing of positioning motors	AAC-Automatic air conditioning
SP0012	Normalizing	STE-R-ESD [STE] Right electric sliding door
SP0013	Detection of sliding movement	STE-R-ESD [STE] Right electric sliding door
SP0014	Denormalization	STE-R-ESD [STE] Right electric sliding door
SP0015	Level calibration	ENR-Electronic rear axle level control
SP0016	Normalizing of forward/back adjustment	ESA driver-Electric seat adjustment driver (with memory)
SP0017	Normalizing of height adjustment at front	ESA driver-Electric seat adjustment driver (with memory)
SP0018	Normalizing of height adjustment at rear	ESA driver-Electric seat adjustment driver (with memory)
SP0019	Normalizing of head restraint adjustment	ESA driver-Electric seat adjustment driver (with memory)
SP0020	Normalizing of backrest adjustment	ESA driver-Electric seat adjustment driver (with memory)
SP0021	Learning of the throttle valve stop	ME 97-Motor electronics 9.7
SP0022	Drive authorization system	ME 97-Motor electronics 9.7
SP0023	Reset adaptation values.	ME 97-Motor electronics 9.7
SP0024	Learning processes	ME 97-Motor electronics 9.7

SP0025	Activate drive authorization system.	CDID2-Common Rail Diesel Injection
SP0026	Maximum vehicle speed limit	CDID2-Common Rail Diesel Injection
SP0027	Resetting the lambda values	CDID2-Common Rail Diesel Injection
SP0028	Activate fuel pump.	CDID2-Common Rail Diesel Injection
SP0029	Teach in component Charge pressure positioner.	CDID2-Common Rail Diesel Injection
SP0030	Reset fill factor of air filter.	CDID2-Common Rail Diesel Injection
SP0031	Teach in component Glow output stage.	CDID2-Common Rail Diesel Injection
SP0032	Write VIN.	CDID2-Common Rail Diesel Injection
SP0033	Quick teach-in of the zero quantity calibration values at idle	CDID2-Common Rail Diesel Injection
SP0034	Quick teach-in of the zero quantity calibration values while driving	CDID2-Common Rail Diesel Injection
SP0035	Teach in new diesel particulate filter.	CDI6-Common Rail Diesel Injection
SP0036	Teach in component Differential pressure sensor.	CDI6-Common Rail Diesel Injection
SP0037	Exhaust gas recirculation valve teach-in	CDI6-Common Rail Diesel Injection
SP0038	Teach in component Pressure control valve.	CDI6-Common Rail Diesel Injection
SP0039	Reset quantity mean value adaptation data.	CDI6-Common Rail Diesel Injection
SP0040	Reset values for HFM drift compensation.	CDI6-Common Rail Diesel Injection
SP0041	Resetting the adaptation values	CDI6-Common Rail Diesel Injection
SP0042	Teach in component Diesel oxidation catalytic converter.	CDI6-Common Rail Diesel Injection
SP0043	Regeneration of diesel particulate filter when driving	CDI6-Common Rail Diesel Injection
SP0044	Regeneration of diesel particulate filter	CDI6-Common Rail Diesel Injection
SP0045	Reset warning message 'SCR'.	CDI6-Common Rail Diesel Injection
SP0046	Drive authorization	CDI4-Common Rail Diesel Injection
SP0047	Initialization of system 'Air filter'	CDI4-Common Rail Diesel Injection
SP0048	Initialization of system 'Throttle valve positioner'	CDI4-Common Rail Diesel Injection
SP0049	Initialization of system 'Air intake, turbocharging'	CDI4-Common Rail Diesel Injection
SP0050	Initialization of system 'Common Rail'	CDI4-Common Rail Diesel Injection
SP0051	Initialization of system 'Catalytic converter'	CDI4-Common Rail Diesel Injection
SP0052	Initialization of system 'Diesel particulate filter'	CDI4-Common Rail Diesel Injection
SP0053	Limit valuesWorking speed control	CDI3-Common Rail Diesel Injection
SP0054	Resetting the wear values of component 'Hot film mass air flow sensor'	CDI60-Common Rail Diesel Injection(OM642 EPA13)
SP0055	Teach in component Y130 (AdBlue(R) injection valve).	CDI60-Common Rail Diesel Injection(OM642 EPA13)

SP0056	Initialize system 'SCR'.	CDI60-Common Rail Diesel Injection(OM642 EPA13)
SP0057	Teach in component SCR catalytic converter.	CDI60-Common Rail Diesel Injection(OM642 EPA13)
SP0058	Teach in component B16/12 (Temperature sensor upstream of SCR catalytic converter).	CDI60-Common Rail Diesel Injection(OM642 EPA13)
SP0059	Teach-in process after replacement of component Diesel particulate filter	CDI60-Common Rail Diesel Injection(OM642 EPA13)
SP0060	Teaching in the diesel particulate filter after replacing the engine control unit	CDI60-Common Rail Diesel Injection(OM642 EPA13)
SP0061	Detach transport protection.	CDI60-Common Rail Diesel Injection(OM642 EPA13)
SP0062	Personalizing	CDI60-Common Rail Diesel Injection(OM642 EPA13)
SP0063	Activate control module CDI.	CDI60-Common Rail Diesel Injection(OM642 EPA13)
SP0064	Initialize component Hot film mass air flow sensor.	CDI4-Common Rail Diesel Injection
SP0065	Teach in component Throttle valve.	CDI4-Common Rail Diesel Injection
SP0066	Initialize system 'Rail pressure regulation'.	CDI4-Common Rail Diesel Injection
SP0067	Perform normalizing of component Sliding/tilting roof.	DBE-Overhead control panel
SP0068	Perform denormalization of component Sliding/tilting roof.	DBE-Overhead control panel
SP0069	Delete denormalization causes.	DBE-Overhead control panel
SP0070	Inversion of rotation direction	DBE-Overhead control panel
SP0071	Reset alarm sources.	DBE-Overhead control panel
SP0072	Teach in component Battery-operated horn.	DBE-Overhead control panel
SP0073	Teach in component Rain/light sensor.	DBE-Overhead control panel
SP0074	Function 'Silent alarm'	DBE-Overhead control panel
SP0075	Calibration of component B24/15 (Yaw rate, lateral and longitudinal acceleration sensor)	ESP-Electronic stability program
SP0076	Component Sensor 'Yaw rate, lateral and longitudinal acceleration':Perform calibration.	ESP9-Electronic stability program
SP0077	Component B37 (Pedal travel sensor):Perform calibration.	ESP9-Electronic stability program
SP0078	Teach in actuator motors.	KLA-Automatic air conditioning
SP0079	Exchange transfer case.	VG-Transfer case
SP0080	Initialize component A9/1ml (Air compressor motor).	ENR-Electronic rear axle level control
SP0081	Initialize component Y36y2 (Right rear level control valve).	ENR-Electronic rear axle level control
SP0082	Idle speed adjustment(800 l/min)	CDI4-Common Rail Diesel Injection

SP0083	ASSYST settings	IC-Instrument cluster
SP0084	Maintenance light reset	IC-Instrument cluster

*XTOOL*