



Shenzhen Xtooltech Co., Ltd

VAUXHALL Function List V10.70

Tips and Instructions:

The programming function only supports H6PRO, H6PRO Master Edition products.

* This feature is new.

✓ This feature is supported.

This feature is not supported.

※ This feature is partially supported.

Year	Model	Control Unit Groups	System Name	Read ECU Information	Read Trouble	Clear Trouble	Live Data	Actuation Test	Special Functions
2020	Astra-J		Engine Control Module	✓	✓	✓	✓	✓	SP0048,SP0084,SP0091,SP0131,SP0092,SP0019,SP0016,SP0093,SP0210,SP0315,SP0320,SP0306
2020	Astra-J		Transmission Control Module	✓	✓	✓	✓	✓	SP0422
2020	Astra-J		Electronic Brake Control Module	✓	✓	✓	✓	✓	SP0083,SP0394,SP0086
2020	Astra-J		Inflatable Restraint Sensing and Diagnostic Module	✓	✓	✓	✓	✓	SP0347
2020	Astra-J		Body Control Module	✓	✓	✓	✓	✓	SP0047,SP0048,SP0045,SP0378,SP0372,SP0376,SP0046,SP0334,SP0332,SP0455
2020	Astra-J		Instrument Cluster	✓	✓	✓	✓	✓	SP0040
2020	Astra-J		HVAC Control Module	✓	✓	✓	✓	✓	SP0211,SP0040,SP0307
2020	Astra-J		Parking Assist Control Module	✓	✓	✓	✓	✓	SP0040
2020	Astra-J		Power Steering Control Module	✓	✓	✓	✓		SP0088,SP0089,SP0090
2020	Astra-J		Headlamp Control Module	✓	✓	✓	✓	✓	SP0366
2020	Astra-J		Parking Brake Control Module	✓	✓	✓	✓	✓	SP0109
2020	Astra-J		Front Seat Heating Control Module	✓	✓	✓	✓	✓	
2020	Astra-J		Frontview Camera Module	✓	✓	✓	✓	✓	SP0040
2020	Astra-J		Multi-Axis Acceleration Sensor Module	✓	✓	✓			SP0350,SP0086
2020	Astra-J		Steering Wheel Angle Sensor Module	✓	✓	✓			SP0082,SP0083
2020	Astra-J		Radio	✓	✓	✓	✓	✓	

2020	Astra-K		Engine Control Module	√	√	√	√	√	SP0048,SP0084,SP0091,SP0017,SP0598,S P0092,SP0541,SP0019,SP058B,SP0132,SP 058C,SP0587,SP0016,SP0210,SP0320,SP0 58E,SP058F,SP0315,SP0306,SP0385,SP00 18,SP0131,SP0599,SP0130,SP0121,SP010 4,SP0135,SP0136,SP0247,SP0248,SP0595, SP0596,SP0106,SP0049,SP0588,SP0589,S P058A,SP058D
2020	Astra-K		Transmission Control Module	√	√	√	√	√	SP0422,SP0597
2020	Astra-K		Electronic Brake Control Module	√	√	√	√	√	SP0590,SP0591,SP0592,SP0109,SP0593,S P0594,SP0083,SP0460
2020	Astra-K		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	SP0347,SP0086
2020	Astra-K		Body Control Module	√	√	√	√	√	SP0047,SP0048,SP0045,SP0378,SP0372,S P0376,SP0046,SP0334,SP0332,SP0455
2020	Astra-K		Instrument Cluster	√	√	√	√	√	SP0040
2020	Astra-K		HVAC Control Module	√	√	√	√	√	SP0211,SP0040,SP0307
2020	Astra-K		HVAC Controls	√	√	√			
2020	Astra-K		Serial Data Gateway Module	√	√	√			
2020	Astra-K		Keyless Entry Control Module	√	√	√	√	√	
2020	Astra-K		Frontview Camera Module	√	√	√	√		SP0108,SP0368
2020	Astra-K		Steering Column Lock Control Module	√	√	√	√		
2020	Astra-K		Radio	√	√	√	√	√	SP0396,SP059A
2020	Astra-K		Power Steering Control Module	√	√	√	√		SP0090
2020	Astra-K		Headlamp Control Module	√	√	√	√	√	SP0366
2020	Astra-K		Parking Assist Control Module	√	√	√	√	√	SP0450,SP0040
2020	Astra-K		Seat Memory Control Module	√	√	√	√	√	
2020	Astra-K		Liftgate Control Module	√	√	√	√		SP0323,SP0343
2020	Astra-K		Trailer Lighting Control Module	√	√	√	√	√	SP0040
2020	Astra-K		Radio Controls	√	√	√			
2020	Astra-K		Multi-Axis Acceleration Sensor Module	√	√	√			SP0350,SP0086
2020	Astra-K		Active Safety Control Module	√	√	√	√	√	
2020	Astra-K		Long Range Radar Sensor Module	√	√	√	√		SP0440
2020	Astra-K		Serial Data Gateway Module - Processor A	√	√	√			
2020	Astra-K		Serial Data Gateway Module - Processor B	√	√	√			
2020	Astra-K		Power Supply Transformer	√	√	√	√		
2020	Astra-K		Telematics Communication Interface Control Module	√	√	√	√		
2020	Astra-K		Audio Amplifier	√	√	√	√		

2020	Combo-E		Engine Control Module	√	√	√	√	√	SP059D,SP0383,SP0458,SP0312,SP059E,SP059F,SP05A0,SP05A1,SP05A2,SP05A3,SP05A4,SP05A5,SP05A6,SP05A7,SP0085,SP05A8,SP059C,SP05A9,SP0356,SP0358,SP0360,SP0362,SP0098,SP0099,SP0101,SP0285,SP0318,SP0102,SP0299,SP0294,S P0103,SP0464,SP05AA,SP05AB,SP0104,S P0260,SP05AC,SP0247,SP0248,SP05AD,S P0136,SP05AE,SP0249,SP0411,SP0354,S P05AF,SP058F,SP0384
2020	Combo-E		Transmission Control Module	√	√	√	√	√	SP0223,SP05B2,SP0122
2020	Combo-E		Electronic Brake Control Module	√	√	√	√	√	SP0083,SP0461,SP0109,SP0469,SP0438,S P0466,SP0435,SP0456
2020	Combo-E		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√		
2020	Combo-E		Body Control Module	√	√	√	√	√	SP0443,SP0355,SP0019,SP059B,SP059C
2020	Combo-E		Instrument Cluster	√	√	√	√	√	
2020	Combo-E		HVAC Control Module	√	√	√	√	√	
2020	Combo-E		HVAC Controls	√	√	√	√	√	
2020	Combo-E		Steering Column Lock Control Module	√	√	√	√		
2020	Combo-E		Head-Up Display Module	√	√	√	√	√	
2020	Combo-E		Power Supply Transformer	√	√	√			
2020	Combo-E		Cargo Overload Indication Control Module	√	√	√	√		
2020	Combo-E		Telematics Communication Interface Control Module	√	√	√	√	√	
2020	Combo-E		Traction Control Switch	√			√	√	
2020	Combo-E		Info Display Module	√	√	√	√	√	
2020	Combo-E		Infotainment Faceplate Control Module	√					
2020	Combo-E		Left Steering Wheel Controls Switch	√	√	√	√	√	
2020	Combo-E		Power Sounder Content Theft Deterrent Alarm Module	√	√	√	√	√	
2020	Combo-E		Radio	√	√	√	√	√	SP0292
2020	Combo-E		Rain/Ambient Light Sensor Module	√	√	√	√		
2020	Combo-E		Steering Column Control Module	√	√	√	√	√	
2020	Combo-E		Trailer Lighting Control Module	√	√	√	√	√	
2020	Combo-E		Ultrasonic Intrusion Sensor	√	√	√			
2020	Combo-E		Driver Door Switch Panel Control Module	√	√	√	√	√	
2020	Combo-E		Parking Assist Control Module	√	√	√	√	√	
2020	Combo-E		Frontview Camera - Windshield	√	√	√	√	√	SP0368
2020	Combo-E		Passenger Seat Belt Indicator	√			√	√	
2020	Combo-E		Parking Heater Control Module	√			√	√	SP05B0,SP05B1
2020	Combo-E		Power Steering Control Module	√	√	√	√	√	

2020	Combo-E		Special Vehicle Control Module	√	√	√	√		
2020	Combo-E		Battery Sensor Module	√			√		
2020	Combo-E		Rearview Display	√			√	√	
2020	Combo-E		Media Disc Player	√	√	√	√	√	
2020	Combo-E		Fuel-Borne Catalyst Pump	√	√	√		√	SP0384,SP05B3
2020	Crossland X		Engine Control Module	√	√	√	√	√	SP059D,SP0383,SP0458,SP0312,SP059E,SP059F,SP05A0,SP05A1,SP05A2,SP05A3,SP05A4,SP05A5,SP05A6,SP05A7,SP0085,SP05A8,SP0096,SP05B4,SP0128,SP0316,SP059C,SP05A9,SP0356,SP0358,SP0360,SP0362,SP0098,SP0099,SP0101,SP0285,SP0318,SP0102,SP0299,SP0294,SP0103,SP0464,SP05AA,SP05AB,SP0104,SP0260,SP05AC,SP0247,SP0248,SP05AD,SP0136,SP05AE,SP0249,SP0411,SP0354,SP05AF,SP058E,SP0384
2020	Crossland X		Transmission Control Module	√	√	√	√	√	SP0223,SP0122
2020	Crossland X		Electronic Brake Control Module	√	√	√	√	√	SP0083,SP0461,SP0109,SP0469,SP0438,SP0466,SP0435,SP0456
2020	Crossland X		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√		
2020	Crossland X		Body Control Module	√	√	√	√	√	SP0443,SP0355,SP0019,SP059B,SP059C
2020	Crossland X		Instrument Cluster	√	√	√	√	√	
2020	Crossland X		HVAC Control Module	√	√	√	√	√	
2020	Crossland X		HVAC Controls	√	√	√	√	√	
2020	Crossland X		Steering Column Lock Control Module	√	√	√	√		
2020	Crossland X		Head-Up Display Module	√	√	√	√	√	
2020	Crossland X		Power Supply Transformer	√	√	√			
2020	Crossland X		Telematics Communication Interface Control Module	√	√	√	√	√	
2020	Crossland X		Traction Control Switch	√			√		
2020	Crossland X		Info Display Module	√	√	√	√	√	
2020	Crossland X		Infotainment Faceplate Control Module	√	√	√			
2020	Crossland X		Left Front Seat Heating Control Module	√			√	√	
2020	Crossland X		Left Steering Wheel Controls Switch	√	√	√	√	√	
2020	Crossland X		Power Sounder Content Theft Deterrent Alarm Module	√	√	√	√	√	
2020	Crossland X		Rain/Ambient Light Sensor Module	√	√	√	√		
2020	Crossland X		Right Front Seat Heating Control Module	√			√	√	
2020	Crossland X		Steering Column Control Module	√	√	√	√	√	
2020	Crossland X		Trailer Lighting Control Module	√	√	√	√	√	
2020	Crossland X		Ultrasonic Intrusion Sensor	√	√	√			

2020	Crossland X		Radio	√	√	√	√	√	SP0292
2020	Crossland X		Driver Door Switch Panel Control Module	√	√	√	√	√	
2020	Crossland X		Parking Assist Control Module	√	√	√	√	√	
2020	Crossland X		Frontview Camera - Windshield	√	√	√	√	√	SP0368
2020	Crossland X		Passenger Seat Belt Indicator	√			√	√	
2020	Crossland X		Headlamp Control Module	√	√	√	√	√	SP0366
2020	Crossland X		Power Steering Control Module	√	√	√	√	√	
2020	Crossland X		Battery Sensor Module	√			√		
2020	Crossland X		Media Disc Player	√	√	√	√	√	
2020	Crossland X		Fuel-Borne Catalyst Pump	√	√	√		√	SP0384,SP05B3
2020	Grandland X		Engine Control Module	√	√	√	√	√	SP059D,SP0383,SP0458,SP0312,SP059E, SP059F,SP05A0,SP05A1,SP05A2,SP05A3 ,SP05A4,SP05A5,SP05A6,SP05A7,SP008 5,SP05A8,SP059C,SP05B5,SP0316,SP041 2,SP0417,SP0260,SP0353,SP0016,SP058E, SP058F,SP05AC,SP05B6,SP0103,SP0101, SP0122,SP0346,SP0364,SP05A9,SP05B7, SP0098,SP0099,SP05AF,SP05B8,SP0385, SP0285,SP05B9,SP0318,SP0102,SP0299,S P0294,SP05BA,SP05BB,SP05BC,SP0104, SP05BD,SP05BE,SP05BF,SP0384,SP0252 ,SP0247,SP0248,SP05C0,SP0136,SP05AE, SP05C1,SP0356,SP0358,SP0360,SP0362,S P0464,SP05AA,SP05AB,SP05AD,SP0249,
2020	Grandland X		Transmission Control Module	√	√	√	√	√	SP0223,SP0122,SP05B2
2020	Grandland X		Electronic Brake Control Module	√	√	√	√	√	SP0083,SP0461,SP0109,SP0469,SP0438,S P0466,SP0435,SP0456
2020	Grandland X		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√		
2020	Grandland X		Body Control Module	√	√	√	√	√	SP0443,SP0355,SP0019,SP059B,SP059C
2020	Grandland X		Instrument Cluster	√	√	√	√	√	
2020	Grandland X		HVAC Control Module	√	√	√	√	√	
2020	Grandland X		HVAC Controls	√	√	√	√	√	
2020	Grandland X		Steering Column Lock Control Module	√	√	√	√		
2020	Grandland X		Battery Voltage Switching Control Module	√			√		
2020	Grandland X		Driver Seat Control Module	√	√	√	√	√	
2020	Grandland X		Hands-Free Liftgate Sensor Control Module	√					
2020	Grandland X		Info Display Module	√	√	√	√	√	
2020	Grandland X		Infotainment Faceplate Control Module	√					
2020	Grandland X		Left Front Seat Heating Control Module	√			√	√	

2020	Grandland X		Liftgate Control Module	√	√	√	√	√	SP0322
2020	Grandland X		Power Sounder Content Theft Deterrent Alarm Module	√	√	√	√	√	
2020	Grandland X		Rain/Ambient Light Sensor Module	√	√	√	√		
2020	Grandland X		Right Front Seat Heating Control Module	√			√	√	
2020	Grandland X		Seat Lumbar Support Control Module - Driver	√			√	√	
2020	Grandland X		Steering Column Control Module	√	√	√	√	√	
2020	Grandland X		Trailer Lighting Control Module	√	√	√	√	√	
2020	Grandland X		Ultrasonic Intrusion Sensor	√	√	√			
2020	Grandland X		Power Supply Transformer	√	√	√			
2020	Grandland X		Telematics Communication Interface Control Module	√	√	√	√	√	
2020	Grandland X		Traction Control Switch	√			√	√	
2020	Grandland X		Driver Door Switch Panel Control Module	√	√	√	√	√	
2020	Grandland X		Left Windshield Wiper Motor Module	√	√	√	√	√	
2020	Grandland X		Parking Assist Control Module	√	√	√	√	√	
2020	Grandland X		Audio Amplifier	√	√	√		√	
2020	Grandland X		Frontview Camera - Windshield	√	√	√	√	√	SP0368
2020	Grandland X		Long Range Radar Sensor Module	√	√	√	√	√	
2020	Grandland X		Passenger Seat Belt Indicator	√			√	√	
2020	Grandland X		Video Processing Control Module	√	√	√	√	√	SP0367,SP0292
2020	Grandland X		Headlamp Control Module	√	√	√	√	√	SP0366
2020	Grandland X		Power Steering Control Module	√	√	√	√	√	
2020	Grandland X		Battery Sensor Module	√			√		
2020	Grandland X		Pedestrian Alert Sound Control Module	√	√	√	√		
2020	Grandland X		Battery Energy Control Module	√	√	√	√		
2020	Grandland X		Hybrid/EV Powertrain Control Module	√	√	√	√		
2020	Grandland X		Battery Charger	√	√	√	√	√	
2020	Grandland X		Brake Booster Control Module	√	√	√	√	√	
2020	Grandland X		Coolant Heater	√	√	√	√	√	
2020	Grandland X		12V Battery Isolator Module 1	√	√	√	√		
2020	Grandland X		A/C Compressor	√	√	√	√		
2020	Grandland X		12V Battery Isolator Module 2	√	√	√			
2020	Grandland X		Transmission Shift Lever	√	√	√	√		
2020	Grandland X		Media Disc Player	√	√	√	√	√	
2020	Grandland X		Drive Motor 2 Control Module	√	√	√	√	√	
2020	Grandland X		Drive Motor 1 Control Module	√	√	√	√		
2020	Grandland X		Fuel-Borne Catalyst Pump	√	√	√		√	SP0384,SP05B3
2020	Grandland X		Radio	√	√	√	√	√	SP0292
2020	Grandland X		Left Steering Wheel Controls Switch	√	√	√	√	√	

2020	Insignia-B		Engine Control Module	√	√	√	√	√	SP0048,SP0084,SP0091,SP0017,SP0598,SP0092,SP0541,SP0019,SP058B,SP0132,SP058C,SP058F,SP0016,SP0210,SP0320,SP058E,SP058F,SP0315,SP0306,SP0380,SP0390,SP0130,SP0131,SP0129,SP0121,SP0104,SP0135,SP0136,SP0137,SP0252,SP0251,SP0388,SP0309,SP0106,SP0049,SP0133,SP0247,SP0248,SP0357,SP0359,SP0361,SP0363,SP0400
2020	Insignia-B		Transmission Control Module	√	√	√	√	√	SP0223,SP0051,SP0422
2020	Insignia-B		Electronic Brake Control Module	√	√	√	√	√	SP0109,SP0083,SP0460
2020	Insignia-B		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	SP0347,SP0086
2020	Insignia-B		Body Control Module	√	√	√	√	√	SP0047,SP0048,SP0045,SP0378,SP0372,SP0376,SP0046,SP0334,SP0332,SP0455
2020	Insignia-B		Instrument Cluster	√	√	√	√	√	SP0040
2020	Insignia-B		HVAC Control Module	√	√	√	√	√	SP0211,SP0040,SP0307
2020	Insignia-B		HVAC Controls	√	√	√			
2020	Insignia-B		Serial Data Gateway Module	√	√	√			
2020	Insignia-B		Keyless Entry Control Module	√	√	√	√	√	
2020	Insignia-B		Parking Assist Control Module	√	√	√	√	√	SP0040
2020	Insignia-B		Steering Column Lock Control Module	√	√	√	√		
2020	Insignia-B		Rear Differential Clutch Control Module	√	√	√	√	√	SP0206
2020	Insignia-B		Suspension Control Module	√	√	√	√	√	
2020	Insignia-B		Liftgate Control Module	√	√	√	√		SP0323,SP0343
2020	Insignia-B		Seat Memory Control Module - Passenger	√	√	√	√	√	
2020	Insignia-B		Seat Memory Control Module - Driver	√	√	√	√	√	
2020	Insignia-B		Radio Controls	√	√	√			
2020	Insignia-B		Trailer Lighting Control Module	√	√	√	√	√	SP0040
2020	Insignia-B		Power Supply Transformer	√	√	√	√		
2020	Insignia-B		Radio	√	√	√	√	√	SP0396,SP059A
2020	Insignia-B		Audio Amplifier	√	√	√	√		
2020	Insignia-B		Headlamp Control Module	√	√	√	√	√	SP0366
2020	Insignia-B		Power Steering Control Module	√	√	√	√		SP0090
2020	Insignia-B		Video Processing Control Module	√	√	√	√	√	SP0401,SP0367,SP0468,SP0437,SP0292
2020	Insignia-B		Left Side Object Sensor Module	√	√	√		√	
2020	Insignia-B		Frontview Camera Module	√	√	√	√	√	SP0368,SP0108
2020	Insignia-B		Active Safety Control Module	√	√	√	√	√	
2020	Insignia-B		Long Range Radar Sensor Module	√	√	√	√		SP0440
2020	Insignia-B		Telematics Communication Interface Control Module	√	√	√	√		

2020	Movano-B		Engine Control Module	√	√	√	√	√	SP05C2,SP0084,SP0098,SP0099,SP0385,S P0285,SP0318,SP0102,SP05C3,SP0103,SP 05C4,SP0349,SP0104,SP0019,SP0135,SP0 354,SP0284,SP0464,SP0356,SP0358,SP03 60,SP0362,SP0106,SP05C5,SP0276,SP008 5,SP0325,SP0048,SP0380,SP0345,SP0352, SP0040
2020	Movano-B		Transmission Control Module	√	√	√	√	√	SP0314,SP0222,SP0427
2020	Movano-B		Electronic Brake Control Module	√	√	√	√	√	SP0083,SP0289,SP0461,SP0086,SP0082,S P0447,SP0290,SP0460,SP0407,SP0286
2020	Movano-B		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	
2020	Movano-B		Body Control Module	√	√	√	√	√	
2020	Movano-B		Instrument Cluster	√	√	√	√	√	
2020	Movano-B		HVAC Control Module	√	√	√	√	√	SP0211
2020	Movano-B		Serial Data Gateway Module	√	√	√	√	√	
2020	Movano-B		Radio	√	√	√	√	√	SP0292
2020	Movano-B		Serial Data Gateway Module - Secondary	√	√	√	√		
2020	Movano-B		Power Steering Control Module	√	√	√	√		
2020	Movano-B		Mobile Device Wireless Charger Module	√	√	√	√		
2020	Movano-B		Telematics Communication Interface Control Module	√	√	√	√		SP0214
2020	Movano-B		Serial Data Gateway Module 3	√	√	√	√	√	
2020	Movano-B		Auxiliary Body Control Module	√	√	√	√	√	SP0354
2020	Movano-B		Parking Assist Control Module	√	√	√	√	√	
2020	Movano-B		Multifunction Accessory Control Module	√	√	√	√		
2020	Movano-B		Parking Heater Control Module	√	√	√	√	√	SP0451,SP0452
2020	Movano-B		Frontview Camera Module	√	√	√	√		
2020	Movano-B		Long Range Radar Sensor Module	√	√	√	√		SP0440
2020	Movano-B		Reductant Control Module	√	√	√	√	√	SP0297,SP0294,SP0299,SP05C3,SP0135,S P05C6
2019	Adam		Engine Control Module	√	√	√	√	√	SP0048,SP0084,SP0091,SP0385,SP0017,S P0018,SP0131,SP0092,SP0541,SP0019,SP 058B,SP0587,SP0599,SP0016,SP0210,SP0 320,SP0306,SP0598,SP0132,SP058C,SP05 8E,SP058F,SP0315,SP0093
2019	Adam		Electronic Brake Control Module	√	√	√	√	√	SP0082,SP0460,SP0269
2019	Adam		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	SP0347,SP0086
2019	Adam		Body Control Module	√	√	√	√	√	SP0047,SP0048,SP0045,SP0372,SP0046,S P0334,SP0332,SP0455
2019	Adam		Instrument Cluster	√	√	√	√	√	SP0040

2019	Adam		HVAC Control Module	√	√	√	√	√	SP0211,SP0040,SP0307
2019	Adam		Radio	√	√	√	√	√	
2019	Adam		Power Steering Control Module	√	√	√	√		SP0090
2019	Adam		Parking Assist Control Module	√	√	√	√	√	SP0040
2019	Adam		Fuel Injector Control Module	√	√	√	√	√	SP0306
2019	Adam		Telematics Communication Interface Control Module	√	√	√	√	√	SP0216,SP0215
2019	Adam		Chassis Control Module	√	√	√	√	√	SP0016,SP0271,SP0365
2019	Ampera-e		Engine Control Module	√	√	√	√	√	SP0048,SP0095
2019	Ampera-e		Electronic Brake Control Module	√	√	√	√	√	SP0083,SP0460
2019	Ampera-e		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	SP0347,SP0311,SP0086
2019	Ampera-e		Body Control Module	√	√	√	√	√	SP0370,SP0413,SP0335,SP0336,SP0337,SP0338,SP0339,SP0340,SP0341,SP0342,SP0047,SP0048,SP0045,SP0372,SP0378,SP0376,SP0046,SP0334,SP0403,SP0332
2019	Ampera-e		Instrument Cluster	√	√	√	√	√	SP0040
2019	Ampera-e		HVAC Control Module	√	√	√	√	√	SP0211,SP0307
2019	Ampera-e		Brake Booster Control Module	√	√	√	√		
2019	Ampera-e		Power Steering Control Module	√	√	√	√		SP0090
2019	Ampera-e		Radio	√	√	√	√	√	
2019	Ampera-e		Trailer Lighting Control Module	√	√	√	√	√	SP0040
2019	Ampera-e		Video Processing Control Module	√	√	√	√	√	SP0401,SP0367,SP0468,SP0437,SP0292
2019	Ampera-e		Chassis Control Module	√	√	√	√	√	
2019	Ampera-e		Parking Assist Control Module	√	√	√	√	√	SP0040
2019	Ampera-e		Pedestrian Alert Sound Control Module	√	√	√	√	√	
2019	Ampera-e		Transmission Range Control Module	√			√		SP0220,SP0254,SP0219
2019	Ampera-e		Battery Energy Control Module	√			√		
2019	Ampera-e		Electric A/C Compressor Control Module	√					
2019	Ampera-e		Telematics Communication Interface Control Module	√	√	√	√	√	SP0216,SP0215
2019	Ampera-e		Power Line Communication Module	√			√		
2019	Ampera-e		Frontview Camera Module	√	√	√	√	√	SP0368
2019	Ampera-e		Left Side Object Sensor Module	√	√	√		√	
2019	Ampera-e		Steering Column Lock Control Module	√	√	√	√		
2019	Ampera-e		Hybrid/EV Powertrain Control Module 1	√	√	√	√	√	SP05C7
2019	Ampera-e		Hybrid/EV Powertrain Control Module 2	√	√	√	√	√	SP0303,SP0444,SP0255,SP0301,SP0302,SP0305
2019	Ampera-e		Keyless Entry Control Module	√	√	√	√	√	
2019	Ampera-e		Serial Data Gateway Module - Processor A	√	√	√			
2019	Ampera-e		Serial Data Gateway Module - Processor B	√	√	√			

2019	Astra-J		Engine Control Module	√	√	√	√	√	SP0048,SP0084,SP0091,SP0131,SP0092,SP0019,SP0016,SP0093,SP0210,SP0315,SP0320,SP0306
2019	Astra-J		Transmission Control Module	√	√	√	√	√	SP0422
2019	Astra-J		Electronic Brake Control Module	√	√	√	√	√	SP0083,SP0394,SP0086
2019	Astra-J		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	SP0347
2019	Astra-J		Body Control Module	√	√	√	√	√	SP0047,SP0048,SP0045,SP0378,SP0372,SP0376,SP0046,SP0334,SP0332,SP0455
2019	Astra-J		Instrument Cluster	√	√	√	√	√	SP0040
2019	Astra-J		HVAC Control Module	√	√	√	√	√	SP0211,SP0040,SP0307
2019	Astra-J		Front Seat Heating Control Module	√	√	√	√	√	
2019	Astra-J		Parking Brake Control Module	√	√	√	√	√	SP0109
2019	Astra-J		Power Steering Control Module	√	√	√	√		SP0088,SP0089,SP0090
2019	Astra-J		Radio	√	√	√	√	√	
2019	Astra-J		Headlamp Control Module	√	√	√	√	√	SP0366
2019	Astra-J		Parking Assist Control Module	√	√	√	√	√	SP0040
2019	Astra-J		Multi-Axis Acceleration Sensor Module	√	√	√			SP0350,SP0086
2019	Astra-J		Steering Wheel Angle Sensor Module	√	√	√			SP0082,SP0083
2019	Astra-J		Frontview Camera Module	√	√	√	√	√	SP0040
2019	Astra-K		Engine Control Module	√	√	√	√	√	SP0084,SP0380,SP0390,SP0130,SP0085,SP0092,SP0131,SP0048,SP0129,SP0121,SP0104,SP0019,SP0132,SP0016,SP0135,SP0136,SP0137,SP0252,SP0251,SP0388,SP0106,SP0049,SP0306,SP0091,SP0017,SP0598,SP0541,SP058B,SP058C,SP0587,SP0210,SP0320,SP058E,SP058F,SP0315,SP0385,SP0019,SP0500
2019	Astra-K		Transmission Control Module	√	√	√	√	√	SP0422
2019	Astra-K		Electronic Brake Control Module	√	√	√	√	√	SP0109,SP0083,SP0460
2019	Astra-K		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	SP0347,SP0086
2019	Astra-K		Body Control Module	√	√	√	√	√	SP0047,SP0048,SP0045,SP0378,SP0372,SP0376,SP0046,SP0334,SP0332,SP0455
2019	Astra-K		Instrument Cluster	√	√	√	√	√	SP0040
2019	Astra-K		HVAC Control Module	√	√	√	√	√	SP0211,SP0040,SP0307
2019	Astra-K		HVAC Controls	√	√	√			
2019	Astra-K		Serial Data Gateway Module	√	√	√			
2019	Astra-K		Power Steering Control Module	√	√	√	√		SP0090
2019	Astra-K		Radio	√	√	√	√	√	SP0396,SP0213
2019	Astra-K		Seat Memory Control Module	√	√	√	√	√	

2019	Astra-K		Radio Controls	√	√	√			
2019	Astra-K		Trailer Lighting Control Module	√	√	√	√	√	SP0040
2019	Astra-K		Power Supply Transformer	√	√	√	√		
2019	Astra-K		Fuel Injector Control Module	√	√	√	√	√	SP0306
2019	Astra-K		Headlamp Control Module	√	√	√	√	√	SP0366
2019	Astra-K		Human Machine Interface Control Module	√	√	√	√	√	SP0326
2019	Astra-K		Telematics Communication Interface Control Module	√	√	√	√	√	SP0216,SP0215
2019	Astra-K		Liftgate Control Module	√	√	√	√		SP0323,SP0343
2019	Astra-K		Parking Assist Control Module	√	√	√	√	√	SP0450,SP0040
2019	Astra-K		Active Safety Control Module	√	√	√	√	√	
2019	Astra-K		Long Range Radar Sensor Module	√	√	√	√		SP0440
2019	Astra-K		Frontview Camera Module	√	√	√	√		SP0108,SP0368,SP0401
2019	Astra-K		Steering Column Lock Control Module	√	√	√	√		
2019	Astra-K		Multi-Axis Acceleration Sensor Module	√	√	√			SP0350,SP0086
2019	Astra-K		Keyless Entry Control Module	√	√	√	√	√	
2019	Cascada		Engine Control Module	√	√	√	√	√	SP0048,SP0084,SP0091,SP0017,SP0598,S P0092,SP0541,SP0019,SP058B,SP0132,SP 058C,SP0587,SP0016,SP0210,SP0320,SP0 58E,SP058F,SP0315,SP0306
2019	Cascada		Transmission Control Module	√	√	√	√	√	SP0422
2019	Cascada		Electronic Brake Control Module	√	√	√	√	√	SP0083,SP0394,SP0086
2019	Cascada		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	SP0347,SP0086
2019	Cascada		Body Control Module	√	√	√	√	√	SP0047,SP0048,SP0045,SP0378,SP0372,S P0376,SP0046,SP0334,SP0332,SP0455
2019	Cascada		Instrument Cluster	√	√	√	√	√	SP0040
2019	Cascada		HVAC Control Module	√	√	√	√	√	SP0211,SP0040,SP0307
2019	Cascada		Folding Top Control Module	√	√	√	√	√	SP0040,SP0207,SP0208
2019	Cascada		Front Seat Heating Control Module	√	√	√	√	√	
2019	Cascada		Parking Brake Control Module	√	√	√	√	√	SP0109
2019	Cascada		Power Steering Control Module	√	√	√	√		SP0088,SP0089,SP0090
2019	Cascada		Radio	√	√	√	√	√	
2019	Cascada		Headlamp Control Module	√	√	√	√	√	SP0366
2019	Cascada		Suspension Control Module	√	√	√	√	√	
2019	Cascada		Digital Radio Receiver Control Module	√	√	√	√	√	SP0040
2019	Cascada		Telematics Communication Interface Control Module	√	√	√	√	√	SP0216,SP0215
2019	Cascada		Parking Assist Control Module	√	√	√	√	√	SP0040
2019	Cascada		Chassis Control Module	√	√	√	√	√	SP0016,SP0271,SP0365
2019	Cascada		Steering Wheel Angle Sensor Module	√	√	√			SP0082,SP0083

2019	Cascada		Frontview Camera Module	√	√	√	√	√	SP0108,SP0368,SP0040
2019	Cascada		Multi-Axis Acceleration Sensor Module	√	√	√			SP0350,SP0086
2019	Combo-E		Engine Control Module	√	√	√	√	√	SP059D,SP0383,SP0458,SP0312,SP059E, SP059F,SP05A0,SP05A1,SP05A2,SP05A3 ,SP05A4,SP05A5,SP05A6,SP05A7,SP008 5,SP05A8,SP059C,SP05A9,SP0356,SP035 8,SP0360,SP0362,SP0098,SP0099,SP0101, SP0285,SP0318,SP0102,SP0299,SP0294,S P0103,SP0464,SP05AA,SP05AB,SP0104,S P0260,SP05AC,SP0247,SP0248,SP05AD,S P0136,SP05AE,SP0249,SP0411,SP0354,S P05AF,SP058F,SP0384,SP0047,SP0129,S P0135,SP05C8,SP05C6,SP0016,SP05C9,S P05BE,SP05C1,SP05C0,SP05BB
2019	Combo-E		Transmission Control Module	√	√	√	√	√	SP0223,SP05B2,SP0122
2019	Combo-E		Electronic Brake Control Module	√	√	√	√	√	SP0083,SP0461,SP0109,SP0469,SP0438,S P0466,SP0435,SP0456
2019	Combo-E		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√		
2019	Combo-E		Body Control Module	√	√	√	√	√	SP0443,SP0355,SP0019,SP059B,SP059C
2019	Combo-E		Instrument Cluster	√	√	√	√	√	
2019	Combo-E		HVAC Control Module	√	√	√	√	√	
2019	Combo-E		HVAC Controls	√	√	√	√	√	
2019	Combo-E		Traction Control Switch	√			√	√	
2019	Combo-E		Driver Door Switch Panel Control Module	√	√	√	√	√	
2019	Combo-E		Power Steering Control Module	√	√	√	√	√	
2019	Combo-E		Info Display Module	√	√	√	√	√	
2019	Combo-E		Radio	√	√	√	√	√	SP0292
2019	Combo-E		Head-Up Display Module	√	√	√	√	√	
2019	Combo-E		Battery Sensor Module	√			√		
2019	Combo-E		Power Sounder Content Theft Deterrent Alarm Module	√	√	√	√	√	
2019	Combo-E		Rain/Ambient Light Sensor Module	√	√	√	√		
2019	Combo-E		Ultrasonic Intrusion Sensor	√	√	√			
2019	Combo-E		Telematics Communication Interface Control Module	√	√	√	√	√	
2019	Combo-E		Steering Column Lock Control Module	√	√	√	√		
2019	Combo-E		Steering Column Control Module	√	√	√	√	√	
2019	Combo-E		Passenger Seat Belt Indicator	√			√	√	
2019	Combo-E		Trailer Lighting Control Module	√	√	√	√	√	
2019	Combo-E		Left Steering Wheel Controls Switch	√	√	√	√	√	
2019	Combo-E		Parking Assist Control Module	√	√	√	√	√	

2019	Combo-E		Parking Heater Control Module	√			√	√	SP05B0,SP05B1
2019	Combo-E		Frontview Camera - Windshield	√	√	√	√	√	SP0368
2019	Combo-E		Power Supply Transformer	√	√	√			
2019	Combo-E		Special Vehicle Control Module	√	√	√	√		
2019	Combo-E		Media Disc Player	√	√	√	√	√	
2019	Combo-E		Infotainment Faceplate Control Module	√					
2019	Combo-E		Fuel-Borne Catalyst Pump	√	√	√		√	SP0384,SP05B3
2019	Combo-E		Rearview Display	√			√	√	
2019	Combo-E		Cargo Overload Indication Control Module	√	√	√	√		
2019	Corsa-E		Engine Control Module	√	√	√	√	√	SP0048,SP0084,SP0091,SP0385,SP0017,SP0018,SP0131,SP0092,SP0541,SP0019,SP058B,SP0587,SP0599,SP0016,SP0210,SP0320,SP0306,SP0598,SP0132,SP058C,SP058E,SP058F,SP0315,SP0093
2019	Corsa-E		Transmission Control Module	√	√	√	√	√	SP0422
2019	Corsa-E		Electronic Brake Control Module	√	√	√	√	√	SP0082,SP0460,SP0269
2019	Corsa-E		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	SP0347,SP0086
2019	Corsa-E		Body Control Module	√	√	√	√	√	SP0047,SP0048,SP0045,SP0372,SP0046,SP0334,SP0332,SP0455
2019	Corsa-E		Instrument Cluster	√	√	√	√	√	SP0040
2019	Corsa-E		HVAC Control Module	√	√	√	√	√	SP0211,SP0040,SP0307
2019	Corsa-E		Trailer Lighting Control Module	√	√	√	√	√	SP0040
2019	Corsa-E		Power Steering Control Module	√	√	√	√		SP0090
2019	Corsa-E		Radio	√	√	√	√	√	
2019	Corsa-E		Fuel Injector Control Module	√	√	√	√	√	SP0306
2019	Corsa-E		Telematics Communication Interface Control Module	√	√	√	√	√	SP0216,SP0215
2019	Corsa-E		Parking Assist Control Module	√	√	√	√	√	SP0040
2019	Corsa-E		Frontview Camera Module	√	√	√	√	√	SP0108,SP0368
2019	Corsa-E		Chassis Control Module	√	√	√	√	√	SP0016,SP0271,SP0365

2019	Crossland X		Engine Control Module	√	√	√	√	√	SP059D,SP0383,SP0458,SP0312,SP059E,SP059F,SP05A0,SP05A1,SP05A2,SP05A3,SP05A4,SP05A5,SP05A6,SP05A7,SP0085,SP05A8,SP0096,SP05B4,SP0128,SP0316,SP059C,SP05A9,SP0356,SP0358,SP0360,SP0362,SP0098,SP0099,SP0101,SP0285,SP0318,SP0102,SP0299,SP0294,SP0103,SP0464,SP05AA,SP05AB,SP0104,SP0260,SP05AC,SP0247,SP0248,SP05AD,SP0136,SP05AE,SP0249,SP0411,SP0354,SP05AF,SP058E,SP0384
2019	Crossland X		Transmission Control Module	√	√	√	√	√	SP0223,SP0122
2019	Crossland X		Electronic Brake Control Module	√	√	√	√	√	SP0083,SP0461,SP0109,SP0469,SP0438,SP0466,SP0435,SP0456
2019	Crossland X		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√		
2019	Crossland X		Body Control Module	√	√	√	√	√	SP0443,SP0355,SP0019,SP059B,SP059C
2019	Crossland X		Instrument Cluster	√	√	√	√	√	
2019	Crossland X		HVAC Control Module	√	√	√	√	√	
2019	Crossland X		HVAC Controls	√	√	√	√	√	
2019	Crossland X		Trailer Lighting Control Module	√	√	√	√	√	
2019	Crossland X		Rain/Ambient Light Sensor Module	√	√	√	√		
2019	Crossland X		Power Sounder Content Theft Deterrent Alarm Module	√	√	√	√	√	
2019	Crossland X		Ultrasonic Intrusion Sensor	√	√	√			
2019	Crossland X		Left Front Seat Heating Control Module	√			√	√	
2019	Crossland X		Power Steering Control Module	√	√	√	√	√	
2019	Crossland X		Right Front Seat Heating Control Module	√			√	√	
2019	Crossland X		Head-Up Display Module	√	√	√	√	√	
2019	Crossland X		Power Supply Transformer	√	√	√			
2019	Crossland X		Fuel Injector Control Module	√	√	√			
2019	Crossland X		Headlamp Control Module	√	√	√	√	√	SP0366
2019	Crossland X		Traction Control Switch	√			√		
2019	Crossland X		Left Steering Wheel Controls Switch	√	√	√	√	√	
2019	Crossland X		Parking Assist Control Module	√	√	√	√	√	
2019	Crossland X		Radio	√	√	√	√	√	SP0292
2019	Crossland X		Info Display Module	√	√	√	√	√	
2019	Crossland X		Infotainment Faceplate Control Module	√	√	√			
2019	Crossland X		Driver Door Switch Panel Control Module	√	√	√	√	√	
2019	Crossland X		Frontview Camera - Windshield	√	√	√	√	√	SP0368
2019	Crossland X		Passenger Seat Belt Indicator	√			√	√	

2019	Crossland X		Steering Column Lock Control Module	√	√	√	√		
2019	Crossland X		Steering Column Control Module	√	√	√	√	√	
2019	Crossland X		Battery Sensor Module	√			√		
2019	Crossland X		Telematics Communication Interface Control Module	√	√	√	√	√	
2019	Crossland X		Media Disc Player	√	√	√	√	√	
2019	Crossland X		Fuel-Borne Catalyst Pump	√	√	√		√	SP0384,SP05B3
2019	Grandland X		Engine Control Module	√	√	√	√	√	SP05A9,SP05B7,SP0098,SP0099,SP0101,SP05AF,SP05B8,SP0385,SP0285,SP05B9,SP0318,SP0102,SP0299,SP0294,SP05BA,SP0103,SP05BB,SP0312,SP059E,SP05BC,SP0104,SP05BD,SP05BE,SP05BF,SP0384,SP0252,SP0247,SP0248,SP05C0,SP0136,SP05AE,SP05C1,SP0356,SP0358,SP0360,SP0362,SP059F,SP059D,SP0383,SP0458,SP05A0,SP05A1,SP05A2,SP05A3,SP05A4,SP05A5,SP05A6,SP05A7,SP0085,SP05A8,SP0316,SP0122,SP0346,SP0412,SP0364,SP0417,SP0260,SP0353,SP059C,SP0464,SP05AA,SP05AB,SP05AC,SP05AD,SP0249,SP0411,SP0354,SP05B5,SP0016,SP058E,S
2019	Grandland X		Transmission Control Module	√	√	√	√	√	SP0223,SP0122,SP05B2
2019	Grandland X		Electronic Brake Control Module	√	√	√	√	√	SP0083,SP0461,SP0109,SP0469,SP0438,SP0466,SP0435,SP0456
2019	Grandland X		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√		
2019	Grandland X		Body Control Module	√	√	√	√	√	SP0443,SP0355,SP0019,SP059B,SP059C
2019	Grandland X		Instrument Cluster	√	√	√	√	√	
2019	Grandland X		HVAC Control Module	√	√	√	√	√	
2019	Grandland X		HVAC Controls	√	√	√	√	√	
2019	Grandland X		Trailer Lighting Control Module	√	√	√	√	√	
2019	Grandland X		Video Processing Control Module	√	√	√	√	√	SP0367,SP0292
2019	Grandland X		Battery Voltage Switching Control Module	√			√		
2019	Grandland X		Power Sounder Content Theft Deterrent Alarm Module	√	√	√	√	√	
2019	Grandland X		Rain/Ambient Light Sensor Module	√	√	√	√		
2019	Grandland X		Ultrasonic Intrusion Sensor	√	√	√			
2019	Grandland X		Driver Seat Control Module	√	√	√	√	√	
2019	Grandland X		Left Front Seat Heating Control Module	√			√	√	
2019	Grandland X		Power Steering Control Module	√	√	√	√	√	
2019	Grandland X		Right Front Seat Heating Control Module	√			√	√	
2019	Grandland X		Seat Lumbar Support Control Module - Driver	√			√	√	

2019	Grandland X		Power Supply Transformer	√	√	√			
2019	Grandland X		Auxiliary Body Control Module	√	√	√	√	√	
2019	Grandland X		Headlamp Control Module	√	√	√	√	√	SP0366
2019	Grandland X		Left Steering Wheel Controls Switch	√	√	√	√	√	
2019	Grandland X		Telematics Communication Interface Control Module	√	√	√	√	√	
2019	Grandland X		Traction Control Switch	√			√	√	
2019	Grandland X		Hands-Free Liftgate Sensor Control Module	√					
2019	Grandland X		Liftgate Control Module	√	√	√	√	√	SP0322
2019	Grandland X		Parking Assist Control Module	√	√	√	√	√	
2019	Grandland X		Radio	√	√	√	√	√	SP0292
2019	Grandland X		Info Display Module	√	√	√	√	√	
2019	Grandland X		Infotainment Faceplate Control Module	√					
2019	Grandland X		Driver Door Switch Panel Control Module	√	√	√	√	√	
2019	Grandland X		Left Windshield Wiper Motor Module	√	√	√	√	√	
2019	Grandland X		Frontview Camera - Windshield	√	√	√	√	√	SP0368
2019	Grandland X		Steering Column Lock Control Module	√	√	√	√		
2019	Grandland X		Steering Column Control Module	√	√	√	√	√	
2019	Grandland X		Battery Sensor Module	√			√		
2019	Grandland X		Long Range Radar Sensor Module	√	√	√	√	√	
2019	Grandland X		Audio Amplifier	√	√	√		√	
2019	Grandland X		Passenger Seat Belt Indicator	√			√	√	
2019	Grandland X		Fuel-Borne Catalyst Pump	√	√	√		√	SP0384,SP05B3
2019	Grandland X		Media Disc Player	√	√	√	√	√	
2019	Insignia-B		Engine Control Module	√	√	√	√	√	SP0084,SP0380,SP0390,SP0130,SP0092,SP0131,SP0048,SP0129,SP0121,SP0104,SP0019,SP0132,SP0016,SP0135,SP0136,SP0137,SP0252,SP0251,SP0388,SP0309,SP0106,SP0049,SP0306,SP0133,SP0247,SP0248,SP0357,SP0359,SP0361,SP0363,SP0400,SP0091,SP0017,SP0598,SP0541,SP058B,SP058C,SP0587,SP0210,SP0320,SP058E,SP058F,SP0315
2019	Insignia-B		Transmission Control Module	√	√	√	√	√	SP0223,SP0051,SP0422
2019	Insignia-B		Electronic Brake Control Module	√	√	√	√	√	SP0109,SP0083,SP0460
2019	Insignia-B		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	SP0347,SP0086
2019	Insignia-B		Body Control Module	√	√	√	√	√	SP0047,SP0048,SP0045,SP0378,SP0372,SP0376,SP0046,SP0334,SP0332,SP0455
2019	Insignia-B		Instrument Cluster	√	√	√	√	√	SP0040
2019	Insignia-B		HVAC Control Module	√	√	√	√	√	SP0211,SP0040,SP0307

2019	Insignia-B		HVAC Controls	√	√	√			
2019	Insignia-B		Serial Data Gateway Module	√	√	√			
2019	Insignia-B		Radio Controls	√	√	√			
2019	Insignia-B		Trailer Lighting Control Module	√	√	√	√	√	SP0040
2019	Insignia-B		Video Processing Control Module	√	√	√	√	√	SP0401,SP0367,SP0468,SP0437,SP0292
2019	Insignia-B		Power Steering Control Module	√	√	√	√		SP0090
2019	Insignia-B		Radio	√	√	√	√	√	SP0396,SP059A
2019	Insignia-B		Seat Memory Control Module - Driver	√	√	√	√	√	
2019	Insignia-B		Seat Memory Control Module - Passenger	√	√	√	√	√	
2019	Insignia-B		Power Supply Transformer	√	√	√	√		
2019	Insignia-B		Headlamp Control Module	√	√	√	√	√	SP0366
2019	Insignia-B		Rear Differential Clutch Control Module	√	√	√	√	√	SP0206
2019	Insignia-B		Suspension Control Module	√	√	√	√	√	
2019	Insignia-B		Liftgate Control Module	√	√	√	√		SP0323,SP0343
2019	Insignia-B		Parking Assist Control Module	√	√	√	√	√	SP0040
2019	Insignia-B		Steering Column Lock Control Module	√	√	√	√		
2019	Insignia-B		Keyless Entry Control Module	√	√	√	√	√	
2019	Insignia-B		Left Side Object Sensor Module	√	√	√		√	
2019	Insignia-B		Long Range Radar Sensor Module	√	√	√	√		SP0440
2019	Insignia-B		Active Safety Control Module	√	√	√	√	√	
2019	Insignia-B		Frontview Camera Module	√	√	√	√	√	SP0368,SP0108
2019	Insignia-B		Audio Amplifier	√	√	√	√		
2019	Insignia-B		Telematics Communication Interface Control Module	√	√	√	√	√	SP0216,SP0215
2019	Karl / Viva		Engine Control Module	√	√	√	√	√	SP0048,SP0084,SP0091,SP0092,SP0019,S P0016,SP0093,SP0315,SP0210,SP0306
2019	Karl / Viva		Electronic Brake Control Module	√	√	√	√	√	SP0083
2019	Karl / Viva		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	SP0347,SP0086
2019	Karl / Viva		Body Control Module	√	√	√	√	√	SP0047,SP0048,SP0045,SP0378,SP0372,S P0376,SP0046,SP0334,SP0332,SP0455
2019	Karl / Viva		Instrument Cluster	√	√	√	√	√	SP0040
2019	Karl / Viva		HVAC Control Module	√	√	√	√	√	SP0211,SP0040,SP0307
2019	Karl / Viva		HVAC Controls	√	√	√			
2019	Karl / Viva		Serial Data Gateway Module	√	√	√			
2019	Karl / Viva		Telematics Communication Interface Control Module	√	√	√	√	√	SP0216,SP0215
2019	Karl / Viva		Power Steering Control Module	√	√	√	√		SP0090
2019	Karl / Viva		Radio	√	√	√	√	√	SP0396
2019	Karl / Viva		Parking Assist Control Module	√	√	√	√	√	SP0450,SP0040
2019	Karl / Viva		Frontview Camera Module	√	√	√	√		SP0108,SP0368,SP0401

2019	Mokka		Engine Control Module	√	√	√	√	√	SP0048,SP0084,SP0091,SP0131,SP0092,SP0019,SP0016,SP0093,SP0210,SP0315,SP0320,SP0306,SP0380,SP0390,SP0130,SP0085,SP0129,SP0121,SP0104,SP0132,SP0135,SP0136,SP0137,SP0252,SP0251,SP0380,SP0106,SP0040
2019	Mokka		Transmission Control Module	√	√	√	√	√	SP0422
2019	Mokka		Electronic Brake Control Module	√	√	√	√	√	SP0083
2019	Mokka		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	SP0347,SP0086
2019	Mokka		Body Control Module	√	√	√	√	√	SP0047,SP0048,SP0045,SP0378,SP0372,SP0376,SP0046,SP0334,SP0332,SP0455
2019	Mokka		Instrument Cluster	√	√	√	√	√	SP0040
2019	Mokka		HVAC Control Module	√	√	√	√	√	SP0211,SP0040,SP0307
2019	Mokka		Serial Data Gateway Module	√	√	√			
2019	Mokka		Radio Controls	√	√	√			
2019	Mokka		Trailer Lighting Control Module	√	√	√	√	√	SP0040
2019	Mokka		Power Supply Transformer	√	√	√	√		
2019	Mokka		Front Seat Heating Control Module	√	√	√	√	√	
2019	Mokka		Power Steering Control Module	√	√	√	√		SP0377
2019	Mokka		Radio	√	√	√	√	√	SP0396,SP0213
2019	Mokka		Rear Differential Clutch Control Module	√	√	√	√		SP0206,SP05CA
2019	Mokka		Human Machine Interface Control Module	√	√	√	√	√	SP0326
2019	Mokka		Fuel Injector Control Module	√			√	√	
2019	Mokka		Headlamp Control Module	√	√	√	√	√	SP0366
2019	Mokka		Amplifier	√	√	√	√		
2019	Mokka		Parking Assist Control Module	√	√	√	√	√	SP0040
2019	Mokka		Steering Wheel Angle Sensor Module	√	√	√			SP0082,SP0083
2019	Mokka		Frontview Camera Module	√	√	√	√	√	SP0108,SP0368,SP0040
2019	Mokka		Steering Column Lock Control Module	√	√	√	√		
2019	Mokka		Keyless Entry Control Module	√	√	√	√	√	
2019	Mokka		Telematics Communication Interface Control Module	√	√	√	√	√	SP0216,SP0215
2019	Movano-B		Engine Control Module	√	√	√	√	√	SP0084,SP0098,SP0276,SP0099,SP0385,SP0285,SP0085,SP0318,SP0102,SP05C4,SP0104,SP0354,SP0349,SP0284,SP0464,SP0356,SP0358,SP0360,SP0362,SP0106,SP0325,SP0048,SP0380,SP0345,SP0352,SP0103,SP0040
2019	Movano-B		Transmission Control Module	√	√	√	√	√	SP0314,SP0222,SP0427
2019	Movano-B		Electronic Brake Control Module	√	√	√	√	√	SP0083,SP0289,SP0461,SP0086,SP0082,SP0447,SP0290,SP0460,SP0407,SP0286

2019	Movano-B		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	
2019	Movano-B		Body Control Module	√	√	√	√	√	
2019	Movano-B		Instrument Cluster	√	√	√	√	√	
2019	Movano-B		HVAC Control Module	√	√	√	√	√	SP0211
2019	Movano-B		Serial Data Gateway Module	√	√	√	√	√	
2019	Movano-B		Info Display Module	√	√	√	√	√	
2019	Movano-B		Radio	√	√	√	√	√	SP0292
2019	Movano-B		Power Steering Control Module	√	√	√	√		
2019	Movano-B		Multifunction Accessory Control Module	√	√	√	√		
2019	Movano-B		Parking Assist Control Module	√	√	√	√		
2019	Movano-B		Telematics Communication Interface Control Module	√	√	√	√		SP0214
2019	Movano-B		Auxiliary Body Control Module	√	√	√	√	√	SP0354
2019	Movano-B		Reductant Control Module	√	√	√	√	√	SP0297,SP0294,SP0299,SP05C3,SP0135
2019	Movano-B		Frontview Camera Module	√	√	√	√		
2019	Movano-B		Tire Pressure Indicator Module	√	√	√	√		SP0402,SP0467,SP0436,SP0434,SP0465
2019	Movano-B		Long Range Radar Sensor Module	√	√	√	√		SP0440
2019	Movano-B		Serial Data Gateway Module - Secondary	√	√	√	√		
2019	Vivaro-B		Engine Control Module	√	√	√	√	√	SP0325,SP0048,SP0380,SP0098,SP0271,SP0276,SP0273,SP0274,SP0385,SP0285,SP0085,SP0318,SP0319,SP0102,SP0352,SP0103,SP0104,SP0354,SP0432,SP0349,SP0464,SP0284,SP0049,SP0106
2019	Vivaro-B		Electronic Brake Control Module	√	√	√	√	√	SP0083,SP0289,SP0461,SP0082,SP0290,SP0460,SP0447,SP0286,SP0407
2019	Vivaro-B		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√		
2019	Vivaro-B		Body Control Module	√	√	√	√	√	SP0402,SP0467,SP0436,SP0434,SP0465
2019	Vivaro-B		Instrument Cluster	√	√	√	√	√	
2019	Vivaro-B		HVAC Control Module	√	√	√	√	√	
2019	Vivaro-B		Serial Data Gateway Module	√	√	√	√	√	
2019	Vivaro-B		Info Display Module	√	√	√	√	√	
2019	Vivaro-B		Power Steering Control Module	√	√	√	√		
2019	Vivaro-B		Radio	√	√	√	√	√	SP0292
2019	Vivaro-B		Parking Heater Control Module	√	√	√	√	√	SP0451,SP0452
2019	Vivaro-B		Multifunction Accessory Control Module	√	√	√	√		
2019	Vivaro-B		Parking Assist Control Module	√	√	√	√	√	SP0423,SP0277
2019	Vivaro-B		Telematics Communication Interface Control Module	√	√	√	√		SP0214
2019	Vivaro-B		Auxiliary Body Control Module	√	√	√	√	√	SP0239,SP0354
2019	Vivaro-B		Reductant Control Module	√	√	√	√	√	SP0297,SP0294,SP0299,SP05C3,SP0135

2019	Vivaro-B		Keyless Entry Control Module	√	√	√	√	√	
2019	Zafira-C		Engine Control Module	√	√	√	√	√	SP0048,SP0084,SP0091,SP0017,SP0598,S P0092,SP0541,SP0019,SP058B,SP0132,SP 058C,SP0587,SP0016,SP0210,SP0320,SP0 58E,SP058F,SP0315,SP0306,SP0380,SP03 90,SP0130,SP0085,SP0131,SP0129,SP012 1,SP0104,SP0135,SP0136,SP0137,SP0247, SP0248,SP0252,SP0251,SP0388,SP0106,S P0049,SP0309,SP0357,SP0359,SP0361,SP 0363,SP0400
2019	Zafira-C		Transmission Control Module	√	√	√	√	√	SP0223,SP0122,SP0422
2019	Zafira-C		Electronic Brake Control Module	√	√	√	√	√	SP0083,SP0394,SP0086
2019	Zafira-C		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	SP0347,SP0086
2019	Zafira-C		Body Control Module	√	√	√	√	√	SP0047,SP0048,SP0045,SP0378,SP0372,S P0376,SP0046,SP0334,SP0332,SP0455
2019	Zafira-C		Instrument Cluster	√	√	√	√	√	SP0040
2019	Zafira-C		HVAC Control Module	√	√	√	√	√	SP0211,SP0040,SP0307
2019	Zafira-C		Trailer Lighting Control Module	√	√	√	√	√	SP0040
2019	Zafira-C		Front Seat Heating Control Module	√	√	√	√	√	
2019	Zafira-C		Parking Brake Control Module	√	√	√	√	√	SP0109
2019	Zafira-C		Power Steering Control Module	√	√	√	√		SP0088,SP0089,SP0090
2019	Zafira-C		Radio	√	√	√	√	√	
2019	Zafira-C		Headlamp Control Module	√	√	√	√	√	SP0366
2019	Zafira-C		Telematics Communication Interface Control Module	√	√	√	√	√	SP0216,SP0215
2019	Zafira-C		Parking Assist Control Module	√	√	√	√	√	SP0040
2019	Zafira-C		Distance Sensing Cruise Control Module	√	√	√	√		SP0231
2019	Zafira-C		Steering Wheel Angle Sensor Module	√	√	√			SP0082,SP0083
2019	Zafira-C		Frontview Camera Module	√	√	√	√	√	SP0108,SP0368,SP0040
2019	Zafira-C		Chassis Control Module	√	√	√	√	√	SP0016,SP0271,SP0365
2018	Adam		Engine Control Module	√	√	√	√	√	SP0048,SP0084,SP0091,SP0385,SP0017,S P0018,SP0131,SP0092,SP0541,SP0019,SP 058B,SP0587,SP0599,SP0016,SP0210,SP0 320,SP0306,SP0598,SP0132,SP058C,SP05 8E,SP058F,SP0315,SP0093
2018	Adam		Transmission Control Module	√	√	√	√	√	SP0314,SP0427,SP0330
2018	Adam		Electronic Brake Control Module	√	√	√	√	√	SP0082,SP0460,SP0269
2018	Adam		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	SP0347,SP0086
2018	Adam		Body Control Module	√	√	√	√	√	SP0047,SP0048,SP0045,SP0372,SP0046,S P0334,SP0332,SP0455

2018	Adam		Instrument Cluster	√	√	√	√	√	SP0040
2018	Adam		HVAC Control Module	√	√	√	√	√	SP0211,SP0040,SP0307
2018	Adam		Telematics Communication Interface Control Module	√	√	√	√	√	SP0216,SP0215
2018	Adam		Trailer Lighting Control Module	√	√	√	√	√	SP0040
2018	Adam		Fuel Injector Control Module	√	√	√	√	√	SP0306
2018	Adam		Power Steering Control Module	√	√	√	√		SP0090
2018	Adam		Parking Assist Control Module	√	√	√	√	√	SP0040
2018	Adam		Radio	√	√	√	√	√	
2018	Adam		Chassis Control Module	√	√	√	√	√	SP0016,SP0271,SP0365
2018	Ampera-e		Engine Control Module	√	√	√	√	√	SP0048,SP0095
2018	Ampera-e		Electronic Brake Control Module	√	√	√	√	√	SP0083,SP0460
2018	Ampera-e		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	SP0347,SP0311,SP0086
2018	Ampera-e		Body Control Module	√	√	√	√	√	SP0370,SP0413,SP0335,SP0336,SP0337,S P0338,SP0339,SP0340,SP0341,SP0342,SP 0047,SP0048,SP0045,SP0372,SP0378,SP0 376,SP0046,SP0334,SP0403,SP0332
2018	Ampera-e		Instrument Cluster	√	√	√	√	√	SP0040
2018	Ampera-e		HVAC Control Module	√	√	√	√	√	SP0211,SP0307
2018	Ampera-e		Serial Data Gateway Module	√	√	√			
2018	Ampera-e		Trailer Lighting Control Module	√	√	√	√	√	SP0040
2018	Ampera-e		Electric A/C Compressor Control Module	√					
2018	Ampera-e		Frontview Camera Module	√	√	√	√	√	SP0368
2018	Ampera-e		Left Side Object Sensor Module	√	√	√		√	
2018	Ampera-e		Power Line Communication Module	√			√		
2018	Ampera-e		Keyless Entry Control Module	√	√	√	√	√	
2018	Ampera-e		Radio	√	√	√	√	√	
2018	Ampera-e		Telematics Communication Interface Control Module	√	√	√	√	√	SP0216,SP0215
2018	Ampera-e		Pedestrian Alert Sound Control Module	√	√	√	√	√	
2018	Ampera-e		Parking Assist Control Module	√	√	√	√	√	SP0040
2018	Ampera-e		Battery Energy Control Module	√			√		
2018	Ampera-e		Hybrid/EV Powertrain Control Module 2	√	√	√	√	√	SP0303,SP0444,SP0255,SP0301,SP0302,S P0305
2018	Ampera-e		Power Steering Control Module	√	√	√	√		SP0090
2018	Ampera-e		Brake Booster Control Module	√	√	√	√		
2018	Ampera-e		Steering Column Lock Control Module	√	√	√	√		
2018	Ampera-e		Chassis Control Module	√	√	√	√	√	
2018	Ampera-e		Transmission Range Control Module	√			√		SP0220,SP0254,SP0219
2018	Ampera-e		Hybrid/EV Powertrain Control Module 1	√	√	√	√	√	SP05C7

2018	Ampera-e		Video Processing Control Module	√	√	√	√	√	SP0401,SP0367,SP0468,SP0437,SP0292
2018	Astra-J		Engine Control Module	√	√	√	√	√	SP0048,SP0084,SP0091,SP0131,SP0092,SP0019,SP0016,SP0093,SP0210,SP0315,SP0320,SP0306,SP0380,SP0390,SP0130,SP0085,SP0129,SP0121,SP0104,SP0132,SP0135,SP0136,SP0137,SP0247,SP0248,SP0252,SP0251,SP0388,SP0106,SP0049,SP0385,SP0017,SP0018,SP0541,SP058B,SP0587,SP0500,SP0005
2018	Astra-J		Transmission Control Module	√	√	√	√	√	SP0422
2018	Astra-J		Electronic Brake Control Module	√	√	√	√	√	SP0083,SP0394,SP0086
2018	Astra-J		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	SP0347
2018	Astra-J		Body Control Module	√	√	√	√	√	SP0047,SP0048,SP0045,SP0378,SP0372,SP0376,SP0046,SP0334,SP0332,SP0455
2018	Astra-J		Instrument Cluster	√	√	√	√	√	SP0040
2018	Astra-J		HVAC Control Module	√	√	√	√	√	SP0211,SP0040,SP0307
2018	Astra-J		Digital Radio Receiver Control Module	√	√	√	√	√	SP0040
2018	Astra-J		Telematics Communication Interface Control Module	√	√	√	√	√	SP0216,SP0215
2018	Astra-J		Parking Assist Control Module	√	√	√	√	√	SP0040
2018	Astra-J		Trailer Lighting Control Module	√	√	√	√	√	SP0040
2018	Astra-J		Fuel Injector Control Module	√			√	√	
2018	Astra-J		Headlamp Control Module	√	√	√	√	√	SP0366
2018	Astra-J		Parking Brake Control Module	√	√	√	√	√	SP0109
2018	Astra-J		Power Steering Control Module	√	√	√	√		SP0088,SP0089,SP0090
2018	Astra-J		Radio	√	√	√	√	√	
2018	Astra-J		Front Seat Heating Control Module	√	√	√	√	√	
2018	Astra-J		Suspension Control Module	√	√	√	√	√	
2018	Astra-J		Steering Wheel Angle Sensor Module	√	√	√			SP0082,SP0083
2018	Astra-J		Multi-Axis Acceleration Sensor Module	√	√	√			SP0350,SP0086
2018	Astra-J		Frontview Camera Module	√	√	√	√	√	SP0108,SP0368,SP0040
2018	Astra-J		Chassis Control Module	√	√	√	√	√	SP0016,SP0271,SP0365
2018	Astra-K		Engine Control Module	√	√	√	√	√	SP0048,SP0084,SP0091,SP0092,SP0019,SP0016,SP0093,SP0315,SP0210,SP0306,SP0380,SP0390,SP0130,SP0085,SP0131,SP0129,SP0121,SP0104,SP0132,SP0135,SP0136,SP0137,SP0252,SP0251,SP0388,SP0106,SP0049,SP0017,SP0598,SP0541,SP058B,SP058C,SP0587,SP0320,SP058E,SP058F,SP0385,SP0018,SP0500
2018	Astra-K		Transmission Control Module	√	√	√	√	√	SP0314,SP0427,SP0330,SP0422

2018	Astra-K		Electronic Brake Control Module	√	√	√	√	√	SP0109,SP0083,SP0460
2018	Astra-K		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	SP0347,SP0086
2018	Astra-K		Body Control Module	√	√	√	√	√	SP0047,SP0048,SP0045,SP0378,SP0372,SP0376,SP0046,SP0334,SP0332,SP0455
2018	Astra-K		Instrument Cluster	√	√	√	√	√	SP0040
2018	Astra-K		HVAC Control Module	√	√	√	√	√	SP0211,SP0040,SP0307
2018	Astra-K		HVAC Controls	√	√	√			
2018	Astra-K		Serial Data Gateway Module	√	√	√			
2018	Astra-K		Radio Controls	√	√	√			
2018	Astra-K		Trailer Lighting Control Module	√	√	√	√	√	SP0040
2018	Astra-K		Telematics Communication Interface Control Module	√	√	√	√	√	SP0216,SP0215
2018	Astra-K		Fuel Injector Control Module	√	√	√	√	√	SP0306
2018	Astra-K		Parking Assist Control Module	√	√	√	√	√	SP0450,SP0040
2018	Astra-K		Liftgate Control Module	√	√	√	√		SP0323,SP0343
2018	Astra-K		Human Machine Interface Control Module	√	√	√	√	√	SP0326
2018	Astra-K		Keyless Entry Control Module	√	√	√	√	√	
2018	Astra-K		Headlamp Control Module	√	√	√	√	√	SP0366
2018	Astra-K		Power Supply Transformer	√	√	√	√		
2018	Astra-K		Active Safety Control Module	√	√	√	√	√	
2018	Astra-K		Frontview Camera Module	√	√	√	√		SP0108,SP0368,SP0401
2018	Astra-K		Multi-Axis Acceleration Sensor Module	√	√	√			SP0350,SP0086
2018	Astra-K		Long Range Radar Sensor Module	√	√	√	√		SP0440
2018	Astra-K		Steering Column Lock Control Module	√	√	√	√		
2018	Astra-K		Power Steering Control Module	√	√	√	√		SP0090
2018	Astra-K		Radio	√	√	√	√	√	SP0396,SP0213
2018	Astra-K		Seat Memory Control Module	√	√	√	√	√	
2018	Cascada		Engine Control Module	√	√	√	√	√	SP0048,SP0084,SP0091,SP0131,SP0092,SP0019,SP0016,SP0093,SP0210,SP0315,SP0320,SP0306,SP0380,SP0129,SP0121,SP0104,SP0132,SP0309,SP0135,SP0247,SP0248,SP0136,SP0357,SP0359,SP0361,SP0363,SP0400,SP0106,SP0049,SP0385,SP0017,SP0018,SP0541,SP058B,SP0587,SP0599,SP0508,SP058C,SP058E,SP058F
2018	Cascada		Transmission Control Module	√	√	√	√	√	SP0422
2018	Cascada		Electronic Brake Control Module	√	√	√	√	√	SP0083,SP0394,SP0086
2018	Cascada		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	SP0347,SP0086
2018	Cascada		Body Control Module	√	√	√	√	√	SP0047,SP0048,SP0045,SP0378,SP0372,SP0376,SP0046,SP0334,SP0332,SP0455

2018	Cascada		Instrument Cluster	√	√	√	√	√	SP0040
2018	Cascada		HVAC Control Module	√	√	√	√	√	SP0211,SP0040,SP0307
2018	Cascada		Folding Top Control Module	√	√	√	√	√	SP0040,SP0207,SP0208
2018	Cascada		Digital Radio Receiver Control Module	√	√	√	√	√	SP0040
2018	Cascada		Telematics Communication Interface Control Module	√	√	√	√	√	SP0216,SP0215
2018	Cascada		Headlamp Control Module	√	√	√	√	√	SP0366
2018	Cascada		Suspension Control Module	√	√	√	√	√	
2018	Cascada		Parking Assist Control Module	√	√	√	√	√	SP0040
2018	Cascada		Chassis Control Module	√	√	√	√	√	SP0016,SP0271,SP0365
2018	Cascada		Multi-Axis Acceleration Sensor Module	√	√	√			SP0350,SP0086
2018	Cascada		Steering Wheel Angle Sensor Module	√	√	√			SP0082,SP0083
2018	Cascada		Frontview Camera Module	√	√	√	√	√	SP0108,SP0368,SP0040
2018	Cascada		Parking Brake Control Module	√	√	√	√	√	SP0109
2018	Cascada		Power Steering Control Module	√	√	√	√		SP0088,SP0089,SP0090
2018	Cascada		Radio	√	√	√	√	√	
2018	Cascada		Front Seat Heating Control Module	√	√	√	√	√	
2018	Combo-D		Engine Control Module	√	√	√	√	√	SP0101,SP0131,SP0385,SP0085,SP0102,SP0464,SP05CB,SP0084,SP0221,SP0325,SP0426,SP0285,SP0274,SP0019,SP0104,SP0121,SP05CC,SP0585,SP0234,SP0251,SP0531,SP0049,SP0106,SP0316,SP0122,SP0330,SP0099,SP0584,SP0273,SP0318,SP0102,SP0530
2018	Combo-D		Transmission Control Module	√	√	√	√	√	SP0314,SP0427
2018	Combo-D		Electronic Brake Control Module	√	√	√	√	√	SP0459,SP0394,SP0083
2018	Combo-D		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	
2018	Combo-D		Body Control Module	√	√	√	√	√	SP0242,SP0418,SP0389
2018	Combo-D		Instrument Cluster	√	√	√	√	√	SP0218
2018	Combo-D		HVAC Control Module	√	√	√	√	√	SP0211
2018	Combo-D		Auxiliary Heater Control Module	√	√	√	√	√	SP0278
2018	Combo-D		Multimedia Player Interface Module	√	√	√	√	√	
2018	Combo-D		Tire Pressure Indicator Module	√	√	√	√		
2018	Combo-D		Parking Assist Control Module	√	√	√	√		SP0344
2018	Corsa-E		Engine Control Module	√	√	√	√	√	SP0048,SP0084,SP0091,SP0385,SP0017,SP0018,SP0131,SP0092,SP0541,SP0019,SP058B,SP0587,SP0599,SP0016,SP0210,SP0320,SP0306,SP0598,SP0132,SP058C,SP058E,SP058F,SP0315,SP0093,SP0380,SP0085,SP0129,SP0121,SP0104,SP0252,SP0251,SP0288,SP0106,SP0040

2018	Corsa-E		Transmission Control Module	√	√	√	√	√	SP0422,SP0314,SP0427,SP0330
2018	Corsa-E		Electronic Brake Control Module	√	√	√	√	√	SP0082,SP0460,SP0269
2018	Corsa-E		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	SP0347,SP0086
2018	Corsa-E		Body Control Module	√	√	√	√	√	SP0047,SP0048,SP0045,SP0372,SP0046,S P0334,SP0332,SP0455
2018	Corsa-E		Instrument Cluster	√	√	√	√	√	SP0040
2018	Corsa-E		HVAC Control Module	√	√	√	√	√	SP0211,SP0040,SP0307
2018	Corsa-E		Telematics Communication Interface Control Module	√	√	√	√	√	SP0216,SP0215
2018	Corsa-E		Trailer Lighting Control Module	√	√	√	√	√	SP0040
2018	Corsa-E		Fuel Injector Control Module	√	√	√	√	√	SP0306
2018	Corsa-E		Power Steering Control Module	√	√	√	√		SP0090
2018	Corsa-E		Radio	√	√	√	√	√	
2018	Corsa-E		Frontview Camera Module	√	√	√	√	√	SP0108,SP0368
2018	Corsa-E		Parking Assist Control Module	√	√	√	√	√	SP0040
2018	Corsa-E		Chassis Control Module	√	√	√	√	√	SP0016,SP0271,SP0365
2018	Crossland X		Engine Control Module	√	√	√	√	√	SP0285,SP0101,SP0047,SP0318,SP0099,S P0356,SP0358,SP0360,SP0362,SP0103,SP 0464,SP0384,SP0129,SP0135,SP05C8,SP0 5C6,SP0016,SP0136,SP05C9,SP05BE,SP0 5AE,SP0104,SP05C1,SP05C0,SP05BB,SP 059F,SP059D,SP0383,SP0458,SP0312,SP0 59E,SP05A0,SP05A1,SP05A2,SP05A3,SP 05A4,SP05A5,SP05A6,SP05A7,SP0085,S P05A8,SP0096,SP05B4,SP0128,SP0316,S P05AF,SP058F,SP059C,SP05A9,SP0098,S P0102,SP0299,SP0294,SP05AA,SP05AB,S P0260,SP05AC,SP0247,SP0248,SP05AD,S P0249,SP0411,SP0354
2018	Crossland X		Transmission Control Module	√	√	√	√	√	SP0223,SP0122
2018	Crossland X		Electronic Brake Control Module	√	√	√	√	√	SP0083,SP0461,SP0109,SP0469,SP0438,S P0466,SP0435,SP0456
2018	Crossland X		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√		
2018	Crossland X		Body Control Module	√	√	√	√	√	SP0443,SP0355,SP0019,SP059B,SP059C
2018	Crossland X		Instrument Cluster	√	√	√	√	√	
2018	Crossland X		HVAC Control Module	√	√	√	√	√	
2018	Crossland X		HVAC Controls	√	√	√	√	√	
2018	Crossland X		Fuel Injector Control Module	√	√	√			
2018	Crossland X		Headlamp Control Module	√	√	√	√	√	SP0366
2018	Crossland X		Passenger Seat Belt Indicator	√			√	√	

2018	Crossland X		Frontview Camera Module	√	√	√	√	√	SP0368
2018	Crossland X		Parking Assist Control Module	√	√	√	√	√	
2018	Crossland X		Trailer Lighting Control Module	√	√	√	√	√	
2018	Crossland X		Left Front Seat Heating Control Module	√			√	√	
2018	Crossland X		Right Front Seat Heating Control Module	√			√	√	
2018	Crossland X		Power Steering Control Module	√	√	√	√	√	
2018	Crossland X		Driver Door Switch Panel Control Module	√	√	√	√	√	
2018	Crossland X		Steering Column Control Module	√	√	√	√	√	
2018	Crossland X		Media Disc Player	√	√	√	√	√	
2018	Crossland X		Head-Up Display Module	√	√	√	√	√	
2018	Crossland X		Power Supply Transformer	√	√	√			
2018	Crossland X		Ultrasonic Intrusion Sensor	√	√	√			
2018	Crossland X		Rain/Ambient Light Sensor Module	√	√	√	√		
2018	Crossland X		Power Sounder Content Theft Deterrent Alarm Module	√	√	√	√	√	
2018	Crossland X		Radio	√	√	√	√	√	SP0292
2018	Crossland X		Info Display Module	√	√	√	√	√	
2018	Crossland X		Infotainment Faceplate Control Module	√	√	√			
2018	Crossland X		Left Steering Wheel Controls Switch	√	√	√	√	√	
2018	Crossland X		Telematics Communication Interface Control Module	√	√	√	√	√	
2018	Crossland X		Traction Control Switch	√			√		
2018	Crossland X		Fuel-Borne Catalyst Pump	√	√	√		√	SP0384,SP05B3
2018	Crossland X		Steering Column Lock Control Module	√	√	√	√		
2018	Crossland X		Battery Sensor Module	√			√		
2018	Grandland X		Engine Control Module	√	√	√	√	√	SP059D,SP0383,SP0458,SP0312,SP059E, SP059F,SP05A0,SP05A1,SP05A2,SP05A3 ,SP05A4,SP05A5,SP05A6,SP05A7,SP008 5,SP05A8,SP0285,SP0101,SP0047,SP0318 ,SP0099,SP0356,SP0358,SP0360,SP0362,S P0103,SP0464,SP0384,SP0129,SP0135,SP 05C8,SP05C6,SP0016,SP0136,SP05C9,SP 05BE,SP05AE,SP0104,SP05C1,SP05C0,S P05BB,SP0316,SP0122,SP0346,SP0412,S P0364,SP0417,SP0260,SP0353,SP05A9,SP 05B7,SP0098,SP05AF,SP05B8,SP0385,SP 05B9,SP0102,SP0299,SP0294,SP05BA,SP 05BC,SP05BD,SP05BF,SP0252,SP0247,S P0248,SP059C,SP05AA,SP05AB,SP05AC, SP05AD,SP0249,SP0411,SP0354
2018	Grandland X		Transmission Control Module	√	√	√	√	√	SP0223,SP0122,SP05B2

2018	Grandland X		Electronic Brake Control Module	√	√	√	√	√	SP0083,SP0461,SP0109,SP0469,SP0438,S P0466,SP0435,SP0456
2018	Grandland X		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√		
2018	Grandland X		Body Control Module	√	√	√	√	√	SP0443,SP0355,SP0019,SP059B,SP059C
2018	Grandland X		Instrument Cluster	√	√	√	√	√	
2018	Grandland X		HVAC Control Module	√	√	√	√	√	
2018	Grandland X		HVAC Controls	√	√	√	√	√	
2018	Grandland X		Driver Door Switch Panel Control Module	√	√	√	√	√	
2018	Grandland X		Video Processing Control Module	√	√	√	√	√	SP0367,SP0292
2018	Grandland X		Trailer Lighting Control Module	√	√	√	√	√	
2018	Grandland X		Traction Control Switch	√			√	√	
2018	Grandland X		Fuel-Borne Catalyst Pump	√	√	√		√	SP0384,SP05B3
2018	Grandland X		Audio Amplifier	√	√	√		√	
2018	Grandland X		Left Windshield Wiper Motor Module	√	√	√	√	√	
2018	Grandland X		Headlamp Control Module	√	√	√	√	√	SP0366
2018	Grandland X		Liftgate Control Module	√	√	√	√	√	SP0322
2018	Grandland X		Info Display Module	√	√	√	√	√	
2018	Grandland X		Infotainment Faceplate Control Module	√					
2018	Grandland X		Radio	√	√	√	√	√	SP0292
2018	Grandland X		Hands-Free Liftgate Sensor Control Module	√					
2018	Grandland X		Parking Assist Control Module	√	√	√	√	√	
2018	Grandland X		Left Front Seat Heating Control Module	√			√	√	
2018	Grandland X		Right Front Seat Heating Control Module	√			√	√	
2018	Grandland X		Power Steering Control Module	√	√	√	√	√	
2018	Grandland X		Power Sounder Content Theft Deterrent Alarm Module	√	√	√	√	√	
2018	Grandland X		Rain/Ambient Light Sensor Module	√	√	√	√		
2018	Grandland X		Ultrasonic Intrusion Sensor	√	√	√			
2018	Grandland X		Battery Sensor Module	√			√		
2018	Grandland X		Passenger Seat Belt Indicator	√			√	√	
2018	Grandland X		Power Supply Transformer	√	√	√			
2018	Grandland X		Left Steering Wheel Controls Switch	√	√	√	√	√	
2018	Grandland X		Telematics Communication Interface Control Module	√	√	√	√		
2018	Grandland X		Steering Column Control Module	√	√	√	√	√	
2018	Grandland X		Steering Column Lock Control Module	√	√	√	√		
2018	Grandland X		Battery Voltage Switching Control Module	√			√		
2018	Grandland X		Auxiliary Body Control Module	√	√	√	√	√	
2018	Grandland X		Driver Seat Control Module	√	√	√	√	√	
2018	Grandland X		Media Disc Player	√	√	√	√	√	

2018	Grandland X		Long Range Radar Sensor Module	√	√	√	√	√	
2018	Grandland X		Frontview Camera - Windshield	√	√	√	√	√	SP0368
2018	Grandland X		Seat Lumbar Support Control Module - Driver	√			√	√	
2018	Insignia-B		Engine Control Module	√	√	√	√	√	SP0084,SP0380,SP0092,SP0131,SP0129,SP0121,SP0104,SP0019,SP0132,SP0133,SP0016,SP0135,SP0247,SP0248,SP0136,SP0137,SP0309,SP0357,SP0359,SP0361,SP0363,SP0400,SP0106,SP0049,SP0306,SP0390,SP0130,SP0048,SP0252,SP0251,SP0388,SP0091,SP0385,SP0017,SP0018,SP0541,SP058B,SP0587,SP0599,SP0210,SP0320
2018	Insignia-B		Transmission Control Module	√	√	√	√	√	SP0223,SP0051,SP0422
2018	Insignia-B		Electronic Brake Control Module	√	√	√	√	√	SP0109,SP0083,SP0460
2018	Insignia-B		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	SP0347,SP0086
2018	Insignia-B		Body Control Module	√	√	√	√	√	SP0047,SP0048,SP0045,SP0378,SP0372,SP0376,SP0046,SP0334,SP0332,SP0455
2018	Insignia-B		Instrument Cluster	√	√	√	√	√	SP0040
2018	Insignia-B		HVAC Control Module	√	√	√	√	√	SP0211,SP0040,SP0307
2018	Insignia-B		HVAC Controls	√	√	√			
2018	Insignia-B		Serial Data Gateway Module	√	√	√			
2018	Insignia-B		Liftgate Control Module	√	√	√	√		SP0323,SP0343
2018	Insignia-B		Human Machine Interface Control Module	√	√	√	√	√	SP0326
2018	Insignia-B		Parking Assist Control Module	√	√	√	√	√	SP0040
2018	Insignia-B		Radio	√	√	√	√	√	SP0396,SP0213
2018	Insignia-B		Seat Memory Control Module - Driver	√	√	√	√	√	
2018	Insignia-B		Seat Memory Control Module - Passenger	√	√	√	√	√	
2018	Insignia-B		Power Steering Control Module	√	√	√	√		SP0090
2018	Insignia-B		Headlamp Control Module	√	√	√	√	√	SP0366
2018	Insignia-B		Active Safety Control Module	√	√	√	√	√	
2018	Insignia-B		Frontview Camera Module	√	√	√	√	√	SP0368,SP0108
2018	Insignia-B		Power Supply Transformer	√	√	√	√		
2018	Insignia-B		Telematics Communication Interface Control Module	√	√	√	√	√	SP0216,SP0215
2018	Insignia-B		Steering Column Lock Control Module	√	√	√	√		
2018	Insignia-B		Rear Differential Clutch Control Module	√	√	√	√	√	SP0206
2018	Insignia-B		Suspension Control Module	√	√	√	√	√	
2018	Insignia-B		Left Side Object Sensor Module	√	√	√		√	
2018	Insignia-B		Radio Controls	√	√	√			
2018	Insignia-B		Long Range Radar Sensor Module	√	√	√	√		SP0440

2018	Insignia-B		Video Processing Control Module	√	√	√	√	√	SP0401,SP0367,SP0468,SP0437,SP0292
2018	Insignia-B		Keyless Entry Control Module	√	√	√	√	√	
2018	Insignia-B		Trailer Lighting Control Module	√	√	√	√	√	SP0040
2018	Insignia-B		Audio Amplifier	√	√	√	√		
2018	Karl / Viva		Engine Control Module	√	√	√	√	√	SP0048,SP0084,SP0091,SP0092,SP0019,S P0016,SP0093,SP0315,SP0210,SP0306
2018	Karl / Viva		Transmission Control Module	√	√	√	√	√	SP0314,SP0427,SP0330
2018	Karl / Viva		Electronic Brake Control Module	√	√	√	√	√	SP0083
2018	Karl / Viva		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	SP0347,SP0086
2018	Karl / Viva		Body Control Module	√	√	√	√	√	SP0047,SP0048,SP0045,SP0378,SP0372,S P0376,SP0046,SP0334,SP0332,SP0455
2018	Karl / Viva		Instrument Cluster	√	√	√	√	√	SP0040
2018	Karl / Viva		HVAC Control Module	√	√	√	√	√	SP0211,SP0040,SP0307
2018	Karl / Viva		HVAC Controls	√	√	√			
2018	Karl / Viva		Serial Data Gateway Module	√	√	√			
2018	Karl / Viva		Telematics Communication Interface Control Module	√	√	√	√	√	SP0216,SP0215
2018	Karl / Viva		Power Steering Control Module	√	√	√	√		SP0090
2018	Karl / Viva		Radio	√	√	√	√	√	SP0396
2018	Karl / Viva		Fuel Injector Control Module	√	√	√	√	√	SP0306
2018	Karl / Viva		Parking Assist Control Module	√	√	√	√	√	SP0450,SP0040
2018	Karl / Viva		Frontview Camera Module	√	√	√	√		SP0108,SP0368,SP0401
2018	Mokka		Engine Control Module	√	√	√	√	√	SP0048,SP0084,SP0091,SP0131,SP0092,S P0019,SP0016,SP0093,SP0210,SP0315,SP 0320,SP0306,SP0385,SP0017,SP0018,SP0 541,SP058B,SP0587,SP0599,SP0380,SP03 90,SP0130,SP0085,SP0129,SP0121,SP010 4,SP0132,SP0135,SP0136,SP0137,SP0247, SP0248,SP0252,SP0251,SP0388,SP0106,S P0040
2018	Mokka		Transmission Control Module	√	√	√	√	√	SP0422
2018	Mokka		Electronic Brake Control Module	√	√	√	√	√	SP0083
2018	Mokka		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	SP0347,SP0086
2018	Mokka		Body Control Module	√	√	√	√	√	SP0047,SP0048,SP0045,SP0378,SP0372,S P0376,SP0046,SP0334,SP0332,SP0455
2018	Mokka		Instrument Cluster	√	√	√	√	√	SP0040
2018	Mokka		HVAC Control Module	√	√	√	√	√	SP0211,SP0040,SP0307
2018	Mokka		Serial Data Gateway Module	√	√	√			
2018	Mokka		Trailer Lighting Control Module	√	√	√	√	√	SP0040
2018	Mokka		Radio Controls	√	√	√			

2018	Mokka		Telematics Communication Interface Control Module	√	√	√	√	√	SP0216,SP0215
2018	Mokka		Human Machine Interface Control Module	√	√	√	√	√	SP0326
2018	Mokka		Fuel Injector Control Module	√			√	√	
2018	Mokka		Headlamp Control Module	√	√	√	√	√	SP0366
2018	Mokka		Front Seat Heating Control Module	√	√	√	√	√	
2018	Mokka		Radio	√	√	√	√	√	SP0396,SP0213
2018	Mokka		Power Steering Control Module	√	√	√	√		SP0377
2018	Mokka		Parking Assist Control Module	√	√	√	√	√	SP0040
2018	Mokka		Steering Wheel Angle Sensor Module	√	√	√			SP0082,SP0083
2018	Mokka		Frontview Camera Module	√	√	√	√	√	SP0108,SP0368,SP0040
2018	Mokka		Rear Differential Clutch Control Module	√	√	√	√		SP0206,SP05CA
2018	Mokka		Power Supply Transformer	√	√	√	√		
2018	Mokka		Amplifier	√	√	√	√		
2018	Mokka		Steering Column Lock Control Module	√	√	√	√		
2018	Mokka		Keyless Entry Control Module	√	√	√	√	√	
2018	Movano-B		Engine Control Module	√	√	√	√	√	SP0084,SP0098,SP0276,SP0099,SP0385,SP0285,SP0085,SP0318,SP0102,SP05C4,SP0104,SP0354,SP0349,SP0284,SP0464,SP0356,SP0358,SP0360,SP0362,SP0106,SP0325,SP0048,SP0380,SP0345,SP0352,SP0102,SP0040
2018	Movano-B		Transmission Control Module	√	√	√	√	√	SP0314,SP0222,SP0427
2018	Movano-B		Electronic Brake Control Module	√	√	√	√	√	SP0083,SP0289,SP0461,SP0086,SP0082,SP0447,SP0290,SP0460,SP0407,SP0286
2018	Movano-B		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	
2018	Movano-B		Body Control Module	√	√	√	√	√	
2018	Movano-B		Instrument Cluster	√	√	√	√	√	
2018	Movano-B		HVAC Control Module	√	√	√	√	√	SP0211
2018	Movano-B		Serial Data Gateway Module	√	√	√	√	√	
2018	Movano-B		Power Steering Control Module	√	√	√	√		
2018	Movano-B		Parking Assist Control Module	√	√	√	√		
2018	Movano-B		Radio	√	√	√	√	√	SP0292
2018	Movano-B		Info Display Module	√	√	√	√	√	
2018	Movano-B		Tire Pressure Indicator Module	√	√	√	√		SP0402,SP0467,SP0436,SP0434,SP0465
2018	Movano-B		Multifunction Accessory Control Module	√	√	√	√		
2018	Movano-B		Reductant Control Module	√	√	√	√	√	SP0297,SP0294,SP0299,SP05C3,SP0135
2018	Movano-B		Auxiliary Body Control Module	√	√	√	√	√	SP0354
2018	Movano-B		Frontview Camera Module	√	√	√	√		
2018	Movano-B		Telematics Communication Interface Control Module	√	√	√	√		SP0214

2018	Movano-B		Serial Data Gateway Module - Secondary	√	√	√	√		
2018	Movano-B		Long Range Radar Sensor Module	√	√	√	√		SP0440
2018	Vivaro-B		Engine Control Module	√	√	√	√	√	SP0325,SP0048,SP0380,SP0098,SP0271,S P0276,SP0273,SP0274,SP0385,SP0285,SP 0085,SP0318,SP0319,SP0102,SP0352,SP0 103,SP0104,SP0354,SP0432,SP0349,SP04 64,SP0284,SP0049,SP0106
2018	Vivaro-B		Electronic Brake Control Module	√	√	√	√	√	SP0083,SP0289,SP0461,SP0082,SP0290,S P0460,SP0447,SP0286,SP0407
2018	Vivaro-B		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√		
2018	Vivaro-B		Body Control Module	√	√	√	√	√	SP0402,SP0467,SP0436,SP0434,SP0465
2018	Vivaro-B		Instrument Cluster	√	√	√	√	√	
2018	Vivaro-B		HVAC Control Module	√	√	√	√	√	
2018	Vivaro-B		Serial Data Gateway Module	√	√	√	√	√	
2018	Vivaro-B		Parking Heater Control Module	√	√	√	√	√	SP0451,SP0452
2018	Vivaro-B		Power Steering Control Module	√	√	√	√		
2018	Vivaro-B		Radio	√	√	√	√	√	SP0292
2018	Vivaro-B		Info Display Module	√	√	√	√	√	
2018	Vivaro-B		Multifunction Accessory Control Module	√	√	√	√		
2018	Vivaro-B		Reductant Control Module	√	√	√	√	√	SP0297,SP0294,SP0299,SP05C3,SP0135
2018	Vivaro-B		Keyless Entry Control Module	√	√	√	√	√	
2018	Vivaro-B		Auxiliary Body Control Module	√	√	√	√	√	SP0239,SP0354
2018	Vivaro-B		Parking Assist Control Module	√	√	√	√	√	SP0423,SP0277
2018	Vivaro-B		Telematics Communication Interface Control Module	√	√	√	√		SP0214
2018	Zafira-C		Engine Control Module	√	√	√	√	√	SP0048,SP0084,SP0091,SP0131,SP0092,S P0019,SP0016,SP0093,SP0210,SP0315,SP 0320,SP0306,SP0096,SP0128,SP0085,SP0 102,SP0380,SP0103,SP0101,SP0129,SP03 90,SP0130,SP0121,SP0104,SP0132,SP013 5,SP0136,SP0137,SP0247,SP0248,SP0252, SP0251,SP0388,SP0106,SP0049,SP0385,S P0017,SP0018,SP0541,SP058B,SP0587,SP 0599,SP0598,SP058C,SP058E,SP058F,SP0 309,SP0357,SP0359,SP0361,SP0363,SP04
2018	Zafira-C		Transmission Control Module	√	√	√	√	√	SP0223,SP0122,SP0422
2018	Zafira-C		Electronic Brake Control Module	√	√	√	√	√	SP0083,SP0394,SP0086
2018	Zafira-C		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	SP0347,SP0086
2018	Zafira-C		Body Control Module	√	√	√	√	√	SP0047,SP0048,SP0045,SP0378,SP0372,S P0376,SP0046,SP0334,SP0332,SP0455

2018	Zafira-C		Instrument Cluster	√	√	√	√	√	SP0040
2018	Zafira-C		HVAC Control Module	√	√	√	√	√	SP0211,SP0040,SP0307
2018	Zafira-C		Telematics Communication Interface Control Module	√	√	√	√	√	SP0216,SP0215
2018	Zafira-C		Digital Radio Receiver Control Module	√	√	√	√	√	SP0040
2018	Zafira-C		Trailer Lighting Control Module	√	√	√	√	√	SP0040
2018	Zafira-C		Fuel Injector Control Module	√			√	√	
2018	Zafira-C		Headlamp Control Module	√	√	√	√	√	SP0366
2018	Zafira-C		Parking Assist Control Module	√	√	√	√	√	SP0040
2018	Zafira-C		Parking Brake Control Module	√	√	√	√	√	SP0109
2018	Zafira-C		Power Steering Control Module	√	√	√	√		SP0088,SP0089,SP0090
2018	Zafira-C		Radio	√	√	√	√	√	
2018	Zafira-C		Front Seat Heating Control Module	√	√	√	√	√	
2018	Zafira-C		Suspension Control Module	√	√	√	√	√	
2018	Zafira-C		Chassis Control Module	√	√	√	√	√	SP0016,SP0271,SP0365
2018	Zafira-C		Distance Sensing Cruise Control Module	√	√	√	√		SP0231
2018	Zafira-C		Steering Wheel Angle Sensor Module	√	√	√			SP0082,SP0083
2018	Zafira-C		Frontview Camera Module	√	√	√	√	√	SP0108,SP0368,SP0040
2017	Adam		Engine Control Module	√	√	√	√	√	SP0048,SP0084,SP0091,SP0131,SP0092,SP0019,SP0016,SP0093,SP0210,SP0315,SP0320,SP0306,SP0385,SP0017,SP0018,SP0541,SP058B,SP0587,SP0599
2017	Adam		Transmission Control Module	√	√	√	√	√	SP0314,SP0427,SP0330
2017	Adam		Electronic Brake Control Module	√	√	√	√	√	SP0082,SP0460,SP0269
2017	Adam		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	SP0347,SP0086
2017	Adam		Body Control Module	√	√	√	√	√	SP0047,SP0048,SP0045,SP0372,SP0046,SP0334,SP0332,SP0455
2017	Adam		Instrument Cluster	√	√	√	√	√	SP0040
2017	Adam		HVAC Control Module	√	√	√	√	√	SP0211,SP0040,SP0307
2017	Adam		Fuel Injector Control Module	√	√	√	√	√	SP0306
2017	Adam		Trailer Interface Control Module	√	√	√	√	√	SP0040
2017	Adam		Power Steering Control Module	√	√	√	√		SP0090
2017	Adam		Radio	√	√	√	√	√	
2017	Adam		Telematics Communication Interface Control Module	√	√	√	√	√	SP0216,SP0215
2017	Adam		Parking Assist Control Module	√	√	√	√	√	SP0040
2017	Adam		Chassis Control Module	√	√	√	√	√	SP0016,SP0271,SP0365
2017	Ampera-e		Engine Control Module	√	√	√	√	√	SP0048,SP0095
2017	Ampera-e		Electronic Brake Control Module	√	√	√	√	√	SP0083,SP0460
2017	Ampera-e		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	SP0347,SP0311,SP0086

2017	Ampera-e		Body Control Module	√	√	√	√	√	SP0370,SP0413,SP0335,SP0336,SP0337,SP0338,SP0339,SP0340,SP0341,SP0342,SP0047,SP0048,SP0045,SP0372,SP0378,SP0376,SP0046,SP0334,SP0403,SP0332
2017	Ampera-e		Instrument Cluster	√	√	√	√	√	SP0040
2017	Ampera-e		HVAC Control Module	√	√	√	√	√	SP0211,SP0307
2017	Ampera-e		Serial Data Gateway Module	√	√	√			
2017	Ampera-e		Keyless Entry Control Module	√	√	√	√	√	
2017	Ampera-e		Frontview Camera Module	√	√	√	√	√	SP0368
2017	Ampera-e		Battery Energy Control Module	√			√		
2017	Ampera-e		Radio	√	√	√	√	√	
2017	Ampera-e		Hybrid/EV Powertrain Control Module 1	√	√	√	√	√	SP05C7
2017	Ampera-e		Parking Assist Control Module	√	√	√	√	√	SP0040
2017	Ampera-e		Pedestrian Alert Sound Control Module	√	√	√	√	√	
2017	Ampera-e		Telematics Communication Interface Control Module	√	√	√	√	√	SP0216,SP0215
2017	Ampera-e		Power Steering Control Module	√	√	√	√		SP0090
2017	Ampera-e		Brake Booster Control Module	√	√	√	√		
2017	Ampera-e		Video Processing Control Module	√	√	√	√	√	SP0401,SP0367,SP0468,SP0437,SP0292
2017	Ampera-e		Power Line Communication Module	√			√		
2017	Ampera-e		Chassis Control Module	√	√	√	√	√	
2017	Ampera-e		Electric A/C Compressor Control Module	√					
2017	Ampera-e		Transmission Range Control Module	√			√		SP0220,SP0254,SP0219
2017	Ampera-e		Steering Column Lock Control Module	√	√	√	√		
2017	Ampera-e		Trailer Lighting Control Module	√	√	√	√	√	SP0040
2017	Ampera-e		Left Side Object Sensor Module	√	√	√		√	
2017	Ampera-e		Hybrid/EV Powertrain Control Module 2	√	√	√	√	√	SP0303,SP0444,SP0255,SP0301,SP0302,SP0305
2017	Antara		Engine Control Module	√	√	√	√	√	SP0084,SP0380,SP0092,SP0131,SP0129,SP0121,SP0104,SP0019,SP0132,SP0016,SP0309,SP0135,SP0247,SP0248,SP0136,SP0357,SP0359,SP0361,SP0363,SP0400,SP0135,SP0334,SP0332
2017	Antara		Transmission Control Module	√	√	√	√	√	SP0223,SP0122
2017	Antara		Electronic Brake Control Module	√	√	√	√	√	SP0083
2017	Antara		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	SP0347,SP0442
2017	Antara		Body Control Module	√	√	√	√	√	SP0047,SP0048,SP0442
2017	Antara		Theft Deterrent Module	√	√	√	√		
2017	Antara		Instrument Cluster	√	√	√	√	√	
2017	Antara		HVAC Control Module	√	√	√		√	

2017	Antara		Headlamp Control Module	√	√	√	√	√	SP0366,SP0243
2017	Antara		Auxiliary Body Control Module	√	√	√	√	√	SP0236
2017	Antara		Remote Control Door Lock Receiver	√	√	√	√	√	SP0374,SP0413,SP0335,SP0336,SP0337,S P0338,SP0332,SP0334,SP05CD,SP0403
2017	Antara		Rear Differential Clutch Control Module	√	√	√	√	√	SP0328
2017	Antara		Parking Brake Control Module	√	√	√	√	√	SP0109
2017	Antara		Parking Assist Control Module	√	√	√	√	√	
2017	Antara		Power Steering Control Module	√	√	√	√		SP0088,SP0089,SP0090
2017	Antara		Radio	√	√	√	√	√	SP0344,SP0428,SP0040,SP0420,SP0243,S P0431,SP0409
2017	Antara		Info Display Module	√	√	√	√	√	SP0344,SP05CE,SP05CF,SP0040,SP0420, SP0243,SP0423,SP0398
2017	Antara		Mobile Telephone Control Module	√	√	√		√	SP0040,SP0243,SP0423,SP0420
2017	Astra-J		Engine Control Module	√	√	√	√	√	SP0048,SP0084,SP0091,SP0131,SP0092,S P0019,SP0016,SP0093,SP0210,SP0315,SP 0320,SP0306,SP0385,SP0017,SP0018,SP0 541,SP058B,SP0587,SP0599,SP0380,SP03 90,SP0130,SP0085,SP0129,SP0121,SP010 4,SP0132,SP0135,SP0136,SP0137,SP0247, SP0248,SP0252,SP0251,SP0388,SP0106,S P0040,SP0095
2017	Astra-J		Transmission Control Module	√	√	√	√	√	SP0422
2017	Astra-J		Electronic Brake Control Module	√	√	√	√	√	SP0083,SP0394,SP0086
2017	Astra-J		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	SP0347
2017	Astra-J		Body Control Module	√	√	√	√	√	SP0047,SP0048,SP0045,SP0378,SP0372,S P0376,SP0046,SP0334,SP0332,SP0455
2017	Astra-J		Instrument Cluster	√	√	√	√	√	SP0040
2017	Astra-J		HVAC Control Module	√	√	√	√	√	SP0211,SP0040,SP0307
2017	Astra-J		Fuel Injector Control Module	√			√	√	
2017	Astra-J		Headlamp Control Module	√	√	√	√	√	SP0366
2017	Astra-J		Trailer Interface Control Module	√	√	√	√	√	SP0040
2017	Astra-J		Suspension Control Module	√	√	√	√	√	
2017	Astra-J		Front Seat Heating Control Module	√	√	√	√	√	
2017	Astra-J		Parking Brake Control Module	√	√	√	√	√	SP0109
2017	Astra-J		Power Steering Control Module	√	√	√	√		SP0088,SP0089,SP0090
2017	Astra-J		Radio	√	√	√	√	√	
2017	Astra-J		Digital Radio Receiver Control Module	√	√	√	√	√	SP0040
2017	Astra-J		Telematics Communication Interface Control Module	√	√	√	√	√	SP0216,SP0215
2017	Astra-J		Parking Assist Control Module	√	√	√	√	√	SP0040

2017	Astra-J		Frontview Camera Module	√	√	√	√	√	SP0108,SP0368,SP0040
2017	Astra-J		Steering Wheel Angle Sensor Module	√	√	√			SP0082,SP0083
2017	Astra-J		Multi-Axis Acceleration Sensor Module	√	√	√			SP0350,SP0086
2017	Astra-J		Chassis Control Module	√	√	√	√	√	SP0016,SP0271,SP0365
2017	Astra-K		Engine Control Module	√	√	√	√	√	SP0048,SP0084,SP0091,SP0092,SP0019,S P0016,SP0093,SP0315,SP0210,SP0306,SP 0385,SP0017,SP0018,SP0131,SP0541,SP0 58B,SP0587,SP0599,SP0320,SP0380,SP03 90,SP0130,SP0085,SP0129,SP0121,SP010 4,SP0132,SP0135,SP0136,SP0137,SP0252, SP0251,SP0388,SP0106,SP0049,SP0598,S P058C,SP058E,SP059E
2017	Astra-K		Transmission Control Module	√	√	√	√	√	SP0422,SP0314,SP0427,SP0330
2017	Astra-K		Electronic Brake Control Module	√	√	√	√	√	SP0109,SP0083,SP0460
2017	Astra-K		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	SP0347,SP0086
2017	Astra-K		Body Control Module	√	√	√	√	√	SP0047,SP0048,SP0045,SP0378,SP0372,S P0376,SP0046,SP0334,SP0332,SP0455
2017	Astra-K		Instrument Cluster	√	√	√	√	√	SP0040
2017	Astra-K		HVAC Control Module	√	√	√	√	√	SP0211,SP0040,SP0307
2017	Astra-K		HVAC Controls	√	√	√	√	√	
2017	Astra-K		Serial Data Gateway Module	√	√	√			
2017	Astra-K		Human Machine Interface Control Module	√	√	√	√	√	SP0326
2017	Astra-K		Liftgate Control Module	√	√	√	√		SP0323,SP0343
2017	Astra-K		Headlamp Control Module	√	√	√	√	√	SP0366
2017	Astra-K		Parking Assist Control Module	√	√	√	√	√	SP0450,SP0040
2017	Astra-K		Power Steering Control Module	√	√	√	√		SP0090
2017	Astra-K		Radio	√	√	√	√	√	SP0396,SP0213
2017	Astra-K		Seat Memory Control Module	√	√	√	√	√	
2017	Astra-K		Telematics Communication Interface Control Module	√	√	√	√	√	SP0216,SP0215
2017	Astra-K		Trailer Interface Control Module	√	√	√	√	√	SP0040
2017	Astra-K		Radio Controls	√	√	√	√	√	SP0326
2017	Astra-K		Keyless Entry Control Module	√	√	√	√	√	
2017	Astra-K		Frontview Camera Module	√	√	√	√		SP0108,SP0368,SP0401
2017	Astra-K		Power Supply Transformer	√	√	√	√		
2017	Astra-K		Steering Column Lock Control Module	√	√	√	√		
2017	Astra-K		Multi-Axis Acceleration Sensor Module	√	√	√			SP0350,SP0086
2017	Astra-K		Long Range Radar Sensor Module	√	√	√	√		SP0440
2017	Astra-K		Active Safety Control Module	√	√	√	√	√	
2017	Astra-K		Fuel Injector Control Module	√	√	√	√	√	SP0306

2017	Cascada		Engine Control Module	√	√	√	√	√	SP0048,SP0084,SP0091,SP0131,SP0092,SP0019,SP0016,SP0093,SP0210,SP0315,SP0320,SP0306,SP0380,SP0129,SP0121,SP0104,SP0132,SP0309,SP0135,SP0247,SP0248,SP0136,SP0357,SP0359,SP0361,SP0363,SP0400,SP0106,SP0049,SP0385,SP0017,SP0018,SP0541,SP058B,SP0587,SP0599
2017	Cascada		Transmission Control Module	√	√	√	√	√	SP0422
2017	Cascada		Electronic Brake Control Module	√	√	√	√	√	SP0083,SP0394,SP0086
2017	Cascada		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	SP0347,SP0086
2017	Cascada		Body Control Module	√	√	√	√	√	SP0047,SP0048,SP0045,SP0378,SP0372,SP0376,SP0046,SP0334,SP0332,SP0455
2017	Cascada		Instrument Cluster	√	√	√	√	√	SP0040
2017	Cascada		HVAC Control Module	√	√	√	√	√	SP0211,SP0040,SP0307
2017	Cascada		Folding Top Control Module	√	√	√	√	√	SP0040,SP0207,SP0208
2017	Cascada		Headlamp Control Module	√	√	√	√	√	SP0366
2017	Cascada		Telematics Communication Interface Control Module	√	√	√	√	√	SP0216,SP0215
2017	Cascada		Digital Radio Receiver Control Module	√	√	√	√	√	SP0040
2017	Cascada		Parking Assist Control Module	√	√	√	√	√	SP0040
2017	Cascada		Suspension Control Module	√	√	√	√	√	
2017	Cascada		Chassis Control Module	√	√	√	√	√	SP0016,SP0271,SP0365
2017	Cascada		Steering Wheel Angle Sensor Module	√	√	√			SP0082,SP0083
2017	Cascada		Multi-Axis Acceleration Sensor Module	√	√	√			SP0350,SP0086
2017	Cascada		Frontview Camera Module	√	√	√	√	√	SP0108,SP0368,SP0040
2017	Cascada		Parking Brake Control Module	√	√	√	√	√	SP0109
2017	Cascada		Radio	√	√	√	√	√	
2017	Cascada		Front Seat Heating Control Module	√	√	√	√	√	
2017	Cascada		Power Steering Control Module	√	√	√	√		SP0088,SP0089,SP0090
2017	Combo-D		Engine Control Module	√	√	√	√	√	SP0101,SP0131,SP0385,SP0085,SP0102,SP0464,SP05CB,SP0084,SP0221,SP0325,SP0426,SP0285,SP0274,SP0019,SP0104,SP0121,SP05CC,SP0585,SP0234,SP0251,SP0531,SP0049,SP0106,SP0316,SP0122,SP0330,SP0099,SP0584,SP0273,SP0318,SP0102,SP0530
2017	Combo-D		Transmission Control Module	√	√	√	√	√	SP0314,SP0427
2017	Combo-D		Electronic Brake Control Module	√	√	√	√	√	SP0459,SP0394,SP0083
2017	Combo-D		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	
2017	Combo-D		Body Control Module	√	√	√	√	√	SP0242,SP0418,SP0389

2017	Combo-D		Instrument Cluster	√	√	√	√	√	SP0218
2017	Combo-D		HVAC Control Module	√	√	√	√	√	SP0211
2017	Combo-D		Auxiliary Heater Control Module	√	√	√	√	√	SP0278
2017	Combo-D		Parking Assist Control Module	√	√	√	√		SP0344
2017	Combo-D		Tire Pressure Indicator Module	√	√	√	√		
2017	Combo-D		Multimedia Player Interface Module	√	√	√	√	√	
2017	Corsa-E		Engine Control Module	√	√	√	√	√	SP0048,SP0084,SP0091,SP0131,SP0092,S P0019,SP0016,SP0093,SP0210,SP0315,SP 0320,SP0306,SP0380,SP0085,SP0129,SP0 121,SP0104,SP0132,SP0252,SP0251,SP03 88,SP0106,SP0049,SP0385,SP0017,SP001 8,SP0541,SP058B,SP0587,SP0599
2017	Corsa-E		Transmission Control Module	√	√	√	√	√	SP0422,SP0314,SP0427,SP0330
2017	Corsa-E		Electronic Brake Control Module	√	√	√	√	√	SP0082,SP0460,SP0269
2017	Corsa-E		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	SP0347,SP0086
2017	Corsa-E		Body Control Module	√	√	√	√	√	SP0047,SP0048,SP0045,SP0372,SP0046,S P0334,SP0332,SP0455
2017	Corsa-E		Instrument Cluster	√	√	√	√	√	SP0040
2017	Corsa-E		HVAC Control Module	√	√	√	√	√	SP0211,SP0040,SP0307
2017	Corsa-E		Fuel Injector Control Module	√	√	√	√	√	SP0306
2017	Corsa-E		Parking Assist Control Module	√	√	√	√	√	SP0040
2017	Corsa-E		Frontview Camera Module	√	√	√	√	√	SP0108,SP0368
2017	Corsa-E		Chassis Control Module	√	√	√	√	√	SP0016,SP0271,SP0365
2017	Corsa-E		Telematics Communication Interface Control Module	√	√	√	√	√	SP0216,SP0215
2017	Corsa-E		Power Steering Control Module	√	√	√	√		SP0090
2017	Corsa-E		Radio	√	√	√	√	√	
2017	Corsa-E		Trailer Interface Control Module	√	√	√	√	√	SP0040
2017	Crossland X		Engine Control Module	√	√	√	√	√	SP0383,SP0458,SP0312,SP059F,SP05A0,S P05A1,SP05A2,SP05A3,SP05A5,SP05A7, SP0096,SP05B4,SP0128,SP0316,SP0285,S P0101,SP0047,SP0318,SP0099,SP0356,SP 0358,SP0360,SP0362,SP0103,SP0464,SP0 384,SP0129,SP0135,SP05C8,SP05C6,SP00 16,SP0136,SP05C9,SP05BE,SP05AE,SP01 04,SP05C1,SP05C0,SP05BB,SP05AF,SP0 5A4,SP058F
2017	Crossland X		Transmission Control Module	√	√	√	√	√	SP0223,SP0122
2017	Crossland X		Electronic Brake Control Module	√	√	√	√	√	SP0083,SP0461,SP0109,SP0469,SP0438,S P0466,SP0435,SP0456

2017	Crossland X		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√		
2017	Crossland X		Body Control Module	√	√	√	√	√	SP0443,SP0355,SP0019,SP059B,SP059C
2017	Crossland X		Instrument Cluster	√	√	√	√	√	
2017	Crossland X		HVAC Control Module	√	√	√	√	√	
2017	Crossland X		HVAC Controls	√	√	√	√	√	
2017	Crossland X		Media Disc Player	√	√	√	√	√	
2017	Crossland X		Head-Up Display Module	√	√	√	√	√	
2017	Crossland X		Power Steering Control Module	√	√	√	√	√	
2017	Crossland X		Steering Column Lock Control Module	√	√	√	√		
2017	Crossland X		Ultrasonic Intrusion Sensor	√	√	√			
2017	Crossland X		Frontview Camera Module	√	√	√	√	√	SP0368
2017	Crossland X		Parking Assist Control Module	√	√	√	√	√	
2017	Crossland X		Passenger Seat Belt Indicator	√			√	√	
2017	Crossland X		Power Supply Transformer	√	√	√			
2017	Crossland X		Driver Door Switch Panel Control Module	√	√	√	√	√	
2017	Crossland X		Rain/Ambient Light Sensor Module	√	√	√	√		
2017	Crossland X		Steering Column Control Module	√	√	√	√	√	
2017	Crossland X		Telematics Communication Interface Control Module	√	√	√	√	√	
2017	Crossland X		Radio	√	√	√	√	√	SP0292
2017	Crossland X		Fuel-Borne Catalyst Pump	√	√	√		√	SP0384,SP05B3
2017	Crossland X		Headlamp Control Module	√	√	√	√	√	SP0366
2017	Crossland X		Battery Sensor Module	√			√		
2017	Crossland X		Power Sounder Content Theft Deterrent Alarm Module	√	√	√	√	√	
2017	Crossland X		Infotainment Faceplate Control Module	√	√	√			
2017	Crossland X		Info Display Module	√	√	√	√	√	
2017	Crossland X		Left Steering Wheel Controls Switch	√	√	√	√	√	
2017	Crossland X		Traction Control Switch	√			√		
2017	Crossland X		Right Front Seat Heating Control Module	√			√	√	
2017	Crossland X		Left Front Seat Heating Control Module	√			√	√	
2017	Crossland X		Trailer Lighting Control Module	√	√	√	√	√	
2017	Insignia		Engine Control Module	√	√	√	√	√	SP0048,SP0084,SP0091,SP0131,SP0092,SP0019,SP0016,SP0093,SP0210,SP0315,SP0320,SP0306,SP0018,SP0380,SP0390,SP0130,SP0085,SP0129,SP0121,SP0104,SP0132,SP0135,SP0136,SP0137,SP0247,SP0248,SP0252,SP0251,SP0388,SP0106,SP0049,SP0309,SP0357,SP0359,SP0361,SP0363,SP0400,SP0385,SP0017,SP0541,SP058B,SP0587,SP0599,SP0095

2017	Insignia		Transmission Control Module	√	√	√	√	√	SP0051,SP0422,SP0223,SP0122
2017	Insignia		Electronic Brake Control Module	√	√	√	√	√	SP0394,SP0083,SP0086,SP0457
2017	Insignia		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	SP0347,SP0086
2017	Insignia		Body Control Module	√	√	√	√	√	SP0047,SP0048,SP0045,SP0378,SP0372,S P0376,SP0046,SP0334,SP0332,SP0455
2017	Insignia		Instrument Cluster	√	√	√	√	√	SP0040
2017	Insignia		HVAC Control Module	√	√	√	√	√	SP0211,SP0040,SP0307
2017	Insignia		HVAC Controls	√	√	√	√	√	
2017	Insignia		Steering Column Lock Control Module	√	√	√	√		
2017	Insignia		Keyless Entry Control Module	√	√	√	√	√	
2017	Insignia		Human Machine Interface Control Module	√	√	√	√	√	SP0326
2017	Insignia		Liftgate Control Module	√	√	√	√		SP0323,SP0343
2017	Insignia		Fuel Injector Control Module	√			√	√	
2017	Insignia		Headlamp Control Module	√	√	√	√	√	SP0366
2017	Insignia		Telematics Communication Interface Control Module	√	√	√	√	√	SP0216,SP0215
2017	Insignia		Amplifier	√	√	√	√		
2017	Insignia		Parking Assist Control Module	√	√	√	√	√	SP0040
2017	Insignia		Left Side Object Detection Control Module	√	√	√		√	
2017	Insignia		Frontview Camera Module	√	√	√	√	√	SP0108,SP0368,SP0040
2017	Insignia		Distance Sensing Cruise Control Module	√	√	√	√		SP0231
2017	Insignia		Steering Wheel Angle Sensor Module	√	√	√			SP0082,SP0083
2017	Insignia		Suspension Control Module	√	√	√	√	√	
2017	Insignia		Rear Differential Clutch Control Module	√	√	√	√	√	
2017	Insignia		Front Seat Heating/Venting/Cooling/Memory Control	√	√	√	√	√	
2017	Insignia		Parking Brake Control Module	√	√	√	√	√	SP0109
2017	Insignia		Power Steering Control Module	√	√	√	√	√	SP0090,SP0088,SP0089
2017	Insignia		Radio	√	√	√	√	√	SP0396,SP0213
2017	Insignia		Chassis Control Module	√	√	√	√	√	SP0016,SP0271,SP0365
2017	Insignia		Radio Controls	√	√	√	√	√	SP0326
2017	Insignia		Trailer Interface Control Module	√	√	√	√	√	SP0040
2017	Karl / Viva		Engine Control Module	√	√	√	√	√	SP0048,SP0084,SP0091,SP0092,SP0019,S P0016,SP0093,SP0315,SP0210,SP0306
2017	Karl / Viva		Transmission Control Module	√	√	√	√	√	SP0314,SP0427,SP0330
2017	Karl / Viva		Electronic Brake Control Module	√	√	√	√	√	SP0083
2017	Karl / Viva		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	SP0347,SP0086
2017	Karl / Viva		Body Control Module	√	√	√	√	√	SP0047,SP0048,SP0045,SP0378,SP0372,S P0376,SP0046,SP0334,SP0332,SP0455
2017	Karl / Viva		Instrument Cluster	√	√	√	√	√	SP0040

2017	Karl / Viva		HVAC Control Module	√	√	√	√	√	SP0211,SP0040,SP0307
2017	Karl / Viva		HVAC Controls	√	√	√	√	√	
2017	Karl / Viva		Serial Data Gateway Module	√	√	√			
2017	Karl / Viva		Fuel Injector Control Module	√	√	√	√	√	SP0306
2017	Karl / Viva		Parking Assist Control Module	√	√	√	√	√	SP0450,SP0040
2017	Karl / Viva		Frontview Camera Module	√	√	√	√		SP0108,SP0368,SP0401
2017	Karl / Viva		Power Steering Control Module	√	√	√	√		SP0090
2017	Karl / Viva		Radio	√	√	√	√	√	SP0396
2017	Karl / Viva		Telematics Communication Interface Control Module	√	√	√	√	√	SP0216,SP0215
2017	Meriva-B		Engine Control Module	√	√	√	√	√	SP0084,SP0380,SP0390,SP0130,SP0085,SP0092,SP0131,SP0129,SP0121,SP0104,SP0019,SP0132,SP0016,SP0135,SP0136,SP0137,SP0247,SP0248,SP0252,SP0251,SP0388,SP0106,SP0049,SP0306,SP0048,SP0091,SP0210,SP0315,SP0320,SP0093
2017	Meriva-B		Transmission Control Module	√	√	√	√	√	SP0223,SP0122
2017	Meriva-B		Electronic Brake Control Module	√	√	√	√	√	SP0082,SP0460,SP0269
2017	Meriva-B		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	SP0347,SP0086
2017	Meriva-B		Body Control Module	√	√	√	√	√	SP0047,SP0045,SP0372,SP0378,SP0376,SP0040,SP0046,SP0217,SP0334,SP0332
2017	Meriva-B		Instrument Cluster	√	√	√	√	√	SP0040
2017	Meriva-B		HVAC Control Module	√	√	√	√	√	SP0211,SP0040
2017	Meriva-B		Headlamp Control Module	√	√	√	√	√	SP0366
2017	Meriva-B		Fuel Injector Control Module	√			√	√	
2017	Meriva-B		Trailer Interface Control Module	√	√	√	√	√	SP0040
2017	Meriva-B		Parking Assist Control Module	√	√	√	√	√	SP0040
2017	Meriva-B		Steering Wheel Angle Sensor Module	√	√	√			SP0082,SP0083
2017	Meriva-B		Parking Brake Control Module	√	√	√	√	√	SP0109
2017	Meriva-B		Power Steering Control Module	√	√	√	√	√	
2017	Meriva-B		Front Seat Heating Control Module	√	√	√	√	√	
2017	Meriva-B		Radio	√	√	√	√	√	
2017	Meriva-B		Digital Radio Receiver Control Module	√	√	√	√	√	SP0040
2017	Meriva-B		Telematics Communication Interface Control Module	√	√	√	√	√	SP0216,SP0215
2017	Meriva-B		Mobile Telephone Control Module	√	√	√	√	√	SP0040

2017	Mokka		Engine Control Module	√	√	√	√	√	SP0048,SP0084,SP0091,SP0131,SP0092,SP0019,SP0016,SP0093,SP0210,SP0315,SP0320,SP0306,SP0380,SP0390,SP0130,SP0085,SP0129,SP0121,SP0104,SP0132,SP0135,SP0136,SP0137,SP0247,SP0248,SP0252,SP0251,SP0388,SP0106,SP0049,SP0385,SP0017,SP0018,SP0541,SP058B,SP0587,SP0500
2017	Mokka		Transmission Control Module	√	√	√	√	√	SP0422
2017	Mokka		Electronic Brake Control Module	√	√	√	√	√	SP0083
2017	Mokka		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	SP0347,SP0086
2017	Mokka		Body Control Module	√	√	√	√	√	SP0047,SP0048,SP0045,SP0378,SP0372,SP0376,SP0046,SP0334,SP0332,SP0455
2017	Mokka		Instrument Cluster	√	√	√	√	√	SP0040
2017	Mokka		HVAC Control Module	√	√	√	√	√	SP0211,SP0040,SP0307
2017	Mokka		Serial Data Gateway Module	√	√	√			
2017	Mokka		Fuel Injector Control Module	√			√	√	
2017	Mokka		Headlamp Control Module	√	√	√	√	√	SP0366
2017	Mokka		Rear Differential Clutch Control Module	√	√	√	√		SP0206,SP05CA
2017	Mokka		Steering Wheel Angle Sensor Module	√	√	√			SP0082,SP0083
2017	Mokka		Frontview Camera Module	√	√	√	√	√	SP0108,SP0368,SP0040
2017	Mokka		Telematics Communication Interface Control Module	√	√	√	√	√	SP0216,SP0215
2017	Mokka		Trailer Interface Control Module	√	√	√	√	√	SP0040
2017	Mokka		Front Seat Heating Control Module	√	√	√	√	√	
2017	Mokka		Power Steering Control Module	√	√	√	√		SP0377
2017	Mokka		Radio	√	√	√	√	√	SP0396,SP0213
2017	Mokka		Parking Assist Control Module	√	√	√	√	√	SP0040
2017	Mokka		Human Machine Interface Control Module	√	√	√	√	√	SP0326
2017	Mokka		Amplifier	√	√	√	√		
2017	Mokka		Keyless Entry Control Module	√	√	√	√	√	
2017	Mokka		Radio Controls	√	√	√	√	√	
2017	Mokka		Steering Column Lock Control Module	√	√	√	√		
2017	Mokka		Power Supply Transformer	√	√	√	√		
2017	Movano-B		Engine Control Module	√	√	√	√	√	SP0084,SP0098,SP0276,SP0099,SP0385,SP0285,SP0085,SP0318,SP0102,SP05C4,SP0104,SP0354,SP0349,SP0284,SP0464,SP0356,SP0358,SP0360,SP0362,SP0106,SP0325,SP0048,SP0380,SP0345,SP0352,SP0102,SP0040
2017	Movano-B		Transmission Control Module	√	√	√	√	√	SP0314,SP0222,SP0427

2017	Movano-B		Electronic Brake Control Module	√	√	√	√	√	SP0083,SP0289,SP0461,SP0086,SP0082,S P0447,SP0290,SP0460,SP0407,SP0286
2017	Movano-B		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	
2017	Movano-B		Body Control Module	√	√	√	√	√	
2017	Movano-B		Instrument Cluster	√	√	√	√	√	
2017	Movano-B		HVAC Control Module	√	√	√	√	√	SP0211
2017	Movano-B		Serial Data Gateway Module	√	√	√	√	√	
2017	Movano-B		Auxiliary Body Control Module	√	√	√	√	√	SP0354
2017	Movano-B		Multifunction Accessory Control Module	√	√	√	√		
2017	Movano-B		Parking Assist Control Module	√	√	√	√		
2017	Movano-B		Frontview Camera Module	√	√	√	√		
2017	Movano-B		Radio	√	√	√	√	√	SP0292
2017	Movano-B		Info Display Module	√	√	√	√	√	
2017	Movano-B		Power Steering Control Module	√	√	√	√		
2017	Movano-B		Tire Pressure Indicator Module	√	√	√	√		SP0402,SP0467,SP0436,SP0434,SP0465
2017	Movano-B		Reductant Control Module	√	√	√	√	√	SP0297,SP0294,SP0299,SP05C3,SP0135
2017	Movano-B		Telematics Communication Interface Control Module	√	√	√	√		SP0214
2017	Vivaro-B		Engine Control Module	√	√	√	√	√	SP0325,SP0048,SP0380,SP0098,SP0271,S P0276,SP0273,SP0274,SP0385,SP0285,SP 0085,SP0318,SP0319,SP0102,SP0352,SP0 103,SP0104,SP0354,SP0432,SP0349,SP04 64,SP0284,SP0049,SP0106
2017	Vivaro-B		Electronic Brake Control Module	√	√	√	√	√	SP0083,SP0289,SP0461,SP0082,SP0290,S P0460,SP0447,SP0286,SP0407
2017	Vivaro-B		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√		
2017	Vivaro-B		Body Control Module	√	√	√	√	√	SP0402,SP0467,SP0436,SP0434,SP0465
2017	Vivaro-B		Instrument Cluster	√	√	√	√	√	
2017	Vivaro-B		HVAC Control Module	√	√	√	√	√	
2017	Vivaro-B		Serial Data Gateway Module	√	√	√	√	√	
2017	Vivaro-B		Auxiliary Body Control Module	√	√	√	√	√	SP0239,SP0354
2017	Vivaro-B		Multifunction Accessory Control Module	√	√	√	√		
2017	Vivaro-B		Parking Assist Control Module	√	√	√	√	√	SP0423,SP0277
2017	Vivaro-B		Keyless Entry Control Module	√	√	√	√	√	
2017	Vivaro-B		Parking Heater Control Module	√	√	√	√	√	SP0451,SP0452
2017	Vivaro-B		Info Display Module	√	√	√	√	√	
2017	Vivaro-B		Power Steering Control Module	√	√	√	√		
2017	Vivaro-B		Radio	√	√	√	√	√	SP0292
2017	Vivaro-B		Reductant Control Module	√	√	√	√	√	SP0297,SP0294,SP0299,SP05C3,SP0135

2017	Vivaro-B		Telematics Communication Interface Control Module	√	√	√	√		SP0214
2017	Zafira-C		Engine Control Module	√	√	√	√	√	SP0048,SP0084,SP0091,SP0131,SP0092,SP0019,SP0016,SP0093,SP0210,SP0315,SP0320,SP0306,SP0096,SP0128,SP0085,SP0102,SP0380,SP0103,SP0101,SP0129,SP0385,SP0017,SP0018,SP0541,SP058B,SP0587,SP0599,SP0390,SP0130,SP0121,SP0104,SP0132,SP0135,SP0136,SP0137,SP0247,SP0248,SP0252,SP0251,SP0388,SP0106,SP0049,SP0309,SP0357,SP0359,SP0361,SP0363,SP0400
2017	Zafira-C		Transmission Control Module	√	√	√	√	√	SP0223,SP0122,SP0422
2017	Zafira-C		Electronic Brake Control Module	√	√	√	√	√	SP0083,SP0394,SP0086
2017	Zafira-C		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	SP0347,SP0086
2017	Zafira-C		Body Control Module	√	√	√	√	√	SP0047,SP0048,SP0045,SP0378,SP0372,SP0376,SP0046,SP0334,SP0332,SP0455
2017	Zafira-C		Instrument Cluster	√	√	√	√	√	SP0040
2017	Zafira-C		HVAC Control Module	√	√	√	√	√	SP0211,SP0040,SP0307
2017	Zafira-C		Fuel Injector Control Module	√			√	√	
2017	Zafira-C		Headlamp Control Module	√	√	√	√	√	SP0366
2017	Zafira-C		Telematics Communication Interface Control Module	√	√	√	√	√	SP0216,SP0215
2017	Zafira-C		Front Seat Heating Control Module	√	√	√	√	√	
2017	Zafira-C		Parking Brake Control Module	√	√	√	√	√	SP0109
2017	Zafira-C		Power Steering Control Module	√	√	√	√		SP0088,SP0089,SP0090
2017	Zafira-C		Radio	√	√	√	√	√	
2017	Zafira-C		Trailer Interface Control Module	√	√	√	√	√	SP0040
2017	Zafira-C		Parking Assist Control Module	√	√	√	√	√	SP0040
2017	Zafira-C		Suspension Control Module	√	√	√	√	√	
2017	Zafira-C		Distance Sensing Cruise Control Module	√	√	√	√		SP0231
2017	Zafira-C		Steering Wheel Angle Sensor Module	√	√	√			SP0082,SP0083
2017	Zafira-C		Frontview Camera Module	√	√	√	√	√	SP0108,SP0368,SP0040
2017	Zafira-C		Chassis Control Module	√	√	√	√	√	SP0016,SP0271,SP0365
2017	Zafira-C		Digital Radio Receiver Control Module	√	√	√	√	√	SP0040
2016	Adam		Engine Control Module	√	√	√	√	√	SP0048,SP0084,SP0091,SP0131,SP0092,SP0019,SP0016,SP0093,SP0210,SP0315,SP0320,SP0306,SP0385,SP0017,SP0018,SP0541,SP058B,SP0587,SP0599
2016	Adam		Transmission Control Module	√	√	√	√	√	SP0314,SP0427,SP0330
2016	Adam		Electronic Brake Control Module	√	√	√	√	√	SP0082,SP0460,SP0269

2016	Adam		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	SP0347,SP0086
2016	Adam		Body Control Module	√	√	√	√	√	SP0047,SP0048,SP0045,SP0372,SP0046,SP0334,SP0332,SP0455
2016	Adam		Instrument Cluster	√	√	√	√	√	SP0040
2016	Adam		HVAC Control Module	√	√	√	√	√	SP0211,SP0040,SP0307
2016	Adam		Fuel Injector Control Module	√	√	√	√	√	SP0306
2016	Adam		Parking Assist Control Module	√	√	√	√	√	SP0040
2016	Adam		Trailer Interface Control Module	√	√	√	√	√	SP0040
2016	Adam		Power Steering Control Module	√	√	√	√		SP0090
2016	Adam		Radio	√	√	√	√	√	
2016	Adam		Telematics Communication Interface Control Module	√	√	√	√	√	SP0216,SP0215
2016	Adam		Chassis Control Module	√	√	√	√	√	SP0016,SP0271,SP0365
2016	Antara		Engine Control Module	√	√	√	√	√	SP0084,SP0380,SP0092,SP0131,SP0129,SP0121,SP0104,SP0019,SP0132,SP0016,SP0309,SP0135,SP0247,SP0248,SP0136,SP0357,SP0359,SP0361,SP0363,SP0400,SP01
2016	Antara		Transmission Control Module	√	√	√	√	√	SP0223,SP0122
2016	Antara		Electronic Brake Control Module	√	√	√	√	√	SP0083
2016	Antara		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	SP0347,SP0442
2016	Antara		Body Control Module	√	√	√	√	√	SP0047,SP0048,SP0442
2016	Antara		Theft Deterrent Module	√	√	√	√		
2016	Antara		Instrument Cluster	√	√	√	√	√	
2016	Antara		HVAC Control Module	√	√	√		√	
2016	Antara		Parking Brake Control Module	√	√	√	√	√	SP0109
2016	Antara		Parking Assist Control Module	√	√	√	√	√	
2016	Antara		Headlamp Control Module	√	√	√	√	√	SP0366,SP0243
2016	Antara		Mobile Telephone Control Module	√	√	√		√	SP0040,SP0243,SP0423,SP0420
2016	Antara		Remote Control Door Lock Receiver	√	√	√	√	√	SP0374,SP0413,SP0335,SP0336,SP0337,SP0338,SP0332,SP0334,SP05CD,SP0403
2016	Antara		Auxiliary Body Control Module	√	√	√	√	√	SP0236
2016	Antara		Info Display Module	√	√	√	√	√	SP0344,SP05CE,SP05CF,SP0040,SP0420,SP0243,SP0423,SP0398
2016	Antara		Radio	√	√	√	√	√	SP0344,SP0428,SP0040,SP0420,SP0243,SP0431,SP0409
2016	Antara		Rear Differential Clutch Control Module	√	√	√	√	√	SP0328
2016	Antara		Power Steering Control Module	√	√	√	√		SP0088,SP0089,SP0090

2016	Astra-J		Engine Control Module	√	√	√	√	√	SP0084,SP0380,SP0390,SP0130,SP0085,SP0092,SP0131,SP0129,SP0121,SP0104,SP0019,SP0132,SP0016,SP0135,SP0136,SP0137,SP0247,SP0248,SP0252,SP0251,SP0388,SP0106,SP0049,SP0306,SP0048,SP0091,SP0093,SP0210,SP0315,SP0320,SP0385,SP0017,SP0018,SP0541,SP058B,SP0587,SP0599,SP0096,SP0098,SP0099,SP0100,SP0101,SP0318,SP0102,SP0103,SP0105,SP0095
2016	Astra-J		Transmission Control Module	√	√	√	√	√	SP0223,SP0122,SP0422
2016	Astra-J		Electronic Brake Control Module	√	√	√	√	√	SP0083,SP0394,SP0086
2016	Astra-J		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	SP0347
2016	Astra-J		Body Control Module	√	√	√	√	√	SP0047,SP0048,SP0045,SP0378,SP0372,SP0376,SP0046,SP0334,SP0332,SP0455
2016	Astra-J		Instrument Cluster	√	√	√	√	√	SP0040
2016	Astra-J		HVAC Control Module	√	√	√	√	√	SP0211,SP0040,SP0307
2016	Astra-J		Steering Wheel Angle Sensor Module	√	√	√			SP0082,SP0083
2016	Astra-J		Frontview Camera Module	√	√	√	√	√	SP0108,SP0368,SP0040
2016	Astra-J		Multi-Axis Acceleration Sensor Module	√	√	√			SP0350,SP0086
2016	Astra-J		Fuel Injector Control Module	√			√	√	
2016	Astra-J		Headlamp Control Module	√	√	√	√	√	SP0366
2016	Astra-J		Parking Assist Control Module	√	√	√	√	√	SP0040
2016	Astra-J		Front Seat Heating Control Module	√	√	√	√	√	
2016	Astra-J		Power Steering Control Module	√	√	√	√		SP0088,SP0089,SP0090
2016	Astra-J		Parking Brake Control Module	√	√	√	√	√	SP0109
2016	Astra-J		Trailer Interface Control Module	√	√	√	√	√	SP0040
2016	Astra-J		Telematics Communication Interface Control Module	√	√	√	√	√	SP0216,SP0215
2016	Astra-J		Radio	√	√	√	√	√	
2016	Astra-J		Digital Radio Receiver Control Module	√	√	√	√	√	SP0040
2016	Astra-J		Suspension Control Module	√	√	√	√	√	
2016	Astra-J		Chassis Control Module	√	√	√	√	√	SP0016,SP0271,SP0365
2016	Astra-K		Engine Control Module	√	√	√	√	√	SP0048,SP0084,SP0091,SP0385,SP0017,SP0018,SP0131,SP0092,SP0541,SP0019,SP058B,SP0587,SP0599,SP0016,SP0210,SP0320,SP0306,SP0380,SP0390,SP0130,SP0085,SP0129,SP0121,SP0104,SP0132,SP0135,SP0136,SP0137,SP0252,SP0251,SP0388,SP0106,SP0049,SP0093,SP0315

2016	Astra-K		Transmission Control Module	√	√	√	√	√	SP0422,SP0314,SP0427,SP0330
2016	Astra-K		Electronic Brake Control Module	√	√	√	√	√	SP0109,SP0083,SP0460
2016	Astra-K		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	SP0347,SP0086
2016	Astra-K		Body Control Module	√	√	√	√	√	SP0047,SP0048,SP0045,SP0378,SP0372,S P0376,SP0046,SP0334,SP0332,SP0455
2016	Astra-K		Instrument Cluster	√	√	√	√	√	SP0040
2016	Astra-K		HVAC Control Module	√	√	√	√	√	SP0211,SP0040,SP0307
2016	Astra-K		HVAC Controls	√	√	√	√	√	
2016	Astra-K		Radio	√	√	√	√	√	SP0396,SP0213
2016	Astra-K		Power Steering Control Module	√	√	√	√		SP0090
2016	Astra-K		Seat Memory Control Module	√	√	√	√	√	
2016	Astra-K		Parking Assist Control Module	√	√	√	√	√	SP0450,SP0040
2016	Astra-K		Trailer Interface Control Module	√	√	√	√	√	SP0040
2016	Astra-K		Radio Controls	√	√	√	√	√	SP0326
2016	Astra-K		Telematics Communication Interface Control Module	√	√	√	√	√	SP0216,SP0215
2016	Astra-K		Human Machine Interface Control Module	√	√	√	√	√	SP0326
2016	Astra-K		Frontview Camera Module	√	√	√	√		SP0108,SP0368,SP0401
2016	Astra-K		Headlamp Control Module	√	√	√	√	√	SP0366
2016	Astra-K		Keyless Entry Control Module	√	√	√	√	√	
2016	Astra-K		Liftgate Control Module	√	√	√	√		SP0323,SP0343
2016	Astra-K		Steering Column Lock Control Module	√	√	√	√		
2016	Astra-K		Power Supply Transformer	√	√	√	√		
2016	Cascada		Engine Control Module	√	√	√	√	√	SP0048,SP0084,SP0091,SP0131,SP0092,S P0019,SP0016,SP0093,SP0210,SP0315,SP 0320,SP0306,SP0385,SP0017,SP0018,SP0 541,SP058B,SP0587,SP0599,SP0380,SP01 29,SP0121,SP0104,SP0132,SP0309,SP013 5,SP0247,SP0248,SP0136,SP0357,SP0359, SP0361,SP0363,SP0400,SP0106,SP0049
2016	Cascada		Transmission Control Module	√	√	√	√	√	SP0422
2016	Cascada		Electronic Brake Control Module	√	√	√	√	√	SP0083,SP0394,SP0086
2016	Cascada		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	SP0347,SP0086
2016	Cascada		Body Control Module	√	√	√	√	√	SP0047,SP0048,SP0045,SP0378,SP0372,S P0376,SP0046,SP0334,SP0332,SP0455
2016	Cascada		Instrument Cluster	√	√	√	√	√	SP0040
2016	Cascada		HVAC Control Module	√	√	√	√	√	SP0211,SP0040,SP0307
2016	Cascada		Steering Wheel Angle Sensor Module	√	√	√			SP0082,SP0083
2016	Cascada		Frontview Camera Module	√	√	√	√	√	SP0108,SP0368,SP0040

2016	Cascada		Multi-Axis Acceleration Sensor Module	√	√	√			SP0350,SP0086
2016	Cascada		Headlamp Control Module	√	√	√	√	√	SP0366
2016	Cascada		Parking Assist Control Module	√	√	√	√	√	SP0040
2016	Cascada		Front Seat Heating Control Module	√	√	√	√	√	
2016	Cascada		Power Steering Control Module	√	√	√	√		SP0088,SP0089,SP0090
2016	Cascada		Parking Brake Control Module	√	√	√	√	√	SP0109
2016	Cascada		Folding Top Control Module	√	√	√	√	√	SP0040,SP0207,SP0208
2016	Cascada		Telematics Communication Interface Control Module	√	√	√	√	√	SP0216,SP0215
2016	Cascada		Digital Radio Receiver Control Module	√	√	√	√	√	SP0040
2016	Cascada		Radio	√	√	√	√	√	
2016	Cascada		Suspension Control Module	√	√	√	√	√	
2016	Cascada		Chassis Control Module	√	√	√	√	√	SP0016,SP0271,SP0365
2016	Combo-D		Engine Control Module	√	√	√	√	√	SP0101,SP0131,SP0385,SP0085,SP0102,S P0464,SP05CB,SP0084,SP0221,SP0325,S P0426,SP0285,SP0274,SP0019,SP0104,SP 0121,SP05CC,SP0585,SP0234,SP0251,SP0 531,SP0049,SP0106,SP0316,SP0122,SP03 30,SP0099,SP0584,SP0273,SP0318,SP010 2,SP0520
2016	Combo-D		Transmission Control Module	√	√	√	√	√	SP0314,SP0427
2016	Combo-D		Electronic Brake Control Module	√	√	√	√	√	SP0459,SP0394,SP0083
2016	Combo-D		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	
2016	Combo-D		Body Control Module	√	√	√	√	√	SP0242,SP0418,SP0389
2016	Combo-D		Instrument Cluster	√	√	√	√	√	SP0218
2016	Combo-D		HVAC Control Module	√	√	√	√	√	SP0211
2016	Combo-D		Multimedia Player Interface Module	√	√	√	√	√	
2016	Combo-D		Tire Pressure Indicator Module	√	√	√	√		
2016	Combo-D		Auxiliary Heater Control Module	√	√	√	√	√	SP0278
2016	Combo-D		Parking Assist Control Module	√	√	√	√		SP0344
2016	Corsa-E		Engine Control Module	√	√	√	√	√	SP0084,SP0380,SP0085,SP0092,SP0131,S P0129,SP0121,SP0104,SP0019,SP0132,SP 0016,SP0252,SP0251,SP0388,SP0106,SP0 049,SP0306,SP0048,SP0091,SP0093,SP02 10,SP0315,SP0320,SP0385,SP0017,SP001 8,SP0541,SP058B,SP0587,SP0599
2016	Corsa-E		Transmission Control Module	√	√	√	√	√	SP0422,SP0314,SP0427,SP0330
2016	Corsa-E		Electronic Brake Control Module	√	√	√	√	√	SP0082,SP0460,SP0269
2016	Corsa-E		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	SP0347,SP0086

2016	Corsa-E		Body Control Module	√	√	√	√	√	SP0047,SP0048,SP0045,SP0372,SP0046,SP0334,SP0332,SP0455
2016	Corsa-E		Instrument Cluster	√	√	√	√	√	SP0040
2016	Corsa-E		HVAC Control Module	√	√	√	√	√	SP0211,SP0040,SP0307
2016	Corsa-E		Frontview Camera Module	√	√	√	√	√	SP0108,SP0368
2016	Corsa-E		Fuel Injector Control Module	√	√	√	√	√	SP0306
2016	Corsa-E		Parking Assist Control Module	√	√	√	√	√	SP0040
2016	Corsa-E		Power Steering Control Module	√	√	√	√		SP0090
2016	Corsa-E		Radio	√	√	√	√	√	
2016	Corsa-E		Trailer Interface Control Module	√	√	√	√	√	SP0040
2016	Corsa-E		Telematics Communication Interface Control Module	√	√	√	√	√	SP0216,SP0215
2016	Corsa-E		Chassis Control Module	√	√	√	√	√	SP0016,SP0271,SP0365
2016	Insignia		Engine Control Module	√	√	√	√	√	SP0048,SP0084,SP0091,SP0131,SP0092,SP0019,SP0016,SP0093,SP0210,SP0315,SP0320,SP0306,SP0385,SP0017,SP0018,SP0541,SP058B,SP0587,SP0599,SP0095,SP0380,SP0129,SP0121,SP0104,SP0132,SP0309,SP0135,SP0247,SP0248,SP0136,SP0357,SP0359,SP0361,SP0363,SP0400,SP0106,SP0049,SP0390,SP0130,SP0085,SP0137,SP0252,SP0251,SP0388
2016	Insignia		Transmission Control Module	√	√	√	√	√	SP0223,SP0122,SP0051,SP0422
2016	Insignia		Electronic Brake Control Module	√	√	√	√	√	SP0394,SP0083,SP0086,SP0457
2016	Insignia		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	SP0347,SP0086
2016	Insignia		Body Control Module	√	√	√	√	√	SP0047,SP0048,SP0045,SP0378,SP0372,SP0376,SP0046,SP0334,SP0332,SP0455
2016	Insignia		Instrument Cluster	√	√	√	√	√	SP0040
2016	Insignia		HVAC Control Module	√	√	√	√	√	SP0211,SP0040,SP0307
2016	Insignia		HVAC Controls	√	√	√	√	√	
2016	Insignia		Keyless Entry Control Module	√	√	√	√	√	
2016	Insignia		Steering Column Lock Control Module	√	√	√	√		
2016	Insignia		Front Seat Heating/Venting/Cooling/Memory Control	√	√	√	√	√	
2016	Insignia		Distance Sensing Cruise Control Module	√	√	√	√		SP0231
2016	Insignia		Steering Wheel Angle Sensor Module	√	√	√			SP0082,SP0083
2016	Insignia		Left Side Object Detection Control Module	√	√	√		√	
2016	Insignia		Frontview Camera Module	√	√	√	√	√	SP0108,SP0368,SP0040
2016	Insignia		Parking Assist Control Module	√	√	√	√	√	SP0040
2016	Insignia		Human Machine Interface Control Module	√	√	√	√	√	SP0326
2016	Insignia		Liftgate Control Module	√	√	√	√		SP0323,SP0343

2016	Insignia		Radio Controls	√	√	√	√	√	SP0326
2016	Insignia		Trailer Interface Control Module	√	√	√	√	√	SP0040
2016	Insignia		Parking Brake Control Module	√	√	√	√	√	SP0109
2016	Insignia		Power Steering Control Module	√	√	√	√	√	SP0090,SP0088,SP0089
2016	Insignia		Rear Differential Clutch Control Module	√	√	√	√	√	
2016	Insignia		Suspension Control Module	√	√	√	√	√	
2016	Insignia		Radio	√	√	√	√	√	SP0396,SP0213
2016	Insignia		Telematics Communication Interface Control Module	√	√	√	√	√	SP0216,SP0215
2016	Insignia		Amplifier	√	√	√	√		
2016	Insignia		Fuel Injector Control Module	√			√	√	
2016	Insignia		Headlamp Control Module	√	√	√	√	√	SP0366
2016	Insignia		Chassis Control Module	√	√	√	√	√	SP0016,SP0271,SP0365
2016	Karl / Viva		Engine Control Module	√	√	√	√	√	SP0048,SP0084,SP0091,SP0092,SP0019,S P0016,SP0093,SP0315,SP0210,SP0306
2016	Karl / Viva		Transmission Control Module	√	√	√	√	√	SP0314,SP0427,SP0330
2016	Karl / Viva		Electronic Brake Control Module	√	√	√	√	√	SP0083
2016	Karl / Viva		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	SP0347,SP0086
2016	Karl / Viva		Body Control Module	√	√	√	√	√	SP0047,SP0048,SP0045,SP0378,SP0372,S P0376,SP0046,SP0334,SP0332,SP0455
2016	Karl / Viva		Instrument Cluster	√	√	√	√	√	SP0040
2016	Karl / Viva		HVAC Control Module	√	√	√	√	√	SP0211,SP0040,SP0307
2016	Karl / Viva		HVAC Controls	√	√	√	√	√	
2016	Karl / Viva		Radio	√	√	√	√	√	SP0396
2016	Karl / Viva		Power Steering Control Module	√	√	√	√		SP0090
2016	Karl / Viva		Parking Assist Control Module	√	√	√	√	√	SP0450,SP0040
2016	Karl / Viva		Frontview Camera Module	√	√	√	√		SP0108,SP0368,SP0401
2016	Karl / Viva		Fuel Injector Control Module	√	√	√	√	√	SP0306
2016	Karl / Viva		Telematics Communication Interface Control Module	√	√	√	√	√	SP0216,SP0215
2016	Meriva-B		Engine Control Module	√	√	√	√	√	SP0084,SP0380,SP0390,SP0130,SP0085,S P0092,SP0131,SP0129,SP0121,SP0104,SP 0019,SP0132,SP0016,SP0135,SP0136,SP0 137,SP0247,SP0248,SP0252,SP0251,SP03 88,SP0106,SP0049,SP0306,SP0048,SP009 1,SP0210,SP0315,SP0320,SP0093
2016	Meriva-B		Transmission Control Module	√	√	√	√	√	SP0223,SP0122
2016	Meriva-B		Electronic Brake Control Module	√	√	√	√	√	SP0082,SP0460,SP0269
2016	Meriva-B		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	SP0347,SP0086

2016	Meriva-B		Body Control Module	√	√	√	√	√	SP0047,SP0045,SP0372,SP0378,SP0376,SP0040,SP0046,SP0217,SP0334,SP0332
2016	Meriva-B		Instrument Cluster	√	√	√	√	√	SP0040
2016	Meriva-B		HVAC Control Module	√	√	√	√	√	SP0211,SP0040
2016	Meriva-B		Steering Wheel Angle Sensor Module	√	√	√			SP0082,SP0083
2016	Meriva-B		Fuel Injector Control Module	√			√	√	
2016	Meriva-B		Headlamp Control Module	√	√	√	√	√	SP0366
2016	Meriva-B		Parking Assist Control Module	√	√	√	√	√	SP0040
2016	Meriva-B		Front Seat Heating Control Module	√	√	√	√	√	
2016	Meriva-B		Parking Brake Control Module	√	√	√	√	√	SP0109
2016	Meriva-B		Power Steering Control Module	√	√	√	√	√	
2016	Meriva-B		Radio	√	√	√	√	√	
2016	Meriva-B		Trailer Interface Control Module	√	√	√	√	√	SP0040
2016	Meriva-B		Telematics Communication Interface Control Module	√	√	√	√	√	SP0216,SP0215
2016	Meriva-B		Digital Radio Receiver Control Module	√	√	√	√	√	SP0040
2016	Meriva-B		Mobile Telephone Control Module	√	√	√	√	√	SP0040
2016	Mokka		Engine Control Module	√	√	√	√	√	SP0084,SP0380,SP0390,SP0130,SP0085,SP0092,SP0131,SP0129,SP0121,SP0104,SP0019,SP0132,SP0016,SP0135,SP0136,SP0137,SP0247,SP0248,SP0252,SP0251,SP0388,SP0106,SP0049,SP0306,SP0048,SP0091,SP0093,SP0210,SP0315,SP0320
2016	Mokka		Transmission Control Module	√	√	√	√	√	SP0422
2016	Mokka		Electronic Brake Control Module	√	√	√	√	√	SP0083
2016	Mokka		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	SP0347,SP0086
2016	Mokka		Body Control Module	√	√	√	√	√	SP0047,SP0048,SP0045,SP0378,SP0372,SP0376,SP0046,SP0334,SP0332,SP0455
2016	Mokka		Instrument Cluster	√	√	√	√	√	SP0040
2016	Mokka		HVAC Control Module	√	√	√	√	√	SP0211,SP0040,SP0307
2016	Mokka		Digital Radio Receiver Control Module	√	√	√	√	√	SP0040
2016	Mokka		Radio	√	√	√	√	√	
2016	Mokka		Steering Wheel Angle Sensor Module	√	√	√			SP0082,SP0083
2016	Mokka		Frontview Camera Module	√	√	√	√	√	SP0108,SP0368,SP0040
2016	Mokka		Trailer Interface Control Module	√	√	√	√	√	SP0040
2016	Mokka		Power Steering Control Module	√	√	√	√		SP0377
2016	Mokka		Headlamp Control Module	√	√	√	√	√	SP0366
2016	Mokka		Fuel Injector Control Module	√			√	√	
2016	Mokka		Front Seat Heating Control Module	√	√	√	√	√	

2016	Mokka		Parking Assist Control Module	√	√	√	√	√	SP0040
2016	Mokka		Telematics Communication Interface Control Module	√	√	√	√	√	SP0216,SP0215
2016	Mokka		Rear Differential Clutch Control Module	√	√	√	√		SP0206,SP05CA
2016	Movano-B		Engine Control Module	√	√	√	√	√	SP0084,SP0098,SP0276,SP0099,SP0385,SP0285,SP0318,SP0102,SP05C4,SP0104,SP0354,SP0349,SP0284,SP0464,SP0356,SP0358,SP0360,SP0362,SP0106,SP0085,SP0325,SP0048,SP0380,SP0345,SP0352,SP0104,SP0040
2016	Movano-B		Transmission Control Module	√	√	√	√	√	SP0314,SP0222,SP0427
2016	Movano-B		Electronic Brake Control Module	√	√	√	√	√	SP0083,SP0289,SP0461,SP0086,SP0082,SP0447,SP0290,SP0460,SP0407,SP0286
2016	Movano-B		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	
2016	Movano-B		Body Control Module	√	√	√	√	√	
2016	Movano-B		Instrument Cluster	√	√	√	√	√	
2016	Movano-B		HVAC Control Module	√	√	√	√	√	SP0211
2016	Movano-B		Serial Data Gateway Module	√	√	√	√	√	
2016	Movano-B		Frontview Camera Module	√	√	√	√		
2016	Movano-B		Power Steering Control Module	√	√	√	√		
2016	Movano-B		Multifunction Accessory Control Module	√	√	√	√		
2016	Movano-B		Tire Pressure Indicator Module	√	√	√	√		SP0402,SP0467,SP0436,SP0434,SP0465
2016	Movano-B		Auxiliary Body Control Module	√	√	√	√	√	SP0354
2016	Movano-B		Radio	√	√	√	√	√	SP0292
2016	Movano-B		Parking Assist Control Module	√	√	√	√		
2016	Movano-B		Reductant Control Module	√	√	√	√	√	SP0297,SP0294,SP0299,SP05C3,SP0135
2016	Vivaro-B		Engine Control Module	√	√	√	√	√	SP0380,SP0098,SP0271,SP0276,SP0273,SP0274,SP0385,SP0285,SP0085,SP0318,SP0319,SP0102,SP0104,SP0354,SP0432,SP0349,SP0464,SP0284,SP0049,SP0106
2016	Vivaro-B		Electronic Brake Control Module	√	√	√	√	√	SP0083,SP0289,SP0461,SP0082,SP0290,SP0460,SP0447,SP0286,SP0407
2016	Vivaro-B		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√		
2016	Vivaro-B		Body Control Module	√	√	√	√	√	SP0402,SP0467,SP0436,SP0434,SP0465
2016	Vivaro-B		Instrument Cluster	√	√	√	√	√	
2016	Vivaro-B		HVAC Control Module	√	√	√	√	√	
2016	Vivaro-B		Serial Data Gateway Module	√	√	√	√	√	
2016	Vivaro-B		Power Steering Control Module	√	√	√	√		
2016	Vivaro-B		Multifunction Accessory Control Module	√	√	√	√		
2016	Vivaro-B		Auxiliary Body Control Module	√	√	√	√	√	SP0239,SP0354

2016	Vivaro-B		Parking Assist Control Module	√	√	√	√	√	SP0423,SP0277
2016	Vivaro-B		Info Display Module	√	√	√	√	√	
2016	Vivaro-B		Radio	√	√	√	√	√	SP0292
2016	Vivaro-B		Keyless Entry Control Module	√	√	√	√	√	
2016	Vivaro-B		Reductant Control Module	√	√	√	√	√	SP0297,SP0294,SP0299,SP05C3,SP0135
2016	Vivaro-B		Telematics Communication Interface Control Module	√	√	√	√	√	SP0214
2016	Vivaro-B		Parking Heater Control Module	√	√	√	√	√	SP0451,SP0452
2016	Zafira-C		Engine Control Module	√	√	√	√	√	SP0084,SP0380,SP0390,SP0130,SP0085,SP0092,SP0131,SP0129,SP0121,SP0104,SP0019,SP0132,SP0016,SP0135,SP0136,SP0137,SP0247,SP0248,SP0252,SP0251,SP0388,SP0106,SP0049,SP0306,SP0309,SP0357,SP0359,SP0361,SP0363,SP0400,SP0048,SP0091,SP0093,SP0210,SP0315,SP0320,SP0096,SP0128,SP0102,SP0103,SP0101,SP0098,SP0099,SP0100,SP0385,SP0318,SP0105,SP0017,SP0018,SP0541,SP058B,SP0587,SP0599
2016	Zafira-C		Transmission Control Module	√	√	√	√	√	SP0223,SP0122,SP0422
2016	Zafira-C		Electronic Brake Control Module	√	√	√	√	√	SP0083,SP0394,SP0086
2016	Zafira-C		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	SP0347,SP0086
2016	Zafira-C		Body Control Module	√	√	√	√	√	SP0047,SP0048,SP0045,SP0378,SP0372,SP0376,SP0046,SP0334,SP0332,SP0455
2016	Zafira-C		Instrument Cluster	√	√	√	√	√	SP0040
2016	Zafira-C		HVAC Control Module	√	√	√	√	√	SP0211,SP0040,SP0307
2016	Zafira-C		Distance Sensing Cruise Control Module	√	√	√	√	√	SP0231
2016	Zafira-C		Steering Wheel Angle Sensor Module	√	√	√	√	√	SP0082,SP0083
2016	Zafira-C		Frontview Camera Module	√	√	√	√	√	SP0108,SP0368,SP0040
2016	Zafira-C		Fuel Injector Control Module	√	√	√	√	√	
2016	Zafira-C		Headlamp Control Module	√	√	√	√	√	SP0366
2016	Zafira-C		Parking Assist Control Module	√	√	√	√	√	SP0040
2016	Zafira-C		Front Seat Heating Control Module	√	√	√	√	√	
2016	Zafira-C		Parking Brake Control Module	√	√	√	√	√	SP0109
2016	Zafira-C		Power Steering Control Module	√	√	√	√	√	SP0088,SP0089,SP0090
2016	Zafira-C		Radio	√	√	√	√	√	
2016	Zafira-C		Trailer Interface Control Module	√	√	√	√	√	SP0040
2016	Zafira-C		Telematics Communication Interface Control Module	√	√	√	√	√	SP0216,SP0215
2016	Zafira-C		Digital Radio Receiver Control Module	√	√	√	√	√	SP0040
2016	Zafira-C		Suspension Control Module	√	√	√	√	√	

2016	Zafira-C		Chassis Control Module	√	√	√	√	√	SP0016,SP0271,SP0365
2016	Zafira-C		Special Vehicle Control Module	√	√	√	√	√	
2015	Adam		Engine Control Module	√	√	√	√	√	SP0048,SP0084,SP0091,SP0131,SP0092,S P0019,SP0016,SP0093,SP0210,SP0315,SP 0320,SP0306,SP0385,SP0017,SP0018,SP0 541,SP058B,SP0587,SP0599
2015	Adam		Transmission Control Module	√	√	√	√	√	SP0314,SP0427,SP0330
2015	Adam		Electronic Brake Control Module	√	√	√	√	√	SP0082,SP0460,SP0269
2015	Adam		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	SP0347,SP0086
2015	Adam		Body Control Module	√	√	√	√	√	SP0047,SP0048,SP0045,SP0372,SP0046,S P0334,SP0332,SP0455
2015	Adam		Instrument Cluster	√	√	√	√	√	SP0040
2015	Adam		HVAC Control Module	√	√	√	√	√	SP0211,SP0040,SP0307
2015	Adam		Fuel Injector Control Module	√	√	√	√	√	SP0306
2015	Adam		Power Steering Control Module	√	√	√	√	√	SP0090
2015	Adam		Parking Assist Control Module	√	√	√	√	√	SP0040
2015	Adam		Trailer Interface Control Module	√	√	√	√	√	SP0040
2015	Adam		Radio	√	√	√	√	√	
2015	Adam		Chassis Control Module	√	√	√	√	√	SP0016,SP0271,SP0365
2015	Ampera		Engine Control Module	√	√	√	√	√	SP0091,SP0017,SP0018,SP0019,SP0016,S P0586
2015	Ampera		Transmission Control Module	√	√	√	√	√	
2015	Ampera		Electronic Brake Control Module	√	√	√	√	√	SP0048,SP0565,SP0086
2015	Ampera		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	SP0347,SP0311,SP0086
2015	Ampera		Body Control Module	√	√	√	√	√	SP0370,SP0413,SP0335,SP0336,SP0337,S P0338,SP0339,SP0340,SP0341,SP0342,SP 0047,SP0048,SP0045,SP0372,SP0378,SP0 376,SP0046,SP0334,SP0403,SP0332
2015	Ampera		Instrument Cluster	√	√	√	√	√	SP0040
2015	Ampera		HVAC Control Module	√	√	√	√	√	SP0211,SP0307
2015	Ampera		Electric A/C Compressor Control Module	√					
2015	Ampera		Battery Energy Control Module	√			√		
2015	Ampera		Coolant Heater Control Module	√	√	√			
2015	Ampera		Battery Charger Control Module	√			√		
2015	Ampera		Hybrid Powertrain Control Module 2	√	√	√	√	√	SP0556,SP0303,SP0240,SP0559,SP0301,S P0302,SP0305
2015	Ampera		Hybrid Powertrain Control Module	√	√	√	√	√	
2015	Ampera		Drive Motor Control Module 1	√	√	√	√		

2015	Ampera		Drive Motor Control Module 2	√	√	√	√		
2015	Ampera		Auxiliary Transmission Fluid Pump	√	√	√	√		
2015	Ampera		Steering Column Lock Control Module	√	√	√	√		
2015	Ampera		Telematics Communication Interface Control Module	√	√	√	√		
2015	Ampera		Chassis Control Module	√	√	√	√	√	SP0016
2015	Ampera		Front Seat Heating Control Module	√	√	√	√	√	
2015	Ampera		Parking Assist Control Module	√	√	√	√	√	SP0040
2015	Ampera		Keyless Entry Control Module	√	√	√	√	√	
2015	Ampera		Radio	√	√	√	√	√	
2015	Ampera		Parking Brake Control Module	√	√	√	√	√	SP0109
2015	Ampera		Digital Radio Receiver Control Module	√	√	√	√	√	SP0040
2015	Ampera		Power Steering Control Module	√	√	√	√		SP0088,SP0089,SP0090
2015	Ampera		Steering Wheel Angle Sensor Module	√	√	√			SP0082,SP0083
2015	Ampera		Frontview Camera Module	√	√	√	√	√	SP0108,SP0368
2015	Antara		Engine Control Module	√	√	√	√	√	SP0048,SP0084,SP0091,SP0017,SP0018,SP0019,SP0016,SP0571,SP0099,SP0385,SP0130,SP05D0,SP0085,SP0318,SP0319,SP0102,SP0131,SP0285,SP05D1,SP0103,SP0121,SP0104,SP0106,SP0313,SP05D2,SP05D3,SP05D4,SP05D5,SP0095,SP0306
2015	Antara		Transmission Control Module	√	√	√	√	√	SP0422
2015	Antara		Electronic Brake Control Module	√	√	√	√	√	SP0083
2015	Antara		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	SP0347,SP0442
2015	Antara		Body Control Module	√	√	√	√	√	SP0047,SP0048,SP0442
2015	Antara		Theft Deterrent Module	√	√	√	√		
2015	Antara		Instrument Cluster	√	√	√	√	√	
2015	Antara		HVAC Control Module	√	√	√		√	
2015	Antara		Headlamp Control Module	√	√	√	√	√	SP0366,SP0243
2015	Antara		Variable Power Steering Control Module	√				√	
2015	Antara		Info Display Module	√	√	√	√	√	SP0344,SP05CE,SP05CF,SP0040,SP0420,SP0243,SP0423,SP0398
2015	Antara		Rear Differential Clutch Control Module	√	√	√	√	√	SP0328
2015	Antara		Parking Brake Control Module	√	√	√	√	√	SP0109
2015	Antara		Parking Assist Control Module	√	√	√	√	√	
2015	Antara		Auxiliary Body Control Module	√	√	√	√	√	SP0236
2015	Antara		Remote Control Door Lock Receiver	√	√	√	√	√	SP0374,SP0413,SP0335,SP0336,SP0337,SP0338,SP0332,SP0334,SP05CD,SP0403
2015	Antara		Mobile Telephone Control Module	√	√	√		√	SP0040,SP0243,SP0423,SP0420

2015	Antara		Radio	√	√	√	√	√	SP0344,SP0428,SP0040,SP0420,SP0243,S P0431,SP0409
2015	Antara		Chassis Control Module	√	√	√	√	√	SP0016,SP0271,SP0365
2015	Astra-J		Engine Control Module	√	√	√	√	√	SP0048,SP0084,SP0091,SP0092,SP0019,S P0016,SP0210,SP0315,SP0320,SP0131,SP 0093,SP0306,SP0380,SP0390,SP0130,SP0 085,SP0129,SP0121,SP0104,SP0132,SP01 33,SP0106,SP0049,SP0135,SP0136,SP013 7,SP0247,SP0248,SP0252,SP0251,SP0388, SP0017,SP0018,SP0385,SP0095,SP0541,S P058B,SP0587,SP0599,SP0096,SP0098,SP 0099,SP0100,SP0101,SP0318,SP0102,SP0 103,SP0105
2015	Astra-J		Transmission Control Module	√	√	√	√	√	SP0223,SP0122,SP0422
2015	Astra-J		Electronic Brake Control Module	√	√	√	√	√	SP0083,SP0394,SP0086
2015	Astra-J		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	SP0347
2015	Astra-J		Body Control Module	√	√	√	√	√	SP0047,SP0048,SP0045,SP0378,SP0372,S P0376,SP0046,SP0334,SP0332,SP0455
2015	Astra-J		Instrument Cluster	√	√	√	√	√	SP0040
2015	Astra-J		HVAC Control Module	√	√	√	√	√	SP0211,SP0040,SP0307
2015	Astra-J		Headlamp Control Module	√	√	√	√	√	SP0366
2015	Astra-J		Fuel Injector Control Module	√			√	√	
2015	Astra-J		Front Seat Heating Control Module	√	√	√	√	√	
2015	Astra-J		Suspension Control Module	√	√	√	√	√	
2015	Astra-J		Parking Assist Control Module	√	√	√	√	√	SP0040
2015	Astra-J		Parking Brake Control Module	√	√	√	√	√	SP0109
2015	Astra-J		Power Steering Control Module	√	√	√	√		SP0088,SP0089,SP0090
2015	Astra-J		Distance Sensing Cruise Control Module	√	√	√	√		SP0231
2015	Astra-J		Multi-Axis Acceleration Sensor Module	√	√	√			SP0350,SP0086
2015	Astra-J		Steering Wheel Angle Sensor Module	√	√	√			SP0082,SP0083
2015	Astra-J		Frontview Camera Module	√	√	√	√	√	SP0108,SP0368,SP0040
2015	Astra-J		Multimedia Player Interface Module	√	√	√	√		
2015	Astra-J		Trailer Interface Control Module	√	√	√	√	√	SP0040
2015	Astra-J		Digital Radio Receiver Control Module	√	√	√	√	√	SP0040
2015	Astra-J		Mobile Telephone Control Module	√	√	√	√	√	SP0040
2015	Astra-J		Radio	√	√	√	√	√	
2015	Astra-J		Chassis Control Module	√	√	√	√	√	SP0016,SP0271,SP0365

2015	Cascada		Engine Control Module	√	√	√	√	√	SP0048,SP0084,SP0091,SP0131,SP0092,SP0019,SP0016,SP0093,SP0210,SP0315,SP0320,SP0306,SP0017,SP0018,SP0385,SP0095,SP0541,SP058B,SP0587,SP0599,SP0096,SP0380,SP0098,SP0099,SP0100,SP0101,SP0085,SP0318,SP0102,SP0103,SP0104,SP0105,SP0106,SP0049,SP0129,SP0121,SP0132,SP0309,SP0135,SP0247,SP0248,SP0136,SP0357,SP0359,SP0361,SP0363,SP0400
2015	Cascada		Transmission Control Module	√	√	√	√	√	SP0223,SP0122,SP0422
2015	Cascada		Electronic Brake Control Module	√	√	√	√	√	SP0083,SP0394,SP0086
2015	Cascada		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	SP0347,SP0086
2015	Cascada		Body Control Module	√	√	√	√	√	SP0047,SP0048,SP0045,SP0378,SP0372,SP0376,SP0046,SP0334,SP0332,SP0455
2015	Cascada		Instrument Cluster	√	√	√	√	√	SP0040
2015	Cascada		HVAC Control Module	√	√	√	√	√	SP0211,SP0040,SP0307
2015	Cascada		Headlamp Control Module	√	√	√	√	√	SP0366
2015	Cascada		Front Seat Heating Control Module	√	√	√	√	√	
2015	Cascada		Suspension Control Module	√	√	√	√	√	
2015	Cascada		Parking Brake Control Module	√	√	√	√	√	SP0109
2015	Cascada		Power Steering Control Module	√	√	√	√		SP0088,SP0089,SP0090
2015	Cascada		Multi-Axis Acceleration Sensor Module	√	√	√			SP0350,SP0086
2015	Cascada		Steering Wheel Angle Sensor Module	√	√	√			SP0082,SP0083
2015	Cascada		Frontview Camera Module	√	√	√	√	√	SP0108,SP0368,SP0040
2015	Cascada		Multimedia Player Interface Module	√	√	√	√		
2015	Cascada		Folding Top Control Module	√	√	√	√	√	SP0040,SP0207,SP0208
2015	Cascada		Digital Radio Receiver Control Module	√	√	√	√	√	SP0040
2015	Cascada		Mobile Telephone Control Module	√	√	√	√	√	SP0040
2015	Cascada		Radio	√	√	√	√	√	
2015	Cascada		Parking Assist Control Module	√	√	√	√	√	SP0040
2015	Cascada		Chassis Control Module	√	√	√	√	√	SP0016,SP0271,SP0365
2015	Combo-D		Engine Control Module	√	√	√	√	√	SP0101,SP0131,SP0385,SP0085,SP0102,SP0464,SP05CB,SP0084,SP0221,SP0325,SP0426,SP0285,SP0274,SP0019,SP0104,SP0121,SP05CC,SP0585,SP0234,SP0251,SP0531,SP0049,SP0106,SP0316,SP0122,SP0320,SP0092,SP0091,SP0019,SP0016,SP0093,SP0210,SP0315,SP0320,SP0306,SP0017,SP0018,SP0385,SP0095,SP0541,SP058B,SP0587,SP0599,SP0096,SP0380,SP0098,SP0099,SP0100,SP0101,SP0085,SP0318,SP0102,SP0103,SP0104,SP0105,SP0106,SP0049,SP0129,SP0121,SP0132,SP0309,SP0135,SP0247,SP0248,SP0136,SP0357,SP0359,SP0361,SP0363,SP0400
2015	Combo-D		Transmission Control Module	√	√	√	√	√	SP0314,SP0427
2015	Combo-D		Electronic Brake Control Module	√	√	√	√	√	SP0459,SP0394,SP0083

2015	Combo-D		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	
2015	Combo-D		Body Control Module	√	√	√	√	√	SP0242,SP0418,SP0389
2015	Combo-D		Instrument Cluster	√	√	√	√	√	SP0218
2015	Combo-D		HVAC Control Module	√	√	√	√	√	SP0211
2015	Combo-D		Auxiliary Heater Control Module	√	√	√	√	√	SP0278
2015	Combo-D		Parking Assist Control Module	√	√	√	√		SP0344
2015	Combo-D		Multimedia Player Interface Module	√	√	√	√	√	
2015	Combo-D		Tire Pressure Indicator Module	√	√	√	√		
2015	Corsa-E		Engine Control Module	√	√	√	√	√	SP0048,SP0084,SP0091,SP0131,SP0092,S P0019,SP0016,SP0093,SP0210,SP0315,SP 0320,SP0306,SP0385,SP0017,SP0018,SP0 541,SP058B,SP0587,SP0599,SP0380,SP00 85,SP0129,SP0121,SP0104,SP0132,SP025 2,SP0251,SP0388,SP0106,SP0049
2015	Corsa-E		Transmission Control Module	√	√	√	√	√	SP0422,SP0314,SP0427,SP0330
2015	Corsa-E		Electronic Brake Control Module	√	√	√	√	√	SP0082,SP0460,SP0269
2015	Corsa-E		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	SP0347,SP0086
2015	Corsa-E		Body Control Module	√	√	√	√	√	SP0047,SP0048,SP0045,SP0372,SP0046,S P0334,SP0332,SP0455
2015	Corsa-E		Instrument Cluster	√	√	√	√	√	SP0040
2015	Corsa-E		HVAC Control Module	√	√	√	√	√	SP0211,SP0040,SP0307
2015	Corsa-E		Power Steering Control Module	√	√	√	√		SP0090
2015	Corsa-E		Trailer Interface Control Module	√	√	√	√	√	SP0040
2015	Corsa-E		Frontview Camera Module	√	√	√	√	√	SP0108,SP0368
2015	Corsa-E		Chassis Control Module	√	√	√	√	√	SP0016,SP0271,SP0365
2015	Corsa-E		Fuel Injector Control Module	√	√	√	√	√	SP0306
2015	Corsa-E		Parking Assist Control Module	√	√	√	√	√	SP0040
2015	Corsa-E		Radio	√	√	√	√	√	
2015	Insignia		Engine Control Module	√	√	√	√	√	SP0048,SP0084,SP0091,SP0131,SP0092,S P0019,SP0016,SP0093,SP0210,SP0315,SP 0320,SP0306,SP0018,SP0017,SP0385,SP0 095,SP0096,SP0380,SP0098,SP0099,SP01 00,SP0101,SP0085,SP0318,SP0102,SP010 3,SP0104,SP0105,SP0106,SP0049,SP0541, SP058B,SP0587,SP0599,SP0129,SP0121,S P0132,SP0309,SP0135,SP0247,SP0248,SP 0136,SP0357,SP0359,SP0361,SP0363,SP0 400
2015	Insignia		Transmission Control Module	√	√	√	√	√	SP0223,SP0122,SP0051,SP0422

2015	Insignia		Electronic Brake Control Module	√	√	√	√	√	SP0394,SP0083,SP0086,SP0457
2015	Insignia		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	SP0347,SP0086
2015	Insignia		Body Control Module	√	√	√	√	√	SP0047,SP0048,SP0045,SP0378,SP0372,SP0376,SP0046,SP0334,SP0332,SP0455
2015	Insignia		Instrument Cluster	√	√	√	√	√	SP0040
2015	Insignia		HVAC Control Module	√	√	√	√	√	SP0211,SP0040,SP0307
2015	Insignia		HVAC Controls	√	√	√	√	√	
2015	Insignia		Human Machine Interface Control Module	√	√	√	√	√	SP0326
2015	Insignia		Radio Controls	√	√	√	√	√	SP0326
2015	Insignia		Headlamp Control Module	√	√	√	√	√	SP0366
2015	Insignia		Rear Differential Clutch Control Module	√	√	√	√	√	
2015	Insignia		Fuel Injector Control Module	√			√	√	
2015	Insignia		Suspension Control Module	√	√	√	√	√	
2015	Insignia		Front Seat Heating/Venting/Cooling/Memory Control	√	√	√	√	√	
2015	Insignia		Parking Assist Control Module	√	√	√	√	√	SP0040
2015	Insignia		Parking Brake Control Module	√	√	√	√	√	SP0109
2015	Insignia		Power Steering Control Module	√	√	√	√	√	SP0088,SP0089,SP0090
2015	Insignia		Trailer Interface Control Module	√	√	√	√	√	SP0040
2015	Insignia		Keyless Entry Control Module	√	√	√	√	√	
2015	Insignia		Steering Column Lock Control Module	√	√	√	√		
2015	Insignia		Chassis Control Module	√	√	√	√	√	SP0016,SP0271,SP0365
2015	Insignia		Distance Sensing Cruise Control Module	√	√	√	√		SP0231
2015	Insignia		Steering Wheel Angle Sensor Module	√	√	√			SP0082,SP0083
2015	Insignia		Frontview Camera Module	√	√	√	√	√	SP0108,SP0368,SP0040
2015	Insignia		Left Side Object Detection Control Module	√	√	√		√	
2015	Insignia		Radio	√	√	√	√	√	SP0396,SP0213
2015	Insignia		Amplifier	√	√	√	√		
2015	Insignia		Infotainment Control Touchpad	√	√	√	√	√	
2015	Insignia		Liftgate Control Module	√	√	√	√		SP0323,SP0343
2015	Meriva-B		Engine Control Module	√	√	√	√	√	SP0096,SP0084,SP0380,SP0098,SP0099,SP0100,SP0101,SP0385,SP0085,SP0318,SP0102,SP0131,SP0103,SP0104,SP0019,SP0105,SP0106,SP0306,SP0049,SP0048,SP0091,SP0092,SP0016,SP0210,SP0315,SP0320,SP0093,SP0390,SP0130,SP0129,SP0121,SP0132,SP0135,SP0136,SP0137,SP0247,SP0248,SP0252,SP0251,SP0388,SP0319
2015	Meriva-B		Transmission Control Module	√	√	√	√	√	SP0223,SP0122

2015	Meriva-B		Electronic Brake Control Module	√	√	√	√	√	SP0082,SP0460,SP0269
2015	Meriva-B		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	SP0347,SP0086
2015	Meriva-B		Body Control Module	√	√	√	√	√	SP0047,SP0045,SP0372,SP0378,SP0376,SP0040,SP0046,SP0217,SP0334,SP0332
2015	Meriva-B		Instrument Cluster	√	√	√	√	√	SP0040
2015	Meriva-B		HVAC Control Module	√	√	√	√	√	SP0211,SP0040
2015	Meriva-B		Steering Wheel Angle Sensor Module	√	√	√			SP0082,SP0083
2015	Meriva-B		Multimedia Player Interface Module	√	√	√	√		
2015	Meriva-B		Power Steering Control Module	√	√	√	√	√	
2015	Meriva-B		Trailer Interface Control Module	√	√	√	√	√	SP0040
2015	Meriva-B		Digital Radio Receiver Control Module	√	√	√	√	√	SP0040
2015	Meriva-B		Radio	√	√	√	√	√	
2015	Meriva-B		Mobile Telephone Control Module	√	√	√	√	√	SP0040
2015	Meriva-B		Front Seat Heating Control Module	√	√	√	√	√	
2015	Meriva-B		Parking Brake Control Module	√	√	√	√	√	SP0109
2015	Meriva-B		Fuel Injector Control Module	√			√	√	
2015	Meriva-B		Headlamp Control Module	√	√	√	√	√	SP0366
2015	Meriva-B		Parking Assist Control Module	√	√	√	√	√	SP0040
2015	Mokka		Engine Control Module	√	√	√	√	√	SP0048,SP0084,SP0091,SP0131,SP0092,SP0019,SP0016,SP0093,SP0210,SP0315,SP0320,SP0306,SP0380,SP0390,SP0130,SP0085,SP0129,SP0121,SP0104,SP0132,SP0133,SP0106,SP0049,SP0135,SP0136,SP0137,SP0247,SP0248,SP0252,SP0251,SP0388
2015	Mokka		Transmission Control Module	√	√	√	√	√	SP0422
2015	Mokka		Electronic Brake Control Module	√	√	√	√	√	SP0083
2015	Mokka		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	SP0347,SP0086
2015	Mokka		Body Control Module	√	√	√	√	√	SP0047,SP0048,SP0045,SP0378,SP0372,SP0376,SP0046,SP0334,SP0332,SP0455
2015	Mokka		Instrument Cluster	√	√	√	√	√	SP0040
2015	Mokka		HVAC Control Module	√	√	√	√	√	SP0211,SP0040,SP0307
2015	Mokka		Headlamp Control Module	√	√	√	√	√	SP0366
2015	Mokka		Rear Differential Clutch Control Module	√	√	√	√		SP0206,SP05CA
2015	Mokka		Fuel Injector Control Module	√			√	√	
2015	Mokka		Front Seat Heating Control Module	√	√	√	√	√	
2015	Mokka		Steering Wheel Angle Sensor Module	√	√	√			SP0082,SP0083
2015	Mokka		Frontview Camera Module	√	√	√	√	√	SP0108,SP0368,SP0040
2015	Mokka		Power Steering Control Module	√	√	√	√		SP0377

2015	Mokka		Parking Assist Control Module	√	√	√	√	√	SP0040
2015	Mokka		Trailer Interface Control Module	√	√	√	√	√	SP0040
2015	Mokka		Digital Radio Receiver Control Module	√	√	√	√	√	SP0040
2015	Mokka		Radio	√	√	√	√	√	
2015	Movano-B		Engine Control Module	√	√	√	√	√	SP0325,SP0048,SP0380,SP0098,SP0345,SP0276,SP0099,SP0385,SP0285,SP0085,SP0318,SP0102,SP0352,SP0103,SP05C4,SP0104,SP0354,SP0349,SP0464,SP0284,SP0049,SP0106,SP0084,SP0356,SP0358,SP0366,SP0369
2015	Movano-B		Transmission Control Module	√	√	√	√	√	SP0314,SP0222,SP0427
2015	Movano-B		Electronic Brake Control Module	√	√	√	√	√	SP0083,SP0289,SP0461,SP0086,SP0082,SP0447,SP0290,SP0460,SP0407,SP0286
2015	Movano-B		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	
2015	Movano-B		Body Control Module	√	√	√	√	√	
2015	Movano-B		Instrument Cluster	√	√	√	√	√	
2015	Movano-B		HVAC Control Module	√	√	√	√	√	SP0211
2015	Movano-B		Serial Data Gateway Module	√	√	√	√	√	
2015	Movano-B		Radio	√	√	√	√	√	
2015	Movano-B		Auxiliary Body Control Module	√	√	√	√	√	SP0354
2015	Movano-B		Power Steering Control Module	√	√	√	√		
2015	Movano-B		Parking Assist Control Module	√	√	√	√		
2015	Movano-B		Navigation Control Module	√	√	√	√	√	
2015	Movano-B		Tire Pressure Indicator Module	√	√	√	√		SP0402,SP0467,SP0436,SP0434,SP0465
2015	Movano-B		Multifunction Accessory Control Module	√	√	√	√		
2015	Vivaro-B		Engine Control Module	√	√	√	√	√	SP0325,SP0048,SP0380,SP0098,SP0271,SP0276,SP0273,SP0274,SP0385,SP0285,SP0085,SP0318,SP0319,SP0102,SP0352,SP0103,SP0104,SP0354,SP0432,SP0349,SP0464,SP0284,SP0049,SP0106
2015	Vivaro-B		Electronic Brake Control Module	√	√	√	√	√	SP0083,SP0289,SP0461,SP0082,SP0290,SP0460,SP0447,SP0286,SP0407
2015	Vivaro-B		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√		
2015	Vivaro-B		Body Control Module	√	√	√	√	√	SP0402,SP0467,SP0436,SP0434,SP0465
2015	Vivaro-B		Instrument Cluster	√	√	√	√	√	
2015	Vivaro-B		HVAC Control Module	√	√	√	√	√	
2015	Vivaro-B		Serial Data Gateway Module	√	√	√	√	√	
2015	Vivaro-B		Parking Assist Control Module	√	√	√	√	√	SP0423,SP0277
2015	Vivaro-B		Power Steering Control Module	√	√	√	√		

2015	Vivaro-B		Info Display Module	√	√	√	√	√	
2015	Vivaro-B		Radio	√	√	√	√	√	SP0292
2015	Vivaro-B		Keyless Entry Control Module	√	√	√	√	√	
2015	Vivaro-B		Auxiliary Body Control Module	√	√	√	√	√	SP0239,SP0354
2015	Vivaro-B		Telematics Communication Interface Control Module	√	√	√	√		SP0214
2015	Vivaro-B		Multifunction Accessory Control Module	√	√	√	√		
2015	Vivaro-B		Parking Heater Control Module	√	√	√	√	√	SP0451,SP0452
2015	Zafira-C		Engine Control Module	√	√	√	√	√	SP0048,SP0084,SP0091,SP0131,SP0092,SP0019,SP0016,SP0093,SP0210,SP0315,SP0320,SP0306,SP0096,SP0128,SP0085,SP0102,SP0380,SP0103,SP0101,SP0129,SP0017,SP0018,SP0385,SP0095,SP0541,SP058B,SP0587,SP0599,SP0390,SP0130,SP0121,SP0104,SP0132,SP0135,SP0136,SP0137,SP0247,SP0248,SP0252,SP0251,SP0388,SP0106,SP0049,SP0098,SP0099,SP0100,SP0318,SP0105,SP0309,SP0357,SP0359,SP0361,SP0363,SP0400
2015	Zafira-C		Transmission Control Module	√	√	√	√	√	SP0223,SP0122,SP0422
2015	Zafira-C		Electronic Brake Control Module	√	√	√	√	√	SP0083,SP0394,SP0086
2015	Zafira-C		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	SP0347,SP0086
2015	Zafira-C		Body Control Module	√	√	√	√	√	SP0047,SP0048,SP0045,SP0378,SP0372,SP0376,SP0046,SP0334,SP0332,SP0455
2015	Zafira-C		Instrument Cluster	√	√	√	√	√	SP0040
2015	Zafira-C		HVAC Control Module	√	√	√	√	√	SP0211,SP0040,SP0307
2015	Zafira-C		Headlamp Control Module	√	√	√	√	√	SP0366
2015	Zafira-C		Fuel Injector Control Module	√			√	√	
2015	Zafira-C		Front Seat Heating Control Module	√	√	√	√	√	
2015	Zafira-C		Parking Brake Control Module	√	√	√	√	√	SP0109
2015	Zafira-C		Power Steering Control Module	√	√	√	√		SP0088,SP0089,SP0090
2015	Zafira-C		Suspension Control Module	√	√	√	√	√	
2015	Zafira-C		Parking Assist Control Module	√	√	√	√	√	SP0040
2015	Zafira-C		Distance Sensing Cruise Control Module	√	√	√	√		SP0231
2015	Zafira-C		Steering Wheel Angle Sensor Module	√	√	√			SP0082,SP0083
2015	Zafira-C		Frontview Camera Module	√	√	√	√	√	SP0108,SP0368,SP0040
2015	Zafira-C		Multimedia Player Interface Module	√	√	√	√		
2015	Zafira-C		Trailer Interface Control Module	√	√	√	√	√	SP0040
2015	Zafira-C		Digital Radio Receiver Control Module	√	√	√	√	√	SP0040
2015	Zafira-C		Mobile Telephone Control Module	√	√	√	√	√	SP0040

2015	Zafira-C		Radio	√	√	√	√	√	
2015	Zafira-C		Chassis Control Module	√	√	√	√	√	SP0016,SP0271,SP0365
2014	Adam		HVAC Control Module	√	√	√	√	√	SP0211,SP0040
2014	Adam		Engine Control Module	√	√	√	√	√	SP0048,SP0084,SP0018,SP0019,SP0016
2014	Adam		Trailer Interface Control Module	√	√	√	√	√	SP0040
2014	Adam		Instrument Cluster	√	√	√	√	√	SP0040
2014	Adam		Fuel Injector Control Module	√			√	√	
2014	Adam		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	
2014	Adam		Body Control Module	√	√	√	√	√	SP0047,SP0048,SP0045,SP0372,SP0046,SP0334,SP0332
2014	Adam		Electronic Brake Control Module	√	√	√	√	√	SP0082,SP0460,SP0269
2014	Adam		Power Steering Control Module	√	√	√	√		SP0090
2014	Adam		Radio	√	√	√	√	√	
2014	Adam		Parking Assist Control Module	√	√	√	√	√	SP0040
2014	Ampera		Chassis Control Module	√	√	√	√	√	SP0016,SP0271,SP0365
2014	Ampera		Auxiliary Transmission Fluid Pump	√	√	√	√		
2014	Ampera		Drive Motor Control Module 1	√	√	√	√		
2014	Ampera		Drive Motor Control Module 2	√	√	√	√		
2014	Ampera		Hybrid Powertrain Control Module	√	√	√	√	√	
2014	Ampera		Electric A/C Compressor Control Module	√					
2014	Ampera		Battery Charger Control Module	√			√		
2014	Ampera		Battery Energy Control Module	√			√		
2014	Ampera		Coolant Heater Control Module	√	√	√			
2014	Ampera		Hybrid Powertrain Control Module 2	√	√	√	√	√	SP0556,SP0303,SP0240,SP0559,SP0301,SP0302,SP0305
2014	Ampera		Telematics Communication Interface Control Module	√	√	√	√		
2014	Ampera		Steering Column Lock Control Module	√	√	√	√		
2014	Ampera		Body Control Module	√	√	√	√	√	SP0370,SP0413,SP0335,SP0336,SP0337,SP0338,SP0339,SP0340,SP0341,SP0342,SP0047,SP0048,SP0045,SP0372,SP0378,SP0376,SP0046,SP0334,SP0403
2014	Ampera		Steering Wheel Angle Sensor Module	√	√	√			SP0082,SP0083
2014	Ampera		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	SP0311
2014	Ampera		Keyless Entry Control Module	√	√	√	√	√	
2014	Ampera		Power Steering Control Module	√	√	√	√		SP0090
2014	Ampera		Frontview Camera Module	√	√	√	√	√	SP0108
2014	Ampera		Digital Radio Receiver Control Module	√	√	√	√	√	SP0040
2014	Ampera		Instrument Cluster	√	√	√	√	√	SP0040,SP0040

2014	Ampera		HVAC Control Module	√	√	√	√	√	SP0211,SP0307
2014	Ampera		Radio	√	√	√	√	√	
2014	Ampera		Front Seat Heating Control Module	√	√	√	√	√	
2014	Ampera		Parking Assist Control Module	√	√	√	√	√	SP0040
2014	Ampera		Electronic Brake Control Module	√	√	√	√	√	SP0565
2014	Ampera		Parking Brake Control Module	√	√	√	√	√	SP0109
2014	Ampera		Engine Control Module	√	√	√	√	√	SP0017,SP0018,SP0016,SP0019,SP0586
2014	Ampera		Transmission Control Module	√	√	√	√	√	
2014	Antara		Rear Differential Clutch Control Module	√	√	√	√	√	
2014	Antara		Transmission Control Module	√	√	√	√	√	SP0422
2014	Antara		Headlamp Control Module	√	√	√	√	√	SP0366
2014	Antara		HVAC Control Module	√	√	√		√	
2014	Antara		Engine Control Module	√	√	√	√	√	SP0048,SP0084,SP0017,SP0018,SP0016,S P0571,SP0019,SP0091
2014	Antara		Radio	√	√	√	√	√	SP0428,SP0040,SP0420,SP0409
2014	Antara		Mobile Telephone Control Module	√	√	√		√	SP0040,SP0243,SP0423,SP0420
2014	Antara		Body Control Module	√	√	√	√	√	SP0048,SP0442
2014	Antara		Auxiliary Body Control Module	√	√	√	√	√	SP0236
2014	Antara		Remote Control Door Lock Receiver	√	√	√	√	√	SP0374,SP0413,SP0335,SP0336,SP0337,S P0338,SP0332,SP0334,SP0403
2014	Antara		Theft Deterrent Module	√	√	√	√		
2014	Antara		Instrument Cluster	√	√	√	√	√	
2014	Antara		Parking Brake Control Module	√	√	√	√	√	SP0109
2014	Antara		Parking Assist Control Module	√	√	√	√	√	
2014	Antara		Electronic Brake Control Module	√	√	√	√	√	SP0083
2014	Antara		Variable Power Steering Control Module	√	√	√		√	
2014	Antara		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	SP0347,SP0442
2014	Antara		Info Display Module	√	√	√	√	√	SP0423,SP0398
2014	Antara		Chassis Control Module	√	√	√	√	√	SP0016,SP0271,SP0365
2014	Astra-J		HVAC Control Module	√	√	√	√	√	SP0211,SP0040
2014	Astra-J		Chassis Control Module	√	√	√	√	√	SP0016,SP0271,SP0365
2014	Astra-J		Transmission Control Module	√	√	√	√	√	SP0223,SP0122
2014	Astra-J		Suspension Control Module	√	√	√	√	√	
2014	Astra-J		Engine Control Module	√	√	√	√	√	SP0048,SP0084,SP0018,SP0016,SP0306,S P0210,SP0093,SP0320,SP0092,SP0091
2014	Astra-J		Body Control Module	√	√	√	√	√	SP0047,SP0048,SP0045,SP0378,SP0372,S P0376,SP0046,SP0334
2014	Astra-J		Instrument Cluster	√	√	√	√	√	SP0040

2014	Astra-J		Trailer Interface Control Module	√	√	√	√	√	SP0040
2014	Astra-J		Headlamp Control Module	√	√	√	√	√	SP0366
2014	Astra-J		Fuel Injector Control Module	√			√	√	
2014	Astra-J		Electronic Brake Control Module	√	√	√	√	√	SP0394,SP0083,SP0086
2014	Astra-J		Power Steering Control Module	√	√	√	√		SP0090
2014	Astra-J		Parking Brake Control Module	√	√	√	√	√	SP0109
2014	Astra-J		Steering Wheel Angle Sensor Module	√	√	√			SP0082,SP0083
2014	Astra-J		Multi-Axis Acceleration Sensor Module	√	√	√			SP0350,SP0086
2014	Astra-J		Multimedia Player Interface Module	√	√	√	√		
2014	Astra-J		Frontview Camera Module	√	√	√	√	√	SP0040
2014	Astra-J		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	SP0347
2014	Astra-J		Front Seat Heating Control Module	√	√	√	√	√	
2014	Astra-J		Digital Radio Receiver Control Module	√	√	√	√	√	SP0040
2014	Astra-J		Mobile Telephone Control Module	√	√	√	√	√	
2014	Astra-J		Radio	√	√	√		√	
2014	Astra-J		Parking Assist Control Module	√	√	√	√	√	SP0040
2014	Astra-J		Distance Sensing Cruise Control Module	√	√	√	√		SP0231
2014	Cascada		HVAC Control Module	√	√	√	√	√	SP0211,SP0040
2014	Cascada		Transmission Control Module	√	√	√	√	√	SP0223,SP0122
2014	Cascada		Suspension Control Module	√	√	√	√	√	
2014	Cascada		Engine Control Module	√	√	√	√	√	SP0048,SP0084,SP0018,SP0016,SP0306,SP0210,SP0093,SP0320,SP0092,SP0091
2014	Cascada		Body Control Module	√	√	√	√	√	SP0047,SP0048,SP0045,SP0378,SP0372,SP0376,SP0046,SP0334
2014	Cascada		Folding Top Control Module	√	√	√	√	√	SP0040,SP0574,SP0575
2014	Cascada		Headlamp Control Module	√	√	√	√	√	SP0366
2014	Cascada		Electronic Brake Control Module	√	√	√	√	√	SP0394,SP0083,SP0086
2014	Cascada		Power Steering Control Module	√	√	√	√		SP0090
2014	Cascada		Parking Brake Control Module	√	√	√	√	√	SP0109
2014	Cascada		Multi-Axis Acceleration Sensor Module	√	√	√			SP0350,SP0086
2014	Cascada		Steering Wheel Angle Sensor Module	√	√	√			SP0082,SP0083
2014	Cascada		Multimedia Player Interface Module	√	√	√	√		
2014	Cascada		Frontview Camera Module	√	√	√	√	√	SP0108
2014	Cascada		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	
2014	Cascada		Front Seat Heating Control Module	√	√	√	√	√	
2014	Cascada		Digital Radio Receiver Control Module	√	√	√	√	√	SP0040
2014	Cascada		Mobile Telephone Control Module	√	√	√	√	√	
2014	Cascada		Radio	√	√	√	√	√	

2014	Cascada		Parking Assist Control Module	√	√	√	√	√	SP0040
2014	Cascada		Instrument Cluster	√	√	√	√	√	SP0040
2014	Cascada		Chassis Control Module	√	√	√	√	√	SP0016,SP0271,SP0365
2014	Combo-D		HVAC Control Module	√	√	√	√	√	SP0211
2014	Combo-D		Engine Control Module	√	√	√	√	√	SP0049,SP0121,SP0104,SP0234,SP0019,S P0585,SP0101,SP0285,SP0085,SP0325,SP 0084,SP0385,SP0426,SP0102,SP0464
2014	Combo-D		Instrument Cluster	√	√	√	√	√	SP0218
2014	Combo-D		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	
2014	Combo-D		Auxiliary Heater Control Module	√	√	√	√	√	SP0278
2014	Combo-D		Transmission Control Module	√	√	√	√	√	SP0314,SP0427
2014	Combo-D		Body Control Module	√	√	√	√	√	SP0242,SP0418,SP0389
2014	Combo-D		Multimedia Player Interface Module	√	√	√	√	√	
2014	Combo-D		Electronic Brake Control Module	√	√	√	√	√	SP0459,SP0394,SP0083
2014	Combo-D		Parking Assist Control Module	√	√	√	√		SP0344
2014	Insignia		HVAC Control Module	√	√	√	√	√	SP0211,SP0040
2014	Insignia		Amplifier	√	√	√	√		
2014	Insignia		Human Machine Interface Control Module	√	√	√	√	√	SP0326
2014	Insignia		Radio	√	√	√	√	√	SP0396,SP0213
2014	Insignia		Transmission Control Module	√	√	√	√	√	SP0223,SP0122
2014	Insignia		Suspension Control Module	√	√	√	√	√	
2014	Insignia		Engine Control Module	√	√	√	√	√	SP0048,SP0084,SP0018,SP0016,SP0306,S P0210,SP0093,SP0320,SP0092,SP0091
2014	Insignia		HVAC Controls	√	√	√	√	√	
2014	Insignia		Infotainment Control Touchpad	√	√	√	√	√	
2014	Insignia		Radio Controls	√	√	√	√	√	SP0326
2014	Insignia		Instrument Cluster	√	√	√	√	√	SP0040
2014	Insignia		Trailer Interface Control Module	√	√	√	√	√	SP0040
2014	Insignia		Liftgate Control Module	√	√	√	√	√	SP0323
2014	Insignia		Body Control Module	√	√	√	√	√	SP0047,SP0048,SP0045,SP0378,SP0372,S P0376,SP0046,SP0334,SP0332
2014	Insignia		Steering Column Lock Control Module	√	√	√	√		
2014	Insignia		Keyless Entry Control Module	√	√	√	√	√	
2014	Insignia		Front Seat Heating/Venting/Cooling/Memory Control	√	√	√	√	√	
2014	Insignia		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	
2014	Insignia		Rear Differential Clutch Control Module	√	√	√	√	√	
2014	Insignia		Steering Wheel Angle Sensor Module	√	√	√			SP0082,SP0083
2014	Insignia		Distance Sensing Cruise Control Module	√	√	√	√		SP0231

2014	Insignia		Frontview Camera Module	√	√	√	√	√	SP0108
2014	Insignia		Multi-Axis Acceleration Sensor Module	√	√	√			SP0350,SP0086
2014	Insignia		Fuel Injector Control Module	√			√	√	
2014	Insignia		Headlamp Control Module	√	√	√	√	√	SP0366
2014	Insignia		Electronic Brake Control Module	√	√	√	√	√	SP0394,SP0083,SP0086,SP0457
2014	Insignia		Power Steering Control Module	√	√	√	√	√	
2014	Insignia		Parking Brake Control Module	√	√	√	√	√	SP0109
2014	Insignia		Parking Assist Control Module	√	√	√	√	√	SP0040
2014	Insignia		Left Side Object Detection Control Module	√	√	√		√	
2014	Insignia		Chassis Control Module	√	√	√	√	√	SP0016,SP0271,SP0365
2014	Mokka		HVAC Control Module	√	√	√	√	√	SP0211,SP0040
2014	Mokka		Engine Control Module	√	√	√	√	√	SP0048,SP0084,SP0018,SP0016,SP0306
2014	Mokka		Body Control Module	√	√	√	√	√	SP0047,SP0048,SP0045,SP0378,SP0372,S P0376,SP0046,SP0334
2014	Mokka		Instrument Cluster	√	√	√	√	√	SP0040
2014	Mokka		Trailer Interface Control Module	√	√	√	√	√	SP0040
2014	Mokka		Headlamp Control Module	√	√	√	√	√	SP0366
2014	Mokka		Transmission Control Module	√	√	√	√	√	SP0422
2014	Mokka		Rear Differential Clutch Control Module	√	√	√	√	√	
2014	Mokka		Electronic Brake Control Module	√	√	√	√	√	SP0083
2014	Mokka		Power Steering Control Module	√	√	√	√		
2014	Mokka		Steering Wheel Angle Sensor Module	√	√	√			SP0082,SP0083
2014	Mokka		Frontview Camera Module	√	√	√	√	√	SP0108
2014	Mokka		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	SP0347,SP0086
2014	Mokka		Front Seat Heating Control Module	√	√	√	√	√	
2014	Mokka		Fuel Injector Control Module	√			√	√	
2014	Mokka		Digital Radio Receiver Control Module	√	√	√	√	√	SP0040
2014	Mokka		Radio	√	√	√	√	√	
2014	Mokka		Parking Assist Control Module	√	√	√	√	√	SP0040
2014	Meriva-B		Engine Control Module						SP0210
2014	Zafira-C		HVAC Control Module	√	√	√	√	√	SP0211,SP0040
2014	Zafira-C		Transmission Control Module	√	√	√	√	√	SP0223,SP0122
2014	Zafira-C		Suspension Control Module	√	√	√	√	√	
2014	Zafira-C		Engine Control Module	√	√	√	√	√	SP0048,SP0084,SP0018,SP0016,SP0306
2014	Zafira-C		Body Control Module	√	√	√	√	√	SP0047,SP0048,SP0045,SP0378,SP0372,S P0376,SP0046,SP0334
2014	Zafira-C		Instrument Cluster	√	√	√	√	√	SP0040
2014	Zafira-C		Trailer Interface Control Module	√	√	√	√	√	SP0040

2014	Zafira-C		Headlamp Control Module	√	√	√	√	√	SP0366
2014	Zafira-C		Fuel Injector Control Module	√			√	√	
2014	Zafira-C		Electronic Brake Control Module	√	√	√	√	√	SP0394,SP0083,SP0086
2014	Zafira-C		Power Steering Control Module	√	√	√	√		SP0090
2014	Zafira-C		Parking Brake Control Module	√	√	√	√	√	SP0109
2014	Zafira-C		Distance Sensing Cruise Control Module	√	√	√	√		SP0231
2014	Zafira-C		Multi-Axis Acceleration Sensor Module	√	√	√			SP0350,SP0086
2014	Zafira-C		Steering Wheel Angle Sensor Module	√	√	√			SP0082,SP0083
2014	Zafira-C		Multimedia Player Interface Module	√	√	√	√		
2014	Zafira-C		Frontview Camera Module	√	√	√	√	√	SP0108
2014	Zafira-C		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	SP0347
2014	Zafira-C		Front Seat Heating Control Module	√	√	√	√	√	
2014	Zafira-C		Digital Radio Receiver Control Module	√	√	√	√	√	SP0040
2014	Zafira-C		Radio	√	√	√		√	
2014	Zafira-C		Mobile Telephone Control Module	√	√	√	√	√	
2014	Zafira-C		Parking Assist Control Module	√	√	√	√	√	SP0040
2014	Zafira-C		Chassis Control Module	√	√	√	√	√	SP0016,SP0271,SP0365
2014	Corsa-D	Body	Interior Lighting	√	√	√	√		
2014	Corsa-D	Body	Wipers/Washer	√	√	√	√		
2014	Corsa-D	Body	Heating,Ventilation and Air Cond.	√	√	√	√		
2014	Corsa-D	Body	Anti Theft Warning System	√	√	√	√		
2014	Corsa-D	Body	Central Door Lock	√	√	√	√	√	
2014	Corsa-D	Body	Immobiliser	√	√	√	√		
2014	Corsa-D	Body	AFL (Adaptive Forward Lighting)	√	√	√	√		
2014	Corsa-D	Body	EHS (Electrical Heater System)	√	√	√	√		
2014	Corsa-D	Body	IPC ECU (Instrument Control Unit)	√	√	√	√		
2014	Corsa-D	Body	PAS (Park Pilot)	√	√	√	√		
2014	Corsa-D	Body	SDM (Airbag)	√	√	√	√		SP0000,SP0001,SP0002,SP0003
2014	Corsa-D	Body	TIM(Trailer Interface Module)	√	√	√	√		
2014	Corsa-D	Body	BCM (Body Control Module)	√	√	√	√		
2014	Corsa-D	Chassis	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)	√	√	√	√	√	
2014	Corsa-D	Chassis	Electronic Power Steering	√	√	√	√		
2014	Corsa-D	Chassis	Fuel injector control module	√			√		
2014	Corsa-D	Engine	Z10XEP	√	√	√	√	√	SP0007,SP0008,SP0009,SP0010,SP0011,SP0012,SP0013,SP0014,SP0015
2014	Corsa-D	Engine	A10XEP	√	√	√	√	√	SP0006,SP0016,SP0017,SP0018,SP0019

2014	Corsa-D	Engine	Z12XEP	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,S P0011,SP0012,SP0013,SP0014
2014	Corsa-D	Engine	A12XER	√	√	√	√	√	SP0006,SP0018
2014	Corsa-D	Engine	A12XEL	√	√	√	√	√	SP0006,SP0018
2014	Corsa-D	Engine	Z13DTH	√	√	√	√	√	SP0020,SP0010,SP0011,SP0014,SP0021
2014	Corsa-D	Engine	Z13DTE	√	√	√	√	√	SP0006
2014	Corsa-D	Engine	Z13DTJ	√	√	√	√	√	SP0019,SP0010,SP0011,SP0014,SP0020
2014	Corsa-D	Engine	A13DTC	√	√	√	√	√	SP0019
2014	Corsa-D	Engine	Z14XEP	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,S P0011,SP0012,SP0013,SP0014
2014	Corsa-D	Engine	A14XEL	√	√	√	√	√	SP0006,SP0015,SP0016,SP0017,SP0018
2014	Corsa-D	Engine	A14XER	√	√	√	√	√	SP0006,SP0015,SP0016,SP0017,SP0018
2014	Corsa-D	Engine	Z16LEL	√	√	√	√	√	
2014	Corsa-D	Engine	Z16LER	√	√	√	√	√	
2014	Corsa-D	Engine	A16LEL	√	√	√	√	√	
2014	Corsa-D	Engine	A16LER	√	√	√	√	√	
2014	Corsa-D	Engine	Z17DTR	√	√	√	√	√	SP0019,SP0022,SP0011,SP0014,SP0023,S P0024,SP0025,SP0012,SP0026,SP0027,SP 0028,SP0029,SP0020,SP0030
2014	Corsa-D	Engine	Engine(default)	√	√	√			
2014	Corsa-D	Transmission	MTA(Easytronic Magneti Marelli)	√	√	√	√	√	
2014	Corsa-D	Transmission	AF 13-4	√	√	√	√	√	SP0031,SP0032,SP0033,SP0034
2014	Corsa-D	Transmission	MTA(Easytronic)	√	√	√	√	√	SP0035,SP0036
2013	Adam		Engine Control Module	√	√	√	√	√	SP0048,SP0084,SP0018,SP0016,SP0306
2013	Adam		Electronic Brake Control Module	√	√	√	√	√	SP0082,SP0460,SP0269
2013	Adam		Power Steering Control Module	√	√	√	√		SP0090
2013	Adam		Body Control Module	√	√	√	√	√	SP0047,SP0048,SP0045,SP0372,SP0046,S P0334,SP0332
2013	Adam		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	
2013	Adam		Instrument Cluster	√	√	√	√	√	SP0040
2013	Adam		Trailer Interface Control Module	√	√	√	√	√	SP0040
2013	Adam		Radio	√	√	√	√	√	
2013	Ampera		Engine Control Module	√	√	√	√	√	SP0017,SP0018,SP0016,SP0019,SP0586
2013	Ampera		Fuel Pump Control Module	√	√	√	√	√	SP0016
2013	Ampera		Hybrid Powertrain Control Module	√	√	√	√	√	
2013	Ampera		Transmission Control Module	√	√	√	√	√	
2013	Ampera		Drive Motor Control Module 1	√	√	√	√		
2013	Ampera		Drive Motor Control Module 2	√	√	√	√		

2013	Ampera		Auxiliary Transmission Fluid Pump	√	√	√	√		
2013	Ampera		Electronic Brake Control Module	√	√	√	√	√	SP0565
2013	Ampera		Parking Brake Control Module	√	√	√	√	√	SP0109
2013	Ampera		Multi-Axis Acceleration Sensor Module	√	√	√			SP0350,SP0086
2013	Ampera		Power Steering Control Module	√	√	√	√		SP0090
2013	Ampera		Steering Wheel Angle Sensor Module	√	√	√			SP0082,SP0083
2013	Ampera		Body Control Module	√	√	√	√	√	SP0047,SP0048,SP0045,SP0372,SP0378,S P0376,SP0046,SP0334,SP0403,SP0332
2013	Ampera		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	SP0311
2013	Ampera		Instrument Cluster	√	√	√	√	√	SP0040,SP0040
2013	Ampera		Radio	√	√	√	√	√	
2013	Ampera		Digital Radio Receiver Control Module	√	√	√	√	√	SP0040
2013	Ampera		Mobile Telephone Control Module	√	√	√	√	√	
2013	Ampera		Telematics Communication Interface Control Module	√	√	√	√		
2013	Ampera		Electric A/C Compressor Control Module	√					
2013	Ampera		Coolant Heater Control Module	√	√	√			
2013	Ampera		Front Seat Heating Control Module	√	√	√	√	√	
2013	Ampera		Keyless Entry Control Module	√	√	√	√	√	
2013	Ampera		Parking Assist Control Module	√	√	√	√	√	SP0040
2013	Ampera		Steering Column Lock Control Module	√	√	√	√		
2013	Ampera		Battery Charger Control Module	√			√		
2013	Ampera		Hybrid Powertrain Control Module 2	√	√	√	√	√	SP0556,SP0303,SP0240,SP0559,SP0301,S P0302,SP0305
2013	Ampera		Battery Energy Control Module	√			√		
2013	Ampera		HVAC Control Module	√	√	√	√	√	SP0211,SP0307
2013	Ampera		Multimedia Player Interface Module	√	√	√	√		SP0040
2013	Ampera		Frontview Camera Module	√	√	√	√	√	SP0108
2013	Antara		Transmission Control Module	√	√	√	√	√	SP0422
2013	Antara		Instrument Cluster	√	√	√	√	√	
2013	Antara		Rear Differential Clutch Control Module	√	√	√	√	√	
2013	Antara		Fuel Pump Control Module	√	√	√	√	√	SP0016
2013	Antara		Parking Assist Control Module	√	√	√	√	√	
2013	Antara		Parking Brake Control Module	√	√	√	√	√	SP0109
2013	Antara		Electronic Brake Control Module	√	√	√	√	√	SP0083
2013	Antara		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	SP0347,SP0442
2013	Antara		Info Display Module	√	√	√	√	√	SP0423,SP0398
2013	Antara		Variable Power Steering Control Module	√	√	√		√	
2013	Antara		Engine Control Module	√	√	√	√	√	SP0313

2013	Antara		Body Control Module	√	√	√	√	√	SP0048,SP0442
2013	Antara		Radio	√	√	√	√	√	SP0428,SP0040,SP0420,SP0409
2013	Antara		HVAC Control Module	√	√	√		√	
2013	Antara		Auxiliary Body Control Module	√	√	√	√	√	SP0236
2013	Antara		Headlamp Control Module	√	√	√	√	√	SP0366
2013	Antara		Remote Control Door Lock Receiver	√	√	√	√	√	SP0374,SP0413,SP0335,SP0336,SP0337,S P0338,SP0332,SP0334,SP0403
2013	Antara		Theft Deterrent Module	√	√	√	√		
2013	Antara		Mobile Telephone Control Module	√	√	√		√	SP0040,SP0243,SP0423,SP0420
2013	Astra-J		Engine Control Module	√	√	√	√	√	SP0048,SP0084,SP0018,SP0019,SP0016
2013	Astra-J		Fuel Pump Control Module	√	√	√	√	√	SP0016
2013	Astra-J		Transmission Control Module	√	√	√	√	√	SP0223,SP0122
2013	Astra-J		Parking Brake Control Module	√	√	√	√	√	SP0109
2013	Astra-J		Multi-Axis Acceleration Sensor Module	√	√	√			SP0350,SP0086
2013	Astra-J		Electronic Brake Control Module	√	√	√	√	√	SP0394,SP0083,SP0086
2013	Astra-J		Power Steering Control Module	√	√	√	√		SP0090
2013	Astra-J		Steering Wheel Angle Sensor Module	√	√	√			SP0082,SP0083
2013	Astra-J		Suspension Control Module	√	√	√	√	√	
2013	Astra-J		Body Control Module	√	√	√	√	√	SP0047,SP0048,SP0045,SP0378,SP0372,S P0376,SP0046,SP0334
2013	Astra-J		Instrument Cluster	√	√	√	√	√	SP0040
2013	Astra-J		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	SP0347
2013	Astra-J		Headlamp Control Module	√	√	√	√	√	SP0366
2013	Astra-J		Trailer Interface Control Module	√	√	√	√	√	SP0040
2013	Astra-J		Radio	√	√	√		√	
2013	Astra-J		Digital Radio Receiver Control Module	√	√	√	√	√	SP0040
2013	Astra-J		Multimedia Player Interface Module	√	√	√	√		
2013	Astra-J		Mobile Telephone Control Module	√	√	√	√	√	
2013	Astra-J		Front Seat Heating Control Module	√	√	√	√	√	
2013	Astra-J		Parking Assist Control Module	√	√	√	√	√	SP0040
2013	Astra-J		HVAC Control Module	√	√	√	√	√	SP0211,SP0040
2013	Cascada		Power Steering Control Module	√	√	√	√		SP0090
2013	Cascada		Electronic Brake Control Module	√	√	√	√	√	SP0394,SP0083,SP0086
2013	Cascada		Body Control Module	√	√	√	√	√	SP0047,SP0048,SP0045,SP0378,SP0372,S P0376,SP0046,SP0334
2013	Cascada		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	
2013	Cascada		Front Seat Heating Control Module	√	√	√	√	√	
2013	Cascada		Parking Assist Control Module	√	√	√	√	√	SP0040

2013	Cascada		Transmission Control Module	√	√	√	√	√	SP0223,SP0122
2013	Cascada		Engine Control Module	√	√	√	√	√	
2013	Cascada		HVAC Control Module	√	√	√	√	√	SP0211,SP0040
2013	Cascada		Mobile Telephone Control Module	√	√	√	√	√	
2013	Cascada		Digital Radio Receiver Control Module	√	√	√	√	√	SP0040
2013	Cascada		Headlamp Control Module	√	√	√	√	√	SP0366
2013	Cascada		Instrument Cluster	√	√	√	√	√	SP0040
2013	Cascada		Multi-Axis Acceleration Sensor Module	√	√	√			SP0350,SP0086
2013	Cascada		Multimedia Player Interface Module	√	√	√	√		
2013	Cascada		Suspension Control Module	√	√	√	√	√	
2013	Cascada		Folding Top Control Module	√	√	√	√	√	SP0040,SP0574,SP0575
2013	Cascada		Steering Wheel Angle Sensor Module	√	√	√			SP0082,SP0083
2013	Cascada		Frontview Camera Module	√	√	√	√	√	SP0108
2013	Cascada		Radio	√	√	√	√	√	
2013	Cascada		Parking Brake Control Module	√	√	√	√	√	SP0109
2013	Cascada		Fuel Pump Control Module	√	√	√	√	√	SP0016
2013	Combo-D		Engine Control Module	√	√	√	√	√	SP0576,SP0230,SP0578,SP0234,SP0221,SP0565,SP0316,SP0325,SP0426,SP0464
2013	Combo-D		Transmission Control Module	√	√	√	√	√	SP0314,SP0427
2013	Combo-D		Electronic Brake Control Module	√	√	√	√	√	SP0459,SP0394,SP0083
2013	Combo-D		Body Control Module	√	√	√	√	√	SP0242,SP0418,SP0389
2013	Combo-D		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	
2013	Combo-D		Instrument Cluster	√	√	√	√	√	SP0218
2013	Combo-D		Multimedia Player Interface Module	√	√	√	√	√	
2013	Combo-D		HVAC Control Module	√	√	√	√	√	SP0211
2013	Combo-D		Auxiliary Heater Control Module	√	√	√	√	√	SP0278
2013	Combo-D		Parking Assist Control Module	√	√	√	√		SP0344
2013	Insignia		Engine Control Module	√	√	√	√	√	SP0048,SP0084,SP0018,SP0019,SP0016
2013	Insignia		Fuel Pump Control Module	√	√	√	√	√	SP0016
2013	Insignia		Transmission Control Module	√	√	√	√	√	SP0223,SP0122
2013	Insignia		Parking Brake Control Module	√	√	√	√	√	SP0109
2013	Insignia		Rear Differential Clutch Control Module	√	√	√	√	√	
2013	Insignia		Multi-Axis Acceleration Sensor Module	√	√	√			SP0350,SP0086
2013	Insignia		Electronic Brake Control Module	√	√	√	√	√	SP0394,SP0083,SP0086
2013	Insignia		Power Steering Control Module	√	√	√	√		SP0090
2013	Insignia		Steering Wheel Angle Sensor Module	√	√	√			SP0082,SP0083
2013	Insignia		Suspension Control Module	√	√	√	√	√	

2013	Insignia		Body Control Module	√	√	√	√	√	SP0047,SP0048,SP0045,SP0378,SP0372,SP0376,SP0046,SP0334
2013	Insignia		Instrument Cluster	√	√	√	√	√	SP0040
2013	Insignia		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	SP0347
2013	Insignia		Headlamp Control Module	√	√	√	√	√	SP0366
2013	Insignia		Trailer Interface Control Module	√	√	√	√	√	SP0040
2013	Insignia		Radio	√	√	√		√	
2013	Insignia		Digital Radio Receiver Control Module	√	√	√	√	√	SP0040
2013	Insignia		Multimedia Player Interface Module	√	√	√	√		
2013	Insignia		Mobile Telephone Control Module	√	√	√	√	√	
2013	Insignia		Liftgate Control Module	√	√	√	√	√	SP0323
2013	Insignia		Parking Assist Control Module	√	√	√	√	√	SP0040
2013	Insignia		Fuel Injector Control Module	√			√	√	
2013	Mokka		Engine Control Module	√	√	√	√	√	SP0048,SP0084,SP0018,SP0019,SP0016
2013	Mokka		Transmission Control Module	√	√	√	√	√	SP0422
2013	Mokka		Rear Differential Clutch Control Module	√	√	√	√	√	
2013	Mokka		Electronic Brake Control Module	√	√	√	√	√	SP0083
2013	Mokka		Multi-Axis Acceleration Sensor Module	√	√	√			SP0350,SP0086
2013	Mokka		Power Steering Control Module	√	√	√	√		
2013	Mokka		Steering Wheel Angle Sensor Module	√	√	√			SP0082,SP0083
2013	Mokka		Body Control Module	√	√	√	√	√	SP0047,SP0048,SP0045,SP0378,SP0372,SP0376,SP0046,SP0334
2013	Mokka		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	SP0347
2013	Mokka		Instrument Cluster	√	√	√	√	√	SP0040
2013	Mokka		Headlamp Control Module	√	√	√	√	√	SP0366
2013	Mokka		Trailer Interface Control Module	√	√	√	√	√	SP0040
2013	Mokka		Radio	√	√	√	√	√	
2013	Mokka		Digital Radio Receiver Control Module	√	√	√	√	√	SP0040
2013	Mokka		Mobile Telephone Control Module	√	√	√	√	√	
2013	Mokka		HVAC Control Module	√	√	√	√	√	SP0211,SP0040
2013	Mokka		Front Seat Heating Control Module	√	√	√	√	√	
2013	Mokka		Parking Assist Control Module	√	√	√	√	√	SP0040
2013	Mokka		Frontview Camera Module	√	√	√	√	√	SP0040
2013	Zafira-C		Engine Control Module	√	√	√	√	√	SP0048,SP0084,SP0018,SP0019,SP0016
2013	Zafira-C		Fuel Injector Control Module	√			√	√	
2013	Zafira-C		Fuel Pump Control Module	√	√	√	√	√	SP0016
2013	Zafira-C		Transmission Control Module	√	√	√	√	√	SP0223,SP0122
2013	Zafira-C		Electronic Brake Control Module	√	√	√	√	√	SP0394,SP0083,SP0086

2013	Zafira-C		Distance Sensing Cruise Control Module	√	√	√	√		SP0231
2013	Zafira-C		Parking Brake Control Module	√	√	√	√	√	SP0109
2013	Zafira-C		Multi-Axis Acceleration Sensor Module	√	√	√			SP0350,SP0086
2013	Zafira-C		Power Steering Control Module	√	√	√	√		SP0090
2013	Zafira-C		Steering Wheel Angle Sensor Module	√	√	√			SP0082,SP0083
2013	Zafira-C		Suspension Control Module	√	√	√	√	√	
2013	Zafira-C		Body Control Module	√	√	√	√	√	SP0047,SP0048,SP0045,SP0378,SP0372,S P0376,SP0046,SP0334
2013	Zafira-C		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	SP0347
2013	Zafira-C		Instrument Cluster	√	√	√	√	√	SP0040
2013	Zafira-C		Headlamp Control Module	√	√	√	√	√	SP0366
2013	Zafira-C		Trailer Interface Control Module	√	√	√	√	√	SP0040
2013	Zafira-C		Radio	√	√	√		√	
2013	Zafira-C		Digital Radio Receiver Control Module	√	√	√	√	√	SP0040
2013	Zafira-C		Multimedia Player Interface Module	√	√	√	√		
2013	Zafira-C		Mobile Telephone Control Module	√	√	√	√	√	
2013	Zafira-C		HVAC Control Module	√	√	√	√	√	SP0211,SP0040
2013	Zafira-C		Front Seat Heating Control Module	√	√	√	√	√	
2013	Zafira-C		Parking Assist Control Module	√	√	√	√	√	SP0040
2013	Zafira-C		Frontview Camera Module	√	√	√	√	√	SP0040
2013	Agila_B	Body	BCM (Body Control Module)		√	√	√	√	
2013	Agila_B	Body	Immobiliser		√	√	√		
2013	Agila_B	Body	SDM (Airbag)	√	√	√	√		SP0000,SP0001,SP0002
2013	Agila_B	Chassis	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)	√	√	√	√		SP0005
2013	Agila_B	Chassis	Electronic Power Steering	√	√	√			
2013	Agila_B	Engine	K10B	√	√	√	√	√	SP0015
2013	Agila_B	Engine	K12B	√	√	√	√	√	SP0015
2013	Agila_B	Engine	D13A / Z 13 DTJ	√	√	√	√	√	SP0041,SP0019,SP0011,SP0021,SP0020,S P0018,SP0028,SP0025,SP0042,SP0043
2013	Agila_B	Transmission	TCM (Transmission Control Module)	√	√	√	√		SP0033
2013	Astra-H	Body	AHL/AFL (Headlamp Levelling)	√	√	√	√		
2013	Astra-H	Body	Exterior Lighting/Turn Indicator System	√	√	√	√		
2013	Astra-H	Body	Interior Lighting	√	√	√	√		
2013	Astra-H	Body	Wipers/Washer	√	√	√	√		
2013	Astra-H	Body	Central Door Lock	√	√	√	√		
2013	Astra-H	Body	Instrument	√	√	√	√		
2013	Astra-H	Body	Immobiliser	√	√	√	√		

2013	Astra-H	Body	CIM (Steering Column Module)	√	√	√	√	√	SP0052,SP0003,SP0053,SP0001,SP0004,SP0054,SP0055,SP0005
2013	Astra-H	Body	Anti Theft Warning System	√	√	√	√		
2013	Astra-H	Body	Electrohydraulic HardTop	√	√	√	√		
2013	Astra-H	Body	ECC/SAC (Electronic Climate Control)	√	√	√	√		
2013	Astra-H	Body	IPC ECU (Instrument Control Unit)	√	√	√	√	√	SP0006,SP0056,SP0057,SP0058,SP0059,SP0060,SP0061,SP0001,SP0004
2013	Astra-H	Body	EHS (Electrical Heater System)	√	√	√	√		
2013	Astra-H	Body	PAS (Park Pilot)	√	√	√	√		
2013	Astra-H	Body	SDM (Airbag)	√	√	√	√		SP0000,SP0001,SP0002
2013	Astra-H	Body	SLM (Shift Lever Module)	√	√	√	√		
2013	Astra-H	Body	UEC (Underhood Electrical Centre)	√	√	√	√		
2013	Astra-H	Body	REC (Rear Electrical Centre)	√	√	√	√		
2013	Astra-H	Body	PEPS (Open&Start)	√	√	√	√		
2013	Astra-H	Body	CIM(Steering Column Module)	√	√	√	√	√	SP0051,SP0003,SP0052,SP0001,SP0004,SP0053,SP0054,SP0005
2013	Astra-H	Chassis	TPMS ECU (Tyre Pressure Monitoring)	√	√	√	√		SP0035
2013	Astra-H	Chassis	TPMS (Tyre Pressure Monitoring System)	√	√	√	√		SP0062
2013	Astra-H	Chassis	EHPS (Electrohydraulic Power Steering)	√	√	√	√		SP0003
2013	Astra-H	Chassis	ABS/TC/ESP ECU(Electronic Control Unit)	√	√	√	√	√	
2013	Astra-H	Chassis	CDC (Continuous Damping Control)	√	√	√	√		
2013	Astra-H	Chassis	ABS/TC/ESP (Vehicle Dynamic System)	√	√	√	√	√	
2013	Astra-H	Engine	Z12XEP	√	√	√	√	√	SP0009,SP0064,SP0011,SP0065,SP0012,SP0066,SP0006,SP0007,SP0008,SP0018
2013	Astra-H	Engine	Y13DTH	√	√	√	√	√	SP0009,SP0063,SP0011,SP0064,SP0012,SP0065,SP0006,SP0007,SP0008,SP0018
2013	Astra-H	Engine	Z13DTH	√	√	√	√	√	SP0006,SP0007,SP0008,SP0019,SP0010,SP0011,SP0067,SP0020,SP0029,SP0028,SP0025,SP0026,SP0018
2013	Astra-H	Engine	Z14XEL	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,SP0011,SP0066,SP0012,SP0013,SP0018
2013	Astra-H	Engine	Z14XEP	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,SP0011,SP0066,SP0012,SP0013,SP0018
2013	Astra-H	Engine	Z16LET	√	√	√	√	√	SP0009,SP0063,SP0011,SP0064,SP0012,SP0065,SP0006,SP0007,SP0008,SP0018
2013	Astra-H	Engine	Z16XE1	√	√	√	√	√	SP0019,SP0009,SP0063,SP0068,SP0064,SP0012,SP0065,SP0069,SP0006,SP0007,SP0008,SP0018

2013	Astra-H	Engine	Z16XEP	√	√	√	√		SP0006,SP0007,SP0008,SP0009,SP0019,S P0010,SP0011,SP0066,SP0012,SP0013,SP 0033,SP0018
2013	Astra-H	Engine	Z16XER	√	√	√	√		SP0019,SP0006,SP0007,SP0008,SP0009,S P0010,SP0011,SP0066,SP0033,SP0012,SP
2013	Astra-H	Engine	A16LET	√	√	√	√	√	SP0009,SP0063,SP0011,SP0064,SP0012,S P0065,SP0006,SP0007,SP0008,SP0018
2013	Astra-H	Engine	A16XER	√	√	√	√	√	SP0019,SP0009,SP0063,SP0067,SP0064,S P0033,SP0012,SP0006,SP0007,SP0008,SP
2013	Astra-H	Engine	Z17DTH	√	√	√	√	√	SP0006,SP0007,SP0008,SP0010,SP0011,S P0066,SP0020,SP0024,SP0012,SP0029,SP 0032,SP0018
2013	Astra-H	Engine	Z17DTJ	√	√	√	√	√	SP0006,SP0007,SP0008,SP0019,SP0010,S P0011,SP0066,SP0014,SP0022,SP0023,SP 0024,SP0012,SP0025,SP0026,SP0027,SP0 028,SP0029,SP0020,SP0018
2013	Astra-H	Engine	Z17DTL	√	√	√	√	√	SP0063,SP0011,SP0064,SP0020,SP0024,S P0012,SP0029,SP0032,SP0018
2013	Astra-H	Engine	Z17DTR	√	√	√	√	√	SP0006,SP0007,SP0008,SP0019,SP0010,S P0011,SP0066,SP0014,SP0022,SP0023,SP 0024,SP0012,SP0025,SP0026,SP0027,SP0 028,SP0029,SP0020,SP0018
2013	Astra-H	Engine	A17DTJ	√	√	√	√	√	SP0019,SP0063,SP0011,SP0064,SP0014,S P0022,SP0023,SP0024,SP0012,SP0028,SP 0025,SP0070,SP0026,SP0071,SP0006,SP0 007,SP0008,SP0027,SP0018
2013	Astra-H	Engine	A17DTR	√	√	√	√	√	SP0019,SP0063,SP0011,SP0064,SP0014,S P0022,SP0023,SP0024,SP0012,SP0028,SP 0025,SP0069,SP0026,SP0070,SP0006,SP0 007,SP0008,SP0027,SP0018
2013	Astra-H	Engine	Z18XE	√	√	√	√		SP0019,SP0006,SP0007,SP0008,SP0009,S P0010,SP0011,SP0066,SP0012,SP0018
2013	Astra-H	Engine	Z18XER	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0019,S P0010,SP0011,SP0066,SP0033,SP0012,SP
2013	Astra-H	Engine	A18XER	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0019,S P0033,SP0018

2013	Astra-H	Engine	Z19DT	√	√	√	√	√	SP0006,SP0007,SP0008,SP0010,SP0011,SP0066,SP0023,SP0024,SP0069,SP0012,SP0032,SP0020,SP0029,SP0026,SP0027,SP0025,SP0028,SP0018
2013	Astra-H	Engine	Z19DTH	√	√	√	√	√	SP0006,SP0007,SP0008,SP0010,SP0011,SP0066,SP0023,SP0024,SP0069,SP0012,SP0032,SP0020,SP0029,SP0026,SP0027,SP0025,SP0028,SP0018
2013	Astra-H	Engine	Z20LEH	√	√	√	√	√	SP0009,SP0063,SP0011,SP0064,SP0012,SP0065,SP0006,SP0007,SP0008,SP0018
2013	Astra-H	Engine	Z20LEL	√	√	√	√	√	SP0009,SP0063,SP0011,SP0064,SP0012,SP0065,SP0006,SP0007,SP0008,SP0018
2013	Astra-H	Engine	Z20LER	√	√	√	√	√	SP0009,SP0063,SP0011,SP0064,SP0012,SP0065,SP0006,SP0007,SP0008,SP0018
2013	Astra-H	Engine	Z22YH	√	√	√	√	√	SP0006,SP0007,SP0008,SP0072,SP0019,SP0010,SP0011,SP0066,SP0012,SP0018
2013	Astra-H	Engine	Engine(default)	√	√	√			
2013	Astra-H	Transmission	AF 40-6	√	√	√	√	√	SP0073,SP0074,SP0075,SP0076,SP0077,SP0078,SP0032,SP0003,SP0033,SP0079
2013	Astra-H	Transmission	AF17-4	√	√	√	√	√	SP0030,SP0031,SP0032,SP0003,SP0033
2013	Astra-H	Transmission	AF 22-4	√	√	√	√	√	SP0032,SP0080,SP0033,SP0030
2013	Astra-H	Transmission	MTA(Easytronic)	√	√	√	√	√	SP0079,SP0034,SP0035,SP0061
2013	Astra-H	Transmission	MTA(Easytronic Magneti Marelli)	√	√	√	√	√	SP0079,SP0004,SP0061
2013	Combo-D		Engine Control Module	√	√	√	√	√	SP0099,SP0085,SP0102,SP0131,SP0104,SP0019,SP0121,SP0106,SP0049,SP0122,SP0101,SP0084
2013	Combo-D		Transmission Control Module	√	√	√	√	√	
2013	Combo-D		Body Control Module	√	√	√	√	√	
2013	Combo-D		Electronic Brake Control Module	√	√	√	√	√	SP0083
2013	Combo-D		HVAC Control Module	√	√	√	√	√	
2013	Combo-D		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	
2013	Combo-D		Instrument Cluster	√	√	√	√	√	
2013	Combo-D		Multimedia Player Interface Module	√	√	√	√	√	
2013	Combo-D		Auxiliary Heater Control Module	√	√	√	√	√	
2013	Combo-D		Parking Assist Control Module	√	√	√	√		
2013	Corsa-D	Body	Exterior Lighting	√	√	√	√		
2013	Corsa-D	Body	Interior Lighting	√	√	√	√		
2013	Corsa-D	Body	Wipers/Washer	√	√	√	√		

2013	Corsa-D	Body	Heating,Ventilation and Air Cond.	√	√	√	√		
2013	Corsa-D	Body	Anti Theft Warning System	√	√	√	√		
2013	Corsa-D	Body	Central Door Lock	√	√	√	√	√	
2013	Corsa-D	Body	Immobiliser	√	√	√	√		
2013	Corsa-D	Body	AFL (Adaptive Forward Lighting)	√	√	√	√		
2013	Corsa-D	Body	EHS (Electrical Heater System)	√	√	√	√		
2013	Corsa-D	Body	IPC ECU (Instrument Control Unit)	√	√	√	√		
2013	Corsa-D	Body	PAS (Park Pilot)	√	√	√	√		
2013	Corsa-D	Body	SDM (Airbag)	√	√	√	√		SP0000,SP0001,SP0002
2013	Corsa-D	Body	TIM(Trailer Interface Module)	√	√	√	√		
2013	Corsa-D	Body	BCM (Body Control Module)	√	√	√	√		
2013	Corsa-D	Chassis	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)	√	√	√	√	√	
2013	Corsa-D	Chassis	Electronic Power Steering	√	√	√	√		
2013	Corsa-D	Chassis	Fuel injector control module	√			√		
2013	Corsa-D	Engine	Z10XEP	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,SP0011,SP0012,SP0013,SP0014
2013	Corsa-D	Engine	A10XEP	√	√	√	√	√	SP0006,SP0015,SP0016,SP0017,SP0018
2013	Corsa-D	Engine	Z12XEP	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,SP0011,SP0012,SP0013,SP0014
2013	Corsa-D	Engine	A12XER	√	√	√	√	√	SP0006,SP0018
2013	Corsa-D	Engine	A12XEL	√	√	√	√	√	SP0006,SP0018
2013	Corsa-D	Engine	Z13DTH	√	√	√	√	√	SP0019,SP0010,SP0011,SP0014,SP0020
2013	Corsa-D	Engine	Z13DTE	√	√	√	√	√	SP0006
2013	Corsa-D	Engine	Z13DTJ	√	√	√	√	√	SP0019,SP0010,SP0011,SP0014,SP0020
2013	Corsa-D	Engine	A13DTC	√	√	√	√	√	SP0019
2013	Corsa-D	Engine	Z14XEP	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,SP0011,SP0012,SP0013,SP0014
2013	Corsa-D	Engine	A14XEL	√	√	√	√	√	SP0006,SP0015,SP0016,SP0017,SP0018
2013	Corsa-D	Engine	A14XER	√	√	√	√	√	SP0006,SP0015,SP0016,SP0017,SP0018
2013	Corsa-D	Engine	Z16LEL	√	√	√	√	√	
2013	Corsa-D	Engine	Z16LER	√	√	√	√	√	
2013	Corsa-D	Engine	A16LEL	√	√	√	√	√	
2013	Corsa-D	Engine	A16LER	√	√	√	√	√	
2013	Corsa-D	Engine	Z17DTR	√	√	√	√	√	SP0019,SP0021,SP0011,SP0014,SP0022,SP0023,SP0024,SP0012,SP0025,SP0026,SP0027,SP0028,SP0020,SP0029
2013	Corsa-D	Engine	Engine(default)	√	√	√			

2013	Corsa-D	Transmission	MTA(Easytronic Magneti Marelli)	√	√	√	√	√	
2013	Corsa-D	Transmission	AF 13-4	√	√	√	√	√	SP0030,SP0031,SP0032,SP0033
2013	Corsa-D	Transmission	MTA(Easytronic)	√	√	√	√	√	SP0034,SP0035
2013	Meriva-B	Body	Front Seat Heating Control Module	√	√	√	√		
2013	Meriva-B	Body	BCM (Body Control Module)	√	√	√	√		
2013	Meriva-B	Body	Headlamp Control Module	√	√	√	√		
2013	Meriva-B	Body	Inflatable Restraint Sensing&Diag.Module	√	√	√	√		
2013	Meriva-B	Body	Parking Assist Control Module	√	√	√	√	√	SP0108,SP0039
2013	Meriva-B	Body	Remote Heater & A/C Control Module	√	√	√	√		
2013	Meriva-B	Body	Instrument	√	√	√	√	√	SP0039
2013	Meriva-B	Body	Trailer Interface Control Module	√	√	√	√		
2013	Meriva-B	Chassis	Electronic Brake Control Module	√	√	√	√		
2013	Meriva-B	Chassis	Electric Power Steering Control Module	√	√	√	√		
2013	Meriva-B	Chassis	Parking Brake Control Module	√	√	√	√	√	SP0109,SP0110
2013	Meriva-B	Chassis	Steering Wheel Angle Sensor Module	√	√	√			SP0081
2013	Meriva-B	Chassis	Fuel injector control module	√			√		
2013	Meriva-B	Engine	A 13 DTC 1.3(LDV)	√	√	√	√	√	SP0083,SP0111,SP0112,SP0023,SP0024,SP0028,SP0025,SP0069,SP0113,SP0114,SP0115,SP0116,SP0117,SP0118
2013	Meriva-B	Engine	A 13 DTE 1.3(LSF)	√	√	√	√	√	SP0083,SP0119,SP0111,SP0023,SP0024,SP0028,SP0025,SP0069,SP0112,SP0113,SP0114,SP0115,SP0116,SP0120,SP0018
2013	Meriva-B	Engine	A 14 NEL (LUH)	√	√	√	√	√	SP0018
2013	Meriva-B	Engine	A 14 NET (LUJ)	√	√	√	√	√	SP0018
2013	Meriva-B	Engine	A 14 XER (LDD)	√	√	√	√	√	SP0018
2013	Meriva-B	Engine	A 17 DTC 1.7(LUE)	√	√	√	√	√	SP0121,SP0103,SP0018
2013	Meriva-B	Engine	A 17 DTS 1.7(LUD)	√	√	√	√	√	SP0120,SP0103,SP0018
2013	Meriva-B	Engine	Engine Control Module	√	√	√	√	√	SP0025,SP0018
2013	Meriva-B	Transmission	Transmission Control Module	√	√	√	√	√	SP0078,SP0122
2013	Vivaro	Body	Park Pilot		√	√	√		
2013	Vivaro	Body	Add On Heater	√	√	√	√	√	SP0123,SP0124
2013	Vivaro	Body	Airbag		√	√	√		SP0004
2013	Vivaro	Engine	F9Q 760/762 (1.9L)	√	√	√	√		
2013	Vivaro	Transmission	MTA(Tecshift)		√	√	√	√	
2013	Zafira-B	Body	AHL/AFL (Headlamp Levelling)	√	√	√	√		
2013	Zafira-B	Body	Exterior Lighting/Turn Indicator System	√	√	√	√		
2013	Zafira-B	Body	Interior Lighting	√	√	√	√		
2013	Zafira-B	Body	Wipers/Washer	√	√	√	√		

2013	Zafira-B	Body	Central Door Lock	√	√	√	√		
2013	Zafira-B	Body	Instrument	√	√	√	√		
2013	Zafira-B	Body	Immobiliser	√	√	√	√		
2013	Zafira-B	Body	CIM (Steering Column Module)	√	√	√	√	√	
2013	Zafira-B	Body	ECC/SAC (Electronic Climate Control)	√	√	√	√		
2013	Zafira-B	Body	EHS (Electrical Heater System)	√	√	√	√		
2013	Zafira-B	Body	PAS (Park Pilot)	√	√	√	√		
2013	Zafira-B	Body	SDM (Airbag)	√	√	√	√		SP0000,SP0001,SP0002
2013	Zafira-B	Body	SLM (Shift Lever Module)	√	√	√	√		
2013	Zafira-B	Body	UEC (Underhood Electrical Centre)	√	√	√	√		
2013	Zafira-B	Body	REC (Rear Electrical Centre)	√	√	√	√		
2013	Zafira-B	Body	PEPS (Open&Start)	√	√	√	√		
2013	Zafira-B	Body	IPC ECU (Instrument Control Unit)	√	√	√	√	√	SP0006,SP0055,SP0056,SP0057,SP0058,S P0059,SP0060,SP0001,SP0004
2013	Zafira-B	Body	Anti Theft Warning System	√	√	√	√		
2013	Zafira-B	Body	CIM(Steering Column Module)	√	√	√	√	√	SP0051,SP0003,SP0052,SP0001,SP0004,S P0053,SP0054,SP0005
2013	Zafira-B	Chassis	ABS/TC/ESP (Vehicle Dynamic System)	√	√	√	√	√	SP0005
2013	Zafira-B	Chassis	TPMS ECU (Tyre Pressure Monitoring)	√	√	√	√		
2013	Zafira-B	Chassis	TPMS (Tyre Pressure Monitoring System)	√	√	√	√		
2013	Zafira-B	Chassis	EHPS (Electrohydraulic Power Steering)	√	√	√	√		SP0003
2013	Zafira-B	Chassis	ABS/TC/ESP ECU(Electronic Control Unit)	√	√	√	√	√	
2013	Zafira-B	Chassis	CDC (Continuous Damping Control)	√	√	√	√		
2013	Zafira-B	Engine	Z16XE1	√	√	√	√	√	SP0033,SP0018
2013	Zafira-B	Engine	Z16XEP	√	√	√	√		SP0006,SP0007,SP0008,SP0009,SP0019,S P0010,SP0011,SP0066,SP0012,SP0013,SP 0033,SP0018
2013	Zafira-B	Engine	Z16XER	√	√	√	√		SP0019,SP0006,SP0007,SP0008,SP0009,S P0010,SP0011,SP0066,SP0033,SP0012,SP
2013	Zafira-B	Engine	Z16YNG	√	√	√	√	√	SP0033,SP0018
2013	Zafira-B	Engine	A16XER	√	√	√	√	√	SP0009,SP0019,SP0033,SP0018
2013	Zafira-B	Engine	Z17DTJ	√	√	√	√	√	SP0019,SP0025,SP0027,SP0020,SP0018
2013	Zafira-B	Engine	A17DTJ	√	√	√	√	√	SP0006,SP0007,SP0008,SP0019,SP0025,S P0027,SP0018
2013	Zafira-B	Engine	A17DTR	√	√	√	√	√	SP0006,SP0007,SP0008,SP0019,SP0025,S P0027,SP0018
2013	Zafira-B	Engine	Z18XER	√	√	√	√		SP0019,SP0006,SP0007,SP0008,SP0009,S P0010,SP0011,SP0066,SP0033,SP0012,SP

2013	Zafira-B	Engine	A18XER	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0019,SP0033,SP0018
2013	Zafira-B	Engine	Z19DT	√	√	√	√	√	SP0006,SP0007,SP0008,SP0010,SP0011,SP0066,SP0023,SP0024,SP0069,SP0012,SP0032,SP0020,SP0029,SP0026,SP0027,SP0025,SP0028,SP0018
2013	Zafira-B	Engine	Z19DTH	√	√	√	√	√	SP0006,SP0007,SP0008,SP0032,SP0010,SP0011,SP0066,SP0023,SP0024,SP0028,SP0025,SP0026,SP0027
2013	Zafira-B	Engine	Z20LEH	√	√	√	√	√	SP0018
2013	Zafira-B	Engine	Z20LER	√	√	√	√	√	SP0018
2013	Zafira-B	Engine	Z22YH	√	√	√	√	√	SP0018
2013	Zafira-B	Engine	Engine(default)	√	√	√			
2013	Zafira-B	Transmission	AF 40-6	√	√	√	√	√	SP0072,SP0073,SP0126,SP0075,SP0076,SP0077,SP0032,SP0033,SP0078
2013	Zafira-B	Transmission	MTA(Easytronic)	√	√	√	√	√	SP0034,SP0035
2013	Zafira-B	Transmission	AF 22-4	√	√	√	√	√	SP0032,SP0033
2012	Ampera		Engine Control Module	√	√	√	√	√	SP0017,SP0018,SP0016,SP0019,SP0586
2012	Ampera		Fuel Pump Control Module	√	√	√	√	√	SP0016
2012	Ampera		Hybrid Powertrain Control Module	√	√	√	√	√	
2012	Ampera		Transmission Control Module	√	√	√	√	√	
2012	Ampera		Drive Motor Control Module 1	√	√	√	√		
2012	Ampera		Drive Motor Control Module 2	√	√	√	√		
2012	Ampera		Auxiliary Transmission Fluid Pump	√	√	√	√		
2012	Ampera		Electronic Brake Control Module	√	√	√	√	√	SP0565
2012	Ampera		Parking Brake Control Module	√	√	√	√	√	SP0109
2012	Ampera		Multi-Axis Acceleration Sensor Module	√	√	√			SP0350
2012	Ampera		Power Steering Control Module	√	√	√	√		SP0090
2012	Ampera		Steering Wheel Angle Sensor Module	√	√	√			
2012	Ampera		Body Control Module	√	√	√	√	√	SP0047,SP0048,SP0045,SP0372,SP0378,SP0376,SP0046,SP0334,SP0332
2012	Ampera		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	SP0311
2012	Ampera		Passenger Presence Module	√	√	√	√		SP0579
2012	Ampera		Instrument Cluster	√	√	√	√	√	SP0040,SP0040
2012	Ampera		Radio	√	√	√	√	√	
2012	Ampera		Digital Radio Receiver Control Module	√	√	√	√	√	
2012	Ampera		Mobile Telephone Control Module	√	√	√	√	√	
2012	Ampera		Telematics Communication Interface Control Module	√	√	√	√	√	SP0580

2012	Ampera		Remote Heater and Air Conditioning Control Module	√	√	√	√	√	SP0211,SP0307
2012	Ampera		Electric A/C Compressor Control Module	√					
2012	Ampera		Coolant Heater Control Module	√	√	√			
2012	Ampera		Front Seat Heating Control Module	√	√	√	√	√	
2012	Ampera		Keyless Entry Control Module	√	√	√	√	√	
2012	Ampera		Parking Assist Control Module	√	√	√	√	√	SP0040
2012	Ampera		Steering Column Lock Control Module	√	√	√	√		
2012	Ampera		Battery Charger Control Module	√			√		
2012	Ampera		Hybrid Powertrain Control Module 2	√	√	√	√	√	SP0556,SP0303,SP0240,SP0559,SP0301,S P0302,SP0305
2012	Ampera		Battery Energy Control Module	√			√		
2012	Antara		Engine Control Module	√	√	√	√	√	SP0048,SP0084,SP0017,SP0018,SP0016,S P0571,SP0019,SP0091
2012	Antara		Fuel Pump Control Module	√	√	√	√	√	SP0016
2012	Antara		Transmission Control Module	√	√	√	√	√	SP0422
2012	Antara		Rear Differential Clutch Control Module	√	√	√	√	√	
2012	Antara		Electronic Brake Control Module	√	√	√	√	√	SP0083
2012	Antara		Parking Brake Control Module	√	√	√	√	√	SP0109
2012	Antara		Variable Power Steering Control Module	√	√	√		√	
2012	Antara		Body Control Module	√	√	√	√	√	SP0048,SP0442
2012	Antara		Auxiliary Body Control Module	√	√	√	√	√	SP0236
2012	Antara		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	SP0347,SP0442
2012	Antara		Instrument Cluster	√	√	√	√	√	
2012	Antara		Headlamp Control Module	√	√	√	√	√	SP0366
2012	Antara		Radio	√	√	√	√	√	SP0428,SP0040,SP0420,SP0409
2012	Antara		Mobile Telephone Control Module	√	√	√		√	SP0040,SP0243,SP0423,SP0420
2012	Antara		HVAC Control Module	√	√	√		√	
2012	Antara		Info Display Module	√	√	√	√	√	SP0423,SP0398
2012	Antara		Remote Control Door Lock Receiver	√	√	√	√	√	SP0374,SP0413,SP0335,SP0336,SP0337,S P0338,SP0332,SP0334,SP0403
2012	Antara		Parking Assist Control Module	√	√	√	√	√	
2012	Antara		Theft Deterrent Module	√	√	√	√		
2012	Astra-J		Engine Control Module	√	√	√	√	√	SP0313,SP0306
2012	Astra-J		Fuel Injector Control Module	√			√	√	
2012	Astra-J		Fuel Pump Control Module	√	√	√	√	√	SP0016
2012	Astra-J		Transmission Control Module	√	√	√	√	√	SP0223,SP0122
2012	Astra-J		Electronic Brake Control Module	√	√	√	√	√	SP0394,SP0083,SP0086
2012	Astra-J		Parking Brake Control Module	√	√	√	√	√	SP0109

2012	Astra-J		Multi-Axis Acceleration Sensor Module	√	√	√			SP0350
2012	Astra-J		Power Steering Control Module	√	√	√	√		SP0090
2012	Astra-J		Steering Wheel Angle Sensor Module	√	√	√			
2012	Astra-J		Suspension Control Module	√	√	√	√	√	
2012	Astra-J		Body Control Module	√	√	√	√	√	SP0047,SP0048,SP0045,SP0378,SP0372,S P0376,SP0046,SP0334,SP0332
2012	Astra-J		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	SP0311
2012	Astra-J		Instrument Cluster	√	√	√	√	√	SP0040
2012	Astra-J		Chime Alarm Control Module	√	√	√		√	
2012	Astra-J		Headlamp Control Module	√	√	√	√	√	SP0366
2012	Astra-J		Trailer Interface Control Module	√	√	√	√	√	SP0040
2012	Astra-J		Radio	√	√	√	√	√	
2012	Astra-J		Digital Radio Receiver Control Module	√	√	√	√	√	
2012	Astra-J		Multimedia Player Interface Module	√	√	√	√		
2012	Astra-J		Mobile Telephone Control Module	√	√	√	√	√	
2012	Astra-J		Remote Heater and Air Conditioning Control Module	√	√	√	√	√	SP0211,SP0040
2012	Astra-J		Front Seat Heating Control Module	√	√	√	√	√	
2012	Astra-J		Parking Assist Control Module	√	√	√	√	√	SP0040
2012	Astra-J		Vehicle Direction Camera Control Module	√	√	√	√	√	
2012	Combo-D		Engine Control Module	√	√	√	√	√	SP0576,SP0230,SP0578,SP0234,SP0122,S P0221,SP0565,SP0316,SP0325,SP0426,SP
2012	Combo-D		Transmission Control Module	√	√	√	√	√	SP0314,SP0427
2012	Combo-D		Electronic Brake Control Module	√	√	√	√	√	SP0459,SP0394,SP0083
2012	Combo-D		Body Control Module	√	√	√	√	√	SP0242,SP0418,SP0389
2012	Combo-D		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	
2012	Combo-D		Instrument Cluster	√	√	√	√	√	SP0218
2012	Combo-D		Multimedia Player Interface Module	√	√	√	√	√	
2012	Combo-D		HVAC Control Module	√	√	√	√	√	SP0211
2012	Combo-D		Auxiliary Heater Control Module	√	√	√	√	√	SP0278
2012	Combo-D		Parking Assist Control Module	√	√	√	√		SP0344
2012	Insignia		Engine Control Module	√	√	√	√	√	SP0084,SP0018,SP0016
2012	Insignia		Fuel Injector Control Module	√			√	√	
2012	Insignia		Fuel Pump Control Module	√	√	√	√	√	SP0016
2012	Insignia		Transmission Control Module	√	√	√	√	√	SP0223,SP0122
2012	Insignia		Rear Differential Clutch Control Module	√	√	√	√	√	
2012	Insignia		Electronic Brake Control Module	√	√	√	√	√	SP0394,SP0083,SP0086
2012	Insignia		Parking Brake Control Module	√	√	√	√	√	SP0109
2012	Insignia		Multi-Axis Acceleration Sensor Module	√	√	√			SP0350

2012	Insignia		Power Steering Control Module	√	√	√	√		SP0090
2012	Insignia		Steering Wheel Angle Sensor Module	√	√	√			
2012	Insignia		Suspension Control Module	√	√	√	√	√	
2012	Insignia		Body Control Module	√	√	√	√	√	SP0047,SP0048,SP0045,SP0378,SP0372,S P0376,SP0046,SP0334,SP0332
2012	Insignia		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	SP0311
2012	Insignia		Instrument Cluster	√	√	√	√	√	SP0040
2012	Insignia		Chime Alarm Control Module	√	√	√		√	
2012	Insignia		Headlamp Control Module	√	√	√	√	√	SP0366
2012	Insignia		Trailer Interface Control Module	√	√	√	√	√	SP0040
2012	Insignia		Radio	√	√	√	√	√	
2012	Insignia		Digital Radio Receiver Control Module	√	√	√	√	√	
2012	Insignia		Multimedia Player Interface Module	√	√	√	√		SP0040
2012	Insignia		Mobile Telephone Control Module	√	√	√	√	√	
2012	Insignia		Remote Heater and Air Conditioning Control Module	√	√	√	√	√	SP0211,SP0040
2012	Insignia		Liftgate Control Module	√	√	√	√	√	SP0323
2012	Insignia		Seat Memory Control Module	√	√	√	√	√	SP0581
2012	Insignia		Front Seat Heating Control Module	√	√	√	√	√	
2012	Insignia		Parking Assist Control Module	√	√	√	√	√	SP0040
2012	Insignia		Vehicle Direction Camera Control Module	√	√	√	√	√	
2012	Insignia		Distance Sensing Cruise Control Module	√	√	√	√		SP0231
2012	Zafira-C		Engine Control Module	√	√	√	√	√	SP0313,SP0105,SP0385,SP0103,SP0102
2012	Zafira-C		Fuel Injector Control Module	√			√	√	
2012	Zafira-C		Transmission Control Module	√	√	√	√	√	SP0223,SP0122
2012	Zafira-C		Electronic Brake Control Module	√	√	√	√	√	SP0394,SP0083,SP0086
2012	Zafira-C		Distance Sensing Cruise Control Module	√	√	√	√		SP0231
2012	Zafira-C		Parking Brake Control Module	√	√	√	√	√	SP0109
2012	Zafira-C		Multi-Axis Acceleration Sensor Module	√	√	√			SP0350
2012	Zafira-C		Power Steering Control Module	√	√	√	√		SP0090
2012	Zafira-C		Steering Wheel Angle Sensor Module	√	√	√			
2012	Zafira-C		Suspension Control Module	√	√	√	√	√	
2012	Zafira-C		Body Control Module	√	√	√	√	√	SP0047,SP0048,SP0045,SP0378,SP0372,S P0376,SP0046,SP0334,SP0332
2012	Zafira-C		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	SP0311
2012	Zafira-C		Instrument Cluster	√	√	√	√	√	SP0040
2012	Zafira-C		Chime Alarm Control Module	√	√	√		√	
2012	Zafira-C		Headlamp Control Module	√	√	√	√	√	SP0366
2012	Zafira-C		Trailer Interface Control Module	√	√	√	√	√	SP0040

2012	Zafira-C		Radio	√	√	√	√	√	
2012	Zafira-C		Digital Radio Receiver Control Module	√	√	√	√	√	
2012	Zafira-C		Multimedia Player Interface Module	√	√	√	√		
2012	Zafira-C		Mobile Telephone Control Module	√	√	√	√	√	
2012	Zafira-C		Remote Heater and Air Conditioning Control Module	√	√	√	√	√	SP0211,SP0040
2012	Zafira-C		Front Seat Heating Control Module	√	√	√	√	√	
2012	Zafira-C		Parking Assist Control Module	√	√	√	√	√	SP0040
2012	Zafira-C		Vehicle Direction Camera Control Module	√	√	√	√	√	SP0040
2012	Agila-B	Body	BCM (Body Control Module)		√	√	√		
2012	Agila-B	Body	Immobiliser		√	√	√		
2012	Agila-B	Body	SDM (Airbag)		√	√	√		SP0000,SP0001,SP0002
2012	Agila-B	Chassis	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)	√	√	√	√		SP0005
2012	Agila-B	Chassis	Electronic Power Steering		√	√	√		
2012	Agila-B	Engine	K10B	√	√	√	√	√	SP0015
2012	Agila-B	Engine	K12B	√	√	√	√	√	SP0015
2012	Agila-B	Engine	D13A / Z 13 DTJ	√	√	√	√	√	SP0040,SP0019,SP0020,SP0018,SP0025,SP0042
2012	Agila-B	Transmission	TCM (Transmission Control Module)	√	√	√	√		SP0033
2012	Astra-H	Body	AHL/AFL (Headlamp Levelling)	√	√	√	√		
2012	Astra-H	Body	Exterior Lighting/Turn Indicator System	√	√	√	√		
2012	Astra-H	Body	Interior Lighting	√	√	√	√		
2012	Astra-H	Body	Wipers/Washer	√	√	√	√		
2012	Astra-H	Body	Central Door Lock	√	√	√	√		
2012	Astra-H	Body	Instrument	√	√	√	√		
2012	Astra-H	Body	Immobiliser	√	√	√	√		
2012	Astra-H	Body	CIM (Steering Column Module)	√	√	√	√	√	
2012	Astra-H	Body	Anti Theft Warning System	√	√	√	√		
2012	Astra-H	Body	Electrohydraulic HardTop	√	√	√	√		
2012	Astra-H	Body	ECC/SAC (Electronic Climate Control)	√	√	√	√		
2012	Astra-H	Body	IPC ECU (Instrument Control Unit)	√	√	√	√	√	SP0006,SP0055,SP0056,SP0057,SP0058,SP0059,SP0060,SP0001,SP0004
2012	Astra-H	Body	EHS (Electrical Heater System)	√	√	√	√		
2012	Astra-H	Body	PAS (Park Pilot)	√	√	√	√		
2012	Astra-H	Body	SDM (Airbag)	√	√	√	√		SP0000,SP0001,SP0002
2012	Astra-H	Body	SLM (Shift Lever Module)	√	√	√	√		
2012	Astra-H	Body	UEC (Underhood Electrical Centre)	√	√	√	√		
2012	Astra-H	Body	REC (Rear Electrical Centre)	√	√	√	√		

2012	Astra-H	Body	PEPS (Open&Start)	√	√	√	√		
2012	Astra-H	Body	CIM(Steering Column Module)	√	√	√	√	√	SP0051,SP0003,SP0052,SP0001,SP0004,S P0053,SP0054,SP0005
2012	Astra-H	Chassis	TPMS ECU (Tyre Pressure Monitoring)	√	√	√	√		
2012	Astra-H	Chassis	TPMS (Tyre Pressure Monitoring System)	√	√	√	√		
2012	Astra-H	Chassis	EHPS (Electrohydraulic Power Steering)	√	√	√	√		SP0003
2012	Astra-H	Chassis	ABS/TC/ESP ECU(Electronic Control Unit)	√	√	√	√	√	
2012	Astra-H	Chassis	CDC (Continuous Damping Control)	√	√	√	√		
2012	Astra-H	Chassis	ABS/TC/ESP (Vehicle Dynamic System)	√	√	√	√	√	
2012	Astra-H	Engine	Z12XEP	√	√	√	√	√	SP0009,SP0063,SP0011,SP0064,SP0012,S P0065,SP0006,SP0007,SP0008,SP0018
2012	Astra-H	Engine	Y13DTH	√	√	√	√	√	SP0009,SP0063,SP0011,SP0064,SP0012,S P0065,SP0006,SP0007,SP0008,SP0018
2012	Astra-H	Engine	Z13DTH	√	√	√	√	√	SP0006,SP0007,SP0008,SP0019,SP0010,S P0011,SP0066,SP0020,SP0029,SP0028,SP 0025,SP0026,SP0018
2012	Astra-H	Engine	Z14XEL	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,S P0011,SP0066,SP0012,SP0013,SP0018
2012	Astra-H	Engine	Z14XEP	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,S P0011,SP0066,SP0012,SP0013,SP0018
2012	Astra-H	Engine	Z16LET	√	√	√	√	√	SP0009,SP0063,SP0011,SP0064,SP0012,S P0065,SP0006,SP0007,SP0008,SP0018
2012	Astra-H	Engine	Z16XE1	√	√	√	√	√	SP0019,SP0009,SP0063,SP0067,SP0064,S P0012,SP0065,SP0068,SP0006,SP0007,SP 0008,SP0018
2012	Astra-H	Engine	Z16XEP	√	√	√	√		SP0006,SP0007,SP0008,SP0009,SP0019,S P0010,SP0011,SP0066,SP0012,SP0013,SP 0033,SP0018
2012	Astra-H	Engine	Z16XER	√	√	√	√		SP0019,SP0006,SP0007,SP0008,SP0009,S P0010,SP0011,SP0066,SP0033,SP0012,SP
2012	Astra-H	Engine	A16LET	√	√	√	√	√	SP0009,SP0063,SP0011,SP0064,SP0012,S P0065,SP0006,SP0007,SP0008,SP0018
2012	Astra-H	Engine	A16XER	√	√	√	√	√	SP0019,SP0009,SP0063,SP0067,SP0064,S P0033,SP0012,SP0006,SP0007,SP0008,SP
2012	Astra-H	Engine	Z17DTH	√	√	√	√	√	SP0006,SP0007,SP0008,SP0010,SP0011,S P0066,SP0020,SP0024,SP0012,SP0029,SP 0032,SP0018

2012	Astra-H	Engine	Z17DTJ	√	√	√	√	√	SP0006,SP0007,SP0008,SP0019,SP0010,S P0011,SP0066,SP0014,SP0022,SP0023,SP 0024,SP0012,SP0025,SP0026,SP0027,SP0 028,SP0029,SP0020,SP0018
2012	Astra-H	Engine	Z17DTL	√	√	√	√	√	SP0063,SP0011,SP0064,SP0020,SP0024,S P0012,SP0029,SP0032,SP0018
2012	Astra-H	Engine	Z17DTR	√	√	√	√	√	SP0006,SP0007,SP0008,SP0019,SP0010,S P0011,SP0066,SP0014,SP0022,SP0023,SP 0024,SP0012,SP0025,SP0026,SP0027,SP0 028,SP0029,SP0020,SP0018
2012	Astra-H	Engine	A17DTJ	√	√	√	√	√	SP0019,SP0063,SP0011,SP0064,SP0014,S P0022,SP0023,SP0024,SP0012,SP0028,SP 0025,SP0069,SP0026,SP0070,SP0006,SP0 007,SP0008,SP0027,SP0018
2012	Astra-H	Engine	A17DTR	√	√	√	√	√	SP0019,SP0063,SP0011,SP0064,SP0014,S P0022,SP0023,SP0024,SP0012,SP0028,SP 0025,SP0069,SP0026,SP0070,SP0006,SP0 007,SP0008,SP0027,SP0018
2012	Astra-H	Engine	Z18XE	√	√	√	√		SP0019,SP0006,SP0007,SP0008,SP0009,S P0010,SP0011,SP0066,SP0012,SP0018
2012	Astra-H	Engine	Z18XER	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0019,S P0010,SP0011,SP0066,SP0033,SP0012,SP
2012	Astra-H	Engine	A18XER	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0019,S P0033,SP0018
2012	Astra-H	Engine	Z19DT	√	√	√	√	√	SP0006,SP0007,SP0008,SP0010,SP0011,S P0066,SP0023,SP0024,SP0069,SP0012,SP 0032,SP0020,SP0029,SP0026,SP0027,SP0 025,SP0028,SP0018
2012	Astra-H	Engine	Z19DTH	√	√	√	√	√	SP0006,SP0007,SP0008,SP0010,SP0011,S P0066,SP0023,SP0024,SP0069,SP0012,SP 0032,SP0020,SP0029,SP0026,SP0027,SP0 025,SP0028,SP0018
2012	Astra-H	Engine	Z20LEH	√	√	√	√	√	SP0009,SP0063,SP0011,SP0064,SP0012,S P0065,SP0006,SP0007,SP0008,SP0018
2012	Astra-H	Engine	Z20LEL	√	√	√	√	√	SP0009,SP0063,SP0011,SP0064,SP0012,S P0065,SP0006,SP0007,SP0008,SP0018
2012	Astra-H	Engine	Z20LER	√	√	√	√	√	SP0009,SP0063,SP0011,SP0064,SP0012,S P0065,SP0006,SP0007,SP0008,SP0018

2012	Astra-H	Engine	Z22YH	√	√	√	√	√	SP0006,SP0007,SP0008,SP0071,SP0019,SP0010,SP0011,SP0066,SP0012,SP0018
2012	Astra-H	Engine	Engine(default)	√	√	√			
2012	Astra-H	Transmission	AF 40-6	√	√	√	√	√	SP0072,SP0073,SP0074,SP0075,SP0076,SP0077,SP0032,SP0003,SP0033,SP0078
2012	Astra-H	Transmission	AF17-4	√	√	√	√	√	SP0030,SP0031,SP0032,SP0003,SP0033
2012	Astra-H	Transmission	AF 22-4	√	√	√	√	√	SP0032,SP0079,SP0033,SP0030
2012	Astra-H	Transmission	MTA(Easytronic)	√	√	√	√	√	SP0079,SP0034,SP0035,SP0061
2012	Astra-H	Transmission	MTA(Easytronic Magneti Marelli)	√	√	√	√	√	SP0079,SP0004,SP0061
2012	Corsa-C	Body	Airbag	√	√	√	√	√	
2012	Corsa-C	Body	Body Control Module	√	√	√	√	√	SP0051,SP0058,SP0139
2012	Corsa-C	Body	Instrument	√	√	√	√		
2012	Corsa-C	Body	Immobiliser	√	√	√	√		SP0140,SP0141
2012	Corsa-C	Body	Add On Heater	√	√	√	√	√	SP0122,SP0123
2012	Corsa-C	Chassis	Electronic Power Steering	√	√	√	√		SP0142
2012	Corsa-C	Chassis	ABS8/ESP8 (Anti-lock Braking System/Electronic Stability Program)		√	√	√	√	SP0005,SP0143,SP0144,SP0145,SP0004
2012	Corsa-C	Chassis	ABS-5.3/5.4 (+TC) (Anti-lock Braking System)	√	√	√	√	√	
2012	Corsa-C	Chassis	Electronic Power Steering	√	√	√	√		SP0141
2012	Corsa-C	Engine	Z10XEP	√	√	√	√	√	SP0011,SP0021,SP0065,SP0033
2012	Corsa-C	Engine	Z12XE	√	√	√	√	√	SP0006,SP0146,SP0009,SP0040,SP0019,SP0021,SP0011,SP0065,SP0033
2012	Corsa-C	Engine	Z12XEP	√	√	√	√	√	SP0011,SP0021,SP0065,SP0033
2012	Corsa-C	Engine	Y13DT	√	√	√	√	√	SP0040,SP0019,SP0021,SP0011,SP0020
2012	Corsa-C	Engine	Z13DT	√	√	√	√	√	SP0019,SP0040,SP0021,SP0011,SP0020
2012	Corsa-C	Engine	Z13DTJ	√	√	√	√	√	SP0040
2012	Corsa-C	Engine	Z14XE	√			√	√	SP0021
2012	Corsa-C	Engine	Z14XEP	√	√	√	√	√	SP0011
2012	Corsa-C	Engine	Z16SE	√	√	√	√	√	
2012	Corsa-C	Engine	Z16YNG	√	√	√	√	√	SP0006,SP0147,SP0145,SP0009,SP0019,SP0011,SP0021
2012	Corsa-C	Engine	Y17DT	√	√	√	√	√	
2012	Corsa-C	Engine	Y17DTL	√	√	√	√	√	
2012	Corsa-C	Engine	Z17DTH	√	√	√	√	√	SP0006,SP0146,SP0019,SP0020,SP0148,SP0022,SP0011,SP0021
2012	Corsa-C	Engine	Z18XE	√	√	√	√	√	SP0145,SP0009,SP0040,SP0019,SP0011,SP0021
2012	Corsa-C	Transmission	AF 13-II/17/20/22 CAN	√	√	√	√	√	

2012	Corsa-C	Transmission	Easytronic(MTA)	√	√	√	√	√	SP0011,SP0149
2012	Corsa-D	Body	Exterior Lighting	√	√	√	√		
2012	Corsa-D	Body	Interior Lighting	√	√	√	√		
2012	Corsa-D	Body	Wipers/Washer	√	√	√	√		
2012	Corsa-D	Body	Heating,Ventilation and Air Cond.	√	√	√	√		
2012	Corsa-D	Body	Anti Theft Warning System	√	√	√	√		
2012	Corsa-D	Body	Central Door Lock	√	√	√	√	√	
2012	Corsa-D	Body	Immobiliser	√	√	√	√		
2012	Corsa-D	Body	AFL (Adaptive Forward Lighting)	√	√	√	√		
2012	Corsa-D	Body	EHS (Electrical Heater System)	√	√	√	√		
2012	Corsa-D	Body	IPC ECU (Instrument Control Unit)	√	√	√	√		
2012	Corsa-D	Body	PAS (Park Pilot)	√	√	√	√		
2012	Corsa-D	Body	SDM (Airbag)	√	√	√	√		SP0000,SP0001,SP0002
2012	Corsa-D	Body	TIM(Trailer Interface Module)	√	√	√	√		
2012	Corsa-D	Body	BCM (Body Control Module)	√	√	√	√		
2012	Corsa-D	Chassis	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)	√	√	√	√	√	
2012	Corsa-D	Chassis	Electronic Power Steering	√	√	√	√		
2012	Corsa-D	Chassis	Fuel injector control module	√			√		
2012	Corsa-D	Engine	Z10XEP	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,SP0011,SP0012,SP0013,SP0014
2012	Corsa-D	Engine	A10XEP	√	√	√	√	√	SP0006,SP0015,SP0016,SP0017,SP0018
2012	Corsa-D	Engine	Z12XEP	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,SP0011,SP0012,SP0013,SP0014
2012	Corsa-D	Engine	A12XER	√	√	√	√	√	SP0006,SP0018
2012	Corsa-D	Engine	A12XEL	√	√	√	√	√	SP0006,SP0018
2012	Corsa-D	Engine	Z13DTH	√	√	√	√	√	SP0019,SP0010,SP0011,SP0014,SP0020
2012	Corsa-D	Engine	Z13DTE	√	√	√	√	√	SP0006
2012	Corsa-D	Engine	Z13DTJ	√	√	√	√	√	SP0019,SP0010,SP0011,SP0014,SP0020
2012	Corsa-D	Engine	A13DTC	√	√	√	√	√	SP0019
2012	Corsa-D	Engine	Z14XEP	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,SP0011,SP0012,SP0013,SP0014
2012	Corsa-D	Engine	A14XEL	√	√	√	√	√	SP0006,SP0015,SP0016,SP0017,SP0018
2012	Corsa-D	Engine	A14XER	√	√	√	√	√	SP0006,SP0015,SP0016,SP0017,SP0018
2012	Corsa-D	Engine	Z16LEL	√	√	√	√	√	
2012	Corsa-D	Engine	Z16LER	√	√	√	√	√	
2012	Corsa-D	Engine	A16LEL	√	√	√	√	√	
2012	Corsa-D	Engine	A16LER	√	√	√	√	√	

2012	Corsa-D	Engine	Z17DTR	√	√	√	√	√	SP0019,SP0021,SP0011,SP0014,SP0022,SP0023,SP0024,SP0012,SP0025,SP0026,SP0027,SP0028,SP0020,SP0029
2012	Corsa-D	Engine	Engine(default)	√	√	√			
2012	Corsa-D	Transmission	MTA(Easytronic Magneti Marelli)	√	√	√	√	√	
2012	Corsa-D	Transmission	AF 13-4	√	√	√	√	√	SP0030,SP0031,SP0032,SP0033
2012	Corsa-D	Transmission	MTA(Easytronic)	√	√	√	√	√	SP0034,SP0035
2012	Meriva-B	Body	Front Seat Heating Control Module	√	√	√	√		
2012	Meriva-B	Body	BCM (Body Control Module)	√	√	√	√		
2012	Meriva-B	Body	Headlamp Control Module	√	√	√	√		
2012	Meriva-B	Body	Inflatable Restraint Sensing&Diag.Module	√	√	√	√		
2012	Meriva-B	Body	Parking Assist Control Module	√	√	√	√	√	SP0107,SP0039
2012	Meriva-B	Body	Remote Heater & A/C Control Module	√	√	√	√		
2012	Meriva-B	Body	Instrument	√	√	√	√	√	SP0039
2012	Meriva-B	Body	Trailer Interface Control Module	√	√	√	√		
2012	Meriva-B	Chassis	Electronic Brake Control Module	√	√	√	√		
2012	Meriva-B	Chassis	Electric Power Steering Control Module	√	√	√	√		
2012	Meriva-B	Chassis	Parking Brake Control Module	√	√	√	√	√	SP0108,SP0109
2012	Meriva-B	Chassis	Steering Wheel Angle Sensor Module	√	√	√			SP0081
2012	Meriva-B	Chassis	Fuel injector control module	√			√		
2012	Meriva-B	Engine	A 13 DTC 1.3(LDV)	√	√	√	√	√	SP0083,SP0110,SP0111,SP0023,SP0024,SP0028,SP0025,SP0069,SP0112,SP0113,SP0114,SP0115,SP0116,SP0117
2012	Meriva-B	Engine	A 13 DTE 1.3(LSF)	√	√	√	√	√	SP0083,SP0118,SP0111,SP0023,SP0024,SP0028,SP0025,SP0069,SP0112,SP0113,SP0114,SP0115,SP0116,SP0119,SP0018
2012	Meriva-B	Engine	A 14 NEL (LUH)	√	√	√	√	√	SP0018
2012	Meriva-B	Engine	A 14 NET (LUJ)	√	√	√	√	√	SP0018
2012	Meriva-B	Engine	A 14 XER (LDD)	√	√	√	√	√	SP0018
2012	Meriva-B	Engine	A 17 DTC 1.7(LUE)	√	√	√	√	√	SP0120,SP0103,SP0018
2012	Meriva-B	Engine	A 17 DTS 1.7(LUD)	√	√	√	√	√	SP0120,SP0103,SP0018
2012	Meriva-B	Engine	Engine Control Module	√	√	√	√	√	SP0025,SP0018
2012	Meriva-B	Transmission	Transmission Control Module	√	√	√	√	√	SP0078,SP0121
2012	Vauxhall VXR8	Body	AHL(Automatic Headlamp Levelling)	√	√	√	√		
2012	Vauxhall VXR8	Body	BCM (Body Control Module)	√	√	√	√		
2012	Vauxhall VXR8	Body	HVAC(Heating Ventilation and Cooling)	√	√	√	√		
2012	Vauxhall VXR8	Body	Immobiliser	√	√	√	√		
2012	Vauxhall VXR8	Body	MSM(Memory Seat and Mirrors)	√	√	√	√		

2012	Vauxhall VXR8	Body	Park Assist	√	√	√	√		
2012	Vauxhall VXR8	Body	SDM(Sensing and Diagnostic Module)	√	√	√	√		
2012	Vauxhall VXR8	Body	IPC (Instrument Panel Cluster)	√	√	√	√		
2012	Vauxhall VXR8	Body	RFA (Multipurpose Receiver Module)	√	√	√	√		
2012	Vauxhall VXR8	Chassis	Fuel Pump Control Module	√	√	√	√		
2012	Vauxhall VXR8	Chassis	EBCM(Electronic Brake Control Module)	√	√	√	√		
2012	Vauxhall VXR8	Chassis	ESC(Electronic Suspension Control)	√	√	√	√		
2012	Vauxhall VXR8	Engine	V8 GEN IV	√	√	√	√	√	SP0150
2012	Vauxhall VXR8	Transmission	Automatic Transmission	√	√	√	√	√	
2012	Vivaro	Body	Airbag		√	√	√		SP0004
2012	Vivaro	Body	Park Pilot		√	√	√		
2012	Vivaro	Body	Add On Heater	√	√	√	√	√	SP0122,SP0123
2012	Vivaro	Body	Body Control Module		√	√	√	√	
2012	Vivaro	Body	Airbag		√	√	√		SP0004
2012	Vivaro	Transmission	MTA(Tecshift)		√	√	√	√	
2012	Zafira-B	Body	AHL/AFL (Headlamp Levelling)	√	√	√	√		
2012	Zafira-B	Body	Exterior Lighting/Turn Indicator System	√	√	√	√		
2012	Zafira-B	Body	Interior Lighting	√	√	√	√		
2012	Zafira-B	Body	Wipers/Washer	√	√	√	√		
2012	Zafira-B	Body	Central Door Lock	√	√	√	√		
2012	Zafira-B	Body	Instrument	√	√	√	√		
2012	Zafira-B	Body	Immobiliser	√	√	√	√		
2012	Zafira-B	Body	CIM (Steering Column Module)	√	√	√	√	√	
2012	Zafira-B	Body	ECC/SAC (Electronic Climate Control)	√	√	√	√		
2012	Zafira-B	Body	EHS (Electrical Heater System)	√	√	√	√		
2012	Zafira-B	Body	PAS (Park Pilot)	√	√	√	√		
2012	Zafira-B	Body	SDM (Airbag)	√	√	√	√		SP0000,SP0001,SP0002
2012	Zafira-B	Body	SLM (Shift Lever Module)	√	√	√	√		
2012	Zafira-B	Body	UEC (Underhood Electrical Centre)	√	√	√	√		
2012	Zafira-B	Body	REC (Rear Electrical Centre)	√	√	√	√		
2012	Zafira-B	Body	PEPS (Open&Start)	√	√	√	√		
2012	Zafira-B	Body	IPC ECU (Instrument Control Unit)	√	√	√	√	√	SP0006,SP0055,SP0056,SP0057,SP0058,SP0059,SP0060,SP0001,SP0004
2012	Zafira-B	Body	Anti Theft Warning System	√	√	√	√		
2012	Zafira-B	Body	CIM(Steering Column Module)	√	√	√	√	√	SP0051,SP0003,SP0052,SP0001,SP0004,SP0053,SP0054,SP0005
2012	Zafira-B	Chassis	ABS/TC/ESP (Vehicle Dynamic System)	√	√	√	√	√	SP0005
2012	Zafira-B	Chassis	TPMS ECU (Tyre Pressure Monitoring)	√	√	√	√		

2012	Zafira-B	Chassis	TPMS (Tyre Pressure Monitoring System)	√	√	√	√		
2012	Zafira-B	Chassis	EHPS (Electrohydraulic Power Steering)	√	√	√	√		SP0003
2012	Zafira-B	Chassis	ABS/TC/ESP ECU(Electronic Control Unit)	√	√	√	√	√	
2012	Zafira-B	Chassis	CDC (Continuous Damping Control)	√	√	√	√		
2012	Zafira-B	Engine	Z16XE1	√	√	√	√	√	SP0033,SP0018
2012	Zafira-B	Engine	Z16XEP	√	√	√	√		SP0006,SP0007,SP0008,SP0009,SP0019,S P0010,SP0011,SP0066,SP0012,SP0013,SP 0033,SP0018
2012	Zafira-B	Engine	Z16XER	√	√	√	√		SP0019,SP0006,SP0007,SP0008,SP0009,S P0010,SP0011,SP0066,SP0033,SP0012,SP
2012	Zafira-B	Engine	Z16YNG	√	√	√	√	√	SP0033,SP0018
2012	Zafira-B	Engine	A16XER	√	√	√	√	√	SP0009,SP0019,SP0033,SP0018
2012	Zafira-B	Engine	Z17DTJ	√	√	√	√	√	SP0019,SP0025,SP0027,SP0020,SP0018
2012	Zafira-B	Engine	A17DTJ	√	√	√	√	√	SP0124,SP0006,SP0007,SP0008,SP0019,S P0025,SP0027,SP0018
2012	Zafira-B	Engine	A17DTR	√	√	√	√	√	SP0006,SP0007,SP0008,SP0019,SP0025,S P0027,SP0018
2012	Zafira-B	Engine	Z18XER	√	√	√	√		SP0019,SP0006,SP0007,SP0008,SP0009,S P0010,SP0011,SP0066,SP0033,SP0012,SP
2012	Zafira-B	Engine	A18XER	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0019,S P0033,SP0018
2012	Zafira-B	Engine	Z19DT	√	√	√	√	√	SP0006,SP0007,SP0008,SP0010,SP0011,S P0066,SP0023,SP0024,SP0069,SP0012,SP 0032,SP0020,SP0029,SP0026,SP0027,SP0 025,SP0028,SP0018
2012	Zafira-B	Engine	Z19DTH	√	√	√	√	√	SP0006,SP0007,SP0008,SP0032,SP0010,S P0011,SP0066,SP0023,SP0024,SP0028,SP 0025,SP0026,SP0027
2012	Zafira-B	Engine	Z20LEH	√	√	√	√	√	SP0018
2012	Zafira-B	Engine	Z20LER	√	√	√	√	√	SP0018
2012	Zafira-B	Engine	Z22YH	√	√	√	√	√	SP0018
2012	Zafira-B	Engine	Engine(default)	√	√	√			
2012	Zafira-B	Transmission	AF 40-6	√	√	√	√	√	SP0072,SP0073,SP0075,SP0076,SP0077,S P0032,SP0033,SP0078
2012	Zafira-B	Transmission	MTA(Easytronic)	√	√	√	√	√	SP0034,SP0035
2012	Zafira-B	Transmission	AF 22-4	√	√	√	√	√	SP0032,SP0033

2011	Antara Captive(Short Body)		Engine Control Module	√	√	√	√	√	SP0048,SP0017,SP0018,SP0084,SP0016,S P0571,SP0019,SP0091
2011	Antara Captive(Short Body)		Fuel Pump Control Module	√	√	√	√	√	SP0016
2011	Antara Captive(Short Body)		Transmission Control Module	√	√	√	√	√	
2011	Antara Captive(Short Body)		Rear Differential Clutch Control Module	√	√	√	√	√	SP0328
2011	Antara Captive(Short Body)		Electronic Brake Control Module	√	√	√	√	√	SP0083,SP0086
2011	Antara Captive(Short Body)		Parking Brake Control Module	√	√	√	√	√	SP0109
2011	Antara Captive(Short Body)		Variable Power Steering Control Module	√	√	√		√	
2011	Antara Captive(Short Body)		Body Control Module	√	√	√	√	√	SP0048,SP0442
2011	Antara Captive(Short Body)		Auxiliary Body Control Module	√	√	√	√	√	SP0236
2011	Antara Captive(Short Body)		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	SP0442
2011	Antara Captive(Short Body)		Instrument Cluster	√	√	√	√	√	
2011	Antara Captive(Short Body)		Headlamp Control Module	√	√	√	√	√	SP0366

2011	Antara Captive(Short Body)		Radio	√	√	√	√	√	SP0344,SP0583
2011	Antara Captive(Short Body)		Mobile Telephone Control Module	√	√	√	√	√	SP0040
2011	Antara Captive(Short Body)		HVAC Control Module	√	√	√		√	
2011	Antara Captive(Short Body)		Info Display Module	√	√	√			SP0344
2011	Antara Captive(Short Body)		Remote Control Door Lock Receiver	√	√	√	√	√	SP0374,SP0413,SP0335,SP0336,SP0337,S P0338,SP0332,SP0334,SP0403
2011	Antara Captive(Short Body)		Parking Assist Control Module	√	√	√	√	√	
2011	Antara Captive(Short Body)		Theft Deterrent Module	√	√	√	√		
2011	Astra-J		Engine Control Module	√	√	√	√	√	SP0313,SP0306
2011	Astra-J		Fuel Injector Control Module	√			√	√	
2011	Astra-J		Fuel Pump Control Module	√	√	√	√	√	SP0016
2011	Astra-J		Transmission Control Module	√	√	√	√	√	SP0223,SP0122
2011	Astra-J		Electronic Brake Control Module	√	√	√	√	√	SP0394,SP0083,SP0086
2011	Astra-J		Parking Brake Control Module	√	√	√	√	√	SP0109
2011	Astra-J		Multi-Axis Acceleration Sensor Module	√	√	√			SP0350
2011	Astra-J		Power Steering Control Module	√	√	√	√		SP0090
2011	Astra-J		Steering Wheel Angle Sensor Module	√	√	√			
2011	Astra-J		Suspension Control Module	√	√	√	√	√	
2011	Astra-J		Body Control Module	√	√	√	√	√	SP0047,SP0048,SP0045,SP0378,SP0372,S P0376,SP0046,SP0334,SP0332
2011	Astra-J		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	SP0311
2011	Astra-J		Instrument Cluster	√	√	√	√	√	SP0040
2011	Astra-J		Chime Alarm Control Module	√	√	√		√	
2011	Astra-J		Headlamp Control Module	√	√	√	√	√	SP0366
2011	Astra-J		Trailer Interface Control Module	√	√	√	√	√	SP0040

2011	Astra-J		Radio	√	√	√	√	√	
2011	Astra-J		Digital Radio Receiver Control Module	√	√	√	√	√	
2011	Astra-J		Multimedia Player Interface Module	√	√	√	√		
2011	Astra-J		Mobile Telephone Control Module	√	√	√	√	√	
2011	Astra-J		Remote Heater and Air Conditioning Control Module	√	√	√	√	√	SP0211,SP0040
2011	Astra-J		Front Seat Heating Control Module	√	√	√	√	√	
2011	Astra-J		Parking Assist Control Module	√	√	√	√	√	SP0040
2011	Astra-J		Vehicle Direction Camera Control Module	√	√	√	√	√	
2011	Insignia		Engine Control Module	√	√	√	√	√	SP0084,SP0018,SP0016
2011	Insignia		Fuel Injector Control Module	√			√	√	
2011	Insignia		Fuel Pump Control Module	√	√	√	√	√	SP0016
2011	Insignia		Transmission Control Module	√	√	√	√	√	SP0223,SP0122
2011	Insignia		Rear Differential Clutch Control Module	√	√	√	√	√	
2011	Insignia		Electronic Brake Control Module	√	√	√	√	√	SP0394,SP0083,SP0086
2011	Insignia		Parking Brake Control Module	√	√	√	√	√	SP0109
2011	Insignia		Multi-Axis Acceleration Sensor Module	√	√	√			SP0350
2011	Insignia		Power Steering Control Module	√	√	√	√		SP0090
2011	Insignia		Steering Wheel Angle Sensor Module	√	√	√			
2011	Insignia		Suspension Control Module	√	√	√	√	√	
2011	Insignia		Body Control Module	√	√	√	√	√	SP0047,SP0048,SP0045,SP0378,SP0372,S P0376,SP0046,SP0334,SP0332
2011	Insignia		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	SP0311
2011	Insignia		Instrument Cluster	√	√	√	√	√	SP0040
2011	Insignia		Chime Alarm Control Module	√	√	√		√	
2011	Insignia		Headlamp Control Module	√	√	√	√	√	SP0366
2011	Insignia		Trailer Interface Control Module	√	√	√	√	√	SP0040
2011	Insignia		Radio	√	√	√	√	√	
2011	Insignia		Digital Radio Receiver Control Module	√	√	√	√	√	
2011	Insignia		Multimedia Player Interface Module	√	√	√	√		SP0040
2011	Insignia		Mobile Telephone Control Module	√	√	√	√	√	
2011	Insignia		Remote Heater and Air Conditioning Control Module	√	√	√	√	√	SP0211,SP0040
2011	Insignia		Liftgate Control Module	√	√	√	√	√	SP0323
2011	Insignia		Seat Memory Control Module	√	√	√	√	√	SP0581
2011	Insignia		Front Seat Heating Control Module	√	√	√	√	√	
2011	Insignia		Parking Assist Control Module	√	√	√	√	√	SP0040
2011	Insignia		Vehicle Direction Camera Control Module	√	√	√	√	√	
2011	Insignia		Distance Sensing Cruise Control Module	√	√	√	√		SP0231
2011	Agila-B	Body	BCM (Body Control Module)		√	√	√	√	

2011	Agila-B	Body	Immobiliser		√	√	√		
2011	Agila-B	Body	SDM (Airbag)		√	√	√		
2011	Agila-B	Chassis	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)	√	√	√	√		SP0005
2011	Agila-B	Chassis	Electronic Power Steering		√	√	√		
2011	Agila-B	Engine	K10B	√	√	√	√	√	SP0015
2011	Agila-B	Engine	K12B	√	√	√	√	√	SP0015
2011	Agila-B	Engine	D13A / Z 13 DTJ	√	√	√	√	√	SP0040,SP0019,SP0011,SP0021,SP0020,S P0018,SP0028,SP0025,SP0041,SP0042
2011	Agila-B	Transmission	TCM (Transmission Control Module)	√	√	√	√		SP0033
2011	Astra-G	Body	Instrument	√	√	√	√		
2011	Astra-G	Chassis	Electronic Power Steering	√	√	√	√	√	
2011	Astra-G	Engine	Z 12 XE	√	√	√	√	√	SP0006,SP0145,SP0009,SP0040,SP0019,S P0021,SP0011,SP0065,SP0033
2011	Astra-G	Transmission	AF 13-II/17/20/22	√	√	√	√	√	
2011	Astra-H	Body	AHL/AFL (Headlamp Levelling)	√	√	√	√		
2011	Astra-H	Body	Exterior Lighting/Turn Indicator System	√	√	√	√		
2011	Astra-H	Body	Interior Lighting	√	√	√	√		
2011	Astra-H	Body	Wipers/Washer	√	√	√	√		
2011	Astra-H	Body	Central Door Lock	√	√	√	√		
2011	Astra-H	Body	Instrument	√	√	√	√	√	SP0055,SP0056,SP0057
2011	Astra-H	Body	Immobiliser	√	√	√	√		
2011	Astra-H	Body	CIM (Steering Column Module)	√	√	√	√	√	SP0051,SP0003,SP0052,SP0001,SP0004,S P0053,SP0054,SP0005
2011	Astra-H	Body	Anti Theft Warning System	√	√	√	√	√	
2011	Astra-H	Body	Electrohydraulic HardTop	√	√	√	√	√	SP0001,SP0004
2011	Astra-H	Body	ECC/SAC (Electronic Climate Control)	√	√	√	√	√	SP0150,SP0159,SP0160,SP0032,SP0001,S P0004,SP0161
2011	Astra-H	Body	IPC ECU (Instrument Control Unit)	√	√	√	√	√	SP0006,SP0055,SP0056,SP0057,SP0058,S P0059,SP0060,SP0001,SP0004
2011	Astra-H	Body	EHS (Electrical Heater System)	√	√	√	√		SP0032,SP0001,SP0004
2011	Astra-H	Body	PAS (Park Pilot)	√	√	√	√	√	SP0001
2011	Astra-H	Body	SDM (Airbag)	√	√	√	√		SP0000,SP0001,SP0002
2011	Astra-H	Body	SLM (Shift Lever Module)	√	√	√	√		
2011	Astra-H	Body	UEC (Underhood Electrical Centre)	√	√	√	√		
2011	Astra-H	Body	REC (Rear Electrical Centre)	√	√	√	√		
2011	Astra-H	Body	PEPS (Open&Start)	√	√	√	√		
2011	Astra-H	Chassis	TPMS ECT(Tyre Pressure Monitoring)	√	√	√	√		

2011	Astra-H	Chassis	TPMS (Tyre Pressure Monitoring System)	√	√	√	√		
2011	Astra-H	Chassis	EHPS (Electrohydraulic Power Steering)	√	√	√	√		SP0003
2011	Astra-H	Chassis	ABS/TC/ESP ECU(Electronic Control Unit)	√	√	√	√	√	
2011	Astra-H	Chassis	CDC (Continuous Damping Control)	√	√	√	√		
2011	Astra-H	Chassis	ABS/TC/ESP (Vehicle Dynamic System)	√	√	√	√	√	
2011	Astra-H	Chassis	TPMS ECU(Tyre Pressure Monitoring)	√	√	√	√		SP0001
2011	Astra-H	Engine	A16XER	√	√	√	√	√	SP0019,SP0009,SP0063,SP0067,SP0064,SP0033,SP0012,SP0006,SP0007,SP0008,SP
2011	Astra-H	Engine	A16LET	√	√	√	√	√	SP0009,SP0063,SP0011,SP0064,SP0012,SP0065,SP0006,SP0007,SP0008,SP0018
2011	Astra-H	Engine	A17DTJ	√	√	√	√	√	SP0019,SP0063,SP0011,SP0064,SP0014,SP0022,SP0023,SP0024,SP0012,SP0028,SP0025,SP0069,SP0026,SP0070,SP0006,SP0007,SP0008,SP0027,SP0018
2011	Astra-H	Engine	A17DTR	√	√	√	√	√	SP0019,SP0063,SP0011,SP0064,SP0014,SP0022,SP0023,SP0024,SP0012,SP0028,SP0025,SP0069,SP0026,SP0070,SP0006,SP0007,SP0008,SP0027,SP0018
2011	Astra-H	Engine	Y13DTH	√	√	√	√	√	SP0009,SP0063,SP0011,SP0064,SP0012,SP0065,SP0006,SP0007,SP0008,SP0018
2011	Astra-H	Engine	Z12XEP	√	√	√	√	√	SP0009,SP0063,SP0011,SP0064,SP0012,SP0065,SP0006,SP0007,SP0008,SP0018
2011	Astra-H	Engine	Z13DTH	√	√	√	√	√	SP0006,SP0007,SP0008,SP0019,SP0010,SP0011,SP0066,SP0020,SP0029,SP0028,SP0025,SP0026,SP0018
2011	Astra-H	Engine	Z14XEP	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,SP0011,SP0066,SP0012,SP0013,SP0018
2011	Astra-H	Engine	Z14XEL	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,SP0011,SP0066,SP0012,SP0013,SP0018
2011	Astra-H	Engine	Z16LET	√	√	√	√	√	SP0009,SP0063,SP0011,SP0064,SP0012,SP0065,SP0006,SP0007,SP0008,SP0018
2011	Astra-H	Engine	Z16XE1	√	√	√	√	√	SP0019,SP0009,SP0063,SP0067,SP0064,SP0012,SP0065,SP0068,SP0006,SP0007,SP0008,SP0018
2011	Astra-H	Engine	Z16XEP	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0019,SP0010,SP0011,SP0066,SP0012,SP0013,SP0033,SP0018

2011	Astra-H	Engine	Z17DTH	√	√	√	√	√	SP0006,SP0007,SP0008,SP0010,SP0011,S P0066,SP0020,SP0024,SP0012,SP0029,SP 0032,SP0018
2011	Astra-H	Engine	Z17DTL	√	√	√	√	√	SP0063,SP0011,SP0064,SP0020,SP0024,S P0012,SP0029,SP0032,SP0018
2011	Astra-H	Engine	Z18XE	√	√	√	√	√	SP0019,SP0006,SP0007,SP0008,SP0009,S P0010,SP0011,SP0066,SP0012,SP0018
2011	Astra-H	Engine	Z18XER	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0019,S P0010,SP0011,SP0066,SP0033,SP0012,SP
2011	Astra-H	Engine	Z19DT	√	√	√	√	√	SP0006,SP0007,SP0008,SP0010,SP0011,S P0066,SP0023,SP0024,SP0069,SP0012,SP 0032,SP0020,SP0029,SP0026,SP0027,SP0 025,SP0028,SP0018
2011	Astra-H	Engine	Z19DTH	√	√	√	√	√	SP0006,SP0007,SP0008,SP0010,SP0011,S P0066,SP0023,SP0024,SP0069,SP0012,SP 0032,SP0020,SP0029,SP0026,SP0027,SP0 025,SP0028,SP0018
2011	Astra-H	Engine	Z20LEH	√	√	√	√	√	SP0009,SP0063,SP0011,SP0064,SP0012,S P0065,SP0006,SP0007,SP0008,SP0018
2011	Astra-H	Engine	Z20LEL	√	√	√	√	√	SP0009,SP0063,SP0011,SP0064,SP0012,S P0065,SP0006,SP0007,SP0008,SP0018
2011	Astra-H	Engine	Z20LER	√	√	√	√	√	SP0009,SP0063,SP0011,SP0064,SP0012,S P0065,SP0006,SP0007,SP0008,SP0018
2011	Astra-H	Engine	Z22YH	√	√	√	√	√	SP0006,SP0007,SP0008,SP0071,SP0019,S P0010,SP0011,SP0066,SP0012,SP0018
2011	Astra-H	Engine	Engine(default)	√	√	√			
2011	Astra-H	Engine	Z 16 XER	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0019,S P0010,SP0011,SP0066,SP0033,SP0012,SP
2011	Astra-H	Engine	Z 17 DTJ	√	√	√	√	√	SP0006,SP0007,SP0008,SP0019,SP0010,S P0011,SP0066,SP0014,SP0022,SP0023,SP 0024,SP0012,SP0025,SP0026,SP0027,SP0 028,SP0029,SP0020,SP0018
2011	Astra-H	Engine	Z 17 DTR	√	√	√	√	√	SP0006,SP0007,SP0008,SP0019,SP0010,S P0011,SP0066,SP0014,SP0022,SP0023,SP 0024,SP0012,SP0025,SP0026,SP0027,SP0 028,SP0029,SP0020,SP0018
2011	Astra-H	Engine	A 18 XER	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0019,S P0010,SP0011,SP0066,SP0033,SP0018

2011	Astra-H	Transmission	AF 40-6	√	√	√	√	√	SP0072,SP0073,SP0074,SP0075,SP0076,SP0077,SP0032,SP0003,SP0033,SP0078
2011	Astra-H	Transmission	AF 17-4	√	√	√	√	√	SP0032,SP0079,SP0033,SP0030,SP0031
2011	Astra-H	Transmission	AF 22-4	√	√	√	√	√	SP0032,SP0079,SP0033,SP0030
2011	Astra-H	Transmission	MTA(Easytronic)	√	√	√	√	√	SP0079,SP0034,SP0035,SP0061
2011	Astra-H	Transmission	MTA(Easytronic Magneti Marelli)	√	√	√	√	√	SP0079,SP0004,SP0061
2011	Meriva-B	Body	Front Seat Heating Control Module	√	√	√	√		
2011	Meriva-B	Body	BCM (Body Control Module)	√	√	√	√		
2011	Meriva-B	Body	Headlamp Control Module	√	√	√	√		
2011	Meriva-B	Body	Inflatable Restraint Sensing&Diag.Module	√	√	√	√		
2011	Meriva-B	Body	Parking Assist Control Module	√	√	√	√	√	SP0107,SP0039
2011	Meriva-B	Body	Remote Heater & A/C Control Module	√	√	√	√		
2011	Meriva-B	Body	Instrument	√	√	√	√	√	SP0039
2011	Meriva-B	Body	Trailer Interface Control Module	√	√	√	√		
2011	Meriva-B	Chassis	Electronic Brake Control Module	√	√	√	√	√	
2011	Meriva-B	Chassis	Electric Power Steering Control Module	√	√	√	√		
2011	Meriva-B	Chassis	Parking Brake Control Module	√	√	√	√	√	SP0108,SP0109
2011	Meriva-B	Chassis	Steering Wheel Angle Sensor Module	√	√	√			SP0081
2011	Meriva-B	Chassis	Fuel injector control module	√			√		
2011	Meriva-B	Engine	A 13 DTC 1.3(LDV)	√	√	√	√	√	SP0083,SP0110,SP0111,SP0023,SP0024,SP0028,SP0025,SP0069,SP0112,SP0113,SP0114,SP0115,SP0116,SP0117
2011	Meriva-B	Engine	A 13 DTE 1.3(LSF)	√	√	√	√	√	SP0083,SP0118,SP0111,SP0023,SP0024,SP0028,SP0025,SP0069,SP0112,SP0113,SP0114,SP0115,SP0116,SP0119,SP0018
2011	Meriva-B	Engine	A 14 NET(LUH)	√	√	√	√	√	SP0083,SP0162,SP0163,SP0015,SP0018,SP0083
2011	Meriva-B	Engine	A 14 NET (LUJ)	√	√	√	√	√	SP0091,SP0083,SP0016,SP0017,SP0015,SP0018
2011	Meriva-B	Engine	A 14 XER (LDD)	√	√	√	√	√	SP0091,SP0083,SP0016,SP0017,SP0015,SP0018
2011	Meriva-B	Engine	A 17 DTC 1.7(LUE)	√	√	√	√	√	SP0120,SP0103,SP0083,SP0118,SP0084,SP0018,SP0164,SP0128
2011	Meriva-B	Engine	A 17 DTS 1.7(LUD)	√	√	√	√	√	SP0120,SP0103,SP0083,SP0118,SP0084,SP0018,SP0163,SP0128
2011	Meriva-B	Engine	Engine Control Module	√	√	√	√	√	SP0083,SP0118,SP0111,SP0023,SP0024,SP0028,SP0025,SP0069,SP0112,SP0113,SP0114,SP0115,SP0116,SP0119,SP0018

2011	Meriva-B	Transmission	Transmission Control Module	√	√	√	√	√	SP0078,SP0121
2011	Astra-G	Body	Add On Heater	√	√	√	√	√	SP0122,SP0123
2011	Astra-G	Body	Airbag	√	√	√	√		
2011	Astra-G	Body	Anti Theft Warning	√	√	√	√		
2011	Astra-G	Body	Central Door Lock	√	√	√	√		
2011	Astra-G	Body	Engine Cooling Module	√	√	√	√		
2011	Astra-G	Body	Electronic Climate Control	√	√	√	√		
2011	Astra-G	Body	HeadLamp Levelling Device	√	√	√	√	√	SP0141
2011	Astra-G	Body	Immobiliser	√	√	√	√		SP0165,SP0166
2011	Astra-G	Body	Instrument	√	√	√	√		
2011	Astra-G	Body	Softtop Controller	√	√	√	√	√	
2011	Astra-G	Chassis	ABS-5.3/5.4 (+TC) (Anti-lock Braking System)	√	√	√	√	√	
2011	Astra-G	Chassis	Electronic Power Steering	√	√	√	√	√	
2011	Astra-G	Chassis	ESP (Electronic Stability Program)	√	√	√	√	√	SP0005
2011	Astra-G	Engine	Z 14 XE	√			√	√	SP0146,SP0145,SP0009,SP0019,SP0021,S P0011
2011	Astra-G	Engine	Z 14 XEP	√	√	√	√	√	SP0006,SP0167,SP0009,SP0146,SP0019,S P0011,SP0021,SP0065,SP0033
2011	Astra-G	Engine	C 16 SEL	√	√	√	√	√	
2011	Astra-G	Engine	Z 16 XE	√			√	√	
2011	Astra-G	Engine	Z 16 SE	√	√	√	√	√	
2011	Astra-G	Engine	Z 16 XEP	√	√	√	√	√	SP0006,SP0146,SP0009,SP0019,SP0011,S P0021,SP0065
2011	Astra-G	Engine	Z 16 YNG	√	√	√	√	√	SP0006,SP0146,SP0145,SP0009,SP0019,S P0011,SP0021
2011	Astra-G	Engine	Y 17 DT	√	√	√	√	√	
2011	Astra-G	Engine	Z 17 DTL	√	√	√	√	√	
2011	Astra-G	Engine	Z 18 XE	√	√	√	√	√	SP0145,SP0009,SP0040,SP0019,SP0011,S P0021
2011	Astra-G	Engine	Z 18 XEL	√	√	√			SP0011,SP0021
2011	Astra-G	Engine	Y 20 DTH	√	√	√	√	√	SP0166,SP0168,SP0169,SP0170
2011	Astra-G	Engine	Z 20 LET	√	√	√	√	√	SP0009,SP0019,SP0040,SP0145,SP0011,S P0021,SP0065,SP0033
2011	Astra-G	Engine	Y 22 DTR	√	√	√	√	√	SP0011,SP0021
2011	Astra-G	Engine	Z 22 SE	√	√	√	√	√	SP0146,SP0009,SP0145,SP0011,SP0021,S P0065,SP0033
2011	Astra-G	Transmission	AF 13-II/17/20/22 CAN	√	√	√	√	√	

2011	Captiva(Long Body)	Body	BCM (Body Control Module)	√	√	√	√	√	
2011	Captiva(Long Body)	Body	ECC (Electronic Climate Control)	√	√	√		√	SP0150,SP0004
2011	Captiva(Long Body)	Body	Immobiliser	√	√	√	√		
2011	Captiva(Long Body)	Body	IPC ECU (Instrument Control Unit)	√	√	√	√	√	
2011	Captiva(Long Body)	Body	XBCM(Auxiliary Body Control Module)	√	√	√	√	√	
2011	Captiva(Long Body)	Body	RFA (Multipurpose Receiver Module)	√	√	√	√		
2011	Captiva(Long Body)	Chassis	ABS/TC/ESP (Vehicle Dynamic System)	√	√	√	√	√	
2011	Captiva(Long Body)	Engine	2.0 L (Diesel)	√	√	√	√	√	SP0010,SP0011,SP0066,SP0020,SP0024,SP0012,SP0028,SP0025,SP0027,SP0029,SP
2011	Captiva(Long Body)	Engine	Z32SE	√	√	√	√	√	
2011	Captiva(Long Body)	Transmission	TCCM(Transfer Case Control Module)	√	√	√	√		SP0152
2011	Captiva(Long Body)	Transmission	Automatic Transmission	√	√	√	√	√	SP0171,SP0154,SP0155,SP0156,SP0033
2011	Corsa-C	Body	Add On Heater	√	√	√	√	√	SP0122,SP0123
2011	Corsa-C	Body	Airbag	√	√	√	√	√	
2011	Corsa-C	Body	Body Control Module	√	√	√	√	√	SP0051,SP0058,SP0138
2011	Corsa-C	Body	Instrument	√	√	√	√		
2011	Corsa-C	Body	Immobiliser	√	√	√	√		SP0164,SP0165
2011	Corsa-C	Chassis	ABS8/ESP8 (Anti-lock Braking System/Electronic Stability Program)		√	√	√	√	SP0005,SP0142,SP0143,SP0144,SP0004
2011	Corsa-C	Chassis	ABS-5.3/5.4 (+TC) (Anti-lock Braking System)	√	√	√	√	√	
2011	Corsa-C	Chassis	Electronic Power Steering	√	√	√	√		SP0141
2011	Corsa-C	Engine	Z 10 XEP	√	√	√	√	√	SP0011,SP0021,SP0065,SP0033
2011	Corsa-C	Engine	Z 12 XE	√	√	√	√	√	SP0006,SP0145,SP0009,SP0040,SP0019,SP0021,SP0011,SP0065,SP0033
2011	Corsa-C	Engine	Z 12 XEP	√	√	√	√	√	SP0011,SP0021,SP0065,SP0033
2011	Corsa-C	Engine	Y 13 DT	√	√	√	√	√	SP0040,SP0019,SP0021,SP0011,SP0020
2011	Corsa-C	Engine	Z 13 DT	√	√	√	√	√	SP0040,SP0019,SP0021,SP0011,SP0020

2011	Corsa-C	Engine	Z 13 DTJ	√	√	√	√	√	SP0040,SP0019,SP0028,SP0025,SP0041,S P0021,SP0011,SP0020,SP0042
2011	Corsa-C	Engine	Z 14 XE	√			√	√	SP0146,SP0145,SP0009,SP0019,SP0021,S P0011
2011	Corsa-C	Engine	Z 14 XEP	√	√	√	√	√	SP0006,SP0166,SP0009,SP0146,SP0019,S P0011,SP0021,SP0065,SP0033
2011	Corsa-C	Engine	Z 16 SE	√	√	√	√	√	
2011	Corsa-C	Engine	Z 16 YNG	√	√	√	√	√	SP0006,SP0146,SP0145,SP0009,SP0019,S P0011,SP0021
2011	Corsa-C	Engine	Y 17 DT	√	√	√	√	√	
2011	Corsa-C	Engine	Y 17 DTL	√	√	√	√	√	
2011	Corsa-C	Engine	Z 17 DTH		√	√	√		
2011	Corsa-C	Engine	Z 18 XE	√	√	√	√	√	SP0145,SP0009,SP0040,SP0019,SP0011,S P0021
2011	Corsa-C	Transmission	AF 13-II/17/20/22 CAN	√	√	√	√	√	
2011	Corsa-C	Transmission	Easytronic(MTA)	√	√	√	√	√	SP0011,SP0148
2011	Corsa-D	Body	Exterior Lighting	√	√	√	√		
2011	Corsa-D	Body	Interior Lighting	√	√	√	√		
2011	Corsa-D	Body	Wipers/Washer	√	√	√	√		
2011	Corsa-D	Body	Heating,Ventilation and Air Cond.	√	√	√	√		
2011	Corsa-D	Body	Anti Theft Warning System	√	√	√	√		
2011	Corsa-D	Body	Central Door Lock	√	√	√	√	√	
2011	Corsa-D	Body	Immobiliser	√	√	√	√		
2011	Corsa-D	Body	AFL (Adaptive Forward Lighting)	√	√	√	√		
2011	Corsa-D	Body	EHS (Electrical Heater System)	√	√	√	√		
2011	Corsa-D	Body	IPC ECU (Instrument Control Unit)	√	√	√	√		
2011	Corsa-D	Body	PAS (Park Pilot)	√	√	√	√		
2011	Corsa-D	Body	SDM (Airbag)	√	√	√	√		SP0000,SP0001,SP0002
2011	Corsa-D	Body	TIM(Trailer Interface Module)	√	√	√	√		
2011	Corsa-D	Body	BCM (Body Control Module)	√	√	√	√		
2011	Corsa-D	Chassis	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)	√	√	√	√	√	
2011	Corsa-D	Chassis	Electronic Power Steering	√	√	√	√		
2011	Corsa-D	Chassis	Fuel injector control module	√			√		
2011	Corsa-D	Engine	Z10XEP	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,S P0011,SP0012,SP0013,SP0014
2011	Corsa-D	Engine	A10XEP	√	√	√	√	√	SP0006,SP0015,SP0016,SP0017,SP0018

2011	Corsa-D	Engine	Z12XEP	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,SP0011,SP0012,SP0013,SP0014
2011	Corsa-D	Engine	A12XER	√	√	√	√	√	SP0006,SP0018
2011	Corsa-D	Engine	A12XEL	√	√	√	√	√	SP0006,SP0018
2011	Corsa-D	Engine	Z13DTH	√	√	√	√	√	SP0019,SP0010,SP0011,SP0014,SP0020
2011	Corsa-D	Engine	Z13DTE	√	√	√	√	√	SP0006
2011	Corsa-D	Engine	Z13DTJ	√	√	√	√	√	SP0019,SP0010,SP0011,SP0014,SP0020
2011	Corsa-D	Engine	A13DTC	√	√	√	√	√	SP0019
2011	Corsa-D	Engine	Z14XEP	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,SP0011,SP0012,SP0013,SP0014
2011	Corsa-D	Engine	A14XEL	√	√	√	√	√	SP0006,SP0015,SP0016,SP0017,SP0018
2011	Corsa-D	Engine	A14XER	√	√	√	√	√	SP0006,SP0015,SP0016,SP0017,SP0018
2011	Corsa-D	Engine	Z16LEL	√	√	√	√	√	
2011	Corsa-D	Engine	Z16LER	√	√	√	√	√	
2011	Corsa-D	Engine	A16LEL	√	√	√	√	√	
2011	Corsa-D	Engine	A16LER	√	√	√	√	√	
2011	Corsa-D	Engine	Z17DTR	√	√	√	√	√	SP0019,SP0021,SP0011,SP0014,SP0022,SP0023,SP0024,SP0012,SP0025,SP0026,SP0027,SP0028,SP0020,SP0029
2011	Corsa-D	Transmission	MTA(Easytronic Magneti Marelli)	√	√	√	√	√	
2011	Corsa-D	Transmission	AF 13-4	√	√	√	√	√	SP0030,SP0031,SP0032,SP0033
2011	Corsa-D	Transmission	MTA(Easytronic)	√	√	√	√	√	SP0034,SP0035
2011	Vauxhall VXR8	Body	AHL(Automatic Headlamp Levelling)	√	√	√	√		
2011	Vauxhall VXR8	Body	BCM (Body Control Module)	√	√	√	√		
2011	Vauxhall VXR8	Body	HVAC(Heating Ventilation and Cooling)	√	√	√	√		
2011	Vauxhall VXR8	Body	Immobiliser	√	√	√	√		
2011	Vauxhall VXR8	Body	MSM(Memory Seat and Mirrors)	√	√	√	√		
2011	Vauxhall VXR8	Body	Park Assist	√	√	√	√		
2011	Vauxhall VXR8	Body	SDM(Sensing and Diagnostic Module)	√	√	√	√		
2011	Vauxhall VXR8	Body	IPC (Instrument Panel Cluster)	√	√	√	√		
2011	Vauxhall VXR8	Body	RFA (Multipurpose Receiver Module)	√	√	√	√		
2011	Vauxhall VXR8	Chassis	Fuel Pump Control Module	√	√	√	√		
2011	Vauxhall VXR8	Chassis	EBCM(Electronic Brake Control Module)	√	√	√	√	√	
2011	Vauxhall VXR8	Chassis	ESC(Electronic Suspension Control)	√	√	√	√		
2011	Vauxhall VXR8	Engine	V8 GEN IV	√	√	√	√	√	SP0015,SP0149,SP0172,SP0173
2011	Vauxhall VXR8	Transmission	Automatic Transmission	√	√	√	√	√	
2011	Vivaro	Body	Park Pilot		√	√	√		
2011	Vivaro	Body	Add On Heater	√	√	√	√	√	SP0122,SP0123

2011	Vivaro	Body	Airbag		√	√	√		SP0004
2011	Vivaro	Body	Body Control Module		√	√	√	√	
2011	Vivaro	Engine	F9Q 760/762 (1.9L)	√	√	√	√		
2011	Vivaro	Transmission	MTA(Tecshift)		√	√	√	√	
2011	Zafira-B	Body	AHL/AFL (Headlamp Levelling)	√	√	√	√		
2011	Zafira-B	Body	Exterior Lighting/Turn Indicator System	√	√	√	√		
2011	Zafira-B	Body	Interior Lighting	√	√	√	√		
2011	Zafira-B	Body	Wipers/Washer	√	√	√	√		
2011	Zafira-B	Body	Central Door Lock	√	√	√	√		
2011	Zafira-B	Body	Instrument	√	√	√	√	√	SP0055,SP0056,SP0057
2011	Zafira-B	Body	Immobiliser	√	√	√	√		
2011	Zafira-B	Body	CIM (Steering Column Module)	√	√	√	√	√	SP0051,SP0003,SP0052,SP0001,SP0004,S P0053,SP0054,SP0005
2011	Zafira-B	Body	ECC/SAC (Electronic Climate Control)	√	√	√	√	√	SP0150,SP0158,SP0159,SP0001,SP0004,S P0160
2011	Zafira-B	Body	EHS (Electrical Heater System)	√	√	√	√		SP0032,SP0001,SP0004
2011	Zafira-B	Body	PAS (Park Pilot)	√	√	√	√	√	SP0001
2011	Zafira-B	Body	SDM (Airbag)	√	√	√	√		SP0000,SP0001,SP0002
2011	Zafira-B	Body	SLM (Shift Lever Module)	√	√	√	√		
2011	Zafira-B	Body	UEC (Underhood Electrical Centre)	√	√	√	√		
2011	Zafira-B	Body	REC (Rear Electrical Centre)	√	√	√	√		
2011	Zafira-B	Body	PEPS (Open&Start)	√	√	√	√		
2011	Zafira-B	Body	IPC ECU (Instrument Control Unit)	√	√	√	√	√	SP0006,SP0055,SP0056,SP0057,SP0058,S P0059,SP0060,SP0001,SP0004
2011	Zafira-B	Body	Anti Theft Warning System	√	√	√	√	√	
2011	Zafira-B	Chassis	ABS/TC/ESP (Vehicle Dynamic System)	√	√	√	√	√	SP0005
2011	Zafira-B	Chassis	TPMS ECU (Tyre Pressure Monitoring)	√	√	√	√		SP0001
2011	Zafira-B	Chassis	TPMS (Tyre Pressure Monitoring System)	√	√	√	√		
2011	Zafira-B	Chassis	EHPS (Electrohydraulic Power Steering)	√	√	√	√		SP0003
2011	Zafira-B	Chassis	ABS/TC/ESP ECU(Electronic Control Unit)	√	√	√	√	√	
2011	Zafira-B	Chassis	CDC (Continuous Damping Control)	√	√	√	√		
2011	Zafira-B	Engine	Z 16 XE1	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0174,S P0010,SP0011,SP0066,SP0012,SP0013,SP 0033,SP0018
2011	Zafira-B	Engine	Z 16 XEP	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0019,S P0010,SP0011,SP0066,SP0012,SP0013,SP 0033,SP0018

2011	Zafira-B	Engine	Z 16 XER	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0019,S P0010,SP0011,SP0066,SP0033,SP0012,SP
2011	Zafira-B	Engine	Z 16 YNG	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0019,S P0010,SP0011,SP0066,SP0012,SP0013,SP 0033,SP0018
2011	Zafira-B	Engine	A 16 XER	√	√	√	√	√	SP0009,SP0019,SP0010,SP0011,SP0066,S P0033,SP0012,SP0018
2011	Zafira-B	Engine	Z 17 DTJ	√	√	√	√	√	SP0019,SP0010,SP0011,SP0066,SP0014,S P0022,SP0023,SP0024,SP0012,SP0025,SP 0026,SP0027,SP0028,SP0029,SP0020,SP0
2011	Zafira-B	Engine	A 17 DTJ	√	√	√	√	√	SP0006,SP0007,SP0008,SP0019,SP0010,S P0011,SP0066,SP0014,SP0022,SP0023,SP 0024,SP0012,SP0028,SP0025,SP0069,SP0 026,SP0070,SP0027,SP0018
2011	Zafira-B	Engine	A 17 DTR	√	√	√	√	√	SP0006,SP0007,SP0008,SP0019,SP0010,S P0011,SP0066,SP0014,SP0022,SP0023,SP 0024,SP0012,SP0028,SP0025,SP0069,SP0 026,SP0070,SP0027,SP0018
2011	Zafira-B	Engine	Z 18 XER	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0019,S P0010,SP0011,SP0066,SP0033,SP0012,SP
2011	Zafira-B	Engine	A 18 XER	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0019,S P0010,SP0011,SP0066,SP0033,SP0018
2011	Zafira-B	Engine	Z 19 DT	√	√	√	√	√	SP0006,SP0007,SP0008,SP0010,SP0011,S P0066,SP0023,SP0024,SP0069,SP0012,SP 0032,SP0020,SP0029,SP0026,SP0027,SP0 025,SP0028,SP0018
2011	Zafira-B	Engine	Z 19 DTH	√	√	√	√	√	SP0006,SP0007,SP0008,SP0032,SP0010,S P0011,SP0066,SP0023,SP0024,SP0028,SP 0025,SP0026,SP0027
2011	Zafira-B	Engine	Z 20 LEH	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,S P0011,SP0066,SP0012,SP0013,SP0018
2011	Zafira-B	Engine	Z 20 LER	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,S P0011,SP0066,SP0012,SP0013,SP0018
2011	Zafira-B	Engine	Z 22 YH	√	√	√	√	√	SP0006,SP0007,SP0008,SP0071,SP0019,S P0010,SP0011,SP0066,SP0012,SP0013,SP
2011	Zafira-B	Engine	Engine(default)	√	√	√			
2011	Zafira-B	Transmission	AF 40-6	√	√	√	√	√	SP0072,SP0073,SP0074,SP0075,SP0076,S P0077,SP0032,SP0003,SP0033,SP0078

2011	Zafira-B	Transmission	MTA(Easytronic)	√	√	√	√	√	SP0003,SP0061,SP0034,SP0035
2011	Zafira-B	Transmission	AF 22-4	√	√	√	√	√	SP0030,SP0032,SP0003,SP0033
2010	Astra-J		Engine Control Module	√	√	√	√	√	SP0313,SP0306
2010	Astra-J		Fuel Injector Control Module	√			√	√	
2010	Astra-J		Fuel Pump Control Module	√	√	√	√	√	SP0016
2010	Astra-J		Transmission Control Module	√	√	√	√	√	SP0223,SP0122
2010	Astra-J		Electronic Brake Control Module	√	√	√	√	√	SP0394,SP0083,SP0086
2010	Astra-J		Parking Brake Control Module	√	√	√	√	√	SP0109
2010	Astra-J		Multi-Axis Acceleration Sensor Module	√	√	√			SP0350
2010	Astra-J		Power Steering Control Module	√	√	√	√		SP0090
2010	Astra-J		Steering Wheel Angle Sensor Module	√	√	√			
2010	Astra-J		Suspension Control Module	√	√	√	√	√	
2010	Astra-J		Body Control Module	√	√	√	√	√	SP0047,SP0048,SP0045,SP0378,SP0372,S P0376,SP0046,SP0334,SP0332
2010	Astra-J		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	SP0311
2010	Astra-J		Instrument Cluster	√	√	√	√	√	SP0040
2010	Astra-J		Chime Alarm Control Module	√	√	√		√	
2010	Astra-J		Headlamp Control Module	√	√	√	√	√	SP0366
2010	Astra-J		Trailer Interface Control Module	√	√	√	√	√	SP0040
2010	Astra-J		Radio	√	√	√	√	√	
2010	Astra-J		Digital Radio Receiver Control Module	√	√	√	√	√	
2010	Astra-J		Multimedia Player Interface Module	√	√	√	√		
2010	Astra-J		Mobile Telephone Control Module	√	√	√	√	√	
2010	Astra-J		Remote Heater and Air Conditioning Control Module	√	√	√	√	√	SP0211,SP0040
2010	Astra-J		Front Seat Heating Control Module	√	√	√	√	√	
2010	Astra-J		Parking Assist Control Module	√	√	√	√	√	SP0040
2010	Astra-J		Vehicle Direction Camera Control Module	√	√	√	√	√	
2010	Insignia		Engine Control Module	√	√	√	√	√	SP0084,SP0018,SP0016
2010	Insignia		Fuel Injector Control Module	√			√	√	
2010	Insignia		Fuel Pump Control Module	√	√	√	√	√	SP0016
2010	Insignia		Transmission Control Module	√	√	√	√	√	SP0223,SP0122
2010	Insignia		Rear Differential Clutch Control Module	√	√	√	√	√	
2010	Insignia		Electronic Brake Control Module	√	√	√	√	√	SP0394,SP0083,SP0086
2010	Insignia		Parking Brake Control Module	√	√	√	√	√	SP0109
2010	Insignia		Multi-Axis Acceleration Sensor Module	√	√	√			SP0350
2010	Insignia		Power Steering Control Module	√	√	√	√		SP0090
2010	Insignia		Steering Wheel Angle Sensor Module	√	√	√			
2010	Insignia		Suspension Control Module	√	√	√	√	√	

2010	Insignia		Body Control Module	√	√	√	√	√	SP0047,SP0048,SP0045,SP0378,SP0372,S P0376,SP0046,SP0334,SP0332
2010	Insignia		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	SP0311
2010	Insignia		Instrument Cluster	√	√	√	√	√	SP0040
2010	Insignia		Chime Alarm Control Module	√	√	√		√	
2010	Insignia		Headlamp Control Module	√	√	√	√	√	SP0366
2010	Insignia		Trailer Interface Control Module	√	√	√	√	√	SP0040
2010	Insignia		Radio	√	√	√	√	√	
2010	Insignia		Digital Radio Receiver Control Module	√	√	√	√	√	
2010	Insignia		Multimedia Player Interface Module	√	√	√	√		SP0040
2010	Insignia		Mobile Telephone Control Module	√	√	√	√	√	
2010	Insignia		Remote Heater and Air Conditioning Control Module	√	√	√	√	√	SP0211,SP0040
2010	Insignia		Liftgate Control Module	√	√	√	√	√	SP0323
2010	Insignia		Seat Memory Control Module	√	√	√	√	√	SP0581
2010	Insignia		Front Seat Heating Control Module	√	√	√	√	√	
2010	Insignia		Parking Assist Control Module	√	√	√	√	√	SP0040
2010	Insignia		Vehicle Direction Camera Control Module	√	√	√	√	√	
2010	Insignia		Distance Sensing Cruise Control Module	√	√	√	√		SP0231
2010	Agila-B	Engine	K10B	√	√	√	√	√	SP0015
2010	Agila-B	Engine	K12B	√	√	√	√	√	SP0015
2010	Agila-B	Engine	D13A / Z 13 DTJ	√	√	√	√	√	SP0040,SP0019,SP0011,SP0021,SP0020,S P0018,SP0028,SP0025,SP0041,SP0042
2010	Agila-B	Transmission	TCM (Transmission Control Module)	√	√	√	√		SP0033
2010	Antara,Captive (Short Body)	Body	AHL(Automatic Headlamp Levelling)	√	√	√	√	√	SP0141
2010	Antara,Captive (Short Body)	Body	Anti Theft Warning System	√	√	√	√	√	
2010	Antara,Captive (Short Body)	Body	BCM(Body Control Module)	√	√	√	√	√	
2010	Antara,Captive (Short Body)	Body	ECC(Electronic Climate Control)	√	√	√		√	SP0150,SP0004
2010	Antara,Captive (Short Body)	Body	Immobiliser	√	√	√	√		
2010	Antara,Captive (Short Body)	Body	IPC ECU(Instrument Control Unit)	√	√	√	√	√	
2010	Antara,Captive (Short Body)	Body	Wipers/Washer	√	√	√	√		

2010	Antara,Captive (Short Body)	Body	PAS(Park Pilot)	√	√	√	√	√	SP0057
2010	Antara,Captive (Short Body)	Body	XBCM(Auxiliary Body Control Module)	√	√	√	√	√	
2010	Antara,Captive (Short Body)	Body	Central Door Lock	√	√	√	√	√	
2010	Antara,Captive (Short Body)	Body	RFA(Multipurpose Receiver Module)	√	√	√	√		
2010	Antara,Captive (Short Body)	Body	SLM(Shift Lever Module)	√	√	√	√		
2010	Antara,Captive (Short Body)	Body	HVAC(Heating Ventilation and Cooling)	√	√	√	√		
2010	Antara,Captive (Short Body)	Body	Interior Lighting	√	√	√	√		
2010	Antara,Captive (Short Body)	Body	Exterior Lighting/Turn Indicator System	√	√	√	√		
2010	Antara,Captive (Short Body)	Body	SDM(Airbag)	√	√	√	√		
2010	Antara,Captive (Short Body)	Chassis	ABS/TC/ESP (Vehicle Dynamic System)	√	√	√	√	√	
2010	Antara,Captive (Short Body)	Engine	2.0 L(Diesel)	√	√	√	√	√	SP0010,SP0011,SP0066,SP0020,SP0024,S P0012,SP0028,SP0025,SP0027,SP0029,SP
2010	Antara,Captive (Short Body)	Engine	Z 24 XE	√	√	√	√	√	SP0010,SP0033,SP0015
2010	Antara,Captive (Short Body)	Engine	Z 32 SE	√	√	√	√	√	SP0015,SP0018,SP0172
2010	Antara,Captive (Short Body)	Transmission	TCCM(Transfer Case Control Module)	√	√	√	√		SP0152
2010	Antara,Captive (Short Body)	Transmission	Automatic Transmission	√	√	√	√	√	SP0153,SP0154,SP0155,SP0156,SP0157
2010	Astra-H	Body	SDM(Airbag)	√	√	√	√		
2010	Astra-H	Body	CIM(Steering Column Module)	√	√	√	√	√	SP0051,SP0003,SP0052,SP0001,SP0004,S P0053,SP0054,SP0005
2010	Astra-H	Body	IPC ECU(Instrument Control Unit)	√	√	√	√		
2010	Astra-H	Body	REC(Rear Electrical Centre)	√	√	√	√		
2010	Astra-H	Body	UEC(Underhood Electrical Centre)	√	√	√	√		
2010	Astra-H	Body	AHL/AFL(Headlamp Levelling)	√	√	√	√		
2010	Astra-H	Body	Exterior Lighting/Turn Indicator System	√	√	√	√		

2010	Astra-H	Body	Interior Lighting	√	√	√	√		
2010	Astra-H	Body	Wipers/Washer	√	√	√	√		
2010	Astra-H	Body	Central Door Lock	√	√	√	√		
2010	Astra-H	Body	Instrument	√	√	√	√	√	SP0055,SP0056,SP0057
2010	Astra-H	Body	Immobiliser	√	√	√	√		
2010	Astra-H	Body	Anti Theft Warning System	√	√	√	√	√	
2010	Astra-H	Body	Electrohydraulic HardTop	√	√	√	√	√	SP0001,SP0004
2010	Astra-H	Body	ECC/SAC(Electronic Climate Control)	√	√	√	√	√	SP0150,SP0158,SP0159,SP0032,SP0001,SP0004,SP0160
2010	Astra-H	Body	EHS(Electrical Heater System)	√	√	√	√		SP0032,SP0001,SP0004
2010	Astra-H	Body	PAS(Park Pilot)	√	√	√	√	√	SP0001
2010	Astra-H	Body	SLM(Shift Lever Module)	√	√	√	√		
2010	Astra-H	Body	PEPS(Open&Start)	√	√	√	√		
2010	Astra-H	Body	IPC ECU(Instrument Control Unit)	√	√	√	√	√	SP0006,SP0055,SP0056,SP0057,SP0058,SP0059,SP0060,SP0001,SP0004
2010	Astra-H	Chassis	ABS/TC/ESP ECU(Electronic Control Unit)	√	√	√	√	√	
2010	Astra-H	Chassis	EHPS(Electrohydraulic Power Steering)	√	√	√	√		
2010	Astra-H	Chassis	TPMS ECU(Tyre Pressure Monitoring)	√	√	√	√		SP0001
2010	Astra-H	Chassis	TPMS(Tyre Pressure Monitoring System)	√	√	√	√		
2010	Astra-H	Chassis	CDC(Continuous Damping Control)	√	√	√	√		
2010	Astra-H	Chassis	ABS/TC/ESP(Vehicle Dynamic System)	√	√	√	√	√	
2010	Astra-H	Engine	A16LET	√	√	√	√	√	SP0009,SP0063,SP0011,SP0064,SP0012,SP0065,SP0006,SP0007,SP0008,SP0018
2010	Astra-H	Engine	A17DTJ	√	√	√	√	√	SP0019,SP0063,SP0011,SP0064,SP0014,SP0022,SP0023,SP0024,SP0012,SP0028,SP0025,SP0069,SP0026,SP0070,SP0006,SP0007,SP0008,SP0027,SP0018
2010	Astra-H	Engine	A17DTR	√	√	√	√	√	SP0019,SP0063,SP0011,SP0064,SP0014,SP0022,SP0023,SP0024,SP0012,SP0028,SP0025,SP0069,SP0026,SP0070,SP0006,SP0007,SP0008,SP0027,SP0018
2010	Astra-H	Engine	Y13DTH	√	√	√	√	√	SP0009,SP0063,SP0011,SP0064,SP0012,SP0065,SP0006,SP0007,SP0008,SP0018
2010	Astra-H	Engine	Z12XEP	√	√	√	√	√	SP0009,SP0063,SP0011,SP0064,SP0012,SP0065,SP0006,SP0007,SP0008,SP0018
2010	Astra-H	Engine	Z13DTH	√	√	√	√	√	SP0006,SP0007,SP0008,SP0019,SP0010,SP0011,SP0066,SP0020,SP0029,SP0028,SP0025,SP0026,SP0018

2010	Astra-H	Engine	Z14XEL	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,S P0011,SP0066,SP0012,SP0013,SP0018
2010	Astra-H	Engine	Z14XEP	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,S P0011,SP0066,SP0012,SP0013,SP0018
2010	Astra-H	Engine	Z16XE1	√	√	√	√	√	SP0019,SP0009,SP0063,SP0067,SP0064,S P0012,SP0065,SP0068,SP0006,SP0007,SP 0008,SP0018
2010	Astra-H	Engine	Z16XEP	√	√	√	√		SP0006,SP0007,SP0008,SP0009,SP0019,S P0010,SP0011,SP0066,SP0012,SP0013,SP 0033,SP0018
2010	Astra-H	Engine	Z16XER	√	√	√	√		SP0019,SP0006,SP0007,SP0008,SP0009,S P0010,SP0011,SP0066,SP0033,SP0012,SP
2010	Astra-H	Engine	Z16LET	√	√	√	√	√	SP0009,SP0063,SP0011,SP0064,SP0012,S P0065,SP0006,SP0007,SP0008,SP0018
2010	Astra-H	Engine	Z17DTH	√	√	√	√	√	SP0006,SP0007,SP0008,SP0010,SP0011,S P0066,SP0020,SP0024,SP0012,SP0029,SP 0032,SP0018
2010	Astra-H	Engine	Z17DTR	√	√	√	√	√	SP0011
2010	Astra-H	Engine	Z17DTJ	√	√	√	√	√	SP0064
2010	Astra-H	Engine	Z17DTL	√	√	√	√	√	SP0063,SP0011,SP0064,SP0020,SP0024,S P0012,SP0029,SP0032,SP0018
2010	Astra-H	Engine	Z18XE	√	√	√	√		SP0019,SP0006,SP0007,SP0008,SP0009,S P0010,SP0011,SP0066,SP0012,SP0018
2010	Astra-H	Engine	Z18XER	√	√	√	√	√	SP0006
2010	Astra-H	Engine	Z19DT	√	√	√	√	√	SP0006,SP0007,SP0008,SP0010,SP0011,S P0066,SP0023,SP0024,SP0069,SP0012,SP 0032,SP0020,SP0029,SP0026,SP0027,SP0 025,SP0028,SP0018
2010	Astra-H	Engine	Z19DTH	√	√	√	√	√	SP0006,SP0007,SP0008,SP0010,SP0011,S P0066,SP0023,SP0024,SP0069,SP0012,SP 0032,SP0020,SP0029,SP0026,SP0027,SP0 025,SP0028,SP0018
2010	Astra-H	Engine	Z20LEH	√	√	√	√	√	SP0009,SP0063,SP0011,SP0064,SP0012,S P0065,SP0006,SP0007,SP0008,SP0018
2010	Astra-H	Engine	Z20LEL	√	√	√	√	√	SP0009,SP0063,SP0011,SP0064,SP0012,S P0065,SP0006,SP0007,SP0008,SP0018
2010	Astra-H	Engine	Z20LER	√	√	√	√	√	SP0009,SP0063,SP0011,SP0064,SP0012,S P0065,SP0006,SP0007,SP0008,SP0018

2010	Astra-H	Engine	Z22YH	√	√	√	√	√	SP0006,SP0007,SP0008,SP0071,SP0019,SP0010,SP0011,SP0066,SP0012,SP0018
2010	Astra-H	Engine	Engine(default)	√	√	√			
2010	Astra-H	Transmission	AF 40-6	√	√	√	√	√	SP0072,SP0073,SP0074,SP0075,SP0076,SP0077,SP0032,SP0003,SP0033,SP0078
2010	Astra-H	Transmission	AF 17-4	√	√	√	√	√	SP0030,SP0031,SP0032,SP0003,SP0033
2010	Astra-H	Transmission	AF 22-4	√	√	√	√	√	SP0032,SP0079,SP0033,SP0030
2010	Astra-H	Transmission	MTA(Easytronic)	√	√	√	√	√	SP0079,SP0034,SP0035,SP0061
2010	Astra-H	Transmission	MTA(Easytronic Magneti Marelli)	√	√	√	√	√	SP0079,SP0004,SP0061
2010	Meriva-B	Body	Front Seat Heating Control Module	√	√	√	√		
2010	Meriva-B	Body	BCM (Body Control Module)	√	√	√	√		
2010	Meriva-B	Body	Headlamp Control Module	√	√	√	√		
2010	Meriva-B	Body	Inflatable Restraint Sensing&Diag.Module	√	√	√	√		
2010	Meriva-B	Body	Parking Assist Control Module	√	√	√	√	√	SP0107,SP0039
2010	Meriva-B	Body	Remote Heater & A/C Control Module	√	√	√	√		
2010	Meriva-B	Body	Instrument	√	√	√	√	√	SP0039
2010	Meriva-B	Body	Trailer Interface Control Module	√	√	√	√		
2010	Meriva-B	Chassis	Electronic Brake Control Module	√	√	√	√	√	
2010	Meriva-B	Chassis	Electric Power Steering Control Module	√	√	√	√		
2010	Meriva-B	Chassis	Parking Brake Control Module	√	√	√	√	√	SP0108,SP0109
2010	Meriva-B	Chassis	Steering Wheel Angle Sensor Module	√	√	√			SP0081
2010	Meriva-B	Engine	A 13 DTC 1.3(LDV)	√	√	√	√	√	SP0083,SP0110,SP0111,SP0023,SP0024,SP0028,SP0025,SP0069,SP0112,SP0113,SP0114,SP0115,SP0116,SP0117
2010	Meriva-B	Engine	A 13 DTE 1.3(LSF)	√	√	√	√	√	SP0083,SP0118,SP0111,SP0023,SP0024,SP0028,SP0025,SP0069,SP0112,SP0113,SP0114,SP0115,SP0116,SP0119,SP0018
2010	Meriva-B	Engine	A 14 NET(LUH)	√	√	√	√	√	SP0083,SP0161,SP0162,SP0015,SP0018,SP0083
2010	Meriva-B	Engine	A 14 NET (LUJ)	√	√	√	√	√	SP0091,SP0083,SP0016,SP0017,SP0015,SP0018
2010	Meriva-B	Engine	A 14 XER (LDD)	√	√	√	√	√	SP0091,SP0083,SP0016,SP0017,SP0015,SP0018
2010	Meriva-B	Engine	A 17 DTC 1.7(LUE)	√	√	√	√	√	SP0120,SP0103,SP0083,SP0118,SP0084,SP0018,SP0163,SP0128
2010	Meriva-B	Engine	A 17 DTS 1.7(LUD)	√	√	√	√	√	SP0120,SP0103,SP0083,SP0118,SP0084,SP0018,SP0163,SP0128

2010	Meriva-B	Engine	Engine Control Module	√	√	√	√	√	SP0083,SP0118,SP0111,SP0023,SP0024,S P0028,SP0025,SP0069,SP0112,SP0113,SP 0114,SP0115,SP0116,SP0119,SP0018
2010	Meriva-B	Transmission	Transmission Control Module	√	√	√	√	√	SP0078,SP0121
2010	Astra-G	Body	Add On Heater	√	√	√	√	√	SP0122,SP0123
2010	Astra-G	Body	Airbag	√	√	√	√		
2010	Astra-G	Body	Anti Theft Warning	√	√	√	√		
2010	Astra-G	Body	Central Door Lock	√	√	√	√		
2010	Astra-G	Body	Engine Cooling Module	√	√	√	√		
2010	Astra-G	Body	Electronic Climate Control	√	√	√	√		
2010	Astra-G	Body	HeadLamp Levelling Device	√	√	√	√	√	SP0141
2010	Astra-G	Body	Immobiliser	√	√	√	√		SP0164,SP0165
2010	Astra-G	Body	Instrument	√	√	√	√		
2010	Astra-G	Body	Softtop Controller	√	√	√	√	√	
2010	Astra-G	Chassis	ABS-5.3/5.4 (+TC) (Anti-lock Braking System)	√	√	√	√	√	
2010	Astra-G	Chassis	Electronic Power Steering	√	√	√	√	√	
2010	Astra-G	Chassis	ESP (Electronic Stability Program)	√	√	√	√	√	SP0005
2010	Astra-G	Engine	Z 12 XE	√	√	√	√	√	SP0006,SP0145,SP0009,SP0040,SP0019,S P0021,SP0011,SP0065,SP0033
2010	Astra-G	Engine	Z 14 XE	√			√	√	SP0146,SP0145,SP0009,SP0019,SP0021,S P0011
2010	Astra-G	Engine	Z 14 XEP	√	√	√	√	√	SP0006,SP0166,SP0009,SP0146,SP0019,S P0011,SP0021,SP0065,SP0033
2010	Astra-G	Engine	C 16 SEL	√	√	√	√	√	
2010	Astra-G	Engine	Z 16 XE	√			√	√	
2010	Astra-G	Engine	Z 16 SE	√	√	√	√	√	
2010	Astra-G	Engine	Z 16 XEP	√	√	√	√	√	SP0006,SP0146,SP0009,SP0019,SP0011,S P0021,SP0065
2010	Astra-G	Engine	Z 16 YNG	√	√	√	√	√	SP0006,SP0146,SP0145,SP0009,SP0019,S P0011,SP0021
2010	Astra-G	Engine	Y 17 DT	√	√	√	√	√	
2010	Astra-G	Engine	Z 17 DTL	√	√	√	√	√	
2010	Astra-G	Engine	Z 18 XE	√	√	√	√	√	SP0145,SP0009,SP0040,SP0019,SP0011,S P0021
2010	Astra-G	Engine	Z 18 XEL	√	√	√			SP0011,SP0021
2010	Astra-G	Engine	Y 20 DTH	√	√	√	√	√	SP0166,SP0167,SP0168,SP0169
2010	Astra-G	Engine	Z 20 LET	√	√	√	√	√	SP0009,SP0019,SP0040,SP0145,SP0011,S P0021,SP0065,SP0033

2010	Astra-G	Engine	Y 22 DTR	√	√	√	√	√	SP0011,SP0021
2010	Astra-G	Engine	Z 22 SE	√	√	√	√	√	SP0146,SP0009,SP0145,SP0011,SP0021,SP0065,SP0033
2010	Astra-G	Transmission	AF 13-II/17/20/22	√	√	√	√	√	
2010	Astra-G	Transmission	AF 13-II/17/20/22 CAN	√	√	√	√	√	
2010	Captiva(Long Body)	Body	BCM (Body Control Module)	√	√	√	√	√	
2010	Captiva(Long Body)	Body	ECC (Electronic Climate Control)	√	√	√		√	SP0150,SP0004
2010	Captiva(Long Body)	Body	Immobiliser	√	√	√	√		
2010	Captiva(Long Body)	Body	IPC ECU (Instrument Control Unit)	√	√	√	√	√	
2010	Captiva(Long Body)	Body	XBCM(Auxiliary Body Control Module)	√	√	√	√	√	
2010	Captiva(Long Body)	Body	RFA (Multipurpose Receiver Module)	√	√	√	√		
2010	Captiva(Long Body)	Chassis	ABS/TC/ESP (Vehicle Dynamic System)	√	√	√	√	√	
2010	Captiva(Long Body)	Engine	2.0 L (Diesel)	√	√	√	√	√	SP0010,SP0011,SP0066,SP0020,SP0024,SP0012,SP0028,SP0025,SP0027,SP0029,SP
2010	Captiva(Long Body)	Engine	Z32SE	√	√	√	√	√	
2010	Captiva(Long Body)	Transmission	TCCM(Transfer Case Control Module)	√	√	√	√		SP0152
2010	Captiva(Long Body)	Transmission	Automatic Transmission	√	√	√	√	√	SP0170,SP0154,SP0155,SP0156,SP0033
2010	Corsa-C	Body	Add On Heater	√	√	√	√	√	SP0122,SP0123
2010	Corsa-C	Body	Airbag	√	√	√	√	√	
2010	Corsa-C	Body	Body Control Module	√	√	√	√	√	SP0051,SP0058,SP0138
2010	Corsa-C	Body	HeadLamp Levelling Device		√	√	√	√	SP0141
2010	Corsa-C	Body	Instrument	√	√	√	√		
2010	Corsa-C	Body	Immobiliser	√	√	√	√		SP0164,SP0165
2010	Corsa-C	Chassis	ABS8/ESP8 (Anti-lock Braking System/Electronic Stability Program)		√	√	√	√	SP0005,SP0142,SP0143,SP0144,SP0004
2010	Corsa-C	Chassis	ABS-5.3/5.4 (+TC) (Anti-lock Braking System)	√	√	√	√	√	
2010	Corsa-C	Chassis	Electronic Power Steering	√	√	√	√		SP0141
2010	Corsa-C	Engine	Z 10 XEP	√	√	√	√	√	SP0011,SP0021,SP0065,SP0033

2010	Corsa-C	Engine	Z 12 XE	√	√	√	√	√	SP0006,SP0145,SP0009,SP0040,SP0019,S P0021,SP0011,SP0065,SP0033
2010	Corsa-C	Engine	Z 12 XEP	√	√	√	√	√	SP0011,SP0021,SP0065,SP0033
2010	Corsa-C	Engine	Y 13 DT	√	√	√	√	√	SP0040,SP0019,SP0021,SP0011,SP0020
2010	Corsa-C	Engine	Z 13 DT	√	√	√	√	√	SP0040,SP0019,SP0021,SP0011,SP0020
2010	Corsa-C	Engine	Z 13 DTJ	√	√	√	√	√	SP0040,SP0019,SP0028,SP0025,SP0041,S P0021,SP0011,SP0020,SP0042
2010	Corsa-C	Engine	Z 14 XE	√			√	√	SP0146,SP0145,SP0009,SP0019,SP0021,S P0011
2010	Corsa-C	Engine	Z 14 XEP	√	√	√	√	√	SP0006,SP0166,SP0009,SP0146,SP0019,S P0011,SP0021,SP0065,SP0033
2010	Corsa-C	Engine	Z 16 SE	√	√	√	√	√	
2010	Corsa-C	Engine	Z 16 YNG	√	√	√	√	√	SP0006,SP0146,SP0145,SP0009,SP0019,S P0011,SP0021
2010	Corsa-C	Engine	Y 17 DT	√	√	√	√	√	
2010	Corsa-C	Engine	Y 17 DTL	√	√	√	√	√	
2010	Corsa-C	Engine	Z 17 DTH		√	√	√		
2010	Corsa-C	Engine	Z 18 XE	√	√	√	√	√	SP0145,SP0009,SP0040,SP0019,SP0011,S P0021
2010	Corsa-C	Transmission	AF 13-II/17/20/22 CAN	√	√	√	√	√	
2010	Corsa-C	Transmission	Easytronic(MTA)	√	√	√	√	√	SP0011,SP0148
2010	Corsa-D	Body	Exterior Lighting	√	√	√	√		
2010	Corsa-D	Body	Interior Lighting	√	√	√	√		
2010	Corsa-D	Body	Wipers/Washer	√	√	√	√		
2010	Corsa-D	Body	Heating,Ventilation and Air Cond.	√	√	√	√		
2010	Corsa-D	Body	Anti Theft Warning System	√	√	√	√		
2010	Corsa-D	Body	Central Door Lock	√	√	√	√	√	
2010	Corsa-D	Body	Immobiliser	√	√	√	√		
2010	Corsa-D	Body	AFL (Adaptive Forward Lighting)	√	√	√	√		
2010	Corsa-D	Body	EHS (Electrical Heater System)	√	√	√	√		
2010	Corsa-D	Body	IPC ECU (Instrument Control Unit)	√	√	√	√		
2010	Corsa-D	Body	PAS (Park Pilot)	√	√	√	√		
2010	Corsa-D	Body	SDM (Airbag)	√	√	√	√		SP0000,SP0001,SP0002
2010	Corsa-D	Body	TIM(Trailer Interface Module)	√	√	√	√		
2010	Corsa-D	Body	BCM (Body Control Module)	√	√	√	√		
2010	Corsa-D	Chassis	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)	√	√	√	√	√	
2010	Corsa-D	Chassis	Electronic Power Steering	√	√	√	√		

2010	Corsa-D	Chassis	Fuel injector control module	√			√		
2010	Corsa-D	Engine	Z10XEP	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,SP0011,SP0012,SP0013,SP0014
2010	Corsa-D	Engine	A10XEP	√	√	√	√	√	SP0006,SP0015,SP0016,SP0017,SP0018
2010	Corsa-D	Engine	Z12XEP	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,SP0011,SP0012,SP0013,SP0014
2010	Corsa-D	Engine	A12XER	√	√	√	√	√	SP0006,SP0018
2010	Corsa-D	Engine	A12XEL	√	√	√	√	√	SP0006,SP0018
2010	Corsa-D	Engine	Z13DTH	√	√	√	√	√	SP0019,SP0010,SP0011,SP0014,SP0020
2010	Corsa-D	Engine	Z13DTE	√	√	√	√	√	SP0006
2010	Corsa-D	Engine	Z13DTJ	√	√	√	√	√	SP0019,SP0010,SP0011,SP0014,SP0020
2010	Corsa-D	Engine	Z14XEP	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,SP0011,SP0012,SP0013,SP0014
2010	Corsa-D	Engine	A14XEL	√	√	√	√	√	SP0006,SP0015,SP0016,SP0017,SP0018
2010	Corsa-D	Engine	A14XER	√	√	√	√	√	SP0006,SP0015,SP0016,SP0017,SP0018
2010	Corsa-D	Engine	Z16LEL	√	√	√	√	√	
2010	Corsa-D	Engine	Z16LER	√	√	√	√	√	
2010	Corsa-D	Engine	A16LEL	√	√	√	√	√	
2010	Corsa-D	Engine	A16LER	√	√	√	√	√	
2010	Corsa-D	Engine	Z17DTR	√	√	√	√	√	SP0019,SP0021,SP0011,SP0014,SP0022,SP0023,SP0024,SP0012,SP0025,SP0026,SP0027,SP0028,SP0020,SP0029
2010	Corsa-D	Transmission	MTA(Easytronic Magneti Marelli)	√	√	√	√	√	
2010	Corsa-D	Transmission	AF 13-4	√	√	√	√	√	SP0030,SP0031,SP0032,SP0033
2010	Corsa-D	Transmission	MTA(Easytronic)	√	√	√	√	√	SP0034,SP0035
2010	Corsa-D		Engine(default)	√	√	√			
2010	Meriva	Body	EHS (Electrical Heater System)	√	√	√	√	√	
2010	Meriva	Body	Add On Heater	√	√	√	√	√	SP0122,SP0123
2010	Meriva	Body	Airbag	√	√	√	√	√	
2010	Meriva	Body	Body Control Module	√	√	√	√	√	SP0051,SP0058,SP0138
2010	Meriva	Body	Electronic Climate Control	√	√	√	√		
2010	Meriva	Body	HeadLamp Levelling Device		√	√	√	√	SP0141
2010	Meriva	Body	Immobiliser	√	√	√	√		SP0164,SP0165
2010	Meriva	Body	Instrument	√	√	√	√		
2010	Meriva	Chassis	ABS8/ESP8 (Anti-lock Braking System/Electronic Stability Program)		√	√	√	√	SP0005,SP0142,SP0143,SP0144,SP0004
2010	Meriva	Chassis	Electronic Power Steering	√	√	√	√		SP0141
2010	Meriva	Engine	Y 13 DT	√	√	√	√	√	SP0040,SP0019,SP0021,SP0011,SP0020

2010	Meriva	Engine	Z 13 DT	√	√	√	√	√	SP0040,SP0019,SP0021,SP0011,SP0020
2010	Meriva	Engine	Z 13 DTJ	√	√	√	√	√	SP0040,SP0019,SP0028,SP0025,SP0041,SP0021,SP0011,SP0020,SP0042
2010	Meriva	Engine	Z 14 XEP	√	√	√	√	√	SP0006,SP0166,SP0009,SP0146,SP0019,SP0011,SP0021,SP0065,SP0033
2010	Meriva	Engine	Z 16 LET	√	√	√	√	√	SP0006,SP0146,SP0009,SP0019,SP0011,SP0021,SP0065
2010	Meriva	Engine	Z 16 SE	√	√	√	√	√	
2010	Meriva	Engine	Z 16 XE	√			√	√	
2010	Meriva	Engine	Z 16 XEP	√	√	√	√	√	SP0006,SP0146,SP0009,SP0019,SP0011,SP0021,SP0065
2010	Meriva	Engine	Z 16 YNG	√	√	√	√	√	SP0006,SP0146,SP0145,SP0009,SP0019,SP0011,SP0021
2010	Meriva	Engine	C 16 SEL	√	√	√	√	√	
2010	Meriva	Engine	Y 17 DT	√	√	√	√	√	
2010	Meriva	Engine	Z 17 DT	√	√	√	√	√	SP0006,SP0146,SP0019,SP0022,SP0011,SP0021,SP0020,SP0147
2010	Meriva	Engine	Z 17 DTR	√	√	√	√		
2010	Meriva	Engine	Z 17 DTH		√	√	√		
2010	Meriva	Engine	Z 18 XE	√	√	√	√	√	SP0145,SP0009,SP0040,SP0019,SP0011,SP0021
2010	Meriva	Transmission	Easytronic(MTA)	√	√	√	√	√	SP0011,SP0148
2010	Movano	Body	Airbag	√	√	√	√		
2010	Movano	Body	Body Control Module	√	√	√	√	√	SP0051,SP0058,SP0138
2010	Movano	Body	Park Pilot		√	√	√		
2010	Movano	Chassis	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)		√	√	√	√	SP0164,SP0165
2010	Movano	Chassis	Pneumatic Suspension		√	√	√	√	
2010	Movano	Transmission	MTA(Tecshift)		√	√	√	√	
2010	Vivaro	Body	Park Pilot		√	√	√		
2010	Vivaro	Body	Add On Heater	√	√	√	√	√	SP0122,SP0123
2010	Vivaro	Body	Airbag		√	√	√		SP0004
2010	Vivaro	Body	Body Control Module		√	√	√	√	
2010	Vivaro	Chassis	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)	√	√	√	√	√	SP0175,SP0176
2010	Vivaro	Engine	F9Q 760/762 (1.9L)	√	√	√	√		
2010	Vivaro	Transmission	MTA(Tecshift)		√	√	√	√	
2010	Zafira-B	Body	AHL/AFL(Headlamp Levelling)	√	√	√	√		

2010	Zafira-B	Body	Exterior Lighting/Turn Indicator System	√	√	√	√		
2010	Zafira-B	Body	Interior Lighting	√	√	√	√		
2010	Zafira-B	Body	Wipers/Washer	√	√	√	√		
2010	Zafira-B	Body	Central Door Lock	√	√	√	√		
2010	Zafira-B	Body	Instrument	√	√	√	√	√	SP0055,SP0056,SP0057
2010	Zafira-B	Body	Immobiliser	√	√	√	√		
2010	Zafira-B	Body	CIM(Steering Column Module)	√	√	√	√	√	SP0051,SP0003,SP0052,SP0001,SP0004,SP0053,SP0054,SP0005
2010	Zafira-B	Body	ECC/SAC(Electronic Climate Control)	√	√	√	√	√	SP0150,SP0158,SP0159,SP0001,SP0004,SP0160
2010	Zafira-B	Body	EHS(Electrical Heater System)	√	√	√	√		SP0032,SP0001,SP0004
2010	Zafira-B	Body	PAS(Park Pilot)	√	√	√	√	√	SP0001
2010	Zafira-B	Body	SDM(Airbag)	√	√	√	√		SP0000,SP0001,SP0002
2010	Zafira-B	Body	SLM(Shift Lever Module)	√	√	√	√		
2010	Zafira-B	Body	UEC(Underhood Electrical Centre)	√	√	√	√		
2010	Zafira-B	Body	REC(Rear Electrical Centre)	√	√	√	√		
2010	Zafira-B	Body	PEPS (Open&Start)	√	√	√	√		
2010	Zafira-B	Body	IPC ECU(Instrument Control Unit)	√	√	√	√	√	SP0006,SP0055,SP0056,SP0057,SP0058,SP0059,SP0060,SP0001,SP0004
2010	Zafira-B	Body	Anti Theft Warning System	√	√	√	√	√	
2010	Zafira-B	Chassis	ABS/TC/ESP (Vehicle Dynamic System)	√	√	√	√	√	SP0005
2010	Zafira-B	Chassis	TPMS ECU (Tyre Pressure Monitoring)	√	√	√	√		SP0001
2010	Zafira-B	Chassis	TPMS (Tyre Pressure Monitoring System)	√	√	√	√		
2010	Zafira-B	Chassis	EHPS (Electrohydraulic Power Steering)	√	√	√	√		SP0003
2010	Zafira-B	Chassis	ABS/TC/ESP ECU(Electronic Control Unit)	√	√	√	√	√	
2010	Zafira-B	Chassis	CDC (Continuous Damping Control)	√	√	√	√		
2010	Zafira-B	Engine	Z 19 DTH	√	√	√	√	√	SP0006,SP0007,SP0008,SP0032,SP0010,SP0011,SP0066,SP0023,SP0024,SP0028,SP0025,SP0026,SP0027
2010	Zafira-B	Engine	Z 16 XER	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0019,SP0010,SP0011,SP0066,SP0033,SP0012,SP0033,SP0018
2010	Zafira-B	Engine	Z 16 YNG	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0019,SP0010,SP0011,SP0066,SP0012,SP0013,SP0033,SP0018
2010	Zafira-B	Engine	Z 18 XER	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0019,SP0010,SP0011,SP0066,SP0033,SP0012,SP0033,SP0018
2010	Zafira-B	Engine	Z 22 YH	√	√	√	√	√	SP0006,SP0007,SP0008,SP0071,SP0019,SP0010,SP0011,SP0066,SP0012,SP0013,SP0033,SP0018

2010	Zafira-B	Engine	Z 20 LER	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,SP0011,SP0066,SP0012,SP0013,SP0018
2010	Zafira-B	Engine	Z 20 LEH	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,SP0011,SP0066,SP0012,SP0013,SP0018
2010	Zafira-B	Engine	Z 19 DT	√	√	√	√	√	SP0006,SP0007,SP0008,SP0010,SP0011,SP0066,SP0023,SP0024,SP0069,SP0012,SP0032,SP0020,SP0029,SP0026,SP0027,SP0025,SP0028,SP0018
2010	Zafira-B	Engine	Z 16 XE1	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0173,SP0010,SP0011,SP0066,SP0012,SP0013,SP0033,SP0018
2010	Zafira-B	Engine	Z 16 XEP	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0019,SP0010,SP0011,SP0066,SP0012,SP0013,SP0033,SP0018
2010	Zafira-B	Engine	A 17 DTJ	√	√	√	√	√	SP0006,SP0007,SP0008,SP0019,SP0010,SP0011,SP0066,SP0014,SP0022,SP0023,SP0024,SP0012,SP0028,SP0025,SP0069,SP0026,SP0070,SP0027,SP0018
2010	Zafira-B	Engine	A 17 DTR	√	√	√	√	√	SP0006,SP0007,SP0008,SP0019,SP0010,SP0011,SP0066,SP0014,SP0022,SP0023,SP0024,SP0012,SP0028,SP0025,SP0069,SP0026,SP0070,SP0027,SP0018
2010	Zafira-B	Engine	Z 17 DTJ	√	√	√	√	√	SP0019,SP0010,SP0011,SP0066,SP0014,SP0022,SP0023,SP0024,SP0012,SP0025,SP0026,SP0027,SP0028,SP0029,SP0020,SP0
2010	Zafira-B	Engine	Engine(default)	√	√	√			
2010	Zafira-B	Transmission	AF 40-6	√	√	√	√	√	SP0072,SP0073,SP0074,SP0075,SP0076,SP0077,SP0032,SP0003,SP0033,SP0078
2010	Zafira-B	Transmission	MTA(Easytronic)	√	√	√	√	√	SP0003,SP0061,SP0034,SP0035
2010	Zafira-B	Transmission	AF 22-4	√	√	√	√	√	SP0030,SP0032,SP0003,SP0033
2009	Insignia		Engine Control Module	√	√	√	√	√	SP0084,SP0018,SP0016
2009	Insignia		Fuel Injector Control Module	√			√	√	
2009	Insignia		Fuel Pump Control Module	√	√	√	√	√	SP0016
2009	Insignia		Transmission Control Module	√	√	√	√	√	SP0223,SP0122
2009	Insignia		Rear Differential Clutch Control Module	√	√	√	√	√	
2009	Insignia		Electronic Brake Control Module	√	√	√	√	√	SP0394,SP0083,SP0086
2009	Insignia		Parking Brake Control Module	√	√	√	√	√	SP0109
2009	Insignia		Multi-Axis Acceleration Sensor Module	√	√	√			SP0350

2009	Insignia		Power Steering Control Module	√	√	√	√		SP0090
2009	Insignia		Steering Wheel Angle Sensor Module	√	√	√			
2009	Insignia		Suspension Control Module	√	√	√	√	√	
2009	Insignia		Body Control Module	√	√	√	√	√	SP0047,SP0048,SP0045,SP0378,SP0372,S P0376,SP0046,SP0334,SP0332
2009	Insignia		Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	SP0311
2009	Insignia		Instrument Cluster	√	√	√	√	√	SP0040
2009	Insignia		Chime Alarm Control Module	√	√	√		√	
2009	Insignia		Headlamp Control Module	√	√	√	√	√	SP0366
2009	Insignia		Trailer Interface Control Module	√	√	√	√	√	SP0040
2009	Insignia		Radio	√	√	√	√	√	
2009	Insignia		Digital Radio Receiver Control Module	√	√	√	√	√	
2009	Insignia		Multimedia Player Interface Module	√	√	√	√		SP0040
2009	Insignia		Mobile Telephone Control Module	√	√	√	√	√	
2009	Insignia		Remote Heater and Air Conditioning Control Module	√	√	√	√	√	SP0211,SP0040
2009	Insignia		Liftgate Control Module	√	√	√	√	√	SP0323
2009	Insignia		Seat Memory Control Module	√	√	√	√	√	SP0581
2009	Insignia		Front Seat Heating Control Module	√	√	√	√	√	
2009	Insignia		Parking Assist Control Module	√	√	√	√	√	SP0040
2009	Insignia		Vehicle Direction Camera Control Module	√	√	√	√	√	
2009	Insignia		Distance Sensing Cruise Control Module	√	√	√	√		SP0231
2009	Agila-B	Body	BCM (Body Control Module)		√	√	√	√	
2009	Agila-B	Body	Immobiliser		√	√	√		
2009	Agila-B	Body	SDM (Airbag)		√	√	√		
2009	Agila-B	Chassis	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)	√	√	√	√		SP0005
2009	Agila-B	Chassis	Electronic Power Steering		√	√	√		
2009	Agila-B	Engine	K10B	√	√	√	√	√	SP0015
2009	Agila-B	Engine	K12B	√	√	√	√	√	SP0015
2009	Agila-B	Engine	D13A / Z 13 DTJ	√	√	√	√	√	SP0040,SP0019,SP0011,SP0021,SP0020,S P0018,SP0028,SP0025,SP0041,SP0042
2009	Agila-B	Transmission	TCM (Transmission Control Module)	√	√	√	√		SP0033
2009	Antara,Captiva (Short Body)	Body	AHL(Automatic Headlamp Levelling)	√	√	√	√	√	SP0141
2009	Antara,Captiva (Short Body)	Body	Anti Theft Warning System	√	√	√	√	√	
2009	Antara,Captiva (Short Body)	Body	BCM (Body Control Module)	√	√	√	√	√	

2009	Antara,Captiva (Short Body)	Body	ECC (Electronic Climate Control)	√	√	√		√	SP0150,SP0004
2009	Antara,Captiva (Short Body)	Body	Immobiliser	√	√	√	√		
2009	Antara,Captiva (Short Body)	Body	IPC ECU (Instrument Control Unit)	√	√	√	√	√	
2009	Antara,Captiva (Short Body)	Body	Wipers/Washer	√	√	√	√		
2009	Antara,Captiva (Short Body)	Body	PAS (Park Pilot)	√	√	√	√	√	SP0057
2009	Antara,Captiva (Short Body)	Body	XBCM(Auxiliary Body Control Module)	√	√	√	√	√	
2009	Antara,Captiva (Short Body)	Body	Central Door Lock	√	√	√	√	√	
2009	Antara,Captiva (Short Body)	Body	RFA (Multipurpose Receiver Module)	√	√	√	√		
2009	Antara,Captiva (Short Body)	Body	SLM (Shift Lever Module)	√	√	√	√		
2009	Antara,Captiva (Short Body)	Body	HVAC(Heating Ventilation and Cooling)	√	√	√	√		
2009	Antara,Captiva (Short Body)	Body	Interior Lighting	√	√	√	√		
2009	Antara,Captiva (Short Body)	Body	Exterior Lighting/Turn Indicator System	√	√	√	√		
2009	Antara,Captiva (Short Body)	Body	SDM (Airbag)	√	√	√	√		
2009	Antara,Captiva (Short Body)	Chassis	ABS/TC/ESP (Vehicle Dynamic System)	√	√	√	√	√	
2009	Antara,Captiva (Short Body)	Engine	2.0 L (Diesel)	√	√	√	√	√	SP0010,SP0011,SP0066,SP0020,SP0024,SP0012,SP0028,SP0025,SP0027,SP0029,SP
2009	Antara,Captiva (Short Body)	Engine	Z 24 XE	√	√	√	√	√	SP0010,SP0033,SP0015
2009	Antara,Captiva (Short Body)	Engine	Z 32 SE	√	√	√	√	√	SP0015,SP0018,SP0172
2009	Antara,Captiva (Short Body)	Transmission	TCCM(Transfer Case Control Module)	√	√	√	√		SP0152
2009	Antara,Captiva (Short Body)	Transmission	Automatic Transmission	√	√	√	√	√	SP0170,SP0154,SP0155,SP0156,SP0033

2009	Astra-G	Body	Immobiliser	√	√	√	√		SP0139,SP0140
2009	Astra-G	Body	Instrument	√	√	√	√		
2009	Astra-G	Body	Airbag	√	√	√	√		
2009	Astra-G	Body	Anti Theft Warning	√	√	√	√		
2009	Astra-G	Body	Central Door Lock	√	√	√	√		
2009	Astra-G	Body	Headlamp Levelling Device	√	√	√	√	√	SP0141
2009	Astra-G	Body	Electronic Climate Control	√	√	√	√		
2009	Astra-G	Body	Engine Cooling Module	√	√	√	√		
2009	Astra-G	Body	Add On Heater	√	√	√	√	√	SP0122,SP0123
2009	Astra-G	Body	Softtop Controller	√	√	√	√	√	
2009	Astra-G	Chassis	ABS-5.3/5.4(+TC)	√	√	√	√	√	
2009	Astra-G	Chassis	ESP	√	√	√	√	√	SP0005
2009	Astra-G	Chassis	Cruise Control	√	√	√	√		
2009	Astra-G	Chassis	Electronic Power Steering	√	√	√	√	√	
2009	Astra-G	Engine	Z12XE	√	√	√	√	√	SP0006,SP0145,SP0009,SP0040,SP0019,S P0021,SP0011,SP0065,SP0033
2009	Astra-G	Engine	Z14XE	√			√	√	SP0146,SP0145,SP0009,SP0019,SP0021,S P0011
2009	Astra-G	Engine	Z14XEP	√	√	√	√	√	SP0033,SP0065,SP0006,SP0166,SP0009,S P0146,SP0019,SP0011,SP0021
2009	Astra-G	Engine	C16SEL	√	√	√	√	√	
2009	Astra-G	Engine	Z16SE	√	√	√	√	√	
2009	Astra-G	Engine	Z16XE	√			√	√	
2009	Astra-G	Engine	Z16XEP	√	√	√	√	√	SP0006,SP0146,SP0009,SP0019,SP0011,S P0021,SP0065
2009	Astra-G	Engine	Z16YNG	√	√	√	√	√	SP0006,SP0146,SP0145,SP0009,SP0019,S P0011,SP0021
2009	Astra-G	Engine	Y17DT	√	√	√	√	√	
2009	Astra-G	Engine	Z17DTL	√	√	√	√	√	
2009	Astra-G	Engine	Z18XE	√	√	√	√	√	SP0145,SP0009,SP0040,SP0019,SP0011,S P0021
2009	Astra-G	Engine	Z18XEL	√	√	√			SP0011,SP0021
2009	Astra-G	Engine	Y20DTH	√	√	√	√	√	SP0166,SP0167,SP0168,SP0169
2009	Astra-G	Engine	Z20LET	√	√	√	√	√	SP0009,SP0019,SP0040,SP0145,SP0011,S P0021,SP0065,SP0033
2009	Astra-G	Engine	Y22DTR	√	√	√	√	√	SP0011,SP0021
2009	Astra-G	Engine	Z22SE	√	√	√	√	√	SP0065,SP0146,SP0145,SP0009,SP0011,S P0021,SP0033

2009	Astra-G	Transmission	AF 13-II/17/20/22	√	√	√	√	√	
2009	Astra-G	Transmission	AF 13-II/17/20/22 CAN	√	√	√	√	√	
2009	Astra-H	Body	SDM(Airbag)	√	√	√	√		
2009	Astra-H	Body	CIM(Steering Column Module)	√	√	√	√	√	SP0051,SP0003,SP0052,SP0001,SP0004,SP0053,SP0054,SP0005
2009	Astra-H	Body	IPC ECU(Instrument Control Unit)	√	√	√	√		
2009	Astra-H	Body	REC(Rear Electrical Centre)	√	√	√	√		
2009	Astra-H	Body	UEC(Underhood Electrical Centre)	√	√	√	√		
2009	Astra-H	Body	AHL/AFL (Headlamp Levelling)	√	√	√	√		
2009	Astra-H	Body	Exterior Lighting/Turn Indicator System	√	√	√	√		
2009	Astra-H	Body	Interior Lighting	√	√	√	√		
2009	Astra-H	Body	Wipers/Washer	√	√	√	√		
2009	Astra-H	Body	Central Door Lock	√	√	√	√		
2009	Astra-H	Body	Instrument	√	√	√	√	√	SP0055,SP0056,SP0057
2009	Astra-H	Body	Immobiliser	√	√	√	√		
2009	Astra-H	Body	Anti Theft Warning System	√	√	√	√	√	
2009	Astra-H	Body	Electrohydraulic HardTop	√	√	√	√	√	SP0001,SP0004
2009	Astra-H	Body	ECC/SAC (Electronic Climate Control)	√	√	√	√	√	SP0150,SP0158,SP0159,SP0032,SP0001,SP0004,SP0160
2009	Astra-H	Body	EHS (Electrical Heater System)	√	√	√	√		SP0032,SP0001,SP0004
2009	Astra-H	Body	PAS (Park Pilot)	√	√	√	√	√	SP0001
2009	Astra-H	Body	SLM (Shift Lever Module)	√	√	√	√		
2009	Astra-H	Body	PEPS (Open&Start)	√	√	√	√		
2009	Astra-H	Body	IPC ECU(Instrument Control Unit)	√	√	√	√	√	SP0006,SP0055,SP0056,SP0057,SP0058,SP0059,SP0060,SP0001,SP0004
2009	Astra-H	Chassis	ABS/TC/ESP ECU(Electronic Control Unit)	√	√	√	√	√	
2009	Astra-H	Chassis	EHPS(Electrohydraulic Power Steering)	√	√	√	√		
2009	Astra-H	Chassis	TPMS ECU (Tyre Pressure Monitoring)	√	√	√	√		SP0001
2009	Astra-H	Chassis	TPMS (Tyre Pressure Monitoring System)	√	√	√	√		
2009	Astra-H	Chassis	CDC (Continuous Damping Control)	√	√	√	√		
2009	Astra-H	Chassis	ABS/TC/ESP (Vehicle Dynamic System)	√	√	√	√	√	
2009	Astra-H	Chassis	EHPS(Electrohydraulic Power Steering)	√	√	√	√		SP0003
2009	Astra-H	Engine	Z13DTH	√	√	√	√	√	SP0006,SP0007,SP0008,SP0019,SP0010,SP0011,SP0066,SP0020,SP0029,SP0028,SP0025,SP0026,SP0018
2009	Astra-H	Engine	Z14XEL	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,SP0011,SP0066,SP0012,SP0013,SP0018

2009	Astra-H	Engine	Z14XEP	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,SP0011,SP0066,SP0012,SP0013,SP0018
2009	Astra-H	Engine	Z16XEP	√	√	√	√		SP0006,SP0007,SP0008,SP0009,SP0019,SP0010,SP0011,SP0066,SP0012,SP0013,SP0033,SP0018
2009	Astra-H	Engine	Z16XER	√	√	√	√		SP0019,SP0006,SP0007,SP0008,SP0009,SP0010,SP0011,SP0066,SP0033,SP0012,SP
2009	Astra-H	Engine	Z17DTH	√	√	√	√	√	SP0006,SP0007,SP0008,SP0010,SP0011,SP0066,SP0020,SP0024,SP0012,SP0029,SP0032,SP0018
2009	Astra-H	Engine	Z17DTR	√	√	√	√	√	SP0006,SP0007,SP0008,SP0019,SP0010,SP0011,SP0066,SP0014,SP0022,SP0023,SP0024,SP0012,SP0025,SP0026,SP0027,SP0028,SP0029,SP0020,SP0018
2009	Astra-H	Engine	Z17DTJ	√	√	√	√	√	SP0006,SP0007,SP0008,SP0019,SP0010,SP0011,SP0066,SP0014,SP0022,SP0023,SP0024,SP0012,SP0025,SP0026,SP0027,SP0028,SP0029,SP0020,SP0018
2009	Astra-H	Engine	Z18XE	√	√	√	√		SP0019,SP0006,SP0007,SP0008,SP0009,SP0010,SP0011,SP0066,SP0012,SP0018
2009	Astra-H	Engine	Z19DT	√	√	√	√	√	SP0006,SP0007,SP0008,SP0010,SP0011,SP0066,SP0023,SP0024,SP0069,SP0012,SP0032,SP0020,SP0029,SP0026,SP0027,SP0025,SP0028,SP0018
2009	Astra-H	Engine	Z19DTH	√	√	√	√	√	SP0006,SP0007,SP0008,SP0010,SP0011,SP0066,SP0023,SP0024,SP0069,SP0012,SP0032,SP0020,SP0029,SP0026,SP0027,SP0025,SP0028,SP0018
2009	Astra-H	Engine	Z 12 XEP	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,SP0011,SP0066,SP0012,SP0013,SP0018
2009	Astra-H	Engine	Y 13 DTH	√	√	√	√	√	SP0019,SP0010,SP0011,SP0066,SP0020,SP0029,SP0028,SP0025,SP0026,SP0018
2009	Astra-H	Engine	A 16 LET	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,SP0011,SP0066,SP0012,SP0013,SP0018
2009	Astra-H	Engine	Z 16 XE1	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0019,SP0010,SP0011,SP0066,SP0012,SP0013,SP0033,SP0018

2009	Astra-H	Engine	Z 16 LET	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,SP0011,SP0066,SP0012,SP0013,SP0018
2009	Astra-H	Engine	A 17 DTJ	√	√	√	√	√	SP0006,SP0007,SP0008,SP0019,SP0010,SP0011,SP0066,SP0014,SP0022,SP0023,SP0024,SP0012,SP0028,SP0025,SP0069,SP0026,SP0070,SP0027,SP0018
2009	Astra-H	Engine	A 17 DTR	√	√	√	√	√	SP0006,SP0007,SP0008,SP0019,SP0010,SP0011,SP0066,SP0014,SP0022,SP0023,SP0024,SP0012,SP0028,SP0025,SP0069,SP0026,SP0070,SP0027,SP0018
2009	Astra-H	Engine	Z 17 DTL	√	√	√	√	√	SP0010,SP0011,SP0066,SP0020,SP0024,SP0012,SP0029,SP0032,SP0018
2009	Astra-H	Engine	Z 18 XER	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0019,SP0010,SP0011,SP0066,SP0033,SP0012,SP
2009	Astra-H	Engine	Z 20 LEH	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,SP0011,SP0066,SP0012,SP0013,SP0018
2009	Astra-H	Engine	Z 20 LEL	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,SP0011,SP0066,SP0012,SP0013,SP0018
2009	Astra-H	Engine	Z 20 LER	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,SP0011,SP0066,SP0012,SP0013,SP0018
2009	Astra-H	Engine	Z 22 YH	√	√	√	√	√	SP0006,SP0007,SP0008,SP0071,SP0019,SP0010,SP0011,SP0066,SP0012,SP0018
2009	Astra-H	Engine	Engine(default)	√	√	√			
2009	Astra-H	Transmission	AF 17-4	√	√	√	√	√	SP0030,SP0031,SP0032,SP0003,SP0033
2009	Astra-H	Transmission	AF 40-6	√	√	√	√	√	SP0072,SP0073,SP0074,SP0075,SP0076,SP0077,SP0032,SP0003,SP0033,SP0078
2009	Astra-H	Transmission	AF 22-4	√	√	√	√	√	SP0030,SP0032,SP0003,SP0033
2009	Astra-H	Transmission	MTA(Easytronic)	√	√	√	√	√	SP0003,SP0061,SP0034,SP0035
2009	Astra-H	Transmission	MTA(Easytronic Magneti Marelli)	√	√	√	√	√	
2009	Astra-J	Electronic Brake Control Module		√	√	√	√		SP0000,SP0085,SP0086
2009	Astra-J	Electronic Power Steering		√	√	√	√		SP0087,SP0088,SP0089
2009	Astra-J	Engine Control	A13DTE	√	√	√	√	√	SP0037,SP0038,SP0080,SP0020

2009	Astra-J	Engine Control	A17DTJ	√	√	√	√	√	SP0037,SP0038,SP0080,SP0020
2009	Astra-J	Front Seet Heating Control		√	√	√	√		
2009	Astra-J	Fuel Pump Control		√	√	√	√		
2009	Astra-J	Keyless Entry Control		√	√	√	√		
2009	Astra-J	Steering Column Lock Control		√	√	√	√		
2009	Astra-J	Steering Wheel Angle Sensor		√	√	√	√	√	SP0081,SP0082
2009	Astra-J	Trailer Interface Control		√	√	√	√		
2009	Astra-J	Transmission Control		√	√	√	√	√	
2009	Captiva(Long Body)	Body	BCM (Body Control Module)	√	√	√	√	√	
2009	Captiva(Long Body)	Body	ECC (Electronic Climate Control)	√	√	√		√	SP0150,SP0004
2009	Captiva(Long Body)	Body	Immobiliser	√	√	√	√		
2009	Captiva(Long Body)	Body	IPC ECU (Instrument Control Unit)	√	√	√	√	√	
2009	Captiva(Long Body)	Body	XBCM(Auxiliary Body Control Module)	√	√	√	√	√	
2009	Captiva(Long Body)	Body	RFA (Multipurpose Receiver Module)	√	√	√	√		
2009	Captiva(Long Body)	Chassis	ABS/TC/ESP (Vehicle Dynamic System)	√	√	√	√	√	
2009	Captiva(Long Body)	Engine	2.0 L (Diesel)	√	√	√	√	√	SP0010,SP0011,SP0066,SP0020,SP0024,S P0012,SP0028,SP0025,SP0027,SP0029,SP
2009	Captiva(Long Body)	Engine	Z32SE	√	√	√	√	√	

2009	Captiva(Long Body)	Transmission	TCCM(Transfer Case Control Module)	√	√	√	√		SP0152
2009	Captiva(Long Body)	Transmission	Automatic Transmission	√	√	√	√	√	SP0170,SP0154,SP0155,SP0156,SP0033
2009	Corsa-C	Body	Body Control Module	√	√	√	√	√	SP0051,SP0058,SP0138
2009	Corsa-C	Body	Immobiliser	√	√	√	√		SP0139,SP0140
2009	Corsa-C	Body	Airbag	√	√	√	√	√	
2009	Corsa-C	Body	Instrument	√	√	√	√	√	SP0177,SP0178
2009	Corsa-C	Body	Add On Heater	√	√	√	√	√	SP0122,SP0123
2009	Corsa-C	Body	HeadLamp Levelling Device		√	√	√	√	SP0141
2009	Corsa-C	Chassis	ABS-5.3/5.4(+TC)	√	√	√	√	√	
2009	Corsa-C	Chassis	ABS8/ESP8		√	√	√	√	SP0005,SP0142,SP0143,SP0144,SP0004
2009	Corsa-C	Chassis	Electronic Power Steering	√	√	√	√		SP0141
2009	Corsa-C	Engine	Z10XEP	√	√	√	√	√	SP0011,SP0021,SP0065,SP0033
2009	Corsa-C	Engine	Z12XE	√	√	√	√	√	SP0006,SP0145,SP0009,SP0040,SP0019,S P0021,SP0011,SP0065,SP0033
2009	Corsa-C	Engine	Z12XEP	√	√	√	√	√	SP0011,SP0021,SP0065,SP0033
2009	Corsa-C	Engine	Y13DT	√	√	√	√	√	SP0040,SP0019,SP0021,SP0011,SP0020
2009	Corsa-C	Engine	Z13DT	√	√	√	√	√	SP0019,SP0040,SP0021,SP0011,SP0020
2009	Corsa-C	Engine	Z14XE	√			√	√	SP0146,SP0145,SP0009,SP0019,SP0021,S P0011
2009	Corsa-C	Engine	Z14XEP	√	√	√	√	√	SP0033,SP0065,SP0006,SP0166,SP0009,S P0146,SP0019,SP0011,SP0021
2009	Corsa-C	Engine	Z16SE	√	√	√	√	√	
2009	Corsa-C	Engine	Z16YNG	√	√	√	√	√	SP0006,SP0146,SP0145,SP0009,SP0019,S P0011,SP0021
2009	Corsa-C	Engine	Y17DT	√	√	√	√	√	
2009	Corsa-C	Engine	Y17DTL	√	√	√	√	√	
2009	Corsa-C	Engine	Z17DTH	√	√	√	√	√	SP0006,SP0146,SP0019,SP0020,SP0147,S P0022,SP0011,SP0021
2009	Corsa-C	Engine	Z18XE	√	√	√	√	√	SP0145,SP0009,SP0040,SP0019,SP0011,S P0021
2009	Corsa-C	Engine	Z13DTJ	√	√	√	√	√	SP0040,SP0019,SP0028,SP0025,SP0041,S P0021,SP0011,SP0020,SP0042
2009	Corsa-C	Transmission	AF 13-II/17/20/22 CAN	√	√	√	√	√	
2009	Corsa-C	Transmission	MTA(Easytronic)	√	√	√	√	√	SP0011,SP0148
2009	Corsa-D	Body	SDM(Airbag)	√	√	√	√		SP0000,SP0001,SP0002

2009	Corsa-D	Body	IPC(Instrument)	√	√	√	√	√	SP0006,SP0055,SP0056,SP0057,SP0001,S P0004
2009	Corsa-D	Body	Central Door Lock	√	√	√	√	√	
2009	Corsa-D	Body	Exterior Lighting	√	√	√	√		
2009	Corsa-D	Body	Interior Lighting	√	√	√	√		
2009	Corsa-D	Body	Wipers/Washer	√	√	√	√		
2009	Corsa-D	Body	Anti Theft Warning System	√	√	√	√		
2009	Corsa-D	Body	Immobiliser	√	√	√	√		
2009	Corsa-D	Body	AFL (Adaptive Forward Lighting)	√	√	√	√		
2009	Corsa-D	Body	EHS (Electrical Heater System)	√	√	√	√		
2009	Corsa-D	Body	IPC ECU (Instrument Control Unit)	√	√	√	√	√	SP0006,SP0055,SP0056,SP0057,SP0001,S P0004
2009	Corsa-D	Body	PAS (Park Pilot)	√	√	√	√		
2009	Corsa-D	Body	TIM(Trailer Interface Module)	√	√	√	√		
2009	Corsa-D	Body	BCM (Body Control Module)	√	√	√	√		
2009	Corsa-D	Body	SDM(Airbag)	√	√	√	√		SP0000,SP0001,SP0002
2009	Corsa-D	Chassis	ABS/ESP	√	√	√	√	√	SP0003,SP0004,SP0179,SP0062
2009	Corsa-D	Chassis	Electronic Power Steering	√	√	√	√		
2009	Corsa-D	Engine	Z10XEP	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,S P0011,SP0012,SP0013,SP0014
2009	Corsa-D	Engine	Z12XEP	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,S P0011,SP0012,SP0013,SP0014
2009	Corsa-D	Engine	Z13DTJ	√	√	√	√	√	SP0019,SP0010,SP0011,SP0014,SP0020
2009	Corsa-D	Engine	Z13DTH	√	√	√	√	√	SP0019,SP0010,SP0011,SP0014,SP0020
2009	Corsa-D	Engine	Z14XEP	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,S P0011,SP0012,SP0013,SP0014
2009	Corsa-D	Engine	Z17DTR	√	√	√	√	√	SP0019,SP0021,SP0011,SP0014,SP0022,S P0023,SP0024,SP0012,SP0025,SP0026,SP 0027,SP0028,SP0020,SP0029
2009	Corsa-D	Engine	Z16LEL	√	√	√	√	√	SP0009,SP0010,SP0011,SP0066,SP0012,S P0013,SP0014
2009	Corsa-D	Engine	Z16LER	√	√	√	√	√	SP0009,SP0010,SP0011,SP0066,SP0012,S P0013,SP0014
2009	Corsa-D	Engine	Engine(default)	√	√	√			
2009	Corsa-D	Transmission	MTA(Easytronic Magneti Marelli)	√	√	√	√	√	
2009	Corsa-D	Transmission	AF 13-4	√	√	√	√	√	SP0030,SP0031,SP0032,SP0033
2009	Corsa-D	Transmission	MTA(Easytronic)	√	√	√	√	√	SP0034,SP0035
2009	Meriva	Body	Body Control Module	√	√	√	√	√	SP0051,SP0058,SP0138

2009	Meriva	Body	Immobiliser	√	√	√	√		SP0139,SP0140
2009	Meriva	Body	Airbag	√	√	√	√	√	
2009	Meriva	Body	Instrument	√	√	√	√	√	SP0176,SP0177
2009	Meriva	Body	Headlamp Levelling Device	√	√	√	√	√	SP0141
2009	Meriva	Body	Electronic Climate Control	√	√	√	√	√	
2009	Meriva	Body	EHS (Electrical Heater System)	√	√	√	√	√	
2009	Meriva	Body	Add On Heater	√	√	√	√	√	SP0122,SP0123
2009	Meriva	Chassis	ABS/ESP8		√	√	√	√	SP0005,SP0142,SP0143,SP0144,SP0004
2009	Meriva	Chassis	Electronic Power Steering	√	√	√	√		SP0141
2009	Meriva	Engine	Y13DT	√	√	√	√	√	SP0040,SP0019,SP0021,SP0011,SP0020
2009	Meriva	Engine	Z14XEP	√	√	√	√	√	SP0033,SP0065,SP0006,SP0166,SP0009,S P0146,SP0019,SP0011,SP0021
2009	Meriva	Engine	Z16SE	√	√	√	√	√	
2009	Meriva	Engine	Z16XE	√			√	√	
2009	Meriva	Engine	Z16XEP	√	√	√	√	√	SP0006,SP0146,SP0009,SP0019,SP0011,S P0021,SP0065
2009	Meriva	Engine	Y17DT	√	√	√	√	√	
2009	Meriva	Engine	Z17DTH	√	√	√	√	√	SP0006,SP0146,SP0019,SP0020,SP0147,S P0022,SP0011,SP0021
2009	Meriva	Engine	Z18XE	√	√	√	√	√	SP0145,SP0009,SP0040,SP0019,SP0011,S P0021
2009	Meriva	Engine	Z13DT	√	√	√	√	√	SP0040,SP0019,SP0021,SP0011,SP0020
2009	Meriva	Engine	Z13DTJ	√	√	√	√	√	SP0040,SP0019,SP0028,SP0025,SP0041,S P0021,SP0011,SP0020,SP0042
2009	Meriva	Engine	Z16LET	√	√	√	√	√	SP0006,SP0146,SP0009,SP0019,SP0011,S P0021,SP0065
2009	Meriva	Engine	Z16YNG	√	√	√	√	√	SP0006,SP0146,SP0145,SP0009,SP0019,S P0011,SP0021
2009	Meriva	Engine	C16SEL	√	√	√	√	√	
2009	Meriva	Engine	Z17DT	√	√	√	√	√	SP0006,SP0146,SP0019,SP0022,SP0011,S P0021,SP0020,SP0147
2009	Meriva	Engine	Z17DTR	√	√	√	√		
2009	Meriva	Transmission	MTA(Easytronic)	√	√	√	√	√	SP0011,SP0148
2009	Movano	Body	Airbag	√	√	√	√		
2009	Movano	Body	Body Control Module	√	√	√	√	√	SP0051,SP0058,SP0138
2009	Movano	Body	Park Pilot		√	√	√		
2009	Movano	Chassis	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)		√	√	√	√	SP0164,SP0165

2009	Movano	Chassis	Pneumatic Suspension		√	√	√	√	
2009	Movano	Transmission	MTA(Tecshift)		√	√	√	√	
2009	Tigra-B	Body	Body Control Module	√	√	√	√	√	SP0051,SP0058,SP0138
2009	Tigra-B	Body	Immobiliser	√	√	√	√		SP0139,SP0140
2009	Tigra-B	Body	Airbag	√	√	√	√	√	
2009	Tigra-B	Body	Instrument	√	√	√	√	√	SP0176,SP0177
2009	Tigra-B	Body	Electrohydraulic HardTop	√	√	√	√	√	
2009	Tigra-B	Chassis	ABS/ESP8		√	√	√	√	SP0005,SP0142,SP0143,SP0144,SP0004
2009	Tigra-B	Chassis	Electronic Power Steering	√	√	√	√		SP0141
2009	Tigra-B	Engine	Z13DT	√	√	√	√	√	SP0019,SP0040,SP0021,SP0011,SP0020
2009	Tigra-B	Engine	Z14XEP	√	√	√	√	√	SP0033,SP0065,SP0006,SP0166,SP0009,S P0146,SP0019,SP0011,SP0021
2009	Tigra-B	Engine	Z18XE	√	√	√	√	√	SP0145,SP0009,SP0040,SP0019,SP0011,S P0021
2009	Tigra-B	Transmission	MTA(Easytronic)	√	√	√	√	√	SP0011,SP0148
2009	Vauxhall VXR8	Body	AHL(Automatic Headlamp Levelling)	√	√	√	√		
2009	Vauxhall VXR8	Body	BCM (Body Control Module)	√	√	√	√		
2009	Vauxhall VXR8	Body	HVAC(Heating Ventilation and Cooling)	√	√	√	√		
2009	Vauxhall VXR8	Body	Immobiliser	√	√	√	√		
2009	Vauxhall VXR8	Body	MSM(Memory Seat and Mirrors)	√	√	√	√		
2009	Vauxhall VXR8	Body	Park Assist	√	√	√	√		
2009	Vauxhall VXR8	Body	SDM(Sensing and Diagnostic Module)	√	√	√	√		
2009	Vauxhall VXR8	Body	IPC (Instrument Panel Cluster)	√	√	√	√		
2009	Vauxhall VXR8	Body	RFA (Multipurpose Receiver Module)	√	√	√	√		
2009	Vauxhall VXR8	Chassis	EBCM(Electronic Brake Control Module)	√	√	√	√	√	
2009	Vauxhall VXR8	Chassis	ESC(Electronic Suspension Control)	√	√	√	√		
2009	Vauxhall VXR8	Engine	V8 GEN IV	√	√	√	√	√	SP0015,SP0149,SP0171,SP0172
2009	Vauxhall VXR8	Transmission	Automatic Transmission	√	√	√	√	√	
2009	Vivaro	Body	Airbag		√	√	√		SP0004
2009	Vivaro	Body	Park Pilot		√	√	√		
2009	Vivaro	Body	Add On Heater	√	√	√	√	√	SP0122,SP0123
2009	Vivaro	Body	Body Control Module		√	√	√	√	
2009	Vivaro	Chassis	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)	√	√	√	√	√	SP0174,SP0175
2009	Vivaro	Engine	F9Q 760/762 (1.9L)	√	√	√	√		
2009	Vivaro	Transmission	MTA(Tecshift)		√	√	√	√	
2009	Zafira-B	Body	SDM(Airbag)	√	√	√	√		SP0000,SP0001,SP0002

2009	Zafira-B	Body	CIM(Steering Column Module)	√	√	√	√	√	SP0051,SP0003,SP0052,SP0001,SP0004,SP0053,SP0054,SP0005
2009	Zafira-B	Body	IPC ECU(Instrument Control Unit)	√	√	√	√		
2009	Zafira-B	Body	REC(Rear Electrical Centre)	√	√	√	√		
2009	Zafira-B	Body	UEC(Underhood Electrical Centre)	√	√	√	√		
2009	Zafira-B	Body	AHL/AFL(Headlamp Levelling)	√	√	√	√		
2009	Zafira-B	Body	Exterior Lighting/Turn Indicator System	√	√	√	√		
2009	Zafira-B	Body	Interior Lighting	√	√	√	√		
2009	Zafira-B	Body	Wipers/Washer	√	√	√	√		
2009	Zafira-B	Body	Central Door Lock	√	√	√	√		
2009	Zafira-B	Body	Instrument	√	√	√	√	√	SP0055,SP0056,SP0057
2009	Zafira-B	Body	Immobiliser	√	√	√	√		
2009	Zafira-B	Body	ECC/SAC(Electronic Climate Control)	√	√	√	√	√	SP0150,SP0158,SP0159,SP0001,SP0004,SP0160
2009	Zafira-B	Body	EHS(Electrical Heater System)	√	√	√	√		SP0032,SP0001,SP0004
2009	Zafira-B	Body	PAS(Park Pilot)	√	√	√	√	√	SP0001
2009	Zafira-B	Body	SLM(Shift Lever Module)	√	√	√	√		
2009	Zafira-B	Body	PEPS(Open&Start)	√	√	√	√		
2009	Zafira-B	Body	Anti Theft Warning System	√	√	√	√	√	
2009	Zafira-B	Body	IPC ECU(Instrument Control Unit)	√	√	√	√	√	SP0006,SP0055,SP0056,SP0057,SP0058,SP0059,SP0060,SP0001,SP0004
2009	Zafira-B	Chassis	ABS/TC/ESP ECU(Electronic Control Unit)	√	√	√	√	√	
2009	Zafira-B	Chassis	EHPS(Electrohydraulic Power Steering)	√	√	√	√		
2009	Zafira-B	Chassis	ABS/TC/ESP(Vehicle Dynamic System)	√	√	√	√	√	SP0005
2009	Zafira-B	Chassis	TPMS ECU(Tyre Pressure Monitoring)	√	√	√	√		SP0001
2009	Zafira-B	Chassis	TPMS(Tyre Pressure Monitoring System)	√	√	√	√		
2009	Zafira-B	Chassis	ABS/TC/ESP ECU(Electronic Control Unit)	√	√	√	√	√	
2009	Zafira-B	Chassis	CDC(Continuous Damping Control)	√	√	√	√		
2009	Zafira-B	Chassis	EHPS(Electrohydraulic Power Steering)	√	√	√	√		SP0003
2009	Zafira-B	Engine	Z16XEP	√	√	√	√		SP0006,SP0007,SP0008,SP0009,SP0019,SP0010,SP0011,SP0066,SP0012,SP0013,SP0033,SP0018
2009	Zafira-B	Engine	Z16XER	√	√	√	√		SP0019,SP0006,SP0007,SP0008,SP0009,SP0010,SP0011,SP0066,SP0033,SP0012,SP0033,SP0018
2009	Zafira-B	Engine	Z18XER	√	√	√	√		SP0019,SP0006,SP0007,SP0008,SP0009,SP0010,SP0011,SP0066,SP0033,SP0012,SP0033,SP0018

2009	Zafira-B	Engine	Z19DT	√	√	√	√	√	SP0006,SP0007,SP0008,SP0010,SP0011,S P0066,SP0023,SP0024,SP0069,SP0012,SP 0032,SP0020,SP0029,SP0026,SP0027,SP0 025,SP0028,SP0018
2009	Zafira-B	Engine	Z19DTH	√	√	√	√	√	SP0006,SP0007,SP0008,SP0032,SP0010,S P0011,SP0066,SP0023,SP0024,SP0028,SP 0025,SP0026,SP0027
2009	Zafira-B	Engine	Z16YNG	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0019,S P0010,SP0011,SP0066,SP0012,SP0013,SP 0033,SP0018
2009	Zafira-B	Engine	Z16XE1	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0173,S P0010,SP0011,SP0066,SP0012,SP0013,SP 0033,SP0018
2009	Zafira-B	Engine	A17DTJ	√	√	√	√	√	SP0006,SP0007,SP0008,SP0019,SP0010,S P0011,SP0066,SP0014,SP0022,SP0023,SP 0024,SP0012,SP0028,SP0025,SP0069,SP0 026,SP0070,SP0027,SP0018
2009	Zafira-B	Engine	A17DTR	√	√	√	√	√	SP0006,SP0007,SP0008,SP0019,SP0010,S P0011,SP0066,SP0014,SP0022,SP0023,SP 0024,SP0012,SP0028,SP0025,SP0069,SP0 026,SP0070,SP0027,SP0018
2009	Zafira-B	Engine	Z22YH	√	√	√	√	√	SP0006,SP0007,SP0008,SP0071,SP0019,S P0010,SP0011,SP0066,SP0012,SP0013,SP
2009	Zafira-B	Engine	Z20LER	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,S P0011,SP0066,SP0012,SP0013,SP0018
2009	Zafira-B	Engine	Z20LEH	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,S P0011,SP0066,SP0012,SP0013,SP0018
2009	Zafira-B	Engine	Engine(default)	√	√	√			
2009	Zafira-B	Transmission	MTA(Easutronic)	√	√	√	√	√	SP0003,SP0061,SP0034,SP0035
2009	Zafira-B	Transmission	AF 40-6	√	√	√	√	√	SP0072,SP0073,SP0074,SP0075,SP0076,S P0077,SP0032,SP0003,SP0033,SP0078
2009	Zafira-B	Transmission	AF 22-4	√	√	√	√	√	SP0030,SP0032,SP0003,SP0033
2008	Agila-B	Body	BCM(Body Control Module)		√	√	√	√	
2008	Agila-B	Body	Immobiliser		√	√	√		
2008	Agila-B	Body	SDM(Airbag)		√	√	√		
2008	Agila-B	Chassis	ABS/ESP(Anti-lock Braking System/Electronic Stability Program)	√	√	√	√		SP0005
2008	Agila-B	Chassis	Electronic Power Steering		√	√	√		

2008	Agila-B	Engine	K10B	√	√	√	√	√	SP0015
2008	Agila-B	Engine	K12B	√	√	√	√	√	SP0015
2008	Agila-B	Engine	D13A / Z 13 DTJ	√	√	√	√	√	SP0040,SP0019,SP0011,SP0021,SP0020,SP0018,SP0028,SP0025,SP0041,SP0042
2008	Agila-B	Transmission	TCM(Transmission Control Module)	√	√	√	√		SP0033
2008	Antara,Captiva (Short Body)	Body	AHL(Automatic Headlamp Levelling)	√	√	√	√	√	SP0141
2008	Antara,Captiva (Short Body)	Body	Anti Theft Warning System	√	√	√	√	√	
2008	Antara,Captiva (Short Body)	Body	BCM(Body Control Module)	√	√	√	√	√	
2008	Antara,Captiva (Short Body)	Body	ECC(Electronic Climate Control)	√	√	√		√	SP0150,SP0004
2008	Antara,Captiva (Short Body)	Body	Immobiliser	√	√	√	√		
2008	Antara,Captiva (Short Body)	Body	IPC ECU(Instrument Control Unit)	√	√	√	√	√	
2008	Antara,Captiva (Short Body)	Body	Wipers/Washer	√	√	√	√		
2008	Antara,Captiva (Short Body)	Body	PAS(Park Pilot)	√	√	√	√	√	SP0057
2008	Antara,Captiva (Short Body)	Body	XBCM(Auxiliary Body Control Module)	√	√	√	√	√	
2008	Antara,Captiva (Short Body)	Body	Central Door Lock	√	√	√	√	√	
2008	Antara,Captiva (Short Body)	Body	RFA(Multipurpose Receiver Module)	√	√	√	√		
2008	Antara,Captiva (Short Body)	Body	SLM(Shift Lever Module)	√	√	√	√		
2008	Antara,Captiva (Short Body)	Body	HVAC(Heating Ventilation and Cooling)	√	√	√	√		
2008	Antara,Captiva (Short Body)	Body	Interior Lighting	√	√	√	√		
2008	Antara,Captiva (Short Body)	Body	Exterior Lighting/Turn Indicator System	√	√	√	√		
2008	Antara,Captiva (Short Body)	Body	SDM(Airbag)	√	√	√	√		

2008	Antara,Captiva (Short Body)	Chassis	ABS/TC/ESP (Vehicle Dynamic System)	√	√	√	√	√	
2008	Antara,Captiva (Short Body)	Engine	2.0 L (Diesel)	√	√	√	√	√	SP0010,SP0011,SP0066,SP0020,SP0024,S P0012,SP0028,SP0025,SP0027,SP0029,SP
2008	Antara,Captiva (Short Body)	Engine	Z 24 XE	√	√	√	√	√	SP0010,SP0033,SP0015
2008	Antara,Captiva (Short Body)	Engine	Z 32 SE	√	√	√	√	√	SP0015,SP0018,SP0172
2008	Antara,Captiva (Short Body)	Transmission	TCCM(Transfer Case Control Module)	√	√	√	√		SP0152
2008	Antara,Captiva (Short Body)	Transmission	Automatic Transmission	√	√	√	√	√	SP0170,SP0154,SP0155,SP0156,SP0033
2008	Astra-G	Body	Immobiliser	√	√	√	√		SP0139,SP0140
2008	Astra-G	Body	Instrument	√	√	√	√		
2008	Astra-G	Body	Airbag	√	√	√	√		
2008	Astra-G	Body	Anti Theft Warning	√	√	√	√		
2008	Astra-G	Body	Central Door Lock	√	√	√	√		
2008	Astra-G	Body	Headlamp Levelling Device	√	√	√	√	√	SP0141
2008	Astra-G	Body	Electronic Climate Control	√	√	√	√		
2008	Astra-G	Body	Engine Cooling Module	√	√	√	√		
2008	Astra-G	Body	Add On Heater	√	√	√	√	√	SP0122,SP0123
2008	Astra-G	Body	Softtop Controller	√	√	√	√	√	
2008	Astra-G	Chassis	ABS-5.3/5.4(+TC)	√	√	√	√	√	
2008	Astra-G	Chassis	ESP	√	√	√	√	√	SP0005
2008	Astra-G	Chassis	Cruise Control	√	√	√	√		
2008	Astra-G	Chassis	Electronic Power Steering	√	√	√	√	√	
2008	Astra-G	Engine	Z12XE	√	√	√	√	√	SP0006,SP0145,SP0009,SP0040,SP0019,S P0021,SP0011,SP0065,SP0033
2008	Astra-G	Engine	Z14XE	√			√	√	SP0146,SP0145,SP0009,SP0019,SP0021,S P0011
2008	Astra-G	Engine	Z14XEP	√	√	√	√	√	SP0033,SP0065,SP0006,SP0166,SP0009,S P0146,SP0019,SP0011,SP0021
2008	Astra-G	Engine	C16SEL	√	√	√	√	√	
2008	Astra-G	Engine	Z16SE	√	√	√	√	√	
2008	Astra-G	Engine	Z16XE	√			√	√	
2008	Astra-G	Engine	Z16XEP	√	√	√	√	√	SP0006,SP0146,SP0009,SP0019,SP0011,S P0021,SP0065

2008	Astra-G	Engine	Z16YNG	√	√	√	√	√	SP0006,SP0146,SP0145,SP0009,SP0019,S P0011,SP0021
2008	Astra-G	Engine	Y17DT	√	√	√	√	√	
2008	Astra-G	Engine	Z17DTL	√	√	√	√	√	
2008	Astra-G	Engine	Z18XE	√	√	√	√	√	SP0145,SP0009,SP0040,SP0019,SP0011,S P0021
2008	Astra-G	Engine	Z18XEL	√	√	√			SP0011,SP0021
2008	Astra-G	Engine	Y20DTH	√	√	√	√	√	SP0166,SP0167,SP0168,SP0169
2008	Astra-G	Engine	Z20LET	√	√	√	√	√	SP0009,SP0019,SP0040,SP0145,SP0011,S P0021,SP0065,SP0033
2008	Astra-G	Engine	Y22DTR	√	√	√	√	√	SP0011,SP0021
2008	Astra-G	Engine	Z22SE	√	√	√	√	√	SP0065,SP0146,SP0145,SP0009,SP0011,S P0021,SP0033
2008	Astra-G	Transmission	AF 13-II/17/20/22	√	√	√	√	√	
2008	Astra-G	Transmission	AF 13-II/17/20/22 CAN	√	√	√	√	√	
2008	Astra-H	Body	SDM(Airbag)	√	√	√	√		
2008	Astra-H	Body	CIM(Steering Column Module)	√	√	√	√	√	SP0051,SP0003,SP0052,SP0001,SP0004,S P0053,SP0054,SP0005
2008	Astra-H	Body	IPC ECU(Instrument Control Unit)	√	√	√	√		
2008	Astra-H	Body	REC(Rear Electrical Centre)	√	√	√	√		
2008	Astra-H	Body	UEC(Underhood Electrical Centre)	√	√	√	√		
2008	Astra-H	Body	AHL/AFL (Headlamp Levelling)	√	√	√	√		
2008	Astra-H	Body	Exterior Lighting/Turn Indicator System	√	√	√	√		
2008	Astra-H	Body	Interior Lighting	√	√	√	√		
2008	Astra-H	Body	Wipers/Washer	√	√	√	√		
2008	Astra-H	Body	Central Door Lock	√	√	√	√		
2008	Astra-H	Body	Instrument	√	√	√	√	√	SP0055,SP0056,SP0057
2008	Astra-H	Body	Immobiliser	√	√	√	√		
2008	Astra-H	Body	Anti Theft Warning System	√	√	√	√	√	
2008	Astra-H	Body	Electrohydraulic HardTop	√	√	√	√	√	SP0001,SP0004
2008	Astra-H	Body	ECC/SAC (Electronic Climate Control)	√	√	√	√	√	SP0150,SP0158,SP0159,SP0032,SP0001,S P0004,SP0160
2008	Astra-H	Body	EHS (Electrical Heater System)	√	√	√	√		SP0032,SP0001,SP0004
2008	Astra-H	Body	PAS (Park Pilot)	√	√	√	√	√	SP0001
2008	Astra-H	Body	SLM (Shift Lever Module)	√	√	√	√		
2008	Astra-H	Body	PEPS (Open&Start)	√	√	√	√		
2008	Astra-H	Body	IPC ECU(Instrument Control Unit)	√	√	√	√	√	SP0006,SP0055,SP0056,SP0057,SP0058,S P0059,SP0060,SP0001,SP0004

2008	Astra-H	Chassis	ABS/TC/ESP ECU(Electronic Control Unit)	√	√	√	√	√	
2008	Astra-H	Chassis	EHPS(Electrohydraulic Power Steering)	√	√	√	√		
2008	Astra-H	Chassis	TPMS ECU(Tyre Pressure Monitoring)	√	√	√	√		SP0001
2008	Astra-H	Chassis	TPMS(Tyre Pressure Monitoring System)	√	√	√	√		
2008	Astra-H	Chassis	CDC(Continuous Damping Control)	√	√	√	√		
2008	Astra-H	Chassis	ABS/TC/ESP(Vehicle Dynamic System)	√	√	√	√	√	
2008	Astra-H	Chassis	EHPS(Electrohydraulic Power Steering)	√	√	√	√		SP0003
2008	Astra-H	Engine	Z13DTH	√	√	√	√	√	SP0006,SP0007,SP0008,SP0019,SP0010,S P0011,SP0066,SP0020,SP0029,SP0028,SP 0025,SP0026,SP0018
2008	Astra-H	Engine	Z14XEL	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,S P0011,SP0066,SP0012,SP0013,SP0018
2008	Astra-H	Engine	Z14XEP	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,S P0011,SP0066,SP0012,SP0013,SP0018
2008	Astra-H	Engine	Z16XEP	√	√	√	√		SP0006,SP0007,SP0008,SP0009,SP0019,S P0010,SP0011,SP0066,SP0012,SP0013,SP 0033,SP0018
2008	Astra-H	Engine	Z16XER	√	√	√	√		SP0019,SP0006,SP0007,SP0008,SP0009,S P0010,SP0011,SP0066,SP0033,SP0012,SP
2008	Astra-H	Engine	Z17DTH	√	√	√	√	√	SP0006,SP0007,SP0008,SP0010,SP0011,S P0066,SP0020,SP0024,SP0012,SP0029,SP 0032,SP0018
2008	Astra-H	Engine	Z17DTR	√	√	√	√	√	SP0006,SP0007,SP0008,SP0019,SP0010,S P0011,SP0066,SP0014,SP0022,SP0023,SP 0024,SP0012,SP0025,SP0026,SP0027,SP0 028,SP0029,SP0020,SP0018
2008	Astra-H	Engine	Z17DTJ	√	√	√	√	√	SP0006,SP0007,SP0008,SP0019,SP0010,S P0011,SP0066,SP0014,SP0022,SP0023,SP 0024,SP0012,SP0025,SP0026,SP0027,SP0 028,SP0029,SP0020,SP0018
2008	Astra-H	Engine	Z18XE	√	√	√	√		SP0019,SP0006,SP0007,SP0008,SP0009,S P0010,SP0011,SP0066,SP0012,SP0018
2008	Astra-H	Engine	Z18XER	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0019,S P0010,SP0011,SP0066,SP0033,SP0012,SP
2008	Astra-H	Engine	Z19DT	√	√	√	√	√	SP0006,SP0007,SP0008,SP0010,SP0011,S P0066,SP0023,SP0024,SP0069,SP0012,SP 0032,SP0020,SP0029,SP0026,SP0027,SP0 025,SP0028,SP0018

2008	Astra-H	Engine	Z19DTH	√	√	√	√	√	SP0006,SP0007,SP0008,SP0010,SP0011,SP0066,SP0023,SP0024,SP0069,SP0012,SP0032,SP0020,SP0029,SP0026,SP0027,SP0025,SP0028,SP0018
2008	Astra-H	Engine	Z16LET	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,SP0011,SP0066,SP0012,SP0013,SP0018
2008	Astra-H	Engine	Z20LEH	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,SP0011,SP0066,SP0012,SP0013,SP0018
2008	Astra-H	Engine	Z22YH	√	√	√	√	√	SP0006,SP0007,SP0008,SP0071,SP0019,SP0010,SP0011,SP0066,SP0012,SP0018
2008	Astra-H	Engine	Z17DTL	√	√	√	√	√	SP0010,SP0011,SP0066,SP0020,SP0024,SP0012,SP0029,SP0032,SP0018
2008	Astra-H	Engine	Z16XE1	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0019,SP0010,SP0011,SP0066,SP0012,SP0013,SP0033,SP0018
2008	Astra-H	Engine	Z12XEP	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,SP0011,SP0066,SP0012,SP0013,SP0018
2008	Astra-H	Engine	Y13DTH	√	√	√	√	√	SP0019,SP0010,SP0011,SP0066,SP0020,SP0029,SP0028,SP0025,SP0026,SP0018
2008	Astra-H	Engine	Z19DTJ	√	√	√		√	SP0010,SP0011,SP0066,SP0023,SP0024,SP0069,SP0012,SP0032,SP0020,SP0029,SP0026,SP0027,SP0025,SP0028,SP0018
2008	Astra-H	Engine	Z20LEL	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,SP0011,SP0066,SP0012,SP0013,SP0018
2008	Astra-H	Engine	Z20LER	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,SP0011,SP0066,SP0012,SP0013,SP0018
2008	Astra-H	Engine	Engine(default)	√	√	√			
2008	Astra-H	Transmission	AF 17-4	√	√	√	√	√	SP0030,SP0031,SP0032,SP0003,SP0033
2008	Astra-H	Transmission	AF 40-6	√	√	√	√	√	SP0072,SP0073,SP0074,SP0075,SP0076,SP0077,SP0032,SP0003,SP0033,SP0078
2008	Astra-H	Transmission	AF 22-4	√	√	√	√	√	SP0030,SP0032,SP0003,SP0033
2008	Astra-H	Transmission	MTA(Easytronic)	√	√	√	√	√	SP0003,SP0061,SP0034,SP0035
2008	Astra-H	Transmission	MTA(Easytronic Magneti Marelli)	√	√	√	√	√	
2008	Captiva(Long Body)	Body	BCM (Body Control Module)	√	√	√	√	√	
2008	Captiva(Long Body)	Body	ECC (Electronic Climate Control)	√	√	√		√	SP0150,SP0004

2008	Captiva(Long Body)	Body	Immobiliser	√	√	√	√		
2008	Captiva(Long Body)	Body	IPC ECU (Instrument Control Unit)	√	√	√	√	√	
2008	Captiva(Long Body)	Body	XBCM(Auxiliary Body Control Module)	√	√	√	√	√	
2008	Captiva(Long Body)	Body	RFA (Multipurpose Receiver Module)	√	√	√	√		
2008	Captiva(Long Body)	Chassis	ABS/TC/ESP (Vehicle Dynamic System)	√	√	√	√	√	
2008	Captiva(Long Body)	Engine	2.0L(Diesel)	√	√	√	√	√	SP0010,SP0011,SP0066,SP0020,SP0024,SP0012,SP0028,SP0025,SP0027,SP0029,SP
2008	Captiva(Long Body)	Engine	Z32SE	√	√	√	√	√	
2008	Captiva(Long Body)	Transmission	TCCM(Transfer Case Control Module)	√	√	√	√		SP0152
2008	Captiva(Long Body)	Transmission	Automatic Transmission	√	√	√	√	√	SP0170,SP0154,SP0155,SP0156,SP0033
2008	Corsa-C	Body	Body Control Module	√	√	√	√	√	SP0051,SP0058,SP0138
2008	Corsa-C	Body	Immobiliser	√	√	√	√		SP0139,SP0140
2008	Corsa-C	Body	Airbag	√	√	√	√	√	
2008	Corsa-C	Body	Instrument	√	√	√	√	√	SP0176,SP0177
2008	Corsa-C	Body	Add On Heater	√	√	√	√	√	SP0122,SP0123
2008	Corsa-C	Body	HeadLamp Levelling Device		√	√	√	√	SP0141
2008	Corsa-C	Chassis	ABS-5.3/5.4(+TC)	√	√	√	√	√	
2008	Corsa-C	Chassis	ABS8/ESP8		√	√	√	√	SP0005,SP0142,SP0143,SP0144,SP0004
2008	Corsa-C	Chassis	Electronic Power Steering	√	√	√	√		SP0141
2008	Corsa-C	Engine	Z10XEP	√	√	√	√	√	SP0011,SP0021,SP0065,SP0033
2008	Corsa-C	Engine	Z12XE	√	√	√	√	√	SP0006,SP0145,SP0009,SP0040,SP0019,SP0021,SP0011,SP0065,SP0033
2008	Corsa-C	Engine	Z12XEP	√	√	√	√	√	SP0011,SP0021,SP0065,SP0033
2008	Corsa-C	Engine	Y13DT	√	√	√	√	√	SP0040,SP0019,SP0021,SP0011,SP0020
2008	Corsa-C	Engine	Z13DT	√	√	√	√	√	SP0019,SP0040,SP0021,SP0011,SP0020
2008	Corsa-C	Engine	Z14XE	√			√	√	SP0146,SP0145,SP0009,SP0019,SP0021,SP0011
2008	Corsa-C	Engine	Z14XEP	√	√	√	√	√	SP0033,SP0065,SP0006,SP0166,SP0009,SP0146,SP0019,SP0011,SP0021
2008	Corsa-C	Engine	Z16SE	√	√	√	√	√	

2008	Corsa-C	Engine	Z16YNG	√	√	√	√	√	SP0006,SP0146,SP0145,SP0009,SP0019,SP0011,SP0021
2008	Corsa-C	Engine	Y17DT	√	√	√	√	√	
2008	Corsa-C	Engine	Y17DTL	√	√	√	√	√	
2008	Corsa-C	Engine	Z17DTH	√	√	√	√	√	SP0006,SP0146,SP0019,SP0020,SP0147,SP0022,SP0011,SP0021
2008	Corsa-C	Engine	Z18XE	√	√	√	√	√	SP0145,SP0009,SP0040,SP0019,SP0011,SP0021
2008	Corsa-C	Engine	Z13DTJ	√	√	√	√	√	SP0040,SP0019,SP0028,SP0025,SP0041,SP0021,SP0011,SP0020,SP0042
2008	Corsa-C	Transmission	AF 13-II/17/20/22 CAN	√	√	√	√	√	
2008	Corsa-C	Transmission	MTA(Easytronic)	√	√	√	√	√	SP0011,SP0148
2008	Corsa-D	Body	SDM(Airbag)	√	√	√	√		SP0000,SP0001,SP0002
2008	Corsa-D	Body	IPC(Instrument)	√	√	√	√	√	SP0006,SP0055,SP0056,SP0057,SP0001,SP0004
2008	Corsa-D	Body	Central Door Lock	√	√	√	√	√	
2008	Corsa-D	Body	Exterior Lighting	√	√	√	√		
2008	Corsa-D	Body	Interior Lighting	√	√	√	√		
2008	Corsa-D	Body	Wipers/Washer	√	√	√	√		
2008	Corsa-D	Body	Anti Theft Warning System	√	√	√	√		
2008	Corsa-D	Body	Immobiliser	√	√	√	√		
2008	Corsa-D	Body	AFL (Adaptive Forward Lighting)	√	√	√	√		
2008	Corsa-D	Body	EHS (Electrical Heater System)	√	√	√	√		
2008	Corsa-D	Body	IPC ECU (Instrument Control Unit)	√	√	√	√	√	SP0006,SP0055,SP0056,SP0057,SP0001,SP0004
2008	Corsa-D	Body	PAS (Park Pilot)	√	√	√	√		
2008	Corsa-D	Body	TIM(Trailer Interface Module)	√	√	√	√		
2008	Corsa-D	Body	SDM(Airbag)	√	√	√	√		SP0000,SP0001,SP0002
2008	Corsa-D	Chassis	ABS/ESP	√	√	√	√	√	SP0003,SP0004,SP0178,SP0062
2008	Corsa-D	Chassis	Electronic Power Steering	√	√	√	√		
2008	Corsa-D	Engine	Z10XEP	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,SP0011,SP0012,SP0013,SP0014
2008	Corsa-D	Engine	Z12XEP	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,SP0011,SP0012,SP0013,SP0014
2008	Corsa-D	Engine	Z13DTJ	√	√	√	√	√	SP0019,SP0010,SP0011,SP0014,SP0020
2008	Corsa-D	Engine	Z13DTH	√	√	√	√	√	SP0019,SP0010,SP0011,SP0014,SP0020
2008	Corsa-D	Engine	Z14XEP	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,SP0011,SP0012,SP0013,SP0014

2008	Corsa-D	Engine	Z17DTR	√	√	√	√	√	SP0019,SP0021,SP0011,SP0014,SP0022,S P0023,SP0024,SP0012,SP0025,SP0026,SP 0027,SP0028,SP0020,SP0029
2008	Corsa-D	Engine	Z16LEL	√	√	√	√	√	SP0009,SP0010,SP0011,SP0066,SP0012,S P0013,SP0014
2008	Corsa-D	Engine	Z16LER	√	√	√	√	√	SP0009,SP0010,SP0011,SP0066,SP0012,S P0013,SP0014
2008	Corsa-D	Engine	Engine(default)	√	√	√			
2008	Corsa-D	Transmission	MTA(Easytronic Magneti Marelli)	√	√	√	√	√	
2008	Corsa-D	Transmission	AF 13-4	√	√	√	√	√	SP0030,SP0031,SP0032,SP0033
2008	Corsa-D	Transmission	MTA(Easytronic)	√	√	√	√	√	SP0034,SP0035
2008	Meriva	Body	Body Control Module	√	√	√	√	√	SP0051,SP0058,SP0138
2008	Meriva	Body	Immobiliser	√	√	√	√		SP0139,SP0140
2008	Meriva	Body	Airbag	√	√	√	√	√	
2008	Meriva	Body	Instrument	√	√	√	√	√	SP0176,SP0177
2008	Meriva	Body	Headlamp Levelling Device	√	√	√	√	√	SP0141
2008	Meriva	Body	Electronic Climate Control	√	√	√	√	√	
2008	Meriva	Body	EHS (Electrical Heater System)	√	√	√	√	√	
2008	Meriva	Body	Add On Heater	√	√	√	√	√	SP0122,SP0123
2008	Meriva	Chassis	ABS8/ESP8		√	√	√	√	SP0005,SP0142,SP0143,SP0144,SP0004
2008	Meriva	Chassis	Electronic Power Steering	√	√	√	√		SP0141
2008	Meriva	Engine	Y13DT	√	√	√	√	√	SP0040,SP0019,SP0021,SP0011,SP0020
2008	Meriva	Engine	Z14XEP	√	√	√	√	√	SP0033,SP0065,SP0006,SP0166,SP0009,S P0146,SP0019,SP0011,SP0021
2008	Meriva	Engine	Z16SE	√	√	√	√	√	
2008	Meriva	Engine	Z16XE	√			√	√	
2008	Meriva	Engine	Z16XEP	√	√	√	√	√	SP0006,SP0146,SP0009,SP0019,SP0011,S P0021,SP0065
2008	Meriva	Engine	Y17DT	√	√	√	√	√	
2008	Meriva	Engine	Z17DTH	√	√	√	√	√	SP0006,SP0146,SP0019,SP0020,SP0147,S P0022,SP0011,SP0021
2008	Meriva	Engine	Z18XE	√	√	√	√	√	SP0145,SP0009,SP0040,SP0019,SP0011,S P0021
2008	Meriva	Engine	Z13DT	√	√	√	√	√	SP0040,SP0019,SP0021,SP0011,SP0020
2008	Meriva	Engine	Z13DTJ	√	√	√	√	√	SP0040,SP0019,SP0028,SP0025,SP0041,S P0021,SP0011,SP0020,SP0042
2008	Meriva	Engine	Z16LET	√	√	√	√	√	SP0006,SP0146,SP0009,SP0019,SP0011,S P0021,SP0065

2008	Meriva	Engine	Z16YNG	√	√	√	√	√	SP0006,SP0146,SP0145,SP0009,SP0019,SP0011,SP0021
2008	Meriva	Engine	C16SEL	√	√	√	√	√	
2008	Meriva	Engine	Z17DT	√	√	√	√	√	SP0006,SP0146,SP0019,SP0022,SP0011,SP0021,SP0020,SP0147
2008	Meriva	Engine	Z17DTR	√	√	√	√		
2008	Meriva	Transmission	MTA(Easytronic)	√	√	√	√	√	SP0011,SP0148
2008	Movano	Body	Airbag	√	√	√	√		
2008	Movano	Body	Body Control Module	√	√	√	√	√	SP0051,SP0058,SP0138
2008	Movano	Body	Park Pilot		√	√	√		
2008	Movano	Chassis	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)		√	√	√	√	SP0164,SP0165
2008	Movano	Chassis	Pneumatic Suspension		√	√	√	√	
2008	Movano	Transmission	MTA(Tecshift)		√	√	√	√	
2008	Tigra-B	Body	Body Control Module	√	√	√	√	√	SP0051,SP0058,SP0138
2008	Tigra-B	Body	Immobiliser	√	√	√	√		SP0139,SP0140
2008	Tigra-B	Body	Airbag	√	√	√	√	√	
2008	Tigra-B	Body	Instrument	√	√	√	√	√	SP0176,SP0177
2008	Tigra-B	Body	Electrohydraulic HardTop	√	√	√	√	√	
2008	Tigra-B	Chassis	ABS8/ESP8		√	√	√	√	SP0005,SP0142,SP0143,SP0144,SP0004
2008	Tigra-B	Chassis	Electronic Power Steering	√	√	√	√		SP0141
2008	Tigra-B	Engine	Z13DT	√	√	√	√	√	SP0019,SP0040,SP0021,SP0011,SP0020
2008	Tigra-B	Engine	Z14XEP	√	√	√	√	√	SP0033,SP0065,SP0006,SP0166,SP0009,SP0146,SP0019,SP0011,SP0021
2008	Tigra-B	Engine	Z18XE	√	√	√	√	√	SP0145,SP0009,SP0040,SP0019,SP0011,SP0021
2008	Tigra-B	Transmission	MTA(Easytronic)	√	√	√	√	√	SP0011,SP0148
2008	Vauxhall VXR8	Body	AHL(Automatic Headlamp Levelling)	√	√	√	√		
2008	Vauxhall VXR8	Body	BCM(Body Control Module)	√	√	√	√		
2008	Vauxhall VXR8	Body	HVAC(Heating Ventilation and Cooling)	√	√	√	√		
2008	Vauxhall VXR8	Body	Immobiliser	√	√	√	√		
2008	Vauxhall VXR8	Body	MSM(Memory Seat and Mirrors)	√	√	√	√		
2008	Vauxhall VXR8	Body	Park Assist	√	√	√	√		
2008	Vauxhall VXR8	Body	SDM(Sensing and Diagnostic Module)	√	√	√	√		
2008	Vauxhall VXR8	Body	IPC(Instrument Panel Cluster)	√	√	√	√		
2008	Vauxhall VXR8	Body	RFA(Multipurpose Receiver Module)	√	√	√	√		
2008	Vauxhall VXR8	Chassis	EBCM(Electronic Brake Control Module)	√	√	√	√	√	
2008	Vauxhall VXR8	Chassis	ESC(Electronic Suspension Control)	√	√	√	√		

2008	Vauxhall VXR8	Engine	V8 GEN IV	√	√	√	√	√	SP0015,SP0149,SP0171,SP0172
2008	Vauxhall VXR8	Transmission	Automatic Transmission	√	√	√	√	√	
2008	Vectra-	Body	SDM(Airbag,Sensing&Diagnostic Module)	√	√	√	√		SP0000,SP0001,SP0002
2008	Vectra-	Body	Instrument	√	√	√	√	√	SP0169,SP0056,SP0057,SP0180,SP0001
2008	Vectra-C/Signum	Body	CIM(Steering Column Module)	√	√	√	√	√	SP0051,SP0003,SP0052,SP0001,SP0004,SP0053,SP0054,SP0005
2008	Vectra-	Body	BCM(Body Control Module)	√	√	√			SP0181,SP0182
2008	Vectra-	Body	DDM(Driver Door Module)	√	√	√			
2008	Vectra-	Body	PDM(Passenger Door Module)	√	√	√			
2008	Vectra-	Body	REC(Rear Electrical Centre)	√	√	√	√		
2008	Vectra-	Body	UEC(Underhood Electrical Centre)	√	√	√	√		
2008	Vectra-	Body	SLM(Shift Lever Module)	√	√	√			
2008	Vectra-	Body	SRM(Sun Roof Module)	√	√	√			
2008	Vectra-	Body	AHL/AFL(Headlamp Levelling)	√	√	√			
2008	Vectra-	Body	Electrical Horn	√	√	√	√	√	
2008	Vectra-C/Signum	Body	SAC (Automatic Climate Control)	√	√	√	√	√	SP0150,SP0158,SP0159,SP0001,SP0004,SP0160
2008	Vectra-	Body	Interior Lighting	√	√	√	√	√	SP0183,SP0059
2008	Vectra-	Body	Electronic Seat Memory/Seat Heating	√	√	√	√		
2008	Vectra-	Body	Anti Theft Warning System	√	√	√	√	√	
2008	Vectra-	Body	Central Door Lock	√	√	√	√		
2008	Vectra-	Body	EHS (Electrical Heater System)	√	√	√	√	√	SP0032,SP0001,SP0004
2008	Vectra-	Body	PAS (Park Pilot)	√	√	√	√	√	SP0001
2008	Vectra-	Chassis	ABS/TC/ESP	√	√	√	√	√	SP0025
2008	Vectra-	Chassis	EHPS(Electronic Power Steering)	√	√	√	√		SP0026
2008	Vectra-	Chassis	TPMS (Tyre Pressure Monitoring System)	√	√	√	√		SP0020
2008	Vectra-	Chassis	CDC(Continuous Damping Control)	√	√	√			SP0012
2008	Vectra-	Chassis	Electronic Cruise Control	√	√	√			
2008	Vectra-	Engine	Engine Cooling	√	√	√	√		
2008	Vectra-	Engine	Z16XEP	√	√	√	√	√	SP0010,SP0011,SP0066,SP0013,SP0149
2008	Vectra-C/Signum	Engine	Z18XE	√	√	√	√	√	SP0019,SP0010,SP0011,SP0066,SP0149,SP0012
2008	Vectra-C/Signum	Engine	Z18XER	√	√	√	√	√	SP0019,SP0009,SP0010,SP0011,SP0066,SP0149,SP0033,SP0012
2008	Vectra-C/Signum	Engine	Z19DT	√	√	√	√	√	SP0149,SP0010,SP0011,SP0066,SP0023,SP0024,SP0069,SP0020,SP0012,SP0026,SP

2008	Vectra-C/Signum	Engine	Z19DTH	√	√	√	√	√	SP0149,SP0010,SP0011,SP0066,SP0023,SP0024,SP0028,SP0025,SP0026,SP0020,SP0012,SP0027,SP0029
2008	Vectra-	Engine	Y20DTH	√	√	√	√	√	SP0010,SP0011,SP0066,SP0149
2008	Vectra-	Engine	Y22DTR	√	√	√	√	√	SP0010,SP0011,SP0066,SP0149
2008	Vectra-	Engine	Z22SE	√	√	√	√	√	SP0010,SP0011,SP0066,SP0149
2008	Vectra-	Engine	Z22YH	√	√	√	√	√	SP0023
2008	Vectra-	Engine	Z32SE	√	√	√	√	√	SP0019,SP0010,SP0011,SP0066,SP0149
2008	Vectra-	Engine	Z30DT	√	√	√	√	√	SP0019,SP0010,SP0066,SP0029
2008	Vectra-C/Signum	Engine	Z28NEH	√	√	√	√	√	SP0009,SP0019,SP0040,SP0184,SP0185,SP0186,SP0011,SP0066,SP0149
2008	Vectra-C/Signum	Engine	Z28NEL	√	√	√	√	√	SP0009,SP0019,SP0040,SP0183,SP0184,SP0185,SP0011,SP0066,SP0149
2008	Vectra-C/Signum	Engine	Z28NET	√	√	√	√	√	SP0009,SP0019,SP0040,SP0183,SP0184,SP0185,SP0011,SP0066,SP0149
2008	Vectra-	Engine	Z16XE	√	√	√	√	√	SP0010,SP0011,SP0066,SP0149,SP0012
2008	Vectra-	Engine	Z20NET	√	√	√	√	√	SP0010,SP0011,SP0066,SP0149
2008	Vectra-	Engine	Engine(default)	√	√	√			
2008	Vectra-	Transmission	AF 23-5/33-5/40-6	√	√	√	√	√	SP0032,SP0033
2008	Vectra-C/Signum	Transmission	CVTronic	√	√	√	√	√	SP0187,SP0188,SP0189,SP0032,SP0003,SP0033
2008	Vectra-	Transmission	MTA(Easytronic)	√	√	√	√	√	
2008	Vivaro	Body	Airbag		√	√	√		SP0004
2008	Vivaro	Body	Park Pilot		√	√	√		
2008	Vivaro	Body	Add On Heater	√	√	√	√	√	SP0122,SP0123
2008	Vivaro	Body	Body Control Module		√	√	√	√	
2008	Vivaro	Chassis	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)	√	√	√	√	√	SP0174,SP0175
2008	Vivaro	Engine	F9Q 760/762 (1.9L)	√	√	√	√		
2008	Vivaro	Transmission	MTA(Tecshift)		√	√	√	√	
2008	Zafira-B	Body	SDM(Airbag)	√	√	√	√		SP0000,SP0001,SP0002
2008	Zafira-B	Body	CIM(Steering Column Module)	√	√	√	√	√	SP0051,SP0003,SP0052,SP0001,SP0004,SP0053,SP0054,SP0005
2008	Zafira-B	Body	IPC ECU(Instrument Control Unit)	√	√	√	√		
2008	Zafira-B	Body	REC(Rear Electrical Centre)	√	√	√	√		
2008	Zafira-B	Body	UEC(Underhood Electrical Centre)	√	√	√	√		
2008	Zafira-B	Body	AHL/AFL(Headlamp Levelling)	√	√	√	√		
2008	Zafira-B	Body	Exterior Lighting/Turn Indicator System	√	√	√	√		

2008	Zafira-B	Body	Interior Lighting	√	√	√	√		
2008	Zafira-B	Body	Wipers/Washer	√	√	√	√		
2008	Zafira-B	Body	Central Door Lock	√	√	√	√		
2008	Zafira-B	Body	Instrument	√	√	√	√	√	SP0055,SP0056,SP0057
2008	Zafira-B	Body	Immobiliser	√	√	√	√		
2008	Zafira-B	Body	ECC/SAC(Electronic Climate Control)	√	√	√	√	√	SP0150,SP0158,SP0159,SP0001,SP0004,S P0160
2008	Zafira-B	Body	EHS(Electrical Heater System)	√	√	√	√		SP0032,SP0001,SP0004
2008	Zafira-B	Body	PAS(Park Pilot)	√	√	√	√	√	SP0001
2008	Zafira-B	Body	SLM(Shift Lever Module)	√	√	√	√		
2008	Zafira-B	Body	PEPS(Open&Start)	√	√	√	√		
2008	Zafira-B	Body	Anti Theft Warning System	√	√	√	√	√	
2008	Zafira-B	Body	IPC ECU(Instrument Control Unit)	√	√	√	√	√	SP0006,SP0055,SP0056,SP0057,SP0058,S P0059,SP0060,SP0001,SP0004
2008	Zafira-B	Chassis	ABS/TC/ESP ECU(Electronic Control Unit)	√	√	√	√	√	
2008	Zafira-B	Chassis	EHPS(Electrohydraulic Power Steering)	√	√	√	√		
2008	Zafira-B	Chassis	TPMS ECU(Tyre Pressure Monitoring)	√	√	√	√		SP0001
2008	Zafira-B	Chassis	TPMS(Tyre Pressure Monitoring System)	√	√	√	√		
2008	Zafira-B	Chassis	ABS/TC/ESP(Vehicle Dynamic System)	√	√	√	√	√	
2008	Zafira-B	Chassis	CDC(Continuous Damping Control)	√	√	√	√		
2008	Zafira-B	Chassis	EHPS(Electrohydraulic Power Steering)	√	√	√	√		SP0003
2008	Zafira-B	Engine	Z16XEP	√	√	√	√		SP0006,SP0007,SP0008,SP0009,SP0019,S P0010,SP0011,SP0066,SP0012,SP0013,SP 0033,SP0018
2008	Zafira-B	Engine	Z16XER	√	√	√	√		SP0019,SP0006,SP0007,SP0008,SP0009,S P0010,SP0011,SP0066,SP0033,SP0012,SP
2008	Zafira-B	Engine	Z18XER	√	√	√	√		SP0019,SP0006,SP0007,SP0008,SP0009,S P0010,SP0011,SP0066,SP0033,SP0012,SP
2008	Zafira-B	Engine	Z19DT	√	√	√	√	√	SP0006,SP0007,SP0008,SP0010,SP0011,S P0066,SP0023,SP0024,SP0069,SP0012,SP 0032,SP0020,SP0029,SP0026,SP0027,SP0 025,SP0028,SP0018
2008	Zafira-B	Engine	Z19DTH	√	√	√	√	√	SP0006,SP0007,SP0008,SP0032,SP0010,S P0011,SP0066,SP0023,SP0024,SP0028,SP 0025,SP0026,SP0027
2008	Zafira-B	Engine	Z16YNG	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0019,S P0010,SP0011,SP0066,SP0012,SP0013,SP 0033,SP0018

2008	Zafira-B	Engine	Z22YH	√	√	√	√	√	SP0006,SP0007,SP0008,SP0071,SP0019,SP0010,SP0011,SP0066,SP0012,SP0013,SP
2008	Zafira-B	Engine	Z20LER	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,SP0011,SP0066,SP0012,SP0013,SP0018
2008	Zafira-B	Engine	Z20LEH	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,SP0011,SP0066,SP0012,SP0013,SP0018
2008	Zafira-B	Engine	Z16XE1	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0173,SP0010,SP0011,SP0066,SP0012,SP0013,SP0033,SP0018
2008	Zafira-B	Engine	Engine(default)	√	√	√			
2008	Zafira-B	Transmission	MTA(Easutronic)	√	√	√	√	√	SP0003,SP0061,SP0034,SP0035
2008	Zafira-B	Transmission	AF 40-6	√	√	√	√	√	SP0072,SP0073,SP0074,SP0075,SP0076,SP0077,SP0032,SP0003,SP0033,SP0078
2008	Zafira-B	Transmission	AF 22-4	√	√	√	√	√	SP0030,SP0032,SP0003,SP0033
2007	Agila	Body	Immobiliser	√	√	√	√		SP0139,SP0140
2007	Agila	Body	Airbag	√	√	√	√		
2007	Agila	Body	Instrument	√	√	√	√		
2007	Agila	Chassis	ABS	√	√	√	√		
2007	Agila	Chassis	Electronic Power Steering	√	√	√	√		
2007	Agila	Engine	Z10XEP	√	√	√	√	√	SP0011,SP0021,SP0065,SP0033
2007	Agila	Engine	Z12XE	√	√	√	√	√	SP0006,SP0145,SP0009,SP0040,SP0019,SP0021,SP0011,SP0065,SP0033
2007	Agila	Engine	Z12XEP	√	√	√	√	√	SP0011,SP0021,SP0065,SP0033
2007	Agila	Engine	Z13DT	√	√	√	√	√	SP0019,SP0040,SP0021,SP0011,SP0020
2007	Antara,Captiva (Short Body)	Body	AHL(Automatic Headlamp Levelling)	√	√	√	√	√	SP0141
2007	Antara,Captiva (Short Body)	Body	Anti Theft Warning System	√	√	√	√	√	
2007	Antara,Captiva (Short Body)	Body	BCM(Body Control Module)	√	√	√	√	√	
2007	Antara,Captiva (Short Body)	Body	ECC(Electronic Climate Control)	√	√	√		√	SP0150,SP0004
2007	Antara,Captiva (Short Body)	Body	Immobiliser	√	√	√	√		
2007	Antara,Captiva (Short Body)	Body	IPC ECU(Instrument Control Unit)	√	√	√	√	√	
2007	Antara,Captiva (Short Body)	Body	Wipers/Washer	√	√	√	√		

2007	Antara,Captiva (Short Body)	Body	PAS(Park Pilot)	√	√	√	√	√	SP0057
2007	Antara,Captiva (Short Body)	Body	XBCM(Auxiliary Body Control Module)	√	√	√	√	√	
2007	Antara,Captiva (Short Body)	Body	Central Door Lock	√	√	√	√	√	
2007	Antara,Captiva (Short Body)	Body	RFA(Multipurpose Receiver Module)	√	√	√	√		
2007	Antara,Captiva (Short Body)	Body	SLM(Shift Lever Module)	√	√	√	√		
2007	Antara,Captiva (Short Body)	Body	HVAC(Heating Ventilation and Cooling)	√	√	√	√		
2007	Antara,Captiva (Short Body)	Body	Interior Lighting	√	√	√	√		
2007	Antara,Captiva (Short Body)	Body	Exterior Lighting/Turn Indicator System	√	√	√	√		
2007	Antara,Captiva (Short Body)	Body	SDM(Airbag)	√	√	√	√		
2007	Antara,Captiva (Short Body)	Chassis	ABS/TC/ESP(Vehicle Dynamic System)	√	√	√	√	√	
2007	Antara,Captiva (Short Body)	Engine	2.0L(Diesel)	√	√	√	√	√	SP0010,SP0011,SP0066,SP0020,SP0024,SP0012,SP0028,SP0025,SP0027,SP0029,SP
2007	Antara,Captiva (Short Body)	Engine	Z24XE	√	√	√	√	√	SP0010,SP0033,SP0015
2007	Antara,Captiva (Short Body)	Engine	Z32SE	√	√	√	√	√	SP0015,SP0018,SP0172
2007	Antara,Captiva (Short Body)	Transmission	TCCM(Transfer Case Control Module)	√	√	√	√		SP0152
2007	Antara,Captiva (Short Body)	Transmission	Automatic Transmission	√	√	√	√	√	SP0170,SP0154,SP0155,SP0156,SP0033
2007	Astra-G	Body	Immobiliser	√	√	√	√		SP0139,SP0140
2007	Astra-G	Body	Instrument	√	√	√	√		
2007	Astra-G	Body	Airbag	√	√	√	√		
2007	Astra-G	Body	Anti Theft Warning	√	√	√	√		
2007	Astra-G	Body	Central Door Lock	√	√	√	√		
2007	Astra-G	Body	Headlamp Levelling Device	√	√	√	√	√	SP0141
2007	Astra-G	Body	Electronic Climate Control	√	√	√	√		
2007	Astra-G	Body	Engine Cooling Module	√	√	√	√		

2007	Astra-G	Body	Add On Heater	√	√	√	√	√	SP0122,SP0123
2007	Astra-G	Body	Softtop Controller	√	√	√	√	√	
2007	Astra-G	Chassis	ABS-5.3/5.4(+TC)	√	√	√	√	√	
2007	Astra-G	Chassis	ESP	√	√	√	√	√	SP0005
2007	Astra-G	Chassis	Cruise Control	√	√	√	√		
2007	Astra-G	Chassis	Electronic Power Steering	√	√	√	√	√	
2007	Astra-G	Engine	Z12XE	√	√	√	√	√	SP0006,SP0145,SP0009,SP0040,SP0019,S P0021,SP0011,SP0065,SP0033
2007	Astra-G	Engine	Z14XE	√			√	√	SP0146,SP0145,SP0009,SP0019,SP0021,S P0011
2007	Astra-G	Engine	Z14XEP	√	√	√	√	√	SP0033,SP0065,SP0006,SP0166,SP0009,S P0146,SP0019,SP0011,SP0021
2007	Astra-G	Engine	C16SEL	√	√	√	√	√	
2007	Astra-G	Engine	Z16SE	√	√	√	√	√	
2007	Astra-G	Engine	Z16XE	√			√	√	
2007	Astra-G	Engine	Z16XEP	√	√	√	√	√	SP0006,SP0146,SP0009,SP0019,SP0011,S P0021,SP0065
2007	Astra-G	Engine	Z16YNG	√	√	√	√	√	SP0006,SP0146,SP0145,SP0009,SP0019,S P0011,SP0021
2007	Astra-G	Engine	Y17DT	√	√	√	√	√	
2007	Astra-G	Engine	Z17DTL	√	√	√	√	√	
2007	Astra-G	Engine	Z18XE	√	√	√	√	√	SP0145,SP0009,SP0040,SP0019,SP0011,S P0021
2007	Astra-G	Engine	Z18XEL	√	√	√			SP0011,SP0021
2007	Astra-G	Engine	Y20DTH	√	√	√	√	√	SP0166,SP0167,SP0168,SP0169
2007	Astra-G	Engine	Z20LET	√	√	√	√	√	SP0009,SP0019,SP0040,SP0145,SP0011,S P0021,SP0065,SP0033
2007	Astra-G	Engine	Y22DTR	√	√	√	√	√	SP0011,SP0021
2007	Astra-G	Engine	Z22SE	√	√	√	√	√	SP0065,SP0146,SP0145,SP0009,SP0011,S P0021,SP0033
2007	Astra-G	Transmission	AF 13-II/17/20/22	√	√	√	√	√	
2007	Astra-G	Transmission	AF 13-II/17/20/22 CAN	√	√	√	√	√	
2007	Astra-H	Body	SDM(Airbag)	√	√	√	√		
2007	Astra-H	Body	CIM(Steering Column Module)	√	√	√	√	√	SP0051,SP0003,SP0052,SP0001,SP0004,S P0053,SP0054,SP0005
2007	Astra-H	Body	IPC ECU(Instrument Control Unit)	√	√	√	√		
2007	Astra-H	Body	REC(Rear Electrical Centre)	√	√	√	√		
2007	Astra-H	Body	UEC(Underhood Electrical Centre)	√	√	√	√		

2007	Astra-H	Body	AHL/AFL(Headlamp Levelling)	√	√	√	√		
2007	Astra-H	Body	Exterior Lighting/Turn Indicator System	√	√	√	√		
2007	Astra-H	Body	Interior Lighting	√	√	√	√		
2007	Astra-H	Body	Wipers/Washer	√	√	√	√		
2007	Astra-H	Body	Central Door Lock	√	√	√	√		
2007	Astra-H	Body	Instrument	√	√	√	√	√	SP0055,SP0056,SP0057
2007	Astra-H	Body	Immobiliser	√	√	√	√		
2007	Astra-H	Body	Anti Theft Warning System	√	√	√	√	√	
2007	Astra-H	Body	Electrohydraulic HardTop	√	√	√	√	√	SP0001,SP0004
2007	Astra-H	Body	ECC/SAC(Electronic Climate Control)	√	√	√	√	√	SP0150,SP0158,SP0159,SP0032,SP0001,SP0004,SP0160
2007	Astra-H	Body	EHS(Electrical Heater System)	√	√	√	√		SP0032,SP0001,SP0004
2007	Astra-H	Body	PAS(Park Pilot)	√	√	√	√	√	SP0001
2007	Astra-H	Body	SLM(Shift Lever Module)	√	√	√	√		
2007	Astra-H	Body	PEPS(Open&Start)	√	√	√	√		
2007	Astra-H	Body	IPC ECU(Instrument Control Unit)	√	√	√	√	√	SP0006,SP0055,SP0056,SP0057,SP0058,SP0059,SP0060,SP0001,SP0004
2007	Astra-H	Chassis	ABS/TC/ESP ECU(Electronic Control Unit)	√	√	√	√	√	
2007	Astra-H	Chassis	EHPS(Electrohydraulic Power Steering)	√	√	√	√		
2007	Astra-H	Chassis	TPMS ECU(Tyre Pressure Monitoring)	√	√	√	√		SP0001
2007	Astra-H	Chassis	TPMS(Tyre Pressure Monitoring System)	√	√	√	√		
2007	Astra-H	Chassis	CDC(Continuous Damping Control)	√	√	√	√		
2007	Astra-H	Chassis	ABS/TC/ESP(Vehicle Dynamic System)	√	√	√	√	√	
2007	Astra-H	Chassis	EHPS(Electrohydraulic Power Steering)	√	√	√	√		SP0003
2007	Astra-H	Engine	Z13DTH	√	√	√	√	√	SP0006,SP0007,SP0008,SP0019,SP0010,SP0011,SP0066,SP0020,SP0029,SP0028,SP0025,SP0026,SP0018
2007	Astra-H	Engine	Z14XEL	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,SP0011,SP0066,SP0012,SP0013,SP0018
2007	Astra-H	Engine	Z14XEP	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,SP0011,SP0066,SP0012,SP0013,SP0018
2007	Astra-H	Engine	Z16XEP	√	√	√	√		SP0006,SP0007,SP0008,SP0009,SP0019,SP0010,SP0011,SP0066,SP0012,SP0013,SP0033,SP0018
2007	Astra-H	Engine	Z16XER	√	√	√	√		SP0019,SP0006,SP0007,SP0008,SP0009,SP0010,SP0011,SP0066,SP0033,SP0012,SP

2007	Astra-H	Engine	Z17DTH	√	√	√	√	√	SP0006,SP0007,SP0008,SP0010,SP0011,S P0066,SP0020,SP0024,SP0012,SP0029,SP 0032,SP0018
2007	Astra-H	Engine	Z17DTR	√	√	√	√	√	SP0006,SP0007,SP0008,SP0019,SP0010,S P0011,SP0066,SP0014,SP0022,SP0023,SP 0024,SP0012,SP0025,SP0026,SP0027,SP0 028,SP0029,SP0020,SP0018
2007	Astra-H	Engine	Z17DTJ	√	√	√	√	√	SP0006,SP0007,SP0008,SP0019,SP0010,S P0011,SP0066,SP0014,SP0022,SP0023,SP 0024,SP0012,SP0025,SP0026,SP0027,SP0 028,SP0029,SP0020,SP0018
2007	Astra-H	Engine	Z18XE	√	√	√	√		SP0019,SP0006,SP0007,SP0008,SP0009,S P0010,SP0011,SP0066,SP0012,SP0018
2007	Astra-H	Engine	Z18XER	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0019,S P0010,SP0011,SP0066,SP0033,SP0012,SP
2007	Astra-H	Engine	Z19DT	√	√	√	√	√	SP0006,SP0007,SP0008,SP0010,SP0011,S P0066,SP0023,SP0024,SP0069,SP0012,SP 0032,SP0020,SP0029,SP0026,SP0027,SP0 025,SP0028,SP0018
2007	Astra-H	Engine	Z19DTH	√	√	√	√	√	SP0006,SP0007,SP0008,SP0010,SP0011,S P0066,SP0023,SP0024,SP0069,SP0012,SP 0032,SP0020,SP0029,SP0026,SP0027,SP0 025,SP0028,SP0018
2007	Astra-H	Engine	Z12XEP	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,S P0011,SP0066,SP0012,SP0013,SP0018
2007	Astra-H	Engine	Y13DTH	√	√	√	√	√	SP0019,SP0010,SP0011,SP0066,SP0020,S P0029,SP0028,SP0025,SP0026,SP0018
2007	Astra-H	Engine	Z16XE1	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0019,S P0010,SP0011,SP0066,SP0012,SP0013,SP 0033,SP0018
2007	Astra-H	Engine	Z16LET	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,S P0011,SP0066,SP0012,SP0013,SP0018
2007	Astra-H	Engine	Z17DTL	√	√	√	√	√	SP0010,SP0011,SP0066,SP0020,SP0024,S P0012,SP0029,SP0032,SP0018
2007	Astra-H	Engine	Z19DTJ	√	√	√		√	SP0010,SP0011,SP0066,SP0023,SP0024,S P0069,SP0012,SP0032,SP0020,SP0029,SP 0026,SP0027,SP0025,SP0028,SP0018

2007	Astra-H	Engine	Z20LEL	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,SP0011,SP0066,SP0012,SP0013,SP0018
2007	Astra-H	Engine	Z20LEH	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,SP0011,SP0066,SP0012,SP0013,SP0018
2007	Astra-H	Engine	Z20LER	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,SP0011,SP0066,SP0012,SP0013,SP0018
2007	Astra-H	Engine	Z22YH	√	√	√	√	√	SP0006,SP0007,SP0008,SP0071,SP0019,SP0010,SP0011,SP0066,SP0012,SP0018
2007	Astra-H	Engine	Engine(default)	√	√	√			
2007	Astra-H	Infotainment System	EHU(Entertainment Head Unit)	√	√	√			
2007	Astra-H	Infotainment System	DIS(Info Display TID,BID,GID,CID)	√	√	√			
2007	Astra-H	Transmission	AF 17-4	√	√	√	√	√	SP0030,SP0031,SP0032,SP0003,SP0033
2007	Astra-H	Transmission	AF 40-6	√	√	√	√	√	SP0072,SP0073,SP0074,SP0075,SP0076,SP0077,SP0032,SP0003,SP0033,SP0078
2007	Astra-H	Transmission	AF 22-4	√	√	√	√	√	SP0030,SP0032,SP0003,SP0033
2007	Astra-H	Transmission	MTA(Easytronic)	√	√	√	√	√	SP0003,SP0061,SP0034,SP0035
2007	Astra-H	Transmission	MTA(Easytronic Magneti Marelli)	√	√	√	√	√	
2007	Captiva(Long Body)	Body	BCM(Body Control Module)	√	√	√	√	√	
2007	Captiva(Long Body)	Body	ECC(Electronic Climate Control)	√	√	√		√	SP0150,SP0004
2007	Captiva(Long Body)	Body	Immobiliser	√	√	√	√		
2007	Captiva(Long Body)	Body	IPC ECU(Instrument Control Unit)	√	√	√	√	√	
2007	Captiva(Long Body)	Body	XBCM(Auxiliary Body Control Module)	√	√	√	√	√	
2007	Captiva(Long Body)	Body	RFA(Multipurpose Receiver Module)	√	√	√	√		
2007	Captiva(Long Body)	Chassis	ABS/TC/ESP(Vehicle Dynamic System)	√	√	√	√	√	
2007	Captiva(Long Body)	Engine	2.0L(Diesel)	√	√	√	√	√	SP0010,SP0011,SP0066,SP0020,SP0024,SP0012,SP0028,SP0025,SP0027,SP0029,SP
2007	Captiva(Long Body)	Engine	Z32SE	√	√	√	√	√	

2007	Captiva(Long Body)	Transmission	TCCM(Transfer Case Control Module)	√	√	√	√		SP0152
2007	Captiva(Long Body)	Transmission	Automatic Transmission	√	√	√	√	√	SP0170,SP0154,SP0155,SP0156,SP0033
2007	Combo	Body	Add On Heater	√	√	√	√	√	SP0122,SP0123
2007	Combo	Body	Airbag	√	√	√	√	√	
2007	Combo	Body	Body Control Module	√	√	√	√	√	SP0051,SP0058,SP0138
2007	Combo	Body	HeadLamp Levelling Device		√	√	√	√	SP0141
2007	Combo	Body	Instrument	√	√	√	√		
2007	Combo	Body	Immobiliser	√	√	√	√		SP0164,SP0165
2007	Combo	Chassis	ABS8/ESP8(Anti-lock Braking System/Electronic Stability Program)		√	√	√	√	SP0005,SP0142,SP0143,SP0144,SP0004
2007	Combo	Chassis	ABS-5.3/5.4 (+TC)(Anti-lock Braking System)	√	√	√	√	√	
2007	Combo	Chassis	Electronic Power Steering	√	√	√	√		SP0141
2007	Combo	Engine	Z10XEP	√	√	√	√	√	SP0011,SP0021,SP0065,SP0033
2007	Combo	Engine	Z12XE	√	√	√	√	√	SP0006,SP0145,SP0009,SP0040,SP0019,SP0021,SP0011,SP0065,SP0033
2007	Combo	Engine	Z12XEP	√	√	√	√	√	SP0011,SP0021,SP0065,SP0033
2007	Combo	Engine	Y13DT	√	√	√	√	√	SP0040,SP0019,SP0021,SP0011,SP0020
2007	Combo	Engine	Z13DT	√	√	√	√	√	SP0040,SP0019,SP0021,SP0011,SP0020
2007	Combo	Engine	Z13DTJ	√	√	√	√	√	SP0040,SP0019,SP0028,SP0025,SP0041,SP0021,SP0011,SP0020,SP0042
2007	Combo	Engine	Z14XE						
2007	Combo	Engine	Z14XEP	√	√	√	√	√	SP0006,SP0166,SP0009,SP0146,SP0019,SP0011,SP0021,SP0065,SP0033
2007	Combo	Engine	Z16SE	√	√	√	√	√	
2007	Combo	Engine	Z16YNG	√	√	√	√	√	SP0006,SP0146,SP0145,SP0009,SP0019,SP0011,SP0021
2007	Combo	Engine	Y17DT	√	√	√	√	√	
2007	Combo	Engine	Y17DTL	√	√	√	√	√	
2007	Combo	Engine	Z17DTH		√	√	√		
2007	Combo	Engine	Z18XE	√	√	√	√	√	SP0145,SP0009,SP0040,SP0019,SP0011,SP0021
2007	Combo	Infotainment System	Trip Info Display TID	√	√	√			
2007	Combo	Transmission	AF 13-II/17/20/22 CAN	√	√	√	√	√	
2007	Combo	Transmission	Easytronic(MTA)	√	√	√	√	√	SP0011,SP0148
2007	Corsa-C	Body	Body Control Module	√	√	√	√	√	SP0051,SP0058,SP0138

2007	Corsa-C	Body	Immobiliser	√	√	√	√		SP0139,SP0140
2007	Corsa-C	Body	Airbag	√	√	√	√	√	
2007	Corsa-C	Body	Instrument	√	√	√	√	√	SP0176,SP0177
2007	Corsa-C	Body	Add On Heater	√	√	√	√	√	SP0122,SP0123
2007	Corsa-C	Body	HeadLamp Levelling Device		√	√	√	√	SP0141
2007	Corsa-C	Chassis	ABS-5.3/5.4(+TC)	√	√	√	√	√	
2007	Corsa-C	Chassis	ABS8/ESP8		√	√	√	√	SP0005,SP0142,SP0143,SP0144,SP0004
2007	Corsa-C	Chassis	Electronic Power Steering	√	√	√	√		SP0141
2007	Corsa-C	Engine	Z10XEP	√	√	√	√	√	SP0011,SP0021,SP0065,SP0033
2007	Corsa-C	Engine	Z12XE	√	√	√	√	√	SP0006,SP0145,SP0009,SP0040,SP0019,SP0021,SP0011,SP0065,SP0033
2007	Corsa-C	Engine	Z12XEP	√	√	√	√	√	SP0011,SP0021,SP0065,SP0033
2007	Corsa-C	Engine	Y13DT	√	√	√	√	√	SP0040,SP0019,SP0021,SP0011,SP0020
2007	Corsa-C	Engine	Z13DT	√	√	√	√	√	SP0019,SP0040,SP0021,SP0011,SP0020
2007	Corsa-C	Engine	Z14XE	√			√	√	SP0146,SP0145,SP0009,SP0019,SP0021,SP0011
2007	Corsa-C	Engine	Z14XEP	√	√	√	√	√	SP0033,SP0065,SP0006,SP0166,SP0009,SP0146,SP0019,SP0011,SP0021
2007	Corsa-C	Engine	Z16SE	√	√	√	√	√	
2007	Corsa-C	Engine	Z16YNG	√	√	√	√	√	SP0006,SP0146,SP0145,SP0009,SP0019,SP0011,SP0021
2007	Corsa-C	Engine	Y17DT	√	√	√	√	√	
2007	Corsa-C	Engine	Y17DTL	√	√	√	√	√	
2007	Corsa-C	Engine	Z17DTH	√	√	√	√	√	SP0006,SP0146,SP0019,SP0020,SP0147,SP0022,SP0011,SP0021
2007	Corsa-C	Engine	Z18XE	√	√	√	√	√	SP0145,SP0009,SP0040,SP0019,SP0011,SP0021
2007	Corsa-C	Engine	Z13DTJ	√	√	√	√	√	SP0040,SP0019,SP0028,SP0025,SP0041,SP0021,SP0011,SP0020,SP0042
2007	Corsa-C	Transmission	AF 13-II/17/20/22 CAN	√	√	√	√	√	
2007	Corsa-C	Transmission	MTA(Easytronic)	√	√	√	√	√	SP0011,SP0148
2007	Corsa-D	Body	SDM(Airbag)	√	√	√	√		SP0000,SP0001,SP0002
2007	Corsa-D	Body	IPC(Instrument)	√	√	√	√	√	SP0006,SP0055,SP0056,SP0057,SP0001,SP0004
2007	Corsa-D	Body	Central Door Lock	√	√	√	√	√	
2007	Corsa-D	Body	Exterior Lighting	√	√	√	√		
2007	Corsa-D	Body	Interior Lighting	√	√	√	√		
2007	Corsa-D	Body	Wipers/Washer	√	√	√	√		

2007	Corsa-D	Body	Anti Theft Warning System	√	√	√	√		
2007	Corsa-D	Body	Immobiliser	√	√	√	√		
2007	Corsa-D	Body	AFL(Adaptive Forward Lighting)	√	√	√	√		
2007	Corsa-D	Body	EHS(Electrical Heater System)	√	√	√	√		
2007	Corsa-D	Body	IPC ECU(Instrument Control Unit)	√	√	√	√	√	SP0006,SP0055,SP0056,SP0057,SP0001,SP0004
2007	Corsa-D	Body	PAS(Park Pilot)	√	√	√	√		
2007	Corsa-D	Body	TIM(Trailer Interface Module)	√	√	√	√		
2007	Corsa-D	Body	SDM(Airbag)	√	√	√	√		SP0000,SP0001,SP0002
2007	Corsa-D	Chassis	ABS/ESP	√	√	√	√	√	SP0003,SP0004,SP0178,SP0062
2007	Corsa-D	Chassis	Electronic Power Steering	√	√	√	√		
2007	Corsa-D	Engine	Z10XEP	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,SP0011,SP0012,SP0013,SP0014
2007	Corsa-D	Engine	Z12XEP	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,SP0011,SP0012,SP0013,SP0014
2007	Corsa-D	Engine	Z13DTJ	√	√	√	√	√	SP0019,SP0010,SP0011,SP0014,SP0020
2007	Corsa-D	Engine	Z13DTH	√	√	√	√	√	SP0019,SP0010,SP0011,SP0014,SP0020
2007	Corsa-D	Engine	Z14XEP	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,SP0011,SP0012,SP0013,SP0014
2007	Corsa-D	Engine	Z17DTR	√	√	√	√	√	SP0019,SP0021,SP0011,SP0014,SP0022,SP0023,SP0024,SP0012,SP0025,SP0026,SP0027,SP0028,SP0020,SP0029
2007	Corsa-D	Engine	Z16LEL	√	√	√	√	√	SP0009,SP0010,SP0011,SP0066,SP0012,SP0013,SP0014
2007	Corsa-D	Engine	Z16LER	√	√	√	√	√	SP0009,SP0010,SP0011,SP0066,SP0012,SP0013,SP0014
2007	Corsa-D	Engine	Engine(default)	√	√	√			
2007	Corsa-D	Transmission	AF 13-4	√	√	√	√	√	SP0030,SP0031,SP0032,SP0033
2007	Corsa-D	Transmission	MTA(Easytronic)	√	√	√	√	√	SP0034,SP0035
2007	Meriva	Body	Body Control Module	√	√	√	√	√	SP0051,SP0058,SP0138
2007	Meriva	Body	Immobiliser	√	√	√	√		SP0139,SP0140
2007	Meriva	Body	Airbag	√	√	√	√	√	
2007	Meriva	Body	Instrument	√	√	√	√	√	SP0176,SP0177
2007	Meriva	Body	Headlamp Levelling Device	√	√	√	√	√	SP0141
2007	Meriva	Body	Electronic Climate Control	√	√	√	√	√	
2007	Meriva	Body	EHS(Electrical Heater System)	√	√	√	√	√	
2007	Meriva	Body	Add On Heater	√	√	√	√	√	SP0122,SP0123
2007	Meriva	Chassis	ABS/ESP8		√	√	√	√	SP0005,SP0142,SP0143,SP0144,SP0004

2007	Meriva	Chassis	Electronic Power Steering	√	√	√	√		SP0141
2007	Meriva	Engine	Y13DT	√	√	√	√	√	SP0040,SP0019,SP0021,SP0011,SP0020
2007	Meriva	Engine	Z13DT	√	√	√	√	√	SP0019,SP0040,SP0021,SP0011,SP0020
2007	Meriva	Engine	Z14XEP	√	√	√	√	√	SP0033,SP0065,SP0006,SP0166,SP0009,S P0146,SP0019,SP0011,SP0021
2007	Meriva	Engine	Z16SE	√	√	√	√	√	
2007	Meriva	Engine	Z16XE	√			√	√	
2007	Meriva	Engine	Z16XEP	√	√	√	√	√	SP0006,SP0146,SP0009,SP0019,SP0011,S P0021,SP0065
2007	Meriva	Engine	Y17DT	√	√	√	√	√	
2007	Meriva	Engine	Z17DTH	√	√	√	√	√	SP0006,SP0146,SP0019,SP0020,SP0147,S P0022,SP0011,SP0021
2007	Meriva	Engine	Z18XE	√	√	√	√	√	SP0145,SP0009,SP0040,SP0019,SP0011,S P0021
2007	Meriva	Engine	Z13DTJ	√	√	√	√	√	SP0040,SP0019,SP0028,SP0025,SP0041,S P0021,SP0011,SP0020,SP0042
2007	Meriva	Engine	Z16LET	√	√	√	√	√	SP0006,SP0146,SP0009,SP0019,SP0011,S P0021,SP0065
2007	Meriva	Engine	Z16YNG	√	√	√	√	√	SP0006,SP0146,SP0145,SP0009,SP0019,S P0011,SP0021
2007	Meriva	Engine	C16SEL	√	√	√	√	√	
2007	Meriva	Engine	Z17DT	√	√	√	√	√	SP0006,SP0146,SP0019,SP0022,SP0011,S P0021,SP0020,SP0147
2007	Meriva	Engine	Z17DTR	√	√	√	√		
2007	Meriva	Transmission	MTA(Easytronic)	√	√	√	√	√	SP0011,SP0148
2007	Movano	Body	Airbag	√	√	√	√		
2007	Movano	Body	Body Control Module	√	√	√	√	√	SP0051,SP0058,SP0138
2007	Movano	Body	Park Pilot		√	√	√		
2007	Movano	Chassis	ABS/ESP(Anti-lock Braking System/Electronic Stability Program)		√	√	√	√	SP0164,SP0165
2007	Movano	Chassis	Pneumatic Suspension		√	√	√	√	
2007	Movano	Transmission	MTA(Tecshift)		√	√	√	√	
2007	Speedster/VX22	Body	Immobiliser	√	√	√	√		SP0139,SP0140
2007	Speedster/VX22	Body	Airbag	√	√	√	√		
2007	Speedster/VX22	Chassis	ABS 430	√	√	√	√		
2007	Speedster/VX22	Engine	Z20LET	√	√	√	√		
2007	Speedster/VX22 0	Engine	Z22SE	√	√	√	√	√	SP0065,SP0146,SP0145,SP0009,SP0011,S P0021,SP0033

2007	Tigra-B	Body	Body Control Module	√	√	√	√	√	SP0051,SP0058,SP0138
2007	Tigra-B	Body	Immobiliser	√	√	√	√		SP0139,SP0140
2007	Tigra-B	Body	Airbag	√	√	√	√	√	
2007	Tigra-B	Body	Instrument	√	√	√	√	√	SP0176,SP0177
2007	Tigra-B	Body	Electrohydraulic HardTop	√	√	√	√	√	
2007	Tigra-B	Chassis	ABS8/ESP8		√	√	√	√	SP0005,SP0142,SP0143,SP0144,SP0004
2007	Tigra-B	Chassis	Electronic Power Steering	√	√	√	√		SP0141
2007	Tigra-B	Engine	Z13DT	√	√	√	√	√	SP0019,SP0040,SP0021,SP0011,SP0020
2007	Tigra-B	Engine	Z14XEP	√	√	√	√	√	SP0033,SP0065,SP0006,SP0166,SP0009,S P0146,SP0019,SP0011,SP0021
2007	Tigra-B	Engine	Z18XE	√	√	√	√	√	SP0145,SP0009,SP0040,SP0019,SP0011,S P0021
2007	Tigra-B	Transmission	MTA(Easytronic)	√	√	√	√	√	SP0011,SP0148
2007	Vauxhall VXR8	Body	AHL(Automatic Headlamp Levelling)	√	√	√	√		
2007	Vauxhall VXR8	Body	BCM(Body Control Module)	√	√	√	√		
2007	Vauxhall VXR8	Body	HVAC(Heating Ventilation and Cooling)	√	√	√	√		
2007	Vauxhall VXR8	Body	Immobiliser	√	√	√	√		
2007	Vauxhall VXR8	Body	MSM(Memory Seat and Mirrors)	√	√	√	√		
2007	Vauxhall VXR8	Body	Park Assist	√	√	√	√		
2007	Vauxhall VXR8	Body	SDM(Sensing and Diagnostic Module)	√	√	√	√		
2007	Vauxhall VXR8	Body	IPC(Instrument Panel Cluster)	√	√	√	√		
2007	Vauxhall VXR8	Body	RFA(Multipurpose Receiver Module)	√	√	√	√		
2007	Vauxhall VXR8	Chassis	EBCM(Electronic Brake Control Module)	√	√	√	√	√	
2007	Vauxhall VXR8	Chassis	ESC(Electronic Suspension Control)	√	√	√	√		
2007	Vauxhall VXR8	Engine	V8 GEN IV	√	√	√	√	√	SP0015,SP0149,SP0171,SP0172
2007	Vauxhall VXR8	Transmission	Automatic Transmission	√	√	√	√	√	
2007	Vectra-	Body	SDM(Airbag,Sensing&Diagnostic Module)	√	√	√	√		SP0000,SP0001,SP0002
2007	Vectra-	Body	Instrument	√	√	√	√	√	SP0169,SP0056,SP0057,SP0179,SP0001
2007	Vectra- C/Signum	Body	CIM(Steering Column Module)	√	√	√	√	√	SP0051,SP0003,SP0052,SP0001,SP0004,S P0053,SP0054,SP0005
2007	Vectra-	Body	BCM(Body Control Module)	√	√	√			SP0180,SP0181
2007	Vectra-	Body	DDM(Driver Door Module)	√	√	√			
2007	Vectra-	Body	PDM(Passenger Door Module)	√	√	√			
2007	Vectra-	Body	REC(Rear Electrical Centre)	√	√	√	√		
2007	Vectra-	Body	UEC(Underhood Electrical Centre)	√	√	√	√		
2007	Vectra-	Body	SLM(Shift Lever Module)	√	√	√			
2007	Vectra-	Body	SRM(Sun Roof Module)	√	√	√			
2007	Vectra-	Body	AHL/AFL(Headlamp Levelling)	√	√	√			

2007	Vectra-	Body	Electrical Horn	√	√	√	√	√	
2007	Vectra-C/Signum	Body	SAC(Automatic Climate Control)	√	√	√	√	√	SP0150,SP0158,SP0159,SP0001,SP0004,S P0160
2007	Vectra-	Body	Interior Lighting	√	√	√	√	√	SP0182,SP0059
2007	Vectra-	Body	Electronic Seat Memory/Seat Heating	√	√	√	√		
2007	Vectra-	Body	Anti Theft Warning System	√	√	√	√	√	
2007	Vectra-	Body	Central Door Lock	√	√	√	√		
2007	Vectra-	Body	EHS(Electrical Heater System)	√	√	√	√	√	SP0032,SP0001,SP0004
2007	Vectra-	Body	PAS(Park Pilot)	√	√	√	√	√	SP0001
2007	Vectra-	Chassis	ABS/TC/ESP	√	√	√	√	√	
2007	Vectra-	Chassis	EHPS(Electronic Power Steering)	√	√	√	√		
2007	Vectra-	Chassis	TPMS (Tyre Pressure Monitoring System)	√	√	√	√		SP0032
2007	Vectra-	Chassis	CDC(Continuous Damping Control)	√	√	√			
2007	Vectra-	Chassis	Electronic Cruise Control	√	√	√			
2007	Vectra-	Engine	Engine Cooling	√	√	√	√		
2007	Vectra-	Engine	Z16XEP	√	√	√	√	√	SP0010,SP0011,SP0066,SP0013,SP0149
2007	Vectra-C/Signum	Engine	Z18XE	√	√	√	√	√	SP0019,SP0010,SP0011,SP0066,SP0149,S P0012
2007	Vectra-C/Signum	Engine	Z18XER	√	√	√	√	√	SP0019,SP0009,SP0010,SP0011,SP0066,S P0149,SP0033,SP0012
2007	Vectra-C/Signum	Engine	Z19DT	√	√	√	√	√	SP0149,SP0010,SP0011,SP0066,SP0023,S P0024,SP0069,SP0020,SP0012,SP0026,SP
2007	Vectra-C/Signum	Engine	Z19DTH	√	√	√	√	√	SP0149,SP0010,SP0011,SP0066,SP0023,S P0024,SP0028,SP0025,SP0026,SP0020,SP 0012,SP0027,SP0029
2007	Vectra-	Engine	Y20DTH	√	√	√	√	√	SP0010,SP0011,SP0066,SP0149
2007	Vectra-	Engine	Y22DTR	√	√	√	√	√	SP0010,SP0011,SP0066,SP0149
2007	Vectra-	Engine	Z22SE	√	√	√	√	√	SP0010,SP0011,SP0066,SP0149
2007	Vectra-	Engine	Z22YH	√	√	√	√	√	SP0019,SP0149
2007	Vectra-	Engine	Z32SE	√	√	√	√	√	SP0019,SP0149
2007	Vectra-	Engine	Engine(default)>	√	√	√			
2007	Vectra-	Engine	Z16XE	√	√	√	√	√	SP0010,SP0011,SP0066,SP0149,SP0012
2007	Vectra-	Engine	Z20NET	√	√	√	√	√	SP0010,SP0011,SP0066,SP0149
2007	Vectra-C/Signum	Engine	Z28NEH	√	√	√	√	√	SP0009,SP0019,SP0040,SP0183,SP0184,S P0185,SP0011,SP0066,SP0149
2007	Vectra-C/Signum	Engine	Z28NEL	√	√	√	√	√	SP0009,SP0019,SP0040,SP0183,SP0184,S P0185,SP0011,SP0066,SP0149

2007	Vectra-C/Signum	Engine	Z28NET	√	√	√	√	√	SP0009,SP0019,SP0040,SP0183,SP0184,SP0185,SP0011,SP0066,SP0149
2007	Vectra-	Engine	Z30DT	√	√	√	√	√	SP0019,SP0010,SP0066,SP0029
2007	Vectra-	Transmission	AF 23-5/33-5/40-6	√	√	√	√	√	SP0032,SP0033
2007	Vectra-C/Signum	Transmission	CVTronic	√	√	√	√	√	SP0186,SP0187,SP0188,SP0032,SP0003,SP0033
2007	Vectra-	Transmission	MTA(Easytronic)	√	√	√	√	√	
2007	Vivaro	Body	Airbag		√	√	√		SP0004
2007	Vivaro	Body	Park Pilot		√	√	√		
2007	Vivaro	Body	Add On Heater	√	√	√	√	√	SP0122,SP0123
2007	Vivaro	Body	Body Control Module		√	√	√	√	
2007	Vivaro	Chassis	ABS/ESP(Anti-lock Braking System/Electronic Stability Program)	√	√	√	√	√	SP0174,SP0175
2007	Vivaro	Engine	F9Q 760/762 (1.9L)	√	√	√	√		
2007	Vivaro	Transmission	MTA(Tecshift)		√	√	√	√	
2007	Zafira-B	Body	SDM(Airbag)	√	√	√	√		SP0000,SP0001,SP0002
2007	Zafira-B	Body	CIM(Steering Column Module)	√	√	√	√	√	SP0051,SP0003,SP0052,SP0001,SP0004,SP0053,SP0054,SP0005
2007	Zafira-B	Body	IPC ECU(Instrument Control Unit)	√	√	√	√		
2007	Zafira-B	Body	REC(Rear Electrical Centre)	√	√	√	√		
2007	Zafira-B	Body	UEC(Underhood Electrical Centre)	√	√	√	√		
2007	Zafira-B	Body	AHL/AFL(Headlamp Levelling)	√	√	√	√		
2007	Zafira-B	Body	Exterior Lighting/Turn Indicator System	√	√	√	√		
2007	Zafira-B	Body	Interior Lighting	√	√	√	√		
2007	Zafira-B	Body	Wipers/Washer	√	√	√	√		
2007	Zafira-B	Body	Central Door Lock	√	√	√	√		
2007	Zafira-B	Body	Instrument	√	√	√	√	√	SP0055,SP0056,SP0057
2007	Zafira-B	Body	Immobiliser	√	√	√	√		
2007	Zafira-B	Body	ECC/SAC(Electronic Climate Control)	√	√	√	√	√	SP0150,SP0158,SP0159,SP0001,SP0004,SP0160
2007	Zafira-B	Body	EHS(Electrical Heater System)	√	√	√	√		SP0032,SP0001,SP0004
2007	Zafira-B	Body	PAS(Park Pilot)	√	√	√	√	√	SP0001
2007	Zafira-B	Body	SLM(Shift Lever Module)	√	√	√	√		
2007	Zafira-B	Body	PEPS(Open&Start)	√	√	√	√		
2007	Zafira-B	Body	Anti Theft Warning System	√	√	√	√	√	
2007	Zafira-B	Body	IPC ECU(Instrument Control Unit)	√	√	√	√	√	SP0006,SP0055,SP0056,SP0057,SP0058,SP0059,SP0060,SP0001,SP0004
2007	Zafira-B	Chassis	ABS/TC/ESP ECU(Electronic Control Unit)	√	√	√	√	√	

2007	Zafira-B	Chassis	EHPS(Electrohydraulic Power Steering)	√	√	√	√		
2007	Zafira-B	Chassis	ABS/TC/ESP(Vehicle Dynamic System)	√	√	√	√	√	SP0005
2007	Zafira-B	Chassis	TPMS ECU(Tyre Pressure Monitoring)	√	√	√	√		SP0001
2007	Zafira-B	Chassis	TPMS(Tyre Pressure Monitoring System)	√	√	√	√		
2007	Zafira-B	Chassis	CDC(Continuous Damping Control)	√	√	√	√		
2007	Zafira-B	Chassis	EHPS(Electrohydraulic Power Steering)	√	√	√	√		SP0003
2007	Zafira-B	Engine	Z16XEP	√	√	√	√		SP0006,SP0007,SP0008,SP0009,SP0019,S P0010,SP0011,SP0066,SP0012,SP0013,SP 0033,SP0018
2007	Zafira-B	Engine	Z18XER	√	√	√	√		SP0019,SP0006,SP0007,SP0008,SP0009,S P0010,SP0011,SP0066,SP0033,SP0012,SP
2007	Zafira-B	Engine	Z19DT	√	√	√	√	√	SP0006,SP0007,SP0008,SP0010,SP0011,S P0066,SP0023,SP0024,SP0069,SP0012,SP 0032,SP0020,SP0029,SP0026,SP0027,SP0 025,SP0028,SP0018
2007	Zafira-B	Engine	Z19DTH	√	√	√	√	√	SP0006,SP0007,SP0008,SP0032,SP0010,S P0011,SP0066,SP0023,SP0024,SP0028,SP 0025,SP0026,SP0027
2007	Zafira-B	Engine	Z16XE1	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0173,S P0010,SP0011,SP0066,SP0012,SP0013,SP 0033,SP0018
2007	Zafira-B	Engine	Z16XER	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0019,S P0010,SP0011,SP0066,SP0033,SP0012,SP
2007	Zafira-B	Engine	Z16YNG	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0019,S P0010,SP0011,SP0066,SP0012,SP0013,SP 0033,SP0018
2007	Zafira-B	Engine	Z20LER	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,S P0011,SP0066,SP0012,SP0013,SP0018
2007	Zafira-B	Engine	Z20LEH	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,S P0011,SP0066,SP0012,SP0013,SP0018
2007	Zafira-B	Engine	Z22YH	√	√	√	√	√	SP0006,SP0007,SP0008,SP0071,SP0019,S P0010,SP0011,SP0066,SP0012,SP0013,SP
2007	Zafira-B	Engine	Engine(default)	√	√	√			
2007	Zafira-B	Transmission	MTA(Easutronic)	√	√	√	√	√	SP0003,SP0061,SP0034,SP0035
2007	Zafira-B	Transmission	AF 40-6	√	√	√	√	√	SP0072,SP0073,SP0074,SP0075,SP0076,S P0077,SP0032,SP0003,SP0033,SP0078
2007	Zafira-B	Transmission	AF 22-4	√	√	√	√	√	SP0030,SP0032,SP0003,SP0033
2006	Agila	Body	Immobiliser	√	√	√	√		SP0139,SP0140

2006	Agila	Body	Airbag	√	√	√	√		
2006	Agila	Body	Instrument	√	√	√	√		
2006	Agila	Chassis	ABS	√	√	√	√	√	SP0190
2006	Agila	Chassis	Electronic Power Steering	√	√	√	√		
2006	Agila	Engine	Z10XEP	√	√	√	√	√	SP0011,SP0021,SP0065,SP0033
2006	Agila	Engine	Z12XE	√	√	√	√	√	SP0006,SP0145,SP0009,SP0040,SP0019,SP0021,SP0011,SP0065,SP0033
2006	Agila	Engine	Z12XEP	√	√	√	√	√	SP0011,SP0021,SP0065,SP0033
2006	Agila	Engine	Z13DT	√	√	√	√	√	SP0019,SP0040,SP0021,SP0011,SP0020
2006	Astra-G	Body	Immobiliser	√	√	√	√		SP0139,SP0140
2006	Astra-G	Body	Instrument	√	√	√	√		
2006	Astra-G	Body	Airbag	√	√	√	√		
2006	Astra-G	Body	Anti Theft Warning	√	√	√	√		
2006	Astra-G	Body	Central Door Lock	√	√	√	√		
2006	Astra-G	Body	Headlamp Levelling Device	√	√	√	√	√	SP0141
2006	Astra-G	Body	Electronic Climate Control	√	√	√	√		
2006	Astra-G	Body	Engine Cooling Module	√	√	√	√		
2006	Astra-G	Body	Add On Heater	√	√	√	√	√	SP0122,SP0123
2006	Astra-G	Body	Softtop Controller	√	√	√	√	√	
2006	Astra-G	Chassis	ABS-5.3/5.4(+TC)	√	√	√	√	√	
2006	Astra-G	Chassis	ESP	√	√	√	√	√	SP0005
2006	Astra-G	Chassis	Cruise Control	√	√	√	√		
2006	Astra-G	Chassis	Electronic Power Steering	√	√	√	√	√	
2006	Astra-G	Engine	Z12XE	√	√	√	√	√	SP0006,SP0145,SP0009,SP0040,SP0019,SP0021,SP0011,SP0065,SP0033
2006	Astra-G	Engine	Z14XE	√			√	√	SP0146,SP0145,SP0009,SP0019,SP0021,SP0011
2006	Astra-G	Engine	Z14XEP	√	√	√	√	√	SP0033,SP0065,SP0006,SP0166,SP0009,SP0146,SP0019,SP0011,SP0021
2006	Astra-G	Engine	C16SEL	√	√	√	√	√	
2006	Astra-G	Engine	Z16SE	√	√	√	√	√	
2006	Astra-G	Engine	Z16XE	√			√	√	
2006	Astra-G	Engine	Z16XEP	√	√	√	√	√	SP0006,SP0146,SP0009,SP0019,SP0011,SP0021,SP0065
2006	Astra-G	Engine	Z16YNG	√	√	√	√	√	SP0006,SP0146,SP0145,SP0009,SP0019,SP0011,SP0021
2006	Astra-G	Engine	Y17DT	√	√	√	√	√	
2006	Astra-G	Engine	Z17DTL	√	√	√	√	√	

2006	Astra-G	Engine	Z18XE	√	√	√	√	√	SP0145,SP0009,SP0040,SP0019,SP0011,S P0021
2006	Astra-G	Engine	Z18XEL	√	√	√			SP0011,SP0021
2006	Astra-G	Engine	Y20DTH	√	√	√	√	√	SP0166,SP0167,SP0168,SP0169
2006	Astra-G	Engine	Z20LET	√	√	√	√	√	SP0009,SP0019,SP0040,SP0145,SP0011,S P0021,SP0065,SP0033
2006	Astra-G	Engine	Y22DTR	√	√	√	√	√	SP0011,SP0021
2006	Astra-G	Engine	Z22SE	√	√	√	√	√	SP0065,SP0146,SP0145,SP0009,SP0011,S P0021,SP0033
2006	Astra-G	Infotainment System	Trip Info Display TID	√	√	√			
2006	Astra-G	Infotainment System	Multi Info Dispaly MID	√	√	√			
2006	Astra-G	Infotainment System	Radio CAR 300	√	√	√			
2006	Astra-G	Infotainment System	Radio CAR 400	√	√	√	√		
2006	Astra-G	Infotainment System	Radio CDR 500	√	√	√	√		
2006	Astra-G	Infotainment System	Radio CCR 600	√	√	√	√		
2006	Astra-G	Infotainment System	Radio CCRT 700	√	√	√	√		
2006	Astra-G	Infotainment System	Radio NCDR 1100/1500	√	√	√	√		
2006	Astra-G	Transmission	AF 13-II/17/20/22	√	√	√	√	√	
2006	Astra-G	Transmission	AF 13-II/17/20/22 CAN	√	√	√	√	√	
2006	Astra-H	Body	SDM(Airbag)	√	√	√	√		
2006	Astra-H	Body	CIM(Steering Column Module)	√	√	√	√	√	SP0051,SP0003,SP0052,SP0001,SP0004,S P0053,SP0054,SP0005
2006	Astra-H	Body	IPC ECU(Instrument Control Unit)	√	√	√	√		
2006	Astra-H	Body	REC(Rear Electrical Centre)	√	√	√	√		
2006	Astra-H	Body	UEC(Underhood Electrical Centre)	√	√	√	√		
2006	Astra-H	Body	AHL/AFL(Headlamp Levelling)	√	√	√	√		
2006	Astra-H	Body	Exterior Lighting/Turn Indicator System	√	√	√	√		
2006	Astra-H	Body	Interior Lighting	√	√	√	√		
2006	Astra-H	Body	Wipers/Washer	√	√	√	√		
2006	Astra-H	Body	Central Door Lock	√	√	√	√		

2006	Astra-H	Body	Instrument	√	√	√	√	√	SP0055,SP0056,SP0057
2006	Astra-H	Body	Immobiliser	√	√	√	√		
2006	Astra-H	Body	Anti Theft Warning System	√	√	√	√	√	
2006	Astra-H	Body	Electrohydraulic HardTop	√	√	√	√	√	SP0001,SP0004
2006	Astra-H	Body	ECC/SAC(Electronic Climate Control)	√	√	√	√	√	SP0150,SP0158,SP0159,SP0032,SP0001,SP0004,SP0160
2006	Astra-H	Body	EHS(Electrical Heater System)	√	√	√	√		SP0032,SP0001,SP0004
2006	Astra-H	Body	PAS(Park Pilot)	√	√	√	√	√	SP0001
2006	Astra-H	Body	SLM(Shift Lever Module)	√	√	√	√		
2006	Astra-H	Body	PEPS(Open&Start)	√	√	√	√		
2006	Astra-H	Body	IPC ECU(Instrument Control Unit)	√	√	√	√	√	SP0006,SP0055,SP0056,SP0057,SP0058,SP0059,SP0060,SP0001,SP0004
2006	Astra-H	Chassis	ABS/TC/ESP ECU(Electronic Control Unit)	√	√	√	√	√	
2006	Astra-H	Chassis	EHPS(Electrohydraulic Power Steering)	√	√	√	√		
2006	Astra-H	Chassis	TPMS ECU(Tyre Pressure Monitoring)	√	√	√	√		SP0001
2006	Astra-H	Chassis	TPMS (Tyre Pressure Monitoring System)	√	√	√	√		
2006	Astra-H	Chassis	CDC (Continuous Damping Control)	√	√	√	√		
2006	Astra-H	Chassis	ABS/TC/ESP(Vehicle Dynamic System)	√	√	√	√	√	
2006	Astra-H	Chassis	EHPS(Electrohydraulic Power Steering)	√	√	√	√		SP0003
2006	Astra-H	Engine	Z13DTH	√	√	√	√	√	SP0006,SP0007,SP0008,SP0019,SP0010,SP0011,SP0066,SP0020,SP0029,SP0028,SP0025,SP0026,SP0018
2006	Astra-H	Engine	Z14XEL	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,SP0011,SP0066,SP0012,SP0013,SP0018
2006	Astra-H	Engine	Z14XEP	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,SP0011,SP0066,SP0012,SP0013,SP0018
2006	Astra-H	Engine	Z16XEP	√	√	√	√		SP0006,SP0007,SP0008,SP0009,SP0019,SP0010,SP0011,SP0066,SP0012,SP0013,SP0033,SP0018
2006	Astra-H	Engine	Z17DTH	√	√	√	√	√	SP0006,SP0007,SP0008,SP0010,SP0011,SP0066,SP0020,SP0024,SP0012,SP0029,SP0032,SP0018
2006	Astra-H	Engine	Z18XE	√	√	√	√		SP0019,SP0006,SP0007,SP0008,SP0009,SP0010,SP0011,SP0066,SP0012,SP0018
2006	Astra-H	Engine	Z18XER	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0019,SP0010,SP0011,SP0066,SP0033,SP0012,SP

2006	Astra-H	Engine	Z19DT	√	√	√	√	√	SP0006,SP0007,SP0008,SP0010,SP0011,S P0066,SP0023,SP0024,SP0069,SP0012,SP 0032,SP0020,SP0029,SP0026,SP0027,SP0 025,SP0028,SP0018
2006	Astra-H	Engine	Z19DTH	√	√	√	√	√	SP0006,SP0007,SP0008,SP0010,SP0011,S P0066,SP0023,SP0024,SP0069,SP0012,SP 0032,SP0020,SP0029,SP0026,SP0027,SP0 025,SP0028,SP0018
2006	Astra-H	Engine	Z12XEP	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,S P0011,SP0066,SP0012,SP0013,SP0018
2006	Astra-H	Engine	Y13DTH	√	√	√	√	√	SP0019,SP0010,SP0011,SP0066,SP0020,S P0029,SP0028,SP0025,SP0026,SP0018
2006	Astra-H	Engine	Z16XER	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0019,S P0010,SP0011,SP0066,SP0033,SP0012,SP
2006	Astra-H	Engine	Z17DTL	√	√	√	√	√	SP0010,SP0011,SP0066,SP0020,SP0024,S P0012,SP0029,SP0032,SP0018
2006	Astra-H	Engine	Z19DTJ	√	√	√		√	SP0010,SP0011,SP0066,SP0023,SP0024,S P0069,SP0012,SP0032,SP0020,SP0029,SP 0026,SP0027,SP0025,SP0028,SP0018
2006	Astra-H	Engine	Z20LEH	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,S P0011,SP0066,SP0012,SP0013,SP0018
2006	Astra-H	Engine	Z20LEL	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,S P0011,SP0066,SP0012,SP0013,SP0018
2006	Astra-H	Engine	Z20LER	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,S P0011,SP0066,SP0012,SP0013,SP0018
2006	Astra-H	Engine	Engine(default)	√	√	√			
2006	Astra-H	Transmission	AF 17-4	√	√	√	√	√	SP0030,SP0031,SP0032,SP0003,SP0033
2006	Astra-H	Transmission	AF 40-6	√	√	√	√	√	SP0072,SP0073,SP0074,SP0075,SP0076,S P0077,SP0032,SP0003,SP0033,SP0078
2006	Astra-H	Transmission	MTA(Easytronic)	√	√	√	√	√	SP0003,SP0061,SP0034,SP0035
2006	Astra-H	Transmission	MTA(Easytronic Magneti Marelli)	√	√	√	√	√	
2006	Combo	Body	Add On Heater	√	√	√	√	√	SP0122,SP0123
2006	Combo	Body	Airbag	√	√	√	√	√	
2006	Combo	Body	Electronic Climate Control	√	√	√	√		
2006	Combo	Body	Body Control Module	√	√	√	√	√	SP0051,SP0058,SP0138
2006	Combo	Body	HeadLamp Levelling Device		√	√	√	√	SP0141
2006	Combo	Body	Immobiliser	√	√	√	√		SP0164,SP0165
2006	Combo	Body	Instrument	√	√	√	√		

2006	Combo	Chassis	ABS8/ESP8 (Anti-lock Braking System/Electronic Stability Program)		√	√	√	√	SP0005,SP0142,SP0143,SP0144,SP0004
2006	Combo	Chassis	ABS-5.3/5.4 (+TC) (Anti-lock Braking System)	√	√	√	√	√	
2006	Combo	Chassis	Electronic Power Steering	√	√	√	√		SP0141
2006	Combo	Engine	Z 10 XEP	√	√	√	√	√	SP0011,SP0021,SP0065,SP0033
2006	Combo	Engine	Z 12 XE	√	√	√	√	√	SP0006,SP0145,SP0009,SP0040,SP0019,SP0021,SP0011,SP0065,SP0033
2006	Combo	Engine	Z 12 XEP	√	√	√	√	√	SP0011,SP0021,SP0065,SP0033
2006	Combo	Engine	Y 13 DT	√	√	√	√	√	SP0040,SP0019,SP0021,SP0011,SP0020
2006	Combo	Engine	Z 13 DT	√	√	√	√	√	SP0040,SP0019,SP0021,SP0011,SP0020
2006	Combo	Engine	Z 14 XE	√			√	√	SP0146,SP0145,SP0009,SP0019,SP0021,SP0011
2006	Combo	Engine	Z 14 XEP	√	√	√	√	√	SP0006,SP0166,SP0009,SP0146,SP0019,SP0011,SP0021,SP0065,SP0033
2006	Combo	Engine	Z 16 SE	√	√	√	√	√	
2006	Combo	Engine	Z 16 YNG	√	√	√	√	√	SP0006,SP0146,SP0145,SP0009,SP0019,SP0011,SP0021
2006	Combo	Engine	Y 17 DT	√	√	√	√	√	
2006	Combo	Engine	Y 17 DTL	√	√	√	√	√	
2006	Combo	Engine	Z 17 DTH		√	√	√		
2006	Combo	Engine	Z 18 XE	√	√	√	√	√	SP0145,SP0009,SP0040,SP0019,SP0011,SP0021
2006	Combo	Infotainment System	Trip Info Display TID	√	√	√			
2006	Combo	Transmission	AF 13-II/17/20/22	√	√	√	√	√	
2006	Combo	Transmission	AF 13-II/17/20/22 CAN	√	√	√	√	√	
2006	Combo	Transmission	Easytronic(MTA)	√	√	√	√	√	SP0011,SP0148
2006	Corsa-C	Body	Body Control Module	√	√	√	√	√	SP0051,SP0058,SP0138
2006	Corsa-C	Body	Immobiliser	√	√	√	√		SP0139,SP0140
2006	Corsa-C	Body	Airbag	√	√	√	√	√	
2006	Corsa-C	Body	Instrument	√	√	√	√	√	SP0176,SP0177
2006	Corsa-C	Body	Add On Heater	√	√	√	√	√	SP0122,SP0123
2006	Corsa-C	Body	Electronic Climate Control	√	√	√	√		
2006	Corsa-C	Body	HeadLamp Levelling Device		√	√	√	√	SP0141
2006	Corsa-C	Chassis	ABS-5.3/5.4(+TC)	√	√	√	√	√	
2006	Corsa-C	Chassis	ABS8/ESP8		√	√	√	√	SP0005,SP0142,SP0143,SP0144,SP0004
2006	Corsa-C	Chassis	Electronic Power Steering	√	√	√	√		SP0141
2006	Corsa-C	Engine	Z10XEP	√	√	√	√	√	SP0011,SP0021,SP0065,SP0033

2006	Corsa-C	Engine	Z12XE	√	√	√	√	√	SP0006,SP0145,SP0009,SP0040,SP0019,S P0021,SP0011,SP0065,SP0033
2006	Corsa-C	Engine	Z12XEP	√	√	√	√	√	SP0011,SP0021,SP0065,SP0033
2006	Corsa-C	Engine	Y13DT	√	√	√	√	√	SP0040,SP0019,SP0021,SP0011,SP0020
2006	Corsa-C	Engine	Z13DT	√	√	√	√	√	SP0019,SP0040,SP0021,SP0011,SP0020
2006	Corsa-C	Engine	Z14XE	√			√	√	SP0146,SP0145,SP0009,SP0019,SP0021,S P0011
2006	Corsa-C	Engine	Z14XEP	√	√	√	√	√	SP0033,SP0065,SP0006,SP0166,SP0009,S P0146,SP0019,SP0011,SP0021
2006	Corsa-C	Engine	Z16SE	√	√	√	√	√	
2006	Corsa-C	Engine	Z16YNG	√	√	√	√	√	SP0006,SP0146,SP0145,SP0009,SP0019,S P0011,SP0021
2006	Corsa-C	Engine	Y17DT	√	√	√	√	√	
2006	Corsa-C	Engine	Y17DTL	√	√	√	√	√	
2006	Corsa-C	Engine	Z17DTH	√	√	√	√	√	SP0006,SP0146,SP0019,SP0020,SP0147,S P0022,SP0011,SP0021
2006	Corsa-C	Engine	Z18XE	√	√	√	√	√	SP0145,SP0009,SP0040,SP0019,SP0011,S P0021
2006	Corsa-C	Infotainment System	Trip Info Display TID	√	√	√			
2006	Corsa-C	Transmission	AF 13-II/17/20/22 CAN	√	√	√	√	√	
2006	Corsa-C	Transmission	MTA(Easytronic)	√	√	√	√	√	SP0011,SP0148
2006	Corsa-C	Transmission	AF 13-II/17/20/22	√	√	√	√	√	
2006	Meriva	Body	Body Control Module	√	√	√	√	√	SP0051,SP0058,SP0138
2006	Meriva	Body	Immobiliser	√	√	√	√		SP0139,SP0140
2006	Meriva	Body	Airbag	√	√	√	√	√	
2006	Meriva	Body	Instrument	√	√	√	√	√	SP0176,SP0177
2006	Meriva	Body	Headlamp Levelling Device	√	√	√	√	√	SP0141
2006	Meriva	Body	Electronic Climate Control	√	√	√	√	√	
2006	Meriva	Body	Add On Heater	√	√	√	√	√	SP0122,SP0123
2006	Meriva	Chassis	ABS8/ESP8		√	√	√	√	SP0005,SP0142,SP0143,SP0144,SP0004
2006	Meriva	Chassis	Electronic Power Steering	√	√	√	√		SP0141
2006	Meriva	Engine	Y13DT	√	√	√	√	√	SP0040,SP0019,SP0021,SP0011,SP0020
2006	Meriva	Engine	Z13DT	√	√	√	√	√	SP0019,SP0040,SP0021,SP0011,SP0020
2006	Meriva	Engine	Z14XEP	√	√	√	√	√	SP0033,SP0065,SP0006,SP0166,SP0009,S P0146,SP0019,SP0011,SP0021
2006	Meriva	Engine	Z16SE	√	√	√	√	√	
2006	Meriva	Engine	Z16XE	√			√	√	

2006	Meriva	Engine	Z16XEP	√	√	√	√	√	SP0006,SP0146,SP0009,SP0019,SP0011,SP0021,SP0065
2006	Meriva	Engine	Y17DT	√	√	√	√	√	
2006	Meriva	Engine	Z17DTH	√	√	√	√	√	SP0006,SP0146,SP0019,SP0020,SP0147,SP0022,SP0011,SP0021
2006	Meriva	Engine	Z18XE	√	√	√	√	√	SP0145,SP0009,SP0040,SP0019,SP0011,SP0021
2006	Meriva	Engine	C16SEL	√	√	√	√	√	
2006	Meriva	Engine	Z16LET	√	√	√	√	√	SP0006,SP0146,SP0009,SP0019,SP0011,SP0021,SP0065
2006	Meriva	Infotainment System	Trip Info Display TID	√	√	√			
2006	Meriva	Transmission	MTA(Easytronic)	√	√	√	√	√	SP0011,SP0148
2006	Movano	Body	Airbag	√	√	√	√		
2006	Movano	Body	Body Control Module	√	√	√	√	√	SP0051,SP0058,SP0138
2006	Movano	Chassis	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)		√	√	√	√	SP0164,SP0165
2006	Speedster/VX22	Body	Immobiliser	√	√	√	√		SP0139,SP0140
2006	Speedster/VX22	Body	Airbag	√	√	√	√		
2006	Speedster/VX22	Chassis	ABS 430	√	√	√	√		
2006	Speedster/VX22	Engine	Z20LET	√	√	√	√		
2006	Speedster/VX220	Engine	Z22SE	√	√	√	√	√	SP0065,SP0146,SP0145,SP0009,SP0011,SP0021,SP0033
2006	Tigra-B	Body	Body Control Module	√	√	√	√	√	SP0051,SP0058,SP0138
2006	Tigra-B	Body	Immobiliser	√	√	√	√		SP0139,SP0140
2006	Tigra-B	Body	Airbag	√	√	√	√	√	
2006	Tigra-B	Body	Instrument	√	√	√	√	√	SP0176,SP0177
2006	Tigra-B	Chassis	ABS8/ESP8		√	√	√	√	SP0005,SP0142,SP0143,SP0144,SP0004
2006	Tigra-B	Chassis	Electronic Power Steering	√	√	√	√		SP0141
2006	Tigra-B	Engine	Z13DT	√	√	√	√	√	SP0019,SP0040,SP0021,SP0011,SP0020
2006	Tigra-B	Engine	Z14XEP	√	√	√	√	√	SP0033,SP0065,SP0006,SP0166,SP0009,SP0146,SP0019,SP0011,SP0021
2006	Tigra-B	Engine	Z18XE	√	√	√	√	√	SP0145,SP0009,SP0040,SP0019,SP0011,SP0021
2006	Tigra-B	Transmission	MTA(Easytronic)	√	√	√	√	√	SP0011,SP0148
2006	Vauxhall Monaro	Engine	V8 GEN IV	√	√	√	√	√	SP0015,SP0149,SP0171,SP0172
2006	Vectra-	Body	SDM(Airbag,Sensing&Diagnostic Module)	√	√	√	√		SP0000,SP0001,SP0002
2006	Vectra-	Body	Instrument	√	√	√	√	√	SP0169,SP0056,SP0057,SP0179,SP0001

2006	Vectra-C/Signum	Body	CIM(Steering Column Module)	√	√	√	√	√	SP0051,SP0003,SP0052,SP0001,SP0004,SP0053,SP0054,SP0005
2006	Vectra-	Body	BCM(Body Control Module)	√	√	√			SP0180,SP0181
2006	Vectra-	Body	DDM(Driver Door Module)	√	√	√			
2006	Vectra-	Body	PDM(Passenger Door Module)	√	√	√			
2006	Vectra-	Body	REC(Rear Electrical Centre)	√	√	√	√		
2006	Vectra-	Body	UEC(Underhood Electrical Centre)	√	√	√	√		
2006	Vectra-	Body	SLM(Shift Lever Module)	√	√	√			
2006	Vectra-	Body	SRM(Sun Roof Module)	√	√	√			
2006	Vectra-	Body	AHL/AFL(Headlamp Levelling)	√	√	√			
2006	Vectra-	Body	Electrical Horn	√	√	√	√	√	
2006	Vectra-C/Signum	Body	SAC (Automatic Climate Control)	√	√	√	√	√	SP0150,SP0158,SP0159,SP0001,SP0004,SP0160
2006	Vectra-	Body	Interior Lighting	√	√	√	√	√	SP0182,SP0059
2006	Vectra-	Body	Electronic Seat Memory/Seat Heating	√	√	√	√		
2006	Vectra-	Body	Anti Theft Warning System	√	√	√	√	√	
2006	Vectra-	Body	Central Door Lock	√	√	√	√		
2006	Vectra-	Body	EHS (Electrical Heater System)	√	√	√	√	√	SP0032,SP0001,SP0004
2006	Vectra-	Body	PAS (Park Pilot)	√	√	√	√	√	SP0001
2006	Vectra-	Chassis	ABS/TC/ESP	√	√	√	√	√	
2006	Vectra-	Chassis	EHPS(Electronic Power Steering)	√	√	√	√		
2006	Vectra-	Chassis	TPMS (Tyre Pressure Monitoring System)	√	√	√	√		SP0032
2006	Vectra-	Chassis	CDC(Continuous Damping Control)	√	√	√			
2006	Vectra-	Chassis	Electronic Cruise Control	√	√	√			
2006	Vectra-	Engine	Engine Cooling	√	√	√	√		
2006	Vectra-	Engine	Z16XEP	√	√	√	√	√	SP0010,SP0011,SP0066,SP0013,SP0149
2006	Vectra-C/Signum	Engine	Z18XE	√	√	√	√	√	SP0019,SP0010,SP0011,SP0066,SP0149,SP0012
2006	Vectra-C/Signum	Engine	Z18XER	√	√	√	√	√	SP0019,SP0009,SP0010,SP0011,SP0066,SP0149,SP0033,SP0012
2006	Vectra-C/Signum	Engine	Z19DT	√	√	√	√	√	SP0149,SP0010,SP0011,SP0066,SP0023,SP0024,SP0069,SP0020,SP0012,SP0026,SP0027,SP0029
2006	Vectra-C/Signum	Engine	Z19DTH	√	√	√	√	√	SP0149,SP0010,SP0011,SP0066,SP0023,SP0024,SP0028,SP0025,SP0026,SP0020,SP0012,SP0027,SP0029
2006	Vectra-	Engine	Y20DTH	√	√	√	√	√	SP0010,SP0011,SP0066,SP0149
2006	Vectra-	Engine	Y22DTR	√	√	√	√	√	SP0010,SP0011,SP0066,SP0149
2006	Vectra-	Engine	Z22SE	√	√	√	√	√	SP0010,SP0011,SP0066,SP0149

2006	Vectra-	Engine	Z22YH	√	√	√	√	√	SP0019,SP0149
2006	Vectra-	Engine	Z32SE	√	√	√	√	√	SP0019,SP0149
2006	Vectra-	Engine	Z16XE	√	√	√	√	√	SP0010,SP0011,SP0066,SP0149,SP0012
2006	Vectra-	Engine	Z20NET	√	√	√	√	√	SP0010,SP0011,SP0066,SP0149
2006	Vectra-C/Signum	Engine	Z28NEH	√	√	√	√	√	SP0009,SP0019,SP0040,SP0183,SP0184,SP0185,SP0011,SP0066,SP0149
2006	Vectra-C/Signum	Engine	Z28NEL	√	√	√	√	√	SP0009,SP0019,SP0040,SP0183,SP0184,SP0185,SP0011,SP0066,SP0149
2006	Vectra-C/Signum	Engine	Z28NET	√	√	√	√	√	SP0009,SP0019,SP0040,SP0183,SP0184,SP0185,SP0011,SP0066,SP0149
2006	Vectra-	Engine	Z30DT	√	√	√	√	√	SP0019,SP0010,SP0066,SP0029
2006	Vectra-	Engine	Engine(default)	√	√	√			
2006	Vectra-	Transmission	AF 23-5/33-5/40-6	√	√	√	√	√	SP0032,SP0033
2006	Vectra-C/Signum	Transmission	CVTronic	√	√	√	√	√	SP0186,SP0187,SP0188,SP0032,SP0003,SP0033
2006	Vectra-	Transmission	MTA(Easytronic)	√	√	√	√	√	
2006	Vivaro	Body	Airbag		√	√	√		SP0004
2006	Vivaro	Body	Add On Heater	√	√	√	√	√	SP0122,SP0123
2006	Vivaro	Body	Body Control Module		√	√	√	√	
2006	Vivaro	Chassis	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)	√	√	√	√	√	SP0174,SP0175
2006	Vivaro	Engine	F9Q 760/762 (1.9L)	√	√	√	√		
2006	Vivaro	Infotainment System	Trip Info Display TID	√	√	√			
2006	Vivaro	Infotainment System	Radio CAR 2003	√	√	√			
2006	Vivaro	Infotainment System	Radio CDR 2005	√	√	√	√		
2006	Vivaro	Infotainment System	Radio CCR 2006	√	√	√	√		
2006	Zafira-B	Body	SDM(Airbag)	√	√	√	√		SP0000,SP0001,SP0002
2006	Zafira-B	Body	CIM(Steering Column Module)	√	√	√	√	√	SP0051,SP0003,SP0052,SP0001,SP0004,SP0053,SP0054,SP0005
2006	Zafira-B	Body	IPC ECU(Instrument Control Unit)	√	√	√	√		
2006	Zafira-B	Body	REC(Rear Electrical Centre)	√	√	√	√		
2006	Zafira-B	Body	UEC(Underhood Electrical Centre)	√	√	√	√		
2006	Zafira-B	Body	AHL/AFL(Headlamp Levelling)	√	√	√	√		
2006	Zafira-B	Body	Exterior Lighting/Turn Indicator System	√	√	√	√		

2006	Zafira-B	Body	Interior Lighting	√	√	√	√		
2006	Zafira-B	Body	Wipers/Washer	√	√	√	√		
2006	Zafira-B	Body	Central Door Lock	√	√	√	√		
2006	Zafira-B	Body	Instrument	√	√	√	√	√	SP0055,SP0056,SP0057
2006	Zafira-B	Body	Immobiliser	√	√	√	√		
2006	Zafira-B	Body	ECC/SAC(Electronic Climate Control)	√	√	√	√	√	SP0150,SP0158,SP0159,SP0001,SP0004,S P0160
2006	Zafira-B	Body	EHS(Electrical Heater System)	√	√	√	√		SP0032,SP0001,SP0004
2006	Zafira-B	Body	PAS(Park Pilot)	√	√	√	√	√	SP0001
2006	Zafira-B	Body	SLM(Shift Lever Module)	√	√	√	√		
2006	Zafira-B	Body	PEPS(Open&Start)	√	√	√	√		
2006	Zafira-B	Body	Anti Theft Warning System	√	√	√	√	√	
2006	Zafira-B	Body	IPC ECU(Instrument Control Unit)	√	√	√	√	√	SP0006,SP0055,SP0056,SP0057,SP0058,S P0059,SP0060,SP0001,SP0004
2006	Zafira-B	Chassis	ABS/TC/ESP ECU(Electronic Control Unit)	√	√	√	√	√	
2006	Zafira-B	Chassis	EHPS(Electrohydraulic Power Steering)	√	√	√	√		
2006	Zafira-B	Chassis	ABS/TC/ESP(Vehicle Dynamic System)	√	√	√	√	√	SP0005
2006	Zafira-B	Chassis	TPMS ECU(Tyre Pressure Monitoring)	√	√	√	√		SP0001
2006	Zafira-B	Chassis	TPMS(Tyre Pressure Monitoring System)	√	√	√	√		
2006	Zafira-B	Chassis	CDC(Continuous Damping Control)	√	√	√	√		
2006	Zafira-B	Chassis	EHPS(Electrohydraulic Power Steering)	√	√	√	√		SP0003
2006	Zafira-B	Engine	Z16XEP	√	√	√	√		SP0006,SP0007,SP0008,SP0009,SP0019,S P0010,SP0011,SP0066,SP0012,SP0013,SP 0033,SP0018
2006	Zafira-B	Engine	Z18XER	√	√	√	√		SP0019,SP0006,SP0007,SP0008,SP0009,S P0010,SP0011,SP0066,SP0033,SP0012,SP
2006	Zafira-B	Engine	Z19DT	√	√	√	√	√	SP0006,SP0007,SP0008,SP0010,SP0011,S P0066,SP0023,SP0024,SP0069,SP0012,SP 0032,SP0020,SP0029,SP0026,SP0027,SP0 025,SP0028,SP0018
2006	Zafira-B	Engine	Z19DTH	√	√	√	√	√	SP0006,SP0007,SP0008,SP0032,SP0010,S P0011,SP0066,SP0023,SP0024,SP0028,SP 0025,SP0026,SP0027
2006	Zafira-B	Engine	Z16YNG	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0019,S P0010,SP0011,SP0066,SP0012,SP0013,SP 0033,SP0018
2006	Zafira-B	Engine	Z16XER	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0019,S P0010,SP0011,SP0066,SP0033,SP0012,SP

2006	Zafira-B	Engine	Z16XE1	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0173,SP0010,SP0011,SP0066,SP0012,SP0013,SP0033,SP0018
2006	Zafira-B	Engine	Z18XE	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0019,SP0010,SP0011,SP0066,SP0012,SP0018
2006	Zafira-B	Engine	Z19DTL	√	√	√	√	√	SP0006,SP0007,SP0008,SP0010,SP0011,SP0066,SP0023,SP0024,SP0069,SP0012,SP0032,SP0020,SP0029,SP0026,SP0027,SP0025,SP0028,SP0018
2006	Zafira-B	Engine	Z20LER	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,SP0011,SP0066,SP0012,SP0013,SP0018
2006	Zafira-B	Engine	Z20LEH	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,SP0011,SP0066,SP0012,SP0013,SP0018
2006	Zafira-B	Engine	Z22YH	√	√	√	√	√	SP0006,SP0007,SP0008,SP0071,SP0019,SP0010,SP0011,SP0066,SP0012,SP0013,SP
2006	Zafira-B	Engine	Engine(default)	√	√	√			
2006	Zafira-B	Transmission	MTA(Easutronic)	√	√	√	√	√	SP0003,SP0061,SP0034,SP0035
2006	Zafira-B	Transmission	AF 40-6	√	√	√	√	√	SP0072,SP0073,SP0074,SP0075,SP0076,SP0077,SP0032,SP0003,SP0033,SP0078
2006	Zafira-B	Transmission	AF 22-4	√	√	√	√	√	SP0030,SP0032,SP0003,SP0033
2005	Agila	Body	Immobiliser	√	√	√	√		SP0139,SP0140
2005	Agila	Body	Airbag	√	√	√	√		
2005	Agila	Body	Instrument	√	√	√	√		
2005	Agila	Chassis	ABS	√	√	√	√	√	SP0189
2005	Agila	Chassis	Electronic Power Steering	√	√	√	√		
2005	Agila	Engine	Z10XEP	√	√	√	√	√	SP0011,SP0021,SP0065,SP0033
2005	Agila	Engine	Z12XE	√	√	√	√	√	SP0006,SP0145,SP0009,SP0040,SP0019,SP0021,SP0011,SP0065,SP0033
2005	Agila	Engine	Z12XEP	√	√	√	√	√	SP0011,SP0021,SP0065,SP0033
2005	Agila	Engine	Z13DT	√	√	√	√	√	SP0019,SP0040,SP0021,SP0011,SP0020
2005	Agila	Infotainment System	Trip Info Display TID	√	√	√			
2005	Astra-G	Body	Immobiliser	√	√	√	√		SP0139,SP0140
2005	Astra-G	Body	Instrument	√	√	√	√		
2005	Astra-G	Body	Airbag	√	√	√	√		
2005	Astra-G	Body	Anti Theft Warning	√	√	√	√		
2005	Astra-G	Body	Central Door Lock	√	√	√	√		
2005	Astra-G	Body	Headlamp Levelling Device	√	√	√	√	√	SP0141

2005	Astra-G	Body	Electronic Climate Control	√	√	√	√		
2005	Astra-G	Body	Engine Cooling Module	√	√	√	√		
2005	Astra-G	Body	Add On Heater	√	√	√	√	√	SP0122,SP0123
2005	Astra-G	Chassis	ABS-5.3/5.4(+TC)	√	√	√	√	√	
2005	Astra-G	Chassis	ESP	√	√	√	√	√	SP0005
2005	Astra-G	Chassis	Cruise Control	√	√	√	√		
2005	Astra-G	Chassis	Electronic Power Steering	√	√	√	√	√	
2005	Astra-G	Engine	Z12XE	√	√	√	√	√	SP0006,SP0145,SP0009,SP0040,SP0019,S P0021,SP0011,SP0065,SP0033
2005	Astra-G	Engine	Z14XE	√			√	√	SP0146,SP0145,SP0009,SP0019,SP0021,S P0011
2005	Astra-G	Engine	Z14XEP	√	√	√	√	√	SP0033,SP0065,SP0006,SP0166,SP0009,S P0146,SP0019,SP0011,SP0021
2005	Astra-G	Engine	C16SEL	√	√	√	√	√	
2005	Astra-G	Engine	Z16SE	√	√	√	√	√	
2005	Astra-G	Engine	Z16XE	√			√	√	
2005	Astra-G	Engine	Z16XEP	√	√	√	√	√	SP0006,SP0146,SP0009,SP0019,SP0011,S P0021,SP0065
2005	Astra-G	Engine	Z16YNG	√	√	√	√	√	SP0006,SP0146,SP0145,SP0009,SP0019,S P0011,SP0021
2005	Astra-G	Engine	Y17DT	√	√	√	√	√	
2005	Astra-G	Engine	Z17DTL	√	√	√	√	√	
2005	Astra-G	Engine	Z18XE	√	√	√	√	√	SP0145,SP0009,SP0040,SP0019,SP0011,S P0021
2005	Astra-G	Engine	Z18XEL	√	√	√			SP0011,SP0021
2005	Astra-G	Engine	Y20DTH	√	√	√	√	√	SP0166,SP0167,SP0168,SP0169
2005	Astra-G	Engine	Z20LET	√	√	√	√	√	SP0009,SP0019,SP0040,SP0145,SP0011,S P0021,SP0065,SP0033
2005	Astra-G	Engine	Y22DTR	√	√	√	√	√	SP0011,SP0021
2005	Astra-G	Engine	Z22SE	√	√	√	√	√	SP0065,SP0146,SP0145,SP0009,SP0011,S P0021,SP0033
2005	Astra-G	Infotainment System	Trip Info Display TID	√	√	√			
2005	Astra-G	Infotainment System	Multi Info Dispaly MID	√	√	√			
2005	Astra-G	Infotainment System	Radio CAR 300	√	√	√			

2005	Astra-G	Infotainment System	Radio CAR 400	√	√	√	√		
2005	Astra-G	Infotainment System	Radio CDR 500	√	√	√	√		
2005	Astra-G	Infotainment System	Radio CCR 600	√	√	√	√		
2005	Astra-G	Infotainment System	Radio CCRT 700	√	√	√	√		
2005	Astra-G	Infotainment System	Radio NCDR 1100/1500	√	√	√	√		
2005	Astra-G	Transmission	AF 13-II/17/20/22	√	√	√	√	√	
2005	Astra-G	Transmission	AF 13-II/17/20/22 CAN	√	√	√	√	√	
2005	Astra-G(GMSA)	Body	Airbag	√	√	√	√		
2005	Astra-G(GMSA)	Body	Anti Theft Warning	√	√	√	√		
2005	Astra-G(GMSA)	Body	Central Door Lock	√	√	√	√		
2005	Astra-G(GMSA)	Body	Engine Cooling Module	√	√	√	√		
2005	Astra-G(GMSA)	Body	Immobiliser	√	√	√	√		SP0164,SP0165
2005	Astra-G(GMSA)	Body	Instrument	√	√	√	√		
2005	Astra-G(GMSA)	Chassis	ABS-5.3/5.4 (+TC) (Anti-lock Braking System)	√	√	√	√	√	
2005	Astra-G(GMSA)	Chassis	Electronic Power Steering	√	√	√	√		SP0141
2005	Astra-G(GMSA)	Engine	C 16 SEL	√	√	√	√	√	
2005	Astra-G(GMSA)	Engine	Z 18 XE	√	√	√	√	√	SP0145,SP0009,SP0040,SP0019,SP0011,S P0021
2005	Astra-G(GMSA)	Engine	Z 22 SE	√	√	√	√	√	SP0146,SP0009,SP0145,SP0011,SP0021,S P0065,SP0033
2005	Astra-G(GMSA)	Infotainment System	Trip Info Display TID	√	√	√			
2005	Astra-H	Body	SDM(Airbag)	√	√	√	√		
2005	Astra-H	Body	CIM(Steering Column Module)	√	√	√	√	√	SP0051,SP0003,SP0052,SP0001,SP0004,S P0053,SP0054,SP0005
2005	Astra-H	Body	IPC ECU(Instrument Control Unit)	√	√	√	√		
2005	Astra-H	Body	REC(Rear Electrical Centre)	√	√	√	√		
2005	Astra-H	Body	UEC(Underhood Electrical Centre)	√	√	√	√		
2005	Astra-H	Body	AHL/AFL(Headlamp Levelling)	√	√	√	√		
2005	Astra-H	Body	Anti Theft Warning System	√	√	√	√	√	
2005	Astra-H	Body	Electrohydraulic HardTop	√	√	√	√	√	SP0001,SP0004
2005	Astra-H	Body	ECC/SAC(Electronic Climate Control)	√	√	√	√	√	SP0150,SP0158,SP0159,SP0032,SP0001,S P0004,SP0160

2005	Astra-H	Body	EHS(Electrical Heater System)	√	√	√	√		SP0032,SP0001,SP0004
2005	Astra-H	Body	PAS(Park Pilot)	√	√	√	√	√	SP0001
2005	Astra-H	Body	SLM(Shift Lever Module)	√	√	√	√		
2005	Astra-H	Body	PEPS(Open&Start)	√	√	√	√		
2005	Astra-H	Body	IPC ECU(Instrument Control Unit)	√	√	√	√	√	SP0006,SP0055,SP0056,SP0057,SP0058,S P0059,SP0060,SP0001,SP0004
2005	Astra-H	Chassis	ABS/TC/ESP ECU(Electronic Control Unit)	√	√	√	√	√	
2005	Astra-H	Chassis	EHPS(Electrohydraulic Power Steering)	√	√	√	√		
2005	Astra-H	Chassis	TPMS ECU(Tyre Pressure Monitoring)	√	√	√	√		SP0001
2005	Astra-H	Chassis	TPMS(Tyre Pressure Monitoring System)	√	√	√	√		
2005	Astra-H	Chassis	CDC(Continuous Damping Control)	√	√	√	√		
2005	Astra-H	Chassis	ABS/TC/ESP(Vehicle Dynamic System)	√	√	√	√	√	
2005	Astra-H	Chassis	EHPS(Electrohydraulic Power Steering)	√	√	√	√		SP0003
2005	Astra-H	Engine	Z13DTH	√	√	√	√	√	SP0006,SP0007,SP0008,SP0019,SP0010,S P0011,SP0066,SP0020,SP0029,SP0028,SP 0025,SP0026,SP0018
2005	Astra-H	Engine	Z14XEP	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,S P0011,SP0066,SP0012,SP0013,SP0018
2005	Astra-H	Engine	Z16XEP	√	√	√	√		SP0006,SP0007,SP0008,SP0009,SP0019,S P0010,SP0011,SP0066,SP0012,SP0013,SP 0033,SP0018
2005	Astra-H	Engine	Z17DTH	√	√	√	√	√	SP0006,SP0007,SP0008,SP0010,SP0011,S P0066,SP0020,SP0024,SP0012,SP0029,SP 0032,SP0018
2005	Astra-H	Engine	Z18XE	√	√	√	√		SP0019,SP0006,SP0007,SP0008,SP0009,S P0010,SP0011,SP0066,SP0012,SP0018
2005	Astra-H	Engine	Z19DTH	√	√	√	√	√	SP0006,SP0007,SP0008,SP0010,SP0011,S P0066,SP0023,SP0024,SP0069,SP0012,SP 0032,SP0020,SP0029,SP0026,SP0027,SP0 025,SP0028,SP0018
2005	Astra-H	Engine	Z16XER	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0019,S P0010,SP0011,SP0066,SP0033,SP0012,SP
2005	Astra-H	Engine	Z17DTL	√	√	√	√	√	SP0010,SP0011,SP0066,SP0020,SP0024,S P0012,SP0029,SP0032,SP0018
2005	Astra-H	Engine	Z19DT	√	√	√	√	√	SP0006,SP0007,SP0008,SP0010,SP0011,S P0066,SP0023,SP0024,SP0069,SP0012,SP 0032,SP0020,SP0029,SP0026,SP0027,SP0 025,SP0028,SP0018

2005	Astra-H	Engine	Z19DTJ	√	√	√		√	SP0010,SP0011,SP0066,SP0023,SP0024,SP0069,SP0012,SP0032,SP0020,SP0029,SP0026,SP0027,SP0025,SP0028,SP0018
2005	Astra-H	Engine	Z20LEL	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,SP0011,SP0066,SP0012,SP0013,SP0018
2005	Astra-H	Engine	Z20LEH	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,SP0011,SP0066,SP0012,SP0013,SP0018
2005	Astra-H	Engine	Z20LER	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,SP0011,SP0066,SP0012,SP0013,SP0018
2005	Astra-H	Engine	Engine(default)	√	√	√			
2005	Astra-H	Transmission	AF 17-4	√	√	√	√	√	SP0030,SP0031,SP0032,SP0003,SP0033
2005	Astra-H	Transmission	MTA(Easytronic)	√	√	√	√	√	SP0003,SP0061,SP0034,SP0035
2005	Combo	Body	Add On Heater	√	√	√	√	√	SP0122,SP0123
2005	Combo	Body	Airbag	√	√	√	√	√	
2005	Combo	Body	Body Control Module	√	√	√	√	√	SP0051,SP0058,SP0138
2005	Combo	Body	Immobiliser	√	√	√	√		SP0164,SP0165
2005	Combo	Body	Instrument	√	√	√	√		
2005	Combo	Body	Electronic Climate Control	√	√	√	√		
2005	Combo	Body	HeadLamp Levelling Device		√	√	√	√	SP0141
2005	Combo	Chassis	ABS-5.3/5.4 (+TC) (Anti-lock Braking System)	√	√	√	√	√	
2005	Combo	Chassis	Electronic Power Steering	√	√	√	√		SP0141
2005	Combo	Chassis	ABS8/ESP8 (Anti-lock Braking System/Electronic Stability Program)		√	√	√	√	SP0005,SP0142,SP0143,SP0144,SP0004
2005	Combo	Engine	Z 10 XEP	√	√	√	√	√	SP0011,SP0021,SP0065,SP0033
2005	Combo	Engine	Z 12 XE	√	√	√	√	√	SP0006,SP0145,SP0009,SP0040,SP0019,SP0021,SP0011,SP0065,SP0033
2005	Combo	Engine	Z 12 XEP	√	√	√	√	√	SP0011,SP0021,SP0065,SP0033
2005	Combo	Engine	Y 13 DT	√	√	√	√	√	SP0040,SP0019,SP0021,SP0011,SP0020
2005	Combo	Engine	Z 13 DT	√	√	√	√	√	SP0040,SP0019,SP0021,SP0011,SP0020
2005	Combo	Engine	Z 14 XE	√			√	√	SP0146,SP0145,SP0009,SP0019,SP0021,SP0011
2005	Combo	Engine	Z 14 XEP	√	√	√	√	√	SP0006,SP0166,SP0009,SP0146,SP0019,SP0011,SP0021,SP0065,SP0033
2005	Combo	Engine	Z 16 SE	√	√	√	√	√	
2005	Combo	Engine	Y 17 DT	√	√	√	√	√	
2005	Combo	Engine	Y 17 DTL	√	√	√	√	√	
2005	Combo	Engine	Z 17 DTH	√	√	√	√	√	SP0006,SP0146,SP0019,SP0022,SP0011,SP0021,SP0020,SP0147

2005	Combo	Engine	Z 18 XE	√	√	√	√	√	SP0145,SP0009,SP0040,SP0019,SP0011,S P0021
2005	Combo	Infotainment System	Trip Info Display TID	√	√	√			
2005	Combo	Transmission	AF 13-II/17/20/22	√	√	√	√	√	
2005	Combo	Transmission	AF 13-II/17/20/22 CAN	√	√	√	√	√	
2005	Combo	Transmission	Easytronic(MTA)	√	√	√	√	√	SP0011,SP0148
2005	Corsa-B(GMSA)	Body	Immobiliser	√	√	√	√		SP0164,SP0165
2005	Corsa-B(GMSA)	Engine	14 NE	√	√	√	√	√	SP0166,SP0191,SP0192,SP0056,SP0193
2005	Corsa-B(GMSA)	Engine	16 SE						
2005	Corsa-C	Body	Body Control Module	√	√	√	√	√	SP0051,SP0058,SP0138
2005	Corsa-C	Body	Immobiliser	√	√	√	√		SP0139,SP0140
2005	Corsa-C	Body	Airbag	√	√	√	√	√	
2005	Corsa-C	Body	Instrument	√	√	√	√	√	SP0176,SP0177
2005	Corsa-C	Body	Add On Heater	√	√	√	√	√	SP0122,SP0123
2005	Corsa-C	Body	Electronic Climate Control	√	√	√	√		
2005	Corsa-C	Body	HeadLamp Levelling Device		√	√	√	√	SP0141
2005	Corsa-C	Chassis	ABS-5.3/5.4(+TC)	√	√	√	√	√	
2005	Corsa-C	Chassis	ABS8/ESP8		√	√	√	√	SP0005,SP0142,SP0143,SP0144,SP0004
2005	Corsa-C	Chassis	Electronic Power Steering	√	√	√	√		SP0141
2005	Corsa-C	Engine	Z10XEP	√	√	√	√	√	SP0011,SP0021,SP0065,SP0033
2005	Corsa-C	Engine	Z12XE	√	√	√	√	√	SP0006,SP0145,SP0009,SP0040,SP0019,S P0021,SP0011,SP0065,SP0033
2005	Corsa-C	Engine	Z12XEP	√	√	√	√	√	SP0011,SP0021,SP0065,SP0033
2005	Corsa-C	Engine	Y13DT	√	√	√	√	√	SP0040,SP0019,SP0021,SP0011,SP0020
2005	Corsa-C	Engine	Z13DT	√	√	√	√	√	SP0019,SP0040,SP0021,SP0011,SP0020
2005	Corsa-C	Engine	Z14XE	√			√	√	SP0146,SP0145,SP0009,SP0019,SP0021,S P0011
2005	Corsa-C	Engine	Z14XEP	√	√	√	√	√	SP0033,SP0065,SP0006,SP0166,SP0009,S P0146,SP0019,SP0011,SP0021
2005	Corsa-C	Engine	Z16SE	√	√	√	√	√	
2005	Corsa-C	Engine	Z16YNG	√	√	√	√	√	SP0006,SP0146,SP0145,SP0009,SP0019,S P0011,SP0021
2005	Corsa-C	Engine	Y17DT	√	√	√	√	√	
2005	Corsa-C	Engine	Y17DTL	√	√	√	√	√	
2005	Corsa-C	Engine	Z17DTH	√	√	√	√	√	SP0006,SP0146,SP0019,SP0020,SP0147,S P0022,SP0011,SP0021

2005	Corsa-C	Engine	Z18XE	√	√	√	√	√	SP0145,SP0009,SP0040,SP0019,SP0011,SP0021
2005	Corsa-C	Infotainment System	Trip Info Display TID	√	√	√			
2005	Corsa-C	Transmission	AF 13-II/17/20/22 CAN	√	√	√	√	√	
2005	Corsa-C	Transmission	MTA(Easytronic)	√	√	√	√	√	SP0011,SP0148
2005	Corsa-C	Transmission	AF 13-II/17/20/22	√	√	√	√	√	
2005	Corsa-C(GMSA)	Body	Airbag	√	√	√	√	√	
2005	Corsa-C(GMSA)	Body	Body Control Module	√	√	√	√	√	SP0051,SP0058,SP0138
2005	Corsa-C(GMSA)	Body	Immobiliser	√	√	√	√		SP0164,SP0165
2005	Corsa-C(GMSA)	Body	Instrument	√	√	√	√		
2005	Corsa-C(GMSA)	Body	Power Window Lifter Front	√	√	√	√		
2005	Corsa-C(GMSA)	Body	Power Window Lifter Rear	√	√	√	√		
2005	Corsa-C(GMSA)	Chassis	ABS-5.3/5.4 (+TC) (Anti-lock Braking System)	√	√	√	√	√	
2005	Corsa-C(GMSA)	Chassis	Electronic Power Steering	√	√	√	√		SP0141
2005	Corsa-C(GMSA)	Engine	Z 14 XE	√			√	√	SP0146,SP0145,SP0009,SP0019,SP0021,SP0011
2005	Corsa-C(GMSA)	Engine	C 14 SE	√	√	√	√	√	SP0145,SP0019
2005	Corsa-C(GMSA)	Engine	C 16 SE	√	√	√	√	√	SP0145,SP0019
2005	Corsa-C(GMSA)	Engine	Y 17 DT	√	√	√	√	√	
2005	Corsa-C(GMSA)	Engine	Y 17 DTL	√	√	√	√	√	
2005	Corsa-C(GMSA)	Engine	C 18 XE	√	√	√	√	√	SP0145,SP0019
2005	Corsa-C(GMSA)	Infotainment System	Trip Info Display TID	√	√	√			
2005	Corsa-C(GMSA)	Infotainment System	Radio CDR 2005	√	√	√	√		
2005	Corsa-C(GMSA)	Infotainment System	Radio CCRT 2008	√	√	√			
2005	Meriva	Body	Body Control Module	√	√	√	√	√	SP0051,SP0058,SP0138
2005	Meriva	Body	Immobiliser	√	√	√	√		SP0139,SP0140
2005	Meriva	Body	Airbag	√	√	√	√	√	
2005	Meriva	Body	Instrument	√	√	√	√	√	SP0176,SP0177
2005	Meriva	Body	Headlamp Levelling Device	√	√	√	√	√	SP0141
2005	Meriva	Body	Electronic Climate Control	√	√	√	√	√	
2005	Meriva	Body	Add On Heater	√	√	√	√	√	SP0122,SP0123
2005	Meriva	Chassis	ABS8/ESP8		√	√	√	√	SP0005,SP0142,SP0143,SP0144,SP0004
2005	Meriva	Chassis	Electronic Power Steering	√	√	√	√		SP0141
2005	Meriva	Engine	Y13DT	√	√	√	√	√	SP0040,SP0019,SP0021,SP0011,SP0020

2005	Meriva	Engine	Z14XEP	√	√	√	√	√	SP0033,SP0065,SP0006,SP0166,SP0009,SP0146,SP0019,SP0011,SP0021
2005	Meriva	Engine	Z16SE	√	√	√	√	√	
2005	Meriva	Engine	Z16XE	√			√	√	
2005	Meriva	Engine	Y17DT	√	√	√	√	√	
2005	Meriva	Engine	Z17DTH	√	√	√	√	√	SP0006,SP0146,SP0019,SP0020,SP0147,SP0022,SP0011,SP0021
2005	Meriva	Engine	Z18XE	√	√	√	√	√	SP0145,SP0009,SP0040,SP0019,SP0011,SP0021
2005	Meriva	Infotainment System	Trip Info Display TID	√	√	√			
2005	Meriva	Transmission	MTA(Easytronic)	√	√	√	√	√	SP0011,SP0148
2005	Movano	Body	Airbag	√	√	√	√		
2005	Movano	Body	Body Control Module	√	√	√	√	√	SP0051,SP0058,SP0138
2005	Movano	Chassis	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)		√	√	√	√	SP0164,SP0165
2005	Speedster/VX22	Body	Immobiliser	√	√	√	√		SP0139,SP0140
2005	Speedster/VX22	Body	Airbag	√	√	√	√		
2005	Speedster/VX22	Chassis	ABS 430	√	√	√	√		
2005	Speedster/VX22	Engine	Z20LET	√	√	√	√		
2005	Speedster/VX220	Engine	Z22SE	√	√	√	√	√	SP0065,SP0146,SP0145,SP0009,SP0011,SP0021,SP0033
2005	Tigra-B	Body	Body Control Module	√	√	√	√	√	SP0051,SP0058,SP0138
2005	Tigra-B	Body	Immobiliser	√	√	√	√		SP0139,SP0140
2005	Tigra-B	Body	Airbag	√	√	√	√	√	
2005	Tigra-B	Body	Instrument	√	√	√	√	√	SP0176,SP0177
2005	Tigra-B	Chassis	ABS8/ESP8		√	√	√	√	SP0005,SP0142,SP0143,SP0144,SP0004
2005	Tigra-B	Chassis	Electronic Power Steering	√	√	√	√		SP0141
2005	Tigra-B	Engine	Z13DT	√	√	√	√	√	SP0019,SP0040,SP0021,SP0011,SP0020
2005	Tigra-B	Engine	Z14XEP	√	√	√	√	√	SP0033,SP0065,SP0006,SP0166,SP0009,SP0146,SP0019,SP0011,SP0021
2005	Tigra-B	Engine	Z18XE	√	√	√	√	√	SP0145,SP0009,SP0040,SP0019,SP0011,SP0021
2005	Tigra-B	Transmission	MTA(Easytronic)	√	√	√	√	√	SP0011,SP0148
2005	Vauxhall Monaro	Engine	V8 GEN IV	√	√	√	√	√	SP0015,SP0149,SP0171,SP0172
2005	Vectra-	Body	SDM(Airbag,Sensing&Diagnostic Module)	√	√	√	√		SP0000,SP0001,SP0002
2005	Vectra-	Body	Instrument	√	√	√	√	√	SP0169,SP0056,SP0057,SP0179,SP0001

2005	Vectra-C/Signum	Body	CIM(Steering Column Module)	√	√	√	√	√	SP0051,SP0003,SP0052,SP0001,SP0004,SP0053,SP0054,SP0005
2005	Vectra-	Body	BCM(Body Control Module)	√	√	√			SP0180,SP0181
2005	Vectra-	Body	DDM(Driver Door Module)	√	√	√			
2005	Vectra-	Body	PDM(Passenger Door Module)	√	√	√			
2005	Vectra-	Body	REC(Rear Electrical Centre)	√	√	√	√		
2005	Vectra-	Body	UEC(Underhood Electrical Centre)	√	√	√	√		
2005	Vectra-	Body	SLM(Shift Lever Module)	√	√	√			
2005	Vectra-	Body	SRM(Sun Roof Module)	√	√	√			
2005	Vectra-	Body	AHL/AFL(Headlamp Levelling)	√	√	√			
2005	Vectra-	Body	Electrical Horn	√	√	√	√	√	
2005	Vectra-	Body	Electronic Seat Memory/Seat Heating	√	√	√	√		
2005	Vectra-	Body	Anti Theft Warning System	√	√	√	√	√	
2005	Vectra-	Body	Central Door Lock	√	√	√	√		
2005	Vectra-	Body	PAS (Park Pilot)	√	√	√	√	√	SP0001
2005	Vectra-	Chassis	ABS/TC/ESP	√	√	√	√	√	
2005	Vectra-	Chassis	EHPS(Electronic Power Steering)	√	√	√	√		
2005	Vectra-	Chassis	TPMS (Tyre Pressure Monitoring System)	√	√	√	√		SP0032
2005	Vectra-	Chassis	CDC(Continuous Damping Control)	√	√	√			
2005	Vectra-	Chassis	Electronic Cruise Control	√	√	√			
2005	Vectra-	Engine	Engine Cooling	√	√	√	√		
2005	Vectra-C/Signum	Engine	Z18XE	√	√	√	√	√	SP0019,SP0010,SP0011,SP0066,SP0149,SP0012
2005	Vectra-C/Signum	Engine	Z19DT	√	√	√	√	√	SP0149,SP0010,SP0011,SP0066,SP0023,SP0024,SP0069,SP0020,SP0012,SP0026,SP
2005	Vectra-C/Signum	Engine	Z19DTH	√	√	√	√	√	SP0149,SP0010,SP0011,SP0066,SP0023,SP0024,SP0028,SP0025,SP0026,SP0020,SP0012,SP0027,SP0029
2005	Vectra-	Engine	Y20DTH	√	√	√	√	√	SP0010,SP0011,SP0066,SP0149
2005	Vectra-	Engine	Y22DTR	√	√	√	√	√	SP0010,SP0011,SP0066,SP0149
2005	Vectra-	Engine	Y30DT	√	√	√	√	√	
2005	Vectra-	Engine	Z22SE	√	√	√	√	√	SP0010,SP0011,SP0066,SP0149
2005	Vectra-	Engine	Z22YH	√	√	√	√	√	SP0019,SP0149
2005	Vectra-	Engine	Z32SE	√	√	√	√	√	SP0019,SP0149
2005	Vectra-	Engine	Z16XE	√	√	√	√	√	SP0010,SP0011,SP0066,SP0149,SP0012
2005	Vectra-	Engine	Z20NET	√	√	√	√	√	SP0010,SP0011,SP0066,SP0149
2005	Vectra-	Engine	Engine(default)	√	√	√			
2005	Vectra-	Transmission	AF 23-5/33-5/40-6	√	√	√	√	√	SP0032,SP0033

2005	Vectra-C/Signum	Transmission	CVTronic	√	√	√	√	√	SP0186,SP0187,SP0188,SP0032,SP0003,SP0033
2005	Vivaro	Body	Airbag		√	√	√		SP0004
2005	Vivaro	Body	Add On Heater	√	√	√	√	√	SP0122,SP0123
2005	Vivaro	Body	Body Control Module		√	√	√	√	
2005	Vivaro	Chassis	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)	√	√	√	√	√	SP0174,SP0175
2005	Vivaro	Engine	F9Q 760/762 (1.9L)	√	√	√	√		
2005	Vivaro	Infotainment System	Trip Info Display TID	√	√	√			
2005	Vivaro	Infotainment System	Radio CAR 2003	√	√	√			
2005	Vivaro	Infotainment System	Radio CDR 2005	√	√	√	√		
2005	Vivaro	Infotainment System	Radio CCR 2006	√	√	√	√		
2005	Zafira	Body	Immobiliser	√	√	√	√		SP0139,SP0140
2005	Zafira	Body	Instrument	√	√	√	√		
2005	Zafira	Body	Airbag	√	√	√	√	√	
2005	Zafira	Body	Anti Theft Warning	√	√	√	√		
2005	Zafira	Body	Central Door Lock	√	√	√	√		
2005	Zafira	Body	Electronic Climate Control	√	√	√	√		
2005	Zafira	Body	Engine Cooling Module	√	√	√	√		
2005	Zafira	Body	Headlamp Adjustment(Left)	√	√	√	√		
2005	Zafira	Body	Headlamp Adjustment(Right)	√	√	√	√		
2005	Zafira	Chassis	ABS-5.3/5.4(+TC)	√	√	√	√	√	
2005	Zafira	Chassis	ESP	√	√	√	√	√	SP0005
2005	Zafira	Chassis	Electronic Power Steering	√	√	√	√		SP0141
2005	Zafira	Engine	Z16XE	√			√	√	
2005	Zafira	Engine	Z16YNG	√	√	√	√	√	
2005	Zafira	Engine	Z18XE	√	√	√	√	√	SP0145,SP0009,SP0040,SP0019,SP0011,SP0021
2005	Zafira	Engine	Y20DTH	√	√	√	√	√	SP0166,SP0167,SP0168,SP0169
2005	Zafira	Engine	Z20LET	√	√	√	√	√	SP0009,SP0019,SP0040,SP0145,SP0011,SP0021,SP0065,SP0033
2005	Zafira	Engine	Y22DTR	√	√	√	√	√	SP0011,SP0021
2005	Zafira	Engine	Z22SE	√	√	√	√	√	SP0065,SP0146,SP0145,SP0009,SP0011,SP0021,SP0033

2005	Zafira	Engine	Z18XEL	√	√	√	√	√	SP0145,SP0009,SP0040,SP0019
2005	Zafira	Infotainment System	Radio CAR 300	√	√	√	√		
2005	Zafira	Infotainment System	Trip Info Display TID	√	√	√			
2005	Zafira	Infotainment System	Multi Info Dispaly MID	√	√	√			
2005	Zafira	Infotainment System	Radio CAR 400	√	√	√	√		
2005	Zafira	Infotainment System	Radio CDR 500	√	√	√	√		
2005	Zafira	Infotainment System	Radio CCR 600	√	√	√	√		
2005	Zafira	Infotainment System	Radio CCRT 700	√	√	√	√		
2005	Zafira	Infotainment System	Radio NCDR 1100/1500	√	√	√	√		
2005	Zafira	Transmission	AF 13-II/17/20/22 CAN	√	√	√	√	√	
2005	Zafira-B	Body	SDM(Airbag)	√	√	√	√		SP0000,SP0001,SP0002
2005	Zafira-B	Body	CIM(Steering Column Module)	√	√	√	√	√	SP0066
2005	Zafira-B	Body	IPC ECU(Instrument Control Unit)	√	√	√	√		SP0033
2005	Zafira-B	Body	REC(Rear Electrical Centre)	√	√	√	√		SP0012
2005	Zafira-B	Body	UEC(Underhood Electrical Centre)	√	√	√	√		SP0018
2005	Zafira-B	Body	AHL/AFL(Headlamp Levelling)	√	√	√	√		
2005	Zafira-B	Body	ECC/SAC(Electronic Climate Control)	√	√	√	√	√	SP0150,SP0158,SP0159,SP0001,SP0004,S P0160
2005	Zafira-B	Body	EHS(Electrical Heater System)	√	√	√	√		SP0032,SP0001,SP0004
2005	Zafira-B	Body	PAS(Park Pilot)	√	√	√	√	√	SP0001
2005	Zafira-B	Body	SLM(Shift Lever Module)	√	√	√	√		
2005	Zafira-B	Body	PEPS(Open&Start)	√	√	√	√		
2005	Zafira-B	Body	Anti Theft Warning System	√	√	√	√	√	
2005	Zafira-B	Body	IPC ECU(Instrument Control Unit)	√	√	√	√	√	SP0006,SP0055,SP0056,SP0057,SP0058,S P0059,SP0060,SP0001,SP0004
2005	Zafira-B	Chassis	ABS/TC/ESP ECU(Electronic Control Unit)	√	√	√	√	√	
2005	Zafira-B	Chassis	EHPS(Electrohydraulic Power Steering)	√	√	√	√		SP0010
2005	Zafira-B	Chassis	ABS/TC/ESP(Vehicle Dynamic System)	√	√	√	√	√	SP0005
2005	Zafira-B	Chassis	TPMS ECU(Tyre Pressure Monitoring)	√	√	√	√		SP0001
2005	Zafira-B	Chassis	TPMS(Tyre Pressure Monitoring System)	√	√	√	√		

2005	Zafira-B	Chassis	CDC(Continuous Damping Control)	√	√	√	√		
2005	Zafira-B	Chassis	EHPS(Electrohydraulic Power Steering)	√	√	√	√		SP0003
2005	Zafira-B	Engine	Z16XEP	√	√	√	√		SP0006,SP0007,SP0008,SP0009,SP0019,S P0010,SP0011,SP0066,SP0012,SP0013,SP 0033,SP0018
2005	Zafira-B	Engine	Z18XER	√	√	√	√		SP0019,SP0006,SP0007,SP0008,SP0009,S P0010,SP0011,SP0066,SP0033,SP0012,SP
2005	Zafira-B	Engine	Z19DT	√	√	√	√	√	SP0006,SP0007,SP0008,SP0010,SP0011,S P0066,SP0023,SP0024,SP0069,SP0012,SP 0032,SP0020,SP0029,SP0026,SP0027,SP0 025,SP0028,SP0018
2005	Zafira-B	Engine	Z19DTH	√	√	√	√	√	SP0006,SP0007,SP0008,SP0032,SP0010,S P0011,SP0066,SP0023,SP0024,SP0028,SP 0025,SP0026,SP0027
2005	Zafira-B	Engine	Z16XE1	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0173,S P0010,SP0011,SP0066,SP0012,SP0013,SP 0033,SP0018
2005	Zafira-B	Engine	Z16XEP	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0019,S P0010,SP0011,SP0066,SP0012,SP0013,SP 0033,SP0018
2005	Zafira-B	Engine	Z18XE	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0019,S P0010,SP0011,SP0066,SP0012,SP0018
2005	Zafira-B	Engine	Z20LER	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,S P0011,SP0066,SP0012,SP0013,SP0018
2005	Zafira-B	Engine	Z22YH	√	√	√	√	√	SP0006,SP0007,SP0008,SP0071,SP0019,S P0010,SP0011,SP0066,SP0012,SP0013,SP
2005	Zafira-B	Engine	Engine(default)	√	√	√			
2005	Zafira-B	Transmission	MTA(Easutronic)	√	√	√	√	√	SP0003,SP0061,SP0034,SP0035
2005	Zafira-B	Transmission	AF 40-6	√	√	√	√	√	SP0072,SP0073,SP0074,SP0075,SP0076,S P0077,SP0032,SP0003,SP0033,SP0078
2005	Zafira-B	Transmission	AF 22-4	√	√	√	√	√	SP0030,SP0032,SP0003,SP0033
2004	Agila	Body	Immobiliser	√	√	√	√		SP0139,SP0140
2004	Agila	Body	Airbag	√	√	√	√		
2004	Agila	Body	Instrument	√	√	√	√		
2004	Agila	Chassis	ABS	√	√	√	√	√	SP0189
2004	Agila	Chassis	Electronic Power Steering	√	√	√	√		
2004	Agila	Engine	Z10XEP	√	√	√	√	√	SP0011,SP0021,SP0065,SP0033

2004	Agila	Engine	Z12XE	√	√	√	√	√	SP0006,SP0145,SP0009,SP0040,SP0019,SP0021,SP0011,SP0065,SP0033
2004	Agila	Engine	Z13DT	√	√	√	√	√	SP0019,SP0040,SP0021,SP0011,SP0020
2004	Agila	Infotainment System	Trip Info Display TID	√	√	√			
2004	Agila	Infotainment System	Radio CAR 2003	√	√	√			
2004	Agila	Infotainment System	Radio CDR 2005	√	√	√	√		
2004	Astra-G	Body	Immobiliser	√	√	√	√		SP0139,SP0140
2004	Astra-G	Body	Instrument	√	√	√	√		
2004	Astra-G	Body	Airbag	√	√	√	√		
2004	Astra-G	Body	Anti Theft Warning	√	√	√	√		
2004	Astra-G	Body	Central Door Lock	√	√	√	√		
2004	Astra-G	Body	Headlamp Levelling Device	√	√	√	√	√	SP0141
2004	Astra-G	Body	Electronic Climate Control	√	√	√	√		
2004	Astra-G	Body	Engine Cooling Module	√	√	√	√		
2004	Astra-G	Body	Add On Heater	√	√	√	√	√	SP0122,SP0123
2004	Astra-G	Body	Softtop Controller	√	√	√	√	√	
2004	Astra-G	Chassis	ABS-5.3/5.4(+TC)	√	√	√	√	√	
2004	Astra-G	Chassis	ESP	√	√	√	√	√	SP0005
2004	Astra-G	Chassis	Cruise Control	√	√	√	√		
2004	Astra-G	Chassis	Electronic Power Steering	√	√	√	√	√	
2004	Astra-G	Engine	Z12XE	√	√	√	√	√	SP0006,SP0145,SP0009,SP0040,SP0019,SP0021,SP0011,SP0065,SP0033
2004	Astra-G	Engine	Z14XE	√			√	√	SP0146,SP0145,SP0009,SP0019,SP0021,SP0011
2004	Astra-G	Engine	C16SEL	√	√	√	√	√	
2004	Astra-G	Engine	Z16SE	√	√	√	√	√	
2004	Astra-G	Engine	Z16XE	√			√	√	
2004	Astra-G	Engine	Z16XEP	√	√	√	√	√	SP0006,SP0146,SP0009,SP0019,SP0011,SP0021,SP0065
2004	Astra-G	Engine	Z16YNG	√	√	√	√	√	SP0006,SP0146,SP0145,SP0009,SP0019,SP0011,SP0021
2004	Astra-G	Engine	Y17DT	√	√	√	√	√	
2004	Astra-G	Engine	Z17DTL	√	√	√	√	√	
2004	Astra-G	Engine	Z18XE	√	√	√	√	√	SP0145,SP0009,SP0040,SP0019,SP0011,SP0021

2004	Astra-G	Engine	Z18XEL	√	√	√			SP0011,SP0021
2004	Astra-G	Engine	Y20DTH	√	√	√	√	√	SP0166,SP0167,SP0168,SP0169
2004	Astra-G	Engine	Z20LET	√	√	√	√	√	SP0009,SP0019,SP0040,SP0145,SP0011,SP0021,SP0065,SP0033
2004	Astra-G	Engine	Y22DTR	√	√	√	√	√	SP0011,SP0021
2004	Astra-G	Engine	Z22SE	√	√	√	√	√	SP0065,SP0146,SP0145,SP0009,SP0011,SP0021,SP0033
2004	Astra-G	Infotainment System	Trip Info Display TID	√	√	√			
2004	Astra-G	Infotainment System	Multi Info Display MID	√	√	√			
2004	Astra-G	Infotainment System	Radio CAR 300	√	√	√			
2004	Astra-G	Infotainment System	Radio CAR 400	√	√	√	√		
2004	Astra-G	Infotainment System	Radio CDR 500	√	√	√	√		
2004	Astra-G	Infotainment System	Radio CCR 600	√	√	√	√		
2004	Astra-G	Infotainment System	Radio CCRT 700	√	√	√	√		
2004	Astra-G	Infotainment System	Radio NCDR 1100/1500	√	√	√	√		
2004	Astra-G	Transmission	AF 13-II/17/20/22	√	√	√	√	√	
2004	Astra-G	Transmission	AF 13-II/17/20/22 CAN	√	√	√	√	√	
2004	Astra-G(GMSA)	Body	Airbag	√	√	√	√		
2004	Astra-G(GMSA)	Body	Anti Theft Warning	√	√	√	√		
2004	Astra-G(GMSA)	Body	Engine Cooling Module	√	√	√	√		
2004	Astra-G(GMSA)	Body	Central Door Lock	√	√	√	√		
2004	Astra-G(GMSA)	Body	Immobiliser	√	√	√	√		SP0164,SP0165
2004	Astra-G(GMSA)	Body	Instrument	√	√	√	√		
2004	Astra-G(GMSA)	Chassis	ABS-5.3/5.4 (+TC) (Anti-lock Braking System)	√	√	√	√	√	
2004	Astra-G(GMSA)	Chassis	Electronic Power Steering	√	√	√	√	√	
2004	Astra-G(GMSA)	Engine	C 16 SEL	√	√	√	√	√	
2004	Astra-G(GMSA)	Engine	Z 18 XE	√	√	√	√	√	SP0145,SP0009,SP0040,SP0019,SP0011,SP0021
2004	Astra-G(GMSA)	Engine	Z 22 SE	√	√	√	√	√	SP0146,SP0009,SP0145,SP0011,SP0021,SP0065,SP0033

2004	Astra-G(GMSA)	Infotainment System	Trip Info Display TID	√	√	√			
2004	Astra-H	Body	SDM(Airbag)	√	√	√	√		
2004	Astra-H	Body	CIM(Steering Column Module)	√	√	√	√	√	SP0051,SP0003,SP0052,SP0001,SP0004,S P0053,SP0054,SP0005
2004	Astra-H	Body	IPC ECU(Instrument Control Unit)	√	√	√	√		
2004	Astra-H	Body	REC(Rear Electrical Centre)	√	√	√	√		
2004	Astra-H	Body	UEC(Underhood Electrical Centre)	√	√	√	√		
2004	Astra-H	Body	AHL/AFL (Headlamp Levelling)	√	√	√	√		
2004	Astra-H	Body	Anti Theft Warning System	√	√	√	√	√	
2004	Astra-H	Body	Electrohydraulic HardTop	√	√	√	√	√	SP0001,SP0004
2004	Astra-H	Body	ECC/SAC (Electronic Climate Control)	√	√	√	√	√	SP0150,SP0158,SP0159,SP0032,SP0001,S P0004,SP0160
2004	Astra-H	Body	EHS (Electrical Heater System)	√	√	√	√		SP0032,SP0001,SP0004
2004	Astra-H	Body	PAS (Park Pilot)	√	√	√	√	√	SP0001
2004	Astra-H	Body	SLM (Shift Lever Module)	√	√	√	√		
2004	Astra-H	Body	PEPS (Open&Start)	√	√	√	√		
2004	Astra-H	Body	IPC ECU(Instrument Control Unit)	√	√	√	√	√	SP0006,SP0055,SP0056,SP0057,SP0058,S P0059,SP0060,SP0001,SP0004
2004	Astra-H	Chassis	ABS/TC/ESP ECU(Electronic Control Unit)	√	√	√	√	√	
2004	Astra-H	Chassis	EHPS(Electrohydraulic Power Steering)	√	√	√	√		
2004	Astra-H	Chassis	CDC (Continuous Damping Control)	√	√	√	√		
2004	Astra-H	Chassis	ABS/TC/ESP (Vehicle Dynamic System)	√	√	√	√	√	
2004	Astra-H	Chassis	EHPS(Electrohydraulic Power Steering)	√	√	√	√		SP0003
2004	Astra-H	Engine	Z14XEP	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,S P0011,SP0066,SP0012,SP0013,SP0018
2004	Astra-H	Engine	Z16XEP	√	√	√	√		SP0006,SP0007,SP0008,SP0009,SP0019,S P0010,SP0011,SP0066,SP0012,SP0013,SP 0033,SP0018
2004	Astra-H	Engine	Z17DTH	√	√	√	√	√	SP0006,SP0007,SP0008,SP0010,SP0011,S P0066,SP0020,SP0024,SP0012,SP0029,SP 0032,SP0018
2004	Astra-H	Engine	Z18XE	√	√	√	√		SP0019,SP0006,SP0007,SP0008,SP0009,S P0010,SP0011,SP0066,SP0012,SP0018
2004	Astra-H	Engine	Z16XER	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0019,S P0010,SP0011,SP0066,SP0033,SP0012,SP
2004	Astra-H	Engine	Z17DTL	√	√	√	√	√	SP0010,SP0011,SP0066,SP0020,SP0024,S P0012,SP0029,SP0032,SP0018

2004	Astra-H	Engine	Z19DT	√	√	√	√	√	SP0006,SP0007,SP0008,SP0010,SP0011,SP0066,SP0023,SP0024,SP0069,SP0012,SP0032,SP0020,SP0029,SP0026,SP0027,SP0025,SP0028,SP0018
2004	Astra-H	Engine	Z20LEL	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,SP0011,SP0066,SP0012,SP0013,SP0018
2004	Astra-H	Engine	Z20LER	√	√	√	√	√	SP0006,SP0007,SP0008,SP0009,SP0010,SP0011,SP0066,SP0012,SP0013,SP0018
2004	Astra-H	Engine	Engine(default)	√	√	√			
2004	Astra-H	Transmission	AF 17-4	√	√	√	√	√	SP0030,SP0031,SP0032,SP0003,SP0033
2004	Astra-H	Transmission	MTA(Easytronic)	√	√	√	√	√	SP0003,SP0061,SP0034,SP0035
2004	Combo	Body	Add On Heater	√	√	√	√	√	SP0122,SP0123
2004	Combo	Body	Airbag	√	√	√	√	√	
2004	Combo	Body	Body Control Module	√	√	√	√	√	SP0051,SP0058,SP0138
2004	Combo	Body	Immobiliser	√	√	√	√		SP0164,SP0165
2004	Combo	Body	Instrument	√	√	√	√		
2004	Combo	Body	Electronic Climate Control	√	√	√	√		
2004	Combo	Body	HeadLamp Levelling Device		√	√	√	√	SP0141
2004	Combo	Chassis	ABS-5.3/5.4 (+TC) (Anti-lock Braking System)	√	√	√	√	√	
2004	Combo	Chassis	Electronic Power Steering	√	√	√	√		SP0141
2004	Combo	Chassis	ABS8/ESP8 (Anti-lock Braking System/Electronic Stability Program)		√	√	√	√	SP0005,SP0142,SP0143,SP0144,SP0004
2004	Combo	Engine	Z 10 XEP	√	√	√	√	√	SP0011,SP0021,SP0065,SP0033
2004	Combo	Engine	Z 12 XE	√	√	√	√	√	SP0006,SP0145,SP0009,SP0040,SP0019,SP0021,SP0011,SP0065,SP0033
2004	Combo	Engine	Z 13 DT	√	√	√	√	√	SP0040,SP0019,SP0021,SP0011,SP0020
2004	Combo	Engine	Z 14 XE	√			√	√	SP0146,SP0145,SP0009,SP0019,SP0021,SP0011
2004	Combo	Engine	Z 14 XEP	√	√	√	√	√	SP0006,SP0166,SP0009,SP0146,SP0019,SP0011,SP0021,SP0065,SP0033
2004	Combo	Engine	Z 16 SE	√	√	√	√	√	
2004	Combo	Engine	Y 17 DT	√	√	√	√	√	
2004	Combo	Engine	Y 17 DTL	√	√	√	√	√	
2004	Combo	Engine	Z 17 DTH	√	√	√	√	√	SP0006,SP0146,SP0019,SP0022,SP0011,SP0021,SP0020,SP0147
2004	Combo	Engine	Z 18 XE	√	√	√	√	√	SP0145,SP0009,SP0040,SP0019,SP0011,SP0021

2004	Combo	Infotainment System	Trip Info Display TID	√	√	√			
2004	Combo	Infotainment System	Radio CAR 2003	√	√	√			
2004	Combo	Infotainment System	Radio CDR 2005	√	√	√	√		
2004	Combo	Infotainment System	Radio CCR 2006	√	√	√	√		
2004	Combo	Transmission	AF 13-II/17/20/22	√	√	√	√	√	
2004	Combo	Transmission	AF 13-II/17/20/22 CAN	√	√	√	√	√	
2004	Combo	Transmission	Easytronic(MTA)	√	√	√	√	√	SP0011,SP0148
2004	Corsa-B(GMSA)	Body	Immobiliser	√	√	√	√		SP0164,SP0165
2004	Corsa-B(GMSA)	Engine	14 NE	√	√	√	√	√	SP0166,SP0190,SP0191,SP0056,SP0192
2004	Corsa-B(GMSA)	Engine	16 SE	√	√	√			
2004	Corsa-C	Body	Body Control Module	√	√	√	√	√	SP0051,SP0058,SP0138
2004	Corsa-C	Body	Immobiliser	√	√	√	√		SP0139,SP0140
2004	Corsa-C	Body	Airbag	√	√	√	√	√	
2004	Corsa-C	Body	Instrument	√	√	√	√	√	SP0176,SP0177
2004	Corsa-C	Body	Add On Heater	√	√	√	√	√	SP0122,SP0123
2004	Corsa-C	Body	Electronic Climate Control	√	√	√	√		
2004	Corsa-C	Body	HeadLamp Levelling Device		√	√	√	√	SP0141
2004	Corsa-C	Chassis	ABS-5.3/5.4(+TC)	√	√	√	√	√	
2004	Corsa-C	Chassis	ABS8/ESP8		√	√	√	√	SP0005,SP0142,SP0143,SP0144,SP0004
2004	Corsa-C	Chassis	Electronic Power Steering	√	√	√	√		SP0141
2004	Corsa-C	Engine	Z10XEP	√	√	√	√	√	SP0011,SP0021,SP0065,SP0033
2004	Corsa-C	Engine	Z12XE	√	√	√	√	√	SP0006,SP0145,SP0009,SP0040,SP0019,SP0021,SP0011,SP0065,SP0033
2004	Corsa-C	Engine	Z13DT	√	√	√	√	√	SP0019,SP0040,SP0021,SP0011,SP0020
2004	Corsa-C	Engine	Z14XE	√			√	√	SP0146,SP0145,SP0009,SP0019,SP0021,SP0011
2004	Corsa-C	Engine	Z14XEP	√	√	√	√	√	SP0033,SP0065,SP0006,SP0166,SP0009,SP0146,SP0019,SP0011,SP0021
2004	Corsa-C	Engine	Z16SE	√	√	√	√	√	
2004	Corsa-C	Engine	Y17DT	√	√	√	√	√	
2004	Corsa-C	Engine	Y17DTL	√	√	√	√	√	
2004	Corsa-C	Engine	Z17DTH	√	√	√	√	√	SP0006,SP0146,SP0019,SP0020,SP0147,SP0022,SP0011,SP0021

2004	Corsa-C	Engine	Z18XE	√	√	√	√	√	SP0145,SP0009,SP0040,SP0019,SP0011,SP0021
2004	Corsa-C	Infotainment System	Trip Info Display TID	√	√	√			
2004	Corsa-C	Infotainment System	Radio CAR 2003	√	√	√			
2004	Corsa-C	Infotainment System	Radio CDR 2005	√	√	√	√		
2004	Corsa-C	Infotainment System	Radio CCR 2006	√	√	√	√		
2004	Corsa-C	Transmission	AF 13-II/17/20/22 CAN	√	√	√	√	√	
2004	Corsa-C	Transmission	MTA(Easytronic)	√	√	√	√	√	SP0011,SP0148
2004	Corsa-C	Transmission	AF 13-II/17/20/22	√	√	√	√	√	
2004	Corsa-C(GMSA)	Body	Airbag	√	√	√	√	√	
2004	Corsa-C(GMSA)	Body	Body Control Module	√	√	√	√	√	SP0051,SP0058,SP0138
2004	Corsa-C(GMSA)	Body	Immobiliser	√	√	√	√		SP0164,SP0165
2004	Corsa-C(GMSA)	Body	Instrument	√	√	√	√		
2004	Corsa-C(GMSA)	Body	Power Window Lifter Front	√	√	√	√		
2004	Corsa-C(GMSA)	Body	Power Window Lifter Rear	√	√	√	√		
2004	Corsa-C(GMSA)	Chassis	ABS-5.3/5.4 (+TC) (Anti-lock Braking System)	√	√	√	√	√	
2004	Corsa-C(GMSA)	Chassis	Electronic Power Steering	√	√	√	√		SP0141
2004	Corsa-C(GMSA)	Engine	C 14 SE	√	√	√	√	√	SP0145,SP0019
2004	Corsa-C(GMSA)	Engine	C 16 SE	√	√	√	√	√	SP0145,SP0019
2004	Corsa-C(GMSA)	Engine	Y 17 DT	√	√	√	√	√	
2004	Corsa-C(GMSA)	Engine	Y 17 DTL	√	√	√	√	√	
2004	Corsa-C(GMSA)	Engine	C 18 XE	√	√	√	√	√	SP0145,SP0019
2004	Corsa-C(GMSA)	Infotainment System	Trip Info Display TID	√	√	√			
2004	Corsa-C(GMSA)	Infotainment System	Radio CDR 2005	√	√	√	√		
2004	Corsa-C(GMSA)	Infotainment System	Radio CCRT 2008	√	√	√			
2004	Meriva	Body	Body Control Module	√	√	√	√	√	SP0051,SP0058,SP0138
2004	Meriva	Body	Immobiliser	√	√	√	√		SP0139,SP0140
2004	Meriva	Body	Airbag	√	√	√	√	√	
2004	Meriva	Body	Instrument	√	√	√	√	√	SP0176,SP0177
2004	Meriva	Body	Headlamp Levelling Device	√	√	√	√	√	SP0141
2004	Meriva	Body	Electronic Climate Control	√	√	√	√	√	

2004	Meriva	Body	Add On Heater	√	√	√	√	√	SP0122,SP0123
2004	Meriva	Chassis	ABS-5.3/5.4(+TC)	√	√	√	√	√	
2004	Meriva	Chassis	ESP	√	√	√	√	√	SP0005
2004	Meriva	Chassis	Electronic Power Steering	√	√	√	√		SP0141
2004	Meriva	Engine	Z16SE	√	√	√	√	√	
2004	Meriva	Engine	Z16XE	√			√	√	
2004	Meriva	Engine	Y17DT	√	√	√	√	√	
2004	Meriva	Engine	Z17DTH	√	√	√	√	√	SP0006,SP0146,SP0019,SP0020,SP0147,S P0022,SP0011,SP0021
2004	Meriva	Engine	Z18XE	√	√	√	√	√	SP0145,SP0009,SP0040,SP0019,SP0011,S P0021
2004	Meriva	Infotainment System	Trip Info Display TID	√	√	√			
2004	Meriva	Infotainment System	Radio CAR 2003	√	√	√			
2004	Meriva	Infotainment System	Radio CDR 2005	√	√	√	√		
2004	Meriva	Infotainment System	Radio CCR 2006	√	√	√	√		
2004	Meriva	Transmission	MTA(Easytronic)	√	√	√	√	√	SP0011,SP0148
2004	Movano	Body	Airbag	√	√	√	√		
2004	Movano	Body	Immobiliser	√	√	√	√		SP0164,SP0165
2004	Movano	Chassis	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)		√	√	√	√	SP0164,SP0165
2004	Speedster/VX22	Body	Immobiliser	√	√	√	√		SP0139,SP0140
2004	Speedster/VX22	Body	Airbag	√	√	√	√		
2004	Speedster/VX22	Chassis	ABS 430	√	√	√	√		
2004	Speedster/VX22	Engine	Z20LET	√	√	√	√		
2004	Speedster/VX22 0	Engine	Z22SE	√	√	√	√	√	SP0065,SP0146,SP0145,SP0009,SP0011,S P0021,SP0033
2004	Vectra-	Body	SDM(Airbag,Sensing&Diagnostic Module)	√	√	√	√		SP0000,SP0001,SP0002
2004	Vectra-	Body	Instrument	√	√	√	√	√	SP0169,SP0056,SP0057,SP0179,SP0001
2004	Vectra- C/Signum	Body	CIM(Steering Column Module)	√	√	√	√	√	SP0051,SP0003,SP0052,SP0001,SP0004,S P0053,SP0054,SP0005
2004	Vectra-	Body	BCM(Body Control Module)	√	√	√			SP0180,SP0181
2004	Vectra-	Body	DDM(Driver Door Module)	√	√	√			
2004	Vectra-	Body	PDM(Passenger Door Module)	√	√	√			
2004	Vectra-	Body	REC(Rear Electrical Centre)	√	√	√	√		

2004	Vectra-	Body	UEC(Underhood Electrical Centre)	√	√	√	√		
2004	Vectra-	Body	SLM(Shift Lever Module)	√	√	√			
2004	Vectra-	Body	SRM(Sun Roof Module)	√	√	√			
2004	Vectra-	Body	AHL/AFL(Headlamp Levelling)	√	√	√			
2004	Vectra-	Chassis	ABS/TC/ESP	√	√	√	√	√	
2004	Vectra-	Chassis	TPMS (Tyre Pressure Monitoring System)	√	√	√	√		SP0032
2004	Vectra-	Chassis	EHPS(Electronic Power Steering)	√	√	√	√		
2004	Vectra-	Chassis	Electronic Cruise Control	√	√	√			
2004	Vectra-	Engine	Engine Cooling	√	√	√	√		
2004	Vectra-C/Signum	Engine	Z18XE	√	√	√	√	√	SP0019,SP0010,SP0011,SP0066,SP0149,SP0012
2004	Vectra-C/Signum	Engine	Z19DT	√	√	√	√	√	SP0149,SP0010,SP0011,SP0066,SP0023,SP0024,SP0069,SP0020,SP0012,SP0026,SP
2004	Vectra-C/Signum	Engine	Z19DTH	√	√	√	√	√	SP0149,SP0010,SP0011,SP0066,SP0023,SP0024,SP0028,SP0025,SP0026,SP0020,SP0012,SP0027,SP0029
2004	Vectra-	Engine	Y20DTH	√	√	√	√	√	SP0010,SP0011,SP0066,SP0149
2004	Vectra-	Engine	Y22DTR	√	√	√	√	√	SP0010,SP0011,SP0066,SP0149
2004	Vectra-	Engine	Y30DT	√	√	√	√	√	
2004	Vectra-	Engine	Z22SE	√	√	√	√	√	SP0010,SP0011,SP0066,SP0149
2004	Vectra-	Engine	Z22YH	√	√	√	√	√	SP0019,SP0149
2004	Vectra-	Engine	Z32SE	√	√	√	√	√	SP0019,SP0149
2004	Vectra-	Engine	Z16XE	√	√	√	√	√	SP0010,SP0011,SP0066,SP0149,SP0012
2004	Vectra-	Engine	Z20NET	√	√	√	√	√	SP0010,SP0011,SP0066,SP0149
2004	Vectra-	Engine	Engine(default)	√	√	√			
2004	Vectra-	Transmission	AF 23-5/33-5/40-6	√	√	√	√	√	SP0032,SP0033
2004	Vectra-C/Signum	Transmission	CVTronic	√	√	√	√	√	SP0186,SP0187,SP0188,SP0032,SP0003,SP0033
2004	Vectra-	Transmission	AF 23-5/33-5	√	√	√	√	√	SP0032,SP0033
2004	Vivaro	Body	Airbag		√	√	√		SP0004
2004	Vivaro	Body	Add On Heater	√	√	√	√	√	SP0122,SP0123
2004	Vivaro	Body	Body Control Module		√	√	√	√	
2004	Vivaro	Chassis	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)	√	√	√	√	√	SP0174,SP0175
2004	Vivaro	Engine	F9Q 760/762 (1.9L)	√	√	√	√		
2004	Vivaro	Infotainment System	Trip Info Display TID	√	√	√			

2004	Vivaro	Infotainment System	Radio CAR 2003	√	√	√			
2004	Vivaro	Infotainment System	Radio CDR 2005	√	√	√	√		
2004	Vivaro	Infotainment System	Radio CCR 2006	√	√	√	√		
2004	Zafira	Body	Immobiliser	√	√	√	√		SP0139,SP0140
2004	Zafira	Body	Instrument	√	√	√	√		
2004	Zafira	Body	Airbag	√	√	√	√	√	
2004	Zafira	Body	Anti Theft Warning	√	√	√	√		
2004	Zafira	Body	Central Door Lock	√	√	√	√		
2004	Zafira	Body	Electronic Climate Control	√	√	√	√		
2004	Zafira	Body	Engine Cooling Module	√	√	√	√		
2004	Zafira	Body	Headlamp Adjustment(Left)	√	√	√	√		
2004	Zafira	Body	Headlamp Adjustment(Right)	√	√	√	√		
2004	Zafira	Chassis	ABS-5.3/5.4(+TC)	√	√	√	√	√	
2004	Zafira	Chassis	ESP	√	√	√	√	√	SP0005
2004	Zafira	Chassis	Electronic Power Steering	√	√	√	√		SP0141
2004	Zafira	Engine	Z16XE	√			√	√	
2004	Zafira	Engine	Z16YNG	√	√	√	√	√	
2004	Zafira	Engine	Z18XE	√	√	√	√	√	SP0145,SP0009,SP0040,SP0019,SP0011,SP0021
2004	Zafira	Engine	Y20DTH	√	√	√	√	√	SP0166,SP0167,SP0168,SP0169
2004	Zafira	Engine	Z20LET	√	√	√	√	√	SP0009,SP0019,SP0040,SP0145,SP0011,SP0021,SP0065,SP0033
2004	Zafira	Engine	Y22DTR	√	√	√	√	√	SP0011,SP0021
2004	Zafira	Engine	Z22SE	√	√	√	√	√	SP0065,SP0146,SP0145,SP0009,SP0011,SP0021,SP0033
2004	Zafira	Engine	Z18XEL	√	√	√	√	√	SP0145,SP0009,SP0040,SP0019
2004	Zafira	Infotainment System	Radio CAR 300	√	√	√	√		
2004	Zafira	Infotainment System	Trip Info Display TID	√	√	√			
2004	Zafira	Infotainment System	Multi Info Display MID	√	√	√			
2004	Zafira	Infotainment System	Radio CAR 400	√	√	√	√		

2004	Zafira	Infotainment System	Radio CDR 500	√	√	√	√		
2004	Zafira	Infotainment System	Radio CCR 600	√	√	√	√		
2004	Zafira	Infotainment System	Radio CCRT 700	√	√	√	√		
2004	Zafira	Infotainment System	Radio NCDR 1100/1500	√	√	√	√		
2004	Zafira	Transmission	AF 13-II/17/20/22 CAN	√	√	√	√	√	
2003	Agila	Body	Immobiliser	√	√	√	√		SP0139,SP0140
2003	Agila	Body	Airbag	√	√	√	√		
2003	Agila	Body	Instrument	√	√	√	√		
2003	Agila	Chassis	ABS	√	√	√	√	√	SP0189
2003	Agila	Chassis	Electronic Power Steering	√	√	√	√		
2003	Agila	Engine	Z10XEP	√	√	√	√	√	SP0011,SP0021,SP0065,SP0033
2003	Agila	Engine	Z12XE	√	√	√	√	√	SP0006,SP0145,SP0009,SP0040,SP0019,SP0021,SP0011,SP0065,SP0033
2003	Agila	Infotainment System	Trip Info Display TID	√	√	√			
2003	Agila	Infotainment System	Radio CAR 2003	√	√	√			
2003	Agila	Infotainment System	Radio CDR 2005	√	√	√	√		
2003	Astra-G	Body	Immobiliser	√	√	√	√		SP0139,SP0140
2003	Astra-G	Body	Instrument	√	√	√	√		
2003	Astra-G	Body	Airbag	√	√	√	√		
2003	Astra-G	Body	Anti Theft Warning	√	√	√	√		
2003	Astra-G	Body	Central Door Lock	√	√	√	√		
2003	Astra-G	Body	Headlamp Levelling Device	√	√	√	√	√	SP0141
2003	Astra-G	Body	Electronic Climate Control	√	√	√	√		
2003	Astra-G	Body	Engine Cooling Module	√	√	√	√		
2003	Astra-G	Body	Add On Heater	√	√	√	√	√	SP0122,SP0123
2003	Astra-G	Body	Softtop Controller	√	√	√	√	√	
2003	Astra-G	Chassis	ABS-5.3/5.4(+TC)	√	√	√	√	√	
2003	Astra-G	Chassis	ESP	√	√	√	√	√	SP0005
2003	Astra-G	Chassis	Cruise Control	√	√	√	√		
2003	Astra-G	Chassis	Electronic Power Steering	√	√	√	√	√	

2003	Astra-G	Engine	Z12XE	√	√	√	√	√	SP0006,SP0145,SP0009,SP0040,SP0019,S P0021,SP0011,SP0065,SP0033
2003	Astra-G	Engine	Z14XE	√			√	√	SP0146,SP0145,SP0009,SP0019,SP0021,S P0011
2003	Astra-G	Engine	C16SEL	√	√	√	√	√	
2003	Astra-G	Engine	Z16SE	√	√	√	√	√	
2003	Astra-G	Engine	Z16XE	√			√	√	
2003	Astra-G	Engine	Z16XEP	√	√	√	√	√	
2003	Astra-G	Engine	Z16YNG	√	√	√	√	√	SP0006,SP0146,SP0145,SP0009,SP0019,S P0011,SP0021
2003	Astra-G	Engine	Y17DT	√	√	√	√	√	
2003	Astra-G	Engine	Z17DTL	√	√	√	√	√	
2003	Astra-G	Engine	Z18XE	√	√	√	√	√	SP0145,SP0009,SP0040,SP0019,SP0011,S P0021
2003	Astra-G	Engine	Z18XEL	√	√	√			SP0011,SP0021
2003	Astra-G	Engine	Y20DTH	√	√	√	√	√	SP0166,SP0167,SP0168,SP0169
2003	Astra-G	Engine	Z20LET	√	√	√	√	√	SP0009,SP0019,SP0040,SP0145,SP0011,S P0021,SP0065,SP0033
2003	Astra-G	Engine	Y22DTR	√	√	√	√	√	SP0011,SP0021
2003	Astra-G	Engine	Z22SE	√	√	√	√	√	SP0065,SP0146,SP0145,SP0009,SP0011,S P0021,SP0033
2003	Astra-G	Infotainment System	Trip Info Display TID	√	√	√			
2003	Astra-G	Infotainment System	Multi Info Dispaly MID	√	√	√			
2003	Astra-G	Infotainment System	Radio CAR 300	√	√	√			
2003	Astra-G	Infotainment System	Radio CAR 400	√	√	√	√		
2003	Astra-G	Infotainment System	Radio CDR 500	√	√	√	√		
2003	Astra-G	Infotainment System	Radio CCR 600	√	√	√	√		
2003	Astra-G	Infotainment System	Radio CCRT 700	√	√	√	√		
2003	Astra-G	Infotainment System	Radio NCDR 1100/1500	√	√	√	√		
2003	Astra-G	Transmission	AF 13-II/17/20/22	√	√	√	√	√	

2003	Astra-G	Transmission	AF 13-II/17/20/22 CAN	√	√	√	√	√	
2003	Astra-G(GMSA)	Body	Airbag	√	√	√	√		
2003	Astra-G(GMSA)	Body	Anti Theft Warning	√	√	√	√		
2003	Astra-G(GMSA)	Body	Central Door Lock	√	√	√	√		
2003	Astra-G(GMSA)	Body	Engine Cooling Module	√	√	√	√		
2003	Astra-G(GMSA)	Body	Immobiliser	√	√	√	√		SP0164,SP0165
2003	Astra-G(GMSA)	Body	Instrument	√	√	√	√		
2003	Astra-G(GMSA)	Chassis	ABS-5.3/5.4 (+TC) (Anti-lock Braking System)	√	√	√	√	√	
2003	Astra-G(GMSA)	Chassis	Electronic Power Steering	√	√	√	√	√	
2003	Astra-G(GMSA)	Engine	C 16 SEL	√	√	√	√	√	
2003	Astra-G(GMSA)	Engine	Z 18 XE	√	√	√	√	√	SP0145,SP0009,SP0040,SP0019,SP0011,S P0021
2003	Astra-G(GMSA)	Engine	20 SEL	√	√	√	√	√	SP0019
2003	Astra-G(GMSA)	Engine	Z 20 LET	√	√	√	√	√	SP0145,SP0009,SP0040,SP0019
2003	Astra-G(GMSA)	Engine	Z 22 SE	√	√	√	√	√	SP0146,SP0009,SP0145,SP0011,SP0021,S P0065,SP0033
2003	Astra-G(GMSA)	Infotainment System	Trip Info Display TID	√	√	√			
2003	Combo	Body	Add On Heater	√	√	√	√	√	SP0122,SP0123
2003	Combo	Body	Airbag	√	√	√	√	√	
2003	Combo	Body	Body Control Module	√	√	√	√	√	SP0051,SP0058,SP0138
2003	Combo	Body	Electronic Climate Control	√	√	√	√		
2003	Combo	Body	Immobiliser	√	√	√	√		SP0164,SP0165
2003	Combo	Body	Instrument	√	√	√	√		
2003	Combo	Chassis	ABS-5.3/5.4 (+TC) (Anti-lock Braking System)	√	√	√	√	√	
2003	Combo	Chassis	Electronic Power Steering	√	√	√	√		SP0141
2003	Combo	Engine	Z 10 XE	√	√	√	√	√	SP0146,SP0194,SP0009,SP0019
2003	Combo	Engine	Z 12 XE	√	√	√	√	√	SP0006,SP0145,SP0009,SP0040,SP0019,S P0021,SP0011,SP0065,SP0033
2003	Combo	Engine	Z 14 XE	√			√	√	SP0146,SP0145,SP0009,SP0019,SP0021,S P0011
2003	Combo	Engine	Z 16 SE	√	√	√	√	√	
2003	Combo	Engine	Y 17 DT	√	√	√	√	√	
2003	Combo	Engine	Y 17 DTL	√	√	√	√	√	
2003	Combo	Engine	Z 18 XE	√	√	√	√	√	SP0145,SP0009,SP0040,SP0019,SP0011,S P0021
2003	Combo	Infotainment System	Radio CCR 2006	√	√	√	√		

2003	Combo	Transmission	AF 13-II/17/20/22	√	√	√	√	√	
2003	Combo	Transmission	AF 13-II/17/20/22 CAN	√	√	√	√	√	
2003	Combo	Transmission	Easytronic(MTA)	√	√	√	√	√	SP0011,SP0148
2003	Combo	Transmission	Trip Info Display TID	√	√	√			
2003	Combo	Transmission	Radio CAR 2003	√	√	√			
2003	Combo	Transmission	Radio CDR 2005	√	√	√	√		
2003	Corsa-B	Body	Immobiliser	√	√	√	√		
2003	Corsa-B	Body	Airbag S	√	√	√	√		
2003	Corsa-B	Body	Airbag SAB6	√	√	√	√		
2003	Corsa-B	Body	Anti Theft Warning	√	√	√	√	√	
2003	Corsa-B	Body	Instrument	√	√	√	√	√	SP0176,SP0177
2003	Corsa-B	Chassis	ABS-5.3	√	√	√	√		
2003	Corsa-B	Chassis	Electronic Power Steering	√	√	√	√		
2003	Corsa-B	Engine	Z14SZ	√	√	√	√	√	
2003	Corsa-B	Engine	C14SE	√	√	√	√		
2003	Corsa-B	Engine	X14NE	√	√	√	√		
2003	Corsa-B	Engine	X16NE	√	√	√	√		
2003	Corsa-B	Infotainment System	Multi Info Dispaly MID	√	√	√			
2003	Corsa-B	Infotainment System	Radio CAR 300	√	√	√			
2003	Corsa-B	Infotainment System	Radio CAR 400	√	√	√	√		
2003	Corsa-B	Infotainment System	Radio CDR 500	√	√	√	√		
2003	Corsa-B	Infotainment System	Radio CCR 600	√	√	√	√		
2003	Corsa-B	Infotainment System	Radio CCRT 700	√	√	√	√		
2003	Corsa-B	Infotainment System	Radio NCDR 1100/1500	√	√	√	√		
2003	Corsa-B(GMSA)	Body	Immobiliser	√	√	√	√		SP0164,SP0165
2003	Corsa-B(GMSA)	Engine	14 NE	√	√	√	√	√	SP0166,SP0190,SP0191,SP0056,SP0192
2003	Corsa-B(GMSA)	Engine	16 SE	√	√	√			
2003	Corsa-C	Body	Body Control Module	√	√	√	√	√	SP0051,SP0058,SP0138
2003	Corsa-C	Body	Immobiliser	√	√	√	√		SP0139,SP0140
2003	Corsa-C	Body	Airbag	√	√	√	√	√	
2003	Corsa-C	Body	Instrument	√	√	√	√	√	SP0176,SP0177

2003	Corsa-C	Body	Add On Heater	√	√	√	√	√	SP0122,SP0123
2003	Corsa-C	Body	Electronic Climate Control	√	√	√	√		
2003	Corsa-C	Chassis	ABS-5.3/5.4(+TC)	√	√	√	√	√	
2003	Corsa-C	Chassis	Electronic Power Steering	√	√	√	√		SP0141
2003	Corsa-C	Engine	Z10XE	√	√	√	√	√	SP0146,SP0193,SP0009,SP0019
2003	Corsa-C	Engine	Z12XE	√	√	√	√	√	SP0006,SP0145,SP0009,SP0040,SP0019,SP0021,SP0011,SP0065,SP0033
2003	Corsa-C	Engine	Z14XE	√			√	√	SP0146,SP0145,SP0009,SP0019,SP0021,SP0011
2003	Corsa-C	Engine	Z16SE	√	√	√	√	√	
2003	Corsa-C	Engine	Y17DT	√	√	√	√	√	
2003	Corsa-C	Engine	Y17DTL	√	√	√	√	√	
2003	Corsa-C	Engine	Z18XE	√	√	√	√	√	SP0145,SP0009,SP0040,SP0019,SP0011,SP0021
2003	Corsa-C	Infotainment System	Trip Info Display TID	√	√	√			
2003	Corsa-C	Infotainment System	Radio CAR 2003	√	√	√			
2003	Corsa-C	Infotainment System	Radio CDR 2005	√	√	√	√		
2003	Corsa-C	Infotainment System	Radio CCR 2006	√	√	√	√		
2003	Corsa-C	Transmission	AF 13-II/17/20/22 CAN	√	√	√	√	√	
2003	Corsa-C	Transmission	MTA(Easytronic)	√	√	√	√	√	SP0011,SP0148
2003	Corsa-C	Transmission	AF 13-II/17/20/22	√	√	√	√	√	
2003	Corsa-C(GMSA)	Body	Airbag	√	√	√	√	√	
2003	Corsa-C(GMSA)	Body	Body Control Module	√	√	√	√	√	SP0051,SP0058,SP0138
2003	Corsa-C(GMSA)	Body	Immobiliser	√	√	√	√		SP0164,SP0165
2003	Corsa-C(GMSA)	Body	Instrument	√	√	√	√		
2003	Corsa-C(GMSA)	Body	Power Window Lifter Front	√	√	√	√		
2003	Corsa-C(GMSA)	Body	Power Window Lifter Rear	√	√	√	√		
2003	Corsa-C(GMSA)	Chassis	ABS-5.3/5.4 (+TC) (Anti-lock Braking System)	√	√	√	√	√	
2003	Corsa-C(GMSA)	Chassis	Electronic Power Steering	√	√	√	√		SP0141
2003	Corsa-C(GMSA)	Engine	C 14 SE	√	√	√	√	√	SP0145,SP0019
2003	Corsa-C(GMSA)	Engine	C 16 SE	√	√	√	√	√	SP0145,SP0019
2003	Corsa-C(GMSA)	Engine	Y 17 DT	√	√	√	√	√	
2003	Corsa-C(GMSA)	Engine	Y 17 DTL	√	√	√	√	√	
2003	Corsa-C(GMSA)	Engine	C 18 XE	√	√	√	√	√	SP0145,SP0019

2003	Corsa-C(GMSA)	Infotainment System	Trip Info Display TID	√	√	√			
2003	Corsa-C(GMSA)	Infotainment System	Radio CDR 2005	√	√	√	√		
2003	Corsa-C(GMSA)	Infotainment System	Radio CCRT 2008	√	√	√			
2003	Frontera-B	Body	Anti Theft Warning	√	√	√			
2003	Frontera-B	Engine	Y22DTH	√	√	√	√	√	SP0006
2003	Frontera-B	Infotainment System	Trip Info Display TID	√	√	√			
2003	Frontera-B	Infotainment System	Multi Info Dispaly MID	√	√	√			
2003	Frontera-B	Infotainment System	Radio CAR 300	√	√	√			
2003	Frontera-B	Infotainment System	Radio CAR 400	√	√	√	√		
2003	Frontera-B	Infotainment System	Radio CDR 500	√	√	√	√		
2003	Frontera-B	Infotainment System	Radio CCR 600	√	√	√	√		
2003	Frontera-B	Infotainment System	Radio CCRT 700	√	√	√	√		
2003	Frontera-B	Infotainment System	Radio NCDR 1100/1500	√	√	√	√		
2003	Frontera-B	Transmission	AR 25/35	√	√	√	√	√	
2003	Frontera-B	Transmission	Airbag	√	√	√	√		
2003	Frontera-B	Transmission	Central Door Lock	√	√	√	√	√	SP0164,SP0165
2003	Frontera-B	Transmission	Immobiliser	√	√	√	√		SP0164,SP0165
2003	Meriva	Body	Body Control Module	√	√	√	√	√	SP0051,SP0058,SP0138
2003	Meriva	Body	Immobiliser	√	√	√	√		SP0139,SP0140
2003	Meriva	Body	Airbag	√	√	√	√	√	
2003	Meriva	Body	Instrument	√	√	√	√	√	SP0176,SP0177
2003	Meriva	Body	Headlamp Levelling Device	√	√	√	√	√	SP0141
2003	Meriva	Body	Electronic Climate Control	√	√	√	√	√	
2003	Meriva	Chassis	ABS-5.3/5.4(+TC)	√	√	√	√	√	
2003	Meriva	Chassis	ESP	√	√	√	√	√	SP0005
2003	Meriva	Chassis	Electronic Power Steering	√	√	√	√		SP0141
2003	Meriva	Engine	Z16SE	√	√	√	√	√	

2003	Meriva	Engine	Z16XE	√			√	√	
2003	Meriva	Engine	Z18XE	√	√	√	√	√	SP0145,SP0009,SP0040,SP0019,SP0011,S P0021
2003	Meriva	Infotainment System	Trip Info Display TID	√	√	√			
2003	Meriva	Infotainment System	Radio CAR 2003	√	√	√			
2003	Meriva	Infotainment System	Radio CDR 2005	√	√	√	√		
2003	Meriva	Infotainment System	Radio CCR 2006	√	√	√	√		
2003	Meriva	Transmission	MTA(Easytronic)	√	√	√	√	√	SP0011,SP0148
2003	Movano	Body	Airbag	√	√	√	√		
2003	Movano	Body	Immobiliser	√	√	√	√		SP0164,SP0165
2003	Omega-B	Body	Immobiliser	√	√	√	√		SP0139,SP0140
2003	Omega-B	Body	Airbag	√	√	√	√	√	
2003	Omega-B	Body	Headlamp Levelling Device	√	√	√	√	√	SP0141
2003	Omega-B	Body	Add On Heater	√	√	√	√	√	SP0122,SP0123
2003	Omega-B	Body	Anti Theft Warning	√	√	√	√	√	
2003	Omega-B	Body	Central Door Lock	√	√	√	√	√	SP0164,SP0165
2003	Omega-B	Body	Electronic Climate Control	√	√	√	√		
2003	Omega-B	Body	Instrument	√	√	√	√		
2003	Omega-B	Chassis	ABS-5.3/5.4(+TC)	√	√	√	√	√	
2003	Omega-B	Chassis	ESP	√	√	√	√		
2003	Omega-B	Engine	Y22DTH	√	√	√	√	√	SP0006
2003	Omega-B	Engine	Z22XE	√	√	√	√	√	SP0146,SP0145,SP0009,SP0040,SP0019
2003	Omega-B	Engine	Y25DT	√	√	√	√		
2003	Omega-B	Engine	Y26SE	√	√	√	√	√	SP0145,SP0009
2003	Omega-B	Engine	X30XE	√	√	√	√		
2003	Omega-B	Engine	Y32SE	√	√	√	√	√	SP0145,SP0009
2003	Omega-B	Infotainment System	Trip Info Display TID	√	√	√			
2003	Omega-B	Infotainment System	Multi Info Dispaly MID	√	√	√			
2003	Omega-B	Infotainment System	Radio CAR 2003	√	√	√			
2003	Omega-B	Infotainment System	Radio CDR 2005	√	√	√	√		

2003	Omega-B	Infotainment System	Radio CCR 2006	√	√	√	√		
2003	Omega-B	Transmission	AR 25/35	√	√	√	√	√	
2003	Omega-B	Transmission	5L40-E	√	√	√	√		
2003	Speedster/VX22	Body	Immobiliser	√	√	√	√		SP0139,SP0140
2003	Speedster/VX22	Body	Airbag	√	√	√	√		
2003	Speedster/VX22	Body	Anti Theft Warning	√	√	√	√	√	
2003	Speedster/VX22	Chassis	ABS 430	√	√	√	√		
2003	Speedster/VX22	Engine	Z20LET	√	√	√	√		
2003	Speedster/VX22 0	Engine	Z22SE	√	√	√	√	√	SP0065,SP0146,SP0145,SP0009,SP0011,S P0021,SP0033
2003	Vectra-	Body	SDM(Airbag,Sensing&Diagnostic Module)	√	√	√	√		SP0000,SP0001,SP0002
2003	Vectra-	Body	Instrument	√	√	√	√	√	SP0169,SP0056,SP0057,SP0179,SP0001
2003	Vectra- C/Signum	Body	CIM(Steering Column Module)	√	√	√	√	√	SP0051,SP0003,SP0052,SP0001,SP0004,S P0053,SP0054,SP0005
2003	Vectra-	Body	BCM(Body Control Module)	√	√	√			SP0180,SP0181
2003	Vectra-	Body	DDM(Driver Door Module)	√	√	√			
2003	Vectra-	Body	PDM(Passenger Door Module)	√	√	√			
2003	Vectra-	Body	REC(Rear Electrical Centre)	√	√	√	√		
2003	Vectra-	Body	UEC(Underhood Electrical Centre)	√	√	√	√		
2003	Vectra-	Body	SLM(Shift Lever Module)	√	√	√			
2003	Vectra-	Body	SRM(Sun Roof Module)	√	√	√			
2003	Vectra-	Body	AHL/AFL(Headlamp Levelling)	√	√	√			
2003	Vectra-	Body	Electrical Horn	√	√	√	√	√	
2003	Vectra-	Body	Electronic Seat Memory/Seat Heating	√	√	√	√		
2003	Vectra-	Body	Anti Theft Warning System	√	√	√	√	√	
2003	Vectra-	Body	Central Door Lock	√	√	√	√		
2003	Vectra-	Body	PAS (Park Pilot)	√	√	√	√	√	SP0001
2003	Vectra-	Chassis	ABS/TC/ESP	√	√	√	√	√	
2003	Vectra-	Chassis	TPMS (Tyre Pressure Monitoring System)	√	√	√	√		SP0032
2003	Vectra-	Chassis	EHPS(Electronic Power Steering)	√	√	√	√		
2003	Vectra-	Chassis	Electronic Cruise Control	√	√	√			
2003	Vectra-	Engine	Engine Cooling	√	√	√	√		
2003	Vectra- C/Signum	Engine	Z18XE	√	√	√	√	√	SP0019,SP0010,SP0011,SP0066,SP0149,S P0012
2003	Vectra-	Engine	Y20DTH	√	√	√	√	√	SP0010,SP0011,SP0066,SP0149
2003	Vectra-	Engine	Y22DTR	√	√	√	√	√	SP0010,SP0011,SP0066,SP0149
2003	Vectra-	Engine	Y30DT	√	√	√	√	√	

2003	Vectra-	Engine	Z22SE	√	√	√	√	√	SP0010,SP0011,SP0066,SP0149
2003	Vectra-	Engine	Z22YH	√	√	√	√	√	SP0019,SP0149
2003	Vectra-	Engine	Z32SE	√	√	√	√	√	SP0019,SP0149
2003	Vectra-	Engine	Z16XE	√	√	√	√	√	SP0010,SP0011,SP0066,SP0149,SP0012
2003	Vectra-	Engine	Z20NET	√	√	√	√	√	SP0010,SP0011,SP0066,SP0149
2003	Vectra-	Engine	Engine(default)	√	√	√			
2003	Vectra-	Transmission	AF 23-5/33-5/40-6	√	√	√	√	√	SP0032,SP0033
2003	Vectra-	Transmission	AF 23-5/33-5	√	√	√	√	√	SP0032,SP0033
2003	Vivaro	Body	Airbag		√	√	√		SP0004
2003	Vivaro	Body	Add On Heater	√	√	√	√	√	SP0122,SP0123
2003	Vivaro	Body	Body Control Module		√	√	√	√	
2003	Vivaro	Chassis	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)	√	√	√	√	√	SP0174,SP0175
2003	Vivaro	Engine	F9Q 760/762 (1.9L)	√	√	√	√		
2003	Vivaro	Infotainment System	Trip Info Display TID	√	√	√			
2003	Vivaro	Infotainment System	Radio CDR 2005	√	√	√	√		
2003	Vivaro	Infotainment System	Radio CCR 2006	√	√	√	√		
2003	Zafira	Body	Immobiliser	√	√	√	√		SP0139,SP0140
2003	Zafira	Body	Instrument	√	√	√	√		
2003	Zafira	Body	Airbag	√	√	√	√	√	
2003	Zafira	Body	Anti Theft Warning	√	√	√	√		
2003	Zafira	Body	Central Door Lock	√	√	√	√		
2003	Zafira	Body	Electronic Climate Control	√	√	√	√		
2003	Zafira	Body	Engine Cooling Module	√	√	√	√		
2003	Zafira	Body	Headlamp Adjustment(Left)	√	√	√	√		
2003	Zafira	Body	Headlamp Adjustment(Right)	√	√	√	√		
2003	Zafira	Chassis	ABS-5.3/5.4(+TC)	√	√	√	√	√	
2003	Zafira	Chassis	ESP	√	√	√	√	√	SP0005
2003	Zafira	Chassis	Electronic Power Steering	√	√	√	√		SP0141
2003	Zafira	Engine	Z16XE	√			√	√	
2003	Zafira	Engine	Z16YNG	√	√	√	√	√	
2003	Zafira	Engine	Z18XE	√	√	√	√	√	SP0145,SP0009,SP0040,SP0019,SP0011,SP0021
2003	Zafira	Engine	Y20DTH	√	√	√	√	√	SP0166,SP0167,SP0168,SP0169

2003	Zafira	Engine	Z20LET	√	√	√	√	√	SP0009,SP0019,SP0040,SP0145,SP0011,S P0021,SP0065,SP0033
2003	Zafira	Engine	Y22DTR	√	√	√	√	√	SP0011,SP0021
2003	Zafira	Engine	Z22SE	√	√	√	√	√	SP0065,SP0146,SP0145,SP0009,SP0011,S P0021,SP0033
2003	Zafira	Infotainment System	Radio CAR 300	√	√	√	√		
2003	Zafira	Infotainment System	Trip Info Display TID	√	√	√			
2003	Zafira	Infotainment System	Multi Info Dispaly MID	√	√	√			
2003	Zafira	Infotainment System	Radio CAR 400	√	√	√	√		
2003	Zafira	Infotainment System	Radio CDR 500	√	√	√	√		
2003	Zafira	Infotainment System	Radio CCR 600	√	√	√	√		
2003	Zafira	Infotainment System	Radio CCRT 700	√	√	√	√		
2003	Zafira	Infotainment System	Radio NCDR 1100/1500	√	√	√	√		
2003	Zafira	Transmission	AF 13-II/17/20/22 CAN	√	√	√	√	√	
2002	Agila	Body	Immobiliser	√	√	√	√		SP0139,SP0140
2002	Agila	Body	Airbag	√	√	√	√		
2002	Agila	Body	Instrument	√	√	√	√		
2002	Agila	Chassis	ABS	√	√	√	√	√	SP0189
2002	Agila	Chassis	Electronic Power Steering	√	√	√	√		
2002	Agila	Engine	Z10XEP	√	√	√	√	√	SP0011,SP0021,SP0065,SP0033
2002	Agila	Engine	Z12XE	√	√	√	√	√	SP0006,SP0145,SP0009,SP0040,SP0019,S P0021,SP0011,SP0065,SP0033
2002	Agila	Infotainment System	Trip Info Display TID	√	√	√			
2002	Agila	Infotainment System	Radio CAR 2003	√	√	√			
2002	Agila	Infotainment System	Radio CDR 2005	√	√	√	√		
2002	Astra-F	Body	Immobiliser	√	√	√	√		SP0139,SP0140
2002	Astra-F	Body	Airbag S	√	√	√	√		

2002	Astra-F	Body	Instrument	√	√	√	√	√	
2002	Astra-F	Body	Anti Theft Warning	√	√	√	√	√	
2002	Astra-F	Engine	X16SZR	√	√	√	√	√	
2002	Astra-F	Engine	X16XEL	√	√	√	√	√	SP0166,SP0195,SP0196,SP0197,SP0198,S P0019
2002	Astra-F	Infotainment System	Trip Info Display TID	√	√	√			
2002	Astra-F	Infotainment System	Radio CAR 300	√	√	√			
2002	Astra-F	Infotainment System	Radio CAR 400	√	√	√	√		
2002	Astra-F	Infotainment System	Radio CDR 500	√	√	√	√		
2002	Astra-G	Body	Immobiliser	√	√	√	√		SP0139,SP0140
2002	Astra-G	Body	Instrument	√	√	√	√		
2002	Astra-G	Body	Airbag	√	√	√	√		
2002	Astra-G	Body	Anti Theft Warning	√	√	√	√		
2002	Astra-G	Body	Central Door Lock	√	√	√	√		
2002	Astra-G	Body	Headlamp Levelling Device	√	√	√	√	√	SP0141
2002	Astra-G	Body	Electronic Climate Control	√	√	√	√		
2002	Astra-G	Body	Engine Cooling Module	√	√	√	√		
2002	Astra-G	Body	Add On Heater	√	√	√	√	√	SP0122,SP0123
2002	Astra-G	Body	Softtop Controller	√	√	√	√	√	
2002	Astra-G	Chassis	ABS-5.3/5.4(+TC)	√	√	√	√	√	
2002	Astra-G	Chassis	ESP	√	√	√	√	√	SP0005
2002	Astra-G	Chassis	Cruise Control	√	√	√	√		
2002	Astra-G	Chassis	Electronic Power Steering	√	√	√	√	√	
2002	Astra-G	Engine	Z12XE	√	√	√	√	√	SP0006,SP0145,SP0009,SP0040,SP0019,S P0021,SP0011,SP0065,SP0033
2002	Astra-G	Engine	Z14XE	√			√	√	SP0146,SP0145,SP0009,SP0019,SP0021,S P0011
2002	Astra-G	Engine	C16SEL	√	√	√	√	√	
2002	Astra-G	Engine	Z16SE	√	√	√	√	√	
2002	Astra-G	Engine	Z16XE	√			√	√	
2002	Astra-G	Engine	Y17DT	√	√	√	√	√	
2002	Astra-G	Engine	Z18XE	√	√	√	√	√	SP0145,SP0009,SP0040,SP0019,SP0011,S P0021
2002	Astra-G	Engine	Z18XEL	√	√	√			SP0011,SP0021

2002	Astra-G	Engine	Y20DTH	√	√	√	√	√	SP0166,SP0167,SP0168,SP0169
2002	Astra-G	Engine	Y20DTL	√	√	√	√		SP0166
2002	Astra-G	Engine	Z20LET	√	√	√	√	√	SP0009,SP0019,SP0040,SP0145,SP0011,S P0021,SP0065,SP0033
2002	Astra-G	Engine	Z22SE	√	√	√	√	√	SP0065,SP0146,SP0145,SP0009,SP0011,S P0021,SP0033
2002	Astra-G	Engine	Y22DTR	√	√	√	√	√	SP0011,SP0021
2002	Astra-G	Infotainment System	Trip Info Display TID	√	√	√			
2002	Astra-G	Infotainment System	Multi Info Dispaly MID	√	√	√			
2002	Astra-G	Infotainment System	Radio CAR 300	√	√	√			
2002	Astra-G	Infotainment System	Radio CAR 400	√	√	√	√		
2002	Astra-G	Infotainment System	Radio CDR 500	√	√	√	√		
2002	Astra-G	Infotainment System	Radio CCR 600	√	√	√	√		
2002	Astra-G	Infotainment System	Radio CCRT 700	√	√	√	√		
2002	Astra-G	Infotainment System	Radio NCDR 1100/1500	√	√	√	√		
2002	Astra-G	Transmission	AF 13-II/17/20/22	√	√	√	√	√	
2002	Astra-G	Transmission	AF 13-II/17/20/22 CAN	√	√	√	√	√	
2002	Astra-G(GMSA)	Body	Instrument	√	√	√	√		
2002	Astra-G(GMSA)	Chassis	ABS-5.3/5.4 (+TC) (Anti-lock Braking System)	√	√	√	√	√	
2002	Astra-G(GMSA)	Chassis	Electronic Power Steering	√	√	√	√	√	
2002	Astra-G(GMSA)	Chassis	Airbag	√	√	√	√		
2002	Astra-G(GMSA)	Chassis	Anti Theft Warning	√	√	√	√		
2002	Astra-G(GMSA)	Chassis	Engine Cooling Module	√	√	√	√		
2002	Astra-G(GMSA)	Chassis	Central Door Lock	√	√	√	√		
2002	Astra-G(GMSA)	Chassis	Immobiliser	√	√	√	√		SP0164,SP0165
2002	Astra-G(GMSA)	Chassis	Trip Info Display TID	√	√	√			
2002	Astra-G(GMSA)	Engine	C 16 SEL	√	√	√	√	√	
2002	Astra-G(GMSA)	Engine	Z 16 XE	√			√	√	
2002	Astra-G(GMSA)	Engine	Z 18 XE	√	√	√	√	√	SP0145,SP0009,SP0040,SP0019,SP0011,S P0021

2002	Astra-G(GMSA)	Engine	X 18 XE1	√	√	√	√	√	SP0199
2002	Astra-G(GMSA)	Engine	20 SEL	√	√	√	√	√	SP0019
2002	Astra-G(GMSA)	Engine	Z 20 LET	√	√	√	√	√	SP0145,SP0009,SP0040,SP0019
2002	Campo	Body	Airbag	√	√	√	√		
2002	Campo	Body	Immobiliser	√	√	√	√		SP0164,SP0165
2002	Combo	Body	Airbag	√	√	√	√		
2002	Combo	Body	Body Control Module	√	√	√	√	√	SP0051,SP0058,SP0138
2002	Combo	Body	Immobiliser	√	√	√	√		SP0164,SP0165
2002	Combo	Chassis	ABS-5.3/5.4 (+TC) (Anti-lock Braking System)	√	√	√	√	√	
2002	Combo	Engine	Z 10 XE	√	√	√	√	√	SP0146,SP0193,SP0009,SP0019
2002	Combo	Engine	Z 12 XE	√	√	√	√	√	SP0006,SP0145,SP0009,SP0040,SP0019,SP0021,SP0011,SP0065,SP0033
2002	Combo	Engine	Z 13 DT	√	√	√	√	√	SP0040,SP0019,SP0021,SP0011,SP0020
2002	Combo	Engine	Z 14 XE	√			√	√	SP0146,SP0145,SP0009,SP0019,SP0021,SP0011
2002	Combo	Engine	Z 16 SE	√	√	√	√	√	
2002	Combo	Engine	Y 17 DT	√	√	√	√	√	
2002	Combo	Engine	Y 17 DTL	√	√	√	√	√	
2002	Combo	Engine	Z 18 XE	√	√	√	√	√	SP0145,SP0009,SP0040,SP0019,SP0011,SP0021
2002	Combo	Infotainment System	Trip Info Display TID	√	√	√			
2002	Combo	Infotainment System	Radio CDR 2005	√	√	√	√		
2002	Combo	Infotainment System	Radio CCR 2006	√	√	√	√		
2002	Corsa-B	Body	Immobiliser	√	√	√	√		
2002	Corsa-B	Body	Airbag S	√	√	√	√		
2002	Corsa-B	Body	Airbag SAB6	√	√	√	√		
2002	Corsa-B	Body	Anti Theft Warning	√	√	√	√	√	
2002	Corsa-B	Body	Instrument	√	√	√	√		
2002	Corsa-B	Chassis	ABS-5.3	√	√	√	√		
2002	Corsa-B	Chassis	Electronic Power Steering	√	√	√	√		
2002	Corsa-B	Engine	Z14SZ	√	√	√	√	√	
2002	Corsa-B	Engine	X14SZ	√	√	√	√	√	SP0200,SP0201,SP0194,SP0195,SP0196,SP0197,SP0202,SP0056
2002	Corsa-B	Engine	X14NE	√	√	√	√		
2002	Corsa-B	Engine	X16NE	√	√	√	√		

2002	Corsa-B	Engine	C14SE	√	√	√	√		
2002	Corsa-B	Infotainment System	Radio CAR 300	√	√	√			
2002	Corsa-B	Infotainment System	Radio CAR 400	√	√	√	√		
2002	Corsa-B	Infotainment System	Radio CDR 500	√	√	√	√		
2002	Corsa-B	Infotainment System	Radio CCR 600	√	√	√	√		
2002	Corsa-B	Infotainment System	Radio CCRT 700	√	√	√	√		
2002	Corsa-B	Infotainment System	Radio NCDR 1100/1500	√	√	√	√		
2002	Corsa-B(GMSA)	Body	Immobiliser	√	√	√	√		SP0164,SP0165
2002	Corsa-B(GMSA)	Engine	14 NE	√	√	√	√	√	SP0166,SP0190,SP0191,SP0056,SP0192
2002	Corsa-B(GMSA)	Engine	16 SE	√	√	√			
2002	Corsa-C	Body	Body Control Module	√	√	√	√	√	SP0051,SP0058,SP0138
2002	Corsa-C	Body	Immobiliser	√	√	√	√		SP0139,SP0140
2002	Corsa-C	Body	Airbag	√	√	√	√	√	
2002	Corsa-C	Body	Instrument	√	√	√	√	√	SP0176,SP0177
2002	Corsa-C	Body	Add On Heater	√	√	√	√	√	SP0122,SP0123
2002	Corsa-C	Body	Electronic Climate Control	√	√	√	√		
2002	Corsa-C	Chassis	ABS-5.3/5.4(+TC)	√	√	√	√	√	
2002	Corsa-C	Chassis	Electronic Power Steering	√	√	√	√		SP0141
2002	Corsa-C	Engine	Z10XE	√	√	√	√	√	SP0146,SP0193,SP0009,SP0019
2002	Corsa-C	Engine	Z12XE	√	√	√	√	√	SP0006,SP0145,SP0009,SP0040,SP0019,SP0021,SP0011,SP0065,SP0033
2002	Corsa-C	Engine	Z14XE	√			√	√	SP0146,SP0145,SP0009,SP0019,SP0021,SP0011
2002	Corsa-C	Engine	Z16SE	√	√	√	√	√	
2002	Corsa-C	Engine	Y17DT	√	√	√	√	√	
2002	Corsa-C	Engine	Y17DTL	√	√	√	√	√	
2002	Corsa-C	Engine	Z18XE	√	√	√	√	√	SP0145,SP0009,SP0040,SP0019,SP0011,SP0021
2002	Corsa-C	Engine	Z16XE	√			√	√	
2002	Corsa-C	Infotainment System	Trip Info Display TID	√	√	√			

2002	Corsa-C	Infotainment System	Radio CAR 2003	√	√	√			
2002	Corsa-C	Infotainment System	Radio CDR 2005	√	√	√	√		
2002	Corsa-C	Infotainment System	Radio CCR 2006	√	√	√	√		
2002	Corsa-C	Transmission	AF 13-II/17/20/22 CAN	√	√	√	√	√	
2002	Corsa-C	Transmission	MTA(Easytronic)	√	√	√	√	√	SP0011,SP0148
2002	Corsa-C(GMSA)	Body	Airbag	√	√	√	√	√	
2002	Corsa-C(GMSA)	Body	Body Control Module	√	√	√	√	√	SP0051,SP0058,SP0138
2002	Corsa-C(GMSA)	Body	Immobiliser	√	√	√	√		SP0164,SP0165
2002	Corsa-C(GMSA)	Body	Instrument	√	√	√	√		
2002	Corsa-C(GMSA)	Body	Power Window Lifter Front	√	√	√	√		
2002	Corsa-C(GMSA)	Body	Power Window Lifter Rear	√	√	√	√		
2002	Corsa-C(GMSA)	Chassis	ABS-5.3/5.4 (+TC) (Anti-lock Braking System)	√	√	√	√	√	
2002	Corsa-C(GMSA)	Chassis	Electronic Power Steering	√	√	√	√		SP0141
2002	Corsa-C(GMSA)	Engine	C 14 SE	√	√	√	√	√	SP0145,SP0019
2002	Corsa-C(GMSA)	Engine	C 16 SE	√	√	√	√	√	SP0145,SP0019
2002	Corsa-C(GMSA)	Engine	Y 17 DT	√	√	√	√	√	
2002	Corsa-C(GMSA)	Engine	C 18 XE	√	√	√	√	√	SP0145,SP0019
2002	Corsa-C(GMSA)	Infotainment System	Trip Info Display TID	√	√	√			
2002	Corsa-C(GMSA)	Infotainment System	Radio CDR 2005	√	√	√	√		
2002	Corsa-C(GMSA)	Infotainment System	Radio CCRT 2008	√	√	√			
2002	Frontera-B	Body	Airbag	√	√	√	√		
2002	Frontera-B	Body	Anti Theft Warning	√	√	√			
2002	Frontera-B	Body	Central Door Lock	√	√	√	√	√	SP0164,SP0165
2002	Frontera-B	Body	Immobiliser	√	√	√	√		SP0164,SP0165
2002	Frontera-B	Engine	Y22DTH	√	√	√	√	√	SP0006
2002	Frontera-B	Infotainment System	Trip Info Display TID	√	√	√			
2002	Frontera-B	Infotainment System	Multi Info Dispaly MID	√	√	√			
2002	Frontera-B	Infotainment System	Radio CAR 300	√	√	√			

2002	Frontera-B	Infotainment System	Radio CAR 400	√	√	√	√		
2002	Frontera-B	Infotainment System	Radio CDR 500	√	√	√	√		
2002	Frontera-B	Infotainment System	Radio CCR 600	√	√	√	√		
2002	Frontera-B	Infotainment System	Radio CCRT 700	√	√	√	√		
2002	Frontera-B	Infotainment System	Radio NCDR 1100/1500	√	√	√	√		
2002	Frontera-B	Transmission	AR 25/35	√	√	√	√	√	
2002	Movano	Body	Immobiliser	√	√	√	√		SP0164,SP0165
2002	Movano	Body	Airbag	√	√	√	√		
2002	Omega-B	Body	Immobiliser	√	√	√	√		SP0139,SP0140
2002	Omega-B	Body	Airbag	√	√	√	√	√	
2002	Omega-B	Body	Headlamp Levelling Device	√	√	√	√	√	SP0141
2002	Omega-B	Body	Add On Heater	√	√	√	√	√	SP0122,SP0123
2002	Omega-B	Body	Anti Theft Warning	√	√	√	√	√	
2002	Omega-B	Body	Central Door Lock	√	√	√	√	√	SP0164,SP0165
2002	Omega-B	Body	Electronic Climate Control	√	√	√	√		
2002	Omega-B	Body	Instrument	√	√	√	√		
2002	Omega-B	Chassis	ABS-5.3/5.4(+TC)	√	√	√	√	√	
2002	Omega-B	Chassis	ESP	√	√	√	√		
2002	Omega-B	Chassis	Servotronic	√	√	√			
2002	Omega-B	Engine	Y22DTH	√	√	√	√	√	SP0006
2002	Omega-B	Engine	Z22XE	√	√	√	√	√	SP0146,SP0145,SP0009,SP0040,SP0019
2002	Omega-B	Engine	Y25DT	√	√	√	√		
2002	Omega-B	Engine	Y26SE	√	√	√	√	√	SP0145,SP0009
2002	Omega-B	Engine	X30XE	√	√	√	√		
2002	Omega-B	Engine	Y32SE	√	√	√	√	√	SP0145,SP0009
2002	Omega-B	Infotainment System	Trip Info Display TID	√	√	√			
2002	Omega-B	Infotainment System	Multi Info Display MID	√	√	√			
2002	Omega-B	Infotainment System	Radio CAR 2003	√	√	√			
2002	Omega-B	Infotainment System	Radio CDR 2005	√	√	√	√		

2002	Omega-B	Infotainment System	Radio CCR 2006	√	√	√	√		
2002	Omega-B	Transmission	AR 25/35	√	√	√	√	√	
2002	Omega-B	Transmission	5L40-E	√	√	√	√		
2002	Speedster/VX22	Body	Immobiliser	√	√	√	√		SP0139,SP0140
2002	Speedster/VX22	Body	Airbag	√	√	√	√		
2002	Speedster/VX22	Body	Anti Theft Warning	√	√	√	√	√	
2002	Speedster/VX22	Chassis	ABS 430	√	√	√	√		
2002	Speedster/VX22	Engine	Z20LET	√	√	√	√		
2002	Speedster/VX22 0	Engine	Z22SE	√	√	√	√	√	SP0065,SP0146,SP0145,SP0009,SP0011,S P0021,SP0033
2002	Vectra-	Body	SDM(Airbag,Sensing&Diagnostic Module)	√	√	√	√		SP0000,SP0001,SP0002
2002	Vectra-	Body	Instrument	√	√	√	√	√	SP0169,SP0056,SP0057,SP0179,SP0001
2002	Vectra- C/Signum	Body	CIM(Steering Column Module)	√	√	√	√	√	SP0051,SP0003,SP0052,SP0001,SP0004,S P0053,SP0054,SP0005
2002	Vectra-	Body	BCM(Body Control Module)	√	√	√			SP0180,SP0181
2002	Vectra-	Body	DDM(Driver Door Module)	√	√	√			
2002	Vectra-	Body	PDM(Passenger Door Module)	√	√	√			
2002	Vectra-	Body	REC(Rear Electrical Centre)	√	√	√	√		
2002	Vectra-	Body	UEC(Underhood Electrical Centre)	√	√	√	√		
2002	Vectra-	Body	SLM(Shift Lever Module)	√	√	√			
2002	Vectra-	Body	SRM(Sun Roof Module)	√	√	√			
2002	Vectra-	Body	AHL/AFL(Headlamp Levelling)	√	√	√			
2002	Vectra-	Body	Electrical Horn	√	√	√	√	√	
2002	Vectra-	Body	Electronic Seat Memory/Seat Heating	√	√	√	√		
2002	Vectra-	Body	Anti Theft Warning System	√	√	√	√	√	
2002	Vectra-	Body	Central Door Lock	√	√	√	√		
2002	Vectra-	Body	PAS (Park Pilot)	√	√	√	√	√	SP0001
2002	Vectra-	Chassis	ABS/TC/ESP	√	√	√	√	√	
2002	Vectra-	Chassis	TPMS (Tyre Pressure Monitoring System)	√	√	√	√		SP0032
2002	Vectra-	Chassis	EHPS(Electronic Power Steering)	√	√	√	√		
2002	Vectra-	Chassis	Electronic Cruise Control	√	√	√			
2002	Vectra-	Engine	Engine Cooling	√	√	√	√		
2002	Vectra- C/Signum	Engine	Z18XE	√	√	√	√	√	SP0019,SP0010,SP0011,SP0066,SP0149,S P0012
2002	Vectra-	Engine	Y20DTH	√	√	√	√	√	SP0010,SP0011,SP0066,SP0149
2002	Vectra-	Engine	Y22DTR	√	√	√	√	√	SP0010,SP0011,SP0066,SP0149
2002	Vectra-	Engine	Z22SE	√	√	√	√	√	SP0010,SP0011,SP0066,SP0149

2002	Vectra-	Engine	Z32SE	√	√	√	√	√	SP0019,SP0149
2002	Vectra-	Engine	Z16XE	√	√	√	√	√	SP0010,SP0011,SP0066,SP0149,SP0012
2002	Vectra-	Engine	Engine(default)	√	√	√			
2002	Vectra-	Transmission	AF 23-5/33-5/40-6	√	√	√	√	√	SP0032,SP0033
2002	Vectra-	Transmission	AF 23-5/33-5	√	√	√	√	√	SP0032,SP0033
2002	Vivaro	Body	Airbag		√	√	√		SP0004
2002	Vivaro	Body	Add On Heater	√	√	√	√	√	SP0122,SP0123
2002	Vivaro	Body	Body Control Module		√	√	√	√	
2002	Vivaro	Chassis	ABS (Anti-lock Braking System)	√	√	√	√	√	SP0174
2002	Vivaro	Engine	F9Q 760/762 (1.9L)	√	√	√	√		
2002	Vivaro	Infotainment System	Trip Info Display TID	√	√	√			
2002	Vivaro	Infotainment System	Radio CDR 2005	√	√	√	√		
2002	Vivaro	Infotainment System	Radio CCR 2006	√	√	√	√		
2002	Zafira	Body	Immobiliser	√	√	√	√		SP0139,SP0140
2002	Zafira	Body	Instrument	√	√	√	√		
2002	Zafira	Body	Airbag	√	√	√	√	√	
2002	Zafira	Body	Anti Theft Warning	√	√	√	√		
2002	Zafira	Body	Central Door Lock	√	√	√	√		
2002	Zafira	Body	Electronic Climate Control	√	√	√	√		
2002	Zafira	Body	Engine Cooling Module	√	√	√	√		
2002	Zafira	Chassis	ABS-5.3/5.4(+TC)	√	√	√	√	√	
2002	Zafira	Chassis	ESP	√	√	√	√	√	SP0005
2002	Zafira	Chassis	Electronic Power Steering	√	√	√	√		SP0141
2002	Zafira	Engine	Z16XE	√			√	√	
2002	Zafira	Engine	Z16YNG	√	√	√	√	√	
2002	Zafira	Engine	Z18XE	√	√	√	√	√	SP0145,SP0009,SP0040,SP0019,SP0011,S P0021
2002	Zafira	Engine	Y20DTH	√	√	√	√	√	SP0166,SP0167,SP0168,SP0169
2002	Zafira	Engine	Z20LET	√	√	√	√	√	SP0009,SP0019,SP0040,SP0145,SP0011,S P0021,SP0065,SP0033
2002	Zafira	Engine	Y22DTR	√	√	√	√	√	SP0011,SP0021
2002	Zafira	Engine	Z22SE	√	√	√	√	√	SP0065,SP0146,SP0145,SP0009,SP0011,S P0021,SP0033
2002	Zafira	Engine	Z18XEL	√	√	√	√	√	SP0145,SP0009,SP0040,SP0019

2002	Zafira	Infotainment System	Radio CAR 300	√	√	√	√		
2002	Zafira	Infotainment System	Trip Info Display TID	√	√	√			
2002	Zafira	Infotainment System	Multi Info Display MID	√	√	√			
2002	Zafira	Infotainment System	Radio CAR 400	√	√	√	√		
2002	Zafira	Infotainment System	Radio CDR 500	√	√	√	√		
2002	Zafira	Infotainment System	Radio CCR 600	√	√	√	√		
2002	Zafira	Infotainment System	Radio CCRT 700	√	√	√	√		
2002	Zafira	Infotainment System	Radio NCDR 1100/1500	√	√	√	√		
2002	Zafira	Transmission	AF 13-II/17/20/22 CAN	√	√	√	√	√	
2002	Zafira	Transmission	MTA(Easytronic)	√	√	√	√	√	SP0011,SP0148
2001	Agila	Body	Immobiliser	√	√	√	√		SP0139,SP0140
2001	Agila	Body	Airbag	√	√	√	√		
2001	Agila	Body	Instrument	√	√	√	√		
2001	Agila	Chassis	ABS	√	√	√	√	√	SP0189
2001	Agila	Chassis	Electronic Power Steering	√	√	√	√		
2001	Agila	Engine	Z10XEP	√	√	√	√	√	SP0011,SP0021,SP0065,SP0033
2001	Agila	Engine	Z12XE	√	√	√	√	√	SP0006,SP0145,SP0009,SP0040,SP0019,SP0021,SP0011,SP0065,SP0033
2001	Agila	Infotainment System	Trip Info Display TID	√	√	√			
2001	Agila	Infotainment System	Radio CAR 2003	√	√	√			
2001	Agila	Infotainment System	Radio CDR 2005	√	√	√	√		
2001	Astra-F	Body	Immobiliser	√	√	√	√		SP0139,SP0140
2001	Astra-F	Body	Airbag S	√	√	√	√		
2001	Astra-F	Body	Instrument	√	√	√	√	√	
2001	Astra-F	Body	Anti Theft Warning	√	√	√	√	√	
2001	Astra-F	Engine	X16SZR	√	√	√	√	√	

2001	Astra-F	Engine	X16XEL	√	√	√	√	√	SP0166,SP0194,SP0195,SP0196,SP0197,S P0019
2001	Astra-F	Infotainment System	Trip Info Display TID	√	√	√			
2001	Astra-F	Infotainment System	Radio CAR 300	√	√	√			
2001	Astra-F	Infotainment System	Radio CAR 400	√	√	√	√		
2001	Astra-F	Infotainment System	Radio CDR 500	√	√	√	√		
2001	Astra-G	Body	Immobiliser	√	√	√	√		SP0139,SP0140
2001	Astra-G	Body	Instrument	√	√	√	√		
2001	Astra-G	Body	Airbag	√	√	√	√		
2001	Astra-G	Body	Anti Theft Warning	√	√	√	√		
2001	Astra-G	Body	Central Door Lock	√	√	√	√		
2001	Astra-G	Body	Engine Cooling Module	√	√	√	√		
2001	Astra-G	Body	Add On Heater	√	√	√	√	√	SP0122,SP0123
2001	Astra-G	Chassis	ABS-5.3/5.4(+TC)	√	√	√	√	√	
2001	Astra-G	Chassis	ESP	√	√	√	√	√	SP0005
2001	Astra-G	Chassis	Cruise Control	√	√	√	√		
2001	Astra-G	Chassis	Electronic Power Steering	√	√	√	√	√	
2001	Astra-G	Engine	Z12XE	√	√	√	√	√	SP0006,SP0145,SP0009,SP0040,SP0019,S P0021,SP0011,SP0065,SP0033
2001	Astra-G	Engine	Z14XE	√			√	√	SP0146,SP0145,SP0009,SP0019,SP0021,S P0011
2001	Astra-G	Engine	C16SEL	√	√	√	√	√	
2001	Astra-G	Engine	Z16SE	√	√	√	√	√	
2001	Astra-G	Engine	Z16XE	√			√	√	
2001	Astra-G	Engine	Y17DT	√	√	√	√	√	
2001	Astra-G	Engine	Z18XE	√	√	√	√	√	SP0145,SP0009,SP0040,SP0019,SP0011,S P0021
2001	Astra-G	Engine	Z18XEL	√	√	√			SP0011,SP0021
2001	Astra-G	Engine	Y20DTH	√	√	√	√	√	SP0166,SP0167,SP0168,SP0169
2001	Astra-G	Engine	Y20DTL	√	√	√	√		SP0166
2001	Astra-G	Engine	Z20LET	√	√	√	√	√	SP0009,SP0019,SP0040,SP0145,SP0011,S P0021,SP0065,SP0033
2001	Astra-G	Engine	Z22SE	√	√	√	√	√	SP0065,SP0146,SP0145,SP0009,SP0011,S P0021,SP0033

2001	Astra-G	Engine	X16SZR	√	√	√	√		
2001	Astra-G	Engine	X18XE1	√	√	√	√	√	SP0198
2001	Astra-G	Infotainment System	Trip Info Display TID	√	√	√			
2001	Astra-G	Infotainment System	Multi Info Dispaly MID	√	√	√			
2001	Astra-G	Infotainment System	Radio CAR 300	√	√	√			
2001	Astra-G	Infotainment System	Radio CAR 400	√	√	√	√		
2001	Astra-G	Infotainment System	Radio CDR 500	√	√	√	√		
2001	Astra-G	Infotainment System	Radio CCR 600	√	√	√	√		
2001	Astra-G	Infotainment System	Radio CCRT 700	√	√	√	√		
2001	Astra-G	Infotainment System	Radio NCDR 1100/1500	√	√	√	√		
2001	Astra-G	Transmission	AF 13-II/17/20/22	√	√	√	√	√	
2001	Astra-G	Transmission	AF 13-II/17/20/22 CAN	√	√	√	√	√	
2001	Astra-G(GMSA)	Body	Airbag	√	√	√	√		
2001	Astra-G(GMSA)	Body	Anti Theft Warning	√	√	√	√		
2001	Astra-G(GMSA)	Body	Engine Cooling Module	√	√	√	√		
2001	Astra-G(GMSA)	Body	Central Door Lock	√	√	√	√		
2001	Astra-G(GMSA)	Body	Instrument	√	√	√	√		
2001	Astra-G(GMSA)	Body	Immobiliser	√	√	√	√		SP0164,SP0165
2001	Astra-G(GMSA)	Chassis	ABS-5.3/5.4 (+TC) (Anti-lock Braking System)	√	√	√	√	√	
2001	Astra-G(GMSA)	Chassis	Electronic Power Steering	√	√	√	√	√	
2001	Astra-G(GMSA)	Engine	C 16 SEL	√	√	√	√	√	
2001	Astra-G(GMSA)	Engine	Z 16 XE	√			√	√	
2001	Astra-G(GMSA)	Engine	Z 18 XE	√	√	√	√	√	SP0145,SP0009,SP0040,SP0019,SP0011,S P0021
2001	Astra-G(GMSA)	Engine	X 18 XE1	√	√	√	√	√	SP0198
2001	Astra-G(GMSA)	Engine	20 SEL	√	√	√	√	√	SP0019
2001	Astra-G(GMSA)	Engine	Z 20 LET	√	√	√	√	√	SP0145,SP0009,SP0040,SP0019
2001	Astra-G(GMSA)	Infotainment System	Trip Info Display TID	√	√	√			
2001	Campo	Body	Airbag	√	√	√	√		

2001	Campo	Body	Immobiliser	√	√	√	√		SP0164,SP0165
2001	Corsa-B	Body	Immobiliser	√	√	√	√		
2001	Corsa-B	Body	Airbag S	√	√	√	√		
2001	Corsa-B	Body	Airbag SAB6	√	√	√	√		
2001	Corsa-B	Body	Anti Theft Warning	√	√	√	√	√	
2001	Corsa-B	Body	Instrument	√	√	√	√		
2001	Corsa-B	Chassis	ABS-5.3	√	√	√	√		
2001	Corsa-B	Chassis	Electronic Power Steering	√	√	√	√		
2001	Corsa-B	Engine	Z14SZ	√	√	√	√	√	
2001	Corsa-B	Engine	X14NE	√	√	√	√		
2001	Corsa-B	Engine	X16NE	√	√	√	√		
2001	Corsa-B	Engine	C14SE	√	√	√	√		
2001	Corsa-B	Infotainment System	Radio CAR 300	√	√	√			
2001	Corsa-B	Infotainment System	Radio CAR 400	√	√	√	√		
2001	Corsa-B	Infotainment System	Radio CDR 500	√	√	√	√		
2001	Corsa-B	Infotainment System	Radio CCR 600	√	√	√	√		
2001	Corsa-B	Infotainment System	Radio CCRT 700	√	√	√	√		
2001	Corsa-B	Infotainment System	Radio NCDR 1100/1500	√	√	√	√		
2001	Corsa-B(GMSA)	Body	Immobiliser	√	√	√	√		SP0164,SP0165
2001	Corsa-B(GMSA)	Engine	14 NE	√	√	√	√	√	SP0166,SP0190,SP0191,SP0056,SP0192
2001	Corsa-B(GMSA)	Engine	16 SE	√	√	√			
2001	Corsa-C	Body	Body Control Module	√	√	√	√	√	SP0051,SP0058,SP0138
2001	Corsa-C	Body	Immobiliser	√	√	√	√		SP0139,SP0140
2001	Corsa-C	Body	Airbag	√	√	√	√	√	
2001	Corsa-C	Body	Instrument	√	√	√	√	√	SP0176,SP0177
2001	Corsa-C	Body	Add On Heater	√	√	√	√	√	SP0122,SP0123
2001	Corsa-C	Chassis	ABS-5.3/5.4(+TC)	√	√	√	√	√	
2001	Corsa-C	Chassis	Electronic Power Steering	√	√	√	√		SP0141
2001	Corsa-C	Engine	Z10XE	√	√	√	√	√	SP0146,SP0193,SP0009,SP0019
2001	Corsa-C	Engine	Z12XE	√	√	√	√	√	SP0006,SP0145,SP0009,SP0040,SP0019,SP0021,SP0011,SP0065,SP0033

2001	Corsa-C	Engine	Z14XE	√			√	√	SP0146,SP0145,SP0009,SP0019,SP0021,S P0011
2001	Corsa-C	Engine	Y17DT	√	√	√	√	√	
2001	Corsa-C	Engine	Y17DTL	√	√	√	√	√	
2001	Corsa-C	Engine	Z18XE	√	√	√	√	√	SP0145,SP0009,SP0040,SP0019,SP0011,S P0021
2001	Corsa-C	Infotainment System	Trip Info Display TID	√	√	√			
2001	Corsa-C	Infotainment System	Radio CAR 2003	√	√	√			
2001	Corsa-C	Infotainment System	Radio CDR 2005	√	√	√	√		
2001	Corsa-C	Infotainment System	Radio CCR 2006	√	√	√	√		
2001	Corsa-C	Transmission	AF 13-II/17/20/22 CAN	√	√	√	√	√	
2001	Corsa-C	Transmission	MTA(Easytronic)	√	√	√	√	√	SP0011,SP0148
2001	Frontera-B	Body	Airbag	√	√	√	√		
2001	Frontera-B	Body	Anti Theft Warning	√	√	√			
2001	Frontera-B	Body	Central Door Lock	√	√	√	√	√	SP0164,SP0165
2001	Frontera-B	Body	Immobiliser	√	√	√	√		SP0164,SP0165
2001	Frontera-B	Engine	Y22DTH	√	√	√	√	√	SP0006
2001	Frontera-B	Infotainment System	Trip Info Display TID	√	√	√			
2001	Frontera-B	Infotainment System	Multi Info Dispaly MID	√	√	√			
2001	Frontera-B	Infotainment System	Radio CAR 300	√	√	√			
2001	Frontera-B	Infotainment System	Radio CAR 400	√	√	√	√		
2001	Frontera-B	Infotainment System	Radio CDR 500	√	√	√	√		
2001	Frontera-B	Infotainment System	Radio CCR 600	√	√	√	√		
2001	Frontera-B	Infotainment System	Radio CCRT 700	√	√	√	√		
2001	Frontera-B	Infotainment System	Radio NCDR 1100/1500	√	√	√	√		
2001	Frontera-B	Transmission	AR 25/35	√	√	√	√	√	

2001	Movano	Body	Immobiliser	√	√	√	√		SP0164,SP0165
2001	Omega-B	Body	Airbag	√	√	√	√	√	
2001	Omega-B	Body	Headlamp Levelling Device	√	√	√	√	√	SP0141
2001	Omega-B	Body	Add On Heater	√	√	√	√	√	SP0122,SP0123
2001	Omega-B	Body	Anti Theft Warning	√	√	√	√	√	
2001	Omega-B	Body	Central Door Lock	√	√	√	√	√	SP0164,SP0165
2001	Omega-B	Body	Electronic Climate Control	√	√	√	√		
2001	Omega-B	Body	Immobiliser	√	√	√	√		SP0164,SP0165
2001	Omega-B	Body	Instrument	√	√	√	√		
2001	Omega-B	Chassis	ABS-5.3/5.4(+TC)	√	√	√	√	√	
2001	Omega-B	Chassis	Servotronic	√	√	√			
2001	Omega-B	Engine	X20XEV	√	√	√	√	√	
2001	Omega-B	Engine	Y22DTH	√	√	√	√	√	SP0006
2001	Omega-B	Engine	Z22XE	√	√	√	√	√	SP0146,SP0145,SP0009,SP0040,SP0019
2001	Omega-B	Engine	Y26SE	√	√	√	√	√	SP0145,SP0009
2001	Omega-B	Engine	X30XE	√	√	√	√		
2001	Omega-B	Engine	Y32SE	√	√	√	√	√	SP0145,SP0009
2001	Omega-B	Infotainment System	Trip Info Display TID	√	√	√			
2001	Omega-B	Infotainment System	Multi Info Dispaly MID	√	√	√			
2001	Omega-B	Infotainment System	Radio CAR 2003	√	√	√			
2001	Omega-B	Infotainment System	Radio CDR 2005	√	√	√	√		
2001	Omega-B	Infotainment System	Radio CCR 2006	√	√	√	√		
2001	Omega-B	Transmission	AR 25/35	√	√	√	√	√	
2001	Speedster/VX22	Body	Immobiliser	√	√	√	√		SP0139,SP0140
2001	Speedster/VX22	Body	Airbag	√	√	√	√		
2001	Speedster/VX22	Body	Anti Theft Warning	√	√	√	√	√	
2001	Speedster/VX22	Chassis	ABS 430	√	√	√	√		
2001	Speedster/VX22 0	Engine	Z22SE	√	√	√	√	√	SP0065,SP0146,SP0145,SP0009,SP0011,SP0021,SP0033
2001	Vectra-B	Body	Immobiliser	√	√	√	√		
2001	Vectra-B	Body	Instrument	√	√	√	√		
2001	Vectra-B	Body	Airbag	√	√	√	√		
2001	Vectra-B	Body	Airbag SAB6	√	√	√	√		

2001	Vectra-B	Body	Add On Heater	√	√	√	√	√	SP0122,SP0123
2001	Vectra-B	Body	Anti Theft Warning	√	√	√	√	√	
2001	Vectra-B	Body	Electronic Climate Control	√	√	√	√		
2001	Vectra-B	Body	Headlamp Adjustment(Left)	√	√	√	√		
2001	Vectra-B	Body	Headlamp Adjustment(Right)	√	√	√	√		
2001	Vectra-B	Chassis	ABS 430	√	√	√	√		
2001	Vectra-B	Chassis	ABS-5.3/5.4(+TC)	√	√	√	√	√	
2001	Vectra-B	Engine	X16XEL	√	√	√	√	√	SP0166,SP0194,SP0195,SP0196,SP0197,S P0019
2001	Vectra-B	Engine	Y16XE	√	√	√	√	√	
2001	Vectra-B	Engine	Z16XE	√			√	√	
2001	Vectra-B	Engine	X18XE	√	√	√	√		SP0166,SP0203,SP0204,SP0205,SP0040
2001	Vectra-B	Engine	Z18XE	√	√	√	√	√	SP0145,SP0009,SP0040,SP0019,SP0011,S P0021
2001	Vectra-B	Engine	Z18XEL	√	√	√			SP0011,SP0021
2001	Vectra-B	Engine	C20SEL	√	√	√	√	√	SP0166
2001	Vectra-B	Engine	Y20DTH	√	√	√	√	√	SP0166,SP0167,SP0168,SP0169
2001	Vectra-B	Engine	X20XEV	√	√	√	√	√	
2001	Vectra-B	Engine	C22SEL	√	√	√	√		SP0204,SP0040,SP0202
2001	Vectra-B	Engine	Y22DTR	√	√	√	√	√	SP0011,SP0021
2001	Vectra-B	Engine	Z22SE	√	√	√	√	√	SP0065,SP0146,SP0145,SP0009,SP0011,S P0021,SP0033
2001	Vectra-B	Engine	Y26SE	√	√	√	√	√	SP0145,SP0009
2001	Vectra-B	Engine	Z18XE1	√	√	√	√	√	SP0145,SP0009,SP0040,SP0019
2001	Vectra-B	Infotainment System	Trip Info Display TID	√	√	√			
2001	Vectra-B	Infotainment System	Multi Info Dispaly MID	√	√	√			
2001	Vectra-B	Infotainment System	Radio CAR 300	√	√	√			
2001	Vectra-B	Infotainment System	Radio CAR 400	√	√	√	√		
2001	Vectra-B	Infotainment System	Radio CDR 500	√	√	√	√		
2001	Vectra-B	Infotainment System	Radio CCR 600	√	√	√	√		
2001	Vectra-B	Infotainment System	Radio CCRT 700	√	√	√	√		

2001	Vectra-B	Infotainment System	Radio NCDR 1100/1500	√	√	√	√		
2001	Vectra-B	Transmission	AF 13-II/17/20/22	√	√	√	√	√	
2001	Vectra-B	Transmission	AF 13-II/17/20/22 CAN	√	√	√	√	√	
2001	Vivaro	Body	Airbag		√	√	√		SP0004
2001	Vivaro	Body	Add On Heater	√	√	√	√	√	SP0122,SP0123
2001	Vivaro	Body	Body Control Module		√	√	√	√	
2001	Vivaro	Chassis	ABS (Anti-lock Braking System)	√	√	√	√	√	SP0174
2001	Vivaro	Engine	F9Q 760/762 (1.9L)	√	√	√	√		
2001	Vivaro	Infotainment System	Trip Info Display TID	√	√	√			
2001	Vivaro	Infotainment System	Multi Info Dispaly MID	√	√	√			
2001	Vivaro	Infotainment System	Radio CDR 2005	√	√	√	√		
2001	Vivaro	Infotainment System	Radio CCR 2006	√	√	√	√		
2001	Zafira	Body	Immobiliser	√	√	√	√		SP0139,SP0140
2001	Zafira	Body	Instrument	√	√	√	√		
2001	Zafira	Body	Airbag	√	√	√	√	√	
2001	Zafira	Body	Anti Theft Warning	√	√	√	√		
2001	Zafira	Body	Central Door Lock	√	√	√	√		
2001	Zafira	Body	Electronic Climate Control	√	√	√	√		
2001	Zafira	Body	Engine Cooling Module	√	√	√	√		
2001	Zafira	Chassis	ABS-5.3/5.4(+TC)	√	√	√	√	√	
2001	Zafira	Chassis	ESP	√	√	√	√	√	SP0005
2001	Zafira	Chassis	Electronic Power Steering	√	√	√	√		SP0141
2001	Zafira	Engine	Z16XE	√			√	√	
2001	Zafira	Engine	Z16YNG	√	√	√	√	√	
2001	Zafira	Engine	Z18XE	√	√	√	√	√	SP0145,SP0009,SP0040,SP0019,SP0011,SP0021
2001	Zafira	Engine	Y20DTH	√	√	√	√	√	SP0166,SP0167,SP0168,SP0169
2001	Zafira	Engine	Z22SE	√	√	√	√	√	SP0065,SP0146,SP0145,SP0009,SP0011,SP0021,SP0033
2001	Zafira	Engine	Z18XEL	√	√	√	√	√	SP0145,SP0009,SP0040,SP0019
2001	Zafira	Infotainment System	Radio CAR 300	√	√	√	√		

2001	Zafira	Infotainment System	Trip Info Display TID	√	√	√			
2001	Zafira	Infotainment System	Multi Info Display MID	√	√	√			
2001	Zafira	Infotainment System	Radio CAR 400	√	√	√	√		
2001	Zafira	Infotainment System	Radio CDR 500	√	√	√	√		
2001	Zafira	Infotainment System	Radio CCR 600	√	√	√	√		
2001	Zafira	Infotainment System	Radio CCRT 700	√	√	√	√		
2001	Zafira	Infotainment System	Radio NCDR 1100/1500	√	√	√	√		
2001	Zafira	Transmission	AF 13-II/17/20/22 CAN	√	√	√	√	√	
2000	Agila	Body	Immobiliser	√	√	√	√		SP0139,SP0140
2000	Agila	Body	Airbag	√	√	√	√		
2000	Agila	Body	Instrument	√	√	√	√		
2000	Agila	Chassis	ABS	√	√	√	√	√	SP0189
2000	Agila	Chassis	Electronic Power Steering	√	√	√	√		
2000	Agila	Engine	Z10XEP	√	√	√	√	√	SP0011,SP0021,SP0065,SP0033
2000	Agila	Engine	Z12XE	√	√	√	√	√	SP0006,SP0145,SP0009,SP0040,SP0019,SP0021,SP0011,SP0065,SP0033
2000	Agila	Engine	Z10XE	√	√	√	√	√	SP0146,SP0193,SP0009,SP0019
2000	Agila	Infotainment System	Trip Info Display TID	√	√	√			
2000	Agila	Infotainment System	Radio CAR 2003	√	√	√			
2000	Agila	Infotainment System	Radio CDR 2005	√	√	√	√		
2000	Arena	Body	Immobiliser	√	√	√	√		SP0164,SP0165
2000	Astra-F	Body	Immobiliser	√	√	√	√		
2000	Astra-F	Body	Airbag S	√	√	√	√		
2000	Astra-F	Body	Instrument	√	√	√	√	√	
2000	Astra-F	Body	Anti Theft Warning	√	√	√	√	√	
2000	Astra-F	Engine	16NZR	√	√	√	√		
2000	Astra-F	Engine	X16SZR	√	√	√	√	√	

2000	Astra-F	Engine	X16XEL	√	√	√	√	√	SP0166,SP0194,SP0195,SP0196,SP0197,S P0019
2000	Astra-F	Infotainment System	Trip Info Display TID	√	√	√			
2000	Astra-F	Infotainment System	Radio CAR 300	√	√	√			
2000	Astra-F	Infotainment System	Radio CAR 400	√	√	√	√		
2000	Astra-F	Infotainment System	Radio CDR 500	√	√	√	√		
2000	Astra-F	Transmission	AF 13II/20/22/30	√	√	√	√		
2000	Astra-G	Body	Immobiliser	√	√	√	√		SP0139,SP0140
2000	Astra-G	Body	Instrument	√	√	√	√		
2000	Astra-G	Body	Airbag	√	√	√	√		
2000	Astra-G	Body	Airbag SAB6	√	√	√	√		
2000	Astra-G	Body	Anti Theft Warning	√	√	√	√		
2000	Astra-G	Body	Central Door Lock	√	√	√	√		
2000	Astra-G	Body	Engine Cooling Module	√	√	√	√		
2000	Astra-G	Body	Add On Heater	√	√	√	√	√	SP0122,SP0123
2000	Astra-G	Chassis	ABS-5.3/5.4(+TC)	√	√	√	√	√	
2000	Astra-G	Chassis	ESP	√	√	√	√	√	SP0005
2000	Astra-G	Chassis	Cruise Control	√	√	√	√		
2000	Astra-G	Chassis	Electronic Power Steering	√	√	√	√	√	
2000	Astra-G	Engine	X12XE	√	√	√	√	√	SP0166,SP0196,SP0202,SP0201
2000	Astra-G	Engine	X14XE	√	√	√	√	√	
2000	Astra-G	Engine	C16SEL	√	√	√	√	√	
2000	Astra-G	Engine	X16SZR	√	√	√	√		
2000	Astra-G	Engine	X16XEL	√	√	√	√	√	SP0166,SP0194,SP0195,SP0196,SP0197,S P0019
2000	Astra-G	Engine	X17DTL	√	√	√	√	√	
2000	Astra-G	Engine	Y17DT	√	√	√	√	√	
2000	Astra-G	Engine	X18XE1	√	√	√	√	√	
2000	Astra-G	Engine	X20DTL	√	√	√	√		
2000	Astra-G	Engine	X20XER	√	√	√	√		
2000	Astra-G	Engine	X20XEV	√	√	√	√		
2000	Astra-G	Engine	Z20LET	√	√	√	√	√	SP0166
2000	Astra-G	Engine	Z22SE	√	√	√	√	√	SP0065,SP0146,SP0145,SP0009,SP0011,S P0021,SP0033

2000	Astra-G	Infotainment System	Trip Info Display TID	√	√	√			
2000	Astra-G	Infotainment System	Multi Info Display MID	√	√	√			
2000	Astra-G	Infotainment System	Radio CAR 300	√	√	√			
2000	Astra-G	Infotainment System	Radio CAR 400	√	√	√	√		
2000	Astra-G	Infotainment System	Radio CDR 500	√	√	√	√		
2000	Astra-G	Infotainment System	Radio CCR 600	√	√	√	√		
2000	Astra-G	Infotainment System	Radio CCRT 700	√	√	√	√		
2000	Astra-G	Infotainment System	Radio NCDR 1100/1500	√	√	√	√		
2000	Astra-G	Transmission	AF 13-II/17/20/22	√	√	√	√	√	
2000	Astra-G(GMSA)	Body	Airbag	√	√	√	√		
2000	Astra-G(GMSA)	Body	Anti Theft Warning	√	√	√	√		
2000	Astra-G(GMSA)	Body	Central Door Lock	√	√	√	√		
2000	Astra-G(GMSA)	Body	Engine Cooling Module	√	√	√	√		
2000	Astra-G(GMSA)	Body	Immobiliser	√	√	√	√		SP0164,SP0165
2000	Astra-G(GMSA)	Body	Instrument	√	√	√	√		
2000	Astra-G(GMSA)	Chassis	ABS-5.3/5.4 (+TC) (Anti-lock Braking System)	√	√	√	√	√	
2000	Astra-G(GMSA)	Chassis	Electronic Power Steering	√	√	√	√	√	
2000	Astra-G(GMSA)	Engine	C 16 SEL	√	√	√	√	√	
2000	Astra-G(GMSA)	Engine	X 18 XE1	√	√	√	√	√	SP0198
2000	Astra-G(GMSA)	Engine	20 SEL	√	√	√	√	√	SP0019
2000	Astra-G(GMSA)	Engine	Z 20 LET	√	√	√	√	√	SP0145,SP0009,SP0040,SP0019
2000	Astra-G(GMSA)	Infotainment System	Trip Info Display TID	√	√	√			
2000	Campo	Body	Airbag	√	√	√	√		
2000	Corsa-B	Body	Immobiliser	√	√	√	√		
2000	Corsa-B	Body	Airbag S	√	√	√	√		
2000	Corsa-B	Body	Airbag SAB6	√	√	√	√		
2000	Corsa-B	Body	Anti Theft Warning	√	√	√	√	√	
2000	Corsa-B	Body	Airbag	√	√	√	√		
2000	Corsa-B	Chassis	ABS-5.3	√	√	√	√		

2000	Corsa-B	Chassis	Electronic Power Steering	√	√	√	√		
2000	Corsa-B	Engine	X10XE	√	√	√	√	√	SP0166,SP0196,SP0202,SP0201
2000	Corsa-B	Engine	X12XE	√	√	√	√	√	SP0166,SP0196,SP0202,SP0201
2000	Corsa-B	Engine	C14SEL	√	√	√	√		
2000	Corsa-B	Engine	X14SZ	√	√	√	√	√	
2000	Corsa-B	Engine	X14XE	√	√	√	√	√	
2000	Corsa-B	Engine	C16SEL	√	√	√	√		
2000	Corsa-B	Engine	X16XE	√	√	√	√	√	SP0166,SP0195,SP0196,SP0197,SP0019,SP0201,SP0056
2000	Corsa-B	Engine	X14NE	√	√	√	√		
2000	Corsa-B	Engine	X16NE	√	√	√	√		
2000	Corsa-B	Engine	C14SE	√	√	√	√		
2000	Corsa-B	Infotainment System	Radio CAR 300	√	√	√			
2000	Corsa-B	Infotainment System	Radio CAR 400	√	√	√	√		
2000	Corsa-B	Infotainment System	Radio CDR 500	√	√	√	√		
2000	Corsa-B	Infotainment System	Radio CCR 600	√	√	√	√		
2000	Corsa-B	Infotainment System	Radio NCDR 1100/1500	√	√	√	√		
2000	Corsa-B	Infotainment System	Radio CCRT 700	√	√	√	√		
2000	Corsa-B	Transmission	AF 13II/20/22/30	√	√	√	√		
2000	Corsa-B	Transmission	AF 13/14/20	√	√	√	√		
2000	Corsa-B(GMSA)	Body	Immobiliser	√	√	√	√		SP0164,SP0165
2000	Corsa-B(GMSA)	Engine	13 NE	√	√	√	√	√	SP0166,SP0190,SP0191,SP0056,SP0192
2000	Corsa-B(GMSA)	Engine	14 NE	√	√	√	√	√	SP0166,SP0190,SP0191,SP0056,SP0192
2000	Corsa-B(GMSA)	Engine	16 SE	√	√	√			
2000	Frontera-B	Body	Airbag	√	√	√	√		
2000	Frontera-B	Body	Anti Theft Warning	√	√	√			
2000	Frontera-B	Body	Central Door Lock	√	√	√	√	√	SP0164,SP0165
2000	Frontera-B	Body	Immobiliser	√	√	√	√		SP0164,SP0165
2000	Frontera-B	Engine	X22DTH	√	√	√	√		
2000	Frontera-B	Engine	Y22DTH	√	√	√	√	√	SP0006
2000	Frontera-B	Infotainment System	Trip Info Display TID	√	√	√			

2000	Frontera-B	Infotainment System	Multi Info Dispaly MID	√	√	√			
2000	Frontera-B	Infotainment System	Radio CAR 300	√	√	√			
2000	Frontera-B	Infotainment System	Radio CAR 400	√	√	√	√		
2000	Frontera-B	Infotainment System	Radio CDR 500	√	√	√	√		
2000	Frontera-B	Infotainment System	Radio CCR 600	√	√	√	√		
2000	Frontera-B	Infotainment System	Radio CCRT 700	√	√	√	√		
2000	Frontera-B	Infotainment System	Radio NCDR 1100/1500	√	√	√	√		
2000	Frontera-B	Transmission	AR 25/35	√	√	√	√	√	
2000	Movano	Body	Immobiliser	√	√	√	√		SP0164,SP0165
2000	Omega-B	Body	Airbag	√	√	√	√	√	
2000	Omega-B	Body	Headlamp Levelling Device	√	√	√	√	√	SP0141
2000	Omega-B	Body	Add On Heater	√	√	√	√	√	SP0122,SP0123
2000	Omega-B	Body	Anti Theft Warning	√	√	√	√	√	
2000	Omega-B	Body	Central Door Lock	√	√	√	√	√	SP0164,SP0165
2000	Omega-B	Body	Electronic Climate Control	√	√	√	√		
2000	Omega-B	Body	Immobiliser	√	√	√	√		SP0164,SP0165
2000	Omega-B	Body	Instrument	√	√	√	√		
2000	Omega-B	Chassis	ABS-5.3/5.4(+TC)	√	√	√	√	√	
2000	Omega-B	Chassis	Servotronic	√	√	√			
2000	Omega-B	Engine	X20DTH	√	√	√	√		
2000	Omega-B	Engine	X20XEV	√	√	√	√	√	
2000	Omega-B	Engine	Y22XE	√	√	√	√		
2000	Omega-B	Engine	X25XE	√	√	√	√		
2000	Omega-B	Engine	Y30XE	√	√	√	√		
2000	Omega-B	Infotainment System	Trip Info Display TID	√	√	√			
2000	Omega-B	Infotainment System	Multi Info Dispaly MID	√	√	√			
2000	Omega-B	Infotainment System	Radio CAR 2003	√	√	√			

2000	Omega-B	Infotainment System	Radio CDR 2005	√	√	√	√		
2000	Omega-B	Infotainment System	Radio CCR 2006	√	√	√	√		
2000	Omega-B	Transmission	AR 25/35	√	√	√	√	√	
2000	Vauxhall VXR8	Body	Airbag	√	√	√	√		
2000	Vauxhall VXR8	Body	Airbag-S	√	√	√	√		
2000	Vauxhall VXR8	Body	Airbag SAB6	√	√	√	√		
2000	Vauxhall VXR8	Body	Immobiliser	√	√	√	√		SP0164,SP0165
2000	Vauxhall VXR8	Chassis	ABS-5.3 (Anti-lock Braking System)	√	√	√	√		
2000	Vauxhall VXR8	Engine	X 14 XE	√	√	√	√	√	
2000	Vauxhall VXR8	Engine	X 16 XE	√	√	√	√	√	SP0166,SP0195,SP0196,SP0197,SP0019,S P0201,SP0056
2000	Vauxhall VXR8	Engine	C 16 SEL	√	√	√	√	√	
2000	Vauxhall VXR8	Infotainment System	Radio CAR 300	√	√	√			
2000	Vauxhall VXR8	Infotainment System	Radio CAR 400	√	√	√	√		
2000	Vauxhall VXR8	Infotainment System	Radio CDR 500	√	√	√	√		
2000	Vauxhall VXR8	Infotainment System	Radio CCR 600	√	√	√	√		
2000	Vauxhall VXR8	Infotainment System	Radio CCRT 700	√	√	√	√		
2000	Vauxhall VXR8	Transmission	AF 13/14/20	√	√	√	√		
2000	Vectra-B	Body	Immobiliser	√	√	√	√		
2000	Vectra-B	Body	Instrument	√	√	√	√		
2000	Vectra-B	Body	Airbag SAB6	√	√	√	√		
2000	Vectra-B	Body	Add On Heater	√	√	√	√	√	SP0122,SP0123
2000	Vectra-B	Body	Anti Theft Warning	√	√	√	√	√	
2000	Vectra-B	Body	Electronic Climate Control	√	√	√	√		
2000	Vectra-B	Body	Headlamp Adjustment(Left)	√	√	√	√		
2000	Vectra-B	Body	Headlamp Adjustment(Right)	√	√	√	√		
2000	Vectra-B	Chassis	ABS 430	√	√	√	√		
2000	Vectra-B	Chassis	ABS-5.3/5.4(+TC)	√	√	√	√	√	
2000	Vectra-B	Engine	X16SZR	√	√	√	√	√	
2000	Vectra-B	Engine	X16XEL	√	√	√	√	√	SP0166,SP0194,SP0195,SP0196,SP0197,S P0019

2000	Vectra-B	Engine	Y16XE	√	√	√	√	√	
2000	Vectra-B	Engine	X18XE1	√	√	√	√	√	
2000	Vectra-B	Engine	20NEJ	√	√	√	√		
2000	Vectra-B	Engine	C20SEL	√	√	√	√	√	SP0166
2000	Vectra-B	Engine	X20DTH	√	√	√	√		
2000	Vectra-B	Engine	X20DTL	√	√	√	√		
2000	Vectra-B	Engine	X20XEV	√	√	√	√	√	
2000	Vectra-B	Engine	C22SEL	√	√	√	√		SP0204,SP0040,SP0202
2000	Vectra-B	Engine	16LZ2	√	√	√	√		
2000	Vectra-B	Engine	X18XE	√	√	√	√		SP0166,SP0202,SP0203,SP0204,SP0040
2000	Vectra-B	Engine	X25XE	√	√	√	√		
2000	Vectra-B	Infotainment System	Trip Info Display TID	√	√	√			
2000	Vectra-B	Infotainment System	Multi Info Dispaly MID	√	√	√			
2000	Vectra-B	Infotainment System	Radio CAR 300	√	√	√			
2000	Vectra-B	Infotainment System	Radio CAR 400	√	√	√	√		
2000	Vectra-B	Infotainment System	Radio CDR 500	√	√	√	√		
2000	Vectra-B	Infotainment System	Radio CCRT 700	√	√	√	√		
2000	Vectra-B	Transmission	AF 13-II/17/20/22	√	√	√	√	√	
2000	Vectra-B	Transmission	AF 13-II/17/20/22 CAN	√	√	√	√	√	
2000	Zafira	Body	Immobiliser	√	√	√	√		SP0139,SP0140
2000	Zafira	Body	Instrument	√	√	√	√		
2000	Zafira	Body	Airbag	√	√	√	√	√	
2000	Zafira	Body	Anti Theft Warning	√	√	√	√		
2000	Zafira	Body	Central Door Lock	√	√	√	√		
2000	Zafira	Body	Electronic Climate Control	√	√	√	√		
2000	Zafira	Body	Engine Cooling Module	√	√	√	√		
2000	Zafira	Body	Airbag SAB6	√	√	√	√		
2000	Zafira	Chassis	ABS-5.3/5.4(+TC)	√	√	√	√	√	
2000	Zafira	Chassis	ESP	√	√	√	√	√	SP0005
2000	Zafira	Chassis	Cruise Control	√	√	√	√		
2000	Zafira	Chassis	Electronic Power Steering	√	√	√	√		SP0141

2000	Zafira	Engine	X16XEL	√	√	√	√	√	SP0166,SP0194,SP0195,SP0196,SP0197,S P0019
2000	Zafira	Engine	X18XE1	√	√	√	√	√	
2000	Zafira	Engine	X20DTL	√	√	√	√		
2000	Zafira	Infotainment System	Radio CAR 300	√	√	√	√		
2000	Zafira	Infotainment System	Trip Info Display TID	√	√	√			
2000	Zafira	Infotainment System	Multi Info Dispaly MID	√	√	√			
2000	Zafira	Infotainment System	Radio CAR 300	√	√	√	√		
2000	Zafira	Infotainment System	Radio CAR 400	√	√	√	√		
2000	Zafira	Infotainment System	Radio CDR 500	√	√	√	√		
2000	Zafira	Infotainment System	Radio CCR 600	√	√	√	√		
2000	Zafira	Infotainment System	Radio CCRT 700	√	√	√	√		
2000	Zafira	Infotainment System	Radio NCDR 1100/1500	√	√	√	√		
2000	Zafira	Transmission	AF 13-II/17/20/22 CAN	√	√	√	√	√	
1999	Arena	Body	Immobiliser	√	√	√	√		SP0164,SP0165
1999	Astra-F	Body	Immobiliser	√	√	√	√		
1999	Astra-F	Body	Airbag S	√	√	√	√		
1999	Astra-F	Body	Instrument	√	√	√	√	√	
1999	Astra-F	Body	Anti Theft Warning	√	√	√	√	√	
1999	Astra-F	Engine	16NZR	√	√	√	√		
1999	Astra-F	Engine	X16SZR	√	√	√	√	√	
1999	Astra-F	Engine	X16XEL	√	√	√	√	√	SP0166,SP0194,SP0195,SP0196,SP0197,S P0019
1999	Astra-F	Engine	18SE	√	√	√	√		
1999	Astra-F	Engine	C18SEL	√	√	√	√		SP0166
1999	Astra-F	Engine	C16SE		√	√	√		
1999	Astra-F	Engine	X18XE	√	√	√	√		SP0166,SP0202,SP0203,SP0204,SP0040
1999	Astra-F	Infotainment System	Trip Info Display TID	√	√	√			

1999	Astra-F	Infotainment System	Multi Info Dispaly MID	√	√	√			
1999	Astra-F	Infotainment System	Radio CAR 300	√	√	√			
1999	Astra-F	Infotainment System	Radio CAR 400	√	√	√	√		
1999	Astra-F	Infotainment System	Radio CDR 500	√	√	√	√		
1999	Astra-F	Transmission	AF 13II/20/22/30	√	√	√	√		
1999	Astra-G	Body	Immobiliser	√	√	√	√		SP0139,SP0140
1999	Astra-G	Body	Instrument	√	√	√	√		
1999	Astra-G	Body	Airbag SAB6	√	√	√	√		
1999	Astra-G	Body	Anti Theft Warning	√	√	√	√		
1999	Astra-G	Body	Central Door Lock	√	√	√	√		
1999	Astra-G	Body	Engine Cooling Module	√	√	√	√		
1999	Astra-G	Chassis	ABS-5.3/5.4(+TC)	√	√	√	√	√	
1999	Astra-G	Chassis	Cruise Control	√	√	√	√		
1999	Astra-G	Engine	X12XE	√	√	√	√	√	SP0166,SP0196,SP0202,SP0201
1999	Astra-G	Engine	X14XE	√	√	√	√	√	
1999	Astra-G	Engine	C16SEL	√	√	√	√	√	
1999	Astra-G	Engine	X16SZR	√	√	√	√		
1999	Astra-G	Engine	X16XEL	√	√	√	√	√	SP0166,SP0194,SP0195,SP0196,SP0197,S P0019
1999	Astra-G	Engine	X17DTL	√	√	√	√	√	
1999	Astra-G	Engine	X18XE1	√	√	√	√	√	
1999	Astra-G	Engine	X20DTL	√	√	√	√		
1999	Astra-G	Engine	X20XEV	√	√	√	√		
1999	Astra-G	Infotainment System	Trip Info Display TID	√	√	√			
1999	Astra-G	Infotainment System	Multi Info Dispaly MID	√	√	√			
1999	Astra-G	Infotainment System	Radio CAR 300	√	√	√			
1999	Astra-G	Infotainment System	Radio CAR 400	√	√	√	√		
1999	Astra-G	Infotainment System	Radio CDR 500	√	√	√	√		

1999	Astra-G	Infotainment System	Radio CCRT 700	√	√	√	√		
1999	Astra-G	Transmission	AF 13-II/17/20/22	√	√	√	√	√	
1999	Astra-G(GMSA)	Body	Immobiliser	√	√	√	√		SP0164,SP0165
1999	Astra-G(GMSA)	Engine	13 NE	√	√	√	√	√	SP0166,SP0190,SP0191,SP0056,SP0192
1999	Astra-G(GMSA)	Engine	14 NE	√	√	√	√	√	SP0166,SP0190,SP0191,SP0056,SP0192
1999	Astra-G(GMSA)	Engine	16 SE	√	√	√			
1999	Corsa-B	Body	Immobiliser	√	√	√	√		
1999	Corsa-B	Body	Airbag S	√	√	√	√		
1999	Corsa-B	Body	Airbag SAB6	√	√	√	√		
1999	Corsa-B	Body	Anti Theft Warning	√	√	√	√	√	
1999	Corsa-B	Body	Instrument	√	√	√	√		
1999	Corsa-B	Chassis	ABS-5.3	√	√	√	√		
1999	Corsa-B	Chassis	Electronic Power Steering	√	√	√	√		
1999	Corsa-B	Engine	X10XE	√	√	√	√	√	SP0166,SP0196,SP0202,SP0201
1999	Corsa-B	Engine	X12XE	√	√	√	√	√	SP0166,SP0196,SP0202,SP0201
1999	Corsa-B	Engine	C14SEL	√	√	√	√		
1999	Corsa-B	Engine	X14SZ	√	√	√	√	√	
1999	Corsa-B	Engine	X14XE	√	√	√	√	√	
1999	Corsa-B	Engine	C16SEL	√	√	√	√		
1999	Corsa-B	Engine	X16XE	√	√	√	√	√	SP0166,SP0195,SP0196,SP0197,SP0019,S P0201,SP0056
1999	Corsa-B	Engine	C14SE	√	√	√	√		
1999	Corsa-B	Infotainment System	Radio CAR 300	√	√	√			
1999	Corsa-B	Infotainment System	Radio CAR 400	√	√	√	√		
1999	Corsa-B	Infotainment System	Radio CDR 500	√	√	√	√		
1999	Corsa-B	Infotainment System	Radio CCRT 700	√	√	√	√		
1999	Corsa-B	Transmission	AF 13II/20/22/30	√	√	√	√		
1999	Corsa-B	Transmission	AF 13/14/20	√	√	√	√		
1999	Corsa-B	Body	Immobiliser	√	√	√	√		SP0164,SP0165
1999	Corsa-B	Engine	13 NE	√	√	√	√	√	SP0166,SP0190,SP0191,SP0056,SP0192
1999	Corsa-B	Engine	14 NE	√	√	√	√	√	SP0166,SP0190,SP0191,SP0056,SP0192
1999	Corsa-B	Engine	16 NE	√	√	√			
1999	Corsa-B	Engine	16 SE	√	√	√			

1999	Frontera-B	Body	Airbag	√	√	√	√		
1999	Frontera-B	Body	Anti Theft Warning	√	√	√			
1999	Frontera-B	Body	Central Door Lock	√	√	√	√	√	SP0164,SP0165
1999	Frontera-B	Body	Immobiliser	√	√	√	√		SP0164,SP0165
1999	Frontera-B	Engine	X22DTH	√	√	√	√		
1999	Frontera-B	Infotainment System	Trip Info Display TID	√	√	√			
1999	Frontera-B	Infotainment System	Multi Info Dispaly MID	√	√	√			
1999	Frontera-B	Infotainment System	Radio CAR 300	√	√	√			
1999	Frontera-B	Infotainment System	Radio CAR 400	√	√	√	√		
1999	Frontera-B	Infotainment System	Radio CDR 500	√	√	√	√		
1999	Frontera-B	Infotainment System	Radio CCRT 700	√	√	√	√		
1999	Frontera-B	Transmission	AR 25/35	√	√	√	√	√	
1999	Monterey	Body	Airbag	√	√	√	√		
1999	Monterey	Body	Immobiliser	√	√	√	√		SP0164,SP0165
1999	Monterey	Body	Anti Theft Warning	√	√	√	√	√	
1999	Monterey	Chassis	ABS 5	√	√	√	√		
1999	Monterey	Engine	4JX1(3.0L)		√	√	√		
1999	Monterey	Engine	6VE1(3.5L,V6)	√	√	√			
1999	Movano	Body	Immobiliser	√	√	√	√		SP0164,SP0165
1999	Omega-B	Body	Airbag SAB6	√	√	√	√		
1999	Omega-B	Body	Headlamp Levelling Device	√	√	√	√	√	SP0141
1999	Omega-B	Body	Add On Heater	√	√	√	√	√	SP0122,SP0123
1999	Omega-B	Body	Anti Theft Warning	√	√	√	√	√	
1999	Omega-B	Body	Central Door Lock	√	√	√	√	√	SP0164,SP0165
1999	Omega-B	Body	Electronic Climate Control	√	√	√	√		
1999	Omega-B	Body	Immobiliser	√	√	√	√		SP0164,SP0165
1999	Omega-B	Body	Instrument	√	√	√	√		
1999	Omega-B	Chassis	ABS-5.3/5.4(+TC)	√	√	√	√	√	
1999	Omega-B	Chassis	Servotronic	√	√	√			
1999	Omega-B	Engine	X20DTH	√	√	√	√		
1999	Omega-B	Engine	X20XEV	√	√	√	√	√	
1999	Omega-B	Engine	X25XE	√	√	√	√		

1999	Omega-B	Engine	Y30XE	√	√	√	√		
1999	Omega-B	Engine	20SE	√	√	√	√		
1999	Omega-B	Infotainment System	Trip Info Display TID	√	√	√			
1999	Omega-B	Infotainment System	Multi Info Dispaly MID	√	√	√			
1999	Omega-B	Infotainment System	Radio CAR 300	√	√	√			
1999	Omega-B	Infotainment System	Radio CAR 400	√	√	√	√		
1999	Omega-B	Infotainment System	Radio CDR 500	√	√	√	√		
1999	Omega-B	Infotainment System	Radio CCRT 700	√	√	√	√		
1999	Omega-B	Transmission	AR 25/35	√	√	√	√	√	
1999	Sintra	Body	Airbag	√	√	√	√		
1999	Sintra	Body	Body Control Module	√	√	√	√	√	SP0051,SP0058,SP0138
1999	Sintra	Body	Immobiliser	√	√	√	√		SP0164,SP0165
1999	Sintra	Engine	X22DTH	√	√	√	√		
1999	Sintra	Infotainment System	Trip Info Display TID	√	√	√			
1999	Sintra	Infotainment System	Multi Info Dispaly MID	√	√	√			
1999	Sintra	Infotainment System	Radio CAR 300	√	√	√			
1999	Sintra	Infotainment System	Radio CAR 400	√	√	√	√		
1999	Sintra	Infotainment System	Radio CDR 500	√	√	√	√		
1999	Sintra	Transmission	AF 13II/20/22/30	√	√	√	√		
1999	Tigra	Body	Immobiliser	√	√	√	√		
1999	Tigra	Body	Airbag S	√	√	√	√		
1999	Tigra	Body	Airbag SAB6	√	√	√	√		
1999	Tigra	Body	Anti Theft Warning	√	√	√	√	√	
1999	Tigra	Chassis	ABS-5.3	√	√	√	√		
1999	Tigra	Engine	C14SEL	√	√	√	√		
1999	Tigra	Engine	X14XE	√	√	√	√	√	
1999	Tigra	Engine	C16SEL	√	√	√	√		

1999	Tigra	Engine	X16XE	√	√	√	√	√	SP0166,SP0195,SP0196,SP0197,SP0019,S P0201,SP0056
1999	Vauxhall VXR8	Body	Anti Theft Warning	√	√	√	√	√	
1999	Vauxhall VXR8	Body	Airbag-S	√	√	√	√		
1999	Vauxhall VXR8	Body	Airbag SAB6	√	√	√	√		
1999	Vauxhall VXR8	Body	Immobiliser	√	√	√	√		SP0164,SP0165
1999	Vauxhall VXR8	Engine	X 14 XE	√	√	√	√	√	
1999	Vauxhall VXR8	Engine	X 16 XE	√	√	√	√	√	SP0166,SP0195,SP0196,SP0197,SP0019,S P0201,SP0056
1999	Vauxhall VXR8	Engine	C 16 SEL	√	√	√	√	√	
1999	Vauxhall VXR8	Infotainment System	Radio CAR 300	√	√	√			
1999	Vauxhall VXR8	Infotainment System	Radio CAR 400	√	√	√	√		
1999	Vauxhall VXR8	Infotainment System	Radio CDR 500	√	√	√	√		
1999	Vauxhall VXR8	Infotainment System	Radio CCRT 700	√	√	√	√		
1999	Vauxhall VXR8	Transmission	AF 13/14/20	√	√	√	√		
1999	Vectra-B	Body	Immobiliser	√	√	√	√		
1999	Vectra-B	Body	Instrument	√	√	√	√		
1999	Vectra-B	Body	Airbag SAB6	√	√	√	√		
1999	Vectra-B	Body	Add On Heater	√	√	√	√	√	SP0122,SP0123
1999	Vectra-B	Body	Anti Theft Warning	√	√	√	√	√	
1999	Vectra-B	Body	Electronic Climate Control	√	√	√	√		
1999	Vectra-B	Chassis	ABS 415	√	√	√	√		
1999	Vectra-B	Chassis	ABS 430	√	√	√	√		
1999	Vectra-B	Chassis	ABS-5.3/5.4(+TC)	√	√	√	√	√	
1999	Vectra-B	Chassis	ABS-5-TC (Anti-lock Braking System)	√	√	√	√		
1999	Vectra-B	Engine	X16SZR	√	√	√	√	√	
1999	Vectra-B	Engine	X16XEL	√	√	√	√	√	SP0166,SP0194,SP0195,SP0196,SP0197,S P0019
1999	Vectra-B	Engine	Y16XE	√	√	√	√	√	
1999	Vectra-B	Engine	X18XE1	√	√	√	√	√	
1999	Vectra-B	Engine	20NEJ	√	√	√	√		
1999	Vectra-B	Engine	C20SEL	√	√	√	√	√	SP0166
1999	Vectra-B	Engine	X20DTH	√	√	√	√		
1999	Vectra-B	Engine	X20DTL	√	√	√	√		

1999	Vectra-B	Engine	X20XEV	√	√	√	√	√	
1999	Vectra-B	Engine	C22SEL	√	√	√	√		SP0204,SP0040,SP0202
1999	Vectra-B	Engine	16LZ2	√	√	√	√		
1999	Vectra-B	Engine	X18XE	√	√	√	√		SP0166,SP0202,SP0203,SP0204,SP0040
1999	Vectra-B	Engine	X25XE	√	√	√	√		
1999	Vectra-B	Infotainment System	Trip Info Display TID	√	√	√			
1999	Vectra-B	Infotainment System	Multi Info Dispaly MID	√	√	√			
1999	Vectra-B	Infotainment System	Radio CAR 300	√	√	√			
1999	Vectra-B	Infotainment System	Radio CAR 400	√	√	√	√		
1999	Vectra-B	Infotainment System	Radio CDR 500	√	√	√	√		
1999	Vectra-B	Infotainment System	Radio CCRT 700	√	√	√	√		
1999	Vectra-B	Transmission	AF 13-II/17/20/22	√	√	√	√	√	
1999	Vectra-B	Transmission	AF 13II/20/22/30	√	√	√	√		
1999	Zafira	Body	Immobiliser	√	√	√	√		SP0139,SP0140
1999	Zafira	Body	Instrument	√	√	√	√		
1999	Zafira	Body	Airbag	√	√	√	√	√	
1999	Zafira	Body	Anti Theft Warning	√	√	√	√		
1999	Zafira	Body	Central Door Lock	√	√	√	√		
1999	Zafira	Body	Electronic Climate Control	√	√	√	√		
1999	Zafira	Body	Engine Cooling Module	√	√	√	√		
1999	Zafira	Body	Airbag SAB6	√	√	√	√		
1999	Zafira	Chassis	ABS-5.3/5.4(+TC)	√	√	√	√	√	
1999	Zafira	Chassis	Cruise Control	√	√	√	√		
1999	Zafira	Chassis	Electronic Power Steering	√	√	√	√		SP0141
1999	Zafira	Engine	X16XEL	√	√	√	√	√	SP0166,SP0194,SP0195,SP0196,SP0197,S P0019
1999	Zafira	Engine	X18XE1	√	√	√	√	√	
1999	Zafira	Infotainment System	Radio CAR 300	√	√	√	√		
1999	Zafira	Infotainment System	Trip Info Display TID	√	√	√			

1999	Zafira	Infotainment System	Multi Info Dispaly MID	√	√	√			
1999	Zafira	Infotainment System	Radio CAR 300	√	√	√	√		
1999	Zafira	Infotainment System	Radio CAR 400	√	√	√	√		
1999	Zafira	Infotainment System	Radio CDR 500	√	√	√	√		
1999	Zafira	Infotainment System	Radio CCRT 700	√	√	√	√		
1999	Zafira	Transmission	AF 13-II/17/20/22 CAN	√	√	√	√	√	
1998	Arena	Body	Immobiliser	√	√	√	√		SP0164,SP0165
1998	Astra-F	Body	Immobiliser	√	√	√	√		
1998	Astra-F	Body	Airbag S	√	√	√	√		
1998	Astra-F	Body	Instrument	√	√	√	√	√	
1998	Astra-F	Body	Anti Theft Warning	√	√	√	√	√	
1998	Astra-F	Engine	X14XE	√	√	√	√		
1998	Astra-F	Engine	16NZR	√	√	√	√		
1998	Astra-F	Engine	X16SZR	√	√	√	√	√	
1998	Astra-F	Engine	X16XEL	√	√	√	√	√	SP0166,SP0194,SP0195,SP0196,SP0197,S P0019
1998	Astra-F	Engine	18SE	√	√	√	√		
1998	Astra-F	Engine	C18SEL	√	√	√	√		SP0166
1998	Astra-F	Engine	X18XE	√	√	√	√		SP0166,SP0202,SP0203,SP0204,SP0040
1998	Astra-F	Engine	X20XEV	√	√	√	√	√	
1998	Astra-F	Engine	C14SE	√	√	√	√		
1998	Astra-F	Engine	C16SE		√	√	√		
1998	Astra-F	Engine	16LZ2	√	√	√	√		
1998	Astra-F	Infotainment System	Multi Info Dispaly MID	√	√	√			
1998	Astra-F	Infotainment System	Radio CAR 300	√	√	√			
1998	Astra-F	Infotainment System	Radio CAR 400	√	√	√	√		
1998	Astra-F	Infotainment System	Radio CDR 500	√	√	√	√		
1998	Astra-F	Transmission	AF 13II/20/22/30	√	√	√	√		
1998	Astra-F	Transmission	AF 13/14/20	√	√	√	√		

1998	Astra-G	Body	Immobiliser	√	√	√	√		SP0139,SP0140
1998	Astra-G	Body	Instrument	√	√	√	√		
1998	Astra-G	Body	Airbag SAB6	√	√	√	√		
1998	Astra-G	Body	Anti Theft Warning	√	√	√	√		
1998	Astra-G	Body	Central Door Lock	√	√	√	√		
1998	Astra-G	Body	Engine Cooling Module	√	√	√	√		
1998	Astra-G	Chassis	ABS-5.3/5.4(+TC)	√	√	√	√	√	
1998	Astra-G	Chassis	Cruise Control	√	√	√	√		
1998	Astra-G	Engine	X12XE	√	√	√	√	√	SP0166,SP0196,SP0202,SP0201
1998	Astra-G	Engine	X14XE	√	√	√	√	√	
1998	Astra-G	Engine	X16SZR	√	√	√	√		
1998	Astra-G	Engine	X16XEL	√	√	√	√	√	SP0166,SP0194,SP0195,SP0196,SP0197,SP0019
1998	Astra-G	Engine	X17DTL	√	√	√	√	√	
1998	Astra-G	Engine	X18XE1	√	√	√	√	√	
1998	Astra-G	Engine	X20DTL	√	√	√	√		
1998	Astra-G	Engine	X20XEV	√	√	√	√		
1998	Astra-G	Infotainment System	Multi Info Display MID	√	√	√			
1998	Astra-G	Infotainment System	Radio CAR 300	√	√	√			
1998	Astra-G	Infotainment System	Radio CAR 400	√	√	√	√		
1998	Astra-G	Infotainment System	Radio CDR 500	√	√	√	√		
1998	Astra-G	Transmission	AF 13-II/17/20/22	√	√	√	√	√	
1998	Astra-G(GMSA)	Body	Immobiliser	√	√	√	√		SP0164,SP0165
1998	Astra-G(GMSA)	Engine	13 NE	√	√	√	√	√	SP0166,SP0190,SP0191,SP0056,SP0192
1998	Astra-G(GMSA)	Engine	14 NE	√	√	√	√	√	SP0166,SP0190,SP0191,SP0056,SP0192
1998	Astra-G(GMSA)	Engine	16 SE	√	√	√			
1998	Corsa-B	Body	Immobiliser	√	√	√	√		
1998	Corsa-B	Body	Airbag S	√	√	√	√		
1998	Corsa-B	Body	Anti Theft Warning	√	√	√	√	√	
1998	Corsa-B	Body	Instrument	√	√	√	√		
1998	Corsa-B	Chassis	ABS-5.3	√	√	√	√		
1998	Corsa-B	Chassis	Electronic Power Steering	√	√	√	√		
1998	Corsa-B	Engine	X10XE	√	√	√	√	√	SP0166,SP0196,SP0202,SP0201
1998	Corsa-B	Engine	X12XE	√	√	√	√	√	SP0166,SP0196,SP0202,SP0201

1998	Corsa-B	Engine	C14SEL	√	√	√	√		
1998	Corsa-B	Engine	C14NZ	√	√	√	√		
1998	Corsa-B	Engine	X14SZ	√	√	√	√	√	
1998	Corsa-B	Engine	X14XE	√	√	√	√	√	
1998	Corsa-B	Engine	C16SEL	√	√	√	√		
1998	Corsa-B	Engine	X16XE	√	√	√	√	√	SP0166,SP0195,SP0196,SP0197,SP0019,S P0201,SP0056
1998	Corsa-B	Infotainment System	Radio CAR 300	√	√	√			
1998	Corsa-B	Infotainment System	Radio CAR 400	√	√	√	√		
1998	Corsa-B	Infotainment System	Radio CDR 500	√	√	√	√		
1998	Corsa-B	Transmission	AF 13II/20/22/30	√	√	√	√		
1998	Corsa-B	Transmission	AF 13/14/20	√	√	√	√		
1998	Corsa-B(GMSA)	Body	Immobiliser	√	√	√	√		SP0164,SP0165
1998	Corsa-B(GMSA)	Engine	13 NE	√	√	√	√	√	SP0166,SP0190,SP0191,SP0056,SP0192
1998	Corsa-B(GMSA)	Engine	14 NE	√	√	√	√	√	SP0166,SP0190,SP0191,SP0056,SP0192
1998	Corsa-B(GMSA)	Engine	16 NE	√	√	√			
1998	Corsa-B(GMSA)	Engine	16 SE	√	√	√			
1998	Frontera	Body	Immobiliser	√	√	√	√		
1998	Frontera	Body	Anti Theft Warning	√	√	√			
1998	Frontera	Body	Central Door Lock	√	√	√	√	√	SP0164,SP0165
1998	Frontera	Chassis	ABS 415	√	√	√	√		
1998	Frontera	Engine	25 TDS	√	√	√	√		
1998	Frontera	Infotainment System	Multi Info Dispaly MID	√	√	√			
1998	Frontera	Infotainment System	Radio CDR 500	√	√	√	√		
1998	Monterey	Chassis	ABS 5	√	√	√	√		
1998	Monterey	Chassis	Anti Theft Warning	√	√	√	√	√	
1998	Monterey	Chassis	Body Control Module	√	√	√	√	√	SP0051,SP0058,SP0138
1998	Monterey	Chassis	Immobiliser	√	√	√	√		SP0164,SP0165
1998	Omega-B	Body	Immobiliser	√	√	√	√		
1998	Omega-B	Body	Airbag SAB6	√	√	√	√		
1998	Omega-B	Body	Headlamp Levelling Device	√	√	√	√	√	SP0141
1998	Omega-B	Body	Add On Heater	√	√	√	√	√	SP0122,SP0123
1998	Omega-B	Body	Anti Theft Warning	√	√	√	√	√	

1998	Omega-B	Body	Central Door Lock	√	√	√	√	√	SP0164,SP0165
1998	Omega-B	Body	Electronic Climate Control	√	√	√	√		
1998	Omega-B	Body	Instrument	√	√	√	√		
1998	Omega-B	Chassis	ABS-5.3/5.4(+TC)	√	√	√	√	√	
1998	Omega-B	Chassis	Servotronic	√	√	√			
1998	Omega-B	Engine	X20DTH	√	√	√	√		
1998	Omega-B	Engine	X20XEV	√	√	√	√	√	
1998	Omega-B	Engine	X25XE	√	√	√	√		
1998	Omega-B	Engine	Y30XE	√	√	√	√		
1998	Omega-B	Engine	20SE	√	√	√	√		
1998	Omega-B	Infotainment System	Trip Info Display TID	√	√	√			
1998	Omega-B	Infotainment System	Multi Info Dispaly MID	√	√	√			
1998	Omega-B	Infotainment System	Radio CAR 300	√	√	√			
1998	Omega-B	Infotainment System	Radio CAR 400	√	√	√	√		
1998	Omega-B	Infotainment System	Radio CDR 500	√	√	√	√		
1998	Omega-B	Transmission	AR 25/35	√	√	√	√	√	
1998	Sintra	Body	Body Control Module	√	√	√	√	√	SP0051,SP0058,SP0138
1998	Sintra	Body	Immobiliser	√	√	√	√		SP0164,SP0165
1998	Sintra	Engine	X22DTH	√	√	√	√		
1998	Sintra	Infotainment System	Multi Info Dispaly MID	√	√	√			
1998	Sintra	Infotainment System	Radio CAR 300	√	√	√			
1998	Sintra	Infotainment System	Radio CAR 400	√	√	√	√		
1998	Sintra	Infotainment System	Radio CDR 500	√	√	√	√		
1998	Sintra	Transmission	AF 13II/20/22/30	√	√	√	√		
1998	Tigra	Body	Immobiliser	√	√	√	√		
1998	Tigra	Body	Airbag S	√	√	√	√		
1998	Tigra	Body	Anti Theft Warning	√	√	√	√	√	
1998	Tigra	Chassis	ABS-5.3	√	√	√	√		
1998	Tigra	Engine	C14SEL	√	√	√	√		

1998	Tigra	Engine	X14XE	√	√	√	√	√	
1998	Tigra	Engine	C16SEL	√	√	√	√		
1998	Tigra	Engine	X16XE	√	√	√	√	√	SP0166,SP0195,SP0196,SP0197,SP0019,S P0201,SP0056
1998	Vauxhall VXR8	Body	Airbag-S	√	√	√	√		
1998	Vauxhall VXR8	Body	Immobiliser	√	√	√	√		SP0164,SP0165
1998	Vauxhall VXR8	Engine	X 14 XE	√	√	√	√	√	
1998	Vauxhall VXR8	Engine	X 16 XE	√	√	√	√	√	SP0166,SP0195,SP0196,SP0197,SP0019,S P0201,SP0056
1998	Vauxhall VXR8	Infotainment System	Radio CAR 300	√	√	√			
1998	Vauxhall VXR8	Infotainment System	Radio CAR 400	√	√	√	√		
1998	Vauxhall VXR8	Infotainment System	Radio CDR 500	√	√	√	√		
1998	Vauxhall VXR8	Transmission	AF 13/14/20	√	√	√	√		
1998	Vectra-B	Body	Immobiliser	√	√	√	√		
1998	Vectra-B	Body	Instrument	√	√	√	√		
1998	Vectra-B	Body	Airbag SAB6	√	√	√	√		
1998	Vectra-B	Body	Add On Heater	√	√	√	√	√	SP0122,SP0123
1998	Vectra-B	Body	Anti Theft Warning	√	√	√	√	√	
1998	Vectra-B	Body	Electronic Climate Control	√	√	√	√		
1998	Vectra-B	Chassis	ABS 415	√	√	√	√		
1998	Vectra-B	Chassis	ABS 430	√	√	√	√		
1998	Vectra-B	Chassis	ABS-5-TC	√	√	√	√		
1998	Vectra-B	Chassis	ABS-5.3/5.4(+TC)	√	√	√	√	√	
1998	Vectra-B	Engine	X16SZR	√	√	√	√	√	
1998	Vectra-B	Engine	X16XEL	√	√	√	√	√	SP0166,SP0194,SP0195,SP0196,SP0197,S P0019
1998	Vectra-B	Engine	Y16XE	√	√	√	√	√	
1998	Vectra-B	Engine	X18XE1	√	√	√	√	√	
1998	Vectra-B	Engine	20NEJ	√	√	√	√		
1998	Vectra-B	Engine	C20SEL	√	√	√	√	√	SP0166
1998	Vectra-B	Engine	X20DTH	√	√	√	√		
1998	Vectra-B	Engine	X20DTL	√	√	√	√		
1998	Vectra-B	Engine	X20XEV	√	√	√	√	√	
1998	Vectra-B	Engine	C22SEL	√	√	√	√		SP0204,SP0040,SP0202
1998	Vectra-B	Engine	16LZ2	√	√	√	√		

1998	Vectra-B	Engine	X18XE	√	√	√	√		SP0166,SP0202,SP0203,SP0204,SP0040
1998	Vectra-B	Engine	X25XE	√	√	√	√		
1998	Vectra-B	Infotainment System	Trip Info Display TID	√	√	√			
1998	Vectra-B	Infotainment System	Multi Info Dispaly MID	√	√	√			
1998	Vectra-B	Infotainment System	Radio CAR 300	√	√	√			
1998	Vectra-B	Infotainment System	Radio CAR 400	√	√	√	√		
1998	Vectra-B	Infotainment System	Radio CDR 500	√	√	√	√		
1998	Vectra-B	Infotainment System	Radio CCRT 700	√	√	√	√		
1998	Vectra-B	Transmission	AF 13-II/17/20/22	√	√	√	√	√	
1998	Vectra-B	Transmission	AF 13II/20/22/30	√	√	√	√		
1997	Astra-F	Body	Immobiliser	√	√	√	√		
1997	Astra-F	Body	Airbag S	√	√	√	√		
1997	Astra-F	Body	Instrument	√	√	√	√	√	
1997	Astra-F	Body	Anti Theft Warning	√	√	√	√	√	
1997	Astra-F	Chassis	Traction Control(TC)	√	√	√	√		
1997	Astra-F	Engine	C14NZ	√	√	√	√		
1997	Astra-F	Engine	X14XE	√	√	√	√		
1997	Astra-F	Engine	16NZR	√	√	√	√		
1997	Astra-F	Engine	X16SZR	√	√	√	√	√	
1997	Astra-F	Engine	X16XEL	√	√	√	√	√	SP0166,SP0194,SP0195,SP0196,SP0197,S P0019
1997	Astra-F	Engine	18SE	√	√	√	√		
1997	Astra-F	Engine	C18SEL	√	√	√	√		SP0166
1997	Astra-F	Engine	X18XE	√	√	√	√		SP0166,SP0202,SP0203,SP0204,SP0040
1997	Astra-F	Engine	X20XEV	√	√	√	√	√	
1997	Astra-F	Engine	C14SE	√	√	√	√		
1997	Astra-F	Engine	C16SE		√	√	√		
1997	Astra-F	Engine	16LZ2	√	√	√	√		
1997	Astra-F	Infotainment System	Multi Info Dispaly MID	√	√	√			
1997	Astra-F	Infotainment System	Radio CAR 300	√	√	√			

1997	Astra-F	Infotainment System	Radio CAR 400	√	√	√	√		
1997	Astra-F	Infotainment System	Radio CDR 500	√	√	√	√		
1997	Astra-F	Transmission	AF 13II/20/22/30	√	√	√	√		
1997	Astra-F	Transmission	AF 13/14/20	√	√	√	√		
1997	Astra-G(GMSA)	Body	Immobiliser	√	√	√	√		SP0164,SP0165
1997	Astra-G(GMSA)	Engine	13 NE	√	√	√	√	√	SP0166,SP0190,SP0191,SP0056,SP0192
1997	Astra-G(GMSA)	Engine	14 NE	√	√	√	√	√	SP0166,SP0190,SP0191,SP0056,SP0192
1997	Astra-G(GMSA)	Engine	16 SE	√	√	√			
1997	Calibra	Body	Immobiliser	√	√	√	√		
1997	Calibra	Body	Airbag-S	√	√	√	√		
1997	Calibra	Body	Anti Theft Warning	√	√	√	√	√	
1997	Calibra	Chassis	Traction Control(TC)	√	√	√	√		
1997	Calibra	Engine	X20XEV	√	√	√	√	√	
1997	Calibra	Engine	X25XE	√	√	√	√		
1997	Calibra	Transmission	AF 13II/20/22/30	√	√	√	√		
1997	Calibra	Transmission	AF 13/14/20	√	√	√	√		
1997	Corsa-B	Body	Immobiliser	√	√	√	√		
1997	Corsa-B	Body	Airbag S	√	√	√	√		
1997	Corsa-B	Body	Anti Theft Warning	√	√	√	√	√	
1997	Corsa-B	Body	Instrument	√	√	√	√		
1997	Corsa-B	Chassis	ABS-5.3	√	√	√	√		
1997	Corsa-B	Chassis	Electronic Power Steering	√	√	√	√		
1997	Corsa-B	Engine	X10XE	√	√	√	√	√	SP0166,SP0196,SP0202,SP0201
1997	Corsa-B	Engine	C14NZ	√	√	√	√		
1997	Corsa-B	Engine	X14SZ	√	√	√	√	√	
1997	Corsa-B	Engine	X14XE	√	√	√	√	√	
1997	Corsa-B	Engine	X16XE	√	√	√	√	√	SP0166,SP0195,SP0196,SP0197,SP0019,S P0201,SP0056
1997	Corsa-B	Infotainment System	Radio CAR 300	√	√	√			
1997	Corsa-B	Infotainment System	Radio CAR 400	√	√	√	√		
1997	Corsa-B	Infotainment System	Radio CDR 500	√	√	√	√		
1997	Corsa-B	Transmission	AF 13/14/20	√	√	√	√		
1997	Corsa-B(GMSA)	Body	Immobiliser	√	√	√	√		SP0164,SP0165

1997	Corsa-B(GMSA)	Engine	13 NE	√	√	√	√	√	SP0166,SP0190,SP0191,SP0056,SP0192
1997	Corsa-B(GMSA)	Engine	14 NE	√	√	√	√	√	SP0166,SP0190,SP0191,SP0056,SP0192
1997	Corsa-B(GMSA)	Engine	16 NE	√	√	√			
1997	Corsa-B(GMSA)	Engine	16 SE	√	√	√			
1997	Frontera	Body	Immobiliser	√	√	√	√		
1997	Frontera	Body	Anti Theft Warning	√	√	√			
1997	Frontera	Chassis	ABS 415	√	√	√	√		
1997	Frontera	Engine	25 TDS	√	√	√	√		
1997	Monterey	Body	Immobiliser	√	√	√	√		SP0164,SP0165
1997	Monterey	Chassis	ABS 5	√	√	√	√		
1997	Omega-B	Body	Immobiliser	√	√	√	√		
1997	Omega-B	Body	Airbag S	√	√	√	√		
1997	Omega-B	Body	Airbag SAB6	√	√	√	√		
1997	Omega-B	Body	Anti Theft Warning	√	√	√	√	√	
1997	Omega-B	Body	Electronic Climate Control	√	√	√	√		
1997	Omega-B	Chassis	ABS-5.3/5.4(+TC)	√	√	√	√	√	
1997	Omega-B	Chassis	Cruise Control	√	√	√	√		
1997	Omega-B	Chassis	ABS 2SE(+TC) (Anti-lock Braking System)	√	√	√	√		
1997	Omega-B	Chassis	ABS 2SE(+TC) (Anti-lock Braking System)	√	√	√	√		
1997	Omega-B	Engine	X20XEV	√	√	√	√	√	
1997	Omega-B	Engine	X25XE	√	√	√	√		
1997	Omega-B	Engine	Y30XE	√	√	√	√		
1997	Omega-B	Engine	20SE	√	√	√	√		
1997	Omega-B	Infotainment System	Trip Info Display TID	√	√	√			
1997	Omega-B	Infotainment System	Multi Info Display MID	√	√	√			
1997	Omega-B	Infotainment System	Radio CAR 300	√	√	√			
1997	Omega-B	Infotainment System	Radio CAR 400	√	√	√	√		
1997	Omega-B	Infotainment System	Radio CDR 500	√	√	√	√		
1997	Omega-B	Transmission	AR 25/35	√	√	√			
1997	Sintra	Body	Immobiliser	√	√	√	√		SP0164,SP0165
1997	Sintra	Body	Body Control Module	√	√	√	√	√	SP0051,SP0058,SP0138
1997	Sintra	Infotainment System	Multi Info Display MID	√	√	√			

1997	Sintra	Infotainment System	Radio CAR 300	√	√	√			
1997	Sintra	Infotainment System	Radio CAR 400	√	√	√	√		
1997	Sintra	Infotainment System	Radio CDR 500	√	√	√	√		
1997	Sintra	Transmission	AF 13II/20/22/30	√	√	√	√		
1997	Tigra	Body	Immobiliser	√	√	√	√		
1997	Tigra	Body	Airbag S	√	√	√	√		
1997	Tigra	Body	Anti Theft Warning	√	√	√	√	√	
1997	Tigra	Chassis	ABS-5.3	√	√	√	√		
1997	Tigra	Engine	X14XE	√	√	√	√	√	
1997	Tigra	Engine	X16XE	√	√	√	√	√	SP0166,SP0195,SP0196,SP0197,SP0019,S P0201,SP0056
1997	Vauxhall VXR8	Body	Airbag-S	√	√	√	√		
1997	Vauxhall VXR8	Body	Anti Theft Warning	√	√	√	√	√	
1997	Vauxhall VXR8	Body	Immobiliser	√	√	√	√		SP0164,SP0165
1997	Vauxhall VXR8	Engine	X 14 XE	√	√	√	√	√	
1997	Vauxhall VXR8	Engine	X 16 XE	√	√	√	√	√	SP0166,SP0195,SP0196,SP0197,SP0019,S P0201,SP0056
1997	Vauxhall VXR8	Engine	ABS-5.3 (Anti-lock Braking System)	√	√	√	√		
1997	Vauxhall VXR8	Infotainment System	Radio CAR 300	√	√	√			
1997	Vauxhall VXR8	Infotainment System	Radio CAR 400	√	√	√	√		
1997	Vauxhall VXR8	Infotainment System	Radio CDR 500	√	√	√	√		
1997	Vauxhall VXR8	Transmission	AF 13/14/20	√	√	√	√		
1997	Vectra-B	Body	Immobiliser	√	√	√	√		
1997	Vectra-B	Body	Instrument	√	√	√	√		
1997	Vectra-B	Body	Airbag	√	√	√	√		
1997	Vectra-B	Body	Airbag SAB6	√	√	√	√		
1997	Vectra-B	Body	Add On Heater	√	√	√	√	√	SP0122,SP0123
1997	Vectra-B	Body	Anti Theft Warning	√	√	√	√	√	
1997	Vectra-B	Body	Electronic Climate Control	√	√	√	√		
1997	Vectra-B	Chassis	ABS 415	√	√	√	√		
1997	Vectra-B	Chassis	ABS-5-TC	√	√	√	√		
1997	Vectra-B	Chassis	Cruise Control	√	√	√	√		

1997	Vectra-B	Engine	X16SZR	√	√	√	√	√	
1997	Vectra-B	Engine	X16XEL	√	√	√	√	√	SP0166,SP0194,SP0195,SP0196,SP0197,S P0019
1997	Vectra-B	Engine	X18XE1	√	√	√	√	√	
1997	Vectra-B	Engine	20NEJ	√	√	√	√		
1997	Vectra-B	Engine	C20SEL	√	√	√	√	√	SP0166
1997	Vectra-B	Engine	X20DTL	√	√	√	√		
1997	Vectra-B	Engine	X20XEV	√	√	√	√	√	
1997	Vectra-B	Engine	16LZ2	√	√	√	√		
1997	Vectra-B	Engine	X18XE	√	√	√	√		SP0166,SP0202,SP0203,SP0204,SP0040
1997	Vectra-B	Engine	X25XE	√	√	√	√		
1997	Vectra-B	Infotainment System	Trip Info Display TID	√	√	√			
1997	Vectra-B	Infotainment System	Multi Info Dispaly MID	√	√	√			
1997	Vectra-B	Infotainment System	Radio CAR 300	√	√	√			
1997	Vectra-B	Infotainment System	Radio CAR 400	√	√	√	√		
1997	Vectra-B	Infotainment System	Radio CDR 500	√	√	√	√		
1997	Vectra-B	Transmission	AF 13II/20/22/30	√	√	√	√		