RENAULT Function List V9.00

Notes:

√	Functions is fully supported and already exited in former software version.
*	Functions is fully supported and newly added in current software version.
#	Functions is partially supported , which means the functions is verified on some vehcile models or systems and it might supports other vehcle models or
	Functions left with blank is not supported.

Vehilce	MODULENAME	ECU INFORMATION	Read Codes	Erase Codes	Live Data	Actuators	Fuction Test	Erase	Read Configuration	Write Configuration	Other Configuration
AVANTIME	A.B.S.	√	√	√	√	√	√			√	
AVANTIME	AIR CONDITIONING	√	√	√	√		√		√	√	
AVANTIME	AIRBAG / PRETENSIONERS	√	√	√	√		√		√		
AVANTIME	AUTOMATIC GEARBOX	√	√	√	√	√	√	√			
AVANTIME	Discharge Lamp	√	√	√	√	√					
AVANTIME	HEATER	√	√	√	√	√	√				
AVANTIME	INJECTION	√	√	√	√	√	√	√	√	√	
AVANTIME	Instrument panel	√	√	√	√	√	√		√	√	
AVANTIME	Lighting	√	√	√	√	√					
AVANTIME	UCH	√	√	√	√	√	√		√	√	
CAPTUR	4 WHEELS DRIVE	√	√	√	√	√	√	√		√	√
CAPTUR	AIR CONDITIONING	√	√	√	√	√	√	√		√	√
CAPTUR	AIRBAG / PRETENSIONERS	√	√	√	√	√	√	√	√		√
CAPTUR	HANDS-FREE MODULE	√	√	√	√	√	√	√	√	√	√
CAPTUR	INJECTION	√	√	√	√	√	√	√	√		√
CAPTUR	Instrument panel	√	√	√	√	√	√	√	√	√	√
CAPTUR	MULTIMEDIA INTERFACE	√	√	√	√	√	√	√		√	
CAPTUR	Radio	√	√	√	√	√	√	√	√	√	√
CAPTUR	Telematic ctrl unit	√	√	√	√	√	√	√	√		
CAPTUR	UCH	√	√	√	√	√	√	√	√	√	
CAPTUR	UPC	√	√	√	√	√	√	√	√	√	√
CAPTUR	VARIABLE P.A.S.	√	√	√	√		√	√			√
CAPTUR_QM3_KABIN	A.B.S.	√	√	√	√	√	√	√	√		√
CAPTUR_QM3_KABIN	AIR CONDITIONING	√	√	√	√	√	√	√	√		√
CAPTUR_QM3_KABIN	AIRBAG / PRETENSIONERS	√	√	√	√	√	√	√	√		√
CAPTUR_QM3_KABIN	AUTOMATIC GEARBOX	√	√	√	√	√	√	√			√
CAPTUR_QM3_KABIN	Amplifier	√	√	√	√	√	√	√	√	√	√
CAPTUR_QM3_KABIN	COMMUNICATIONS UNIT	√	√	√	√	√	√	√	√	√	
CAPTUR_QM3_KABIN	HANDS-FREE MODULE	√	√	√	√	√	√	√	√	√	√
CAPTUR_QM3_KABIN	INJECTION	√	√	√	√	√	√	√	√	√	√
CAPTUR_QM3_KABIN	Instrument panel	√	√	√	√	√	√	√	√	√	√
CAPTUR_QM3_KABIN	MULTIMEDIA INTERFACE	√	√	√	√	√	√	√		√	
CAPTUR_QM3_KABIN	PARKING PROX CAN	√	√	√	√	√	√	√	√	√	√
CAPTUR_QM3_KABIN	Radio	√	√	√	√	√	√	√	√	√	√
CAPTUR_QM3_KABIN	Telematic ctrl unit	√	√	√	√	√	√	√	√		√
CAPTUR_QM3_KABIN	UCH	√	√	√	√	√	√	√	√	√	√
CAPTUR_QM3_KABIN	UPC	√	√	√	√	√	√	√	√	√	√
CAPTUR_QM3_KABIN	VARIABLE P.A.S.	√	√	√	√	√	√	√			√
CLIO II	A.B.S.	√	√	√	√	√	√		√	√	
CLIO II	AIR CONDITIONING	√	√	√	√	√	√			√	
CLIO II	AIRBAG / PRETENSIONERS	√	√	√	√	√	√		√	√	
CLIO II	AUTOMATIC GEARBOX	√	√	√	√	√	√	√	√	√	
CLIO II	GAS INJ.	√	√	√	√	√	√		√		
CLIO II	INJECTION	√	√	√	√	√	√	√	√		√
CLIO II	INJECTION	√	√	√	√	√	√	√	√	√	
CLIO II	UCH	√	√	√	√	√	√		√	√	
CLIO II Ph 6	A.B.S.	√	√	√	√	√	√	√			√
CLIO II Ph 6	AIRBAG / PRETENSIONERS	√	√	√	√		√	√	√	√	√
CLIO II Ph 6	INJECTION	√	√	√	√	√	√	√			√
CLIO II Ph 6	INJECTION	√	√	√	√	√	√	√	√		√
CLIO II Ph 6	TRACKER	√	√	√	√		√	√	√	√	√
CLIO II Ph 6	UCH	√	√	√	√	√	√	√	√	√	√
CLIO III	A.B.S.	√	√	√	√	√	√	√			√
CLIO III	AIR CONDITIONING	√	√	√	√	√	√	√	√	√	√
CLIO III	AIRBAG / PRETENSIONERS	√	√	√	√		√	√	√	√	√
CLIO III	AUTOMATIC GEARBOX	√	√	√	√	√	√	√			√
CLIO III	COMMUNICATIONS UNIT	√	√	√	√	√	√	√	√	√	√
CLIO III	INJECTION	√	√	√	√	√	√	√	√		√
CLIO III	Instrument panel	√	√	√	√	√	√	√	√	√	√
CLIO III	Lighting	√	√	√	√	√	√	√	√	√	√
CLIO III	MULTIMED. CONNECTION	√	√	√	√		√	√		√	√
CLIO III	MULTIMEDIA INTERFACE	√	√	√	√	√	√	√	√	√	√
CLIO III	PARKING ASSISTANCE	√	√	√	√		√	√	√	√	√
CLIO III	Radio	√	√	√	√	√	√	√	√		√
CLIO III	TYRES	√	√	√	√		√	√	√	√	√
CLIO III	UCH	√	√	√	√	√	√	√	√	√	√
CLIO III	UPC	√	√	√	√	√	√	√	√		√
CLIO III	VARIABLE P.A.S.	√	√	√	√		√	√	√		√
CLIO IV	A.B.S.	√	√	√	√	√	√	√	√		√
CLIO IV	AIR CONDITIONING	√	√	√	√	√	√	√	√		√
CLIO IV	AIRBAG / PRETENSIONERS	√	√	√	√	√	√	√	√		√
CLIO IV	AUTOMATIC GEARBOX	√	√	√	√	√	√	√			√
CLIO IV	Amplifier	√	√	√	√	√	√	√	√	√	√
CLIO IV	COMMUNICATIONS UNIT	√	√	√	√	√	√	√	√	√	
CLIO IV	HANDS-FREE MODULE	√	√	√	√	√	√	√	√	√	√
CLIO IV	INJECTION	√	√	√	√	√	√	√	√	√	√
CLIO IV	Instrument panel	√	√	√	√	√	√	√	√	√	√
CLIO IV	MULTIMEDIA INTERFACE	√	√	√	√	√	√	√		√	
CLIO IV	PARKING PROX CAN	√	√	√	√	√	√	√	√	√	√
CLIO IV	Radio	√	√	√	√	√	√	√	√	√	√
CLIO IV	Telematic ctrl unit	√	√	√	√	√	√	√	√		√
CLIO IV	UCH	√	√	√	√	√	√	√	√	√	√
CLIO IV	UPC	√	√	√	√	√	√	√	√	√	√
CLIO IV	VARIABLE P.A.S.	√	√	√	√	√	√	√			√
CLIO V6	AIR CONDITIONING	√	√	√	√	√	√			√	
CLIO V6	AIRBAG / PRETENSIONERS	√	√	√	√	√	√		√	√	
CLIO V6	UCH	√	√	√	√	√				√	
CLIO V6 ph 2	AIR CONDITIONING	√	√	√	√	√					
CLIO V6 ph 2	AIRBAG / PRETENSIONERS	√	√	√	√				√	√	
CLIO V6 ph 2	UCH	√	√	√	√	√	√		√	√	
CLIOIIp2 3 4	A.B.S.	√	√	√	√	√	√		√	√	
CLIOIIp2 3 4	AIR CONDITIONING	√	√	√	√	√					
CLIOIIp2 3 4	AIRBAG / PRETENSIONERS	√	√	√	√				√	√	
CLIOIIp2_3_4	AUTOMATIC GEARBOX	√	√	√	√	√	√	√	√	√	
CLIOIIp2 3 4	Discharge Lamp	√	√	√	√	√					
CLIOIIp2 3 4	GAS INJ.	√	√	√	√	√	√		√		
CLIOIIp2_3_4	INJECTION	√	√	√	√	√	√	√	√		√
CLIOIIp2 3 4	INJECTION	√	√	√	√	√	√	√	√	√	
CLIOIIp2 3 4	Lighting	√	√	√	√	√					
CLIOIIp2 3 4	UCH	√	√	√	√	√	√		√	√	
CLIOIIp2 3 4	VARIABLE P.A.S.	√	√	√	√					√	
DOKKER KANGOO	A.B.S.	√	√	√	√	√	√	√	√		√
DOKKER KANGOO	AIRBAG / PRETENSIONERS	√	√	√	√	√	√	√	√		√
DOKKER KANGOO	HANDS-FREE MODULE	√	√	√	√	√	√	√	√	√	√
DOKKER KANGOO	INJECTION	√	√	√	√	√	√	√	√		√
DOKKER KANGOO	Instrument panel	√	√	√	√	√	√	√	√	√	√
DOKKER KANGOO	MULTIMEDIA INTERFACE	√	√	√	√	√	√	√		√	
DOKKER KANGOO	Radio	√	√	√	√	√	√	√	√	√	√

DOKKER KANGOO	Telematic ctrl unit	√	√	√	√	√	√	√	√		
DOKKER KANGOO	UCH	√	√	√	√	√	√	√	√	√	√
DOKKER KANGOO	VARIABLE P.A.S.	√	√	√	√		√	√			√
DUSTER	4 WHEELS DRIVE	√	√	√	√	√	√	√		√	√
DUSTER	A.B.S.	√	√	√	√	√	√	√			√
DUSTER	AIRBAG / PRETENSIONERS	√	√	√	√		√	√	√	√	√
DUSTER	AUTOMATIC GEARBOX	√	√	√	√	√	√	√			√
DUSTER	INJECTION	√	√	√	√	√	√	√	√		√
DUSTER	Radio	√	√	√	√	√	√	√	√	√	√
DUSTER	TRACKER	√	√	√	√		√	√	√	√	√
DUSTER	UCH	√	√	√	√	√	√	√	√	√	√
DUSTER	VARIABLE P.A.S.	√	√	√	√		√	√	√		√
Duster	4 WHEELS DRIVE	√	√	√	√	√	√	√		√	√
Duster	A.B.S.	√	√	√	√	√	√	√			√
Duster	AIRBAG / PRETENSIONERS	√	√	√	√		√	√	√	√	√
Duster	AUTOMATIC GEARBOX	√	√	√	√	√	√	√			√
Duster	INJECTION	√	√	√	√	√	√	√	√		√
Duster	Radio	√	√	√	√	√	√	√	√	√	√
Duster	TRACKER	√	√	√	√		√	√	√	√	√
Duster	UCH	√	√	√	√	√	√	√	√	√	√
Duster	VARIABLE P.A.S.	√	√	√	√		√	√	√		√
DUSTER II Ph	4 WHEELS DRIVE	√	√	√	√	√	√	√		√	√
DUSTER II Ph	A.B.S.	√	√	√	√	√	√	√	√		√
DUSTER II Ph	AIR CONDITIONING	√	√	√	√	√	√	√		√	√
DUSTER II Ph	AIRBAG / PRETENSIONERS	√	√	√	√	√	√	√	√		√
DUSTER II Ph	HANDS-FREE MODULE	√	√	√	√	√	√	√	√	√	√
DUSTER II Ph	INJECTION	√	√	√	√	√	√	√	√	√	√
DUSTER II Ph	MULTIMEDIA INTERFACE	√	√	√	√	√	√	√		√	
DUSTER II Ph	Radio	√	√	√	√	√	√	√	√	√	√
DUSTER II Ph	Telematic ctrl unit	√	√	√	√	√	√	√	√		
DUSTER II Ph	UCH	√	√	√	√	√	√	√	√	√	√
DUSTER II Ph	VARIABLE P.A.S.	√	√	√	√		√	√			√
ESPACE	A.B.S.	√	√	√	√	√	√			√	
ESPACE	AIR CONDITIONING	√	√	√	√		√		√	√	
ESPACE	AIRBAG / PRETENSIONERS	√	√	√	√	√	√			√	
ESPACE	AUTOMATIC GEARBOX	√	√	√	√	√	√	√	√	√	
ESPACE	Discharge Lamp	√	√	√	√	√					
ESPACE	HEATER	√	√	√	√	√	√				
ESPACE	INJECTION	√	√	√	√	√	√	√	√	√	
ESPACE	Instrument panel	√	√	√	√		√		√	√	
ESPACE	Lighting	√	√	√	√	√					
ESPACE	UCH	√	√	√	√	√	√		√	√	
ESPACE_IV	A.B.S.	√	√	√	√	√	√	√	√	√	√
ESPACE_IV	AIR CONDITIONING	√	√	√	√	√	√	√	√	√	√
ESPACE_IV	AIRBAG / PRETENSIONERS	√	√	√	√		√	√	√	√	√
ESPACE_IV	AUTOMATIC GEARBOX	√	√	√	√	√	√	√			√
ESPACE_IV	Discharge Lamp	√	√	√	√	√	√	√	√	√	√
ESPACE_IV	HANDS-FREE KIT	√	√	√	√	√	√	√	√	√	√
ESPACE_IV	HEATER	√	√	√	√	√	√	√			
ESPACE_IV	INJECTION	√	√	√	√	√	√	√	√		√
ESPACE_IV	INJECTION	√	√	√	√	√	√	√	√	√	√
ESPACE_IV	Instrument panel	√	√	√	√	√	√	√	√	√	√
ESPACE_IV	PARKING ASSISTANCE	√	√	√	√		√	√	√	√	√
ESPACE_IV	PARKING BRAKE	√	√	√	√	√	√	√	√	√	√
ESPACE_IV	UCH	√	√	√	√	√	√	√	√	√	√
ESPACE_V	4 WHEELS STEERING	√	√	√	√	√	√	√			√
ESPACE_V	A.B.S.	√	√	√	√	√	√	√	√	√	√
ESPACE_V	AIR CONDITIONING	√	√	√	√	√	√	√			√
ESPACE_V	AIRBAG / PRETENSIONERS	√	√	√	√	√	√	√	√	√	√
ESPACE_V	AUTOMATIC GEARBOX	√	√	√	√	√	√	√			√
ESPACE_V	Amplifier	√	√	√	√	√	√	√		√	√
ESPACE_V	DRIVER'S SEAT	√	√	√	√	√	√	√			√
ESPACE_V	FRONT RADAR	√	√	√	√		√	√			√
ESPACE_V	Front camera	√	√	√	√		√	√		√	√
ESPACE_V	GEARBOX ELEC CONTROL	√	√	√	√	√	√	√			√
ESPACE_V	HEAD UP DISPLAY	√	√	√		√		√			√
ESPACE_V	INJECTION	√	√	√	√	√	√	√	√		√
ESPACE_V	Instrument panel	√	√	√	√	√	√	√	√	√	√
ESPACE_V	LEFT-HAND DOOR or PASSENGER	√	√	√	√	√	√	√			√
ESPACE_V	MULTIMEDIA INTERFACE	√	√	√		√		√			√
ESPACE_V	PARKING BRAKE	√	√	√	√		√	√	√		√
ESPACE_V	PARKING PROX CAN	√	√	√	√	√	√	√	√	√	√
ESPACE_V	PILOTED SUSPENSION	√	√	√	√		√	√			√
ESPACE_V	POWER BACK DOOR	√	√	√	√		√	√		√	
ESPACE_V	RIGHT-HAND DOOR or COLLAPSI	√	√	√	√	√	√	√			√
ESPACE_V	Radio	√	√	√	√	√	√	√	√	√	√
ESPACE_V	Telematic ctrl unit	√	√	√	√	√	√	√	√		
ESPACE_V	UCH	√	√	√	√	√	√	√	√	√	√
ESPACE_V	UPC	√	√	√	√	√	√	√			√
ESPACE_V	VARIABLE P.A.S.	√	√	√	√		√	√			√
ESPACEIV_ph2_3_4	A.B.S.	√	√	√	√	√	√	√	√	√	√
ESPACEIV_ph2_3_4	AIR CONDITIONING	√	√	√	√	√	√	√	√	√	√
ESPACEIV_ph2_3_4	AIRBAG / PRETENSIONERS	√	√	√	√		√	√	√	√	√
ESPACEIV_ph2_3_4	AUTOMATIC GEARBOX	√	√	√	√	√	√	√			√
ESPACEIV_ph2_3_4	COMMUNICATIONS UNIT	√	√	√	√	√	√	√	√	√	√
ESPACEIV_ph2_3_4	HEATER	√	√	√	√	√	√	√			
ESPACEIV_ph2_3_4	INJECTION	√	√	√	√	√	√	√	√		√
ESPACEIV_ph2_3_4	INJECTION	√	√	√	√	√	√	√	√	√	√
ESPACEIV_ph2_3_4	Instrument panel	√	√	√	√	√	√	√	√	√	√
ESPACEIV_ph2_3_4	Lighting	√	√	√	√	√	√	√	√	√	√
ESPACEIV_ph2_3_4	MULTIMED. CONNECTION	√	√	√	√		√	√		√	√
ESPACEIV_ph2_3_4	MULTIMEDIA INTERFACE	√	√	√	√	√	√	√	√	√	√
ESPACEIV_ph2_3_4	PARKING ASSISTANCE	√	√	√	√		√	√	√	√	√
ESPACEIV_ph2_3_4	PARKING BRAKE	√	√	√	√	√	√	√	√	√	√
ESPACEIV_ph2_3_4	PARKING PROX CAN	√	√	√	√		√	√	√	√	√
ESPACEIV_ph2_3_4	Radio	√	√	√	√	√	√	√	√	√	√
ESPACEIV_ph2_3_4	UCH	√	√	√	√	√	√	√	√	√	√
ESPACEIV_ph2_3_4	VARIABLE P.A.S.	√	√	√	√		√	√			√
KADJAR	4 WHEELS DRIVE	√	√	√	√		√	√			
KADJAR	A.B.S.	√	√	√	√	√	√	√	√		√
KADJAR	AIR CONDITIONING	√	√	√	√	√	√	√			√
KADJAR	AIRBAG / PRETENSIONERS	√	√	√	√	√	√	√	√	√	√
KADJAR	AUTOMATIC GEARBOX	√	√	√	√	√	√	√			√
KADJAR	Amplifier	√	√	√	√	√	√	√		√	√
KADJAR	FRONT RADAR	√	√	√				√			√
KADJAR	Front camera	√	√	√	√		√	√		√	
KADJAR	INJECTION	√	√	√	√	√	√	√	√		√
KADJAR	Instrument panel	√	√	√	√	√	√	√	√	√	√
KADJAR	MULTIMEDIA INTERFACE	√	√	√				√			√
KADJAR	PARKING BRAKE	√	√	√	√		√	√	√		√
KADJAR	PARKING PROX CAN	√	√	√	√	√	√	√	√	√	√
KADJAR	Radio	√	√	√	√	√	√	√	√	√	√
KADJAR	Telematic ctrl unit	√	√	√	√	√	√	√	√		
KADJAR	UCH	√	√	√	√	√	√	√	√	√	√
KADJAR	UPC	√	√	√	√	√	√	√			√
KADJAR	VARIABLE P.A.S.	√	√	√	√		√	√			
KADJAR_CN	4 WHEELS DRIVE	√	√	√	√		√	√			
KADJAR_CN	A.B.S.	√	√	√	√	√	√	√	√		√

KADJAR_CN	AIR CONDITIONING	√	√	√	√	√	√	√			√
KADJAR_CN	AIRBAG / PRETENSIONERS	√	√	√	√	√	√	√	√	√	√
KADJAR_CN	AUTOMATIC GEARBOX	√	√	√	√		√	√			√
KADJAR_CN	Amplifier	√	√	√	√	√	√	√		√	√
KADJAR_CN	INJECTION	√	√	√	√	√	√	√	√		√
KADJAR_CN	Instrument panel	√	√	√	√	√	√	√	√	√	√
KADJAR_CN	MULTIMEDIA INTERFACE	√	√	√				√			√
KADJAR_CN	PARKING BRAKE	√	√	√	√		√	√	√		√
KADJAR_CN	PARKING PROX CAN	√	√	√	√	√	√	√	√	√	√
KADJAR_CN	Radio	√	√	√	√	√	√	√	√	√	√
KADJAR_CN	Telematic ctrl unit	√	√	√	√	√	√	√	√		
KADJAR_CN	UCH	√	√	√	√	√	√	√	√	√	√
KADJAR_CN	UPC	√	√	√	√	√	√	√			√
KADJAR_CN	VARIABLE P.A.S.	√	√	√	√		√	√			
KANGOO	A.B.S.	√	√	√	√	√	√			√	
KANGOO	AIR CONDITIONING	√	√	√	√	√	√			√	
KANGOO	AIRBAG / PRETENSIONERS	√	√	√	√	√	√		√	√	
KANGOO	AUTOMATIC GEARBOX	√	√	√	√	√	√	√	√	√	
KANGOO	GAS INJ.	√	√	√	√	√	√		√		
KANGOO	HEATER	√	√	√	√	√	√				
KANGOO	INJECTION	√	√	√	√	√	√	√	√		√
KANGOO	INJECTION	√	√	√	√	√	√	√	√	√	
KANGOO	INVERTER	√	√	√	√	√					
KANGOO	Supervisor or DCDC	√	√	√	√	√	√			√	
KANGOO	UCH	√	√	√	√	√	√			√	
KANGOO_II	A.B.S.	√	√	√	√	√	√	√			√
KANGOO_II	ADAPTATION UNIT	√	√	√	√		√	√			
KANGOO_II	AIR CONDITIONING	√	√	√	√	√	√	√	√	√	√
KANGOO_II	AIRBAG / PRETENSIONERS	√	√	√	√	√	√	√	√	√	√
KANGOO_II	AUTOMATIC GEARBOX	√	√	√	√	√	√	√			√
KANGOO_II	COMMUNICATIONS UNIT	√	√	√	√	√	√	√	√	√	√
KANGOO_II	INJECTION	√	√	√	√	√	√	√	√		√
KANGOO_II	Instrument panel	√	√	√	√	√	√	√	√	√	√
KANGOO_II	MULTIMED. CONNECTION	√	√	√	√		√	√		√	√
KANGOO_II	MULTIMEDIA INTERFACE	√	√	√	√	√	√	√	√	√	√
KANGOO_II	PARKING ASSISTANCE	√	√	√	√		√	√	√	√	√
KANGOO_II	Radio	√	√	√	√	√	√	√	√	√	√
KANGOO_II	TYRES	√	√	√				√			
KANGOO_II	Telematic ctrl unit	√	√	√	√	√	√	√	√	√	
KANGOO_II	UCH	√	√	√	√	√	√	√	√		√
KANGOO_II	UPC	√	√	√	√	√	√	√	√		√
KANGOO_II	VARIABLE P.A.S.	√	√	√	√		√	√	√	√	√
KANGOO_MUX	A.B.S.	√	√	√	√	√	√		√	√	
KANGOO_MUX	AIRBAG / PRETENSIONERS	√	√	√	√	√	√		√	√	
KANGOO_MUX	AUTOMATIC GEARBOX	√	√	√	√	√	√	√	√	√	
KANGOO_MUX	GAS INJ.	√	√	√	√	√	√		√		
KANGOO_MUX	INJECTION	√	√	√	√	√	√	√	√		√
KANGOO_MUX	INJECTION	√	√	√	√	√	√	√	√	√	
KANGOO_MUX	UCH	√	√	√	√	√	√		√	√	
KANGOO_VLL	A.B.S.	√	√	√	√	√	√	√			√
KANGOO_VLL	AIRBAG / PRETENSIONERS	√	√	√	√		√	√	√		√
KANGOO_VLL	INJECTION	√	√	√	√	√	√	√			√
KANGOO_VLL	INJECTION	√	√	√	√	√	√	√	√		√
KANGOO_VLL	TRACKER	√	√	√	√		√	√	√	√	√
KANGOO_VLL	UCH	√	√	√	√	√	√	√	√	√	√
KANGOO_VLL	VARIABLE P.A.S.	√	√	√	√			√			√
KANGOO_Z.E.	A.B.S.	√	√	√	√	√	√	√	√		√
KANGOO_Z.E.	ADAPTATION UNIT	√	√	√	√		√	√			
KANGOO_Z.E.	AIR CONDITIONING	√	√	√	√	√	√	√	√	√	√
KANGOO_Z.E.	AIRBAG / PRETENSIONERS	√	√	√	√	√	√	√	√	√	√
KANGOO_Z.E.	AUTOMATIC GEARBOX	√	√	√	√	√	√	√			√
KANGOO_Z.E.	BCB	√	√	√	√	√	√	√			
KANGOO_Z.E.	BMS	√	√	√	√		√	√			√
KANGOO_Z.E.	BMS safety	√	√	√	√		√	√			√
KANGOO_Z.E.	CHARGE CONTROLLER	√	√	√	√		√	√			
KANGOO_Z.E.	COMMUNICATIONS UNIT	√	√	√	√	√	√	√	√	√	√
KANGOO_Z.E.	EVC	√	√	√	√	√	√	√	√	√	√
KANGOO_Z.E.	HEATER	√	√	√	√		√	√			
KANGOO_Z.E.	INJECTION	√	√	√	√	√	√	√	√		√
KANGOO_Z.E.	Instrument panel	√	√	√	√	√	√	√		√	√
KANGOO_Z.E.	MULTIMED. CONNECTION	√	√	√	√	√	√	√			√
KANGOO_Z.E.	MULTIMEDIA INTERFACE	√	√	√	√	√	√	√		√	
KANGOO_Z.E.	PARKING ASSISTANCE	√	√	√	√	√	√	√	√	√	
KANGOO_Z.E.	PARKING PROX CAN	√	√	√	√	√	√	√	√	√	√
KANGOO_Z.E.	PEB	√	√	√	√		√	√			
KANGOO_Z.E.	Radio	√	√	√	√	√	√	√	√	√	√
KANGOO_Z.E.	TYRES	√	√	√	√		√	√			
KANGOO_Z.E.	Telematic ctrl unit	√	√	√	√	√	√	√	√		√
KANGOO_Z.E.	UCH	√	√	√	√	√	√	√	√	√	
KANGOO_Z.E.	UPC	√	√	√	√	√	√	√	√	√	√
KANGOO_Z.E.	VARIABLE P.A.S.	√	√	√	√		√	√	√	√	√
KOLEOS_II_QM6	4 WHEELS DRIVE	√	√	√	√		√	√			
KOLEOS_II_QM6	A.B.S.	√	√	√	√	√	√	√	√		√
KOLEOS_II_QM6	AIR CONDITIONING	√	√	√	√	√	√	√			√
KOLEOS_II_QM6	AIRBAG / PRETENSIONERS	√	√	√	√	√	√	√	√	√	√
KOLEOS_II_QM6	AUTOMATIC GEARBOX	√	√	√	√		√	√			√
KOLEOS_II_QM6	Amplifier	√	√	√	√	√	√	√		√	√
KOLEOS_II_QM6	FRONT RADAR	√	√	√				√			√
KOLEOS_II_QM6	Front camera	√	√	√	√		√	√		√	
KOLEOS_II_QM6	INJECTION	√	√	√	√	√	√	√	√		√
KOLEOS_II_QM6	Instrument panel	√	√	√	√	√	√	√	√	√	√
KOLEOS_II_QM6	MULTIMEDIA INTERFACE	√	√	√	√	√	√	√			√
KOLEOS_II_QM6	PARKING BRAKE	√	√	√	√		√	√	√		√
KOLEOS_II_QM6	PARKING PROX CAN	√	√	√	√	√	√	√	√	√	√
KOLEOS_II_QM6	POWER BACK DOOR	√	√	√	√		√	√		√	
KOLEOS_II_QM6	Radio	√	√	√	√	√	√	√	√	√	√
KOLEOS_II_QM6	Telematic ctrl unit	√	√	√	√	√	√	√	√		
KOLEOS_II_QM6	UCH	√	√	√	√	√	√	√	√	√	√
KOLEOS_II_QM6	UPC	√	√	√	√	√	√	√			√
KOLEOS_II_QM6	VARIABLE P.A.S.	√	√	√	√		√	√			
KOLEOS_QM5	4 WHEELS DRIVE	√	√	√	√		√	√			
KOLEOS_QM5	A.B.S.	√	√	√	√	√	√	√			√
KOLEOS_QM5	AIRBAG / PRETENSIONERS	√	√	√	√		√	√			
KOLEOS_QM5	AUTO FRONT LIGHTING	√	√	√	√	√	√	√			√
KOLEOS_QM5	AUTOMATIC GEARBOX	√	√	√	√		√	√			√
KOLEOS_QM5	Amplifier	√	√	√	√	√	√	√	√	√	√
KOLEOS_QM5	Blind spot detection	√	√	√	√	√	√	√		√	√
KOLEOS_QM5	COMMUNICATIONS UNIT	√	√	√	√	√	√	√	√	√	√
KOLEOS_QM5	Discharge Lamp	√	√	√	√	√	√	√			√
KOLEOS_QM5	INJECTION	√	√	√	√	√	√	√	√		√
KOLEOS_QM5	Instrument panel	√	√	√	√		√	√	√	√	√
KOLEOS_QM5	MULTIMED. CONNECTION	√	√	√	√		√	√		√	√
KOLEOS_QM5	MULTIMEDIA INTERFACE	√	√	√	√	√	√	√	√	√	√
KOLEOS_QM5	PARKING BRAKE	√	√	√	√	√	√	√	√	√	√
KOLEOS_QM5	PARKING PROX CAN	√	√	√	√		√	√	√	√	√
KOLEOS_QM5	Radio	√	√	√	√	√	√	√	√	√	√
KOLEOS_QM5	TYRES	√	√	√	√	√	√	√		√	√
KOLEOS_QM5	Telematic ctrl unit	√	√	√	√	√	√	√	√	√	

KOLEOS_QM5	UCH	√	√	√	√	√	√	√	√	√	√
KOLEOS_QM5	UPC	√	√	√	√	√	√	√			
KOLEOS_QM5	VARIABLE P.A.S.	√	√	√	√		√	√			
KWID	AIRBAG / PRETENSIONERS	√	√	√	√	√	√	√	√		√
KWID	INJECTION	√	√	√	√	√	√	√			√
KWID	Instrument panel	√	√	√	√	√	√	√	√	√	√
KWID	Radio	√	√	√	√	√	√	√	√	√	√
KWID	UCH	√	√	√	√	√	√	√			
KWID	VARIABLE P.A.S.	√	√	√	√		√	√			
LAGUNA	A.B.S.	√	√	√	√	√	√			√	
LAGUNA	AIR CONDITIONING	√	√	√	√		√				
LAGUNA	AIRBAG / PRETENSIONERS	√	√	√	√	√	√			√	
LAGUNA	AUTOMATIC GEARBOX	√	√	√	√	√	√			√	
LAGUNA	DRIVER'S SEAT	√	√	√	√	√	√			√	
LAGUNA	INJECTION	√	√	√	√	√	√		√	√	
LAGUNA	Instrument panel	√	√	√	√		√		√	√	
LAGUNA	UCH	√	√	√	√	√	√			√	
LAGUNA	VARIABLE P.A.S.	√	√	√	√	√	√			√	
LAGUNA	Voice synthesiser	√	√	√	√		√		√	√	
LAGUNA_II	A.B.S.	√	√	√	√	√	√	√	√	√	√
LAGUNA_II	AIR CONDITIONING	√	√	√	√	√	√	√	√	√	√
LAGUNA_II	AIRBAG / PRETENSIONERS	√	√	√	√		√	√	√	√	√
LAGUNA_II	AUTOMATIC GEARBOX	√	√	√	√	√	√	√	√	√	√
LAGUNA_II	Discharge Lamp	√	√	√	√	√	√	√	√	√	√
LAGUNA_II	GAS INJ.	√	√	√	√	√	√	√	√		
LAGUNA_II	HEATER	√	√	√	√	√	√	√			
LAGUNA_II	INJECTION	√	√	√	√	√	√	√	√	√	√
LAGUNA_II	Instrument panel	√	√	√	√		√	√	√	√	√
LAGUNA_II	Instrument panel	√	√	√	√	√	√	√	√	√	√
LAGUNA_II	PARKING ASSISTANCE	√	√	√	√		√	√	√	√	√
LAGUNA_II	UCH	√	√	√	√	√	√	√	√	√	√
LAGUNA_III	4 WHEELS STEERING	√	√	√	√	√	√	√			√
LAGUNA_III	A.B.S.	√	√	√	√	√	√	√	√		√
LAGUNA_III	AIR CONDITIONING	√	√	√	√	√	√	√	√	√	√
LAGUNA_III	AIRBAG / PRETENSIONERS	√	√	√	√		√	√	√	√	√
LAGUNA_III	AUTOMATIC GEARBOX	√	√	√	√	√	√	√	√		√
LAGUNA_III	Amplifier	√	√	√	√	√	√	√	√	√	√
LAGUNA_III	COMMUNICATIONS UNIT	√	√	√	√	√	√	√	√	√	√
LAGUNA_III	DRIVER'S SEAT	√	√	√	√		√	√			√
LAGUNA_III	Driver's door	√	√	√	√	√	√	√			√
LAGUNA_III	INJECTION	√	√	√	√	√	√	√	√		√
LAGUNA_III	Instrument panel	√	√	√	√	√	√	√	√	√	√
LAGUNA_III	LEFT-HAND DOOR or PASSENGER	√									√
LAGUNA_III	Lighting	√	√	√	√	√	√	√	√		√
LAGUNA_III	MULTIMED. CONNECTION	√	√	√	√	√	√	√			√
LAGUNA_III	MULTIMEDIA INTERFACE	√	√	√	√	√	√	√	√	√	√
LAGUNA_III	PARKING BRAKE	√	√	√	√	√	√	√	√		√
LAGUNA_III	PARKING PROX CAN	√	√	√	√	√	√	√	√	√	√
LAGUNA_III	Passenger's door	√	√	√	√	√	√	√			√
LAGUNA_III	RIGHT-HAND DOOR or COLLAPSI	√								√	√
LAGUNA_III	Radio	√	√	√	√	√	√	√	√	√	√
LAGUNA_III	Telematic ctrl unit	√	√	√	√	√	√	√			
LAGUNA_III	UCH	√	√	√	√	√	√	√	√	√	√
LAGUNA_III	UPC	√	√	√	√	√	√	√	√	√	√
LAGUNA_III	VARIABLE P.A.S.	√	√	√	√		√	√			√
LAGUNA_phase_2	A.B.S.	√	√	√	√	√	√			√	
LAGUNA_phase_2	AIR CONDITIONING	√	√	√	√		√				
LAGUNA_phase_2	AIRBAG / PRETENSIONERS	√	√	√	√	√	√		√	√	
LAGUNA_phase_2	AUTOMATIC GEARBOX	√	√	√	√	√	√			√	
LAGUNA_phase_2	DRIVER'S SEAT	√	√	√	√	√	√			√	
LAGUNA_phase_2	GAS INJ.	√	√	√	√	√	√		√		
LAGUNA_phase_2	INJECTION	√	√	√	√	√	√		√	√	
LAGUNA_phase_2	Instrument panel	√	√	√	√		√		√	√	
LAGUNA_phase_2	UCH	√	√	√	√	√	√			√	
LAGUNA_phase_2	VARIABLE P.A.S.	√	√	√	√	√	√			√	
LAGUNA_phase_2	Voice synthesiser	√	√	√	√		√		√	√	
LAGUNAII_ph2	A.B.S.	√	√	√	√	√	√	√	√	√	√
LAGUNAII_ph2	AIR CONDITIONING	√	√	√	√	√	√	√	√	√	√
LAGUNAII_ph2	AIRBAG / PRETENSIONERS	√	√	√	√		√	√	√	√	√
LAGUNAII_ph2	AUTOMATIC GEARBOX	√	√	√	√	√	√	√			√
LAGUNAII_ph2	COMMUNICATIONS UNIT	√	√	√	√	√	√	√	√	√	√
LAGUNAII_ph2	HANDS-FREE KIT	√	√	√	√	√	√	√	√	√	√
LAGUNAII_ph2	HEATER	√	√	√	√	√	√	√			
LAGUNAII_ph2	INJECTION	√	√	√	√	√	√	√	√	√	√
LAGUNAII_ph2	Instrument panel	√	√	√	√	√	√	√	√	√	√
LAGUNAII_ph2	Lighting	√	√	√	√	√	√	√	√	√	√
LAGUNAII_ph2	PARKING ASSISTANCE	√	√	√	√		√	√	√	√	√
LAGUNAII_ph2	PARKING BRAKE	√	√	√	√	√	√	√	√	√	√
LAGUNAII_ph2	Radio	√									
LAGUNAII_ph2	UCH	√	√	√	√	√	√	√	√	√	√
LATITUDE_SM5	A.B.S.	√	√	√	√	√	√	√	√		√
LATITUDE_SM5	AIR CONDITIONING	√	√	√	√	√	√	√	√	√	√
LATITUDE_SM5	AIRBAG / PRETENSIONERS	√	√	√	√		√	√	√	√	√
LATITUDE_SM5	AUTOMATIC GEARBOX	√	√	√	√	√	√	√			√
LATITUDE_SM5	Amplifier	√	√	√	√	√		√	√	√	√
LATITUDE_SM5	Blind spot detection	√	√	√	√	√	√	√			√
LATITUDE_SM5	COMMUNICATIONS UNIT	√	√	√	√	√	√	√	√	√	√
LATITUDE_SM5	DRIVER'S SEAT	√	√	√	√		√	√			√
LATITUDE_SM5	Driver's door	√	√	√	√	√	√	√			
LATITUDE_SM5	INJECTION	√	√	√	√	√	√	√	√		√
LATITUDE_SM5	Instrument panel	√	√	√	√	√	√	√	√	√	√
LATITUDE_SM5	LEFT-HAND DOOR or PASSENGER	√			√		√				√
LATITUDE_SM5	Lighting	√	√	√	√	√	√	√	√		√
LATITUDE_SM5	MULTIMED. CONNECTION	√	√	√	√		√	√			√
LATITUDE_SM5	MULTIMEDIA INTERFACE	√	√	√	√	√	√	√	√	√	
LATITUDE_SM5	PARKING BRAKE	√	√	√	√	√	√	√	√		√
LATITUDE_SM5	PARKING PROX CAN	√	√	√	√	√	√	√	√	√	√
LATITUDE_SM5	Passenger's door	√	√	√	√	√	√	√			
LATITUDE_SM5	RIGHT-HAND DOOR or COLLAPSI	√			√		√				√
LATITUDE_SM5	Radio	√	√	√	√	√	√	√	√	√	√
LATITUDE_SM5	Telematic ctrl unit	√	√	√	√	√	√	√			√
LATITUDE_SM5	UCH	√	√	√	√	√	√	√	√	√	√
LATITUDE_SM5	UPC	√	√	√	√	√	√	√	√	√	√
LATITUDE_SM5	VARIABLE P.A.S.	√	√	√	√		√	√			√
LODGY	A.B.S.	√	√	√	√	√	√	√	√		√
LODGY	AIRBAG / PRETENSIONERS	√	√	√	√	√	√	√	√		√
LODGY	HANDS-FREE MODULE	√	√	√	√	√	√	√	√	√	√
LODGY	INJECTION	√	√	√	√	√	√	√	√		√
LODGY	Instrument panel	√	√	√	√	√	√	√	√	√	√
LODGY	Radio	√	√	√	√	√	√	√	√	√	√
LODGY	UCH	√	√	√	√	√	√	√	√	√	√
LODGY	VARIABLE P.A.S.	√	√	√	√		√	√			√
LOGAN	A.B.S.	√	√	√	√	√	√	√			√
LOGAN	AIRBAG / PRETENSIONERS	√	√	√	√		√	√	√	√	√
LOGAN	AUTOMATIC GEARBOX	√	√	√	√	√	√	√			√
LOGAN	GAS INJ.	√	√	√	√	√	√		√		√
LOGAN	INJECTION	√	√	√	√	√	√	√	√		√
LOGAN	Radio	√	√	√	√	√	√	√	√	√	√

LOGAN	TRACKER	√	√	√	√		√	√	√	√	√
LOGAN	UCH	√	√	√	√	√	√	√	√	√	√
LOGAN	VARIABLE P.A.S.	√	√	√	√		√	√	√		√
LOGAN II SANDERO II	A.B.S.	√	√	√	√	√	√	√	√		√
LOGAN II SANDERO II	AIR CONDITIONING	√	√	√	√	√	√	√	√		√
LOGAN II SANDERO II	AIRBAG / PRETENSIONERS	√	√	√	√	√	√	√	√		√
LOGAN II SANDERO II	AUTOMATIC GEARBOX	√	√	√	√	√	√	√			
LOGAN_II_SANDERO_II	HANDS-FREE MODULE	√	√	√	√	√	√	√	√	√	√
LOGAN II SANDERO II	INJECTION	√	√	√	√	√	√	√	√	√	√
LOGAN II SANDERO II	Instrument panel	√	√	√	√	√	√	√	√	√	√
LOGAN_II_SANDERO_II	MULTIMEDIA INTERFACE	√	√	√	√	√	√	√		√	
LOGAN II SANDERO II	Radio	√	√	√	√	√	√	√	√	√	√
LOGAN II SANDERO II	TRACKER	√	√	√	√		√	√	√	√	√
LOGAN_II_SANDERO_II	Telematic ctrl unit	√	√	√	√	√	√	√	√		
LOGAN II SANDERO II	UCH	√	√	√	√	√	√	√	√	√	√
LOGAN II SANDERO II	VARIABLE P.A.S.	√	√	√	√		√	√			√
MAST_RWD_ph2	A.B.S.	√	√	√	√	√	√			√	
MAST RWD ph2	ADAPTATION UNIT	√	√	√	√						
MAST RWD ph2	AIRBAG / PRETENSIONERS	√	√	√	√		√		√		
MAST RWD ph2	INJECTION	√	√	√	√	√	√	√	√		
MAST RWD ph2	UCH	√	√	√	√	√	√		√	√	
MAST RWD ph3	A.B.S.	√	√	√	√	√	√	√	√		√
MAST RWD ph3	ADAPTATION UNIT	√	√	√	√		√	√			
MAST_RWD_ph3	AIRBAG / PRETENSIONERS	√	√	√	√		√	√	√		√
MAST RWD ph3	COMMUNICATIONS UNIT	√	√	√	√	√	√	√	√		√
MAST RWD ph3	INJECTION	√	√	√	√	√	√	√	√		√
MAST_RWD_ph3	UCH	√	√	√	√	√	√	√	√	√	√
MASTER	A.B.S.	√	√	√	√	√					
MASTER	AIRBAG / PRETENSIONERS	√	√	√	√	√	√		√	√	
MASTER	INJECTION	√	√	√	√	√	√	√	√	√	
MASTER	PILOTED SUSPENSION	√	√	√	√		√			√	
MASTER	UCH	√	√	√	√	√	√			√	
MASTER III	A.B.S.	√	√	√	√	√	√	√	√	√	√
MASTER III	ADAPTATION UNIT	√	√	√				√			
MASTER III	ADAPTATION UNIT	√	√	√	√		√	√			
MASTER III	AIR CONDITIONING	√	√	√	√	√	√	√			√
MASTER_III	AIR CONDITIONING	√	√	√	√	√	√	√	√		√
MASTER III	AIRBAG / PRETENSIONERS	√	√	√	√		√	√	√	√	√
MASTER III	AUTOMATIC GEARBOX	√	√	√	√	√	√	√			√
MASTER_III	COMMUNICATIONS UNIT	√	√	√	√	√	√	√	√	√	√
MASTER III	Front camera	√	√	√	√		√	√			
MASTER III	HANDS-FREE ACCESS	√	√	√	√	√	√	√			√
MASTER_III	INJECTION	√	√	√	√	√	√	√	√		√
MASTER III	Instrument panel	√	√	√	√	√	√	√		√	√
MASTER III	Lighting	√	√	√	√	√	√	√			
MASTER_III	MULTIMED. CONNECTION	√	√	√	√	√	√	√			√
MASTER III	MULTIMEDIA INTERFACE	√	√	√	√	√	√	√		√	√
MASTER III	PARKING ASSISTANCE	√	√	√	√	√	√	√	√	√	
MASTER III	Radio	√	√	√	√	√	√	√	√	√	
MASTER III	Radio	√	√	√	√	√	√	√	√	√	√
MASTER III	TRACKER	√	√	√	√		√	√	√	√	√
MASTER III	TYRES	√	√	√	√		√	√			
MASTER III	Telematic ctrl unit	√	√	√	√	√	√	√	√		√
MASTER III	UCH	√	√	√	√	√	√	√	√	√	√
MASTER III	UPC	√	√	√	√	√	√	√	√	√	√
MASTER_III	UREA DOSING CONTROL MODULE	√	√	√	√	√	√	√			√
MASTER III	VARIABLE P.A.S.	√	√	√	√		√	√	√	√	√
MASTER ph 2	A.B.S.	√	√	√	√	√	√				
MASTER_ph_2	ADAPTATION UNIT	√	√	√	√						
MASTER ph 2	AIRBAG / PRETENSIONERS	√	√	√	√		√		√		
MASTER ph 2	AUTOMATIC GEARBOX	√	√	√	√	√	√	√			
MASTER_ph_2	INJECTION	√	√	√	√	√	√	√	√	√	
MASTER ph 2	PARKING ASSISTANCE	√	√	√	√				√	√	
MASTER ph 2	PARKING PROX CAN	√	√	√	√				√	√	
MASTER ph 2	PILOTED SUSPENSION	√	√	√	√		√			√	
MASTER ph 2	UCH	√	√	√	√	√	√		√	√	
MASTER ph 3	A.B.S.	√	√	√	√	√	√	√	√		√
MASTER ph 3	ADAPTATION UNIT	√	√	√	√		√	√			
MASTER_ph_3	AIRBAG / PRETENSIONERS	√	√	√	√		√	√	√		√
MASTER ph 3	AUTOMATIC GEARBOX	√	√	√	√	√	√	√			√
MASTER ph 3	COMMUNICATIONS UNIT	√	√	√	√	√	√	√	√		√
MASTER_ph_3	INJECTION	√	√	√	√	√	√	√	√		√
MASTER ph 3	INJECTION	√	√	√	√	√	√	√	√	√	√
MASTER ph 3	PARKING ASSISTANCE	√	√	√	√		√	√	√	√	√
MASTER_ph_3	PILOTED SUSPENSION	√	√	√	√	√	√	√			
MASTER ph 3	TRACKER	√	√	√	√		√	√	√	√	√
MASTER ph 3	UCH	√	√	√	√	√	√	√	√	√	√
MASTER RWD	AIRBAG / PRETENSIONERS	√	√	√	√	√	√		√	√	
MASTER RWD	INJECTION	√		√	√						
MASTER RWD	UCH	√	√	√	√	√	√			√	
MEGANE II	A.B.S.	√	√	√	√	√	√	√			√
MEGANE II	AIR CONDITIONING	√	√	√	√		√	√	√	√	√
MEGANE II	AIRBAG / PRETENSIONERS	√	√	√	√		√	√	√	√	√
MEGANE II	AUTOMATIC GEARBOX	√	√	√	√	√	√	√			√
MEGANE II	COMMUNICATIONS UNIT	√	√	√	√	√	√	√	√		√
MEGANE II	Discharge Lamp	√	√	√	√		√	√	√	√	√
MEGANE II	GAS INJ.	√	√	√	√	√	√	√	√		√
MEGANE II	INJECTION	√	√	√	√	√	√	√	√	√	√
MEGANE II	Instrument panel	√	√	√	√	√	√	√	√	√	√
MEGANE II	Left COSLAD	√	√	√	√	√	√	√	√	√	√
MEGANE II	Lighting	√	√	√	√	√	√	√	√	√	√
MEGANE II	PARKING ASSISTANCE	√	√	√	√		√	√	√	√	√
MEGANE II	Right COSLAD	√	√	√	√	√	√	√	√	√	√
MEGANE II	SUNROOF CONTROL UNIT	√	√	√	√	√	√	√	√	√	√
MEGANE II	TRACKER	√	√	√	√		√	√	√	√	√
MEGANE II	UCH	√	√	√	√	√	√	√	√	√	√
MEGANE II	UPC	√	√	√	√	√	√	√	√	√	√
MEGANE_II	VARIABLE P.A.S.	√	√	√	√		√	√	√	√	√
MEGANE IV	4 WHEELS STEERING	√	√	√	√	√	√	√			√
MEGANE IV	A.B.S.	√	√	√	√	√	√	√	√	√	√
MEGANE_IV	AIR CONDITIONING	√	√	√	√	√	√	√			√
MEGANE IV	AIRBAG / PRETENSIONERS	√	√	√	√	√	√	√	√	√	√
MEGANE IV	AUTOMATIC GEARBOX	√	√	√	√	√	√	√			√
MEGANE_IV	Amplifier	√	√	√	√	√	√	√		√	√
MEGANE IV	BMS	√	√	√	√	√	√	√			√
MEGANE IV	BMS safety	√	√	√				√			√
MEGANE_IV	DRIVER'S SEAT	√	√	√	√	√	√	√			√
MEGANE IV	FRONT RADAR	√	√	√	√		√	√			√
MEGANE IV	Front camera	√	√	√	√		√	√		√	√
MEGANE_IV	HEAD UP DISPLAY	√	√	√		√		√			√
MEGANE IV	INJECTION	√	√	√	√	√	√	√	√		√
MEGANE IV	Instrument panel	√	√	√	√	√	√	√	√	√	√
MEGANE IV	LEFT-HAND DOOR or PASSENGER	√	√	√	√	√	√	√			√
MEGANE IV	MULTIMEDIA INTERFACE	√	√	√	√	√	√	√			√
MEGANE IV	PARKING BRAKE	√	√	√	√		√	√	√		√
MEGANE IV	PARKING PROX CAN	√	√	√	√	√	√	√	√	√	√
MEGANE_IV	PEB	√	√	√	√		√	√			
MEGANE IV	Radio	√	√	√	√	√	√	√	√	√	√

MEGANE_IV	Supervisor or DCDC	√	√	√	√	√	√	√			
MEGANE_IV	Telematic ctrl unit	√	√	√	√	√	√	√	√		
MEGANE_IV	UCH	√	√	√	√	√	√	√	√	√	√
MEGANE_IV	UPC	√	√	√	√	√	√	√			√
MEGANE_IV	VARIABLE P.A.S.	√	√	√	√		√	√			√
MEGANE_SCEN.	A.B.S.	√	√	√	√	√	√			√	
MEGANE_SCEN.	AIR CONDITIONING	√	√	√	√	√	√		√	√	
MEGANE_SCEN.	AIRBAG / PRETENSIONERS	√	√	√	√	√	√		√	√	
MEGANE_SCEN.	AUTOMATIC GEARBOX	√	√	√	√	√	√	√	√	√	
MEGANE_SCEN.	DRIVER'S SEAT	√	√	√	√	√	√			√	
MEGANE_SCEN.	GAS INJ.	√	√	√	√	√	√				
MEGANE_SCEN.	INJECTION	√	√	√	√	√	√	√	√	√	
MEGANE_SCEN.	SUNROOF CONTROL UNIT	√	√	√	√	√	√				
MEGANE_SCEN.	TYRES	√	√	√	√	√		√	√	√	
MEGANEIII_SCENICIII	A.B.S.	√	√	√	√	√	√	√	√		√
MEGANEIII_SCENICIII	AIR CONDITIONING	√	√	√	√	√	√	√	√		√
MEGANEIII_SCENICIII	AIRBAG / PRETENSIONERS	√	√	√	√		√	√	√	√	√
MEGANEIII_SCENICIII	AUTOMATIC GEARBOX	√	√	√	√	√	√	√			√
MEGANEIII_SCENICIII	COMMUNICATIONS UNIT	√	√	√	√	√	√	√	√	√	√
MEGANEIII_SCENICIII	DRIVER'S SEAT	√	√	√	√		√	√			√
MEGANEIII_SCENICIII	Driver's door	√	√	√	√	√	√	√			√
MEGANEIII_SCENICIII	Front camera	√	√	√	√		√	√		√	
MEGANEIII_SCENICIII	INJECTION	√	√	√	√	√	√	√	√		√
MEGANEIII_SCENICIII	Instrument panel	√	√	√	√	√	√	√	√	√	√
MEGANEIII_SCENICIII	MULTIMED. CONNECTION	√	√	√	√	√	√	√			√
MEGANEIII_SCENICIII	MULTIMEDIA INTERFACE	√	√	√	√	√	√	√		√	√
MEGANEIII_SCENICIII	PARKING BRAKE	√	√	√	√	√	√	√	√		√
MEGANEIII_SCENICIII	PARKING PROX CAN	√	√	√	√	√	√	√	√	√	√
MEGANEIII_SCENICIII	Passenger's door	√	√	√	√		√	√			√
MEGANEIII_SCENICIII	Radio	√	√	√	√	√	√	√	√	√	√
MEGANEIII_SCENICIII	SUNROOF CONTROL UNIT	√	√	√	√	√	√	√			√
MEGANEIII_SCENICIII	Telematic ctrl unit	√	√	√	√	√	√	√	√		√
MEGANEIII_SCENICIII	UCH	√	√	√	√	√	√	√	√	√	√
MEGANEIII_SCENICIII	UPC	√	√	√	√	√	√	√		√	√
MEGANEIII_SCENICIII	VARIABLE P.A.S.	√	√	√	√	√	√	√			√
MODUS	A.B.S.	√	√	√	√	√	√	√			√
MODUS	AIR CONDITIONING	√	√	√	√	√	√	√	√	√	√
MODUS	AIRBAG / PRETENSIONERS	√	√	√	√		√	√	√	√	√
MODUS	AUTOMATIC GEARBOX	√	√	√	√	√	√	√			√
MODUS	HANDS-FREE KIT	√	√	√	√	√	√	√	√	√	√
MODUS	INJECTION	√	√	√	√	√	√	√	√		√
MODUS	Instrument panel	√	√	√	√	√	√	√	√	√	√
MODUS	Lighting	√	√	√	√	√	√	√	√	√	√
MODUS	PARKING ASSISTANCE	√	√	√	√		√	√	√	√	√
MODUS	TYRES	√	√	√	√		√	√	√	√	√
MODUS	UCH	√	√	√	√	√	√	√	√	√	√
MODUS	UPC	√	√	√	√	√	√	√	√		√
MODUS	VARIABLE P.A.S.	√	√	√	√		√	√	√		√
NEW_SM3_FLUENCE_MEGANE	A.B.S.	√	√	√	√	√	√	√	√		√
NEW_SM3_FLUENCE_MEGANE	AIR CONDITIONING	√	√	√	√	√	√	√	√		√
NEW_SM3_FLUENCE_MEGANE	AIRBAG / PRETENSIONERS	√	√	√	√		√	√	√	√	√
NEW_SM3_FLUENCE_MEGANE	AUTOMATIC GEARBOX	√	√	√	√	√	√	√			√
NEW_SM3_FLUENCE_MEGANE	Amplifier	√	√	√	√	√	√	√	√	√	√
NEW_SM3_FLUENCE_MEGANE	BCB	√	√	√	√	√	√	√	√	√	
NEW_SM3_FLUENCE_MEGANE	BMS	√	√	√	√		√	√			√
NEW_SM3_FLUENCE_MEGANE	BMS safety	√	√	√	√		√	√			√
NEW_SM3_FLUENCE_MEGANE	Blind spot detection	√	√	√	√	√	√	√			√
NEW_SM3_FLUENCE_MEGANE	COMMUNICATIONS UNIT	√	√	√	√	√	√	√	√	√	√
NEW_SM3_FLUENCE_MEGANE	Driver's door	√	√	√	√	√	√	√			√
NEW_SM3_FLUENCE_MEGANE	EVC	√	√	√	√	√	√	√	√	√	√
NEW_SM3_FLUENCE_MEGANE	INJECTION	√	√	√	√	√	√	√	√	√	√
NEW_SM3_FLUENCE_MEGANE	Instrument panel	√	√	√	√	√	√	√	√	√	√
NEW_SM3_FLUENCE_MEGANE	MULTIMED. CONNECTION	√	√	√	√	√	√	√			√
NEW_SM3_FLUENCE_MEGANE	MULTIMEDIA INTERFACE	√	√	√	√	√	√	√		√	√
NEW_SM3_FLUENCE_MEGANE	PARKING BRAKE	√	√	√	√	√	√	√	√		√
NEW_SM3_FLUENCE_MEGANE	PARKING PROX CAN	√	√	√	√	√	√	√	√	√	√
NEW_SM3_FLUENCE_MEGANE	PEB	√	√	√	√		√	√			
NEW_SM3_FLUENCE_MEGANE	Radio	√	√	√	√	√	√	√	√	√	√
NEW_SM3_FLUENCE_MEGANE	SUNROOF CONTROL UNIT	√	√	√	√	√	√	√			√
NEW_SM3_FLUENCE_MEGANE	TRACKER	√	√	√	√		√	√	√	√	√
NEW_SM3_FLUENCE_MEGANE	Telematic ctrl unit	√	√	√	√	√	√	√	√		√
NEW_SM3_FLUENCE_MEGANE	UCH	√	√	√	√	√	√	√	√	√	
NEW_SM3_FLUENCE_MEGANE	UPC	√	√	√	√	√	√	√	√	√	√
NEW_SM3_FLUENCE_MEGANE	VARIABLE P.A.S.	√	√	√	√	√	√	√			√
SANDERO	A.B.S.	√	√	√	√	√	√	√			√
SANDERO	AIRBAG / PRETENSIONERS	√	√	√	√		√	√	√	√	√
SANDERO	AUTOMATIC GEARBOX	√	√	√	√	√	√	√			√
SANDERO	GAS INJ.	√	√	√	√	√	√		√		√
SANDERO	INJECTION	√	√	√	√	√	√	√	√		√
SANDERO	Radio	√	√	√	√	√	√	√	√	√	√
SANDERO	TRACKER	√	√	√	√		√	√	√	√	√
SANDERO	UCH	√	√	√	√	√	√	√	√	√	√
SANDERO	VARIABLE P.A.S.	√	√	√	√		√	√	√		√
SCENIC_II	A.B.S.	√	√	√	√	√	√	√			√
SCENIC_II	AIR CONDITIONING	√	√	√	√		√	√	√	√	√
SCENIC_II	AIRBAG / PRETENSIONERS	√	√	√	√		√	√	√	√	√
SCENIC_II	AUTOMATIC GEARBOX	√	√	√	√	√	√	√			√
SCENIC_II	COMMUNICATIONS UNIT	√	√	√	√	√	√	√	√	√	√
SCENIC_II	Discharge Lamp	√	√	√	√	√	√	√	√	√	√
SCENIC_II	GAS INJ.	√	√	√	√	√	√	√	√		√
SCENIC_II	INJECTION	√	√	√	√	√	√	√	√	√	√
SCENIC_II	Instrument panel	√	√	√	√	√	√	√	√	√	√
SCENIC_II	MULTIMEDIA INTERFACE	√	√	√	√	√	√	√	√	√	√
SCENIC_II	PARKING ASSISTANCE	√	√	√	√		√	√	√	√	√
SCENIC_II	PARKING BRAKE	√	√	√	√	√	√	√	√	√	√
SCENIC_II	PARKING PROX CAN	√	√	√	√		√	√	√	√	√
SCENIC_II	Radio	√	√	√	√	√	√	√	√	√	√
SCENIC_II	UCH	√	√	√	√	√	√	√	√	√	√
SCENIC_II	UPC	√	√	√	√	√	√	√	√	√	√
SCENIC_II	VARIABLE P.A.S.	√	√	√	√		√	√	√	√	√
SCENIC_IV	A.B.S.	√	√	√	√	√	√	√	√	√	√
SCENIC_IV	AIR CONDITIONING	√	√	√	√	√	√	√			√
SCENIC_IV	AIRBAG / PRETENSIONERS	√	√	√	√	√	√	√	√	√	√
SCENIC_IV	Amplifier	√	√	√	√	√	√	√		√	√
SCENIC_IV	BMS	√	√	√	√	√	√	√			√
SCENIC_IV	BMS safety	√	√	√				√			√
SCENIC_IV	DRIVER'S SEAT	√	√	√	√	√	√	√			√
SCENIC_IV	HEAD UP DISPLAY	√	√	√		√		√			√
SCENIC_IV	INJECTION	√	√	√	√	√	√	√	√		√
SCENIC_IV	Instrument panel	√	√	√	√	√	√	√	√	√	√
SCENIC_IV	LEFT-HAND DOOR or PASSENGER	√	√	√	√	√	√	√			√
SCENIC_IV	MULTIMEDIA INTERFACE	√	√	√	√	√	√	√			√
SCENIC_IV	PARKING BRAKE	√	√	√	√		√	√	√		√
SCENIC_IV	PARKING PROX CAN	√	√	√	√	√	√	√	√	√	√
SCENIC_IV	PEB	√	√	√	√		√	√			
SCENIC_IV	RIGHT-HAND DOOR or COLLAPSI	√	√	√	√	√	√	√			√
SCENIC_IV	Radio	√	√	√	√	√	√	√	√	√	√
SCENIC_IV	Supervisor or DCDC	√	√	√	√	√	√	√			

SCENIC_IV	Telematic ctrl unit	√	√	√	√	√	√	√	√		
SCENIC_IV	UCH	√	√	√	√	√	√	√	√	√	√
SCENIC_IV	UPC	√	√	√	√	√	√	√			√
SCENIC_IV	VARIABLE P.A.S.	√	√	√	√		√	√			√
SM7_L47	A.B.S.	√	√	√	√	√	√	√	√		√
SM7_L47	AIR CONDITIONING	√	√	√	√	√	√	√	√	√	√
SM7_L47	AIRBAG / PRETENSIONERS	√	√	√	√		√	√	√	√	√
SM7_L47	AUTOMATIC GEARBOX	√	√	√	√	√	√	√			√
SM7_L47	Amplifier	√	√	√	√	√		√	√	√	√
SM7_L47	Blind spot detection	√	√	√	√	√	√	√			√
SM7_L47	COMMUNICATIONS UNIT	√	√	√	√	√	√	√	√	√	√
SM7_L47	DRIVER'S SEAT	√	√	√	√		√	√			√
SM7_L47	Driver's door	√	√	√	√	√	√	√			
SM7_L47	INJECTION	√	√	√	√	√	√	√	√		√
SM7_L47	Instrument panel	√	√	√	√	√	√	√	√	√	√
SM7_L47	LEFT-HAND DOOR or PASSENGER	√			√		√				√
SM7_L47	Lighting	√	√	√	√	√	√	√	√		√
SM7_L47	MULTIMED. CONNECTION	√	√	√	√		√	√			√
SM7_L47	MULTIMEDIA INTERFACE	√	√	√	√	√	√	√	√	√	
SM7_L47	PARKING BRAKE	√	√	√	√	√	√	√	√		√
SM7_L47	PARKING PROX CAN	√	√	√	√		√	√	√	√	√
SM7_L47	Passenger's door	√	√	√	√	√	√	√			
SM7_L47	RIGHT-HAND DOOR or COLLAPSI	√			√		√				√
SM7_L47	Radio	√	√	√	√	√	√	√	√	√	√
SM7_L47	UCH	√	√	√	√	√	√	√	√	√	√
SM7_L47	UPC	√	√	√	√	√	√	√	√		√
SM7_L47	VARIABLE P.A.S.	√	√	√	√		√	√			√
TALISMAN_SM6	4 WHEELS STEERING	√	√	√	√	√	√	√			√
TALISMAN_SM6	A.B.S.	√	√	√	√	√	√	√	√	√	√
TALISMAN_SM6	AIR CONDITIONING	√	√	√	√	√	√	√			√
TALISMAN_SM6	AIRBAG / PRETENSIONERS	√	√	√	√	√	√	√	√	√	√
TALISMAN_SM6	AUTOMATIC GEARBOX	√	√	√	√	√	√	√			√
TALISMAN_SM6	Amplifier	√	√	√	√	√	√	√		√	√
TALISMAN_SM6	DRIVER'S SEAT	√	√	√	√	√	√	√			√
TALISMAN_SM6	FRONT RADAR	√	√	√	√		√	√			√
TALISMAN_SM6	Front camera	√	√	√	√		√	√		√	√
TALISMAN_SM6	HEAD UP DISPLAY	√	√	√		√		√			√
TALISMAN_SM6	INJECTION	√	√	√	√	√	√	√	√		√
TALISMAN_SM6	Instrument panel	√	√	√	√	√	√	√	√	√	√
TALISMAN_SM6	LEFT-HAND DOOR or PASSENGER	√	√	√	√	√	√	√			√
TALISMAN_SM6	MULTIMEDIA INTERFACE	√	√	√	√	√	√	√			√
TALISMAN_SM6	PARKING BRAKE	√	√	√	√		√	√	√		√
TALISMAN_SM6	PARKING PROX CAN	√	√	√	√	√	√	√	√	√	√
TALISMAN_SM6	PILOTED SUSPENSION	√	√	√	√		√	√			√
TALISMAN_SM6	POWER BACK DOOR	√	√	√	√		√	√		√	
TALISMAN_SM6	Radio	√	√	√	√	√	√	√	√	√	√
TALISMAN_SM6	Telematic ctrl unit	√	√	√	√	√	√	√	√		
TALISMAN_SM6	UCH	√	√	√	√	√	√	√	√	√	√
TALISMAN_SM6	UPC	√	√	√	√	√	√	√			√
TALISMAN_SM6	VARIABLE P.A.S.	√	√	√	√		√	√			√
THALIA_SYMB.2	A.B.S.	√	√	√	√	√	√	√			√
THALIA_SYMB.2	AIR CONDITIONING	√	√	√	√	√	√	√			
THALIA_SYMB.2	AIRBAG / PRETENSIONERS	√	√	√	√		√	√	√	√	√
THALIA_SYMB.2	AUTOMATIC GEARBOX	√	√	√	√	√	√	√	√		√
THALIA_SYMB.2	INJECTION	√	√	√	√	√	√	√			√
THALIA_SYMB.2	INJECTION	√	√	√	√	√	√	√	√	√	√
THALIA_SYMB.2	TRACKER	√	√	√	√		√	√	√	√	√
THALIA_SYMB.2	UCH	√	√	√	√	√	√	√	√	√	√
THALIA_SYMB.2	VARIABLE P.A.S.	√	√	√	√			√			√
THALIA_SYMBL	A.B.S.	√	√	√	√	√	√		√	√	
THALIA_SYMBL	AIR CONDITIONING	√	√	√	√	√	√			√	
THALIA_SYMBL	AIRBAG / PRETENSIONERS	√	√	√	√	√	√		√	√	
THALIA_SYMBL	AUTOMATIC GEARBOX	√	√	√	√	√	√	√	√	√	
THALIA_SYMBL	INJECTION	√	√	√	√	√	√	√	√		√
THALIA_SYMBL	INJECTION	√	√	√	√	√	√	√	√	√	
THALIA_SYMBL	UCH	√	√	√	√	√	√		√	√	
TRAFIC_II	A.B.S.	√	√	√	√	√	√		√		
TRAFIC_II	ADAPTATION UNIT	√	√	√	√						
TRAFIC_II	AIRBAG / PRETENSIONERS	√	√	√	√		√		√	√	
TRAFIC_II	AUTOMATIC GEARBOX	√	√	√	√	√	√	√			
TRAFIC_II	HEATER	√	√	√	√	√	√				
TRAFIC_II	INJECTION	√	√	√	√	√	√	√	√	√	
TRAFIC_II	UCH	√	√	√	√	√	√		√	√	
TRAFIC_III	A.B.S.	√	√	√	√	√	√	√	√	√	√
TRAFIC_III	ADAPTATION UNIT	√	√	√				√			
TRAFIC_III	AIR CONDITIONING	√	√	√	√	√	√	√		√	√
TRAFIC_III	AIRBAG / PRETENSIONERS	√	√	√	√	√	√	√	√		√
TRAFIC_III	COMMUNICATIONS UNIT	√	√	√	√	√	√	√	√	√	
TRAFIC_III	HANDS-FREE MODULE	√	√	√	√	√	√	√	√	√	
TRAFIC_III	HEATER	√	√	√	√		√	√			
TRAFIC_III	INJECTION	√	√	√	√	√	√	√	√		√
TRAFIC_III	Instrument panel	√	√	√	√	√	√	√	√	√	√
TRAFIC_III	MULTIMEDIA INTERFACE	√	√	√	√	√	√	√		√	
TRAFIC_III	PARKING PROX CAN	√	√	√	√	√	√	√	√	√	√
TRAFIC_III	Radio	√	√	√	√	√	√	√	√	√	
TRAFIC_III	Radio	√	√	√	√	√	√	√	√	√	√
TRAFIC_III	Telematic ctrl unit	√	√	√	√	√	√	√	√		
TRAFIC_III	UCH	√	√	√	√	√	√	√	√	√	
TRAFIC_III	UPC	√	√	√	√	√	√	√	√	√	√
TRAFIC_III	UREA DOSING CONTROL MODULE	√	√	√	√	√	√	√			√
TRAFIC_III	VARIABLE P.A.S.	√	√	√	√		√	√	√	√	√
TRAFICIIp2_3	A.B.S.	√	√	√	√	√	√	√			√
TRAFICIIp2_3	A.B.S.	√	√	√	√	√	√	√	√		√
TRAFICIIp2_3	ADAPTATION UNIT	√	√	√	√		√	√			
TRAFICIIp2_3	AIR CONDITIONING	√	√	√	√	√	√	√	√	√	√
TRAFICIIp2_3	AIRBAG / PRETENSIONERS	√	√	√	√		√	√	√	√	√
TRAFICIIp2_3	AUTOMATIC GEARBOX	√	√	√	√	√	√	√			√
TRAFICIIp2_3	COMMUNICATIONS UNIT	√	√	√	√	√	√	√	√	√	√
TRAFICIIp2_3	HEATER	√	√	√	√	√	√	√			
TRAFICIIp2_3	INJECTION	√	√	√	√	√	√	√	√	√	√
TRAFICIIp2_3	Instrument panel	√	√	√	√	√	√	√	√	√	√
TRAFICIIp2_3	MULTIMED. CONNECTION	√	√	√	√		√	√		√	√
TRAFICIIp2_3	MULTIMEDIA INTERFACE	√	√	√	√	√	√	√	√	√	√
TRAFICIIp2_3	PARKING ASSISTANCE	√	√	√	√		√	√	√	√	√
TRAFICIIp2_3	Radio	√	√	√	√	√	√	√	√		√
TRAFICIIp2_3	UCH	√	√	√	√	√	√	√	√	√	√
TWINGO_II	A.B.S.	√	√	√	√	√	√	√	√	√	√
TWINGO_II	AIR CONDITIONING	√	√	√	√	√	√	√	√	√	√
TWINGO_II	AIRBAG / PRETENSIONERS	√	√	√	√		√	√	√	√	√
TWINGO_II	AUTOMATIC GEARBOX	√	√	√	√	√	√	√			√
TWINGO_II	INJECTION	√	√	√	√	√	√	√	√		√
TWINGO_II	Instrument panel	√	√	√	√	√	√	√	√	√	√
TWINGO_II	MULTIMED. CONNECTION	√	√	√	√		√	√		√	√
TWINGO_II	MULTIMEDIA INTERFACE	√	√	√	√	√	√	√	√	√	√
TWINGO_II	PARKING ASSISTANCE	√	√	√	√		√	√	√	√	√
TWINGO_II	REV COUNTER/SYMBOL	√	√	√	√	√	√		√	√	√
TWINGO_II	Radio	√	√	√	√	√	√	√	√	√	√
TWINGO_II	UCH	√	√	√	√	√	√	√	√	√	√

TWINGO_II	VARIABLE P.A.S.	√	√	√	√		√	√	√	√	
TWINGO III	A.B.S.	√	√	√	√	√	√	√	√		√
TWINGO III	AIR CONDITIONING	√	√	√	√	√	√	√			√
TWINGO III	AIRBAG / PRETENSIONERS	√	√	√	√	√	√	√	√		√
TWINGO III	AUTOMATIC GEARBOX	√	√	√	√	√	√	√	√	√	√
TWINGO III	COMMUNICATIONS UNIT	√	√	√	√	√	√	√	√	√	
TWINGO III	FRONT RADAR	√	√	√	√		√	√			√
TWINGO III	Front camera	√	√	√	√		√	√			
TWINGO III	GEARBOX ELEC CONTROL	√	√	√				√			
TWINGO III	INJECTION	√	√	√	√	√	√	√	√		√
TWINGO III	Instrument panel	√	√	√	√	√	√	√	√	√	
TWINGO III	MULTIMEDIA INTERFACE	√	√	√	√	√	√	√		√	
TWINGO III	Radio	√	√	√	√	√	√	√	√	√	
TWINGO III	Telematic ctrl unit	√	√	√	√	√	√	√	√		
TWINGO III	UCH	√	√	√	√	√	√	√	√	√	
TWINGO III	UPC	√	√	√	√	√	√	√	√	√	√
TWINGO III	VARIABLE P.A.S.	√	√	√	√	√	√	√			
TWINGO phase 2	A.B.S.	√	√	√	√	√	√		√	√	
TWINGO phase 2	AIRBAG / PRETENSIONERS	√	√	√	√	√	√		√	√	
TWINGO phase 2	AUTOMATIC GEARBOX	√	√	√	√	√	√	√	√	√	
TWINGO phase 2	GAS INJ.	√	√	√	√	√	√		√		
TWINGO phase 2	INJECTION	√	√	√	√	√	√	√	√		
TWINGO phase 2	INJECTION	√	√	√	√	√	√	√	√		√
TWINGO phase 2	UCH	√	√	√	√	√	√		√	√	
TWIZY	ADAPTATION UNIT	√	√	√	√		√	√			√
TWIZY	AIRBAG / PRETENSIONERS	√	√	√	√		√	√	√	√	√
TWIZY	BCB	√	√	√	√						
TWIZY	BMS	√	√	√	√		√				√
TWIZY	Instrument panel	√	√	√	√		√	√	√	√	√
TWIZY	UCH	√	√	√	√	√	√	√	√	√	√
VEL SATIS	A.B.S.	√	√	√	√	√	√	√	√	√	√
VEL SATIS	AIR CONDITIONING	√	√	√	√	√	√	√	√	√	√
VEL SATIS	AIRBAG / PRETENSIONERS	√	√	√	√		√	√	√	√	√
VEL SATIS	AUTOMATIC GEARBOX	√	√	√	√	√	√	√			√
VEL SATIS	Discharge Lamp	√	√	√	√	√	√	√	√	√	√
VEL SATIS	FRONT RADAR	√	√	√	√		√	√	√	√	√
VEL SATIS	HANDS-FREE KIT	√	√	√	√	√	√	√	√	√	√
VEL SATIS	HEATER	√	√	√	√	√	√	√			
VEL SATIS	INJECTION	√	√	√	√	√	√	√	√		√
VEL SATIS	INJECTION	√	√	√	√	√	√	√	√	√	√
VEL SATIS	Instrument panel	√	√	√	√	√	√	√	√	√	√
VEL SATIS	PARKING ASSISTANCE	√	√	√	√		√	√	√	√	√
VEL SATIS	PARKING BRAKE	√	√	√	√	√	√	√	√	√	√
VEL SATIS	TYRES	√	√	√	√	√	√	√	√	√	√
VEL SATIS	UCH	√	√	√	√	√	√	√	√	√	√
VELSATIS ph2	A.B.S.	√	√	√	√	√	√	√	√	√	√
VELSATIS ph2	AIR CONDITIONING	√	√	√	√	√	√	√	√	√	√
VELSATIS ph2	AIRBAG / PRETENSIONERS	√	√	√	√		√	√	√	√	√
VELSATIS ph2	AUTOMATIC GEARBOX	√	√	√	√	√	√	√			√
VELSATIS ph2	COMMUNICATIONS UNIT	√	√	√	√	√	√	√	√	√	√
VELSATIS ph2	HANDS-FREE KIT	√	√	√	√	√	√	√	√	√	√
VELSATIS ph2	HEATER	√	√	√	√	√	√	√			
VELSATIS ph2	INJECTION	√	√	√	√	√	√	√	√		√
VELSATIS ph2	INJECTION	√	√	√	√	√	√	√	√	√	√
VELSATIS ph2	Instrument panel	√	√	√	√	√	√	√	√	√	√
VELSATIS ph2	Lighting	√	√	√	√	√	√	√	√	√	√
VELSATIS ph2	PARKING ASSISTANCE	√	√	√	√		√	√	√	√	√
VELSATIS ph2	PARKING BRAKE	√	√	√	√	√	√	√	√	√	√
VELSATIS ph2	PARKING PROX CAN	√	√	√	√		√	√	√	√	√
VELSATIS ph2	Radio	√									
VELSATIS ph2	UCH	√	√	√	√	√	√	√	√	√	√
WIND	A.B.S.	√	√	√	√	√	√	√	√	√	√
WIND	AIR CONDITIONING	√	√	√	√	√	√	√	√	√	√
WIND	AIRBAG / PRETENSIONERS	√	√	√	√		√	√	√	√	√
WIND	INJECTION	√	√	√	√	√	√	√	√		√
WIND	Instrument panel	√	√	√	√	√	√	√	√	√	√
WIND	MULTIMED. CONNECTION	√	√	√	√		√	√		√	√
WIND	MULTIMEDIA INTERFACE	√	√	√	√	√	√	√	√	√	√
WIND	Radio	√	√	√	√	√	√	√	√	√	√
WIND	SUNROOF CONTROL UNIT	√	√	√	√		√	√			√
WIND	UCH	√	√	√	√	√	√	√	√	√	√
WIND	VARIABLE P.A.S.	√	√	√	√		√	√	√	√	
ZOE	A.B.S.	√	√	√	√	√	√	√	√		√
ZOE	ADAPTATION UNIT	√	√	√	√		√	√			√
ZOE	AIR CONDITIONING	√	√	√	√	√	√	√	√		√
ZOE	AIRBAG / PRETENSIONERS	√	√	√	√	√	√	√	√		√
ZOE	BCB	√	√	√	√	√	√	√	√	√	
ZOE	BMS	√	√	√	√		√	√			√
ZOE	BMS safety	√	√	√				√			
ZOE	COMMUNICATIONS UNIT	√	√	√	√	√	√	√	√	√	
ZOE	EVC	√	√	√	√	√	√	√	√		
ZOE	Instrument panel	√	√	√	√	√	√	√	√	√	
ZOE	PARKING PROX CAN	√	√	√	√	√	√	√	√	√	√
ZOE	PEB	√	√	√	√		√	√			
ZOE	Radio	√	√	√	√	√	√	√	√	√	√
ZOE	Telematic ctrl unit	√	√	√	√	√	√	√	√		√
ZOE	UCH	√	√	√	√	√	√	√	√	√	
ZOE	UNCOUPLED PEDAL	√	√	√	√	√	√	√			√
ZOE	UPC	√	√	√	√	√	√	√			√
ZOE	VARIABLE P.A.S.	√	√	√	√	√	√	√			√