Shenzhen Xtooltech Co., Ltd

DFFENGSHEN Function table V26.59

Description: ○: All support by OBD △: Partially support by OBD □: All support (Disassembly)
●: All support by OBD(Need accessories) ▲: Partially support by OBD(Need accessories) ■: Partially support (Disassembly)
×: Not support /:Unnecessary ◎: Conditional support

Make	Model	Year	Key Type	Read PIN	Add Keys	All Keys Lost	Programme Remote	Other Functions
DFFENGSHEN	A30		Blade key	×	○	○	/	1. Replace the anti-theft controller 2. Replace EMS 3. Replace the anti-theft host and EMS 4. Rematch the faulty parts
DFFENGSHEN	A30		Blade key	×	○	○	○	1. Remote control matching after replacing the body
DFFENGSHEN	A60	A60-A16/A14T	Smart key	/	○	○	/	1. Match ESCL 2. Match PEPS 3. Match EMS 4. New system matching
DFFENGSHEN	A60	A60-A16/A14T	Blade key	/	○	○	/	1. Match BCM
DFFENGSHEN	A60	A60-HR16/MR20 Type1	Blade key	○	○	○	○	1. Read fault code 2. Clear the fault code
DFFENGSHEN	A60	A60-HR16/MR20 Type2	Blade key	○	○	○	○	1. Clear fault code
DFFENGSHEN	A60	A60-HR16/MR20	Smart key	○	○	○	/	1. Match steering lock
DFFENGSHEN	A60EV		Blade key	/	○	○	/	1. Match BCM
DFFENGSHEN	A9		Smart key	○	○	○	/	
DFFENGSHEN	AX3		Blade key	/	○	○	○	
DFFENGSHEN	AX3		Blade key	×	○	○	/	1. Replace the anti-theft controller 2. Replace EMS 3. Replace the anti-theft host and EMS 4. Rematch the faulty parts
DFFENGSHEN	AX3		Smart key	/	○	○	/	1. Match ESCL 2. Match PEPS 3. Match EMS 4. New system matching
DFFENGSHEN	AX4		Blade key	/	○	○	○	
DFFENGSHEN	AX4		Blade key	×	○	○	/	1. Replace the anti-theft controller 2. Replace EMS 3. Replace the anti-theft host and EMS 4. Rematch the faulty parts
DFFENGSHEN	AX4		Smart key	/	○	○	/	1. Match ESCL 2. Match PEPS 3. Match EMS 4. New system matching
DFFENGSHEN	AX5		Smart key	/	○	○	/	1. Match ESCL 2. Match PEPS 3. Match EMS 4. New system matching
DFFENGSHEN	AX5		Blade key	/	○	○	/	1. Match BCM
DFFENGSHEN	AX7		Smart key	/	○	○	/	1. Match ESCL 2. Match PEPS 3. Match EMS 4. New system matching
DFFENGSHEN	AX7		Blade key	/	○	○	/	1. Match BCM
DFFENGSHEN	AX7 PHEV		Smart key	/	○	○	/	1. Match ESCL 2. Match PEPS 3. Match EMS 4. New system matching
DFFENGSHEN	AX7	2020	Smart key	/	○	○	/	1. Match ESCL 2. Match PEPS 3. Match EMS 4. New system matching
DFFENGSHEN	AX7 PRO		Smart key	/	○	○	/	1. Match BCM 2. Match EMS 3. Match ESCL 4. New match 5. Body module write configuration
DFFENGSHEN	D01		Blade key	×	○	○	/	
DFFENGSHEN	E70(280)		Smart key	/	○	○	/	1. Match ESCL 2. Match PEPS
DFFENGSHEN	E70(280)							1. Match BCM
DFFENGSHEN	E70(300)		Smart key	/	○	○	/	1. Matching smart box 2. Match the steering column lock 3. After-sales faulty parts matching
DFFENGSHEN	E70(300)		Blade key	/	○	○	/	1. Matching body computer
DFFENGSHEN	E70(400/500)		Smart key	/	○	○	/	1. Matching smart box 2. Match the steering column lock 3. Smart box write configuration
DFFENGSHEN	E70(400/500)		Blade key	/	○	○	/	1. Matching body computer 2. Body module write configuration
DFFENGSHEN	H30	Type 1	Blade key	×	○	○	◎	1. Decoder programming 2. Engine ECU matching 3. Key and engine initialization 4. Configuration
DFFENGSHEN	H30	Type 2	Blade key	×	○	○	/	1. Read version information 2. Read the fault code 3. Clear the fault code 4. Read the data stream 5. Programming function
DFFENGSHEN	H30	Type 3	Blade key	×	○	○	/	1. Replace the anti-theft controller 2. Replace EMS 3. Replace the anti-theft host and EMS 4. Rematch the faulty parts
DFFENGSHEN	H30 CROSS	Type 1	Blade key	×	○	○	◎	1. Decoder programming 2. Engine ECU matching 3. Key and engine initialization 4. Configuration
DFFENGSHEN	H30 CROSS	Type 2	Blade key	×	○	○	/	1. Read version information 2. Read the fault code 3. Clear the fault code 4. Read the data stream 5. Programming function
DFFENGSHEN	H30 CROSS	Type 3	Blade key	×	○	○	/	1. Replace the anti-theft controller 2. Replace EMS 3. Replace the anti-theft host and EMS 4. Rematch the failed parts
DFFENGSHEN	S30	Type 1	Blade key	×	○	○	◎	1. Decoder programming 2. Engine ECU matching 3. Key and engine initialization 4. Configuration
DFFENGSHEN	S30	Type 2	Blade key	×	○	○	/	1. Read version information 2. Read the fault code 3. Clear the fault code 4. Read the data stream 5. Programming function

Shenzhen Xtooltech Co., Ltd

DFFENGSHEN Function table V26.59

Description: ○: All support by OBD
●: All support by OBD(Need accessories)
×: Not support
△: Partially support by OBD
▲: Partially support by OBD(Need accessories)
/:Unnecessary
□: All support (Disassembly)
■: Partially support (Disassembly)
◎: Conditional support

Make	Model	Year	Key Type	Read PIN	Add Keys	All Keys Lost	Programme Remote	Other Functions
DFFENGSHEN	S30	Type 3	Blade key	×	○	○	/	1. Replace the anti-theft controller 2. Replace EMS 3. Replace the anti-theft host and EMS 4. Rematch the faulty parts
DFFENGSHEN	L60		Blade key	○	○	○	◎	
DFFENGSHEN	L60		Smart key	○	○	○	/	
DFFENGSHEN	Yixuan		Smart key	/	○	○	/	1. Match BCM 2. Match EMS 3. Match ESCL 4. New match 5. Body module write configuration
DFFENGSHEN	Yixuan		Blade key	/	○	○	/	1. Match BCM 2. Match EMS 3. New system matching 4. Matching faulty parts 5. Reset ECU
DFFENGSHEN	Yixuan GS		Smart key	/	○	○	/	1. Match BCM 2. Match EMS 3. Match ESCL 4. New match 5. Body module write configuration
DFFENGSHEN	Yixuan GS		Blade key	/	○	○	/	1. Match BCM 2. Match EMS 3. New system matching 4. Matching faulty parts 5. Reset ECU
DFFENGSHEN	Yixuan MAX		Smart key	/	○	○	/	1. Match BCM 2. Match EMS 3. Match ESCL 4. New match 5. Body module write configuration
DFFENGSHEN	Yixuan EV		Smart key	/	○	○	/	1. Match BCM 2. Match EMS 3. Match ESCL 4. New match 5. Body module write configuration